


SPECIFICATIONS



Power source	On specification label
Water Level	H : 84 Litres, L : 72 Litres, M : 60 Litres, S : 50 Litres
Water Pressure	Less than 100 kPa (1 kgf/cm ²)
Dimension	880 x 530 x 1025 mm, (W x D x H)
Weight	31.5 kg

How to read the manufactured month and year from the label stuck on the back of the product.

EX. 8 0 1 T W A A 0 0 0 0 1

Serial No.
Password code
Product code
Month
Year (The last digit to year)

Part name

- WASH MOTOR
- SPIN MOTOR
- S.D. BASKET
- CYCLE TIMER ASSEMBLY
- CAPACITOR
- GEAR CASE ASM

Remark

- 105 W (Output)
- 105 W (Output)
- PLASTIC

8

P/No. : MFL39986109



OWNER'S MANUAL

WASHING MACHINE

Please read this manual carefully before operating your washing machine and retain it for future reference.

P1460RWP/WP-1460RWP

P1160RWP/WP-1590RWP

P/No. : MFL39986109

www.lg.com

CAUTION



Installation Area

- Avoid area exposed to snow, rain, or where humidity is high. It may cause electric shock.

Switch Area

- Avoid watering on the switch area. It may cause electric shock or fire.

Volatile Material

- Do not use volatile material such as Benzene, Gasoline, bug killer.
- Do not leave strong alkaline substance such as bleach inside the tub. Damage on plastic surface and rubber parts may occur.

In Operation

- Do not insert the hand inside the spin dryer basket while the machine is in operation.
- Do not drain the water out of the wash tub while the spin dryer basket is in operation. Otherwise the spin motor could be damaged.
- When the spin dryer basket does not stop within 15 seconds after opening the lid during the spin cycle, immediately unplug the power socket and contact service.

Electric Outlet

- Avoid connecting several electric devices to single outlet. It may cause fire.

Heat

- Avoid electric heater, candle light, cigarette light, bug smoker, etc. near the machine. It may ignite or deform plastic part.

Hot water

- Avoid using hot water over 50 °C. It may deform plastic parts or cause malfunction.

Installation

- Install the washing machine on a horizontal support. Otherwise, it may cause vibration and noise.



Power Cord and Plug



- If the power supply cord is damaged, it must only be replaced by the manufacture or its service agent or a similarly qualified person in order to avoid a hazard.
- Do not damage, bend or distort the power cord. Do not place any heavy object on its.
- When prong of power plug of prong is soiled with dirt or dust, wipe it off with a clean cloth.
- Do not put the plug in the power supply socket if your hand is wet.
- Remove the plug from the socket if the unit will not be used for an extended period. Remove by holding the plug not the cord.

- Do not let children climb on the machine or climb into the tub. Injury may occur.
- Do not step on the washing machine or place any heavy objects on it.
- Do not wash, rinse or spin dry the water proof sheets and clothes.
- Be sure to earth the washer to prevent electric shock. To reduce the risk of electric shock, do not install the washer in humid spaces.
- Be sure to disconnect the power cord from the electric outlet before starting care and maintenance
- The units should not be repaired, disassembled or modified by any person except the authorized technicians.

*Remark : Avoid using hot water over 60°C (Only for Saudi Arabia Country)

2

FEATURES



1. Water Supply Inlet

Connect here with the inlet hose from the water faucet to feed water to the tub.

2. Water Supply Selector

Select "WASH" to supply water for washing and rinsing and "SPIN" for spin shower rinse.

3. Wash Timer

Select the desired time for washing or rinsing. The maximum is 35 min. (Period 16-35 min. the machine will switch between washing and soaking).

4. Wash Program

Set the program to "Gentle", "Normal", "Strong" according to kinds and quantity of the laundry.

5. Drain Selector

Select "Wash•Rinse" for washing and rising and "Drain" to drain the water out of the Cabinet, and "Off" to turn off the drain pump.

6. Spin Timer

Select the desired time for spinning. The maximum limit is 10 min. but shall not be continued over 3 cycle. Don't rotate the knob more than prescribed limit.

**After continue using spinning program 3 times continue, Please stop spinning more than 1 hour otherwise the spin motor could be damage of fire or stop operation.

***To obtain an efficient performance according to energy label according to energy label, Wash program 30 mins (60 °C), Rinse 2 times, Spin 1 times should be applied.

(Only for Saudi Arabia Country)

3

INSTALLATION

Installation area

- Set on flat and firm floor.
- Incorrect installation may cause severe noise and break down.




- Maintain more than 10 cm. between the side of drain hose and the wall.
- A carpet must not obstruct the ventilation openings.



Connecting the earth wire


- Install the earth wire to prevent short-circuit due to leaking current and electric shock.
- It is attached at the back of the washer. Connect it to the metal water pipe. If the water pipe is made of plastic, it does not have the earth effect.
- Do not connect the earth wire to the gas pipe, lightning arrester, telephone connector, etc.



Warning-the appliance with two-pronged plug must be grounded

Connecting the power plug

- Insert the power plug into the outlet.
- Before connecting the power plug, check if the voltage setting of the washer matches the outlet voltage.
- If AC outlet with ground terminal is used, grounding is not needed. If not, never forget earthing (earthing method above).
- The appliance must be positioned so that the plug is accessible.






Voltage Change (only for dual voltage)

- This washer is assembled for 220V, but can be changed from 220V to 110V(or 127V).
- Check your electrical source and follow the diagram below to convert voltage.



Other earthing method

- After connecting the earth wire to the earth copper plate, bury it at least 75cm deep under the wet ground.
- Connect to the earthing-only outlet.
- When installing it in an area where earthing is not possible, purchase a short-circuit breaker connect it to the outlet.



Connecting the drain hose

- Push the clamp toward the body of the washing machine as shown in the figure.
- L <= 1 m.



4

INSTALLATION & HOW TO WASH

Before washing

- Check the washing instruction labels on the clothing to be washed.
- Remove all objects from the pockets of the clothing. Objects left in the pockets may damage clothing or break the washing machine (could cause the drain hose to clog).
- After separating oiled or dyed clothing, wash.
- For your convenience hang up the wash cover on the right or left side of the washing machine tub when not in use.

Remove this before washing



How to wash

1 Set the drain selector Set as "off" position. 	5 Select the wash program to "Gentle", "Normal" or "Strong" according to the kinds and quantity of the laundry. (Refer to Table 2) 	7 When washing is finished, locate the drain selector to "Drain" position and drain the water out.
2 Set the water selector to "WASH" 		
3 Put the appropriate amount of detergent and the laundry into the wash tub. And add water to the desired water level which you want. (Refer to Table 2) 	6 Set the desired wash time. 	8 Spinning in the spin dryer basket. Move the laundry into spin dryer basket. Put the laundry down lightly. Place the safety cover horizontally on the laundry. Set the desired spin time with the spin timer.
4 Open water supply and fill water till your desired level of tap mark. That is because clothes can absorb adequate amount of water and water will not short. 	<p>In the period 0~15 min. The machine will run the washing function</p> <p>In the period 16~35 min. The machine will switch between washing and soaking.</p>	

5

HOW TO RINSE & HOW TO SPIN


Interim spin rinse

- Interim spin rinse prior to regular rinsing helps removing sudsy water from the laundry and improve rinsing efficiency. Also is helpful to water saving.

1 After washing. • Move the laundry into the spin dryer basket. • Place the safety cover horizontally on the laundry. 	2 Set the water selector to "SPIN". 	4 After interim spin rinse, move the laundry into the wash tub for rinsing.
	3 Set the desired spin flow appropriately. **Max. 5 min. each cycle for spin rinse. (Refer to Tabel 3) 	

Note for spinning


- Put the laundry evenly into the spin dryer basket.
- Put the laundry down lightly.
- Place the safety cover horizontally over the laundry, washing machine will be damage if the safety cover is not placed.
- Close the spin dryer cover.
- Do not drain the water out of the wash tub while the spin dryer basket is in operation.
- If the spin dryer basket is off-balance and vibrates excessively, stop the spinning, rearrange the clothes evenly, and then resume spinning.



CARE & MAINTENANCE

Overflow filter & Rotation filter-C

- Lift up the area (A) of the over flow filter and take out the rotation filter-C by pulling in direction as shown.
- Pull the overflow filter forward from the wash tub in the direction of the arrow.
- Turn the net over and rinse in water.
- Use a brush or hand to remove all of the lint which has adhered to the overflow filter.
- Insert the overflow filter back into the wash tub.
- Insert the rotation filter-C back into the overflow filter.



6

REFERENCE

TABLE 1. WEIGHT GUIDE FOR CLOTHES

Type of clothing	Type of fabric	Weight per piece
Handkerchief	Cotton	50g(1.8oz)
Bath towel	Cotton	300g(10.6oz)
Shirt	Mixed fabric	200g(7.1oz)
Pajama (shirt and pants)	Cotton	500g(17.6oz)
Workclothes	Mixed fabric	800g(28.2oz)
Blouse	Mixed fabric	200g(7.1oz)

TABLE 2. GUIDE FOR WASHING

Type of Fabric	Wash Selector	Amount of Laundry (kg)	Water Level	Amount of Water (l)	Amount of Detergent (g)
Synthetics, Silk, Woolen, Knits	Gentle	4.0 ~ 5.0	S	50	50
Cotton, Linen	Normal	5.0 ~ 6.0	L	60	60
Very soiled cotton and linen	Strong	6.0 ~ 7.0	M	72	72
		7.0 ~	H	84	84

TABLE 3. GUIDE FOR SPINNING

Spin Time (min.)	Type of Fabric
2 ~ 3	Synthetics, Silk, Woolen, Knits
3 ~ 5	Cotton, Linen
5 ~ 10	Very soiled, cotton and linen
5	Synthetics, Silk, Knits, Cotton, Linen, Very soiled

- Amount of laundry is based on dry laundry.
- Detergent amount is based on a general synthetic detergent.
- If washing and spinning must be operated together, starting washing and spinning operation shall be done at the same time to cope with EMC requirement.

TROUBLESHOOTING GUIDE

Before Requesting Service

Problem	Checking point
Motor does not operate,	<ul style="list-style-type: none"> Is the power cord firmly plugged in? Is the timer turned to a suitable point except "Off" ?
Spin dryer basket does not operate.	<ul style="list-style-type: none"> Is there any clothing dropped between the basket and tub? Is the spin dryer cover closed? Is the laundry gathered to one side of the spin dryer basket?
No draining	<ul style="list-style-type: none"> Is the drain pump operated?

7