



Please read this manual carefully before operating your set and retain it for future reference.

LHD657M (LHD657M, S67T4-S, S67T4-C, S67T2-W)



Safety Information



CAUTION

RISK OF ELECTRIC SHOCK DO NOT OPEN



CAUTION: TO REDUCE THE RISK OF ELECTRIC SHOCK DO NOT REMOVE COVER (OR BACK) NO USER-SERVICEABLE PARTS INSIDE REFER SERVICING TO QUALIFIED SERVICE PERSONNEL.



This lightning flash with arrowhead symbol within an equilateral triangle is intended to alert the user to the presence of uninsulated dangerous voltage within the product's enclosure that may be of sufficient magnitude to constitute a risk of electric shock to persons.



The exclamation point within an equilateral triangle is intended to alert the user to the presence of important operating and maintenance (servicing) instructions in the literature accompanying the product.

WARNING: TO PREVENT FIRE OR ELECTRIC SHOCK HAZARD, DO NOT EXPOSE THIS PRODUCT TO RAIN OR MOISTURE.

CAUTION: The apparatus should not be exposed to water (dripping or splashing) and no objects filled with liquids, such as vases, should be placed on the apparatus.

WARNING: Do not install this equipment in a confined space such as a book case or similar unit.

CAUTION: Do not use high voltage products around this product. (ex. Electrical swatter) This product may malfunction due to electrical shock.

CAUTION: Do not block any ventilation openings. Install in accordance with the manufacturer's instructions.

Slots and openings in the cabinet are provided for ventilation and to ensure reliable operation of the product and to protect it from over heating. The openings shall be never be blocked by placing the product on a bed, sofa, rug or other similar surface. This product shall not be placed in a built-in installation such as a bookcase or rack unless proper ventilation is provided or the manufacturer's instruction has been adhered to.



CAUTION: This product employs a Laser System. To ensure proper use of this product, please read this owner's manual carefully and retain it for future reference. Shall the unit require maintenance, contact an authorized service center.

Use of controls, adjustments or the performance of procedures other than those specified herein may result in hazardous radiation exposure.

To prevent direct exposure to laser beam, do not try to open the enclosure.

CAUTION concerning the Power Cord

Most appliances recommend they be placed upon a dedicated circuit;

That is, a single outlet circuit which powers only that appliance and has no additional outlets or branch circuits. Check the specification page of this owner's manual to be certain. Do not overload wall outlets. Overloaded wall outlets, loose or damaged wall outlets, extension cords, frayed power cords, or damaged or cracked wire insulation are dangerous. Any of these conditions could result in electric shock or fire. Periodically examine the cord of your appliance, and if its appearance indicates damage or deterioration, unplug it, discontinue use of the appliance, and have the cord replaced with an exact replacement part by an authorized service center. Protect the power cord from physical or mechanical abuse, such as being twisted, kinked, pinched, closed in a door, or walked upon. Pay particular attention to plugs, wall outlets, and the point where the cord exits the appliance. The Power Plug is the disconnecting device. In case of an emergency, the Power Plug must remain readily accessible.

This device is equipped with a portable battery or accumulator

Safety way to remove the battery or the battery from the equipment: Remove the old battery or battery pack, follow the steps in reverse order than the assembly. To prevent contamination of the environment and bring on possible threat to human and animal health, the old battery or the battery put it in the appropriate container at designated collection points. Do not dispose of batteries or battery together with other waste. It is recommended that you use local, free reimbursement systems batteries and accumulators. The battery shall not be exposed to excessive heat such as sunshine, fire or the like

NOTICE: For safety marking information including product identification and supply ratings, please refer to the main label on the bottom or the other surface of the product.

CAUTION: No naked flame sources, such as lighted candles, should be placed on the apparatus.

Symbols

~	Refers to alternating current(AC).		
===	Refers to direct current(DC).		
	Refers to class II equipment.		
(h)	Refers to stand-by.		
ı	Refers to "ON" (power).		
4	Refers to dangerous voltage.		

POWER: This unit operates on a mains supply of $200-240 \text{ V} \sim$, 50/60 Hz.

Wiring: This unit is supplied with a BS 1363 approved main plug. When replacing the fuse, always use of the same rating approved to BS 1362. Never use this plug with the fuse cover omitted. To obtain a replacement fuse cover contact your dealer. If the type of plug supplied is not suitable for the mains sockets in your home, then the plug should be removed and a suitable type fitted. Please refer to the wiring instructions below:

Warning: A mains plug removed from the mains lead of this unit must be destroyed. A mains plug with bared wires is hazardous if inserted in a mains socket. Do not connect either wire to the earth pin, marked with the letter E or with the earth symbol $\stackrel{\bot}{=}$ or coloured green or green and yellow. If any other plug is fitted, use same rating of fuse in the plug.

Important: The wires in this mains lead are coloured in accordance with the following codes:

- BLUE: NEUTRAL, BROWN: LIVE - As the colours of the wires in the mains lead of this unit may not correspond with the coloured marking identifying the terminals in your plug, proceed as follows: The wire which is coloured blue must be connected to the terminal which is marked with the letter N or coloured black. The wire which is coloured brown must be connected to the terminal which is marked with the letter L or coloured red.

Table of Contents

1 Getting Started

- 2 Safety Information
- 4 Table of Contents
- 6 Unique Features
- 6 Portable In
- 6 USB Direct Recording
- 6 Full HD up-scaling
- 6 Home Theater Speaker ez Setup
- 6 Bluetooth®
- 7 Introduction
- 7 Playable Discs
- 7 About the "⊘" Symbol Display
- 7 Symbols Used in this Manual
- 7 Regional Codes
- 8 Playable file Requirement
- 9 Remote control
- 10 Front panel
- 11 Rear panel

2 Connecting

- 12 Assembling the speaker
- 14 Attaching the speakers to the unit
- 15 Positioning the system
- 16 How to Affix the Ferrite Core
- 16 Affix the Ferrite Core for HDMI cable
- 16 Connections to Your TV
- 17 HDMI Out Connection
- 18 What is SIMPLINK?
- 18 Video Connection
- 19 Resolution Setting
- 19 Video Output Resolution
- 20 Optional Equipment Connection
- 20 AUX (L/R) INPUT Connection
- 20 PORT. IN (Portable Input) Connection
- 20 Listening to music from your portable player or external device
- 21 USB Connection
- 21 OPTICAL IN connection
- 21 Home theater speaker ez setup
- 22 Antenna Connection

3 System Setting

- 23 Adjust the setup settings
- 23 OSD Initial language settings Optional
- 23 To display and exit the Setup menu
- 24 Language
- 24 Display
- 25 Audio
- 26 Lock (Parental Control)

4 Operating

- 27 Using the Home Menu
- 27 Basic Operations
- 28 Other Operations
- 28 Displaying Disc Information on-screen
- 28 To display the DVD Menu
- 28 To display the DVD title
- 28 1.5 times speed playback
- 28 Screen Saver
- 28 Starting play from selected time
- 28 Resume playback
- 29 Changing subtitle code page
- 29 Marked Playback
- 30 Viewing a PHOTO file
- 31 Sleep Timer Setting
- 31 Dimmer
- 31 Turn off the sound temporarily
- 31 Last Scene Memory
- 31 Power Resume Optional
- 31 System Select Optional
- 32 Adjust the speaker level settings
- 32 VOCAL FADER
- 32 Auto power down
- 33 Radio Operations
- 33 Listening to the radio
- 33 Presetting the Radio Stations
- 33 Deleting all the saved stations
- 33 Deleting a saved station
- 33 Improving poor FM reception
- 34 Sound adjustment
- 34 Setting the surround mode
- 34 Setting the USER EQ
- 35 Advanced Operations
- 35 Recording to USB
- 36 Using a Bluetooth wireless technology
- 36 Listening to music of a Bluetooth device
- 38 Auto function change
- 38 AUTO POWER On

5 Troubleshooting

39 Troubleshooting

6 Appendix

- 40 Maintenance
- 40 Handling the Unit
- 40 Notes on Discs
- 41 Area Code List
- 42 Language code List
- 43 Trademarks and Licenses
- 44 Specifications

Unique Features

Portable In

Listen to music from your portable device. (MP3, Notebook, etc.)

USB Direct Recording

Records music from CD to your USB device.

Full HD up-scaling

Views Full HD picture quality with simple setup.

Home Theater Speaker ez Setup

Listen to sounds from TV, DVD and Digital device with vivid $5.1 \ (2.1 \ \text{or} \ 2.0)$ ch mode.

Bluetooth®

Listens to music stored on your Bluetooth device.

Introduction

Playable Discs

This unit plays DVD±R/RW and CD-R/RW that contains audio titles, MP3, WMA and/or JPEG files. Some DVD±RW/DVD±R or CD-RW/CD-R cannot be played on this unit due to the recording quality or physical condition of the disc, or the characteristics of the recording device and authoring software.



DVD-VIDEO (8 cm/12 cm disc)

Discs such as movies that can be purchased or rented.



DVD±R (8 cm/12 cm disc)
Video mode and finalized only.



DVD-RW (8 cm/12 cm disc)



Video mode and finalized only.

DVD+R: Video mode only

Supports the double layer disc also.



DVD+RW (8 cm/12 cm disc) Video mode and finalized only.



Audio CD: Music CDs or CD-R/CD-RW in music CD format that can be purchased.

About the "⊘" Symbol Display

"O" may appear on your TV display during operation and indicates that the function explained in this owner's manual is not available on that specific media.

Symbols Used in this Manual

DVD

DVD-Video, DVD±R/RW in Video mode or VR mode and finalized

ACD

Audio CDs

MOVIE

Video files contained in the USB/

Disc

MUSIC

Audio files contained in the USB/

Disc

PHOTO

Photo files contained in the USB/

0

Note

Indicates special notes and operating features.



Tip

Indicates tip and hints for making the task easier.



Caution

Indicates cautions for preventing possible damages from abuse.

Regional Codes

This unit has a regional code printed on the unit. This unit can play only DVD discs labeled same as the unit or "ALL"

- Most DVD discs have a globe with one or more numbers in it clearly visible on the cover. This number must match your unit's regional code or the disc cannot play.
- If you try to play a DVD with a different regional code from your unit, the message "Check Regional Code" appears on the TV screen.

Playable file Requirement

Music file requirement

MP3/ WMA file compatibility with this unit is limited as follows:

- Sampling frequency: within 32 to 48 kHz (MP3), within 32 to 48 kHz (WMA)
- Bit rate: within 32 to 320 kbps (MP3), 40 to 192 kbps (WMA)
- Support Version: v2, v7, v8, v9
- Maximum files : Under 999
- File extensions : ".mp3" / ".wma"
- CD-ROM file format: ISO9660/ JOLIET
 We recommend that you use Easy-CD Creator,
- which creates an ISO9660 file system.
 You have to set the disc format option to
- You have to set the disc format option to
 [Mastered] in order to make the discs compatible
 with the LG players when formatting rewritable
 discs. When setting the option to Live File System,
 you cannot use it on LG players.(Mastered/ Live
 File System: Disc format system for Windows
 Vista)

The DTS is not supported. In case of DTS audio format, audio is not output.

Photo file requirement

Photo file compatibility with this unit is limited as follows:


- Max pixel in width: 2760 x 2048 pixel
- Maximum files: Under 999
- Some discs may not operate due to a different recording format or the condition of disc.
- File extensions: "jpg"
- CD-ROM file format: ISO9660/ JOLIET

Video file requirement

Video file compatibility with this unit is limited as follows:

- Available resolution: within 720 x 576 (W x H) pixels.
- The file name of the Video subtitle should be entered within 45 characters.
- If there is impossible code to express in the Video file, it may be displayed as "_ " mark on the display.
- · Frame rate: less than 30 fps.
- If the video and audio structure of recorded files is not interleaved, either video or audio is outputted.
- Playable Video file: "avi", "mpq", "mpeq"
- Playable Subtitle format: SubRip (*.srt/*.txt), SAMI (*.smi), SubStation Alpha (*.ssa/*.txt), MicroDVD (*.sub/*.txt), SubViewer 2.0 (*.sub/ *.txt), Vobsub (*.sub)
- Playable Codec format: "Xvid", "MPEG-1", "MPEG-2"
- Playable Audio format: "AC3", "PCM", "MP3", "WMA",
- Sampling frequency: within 32 to 48 kHz (MP3), within 32 to 48 kHz (WMA)
- Bit rate: within 32 to 320 kbps (MP3), 40 to 192 kbps (WMA)
- For Discs formatted in Live file system, you can not it on this unit.
- If the name of movie file is different from that of the subtitle file, during playback of a Video file, subtitle may not be display.
- If you play a Xvid file differ from Xvid spec, it may not operate normally.
- If you play GMC video file which is more than 1-warp point, video playback screen will not smooth.

Remote control



Replacement of battery



Remove the battery cover on the rear of the remote control, and insert the battery with lacktriangle and lacktriangle matched correctly.

- (b) (Standby/On): Switches the
- ▲ (Open/Close) : Opens and closes the disc tray.
- **FUNCTION**: Selects the function and input source.

SLEEP: Sets the System to turn off automatically at a specified time.

(Dimmer: The display window will be darken by half.)

MARKER: Marks play list.

Screen Display.

(Home): Displays the [Home Menu].

☐ INFO/DISPLAY : Accesses On-

DISC MENU: Accesses the menu on a DVD disc.

\/\V/</> (up/ down/ left/ right): Used to navigate on-screen displays.

PRESET (Λ/V): Selects programme of Radio.

TUNING +/-: Tunes in the desired radio station.

© ENTER: Acknowledges menu selection.

Presetting the radio stations.

RETURN: Moves backwards in the menu or exits the setup menu.

TITLE: If the current DVD title has a menu, the title menu appears on the screen. Otherwise, the disc menu may not appear.

- ► (Play) MONO/STEREO: Starts playback. Selects Mono/ Stereo.
- **II** (Pause/Step) : Pauses playback.

I (Skip): Goes to the next or previous chapter / track / file

◄◄/▶ (Scan): Searches backward or forward.

. 4

SPEAKER LEVEL: Sets the sound level of desired speaker.

SOUND EFFECT: Selects a sound effect mode.

VOL -/+ (Volume): Adjusts speaker volume.

- (Mute): Mutes the sound.
- REC : USB Direct Recording.
- **0-9 numerical buttons** : Selects numbered options in a menu.

REPEAT : Selects a play mode. (Repeat/ Random)

CLEAR: Removes a number when setting the password.

TV Control buttons : Controls the TV. (LG TV only)

 You can control the sound level, input source, and power switching of LG TVs as well.
 Hold (b) (TV) and press PR/CH (\(\Lambda\)/\(\V\)) button repeatedly until the TV turns on or off.

OPTICAL: Changes input source to optical directly.


★: This button is not available.

MIC VOL -/+ (Microphone Volume) : Adjusts microphone volume.

ECHO VOL -/+ (Volume): Adjusts echo volume.

VOCAL FADER: You can enjoy the function as karaoke, by reducing singer vocal of music in the various source.


Front panel



- 1 Disc Tray
- 2 Display window Shows the current status of the unit.
- 3 Microphone jacks 1/2
- 4 PORT. IN Connects to a portable player with audio outputs.
- 5 USB Port Connects a USB device.
- 6 △ (Open/Close) Opens or closes the disc tray.

- 7 > II (Play/Pause)
 - Starts playback.
 - Pauses playback temporarily, press again to exit pause mode.
- **8 □** (Stop) Stops playback.
- 9 F (Function) Changes the input source or function.
- **10 -/+**(Volume) Adjusts speaker volume.
- 11 ((Standby/On) Switches the unit ON or OFF.

Rear panel



- 1 Power cord
- 2 Speaker connectors Connects the speaker cables.
- **3 OPTICAL IN**Connects to optical audio equipment.
- 4 HDMI OUT TO TV


 Connects to TV with HDMI inputs.

 (Interface for digital audio and video)


- **5 VIDEO OUT**Connects to a TV with video inputs.
- 6 AUX (L/R) INPUT Connects to an external source with 2 channel audio outputs.
- 7 ANTENNA FM FM- Connects the FM wired antenna.

Assembling the speaker


Before connecting the speakers, assemble the speakers. Please check the items for assembling the speakers.



1. Attach the pole to the base, then secure the connection with a supplied screw.




2. Draw the speaker cord through the hole on the base.



Make sure speaker cable unfolded or in straight condition before insert it to the hole.


3. Attach the speakers to the speaker stands by rotating the screws.



Note

Do not catch the speaker cord between speaker and the pole.

4. Connect the speaker wire to the terminal on the speaker. Make sure the wire marked black goes in to the terminal marked "-"(minus) and the other wire goes in to the terminal marked "+"(plus).





! Caution


Be careful that the speaker does not fall down. Otherwise it may result in the speaker malfunction and cause personal injury and/ or property damage.



Attaching the speakers to the unit


1. Connect the wires to the unit. Match each wire's colored band to the same colored connection terminal on the rear of the

To connect the cable to the unit, press each plastic finger pad to open the connection terminal. Insert the wire and release the finger



Connect the black stripe of each wire to the terminals marked -(minus) and the other end to the terminals marked + (plus).

Connect a woofer cord to the player. When connecting a woofer cord to the player, insert the connector until it clicks.



2. Connect the wires to the speakers. Connect the other end of each wire to the correct speaker according to the color coding:

Color	Speaker	Position
Grey	Rear	Rear right
Blue	Rear	Rear left
Green	Center	Center
Orange	Subwoofer	Any front position
Red	Front	Front right
White	Front	Front left

To connect the cable to the speakers, press each plastic finger pad to open the connection terminals on the base of each speaker. Insert the wire and release the finger pad.




Caution

- Be careful to make sure children do not put their hands or any objects into the *speaker duct.
 - *speaker duct : A hole for plentiful bass sound on speaker cabinet (enclosure).
- Place the center speaker at a safe distance from the child's reach. Otherwise it may result in the speaker falling down and causing personal injury and/or property damage.
- The speakers contain magnet parts, so color irregularity may occur on the TV screen or PC monitor screen. Please use the speakers far away from either TV screen or PC monitor.
- Before using the subwoofer, remove the protective vinyl.

Positioning the system

The following illustration shows an example of positioning the system. Note that the illustrations in these instructions differ from the actual unit for explanation purposes.

For the best possible surround sound, all the speakers other than the subwoofer should be placed at the same distance from the listening position (a).



- Front left speaker (L) / ® Front right speaker (R):
 Place the front speakers to the sides of the monitor or screen and as flush with the screen surface as possible.
- © Center speaker. Place the center speaker above or below the monitor or screen.
- Surround left speaker (L) /
 Surround right speaker (R):
 Place these speakers behind your listening position, facing slightly inwards.
- © Subwoofer. The position of the subwoofer is not so critical, because low bass sounds are not highly directional. But it is better to place the subwoofer near the front speakers. Turn it slightly toward the center of the room to reduce the wall reflections.
- (G) | Init


How to Affix the Ferrite Core

Ferrite core may not be provided depending on each nation's regulations.

Affix the Ferrite Core for HDMI cable

You must affix a ferrite core in order to reduce or eliminate electrical interference.

- 1. Pull the stopper [a] of the ferrite core to open.
- 2. Wind the HDMI cable around the ferrite core
- 3. Close the ferrite core until it clicks.



Connections to Your TV

Make one of the following connections, depending on the capabilities of your existing equipment.



Note

- Depending on your TV and other equipment you wish to connect, there are various ways you could connect the player. Use only one of the connections described in this manual.
- Please refer to the manuals of your TV, Stereo System or other devices as necessary to make the best connections.



!\ Caution


- · Make sure the unit is connected directly to the TV. Tune the TV to the correct video input
- Do not connect your player via your VCR. The image could be distorted by the copy protection system.

2

HDMI Out Connection

If you have a HDMI TV or monitor, you can connect it to this unit using a HDMI cable (Type A, High Speed HDMI™ Cable).

Connect the HDMI OUT jack on the unit to the HDMI IN jack on a HDMI compatible TV or monitor. Set the TV's source to HDMI (refer to TV's Owner's manual).





Tip

- You can fully enjoy digital audio and video signals together with this HDMI connection.
- When you use HDMl connection, you can change the resolution for the HDMl output. (Refer to "Resolution Setting" on page 19.)

<u>(!)</u>

Caution

- Changing the resolution when the connection has already been established may result in malfunctions. To solve the problem, turn off the unit and then turn it on again.
- When the HDMI connection with HDCP is not verified, TV screen is changed to black or green screen or the snow noise may occur on the screen. In this case, check the HDMI connection, or disconnect the HDMI cable.



- If a connected HDMI device does not accept the audio output of the unit, the HDMI device's audio sound may be distorted or may not output.
- When you connect a HDMI or DVI compatible device make sure of the following:
 - Try switching off the HDMI/DVI device and this unit. Next, switch on the HDMI/DVI device and leave it for around 30 seconds, then switch on this unit.
 - The connected device's video input is set correctly for this unit.
 - The connected device is compatible with 720 x 480i (or 576i), 720 x 480p (or 576p), 1280 x 720p, 1920 x 1080i or 1920 x 1080p video input.
- Not all HDCP-compatible HDMI or DVI devices will work with this unit.
 - The picture will not be displayed properly with non-HDCP device.
 - This unit does not playback and TV screen is changed to black or green screen or the snow noise may occur on the screen.
- If there is noise or lines on the screen, please check the HDMI cable and use a higher version cable than High Speed HDMI™ Cable.
- If you use **Bluetooth** or AUX-OPT Function of the unit, the audio is not output to HDMI.

What is SIMPLINK?



Some functions of this unit are controlled by the TV's remote control when this unit and LG TV's with SIMPLINK are connected through HDMI connection.

Controllable functions by LG TV's remote control; Power on/off, volume up/down, mute, etc.

Refer to the TV owner's manual for the details of SIMPLINK function

LG TV's with SIMPLINK function has the logo as shown above.




- · Depending on the disc type or playing status, some SIMPLINK operation may differ from your purpose or not work.
- The function is automatically changed to optical when you change the speaker setting of simplink to external, no matter what kind of the function you are using.

Video Connection

Connect the VIDEO OUT jack on the unit to the video in jack on the TV using a video cable.

You can hear the sound through the system's speakers.



Resolution Setting

The unit provides several output resolutions for HDMI $\ensuremath{\mathsf{OUT}}.$

You can change the resolution using [Setup] menu.

- 1. Press 📤.
- 2. Use </> to select the [Setup] and press © ENTER. The [Setup] menu appears.



- Use ∧/V to select [Display] option then press > to move to the second level.
- 4. Use **∧/V** to select the [Resolution] option then press **>** to move to the third level.
- Use **∧/V** to select the desired resolution then press **⊙** ENTER to confirm your selection.



If your TV does not accept the resolution you have set on the player, you can set resolution to 480p (or 576p) as follows:

Press for more than 5 seconds.

Video Output Resolution

[VIDEO OUT]: 480i (or 576i)


Displayed resolution in display window and outputted resolution may different according to connection type.

[HDMI OUT] : 1080p, 1080i, 720p and 480p (or 576p) and 480i (or 576i)

Optional Equipment Connection

AUX (L/R) INPUT Connection

Connect an Output of auxiliary device to the AUX (L/ R) INPUT Connector.




Note

If your TV has only one output for audio (mono), connect it to the left (white) audio jack on the unit.

PORT. IN (Portable Input) Connection

Connect an output of portable device (MP3 or PMP etc.) to the PORT. IN connector.



Listening to music from your

portable player or external device

The unit can be used to play the music from many types of portable player or external devices.


1. Connect the portable player to the PORT. IN (PORTABLE IN) connector of the unit.

Connect the external device to the AUX (L/R) INPUT connector of the unit.

- 2. Turn the power on by pressing ()/1.
- 3. Select the PORTABLE or AUX function by pressing • FUNCTION.
- 4. Turn on the portable player or external device and start it playing.

USB Connection

Connect the USB port of USB Memory (or MP3 player, etc.) to the USB port on the front of the unit.





Note

Removing the USB Device from the unit.

- Choose a different function mode or press
 twice in a row.
- 2. Remove the USB device from the unit.

Compatible USB Devices


- MP3 Player: Flash type MP3 player.
- USB Flash Drive : Devices that support USB2.0 or USB1.1.
- The USB function of this unit does not support some USB devices

USB device requirement

- Devices which require additional program installation connected to a computer, are not supported.
- Do not extract the USB device while in operation.
- For a large capacity USB, it may take longer than a few minute to be searched.
- · To prevent data loss, back up all data.
- If you use a USB extension cable or USB hub, the USB device is not recognized.
- Using NTFS file system is not supported. (Only FAT(16/32) file system is supported.)
- This unit is not supported when the total number of files is 1000 or more.
- External HDD, Card readers, Locked devices, or hard type usb devices are not supported.
- USB port of the unit cannot be connected to PC.
 The unit can not be used as a storage device.
- · Some USB may not work with this unit.

OPTICAL IN connection

Connect an optical output of Unit (or Digital Device etc) to the OPTICAL IN connector.



Home theater speaker ez setup

Listen to sound from TV, DVD and Digital Device with 5.1(2.1 or 2)ch mode. Even in power off mode, if you press **OPTICAL**, then power is on and automatically changed to AUX OPT mode.

- 1. Connect the unit's OPTICAL IN jack to jack on optical out of your TV (or Digital Device etc.).
- 2. Select the AUX OPT by using the **OPTICAL** on the remote control to select the AUX OPT directly.

0


To select the AUX OPT function, press FUNCTION on the remote control.

- 3. Listen sound with 5.1(2.1 or 2)ch speaker.
- 4. To escape from AUX OPT by using the **OPTICAL**. Function is retuned to previous one.

Antenna Connection

Connect the supplied FM antenna for listening to the

Connect the FM Wire antenna to the FM antenna connector.





Note -

Be sure to fully extend the FM wire antenna.

Adjust the setup settings

By using the Setup menu, you can make various adjustments to items such as picture and sound.

You can also set a language for the subtitles and the Setup menu, among other things. For details on each Setup menu item, see pages 23 to 26.

OSD Initial language settings - Optional

During the first use of this unit, the initial language setup menu appears on your TV screen. You must complete initial language selection before using the unit. English will be selected as the initial language.

- 1. Press ()(POWER) to turn the unit on. The language setup menu will appear on the screen.
- Use ∧ V <> to select a language then press
 ENTER.

The confirm menu will appear.



3. Use **>** to select the [Enter] then press **©** ENTER to finish the language setup.

To display and exit the Setup menu



- 2. Select an [Setup] by using <>.
- Press ENTER. Displays the [Setup].
- Press
 or
 RETURN to exit in the [Setup]
 Menu.

About help menu for Setup

Menu	Buttons	Operation		
IVICIIU	Duttons	Орегасіоп		
▲▼ Move	۸۷	Moving to another menu.		
◄ Move	<	Moving to previous level.		
► Move	>	Moving to next level or selecting menu.		
Close	ℰ Դ RETURN	To exit the [Setup] menu or [5.1 Speaker Setup].		
⊙ Select	⊙ ENTER	To confirm menu.		

Language

Menu Language

Select a language for the Setup menu and on screen display.

Disc Audio / Disc Subtitle / Disc Menu

Select the language you prefer for the audio track (disc audio), subtitles, and the disc menu.

[Original]

Refers to the original language in which the disc was recorded.

[Other]

To select another language, press numeric buttons and then **© ENTER** to enter the corresponding 4-digit number according to the language code list on the page 42. If you enter the wrong language code, press **CLEAR**.

[Off (for Disc Subtitle)]

Turns off Subtitle.

Display

TV Aspect

Select the screen aspect to use based on the shape of your TV screen.

[4:3]

Select when a standard 4:3 TV is connected.

[16:9]

Select when a 16:9 wide TV is connected.

Display Mode

The Display Mode setting works only when the TV Aspect mode is set to 4:3.

[Letterbox]

Displays a wide picture with bands on the upper and lower portions of the screen.

[Panscan]

Automatically displays the wide picture on the entire screen and cuts off the portions that do not fit. (If the disc/file is not compatible with Pan Scan, the picture is displayed at Letterbox ratio.)

Resolution

Sets the output resolution of HDMI video signal. Refer to "Resolution Setting" for details about the resolution (Refer to the page 19).

[Auto]

If the HDMI OUT jack is connected to TVs providing display information (EDID), automatically selects the resolution best suited to the connected TV. If VIDEO OUT is only connected, this changes the resolution to 480i (or 576i) as default resolution.

[1080p]

Outputs 1080 lines of progressive video.

[1080i]

Outputs 1080 lines of interlaced video.

[720p]

Outputs 720 lines of progressive video.

[480p (or 576p)]

Outputs 480 (or 576) lines of progressive video.

[480i (or 576i)]

Outputs 480 (or 576) lines of interlaced video.

3

Audio

5.1 Speaker Setup

Make the following settings for the built-in 5.1 channel surround decoder.

- 1. Select [5.1 Speaker Setup] on the [Audio] menu.
- Press ENTER. The [5.1 SPEAKER] appears.



- 3. Use <> to select the desired speaker.
- 4. Adjust options using $\Lambda V <>$ buttons.
- 5. Returns to the previous menu by pressing RETURN.

[Speaker]

Select a speaker that you want to adjust.



Note

Certain speaker settings are prohibited by the Dolby Digital licensing agreement.

[Size]

Since the speaker settings are fixed, you cannot change the settings.

[Volume]

Adjust the output level of each speaker.

[Distance]

Adjust the distance between each speaker and the listening position.

[Speaker Test Start]

Select [Speaker Test Start] by using the ΛV and press @ ENTER.

Press **O** ENTER again to stop.

Adjust the volume to match the volume of test signals memorized in the system.

DRC (Dynamic Range Control)

Make the sound clear when the volume is turned down (Dolby Digital only). Set to [On] for this effect.

Vocal

Select [On] to mix karaoke channels into normal stereo.

This function is effective for multi-channel karaoke DVDs only.

HD AV Sync

Sometimes Digital TV encounters a delay between picture and sound. If this happens you can compensate by setting a delay on the sound so that it effectively 'waits' for the picture to arrive: this is called HD AV Sync. Use ΛV (on the remote control) to scroll up and down through the delay amount, which you can set at anything between 0 and 300ms.

Semi Karaoke

When a chapter/title/track is fully finished, this function shows the score in the screen with a fanfare sound.

[On]

When you finished singing a score will appear on the screen.

[Off]

Fanfare and score do not appear on the screen.



) Note

- DVD, DVD Karaoke discs with more than 2 tracks are available discs for the this function.
- When you watch movies, "off" the Semi Karaoke at the SETUP menu or enjoy it without connecting the MIC if the fanfare or score appears during changing a chapter.
- This function operate on the DVD/CD mode.
- The Semi Karaoke function is available only when a microphone is connected.
- If you do not use the microphone, turn down the volume and disconnect the microphone.

Lock (Parental Control)

Initial Setting the Area Code:

When you use this unit for the first time, you have to set the Area Code.

- Select the [Lock] menu and then press >.
- 3. Select the first character using ΛV buttons.
- Press **⊙** ENTER and select the second character using ∧ V buttons.
- Press ENTER to confirm your Area code selection.

Rating

Blocks playback of rated DVDs based on their contents. Not all discs are rated.

- Select [Rating] on the [Lock] menu then press >.
- 2. Input a password and press **© ENTER**.
- 3. Select a rating from 1 to 8 using the ΛV buttons.

[Rating 1-8]

Rating one (1) has the most restrictions and rating eight (8) is the least restrictive.

[Unlock]

If you select unlock, parental control is not active and the disc plays in full.

4. Press **© ENTER** to confirm your rating selection.

Password

You can enter or change password.

- Select [Password] on the [Lock] menu and then press >.
- 2. Press **© ENTER**.
- Input a password and press © ENTER.
 To change the password, press © ENTER when the [Change] option is highlighted.
 Input a password and press © ENTER.
 Enter it again and press © ENTER to verify.
- 4. Press to exit the menu.



If you forget your password, you can clear it using the following steps:

- Select the [Setup] menu on the [Home Menu].
- 2. Input the 6-digit number "210499" and press **© ENTER**. The password is cleared.

Area Code

Enter the code of the area whose standards were used to rate the DVD video disc, based on the list on page 41.

- Select [Area Code] on the [Lock] menu then press >.
- 2. Input a password and press **© ENTER**.
- 3. Select the first character using ΛV buttons.
- Press **⊙** ENTER and select the second character using **∧V** buttons.
- 5. Press **© ENTER** to confirm your Area code selection.

Using the Home Menu



- 2. Select an option by using <>.
- 3. Press **©** ENTER then selected option menu.

[Music] - Displays [Music] menu.

[Movie] – Start video media's playback or displays the [Movie] menu.

[Photo] - Displays [Photo] menu.

[Setup] - Displays the [Setup] menu.



Note

You can not select the [Music], [Movie] or [Photo] option when the USB device is not connected or a disc is not inserted.

Basic Operations

- Insert the disc by using the ▲ or connect the USB device to the USB port.
- Select an option by using <>.
 If you select the [Movie], [Photo] or [Music] option when you connect up to two devices, it appears as belows. Select a media then press
 O ENTER.



4. Press **©** ENTER then selected option menu.



- For the most Audio CD and DVD-ROM discs, playback starts automatically.
- The unit plays only music file contained in the USB storage device or disc automatically.

То	Do this
Stop	Press ■.
Playback	Press ► MONO/STEREO.
Pause	Press II.
Frame-by- Frame playback	Press II repeatedly to play title Frame-by-Frame. (DVD, Movie only)
Skipping to the next/ previous chapter/ track/ file	During playback, press
	step back to the previous chapter/ track/ file.
Locating a point quickly by playing a file in fast forward or fast reverse	During playback, press
Playing repeatedly or randomly	Press REPEAT repeatedly, and the current title, chapter or track will be played back repeatedly or randomly. - DVD: Chapter/ Title/ Off - Video(MOVIE): Title/ All/ Off - Audio CD/ MP3/ WMA: Track/ All/ Random/ Off
Slowing down	In the pause mode, press
the playing speed	In the pause mode, press ➤ to select the required speed. (Movie only) To return to normal speed, press ➤ MONO/STEREO.

Other Operations

Displaying Disc Information onscreen

You can display various information about the disc loaded on-screen.

- 1. Press I INFO/DISPLAY to show various playback information. The displayed items differ depending on the disc type or playing status.
- 2. You can select an item by pressing ΛV and change or select the setting by pressing <>.

Title - Current title number/ total number of titles.

Chapter - Current chapter number/ total number of chapters.

Time - Elapsed playing time.

Audio - Selected audio language or channel.

Subtitle - Selected subtitle.

Angle - Selected angle/ total number of angles.



Note

If any button is not pressed for a few seconds, the on-screen display disappears.

To display the DVD Menu DVD

When you play a DVD which contains several menu, you can select the menu you want using the Menu.

- 1. Press DISC MENU. The disc's menu appears.
- 2. Select the menu by using $\Lambda V < >$.
- Press ► MONO/STEREO to confirm.

To display the DVD title

DVD

When you play a DVD which contains several title, you can select the title you want using the Menu.

- Press TITLE. The disc's title appears.
- 2. Select the menu by pressing $\Lambda V \ll 2$.
- 3. Press ► MONO/STEREO to confirm.

1.5 times speed playback

DVD

The 1.5 speed allows you to watch the pictures and listen to the sound quicker than playing at a normal speed.

- 1. During playback, press ► MONO/STEREO to play at 1.5 times speed. "▶X1.5" appears on the
- Press ► MONO/STEREO again to exit.

Screen Saver

The screen saver appears when you leave the unit in Stop mode for about five minutes.

Starting play from selected time

DVD MOVIE

To start playing at any chosen time on the file or title.

- 1. Press I INFO/DISPLAY during playback.
- 2. Press ΛV to select the time clock icon and "--:--" appears.
- 3. Input the required start time in hours, minutes, and seconds from left to right. If you enter the wrong numbers, press CLEAR to remove the numbers you entered. Then input the correct numbers.
 - For example, to find a scene at 1 hour, 10 minutes, and 20 seconds, enter "11020" by using numerical buttons.
- 4. Press **© ENTER** to confirm. Playback starts from the selected time.

Resume playback

DVD MOVIE MUSIC ACD

The unit records the point where you pressed the depending on the disc.

If "■■ (Resume Stop)" appears on the screen briefly, press ► MONO/STEREO to resume playback (from the scene point).

If you press twice or unload the disc,

"

"(Complete Stop) appears on the screen. The unit will clear the stopped point.



Note

- The resume point may be cleared when a button is pressed (for example; ()(POWER), <u></u>, etc).
- This function may not work on some disc or title/track.

Changing subtitle code page

If the subtitle is not displayed properly, you can change the subtitle code page to view the subtitle file properly.

- During playback, press INFO/DISPLAY to display the On-Screen display.
- 2. Use ΛV to select the [Code Page] option.
- 3. Use <> to select desired code option.
- 4. Press RETURN to exit the On-Screen display.

Marked Playback

MUSIC ACD

The mark function enables you to store your favourite files from any disc or USB device in the unit memory.

1. Select [Music] on the [Home Menu].

Returning to the upper folder. (MP3/ WMA only)

File information will be displayed according to the ID3TAG information on the appropriate music file. (MP3 only)



Selecting all tracks/ files.

Deselecting all tracks/files.

Moving to the previous or next file list.

- Select a desired music on the [List] by using the \(\mathbf{V} \) then press MARKER to appears the mark on the list.
- Press
 ENTER.
 Displays the play mode.
- 4. Select the play mode by using the $\bigwedge V$ and press \bigcirc ENTER

[Mark Play]

Marked playback.

[Current Play]

Normal playback



Note

If you want to select all files on the list, select [Select All] and press **© ENTER**.

To delete a Marker

- Use \(\Lambda\V\) to select the track that you wish to erase from the marked file.
- 2. Press MARKER.

To delete all Markers

Use $\Lambda V <>$ to select [Deselect All] then press \odot ENTER in program edit mode.



Note

The markers are also cleared when the disc or USB device is removed, the unit is switched to power off or the function is switched to others.

Viewing a PHOTO file

PHOTO

This unit can play discs with photo files.

Select [Photo] on the [Home Menu] and press
 ENTER.

Moving to the previous or next file list.



Returning to the upper folder.

- Press ∧ V to select a folder, and then press
 ENTER.
- If you want to view a slide show, press ∧ V to highlight a file and press ► MONO/STEREO.

About help menu in the [Photo] menu

Menu	Buttons	Operation
➤ Slide Show	MONO/ STEREO	Viewing a slide show.
▲▼◆ ► Move	۸٧<>	Moving to another file or content.
⊚ Select		Viewing a particular file.
Close	ℰ ` RETURN	Returning to the [Home Menu].

About help menu in the full screen

Menu	Buttons	Operation		
Menu	INFO/ DISPLAY	Displaying the Option menu.		
◄/► Prev./ Next		Moving to another file.		
رة List	RETURN	Returning to the [Photo] menu.		

Options while viewing a photo

You can use various options during viewing a photo in full screen.

- While viewing a photo in full screen, press
 INFO/DISPLAY to display the option menu.
- 2. Select an option using $\Lambda V <>$.



- 1 Current photo/ Total number of photos Use <> to view previous/next photo.
- 2 Slide Show ►/II Press **⊙** ENTER to start or pause slide show.
- 3 Speed x3/ x2/ x1 − Use **⊙** ENTER to select a delaying speed between photos in a slide show.
- 4 Rotate Press O ENTER to rotate the photo.
- **5 Go to list** Press **© ENTER** to return [Photo] menu.

Sleep Timer Setting

Press **SLEEP** one or more times to select delay time between 10 and 180 minutes, after the unit will turn off.

To check the remaining time, press SLEEP.

To cancel the sleep function, press **SLEEP** repeatedly until "SLEEP 10" appears, and then press **SLEEP** once again while "SLEEP 10" is displayed.



Note

You can check the remaining time before the Unit turns off.

Press **SLEEP** The remaining time appears in the display window.

Dimmer

Press **SLEEP** once. The display window will be darken by half. To cancel it, press **SLEEP** repeatedly until dim off.

Turn off the sound temporarily

Press w to mute your unit.

You can mute your unit in order, for example, to answer the telephone, appears the MUTE in the display window.

To cancel it, press again $\sqrt[4]{}$ or change the volume level.

Last Scene Memory

DVD

This unit memorizes last scene from the last disc that is viewed. The last scene remains in memory even if you remove the disc from the unit or switch off the unit. If you load a disc that has the scene memorized, the scene is automatically recalled.

Power Resume - Optional

DVD

Even if the power suddenly goes out, turn on the unit and then it plays a position where the contents is being played. System will periodically save current playback status.

System Select - Optional

You must select the appropriate system mode for your TV system. Press and hold **II** for more than five seconds to be able to select a system in the [Home Menu].



Note

If the USB device is connected or a disc is inserted, this function is not operated.

4 0

Adjust the speaker level settings

You can adjust the sound level of each speaker.

- Press SPEAKER LEVEL repeatedly to select a desired speaker to set.
- Press VOL -/+ to adjust the sound level of the selected speaker while the level setting menu is displayed on the display window.
- 3. Repeat and adjust the sound level of the other speakers.

VOCAL FADER

You can enjoy the function as karaoke, by reducing singer vocal of music in the various source. (MP3/WMA/CD/ etc.) Press the **VOCAL FADER**, and "FADE ON" will appear in display window.

To cancel it, press VOCAL FADER again.

The quality of the **VOCAL FADER** may be different depending on the recording conditions of music files.



Note

- This function is available to use only when a microphone is connected.
- It is not available on the MONO source.

Auto power down

This unit will be off itself to save electric consumption in the case main unit is not connected to external device and is not used for 20 minutes. So does this unit after six hours since Main unit has been connected to other device using analog input.

How to disconnect the wireless network connection or the wireless device

Turn off the unit by pressing the power button for more than 5 seconds.

Radio Operations

Be sure that FM antenna is connected. (Refer to the page 22.)

Listening to the radio

- Press FUNCTION until FM appears in the display window.
 The last received station is tuned in.
- Press and hold TUNING (-/+) for about two seconds until the frequency indication starts to change, then release. Scanning stops when the unit tunes in a station.

or

Press TUNING (-/+) repeatedly.

3. Adjust the volume by pressing **VOL (-/+)** repeatedly.

Presetting the Radio Stations

You can preset 50 stations for FM.

Before tuning, make sure that you have turned down the volume.

- Press FUNCTION until FM appears in the display window.
- 2. Select the desired frequency by using **TUNING** (-/+).
- Press ENTER a preset number will flash in the display window.
- Press PRESET (∧/V) to select the preset number you want.
- Press
 ENTER.

 The station is stored.
- 6. Repeat the steps 2 to 5 to store other stations.
- To listen a preset station, press
 PRESET (\(\Lambda\)\) or 0 to 9 numerical buttons on the remote control.

Deleting all the saved stations

- Press and hold CLEAR for two seconds. "ERASEALL" will flash up on the unit display.
- 2. Press **CLEAR** to erase all saved of the radio stations.

Deleting a saved station

- Press PRESET \(\Lambda/\) to select a preset number you want to delete.
- Press CLEAR, the preset number will blink in the display window.
- Press CLEAR again to delete the selected preset number.

Improving poor FM reception

Press ► MONO/STEREO on the remote control. This will change the tuner from stereo to mono and usually improve the reception.

Sound adjustment

Setting the surround mode

This system has a number of pre-set surround sound fields. You can select a desired sound mode by using SOUND EFFECT.

You can change the **SOUND EFFECT** using <> arrow key while the sound effect information is displayed on.

The displayed items for the equalizer maybe different depending on sound sources and effects.

On Display	Description
STANDARD (STD)	You can enjoy the sound without equalizer effect.
BASS BLAST (BASS)	The BASS is Bass Blast. During playback, reinforce the treble, bass and surround sound effect.
USER EQ	You can adjust the sound effect.
FOOTBALL	You can enjoy more dynamic sound as watching sports game in the stadium.
POWER FRONT (P-FRONT)	You can enjoy the harmonious sound. This mode is suited for front-positioned speakers when they are all placed in a row.



Note

- In some of surround modes, some speakers, there's no sound or low sound. It depends on the mode of surround and the source of audio, it is not defective.
- This function is not operated when the microphone is connected to the unit.

Setting the USER EQ

You can adjust the sound level of Bass(BASS) and Treble(TRE) as your preference.

- 1. Use **SOUND EFFECT** to select the USER EQ then press • ENTER.
- 2. Use ΛV to select Bass (BASS) or Treble(TRE).
- 3. Use **>** to select the sound level of Bass(BASS) or Treble(TRE) then press **© ENTER** to save the setting.

Advanced Operations

Recording to USB

You can record music or sound souce to USB device by connecting in to the port on the unit.

- 1. Connect the USB device to the unit.
- 2. Select a mode in which you want to record. Playback a sound source first.
- 3. Start the recording by pressing REC.
- 4. To stop recording, press ■.

[All tracks/ files recording]

Record to USB in stop or play mode.

[Program list recording]

After marking desired file(s) and you can record it to USB (Refer to the page 29).

It'll be stored as follows.

Audio CD	CD_REC - TRK_001 - TRK_002
MP3/ WMA	FILE_REC - 001_ABC(File name) - 002_DEF(File name)
The other sources (Tuner, AUX, Portable)	EXT_REC - AUDIO_001 - AUDIO_002

1

Note

- You can check the recording percentage rate for the USB record on the screen during the recording. (Audio CD or MP3/ WMA CD only)
- During recording MP3/WMA, there is no sound.
- When you stop recording during playback, the file that has been recorded at that time will be stored. (Except MP3/WMA files)
- Do not remove the USB device or turn off the unit during USB recording. If does not, an incomplete file may be made and not deleted on PC.
- Recording through microphones is not available.
- If USB recording does not work, the message like "NO USB", "ERROR", "USB FULL" or "NO REC" is displayed on the display window.
- Multi card reader device or external HDD can not be used for USB recording.
- A file is recorded by 128 Mbyte (about 2 hours) when you record for a long term. There are recorded less than 4 files.
- In the state CD-G, DTS disc USB record is not operated.
- The files in the sub-folders are not recorded during all track recording.
- · You may not record more than 999 files.
- The numbering of the recording file is entered from the lowest number. So if you delete some of the recording files, the next recording file could be the lowest number among them.

The making of unauthorized copies of copyprotected material, including computer programs, files, broadcasts and sound recordings, may be an infringement of copyrights and constitute a criminal offense. This equipment should not be used for such purposes.

Be responsible Respect copyrights.

Using a Bluetooth wireless technology

About Bluetooth

Bluetooth is wireless communication technology for short range connection.

The sound may be interrupted when the connection interfered by the other electronic wave or you connect the **Bluetooth** in the other rooms.

Connecting individual devices under **Bluetooth**® wireless technology does not incur any charges. A mobile phone with **Bluetooth** wireless technology can be operated via the Cascade if the connection was made via **Bluetooth** wireless technology.

Available Devices: Mobile phone, MP3, Laptop, PDA

Bluetooth Profiles

In order to use **Bluetooth** wireless technology, devices must be able to interpret certain profiles. This unit is compatible with following profile.

A2DP (Advanced Audio Distribution Profile)

Listening to music of a Bluetooth device

Pairing your unit and Bluetooth device

Before you start the pairing procedure, make sure the **Bluetooth** feature is turned on in to your **Bluetooth** device. Refer to your **Bluetooth** device's user guide. Once a pairing operation is performed, it does not need to be performed again.

- Select the **Bluetooth** function by using the
 ► FUNCTION.
 - Appears "BT READY" in display window.
- Operate the **Bluetooth** device and perform the pairing operation. When searching for this unit with the **Bluetooth** device, a list of the devices found may appear in the **Bluetooth** device display depending on the type of **Bluetooth** device. Your unit appears as "LG HTS(XX:XX)".



Note

XX:XX means the last four digits of BT address. For example, if your unit has a BT address such as 9C:02:98:4A:F7:08, you will see "LG HTS(F7:08)" on your **Bluetooth** device.

 When this unit is successfully connected with your **Bluetooth** device, "PAIRED" appears on the display window and change to **Bluetooth** device name soon.



Not

Depending on the **Bluetooth** device type, some device have a different pairing way.

4. Listening to music.

To play a music stored on your **Bluetooth** device, refer to your **Bluetooth** device's user guide.



- If you change the function of the unit, the Bluetooth function is disconnected, operate pairing again.
 - (Bluetooth ←→ Function other than the Bluetooth)
- Depending on the Bluetooth device type, some device have a different pairing way. (Enter the PIN code (0000) as needed.)



- The sound may be interrupted when the connection interfered by the other electronic wave.
- You cannot control the Bluetooth device with this unit.
- Pairing is limited one **Bluetooth** device per one unit and multi-pairing is not supported.
- Depending on the type of the device, you may not be able to use the **Bluetooth** function.
- You can enjoy wireless system using phone, MP3. Notebook, headset, etc..
- When not connected the Bluetooth, "BT READY" appears on the display window.
- The Electrical malfunction due to devices using same frequency such as Medical equipment, Microwaves or wireless LAN devices, the connection will be disconnected.
- When someone stands and interrupts communication between **Bluetooth** device and the player, the connection will be disconnected.
- If the gotten away of the distance between Bluetooth and the unit, the sound quality is lower and lower the connection will disconnect when the space between the Bluetooth and the unit gets out of the operating range of Bluetooth.
- If the function is changed to Bluetooth again from other function, Bluetooth device is paired automatically.
- If the Bluetooth device name contains special characters, they are displayed as "_" on the display window.
- **Bluetooth** connection are unavailable during recording.

Auto function change

This unit recognizes input signals such as **Bluetooth** and then changes suitable function automatically.

When you try to connect Bluetooth device

When you try to connect your **Bluetooth** device to this unit, **Bluetooth** function is selected. Play your music on the **Bluetooth** device.



Note

- The Bluetooth unit which is not paired with this unit, cannot use the auto function change.
- If you change the this unit's function to other function, some **Bluetooth** unit may try to connecting in succession. Disconnect the **Bluetooth** connection before changing of the this unit's function.

AUTO POWER On

This unit automatically turns on by an input source : **Bluetooth**.

When you turn on your external device connected to this unit, this unit recognizes the input signal and select the suitable function. You can hear the sound from your device.

If you try to connect your **Bluetooth** device, this unit turns on and is paired automatically. And then play your music.



- After the unit is turned on by AUTO POWER function, it will be automatically turned off if there is no signal for a certain period of time from the external device.
- Depending on the connected device, this function may not operate.
- If you disconnect Bluetooth connection by this unit, some Bluetooth devices try to connect to the unit continually. Therefore it is recommended to disconnect the connection before turn off the unit.
- If you want to use AUTO POWER, SIMPLINK must be turned off. It takes for about 30 seconds to switch on or off SIMPLINK.
- If you have already paired with this unit automatically this unit can turn on by an input.
- If you turn off the unit by pressing the power button for more than 5 seconds, Auto Power On function is disabled. To activate it, turn on the unit.

Troubleshooting

PROBLEM	CORRECTION
The unit does not work properly.	Turn off the power of this unit and the connected external device (TV, Woofer, DVD-player, Amplifier, etc.) and turn it on again.
The unit does not work property.	Disconnect the power cord of this unit and the connected external device (TV, Woofer, DVD-player, Amplifier, etc.) and then try connecting again.
No power	Plug the power cord into the wall outlet securely.
No picture	Select the appropriate video input mode on the TV so the picture from the unit appears on the TV screen.
'	Connect the video cables securely to both the TV and unit.
	Select the correct input mode of the unit so you can hear the sound from the unit.
There is little or no sound	Connect the audio cables into the connection terminals correctly.
	Replace with a new audio cable.
The DVD picture quality is poor	Clean the disc using a soft cloth with outward strokes.
	Insert a disc.
A DVD/CD will not play	Insert a playable disc (check the disc type, colour system and regional code).
/ (BVB) CB Will Hot play	Place the disc with the label or printed side facing upwards.
	Enter your password or change the rating level.
Humming noise heard while a DVD or	Clean the disc using a soft cloth with outward strokes.
CD is playing	Move unit and audio components further away from your TV.
	Check the antenna connection and adjust its position.
Radio stations can't be tuned in	Attach an external antenna if necessary.
properly	Tune to the station manually.
	Preset some radio stations, see page 33 for details.
	The remote is not pointed directly at the unit. Point the remote directly at the unit.
	The remote is too far from the unit. Use the remote within 23 feet (7 m) of the unit.
The remote control doesn't work well / at all	There is an obstacle in the path between the remote control and the unit. Remove the obstacle.
	The battery in the remote control are flat. Replace the battery with new ones.
The AUTO POWER function does not	Check connection of the external device such as TV, DVD/Blu-Ray player or Bluetooth device.
work.	Check the state of SIMPLINK and turn off SIMPLINK.
	Depending on the connected device, this function may not operate.

Maintenance

Handling the Unit

When shipping the unit

Please save the original shipping carton and packing materials. If you need to ship the unit, for maximum protection, re-pack the unit as it was originally packed at the factory.

Keeping the exterior surfaces clean

- Do not use volatile liquids such as insecticide spray near the unit.
- · Wiping with strong pressure may damage the surface.
- Do not leave rubber or plastic products in contact with the unit for a long period of time.

Cleaning the unit

To clean the player, use a soft, dry cloth. If the surfaces are extremely dirty, use a soft cloth lightly moistened with a mild detergent solution. Do not use strong solvents such as alcohol, benzine, or thinner, as these might damage the surface of the unit.

Maintaining the Unit

The unit is a high-tech, precision device. If the optical pick-up lens and disc drive parts are dirty or worn, the picture quality could be diminished. For details, please contact your nearest authorized service center.

Notes on Discs

Handling Discs

Do not touch the playback side of the disc. Hold the disc by the edges so that fingerprints do not get on the surface. Never stick paper or tape on the disc.

Storing Discs

After playing, store the disc in its case. Do not expose the disc to direct sunlight or sources of heat and never leave it in a parked car exposed to direct sunlight.

Cleaning Discs

Fingerprints and dust on the disc can cause poor picture quality and sound distortion. Before playing, clean the disc with a clean cloth. Wipe the disc from the center to out.

Do not use strong solvents such as alcohol, benzine, thinner, commercially available cleaners, or anti-static spray intended for older vinyl records.

Area Code List

Choose an area code from this list.

Area	Code	Area	Code	Area	Code	Area	Code
Afghanistan	AF	Fiji	FJ	Monaco	MC	Singapore	SG
Argentina	AR	Finland	FI	Mongolia	MN	Slovak Republic	SK
Australia	AU	France	FR	Morocco	MA	Slovenia	SI
Austria	AT	Germany	DE	Nepal	NP	South Africa	ZA
Belgium	BE	Great Britain	GB	Netherlands	NL	South Korea	KR
Bhutan	BT	Greece	GR	Antilles	AN	Spain	ES
Bolivia	ВО	Greenland	GL	New Zealand	NZ	Sri Lanka	LK
Brazil	BR	Hong Kong	HK	Nigeria	NG	Sweden	SE
Cambodia	KH	Hungary	HU	Norway	NO	Switzerland	CH
Canada	CA	India	IN	Oman	OM	Taiwan	TW
Chile	CL	Indonesia	ID	Pakistan	PK	Thailand	TH
China	CN	Israel	IL	Panama	PA	Turkey	TR
Colombia	CO	Italy	IT	Paraguay	PY	Uganda	UG
Congo	CG	Jamaica	JM	Philippines	PH	Ukraine	UA
Costa Rica	CR	Japan	JP	Poland	PL	United States	US
Croatia	HR	Kenya	KE	Portugal	PT	Uruguay	UY
Czech Republic	CZ	Kuwait	KW	Romania	RO	Uzbekistan	UZ
Denmark	DK	Libya	LY	Russian		Vietnam	VN
Ecuador	EC	Luxembourg	LU	Federation	RU	Zimbabwe	ZW
Egypt	EG	Malaysia	MY	Saudi Arabia	SA		
El Salvador	SV	Maldives	MV	Senegal	SN		
Ethiopia	ET	Mexico	MX				

Language code List

Use this list to input your desired language for the following initial settings: [Disc Audio], [Disc Subtitle] and [Disc Menu].

Language	Code	Language	Code	Language	Code	Language	Code
Afar	6565	French	7082	Lithuanian	7684	Sindhi	8368
Afrikaans	6570	Frisian	7089	Macedonian	7775	Singhalese	8373
Albanian	8381	Galician	7176	Malagasy	7771	Slovak	8375
Ameharic	6577	Georgian	7565	Malay	7783	Slovenian	8376
Arabic	6582	German	6869	Malayalam	7776	Spanish	6983
Armenian	7289	Greek	6976	Maori	7773	Sudanese	8385
Assamese	6583	Greenlandic	7576	Marathi	7782	Swahili	8387
Aymara	6588	Guarani	7178	Moldavian	7779	Swedish	8386
Azerbaijani	6590	Gujarati	7185	Mongolian	7778	Tagalog	8476
Bashkir	6665	Hausa	7265	Nauru	7865	Tajik	8471
Basque	6985	Hebrew	7387	Nepali	7869	Tamil	8465
Bengali; Bangla	6678	Hindi	7273	Norwegian	7879	Telugu	8469
Bhutani	6890	Hungarian	7285	Oriya	7982	Thai	8472
Bihari	6672	Icelandic	7383	Panjabi	8065	Tonga	8479
Breton	6682	Indonesian	7378	Pashto, Pushto	8083	Turkish	8482
Bulgarian	6671	Interlingua	7365	Persian	7065	Turkmen	8475
Burmese	7789	Irish	7165	Polish	8076	Twi	8487
Byelorussian	6669	Italian	7384	Portuguese	8084	Ukrainian	8575
Chinese	9072	Japanese	7465	Quechua	8185	Urdu	8582
Croatian	7282	Kannada	7578	Rhaeto-Romance	8277	Uzbek	8590
Czech	6783	Kashmiri	7583	Rumanian	8279	Vietnamese	8673
Danish	6865	Kazakh	7575	Russian	8285	Volapük	8679
Dutch	7876	Kirghiz	7589	Samoan	8377	Welsh	6789
English	6978	Korean	7579	Sanskrit	8365	Wolof	8779
Esperanto	6979	Kurdish	7585	Scots Gaelic	7168	Xhosa	8872
Estonian	6984	Laothian	7679	Serbian	8382	Yiddish	7473
Faroese	7079	Latin	7665	Serbo-Croatian	8372	Yoruba	8979
Fiji	7074	Latvian, Lettish	7686	Shona	8378	Zulu	9085
Finnish	7073	Lingala	7678				

Trademarks and Licenses

All other trademarks are trademarks of their respective owners.



Manufactured under license from Dolby Laboratories. Dolby and the double-D symbol are trademarks of Dolby Laboratories.



The terms HDMI and HDMI High-Definition Multimedia Interface, and the HDMI logo are trademarks or registered trademarks of HDMI Licensing LLC in the United States and other countries.



"DVD Logo" is a trademark of DVD Format/Logo Licensing Corporation.

Bluetooth®

The **Bluetooth®** word mark and logos are owned by the Bluetooth® SIG, Inc. and any use of such marks by LG Electronics is under license.

Other trademarks and trade names are those of their respective owners.

Notes on Copyrights

- This product incorporates copyright protection technology that is protected by U.S. patents and other intellectual property rights. Use of this copyright protection technology must be authorized by Rovi, and is intended for home and other limited viewing uses only unless otherwise authorized by Rovi. Reverse engineering or disassembly is prohibited.
- Under the U.S. Copyright laws and Copyright laws of other countries, unauthorized recording, use, display, distribution, or revision of television programs, videotapes, BD-ROM discs, DVDs, CDs and other materials may subject you to civil and/or criminal liability.

Specifications

General	
Power requirements	Refer to main label.
Dower concumption	Refer to main label.
Power consumption	Networked standby 0.5 W (If all network ports are activated.)
Dimensions (W x H x D)	Approx. (360 x 58 x 298.5) mm without foot
Net Weight (Approx.)	Approx. 2.46 kg
Operating temperature	5 °C to 35 °C
Operating humidity	5 % to 90 %
Bus Power Supply	5 V === 500 mA

Inputs/ Outputs		
VIDEO OUT	1.0 V (p-p), 75 Ω , sync negative, RCA jack x 1	
HDMI OUT (video/audio)	19 pin (Type A, HDMI™ Connector) x 1	
ANALOG AUDIO IN	2.0 Vrms (1 kHz, 0 dB), 600 Ω, RCA jack (L, R) x 1	
DIGITAL IN (OPTICAL)	3 V (p-p), Optical jack x 1	
PORT. IN	0.5 Vrms (3.5 mm stereo jack) x 1	

Amplifier			
Stereo mode	167 W + 167 W (3 Ω at 1kHz)		
Surround mode	Front	167 W + 167 W (3 Ω at 1 kHz)	
	Center	167 W (3 Ω at 1 kHz)	
	Surround	167 W + 167 W (3 Ω at 1 kHz)	
	Subwoofer	167 W (3 Ω at 60 Hz)	

Tuner	
FM Tuning Range	87.5 to 108.0 MHz or 87.50 to 108.00 MHz

Front Speaker		
Туре	1 way 1 speaker	
Impedance	3Ω	
Rated Input Power	167 W	
Max. Input Power	334 W	
Net Dimensions (W x H x D)	Approx. (250 x 1150 x 250) mm	
Net Weight	Approx. 3.7 kg	

Rear Speaker		
Туре	1 way 1 speaker	
Impedance	3Ω	
Rated Input Power	167 W	
Max. Input Power	334 W	
Net Dimensions (W x H x D)	Approx. (250 x 1150 x 250) mm	
Net Weight	Approx. 3.7 kg	

Center Speaker		
Туре	1 way 1 speaker	
Impedance	3Ω	
Rated Input Power	167 W	
Max. Input Power	334 W	
Net Dimensions (W x H x D)	Approx. (260 x 93 x 73) mm	
Net Weight	Approx. 0.65 kg	

Passive Subwoofer		
Туре	1 Way 1 Speaker	
Impedance	3Ω	
Rated Input Power	167 W	
Max. Input Power	334 W	
Net Dimensions (W x H x D)	Approx. (191 x 386 x 318) mm	
Net Weight	Approx. 5.2 kg	

• Design and specifications are subject to change without notice.

