



**MICROWAVE OVEN
MIKROVÅGSUGN
MIKROBØLGEOVN
MIKROBØLGEOVN
MIKROAALTOUUNI**

**OWNER'S MANUAL
ANVÄNDARHANDBOK
BRUKERHÅNDBOK
BRUGERVEJLEDNING
KÄYTTÖOHJEET**

**MH-607Y/ 607YS
MH-667Y/ 667YS
MG-567Y/ 567YS**

PLEASE READ THIS OWNER'S MANUAL THOROUGHLY BEFORE OPERATING.
LÄS IGENOM DENNA ANVÄNDARHANDBOK NOGA INNAN MIKROVÅGSUGNEN ANVÄNDS.
SETT DEG GRUNDIG INN I INNEHÅLLET I DENNE BRUKERHÅNDBOKEN FØR APPARATET TAS I BRUK.
LÆS VENLIGST VEJLEDNINGEN GRUNDIGT, INDEN OVNEEN TAGES I BRUG.
LUKEKAA NÄMÄ OHJEET HUOLELLISESTI ENNEN MIKROAALTOUUNIN KÄYTTÖÄ.

Precautions

Precautions to avoid possible exposure to excessive microwave energy.

You cannot operate your oven with the door open due to the safety interlocks built into the door mechanism. These safety interlocks automatically switch off any cooking activity when the door is opened; which in the case of a microwave oven could result in harmful exposure to microwave energy.

It is important not to tamper with the safety interlocks.

Do not place any object between the oven front face and the door or allow food or cleaner residue to accumulate on sealing surfaces.

Do not operate your oven if it is damaged. It is particularly important that the oven door closes properly and that there is no damage to the: (1) door (bent), (2) hinges and latches (broken or loosened), (3) door seals and sealing surfaces.

Your oven should not be adjusted or repaired by anyone except qualified service personnel.

Warning

When heating liquids, e.g. soups, sauces and beverages in your microwave oven, delayed eruptive boiling can occur without evidence of bubbling. This could result in a sudden boil over of the hot liquid. To prevent this possibility the following steps should be taken:

- 1 Avoid using straight sided containers with narrow necks.
- 2 Do not overheat.
- 3 Stir the liquid before placing the container in the oven and again halfway through the heating time.
- 4 After heating, allow to stand in the oven for a short time, stir or shake them (especially the contents of feeding bottles and baby food jars) again carefully and check the temperature of them before consumption to avoid burns (especially, contents of feeding bottles and baby food jars). Be careful when handling the container.

Warning

Always allow food to stand after being cooked by microwaves and check the temperature of them before consumption. Especially contents of feeding bottles and baby food jars.

How the Microwave Oven Works

Microwaves are a form of energy similar to radio and television waves and ordinary daylight. Normally, microwaves spread outwards as they travel through the atmosphere and disappear without effect. Microwave ovens, however, have a magnetron which is designed to make use of the energy in microwaves. Electricity, supplied to the magnetron tube, is used to create microwave energy.

These microwaves enter the cooking area through openings inside the oven. A turntable or tray is located at the bottom of the oven. Microwaves cannot pass through metal walls of the oven, but they can penetrate such materials as glass, porcelain and paper, the materials out of which microwave-safe cooking dishes are constructed.

Microwaves do not heat cookware, though cooking vessels will eventually get hot from the heat generated by the food.

A very safe appliance


Your microwave oven is one of the safest of all home appliances. When the door is opened, the oven automatically stops producing microwaves. Microwave energy is converted completely to heat when it enters food, leaving no “left over” energy to harm you when you eat your food.

| | |
|---|---------|
| Precautions | 3 |
| Contents | 4 |
| Unpacking & Installing | 5 ~ 6 |
| Setting the Clock | 7 |
| Child Lock | 8 |
| Micro Power Cooking | 9 |
| Micro Power Level | 10 |
| Two Stage Cooking | 11 |
| Quick Start | 12 |
| Auto Cook | 13 ~ 14 |
| Auto Defrost | 15 ~ 16 |
| Quick Defrost | 17 ~ 18 |
| Favorite Cook | 19 |
| Timer | 20 |
| Grill Cooking | 21 |
| Combination Cooking | 22 |
| Heating or Reheating Guide | 23 |
| Fresh vegetable Guide | 24 |
| Grill Cooking Guide | 25 |
| Safety precautions | 26 |
| Microwave - safe Utensils | 27 |
| Food characteristics & Microwave cooking | 28 ~ 29 |
| Questions & Answers | 30 |
| Plug Wiring Information/ Technical Specifications | 31 |


Unpacking & Installing

By following the basic steps on these two pages you will be able to quickly check that your oven is operating correctly. Please pay particular attention to the guidance on where to install your oven. When unpacking your oven make sure you remove all accessories and packing. Check to make sure that your oven has not been damaged during delivery.

- 1** Unpack your oven and place it on a flat level surface.



GLASS TRAY




MH-607Y/ 607YS




MH-667Y/ 667YS
MG-567Y/ 567YS

ROTATING RING




MH-607Y/ 607YS



MH-667Y/ 667YS
MG-567Y/ 567YS

GRILL RACK

- 2** Place the oven in the level location of your choice with more than 85cm height but make sure there is at least 30cm of space on the top and 10cm at the rear for proper ventilation. The front of the oven should be at least 8cm from the edge of the surface to prevent tipping. An exhaust outlet is located on top or side of the oven. Blocking the outlet can damage the oven.




THIS OVEN SHOULD NOT BE USED FOR COMMERCIAL CATERING PURPOSES

3 Plug your oven into a standard household socket. Make sure your oven is the only appliance connected to the socket. **If your oven does not operate properly, unplug it from the electrical socket and then plug it back in.**

4 Open your oven door by pulling the **DOOR HANDLE**. Place the **ROTATING RING** inside the oven and place the **GLASS TRAY** on top.

5 Fill a **microwave safe container** with 300 ml (1/2 pint) of water. Place on the **GLASS TRAY** and close the oven door. If you have any doubts about what type of container to use please refer to page 27.




6 Press the **STOP** button, and press the **START** button six times to set 3 minutes of cooking time.



You will hear a BEEP each time you press the button. Your oven will start before you have finished the sixth press; don't worry this is normal.

7 The **DISPLAY** will count down from 3 minutes. When it reaches 0 it will sound BEEPS. Open the oven door and test the temperature of the water. If your oven is operating the water should be warm. **Be careful when removing the container it may be hot.**



Setting the Clock

You can set either 12 hour clock or 24 hour clock.
In the following example I will show you how to set the time for 14:35 when using the 24 clock.
Make sure that you have removed all packaging from your oven.



When your oven is plugged in for the first time or when power resumes after a power cut, a '0' will be shown in the display; you will have to reset the clock.

If the clock (or display) shows any strange looking symbols, unplug your oven from the electrical socket and plug it back in and reset the clock.

During clock setting the START button will flash. After setting the START button will stop flashing.

Make sure that you have correctly installed your oven as described earlier



Press **STOP/CLEAR**.



Press **CLOCK**.



(If you want to select a different option, Press **CLOCK** once more.

If you want to change different option after setting clock, you have to unplug and plug it back in.)



Turn **PL** until display shows "14:00".



Press **START** for confirmation.



Turn **PL** until display shows "14:35".



Press **START**.
The clock starts counting.



Child Lock



Your oven has a safety feature that prevents accidental running of the oven. Once the child lock is set, you will be unable to use any functions and no cooking can take place. However your child can still open the oven door.

Press **STOP/CLEAR**



Press and hold **STOP/CLEAR** until "L" appears in the display and the **CHILD LOCK** is set.



The time will disappear on the display if you have set the clock.

"L" remains on the display to let you know that **CHILD LOCK** is set.



To cancel **CHILD LOCK** press and hold **STOP/CLEAR** until "L" disappears. You will hear BEEP when it's released.



Micro Power Cooking

In the following example I will show you how to cook some food on 80% power for 5 minutes and 30 seconds.



Your oven has five microwave Power settings. High power is automatically selected but repeated presses of the **POWER** button will select a different power level.

| POWER | % | Press MICRO | time | Power Output | |
|-----------------------|------|----------------|-------|---------------------|--|
| | | | | MH-607Y MH-607YS | MH-667Y MH-667YS MG-567Y MG-567YS |
| HIGH MAX | 100% | 1 | time | 800W | 900W |
| MEDIUM HIGH | 80% | 2 | times | 640W | 720W |
| MEDIUM | 60% | 3 | times | 480W | 540W |
| DEFROST MEDIUM LOW | 40% | 4 | times | 320W | 360W |
| LOW | 20% | 5 | times | 160W | 180W |

Make sure that you have correctly installed your oven as described earlier

Press **STOP/CLEAR**.

Press **POWER** to select 80% power.

Turn **DISPLAY** until display shows "5:30".

Press

Micro Power Level

Your microwave oven is equipped with 5 power levels to give you maximum flexibility and control over cooking. The table below shows the examples of food and their recommended cooking power levels for use with this microwave oven.

| POWER LEVEL | USE | POWER LEVEL (%) | POWER OUTPUT | |
|--------------------------------|--|-----------------|---------------------|---|
| | | | MH-607Y MH-607YS | MH-667Y/ MH-667YS MG-567YS/ MG-567YS |
| HIGH | <ul style="list-style-type: none"> * Boil Water * Brown minced beef * Cook poultry pieces, fish, vegetables * Cook tender cuts of meat | 100% | 800W | 900W |
| MEDIUM HIGH | <ul style="list-style-type: none"> * All reheating * Roast meat and poultry * Cook mushrooms and shellfish * Cook foods containing cheese and eggs | 80% | 640W | 720W |
| MEDIUM | <ul style="list-style-type: none"> * Bake cakes and scones * Prepare eggs * Cook custard * Prepare rice, soup | 60% | 480W | 540W |
| DEFROST/ MEDIUM LOW | <ul style="list-style-type: none"> * All thawing * Melt butter and chocolate * Cook less tender cuts of meat | 40% | 320W | 360W |
| LOW | <ul style="list-style-type: none"> * Soften butter & cheese * Soften ice cream * Raise yeast dough | 20% | 160W | 180W |



Two stage Cooking

In the following example I will show you how to cook some food in two stages. The first stage will cook your food for 11 minutes on HIGH; the second will cook for 35 minutes on 40%.




During two stage cooking the oven door can be opened and food checked. Close the oven door and press **START** and the cooking stage will continue.

At the end of stage1, **BEEP** sounds and stage 2 commences.

Should you wish to clear the programme press **STOP/ CLEAR** twice.

Press **STOP/ CLEAR** once to stop the cooking time for **stage1**.
Press **POWER** once to select HIGH power.



Turn **POWER** until display shows "11:00".



Set the cooking time for **stage2**.
Press **POWER** to select 40% power.



Turn **POWER** until display shows "35:00".
Press **STOP/ CLEAR** once to stop the cooking time for **stage2**.



Quick Start

In the following example I will show you how to set 2 minutes of cooking on high power.



The **QUICK START** feature allows you to set 30 seconds intervals of HIGH power cooking with a touch of the **START** button.

Press **START**



Press **START** four times to select 2 minutes on HIGH power .
You have finished the fourth press.



During **QUICK START** cooking, you can extend the cooking time by repeatedly pressing the



Auto Cook

In the following example I will show you how to cook 0.6kg of fresh vegetable.



AUTO COOK allows you to cook most of your favorite food easily by selecting the food type and entering the weight of the food.

| Category | Press AUTO COOK |
|------------------|--------------------|
| JACKET POTATO | 1 time |
| FRESH VEGETABLE | 2 times |
| FROZEN VEGETABLE | 3 times |



| <i>FOOD CATEGORY</i> | <i>FOOD TEMP.</i> | <i>UTENSILS</i> | <i>WEIGHT LIMIT</i> | <i>INSTRUCTIONS</i> |
|-----------------------------|-------------------|-----------------|---------------------|---|
| 1. JACKET POTATO | Room temp. | Glass tray | 0.1 kg ~ 1.0 kg | Wash, dry and prick potato with a fork several times. Place the potato with three pieces of paper towel in the centre of the glass tray. After Cooking, let stand for 5 minutes. |
| 2. FRESH VEGETABLES | Room temp. | Glass tray | 0.2 kg ~ 0.8 kg | Place prepared vegetables into a suitable sized container (e.g. casserole dish). Add 30 ml water per 200 g vegetables. After Cooking, let stand for 5 minutes. |
| 3. FROZEN VEGETABLES | Frozen | Glass tray | 0.2 kg ~ 0.8 kg | Place prepared frozen vegetables into a suitable sized container. Add 30 ml water per 200 g vegetable. Cover and place in the centre of the glass tray. After Cooking, let stand for 5 minutes. |

Auto Defrost

The temperature and density of food varies, I would recommend that the food is checked before cooking commences. Pay particular attention to large joints of meat and chicken, some foods should not be completely thawed before cooking. The **BREAD** programme is suitable for defrosting small items such as rolls or a small loaf. These will require a standing time to allow the centre to thaw. In the following example I will show you how to defrost 1.4 Kg of frozen poultry.



Your oven has four microwave defrost settings:- **MEAT**, **POULTRY**, **FISH** and **BREAD**; each defrost category has different power settings.

| Category | Press |
|----------------|----------------|
| | DEFROST |
| MEAT | 1 time |
| POULTRY | 2 times |
| FISH | 3 times |
| BREAD | 4 times |

Press **START** to begin defrosting.
When you are about to defrost. Be certain to remove any metal items. Then place the food in your oven and close the oven door.

Press **ALTER** and **DEFROST** twice to select the **POULTRY** defrosting programme.

Enter the weight of the frozen food that you are about to defrost.

The display shows "1.4".

Press **START**

During defrosting your oven will "BEEP", at which point open the oven door, turn food over and separate to ensure even thawing. Remove any portions that have thawed or shield them to help slow down thawing. After checking close the oven door and press **START** to resume defrosting.

Your oven will not stop defrosting (even when the beep sounded) unless the door is opened.

AUTO WEIGHT DEFROST SEQUENCE LIST

| SEQUENCE | | FOOD | MIN./ MAX. |
|------------|-----------|---|-------------|
| 1. MEAT | Beef | Minced beef, Fillet steak, Cubes for stew, Sirloin steak, Pot roast, Rump roast, Beef burger. | 0.1/ 4.0 kg |
| | Lamb | Chops(2.5 cm thick), Filled roast. | |
| | Veal | Cutlets(450 g, 1.2 cm thick) | |
| 2. POULTRY | Chicken | Whole(under 2 Kg), Cut up Breasts(boneless), Legs. | 0.1/ 4.0 kg |
| | Turkey | Breasts(under 2.5 Kg) | |
| 3. FISH | Fish | Fillets, Steaks, Whole | 0.1/ 4.0 kg |
| | Shellfish | Crabmeat, Lobster tails, Shrimp, Scallops | |
| 4. BREAD | | Sliced brown/ white bread, White/ brown rolls, French stick, Baguette, Croissant | 0.1/ 0.5 kg |

* The benefit of this Auto Defrost feature is automatic setting and control of defrosting, but just like conventional defrosting you must check the food during the defrosting time.

* For best results, remove meat and poultry from its original paper or plastic package(wrapper). Otherwise, the wrap will hold steam and juice close to the food which can cause the outer surface of the food to cook.

* Place foods in a shallow glass baking dish to catch drippings.

* Food should still be some what icy in the centre when removed from the oven.

* When it is difficult to remove the wrap from the food, defrost the wrapped food for about a quarter of the total defrost time, which is displayed at the beginning of the defrost cycle. Then remove the food from the oven and remove the wrap from the food.

* Sliced bread should be placed between sheets of kitchen towel and bread rolls should be cut in half before defrosting.

* After defrosting, let stand for 5 to 10 minutes or until completely thawed.



Quick Defrost

Use this function to thaw only 0.5kg of Minced meat very quickly.
This will require a standing time to allow the center to thaw. In the following example will show you how to defrost 0.5kg of frozen minced meat.



Your oven has a microwave quick defrost setting (MEAT).



Press **DE/CLF** when your food items are about to defrost. Be certain to remove any metal covers or trays, then place the food in your oven and close the oven door.



Press **QUICK DEFROST 2** to select the **MEAT** defrosting programme.



During defrosting your oven will "BEEP", at which point open the oven door, turn food over and separate to allow faster thawing. Remove any portions that have thawed or shield them to help slow down thawing. After checking close the oven door and press **START** to resume defrosting.

Your oven will not stop defrosting (even when the beep sounded) unless the door is opened.

QUICK DEFROST

| SEQUENCE | | FOOD | MIN./ MAX. FOOD |
|----------|----------------------|-------------|-----------------|
| 1. MEAT | Beef Lamb Veal | Minced meat | 0.5 kg |

- * The benefit of this Quick Defrost feature is automatic setting and control of defrosting, but just like conventional defrosting you must check the food during the defrosting time.
- * For best results, remove fish, shellfish, meat and poultry from its original paper or plastic package(wrapper). Otherwise, the wrap will hold steam and juice close to the food which can cause the outer surface of the food to cook.
- * Place foods in a shallow glass baking dish to catch drippings.
- * Food should still be some what icy in the center when removed from the oven.
- * After defrosting, let stand for 10 minutes or untill thawed.



Favorite Cook

This feature allows you to set and execute a frequently used single stage programme. Once the cooking programme is set, you can use it by pressing the favorite cook key. In the following example I will show you how to set the cooking programme for 10 minutes 30 seconds at power level 80%.



The cooking programme is stored permanently in the memory of your microwave oven.

If you wish to change your FAVORITE COOK, simply enter a new cooking programme.

1. To set

Press **FAVORITE COOK**



Press **10:30** 50-1 appears on the display.

Press **80%** to select 80% power.



Turn **DIAL** knob until display shows "10:30"

Press **START**
Successfully finished setting the favorite cook.



2. To cook

When ready, press the favorite cook key.

Press **FAVORITE COOK**



Press **START**



This pad performs two function; 1) It operate as an independent timer.
2) It can be set to delay cooking.



Your oven also has a Timer that can be used for noncooking functions. When used as an independent timer, the oven is not running. The Timer is simply counting down in seconds.

1. Timer



To [button] you want to count down.



Turn [button] display shows "15:00".



Press [button] counting down in the display window with no cooking or heating in the oven. BEEP will sound and the word "End" will show in the display window at the end of the countdown period.



2. Delay start



To [button] time to delay the start of cooking.



To [button] time to cook.



Press [button] zero, beep sounds and [button] to cook.




Grill Cooking

In the following example I will show you how to use the grill to cook some food for 12 minutes and 30 seconds.



This feature will allow you to brown and crisp food quickly.



GRILL RACK

Press



Press



Turn the dial until display shows "12:30".



Press



Combination Cooking

In the following example I will show you how to programme your oven with combi mode co-3 for a cooking time of 25 minutes.



Your oven has a combination cooking feature which allows you to cook food with **heater** and **microwave** at the same time or alternately. This generally means it takes less time to cook your food.

The **sheath heater** grills the surface of the food while **microwave** heats inside. Moreover, preheating your oven is not necessary.

Press **START**



Press **COOKING** times.



Turn **DIAL** until display shows "25:00".



Press **START**



Be careful when opening your food because the container will be hot!



Combination Cooking Mode

| CATEGORY | MICRO POWER (%) | HEATER POWER (%) |
|----------|-----------------|------------------|
| Co-1 | 20 | 80 |
| Co-2 | 40 | 60 |
| Co-3 | 60 | 40 |

Heating or Reheating Guide

To heat or reheat successfully in the microwave, it is important to follow several guidelines. Measure the amount of food in order to determine the time needed to reheat. Arrange the food in a circular pattern for best results. Room temperature food will heat faster than refrigerated food. Canned foods should be taken out of the can and placed in a microwavable container. The food will be heated more evenly if covered with a microwavable lid or vented plastic wrap. Remove cover carefully to prevent steam burns. Use the following chart as a guide for reheating cooked food.

| <i>Item</i> | <i>Cook time (at HIGH)</i> | <i>Special Instructions</i> |
|--|------------------------------|---|
| Sliced meat 3 slices (0.5cm thick) | 1~2 minutes | Place sliced meat on microwavable plate. Cover with plastic wrap and vent. • Note: Gravy or sauce helps to keep meat juicy. |
| Chicken pieces 1 breast 1 leg and thigh | 2~3 minutes 3~3½ minutes | Place chicken pieces on microwavable plate. Cover with plastic wrap and vent. |
| Fish fillet (170-230g) | 1~2 minutes | Place fish on microwavable plate. Cover with plastic wrap and vent. |
| Lasagne 1 serving (300g) | 4~6 minutes | Place lasagne on microwavable plate. Cover with plastic wrap and vent. |
| Casserole 1 cup 4 cups | 1½~3 minutes 4½~7 minutes | COOK covered in microwavable casserole dish. Stir once halfway through cooking. |
| Casserole cream or cheese 1 cup 4 cups | 1~2½ minutes 3½~6 minutes | COOK covered in microwavable casserole dish. Stir once halfway through cooking. |
| Sloppy jeb or Barbecued beef 1 sandwich (½ cup meat filling) without bun | 1~2½ minutes | Reheat filling and bun separately. Cook filling covered in microwavable casserole dish. Stir once. Heat bun as directed in chart below. |

| <i>Item</i> | <i>Cook time (at HIGH)</i> | <i>Special Instructions</i> |
|--|--------------------------------|--|
| Mashed potatoes 1 cup 4 cups | 2½~3½ minutes 6~9 minutes | COOK covered in microwavable casserole dish. Stir once halfway through cooking. |
| Baked beans 1 cup | 1½~3 minutes | COOK covered in microwavable casserole dish. Stir once halfway through cooking. |
| Pavoli or pasta in sauce 1 cup 4 cups | 2½~4 minutes 7½~11 minutes | COOK covered in microwavable casserole dish. Stir once halfway through cooking. |
| Foe 1 cup 4 cups | 1~1½ minutes 3½~5 minutes | COOK covered in microwavable casserole dish. Stir once halfway through cooking. |
| Sandwich roll or bun 1 roll | 15~30 seconds | Wrap in paper towel and place on glass tray. |
| Vegetables 1 cup 4 cups | 1½~2½ minutes 3½~5½ minutes | COOK covered in microwavable casserole dish. Stir once halfway through cooking. |
| Soup 1 serving (8 oz.) | 1½~2 minutes | COOK covered in microwavable casserole dish. Stir once halfway through cooking. |

Fresh Vegetable Guide

| Vegetable | Amount | Cook time (at HIGH) | Instructions | Standing Time |
|--|----------------------|------------------------|---|------------------|
| Artichokes (230g each) | 2 medium 4 medium | 4 1/2 ~ 7 10 ~ 12 | Trim. Add 2 tsp water and 2 tsp juice. Cover. | 2~3 minutes |
| Asparagus, Fresh, Spears | 450g | 2 1/2 ~ 6 | Add 1 cup water. Cover. | 2~3 minutes |
| Green Beans | 450g | 7 ~ 11 | Add 1/2 cup water in 1.5 litre casserole dish. Stir halfway through cooking. | 2~3 minutes |
| Beats, Fresh | 450g | 11 ~ 16 | Add 1/2 cup water in 1.5 litre covered casserole dish. Rearrange halfway through cooking. | 2~3 minutes |
| Broccoli, Fresh, Spears | 450g | 5 ~ 8 | Place broccoli in baking dish. Add 1/2 cup water. | 2~3 minutes |
| Cabbage, Fresh, Chopped | 450g | 5 1/2-7 1/2 | Add 1/2 cup water in 1.5 litre covered casserole dish. Stir halfway through cooking. | 2~3 minutes |
| Carrots, Fresh, Sliced | 200g | 2 ~ 3 | Add 1/4 cup water in 1.5 litre covered casserole dish. Stir halfway through cooking. | 2~3 minutes |
| Cauliflower, Fresh, Whole | 450g | 5 ~ 7 | Trim. Add 1/4 cup water in 1.5 litre covered casserole dish. Stir halfway through cooking. | 2~3 minutes |
| Fresh, Flowerettes Celery, Fresh, Sliced | 2 cups 4 cups | 11 ~ 16 | Slice. Add 1/2 cup water in 1.5 litre covered casserole dish. Stir halfway through cooking. | 2~3 minutes |

| Vegetable | Amount | Cook time (at HIGH) | Instructions | Standing Time |
|--|--------------------------|-----------------------------|--|------------------|
| Corn, Fresh | 2 ears | 4 ~ 8 | Husk. Add 2 tbsp water in 1.5 litre baking dish. Cover. | 2~3 minutes |
| Mushrooms, Fresh, Sliced | 230g | 1 1/2 ~ 2 1/2 | Place mushrooms in 1.5 litre covered casserole dish. Stir halfway through cooking. | 2~3 minutes |
| Parsnips, Fresh, Sliced | 450g | 4 ~ 7 | Add 1/2 cup water in 1.5 litre covered casserole dish. Stir halfway through cooking. | 2~3 minutes |
| Peas, Green, Fresh | 4 cups | 6 ~ 9 | Add 1/2 cup water in 1.5 litre covered casserole dish. Stir halfway through cooking. | 2~3 minutes |
| Sweet Potatoes Whole Baking (170~230g each) | 2 medium 4 medium | 4 ~ 9 6~ 12 | Pierce potatoes several times with fork. Place on 2 paper towels. Turn over halfway through cooking. | 2~3 minutes |
| White potatoes, Whole Baking (170~230g each) | 2 potatoes 4 potatoes | 5 1/2 ~ 7 1/2 9 1/2 ~ 14 | Pierce potatoes several times with fork. Place on 2 paper towels. Turn over halfway through cooking. | 2~3 minutes |
| Spinach, Fresh, Leaf | 450g | 4 1/2 ~ 7 1/2 | Add 1/2 cup water in 2 litre covered casserole dish. | 2~3 minutes |
| Courgette, Fresh, Sliced | 450g | 4 1/2 ~ 7 1/2 | Add 1/2 cup water in 1.5 litre covered casserole dish. Stir halfway through cooking. | 2~3 minutes |
| Courgette, Fresh, Whole | 450g | 6 ~ 9 | Pierce. Place on 2 paper towels. Turn courgette over and rearrange halfway through cooking. | 2~3 minutes |

Grill Cooking

Guide

Directions for grilling meat on grill

- Trim excess fat from meat. Cut fat, making sure you do not cut into the lean. (This will stop the fat curling.)
- Arrange on the rack. Brush with melted butter or oil.
- Halfway through, turn the meat over.

| | | | |
|----------------------------------|---------------------|----------------|--|
| Beefburgers | 50g x 2 100g x 2 | 13-16 19-23 | Baste with oil or melted butter. Thin items should be placed on the grill rack. Thick items can be placed on to a drip tray. Turn food over after half the cooking time. |
| Beefsteaks (2.5cm (1") thick) | | | |
| Rare | 230g x 2 | 18-20 | |
| Medium | 230g x 2 | 22-24 | |
| Well | 230g x 2 | 26-28 | |
| Pork chops (2.5cm (1") thick) | 230g x 2 | 27-32 | |
| Lamb chops (2.5cm (1") thick) | 230g x 2 | 25-32 | |
| Sausages (2.5cm (1") thick) | 230g | 13-16 | Turn frequently. |

Directions for grilling fish and seafood

Place fish and seafood on the rack. Whole fish should be scored diagonally on both sides before grilling. Brush fish and seafood with melted butter, margarine or oil before and during cooking. This helps stop the fish drying out. Grill for times recommended in the chart. Whole fish and fish steaks should be carefully turned over halfway through grilling time. If desired thick fillets can also be turned halfway.

| | | | |
|-----------------------------------|-----------------------|----------------|---|
| Fish fillets 1 cm (1/2") thick | 230g | 17-21 | Brush with melted butter and turn over halfway through cooking. |
| 1.5cm (1/2") thick | 230g | 20-24 | |
| Fish steaks 2.5 cm (1") thick | 230g | 24-28 | |
| Whole fish | 225-350g each 450g | 16-20 24-28 | Allow extra time for thick and oily fish. |
| Scallops | 450g | 16-20 | Baste well during cooking. |
| Prawns uncooked | 450g | 16-20 | |

WARNING

Please ensure cooking times are correctly set as over cooking may result in FIRE and subsequent DAMAGE to the OVEN.

- 1 Do not attempt to tamper with, or make any adjustments or repairs to the door, control panel, safety interlock switches or any other part of the oven. It is hazardous for anyone to carry out any service or repair operation which involves the removal of any cover which gives protection against exposure to microwave energy. Repairs should only be undertaken by a qualified service technician.
- 2 Do not operate the oven when empty. It is best to leave a glass of water in the oven when not in use. The water will safely absorb all microwave energy, if the oven is accidentally started.
- 3 Do not dry clothes in the microwave oven, which may become carbonized or burned if heated too long.
- 4 Do not cook food wrapped in paper towels, unless your cook book contains instructions, for the food you are cooking.
- 5 Do not use newspaper in place of paper towels for cooking.
- 6 Do not use wooden containers. They may heat-up and char. Do not use ceramic containers which have metallic (e.g. gold or silver) inlays. Always remove metal twist ties. Metal objects in the oven may arc, which can cause serious damage.
- 7 Do not operate the oven with a kitchen towel, a napkin or any other obstruction between the door and the front edges of the oven, which may cause microwave energy leakage.
- 8 Do not use recycled paper products since they may contain impurities which may cause sparks and/ or fires when used in cooking.
- 9 Do not rinse the turntable by placing it in water just after cooking. This may cause breakage or damage.
- 10 Small amounts of food require shorter cooking or heating time. If normal times are allowed they may overheat and burn.
- 11 Be certain to place the oven so the front of the door is 8 cm or more behind the edge of the surface on which it is placed, to avoid accidental tipping of the appliance.
- 12 Before cooking, pierce the skin of potatoes, apples or any such fruit or vegetable.
- 13 Do not cook eggs in their shell. Pressure will build up inside the egg which will burst.
- 14 Do not attempt deep fat frying in your oven.
- 15 Remove the plastic wrapping from food before cooking or defrosting. Note though that in some cases food should be covered with plastic film, for heating or cooking.
- 16 If the oven door or door seals are damaged, the oven must not be operated until it has been repaired by a qualified service technician.
- 17 If smoke is observed, switch off or disconnect the oven from the power supply and keep the oven door closed in order to stifle any flames.
- 18 When food is heated or cooked in disposable containers of plastic, paper or other combustible materials, check the oven frequently due to the possibility of ignition.
- 19 Only allow children to use the oven without supervision when adequate instructions have been given so that the child is able to use the oven in a safe way and understands the hazards of improper use.
- 20 Liquids or other foods must not be heated in sealed containers since they are liable to explode.

Microwave-safe Utensils

Never use metal or metal trimmed utensils in your microwave oven

Microwaves cannot penetrate metal. They will bounce off any metal object in the oven and cause arcing, an alarming phenomenon that resembles lightning.

Most heat resistant non metallic cooking utensils are safe for use in your microwave oven. However, some may contain materials that render them unsuitable as microwave cookware. If you have any doubts about a particular utensil, there's a simple way to find out if it can be used in your microwave oven.

Place the utensil in question next to a glass bowl filled with water in the microwave oven. Microwave at power HIGH for 1 minute. If the water heats up but the utensil remains cool to the touch, the utensil is microwave-safe. However, if the water does not change temperature but the utensil becomes warm, microwaves are being absorbed by the utensil and it is not safe for use in the microwave oven. You probably have many items on hand in your kitchen right now that can be used as cooking equipment in your microwave oven. Just read through the following checklist.

Dinner plates

Many kinds of dinner-ware are microwave-safe. If in doubt consult the manufacturer's literature or perform the microwave test.

Glassware

Glassware that is heat-resistant is microwave-safe. This would include all brands of oven tempered glass cookware. However, do not use delicate glassware, such as tumblers or wine glasses, as these might shatter as the food warms.

Plastic storage containers

These can be used to hold foods that are to be quickly reheated. However, they should not be used to hold foods that will need considerable time in the oven as hot foods will eventually warp or melt plastic containers.

Paper

Paper plates and containers are convenient and safe to use in your microwave oven, provided that the cooking time is short and foods to be cooked are low in fat and moisture. Paper towels are also very useful for wrapping foods and for lining baking trays in which greasy foods such as bacon are cooked. In general, avoid colored paper products as the colour may run. Some recycled paper products may contain impurities which could cause arcing or fires when used in the microwave oven.

Plastic cooking bags

Stirring is one of the most important of all microwaving techniques. In conventional cooking, foods are stirred for the purpose of blending. Microwaved foods, however, are stirred in order to spread and redistribute heat. Always stir from the outside towards the centre as the outside of the food heats first.

Plastic microwave cookware

A variety of shapes and sizes of microwave cookware are available. For the most part, you can probably use items you already have on hand rather than investing in new kitchen equipment.

Pottery, stoneware and ceramic

Containers made of these materials are usually fine for use in your microwave oven, but they should be tested to be sure.

CAUTION

Some items with high lead or iron content are not suitable for cooking utensils.

Utensils should be checked to ensure that they are suitable for use in microwave ovens.

Food characteristics & Microwave cooking

Keeping an eye on things

The recipes in the book have been formulated with great care, but your success in preparing them depends on how much attention you pay to the food as it cooks. Always watch your food while it cooks. Your microwave oven is equipped with a light that turns on automatically when the oven is in operation so that you can see inside and check the progress of your food. Directions given in recipes to elevate, stir, and the like should be thought of as the minimum steps recommended. If the food seems to be cooking unevenly, simply make the necessary adjustments you think appropriate to correct the problem.

Factors affecting microwave cooking times

Many factors affect cooking times. The temperature of ingredients used in a recipe makes a big difference in cooking times. For example, a cake made with ice-cold butter, milk, and eggs will take considerably longer to bake than one made with ingredients that are at room temperature. All of the recipes in this book give a range of cooking times. In general, you will find that the food remains under-cooked at the lower end of the time range, and you may sometimes want to cook your food beyond the maximum time given, according to personal preference. The governing philosophy of this book is that it is best for a recipe to be conservative in giving cooking times. While overcooked food is ruined for good. Some of the recipes, particularly those for bread, cake, and custards, recommend that food be removed from the oven when they are slightly undercooked. This is not a mistake. When allowed to stand, usually covered, these foods will continue to cook outside of the oven as the heat trapped within the outer portions of the food gradually travels inward. If the food is left in the oven until it is cooked all the way through, the outer portions will become overcooked or even burnt. You will become increasingly skilful in estimating both cooking and standing times for various foods.

Density of food

Light, porous food such as cakes and breads cook more quickly than heavy, dense foods such as roasts and casseroles. You must take care when microwaving porous food that the outer edges do not become dry and brittle.

Height of food

The upper portion of tall food, particularly roasts, will cook more quickly than the lower portion. Therefore, it is wise to turn tall food during cooking, sometimes several times.

Moisture content of food

Since the heat generated from microwaves tends to evaporate moisture, relatively dry food such as roasts and some vegetables should either be sprinkled with water prior to cooking or covered to retain moisture.

Bone and fat content of food

Bones conduct heat and fat cooks more quickly than meat. Care must be taken when cooking bony or fatty cuts of meat that they do not cook unevenly and do not become overcooked.

Quantity of food

The number of microwaves in your oven remains constant regardless of how much food is being cooked. Therefore, the more food you place in the oven, the longer the cooking time. Remember to decrease cooking times by at least one third when halving a recipe.

Shape of food

Microwaves penetrate only about 2 cm into food, the interior portion of thick foods are cooked as the heat generated on the outside travels inward. Only the outer edge of food is cooked by microwave energy; the rest is cooked by conduction. The worst possible shape for a food that is to be microwaved is a thick square. The corners will burn long before the centre is even warm. Round thin foods and ring shaped foods cook successfully in the microwave.

Covering

A cover traps heat and steam which causes food to cook more quickly. Use a lid or microwave cling film with a corner folded back to prevent splitting.

Browning

Meats and poultry that are cooked fifteen minutes or longer will brown lightly in their own fat. Foods that are cooked for a shorter period of time may be brushed with a browning sauce such as Worcestershire sauce, soy sauce or barbecue sauce to achieve an appetizing colour. Since relatively small amounts of browning sauces are added to food the original flavour of the recipe is not altered.

Covering with greaseproof paper

Greaseproofing effectively prevents spattering and helps food retain some heat. But because it makes a looser cover than a lid or clingfilm, it allows the food to dry out slightly.

Arranging and spacing

Individual foods such as baked potatoes, small cakes and hors d'oeuvres will heat more evenly if placed in the oven an equal distance apart, preferably in a circular pattern. Never stack foods on top of one another.

Food characteristics & Microwave cooking

Stirring

Stirring is one of the most important of all microwaving techniques. In conventional cooking, food is stirred for the purpose of blending. Microwaved food, however, is stirred in order to spread and redistribute heat. Always stir from the outside towards the centre as the outside of the food heats first.

Turning over

Large, tall foods such as roasts and whole chickens should be turned so that the top and bottom will cook evenly. It is also a good idea to turn cut up chicken and chops.

Placing thicker portions facing outwards

Since microwaves are attracted to the outside portion of food, it makes sense to place thicker portions of meat, poultry and fish to the outer edge of the baking dish. This way, thicker portions will receive the most microwave energy and the food will cook evenly.

Shielding

Strips of aluminium foil (which block microwaves) can be placed over the corners or edges of square and rectangular foods to prevent those portions from overcooking. Never use too much foil and make sure the foil is secured to the dish or it may cause 'arcing' in the oven.

Elevating

Thick or dense foods can be elevated so that microwaves can be absorbed by the underside and centre of the foods.

Piercing

Foods enclosed in a shell, skin or membrane are likely to burst in the oven unless they are pierced prior to cooking. Such foods include yolks and whites of eggs, clams and oysters and whole vegetables and fruits.

Testing if cooked

Food cooks so quickly in a microwave oven, it is necessary to test it frequently. Some foods are left in the microwave until completely cooked, but most foods, including meats and poultry, are removed from the oven while still slightly undercooked and allowed to finish cooking during standing time. The internal temperature of foods will rise between 5°F (3°C) and 15°F (8°C) during standing time.

Standing time

Foods are often allowed to stand for 3 to 10 minutes after being removed from the microwave oven. Usually the foods are covered during standing time to retain heat unless they are supposed to be dry in texture (some cakes and biscuits, for example). Standing allows foods to finish cooking and also helps flavour blend and develop.

To Clean Your Oven

1 Keep the inside of the oven clean

Food spatters or spilled liquids stick to oven walls and between seal and door surface. It is best to wipe up spills with a damp cloth right away. Crumbs and spillovers will absorb microwave energy and lengthen cooking times. Use a damp cloth to wipe out crumbs that fall between the door and the frame. It is important to keep this area clean to assure a tight seal. Remove greasy spatters with a soapy cloth then rinse and dry. Do not use harsh detergent or abrasive cleaners. The glass tray can be washed by hand or in the dishwasher.

2 Keep the outside of the oven clean

Clean the outside of your oven with soap and water then with clean water and dry with a soft cloth or paper towel. To prevent damage to the operating parts inside the oven, the water should not be allowed to seep into the ventilation openings. To clean control panel, open the door to prevent oven from accidentally starting, and wipe a damp cloth followed immediately by a dry cloth. Press STOP/CLEAR after cleaning.

3 If steam accumulates inside or around the outside of the oven door, wipe the panels with a soft cloth. This may occur when the microwave oven is operated under high humidity conditions and in no way indicates a malfunction of the unit.

4 The door and door seals should be kept clean. Use only warm, soapy water, rinse then dry thoroughly.

DO NOT USE ABRASIVE MATERIALS, SUCH AS CLEANING POWDERS OR STEEL AND PLASTIC PADS.

Metal parts will be easier to maintain if wiped frequently with a damp cloth.

Questions & Answers

Q What's wrong when the oven light will not glow?

- A There may be several reasons why the oven light will not glow.
Light bulb has blown
Door is not closed

Q Does microwave energy pass through the viewing screen in the door?

- A No. The holes, or ports, are made to allow light to pass; they do not let microwave energy through.

Q Why does the beep tone sound when a pad on the Control Panel is touched?

- A The beep tone sounds to assure that the setting is being properly entered.

Q Will the microwave oven be damaged if it operates empty?

- A Yes Never run it empty or without the glass tray.

Q Why do eggs sometimes pop?

- A When baking, frying, or poaching eggs, the yolk may pop due to steam build up inside the yolk membrane. To prevent this, simply pierce the yolk before cooking. Never microwave eggs in the shell.

Q Why is standing time recommended after microwave cooking is over?

- A After microwave cooking is finished, food keeps on cooking during standing time. This standing time finishes cooking evenly throughout the food. The amount of standing time depends on the density of the food.

Q Is it possible to pop corn in a microwave oven?

- A Yes, if using one of the two methods described below
- 1 Popcorn-popping utensils designed specifically for microwave cooking.
 - 2 Prepackaged commercial microwave popcorn that contains specific times and power outputs needed for an acceptable final product.

FOLLOW EXACT DIRECTIONS GIVEN BY EACH MANUFACTURER FOR THEIR POPCORN PRODUCT. DO NOT LEAVE THE OVEN UNATTENDED WHILE THE CORN IS BEING POPPED. IF CORN FAILS TO POP AFTER THE SUGGESTED TIMES, DISCONTINUE COOKING. OVERCOOKING COULD RESULT IN THE CORN CATCHING FIRE.

CAUTION

NEVER USE A BROWN PAPER BAG FOR POPPING CORN. NEVER ATTEMPT TO POP LEFTOVER KERNELS.

Q Why doesn't my oven always cook as fast as the cooking guide says?

- A Check your cooking guide again to make sure you've followed directions correctly, and to see what might cause variations in cooking time. Cooking guide times and heat settings are suggestions, chosen to help prevent overcooking, the most common problem in getting used to a microwave oven. Variations in the size, shape, weight and dimensions of the food require longer cooking time. Use your own judgement along with the cooking guide suggestions to test food condition, just as you would do with a conventional cooker.

Plug wiring information/

Technical Specifications

Warning

This appliance must be earthed

The wires in this mains lead are colored in accordance with the following codes
BLUE ~ Neutral
BROWN ~ Live
GREEN & YELLOW ~ Earth

As the colours of the wires in the mains lead of this appliance may not correspond with the coloured markings identifying the terminals in your plug proceed as follows:

The wire which is colored BLUE must be connected to the terminal which is marked with the letter N or Colored BLACK.

The wire which is colored BROWN must be connected to the terminal which is marked with the letter L or colored RED.

The wire which is colored GREEN & YELLOW or GREEN must be connected to the terminal which is marked with the letter E or .

If the supply cord is damaged, it must be replaced by the manufacturer or its service agent or a similarly qualified person in order to avoid a hazard;

Technical Specification

| | MH-607Y/ MH-607YS | MH-667Y/ MH-667YS MG-567Y/ MG-567YS |
|---------------------|----------------------------------|--|
| Power Input | 230 V AC / 50Hz | 230 V AC / 50Hz |
| Output | 800 W (IEC60705 rating standard) | 900 W (IEC60705 rating standard) |
| Microwave Frequency | 2,450 MHz | 2,450 MHz |
| Outside Dimension | 485mm(W) X 280mm(H) X 375mm(D) | 512mm(W) X 307mm(H) X 420mm(D) |
| Power Consumption | Microwave | 1,200 Watts |
| | Grill | 1,100 Watts |
| | Combination | 2,250 Watts |



P/ No: 3828W5A2234
Artikelnummer: 3828W5A2234
P/ No: 3828W5A2234
P/ nr.: 3828W5A2234
P/ No: 3828W5A2234