



Please read this installation manual completely before installing the product. Installation work must be performed in accordance with the national wiring standards by authorized personnel only.

Please retain this installation manual for future reference after reading it thoroughly.

BUILT - IN DUCT - LOW STATIC Original instruction




P/NO · MEI 69/18070/



# TABLE OF CONTENTS

Installation Requirements	Required Parts	Required Tools
Features3		
Safety Precautions4		
Installation	☐ Four type "A" screws ☐ Connecting cable	☐ Level gauge ☐ Screw driver ☐ Flectric drill
Selection of the best location7		☐ Hole core drill
Ceiling dimension and hanging bolt location8	☐ Pipes: Gas side Liquid side (Refer to Product Data)	☐ Flaring tool set ☐ Specified torque wrenches (different depending on model No.) ☐ SpannerHalf union
Indoor Unit Installation9	☐ Insulation materials☐ Additional drain pipe	
Checking the Drainage10		☐ A glass of water☐ Screw driver
Drain Piping11		☐ Hexagonal wrench☐ Gas-leak detector☐ Vacuum pump
Dip Switch Setting13		☐ Gauge manifold
Group Control Setting14		☐ Owner's manual ☐ Thermometer
Model Designation19		
Airborne Noise Emission19		
Limiting concentration19		
How to Set E.S.P?20		

# **Features**



### **Installation Tool**

Name	Drain hose	Clamp metal Washer for hanging bracket		Clamp (Tie Wrap)	Insulation for fitting	(Other)
Quantity	1 EA	2 EA	8 EA	4 EA	1 SET	
Shape		Ö			for gas pipe for liquid pipe	Owner's manual     Installation manual

# **Safety Precautions**

To prevent injury to the user or other people and property damage, the following instructions must be followed.

■ Incorrect operation due to ignoring instruction will cause harm or damage. The seriousness is classified by the following indications.

**AWARNING** This symbol indicates the possibility of death or serious injury.

**ACAUTION** This symbol indicates the possibility of injury or damage to properties only.

■ Meanings of symbols used in this manual are as shown below.

	Be sure not to do.
0	Be sure to follow the instruction.

# **WARNING**

#### ■ Installation

Do not use a defective or underrated circuit breaker. Use this appliance on a dedicated circuit.

 There is risk of fire or electric shock.

# Install the panel and the cover of control box securely.

 There is risk of fire or electric shock

# Do not modify or extend the power cable.

 There is risk of fire or electric shock.

#### For installation, always contact the dealer or an Authorized Service Center.

• There is risk of fire, electric shock, explosion, or injury.

# For electrical work, contact the dealer, seller, a qualified electrician, or an Authorized Service Center.

 Do not disassemble or repair the product. There is risk of fire or electric shock

# Always install a dedicated circuit and breaker.

 Improper wiring or installation may cause fire or electric shock.

# Do not install, remove, or re-install the unit by yourself (customer).

 There is risk of fire, electric shock, explosion, or injury.

# Do not install the product on a defective installation stand.

 It may cause injury, accident, or damage to the product.

#### Always ground the product.

 There is risk of fire or electric shock.

# Use the correctly rated breaker or fuse.

 There is risk of fire or electric shock.

# Be cautious when unpacking and installing the product.

 Sharp edges could cause injury.
 Be especially careful of the case edges and the fins on the condenser and evaporator.

# Be sure the installation area does not deteriorate with age.

 If the base collapses, the air conditioner could fall with it, causing property damage, product failure, and personal injury. Do not turn on the breaker or power under condition that front panel, cabinet, top cover, control box cover are removed or opened.

· Otherwise, it may cause fire, electric shock, explosion or death.

Use a vacuum pump or Inert (nitrogen) gas when doing leakage test or air purge. Do not compress air or Oxygen and Do not use Flammable gases. Otherwise, it may cause fire or explosion.

· There is the risk of death, injury, fire or explosion.

### Operation

Do not let the air conditioner run for a long time when the humidity is very high and a door or a window is left open.

· Moisture may condense and wet or damage furniture.

Do not plug or unplug the power supply plug during operation.

· There is risk of fire or electric shock.

Do not allow water to run into electric parts.

· It may cause There is risk of fire, failure of the product, or electric shock.

When flammable gas leaks, turn off the gas and open a window for ventilation before turn the product on.

· Do not use the telephone or turn switches on or off. There is risk of explosion or fire.

Do not open the inlet grill of the product during operation. (Do not touch the electrostatic filter, if the unit is so equipped.)

· There is risk of physical injury, electric shock, or product failure. Take care to ensure that power cable could not be pulled out or damaged during operation.

· There is risk of fire or electric shock.

Do not touch(operate) the product with wet hands.

 There is risk of fire or electrical. shock.

Do not store or use flammable gas or combustibles near the product.

· There is risk of fire or failure of product.

If strange sounds, or small or smoke comes from product. Turn the breaker off or disconnect the power supply cable.

· There is risk of electric shock or fire.

When the product is soaked (flooded or submerged), contact an Authorized Service Center.

· There is risk of fire or electric shock.

Do not place anything on the power cable.

· There is risk of fire or electric shock.

Do not place a heater or other appliances near the power cable.

 There is risk of fire and electric shock.

Do not use the product in a tightly closed space for a long time.

· Oxygen deficiency could occur.

Stop operation and close the window in storm or hurricane. If possible, remove the product from the window before the hurricane arrives.

 There is risk of property damage. failure of product, or electric shock.

Be cautious that water could not enter the product.

· There is risk of fire, electric shock, or product damage.

Ventilate the product from time to time when operating it together with a stove, etc.

There is risk of fire or electric shock.

When the product is not be used for a long time, disconnect the power supply plug or turn off the breaker.

· There is risk of product damage or failure, or unintended operation.

Turn the main power off when cleaning or maintaining the product.

There is risk of electric shock.

Take care to ensure that nobody could step on or fall onto the outdoor unit.

· This could result in personal injury and product dam-

# **ACAUTION**

#### ■ Installation

Always check for gas (refrigerant) leakage after installation or repair of product.

 Low refrigerant levels may cause failure of product.

Do not install the product where the noise or hot air from the outdoor unit could damage the neighborhoods.

 It may cause a problem for your neighbors. Install the drain hose to ensure that water is drained away properly.

 A bad connection may cause water leakage.

Use two or more people to lift and transport the product.

· Avoid personal injury.

Keep level even when installing the product.

 To avoid vibration or water leakage.

Do not install the product where it will be exposed to sea wind (salt spray) directly.

 It may cause corrosion on the product.
 Corrosion, particularly on the condenser and evaporator fins, could cause product malfunction or inefficient operation.

### Operation

Do not expose the skin directly to cool air for long periods of time. (Don't sit in the draft.)

· This could harm to your health.

Use a soft cloth to clean. Do not use harsh detergents, solvents, etc.

 There is risk of fire, electric shock, or damage to the plastic parts of the product.

Always insert the filter securely. Clean the filter every two weeks or more often if necessary.

 A dirty filter reduces the efficiency of the air conditioner and could cause product malfunction or damage.

Use a firm stool or ladder when cleaning or maintaining the product.

· Be careful and avoid personal injury.

Do not use the product for special purposes, such as preserving foods, works of art, etc. It is a consumer air conditioner, not a precision refrigeration system.

There is risk of damage or loss of property.

Do not touch the metal parts of the product when removing the air filter. They are very sharp!

· There is risk of personal injury.

Do not insert hands or other objects through the air inlet or outlet while the product is operated.

 There are sharp and moving parts that could cause personal injury.

Replace the all batteries in the remote control with new ones of the same type. Do not mix old and new batteries or different types of batteries.

• There is risk of fire or explosion.

Do not block the inlet or outlet of air flow.

· It may cause product failure.

Do not step on or put anyting on the product. (outdoor units)

 There is risk of personal injury and failure of product.

Do not drink the water drained from the product.

 It is not sanitary and could cause serious health issues.

Do not recharge or disassemble the batteries.

Do not dispose of batteries in a fire

· They may burn or explode.

If the liquid from the batteries gets onto your skin or clothes, wash it well with clean water. Do not use the remote if the batteries have leaked.

 The chemicals in batteries could cause burns or other health hazards. If you eat the liquid from the batteries, brush your teeth and see doctor. Do not use the remote if the batteries have leaked.

 The chemicals in batteries could cause burns or other health hazards.

# Installation

# Selection of the best location

#### Indoor unit

Install the air conditioner in the location that satisfies the following conditions.


- · The place shall easily bear a load exceeding four times the indoor unit's weight.
- The place shall be able to inspect the unit as the
- The place where the unit shall be leveled.
- The place shall easily connect with the outdoor
- The place where the unit is not affected by an electrical noise.
- The place where air circulation in the room will be good.
- · There should not be any heat source or steam near the unit


Confirm the positional relationship between the unit and suspension bolts.


· Installation the ceiling opening to clean the filter or service under the product.

(Length: mm)

Capacity(Btu/h)	А	В
B3	600	900
B4	600	1100









· Refer to Suction grille and Suction canvas installation manual for detail installation of Builtin duct type

**Built-in Duct type** 





# Ceiling dimension and hanging bolt location

#### Installation of Unit

Install the unit above the ceiling correctly.

### CASE 1

#### POSITION OF SUSPENSION BOLT

- Apply a joint-canvas between the unit and duct to absorb unnecessary vibration.
- · Apply a filter Accessory at air return hole.

#### (Unit:mm)


Dimension Capacity(Btu/h)	А	В	С	D	Е	F	G	Н	I	J
В3	850	900	383	575	93	190	21	795	163	820
B4	1130	1180	383	575	93	190	21	1065	163	1100


#### CASE 2

 Install the unit leaning to a drainage hole side as a figure for easy water drainage.

#### POSITION OF CONSOLE BOLT


- A place where the unit will be leveled and that can support the weight of the unit.
- A place where the unit can withstand its vibration.
- A place where service can be easily performed.






### Indoor Unit Installation

- · Select and mark the position for fixing bolts.
- · Drill the hole for set anchor on the face of ceilina.



**CAUTION: Tighten the nut and bolt** to prevent unit falling.


- Insert the set anchor and washer onto the suspension bolts for locking the suspension bolts on the ceiling.
- · Mount the suspension bolts to the set anchor firmly.
- · Secure the installation plates onto the suspension bolts (adjust level roughly) using nuts, washers and spring washers.



# Wiring Connection

Connect the wires to the terminals on the control board individually according to the outdoor unit connec-

· Ensure that the color of the wires of outdoor unit and the terminal No. are the same as those of indoor unit respectively.






WARNING: Make sure that the screws of the terminal are free from looseness.

#### Clamping of cables

- 1) Arrange 2 power cables on the control panel.
- 2) First, fasten the steel clamp with a screw to the inner boss of control panel.
- 3) For the cooling model, fix the other side of the clamp with a screw strongly. For the heat pump model, put the 0.75mm<sup>2</sup> cable(thinner cable) on the clamp and tighten it with a plastic clamp to the other boss of the control panel.



CAUTION: The Power cord connected to the unit should be selected according to the following specifications.




# Checking the Drainage

#### 1. Remove the Air Filter.

### 2. Check the drainage.

- Spray one or two glasses of water upon the evaporator.
- Ensure that water flows drain hose of indoor unit without any leakage.




### **CAUTION**

- 1. Install declination of the indoor unit is very important for the drain of the duct type air conditioner
- 2. Minimum thickness of the insulation for the connecting pipe shall be 19mm.

#### Front of view


• The unit must be horizontal or declined to the drain hose connected when finished installation.



## Drain Piping

- Drain piping must have down-slope (1/50 to 1/100): be sure not to provide up-and-down slope to prevent reversal flow.
- · During drain piping connection, be careful not to exert extra force on the drain port on the indoor unit.
- · The outside diameter of the drain connection on the indoor unit is 32mm.


Piping material: Polyvinyl chloride pipe VP-25 and pipe fittings. Be sure to install heat insulation on the drain piping!



Heat insulation material: Polyethylene foam with thickness more than 8 mm.

#### **Drain test**

The air conditioner uses a drain pump to drain water. Use the following procedure to test the drain pump operation:



- · Connect the main drain pipe to the exterior and leave it provisionally until the test comes to an end.
- · Feed water to the flexible drain hose and check the piping for leakage.
- · Be sure to check the drain pump for normal operating and noise when electrical wiring is complete.
- When the test is complete, connect the flexible drain hose to the drain port on the indoor unit.



#### **CAUTION:**

After the confirmation of the above conditions, prepare the wiring as follows:

- 1) Never fail to have an individual power specialized for the air conditioner. As for the method of wiring, be guided by the circuit diagram posted on the inside of control box cover.
- 2) Provide a circuit breaker switch between power source and the unit.
- 3) The screws which fasten the wiring in the casing of electrical fittings are liable to come loose from vibrations to which the unit is subjected during the course of transportation. Check them and make sure that they are all tightly fastened. (If they are loose, it could give rise to burn-out of the wires.)
- 4) Specification of power source
- 5) Confirm that electrical capacity is sufficient.
- 6) Be sure that the starting voltage is maintained at more than 90 percent of the rated voltage marked on the name plate.
- 7) Confirm that the cable thickness is as specified in the power sources specification. (Particularly note the relation between cable length and thickness.)
- 8) Never fail to equip a leakage breaker where it is wet or moist.
- 9) The following troubles would be caused by voltage drop-down.
  - Vibration of a magnetic switch, damage on the contact point, fuse breaking, disturbance by the normal function of an overload protection device.
  - · Proper starting power is not given to the compressor.

#### HAND OVER

Teach the customer the operation and maintenance procedures, using the operation manual. (air filter cleaning, temperature control, etc.)

# Dip Switch Setting

#### 1. Indoor Unit

	Function	Description	Setting Off	Setting On	Default
SW1	Communication	N/A (Default)	-	-	Off
SW2	Cycle	N/A (Default)	-	-	Off
SW3	Group Control	Selection of Master or Slave	Master	Slave	Off
SW4	Dry Contact Mode	Selection of Dry Contact Mode	Wired/Wireless remote controller selection of Manual or Auto operation Mode	Auto	Off
SW5	Installation	Fan continuous operation	Continuous operation Removal	-	Off
SW6	Heater linkage	N/A	-	-	Off
	Ventilator link- age	Selection of Ventilator linkage	Linkage Removal	Working	
SW7	Vane selection (Console)	Selection of up/down side Vane	Up side + Down side Vane	Up side Vane Only	Off
	Region selection	Selection tropical region	General model	Tropical model	
SW8	Etc.	Spare	-	-	Off




## **A** CAUTION


For Multi V Models, DIP switch 1, 2, 6, 8 must be set OFF.

#### 2. Outdoor Unit

In case that the products meet specific conditions, "Auto addressing" function can start automatically with the improved speed by turning the DIP switch #3 of the outdoor unit and resetting the power.

- \* Specific conditions:
- All names of the indoor units are ARNU\*\*\*\*4.
- The serial number of Multi V super IV (outdoor units) is after October 2013.






**Outdoor Unit PCB** 

**Outdoor Unit DIP Switch** 

### Group Control Setting

#### 1. Group Control 1

#### ■ Wired remote controller 1 + Standard Indoor Units



#### ■ DIP Switch in PCB

- **1 Master Setting** 
  - No. 3 Off



# Slave SettingNo. 3 On

DN KSD08H

Indoor Unit DIP Switch

Some products have no DIP switch on PCB. It is possible to set indoor units to Master or Slave by using the wireless remote controller instead of DIP switch.

For the details of the setting, please refer to the manual of the wireless remote controller.

- 1. It is possible to 16 indoor units(Max.) by one wired remote controller.
  - Set only one indoor unit to Master, set the others to Slave.
- 2. It is possible to connect with every type of indoor units.
- 3. It is possible to use wireless remote controller at the same time.
- 4. It is possible to connect with Dry Contact and Central controller at the same time.
  - The Master indoor unit is possible to recognize Dry Contact and Central Controller only.
- In case that any error occurs at indoor unit, the error code is displayed on the wired remote controller.


It is possible to control the other indoor units except the error units.

- \* It is possible to connect indoor units since Feb. 2009.
- \* It can be the cause of malfuctions when there is no setting of master and slave.
- \* In case of Group Control, it is possible to use following functions.
  - Selection of operation, stop or mode
  - Temperature setting and room temperature check
  - Current time change
  - Control of flow rate (High/Middle/Low)
  - Reservation settings

It is not possible to use some functions.

### 2. Group Control 2


#### ■ Wired remote controllers + Standard Indoor Units



- # It is possible to control 16 indoor units(Max.) with the master wired remote control.
- \* Other than those, it is same with the Group Control 1.

#### 3. Group Control 3

#### ■ Mixture connection with indoor units and Fresh Air Intake Unit



- # In case of connecting with standard indoor unit and Fresh Air Intake Unit, separate Fresh Air Intake Unit with standard units. (N, M ≤ 16) (Because setting temperature are different.)

  # In case of connecting with standard indoor unit and Fresh Air Intake Unit, separate Fresh Air Intake Unit with standard units.


  # In case of connecting with standard indoor unit and Fresh Air Intake Unit, separate Fresh
- \* Other than those, it is same with Group Control 1.



\* FAU : Fresh Air Intake Unit Standard: Standard Indoor Unit

#### 4. 2 Remote Control


#### ■ Wired remote controller 2 + Indoor unit 1



- 1. It is possible to connect two wired remote controllers (Max.) with one indoor unit. Set only one indoor unit to Master, set the others to Slave. Set only one wired remote controller to Master, set the others to Slave.
- 2. Every types of indoor unit is possible to connect two remote controller.
- 3. It is possible to use wireless remote controller at the same time.
- 4. It is possible to connect with Dry Contact and Central controller at the same time.
- 5. In case that any error occurs at indoor unit, the error code is displayed on the wired remote controller.
- 6. There isn't limits of indoor unit function.

#### 5. Accessories for group control setting

It is possible to set group control by using below accessories.






## **A** CAUTION

· Apply totally enclosed noncombustible conduit in case of local building code Requiring plenum cable usage.

## **Model Designation**



#### Airborne Noise Emission

The A-weighted sound pressure emitted by this product is below 70 dB.

\*\* The noise level can vary depending on the site.

The figures quoted are emission level and are not necessarily safe working levels. Whilst there is a correlation between the emission and exposure levels, this cannot be used reliably to determine whether or not further precautions are required. Factor that influence the actual level of exposure of the workforce include the characteristics of the work room and the other sources of noise, i.e. the number of equipment and other adjacent processes and the length of time for which an operator exposed to the noise. Also, the permissible exposure level can vary from country to country. This information, however, will enable the user of the equipment to make a better evaluation of the hazard and risk.

# Limiting concentration

Limiting concentration is the limit of Freon gas concentration where immediate measures can be taken without hurting human body when refrigerant leaks in the air. The limiting concentration shall be described in the unit of kg/m³ (Freon gas weight per unit air volume) for facilitating calculation

Limiting concentration: 0.44kg/m3(R410A)

#### ■ Calculate refrigerant concentration

Total amount of replenished refrigerant in refrigerant facility (kg) Refrigerant concentration = Capacity of smallest room where indoor unit is installed (m<sup>3</sup>)

# How to Set E.S.P?

ARNU07GB3G4+PBSGB30(Acc'y), PBSC30(Acc'y) ARNU09GB3G4+PBSGB30(Acc'y), PBSC30(Acc'y) ARNU12GB3G4+PBSGB30(Acc'y), PBSC30(Acc'y) ARNU15GB3G4+PBSGB30(Acc'y), PBSC30(Acc'y)

(Unit: CMM)

Cotting Value	Static Pressure(mmAq(Pa))						
Setting Value	0(0)	1(10)	2(20)	3(30)	4(40)		
60	6.29	3.03	0.93	-	-		
65	6.61	4.84	1.52	-	-		
70	7.69	5.64	2.18	0.79	•		
75	8.19	6.28	2.81	0.85	•		
80	8.91	7.43	4.96	1.58	•		
85	9.51	8.14	5.91	2.75	0.95		
90	10.21	8.76	6.79	3.41	1.36		
95	10.83	9.62	8.11	5.48	2.61		
100	11.31	10.55	9.02	6.12	3.31		
105	11.84	11.19	9.99	8.28	5.32		
110	12.68	11.88	10.38	9.16	6.92		
115	13.19	12.22	11.55	10.21	8.23		

### ARNU18GB4G4+PBSGB40(Acc'y), PBSC40(Acc'y) ARNU24GB4G4+PBSGB40(Acc'y), PBSC40(Acc'y)

(Unit: CMM)

Setting Value	Static Pressure(mmAq(Pa))						
	0(0)	1(10)	2(20)	3(30)	4(40)		
75	10.32	7.68	3.55	-	-		
80	11.06	8.77	4.71	1.38	-		
85	11.84	10.02	6.95	2.16	-		
90	12.73	10.74	8.26	4.73	1.25		
95	13.47	12.13	9.93	6.74	2.73		
100	14.16	13.25	10.51	8.41	3.65		
105	15.29	14.11	12.31	9.83	6.21		
110	16.09	14.77	13.49	10.39	8.32		
115	16.91	15.88	14.48	12.77	9.92		
120	17.81	16.88	15.15	13.98	10.85		
125	18.55	17.84	16.12	15.13	12.97		
130	19.01	18.55	17.33	16.28	14.59		

Note: 1. The above table shows the correlation between the air rates and E.S.P.

Make sure to check and adjust E.S.P (external static pressure) value after the installation of the product. Otherwise, there is a risk of weak cooling/heating and condensed water discharge/drop.

