



Please read this installation manual completely before installing the product. Installation work must be performed in accordance with the national wiring standards by authorized personnel only.

Please retain this installation manual for future reference after reading it thoroughly.

Floor Standing Concealed Floor Standing

Original instruction



http://www.lghvac.com www.lg.com


Floor Standing Concealed Floor Standing Type Indoor Unit Installation Manual

TABLE OF CONTENTS


Installation Requirements	Required Parts	Required Tools	
Features3			
Safety Precautions4			
Installation	☐ Four type "A" screws	☐ Level gauge ☐ Screw driver	
Selection the best location7	☐ Connecting cable	☐ Electric drill☐ Hole core drill☐	
How to connect wirings9	☐ Pipes: Gas side Liquid side	☐ Flaring tool set☐ Specified torque wrenches	
Wiring Connection9	(Refer to Product Data) ☐ Insulation materials	(different depending on model No.) ☐ SpannerHalf union	
Indoor Unit Drain Piping10	☐ Additional drain pipe		
Dip Switch Setting13		☐ A glass of water☐ Screw driver	
Group Control Setting14		☐ Hexagonal wrench☐ Gas-leak detector☐ Vacuum pump☐	
Model Designation18		☐ Gauge manifold	
Airborne Noise Emission18		☐ Owner's manual☐ Thermometer	
Limiting concentration18			

Features

[CEA/CFA Type]



[CEU/CFU Type]



Installation Tool

Name	Drain hose	Screw	Insulation for fitting	Clamp (Tie Wrap)	Conduit mounting plate	(Other)
Quantity	1 EA	4 EA	1 each.	8 EA	1 EA	• Owner's
Shape		F	for gas pipe for liquid pipe		0	manual • Installation manual

Safety Precautions

To prevent injury to the user or other people and property damage, the following instructions must be followed.

■ Incorrect operation due to ignoring instruction will cause harm or damage. The seriousness is classified by the following indications.

▲ WARNING This symbol indicates the possibility of death or serious injury. **▲ CAUTION** This symbol indicates the possibility of injury or damage to properties only.

Meanings of symbols used in this manual are as shown below.

\bigcirc	Be sure not to do.
0	Be sure to follow the instruction.



Installation

- · Do not use a defective or underrated circuit breaker. Use this appliance on a dedicated circuit.
- There is risk of fire or electric shock.
- · For electrical work, contact the dealer, seller, a qualified electrician, or an Authorized Service Center.
- Do not disassemble or repair the product. There is risk of fire or electric shock.
- · Always ground the product.
 - There is risk of fire or electric shock.
- · Install the panel and the cover of control box securely.
- There is risk of fire or electric shock.
- · Always install a dedicated circuit and breaker.
 - Improper wiring or installation may cause fire or electric shock.
- · Use the correctly rated breaker or fuse.
- There is risk of fire or electric shock.
- · Do not modify or extend the power cable.
- There is risk of fire or electric shock.
- Do not install, remove, or re-install the unit by yourself (customer).
- There is risk of fire, electric shock, explosion, or injury.
- · Be cautious when unpacking and installing the product.
 - Sharp edges could cause injury. Be especially careful of the case edges and the fins on the condenser and evaporator.
- For installation, always contact the dealer or an Authorized Service Center.
 - There is risk of fire, electric shock, explosion, or injury.
- Do not install the product on a defective installation stand.
 - It may cause injury, accident, or damage to the product.
- · Be sure the installation area does not deteriorate with age.
- If the base collapses, the air conditioner could fall with it, causing property damage, product failure, and personal injury.
- Do not turn on the breaker or power under condition that front panel, cabinet, top cover, control box cover are removed or opened.
- Otherwise, it may cause fire, electric shock, explosion or death.

- · Use a vacuum pump or Inert (nitrogen) gas when doing leakage test or air purge. Do not compress air or Oxygen and Do not use Flammable gases. Otherwise, it may cause fire or explosion.
- There is the risk of death, injury, fire or explosion.

Operation

- · Do not let the air conditioner run for a long time when the humidity is very high and a door or a window is left open.
- Moisture may condense and wet or damage furniture.
- Take care to ensure that power cable could not be pulled out or damaged during operation.
 - There is risk of fire or electric shock.
- Do not place anything on the power cable.
- There is risk of fire or electric shock.
- Do not plug or unplug the power supply plug during operation.
- There is risk of fire or electric shock.
- Do not touch(operate) the product with wet hands.
- There is risk of fire or electrical shock.
- Do not place a heater or other appliances near the power cable.
 - There is risk of fire and electric shock.
- · Do not allow water to run into electric parts.
 - It may cause There is risk of fire, failure of the product, or electric shock.
- Do not store or use flammable gas or combustibles near the product.
- There is risk of fire or failure of product.
- Do not use the product in a tightly closed space for a long time.
- Oxygen deficiency could occur.
- · When flammable gas leaks, turn off the gas and open a window for ventilation before turn the product on.
- Do not use the telephone or turn switches on or off. There is risk of explosion or fire.
- If strange sounds, or small or smoke comes from product, Turn the breaker off or disconnect the power supply cable.
- There is risk of electric shock or fire.
- · Stop operation and close the window in storm or hurricane. If possible, remove the product from the window before the hurricane arrives.
- There is risk of property damage, failure of product, or electric shock.
- Do not open the inlet grill of the product during operation. (Do not touch the electrostatic filter, if the unit is so equipped.)
- There is risk of physical injury, electric shock, or product failure.
- · When the product is soaked (flooded or submerged), contact an Authorized Service Center.
 - There is risk of fire or electric shock.
- Be cautious that water could not enter the product.
 - There is risk of fire, electric shock, or product damage.
- Ventilate the product from time to time when operating it together with a stove, etc.
 - There is risk of fire or electric shock.
- Turn the main power off when cleaning or maintaining the product.
 - There is risk of electric shock.
- · When the product is not be used for a long time, disconnect the power supply plug or turn off the breaker.
- There is risk of product damage or failure, or unintended operation.
- Take care to ensure that nobody could step on or fall onto the outdoor unit.
 - This could result in personal injury and product damage.

ACAUTION

Installation

- · Always check for gas (refrigerant) leakage after installation or repair of product.
 - Low refrigerant levels may cause failure of product.
- · Install the drain hose to ensure that water is drained away properly.
- A bad connection may cause water leakage.
- · Keep level even when installing the product.
 - To avoid vibration or water leakage.
- Do not install the product where the noise or hot air from the outdoor unit could damage the neighborhoods.
- It may cause a problem for your neighbors.
- · Use two or more people to lift and transport the product.
- Avoid personal injury.
- Do not install the product where it will be exposed to sea wind (salt spray) directly.
 - It may cause corrosion on the product. Corrosion, particularly on the condenser and evaporator fins, could cause product malfunction or inefficient operation.

Operation

- Do not expose the skin directly to cool air for long periods of time. (Don't sit in the draft.)
 - This could harm to your health.
- Do not use the product for special purposes, such as preserving foods, works of art, etc. It is a consumer air conditioner, not a precision refrigeration system.
 - There is risk of damage or loss of property.
- · Do not block the inlet or outlet of air flow.
- It may cause product failure.
- Use a soft cloth to clean. Do not use harsh detergents, solvents, etc.
- There is risk of fire, electric shock, or damage to the plastic parts of the product.
- Do not touch the metal parts of the product when removing the air filter. They are very sharp!
- There is risk of personal injury.
- · Do not step on or put anyting on the product. (outdoor units)
- There is risk of personal injury and failure of product.
- · Always insert the filter securely. Clean the filter every two weeks or more often if necessary.
- A dirty filter reduces the efficiency of the air conditioner and could cause product malfunction or damage.
- Do not insert hands or other objects through the air inlet or outlet while the product is operated.
- There are sharp and moving parts that could cause personal injury.
- · Do not drink the water drained from the product.
- It is not sanitary and could cause serious health issues.
- · Use a firm stool or ladder when cleaning or maintaining the product.
- Be careful and avoid personal injury.
- Replace the all batteries in the remote control with new ones of the same type. Do not mix old and new batteries or different types of batteries.
 - There is risk of fire or explosion.
- · Do not recharge or disassemble the batteries. Do not dispose of batteries in a fire.
- They may burn or explode.
- If the liquid from the batteries gets onto your skin or clothes, wash it well with clean water. Do not use the remote if the batteries have leaked.
 - The chemicals in batteries could cause burns or other health hazards.
- If you eat the liquid from the batteries, brush your teeth and see doctor. Do not use the remote if the batteries have leaked.
 - The chemicals in batteries could cause burns or other health hazards.

Installation

Selection of the best location

Indoor unit

Install the air conditioner in the location that satisfies the following conditions.

- · The place shall easily bear a load exceeding four times the indoor unit's weight.
- Sufficient space should be available to inspect the unit as in the figure shown on the right.
- The place where the unit is installed shall be leveled.
- The place shall be suitable for easy connection of the indoor unit with the outdoor unit.
- The place where the unit is installed should not be affected by electrical noise.
- The place where air circulation in the room will be good.
- · There should not be any heat source or steam near the unit


Service space


Select an installation site where the following conditions are satisfied and that meets your customer's approval.

- · Where the floor is strong enough to bear the indoor unit weight.
- · Where the floor is not significantly inclined.
- · Where nothing blocks the air passage.
- · Where condensate can be properly drained.
- · Where sufficient clearance for installation and maintenance can be ensured.
- · Where there is no possibility of flammable gas
- Where optimum air distribution can be ensured.
- · Where piping between indoor and outdoor units is possible within the allowable limit (Refer to the installation manual of the outdoor unit.)
- · Keep the indoor and outdoor unit, power cable and transmission wiring, at least 1m from TVs and radios, to prevent distorted pictures and static.(Depending on the type and source of the electrical waves, static may be heard even when more than 1 m away.)

(Unit: mm)

		, ,
Type	A	В
CEU Type	788	1080
CFU Type	1066	1358





Leave sufficient clearance for air inlet and maintenance.


Bolt pitch

· Positioning of holes for fastening to the wall

(Unit:mm)


Capacity(Btu/h)	A
CE	858
CF	1136

- Use the installationmount for installation. Check whether the wall is strong enough to bear the weight of the unit or not. if there is a risk, reinforce the wall before installing the unit.
- The unit requires a minimum 100 mm clearance on the underside for air intake. Also, ensure the unit is level when installed so that drainage flows smoothly. If inclined, water can leak.
- 3. By a state of the wall, operating sound may become bigger.




How to open/close front panel

- · How to open/close the front panel
- (1) Open the lid of control panel (Both left and right)
- (2) Remove screws(Both left and right)
- (3) Lift the front panel of the unit
 - To close, perform the procedure in opposite order.



How to connect wirings


Remove the electric parts Box cover and connect the wiring



Wiring Connection

Connect the wires to the terminals on the control board individually according to the outdoor unit connection.

· Ensure that the color of the wires of outdoor unit and the terminal No. are the same as those of indoor unit respectively.





WARNING: Make sure that the screws of the terminal are free from looseness.


Clamping of cables

- 1) Arrange 2 power cables on the control panel.
- 2) First, fasten the steel clamp with a screw to the inner boss of control panel.
- 3) For the cooling model, fix the other side of the clamp with a screw strongly. For the heat pump model, put the AWG18 cable(thinner cable) on the clamp and tighten it with a plastic clamp to the other boss of the control panel.

HEAT INSULATION

- Use the heat insulation material for the refrigerant piping which has an excellent heat-resistance (over 120°C).
- 2. Precautions in high humidity circumstance: This air conditioner has been tested according to the "ISO Conditions with Mist" and confirmed that there is not any default. However, if it is operated for a long time in high humid atmosphere (dew point temperature: more than 23°C), water drops are liable to fall. In this case, add heat insulation material according to the following procedure:
 - Heat insulation material to be prepared... EPDM (Ethylene Propylene Diene Methylene)-over 120°C the heat-resistance temperature.
 - Add the insulation over 10mm thickness at high humidity environment.

After inspecting pipe joints for gas leakage, be sure to insulate wit the accessory joint insulation for fitting while referrig to the figure. (Fasten both ends with clamps)



Drain piping work


- Drain piping must have downward (1/50 to 1/100): be sure not to provide up-and-down slope to prevent reverse flow.
- · During drain piping connection, be careful not to exert extra force on the drain port on the indoor unit.
- The outside diameter of the drain connection on the inddor unit is 21mm.

Piping material: Polyvinyl chloride pipe 25mm and pipe fittings

Be sure to install heat insulation on the drain piping

Heat insulation material: Polyethylene foam with thickness more than 10 mm.

• If converging multiple dranin pipes, install according to the procedure shown below.



- · After piping work is finished check drainage flows smothly.
- · Be sure to insulate all indoor units.



CAUTION:

After the confirmation of the above conditions, prepare the wiring as follows:

- 1) Never fail to have an individual power specialized for the air conditioner. As for the method of wiring, be guided by the circuit diagram posted on the inside of control box cover.
- 2) Provide a circuit breaker switch between power source and the unit.
- 3) The screws which fasten the wiring in the casing of electrical fittings are liable to come loose from vibrations to which the unit is subjected during the course of transportation. Check them and make sure that they are all tightly fastened. (If they are loose, it could give rise to burn-out of the wires.)
- 4) Specification of power source
- 5) Confirm that electrical capacity is sufficient.
- 6) Be sure that the starting voltage is maintained at more than 90 percent of the rated voltage marked on the name plate.
- 7) Confirm that the cable thickness is as specified in the power sources specification. (Particularly note the relation between cable length and thickness.)
- 8) Never fail to equip a leakage breaker where it is wet or moist.
- 9) The following troubles would be caused by voltage drop-down.
 - · Vibration of a magnetic switch, damage on the contact point, fuse breaking, disturbance by the normal function of an overload protection device.
 - Proper starting power is not given to the compressor.


HAND OVER

Teach the customer the operation and maintenance procedures, using the operation manual. (air filter cleaning, temperature control, etc.)



CAUTION:


The connecting cable connected to the indoor and outdoor unit should be complied with the following specifications (This equipment shall be provided with a cord set complying with the national regulation).



If the supply cord is damaged, it must be replaced by a special cord or assembly available from the manufacturer of its service agent.

♦ Precautions when laying power and ground wiring

Use round pressure terminals for connections to the power terminal block. When laying ground wiring, you must use round pressure terminals.



When none are available, follow the instructions below.

- Do not connect wiring of different thicknesses to the power terminal block. (Slack in the power wiring may cause abnormal heat.)
- When connecting wiring which is the same thickness, do as shown in the figure below.







- For wiring, use the designated power wire and connect firmly, then secure to prevent outside pressure being exerted on the terminal block.
- Use an appropriate screwdriver for tightening the terinal screws. A screwdriver with a small head will strip the head and make proper tighterning impossible.
- · Over-tightening the terminal screws may break them.

Dip Switch Setting

1. Indoor Unit

	Function	Description	Setting Off	Setting On	Default
SW1	Communication	N/A (Default)	-	-	Off
SW2	Cycle	N/A (Default)	-	-	Off
SW3	Group Control	Selection of Master or Slave	Master	Slave	Off
SW4	Dry Contact Mode	Selection of Dry Contact Mode	Wired/Wireless remote controller selection of Manual or Auto operation Mode	Auto	Off
SW5	Installation	Fan continuous operation	Continuous operation Removal	-	Off
SW6	Heater linkage	N/A	-	-	Off
	Ventilator link- age	Selection of Ventilator linkage	Linkage Removal	Working	
SW7	Vane selection (Console)	Selection of up/down side Vane	Up side + Down side Vane	Up side Vane Only	Off
	Region selection	Selection tropical region	General model	Tropical model	
SW8	Etc.	Spare	-	-	Off




A CAUTION


For Multi V Models, DIP switch 1, 2, 6, 8 must be set OFF.

2. Outdoor Unit

In case that the products meet specific conditions, "Auto addressing" function can start automatically with the improved speed by turning the DIP switch #3 of the outdoor unit and resetting the power.

- * Specific conditions:
 - All names of the indoor units are ARNU****4.
 - The serial number of Multi V super IV (outdoor units) is after October 2013.






Outdoor Unit PCB

Outdoor Unit DIP Switch

Group Control Setting

1. Group Control 1

■ Wired remote controller 1 + Standard Indoor Units



■ DIP Switch in PCB

- **1 Master Setting**
 - No. 3 Off



Slave SettingNo. 3 On



Indoor Unit DIP Switch

Some products have no DIP switch on PCB. It is possible to set indoor units to Master or Slave by using the wireless remote controller instead of DIP switch.

For the details of the setting, please refer to the manual of the wireless remote controller.

- 1. It is possible to 16 indoor units(Max.) by one wired remote controller.
 - Set only one indoor unit to Master, set the others to Slave.
- 2. It is possible to connect with every type of indoor units.
- 3. It is possible to use wireless remote controller at the same time.
- 4. It is possible to connect with Dry Contact and Central controller at the same time.
 - The Master indoor unit is possible to recognize Dry Contact and Central Controller only.
- In case that any error occurs at indoor unit, the error code is displayed on the wired remote controller.


It is possible to control the other indoor units except the error units.

- * It is possible to connect indoor units since Feb. 2009.
- ★ It can be the cause of malfuctions when there is no setting of master and slave.
- * In case of Group Control, it is possible to use following functions.
 - Selection of operation, stop or mode
 - Temperature setting and room temperature check
 - Current time change
 - Control of flow rate (High/Middle/Low)
 - Reservation settings

It is not possible to use some functions.

2. Group Control 2


■ Wired remote controllers + Standard Indoor Units




- # It is possible to control 16 indoor units(Max.) with the master wired remote control.
- * Other than those, it is same with the Group Control 1.

3. Group Control 3

■ Mixture connection with indoor units and Fresh Air Intake Unit




- # In case of connecting with standard indoor unit and Fresh Air Intake Unit, separate Fresh Air Intake Unit with standard units. (N, M ≤ 16) (Because setting temperature are different.)
- * Other than those, it is same with Group Control 1.



* FAU : Fresh Air Intake Unit Standard: Standard Indoor Unit

4. 2 Remote Control


■ Wired remote controller 2 + Indoor unit 1



- 1. It is possible to connect two wired remote controllers (Max.) with one indoor unit. Set only one indoor unit to Master, set the others to Slave.
- Set only one wired remote controller to Master, set the others to Slave. 2. Every types of indoor unit is possible to connect two remote controller.
- 3. It is possible to use wireless remote controller at the same time.
- 4. It is possible to connect with Dry Contact and Central controller at the same time.
- 5. In case that any error occurs at indoor unit, the error code is displayed on the wired remote controller.
- 6. There isn't limits of indoor unit function.

5. Accessories for group control setting

It is possible to set group control by using below accessories.






A CAUTION

· Apply totally enclosed noncombustible conduit in case of local building code Requiring plenum cable usage.

Model Designation



Airborne Noise Emission

The A-weighted sound pressure emitted by this product is below 70 dB.

** The noise level can vary depending on the site.

The figures quoted are emission level and are not necessarily safe working levels. Whilst there is a correlation between the emission and exposure levels, this cannot be used reliably to determine whether or not further precautions are required. Factor that influence the actual level of exposure of the workforce include the characteristics of the work room and the other sources of noise, i.e. the number of equipment and other adjacent processes and the length of time for which an operator exposed to the noise. Also, the permissible exposure level can vary from country to country. This information, however, will enable the user of the equipment to make a better evaluation of the hazard and risk.

Limiting concentration

Limiting concentration is the limit of Freon gas concentration where immediate measures can be taken without hurting human body when refrigerant leaks in the air. The limiting concentration shall be described in the unit of kg/m³ (Freon gas weight per unit air volume) for facilitating calculation

Limiting concentration: 0.44kg/m³(R410A)

Calculate refrigerant concentration

Refrigerant concentration = $\frac{\text{Total amount of replenished refrigerant in refrigerant facility (kg)}}{\text{Capacity of smallest room where indoor unit is installed (m³)}}$