

www.lg.com

INSTALLATION MANUAL **AIR CONDITIONER**

- Please read this installation manual completely before installing the product.
- Installation work must be performed in accordance with the national wiring standards by authorized personnel only.
- Please retain this installation manual for future reference after reading it thoroughly.

TYPE : 4-WAY CEILING CASSETTE



CONTENTS

Safety Precautions	3
Installation Places	6
The indoor unit installation	6
Remote Controller Installation	10
Installation to Decorative Panel(Accessory)	13
Test running	15
Optional Operation	17
How to Set E.S.P?	25

Safety Precautions

To prevent the injury of the user or other people and property damage, the following instructions must be followed.

- Be sure to read before installing the air conditioner.
- Be sure to observe the cautions specified here as they include important items related to safety.
- Incorrect operation due to ignoring instruction will cause harm or damage. The seriousness is classified by the following indications.

WARNING This symbol indicates the possibility of death or serious injury.

 ACAUTION This symbol indicates the possibility of injury or damage to properties only.

The meanings of the symbols used in this manual are as shown below.

\bigcirc	Be sure not to do.
	Be sure to follow the instruction.

	Ω	WA	DNI	
=		VV A	RN	
· · ·				

Installation

· Otherwise, it may cause

electrical shock.

outdoor unit.

dust. water. etc.

Always perform grounding.

Securely attach the electrical

part cover to the indoor unit

and the service panel to the

If the electrical part cover of the

panel of the outdoor unit are not attached securely, it could result in a fire or electric shock due to

indoor unit and the service

Don't use a power cord, a plug or a loose socket which is damaged.

• Otherwise, it may cause a fire or electrical shock.

Always install an air leakage breaker and a dedicated switching board.

• No installation may cause a fire and electrical shock.

For installation of the product, always contact the service center or a professional installation agency.

 Otherwise, it may cause a fire, electrical shock, explosion or injury.

Do not keep or use flammable gases or combustibles near the air conditioner.

• Otherwise, it may cause a fire or the failure of product.

Ensure that an installation frame of the outdoor unit is not damaged due to use for a long time.

• It may cause injury or an accident.

Do not disassemble or repair the product randomly.

• It will cause a fire or electrical shock.

Do not install the product at a place that there is concern of falling down.

· Otherwise, it may result in personal injury.

Use caution when unpacking and installing.

· Sharp edges may cause injury.

Use a vacuum pump or Inert (nitrogen) gas when doing leakage test or air purge. Do not compress air or Oxygen and Do not use Flammable gases. Otherwise, it may cause fire or explosion.

• There is the risk of death, injury, fire or explosion.

Operation Do not share the outlet with Do not use the damaged Do not modify or extend the other appliances. power cord. power cord randomly. It will cause an electric shock · Otherwise, it may cause a fire · Otherwise, it may cause a fire or electrical shock or electrical shock or a fire due to heat generation. Take care so that the power Unplug the unit if strange Keep the flames away. cord may not be pulled sounds, smell, or smoke during operation. comes from it. Otherwise, it may cause a fire · Otherwise, it may cause · Otherwise, it may cause a fire. electrical shock or a fire. or electrical shock. Take the power plug out if Do not use the power cord Do not open the suction necessary, holding the head near the heating tools. inlet of the indoor/outdoor of the plug and do not touch unit during operation. it with wet hands. Otherwise, it may cause a fire · Otherwise, it may cause a fire · Otherwise, it may electrical shock and failure. or electrical shock. and electrical shock. Do not allow water to run Hold the plug by the head Never touch the metal parts when taking it out. of the unit when removing into electrical parts. the filter. · Otherwise, it may cause the It may cause electric shock They are sharp and may failure of machine or electrical and damage. cause iniurv. shock Do not step on the indoor/outdoor unit and Do not place a heavy object on the power do not put anything on it. cord. It may cause an injury through dropping of the Otherwise, it may cause a fire or electrical unit or falling down. shock. When the product is submerged into water, Take care so that children may not step on always contact the service center. the outdoor unit. · Otherwise, children may be seriously injured Otherwise, it may cause a fire or electrical shock. due to falling down.

		CAUTION	
--	--	---------	--

Installation	

Install the drain hose to ensure that drain can be securely done.

· Otherwise, it may cause water leakage.

Always inspect gas leakage after the installation and repair of product.

· Otherwise, it may cause the failure of product.

■ Operation —

Avoid excessive cooling and perform ventilation sometimes.

• Otherwise, it may do harm to your health.

Do not use an appliance for special purposes such as preserving animals vegetables, precision machine, or art articles.

· Otherwise, it may damage your properties.

- Install the product so that the noise or hot wind from the outdoor unit may not cause any damage to the neighbors.
- Otherwise, it may cause dispute with the neighbors.

Keep level parallel in installing the product.

• Otherwise, it may cause vibration or water leakage.

Use a soft cloth to clean. Do not use wax, thinner, or a strong detergent.

• The appearance of the air conditioner may deteriorate, change color, or develop surface flaws.

Do not place obstacles around the flow inlet or outlet.

• Otherwise, it may cause the failure of appliance or an accident.


Installation Places


1. Indoor unit Cassette type

- There should not be any heat source or steam near the unit.
- There should not be any obstacles to prevent the air circulation.
- A place where air circulation in the room will be good.
- A place where drainage can be easily obtained.
- A place where noise prevention is taken into consideration.
- · Do not install the unit near the door way.
- Ensure the spaces indicated by arrows from the wall, ceiling, or other obstacles.
- The indoor unit must keep the maintenance space.

The indoor unit installation

1. Cassette type





CAUTION :

- This air-conditioner uses a drain pump.
- Install the unit horizontally using a level gauge.
- During the installation, care should be taken not to damage electric wires.
- Please use an annexed sheet or the corrugated cardboard on the bottom of packing as installation sheet.


- Select and mark the position for fixing bolts and piping hole.
- Decide the position for fixing bolts slightly tilted to the drain direction after considering the direction of drain hose.
- · Drill the hole for anchor bolt on the wall.





Annexed sheet


Packing corrugated cardboard on the bottom




NOTICE


Avoid the following installation location.

- Such places as restaurants and kitchen where considerable amount of oil steam and flour is generated. These may cause heat exchange efficiency reduction, or water drops, drain pump mal-function. In these cases, take the following actions;
 - Make sure that ventilation fan is enough to cover all noxious gases from this place.
 - Ensure enough distance from the cooking room to install the air conditioner in such a place where it may not suck oily steam.
- 2. Avoid installng air conditioner in such places where cooking oil or iron powder is generated.
- 3. Avoid places where inflammable gas is generated.
- 4. Avoid place where noxious gas is generated.
- 5. Avoid places near high frequency generators.






- The following parts is option.
- 1 Hanging Bolt W 3/8 or M10
- ② Nut W 3/8 or M10
- ③ Spring Washer M10
- ④ Plate Washer M10



 \cdot Drill the piping hole on the wall slightly tilted to the outdoor side using a Ø 70 hole-core drill.




Indoor Unit Drain Piping

- Drain piping must have down-slope (1/50 to 1/100): be sure not to provide up-and-down slope to prevent reversal flow.
- During drain piping connection, be careful not to exert extra force on the drain port on the indoor unit.
- The outside diameter of the drain connection on the indoor unit is 32mm.

Piping material: Polyvinyl chloride pipe VP-25 and pipe fittings

- Be sure to execute heat insulation on the drain piping.
- Install the drain raising pipes at a right angle to the indoor unit and no more than 300mm from the unit.




Heat insulation material: Polyethylene foam with thickness more than 8 mm.

Drain test

The air conditioner uses a drain pump to drain water.


Use the following procedure to test the drain pump operation:



- Connect the main drain pipe to the exterior and leave it provisionally until the test comes to an end.
- Feed water to the flexible drain hose and check the piping for leakage.
- Be sure to check the drain pump for normal operating and noise when electrical wiring is complete.
- When the test is complete, connect the flexible drain hose to the drain port on the indoor unit.

Heat insulation

- 1. Use the heat insulation material for the refrigerant piping which has an excellent heat-resistance (over 120°C).
- 2. Precautions in high humidity circumstance: This air conditioner has been tested according to the "KS Standard Conditions with Mist" and confirmed that there is not any default. However, if it is operated for a long time in high humid atmosphere (dew point temperature: more than 23°C), water drops are liable to fall. In this case, add heat insulation material according to the following procedure:




- · Heat insulation material to be prepared... Adiabatic glass wool with thickness 10 to 20mm.
- · Stick glass wool on all air conditioners that are located in ceiling atmosphere.


ENGLISH

Wiring Connection

- · Open the control box cover and connect the Remote controller cord and Indoor power wires.
- Remove the control box cover for electrical connection between the indoor and outdoor unit.
- (Remove screws ①)
- · Use the cord clamper to fix the cord.



A CAUTION



CAUTION:

The Power cord connected to the unit should be selected according to the following specifications.

Precautions when laying power wiring

Use round pressure terminals for connections to the power terminal block.



When none are available, follow the instructions below.

- · Do not connect wiring of different thicknesses to the power terminal block. (Slack in the power wiring may cause abnormal heat.)
- When connecting wiring which is the same thickness, do as shown in the figure below.








WARNING:

Make sure that the screws of the terminal are free from looseness.

Remote Controller Installation


1. Please fix tightly using provided screw after placing remote controller setup board on the place where you like to setup.

- Please set it up not to bend because poor setup could take place if setup board bends. Please set up remote controller board fit to the reclamation box if there is a reclamation box.
- Install the product so as not to make a gap with the wall side and to prevent shaking after the installation.




2. Can set up Wired remote controller cable into three directions.


- Setup direction: the surface of wall reclamation, upper, right
- If setting up remote controller cable into upper and right side, please set up after removing remote controller cable guide groove.
- ℜ Remove guide groove with long nose.
- ① Reclamation to the surface of the wall
- ② Upper part guide groove
- ③ Right part guide groove




<Wire guide grooves>



4. Please connect indoor unit and remote controller using connection cable.



5. Please use extension cable if the distance between wired remote controller and indoor unit is more than 10m.



Wired remote controller installation

• Since the room temperature sensor is in the remote controller, the remote controller box should be installed in a place away from direct sunlight, high humidity and direct supply of cold air to maintain proper space temperature. Install the remote controller about 5ft(1.5m) above the floor in an area with good air circulation at an average temperature.

Do not install the remote controller where it can be affected by:

- Drafts, or dead spots behind doors and in corners.
- Hot or cold air from ducts.
- Radiant heat from sun or appliances.
- Concealed pipes and chimneys.
- Uncontrolled areas such as an outside wall behind the remote controller.
- This remote controller is equipped with a seven segment LED. display. For proper display of the remote controller LED's, the remote controller should be installed properly as shown in Fig.1.
 - (The standard height is 1.2~1.5 m from floor level.)




Fig.1 Typical locations for remote controller


Installation to Decorative Panel(Accessory)

The decorative panel has its installation direction. Before installing the decorative panel, always remove the paper template.

- 1. Remove the packing and take out air inlet grille from front panel.
- 2. Remove the Corner covers of the panel.

3. Fit the panel on the unit by inserting hooks as shown in picture.


4. Insert two screws on diagonal corners of panel. Do not tighten the bolts completely. (The fixing screws are included in the indoor unit box.) Check the alignment of panel with the ceiling. Height can be adjusted using hanging bolts as shown in picture. Insert the other two screws and tighten all screws completely. Front grille -



Coner cover -

Hook clip -

Hook








5. Fit the corner covers.


6. Open two screws of control panel cover.

- Connect one display connector and two vane control connectors of front panel to indoor unit PCB.
 The position marking on PCB is as: Display connector : CN-DISPLAY
 Vane control connector: CN-VANE 1,2
- 8. Close the cover for control box.
- 9. Install the air inlet grille and Filter on the panel.














CAUTION: Install certainly the decorative panel. Cool air leakage causes sweating. □ Water drops fall.



ENGLISH

Test running

1. PRECAUTIONS IN TEST RUNNING

• The initial power supply must provide at least 90% of the rated voltage. Otherwise, the air conditioner should not be operated.



- **CAUTION** ⁽¹⁾ For test run, carry out the cooling operation firstly even during heating season. If heating operation is carried out firstly, it leads to the trouble of compressor. Then attention must be paid.
 - (2) Carry out the test run more than 5 minutes without fail. (Test run will be cancelled 18 minutes later automatically)
- To cancel the test run, press any button.

CHECK THE FOLLOWING ITEMS WHEN INSTALLATION IS COMPLETE

- After completing work, be sure to measure and record trial run properties, and store measured data. etc.
- · Measuring items are room temperature, outside temperature, suction temperature, blow out temperature, wind velocity, wind volume, voltage, current, presence of abnormal vibration and noise, operating pressure, piping temperature, compressive pressure.
- As to the structure and appearance, check following items.
 - □ Is the circulation of air adequate?
 - Is the draining smooth?
 - □ Is the heat insulation complete (refrigerant and drain piping)?
 - □ Is there any leakage of refrigerant?

□ Is the remote controller switch operated? □ Is there any faulty wiring? □ Are not terminal screws loosened?


M4118N·cm{12kgf·cm}	M5196N·cm{20kgf·cm}
M6245N·cm{25kgf·cm}	M8588N·cm{60kgf·cm}

2. Connection of power supply

- 1. Connect the power supply cord to the independent power supply. Circuit breaker is required.
- 2. Operate the unit for fifteen minutes or more.

3. Evaluation of the performance

- 1. Measure the temperature of the intake and discharge air.
- 2. Ensure the difference between the intake temperature and the discharge one is more than 8°C (Cooling) or reversely (Heating).



CAUTION: After the confirmation of the above conditions, prepare the wiring as follows:

- 1) Never fail to have an individual power specialized for the air conditioner. As for the method of wiring, be guided by the circuit diagram pasted on the inside of control box cover.
- 2) Provide a circuit breaker switch between power source and the unit.
- 3) The screw which fasten the wiring in the casing of electrical fittings are liable to come loose from vibrations to which the unit is subjected during the course of transportation. Check them and make sure that they are all tightly fastened. (If they are loose, it could give rise to burnout of the wires.)
- 4) Specification of power source
- 5) Confirm that electrical capacity is sufficient.
- 6) Be sure that the starting voltage is maintained at more than 90 percent of the rated voltage marked on the name plate.
- 7) Confirm that the cable thickness is as specified in the power sources specification.

(Particularly note the relation between cable length and thickness.)

- 8) Never fail to equip a leakage breaker where it is wet or moist.
- 9) The following troubles would be caused by voltage drop-down.
 Vibration of a magnetic switch, damage on the contact point there of, fuse breaking, disturbance to the normal function of a overload protection device.
 Proper starting power is not given to the compressor.
- 10) Use only 1 remote-controller contained in indoor unit, when you combine to use both cassette type indoor unit and different Indoor units combinations as shown below.
 After pathe and the Provide the providet the provide the provide the provide the providet

After setting the ESP value in the Duct Type Indoor Unit, the main power turns off and then remove the remote controller.


HAND OVER

Teach the customer the operation and maintenance procedures, using the operation manual (air filter cleaning, temperature control, etc.).

Optional Operation


Installer Setting -Test Run Mode

After installing the product, you must run a Test Run mode. For details related to this operation, refer to the product manual.




Installer Setting - Setting Address of Central Control

It's the function to use for connecting central control. Please refer to central controller manual for the details



Installer Setting -Thermistor

This is the function to select the temperature sensor to judge the room temperature.




<Thermistor Table>

Ter	nperature ser	nsor selection	Function
01	Remote cont	roller	Operation in remote controller temperature sensor
02	Indoor unit		Operation in indoor unit temperature sensor
03	2TH	Cooling	Operation of higher temperature by comparing indoor unit's and wired remote controller's temperature. (There are products that operate at a lower temperature.)
		Heating	Operation of lower temperature by comparing indoor unit's and wired remote controller's temperature.

* The function of 2TH has different operation characteristics according to the product.

Installer Setting -Ceiling Height Selection

This function is to adjust FAN Airflow rate according to ceilingheight (only cassette model)



<Ceiling Height Selection Table>

C	eiling Height Level	Description
01	Low	Decrease the indoor airflow rate 1 step from standard level
02	Standard	Set the indoor airflow rate as standard level
03	High	Increase indoor airflow rate 1 step from standard level
04	Super high	Increase indoor airflow rate 2 steps from standard level

* Ceiling height setting is available only for some products.


* Ceiling height of 'Super high' function may not exist depending on the indoor unit.

* Refer to the product manual for more details.

ENGLISH

Installer Setting-Group Setting

It is a function for settings in group control, or 2-remote controller control.




Remote controller	Function
Master	Indoor unit operates based on master remote controller at group control. (Master is set when delivering from the warehouse.)
Slave	Setup all remote controllers except one master remote controller to slave at group control

ℜ Refer to the 'group control' part for details

• When controlling in groups, basic operation settings, airflow strength weak/medium/strong, lock setting of the remote controller, time settings, and other functions may be restricted.

Installer Setting-Dry Contact Mode Setting

Dry contact function is the function that is possible to use only when dry contact equipment is separately purchased/setup.




What is Dry Contact?

Like hotel card key and body perception sensor, it is the signal of the point of contact when using air-conditioner by interlocking.

• Please refer to dry contact manual for more details.

Installer Setting-Celsius / Fahrenheit Switching

This function is used for switching the display between Celsius and Fahrenheit. (Optimized only for U.S.A)



* Whenever press v button in Fahrenheit mode, the temperature will increase/drop 2 degrees.

Installer Setting -Optional Function Setting


Setting feature for indoor unit when air cleaning / heater / humidifier / Up/down grill / Ventilation KIT /Auxiliary Heater is newly installed, or installed unit is removed.

 If pressing button long for 3 seconds, it enters into remote controller setter setup mode. If pressing once shortly, it enters into user setup mode. Please press more than 3 seconds for sure.
If pressing button repeatedly, it moves to the selected option function code as picture below. Image: select option function code as picture below.
3 Select existing condition of each mode by pressing
4 Press 📾 button to save.
 Pressing (E) button will exit settings mode. After setup, it automatically gets out of setup mode if there is no button input for 25 seconds. When exiting without pressing set button, the manipulated value is not reflected.

How to Set E.S.P?

This is the function that decides the strength of the wind for each wind level and because this function is to make the installation easier.

If you set ESP incorrectly, the air conditioner may malfunction. This setting must be carried out by a certificated-technician.



• When setting ESP value on the product without very weak wind or power wind function, it may not work.

