



MICROWAVE OVEN

MIKROVLNNÁ TROUBA/GRILL/KOMBINACE

MIKROVLNNÁ RÚRA /GRIL/KOMBINÁCIA

HASZNÁLATI UTASÍTÁS

INSTRUKCJA OBSŁUGI

MC-7684B
MC-7684BS

P/No: MFL32548001

GB	-----	4~40
	MICROWAVE OVEN OWNER'S MANUAL Please read this owner's manual thoroughly before operating.	
CZ	-----	41~77
	MIKROVLNNÁ TROUBA/GRILL/KOMBINACE návod k obsluze Před uvedením trouby do provozu si důkladně přečtěte tento návod k obsluze	
SK	-----	78~114
	MIKROVLNNÁ RÚRA GRIL / KOMBINÁCIA NÁVOD NA OBSLUHU Pred uvedením rúry do prevádzky si dôkladne prečítajte tento návod na obsluhu	
HU	-----	115~151
	MIKROHULLÁMÚ SŰTŐ FELHASZNÁLÓI KÉZIKÖNYVE	
PL	-----	152~193
	INSTRUKCJA OBSŁUGI KUCHENKA MIKROFALOWA	

Precautions

Precautions to avoid possible exposure to excessive microwave energy.

GB You cannot operate your oven with the door open due to the safety interlocks built into the door mechanism. These safety interlocks automatically switch off any cooking activity when the door is opened; which in the case of a microwave oven could result in harmful exposure to microwave energy.

It is important not to tamper with the safety interlocks.

Do not place any object between the oven front face and the door or allow food or cleaner residue to accumulate on sealing surfaces.

Do not operate your oven if it is damaged. It is particularly important that the oven door closes properly and that there is no damage to the: (1) door(bent), (2) hinges and latches (broken or loosened), (3) door seals and sealing surfaces.

Your oven should not be adjusted or repaired by anyone except qualified service personnel.

Warning

Please ensure cooking times are correctly set as over cooking may result in the FOOD catching fire and subsequent damage to your oven.

When heating liquids, e.g. soups, sauces and beverages in your microwave oven, delayed eruptive boiling can occur without evidence of bubbling. This could result in a sudden boil over of the hot liquid. To prevent this possibility the following steps should be taken:

- 1 Avoid using straight sided containers with narrow necks.
- 2 Do not overheat.
- 3 Stir the liquid before placing the container in the oven and again halfway through the heating time.
- 4 After heating, allow to stand in the oven for a short time, stir or shake them(especially the contents of feeding bottles and baby food jars) again carefully and check the temperature of them before consumption to avoid burns (especially, contents of feeding bottles and baby food jars).
Be careful when handling the container.

Warning

Always allow food to stand after being cooked by microwaves and check the temperature of them before consumption. Especially contents of feeding bottles and baby food jars.

Contents

How the Microwave Oven Works

Microwaves are a form of energy similar to radio and television waves and ordinary daylight. Normally, microwaves spread outwards as they travel through the atmosphere and disappear without effect. Microwave ovens, however, have a magnetron which is designed to make use of the energy in microwaves. Electricity, supplied to the magnetron tube, is used to create microwave energy.

These microwaves enter the cooking area through openings inside the oven. A turntable or tray is located at the bottom of the oven. Microwaves cannot pass through metal walls of the oven, but they can penetrate such materials as glass, porcelain and paper, the materials out of which microwave-safe cooking dishes are constructed.

Microwaves do not heat cookware, though cooking vessels will eventually get hot from the heat generated by the food.

A very safe appliance

Your microwave oven is one of the safest of all home appliances. When the door is opened, the oven automatically stops producing microwaves. Microwave energy is converted completely to heat when it enters food, leaving no "left over" energy to harm you when you eat your food.

Precautions	4
Contents	5
Unpacking & Installing	6 ~ 7
Setting the Clock	8
Child Lock	9
Micro Power Cooking	10
Micro Power Level	11
Quick Start	12
More or Less Cooking	13
Grill Cooking	14
Convection Cooking	15 ~ 16
Combination Cooking	17 ~ 18
Auto Defrost	19 ~ 20
Quick Defrost	21 ~ 22
Auto Cook	23 ~ 25
Auto Roast Cook	26 ~ 27
European Menu	28 ~ 30
Heating or Reheating Guide	31
Fresh Vegetable Guide	32
Grill Cooking Guide	33
Important safety instructions	34 ~ 35
Microwave - safe Utensils	36
Food characteristics & Microwave cooking	37 ~ 38
Questions & Answers	39
Plug Wiring Information/Technical Specifications	40


GB

Unpacking & Installing


By following the basic steps on these two pages you will be able to quickly check that your oven is operating correctly. Please pay particular attention to the guidance on where to install your oven. When unpacking your oven make sure you remove all accessories and packing. Check to make sure that your oven has not been damaged during delivery.

GB

1 Unpack your oven and place it on a flat level surface.



HIGH RACK
GLASS TRAY



LOW RACK




ROTATING RING



METAL TRAY

2 Place the oven in the level location of your choice with more than 85cm height but make sure there is at least 30cm of space on the top and 10cm at the rear for proper ventilation. The front of the oven should be at least 8cm from the edge of the surface to prevent tipping. An exhaust outlet is located on top or side of the oven. Blocking the outlet can damage the oven.




THIS OVEN SHOULD NOT BE USED FOR COMMERCIAL CATERING PURPOSES

3 Plug your oven into a standard household socket. Make sure your oven is the only appliance connected to the socket. If your oven does not operate properly, unplug it from the electrical socket and then plug it back in.

4 Open your oven door by pulling the DOOR HANDLE. Place the ROTATING RING inside the oven and place the GLASS TRAY on top.

5 Fill a microwave safe container with 300 ml (1/2 pint) of water. Place on the GLASS TRAY and close the oven door. If you have any doubts about what type of container to use please refer to page 36.



6 Press the STOP/CLEAR button, and press the START button one time to set 30 seconds of cooking time.



7 The DISPLAY will count down from 30 seconds. When it reaches 0 it will sound BEEPS. Open the oven door and test the temperature of the water. If your oven is operating the water should be warm. Be careful when removing the container it may be hot.

GB



YOUR OVEN IS NOW INSTALLED

8 The contents of feeding bottles and baby food jars shall be stirred or shaken and the temperature checked before consumption, in order to avoid burns.

Setting the Clock

You can set either 12 hour clock or 24 hour clock.

In the following example I will show you how to set the time for 14:35 when using the 24 clock.
Make sure that you have removed all packaging from your oven.

GB




When your oven is plugged in for the first time or when power resumes after a power cut, a '0' will be shown in the display; you will have to reset the clock.

If the clock (or display) shows any strange looking symbols, unplug your oven from the electrical socket and plug it back in and reset the clock.


Make sure that you have correctly installed your oven as described earlier in this book.

Press **STOP/CLEAR**.




Press **CLOCK** once.

(If you want to use different option, Press **CLOCK** once more.
If you want to change different option after setting clock, you have to unplug and plug it back in.)



Turn **DIAL** until display shows "14: ".


Press **CLOCK (or START)** for hour confirmation.



Turn **DIAL** until display shows "14:35".

Press **CLOCK (or START)**.

The clock starts counting.




Child Lock



Your oven has a safety feature that prevents accidental running of the oven. Once the child lock is set, you will be unable to use any functions and no cooking can take place. However your child can still open the oven door.

Press **STOP/CLEAR**.




GB

Press and hold **STOP/CLEAR** until "L" appears on the display and BEEP sounds.


The **CHILD LOCK** is now set.

The time will disappear on the display but will reappear on the display a few seconds later.

If any button is pressed, "L" will appear on the display



To cancel **CHILD LOCK** press and hold **STOP/CLEAR** until "L" disappears. You will hear BEEP when it's released.



Micro Power Cooking

In the following example I will show you how to cook some food on 80% power for 5 minutes and 30 seconds.


GB




Your oven has five microwave Power settings.

POWER	%	Power Output
HIGH MAX	100%	900W
MEDIUM HIGH	80%	720W
MEDIUM	60%	540W
DEFROST (**) MEDIUM LOW	40%	360W
LOW	20%	180W


Make sure that you have correctly installed your oven as described earlier in this book.
Press **STOP/CLEAR**.




Turn **DIAL** to select the 720W.



Turn **DIAL** until display shows "5:30".



Press **START**.



Micro Power Level

Your microwave oven is equipped with 5 power levels to give you maximum flexibility and control over cooking. The table below shows the examples of food and their recommended cooking power levels for use with this microwave oven.

POWER LEVEL	USE	POWER LEVEL (%)	POWER OUTPUT
HIGH	<ul style="list-style-type: none"> * Boil Water * Brown minced beef * Cook poultry pieces, fish, vegetables * Cook tender cuts of meat 	100%	900W
MEDIUM HIGH	<ul style="list-style-type: none"> * All reheating * Roast meat and poultry * Cook mushrooms and shellfish * Cook foods containing cheese and eggs 	80%	720W
MEDIUM	<ul style="list-style-type: none"> * Bake cakes and scones * Prepare eggs * Cook custard * Prepare rice, soup 	60%	540W
DEFROST/ (ðð) MEDIUM LOW	<ul style="list-style-type: none"> * All thawing * Melt butter and chocolate * Cook less tender cuts of meat 	40%	360W
LOW	<ul style="list-style-type: none"> * Soften butter & cheese * Soften ice cream * Raise yeast dough 	20%	180W



GB

Quick Start


In the following example I will show you how to set 2 minutes of cooking on high power.

GB




The **QUICK START** feature allows you to set 30 seconds intervals of HIGH power cooking with a touch of the **START** button.

Press **STOP/CLEAR**.



Press **START** four times to select 2 minutes on HIGH power. Your oven will start before you have finished the fourth press.



More or Less Cooking

In the following example I will show you how to change the preset AUTO COOK programmes for a longer or shorter cooking time.




If you find that your food is over or undercooked when using the AUTO COOK programme, you can increase or decrease cooking time by turning DIAL.

When cooking with auto and manual function, you can lengthen or shorten the cooking time at any point by turning DIAL.

There is no need to stop the cooking process.



Press **STOP/CLEAR**.




GB

Set the required **AUTO COOK** programme.


Select weight of food.

Press **START**.



Turn **DIAL** clockwise. The cooking time will increase.

Turn **DIAL** counterclockwise. The cooking time will decrease.



Grill Cooking

In the following example I will show you how to use the grill to cook some food for 12 minutes and 30 seconds.

GB




This model is fitted with a **SHEATH HEATER**, so preheating is not needed.


This feature will allow you to brown and crisp food quickly.

The metal tray is placed between a glass tray and a grill rack at the grill mode.


The grill rack (high rack) must be used during grill cooking.




Press **STOP/CLEAR**.




Turn **KNOB** to select the GRILL mode.



Turn **DIAL** until display shows "12:30".



Press **START**.



Convection Cooking

In the following example I will show you how to preheat the oven at a temperature of 230°C.




The convection oven has a temperature range of 40°C and 100°C~250°C (180°C is automatically available when convection mode is selected).

The oven has a ferment function at the oven temperature of 40°C. You may wait until the oven is cool because you cannot use a ferment function if the oven temperature is over 40°C.

Your oven will take a few minutes to reach the selected temperature.


Once it has reached correct temperature, your oven will BEEP to let you know that it has reached the correct temperature. Then place your food in your oven: then tell your oven to start cooking.

1. To preheat.
Press **STOP/CLEAR**.




GB


Turn **KNOB** to select CONVECTION mode.



Turn **DIAL** until display shows "230°C".
The cooking temperature can be changed by turning **DIAL**.
Press **START**.



Press **START**.
Preheating will be started with displaying "Pr-H".



Convection Cooking


In the following example I will show you how to preheat the oven first, then cook some food at a temperature of 230°C for 50 minutes.

GB




If you do not set a temperature your oven will automatically select 180°C. The cooking temperature can be changed by turn the DIAL.

The convection rack (low rack) must be used during convection cooking.




2. To cook,

Press **STOP/CLEAR**.




Turn **KNOB** to select CONVECTION mode.




Turn **DIAL** until display shows "230°C".

Press **START**.



Turn **DIAL** until display shows "50:00"

Press **START**.



Combination Cooking

In the following example I will show you how to programme your oven with micro power 20% and grill for a cooking time of 25 minutes.




Your oven has a combination cooking feature which allows you to cook food with **heater** and **microwave** at the same time or alternately. This generally means it takes less time to cook your food.

You can set two kinds of micro power level (20% and 60%) in combi mode.

Category	Microwave Power(%)
Co-1	20
Co-2	60


1. GRILL COMBINATION.

Press **STOP/CLEAR**.




GB

Turn **FUNCTION** to select the grill Co-1 mode.




Turn **DIAL** until display shows "25:00".



Press **START**.

When cooking you can use by turning DIAL to increase or decrease cooking time.



Be careful when removing your food because the container will be hot!

Combination Cooking

In the following example I will show you how to programme your oven with:- micro power 60% and at a convection temperature 200 °C for a cooking time of 25 minutes.


GB




Your oven has a combination cooking feature which allows you to cook food with **heater** and **microwave** at the same time or alternately. This generally means it takes less time to cook your food.

2. CONVECTION COMBINATION.

Press **STOP/CLEAR**.




Turn **FUNCTION** to select the convection Co-2 mode.




Turn **DIAL** until display shows "200 °C".

Press **START** for temperature confirmation.




Turn **DIAL** until display shows "25:00".



Press **START**.

When cooking you can use by turning DIAL to increase or decrease cooking time.



Be careful when removing your food because the container will be hot!

Auto Defrost

The temperature and density of food varies, I would recommend that the food is checked before cooking commences. Pay particular attention to large joints of meat and chicken, some foods should not be completely thawed before cooking. These will require a standing time to allow the centre to thaw. In the following example I will show you how to defrost 1.4 Kg of frozen poultry.




Your oven has four microwave defrost settings:- **MEAT**, **POULTRY**, **FISH** and **FROZEN VEGETABLES**; each defrost category has different power settings. Repeated presses of the **AUTO DEFROST** button will select a different setting.

Category	Press DEFROST	
MEAT	1	time
POULTRY	2	times
FISH	3	times
FROZEN VEGETABLES	4	times

Press **STOP/CLEAR**.

Weight the food that you are about to defrost. Be certain to remove any metallic ties or wraps; then place the food in your oven and close the oven door.



GB


Press **AUTO DEFROST** twice to select the **POULTRY** defrosting programme.




Enter the weight of the frozen food that you are about to defrost.



Turn **DIAL** until display shows "1.4".



Press **START**.



During defrosting your oven will "BEEP", at which point open the oven door, turn food over and separate to ensure even thawing. Remove any portions that have thawed or shield them to help slow down thawing. After checking close the oven door and press **START** to resume defrosting.

Your oven will not stop defrosting (even when the beep sounded) unless the door is opened.

GB

AUTO WEIGHT DEFROST GUIDE

- * Food to be defrosted should be in a suitable microwave proof container and place uncovered on the glass turntable.
- * If necessary, shield small areas of meat or poultry with flat pieces of aluminum foil. This will prevent thin areas becoming warm during defrosting. Ensure the foil does not touch the oven walls.
- * Separate items like minced meat and chops as soon as possible.
- * **When BEEP**, at this point remove the food from the microwave oven, turn the food over and return to the microwave oven. Press start to continue. At the end of the program, remove the food from the microwave oven, cover with foil and allow to stand until completely thawed. To thaw completely, for example joints of meat and whole chickens should STAND for a minimum of 1 hour before cooking.

Category	Weight Limit	Utensil	Food
Meat Poultry Fish	0.1 ~ 4.0 kg	Microwave ware (Flat plate)	Meat Minced beef, Fillet steak, Cubes for stew, Sirloin steak, Pot roast, Rump roast, Beef burger Lamb chops, Rolled roast, Sausage, Cutlets(2cm) Turn food over at beep. After defrosting, let stand for 5-15 minutes. Poultry Whole chicken, Legs, Breasts, Turkey breasts(under 2.0kg) Turn food over at beep. After defrosting, let stand for 20-30 minutes. Fish Fillets, Steaks, Whole fish, Sea foods Turn food over at beep. After defrosting, let stand for 10-20 minutes.
Frozen vegetables	0.1 ~ 2.0 kg	Microwave ware bowl	Put the frozen food on a microwave-safe bowl. Place in the oven. Adjust weight and press start. When beep, open the door and stir. After defrosting, let stand for 5-8 minutes.

Use this function to thaw only 0.5kg of Minced meat very quickly.
This will require a standing time to allow the center to thaw. In the following example will show you how to defrost 0.5kg of frozen minced meat.


Quick Defrost



Your oven has a microwave quick defrost setting (MEAT).

Press **STOP/CLEAR**.


Weight the food that you are about to defrost. Be certain to remove any metallic ties or wraps; then place the food in your oven and close the oven door.



GB

Press **QUICK DEFROST** to select the **MEAT** defrosting programme.

The oven works automatically.



During defrosting your oven will "BEEP", at which point open the oven door, turn food over and separate to ensure even thawing. Remove any portions that have thawed or shield them to help slow down thawing. After checking close the oven door and press **START** to resume defrosting.

Your oven will not stop defrosting (even when the beep sounded) unless the door is opened.

QUICK DEFROST GUIDE

Use this function to defrost quickly for minced meat.

Remove the meat completely from its wrapping. Place the mince onto a microwave-safe plate. When beeps, at this point remove the mince from the microwave oven, turn the mince over and return to the microwave oven. Press start to continue. At the end of the program remove the mince from the microwave oven, cover with foil and allow to stand 5-15 minutes or until completely thawed.

GB

<i>Category</i>	<i>Weight</i>	<i>Utensil</i>	<i>Instructions</i>
Minced Meat	0.5kg	Microwave ware (Flat plate)	Minced meat Turn food over at beep. After defrosting, let stand for 5-15 minutes.

Auto Cook


In the following example I will show you how to cook 0.6kg of fried chicken legs.



AUTO COOK allows you to cook most of your favorite food easily by selecting the food type and entering the weight of the food.

Category	Display
Fried Chicken	Ac 1
Fried Chicken Legs	Ac 2
Fried Fish	Ac 3
Frozen Pizza	Ac 4
Fresh Pizza	Ac 5
Vegetable Ragout	Ac 6
Baked Potatoes	Ac 7

Press **STOP/CLEAR**.




GB


Press **AUTO COOK**.




Turn **DIAL** until display shows "Ac 2".




Press **START** for category confirmation.



Turn **DIAL** until display shows "0.6".



Press **START**.



Function	Category	Weight Limit	Utensil	Food Temp.	Instructions
Auto Cook	Fried Chicken (Ac 1)	0.8 ~ 1.5kg	low rack & Metal tray	Refri.	Wash and dry skin. Brush the chicken with oil. Tie its feet with a cotton thread. Place on the rack on the metal tray. When beep, turn food over. After cooking, stand covered with aluminum foil for 10 minutes.
	Fried Chicken Legs (Ac 2)	0.2 ~ 0.8kg	low rack & Metal tray	Room	Wash and dry skin. Brush the chicken pieces with oil. Place on the rack on the metal tray. When beep, turn food over. After cooking, stand covered with aluminum foil for 2 minutes.
	Fried Fish (Ac 3)	0.2 ~ 0.8kg	high rack & Metal tray	Refri.	Clean and dry. Place food on the rack. When beep, turn food over. After cooking, stand covered with aluminum foil for 2 minutes.
	Frozen Pizza (Ac 4)	0.1 ~ 0.5kg	low rack & Metal tray	Refri.	This function is for cooking frozen pizza. Remove all package. Place on the low rack over the metal tray on the glass turntable in the oven. Adjust weight and press start. After cooking, remove from the oven and stand for 1-2 minutes.

Function	Category	Weight Limit	Utensil	Food Temp.	Instructions
Auto Cook	Fresh Pizza (Ac 5)	1 Pan	Low rack & Metal tray	Room	<p>Ingredients Dough: Flour - 250 g, Milk - 130 ml Yeast(dry) - 5 g, Sugar - 5 g Salt - 2 g, Butter(soften) - 25 g Stuffing: Holland cheese - 250 g, Vegetable oil - 50 ml Sausage - 100 g, Tomato - 2 pieces Paprika - 1 pieces, Black olives - 50 g Tomato paste - 3 tablespoons</p> <p>Combine all ingredients. Knead dough until smooth. Roll it out and up the edges. Oil the metal tray. Place the dough on the greased metal tray. Oil dough, cover it with tomato paste and with the stuffing: sausage, paprika, tomatoes, olives, strew with grated cheese. Choose the menu and press start without food. The oven will beep at end of the preheating period. Open the door and place the prepared food on the low rack on the glass tray. After cooking, remove from the oven and stand 2-3min.</p>
	Vegetable Ragout (Ac 6)	4 servings	Microwave safe Bowl	Room	<p>Ingredients Eggplant - 2.5 pieces, cut into bricks Paprika - 3 pieces, cut into sticks Tomato - 2.5 pieces, cut into small pieces Vegetable marrow - 0.5 piece, cut into bricks Onion - 1.5 ~ 2 pieces, cut into small pieces Carrot - 1 piece, cut into sticks Vegetable oil - 0.25 glass Sugar - 1 tablespoon Spices - bay leaf, garlic, salt, pepper to taste</p> <p>Place all vegetables into a pan for microwave-safe bowl by layers, spice them with salt and pepper, add sugar and vegetable oil. Cover with vented plastic wrap or lid. Place the prepared bowl in the oven. Choose the menu and press start to cook. Knead twice while cooking. After cooking, remove from the oven and stand 2-3min.</p>
	Baked Potatoes (Ac 7)	0.2 ~ 1.0 kg	Metal tray	Room	<p>Choose medium sized potatoes 180 -220g. Wash and dry potatoes. Pierce potatoes several times with a fork. Place potatoes in the oven After cooking, stand covered with aluminum foil for 5 minutes.</p>

Auto Roast Cook


In the following example I will show you how to cook 0.6kg of Roast Veal.

GB



AUTO ROAST cook allows you to cook most of your favorite food easily by selecting the food type and entering the weight of the food.

Press **STOP/CLEAR**.




Press **AUTO ROAST**.




Turn **DIAL** until display shows "Ar 3".

Press **START** for category confirmation.



Turn **DIAL** until display shows "0.6".

Press **START**.



AUTO GRILL GUIDE

Function	Category	Weight Limit	Utensil	Food Temp.	Instructions
Auto Grill	Roast Beef (Ar 1)	0.5 ~ 1.5 kg	Low rack & Metal tray	Refrigerated	Brush the beef with melted margarine or butter. Place on the low rack over the metal tray. When beeps, turn food over. And then press start to continue cooking. After cooking, stand covered with foil for 10 minutes.
	Roast Pork (Ar 2)	0.5 ~ 1.5 kg	Low rack & Metal tray	Refrigerated	Brush the pork with melted margarine or butter. Place on the low rack over the metal tray. When beeps, turn food over. And then press start to continue cooking. After cooking, stand covered with foil for 10 minutes.
	Roast Veal (Ar 3)	0.5 ~ 1.5 kg	Low rack & Metal tray	Refrigerated	Prepare marinade : mix lemon juice, vegetable oil, and spices, cut garlic Marinate meat for 1 hour. Place the veal on the low rack on the metal tray. Choose the menu and adjust weight. Press start to cook. When beep, open the door and turn food over. Press start to continue cooking. After cooking, remove from the oven and stand covered with aluminum foil for 10 minutes.

GB

European Menu


In the following example I will show you how to cook 0.5 kg of Baked beans.

GB





European Menu allows you to cook most of your favorite food easily by selecting the food type and entering the weight of food by turn **DIAL**



Category	Display
OATMEAL	Sc 1
PASTA	Sc 2
BAKED BEAN	Sc 3
HOTDOG	Sc 4
STEW	Sc 5
SCRAMBLED EGG	Sc 6
GRILLED FISH	Sc 7
SAUSAGE	Sc 8



Press **European Menu**.
Turn **DIAL** until display shows "Sc 3".



Press **START** for category confirmation.
Turn **DIAL** until display shows 0.5kg.



FOOD CATEGORY	WEIGHT LIMIT	UTENSILS	FOOD TEMP.	INSTRUCTIONS															
1. OATMEAL	1 - 4 serves	Microwave-safe bowl	Room	Place the oats and milk in a deep microwave- safe bowl. Cook uncovered. The oven will beep, stir the oats well and press start to continue. After cooking, stir well and stand for 1 minute before serving.															
				<table border="1"> <thead> <tr> <th></th> <th>1 serve</th> <th>2 serves</th> <th>3 serves</th> <th>4 serves</th> </tr> </thead> <tbody> <tr> <td>Oats 1 package Approx. 40g</td> <td>1/3 cup (1 package)</td> <td>2/3 cups (2 packages)</td> <td>1 cup (3 packages)</td> <td>1 1/3 cups (4 packages)</td> </tr> <tr> <td>Cold Milk</td> <td>3/4 cup (180ml)</td> <td>1 1/2 cups (360ml)</td> <td>2 1/2 cups (540ml)</td> <td>3 cups (720ml)</td> </tr> </tbody> </table>		1 serve	2 serves	3 serves	4 serves	Oats 1 package Approx. 40g	1/3 cup (1 package)	2/3 cups (2 packages)	1 cup (3 packages)	1 1/3 cups (4 packages)	Cold Milk	3/4 cup (180ml)	1 1/2 cups (360ml)	2 1/2 cups (540ml)	3 cups (720ml)
					1 serve	2 serves	3 serves	4 serves											
Oats 1 package Approx. 40g	1/3 cup (1 package)	2/3 cups (2 packages)	1 cup (3 packages)	1 1/3 cups (4 packages)															
Cold Milk	3/4 cup (180ml)	1 1/2 cups (360ml)	2 1/2 cups (540ml)	3 cups (720ml)															
2. PASTA	0. 1 kg - 0. 3 kg	Microwave-safe bowl	Room	Place pasta and boiling water with 1/4 to 1 teaspoon salt in a deep and large bowl.															
				<table border="1"> <thead> <tr> <th>Weight</th> <th>100g</th> <th>200g</th> <th>300g</th> <th>Cover</th> </tr> </thead> <tbody> <tr> <td>Boiling water</td> <td>400ml</td> <td>700ml</td> <td>1000ml</td> <td>No</td> </tr> </tbody> </table> <p>Cook uncovered. The oven will beep, stir the pasta well and press start to continue. After cooking, stir and stand for 1 minute if required. Rinse pasta with cold water.</p>	Weight	100g	200g	300g	Cover	Boiling water	400ml	700ml	1000ml	No					
Weight	100g	200g	300g	Cover															
Boiling water	400ml	700ml	1000ml	No															
3. BAKED BEANS, REHEAT	0.2 kg - 0. 8 kg	Microwave-safe dish	Room	Pour beans into the microwave- safe dish. Cover. Place dish on the glass tray. After reheating, stir and then stand for 1- 2 minutes with cover.															
4. HOTDOGS INCLUDING BRINE	0.2 kg - 0. 6 kg	Microwave-safe bowl	Room	Place contents of can including brine in a microwave- save bowl. Heat uncovered. After heating, stir well. Drain and serve.															
5. STEW	0.2 kg - 0.6 kg	Microwave-safe bowl	Room	Place stew in a microwave- save bowl. Cover with wrap loosely. After heating, stir well and stand for 3 minutes.															
6. SCRAMBLED EGGS	1- 4 eggs	Microwave-safe bowl	Refrigerated	Place desired number of eggs and milk into a large bowl. Whisk slightly. Cover with wrap. After cooking, remove from the oven. Stir well and stand for 1- 2 minutes with cover until firm. Add amount of milk according to the quantity. ** 1 egg : 1 Tablespoon of milk 2 eggs : 2 Tablespoons of milk 3 eggs : 3 Tablespoons of milk 4 eggs : 4 Tablespoons of milk															

<i>FOOD CATEGORY</i>	<i>WEIGHT LIMIT</i>	<i>UTENSILS</i>	<i>FOOD TEMP.</i>	<i>INSTRUCTIONS</i>
7. GRILLED FISH	0.2-0.6kg	High rack	Refrigerated	Clean and dry. Place on the high rack. The oven will beep, turn food over and press start to continue. After cooking, remove from the oven. And serve.
8. SAUSAGE	0.1-0.5kg	High rack	Refrigerated	Remove package. Place on the high rack. The oven will beep, turn food over and press start to continue. After cooking, remove from the oven. And serve.

GB

To heat or reheat successfully in the microwave, it is important to follow several guidelines. Measure the amount of food in order to determine the time needed to reheat. Arrange the food in a circular pattern for best results. Room temperature food will heat faster than refrigerated food. Canned foods should be taken out of the can and placed in a microwavable container. The food will be heated more evenly if covered with a microwavable lid or vented plastic wrap. Remove cover carefully to prevent steam burns. Use the following chart as a guide for reheating cooked food.

Heating or Reheating Guide

Item	Cook time (at HIGH)	Special Instructions
Sliced meat 3 slices (0.5cm thick)	1½~2½ minutes	Place sliced meat on microwavable plate. Cover with plastic wrap and vent. • Note: Gravy or sauce helps to keep meat juicy.
Chicken pieces 1 breast 1 leg and thigh	2~3½ minutes 1½~2½ minutes	Place chicken pieces on microwavable plate. Cover with plastic wrap and vent.
Fish fillet (170-230g)	1~2 ½ minutes	Place fish on microwavable plate. Cover with plastic wrap and vent.
Lasagne 1 serving(300g)	4½~7 minutes	Place lasagne on microwavable plate. Cover with plastic wrap and vent.
Casserole 1 cup 4 cups	1½~3 minutes 5~7½ minutes	COOK covered in microwavable casserole dish. Stir once halfway through cooking.
Casserole cream or cheese 1 cup 4 cups	1½~3 minutes 4~6½ minutes	COOK covered in microwavable casserole dish. Stir once halfway through cooking.
Sloppy Joe or Barbecued beef 1 sandwich (½ cup meat filling) without bun	1~3 minutes	COOK covered in microwavable casserole dish. Stir once. Heat bun as directed in chart below.

Item	Cook time (at HIGH)	Special Instructions
Mashed potatoes 350g	6~7 minutes (at 540W)	COOK covered in microwavable casserole dish. Stir once halfway through cooking.
Baked beans 1 cup	2~3½ minutes	COOK covered in microwavable casserole dish. Stir once halfway through cooking.
Ravioli or pasta in sauce 1 cup 4 cups	3~4½ minutes 8~11½ minutes	COOK covered in microwavable casserole dish. Stir once halfway through cooking.
Rice 1 cup 4 cups	1½~2 minutes 4~6 minutes	COOK covered in microwavable casserole dish. Stir once halfway through cooking.
Sandwich roll or bun 1 roll	20~35 seconds	Wrap in paper towel and place on glass tray.
Vegetables 1 cup 4 cups	1½~3 minutes 4~6 minutes	COOK covered in microwavable casserole dish. Stir once halfway through cooking.
Soup 1 serving (8 oz.)	2~3 minutes	COOK covered in microwavable casserole dish. Stir once halfway through cooking.
Plated meal (1 serving) Meat 125g, Mashed potato 150g Carrot, cooked 150g	12½~14½ minutes (at 540W)	COOK covered in microwavable dinner plate.

GB

Fresh Vegetable Guide

GB

Vegetable	Amount	Cook time (at HIGH)	Instructions	Standing Time
Artichokes (230g each)	2 medium 4 medium	4 ~ 8 10 ~ 13	Trim. Add 2 tsp water and 2 tsp juice. Cover.	2~3 minutes
Asparagus, Fresh, Spears	450g	2 ~ 6	Add 1 cup water. Cover.	2~3 minutes
Green Beans	450g	7 ~ 12	Add 1/2 cup water in 1.5 litre casserole dish. Stir halfway through cooking.	2~3 minutes
Beets, Fresh	450g	12 ~ 17	Add 1/2 cup water in 1.5 litre covered casserole dish. Rearrange halfway through cooking.	2~3 minutes
Broccoli, Fresh, Spears	300g	5 ~ 7	Place broccoli in baking dish. Add 1/2 cup water.	2~3 minutes
Cabbage, Fresh, Chopped	450g	5-8	Add 1/2 cup water in 1.5 litre casserole dish. Stir halfway through cooking.	2~3 minutes
Carrots, Fresh, Sliced	200g	3 ~ 6	Add 1/4 cup water in 1.5 litre casserole dish. Stir halfway through cooking.	2~3 minutes
Cauliflower, Fresh, Whole	450g	7 ~ 10	Trim. Add 1/4 cup water in 1.5 litre casserole dish. Stir halfway through cooking.	2~3 minutes

Vegetable	Amount	Cook time (at HIGH)	Instructions	Standing Time
Corn, Fresh	2 ears	4 ~ 8	Husk. Add 2 tbsp water in 1.5 litre baking dish. Cover.	2~3 minutes
Mushrooms, Fresh, Sliced	230g	2 ~ 3	Place mushrooms in 1.5 litre casserole dish. Stir halfway through cooking.	2~3 minutes
Parsnips, Fresh, Sliced	450g	3 ~ 7	Add 1/2 cup water in 1.5 litre casserole dish. Stir halfway through cooking.	2~3 minutes
Peas, Green, Fresh	4 cups	6 ~ 9	Add 1/2 cup water in 1.5 litre casserole dish. Stir halfway through cooking.	2~3 minutes
Sweet Potatoes Whole Baking (170~230g each)	2 medium 4 medium	4 ~ 8 8~ 12	Pierce potatoes several times with fork. Place on 2 paper towels. Turn over halfway through cooking.	2~3 minutes
White potatoes, Whole Baking (170~230g each)	2 potatoes 4 potatoes	4 ~ 6 7 ~ 10	Pierce potatoes several times with fork. Place on 2 paper towels. Turn over halfway through cooking.	2~3 minutes
Spinach, Fresh, Leaf	450g	5 ~ 8	Add 1/2 cup water in 2 litre casserole dish.	2~3 minutes
Courgette, Fresh, Sliced	450g	5 ~ 8	Add 1/2 cup water in 1.5 litre casserole dish. Stir halfway through cooking.	2~3 minutes
Courgette, Fresh, Whole	450g	6 ~ 9	Pierce. Place on 2 paper towels. Turn courgette over and rearrange halfway through cooking.	2~3 minutes

Grill Cooking Guide

Directions for grilling meat on grill

- Trim excess fat from meat. Cut fat, making sure you do not cut into the lean. (This will stop the fat curling.)
- Arrange on the rack. Brush with melted butter or oil.
- Halfway through, turn the meat over.

Item	Weight	Approx. cooking time (in minutes)	Hints
Beefburgers	50g x 2 100g x 2	13-16 19-23	Baste with oil or melted butter. Thin items should be placed on the grill rack. Thick items can be placed on to a drip tray. Turn food over after half the cooking time.
Beefsteaks (2.5cm (1") thick)			
Rare	230g x 2	18-20	
Medium	230g x 2	22-24	
Well	230g x 2	26-28	
Lamb chops (2.5cm (1") thick)	230g x 2	25-32	

Directions for grilling fish and seafood

Place fish and seafood on the rack. Whole fish should be scored diagonally on both sides before grilling. Brush fish and seafood with melted butter, margarine or oil before and during cooking. This helps stop the fish drying out. Grill for times recommended in the chart. Whole fish and fish steaks should be carefully turned over halfway through grilling time. If desired thick fillets can also be turned halfway.

GB

Item	Weight	Approx. cooking time (in minutes)	Hints
Fish fillets			Brush with melted butter and turn over halfway through cooking.
1 cm (1/2") thick	230g	17-21	
1.5cm (1/2") thick	230g	20-24	
Fish steaks			Allow extra time for thick and oily fish. Turn over halfway through cooking.
2.5 cm (1") thick	230g	24-28	
Whole fish	225-350g each 400g	16-20 24-28	
Scallops	450g	16-20	Baste well during cooking. Turn over halfway through cooking.
Prawns uncooked	450g	16-20	

Important safety instructions

Read carefully and keep for future reference

WARNING

Please ensure cooking times are correctly set as over cooking may result in FIRE and subsequent DAMAGE to the OVEN.

GB

- 1 Do not attempt to tamper with, or make any adjustments or repairs to the door, control panel, safety interlock switches or any other part of the oven. It is hazardous for anyone to carry out any service or repair operation which involves the removal of any cover which gives protection against exposure to microwave energy. Repairs should only be undertaken by a qualified service technician.
- 2 Do not operate the oven when empty. It is best to leave a glass of water in the oven when not in use. The water will safely absorb all microwave energy, if the oven is accidentally started.
- 3 Do not dry clothes in the microwave oven, which may become carbonized or burned if heated too long.
- 4 Do not cook food wrapped in paper towels, unless your cook book contains instructions, for the food you are cooking.
- 5 Do not use newspaper in place of paper towels for cooking.
- 6 Do not use wooden containers. They may heat-up and char. Do not use ceramic containers which have metallic (e.g. gold or silver) inlays. Always remove metal twist ties. Metal objects in the oven may arc, which can cause serious damage.
- 7 Do not operate the oven with a kitchen towel, a napkin or any other obstruction between the door and the front edges of the oven, which may cause microwave energy leakage.
- 8 Do not use recycled paper products since they may contain impurities which may cause sparks and/or fires when used in cooking.
- 9 Do not rinse the turntable by placing it in water just after cooking. This may cause breakage or damage.
- 10 Small amounts of food require shorter cooking or heating time. If normal times are allowed they may overheat and burn.
- 11 Be certain to place the oven so the front of the door is 8 cm or more behind the edge of the surface on which it is placed, to avoid accidental tipping of the appliance.
- 12 Before cooking, pierce the skin of potatoes, apples or any such fruit or vegetable.
- 13 Do not cook eggs in their shell. Pressure will build up inside the egg which will burst.
- 14 Do not attempt deep fat frying in your oven.
- 15 Remove the plastic wrapping from food before cooking or defrosting. Note though that in some cases food should be covered with plastic film, for heating or cooking.
- 16 If the oven door or door seals are damaged, the oven must not be operated until it has been repaired by a qualified service technician.
- 17 If smoke is observed, switch off or disconnect the oven from the power supply and keep the oven door closed in order to stifle any flames.
- 18 When food is heated or cooked in disposable containers of plastic, paper or other combustible materials, check the oven frequently due to the possibility of the food container is deteriorating.
- 19 Only allow children to use the oven without supervision when adequate instructions have been given so that the child is able to use the oven in a safe way and understands the hazards of improper use.
- 20 Liquids or other foods must not be heated in sealed containers since they are liable to explode.
- 21 Do not operate the oven, if the door seals and adjacent parts of the microwave oven are faulty, until the oven has been repaired by a qualified service technician.
- 22 Check the utensils are suitable for use in microwave ovens before use.
- 23 Do not touch the oven door, outer cabinet, rear cabinet, oven cavity, accessories and dishes during grill mode, convection mode and auto cook operations, unless wearing thick oven gloves, as they will become hot. Before clearing make sure they are not hot.

WARNING

Please do not let the **POWER CORD** touch the **BACK COVER**.

Important safety instructions

Read carefully and keep for future reference

- 24 Only use utensils that are suitable for use in microwave ovens.
- 25 When heating food in plastic or paper containers, keep an eye on the oven due to the possibility of ignition.
- 26 If smoke is observed, switch off or unplug the appliance and keep the door closed in order to stifle any flames.
- 27 Microwave heating of beverages can result in delayed eruptive boiling, therefore care must be taken when handling the container.
- 28 The contents of feeding bottles and baby food jars shall be stirred or shaken and the temperature checked before consumption, in order to avoid burns.
- 29 Eggs in their shell and whole hard-boiled eggs should not be heated in microwave ovens since they may explode, even after microwave heating has ended.
- 30 Details for cleaning door seals, cavities and adjacent parts.
- 31 The oven should be cleaned regularly and any food deposits removed.
- 32 Failure to maintain the oven in a clean condition could lead to deterioration of the surface that could adversely affect the life of the appliance and possibly result in a hazardous situation.

- 33 Only use the temperature probe recommended for this oven (for appliances having a facility to use a temperature-sensing probe).
- 34 If heating elements are provided, during use the appliance becomes hot. Care should be taken to avoid touching heating elements inside the oven.
- 35 The appliance is not intended for use by young children or infirm persons without supervision.

GB

WARNING: If the door or door seals are damaged, the oven must not be operated until it has been repaired by a competent person.

WARNING: It is hazardous for anyone other than a competent person to carry out any service or repair operation that involves the removal of a cover which gives protection against exposure to microwave energy.

WARNING: Liquids and other foods must not be heated in sealed containers since they are liable to explode.

WARNING: Only allow children to use the oven without supervision when adequate instructions have been given so that the child is able to use the oven in a safe way and understands the hazards of improper use.

Microwave-safe Utensils

GB

Never use metal or metal trimmed utensils in your microwave oven

Microwaves cannot penetrate metal. They will bounce off any metal object in the oven and cause arcing, an alarming phenomenon that resembles lightning.

Most heat resistant non metallic cooking utensils are safe for use in your microwave oven. However, some may contain materials that render them unsuitable as microwave cookware. If you have any doubts about a particular utensil, there's a simple way to find out if it can be used in your microwave oven.

Place the utensil in question next to a glass bowl filled with water in the microwave oven. Microwave at power HIGH for 1 minute. If the water heats up but the utensil remains cool to the touch, the utensil is microwave-safe. However, if the water does not change temperature but the utensil becomes warm, microwaves are being absorbed by the utensil and it is not safe for use in the microwave oven. You probably have many items on hand in your kitchen right now that can be used as cooking equipment in your microwave oven. Just read through the following checklist.

Dinner plates

Many kinds of dinner-ware are microwave-safe. If in doubt consult the manufacturer's literature or perform the microwave test.

Glassware

Glassware that is heat-resistant is microwave-safe. This would include all brands of oven tempered glass cookware. However, do not use delicate glassware, such as tumblers or wine glasses, as these might shatter as the food warms.

Plastic storage containers

These can be used to hold foods that are to be quickly reheated. However, they should not be used to hold foods that will need considerable time in the oven as hot foods will eventually warp or melt plastic containers.

Paper

Paper plates and containers are convenient and safe to use in your microwave oven, provided that the cooking time is short and foods to be cooked are low in fat and moisture. Paper towels are also very useful for wrapping foods and for lining baking trays in which greasy foods such as bacon are cooked. In general, avoid coloured paper products as the colour may run. Some recycled paper products may contain impurities which could cause arcing or fires when used in the microwave oven.

Plastic cooking bags

Provided they are made specially for cooking, cooking bags are microwave safe. However, be sure to make a slit in the bag so that steam can escape. Never use ordinary plastic bags for cooking in your microwave oven, as they will melt and rupture.

Plastic microwave cookware

A variety of shapes and sizes of microwave cookware are available. For the most part, you can probably use items you already have on hand rather than investing in new kitchen equipment.

Pottery, stoneware and ceramic

Containers made of these materials are usually fine for use in your microwave oven, but they should be tested to be sure.

CAUTION

Some items with high lead or iron content are not suitable for cooking utensils.

Utensils should be checked to ensure that they are suitable for use in microwave ovens.

Food characteristics & Microwave cooking

Keeping an eye on things

The recipes in the book have been formulated with great care, but your success in preparing them depends on how much attention you pay to the food as it cooks. Always watch your food while it cooks. Your microwave oven is equipped with a light that turns on automatically when the oven is in operation so that you can see inside and check the progress of your food. Directions given in recipes to elevate, stir, and the like should be thought of as the minimum steps recommended. If the food seems to be cooking unevenly, simply make the necessary adjustments you think appropriate to correct the problem.

Factors affecting microwave cooking times

Many factors affect cooking times. The temperature of ingredients used in a recipe makes a big difference in cooking times. For example, a cake made with ice-cold butter, milk, and eggs will take considerably longer to bake than one made with ingredients that are at room temperature. All of the recipes in this book give a range of cooking times. In general, you will find that the food remains under-cooked at the lower end of the time range, and you may sometimes want to cook your food beyond the maximum time given, according to personal preference. The governing philosophy of this book is that it is best for a recipe to be conservative in giving cooking times. While overcooked food is ruined for good. Some of the recipes, particularly those for bread, cake, and custards, recommend that food be removed from the oven when they are slightly undercooked. This is not a mistake. When allowed to stand, usually covered, these foods will continue to cook outside of the oven as the heat trapped within the outer portions of the food gradually travels inward. If the food is left in the oven until it is cooked all the way through, the outer portions will become overcooked or even burnt. You will become increasingly skilful in estimating both cooking and standing times for various foods.

Density of food

Light, porous food such as cakes and breads cook more quickly than heavy, dense foods such as roasts and casseroles. You must take care when microwaving porous food that the outer edges do not become dry and brittle.

Height of food

The upper portion of tall food, particularly roasts, will cook more quickly than the lower portion. Therefore, it is wise to turn tall food during cooking, sometimes several times.

Moisture content of food

Since the heat generated from microwaves tends to evaporate moisture, relatively dry food such as roasts and some vegetables should either be sprinkled with water prior to cooking or covered to retain moisture.

Bone and fat content of food

Bones conduct heat and fat cooks more quickly than meat. Care must be taken when cooking bony or fatty cuts of meat that they do not cook unevenly and do not become overcooked.

Quantity of food

The number of microwaves in your oven remains constant regardless of how much food is being cooked. Therefore, the more food you place in the oven, the longer the cooking time. Remember to decrease cooking times by at least one third when halving a recipe.

Shape of food

Microwaves penetrate only about 2.cm into food, the interior portion of thick foods are cooked as the heat generated on the outside travels inward. Only the outer edge of food is cooked by microwave energy; the rest is cooked by conduction. The worst possible shape for a food that is to be microwaved is a thick square. The corners will burn long before the centre is even warm. Round thin foods and ring shaped foods cook successfully in the microwave.

Covering

A cover traps heat and steam which causes food to cook more quickly. Use a lid or microwave cling film with a corner folded back to prevent splitting.

Browning

Meats and poultry that are cooked fifteen minutes or longer will brown lightly in their own fat. Foods that are cooked for a shorter period of time may be brushed with a browning sauce such as worcestershire sauce, soy sauce or barbecue sauce to achieve an appetizing colour. Since relatively small amounts of browning sauces are added to food the original flavour of the recipe is not altered.

Covering with greaseproof paper

Greaseproofing effectively prevents spattering and helps food retain some heat. But because it makes a looser cover than a lid or clingfilm, it allows the food to dry out slightly.

Arranging and spacing

Individual foods such as baked potatoes, small cakes and hors d'oeuvres will heat more evenly if placed in the oven an equal distance apart, preferably in a circular pattern. Never stack foods on top of one another.

GB

Food characteristics & Microwave cooking

GB

Stirring

Stirring is one of the most important of all microwaving techniques. In conventional cooking, food is stirred for the purpose of blending. Microwaved food, however, is stirred in order to spread and redistribute heat. Always stir from the outside towards the centre as the outside of the food heats first.

Turning over

Large, tall foods such as roasts and whole chickens should be turned so that the top and bottom will cook evenly. It is also a good idea to turn cut up chicken and chops.

Placing thicker portions facing outwards

Since microwaves are attracted to the outside portion of food, it makes sense to place thicker portions of meat, poultry and fish to the outer edge of the baking dish. This way, thicker portions will receive the most microwave energy and the food will cook evenly.

Shielding

Strips of aluminium foil (which block microwaves) can be placed over the corners or edges of square and rectangular foods to prevent those portions from overcooking. Never use too much foil and make sure the foil is secured to the dish or it may cause 'arcing' in the oven.

Elevating

Thick or dense foods can be elevated so that microwaves can be absorbed by the underside and centre of the foods.

Piercing

Foods enclosed in a shell, skin or membrane are likely to burst in the oven unless they are pierced prior to cooking. Such foods include yolks and whites of eggs, clams and oysters and whole vegetables and fruits.

Testing if cooked

Food cooks so quickly in a microwave oven, it is necessary to test it frequently. Some foods are left in the microwave until completely cooked, but most foods, including meats and poultry, are removed from the oven while still slightly undercooked and allowed to finish cooking during standing time. The internal temperature of foods will rise between 5°F (3°C) and 15°F (8°C) during standing time.

Standing time

Foods are often allowed to stand for 3 to 10 minutes after being removed from the microwave oven. Usually the foods are covered during standing time to retain heat unless they are supposed to be dry in texture (some cakes and biscuits, for example). Standing allows foods to finish cooking and also helps flavour blend and develop.

To Clean Your Oven

1 Keep the inside of the oven clean

Food spatters or spilled liquids stick to oven walls and between seal and door surface. It is best to wipe up spillovers with a damp cloth right away. Crumbs and spillovers will absorb microwave energy and lengthen cooking times. Use a damp cloth to wipe out crumbs that fall between the door and the frame. It is important to keep this area clean to assure a tight seal. Remove greasy spatters with a soapy cloth then rinse and dry. Do not use harsh detergent or abrasive cleaners. The glass tray can be washed by hand or in the dishwasher.

2 Keep the outside of the oven clean

Clean the outside of your oven with soap and water then with clean water and dry with a soft cloth or paper towel. To prevent damage to the operating parts inside the oven, the water should not be allowed to seep into the ventilation openings. To clean control panel, open the door to prevent oven from accidentally starting, and wipe a damp cloth followed immediately by a dry cloth. Press STOP/CLEAR after cleaning.

3 If steam accumulates inside or around the outside of the oven door, wipe the panels with a soft cloth. This may occur when the microwave oven is operated under high humidity conditions and in no way indicates a malfunction of the unit.

4 The door and door seals should be kept clean. Use only warm, soapy water, rinse then dry thoroughly.

DO NOT USE ABRASIVE MATERIALS, SUCH AS CLEANING POWDERS OR STEEL AND PLASTIC PADS.

Metal parts will be easier to maintain if wiped frequently with a damp cloth.

Questions & Answers

Q What's wrong when the oven light will not glow?

A There may be several reasons why the oven light will not glow.
Light bulb has blown
Door is not closed

Q Does microwave energy pass through the viewing screen in the door?

A No. The holes, or ports, are made to allow light to pass; they do not let microwave energy through.

Q Why does the beep tone sound when a pad on the Control Panel is touched?

A The beep tone sounds to assure that the setting is being properly entered.

Q Will the microwave oven be damaged if it operates empty?

A Yes Never run it empty or without the glass tray.

Q Why do eggs sometimes pop?

A When baking, frying, or poaching eggs, the yolk may pop due to steam build up inside the yolk membrane. To prevent this, simply pierce the yolk before cooking. Never microwave eggs in the shell.

Q Why is standing time recommended after microwave cooking is over?

A After microwave cooking is finished, food keeps on cooking during standing time. This standing time finishes cooking evenly throughout the food. The amount of standing time depends on the density of the food.

Q Is it possible to pop corn in a microwave oven?

A Yes, if using one of the two methods described below

- 1 Popcorn-popping utensils designed specifically for microwave cooking.
- 2 Prepackaged commercial microwave popcorn that contains specific times and power outputs needed for an acceptable final product.

FOLLOW EXACT DIRECTIONS GIVEN BY EACH MANUFACTURER FOR THEIR POPCORN PRODUCT. DO NOT LEAVE THE OVEN UNATTENDED WHILE THE CORN IS BEING POPPED. IF CORN FAILS TO POP AFTER THE SUGGESTED TIMES, DISCONTINUE COOKING. OVERCOOKING COULD RESULT IN THE CORN CATCHING FIRE.

CAUTION

NEVER USE A BROWN PAPER BAG FOR POPPING CORN. NEVER ATTEMPT TO POP LEFTOVER KERNELS.

Q Why doesn't my oven always cook as fast as the cooking guide says?

A Check your cooking guide again to make sure you've followed directions correctly, and to see what might cause variations in cooking time. Cooking guide times and heat settings are suggestions, chosen to help prevent overcooking, the most common problem in getting used to a microwave oven. Variations in the size, shape, weight and dimensions of the food require longer cooking time. Use your own judgement along with the cooking guide suggestions to test food condition, just as you would do with a conventional cooker.

GB

Plug wiring information/ Technical Specifications

GB

Warning


This appliance must be earthed

The wires in this mains lead are colored in accordance with the following codes
 BLUE ~ Neutral
 BROWN ~ Live
 GREEN & YELLOW ~ Earth

As the colours of the wires in the mains lead of this appliance may not correspond with the coloured markings identifying the terminals in your plug proceed as follows:

The wire which is colored BLUE must be connected to the terminal which is marked with the letter N or Colored BLACK.

The wire which is colored BROWN must be connected to the terminal which is marked with the letter L or colored RED.

The wire which is colored GREEN & YELLOW or GREEN must be connected to the terminal which is marked with the letter E or .

If the supply cord is damaged, it must be replaced by the manufacturer or its service agent or a similarly qualified person in order to avoid a hazard;

Technical Specification

		MC-7684B / MC-7684BS
Power Input		230 V AC / 50Hz
Output		900 W (IEC60705 rating standard)
Microwave Frequency		2450 MHz
Outside Dimension		512mm(W) X 307 mm(H) X 510 mm(D)
Power	Microwave	1 300 Watts
	Grill	1 150 Watts
Consumption	Combination	2650 Watts
	Convection	1350 Watts(Max 2450 Watts)



LG Electronics Polska

www.lge.pl

KARTA GWARANCYJNA

KUCHENKA MIKROFALOWA

Nazwa sprzętu

Model^(*)

Nr fabryczny^(*)

Data sprzedaży^(*)

Imię i nazwisko klienta^(*)

Adres zamieszkania^(*)

Akceptuję warunki gwarancji i kwituję odbiór sprawnego sprzętu

2 lata gwarancji

^(*)wypełnia sprzedawca

.....
Pieczętka sklepu i podpis sprzedawcy

Szanowni Państwo!

Dziękujemy za dokonanie zakupu produktu marki LG i gratulujemy trafnego wyboru. Urządzenia marki LG, zaprojektowane i wyprodukowane według najnowszych technologii, reprezentują światowe standardy jakości i niezawodności – a jednocześnie są przyjazne dla użytkownika i jego środowiska naturalnego.

Przed rozpoczęciem korzystania ze sprzętu prosimy o dokładne zapoznanie się z procedurami instalacji oraz warunkami eksploatacji, szczegółowo opisanymi w Instrukcji Obsługi.

W przypadku jakichkolwiek problemów prosimy o zwrócenie się do Autoryzowanej Stacji Serwisowej LG Electronics (ASS). Nasza wyspecjalizowana sieć serwisowa służy Państwu wszelką pomocą w zakresie realizacji uprawnień gwarancyjnych oraz porad technicznych i eksploatacyjnych.

Warunki gwarancji.

1. Gwarancja dotyczy wyrobów powszechnego użytku dystrybuowanych w Polsce przez LG Electronics Polska Sp. z o. o. i jest ważna wyłącznie na terytorium Rzeczypospolitej Polskiej.
2. LG Electronics Polska Sp. z o. o. gwarantuje sprawne działanie sprzętu, na który wydana jest niniejsza Karta Gwarancyjna, pod warunkiem korzystania ze sprzętu zgodnie z przeznaczeniem i warunkami techniczno-eksploatacyjnymi opisanymi w Instrukcji Obsługi.
3. Karta gwarancyjna jest ważna, jeżeli sporządzona jest na oryginalnym druku i zawiera następujące dane: nazwę sprzętu, model, numer fabryczny, datę sprzedaży, pieczęć i podpis sprzedawcy oraz podpis klienta. Dokonywanie jakichkolwiek skreśleń lub poprawek w karcie gwarancyjnej pośaga za sobą jej unieważnienie.
4. LG Electronics Polska Sp. z o. o. udziela gwarancji na okres 24 miesięcy, licząc od daty sprzedaży sprzętu. Realizacja uprawnień gwarancyjnych odbywać się będzie po przedstawieniu w ASS ważnej Karty Gwarancyjnej wraz z dowodem zakupu oraz potwierdzeniu zgodności zapisów w karcie gwarancyjnej ze stanem faktycznym.
5. Wady ujawnione w okresie gwarancji usuwane będą bezpłatnie przez ASS, w możliwie krótkim terminie, nie przekraczającym 14 dni, licząc od daty przyjęcia sprzętu do naprawy.
6. Sprzęt powinien zostać dostarczony do ASS lub przekazany do transportu w oryginalnym opakowaniu fabrycznym. W przypadku braku opakowania fabrycznego ryzyko uszkodzenia sprzętu podczas transportu ponosi reklamujący. Reklamowany sprzęt winien odpowiadać podstawowym warunkom higienicznym przyjętym w obrocie.
7. Gwarancja objęta są wyłącznie uszkodzenia i wady powstałe z przyczyn tkwiących w sprzedanym urządzeniu. Nie są objęte gwarancją uszkodzenia powstałe z przyczyn zewnętrznych, jak np.: mechaniczne, spowodowane zjawiskami atmosferycznymi, zanieczyszczenia, zalania, uszkodzenia powstałe wskutek użycia niewłaściwych materiałów eksploatacyjnych (np. środków czyszczących).
8. Gwarancją nie są objęte czynności należące do normalnej obsługi eksploatacyjnej, np. zainstalowanie sprzętu, programowanie, czyszczenie i konserwacja, wymiana żarówek i bezpieczników, sprawdzanie działania. Usługi w/w są płatne przez Nabywcę.
9. Nabywca traci wszelkie prawa wynikające z gwarancji w przypadku stwierdzenia dokonywania nieautoryzowanych napraw lub zmian konstrukcyjnych. Gwarancja może nie mieć zastosowania w sytuacji, gdy sprzęt używany jest do celów przemysłowych, komercyjnych lub innych niezgodnych z przeznaczeniem.
10. Nabywcy przysługuje prawo wymiany sprzętu na nowy, jeżeli w okresie gwarancji dokonano czterech napraw, a sprzęt nadal wykazuje wady uniemożliwiające jego użytkowanie zgodnie z przeznaczeniem. Jeżeli wymiana na nowy jest niewykonalna Nabywcy przysługuje zwrot ceny zakupu.
11. LG Electronics Polska Sp. z o. o. nie będzie ponosiła odpowiedzialności za terminowość napraw gwarancyjnych jeżeli działalność sieci serwisowej zakłócona zostanie nieprzewidzianymi okolicznościami o charakterze siły wyższej.
12. Gwarancja nie wyłącza, nie ogranicza ani nie zawieszają uprawnień nabywcy wynikających z niezgodności towaru z umową (Ustawa z dn. 27.07.2002, Dz. U nr 141 poz. 1176)

Uwagi i reklamacje dotyczące działalności Autoryzowanych Stacji Serwisowych prosimy kierować do:

LG Electronics Polska Sp. z o. o.
Dział Obsługi Sieci Serwisowej
ul. Domaniewska 41
02-672 Warszawa

tel. (0-22) 874-30-78
fax. (0-22) 606-14-55
e-mail: service@lge.pl
<http://pl.lgservice.com>

Stacje serwisowe autoryzowane przez LG Electronics Polska

WOJEWÓDZTWO	MIASTO	NAZWA	ULICA	TEL	KIEROWNIK
dolnośląskie	Lębork	Autoryzowany Zakład Polar-Serwis	Kępiński 15	0-76 854 96-46	Czesław Leszczyński
dolnośląskie	Wieliczka	Z.U.H. AGD-SERWIS s.c.	Andersa 92	0-74 841 65-08	Sławomir Sułtys
dolnośląskie	Wrocław	PPHU "FRATER"	Jagiellońska 30a	0-71 321 02-93	Łucja Kłoc
kujawsko-pomorskie	Białogóra	FUH Service Autoryzowany AGD	Koyniska 6	0-52 379-31-02	Roman Buzkiewicz
kujawsko-pomorskie	Toruń	ZUH "Preston-Service"	Wojciecha Polakiego 43/45	0-56 823-15-03	Regina Muchalska
lubelskie	Biała Podlaska	Narawa Strzemu AGD	Francuska 2a	0-43 344-51-44	Roman Wolski
lubelskie	Lublin	PHUP "WOL-HURT-Service" s.c	Głębiny 19	0-61 534-67-37	Regina Muchalska
lubelskie	Węgrzynów-Podlaski	Narawa Strzemu AGD	Partyzantów 4a	0-45 371-72-08	Barbara Poznaniak
lubelskie	Zamość	Zakład Narawy AGD	Spasak 33	0-84 639-32-10	Zbigniew Szacko
lubuskie	Gorzów Wlkp.	UHZE "TELMISS"	Lokatka 32-33/9	0-65 735-22-22	Zbigniew Szacko
lubuskie	Gorzów Wlkp.	UHZE "TELMISS"	Wrocławskiego 39	0-65 724-03-79	Miroslaw Korzak
lubuskie	Gorzów Wlkp.	Zakład Handlowo-Usługowy "Olejarz"	Moskiewskiego 14	0-65 729-20-93	Elżbieta Słota
lubuskie	Zielona Góra	"ELDOM"	Okulickiego 35	0-48 326-22-37	Mieczysław Polowczak
łódzkie	Białzostka	ZUH "MGW" Service s.c.	Pieluskiego 2/8	0-46 874-26-30	Adam Welicki
łódzkie	Łęczyca	"AGD Service" Narawa Strzemu AGD	Blawy nad Boura 1/6	0-64 721 68-65	Mieczysław Polowczak
łódzkie	Łódź	ZUH "MGW" Service s.c.	Pomorska 100	0-42 678 92-92	Zbigniew Kusiel
łódzkie	Piotków Tyto	Handel Usługi AGD	Słowackiego 70	0-44 847-11-27	Mieczysław Polowczak
łódzkie	Rawa Mazowiecka	ZUH "MGW" Service s.c.	Pl. Piłsudskiego 6	0-46 814 23-37	Paweł Topolewski
łódzkie	Szczepanów	Narawa Strzemu AGD	Polska 35	0-43 827-40-32	Adam Welicki
łódzkie	Zgierz	"AGD Service" Narawa Strzemu AGD	Łęczycka 65	0-42 71 61-75	Marek Lis
małopolskie	Kraków	"Dom-Service" sp. z o.o.	Os. Wilowa 30	0-12 644-40-69	Włodzisław Kryniewski
małopolskie	Nowy Sącz	"ART-DOOM" Handel-Usługi AGD	Zamecznika 3	0-18 443-77-38	Adam Welicki
małopolskie	Tarnów	ZUH "WORS"	Główna 8a	0-14 826-00-99	Adam Welicki
mazowieckie	Pock	"AGD Service" Narawa Strzemu AGD	Bielska 57a	0-24 366 70-61	Miroslaw Kalin
mazowieckie	Radiom	PHU "Dom-Service"	Chrobrego 54	0-46 364-88-48	Andrzej Bulowski
mazowieckie	Radiom	PW "UNITRON" s.c.	Sobieskiego 1	0-46 333-13-80	Krzysztof Wigowski
mazowieckie	Siedlca	AGD-Service	Partyzantów 27a	0-25 632 72-08	Robert Ornoch
mazowieckie	Warszawa	Preston Service	Grodzka 207	0-22 819-40-68	Zbigniew Dzierżewski
opolskie	Cieplice	PHU "Barok-Jollymar"	Szarych Szeregów 23	0-77 403 02-00	Włodzisław Kryniewski
opolskie	Koszę	AZUH "Mio-Service AGD"	Legionów 2a	0-13 432-28-93	Włodzisław Kryniewski
opolskie	Przemysław	"Eko-Service"	Mickiewicza 9	0-16 676 77-05	Jerzy Stępek
opolskie	Racibórz	A.Z.U. "TECH-DOOM"	Dąbrowskiego 44	0-17 854-15-15	Marek Ostrowski
opolskie	Tarnobrzeg	Zakład Usługowy AGD	Kiełuski 24	0-15 622-35-74	Jenasz Rzeczycki
opolskie	Białystok	ZUH "ELDOM"	Warszawska 79	0-45 732-38-30	Artur Siemieniowski
opolskie	Lomża	ZUH SPRZĘTU AGD S.C.	Rządowa 12	0-46 21 16-32-74	Zdzisław Święcki
opolskie	Suwalski	AZU "Kuzniarski Service"	Liniarskiego 18	0-67 657 28-58	Henryk Kuzniarski
opolskie	Głubisz	PHU Eldom s.c.	Halina 16/9	0-68 520 13-25	Miroslaw Kaprinski
opolskie	Głubisz	PHU Eldom s.c.	Halina 9	0-68 885 15-15	Miroslaw Kaprinski
opolskie	Ślęsk	FHU "ARBEZ"	Piaskiego 70	0-59 843-54-68	Henryk Szewczyk
opolskie	Wieliczka	Hurtownia "PSU"	Oronowców Hełu 3	0-58 672 79-97	Jacek Pomocznicki
śląskie	Częstochowa	"OHM 2" s.c.	Wschylowa Skoczkiego 4/6	0-34 365 67-93	Artur Nosiński
śląskie	Gliwice	EuroService	Chrobrowska 1	0-32 231 56-14	Dariusz Kujac
śląskie	Gliwice	Zakład Usługowo-Handlowy	Jagiellońska 12	0-32 231 05-79	Józef Trzciński
śląskie	Katowice	ZUH "ELDOM"	Tysiąclecia 3	0-32 254-11-81	Andrzej Kosak
śląskie	Łódzki	ZUH "ELDOM"	Pogonia 2	0-33 865 16-12	Miroslaw Ochty
świętokrzyskie	Kielce	ZUH "Elektronum"	Chopinika 41	0-41 362 26-60	Ryszard Kucab
świętokrzyskie	Cielmierz	Autoryzowany PHU "Dom-Service"	Gorzewska 3	0-41 262 03-98	Zdzisław Szlachta
warmińsko-mazurskie	Elbląg	Narawa Strzemu AGD	Lokatka 44	0-55 237-94-05	Włodzisław Kryniewski
warmińsko-mazurskie	Olsztyn	Narawa Strzemu AGD	Barczka 9A	0-49 545 74-42	Szczepan Błogos
wielkopolskie	Konin	ZUH "DOMEL-SERVICE"	Al. Męgi 15	0-63 242 17-69	Aleksandra Jędrzejewska
wielkopolskie	Leszno	Narawa AGD	Chrobrego 35	0-65 529-94-38	Andrzej Nowakowski
wielkopolskie	Częstochowa	"Service RTV"	Konny 3	0-42 736 76-44	Jan Jas
wielkopolskie	Pila	UHZE "TELMISS"	Młynarska 4/4L	0-67 215 92-28	Zbigniew Szacko
wielkopolskie	Pila	UHZE "TELMISS"	Tęgorzowa 105/11	0-67 215 64-63	Zbigniew Szacko
wielkopolskie	Poznań	PHU "Mio-Service" s.c.	Os. Piarowska 18	0-61 977 53-11	Aleksander Marcial
zachodniopomorskie	Koszalin	PHU "AGRA"	Soyków 4	0-94 341 66-68	Ryszard Morigallo
zachodniopomorskie	Szczecin	MC Service s.c.	Ormińskiego 18	0-91 482 11-44	Dariusz Ojmer

Aktualne informacje o sieci autoryzowanych stacji serwisowych można uzyskać pod numerem telefonu: (0-22) 674 30 78 lub w witrynie internetowej www.lge.pl

ADNOTACJE O PRZEBIEGU NAPRAWY

Lp.	Data zgłoszenia sprzętu do naprawy	Data zakończenia naprawy	Data wydania sprzętu z serwisu	Opis naprawy	Pieczętka zakładu	Pokwitowanie klienta

<English>

Disposal of your old appliance

1. When this crossed-out wheeled bin symbol is attached to a product it means the product is covered by the European Directive 2002/96/EC.
2. All electrical and electronic products should be disposed of separately from the municipal waste stream via designated collection facilities appointed by the government or the local authorities.
3. The correct disposal of your old appliance will help prevent potential negative consequences for the environment and human health.
4. For more detailed information about disposal of your old appliance, please contact your city office, waste disposal service or the shop where you purchased the product.

<Czech>

Likvidace starých spotřebičů

1. Pokud je u výrobku uveden symbol pojízdného kontejneru v přeškrtnutém poli, znamená to, že na výrobek se vztahuje směrnice Evropské unie číslo 2002/96/EC.
2. Všechny elektrické a elektronické výrobky by měly být likvidovány odděleně od běžného komunálního odpadu prostřednictvím sběrných zařízení zřízených za tímto účelem vládou nebo místní samosprávou.
3. Správný způsob likvidace starého elektrického spotřebiče pomáhá zamezit možným negativním dopadům na životní prostředí a zdraví.
4. Blíží informace o likvidaci starého spotřebiče získáte u místní samosprávy, ve sběrném zařízení nebo v obchodě, ve kterém jste výrobek zakoupili.

<Slovak>

Likvidácia vášho starého prístroja

1. Keď sa na produkte nachádza tento symbol prečiarknutej smetnej nádoby s kolieskami, znamená to, že daný produkt vyhovuje európskej Smernici č. 2002/96/EC.
2. Všetky elektrické a elektronické produkty by mali byť zlikvidované oddelene od komunálneho odpadu prostredníctvom na to určených zberných zariadení, ktoré boli ustanovené vládou alebo orgánmi miestnej správy.
3. Správnou likvidáciou starých zariadení pomôžete predchádzať potenciálnym negatívnym následkom pre prostredie a ľudské zdravie.
4. Podrobnejšie informácie o likvidácii starých zariadení nájdete na miestnom úrade, v službe na likvidáciu odpadu alebo u predajcu, kde ste tento produkt zakúpili.

<Hungarian>

Régi eszközök ártalmatlanítása

1. A termékhez csatolt áthúzott, kerekes szeméttároló jel jelöli, hogy a termék a 2002/96/EC EU-direktíva hatálya alá esik.
2. Minden elektromos és elektronikai terméket a lakossági hulladéktól elkülönítve kell begyűjteni, a kormány vagy az önkormányzatok által kijelölt begyűjtő eszközök használatával.
3. Régi eszközeinek megfelelő ártalmatlanítása segíthet megelőzni az esetleges egészségre vagy környezetre ártalmas hatásokat.
4. Ha több információra van szüksége régi eszközeinek ártalmatlanításával kapcsolatban, tanulmányozza a vonatkozó környezetvédelmi szabályokat, vagy lépjen kapcsolatba az üzlettel, ahol a terméket vásárolta.

<Polish>

Utylizacja starych urządzeń

1. Kiedy do produktu dołączony jest niniejszy przekreślony symbol kołowego pojemnika na śmieci, oznacza to, że produkt jest objęty dyrektywą 2002/96/EC.
2. Wszystkie elektryczne i elektroniczne produkty powinny być utylizowane niezależnie od odpadów miejskich, z wykorzystaniem przeznaczonych do tego miejsc składowania wskazanych przez rząd lub miejscowe władze.
3. Właściwy sposób utylizacji starego urządzenia pomoże zapobiec potencjalnie negatywnemu wpływowi na zdrowie i środowisko.
4. Aby uzyskać więcej informacji o sposobach utylizacji starych urządzeń, należy skontaktować się z władzami lokalnymi, przedsiębiorstwem zajmującym się utylizacją odpadów lub sklepem, w którym produkt został kupiony.

