



**MICROWAVE/GRILL/CONVECTION
OVENMAGNETRON/GRILL/CONVECTIEOVEN
FOUR COMBINE MICRO-ONDES/GRIL/CONVECTION**

**OWNER'S MANUAL
GEBRUIKSAANWIJZING
MANUEL D'UTILISATION**

PLEASE READ THIS OWNER'S MANUAL THOROUGHLY BEFORE OPERATING.
LEES DEZE GEBRUIKERSHANDLEIDING AANDACHTIG ALVORENS DE OVEN TE
GEBRUIKEN.
LIRE ATTENTIVEMENT LE MANUEL AVANT D'UTILISER L'APPAREIL.

**MC-9283JR
MC-9283JRS
MC-9283JLR**

P/No: MFL33716102

Precautions

Precautions to avoid possible exposure to excessive microwave energy.

You cannot operate your oven with the door open due to the safety interlocks built into the door mechanism. These safety interlocks automatically switch off any cooking activity when the door is opened; which in the case of a microwave oven could result in harmful exposure to microwave energy.

It is important not to tamper with the safety interlocks.

Do not place any object between the oven front face and the door or allow food or cleaner residue to accumulate on sealing surfaces.

Do not operate your oven if it is damaged. It is particularly important that the oven door closes properly and that there is no damage to the: (1) door(bent), (2) hinges and latches (broken or loosened), (3) door seals and sealing surfaces.

Your oven should not be adjusted or repaired by anyone except qualified service personnel.

Warning

Please ensure cooking times are correctly set as over cooking may result in the FOOD catching fire and subsequent damage to your oven.

When heating liquids, e.g. soups, sauces and beverages in your microwave oven, delayed eruptive boiling can occur without evidence of bubbling. This could result in a sudden boil over of the hot liquid. To prevent this possibility the following steps should be taken:

- 1 Avoid using straight sided containers with narrow necks.
- 2 Do not overheat.
- 3 Stir the liquid before placing the container in the oven and again halfway through the heating time.
- 4 After heating, allow to stand in the oven for a short time, stir or shake them(especially the contents of feeding bottles and baby food jars) again carefully and check the temperature of them before consumption to avoid burns (especially, contents of feeding bottles and baby food jars). Be careful when handling the container.

Warning

Always allow food to stand after being cooked by microwaves and check the temperature of them before consumption. Especially contents of feeding bottles and baby food jars.

How the Microwave Oven Works

Microwaves are a form of energy similar to radio and television waves and ordinary daylight. Normally, microwaves spread outwards as they travel through the atmosphere and disappear without effect. Microwave ovens, however, have a magnetron which is designed to make use of the energy in microwaves. Electricity, supplied to the magnetron tube, is used to create microwave energy.

These microwaves enter the cooking area through openings inside the oven. A turntable or tray is located at the bottom of the oven. Microwaves cannot pass through metal walls of the oven, but they can penetrate such materials as glass, porcelain and paper, the materials out of which microwave-safe cooking dishes are constructed.

Microwaves do not heat cookware, though cooking vessels will eventually get hot from the heat generated by the food.

A very safe appliance

Your microwave oven is one of the safest of all home appliances. When the door is opened, the oven automatically stops producing microwaves. Microwave energy is converted completely to heat when it enters food, leaving no "left over" energy to harm you when you eat your food.


Precautions	2
Contents	3
Unpacking & Installing	4 ~ 5
Setting the Clock	6
Setting the Scroll Speed	7
Child Lock	8
Micro Power Cooking	9
Micro Power Level	10
Two Stage Cooking	11
Quick Start	12
Grill Cooking	13
Convection Cooking	14~15
Combination Cooking	16~17
Memory	18
Keep Warming	19
Quick Defrost	20~21
Auto Defrost	22
Auto Weight Defrost Guide	23
Auto Menus	24~27
Auto Cook	28~31
Auto Reheat	32~33
Auto Roast	34~35
More or less cooking	36
Rotisserie Assembly	37
Rotisserie Installation & Cooking	38~39
Heating or Reheating Guide	40
Fresh Vegetable Guide	41
Grill Cooking Guide	42
Important safety instructions	43~44
Microwave - safe Utensils	45
Food characteristics & Microwave cooking	46~47
Questions & Answers	48
Plug Wiring Information/Technical Specifications	49

Unpacking & Installing

By following the basic steps on these two pages you will be able to quickly check that your oven is operating correctly. Please pay particular attention to the guidance on where to install your oven. When unpacking your oven make sure you remove all accessories and packing. Check to make sure that your oven has not been damaged during delivery.

1

Unpack your oven and place it on a flat level surface.




GB



HIGH RACK



LOW RACK




ROTISSERIE BAR


GLASS TRAY



ROTATING RING




METAL TRAY



HANDLE

2

Place the oven in the level location of your choice with more than 85cm height but make sure there is at least 20cm of space on the top and 10cm at the rear for proper ventilation. The front of the oven should be at least 8cm from the edge of the surface to prevent tipping. An exhaust outlet is located on top or side of the oven. Blocking the outlet can damage the oven.



MC-9283JR
MC-9283JRS

MC-9283JLR

THIS OVEN SHOULD NOT BE USED FOR COMMERCIAL CATERING PURPOSES


3 Plug your oven into a standard household socket. Make sure your oven is the only appliance connected to the socket. **If your oven does not operate properly, unplug it from the electrical socket and then plug it back in.**

6 Press the **STOP** button, and press the **START** button six times to set 30 seconds of cooking time. You will hear a BEEP each time you press the button. Your oven will start before you have finished the sixth press; don't worry this is normal.




4 Open your oven door by pulling the **DOOR OPEN HANDLE**. Place the **ROTATING RING** inside the oven and place the **GLASS TRAY** on top.

7 The **DISPLAY** will count down from 30 seconds. When it reaches 0 it will sound BEEPS. Open the oven door and test the temperature of the water. If your oven is operating the water should be warm. **Be careful when removing the container it may be hot.**




YOUR OVEN IS NOW INSTALLED

5 Fill a **microwave safe container** with 300 ml (1/2 pint) of water. Place on the **GLASS TRAY** and close the oven door. If you have any doubts about what type of container to use please refer to page 45.



8 The contents of feeding bottles and baby food jars shall be stirred or shaken and the temperature checked before consumption, in order to avoid burns.

HOW TO USE THE ACCESSORY



Setting the Clock



GB

When your oven is plugged in for the first time or when power resumes after a power cut, a ' : ' will be shown in the display; you will have to reset the clock.

If the clock (or display) shows any strange looking symbols, unplug your oven from the electrical socket and plug it back in and reset the clock.

You can set either 12 hour clock or 24 hour clock.

In the following example I will show you how to set the time for 14:35 when using the 24 clock. Make sure that you have removed all packaging from your oven.

1 Make sure that you have correctly installed your oven as described earlier in this book.


Press **STOP/CLEAR**.



2 Press **SETTING** once.

Turn **DIAL** to select the CLOCK SETTING.

Press the **DIAL** to **ENTER**.




3 Turn **DIAL** to select the 24H.

Press the **DIAL** for hour confirmation.



4 Turn **DIAL** until display shows "14:00".

Press the **DIAL** to **ENTER**.



5 Turn **DIAL** until display shows "14:35".

Press the **DIAL** to **ENTER**.



Setting the Scroll Speed

You can set scroll speed.
In the following example I will show you how to set Slow scroll speed.
Make sure that you have removed all packaging from your oven.




When your oven is plugged in for the first time or when power resumes after a power cut, a ':' will be shown in the display; you will have to reset the scroll speed.

If display shows any strange looking symbols, unplug your oven from the electrical socket and plug it back in and reset the scroll speed.

Make sure that you have correctly installed your oven as described earlier in this book.


Press **STOP/CLEAR**.



Press **SETTING** once.

Turn **DIAL** to select the SCROLL SPEED SETTING.


Press the **DIAL** to **ENTER**.



GB

Turn **DIAL** until display shows "SLOW".

Press the **DIAL** to **ENTER**.



Child Lock



GB

Your oven has a safety feature that prevents accidental running of the oven. Once the child lock is set, you will be unable to use any functions and no cooking can take place. However your child can still open the oven door.

Press **STOP/CLEAR**.




Press and hold **STOP/CLEAR** until "**CHILD LOCKED**" appears on the display and **BEEP** sounds.

The **CHILD LOCK** is now set.

"**CHILD LOCKED**" will appear on the display.



To cancel **CHILD LOCK** press and hold **STOP/CLEAR** until "**CHILD LOCKED**" disappears. You will hear **BEEP** when it's released.



Micro Power Cooking

In the following example I will show you how to cook some food on 80% power for 5 minutes and 30 seconds.




Your oven has five microwave Power settings.

POWER	%	Power Output
HIGH MAX	100%	900W
MEDIUM HIGH	80%	720W
MEDIUM	60%	540W
DEFROST MEDIUM LOW	40%	360W(**)
LOW	20%	180W

Don't Use



METAL TRAY



ROTISSERIE

Make sure that you have correctly installed your oven as described earlier in this book.

Press **STOP/CLEAR**.




Press **MICRO**.




GB

Turn **DIAL** until display shows "720W".

Press the **DIAL** to **ENTER**.



Turn **DIAL** until display shows "5:30".



Press **START**.

When **cooking** you can increase or decrease cooking time by turning **DIAL**.



Micro Power Level

Your microwave oven is equipped with 5 power levels to give you maximum flexibility and control over cooking. The table below shows the examples of food and their recommended cooking power levels for use with this microwave oven.

POWER LEVEL	USE	POWER LEVEL (%)	POWER OUTPUT
HIGH	<ul style="list-style-type: none"> * Boil Water * Brown minced beef * Cook poultry pieces, fish, vegetables * Cook tender cuts of meat 	100%	900W
MEDIUM HIGH	<ul style="list-style-type: none"> * Reheating(Liquid) * Roast meat and poultry * Cook mushrooms and shellfish * Cook foods containing cheese and eggs 	80%	720W
MEDIUM	<ul style="list-style-type: none"> * Reheating(Mashed potato, Plated meal, Ready meal) * Prepare eggs * Cook custard * Prepare rice, soup 	60%	540W
DEFROST/ MEDIUM LOW	<ul style="list-style-type: none"> * All thawing * Melt butter and chocolate * Cook less tender cuts of meat 	40%	360W(**)
LOW	<ul style="list-style-type: none"> * Soften butter & cheese * Soften ice cream * Raise yeast dough 	20%	180W



Two stage Cooking

In the following example I will show you how to cook some food in two stages. The first stage will cook your food for 11 minutes on 900W the second will cook for 35 minutes on 360W power.



During two stage cooking the oven door can be opened and food checked. Close the oven door and press **START** and the cooking stage will continue.

At the end of stage1, BEEP sounds and stage 2 commences.


Should you wish to clear the programme press **STOP** twice.

In case of Auto Defrost cooking, you can cook the food in maximum three stages. (Auto Defrost + Stage 1 + Stage 2) Therefore you can Auto Defrost the food and cook it without resetting the oven at each stage.

Don't Use



METAL TRAY



ROTISSERIE

Press **STOP/CLEAR**.



Set the power and the cooking time for **stage 1**.
(You can omit this process for High power.)

Press **MICRO** key once to select 900W power and press the **DIAL** to **ENTER**.



GB


Turn **DIAL** until display shows "11:00".

Set the power and the cooking time for **stage 2**.

Press **MICRO**.

Turn **DIAL** until display shows "360W".

Press the **DIAL** to **ENTER**.



Turn **DIAL** until display shows "35:00".

Press **START**.



Quick Start

In the following example I will show you how to set 2 minutes of cooking on 900W power.




GB

The **QUICK START** feature allows you to set 30 seconds intervals of HIGH power cooking with a touch of the **Q-START** button.

Don't Use




METAL TRAY



ROTISSERIE

Press **STOP/CLEAR**.



Press **Q-START** four times to select 2 minutes on 900W power. Your oven will start before you have finished the fourth press.



During **Q-START** cooking, you can extend the cooking time up to 99 minutes 59 seconds by repeatedly pressing the **Q-START** button.



Grill Cooking

In the following example I will show you how to use the grill to cook some food for 12 minutes and 30 seconds.




This model is fitted with a **QUARTZ GRILL**, so preheating is not needed.

This feature will allow you to brown and crisp food quickly.

The metal tray is placed between a glass tray and a grill rack at the grill mode.


The grill rack (high rack) must be used during grill cooking.



Press **STOP/CLEAR**.




Press **GRILL**.



GB

Turn **DIAL** until display shows "12:30".



Press **START**.



When cooking you can increase or decrease cooking time by turning **DIAL**.



Convection Cooking

In the following example I will show you how to preheat the oven first, then cook some food at a temperature of 230 °C for 50 minutes.



GB

The convection oven has a temperature range of 40 °C and 100 °C~250 °C (180 °C is automatically available when convection mode is selected).

The oven has a ferment function at the oven temperature of 40°C. You may wait until the oven is cool because you cannot use a ferment function if the oven temperature is over 40°C.

When you use this function if the oven temperature is over 70°C Error code "E-05" displays.


Your oven will take a few minutes to reach the selected temperature.

Once it has reached correct temperature, your oven will BEEP to let you know that it has reached the correct temperature.

Then place your food in your oven: then tell your oven to start cooking.

1. To preheat.


Press **STOP/CLEAR**.



Press **CONVECTION**.



Turn **DIAL** until display shows "230C".



Press **START**.

Preheating will be started with displaying "PREHEAT".




Convection Cooking



If you do not set a temperature your oven will automatically select 180 °C, the cooking temperature can be changed by turning DIAL.

The convection rack (low rack) must be used during convection cooking.




2. To cook,

Press **STOP/CLEAR**.



Press **CONVECTION**.




GB

Turn **DIAL** until display shows "230C".

Press the **DIAL** for temperature confirmation.



Turn **DIAL** until display shows "50:00".



Press **START**.

When **cooking** you can increase or decrease cooking time by turning **DIAL**.



Combination Cooking



Your oven has a combination cooking feature which allows you to cook food with **heater** and **microwave** at the same time or alternately. This generally means it takes less time to cook your food.


You can set three kinds of micro power level (20%, 40% and 60%) in combi mode.

Microwave Power	
(%)	(Watts)
20	180
40	360
60	540

In the following example I will show you how to programme your oven with micro power 20% and grill for a cooking time of 25 minutes.


1. GRILL COMBINATION.

Press **STOP/CLEAR**.



Press **COMBI**.

Turn **DIAL** until display shows "GRILL COMBINATION".




Press the **DIAL** to **ENTER**.

Turn **DIAL** until display shows "180W".

Press the **DIAL** to **ENTER**.



Turn **DIAL** until display shows "25:00".



Press **START**.

When cooking you can increase or decrease cooking time by turning **DIAL**.



Be careful when removing your food because the container will be hot!

Combination Cooking

In the following example I will show you how to programme your oven with micro power 60% and at a convection temperature 200 °C for a cooking time of 25 minutes.



You can set three kinds of micro power level (20%, 40% and 60%) in combi mode.

Microwave Power	
(%)	(Watts)
20	180
40	360
60	540


2. CONVECTION COMBINATION.

Press **STOP/CLEAR**.



Press **COMBI**.

Turn **DIAL** until display shows "CONVECTION COMBINATION".



Press the **DIAL** to **ENTER**.

Turn **DIAL** until display shows "540W".




Press the **DIAL** to **ENTER**.

Turn **DIAL** until display shows "200C".



Press the **DIAL** for temperature confirmation.

Turn **DIAL** until display shows "25:00".



Press **START**.

When **cooking** you can increase or decrease cooking time by turning **DIAL**.



Be careful when removing your food because the container will be hot!

GB


Memory

This feature allows you to set and execute a frequently used single stage programme. Once the cooking programme is set, you can use it by pressing the Memory cook key. In the following example I will show you how to set the cooking programme for 10 minutes 30 seconds at power level 80%.





1. To Set

Press **STOP/CLEAR**.





Press **MEMORY**.

Turn the **DIAL** until display shows "MICROWAVE COOK" and then press the **DIAL** for confirmation.




Turn **DIAL** knob until display shows "720W".



Press the **DIAL** and turn the **DIAL** until display shows "10:30".

Press the **DIAL** to **ENTER**.



GB When MEMORY is set. The cooking programme is stored in the memory of your microwave oven. Your oven will be reset, if you unplug the microwave oven from the electrical socket. If you wish to change your MEMORY, simply enter a new cooking programme.

2. To Cook

When you cook, use it by pressing the **MEMORY** key.

Press **MEMORY** key.



Press **START**.



Keep Warming

In the following example I will show you how to keep warming at the temperature of 90 °C for 30 minutes.



The oven has a temperature range of 30 °C~90 °C when keep warming is selected.

When you press keep warming, 60 °C is set initially.

If you press START directly after keep warming was pressed, 99:59 is set automatically.

Your oven will take a few minutes to reach the selected temperature.

Once it has reached correct temperature, your oven will BEEP to let you know that it has reached the correct temperature.


Press **STOP/CLEAR**.



Press **KEEP WARMING**.


Turn the **DIAL** until display shows "90C".

Press the **DIAL** for temperature confirmation.




GB

Turn **DIAL** to set keep warming time until display shows "30:00".



Press **START**.

Keep warming will be started with displaying "KEEP WARM".



Quick Defrost

Use this function to thaw only 0.5kg of Minced meat very quickly. This will require a standing time to allow the center to thaw. In the following example will show you how to defrost 0.5kg of frozen minced meat.



Press **STOP/CLEAR**.

Weight the food that you are about to defrost. Be certain to remove any metallic ties or wraps; then place the food in your oven and close the oven door.



Press **QUICK DEFROST**.

The oven will start automatically.



During defrosting your oven will "BEEP", at which point open the oven door, turn food over and separate to ensure even thawing. Remove any portions that have thawed or shield them to help slow down thawing. After checking close the oven door and press **START** to resume defrosting.

Your oven will not stop defrosting (even when the beep sounded) unless the door is opened.


GB

Your oven has a microwave quick defrost setting (MEAT).

Don't Use



METAL TRAY



ROTISSERIE

QUICK DEFROST GUIDE

Use this function to defrost quickly for minced meat.

Remove the meat completely from its wrapping. Place the mince onto a microwave-safe plate. When beeps, at this point remove the mince from the microwave oven, turn the mince over and return to the microwave oven. Press start to continue. At the end of the program remove the mince from the microwave oven, cover with foil and allow to stand 5-15 minutes or until completely thawed.

<i>Category</i>	<i>Weight</i>	<i>Utensil</i>	<i>Instructions</i>
Minced Meat	0.5kg	Microwave ware (Flat plate)	Minced meat only Turn food over at beep After defrosting, let stand for 5-15 minutes.

GB

Auto Defrost




GB

Your oven has four microwave defrost settings:- **MEAT, POULTRY, FISH** and **BREAD**; each defrost category has different power settings.

Don't Use



METAL TRAY




ROTISSERIE

The temperature and density of food varies, I would recommend that the food is checked before cooking commences. Pay particular attention to large joints of meat and chicken, some foods should not be completely thawed before cooking. For example fish cooks so quickly that it is sometimes better to begin cooking while still slightly frozen. The **BREAD** programme is suitable for defrosting small items such as rolls or a small loaf. These will require a standing time to allow the centre to thaw. In the following example I will show you how to defrost 1.4Kg of frozen poultry.

Press **STOP/CLEAR**.


Weight the food that you are about to defrost. Be certain to remove any metallic ties or wraps; then place the food in your oven and close the oven door.



Press **AUTO DEFROST**.


Turn **DIAL** to select the **POULTRY** defrosting programme. "def2" appears on the display window.

Press the **DIAL** to **ENTER**.



Enter the **weight** of the frozen food that you are about to defrost.

Turn **DIAL** until display shows "1.4kg".



Press **START**.



During defrosting your oven will "BEEP", at which point open the oven door, turn food over and separate to ensure even thawing. Remove any portions that have thawed or shield them to help slow down thawing. After checking close the oven door and press **START** to resume defrosting.

Your oven will not stop defrosting (even when the beep sounded) unless the door is opened.

Auto weight defrost guide

- * Food to be defrosted should be in a suitable microwave proof container and place uncovered on the glass turntable.
- * If necessary, shield small areas of meat or poultry with flat pieces of aluminum foil. This will prevent thin areas becoming warm during defrosting. Ensure the foil does not touch the oven walls.
- * Separate items like minced meat, chops and bacon as soon as possible.
- * When BEEP, at this point remove the food from the microwave oven, turn the food over and return to the microwave oven. Press start to continue. At the end of the program, remove the food from the microwave oven, cover with foil and allow to stand until completely thawed. To thaw completely, for example joints of meat and whole chickens should STAND for a minimum of 1 hour before cooking.

Category	Weight Limit	Utensil	Food
Meat (dEF1)	0.1 ~ 4.0 kg	Microwave ware (Flat plate)	Meat Minced beef, Fillet steak, Cubes for stew, Sirloin steak, Pot roast, Rump roast, Beef burger, Lamp chops, Rolled roast, Cutlets(.2cm) Turn food over at beef After defrosting, let stand for 5-15 minutes.
Poultry (dEF2)			Poultry Whole chicken, Legs, Breasts, Turkey breasts(under 2.0kg) Turn food over at beef After defrosting, let stand for 20-30 minutes.
Fish (dEF3)			Fish Fillets, Steaks, Whole fish, Sea foods Turn food over at beef After defrosting, let stand for 10-20 minutes.
Bread (dEF4)	0.1 ~ 0.5 kg	Paper towel or flat plate	Sliced bread, Buns, Baguette, etc.

Auto Menus



GB


AUTO MENUS allow you to cook most of your special food (kebab, pizza, chicken) easily by selecting the food type and entering the weight of the food and you can easily use automatic function by pressing A. Cook, A. Reheat, A. Roast.

Auto Menus are composed of six buttons.

In Auto Menus, there are three special food menus (kebab, pizza, chicken)

In the following example, I will show you how to cook the chilled pizza of 0.3kg.

Press **STOP/CLEAR**.




Press **PIZZA**.




Turn **DIAL** to select your favorite pizza type of chilled pizza, fresh pizza, frozen pizza.

In this example, turn **DIAL** until display shows "Pc-1"



Press the **DIAL** for category confirmation.



Turn **DIAL** until display shows "0.3kg".



Press **START**.



<i>Category</i>	<i>Weight Limit</i>	<i>Utensil</i>	<i>Food Temp.</i>	<i>Instructions</i>
Kebab	0.2 - 1.0kg	Rotisserie over the metal tray	Refrigerated	<p>600g meat(lamb, beef) 2 tablespoon Salt 1 large onion Olive oil 1 skewer: approx.0.2-0.25kg</p> <ol style="list-style-type: none"> 1. Cut the meat into the small and equal pieces. Grate the onion and separate its juice. Mix the onion juice and olive oil. Then cover the pieces of meat with the olive oil and onion juice for 3-4 hours. 2. Fix the meat pieces into the skewers. Note that the skewers pass the meat center. Insert the roti-bar into the Roti-holder over the metal tray. 3. Adjust weight and press start. 4. After cooking, remove from the oven.

Category	Weight Limit	Utensil	Food Temp.	Instructions																																				
Chilled Pizza (Pc-1)	0.2 - 0.6kg	Low rack on the metal tray	Refrigerated	This function is for reheating leftover chilled pizza. Place chilled pizza on the low rack on the metal tray. After cooking, take food out immediately. Stand for 1~2 minutes.																																				
Fresh Pizza (Pc-2)	0.7 - 1.0kg	Metal tray on the low rack	Room	<table border="1" style="display: inline-table; margin-right: 20px;"> <thead> <tr> <th>Batter</th> <th>1.0kg</th> <th>0.7kg</th> </tr> </thead> <tbody> <tr> <td>Dry yeast(g)</td> <td>7</td> <td>4</td> </tr> <tr> <td>All-purpose flour(g)</td> <td>300</td> <td>200</td> </tr> <tr> <td>Water, tepid(ml)</td> <td>150</td> <td>100</td> </tr> <tr> <td>Sugar(g)</td> <td>8</td> <td>5</td> </tr> <tr> <td>Salt(g)</td> <td>5</td> <td>3</td> </tr> <tr> <td>Vegetable oil(tablespoon)</td> <td>3</td> <td>1 1/2</td> </tr> </tbody> </table> <table border="1" style="display: inline-table;"> <thead> <tr> <th>The others</th> <th>1.0kg</th> <th>0.7kg</th> </tr> </thead> <tbody> <tr> <td>Tomato puree(tablespoon)</td> <td>4</td> <td>3</td> </tr> <tr> <td>Canned tomatoes(g)</td> <td>300</td> <td>200</td> </tr> <tr> <td>Ham, precooked(g)</td> <td>80</td> <td>50</td> </tr> <tr> <td>Shredded mozzarella cheese(g)</td> <td>200</td> <td>100</td> </tr> </tbody> </table> <ol style="list-style-type: none"> 1. Combine a flour, yeast, sugar, salt and warm water. 2. Add oil and knead the batter well. And stand for 15-25 minutes on Convection 40°.... After finishing, knead again. 3. Drain the juice of canned tomatoes. 4. Grease the oil on the metal tray. Spread the batter on the metal tray. And prick the surface of the batter with a fork. 5. Place the tomato puree and canned tomatoes. 6. Place the other ingredients on the pie. 7. Sprinkle shredded mozzarella cheese on the pizza. 8. Choose the menu and press start without food. 9. The oven will beep at end of the preheating period. Open the door and place the prepared food on the low rack on the glass turntable. Press start to continue cooking. 10. After cooking, remove food from the oven and serve. 	Batter	1.0kg	0.7kg	Dry yeast(g)	7	4	All-purpose flour(g)	300	200	Water, tepid(ml)	150	100	Sugar(g)	8	5	Salt(g)	5	3	Vegetable oil(tablespoon)	3	1 1/2	The others	1.0kg	0.7kg	Tomato puree(tablespoon)	4	3	Canned tomatoes(g)	300	200	Ham, precooked(g)	80	50	Shredded mozzarella cheese(g)	200	100
Batter	1.0kg	0.7kg																																						
Dry yeast(g)	7	4																																						
All-purpose flour(g)	300	200																																						
Water, tepid(ml)	150	100																																						
Sugar(g)	8	5																																						
Salt(g)	5	3																																						
Vegetable oil(tablespoon)	3	1 1/2																																						
The others	1.0kg	0.7kg																																						
Tomato puree(tablespoon)	4	3																																						
Canned tomatoes(g)	300	200																																						
Ham, precooked(g)	80	50																																						
Shredded mozzarella cheese(g)	200	100																																						
Frozen Pizza (Pc-3)	0.1 - 0.6kg	Low rack on the metal tray	Frozen	This function is for cooking frozen pizza. Remove all package and place on low rack on the metal tray. After cooking, stand for 1~2 minutes.																																				

<i>Category</i>	<i>Weight Limit</i>	<i>Utensil</i>	<i>Food Temp.</i>	<i>Instructions</i>
Whole Chicken	0.8 - 2.4kg	Rotisserie over the metal tray	Refrigerated	<p>Whole chicken approx. 1.2kg (with skin) 2 large onions 3 tablespoon olive oil Salt</p> <ol style="list-style-type: none"> 1. Cover the chicken with the onion juice, salt and oil(or butter) for 3-4 hours. 2. Pierce the chicken with the roti-bar. Note that the bar pass through the chicken completely. 3. Tie its feet, wings and body with a cotton thread and insert the bar into the roti-holder over the metal tray. 4. Adjust weight and press start. 5. After cooking, remove from the oven. Stand covered with aluminium foil for 5 minutes before serving.

Auto Cook

In the following example I will show you how to cook 0.3kg of Rice. (Ac-2)




GB

AUTO COOK allows you to cook most of your favorite food easily by selecting the food type and entering the weight of the food.

Press **STOP/CLEAR**.





Press **AUTO COOK**.




Turn **DIAL** until display shows "Ac-2".


Press the **DIAL** for category confirmation.





Turn **DIAL** until display shows "0.3kg".


Press **START**.



Auto Cook	Category	Weight Limit	Utensil	Food Temp.	Instructions
 <p>Don't Use</p> <p>ROTISSERIE</p>	Jacket Potato (Ac-1)	0.1 - 1.0kg	Low rack on the metal tray	Room	<p>Choose medium sized potatoes 170 -200g. Wash and dry potatoes. Pierce the potatoes several times with a fork. Place the potatoes on the metal tray and glass tray. Adjust weight and press start. After cooking, remove the potatoes from the oven. Let stand covered with foil for 5 minutes. CAUTION: The grill and surrounding oven will get very HOT. Use oven gloves.</p>
	Rice (Ac-2)	0.1 - 0.4kg	Microwave- safe bowl	Room	<p>1. Place rice and boiling water with 1/4 to 1 teaspoon salt in a deep and large bowl. Place food in the oven. 2. After cooking, stir. Stand covered for 5 minutes.</p> <p>Notes : Add 300ml of boiling water per 100g white rice. Cover with plastic wrap and vent.</p>
	Pasta (Ac-3)	0.1 - 0.4kg	Microwave- safe bowl	Room	<p>1. Place pasta and boiling water with 1/4 to 1 teaspoon salt in a deep and large bowl. Place food in the oven. 2. After cooking, stir. Stand covered for 5 minutes.</p> <p>Notes : Add 400ml of boiling water per 100g pasta. Do not cover. Stir at least twice during cooking to prevent sticking.</p>

GB

Auto Cook	Category	Weight Limit	Utensil	Food Temp.	Instructions
<p>Don't Use</p>   <p>ROTISSERIE</p>	<p>Fresh Vegetable (Ac-4)</p>	<p>0.2 - 0.8kg</p>	<p>Microwave-safe bowl</p>	<p>Room</p>	<p>Place vegetables in a microwave-safe bowl. Add water. Cover with wrap. Adjust weight and press start. After cooking, stir and allow to stand for 2minutes. Add amount of water according to the quantity. ** 0.2kg - 0.4kg : 2 Tablespoon ** 0.5kg - 0.8kg : 4 Tablespoon</p>
	<p>Frozen Vegetable (Ac-5)</p>	<p>0.2 - 0.8kg</p>	<p>Microwave-safe bowl</p>	<p>Frozen</p>	<p>Place vegetables in a microwave-safe bowl. Add water. Cover with wrap. Adjust weight and press start. After cooking, stir and allow to stand for 2 minutes. Add amount of water according to the quantity. ** 0.2kg - 0.4kg : 2 Tablespoon ** 0.5kg - 0.8kg : 4 Tablespoon</p>
	<p>Fresh Fish (Ac-6)</p>	<p>0.1 - 0.6kg</p>	<p>Microwave-safe flan dish</p>	<p>Refrigerated</p>	<p>Whole fish, steaks - Oily fish : salmon, mackerel - White fish : cod, haddock Arrange in a single layer in a large microwave-safe flan dish. Add 2 tablespoons of lemon juice. Cover dish tightly with plastic wrap and pierce in several places. Place on the glass turntable. Adjust weight and press start. After cooking, remove the dish from the oven. Allow to stand for 3 minutes before serving.</p>

Auto Cook	Category	Weight Limit	Utensil	Food Temp.	Instructions
 <p>Don't Use ROTISSERIE</p>	French fries (Ac-7)	0.2 - 0.5kg	Metal tray on the High rack	Frozen	Spread frozen potato products out on the metal tray on the high rack. For the best results, cook in a single layer. After cooking, remove from the oven and stand for 1~2 minutes.
	Gratin (Ac-8)	0.5 - 1.2kg	Low rack on the Metal tray	Room	<p>Use this key to cook home made Gratins.</p> <p>* Potato Gratin *</p> <p>Ingredients 400g potatoes 100g onions(cut into thin slices) 2/3 tablespoon butter 3 slices of bacon 350g white sauce 80g shredded mozzarella cheese Salt, black pepper</p> <p>(White Sauce) 3 tablespoon butter, 5 tablespoon flour, 2 cups of milk Place butter in a large bowl. Microwave at HIGH until butter melts. Add flour and microwave for 2 minutes at HIGH. Add milk, salt and black pepper. Microwave at HIGH for 15 minutes. (During cooking, stir several times.)</p> <p>Method</p> <ol style="list-style-type: none"> 1. Bake potatoes for 7-8 minutes on Microwave HIGH. And then peel and slice into small size. Add salt, pepper. 2. Combine onions and butter in a bowl. Microwave at HIGH for 2 minutes. 3. Place one third of the white sauce in gratin dish. Add potatoes, onions and bacon. Cover with the rest of the white sauce. 4. Sprinkle with cheese. Place on low rack on the metal tray. After cooking, stand for 2~3 minutes.

GB

Auto Reheat



In the following example I will show you how to cook 0.3kg of Sauce. (rh-2)



GB


AUTO REHEAT cooking make food reheating convenient and easy to use. The oven has been pre-programmed to automatically reheat food.

Your oven has four **AUTO REHEAT** settings: Soup, Sauce, Chilled Meal, Frozen Meal.




Turn **DIAL** until display shows "rh-2".

press the **DIAL** for category confirmation.



Turn **DIAL** until display shows "0.3kg"



Category	Weight Limit	Utensil	Food Temp.	Instructions
Soup (rh-1)	0.2 - 0.6kg	Microwave-safe bowl	Room	Pour the soup into a microwave-safe bowl. Cover with lid or plastic wrap. After heating, stir. Allow to stand for 2 minutes with cover. And then stir again.
Sauce (rh-2)	0.2 - 0.6kg	Microwave-safe bowl	Room	Pour the sauce into a microwave-safe bowl. Cover with lid or plastic wrap. After heating, stir. Allow to stand for 2 minutes with cover. And then stir again.
Chilled meal (rh-3)	0.3 - 0.6kg	Own tray	Refrigerated	Pierce using a skewer on the surface. Place food on the glass turntable. After cooking, allow to stand for 2-3 minutes before serving. - Stirrable e.g : Spaghetti bolognese, Beef stew - Non-stirrable e.g : Lasagne, Cottage pie Note : For food contained in bag(s), pierce meat portion and rice/pasta portions, etc. - For stirrable foods, stir at beep. - Non-stirrable foods, it is not necessary to stir at beep.
Frozen meal (rh-4)	0.3 - 0.6kg	Own tray	Frozen	Same as above.

Auto Roast

In the following example I will show you how to cook 0.5kg of Roast Beef. (Ar-1)




GB

AUTO ROAST allows you to cook most of your favorite food easily by selecting the food type and entering the weight of the food.

Press **STOP/CLEAR**.




Press **AUTO ROAST**.



Turn **DIAL** until display shows "Ar-1".




Press the **DIAL** for category confirmation.



Turn **DIAL** until display shows "0.5kg".



Press **START**.



<i>Category</i>	<i>Weight Limit</i>	<i>Utensil</i>	<i>Food Temp.</i>	<i>Instructions</i>
Roast Beef (Ar-1)	0.5 - 1.8kg	Rotisserie over the metal tray	Refrigerated	<ol style="list-style-type: none"> 1. Brush the beef with melted margarine or butter. 2. Pierce the beef with the roti-bar. Note that the bar pass through the beef completely. 3. Tie the beef with a cotton thread and insert the bar into the roti-holder over the metal tray. 4. Adjust weight and press start. 5. After cooking, remove from the oven. Stand covered with foil for 10-15 minutes before serving.
Roast Pork (Ar-2)	0.5 - 1.8kg	Rotisserie over the metal tray	Refrigerated	<ol style="list-style-type: none"> 1. Brush the pork with melted margarine or butter. 2. Pierce the pork with the roti-bar. Note that the bar pass through the pork completely. 3. Tie the pork with a cotton thread and insert the bar into the roti-holder over the metal tray. 4. Adjust weight and press start. 5. After cooking, remove from the oven. Stand covered with foil for 10-15 minutes before serving.
Chicken Portions (Ar-3)	0.2 - 0.8kg	High rack on the metal tray	Refrigerated	<p>Wash and dry skin. Brush the chicken legs with melted margarine or butter. Place on the high rack on the metal tray.</p> <p>Adjust weight and press start.</p> <p>When beeps, turn food over. And then press start to continue cooking. After cooking, stand covered with foil for 2-5 minutes.</p>

More or Less Cooking

In the following example I will show you how to change the preset AUTO COOK programmes for a longer or shorter cooking time.



GB

If you find that your food is over or undercooked when using the AUTO COOK programme, you can increase or decrease cooking time by turning DIAL.

When cooking with auto and manual function, you can lengthen or shorten the cooking time at any point by turning DIAL.

There is no need to stop the cooking process.

Press **STOP/CLEAR**.



Set the required **AUTO COOK** programme.

Select weight of food.

Press **START**.




*See **AUTO COOK** (page 28).

Turn **DIAL** clockwise.

The cooking time will increase by **10** seconds for each turning DIAL.

Turn **DIAL** counterclockwise.


The cooking time will decrease by **10** seconds for each turning DIAL.



Rotisserie Assembly



1 Barbecue bars into the left plate




Screw the barbecue bar clockwise into the left plate

CAUTION


Rotisserie is not a toy.
Keep the Rotisserie away
from the child.

2 Assemble the right plate



Push barbecue bars into right plate.

3 Assemble skewers



Install the handle on the rotisserie.

Insert the pointed edge of the skewer into hole on the left plate.

Insert the other edge of the skewer into a hole on the right plate.

Turn it clockwise until it's fixed. Repeat 4 times until rotisserie is assembled.

GB

Rotisserie

Installation & Cooking




Chicken



Press **WHOLE CHICKEN** of **ROTISSERIE COOK**.

Turn **DIAL** in order to set weight.

Prepare foods with the rotisserie.



CAUTION

Rotisserie is not a toy. Keep the Rotisserie away from the child.

Tie the chicken's feet, wings and body with a cotton thread before cooking whole chicken as show in the picture.


Kebab



Press **KEBAB** of **ROTISSERIE COOK**.

Turn **DIAL** in order to set weight.

Clean the work space, before inserting the kebab.




Rotisserie Installation & Cooking



To Clean ROTISSERIE & METAL TRAY


When cooking is completed, separate the ROTISSERIE from the food. Take care when handling both ROTISSERIE & metal tray and food stuff as it is very hot. During cooking it is normal for the ROTISSERIE & metal tray to be stained from the food. Simply clean the ROTISSERIE & metal tray with a warm soapy water and a soft cloth. If the ROTISSERIE & metal tray remain stained after washing, Utensils in hot soapy water for a few minutes. Do not use metal scouring pads. They will scratch the surface .

Insert the shaft of right plate into the shaft of motor.



The shaft of motor

Put the shaft of left plate on the holder of rotisserie.



The holder of Rotisserie

Press **START**.



After cooking hold the rotisserie bar of both side with the handle and lift up the right end slightly and pull out from the left end.

NOTE:

1. The rotisserie cooking is convenient for grilling of meat and poultry. All the surface of the food will become even brown without overturning.
2. The rotisserie cooking can be used in grill mode, convection mode and Persian Cook.
3. The rotisserie bar is used for rotisserie cooking only. After rotisserie cooking is finished remove the rotisserie bar and store with other accessories.

CAUTION

1. **DO NOT USE THE METAL TRAY AND ROTISSERIE WITH NO LOAD, IT WILL BE DAMAGED THE OVEN.**
2. **AFTER COOKING, THE METAL TRAY WILL BECOME EXTREMELY HOT.**
3. It is recommended to remove the grease from the turntable every time before cooking. Hot grease on the turntable may cause smoke.



GB

Heating or Reheating Guide

To heat or reheat successfully in the microwave, it is important to follow several guidelines. Measure the amount of food in order to determine the time needed to reheat. Arrange the food in a circular pattern for best results. Room temperature food will heat faster than refrigerated food. Canned foods should be taken out of the can and placed in a microwavable container. The food will be heated more evenly if covered with a microwavable lid or vented plastic wrap. Remove cover carefully to prevent steam burns. Use the following chart as a guide for reheating cooked food.

Item	Cook time (at HIGH)	Special Instructions
Sliced meat 3 slices (0.5cm thick)	1~2 minutes	Place sliced meat on microwavable plate. Cover with plastic wrap and vent. • Note: Gravy or sauce helps to keep meat juicy.
Chicken pieces 1 breast 1 leg and thigh	2~3 minutes 3~3½ minutes	Place chicken pieces on microwavable plate. Cover with plastic wrap and vent.
Fish fillet (170-230g)	1~2 minutes	Place fish on microwavable plate. Cover with plastic wrap and vent.
Lasagne 1 serving(300g)	4~6 minutes	Place lasagne on microwavable plate. Cover with plastic wrap and vent.
Casserole 1 cup 4 cups	1½~3 minutes 4½~7minutes	COOK covered in microwavable casserole dish. Stir once halfway through cooking.
Casserole cream or cheese 1 cup 4 cups	1~2½ minutes 3½~6 minutes	COOK covered in microwavable casserole dish. Stir once halfway through cooking.
Sloppy Joe or Barbecued beef 1 sandwich (½ cup meat filling) without bun	1~2½ minutes	Reheat filling and bun separately. COOK covered in microwavable casserole dish. Stir once. Heat bun as directed in chart below.

Item	Cook time (at HIGH)	Special Instructions
Mashed potatoes 350 g	6~7 minutes (at Medium)	COOK covered in microwavable casserole dish. Stir once halfway through cooking.
Baked beans 1 cup	1½~3 minutes	COOK covered in microwavable casserole dish. Stir once halfway through cooking.
Ravioli or pasta in sauce 1 cup 4 cups	2½~4 minutes 7½~11 minutes	COOK covered in microwavable casserole dish. Stir once halfway through cooking.
Rice 1 cup 4 cups	1~1½ minutes 3½~5 minutes	COOK covered in microwavable casserole dish. Stir once halfway through cooking.
Sandwich roll or bun 1 roll	15~30 seconds	Wrap in paper towel and place on glass tray.
Vegetables 1 cup 4 cups	1½~2½ minutes 3½~5½ minutes	COOK covered in microwavable casserole dish. Stir once halfway through cooking.
Soup 1 serving (8 oz.)	1½~2 minutes	COOK covered in microwavable casserole dish. Stir once halfway through cooking.

Fresh Vegetable Guide

Vegetable	Amount	Cook time (at HIGH)	Instructions	Standing Time
Artichokes (230g each)	2 medium 4 medium	4 1/2 ~ 7 10 ~ 12	Trim. Add 2 tsp water and 2 tsp juice. Cover.	2~3 minutes
Asparagus, Fresh, Spears	450g	2 1/2 ~ 6	Add 1 cup water. Cover.	2~3 minutes
Green Beans	450g	7 ~ 11	Add 1/2 cup water in 1.5 litre casserole dish. Stir halfway through cooking.	2~3 minutes
Beets, Fresh	450g	11 ~ 16	Add 1/2 cup water in 1.5 litre covered casserole dish. Rearrange halfway through cooking.	2~3 minutes
Broccoli, Fresh, Spears	450g	5 ~ 8	Place broccoli in baking dish. Add 1/2 cup water.	2~3 minutes
Cabbage, Fresh, Chopped	450g	5 1/2-7 1/2	Add 1/2 cup water in 1.5 litre covered casserole dish. Stir halfway through cooking.	2~3 minutes
Carrots, Fresh, Sliced	200g	2 ~ 3	Add 1/4 cup water in 1.5 litre covered casserole dish. Stir halfway through cooking.	2~3 minutes
Cauliflower, Fresh, Whole	450g	5 ~ 7	Trim. Add 1/4 cup water in 1.5 litre covered casserole dish. Stir halfway through cooking.	2~3 minutes
Fresh, Flowerettes Celery, Fresh, Sliced	2 cups 4 cups	11 ~ 16	Slice. Add 1/2 cup water in 1.5 litre covered casserole dish. Stir halfway through cooking.	2~3 minutes

Vegetable	Amount	Cook time (at HIGH)	Instructions	Standing Time
Corn, Fresh	2 ears	4 ~ 8	Husk. Add 2 tbsp water in 1.5 litre baking dish. Cover.	2~3 minutes
Mushrooms, Fresh, Sliced	230g	1 1/2 ~ 2 1/2	Place mushrooms in 1.5 litre covered casserole dish. Stir halfway through cooking.	2~3 minutes
Parsnips, Fresh, Sliced	450g	4 ~ 7	Add 1/2 cup water in 1.5 litre covered casserole dish. Stir halfway through cooking.	2~3 minutes
Peas, Green, Fresh	4 cups	6 ~ 9	Add 1/2 cup water in 1.5 litre covered casserole dish. Stir halfway through cooking.	2~3 minutes
Sweet Potatoes Whole Baking (170~230g each)	2 medium 4 medium	4 ~ 9 6~ 12	Pierce potatoes several times with fork. Place on 2 paper towels. Turn over halfway through cooking.	2~3 minutes
White potatoes, Whole Baking (170~230g each)	2 potatoes 4 potatoes	5 1/2 ~ 7 1/2 9 1/2 ~ 14	Pierce potatoes several times with fork. Place on 2 paper towels. Turn over halfway through cooking.	2~3 minutes
Spinach, Fresh, Leaf	450g	4 1/2 ~ 7 1/2	Add 1/2 cup water in 2 litre covered casserole dish.	2~3 minutes
Courgette, Fresh, Sliced	450g	4 1/2 ~ 7 1/2	Add 1/2 cup water in 1.5 litre covered casserole dish. Stir halfway through cooking.	2~3 minutes
Courgette, Fresh, Whole	450g	6 ~ 9	Pierce. Place on 2 paper towels. Turn courgette over and rearrange halfway through cooking.	2~3 minutes

GB

Grill Cooking Guide

Directions for grilling meat on grill

- Trim excess fat from meat. Cut fat, making sure you do not cut into the lean. (This will stop the fat curling.)
- Arrange on the rack. Brush with melted butter or oil.
- Halfway through, turn the meat over.

Item	Weight	Approx. cooking time (in minutes)	Hints
Beefburgers	50g x 2 100g x 2	13-16 19-23	Baste with oil or melted butter. Thin items should be placed on the grill rack. Turn food over after half the cooking time.
Beefsteaks (2.5cm (1") thick)			
Rare Medium Well	230g x 2 230g x 2 230g x 2	18-20 22-24 26-28	
Lamb chops (2.5cm (1") thick)	230g x 2	25-32	Turn frequently.

Directions for grilling fish and seafood

Place fish and seafood on the rack. Whole fish should be scored diagonally on both sides before grilling. Brush fish and seafood with melted butter, margarine or oil before and during cooking. This helps stop the fish drying out. Grill for times recommended in the chart. Whole fish and fish steaks should be carefully turned over halfway through grilling time. If desired thick fillets can also be turned halfway.

Item	Weight	Approx. cooking time (in minutes)	Hints
Fish fillets			Brush with melted butter and turn over halfway through cooking.
1 cm (1/2") thick	230g	17-21	
1.5cm (1/2") thick	230g	20-24	
Fish steaks			
2.5 cm (1") thick	230g	24-28	
Whole fish	225-350g each 450g	16-20 24-28	Allow extra time for thick and oily fish.
Scallops	450g	16-20	Baste well during cooking.
Prawns uncooked	450g	16-20	

WARNING

Please ensure cooking times are correctly set as over cooking may result in **FIRE** and subsequent **DAMAGE** to the **OVEN**.

Important safety instructions

Read carefully and keep for future reference

- 1 Do not attempt to tamper with, or make any adjustments or repairs to the door, control panel, safety interlock switches or any other part of the oven. It is hazardous for anyone to carry out any service or repair operation which involves the removal of any cover which gives protection against exposure to microwave energy. Repairs should only be undertaken by a qualified service technician.
- 2 Do not operate the oven when empty. It is best to leave a glass of water in the oven when not in use. The water will safely absorb all microwave energy, if the oven is accidentally started.
- 3 Do not use the oven for the purpose of dehumidification. It can be the cause of serious damage of safety. (ex. Operating the microwave oven with the wet newspapers, clothes, toys, pet or portable electric devices, etc.)
- 4 Do not cook food wrapped in paper towels, unless your cook book contains instructions, for the food you are cooking.
- 5 Do not use newspaper in place of paper towels for cooking.
- 6 Do not use wooden containers. They may heat-up and char. Do not use ceramic containers which have metallic (e.g. gold or silver) inlays. Always remove metal twist ties. Metal objects in the oven may arc, which can cause serious damage.
- 7 Do not operate the oven with a kitchen towel, a napkin or any other obstruction between the door and the front edges of the oven, which may cause microwave energy leakage.
- 8 Do not use recycled paper products since they may contain impurities which may cause sparks and/or fires when used in cooking.
- 9 Do not rinse the turntable by placing it in water just after cooking. This may cause breakage or damage.
- 10 Small amounts of food require shorter cooking or heating time. If normal times are allowed they may overheat and burn.
- 11 Be certain to place the oven so the front of the door is 8 cm or more behind the edge of the surface on which it is placed, to avoid accidental tipping of the appliance.
- 12 Before cooking, pierce the skin of potatoes, apples or any such fruit or vegetable.
- 13 Do not cook eggs in their shell. Pressure will build up inside the egg which will burst.
- 14 Do not attempt deep fat frying in your oven.
- 15 Remove the plastic wrapping from food before cooking or defrosting. Note though that in some cases food should be covered with plastic film, for heating or cooking.
- 16 If the oven door or door seals are damaged, the oven must not be operated until it has been repaired by a qualified service technician.
- 17 If smoke is observed, switch off or disconnect the oven from the power supply and keep the oven door closed in order to stifle any flames.
- 18 When food is heated or cooked in disposable containers of plastic, paper or other combustible materials, check the oven frequently due to the possibility of the food container is deteriorating.
- 19 Only allow children to use the oven without supervision when adequate instructions have been given so that the child is able to use the oven in a safe way and understands the hazards of improper use.
- 20 Liquids or other foods must not be heated in sealed containers since they are liable to explode.
- 21 Do not operate the oven, if the door seals and adjacent parts of the microwave oven are faulty, until the oven has been repaired by a qualified service technician.
- 22 Check the utensils are suitable for use in microwave ovens before use.
- 23 Do not touch the oven door, outer cabinet, rear cabinet, oven cavity, accessories and dishes during grill mode, convection mode and auto cook operations, unless wearing thick oven gloves, as they will become hot. Before clearing make sure they are not hot.

Important safety instructions

Read carefully and keep for future reference

- 24 Only use utensils that are suitable for use in microwave ovens.
- 25 When heating food in plastic or paper containers, keep an eye on the oven due to the possibility of ignition.
- 26 If smoke is observed, switch off or unplug the appliance and keep the door closed in order to stifle any flames.
- 27 Microwave heating of beverages can result in delayed eruptive boiling, therefore care must be taken when handling the container.
- 28 The contents of feeding bottles and baby food jars shall be stirred or shaken and the temperature checked before consumption, in order to avoid burns.
- 29 Eggs in their shell and whole hard-boiled eggs should not be heated in microwave ovens since they may explode, even after microwave heating has ended.
- 30 Details for cleaning door seals, cavities and adjacent parts.
- 31 The oven should be cleaned regularly and any food deposits removed.
- 32 Failure to maintain the oven in a clean condition could lead to deterioration of the surface that could adversely affect the life of the appliance and possibly result in a hazardous situation.

- 33 Only use the temperature probe recommended for this oven (for appliances having a facility to use a temperature-sensing probe).
- 34 If heating elements are provided, during use the appliance becomes hot. Care should be taken to avoid touching heating elements inside the oven.
- 35 The appliance is not intended for use by young children or infirm persons without supervision.

- ⚠ WARNING:** If the door or door seals are damaged, the oven must not be operated until it has been repaired by a competent person.
- ⚠ WARNING:** It is hazardous for anyone other than a competent person to carry out any service or repair operation that involves the removal of a cover which gives protection against exposure to microwave energy.
- ⚠ WARNING:** Liquids and other foods must not be heated in sealed containers since they are liable to explode.
- ⚠ WARNING:** Only allow children to use the oven without supervision when adequate instructions have been given so that the child is able to use the oven in a safe way and understands the hazards of improper use.

Microwave-safe Utensils

Never use metal or metal trimmed utensils in your microwave oven

Microwaves cannot penetrate metal. They will bounce off any metal object in the oven and cause arcing, an alarming phenomenon that resembles lightning.

Most heat resistant non metallic cooking utensils are safe for use in your microwave oven. However, some may contain materials that render them unsuitable as microwave cookware. If you have any doubts about a particular utensil, there's a simple way to find out if it can be used in your microwave oven.

Place the utensil in question next to a glass bowl filled with water in the microwave oven. Microwave at power HIGH for 1 minute. If the water heats up but the utensil remains cool to the touch, the utensil is microwave-safe. However, if the water does not change temperature but the utensil becomes warm, microwaves are being absorbed by the utensil and it is not safe for use in the microwave oven. You probably have many items on hand in your kitchen right now that can be used as cooking equipment in your microwave oven. Just read through the following checklist.

Dinner plates

Many kinds of dinner-ware are microwave-safe. If in doubt consult the manufacturer's literature or perform the microwave test.

Glassware

Glassware that is heat-resistant is microwave-safe. This would include all brands of oven tempered glass cookware. However, do not use delicate glassware, such as tumblers or wine glasses, as these might shatter as the food warms.

Plastic storage containers

These can be used to hold foods that are to be quickly reheated. However, they should not be used to hold foods that will need considerable time in the oven as hot foods will eventually warp or melt plastic containers.

Paper

Paper plates and containers are convenient and safe to use in your microwave oven, provided that the cooking time is short and foods to be cooked are low in fat and moisture. Paper towels are also very useful for wrapping foods and for lining baking trays in which greasy foods such as bacon are cooked. In general, avoid coloured paper products as the colour may run. Some recycled paper products may contain impurities which could cause arcing or fires when used in the microwave oven.

Plastic cooking bags

Provided they are made specially for cooking, cooking bags are microwave safe. However, be sure to make a slit in the bag so that steam can escape. Never use ordinary plastic bags for cooking in your microwave oven, as they will melt and rupture.

Plastic microwave cookware

A variety of shapes and sizes of microwave cookware are available. For the most part, you can probably use items you already have on hand rather than investing in new kitchen equipment.

Pottery, stoneware and ceramic

Containers made of these materials are usually fine for use in your microwave oven, but they should be tested to be sure.

CAUTION

Some items with high lead or iron content are not suitable for cooking utensils.

Utensils should be checked to ensure that they are suitable for use in microwave ovens.

GB

Food characteristics & Microwave cooking

Keeping an eye on things

The recipes in the book have been formulated with great care, but your success in preparing them depends on how much attention you pay to the food as it cooks. Always watch your food while it cooks. Your microwave oven is equipped with a light that turns on automatically when the oven is in operation so that you can see inside and check the progress of your food. Directions given in recipes to elevate, stir, and the like should be thought of as the minimum steps recommended. If the food seems to be cooking unevenly, simply make the necessary adjustments you think appropriate to correct the problem.

Factors affecting microwave cooking times

Many factors affect cooking times. The temperature of ingredients used in a recipe makes a big difference in cooking times. For example, a cake made with ice-cold butter, milk, and eggs will take considerably longer to bake than one made with ingredients that are at room temperature. All of the recipes in this book give a range of cooking times. In general, you will find that the food remains under-cooked at the lower end of the time range, and you may sometimes want to cook your food beyond the maximum time given, according to personal preference. The governing philosophy of this book is that it is best for a recipe to be conservative in giving cooking times. While overcooked food is ruined for good. Some of the recipes, particularly those for bread, cake, and custards, recommend that food be removed from the oven when they are slightly undercooked. This is not a mistake. When allowed to stand, usually covered, these foods will continue to cook outside of the oven as the heat trapped within the outer portions of the food gradually travels inward. If the food is left in the oven until it is cooked all the way through, the outer portions will become overcooked or even burnt. You will become increasingly skilful in estimating both cooking and standing times for various foods.

Density of food

Light, porous food such as cakes and breads cook more quickly than heavy, dense foods such as roasts and casseroles. You must take care when microwaving porous food that the outer edges do not become dry and brittle.

Height of food

The upper portion of tall food, particularly roasts, will cook more quickly than the lower portion. Therefore, it is wise to turn tall food during cooking, sometimes several times.

Moisture content of food

Since the heat generated from microwaves tends to evaporate moisture, relatively dry food such as roasts and some vegetables should either be sprinkled with water prior to cooking or covered to retain moisture.

Bone and fat content of food

Bones conduct heat and fat cooks more quickly than meat. Care must be taken when cooking bony or fatty cuts of meat that they do not cook unevenly and do not become overcooked.

Quantity of food

The number of microwaves in your oven remains constant regardless of how much food is being cooked. Therefore, the more food you place in the oven, the longer the cooking time. Remember to decrease cooking times by at least one third when halving a recipe.

Shape of food

Microwaves penetrate only about 2 cm into food, the interior portion of thick foods are cooked as the heat generated on the outside travels inward. Only the outer edge of food is cooked by microwave energy; the rest is cooked by conduction. The worst possible shape for a food that is to be microwaved is a thick square. The corners will burn long before the centre is even warm. Round thin foods and ring shaped foods cook successfully in the microwave.

Covering

A cover traps heat and steam which causes food to cook more quickly. Use a lid or microwave cling film with a corner folded back to prevent splitting.

Browning

Meats and poultry that are cooked fifteen minutes or longer will brown lightly in their own fat. Food that are cooked for a shorter period of time may be brushed with a browning sauce such as worcestershire sauce, soy sauce or barbecue sauce to achieve an appetizing colour. Since relatively small amounts of browning sauces are added to food the original flavour of the recipe is not altered.

Covering with greaseproof paper

Greaseproofing effectively prevents spattering and helps food retain some heat. But because it makes a looser cover than a lid or clingfilm, it allows the food to dry out slightly.

Arranging and spacing

Individual foods such as baked potatoes, small cakes and hors d'oeuvres will heat more evenly if placed in the oven an equal distance apart, preferably in a circular pattern. Never stack foods on top of one another.

Food characteristics & Microwave cooking

Stirring

Stirring is one of the most important of all microwaving techniques. In conventional cooking, food is stirred for the purpose of blending. Microwaved food, however, is stirred in order to spread and redistribute heat. Always stir from the outside towards the centre as the outside of the food heats first.

Turning over

Large, tall foods such as roasts and whole chickens should be turned so that the top and bottom will cook evenly. It is also a good idea to turn cut up chicken and chops.

Placing thicker portions facing outwards

Since microwaves are attracted to the outside portion of food, it makes sense to place thicker portions of meat, poultry and fish to the outer edge of the baking dish. This way, thicker portions will receive the most microwave energy and the food will cook evenly.

Shielding

Strips of aluminium foil (which block microwaves) can be placed over the corners or edges of square and rectangular foods to prevent those portions from overcooking. Never use too much foil and make sure the foil is secured to the dish or it may cause 'arcing' in the oven.

Elevating

Thick or dense foods can be elevated so that microwaves can be absorbed by the underside and centre of the foods.

Piercing

Foods enclosed in a shell, skin or membrane are likely to burst in the oven unless they are pierced prior to cooking. Such foods include yolks and whites of eggs, clams and oysters and whole vegetables and fruits.

Testing if cooked

Food cooks so quickly in a microwave oven, it is necessary to test it frequently. Some foods are left in the microwave until completely cooked, but most foods, including meats and poultry, are removed from the oven while still slightly undercooked and allowed to finish cooking during standing time. The internal temperature of foods will rise between 59F (30C) and 150F (80C) during standing time.

Standing time

Foods are often allowed to stand for 3 to 10 minutes after being removed from the microwave oven. Usually the foods are covered during standing time to retain heat unless they are supposed to be dry in texture (some cakes and biscuits, for example). Standing allows foods to finish cooking and also helps flavour blend and develop.

To Clean Your Oven

1 Keep the inside of the oven clean

Food spatters or spilled liquids stick to oven walls and between seal and door surface. It is best to wipe up spills with a damp cloth right away. Crumbs and spillovers will absorb microwave energy and lengthen cooking times. Use a damp cloth to wipe out crumbs that fall between the door and the frame. It is important to keep this area clean to assure a tight seal. Remove greasy spatters with a soapy cloth then rinse and dry. Do not use harsh detergent or abrasive cleaners. The glass tray can be washed by hand or in the dishwasher.

2 Keep the outside of the oven clean

Clean the outside of your oven with soap and water then with clean water and dry with a soft cloth or paper towel. To prevent damage to the operating parts inside the oven, the water should not be allowed to seep into the ventilation openings. To clean control panel, open the door to prevent oven from accidentally starting, and wipe a damp cloth followed immediately by a dry cloth. Press STOP/CLEAR after cleaning.

3 If steam accumulates inside or around the outside of the oven door, wipe the panels with a soft cloth. This may occur when the microwave oven is operated under high humidity conditions and in no way indicates a malfunction of the unit.

4 The door and door seals should be kept clean. Use only warm, soapy water, rinse then dry thoroughly.

DO NOT USE ABRASIVE MATERIALS, SUCH AS CLEANING POWDERS OR STEEL AND PLASTIC PADS.

Metal parts will be easier to maintain if wiped frequently with a damp cloth.

GB

Questions & Answers

Q What's wrong when the oven light will not glow?

- A There may be several reasons why the oven light will not glow.
Light bulb has blown
Door is not closed

Q Does microwave energy pass through the viewing screen in the door?

- A No. The holes, or ports, are made to allow light to pass; they do not let microwave energy through.

Q Why does the beep tone sound when a pad on the Control Panel is touched?

- A The beep tone sounds to assure that the setting is being properly entered.

Q Will the microwave oven be damaged if it operates empty?

- A Yes Never run it empty or without the glass tray.

Q Why do eggs sometimes pop?

- A When baking, frying, or poaching eggs, the yolk may pop due to steam build up inside the yolk membrane. To prevent this, simply pierce the yolk before cooking. Never microwave eggs in the shell.

Q Why is standing time recommended after microwave cooking is over?

- A After microwave cooking is finished, food keeps on cooking during standing time. This standing time finishes cooking evenly throughout the food. The amount of standing time depends on the density of the food.

Q Is it possible to pop corn in a microwave oven?

- A Yes, if using one of the two methods described below
1 Popcorn-popping utensils designed specifically for microwave cooking.
2 Prepackaged commercial microwave popcorn that contains specific times and power outputs needed for an acceptable final product.

FOLLOW EXACT DIRECTIONS GIVEN BY EACH MANUFACTURER FOR THEIR POPCORN PRODUCT. DO NOT LEAVE THE OVEN UNATTENDED WHILE THE CORN IS BEING POPPED. IF CORN FAILS TO POP AFTER THE SUGGESTED TIMES, DISCONTINUE COOKING. OVERCOOKING COULD RESULT IN THE CORN CATCHING FIRE.

CAUTION

NEVER USE A BROWN PAPER BAG FOR POPPING CORN. NEVER ATTEMPT TO POP LEFTOVER KERNELS.

Q Why doesn't my oven always cook as fast as the cooking guide says?

- A Check your cooking guide again to make sure you've followed directions correctly, and to see what might cause variations in cooking time. Cooking guide times and heat settings are suggestions, chosen to help prevent overcooking, the most common problem in getting used to a microwave oven. Variations in the size, shape, weight and dimensions of the food require longer cooking time. Use your own judgement along with the cooking guide suggestions to test food condition, just as you would do with a conventional cooker.

Q Why is the Cooling fan operated after some cooking? Is the oven wrong?

- A When the oven inside is hot, the cooling fan is automatically operating to cool down the oven for short time. This is not fault.

Plug wiring information/ Technical Specifications

Warning


This appliance must be earthed

The wires in this mains lead are colored in accordance with the following codes
BLUE ~ Neutral
BROWN ~ Live
GREEN & YELLOW ~ Earth

As the colours of the wires in the mains lead of this appliance may not correspond with the coloured markings identifying the terminals in your plug proceed as follows:

The wire which is colored BLUE must be connected to the terminal which is marked with the letter N or Colored BLACK.

The wire which is colored BROWN must be connected to the terminal which is marked with the letter L or colored RED.

The wire which is colored GREEN & YELLOW or GREEN must be connected to the terminal which is marked with the letter E or .

If the supply cord is damaged, it must be replaced by the manufacturer or its service agent or a similarly qualified person in order to avoid a hazard;

Technical Specification

	MC-9283JR/MC-9283JRS/MC-9283JLR
Power Input	230 V AC / 50Hz
Output	900 W (IEC60705 rating standard)
Microwave Frequency	2450 MHz
Outside Dimension	574 mm(W) X 376 mm(H) X 510 mm(D)
Power Consumption	
Microwave	1350 Watts
Grill	1250 Watts
Combination	2600 Watts
Convection	1950 Watts

GB

Disposal of your old appliance

1. When this crossed-out wheeled bin symbol is attached to a product it means the product is covered by the European Directive 2002/96/EC.
2. All electrical and electronic products should be disposed of separately from the municipal waste stream via designated collection facilities appointed by the government or the local authorities.
3. The correct disposal of your old appliance will help prevent potential negative consequences for the environment and human health.
4. For more detailed information about disposal of your old appliance, please contact your city office, waste disposal service or the shop where you purchased the product.

Uw oude toestel wegdoen

1. Als het symbool met de doorgekruiste verrijdbare afvalbak op een product staat, betekent dit dat het product valt onder de Europese Richtlijn 2002/96/EC.
2. Elektrische en elektronische producten mogen niet worden meegegeven met het huishoudelijk afval, maar moeten worden ingeleverd bij speciale inzamelingspunten die door de lokale of landelijke overheid zijn aangewezen.
3. De correcte verwijdering van uw oude toestel helpt negatieve gevolgen voor het milieu en de menselijke gezondheid voorkomen.
4. Wilt u meer informatie over de verwijdering van uw oude toestel? Neem dan contact op met uw gemeente, de afvalphaaldienst of de winkel waar u het product hebt gekocht.

Élimination de votre ancien appareil

1. Ce symbole, représentant une poubelle sur roulettes barrée d'une croix, signifie que le produit est couvert par la directive européenne 2002/96/EC.
2. Les éléments électriques et électroniques doivent être jetés séparément, dans les vide-ordures prévus à cet effet par votre municipalité.
3. Une élimination conforme aux instructions aidera à réduire les conséquences négatives et risques éventuels pour l'environnement et la santé humaine.
4. Pour plus d'information concernant l'élimination de votre ancien appareil, veuillez contacter votre mairie, le service des ordures ménagères ou encore la magasin où vous avez acheté ce produit.

