



**LG**

Life's Good

# OWNER'S MANUAL LG DRYER

Please read this manual carefully before operating your dryer and retain it for future reference.


RC9041A3 / B3 / C3 / E3

# Features




## ● Ultra big Capacity Drum

The Ultra big 9.0kg capacity drum on this LG Dryer allows you to dry your washing in larger loads than ever before




## ● Lower Energy Consumption

LG dryers use less energy than conventional dryers due to the cutting-edge technology we have applied to the drying system and to the heat control mechanism. This LG Dryer has been designed to save your money.




## ● Reduced drying times

Drying times are now shorter due to the efficient air flow mechanism and optimised heater on this LG Dryer.



## ● Reduced noise levels

We have reduced the operating noise of this LG Dryer by using innovative sound-absorbing and noise-screening technologies, making it much quieter than conventional dryers.



## ● Dryers to Use

The wide, electronically controlled LED display on this machine is very easy to use. Simply select the programme you require and your LG Dryer will do the rest.

# Contents

|                                     |    |
|-------------------------------------|----|
| Safety Instructions .....           | 3  |
| Installation Instructions .....     | 6  |
| Appearance & Design .....           | 10 |
| Operating Your Dryer .....          | 11 |
| Additional Functions .....          | 15 |
| Caring for Your Dryer.....          | 17 |
| Additional Tips for Smart Use ..... | 20 |
| Troubleshooting Guidelines .....    | 22 |
| Technical Data .....                | 24 |
| Warranty .....                      | 25 |


# Safety Instructions

To help reduce any risk of electric shock, fire, or other personal or property injury when using your dryer, please follow basic safety instructions.

## ⚠ WARNING

Serious injury or death may occur when not observing the following rules.


### ⊘ Hazards



- Before plugging power cord, make sure cord is earthed and connected to circuit breaker.

.....


**No Earthing may cause breakdowns or an electric shock.**



- Do not use a damaged power cord or place heavy objects on the cord.

.....


**A damaged power cord may cause fire or electric shock**



- Do not plug into an adaptor. Do not use with an extension lead.

.....


**Abnormal heating of outlet may cause a fire.**



- Do not touch the plug or switch on with wet hands

.....


**May cause electric shock**



- Do not remove the top plate when installing the dryer.
- Do not modify this product.

.....


**May cause breakdown, fire or electric shock**



- Disconnect the power cord by grasping the plug, not the cord.

.....


**May cause wires to loosen resulting in fire**



- Keep the dryer away from cookers, naked flames, or any other inflammable objects.

.....

**May cause parts to melt or fire**




- Wipe dirt and stains from the power cord and insert firmly into the socket

.....


**Dirt and poor connections may cause fire**

# Safety Instructions




- Do not use if power cord, plug or socket is damaged

**May cause fire or electric shock**




- Keep pets away from the dryer

**Pets may damage the dryer, or may receive an electric shock**




- Do not install or store the dryer where it will be exposed to the weather.

**May cause fire, electric shock or malfunction**




- Do not depress buttons using sharp implements such as knives and screwdrivers

**May damage the dryer or cause electric shock**




- Do not use an extension cord or an adaptor to connect the power cord.

**May cause fire or electric shock**




- Do not dry articles that have been cleaned in, washed in, soaked in, or spotted with combustible or explosive substances (such as wax, oil, paint, gasoline, degreasers, dry-cleaning solvents, kerosene, etc.)

**May cause fire or electric shock**




- Do not splash water on to the dryer.

**May cause fire or electric shock**




- Do not place flammable items near the dryer.

**May cause toxic gases, parts damage, fire or explosion**



- Unplug the power cord when cleaning or not using the dryer.

**Water or dirt may cause an electric shock.**



- Before the appliance is removed from service or discarded, disassemble the door and cut off the power cord to prevent the future use.


**May cause accident and injury**



- Do not allow children or pets to play on or inside the dryer.
- The appliance is not intended for use by young children or infirm persons without supervision.
- Young Children should be supervised to ensure that they do not play with appliance.


**Children and pets may injure or suffocate themselves.**

# Safety Instructions




- If this appliance is supplied from a cord extension set or an electrical connector, portable outlet device must be positioned so that is not subject to splashing or ingress of moisture.

.....  
**It may cause an electric shock, a fire, malfunction and deformation.**




- Items that have been spotted or soaked with vegetable or cooking oil constitute a fire hazard and should not be placed in a tumble dryer.
- Items that have been soiled with substances such as cooking oil, acetone, alcohol, petrol, kerosene, spot removers, turpentine, waxes and wax removers should be washed in hot water with an extra amount of detergent before being dried in the tumble dryer.

.....  
**May cause spontaneous combustion leading to explosion and fire**



- Items that have been previously cleaned in washed in soaked in or spotted with petrol/gasoline, dry cleaning solvents or other flammable or explosive substances should not be used in a tumble dryer.

.....  
**May cause spontaneous combustion leading to explosion and fire**




- Items made of foam, rubber, plastic, or other heat-sensitive fabrics (such as bathroom rugs, nonslip mats or raincoats) should not be dried in a tumble dryer on a heat setting.
- Items such as foam rubber (latex foam), shower caps, waterproof textiles, rubber backed articles and clothes or pillows fitted with foam rubber pads should not be dried in the tumble dryer.

.....  
**May cause spontaneous combustion leading to explosion and fire**



- Plastic articles such as shower caps or waterproof nappy covers should not be placed in a tumble dryer.

.....  
**May cause spontaneous combustion leading to explosion and fire**



- If dryer is installed on a carpet, damage may be caused to it by ventilated air

.....  
**May cause spontaneous combustion leading to explosion and fire**

- Fabric softeners, or similar products, should be used as specified by the fabric softener instructions.
- To reduce the risk of personal injury, adhere to all industry recommended safety procedures including the use of long sleeved gloves and safety glasses. Failure to follow all of the safety warnings in this manual could result in property damage, personal injury or death.

# Installation Instructions

The following instructions will guide you through the initial steps of setting up your dryer. Please note that every section of this manual provides important information regarding the preparation and use of your dryer, and it is important that you review this entire manual before proceeding with any installation or use. Be sure to observe all listed warnings and cautions. These installation instructions are intended for use by qualified installers. Read these installation instructions completely and carefully.

## Safety Information

### Risk of Injury

The dryer is very heavy so you shouldn't try to lift it alone.

Do not lift the dryer by grasping any of the protruding parts e.g. or the jog dial or the door. they may break off.

### Risk of Tripping

Ensure there are no loose hoses or cables.

### Check the dryer for damage occurred during transportation.

Do not connect the dryer if it has visible signs of damage.

If you are not confident, contact your local LG agent. Always empty the dryer completely before transporting it.

Your dryer should not be located near to a gas hob, cooker, heater or grill, as flames from the burners could damage your dryer. When the dryer is fitted beneath a work surface, allow 30cm~50cm space at either side of the dryer and at the back of the dryer to allow air to exit the rear grille. This air flow is critical for condensation of water during the drying process.

If you use this dryer near or stacked on top of your washing machine, separate main plugs and sockets must be used for each appliance. Do not use 2-way adaptor or extension lead.

You can stack the dryer on top your washing of washing machine to save space. A stacking kit is available from your local shop.

## Stacking Installation Instructions

Your LG dryer can be placed on top of a front loading washing machine and securely fixed with a stacking kit (see following page for instructions). This installation must be conducted by an experienced installer to ensure it has been installed correctly.

An installer will ensure you have the correct stacking kit for your model of washing machine and will ensure it is firmly fixed. For these reasons, expert fitting is essential.

## ⚠ CAUTION

### CAUTION Concerning the power cord

Most appliances recommend they be placed upon a dedicated circuit; that is, a single outlet circuit which powers only that appliance and has no additional outlets or branch circuits. Check the specification page of this owner's manual to be certain.


Do not overload wall outlets. Overloaded wall outlets, loose or damaged wall outlets, extension cords, frayed power cords, or damaged or cracked wire insulation are dangerous. Any of these could result in electric shock or fire. Periodically examine the cord of your appliance, and if its appearance indicates damage or deterioration, unplug it, discontinue use of the appliance, and have the cord replaced with an exact replacement part by an authorized servicer.

Protect the power cord from physical or mechanical abuse, such as being twisted, kinked, trapped in a door, or walked upon. Pay particular attention to plugs, wall outlets, and the point where the cord exits the appliance.

# Installation Instructions

## Stacking Kit

In order to stack this dryer an LG stacking kit is required.




This dryer may only be stacked on top of an LG washer. DO NOT attempt to stack this dryer on any other washer, as damage, injury or property damage could result.

To stack this dryer, the support holder included with the stacking kit must be used.

| Shape | Washer Top plate size |                   | Support Holder |
|-------|-----------------------|-------------------|----------------|
|       | 21.7 inch (550mm)     | 23.6 inch (600mm) |                |
|       |                       |                   |                |

## Installation Procedure

1. Place the LG dryer on the LG Washing machine.
2. Remove the two screws from the bottom of the rear cover on each side as illustrated below.




## WARNING

- Incorrect installation can cause serious accidents.
- The weight of the dryer and the height of installation makes the stacking procedure too risky for one person. This procedure should be performed by 2 or more experienced service personnel.
- The dryer is not suitable for a built-in installation. Please do not install as a built-in.
- Do not operate if the dryer is disassembled.


3. Assemble the stacking kit as following.

- Peel the protective film from the double-sided tape on the bracket for your size washer.
- Attach the support holder.
- Align the stacking kit holes and the rear cover holes and then firmly attach the bracket to the side of the washer in that position.

23.6 inch(600 mm)




21.7 inch(550 mm)



4. Assemble the stacking kit as follows

- Screw the 2 screws that were removed earlier into the washer, dryer and stacking kit
- Use accessory screws [1.2inch (30mm)] to assemble washer rear cover and stacking kit. ②,③
- The procedure for the opposite side will be the same.



# Installation Instructions

## Earthing Instructions

This appliance must be earthed. In the event of malfunction or breakdown, earthing will reduce the risk of electric shock by providing a path of least resistance for the electric current.

This appliance is equipped with an earthed cord and an earthing plug. The plug must be plugged into an appropriate outlet that is properly installed and earthed in accordance with Standard.

## Additional Grounding Procedure


Some local codes may require a separate ground. In such cases, the required accessory ground wire, clamp and screw must be purchased separately.

## Condensed Water Drain

This appliance can be plumbed directly into the mains waste with the adaptor supplied. Condensed water will drain away. A plumber will be required.

## Note

For better drying performance, Please keep the rear of product away from wall.






# Installation Instructions

## ● Level the Dryer



1. Levelling the dryer prevents undesirable noise and vibration. Place your dryer on a solid, level floor

Place the dryer in an area free from flammable materials, condensation and not liable to freezing.



2. If the dryer is not properly level, adjust the front levelling legs as necessary.

Turn them clockwise to raise and counterclockwise to lower until the dryer is not wobbling both front-to-back and side-to-side.

### \* Diagonal Check


*When pushing down the edges of the machine, the machine should not move up and down at all.*

*(Please, check both of two directions)*


*If machine rocks when pushing the machine top plate diagonally, adjust the feet again.*

# Appearance & Design

## ● Product Layout



## ● Control Panel



# Operating Your Dryer

## Cycle Selection Table

| Sensor Dry Cycle  |   |  |              |
|---|---|--|--------------|
| Course  | Laundry type  | Detail   | Drying Level |
| Cotton Cycles<br><b>Note</b> Select the gentle cycle by pressing the option button for heat-sensitive items       | Towels, dressing gowns and bed linen  | For thick and quilted fabrics  | Extra        |
|   | Terry towels, tea towels, towels and bed linen  | For thick and quilted fabrics that do not need to be ironed            | Very         |
|   | Bath towels, tea towels, underwear and cotton socks   | For fabrics that do not need to be ironed                              | Cupboard     |
|   | Sheets, pillowcase and towels   | For fabrics that do not need to be ironed                              | Light        |
|   | Bed linen, table linen, towels, T-shirts, Polo shirts and work clothes                            | For fabrics that do need to be ironed                                  | Iron         |
| Mixed Fabric Cycles<br><b>Note</b> Select the gentle cycle by pressing the option button for heat-sensitive items | Bed linen, table linen, tracksuits, anorak and blankets   | For thick and quilted fabrics that do not need to be ironed            | Very         |
|   | Shirts and blouses  | For fabrics that do not need to be ironed                              | Cupboard     |
|   | Trousers, dressers, skirts and blouses  | For fabrics that do need to be ironed                                  | Iron         |
| Easy care   | Shirts, T-shirts, trousers, under wear and socks  | For polyamide, acrylic, and polyester that do not need to be ironed    | Cupboard     |
|   | Shirts, T-shirts, under wear, anoraks and socks   | For polyamide, acrylic, polyester that do need to be ironed            | Iron         |
| Bulky Item  | Bed clothes, sheets   | For bulky items  | -            |
| Quick Dry   | Linen and towels, excluding fabrics applied to Delicate, Sports wear, Wool and Bulky Item course. | For small loads of suitable fabrics with short drying times            | -            |
| Skin Care   | T-shirts, pillowcase, and towels  | For cotton fabrics which do not need to be ironed                      | -            |
| Refresh (Refer to the Note)   | Shirts and blouses  | Odor removal of fabric (For fabrics in need of odor removal)           | -            |
| Sports Wear   | Soccer kit and training wear  | For polyester material   | -            |
| Jeans   | Jeans and Color fading  | For jeans which do not need to be ironed                               | -            |
| Delicate  | Silk, Fine fabrics and lingerie   | For fabrics that are heat-sensitive like synthetic fabrics             | -            |
| Wool  | Wool  | For wool fabrics   | -            |
| Timed Drying Cycle  |   |  |              |
| Rack Dry  | Silk, wool, delicate lingerie   | Refresh clothes without tumble drying                                  | -            |
| Cool Air  | All fabrics that need refreshing  | Tumbles without heat   | -            |
| Warm Air  | Bath towels, bath robes, dishclothes and quilted fabrics made of acrylic                          | Small Items & damp clothing<br>Everyday items suitable for heat drying | -            |

### Note

When using the "Refresh" course, please spray cold or warm water on the fabric for a fresher outcome. (The recommend amount is 20cc of water per shirt.)

### CAUTION

If the load is less than 1kg, please use "Warm Air" Cycle in timed drying Cycle. Wool items should be dried using "Wool" Cycle and heat-sensitive fabrics including silk, underwear and lingerie should be dried using "Delicates" Cycle. Please comply with the recommended laundry load when you use the Assigned Cycle. Otherwise, your clothes may be damaged.

# Operating Your Dryer

## ● Please read before using your LG Dryer for the first time

※ After removing the packaging, please carry out the following checks to ensure the LG Dryer is correctly installed and ready for use. (see installation instructions)


1. Check the dryer is well balanced by using a spirit level. If not, adjust the feet of the LG Dryer until the machine is balanced.
2. Check the water container, condenser, control panel and drum to make sure everything is in place.
3. Set the machine to dry for 5 minutes to warm up the drum.
4. Open the door between loads the first few times you use the machine to allow any odours from the interior of the LG Dryer to escape.

## Note

The final part of a tumble dryer cycle occurs without heat (cool down cycle) to ensure that the items are left at a temperature that ensures that the items will not be damaged.

### 1. Turn the power on.

First, press the “Power” button. The indicator light above the button will become illuminated indicating that the machine is all set to run.




Turn the power on.

### 2. Open the door.

### 3. Check the lint filter and container are clean

All fabrics that need refreshing. Tumbles without heat. The lint filter is inside the door rim or in the back of the door. It needs to be cleaned before and after drying.

Open the door and check the lint filter is clean. If not, please clean it referring to page 17. Also check if water container or condenser need to be emptied and cleaned for better drying results.




Open the Door.

### 4. Place laundry into the drum after sorting.

The clothes should be sorted by fabric type and dryness level and all the strings and belts of clothes should be well tied and fixed before being put into the drum.

Push the laundry to the back to keep it away from the door seal.

If not, the door seal and clothes may be damaged.



Check the lint filter.

## ⚠ CAUTION

Do not dry unwashed items in the tumble dryer.

# Operating Your Dryer

## 5. Close the door.

Before you close the door, make sure fabrics are well placed inside and that foreign objects, especially flammable ones, are not caught around door.

### ⚠ CAUTION

- Be careful not to trap laundry between the loading door and rubber seal.

## 6. Select the drying cycle you want.

You can choose a cycle by turning the program control knob until the required program is indicated.

If you press Start/Pause button without choosing a cycle, the dryer will proceed with the Cupboard program. [Please refer to Cycle Selection table (page 11) for the detailed information.]

## 7. Press the start button.

You will hear drum rotating.

## 8. After the cycle has finished, open the door and remove the laundry.

Careful! the drum inside could still be hot.  
(Operation time varies depending on your cycle selection or options.)

### Note

The final part of a tumble dryer cycle occurs without heat (cool down cycle) to ensure that the items are left at a temperature that will not damage them.

## 9. Clean the lint filters and empty water container.


The lint filter should be cleaned after each load.

## 10. Turn off the dryer.


Press the "Power" button.

### ⚠ CAUTION


- if using a vacuum cleaner to clean the lint as it is easily damaged and torn. If there is a residue build up on the filter, scrub the lint screen with a brush to remove.
- If you want to open the door while dryer is operating, please press the Start/Pause button first, wait until drum completely stops and then open the door.



Select the desired cycle.



Take out the laundry.



Clean the door lint filter.

### ⚠ WARNING

Never stop a tumble dryer before the end of the drying cycle unless all items are quickly removed and spread out so that the heat is dissipated.

### ⚠ CAUTION

It must not be used for purposes other than those for which it was designed.

# Operating your dryer

## Rack Dry

The dryer Rack is placed inside the dryer like the picture. Remove and discard packing material before use. The Rack Dry is designed for use with items that you do not want to tumble dry including sweaters and delicate fabrics.


*To use the Rack Dry :*

1. Open the door.
2. Do not remove the lint screen.
3. Place dryer Rack over the bottom of the dryer door opening. Reset the Rack on the dryer back ledge. Push down on the frame front to secure over lint screen.
4. Place wet items on top of the Rack. Allow space around items for air to circulate. The Rack does not move, but the drum will rotate.
5. Close the door.
6. Select Rack Dry.


## Note

Check the lint filter and remove any lint accumulated from items dried on the Rack.


1. Insert wire edge to the drum centre.



2. Place delicate fabrics or sportshoes.



# Additional Functions



## ● Time Delay

You can use the Time Delay function to delay the finishing time of drying cycle. Maximum Time Delay is 19 hours. Minimum Time Delay is 3 hours.

1. Turn the dryer on
2. Select cycle
3. Set time delay hour
4. Press Start/Pause button

## ● Favorite

If you have a series of settings that you always seem to come back to, you can store this as a unique drying programme. For example, if your favorite setting is normally Extra Dry Cotton, with Low Temp and Anti-Crease, just select these settings and press "Favorite" until the dryer beeps. This programme is now stored as your Favorite and ready to be used again and again.

## ● Anti-Crease

The Anti Crease function prevents creases that are formed when the laundry is not unloaded promptly at the end of the drying cycle. When Anti Crease is selected, the dryer repeatedly runs and pauses, giving you 4 hours to unload the washing. If the door is opened during the Anti-Crease cycle, the cycle is cancelled.

## ● Drum Light

Whilst the dryer is running it is possible to see inside the drum if you select the Drum Light function.

# Additional Functions

## More Time/Less Time

Press More Time or Less Time until the desired drying time is set.

### Note

These buttons are available only with Timed Drying, before you push Start/Pause button.

### Note

The above functions can all be selected using the option button.

- Once : Gentle is selected.
- Twice : Damp Dry Beep option is selected.
- 3 Times : Gentle and Damp Dry Beep options are selected.
- 4 Times : No selected.

## Child Lock (CL)

For the safety of your children, press More Time and Less Time buttons at the same time for about 3 seconds. You will see “CL” sign on LED window.

- All controls except child lock and power Buttons will be disabled.
- Child lock lasts after the end of cycle.

### Note

For “CL” off, press More Time and Less Time buttons at the same time for about 3 seconds.

## Buzzer

This is a function to able to adjust volume of beeper sound.

## Option

### Gentle

- This function shortens or lengthens the cycle time by increasing or decreasing temperature.

- This option is used only with the Cotton and Mixed Fabric cycles.

### Damp Dry Beep

This function lets you know when the clothes are ready for ironing.

- This option is used only with the Cotton and Mixed Fabric cycles.

- You cannot use the 'Damp Dry Beep' when you select Iron Dry.

### Crease Care

- This function reduces creases.

- This is the default function when you select the Mixed Fabric And Easy Care Cycle and it cannot be cancelled.



# Caring for Your Dryer

## Care and Cleaning is very Important

It's not difficult to care for your dryer but it is important that you do care for it. Follow the instructions below

### Clean Lint Filter


Clean lint filter after each use and check it before each use. It should also be cleaned if the "Clean Filter" light becomes illuminated and the buzzer sounds during operation of the dryer:

Cleaning or emptying the filter will reduce drying times and energy consumption and lengthen the dryer life.


#### ⚠ CAUTION

- The lint trap has to be cleaned frequently, if applicable.
- Lint must not be allowed to accumulate around the tumble dryer.


1. Open the door.



2. Pull the filter out.




3. Clean the filter by using a vacuum cleaner or rinsing under the tap.



4. Replace the filter.

- Push the filter all the way down to avoid interference with the door.



5. Close the door.

#### ⚠ CAUTION

- After washing the lint filter please dry thoroughly
- Lint must not be left to accumulate in the dryer

### Clean lint filter during a cycle

If "Clean Filter" indicator lamp flashes during operation, clean the filter promptly.


1. Cool the dryer down and follow the mentioned steps.
2. Press the start/Pause button.

## Empty Water Container


Condensed water is collected in the water container.

**Empty the water container after every use.** Not doing so will affect the drying performance. If the water container is full, the "Empty Water" lamp glows and the buzzer sounds while the dryer is operating. If this should occur, the water container needs to be emptied within the next hour.

1. Draw water container out.



2. Empty water container to sink.



3. Push it back.

4. Press the Start/Pause button.

#### Note

A high atmospheric temperature and a small room may both increase drying time as well as energy consumption

#### ⚠ WARNING

Do not drink the condensed water.

#### ⚠ CAUTION

If the laundry is not spun at a high speed during washing, energy consumption and drying time will increase


In some instances, the laundry lamp may flash "Empty Water" and the dryer may stop because the water container is full

# Caring for Your Dryer


## Condenser

Condenser is also a very important part for efficient drying performance result so it needs a special care from you. It is recommended that condenser be cleaned three or four times a year or when the condenser clean lamp blinks.


1. Push the cap and open the condensing cover.




2. Open seal by turning the locking lever



3. Pull the condenser out by inserting a finger into the tab at the front of the condenser. (Don't force the condenser)




4. Clean the condenser thoroughly under a tap, letting the water flow through



5. Put everything back together by following the instructions in reverse order

### ⚠ CAUTION

The locking lever must be closed after cleaning the condenser as below.




### ⚠ CAUTION

- Operating when the condenser is clogged with lint can damage the dryer. This also increases energy consumption.
- Do not use sharp objects to clean the heat exchanger. This could cause damage and leaking.
- Never operate the dryer without the heat exchanger.

# Caring for Your Dryer

## Ventilation Grille and Cool Air Inlet Grille

Vacuum the front ventilation grille 3-4 times a year to make sure there is no build up of lint or dirt that could cause improper air flow




### Note

- Warm air is exhausted through the ventilation grill
- Adequate ventilation has to be provided to avoid the back flow of gases into the room from appliance's burning other fuels, including open fires.


## Condensed Water Drain-out

Normally, condensed water is pumped up to the water container where water is collected until manually emptied. Water can also be drained out directly to a mains drain, especially when the dryer is stacked on top of a washing machine. With a connecting kit for a mains drain hose, simply change the water path and reroute to the drainage facility as below:


1. Take connecting kit out.



2. Separate water container hose from the kit.




3. Connect drain hose to the kit.



## Moisture Sensor?

The device senses the moisture level of the laundry during operation, which means it must be cleaned regularly to remove any build up of lime scale on the surface of the sensor. Wipe the sensors inside drum (as illustrated)



# Additional Tips for Smart Use

## Drying Guide & Energy consumption

| PROGRAMME    |          | Ca. of Dryer         | Display Drying Time<br>(Including Cooling Time) | Energy Consumption |
|--------------|----------|----------------------|---|--------------------|
| Cotton       | Iron     | 9 kg                 | 97 min  | 3.81 kWh           |
|              | Light*   | 9 kg                 | 103 min   | 5.05 kWh           |
|              | Cupboard | 9 kg                 | 115 min   | 5.55 kWh           |
| Mixed Fabric | Cupboard | 4 kg                 | 48 min  | 1.70 kWh           |
| Easy Care    | Cupboard | 2 kg                 | 58 min  | 0.93 kWh           |
|              | Iron     | 2 kg                 | 51 min  | 0.54 kWh           |
| Bulky Item   |          | 1.5 kg               | 60 min  | 2.85 kWh           |
| Skin Care    |          | 2 kg                 | 118 min   | 2.85 kWh           |
| Refresh      |          | Dress Shirts Max.4EA | 20 min  | 0.50 kWh           |
| Sports Wear  |          | 1.5 kg               | 30 min  | 0.69 kWh           |
| Jeans        |          | 4.5 kg               | 36 min  | 1.80 kWh           |
| Delicate     |          | 1.5 kg               | 45 min  | 0.85 kWh           |
| Wool         |          | 1 kg                 | 21 min  | 0.45 kWh           |
| Quick Dry    |          | 2 kg                 | 50 min  | 1.41 kWh           |

\* Tested in accordance with EN61121 : 2005 test program

- Energy consumption might not be the same as the value in the "Energy Consumption" table by spin rpm of the washing machine, installation condition and using condition.

### WOOLLENS

Dry woollens on "wool" cycle. Be sure to follow fabric care label "symbols", first. Wool is not completely dried from the program so don't repeat drying. Pull woollens to their original shape and dry them flat.

### Woven and Loopknit Materials

Some woven and loop knit materials may shrink, depending on quality.

### Permanent Press and Synthetics

Do not overload your dryer. Take out permanent press items as soon as the dryer stops to reduce creases.

### Baby Clothes and Night Gowns

Always check the manufacturer's instructions.

### Rubber and Plastics

Do not dry any items made from or containing rubber or plastics such as:

- Aprons, Bibs and Chair Covers
- Curtains and Table Clothes
- Bathmats

### FIBREGLASS

Do not dry fiberglass articles in your dryer. Glass particles left in the dryer could be picked up by your clothes the next time you use the dryer and irritate your skin.















### Fabric Care Labels

Clothes have their own wash care labels, so drying according to the wash care label is recommended.

Not only that, the laundry must be sorted according to size and fabric type.

For the best drying performance and most efficient energy usage, do not overload the dryer.

*Below are fabric care labels.*

| Symbols  | Instructions                           |
|--|--|
|  | Dry                                    |
|  | Tumble dry                             |
|  | Permanent Press /<br>Wrinkle resistant |
|  | Gentle / Delicate                      |
|  | Do not tumble dry                      |
|  | Do not dry                             |
|  | High heating                           |
|  | Medium heating                         |
|  | Low heating                            |
|  | No heat / air                          |
|  | Line Dry / hang to dry                 |
|  | Drip dry                               |
|  | Dry flat                               |
|  | In the shade                           |

# Additional Tips for Smart Use

## Spare Parts

Spare parts that are required under the terms of warranty are provided free of charge. If the warranty has expired then spare parts must be purchased from the service centre.

## Disposal of the Dryer

It is requested that you dispose of your dryer safely to protect your children and others from possible injury.

The door, lid and other protruding parts must be removed and the power cord cut off before safe disposal.

## Service Contact


If there is a problem with your dryer, first consult the Trouble Shooting table. If you cannot find the error and you are unable to resolve the problem, please contact the Service Centre.

A Customer Service representative will ask you the following questions:


1. Name, address and postcode
2. Phone number
3. Description of problem
4. Model number and serial number of your dryer
5. Date of Purchase

## Accessory Parts

- Your dryer comes with accessories such as



## Stacking Kit



- Stacking kit Use
  - fig ① : Washer top plate size 550
  - fig ② : Washer top plate size 600

**If stacking is needed, you must stack the dryer upon LG washing machine. In order to do this, stacking kit must be purchased separately.**

# Troubleshooting Guidelines

## ● Troubleshooting Tips

To save you time and money, the following page will help answer your questions before service call.

| Questions                                | What to do  |
|--|---|
| <b>Dryer won't run</b>                   | <ol style="list-style-type: none"> <li>1. Check dryer is plugged in.</li> <li>2. Check "Start" button is pressed.</li> <li>3. Check door is properly closed.</li> <li>4. Check Room temperature is below 5°C.</li> <li>5. Check a fuse is not blown or the circuit breaker is tripped and replace them.<br/>(Caution : electric dryers generally use two fuses or breakers)<br/>After emptying the water container and Cleaning filter during operation, you must press Start button, then the dryer operates again.</li> </ol> |
| <b>It takes a long time to dry</b>       | <ol style="list-style-type: none"> <li>1. Filter should be cleaned after each load.</li> <li>2. Check water container is emptied.</li> <li>3. Check cleanness of condenser.</li> <li>4. Select correct programme setting for fabric type</li> <li>5. Check air ventilation grille or rear vents of dryer are not obstructed</li> <li>6. Check clothes are not excessively wet</li> <li>7. Check the dryer is not overloaded</li> <li>8. Check dryer is overloaded.</li> </ol>   |
| <b>"Clean Filter" lamp flashes</b>       | <ol style="list-style-type: none"> <li>1. Check filter is clean</li> <li>2. Check condenser unit is not clogged</li> </ol>  |
| <b>Clothes are covered in Fluff</b>      | <ol style="list-style-type: none"> <li>1. Check lint filter is empty.</li> <li>2. Check all the items in the dryer are clean</li> <li>3. Check all the laundry has been correctly sorted by fabric type</li> <li>4. Check laundry is not overloaded</li> <li>5. Check if there is any paper, tissues or other degradable items amongst the laundry and remove.</li> </ol>   |
| <b>The drying time is not consistent</b> | The drying time for a load will vary depending on the heat setting, the size of the load, the type of fabrics, the wetness of the clothes and the condition of the lint filter.   |
| <b>Water is leaking</b>                  | Check if the door or seal cover is dirty or damaged   |
| <b>The clothes are creased</b>           | Check the laundry is not overloaded. Try a shorter drying time and remove items whilst they still retain a slight amount of moisture. Use the anti-crease function  |
| <b>The garments have shrunk</b>          | To avoid shrinkage, please follow the care and use instructions for your garment, as some fabrics shrink naturally when washed and other fabrics should not be placed in a dryer.   |

# Troubleshooting Guidelines

---


## ● Error Mode

- *dE* : LED displays “*dE*” in case of the door open. The door must be closed and start Button must be pressed for re-operation.
- *EE1, EE3* : If error message continues to occur, unplug the power cord and call the Service Centre for advice.

## ● Drum light does not work

- Contact the customer service centre.

# T echnical Data



## ● Electrical Requirements

| Volts     | Hertz | Watts |
|-----------|-------|-------|
| 220-240 V | 50 Hz | 2600  |

Ensure you connect the dryer to the correct electricity voltage. The ratings plate on your dryer shows you what the voltage should be.


## ● Ventilation Requirement

| Alcove or undercounter                          | Closet  |
|---|---|
| Ensure air flow of 112 cu.ft./min through dryer | Closet door must have 2(louvered) openings, each having a minimum area of 60 sq. inches (387 sq.cm), located 3 inches (8 cm) from bottom and top of door. |



# Warranty

## Disposal of your old appliance



1. When this crossed-out wheeled bin symbol is attached to a product it means the product is covered by the European Directive 2002/96/EC.
2. All electrical and electronic products should be disposed of separately from the municipal waste stream via designated collection facilities appointed by the government or the local authorities.
3. The correct disposal of your old appliance will help prevent potential negative consequences for the environment and human health.
4. For more detailed information about disposal of your old appliance, please contact your city office, waste disposal service or the shop where you purchased the product.

## ■ What is not covered.

Service trips to your home to instruct you on the product.

If the product is connected to any voltage other than that shown on the rating plate.

Faults caused by accidental damage, neglect, misuse or Acts of God

If the fault is caused by reasons except for normal domestic use or use in accordance with the owner's manual.

Faults caused by vermin, for example rats, mice etc

Noise or vibration that is considered normal, for example, water drain sound, spin sound or warning beeps.

Correcting the installation for example, levelling the product, adjustment of drain.

Normal maintenance recommended by the owner's manual.

Removal of foreign objects/substances from the machine including the pump and inlet hose filter, for example, grit, nails, bra wires and buttons etc..

Replacing fuses, correcting wiring or correcting plumbing

Correction of unauthorized repairs.

Incidental or consequential damage to personal property caused by possible defects with this appliance.

If this product is used for commercial purposes its warranty is invalidated

(Example: Public places such as public bathroom, lodging house, training center, dormitory)

If the product is installed outside the normal service area, any cost of transportation involved in the repair of the products, or the replacement of a defective part, shall be borne by the owner.

# Memo

---

# Memo

---

