



Please read this manual carefully before operating your set and retain it for future reference.

MODELS

PH1 PH1L PH1R



Safety Information



CAUTION

RISK OF ELECTRIC SHOCK DO NOT OPEN



CAUTION: TO REDUCE THE RISK OF ELECTRIC SHOCK DO NOT REMOVE COVER (OR BACK) NO USER-SERVICEABLE PARTS INSIDE REFER SERVICING TO QUALIFIED SERVICE PERSONNEL.



This lightning flash with arrowhead symbol within an equilateral triangle is intended to alert the user to the presence of uninsulated dangerous voltage within the product's enclosure that may be of

sufficient magnitude to constitute a risk of electric shock to persons.



The exclamation point within an equilateral triangle is intended to alert the user to the presence of important operating and maintenance (servicing)

instructions in the literature accompanying the product.

WARNING: TO PREVENT FIRE OR ELECTRIC SHOCK HAZARD, DO NOT EXPOSE THIS PRODUCT TO RAIN OR MOISTURE.

CAUTION: The apparatus should not be exposed to water (dripping or splashing) and no objects filled with liquids, such as vases, should be placed on the apparatus.

WARNING: Do not install this equipment in a confined space such as a book case or similar unit.

CAUTION: Do not use high voltage products around this product. (ex. Electrical swatter) This product may malfunction due to electrical shock.

CAUTION: No naked flame sources, such as lighted candles, should be placed on the apparatus.

CAUTION: Do not block any ventilation openings. Install in accordance with the manufacturer's instructions.

Slots and openings in the cabinet are provided for ventilation and to ensure reliable operation of the product and to protect it from over heating. The openings shall be never be blocked by placing the product on a bed, sofa, rug or other similar surface. This product shall not be placed in a built-in installation such as a bookcase or rack unless proper ventilation is provided or the manufacturer's instruction has been adhered to.

CAUTION concerning the Power Cord

The Power Plug is the disconnecting device. In case of an emergency, the Power Plug must remain readily accessible.

Check the specification page of this owner's manual to be certain of the current requirements

Do not overload wall outlets. Overloaded wall outlets loose or damaged wall outlets, extension cords, frayed power cords, or damaged or cracked wire insulation are dangerous. Any of these conditions could result in electric shock or fire. Periodically examine the cord of your device, and if its appearance indicates damage or deterioration, unplug it, discontinue use of the device, and have the cord replaced with an exact replacement part by an authorized service center. Protect the power cord from physical or mechanical abuse, such as being twisted, kinked, pinched, closed in a door, or walked upon. Pay particular attention to plugs, wall outlets, and the point where the cord exits the device.

NOTICE: For safety marking information including product identification and supply ratings, please refer to the main label on the bottom or the other surface of the product.

CAUTION when using this product in environments of low humidity

- It may cause static electricity in environments of low humidity.
- It is recommended to use this product after touching any metal object which conducts electricity.

This device is equipped with a portable battery or accumulator.

How to Safely remove the batteries or the battery pack from the equipment: To Remove the old batteries or battery pack, follow the assembly steps in reverse order. To prevent contamination of the environment and bring on possible threat to human and/or animal health, the old batteries or the battery pack must be put in an appropriate container at designated collection points. Do not dispose of batteries or battery pack together with other waste. It is recommended that you use local, free reimbursement systems batteries or battery packs, (may not be available in your area). The batteries or the battery pack should not be exposed to excessive heat such as sunshine, fire or the like.

Symbols

| ~ | Refers to alternating current (AC). |
|-----|-------------------------------------|
| === | Refers to direct current (DC). |
| | Refers to class II equipment. |
| (h) | Refers to stand-by. |
| I | Refers to "ON" (power). |
| 4 | Refers to dangerous voltage. |

3

2

Table of Contents

1 Getting Started

- 2 Safety Information
- 6 Introduction
- 6 Accessories
- 7 Main Unit
- 8 Charging the Unit
- 8 Connecting the AC adapter
- 8 Checking Battery status
- 8 Checking the charging status

2 Operating

- 9 Basic Operations
- 9 Using power button
- 9 Bluetooth Connection
- 9 Simple Operation Guide
- 10 Bluetooth LED (BLUE) status
- 10 Bluetootii LLD (BLOL) Sta
- 10 Handsfree Function
- 11 Mood LED light
- 12 Listening to Music from Your External Device
- 12 Using BLUETOOTH® technology
- Listening to music stored on the BLUETOOTH devices
- 14 Other Operation
- 14 Resetting
- 14 Notice for Auto Power Off

3 Troubleshooting

15 Troubleshooting

4 Appendix

- 16 Trademarks and Licenses
- 16 Handling the Unit
- 17 Specifications

Introduction

Symbol used in this manual



Note

Indicates special notes and operating features.



Caution

Indicates cautions for preventing possible damages from abuse.

Accessories

Please check and identify the supplied accessories.






USB cable (1)

Simple Manual (1)

Main Unit



- 1 MIC
- 2 BLUETOOTH LED
- 3 6

Receives or redials on the **Bluetooth** device. (Refer to the page 10.)

4 >II

Starts or pauses playback on the ${\bf Bluetooth}$ mode.

5 ф/і

Turns On / Off: Press and hold it.

- 6 : Turn down the volume.
- 7 +: Turn up the volume.

- 8 Battery LED
- 9 ৡ

Turns on mood LED light. (Refer to the page 11.)


- 10 Portable In connector
 Listens to music from your portable device.
- 11 USB port for charging

Charging the Unit

Connecting the AC adapter

This device uses built-in battery. Before using it, charge the battery by connecting the AC Adapter.

- Connect the supplied USB cable to the AC adapter.
- 2. Connect the USB cable to USB port of of the unit.
- 3. Plug the AC adapter into an AC outlet.



If the battery is fully charged in charging mode, **EED** (RED) is turned off.

. (!)

!\ Caution

AC adapter is not supplied.

It is recommended that you use the 5 V AC adapter approved by LG Electronics Inc. (more than 1.8 A) with this speaker because of danger of explosion. If you do not use the recommended adapter, charging is unavailable or charging time may differ.

Checking Battery status

When AC Adapter is connected, battery charging is started. You can check the charging status by **EED** (RED).

| LED | Condition | Description |
|-----------------|--|-------------------------------|
| | Battery LED turns off. | Battery is full charged. |
| (O) | Battery LED blinks with the sound. | Battery is low. (Power on) |
| (7774) | Battery LED turns on. | Battery is charging. |



Note

- Operating time is approx. 5 hours. (Based on fully charged the battery and continuous playback using 50 % volume level.) It may vary depending on the battery status and operational conditions.
- If you listening the music while charging, it will take longer to charge.

Checking the charging status

If the power turned on, you can check the charging status by pressing **()/I** button. Then Mood LED light will blink depending on battery charging status.

| Mood LED light blinking | Battery Status |
|----------------------------|--------------------|
| 3 times | 1 ≥ 60 % |
| twice | □ ≥ 60~25 % |
| once | |




Note

When Mood LED light turn off, you can check battery charging status.

Basic Operations

Using power button



Power On / Off

Press and hold the **b/|** button for more than 2 seconds.

Bluetooth Connection



Play the desired music on the **Bluetooth** device. After pairing, you can control playback using the buttons on the front of the unit.

Simple Operation Guide

| Function | How to | Status |
|-------------------|---|---|
| Power On | Press and hold the 🖒/ button. | ≯ LED blinks with the sound. |
| Power Off | Press and hold the 🖒/ button. | \$ LED turns off with the sound. |
| Bluetooth pairing | When \$ LED blinks with the sound., select LG PH1 (XX) from device list on your smart device. | ≯ LED turns on with the sound. |
| Play / Pause | Press > . | - |
| Forward skip | Press > twice. | - |
| Backward skip | Press > three times. | - |
| Volume control | Press — or + | When this unit reaches minimum volume or maximum volume, you can hear beep sound. |

Bluetooth LED (BLUE) status

| LED | Condition | Description |
|--------|-------------------------------------|---------------------------------|
| * | ≯ LED blinks with the sound. | Searching for Bluetooth device. |
| • * | ★ LED turns on with the sound. | Bluetooth device is connected. |



Note

- Once pairing is performed, it does not need to be done again even if you turn off this unit.
- To disconnect the **Bluetooth** device, press and hold > | on the front of the unit for 3 seconds. The unit is disconnected.

Handsfree Function

You can receive incoming call and redial the last call on your **Bluetooth** device to this speaker. Connect the speaker to a **Bluetooth** device.



| Function | How to |
|-------------------------------|---------------------------------|
| Receive a call. | Press (". |
| Redial the last sending call. | Press 🌈 twice. |
| Reject a call. | Press (* for 2 seconds. |
| End the call. | Press (". |



You can adjust the call volume.

Mood LED light

You can turn on mood LED light on this speaker.

When you press & button, the mood LED light settings will be appeared in the order as below.




| Function | How to | Status |
|--------------------|------------------------------|---|
| Turns on | Press and hold the 🌣 button. | Turns on mood LED light. |
| Turns off | Press and hold the 🌣 button. | Turns off mood LED light. |
| Various colors | Press ў. | Changes automatically mood LED light color. (White→Green→Red) |
| White color | Press 🌣. | Turns on mood LED light. (White) |
| Music-synchronized | Press ў. | Synchronizes mood LED light to music. Music-synchronized option is available only when the speaker is on. |



Even though speaker is off, you can adjust mood LED light.

Listening to Music from Your External Device

The unit can be used to listen to the music from many types of external device.



- Connect the external device to the Portable In connector of the unit.
- 2. Turn the power on by pressing and holding **b/l** button.
- 3. Turn the external device on and start playing.



When you connect the portable cable, the function is changed to portable in mode automatically.

Using BLUETOOTH® technology

About BLUETOOTH

Bluetooth is wireless communication technology for short range connection.

The sound may be interrupted when the connection interfered by the other electronic wave or you connect the **Bluetooth** in the other rooms.

Connecting individual devices under **Bluetooth** wireless technology does not incur any charges. A mobile phone with **Bluetooth** wireless technology can be operated via the Cascade if the connection was made via **Bluetooth** wireless technology.

• Available Devices: Smart phone, MP3 player, etc.

Version: 3.0Codec: SBC

BLUETOOTH Profiles

In order to use **Bluetooth** wireless technology, devices must be able to interpret certain profiles. This unit is compatible with following profile. A2DP (Advanced Audio Distribution Profile)

Listening to music stored on the BLUFTOOTH devices

Pairing your unit and BLUETOOTH device

Before you start the pairing procedure, make sure the **Bluetooth** feature is turned on in to your **Bluetooth** device. Refer to your Bluetooth device's user guide. Once a pairing operation is performed, it does not need to be performed again.

- 1. Turn on the unit then \$\mathbb{L} LED blinks with the sound
- 2. Operate the **Bluetooth** device and perform the pairing operation. When searching for this unit with the Bluetooth device, a list of the devices found may appear in the **Bluetooth** device display depending on the type of Bluetooth device. Your unit appears as "LG PH1 (xx)".
- 3. Select "LG PH1 (xx)".



Note -

- · XX means the last two digits of Bluetooth address. For example, if your unit has a Bluetooth address such as 9C:02:98:4A:F7:08, you will see "LG PH1 (08)" on your Bluetooth device.
- Depending on the Bluetooth device type, some device have a different pairing way. Enter the PIN code (0000) as needed.
- 4. When this unit is successfully connected with your **Bluetooth** device, \$\\$ LED will turn on with the sound.
- 5. Listen to music. To play a music stored on your Bluetooth device, refer to your Bluetooth device's user quide.



Note

- When using Bluetooth technology, you have to make a connection between the unit and the **Bluetooth** device as close as possible and keep the distance.
 - However you may experience issues in the cases below:
 - There is an obstacle between the unit and the Bluetooth device.
 - There is a device using same frequency with **Bluetooth** technology such as a medical equipment, a microwave or a wireless I AN device.
- You should connect your **Bluetooth** device to this unit again when you restart it.
- The sound may be interrupted when the connection interfered by the other electronic wave.
- You may not control the Bluetooth device with this unit.
- Pairing is limited one **Bluetooth** device per one unit and multi-pairing is not supported.
- Depending on the type of the device, you may not be able to use the Bluetooth function.
- You can enjoy **Bluetooth** function using Smart phone, MP3 player, etc..
- The more distance between the unit and the **Bluetooth** device, the lower the sound quality becomes.
- Bluetooth connection will be disconnected. when the unit is turned off or the Bluetooth device gets too far from the unit.
- When Bluetooth connection is disconnected. connect the Bluetooth device to the unit again.
- When you connect **Bluetooth** device (iOS device etc.) to this unit or operate the device, the volume level can be synchronized with each other.
- When the unit is not connected. **Bluetooth** LED will blink.
- Bluetooth connection using the TV, PC or dongle is not supported.

Other Operation

Resetting

In case that the unit freezes due to malfunction, press > II and + buttons at the same time. Then the unit is turned off completely.

Notice for Auto Power Off

When the unit is in **Bluetooth** mode without music playback for 20 minutes or in portable input mode without button operation for 6 hours, this unit is turned off automatically.

Troubleshooting

| Problem | Cause & Correction |
|-------------------------------------|---|
| No Power. | The battery is discharged. Recharge the battery. Connect the unit to the power supply with the AC adapter. |
| No sound or sound distortion. | The unit or your smart device's volume is set to minimum. Check and adjust the volume of the unit or Bluetooth device's volume. |
| | When you use an external device at high volume, the sound quality may be deteriorated. Lower the volume of the devices. |
| | If you use the unit for purposes other than listening to music, the sound quality may be lowered or the unit may not work properly. |
| | Switch Bluetooth off and on again on your Bluetooth device, then try pairing again. |
| Bluetooth pairing does | Be sure your Bluetooth device is on. |
| not work well. | Remove the obstacle in the path of the Bluetooth device and the unit. |
| | Depending on the type of the Bluetooth device or surrounding environment, your device may not be paired with the unit. |
| The unit does not operate normally. | If the battery was fully discharged, the stored Bluetooth information can be deleted. Previous setting may not be saved when the unit's power is shut off. |
| | In case of malfunction, please use the unit in proper place where the temperature or humidity is not so high or low. |

Trademarks and Licenses



The **Bluetooth** word mark and logos are owned by the Bluetooth SIG, Inc. and any use of such marks by LG Electronics is under license.

Other trademarks and trade names are those of their respective owners.

Handling the Unit

When shipping the unit

Please save the original shipping carton and packing materials. If you need to ship the unit, for maximum protection, re-pack the unit as it was originally packed at the factory.

Keeping the exterior surfaces clean

- Do not use volatile liquids such as insecticide spray near the unit.
- · Wiping with strong pressure may damage the
- Do not leave rubber or plastic products in contact with the unit for a long period of time.

Cleaning the unit

To clean the player, use a soft, dry cloth. If the surfaces are extremely dirty, use a soft cloth lightly moistened with a mild detergent solution. Do not use strong solvents such as alcohol, benzine, or thinner, as these might damage the surface of the unit.

Specifications

| General | |
|------------------------|--|
| Power requirements | 5 V === 1.8 A (AC adapter) Built-in rechargeable battery |
| Power consumption | 2.5 W |
| Dimensions (W x H x D) | Approx. 81 mm X 88mm X 82 mm |
| Net Weight | Approx. 0.19 kg |
| Operating temperature | 0 °C to 35 °C |
| Operating humidity | 5 % to 60 % |

| Inputs | |
|----------|-------------------------------------|
| PORT. IN | 0.25 Vrms (3.5 mm stereo jack) |
| USB | Micro USB port for charging battery |

| Speaker | |
|-------------------|----------|
| Туре | Built-in |
| Impedance Rated | 4 Ω |
| Rated Input Power | 2 W |
| Max Input Power | 4 W |

| Battery | |
|------------------|--|
| Battery capacity | 700 mAh |
| Operating time | Approx. 5 hours. It may vary depending on the battery status and operational conditions. |
| Charging time | Less than 3 hours. The operating time can be varied depending on the conditions of the battery or operation. |

• Design and specifications are subject to change without notice.

