

INSTALLATION MANUAL

AIR-TO-WATER HEAT PUMP

Please read this installation manual completely before installing the product. Installation work must be performed in accordance with the national wiring standards by authorized personnel only. Please retain this installation manual for future reference after reading it thoroughly.

THERMA V™

Original instruction



MFL68681836
Rev.03_032624

Copyright © 2022 - 2024 LG Electronics Inc. All Rights Reserved.

www.lg.com

PORTUGUÊS

ENGLISH

MAGYAR

ITALIANO

БЪЛГАРСКИ

ESPAÑOL

SRPSKI

FRANÇAIS

HRVATSKI

DEUTSCH

SLOVENŠČINA

EAHNIKA

DANSK

ČEŠTINA

NEDERLANDS

POLSKI

LIMBA ROMÂNĂ

TABLE OF CONTENTS

6 PREFACE

[Chapter 1]

7 SAFETY INSTRUCTIONS

[Chapter 2]

15 INSTALLATION PART

[Chapter 3]

17 GENERAL INFORMATION

- 17 Model Information
- 19 Related Information
- 20 Parts and Dimensions
- 25 Control Parts
- 26 Control Panel
- 27 Typical Installation Example
- 30 Cycle Diagram
- 31 Water cycle

[Chapter 4]

32 INSTALLATION OF OUTDOOR UNIT

- 32 Conditions where Outdoor Unit is Installed
- 32 Drill a Hole in the Wall
- 33 Transporting the Unit
- 35 Installation at Seaside
- 36 Seasonal Wind and Cautions in Winter

[Chapter 5]

37 INSTALLATION OF INDOOR UNIT

- 37 Conditions where Indoor Unit is Installed
- 39 Transporting the Unit
- 40 Connecting Condensate drainage
- 40 Front Panel Removal
- 41 Floor area requirement : Indoor unit

- 42 Ventilation requirements
- 45 Electrical Wiring

[Chapter 6]

48 PIPING AND WIRING FOR OUTDOOR UNIT

- 48 Refrigerant Piping
- 49 Preparation for Piping
- 50 Connecting Pipe to Indoor Unit
- 50 Connecting Pipe to Outdoor Unit
- 53 Finalizing
- 54 Leakage test and Evacuation
- 56 Electrical Wiring

[Chapter 7]

60 PIPING AND WIRING FOR INDOOR UNIT

- 60 Water Piping and Water Circuit Connection
- 62 Connection to the Domestic hot water system
- 65 Connection to the Heating system
- 67 Water Volume and Expansion Vessel Pressure
- 68 Water Charging
- 70 Water pump Capacity
- 70 Pressure Drop
- 71 Performance curve
- 72 Water Quality
- 72 Frost protection by antifreeze

[Chapter 8]

73 ACCESSORIES INSTALLATION

- 74 Before Installation
- 75 Thermostat
- 78 2nd Circuit
- 81 3rd Party Boiler
- 82 3rd Party Controller
- 83 Meter Interface
- 84 Central Controller
- 86 Dry Contact
- 89 External Controller - Setting up programmable digital input operation
- 90 Remote Temperature Sensor
- 92 External pump

4 TABLE OF CONTENTS

93	Wi-fi Modem
94	Energy State
95	Digital Input for energy saving (ESS, Smart Grid)
96	2Way Valve
97	Domestic hot water expansion vessel – integrated into the unit
98	Final check

[Chapter 9]

99 CONFIGURATION

99	DIP Switch Setting
----	--------------------

105 SERVICE SETTING

105	How to enter service setting
105	Service setting
106	Service contact
107	Model information
108	RMC version information
109	Open source license

110 INSTALLER SETTING

110	How to enter installer setting
111	Installer setting
115	Select Temperature Sensor
116	Use Heating Tank Heater
117	Mixing Circuit
120	Use External Pump
121	RMC master/slave
122	LG Therma V Configuration
123	Forced operation
124	Pump Prerun/Overrun
125	Water Flow Control
126	Energy Monitoring
127	Anti-Freezing Option 1
128	Password Reset
129	Heating temp. setting
130	Air heating set temp.
131	Water heating set temp.
132	Hysteresis Heating Water
133	Hysteresis Room Air(Heating)
134	Pump setting in heating
135	Heater on temperature
136	Screed drying

138	Cooling temp. setting
139	Air cooling set temp.
140	Water cooling set temp.
141	Water supply off temp. during cooling
143	Hysteresis Cooling Water
144	Hysteresis Room Air(Cooling)
145	Pump setting in cooling
146	Seasonal auto temp.
148	DHW set temp.
149	Tank disinfection setting 1, 2
150	Tank setting 1
151	Tank setting 2
153	DHW time setting
155	Recirculation time
156	Pump test run
157	Frost Protection Temp.
158	Dry Contact Mode
159	Central Control Address
160	CN_CC
161	Modbus Address
162	Modbus gateway memory map
165	CN_EXT
166	3rd Party Boiler
167	Meter Interface
168	Energy state
170	Thermostat control type
171	Pump operation time
172	IDU operation time
173	Current flow rate
174	Data logging

[Chapter 10]

175 COMMISSIONING

175	Check List before Starting Operation
176	Starting Operation
177	Starting Operation flow chart
177	Airborne Noise Emission
178	Vacuum & Charge of Refrigerant
180	Decommissioning and Recycling
182	Reset of the thermal protection of the electrical heater
183	Troubleshooting
188	Open Source Software Notice Information

PREFACE

This installation manual is to present information and guide about understanding, installing, and checking **THERMAV™**.

Your careful reading before installation is highly appreciated to make no mistake and to prevent potential risks. The manual is divided into ten chapters. These chapters are classified according to installation procedure. See the table below to get summarized information.

Chapters	Contents
Chapter 1	- Warning and Caution concerned with safety. - This chapter is directly related with human safety. We strongly recommend reading this chapter carefully.
Chapter 2	- Items Inside product Box - Before starting installation, please make it sure that all parts are found inside the product box.
Chapter 3	- Fundamental knowledge about THERMAV™. - Model identification, accessories information, refrigerant and water cycle diagram, parts and dimensions, electrical wiring diagrams, etc. - This chapter is important to understand THERMAV™.
Chapter 4	- Installation about the outdoor unit. - Installation location, constraints on installation site, etc
Chapter 5	- Installation about the indoor unit. - Installation location, constraints on installation site, etc - Constrains when accessories are installed
Chapter 6	- How to perform piping (for refrigerant) and wiring at the outdoor unit. - Refrigerant pipe connection between the indoor unit and the outdoor unit. - Electrical wiring at the outdoor unit.
Chapter 7	- How to perform piping (for water) and wiring at the indoor unit. - Water pipe connection between the indoor unit and pre-built under floor water loop pipe. - Electrical wiring at the indoor unit. - System set-up and configuration. - As many control parameters of THERMAV™ is adjustable by control panel, deep understanding about this chapter is required to secure the operation flexibility of THERMAV™. - For more detailed information, please read the separate operation manual to use control panel and adjust control parameters.
Chapter 8	- Information about supported accessories - Specification, Constraints, and wiring are described. - Before purchasing accessories, please find supported specification to buy proper one.
Chapter 9	Test operation and check point while test running.
Chapter 10	- Check points before starting operation are explained. - Troubleshooting, maintenance, and error code list are presented to correct problems.

**REMARK : ALL CONTENTS OF THIS MANUAL ARE SUBJECT TO CHANGE WITHOUT NOTICE.
TO GET THE LATEST INFORMATION, PLEASE VISIT LG ELECTRONICS WEB SITE.**

* The feature may be vary according to the type of model.

SAFETY INSTRUCTIONS

	Read the precautions in this manual carefully before operating the unit.		This appliance is filled with flammable refrigerant (R32)
	This symbol indicates that the Operation Manual should be read carefully.		This symbol indicates that a service personnel should be handling this equipment with reference to the Installation Manual.

The following safety guidelines are intended to prevent unforeseen risks or damage from unsafe or incorrect operation of the appliance. The guidelines are separated into 'WARNING' and 'CAUTION' as described below.

 This symbol is displayed to indicate matters and operations that can cause risk. Read the part with this symbol carefully and follow the instructions in order to avoid risk.

WARNING

This indicates that the failure to follow the instructions can cause serious injury or death.

CAUTION

This indicates that the failure to follow the instructions can cause the minor injury or damage to the product.

WARNING

Installation

- Do not use a defective or underrated circuit breaker. Use this appliance on a dedicated circuit.
 - There is risk of fire or electric shock.
- For electrical work, contact the dealer, seller, a qualified electrician, or an Authorized Service Center.
 - There is risk of fire or electric shock.

- Always ground the unit.
 - There is risk of fire or electric shock.
- Install the panel and the cover of control box securely.
 - There is risk of fire or electric shock.
- Always install a dedicated circuit and breaker.
 - Improper wiring or installation may cause fire or electric shock.
- Use the correctly rated breaker or fuse.
 - There is risk of fire or electric.
- Do not modify or extend the power cable.
 - There is risk of fire or electric shock.
- Do not install, remove, or reinstall the unit by yourself (customer).
 - There is risk of fire, electric shock, explosion, or injury
- For antifreeze, always contact the dealer or an authorized service center.
 - Almost the antifreeze is a toxic product.
- For installation, always contact the dealer or an authorized Service Center.
 - There is risk of fire, electric shock, explosion, or injury.
- Do not install the unit on a defective installation stand.
 - It may cause injury, accident, or damage to the unit.
- Be sure the installation area does not deteriorate with age.
 - If the base collapses, the unit could fall with it, causing property damage, unit failure, and personal injury.
- Do not install the water pipe system as Open loop type.
 - It may cause failure of unit.
- Use a vacuum pump or inert (nitrogen) gas when doing leakage test or purging air. Do not compress air or oxygen and do not use flammable gases.
 - There is the risk of death, injury, fire or explosion.
- Make sure the connected condition of connector in product after maintenance.
 - Otherwise, it may cause product damage.

- Do not touch leaked refrigerant directly.
 - There is risk of frostbite.
- Copper in contact with refrigerants shall be oxygen-free or deoxidized, for example Cu-DHP as specified in EN 12735-1 and EN 12735-2.
- Compliance with national gas regulations shall be observed. (for R32)
- Refrigerant tubing shall be protected or enclosed to avoid damage. (for R32)
- The installation of pipe-work shall be kept to a minimum. (for R32)
- A brazed, welded, or mechanical connection shall be made before opening the valves to permit refrigerant to flow between the refrigerating system parts. A vacuum valve shall be provided to evacuate the interconnecting pipe and/or any uncharged refrigerating system part. (for R32)
- Any person who is involved with working on or breaking into a refrigerant circuit should hold a current valid certificate from an industry-accredited assessment authority, which authorises their competence to handle refrigerants safely in accordance with an industry recognised assessment specification. (for R32)
- Do not use means to accelerate the defrosting process or to clean, other than those recommended by the manufacturer. (for R32)
- Do not pierce or burn. (for R32)
- Be aware that refrigerants may not contain an odour. (for R32)
- Dismantling the unit, treatment of the refrigerant oil and eventual parts should be done in accordance with local and national standards. (for R32)
- Flexible refrigerant connectors (such as connecting lines between the indoor and outdoor unit) that may be displaced during normal operations shall be protected against mechanical damage. (for R32)

- Pipe-work shall be protected from physical damage. (for R32)
- Mechanical connections (mechanical connectors or flared joints) shall be accessible for maintenance purposes. (for R32)

Operation

- Take care to ensure that power cable could not be pulled out or damaged during operation.
 - There is risk of fire or electric shock.
- Do not place anything on the power cable.
 - There is risk of fire or electric shock.
- Do not plug or unplug the power supply plug during operation.
 - There is risk of fire or electric shock.
- Do not touch (operate) the unit with wet hands.
 - There is risk of fire or electric shock.
- Do not place a heater or other appliances near the power cable.
 - There is risk of fire or electric shock.
- Do not allow water to run into electric parts.
 - There is risk of fire, failure of the unit, or electric shock.
- Do not store or use flammable gas or combustibles near the unit.
 - There is risk of fire or failure of unit.
- Do not use the unit in a tightly closed space for a long time.
 - It may cause damage to the unit.
- When flammable gas leaks, turn off the gas and open a window for ventilation before turning the unit on.
 - There is risk of explosion or fire.
- If strange sounds, or smell or smoke comes from unit, turn the breaker off or disconnect the power supply cable.
 - There is risk of electric shock or fire.

- Stop operation and close the window in storm or hurricane. If possible, remove the unit from the window before the hurricane arrives.
 - There is risk of property damage, failure of unit, or electric shock.
- Do not open the front cover of the unit while operation. (Do not touch the electrostatic filter, if the unit is so equipped.)
 - There is risk of physical injury, electric shock, or unit failure.
- Do not touch any electric part with wet hands. you should be power off before touching electric part.
 - There is risk of electric shock or fire.
- Do not touch refrigerant pipe and water pipe or any internal parts while the unit is operating or immediately after operation.
 - There is risk of burns or frostbite, personal injury.
- If you touch the pipe or internal parts, you should be wear protection or wait time to return to normal temperature.
 - Otherwise , it may cause burns or frostbite, personal injury.
- Turn the main power on 6 hours ago before the product starting operation.
 - Otherwise, it may cause compressor damage.
- Do not touch electric parts for 10 minutes after main power off.
 - There is risk of physical injury, electric shock.
- The inside heater of product may operate during stop mode. It is intended to protect the product.
- Be careful that some part of the control box are hot.
 - There is risk of physical injury or burns.
- When the unit is soaked (flooded or submerged), contact an Authorized Service Center.
 - There is risk of fire or electric shock.
- Be cautious that water could not be poured to the unit directly.
 - There is risk of fire, electric shock, or unit damage.

- Ventilate the unit from time to time when operating it together with a stove, etc.
 - There is risk of fire or electric shock.
- Turn the main power off when cleaning or maintaining the unit.
 - There is risk of electric shock.
- Take care to ensure that nobody could step on or fall onto the unit.
 - This could result in personal injury and unit damage.
- If the unit is not used for long time, we strongly recommend not to switch off the power supply to the unit.
 - There is risk of water freezing.
- The appliance shall be stored in a well-ventilated area where the room size corresponds to the room area as specified for operation. (for R32)
- The appliance shall be stored in a room without continuously operating open flames (for example an operating gas appliance) and ignition sources (for example an operating electric heater). (for R32)
- The appliance shall be stored so as to prevent mechanical damage from occurring. (for R32)
- Servicing shall only be performed as recommended by the equipment manufacturer. Maintenance and repair requiring the assistance of other skilled personnel shall be carried out under the supervision of the person competent in the use of flammable refrigerants. (for R32)
- When mechanical connectors are reused indoors, sealing parts shall be renewed. When flared joints are reused indoors, the flare part shall be re-fabricated. (for R32)
- Periodic(more than once/year) cleaning of the dust or salt particles stuck on the heat exchangers by using water. (for R32)
- Keep any required ventilation openings clear of obstruction. (for R32)

CAUTION

Installation

- Always check for gas (refrigerant) leakage after installation or repair of unit.
 - Low refrigerant levels may cause failure of unit.
- Keep level even when installing the unit.
 - To avoid vibration or water leakage.
- Use two or more people to lift and transport the unit.
 - Avoid personal injury.
- In order to avoid a hazard due to inadvertent resetting of the thermal cut-out, this appliance must not be supplied through an external switching device, such as a timer, or connected to a circuit that is regularly switched on and off by the utility.
- Do not install the unit in potentially explosive atmospheres.
- The water may drip from the discharge pipe of the pressure-relief device and that this pipe must be left open to the atmosphere.
- The pressure-relief device is to be operated regularly to remove lime deposits and to verify that it is not blocked.
- A discharge pipe connected to the pressure-relief device is to be installed in a continuously downward direction and in a frost-free environment.

Operation

- Do not use the unit for special purposes, such as preserving foods, works of art, etc.
 - There is risk of damage or loss of property.
- Use a soft cloth to clean. Do not use harsh detergents, solvents, etc.
 - There is risk of fire, electric shock, or damage to the plastic parts of the unit.
- Do not step on or put anything on the unit.
 - There is risk of personal injury and failure of unit.


- Use a firm stool or ladder when cleaning or maintaining the unit.
 - Be careful and avoid personal injury.
- Do not turn on the breaker or power under condition that front panel cabinet, top cover, control box cover are removed or opened.
 - Otherwise it may cause fire, electric shock, explosion or death.
- The appliance shall be disconnected from its power source during service and when replacing parts.
- Means for disconnection must be incorporated in the fixed wiring in accordance with the wiring rules.
- The Installation kit supplied with the appliance are to be used and that old Installation kit should not be reused.
- If the supply cord is damaged, it must be replaced by the manufacturer, its service agent or similarly qualified persons in order to avoid a hazard. Installation work must be performed in accordance with the national wiring standards by authorized personnel only.
- This equipment shall be provided with a supply conductor complying with the national regulation.
- The instructions for service to be done by specialized personnel, mandated by the manufacturer or the authorized representative may be supplied in only one Community language which the specialized personnel understand.
- This appliance is not intended for use by persons (including children) with reduced physical, sensory or mental capabilities or lack of experience and knowledge, unless they have been given supervision or instruction concerning use of the appliance by a person responsible for their safety. Children should be supervised to ensure that they do not play with the appliance.

INSTALLATION PART

Thank you for choosing LG Electronics Air-to-Water Heat Pump **THERMAV**.



Before starting installation, please make it sure that all parts are found inside the product box.

INDOOR UNIT BOX



Item	Image	Quantity	Item	Image	Quantity
Indoor unit		1	Connection Hose		1
Card, Installation		1	Gasket (G1")		2
Owner's / Installation manual		1	Adapter Cable		1

* There are 3 gaskets between pipes and caps, which is in Heating circuit outlet pipe, Domestic cold water inlet pipe and DHW Re-Circulation pipe. 2 gaskets are enclosed inside the product box.

OUTDOOR UNIT BOX

Item	Image	Quantity
Outdoor Unit U36A Chassis		1
Drain Cap		4
Drain Nipple		1
Damper		4

INSTALLATION TOOLS

Figure	Name	Figure	Name
	Screw driver		Ohmmeter
	Electric drill		Hexagonal wrench
	Measuring tape, Knife		Ammeter
	Hole core drill		Leak detector
	Spanner		Thermometer, Horizontal meter
	Torque wrench		Flaring tool set
	Manifold Gauge		Vacuum Pump
	Pliers	-	-

GENERAL INFORMATION

With advanced inverter technology, **THERMAV** is suitable for applications like under floor heating, under floor cooling, and hot water generation. By Interfacing to various accessories user can customize the range of the application.

In this chapter, general information of **THERMAV** is presented to identify the installation procedure. Before beginning installation, read this chapter carefully and find helpful information on installation.

Energy Labels and Product Fiches for all possible combinations can be found at <https://www.lg.com/global/support/cedoc/cedoc>. Search for outdoor unit name in cedoc page.

Model Information

Factory Model Name

Outdoor unit

Model	No.						
	1	2	3	4	5	6	7
Split	ZH	U	W	09	6	A	0

	Signification
1	ZH : Air-to-Water-Heat Pump for R32
2	Classification - U : Outdoor unit of Split
3	Model Type - W : Inverter Heat Pump
4	Heating Capacity - e.g. 09 : 9 kW
5	Electrical ratings - 6 : 1Ø, 220-240V, 50 Hz
6	Function - A : General function of Split
7	Series number (Factory)

Indoor unit

Model	No.							
	1	2	3	4	5	6	7	8
Split	ZH	N	W	20	6	03	I	1

	Signification
1	ZH : Air-to-Water-Heat Pump for R32
2	Classification - N : Indoor unit
3	Model Type - W : Inverter Heat Pump
4	Water Tank Capacity - 20 : 200L
5	Electrical ratings - 6 : 1Ø, 220-240V, 50 Hz
6	Heater Capacity - 3: 3 kW Heater
7	Function - I : Split IWT
8	Series number (Factory)

Buyer Model Name**Outdoor unit**

Type	Refrigerant	No.							
		1	2	3	4	5	6	8	9
Split	R32	H	U	09	1	M	R	U4	4

	Signification
1	Air-to-Water Heat Pump
2	Classification - U : Outdoor unit
3	Heating Capacity - e.g. 9 : 9 kW
4	Electrical ratings - 1 : 1Ø, 220-240V, 50 Hz
5	Leaving water combination - M : Medium Temperature
6	Refrigerant - R : R32
8	Chassis - U4 : U36A Chassis
9	Series number (Buyer)

Indoor unit

Type	Refrigerant	No.									
		1	2	3	4	5	6	8	9	10	
Split	R32	H	N	09	1	3	T	N	K	0	

	Signification
1	Air-to-Water Heat Pump
2	Classification - N : Indoor unit
3	Heating Capacity - e.g. 09 : 9 kW
4	Electrical ratings - 1 : 1Ø, 220-240V, 50 Hz
5	Heater capacity (kW) - 3: 3kW Heater
6	Function - T: Split IWT
8	Classification - N : Indoor unit
9	Chassis (Platform) - K : K5 Chassis
10	Series number (Buyer)

Check the model information based on the buyer model series number.
(e.g., geometry, cycle, etc.)

Related Information

Unit									
Heat Pump								Backup Heater	
Type	Refrigerant	Outdoor Unit		Indoor Unit	Power Supply	Capacity		Capacity [kW]	Power Supply
		Phase	Capacity [kW]	Phase		Heating [kW] ^{*1}	Cooling [kW] ^{*2}		
Split	R32	1Ø	5	1Ø	220-240 V~ 50 Hz	5.5	5.5	3	220-240 V~ 50 Hz
			7			7.0	7.0		
			9			9.0	9.0		

*1 : Tested under EN14511

(water temperature 30 °C → 35 °C at outdoor ambient temperature 7 °C / 6 °C)

*2 : Tested under EN14511

(water temperature 23 °C → 18 °C at outdoor ambient temperature 35 °C / 24 °C)

✱ All appliances were tested at atmospheric pressure.

Refrigerant			R32
Max allowable pressure	High side [MPa]		4.32
	Low side [MPa]		2.4
Operating temperature of leaving water (Min. ~ Max.)	Heating [°C]	For Fan coil unit / Radiator	15 ~ 65
		For under floor	15 ~ 65
	Cooling [°C]	For Fan coil unit	5 ~ 27
		For under floor	16 ~ 27
	DHW		15 ~ 80
Inlet water pressure [MPa] (Min. ~ Max.)			0.03 ~ 0.3
Maximum DHW tank pressure [MPa]			1.0

* DHW: Domestic hot water

* IWT : Integrated water tank indoor unit


- Energy Labels and Product Fiches for all possible combinations can be found at <https://www.lg.com/global/support/cedoc/cedoc>. Search for outdoor unit name in cedoc page.

- Additional Information : Serial number is refer to the barcode on the product.

Parts and Dimensions

Indoor unit : External

(unit : mm)







* The feature may be vary according to the type of model.

Description

No.	Part Name	Remark
1	Refrigerant gas pipe	SAE 5/8"
2	Refrigerant liquid pipe	SAE 3/8"
3	Heating circuit outlet pipe	Female G1" according to ISO228-1(parallel pipe threads)
4	Heating circuit inlet pipe	Female G1" according to ISO228-1(parallel pipe threads)
5	Domestic cold water inlet pipe	Female G1" according to ISO228-1(parallel pipe threads)
6	Domestic hot water outlet pipe	Female G1" according to ISO228-1(parallel pipe threads)
7	DHW RE-Circulation pipe	Female G1" according to ISO228-1(parallel pipe threads)
8	Control panel	Built-in Remote controller

Indoor unit : Internal

(unit : mm)




Description

No.	Part Name	Remark
1	DHW Tank	Domestic hot water tank(200L)
2	Heater	Electric heater (3kW)
3	Flow sensor	Flow metering sensor
4	3Way valve	For DHW / Heating
5	Pressure sensor	Pressure sensor
6	Expansion vessel	8L for Heating circuit
7	DHW tank sensor	Temperature sensor
8	Heat exchanger 1	Coil Heat Exchange (water / DHW)
9	Heat exchanger 2	Plate Heat Exchange (Ref. / Water)
10	Water pump	Main circulation pump
11	Control Box	PCB'A and Terminal blocks
12	Air vent	For Air purging
13	Drain cock 1	Valve for DHW Tank drain
14	Drain cock 2	Valve for water circuit drain
15	Strainer	For water circuit
16	Safety valve	For DHW (10 bar)
17	Safety valve	For water circuit (3 bar)

Outdoor unit : External

Product Heating Capacity : 5 kW, 7 kW, 9 kW
 Chassis : U36A

(unit : mm)




Description

No	Name
1	Liquid-side Service Valve
2	Gas-side Service Valve
3	Air discharge Grille

Control Parts

Control Box : Indoor Unit


1Ø Electric Heater Model



Description

No	Name	Remark
1	Terminal blocks	The terminal blocks allow easy connection of field wiring
2	Unit ELB	The ELB protects the unit against overload or short circuit
3	Heater PCB (Relay)	Heater PCB (Printed Circuit Board) controls the functioning of the backup heater
4	Main PCB	The main PCB (Printed Circuit Board) controls the functioning of the unit

Control Panel



Operation display window	Operation and Settings status display
Back button	When you move to the previous stage from the menu's setting stage
Up/down/left/right button	When you change the menu's setting value
OK button	When you save the menu's setting value
On/Off button	When you turn ON/OFF the AWHP

Typical Installation Example

CAUTION


If **THERMAV** is installed with pre-existing boiler, the boiler and **THERMAV** should not be operated together. If entering water temperature of **THERMAV** is above 55 °C, the system will stop operation to prevent mechanical damage of the product. For detailed electric wiring and water piping, please contact authorized installer.

Some installation scenes are presented for example. As these scenes are conceptual figures, installer should optimize the installation scene according to the installation conditions.

Note that buffer tank should be installed.

CASE 1 : Connecting Heat Emitters for Heating and Cooling & DHW

(Under floor loop, Fan Coil Unit, Radiator, and Domestic hot water)




NOTE

- Room thermostat
 - Type of thermostat and specification should be complied with chapter 8 and chapter 9 of **THERMAV** installation manual.
- 2way valve
 - It is important to install 2way valve to prevent dew condensation on the floor and radiator while cooling mode.
 - Type of 2way control valve and specification should be complied with chapter 8 and chapter 9 of **THERMAV** installation manual.
 - 2way valve should be installed at the supply side of the collector.
- By-pass valve
 - To secure enough water flow rate, by-pass valve should be installed at the collector.
 - By-pass valve should guarantee minimum water flow rate in any case. Minimum water flow rate is described in water pump characteristics curve.

— High Temperature	⊗ 2way valve (Field supply)	⊗ Room Thermostat (Field supply)
.... Low Temperature	⊗ By-pass valve (Field supply)	⊗ DHW Expansion vessel (Field Supply)
(M/F) Magnetic Filter (Mandatory)	⊗ Shut-off valve with strainer(Field Supply)	
⊗ Shut-off valve (Field supply)	⊗ Pump (Field supply)	

CASE 2 : Connecting mixed Circuit




NOTE

- Mix Kit
 - You can install it when you want to set the temperature of two rooms individually
 - When heating, Circuit 2 can not be higher than Circuit 1.
 - When cooling, Circuit 2 can not be lower than Circuit 1.
 - The types and specifications of the Mix Kit are to comply with chapter 8 and chapter 9 of the **THERMA V** Installation Manual.

High Temperature	Mix Kit (Field supply)	Room Thermostat (Field supply)
Low Temperature	By-pass valve (Field supply)	DHW Expansion vessel (Field Supply)
Magnetic Filter (Mandatory)	Shut-off valve with strainer(Field Supply)	Buffer tank (Field Supply)
Shut-off valve (Field supply)	Pump (Field supply)	Pressure Regulation valve (Field supply)

CASE 3 : Connecting 3rd Party Boiler




NOTE

- 3rd party Boiler
 - You can control the boiler automatically and manually by comparing the outside temperature and the set temperature.

— High Temperature	⊗ 2way valve (Field supply)	⊗ Room Thermostat (Field supply)
.... Low Temperature	⊗ By-pass valve (Field supply)	⊗ DHW Expansion vessel (Field Supply)
⊗ Magnetic Filter (Mandatory)	⊗ Shut-off valve with strainer(Field Supply)	⊗ Buffer tank (Field Supply)
⊗ Shut-off valve (Field supply)	⊗ Pump (Field supply)	⊗ Aquastat Valve
▲ Check Valve	⊗ Air vent (Field supply)	

Cycle Diagram



Description


Category	Symbol	Meaning
Refrigerant side	S1	Compressor-suction pipe temperature sensor
	S2	Injection EEV discharge temperature sensor
	S3	Outdoor air temperature sensor
	S4	Outdoor-HEX temperature sensor
	S5	Compressor-discharge pipe temperature sensor
	S6	Outdoor-HEX middle temperature sensor
	S9	PHEX gas temperature sensor
	S10	PHEX liquid temperature sensor
	EEV1	Electronic Expansion Valve (Heating/Cooling)
	EEV3	Electronic Expansion Valve (Injection)
Water Side	S11	Inlet water temperature sensor (WATER IN)
	S12	Outlet water temperature sensor (PHEX OUT)
	S13	Backup heater outlet sensor (WATER OUT)
	S14	DHW tank temperature sensor
	S17	Flow sensor
	S19	Water pressure sensor
	A1	Main water pump
	A8	Electric backup heater

INSTALLATION OF OUTDOOR UNIT

The outdoor unit of **THERMAV**™ is installed outside to exchange heat with ambient air. Therefore, it is important to secure proper space around the outdoor unit and care for specific external conditions. This chapter presents a guide to install the outdoor unit, make a route to connect with the indoor, and what to do when installed around seaside.

Conditions where Outdoor Unit is Installed


- If a sunroof is built over the unit to prevent direct sunlight or rain exposure, make sure that heat radiation from the heat exchanger is not restricted.
- Ensure that the spaces indicated by arrows around front, back and side of the unit.
- Do not place animals and plants in the path of the warm air.
- Take the weight of the outdoor unit into account and select a place where noise and vibration are minimum.
- Select a place so that the warm air and noise from the outdoor unit do not disturb neighbors.
- Place that can sufficiently endure the weight and vibration of the outdoor unit and where even Installation is possible.
- Place that has no direct influence of snow or rain.
- Place with no danger of snowfall or icicle drop.
- Place without weak floor of base such as decrepit part of the building or with a lot of snow accumulation.



※ The feature may be vary according to the type of model.




Drill a Hole in the Wall

- If making a hole to the wall is required to connect pipe between the indoor unit and the outdoor unit, please follow below descriptions.
Drill the piping hole with a $\varnothing 70$ mm core drill.
Piping hole should be slightly slant to the outdoor side to prevent raindrop into indoor side.




Transporting the Unit

- When carrying the suspended unit, pass the ropes between legs of base panel under the unit.
- Always lift the unit with ropes attached at four points so that impact is not applied to the unit.
- Attach the ropes to the unit at an angle $\textcircled{A}$ of 40° or less.
- Use only accessories and parts which are of the designated specification when installing.
- Forklift trucks are not available without a palette.
- Be careful not to damage the product when moving the forklift.



Always hold the unit by the corners, as holding it by the side intake holes on the casing may cause them to deform.





CAUTION

Be very careful while carrying the product.

- Do not have only one person carry product if it is more than 20 kg.
- PP bands are used to pack some products. Do not use them as a mean for transportation because they are dangerous.
- Do not touch heat exchanger fins with your bare hands. Otherwise you may get a cut in your hands.
- Tear plastic packaging bag and scrap it so that children cannot play with it. Otherwise plastic packaging bag may suffocate children to death.
- When carrying in Unit, be sure to support it at four points. Carrying in and lifting with 3-point support may make Outdoor Unit unstable, resulting in a fall.
- Use 2 belts of at least 8 m long.
- Place extra cloth or boards in the locations where the casing comes in contact with the sling to prevent damage.
- Hoist the unit making sure it is being lifted at its center of gravity.


Installation at Seaside

⚠ CAUTION


- Unit should not be installed in areas where corrosive gases, such as acid or alkaline gas, are produced.
- Do not install the product where it could be exposed to sea wind (salty wind) directly. It can result corrosion on the product. Corrosion, particularly on the condenser and evaporator fins, could cause product malfunction or inefficient performance.
- If outdoor unit is installed close to the seaside, it should avoid direct exposure to the sea wind. Otherwise it needs additional anti-corrosion treatment on the heat exchanger.

Selecting the location(Outdoor Unit)

- If the outdoor unit is to be installed close to the seaside, direct exposure to the sea wind should be avoided. Install the outdoor unit on the opposite side of the sea wind direction.



- In case, to install the outdoor unit on the seaside, set up a windbreak not to be exposed to the sea wind.





- It should be strong enough like concrete to prevent the sea wind from the sea.
- The height and width should be more than 150% of the outdoor unit.
- It should be keep more than 700 mm of space between outdoor unit and the windbreak for easy air flow.

- Select a well-drained place.
Periodic (more than once/year) cleaning of the dust or salt particles stuck on the heat exchanger by using water.
- If you can't meet above guide line in the seaside installation, please contact your supplier for the additional anti-corrosion treatment.

Seasonal Wind and Cautions in Winter

In areas with low ambient temperature, high humidity, or heavy snowfall, particular measures are required to ensure that the unit operates properly.

- Install the unit so that it does not come into direct contact with snow. If snow accumulates and freezes in the air inlet, the system may malfunction. When installing in an area with heavy snowfall, attach the hood to the system.
- Install the suction and discharge ducts to prevent the entry of snowfall or rainfall.
- When installing in an area with heavy snowfall, install it on an installation console which is 500mm higher than the average snowfall (annual average snowfall).
- The height of the H frame must be at least twice the amount of snowfall and its width must not exceed the width of the unit. (Snow may accumulate if the width of the frame is wider than the width of the unit.)
- If condensed water from the outdoor unit freezes around the product, the floor/ground may become slippery and cause an accident, so do not install the outdoor unit near a sidewalk. If it is unavoidable, install a water channel or drainage pipe to prevent condensed water from flowing onto the sidewalk.
- Use "Rapid Defrost Mode" in sites with snowfall or low temperatures and high humidity.
 - * The Rapid Defrost Mode is a rapid defrost mode designed to prevent accumulated icing in sites with snowfall or low temperatures and high humidity. Refer to "Dip Switch Setting".
- If more than 100mm of snow has accumulated on the top of the product, be sure to remove the snow before carrying out any work on the unit.
- Do not install the inlet or outlet of the unit so that they face seasonal winds.
- Make preparations for snow and/or seasonal winter winds in all areas in which the unit is installed.



INSTALLATION OF INDOOR UNIT

The indoor unit of **THERMAV** is installed inside where terminal of under floor water pipe cycle and refrigerant pipe from the outdoor unit are accessible at the same time.

In this chapter conditions for installation place is described. In addition, considerations when installing accessories or 3rd party accessories are described, too.

Conditions where Indoor Unit is Installed

Specific conditions are required for installation place such as service space, condensate drainage, water pipe length and height, total volume of water, adjusting expansion vessel, and water quality.

General Considerations

Followings are should be considered before the installation of the indoor unit.

- The installation place should be free from outdoor weather conditions such as rain, snow, wind, frost, etc.
- Choose the place where is water-resistant or good drainage.
- Service space should be secured.
- No flammable materials around the indoor unit.
- Mice can not be appeared to prevent entering the indoor unit or attacking wires.
- Do not place anything in front of the indoor unit to ensure air circulation around the indoor unit.
- Do not locate anything under the indoor unit to be free from unexpected water out.
- In case of water pressure increasing to 3 bar or tank pressure increasing to 10 bar, water drainage should be treated when water is drained by safety valve.



WARNING

Do not block the venting openings on the backside of the unit!



CAUTION

The device must not be installed under pipelines because there is a possibility of condensate forming. Ingress of water condensate can cause disturbances in the operation.

NOTICE


The installation location of the indoor unit must be dry and in the temperature range between +10 °C and 40 °C, for a short period (up to 24h) also up to 55 °C.

Service Space

- Ensure that the spaces indicated by arrows around front, right, and top side.
- Wider spaces are preferred for easy maintenance and piping.
- If minimum service space is not secured, air circulation can be troubled and internal parts of the indoor unit can be damaged by overheating.

NOTE

- Provide enough space for servicing and air circulation. The unit is designed to allow servicing from front side. However, if it becomes necessary to replace components, a service area of approximately 500 mm on the right side, makes the task much easier.




Minimum service space
(unit : mm)

Transporting the Unit

⚠ CAUTION

- The device must be transported with transport devices.
- Secure the device during transport to prevent damage.
- The device must not be stacked and other objects must not be placed on it.
- Appropriate transport equipment must be used for installing the device. Safety regulations and good practice have to be applied.
- When lifting the unit, use the dedicated carrying handles at bottom and backside of the product
- Tilt over the unit carefully with at least two persons
- Do not tilt the unit forwards (because of drainage)



Connecting Condensate drainage



Step 1. Before the indoor unit's final positioning, Insert the drainage hose into the drain ①, which leads to the sinkhole or storm drain. Seal the gap with a suitable gasket.

Step 2. Then push the appliance to the wall ②.



CAUTION

- Attaching the hose for the condensate drain to the sewer hose can cause corrosion of the appliance's internal components.
- The drain pipe must have an odor trap!





Step 3. Before connecting any pipes, level the indoor unit with supplied adjustable levelling feet.

Front Panel Removal

Step 1. After releasing screws from the top the Indoor unit, detach front panel ①.

Step 2. Lift the front panel ② and tilt it towards you ③ for opening

Step 3. Before taking front panel off completely, disconnect the cable of the remote controller ④.




CAUTION

After installation is completed, reconnect the cable of remote controller.

Floor area requirement : Indoor unit

- If the total refrigerant charge (m_c) is in system ≥ 1.842 kg, additional minimum floor area requirements is complied in the following flow chart.




Determine :

- The total refrigerant charge in the system, m_c (kg)
- The room A area installed the appliance, A_{Room} (m^2)

Calculate based on Table 1 :

- The maximum refrigerant charge allowed for room A_{max} (kg)




Determine :

- The adjacent room B area, B_{Room} (m^2)

Calculate based on Table 2 :

- The total minimum floor area required for the total refrigerant charge m_c , A_{min} (m^2)



Calculate based on Table 3 :

- The minimum opening area for natural ventilation between room A and room B according to the value of m_c and A_{Room} , A_{min} (m^2)

The unit can be installed in room A when the following **ventilation requirements** are fulfilled.

please contact your local engineer / dealer.

Ventilation requirements

- Two ventilation openings, one at bottom, another at top, for ventilation purposes are made between room A and room B.
- Bottom opening :
 - Must comply to the minimum area requirement of Anv_{min} .
 - Opening must be located 300mm from the floor.
 - At least 50% of required opening area must be 200mm from the floor.
 - The bottom of the opening shall not be higher than the point of release when the unit is installed and must be situated 100mm above the floor.
 - Must be as close as possible to the floor and lower than h_0 .
(h_0 =Installation height, The value of h_0 in this unit is considered as 1.2m)
- Top opening :
 - The total size of the Top opening must be more than 50% of Anv_{min}
 - Opening must be located 1500mm above the floor.
- The height of the openings between the wall and floor which connect the rooms are not less than 20 mm.
- Ventilation openings to the outside are NOT considered suitable ventilation openings (the user can block them when it is cold).

Table 1 - Maximum refrigerant charge allowed in a room

A_{room} (m ²)	Maximum refrigerant charge in a room m_{max} (kg)
	Based on h_0 1.2 m
1	0.28
2	0.55
3	0.83
4	1.11
5	1.38
6	1.66
7	1.81
8	1.94
9	2.06
10	2.17
11	2.27
12	2.37
13	2.47
14	2.57
15	2.66
16	2.74
17	2.83
18	2.91
19	2.99
20	3.07
21	3.14


NOTE

- The value of "Release height (h_0)" in this unit is considered 1200 mm to comply to IEC 60335-2-40:2013 A1 2016 Clause GG2.
- For intermediate A_{room} values, the value that corresponds to the lower A_{room} value from the table is considered. (If $A_{room}=10.5$ m², consider the value that corresponds to $A_{room}=10$ m².)

Table 2 - Minimum floor area

Total Ref. Amount m_c (kg)	Minimum Floor Area A_{min} (m ²) Based on h_0 1.2 m
1.84	7.20
1.86	7.36
1.88	7.52
1.90	7.68
1.92	7.84
1.94	8.01
1.96	8.17
1.98	8.34
2.00	8.51
2.02	8.68
2.04	8.85
2.06	9.03
2.08	9.21
2.10	9.38
2.12	9.56
2.14	9.74
2.16	9.93
2.18	10.11
2.20	10.30
2.22	10.49
2.24	10.68
2.26	10.87
2.28	11.06
2.30	11.26
2.32	11.45
2.34	11.65
2.36	11.85
2.38	12.05
2.40	12.26
2.42	12.46
2.44	12.67
2.46	12.88
2.48	13.09
2.50	13.30
2.52	13.51
2.54	13.73
2.56	13.94
2.58	14.16
2.60	14.38
2.62	14.61
2.64	14.83
2.66	15.05
2.68	15.28
2.70	15.51
2.72	15.74
2.74	15.97
2.76	16.21

Total Ref. Amount m_c (kg)	Minimum Floor Area A_{min} (m ²) Based on h_0 1.2 m
2.78	16.44
2.80	16.68
2.82	16.92
2.84	17.16
2.86	17.40
2.88	17.65
2.90	17.89
2.92	18.14
2.94	18.39
2.96	18.64
2.98	18.89
3.00	19.15
3.02	19.41
3.04	19.66
3.06	19.92
3.08	20.18
3.10	20.45



NOTE

- The value of "Release height (h_0)" in this unit is considered 1200 mm to comply to IEC 60335-2-40:2013 A1 2016 Clause GG2.
- For intermediate m_c values, the value that corresponds to the higher m_c value from the table is considered.
(If $m_c = 1.85$ kg, the value that corresponds to $m_c = 1.86$ kg is considered.)
- Systems with total refrigerant charge lower than 1.84 kg are not subjected to any room area requirements.
- Charges above 3.10 kg are not allowed in the unit.

Table 3 - Minimum venting opening area for natural ventilation

A_{room} (m^2)	Minimum opening area $A_{\text{nv,min}}$ (cm^2) (Based on h_0 1.2 m)													
	Total Ref. Amount m_c (kg)													
	3.1	3.0	2.9	2.8	2.7	2.6	2.5	2.4	2.3	2.2	2.1	2.0	1.9	
1	808	779	751	722	693	665	636	607	579	550	522	493	464	
2	729	700	671	643	614	586	557	528	500	471	443	414	385	
3	650	621	592	564	535	507	478	449	421	392	364	335	306	
4	571	542	513	485	456	428	399	370	342	313	285	256	227	
5	492	463	434	406	377	349	320	291	263	234	206	177	148	
6	413	384	355	327	298	270	241	212	184	155	126	98	69	
7	380	350	321	291	262	232	203	173	144	114	85	55	25	
8	355	324	293	263	232	202	171	141	110	80	49	19		
9	328	297	265	234	202	171	139	108	77	45	14			
10	301	269	236	204	172	140	107	75	43	10				
11	273	240	207	174	141	108	75	42	9					
12	245	211	177	144	110	76	42	9						
13	217	182	148	113	79	44	10							
14	188	153	118	83	47	12								
15	159	123	88	52	16									
16	130	94	57	21										
17	101	64	27											
18	72	34												
19	42	4												
20	13													

NOTE

- The value of "Release height (h_0)" in this unit is considered 1200 mm to comply to IEC 60335-2-40:2013 A1 2016 Clause GG2.
- For intermediate A_{room} values, the value that corresponds to the lower A_{room} value from the table is considered. (If $A_{\text{room}}=10.5 \text{ m}^2$, consider the value that corresponds to $A_{\text{room}}=10 \text{ m}^2$.)
- For intermediate m_c values, the value that corresponds to the higher m_c value from the table is considered. (If $m_c = 2.15 \text{ kg}$, the value that corresponds to $m_c = 2.2 \text{ kg}$ is considered.)


Electrical Wiring

Two kind of cables should be connected to the outdoor unit : One is 'Power cable', the other one is 'Connecting cable'. Power cable is a cable which is used to supply external electricity to the outdoor unit. This cable is generally connected between external power source (such as main electric power distribution panel of user's house) and the outdoor unit. Connecting cable is, on the other hand, used to connect between the outdoor unit and the indoor unit to supply electric power to the indoor unit and to establish the communication between the outdoor unit and the indoor unit.

Procedure for wiring to the outdoor unit is four steps. Before starting wiring, check if wire specification is suitable and read following directions and cautions VERY carefully.

CAUTION


The power cord connected to the outdoor unit should be complied with IEC 60245 or HD 22.4 S4 (This equipment shall be provided with a cord set complying with the national regulation.)



NORMAL CROSS-SECTIONAL AREA

Model Name		Area (mm²)	Cable Type
Phase (Ø)	Capacity (kW)		
1	5	4	H07RN-F
	7		
	9		
	12	6	
	14		
	16		
3	12	2.5	
	14		
	16		

The connecting cable connected to the outdoor unit should be complied with IEC 60245 or HD 22.4 S4 (This equipment shall be provided with a cord set complying with the national regulation.)




When the connection line between the indoor unit and outdoor unit is over 40 m, connect the telecommunication line and power line separately.

In order to avoid a hazard due to inadvertent resetting of the thermal cut-out, this appliance must not be supplied through an external switching device, such as a timer, or connected to a circuit that is regularly switched on and off by the utility.

If the supply cord is damaged, it must be replaced by the manufacturer, its service agent or similarly qualified persons in order to avoid a hazard.


Precautions when laying power wiring

Use round pressure terminals for connections to the power terminal block.



When none are available, follow the instructions below.

- Do not connect wiring of different thicknesses to the power terminal block. (Slack in the power wiring may cause abnormal heat.)
- When connecting wiring which is the same thickness, do as shown in the figure below.



- For wiring, use the designated power wire and connect firmly, then secure to prevent outside pressure being exerted on the terminal block.
- Use an appropriate screwdriver for tightening the terminal screws. A screwdriver with a small head will strip the head and make proper tightening impossible.
- Over-tightening the terminal screws may break them.

WARNING

Make sure that the screws of the terminal are free from looseness.

Point for attention regarding quality of the public electric power supply

- European/International Technical Standard setting the limits for voltage changes, voltage fluctuations and flicker in public low-voltage supply systems for equipment with rated current ≤ 75 A.
- European/International Technical Standard setting the limits for harmonic currents produced by equipment connected to public low-voltage systems with input current ≤ 16 A of > 75 A per phase.

For Split IWT

- This equipment complies with IEC (EN) 61000-3-2.
- This equipment complies with IEC (EN) 61000-3-12.
- This equipment complies with IEC (EN) 61000-3-3.


Circuit Breaker Specification

Perform the electrical wiring work according to the electrical wiring connection.

- All wiring must comply with local requirements.
- Select a power source that is capable of supplying the current required by the unit.
- Use a recognized ELCB(Electric Leakage Circuit Breaker) between the power source and the unit. A disconnection device to adequately disconnect all supply lines must be fitted.
- Model of circuit breaker recommended by authorized personnel only

*Pipes and wires should be purchased separately for installation of the product.

When the electrical phase of outdoor unit and heater is same



Type	Capacity [kW]	Phase [Ø]	Area [mm ²]	CB (A)
Split	5 / 7 / 9	1	4	20 / 25 / 30

Type	Capacity [kW]	Phase [Ø]	Area [mm ²]	Maximum Current [A]
Electric Heater	3	1	2.5	13.0

PIPING AND WIRING FOR OUTDOOR UNIT

Procedures about refrigerant piping, water piping and electric wiring at the outdoor are described in this chapter. Most of procedures are similar to those of LG Air Conditioner.


*Pipes and wires should be purchased separately for installation of the product.

Refrigerant Piping

Before starting refrigerant piping, constraints in pipe length and elevation should be examined. After resolving all constraints, some preparations are required to proceed. Then connecting pipe to the outdoor and the indoor unit is beginning.

Constraints in Pipe Length and Elevation

Refrigerant	Capacity (kW)	Pipe Diameter [mm(inch)]		Length A (m)		Elevation B (m)	Additional Refrigerant (g/m)
		Gas	Liquid	Standard	Max.	Max.	
R32	5/7/9	15.88(5/8")	9.52(3/8")	5	50	30	40 (longer than 10 m)



A trap is necessary when the outdoor unit is installed in a higher position than the indoor unit.

CAUTION

- For R32 products, standard pipe length is 5 m, If the pipe length is longer than 10 m, additional charge of the refrigerant is required according to the table.
 - Example : If R32 9 kW model is installed at a distance of 50 m, 1 600 g of refrigerant should be added according to following formula : $(50-10) \times 40 \text{ g} = 1\,600 \text{ g}$
- Rated capacity of the product is based on standard length and maximum allowable length is based on the product reliability in the operation.
- Improper refrigerant charge may result in abnormal operation.
- Oil trap should be installed every 10 meters, when the outdoor unit is installed in a higher position than the indoor unit.
- Installing a refrigerant pipe that is shorter than the standard length may result in noise or abnormal operation of the product.

NOTE

Fill in the f-gas Label attached on outdoor about the quantity of the fluorinated greenhouse gases (This note about f-gas label may not apply depending on your product type or market.)



- Manufacturing site (See Model Name label)
- Installation site (If possible being placed adjacent to the service points for the addition or removal of refrigerant)
- The total Charge (① + ②)

Preparation for Piping

- Main cause of gas leakage is defect in flaring work. Carry out correct flaring work in the following procedure.
- Use the de-oxidised copper as piping materials to install.

Step 1. Cut the pipes and the cable.

- Use the accessory piping kit or the pipes purchased locally.
- Measure the distance between the indoor unit and the outdoor unit.
- Cut the pipes a little longer than measured distance.
- Cut the cable 1.5 m longer than the pipe length.




Step 2. Burrs removal

- Completely remove all burrs from the cut cross section of pipe/tube.
- Put the end of the copper tube/pipe to downward direction as you remove burrs in order to avoid to let burrs drop in the tubing.

Step 3. Putting nut on



- Remove flare nuts attached to indoor and outdoor units, then put them on pipe/tube having completed burr removal. (Not possible to put them on after flaring work)



Step 4. Flaring work.

- Carry out flaring work using dedicated flaring tool for R-410A refrigerant as shown below.


Pipe diameter [inch(mm)]	A inch (mm)	
	Wing nut type	Clutch type
1/4 (6.35)	0.04~0.05(1.1~1.3)	0~0.02 (0~0.5)
3/8 (9.52)	0.06~0.07(1.5~1.7)	
1/2 (12.7)	0.06~0.07(1.6~1.8)	
5/8 (15.88)	0.06~0.07(1.6~1.8)	
3/4 (19.05)	0.07~0.08(1.9~2.1)	



- Firmly hold copper tube in a bar(or die) as indicated dimension in the table above.

Step 5. Check

- Compare the flared work with right figure.
- If flare is seemed to be defective, cut off the flared section and do flaring work again.




Connecting Pipe to Indoor Unit

Connecting pipe to the indoor unit is two steps. Read following directions carefully.


Step 1. Pre-tightening.

- Align the center of the pipes and sufficiently tighten the flare nut by hand.



Step 2. Tightening.

- Tighten the flare nut with a wrench.
- Tightening torque is as following.





Outside diameter [mm(inch)]	Torque [kgf·m]
9.52 (3/8)	3.4 ~ 4.2
15.88 (5/8)	6.6 ~ 8.2

Connecting Pipe to Outdoor Unit

Connecting pipe to the outdoor unit is five steps including PCB setting.

Step 1. Determine direction of pipes.


- The pipes can be connectable in three directions.
- The directions are expressed in below figure.
- When connecting in a downward direction, knock out the knock-out hole of the base pan.
- Detailed geometry may vary by model.



Step 2. Tightening


- Align the center of the pipes and sufficiently tighten the flare nut by hand.
- Tighten the flare nut with a wrench until the wrench clicks.
- Tightening torque is as following.

Outside diameter [mm(inch)]	Torque [kgf·m]
9.52 (3/8)	3.4 ~ 4.2
15.88 (5/8)	6.6 ~ 8.2



Step 3. Preventing entering of foreign objects

- Plug the pipe through-holes with putty or insulation material (procured locally) to fill up all gaps as shown in right figure.
- If insects or small animals enter the outdoor unit, it may cause a short circuit in the electrical box.
- Finally, form the pipes by wrapping the connecting portion of the indoor unit with insulation material and secure it with two kinds of vinyl tape. Ensuring thermal insulation is very important.




Wiring Procedure for Power Cable and Connecting Cable

Step 1. Disassemble the side panel from the outdoor unit by loosening screws.


Step 2. Connect power cable to main power terminal

See below figure for detailed information. When connecting earth cable, the diameter of cable should be refer to the below table. The earth cable is connected to the Control box case where earth symbol is $\oplus$ marked.



Step 3. Use cable clamps (or cord clamps) to prevent unintended move of Power cable and Connecting cable.

Step 4. Reassemble the side panel to the outdoor unit by fastening screws.



CAUTION

After checking and confirming following conditions, start wiring work.

- Secure dedicated power source for the Air-to-Water heat pump. The wiring diagram (attached inside the control box of the indoor unit) is presenting related information.
- Provide a circuit breaker switch between power source and the outdoor unit.
- Although it is very rare case, sometimes the screws used to fasten internal wires can be loosen due to the vibration while product transportation. Check these screws and make it sure if they are all fastened tightly. If not tightened, burn-out of the wire can be occurred.
- Check the specification of power source such as phase, voltage, frequency, etc.
- Confirm that electrical capacity is sufficient.
- Be sure that the starting voltage is maintained at more than 90 percent of the rated voltage marked on the name plate.
- Confirm that the cable thickness is as specified in the power sources specification. (Particularly note the relation between cable length and thickness.)
- Provide an ELB(electric leakage breaker) when the installation place is wet or moist.
- The following troubles would be caused by abnormal voltage supply such as sudden voltage increasing or voltage drop-down.
 - Chattering of a magnetic switch. (frequent on and off operation.)
 - Physical damage of parts where magnetic switch is contacted.
 - Break of fuse.
 - Malfunction of overload protection parts or related control algorithms.
 - Failure of compressor start up.
- Ground wire to ground outdoor unit to prevent electrical shock.




CAUTION

The Power cord connected to the unit should be selected according to the following specifications.

Finalizing

After pipes are connected and electric cables are wired, pipe forming and some tests are remained. Especially, careful attention is required while proceeding leakage test because the leakage of the refrigerant effects degrade of performance directly. Also, it is very hard to find leaked point after all installation procedures are finished.

Pipe Forming




Do pipe forming by wrapping the connecting cable and refrigerant pipe (between the indoor unit and outdoor unit) with thermal insulation material and secure it with two kinds of vinyl tape.


- Tape the refrigerant pipe, power cable and connecting cable from down to up.
- Secure the taped pipe is along with the exterior wall. Form a trap to prevent water entering the room and electrical part.
- Fix the taped pipe onto the wall by saddle or equivalent.

Taping Procedure

- Tape the pipes, connecting cable and power cable from down to up. If taping direction is up to down, rain drop may be sinking into the pipes or cables.
- Secure the taped pipe along the exterior wall using saddle or equivalent.
- Trap is required to prevent water from entering into electrical parts.



- Trap is required to prevent water from entering into electrical parts.



Leakage test and Evacuation

Air and moisture remaining in the refrigerant system have undesirable effects as indicated below.

- Pressure in the system rises.
- Operating current rises.
- Cooling(or heating) efficiency drops.
- Moisture in the refrigerant circuit may freeze and block capillary tubing.
- Water may lead to corrosion of parts in the refrigeration system.

Therefore, the indoor/outdoor unit and connecting tube must be checked for leak tight, and vacuumed to remove incondensable gas and moisture in the system.

Preparation

- Check that each tube(both liquid and gas side tubes) between the indoor and outdoor units have been properly connected and all wiring for the test run has been completed. Remove the service valve caps from both the gas and the liquid side on the outdoor unit. Check that both the liquid and the gas side service valves on the outdoor unit are kept closed at this stage.

Leakage test

- Connect the manifold valve(with pressure gauges) and dry nitrogen gas cylinder to this service port with charge hoses.




CAUTION

Be sure to use a manifold valve for leakage test. If it is not available, use a stop valve for this purpose. The "Hi" knob of the manifold valve must always be kept close.

- Pressurize the system to no more than 3.0 MPa with dry nitrogen gas and close the cylinder valve when the gauge reading reached 3.0 MPa Next, test for leaks with liquid soap.

To avoid nitrogen entering the refrigerant system in a liquid state, the top of the cylinder must be higher than its bottom when you pressurize the system. Usually, the cylinder is used in a vertical standing position.

- Do a leakage test of all joints of the tubing(both indoor and outdoor) and both gas and liquid side service valves. Bubbles indicate a leak. Be sure to wipe off the soap with a clean cloth
- After the system is found to be free of leaks, relieve the nitrogen pressure by loosening the charge hose connector at the nitrogen cylinder. When the system pressure is reduced to normal, disconnect the hose from the cylinder.



Electrical Wiring

General Consideration


Followings are should be considered before beginning indoor unit wiring.

- Field-supplied electrical components such as power switches, circuit breakers, wires, terminal boxes, etc should be properly chosen with compliance with national electrical legislation or regulation.
- Make it sure that supplied electricity is enough to operate the product including outdoor unit, electric heater, water tank heater, etc. The capacity of fuse also selected according to the power consumption.
- The main electricity supply should be dedicated line. Sharing main electricity supply with other devices such as washing machine or vacuum cleaner is not permitted.



CAUTION

- Before starting wiring job, the main electricity supply should be turned off until wiring is completed.
- When adjusting or changing wiring, the main electricity supply should be turned off and ground wire should be connected securely.
- Installation place should be free from the attack of wild animal. For example, mice's wire attacking or frog's entering into the indoor unit may cause critical electrical accident.
- All power connections should be protected from dew condensation by thermal insulation.
- All electrical wiring should comply with national or local electrical legislation or regulation.
- The ground should be connected exactly. Do not earth the product to the copper pipe, steel fence at the veranda, city water outlet pipe, or any other conductivity materials.
- Fix all cable using cord clamp tightly. (When cable is not fixed with cord clamp, use additionally supplied cable ties.)



Hole A : For High Voltage line (Wire which is connected to the terminal block of Heater Power)

Hole B : For AC line (Wire which is connected to the terminal block of the control box)


Hole C : For DC line (Wire which is connected to the PCB of the control box)

Terminal Block Information

Symbols used below pictures are as follows :

- L, L1, L2 : Live (230 V AC)
- N : Neutral (230 V AC)
- BR : Brown, WH : White, BL : Blue, BK : Black

For 1Ø



Terminal Block 1 ~ 3

Connection
for 3rd Party
controller
(5 V DC)

21(A)	22(B)
3rd PARTY CONTROLLER 3. PARTİ KONTROLÖR (5V DC)	

Connection for thermostat
(230 V AC)
Supporting type : Heating only or
Heating/Cooling

23(L)	24(N)	25(L1)	26(L2)	27(L3)
THERMOSTAT (Default : 230V AC) THERMOSTAT (Varsayılan : 230V AC)				


1	2	3(L)	4(N)	5	6	7(L)	8(N)	9(L1)	10(L2)	11(N)	12	13	14	15(L1)	16(L2)	17(N)	18(1(L))	19(2(N))	20(3)
		WATER PUMP SU POMPASI (C)				MIX PUMP MIX POMPASI		MIX VALVE MIX VANA						2WAY VALVE 2YOLLU VALF (A)			OUTDOOR UNIT DIŞ MEKAN ÜNİTESİ		
Energizing Water pump For DHW recirculation						Power supply for 2nd heating kit						opening or closing water flow for FCU cooling				Power supply for Indoor unit and communication			

Terminal Block 5


1	2	3(L)	4(N)		
POWER SUPPLY (1 Ø, 220-240 V, 50 Hz)					
connecting external electric power supply for backup heater					

CAUTION

You should separate the communication wiring, in case of communication wiring length is over 40 m.



Connecting with Outdoor Unit




The feature may be changed according to the type of model.

Backup Heater Wiring


CAUTION

Power Cable Specification : The power cord connected to the outdoor unit should be complied with IEC 60245 or HD 22.4 S4(Rubber insulated cord, type 60245 IEC 66 or H07RN-F)



If the supply cord is damaged, it must be replaced by the manufacturer, its service agent or similarly qualified persons in order to avoid a hazard.

External power supply
(same dedicated power supply for
the indoor unit and outdoor unit)



1Ø Backup Heater

PIPING AND WIRING FOR INDOOR UNIT

Procedures about water piping and electric wiring at the indoor unit are described in this chapter. Water piping and water circuit connection, water charging, pipe insulations will be shown for water piping procedures. For wiring, terminal block connection, connecting with the outdoor unit, electric heater wiring will be introduced. Accessories connection, such as sanitary water tank, thermostat, 3way or 2way valves, etc will be dealt in separated chapter.

Water Piping and Water Circuit Connection



CAUTION

General Considerations

Followings are should be considered before beginning water circuit connection.

- Service space should be secured.
- Water pipes and connections should be cleaned using water.
- Space for installing external water pump should be provided if internal water pump capacity is not enough for installation field.
- Never connect electric power while proceeding water charging.

Definition of terms are as follow :

- Water piping : Installing pipes where water is flowing inside the pipe.
- Water circuit connecting : Making connection between the product and water pipes or between pipes and pipes. Connecting valves or elbows are, for example, in this category.

Configuration of water circuit is shown in Chapter 2. All connections should be complied with presented diagram.

While installing water pipes, followings should be considered :

- While inserting or putting water pipes, close the end of the pipe with pipe cap to avoid dust entering.
- When cutting or welding the pipe, always be careful that inner section of the pipe should not be defective. For example, no weldments or no burrs are found inside the pipe.
- Drain piping should be provided in case of water discharge by the operation of the safety valve. This situation can be happened when the internal pressure is over 3.0 bar and water inside the indoor unit will be discharged to drain hose.

While connecting water pipes, followings should be considered.

- Pipe fittings (e.g. L-shape elbow, T-shape tee, diameter reducer, etc) should be tightened strongly to be free from water leakage.
- Connected sections should be leakage-proof treatment by applying teflon tape, rubber bushing, sealant solution, etc.
- Appropriate tools and tooling methods should be applied to prevent mechanical breakage of the connections.
- Operation time of flow control valve(e.g. 3way valve or 2way valve) should be less than 90 seconds.
- Drain hose should be connected with drain piping.
- Maximum allowable Torque at the water piping connection is 50 N·m
- Connect the water for filling or refilling the heating system as specified by EN 1717/EN 61770 to avoid contamination of drinking water by return flow.



WARNING

Water condensation on the floor

While cooling operation, it is very important to keep leaving water temperature higher than 16 °C. Otherwise, dew condensation can be occurred on the floor.

If floor is in humid environment, do not set leaving water temperature below 18 °C.

Water condensation on the radiator

While cooling operation, cold water may not flow to the radiator. If cold water enters to the radiator, dew generation on the surface of the radiator can be occurred.

Drainage treatment

While cooling operation, condensed dew can drop down to the bottom of the indoor unit. In this case, prepare drainage treatment (for example, vessel to contain condensed dew) to avoid water drop.


Connection to the Domestic hot water system

The hydraulic connection has to be installed in accordance with the national and local regulations. For connecting DHW to enable the water flow in full force. To prevent water leakage, install a drain through the floor below the level of the device. The following picture shows the correct hydraulic connection of the device.

Water Piping

Connect the hot water pipe ①, the cold water supply ② and optionally the re-circulation pipe ③ as shown below. If a re-circulation pipe is not used, close it with a 1" cap.

Use a counter wrench to tighten the connections firmly.




No.	Connections	Recommended tightening torque [N·m]
①	Domestic hot water outlet pipe (female G1")	42 ± 2
②	Domestic cold water inlet pipe (female G1")	
③	DHW recirculation pipe (female G1")	

NOTE

Before connect domestic water pipes, use the provided gaskets(G1") for each water pipe.

* There are 3 gaskets between pipes and caps, which is in Heating circuit outlet pipe, Domestic cold water inlet pipe and DHW Re-Circulation pipe. 2 gaskets are enclosed inside the product box.



CAUTION

- Because different materials are used on the pipe installation, all connections on the device (cold and hot water, circulation, heat conductor) have to be galvanically isolated; otherwise corrosion of connections can occur. We recommend placing galvanic isolators made of red brass the length of at least twice the diameter of the pipe on the connections.
- The DHW tank is intended for storing drinking water, this is why the water has to be in accordance with the national regulations on drinking water in force; otherwise, damage to the device and a termination of the warranty can arise.
- The unit is equipped with a safety valve with a rated pressure of 1 MPa (10 bar).
- In addition, it is necessary to install either a DHW expansion vessel. Alternatively, another pressure relief valve must be installed with suitable set point lower than that of the safety valve. Such a valve would need to be equipped with a hose and connected to a sink.

Setting the pressure for the expansion vessel for DHW

NOTE

- The cold DHW connection must be fitted with an expansion vessel suitable for drinking water. The selection and installation must be in accordance with the standard DIN 4807 T5.
 - An expansion vessel of 8 l volume can be integrated into the unit.
 - The actual size of the vessel must be decided by the installer. If a larger volume is needed, a third-party expansion vessel must be installed outside of the unit.
-
- For proper operation of the expansion vessel, a suitable setting of the vessels operating pressure must be made. The pressure is set in regards to the pressure in the DHW system. The setting needs to be checked every 12 months.
 - Expansion vessel for DHW is factory filled to a precharge pressure p_0 with dry nitrogen. The pressure must be set depending on the settings of the pressure reducing valve on the DHW supply to the building.
 - The pressure in the expansion vessel must be set according to the following formula:

$$p_0 = p_{rv} - 0,2 \text{ bar}$$

p_0 – pressure in the expansion vessel

p_{rv} – setting of the pressure reducing valve

Connection to the Heating system

The selection of circulation pumps, valves, safety elements and pipes has to be performed by the design engineer according to the heating/cooling capacity of the device and minimum water flow rate.


!

CAUTION

- Before connecting the device, it is necessary to rinse the pipe system thoroughly and remove impurities. Use suitable detergents if necessary.
- Thorough venting of the system has to be ensured. Otherwise, malfunctions in operation may occur.

Water Piping

Assemble ball valves (field supply) before connecting the Inlet ① and Outlet ② pipes. Use a counter wrench to tighten the connections firmly.



No.	Connections	Recommended tightening torque [N·m]
①	Heating/Cooling circuit inlet pipe (female G1")	42 ± 2
②	Heating/Cooling circuit outlet pipe (female G1")	

NOTE

Before connect heating water pipes, use the provided gaskets(G1") for each water pipe.


* There are 3 gaskets between pipes and caps, which is in Heating circuit outlet pipe, Domestic cold water inlet pipe and DHW Re-Circulation pipe. 2 gaskets are enclosed inside the product box.

Water Volume and Expansion Vessel Pressure

- The expansion vessel must be dimensioned in accordance with standard EN 12828. The integrated vessel has a volume of 8 liters. If the expansion volume is not enough, and additional vessel must be installed externally (Field supply).

CAUTION

- For normal operation of the expansion vessel, it is necessary to perform proper adjustments of the vessel's working pressure. The integrated vessel is supplied with a factory pre-charge of 1 bar. The settings have to be checked every 12 months.
- Consider the maximal operational pressure of the vessel.
- Unsuitable charge of the expansion vessel with the pressure p_0 is the reason for incorrect operation of the heating system.



H - Height of the heating system
 p_{sv} - Pressure of the safety valve.

Setting the pressure for the expansion vessel p_0

- Before filling the system with water, check and set the pressure p_0 . The expansion vessel is factory set to the pressure specified on its data label. For correct operation of the system, set the pressure p_0 according to the equation below. The filling must not exceed the maximum operational pressure specified on the data label of the expansion vessel.
- Calculate the p_0 pressure value with the help of the equation:

$$p_0[\text{bar}] = H[\text{m}]/10 + 0.3 [\text{bar}]$$

$p_0[\text{bar}]$ – pressure in the expansion vessel

$p_{0min} [\text{bar}]$ – minimum allowable pressure of the heating system

$p_{0max} [\text{bar}]$ – maximum allowable pressure of the heating system

$H[\text{m}]$ – Height of the heating system (from expansion vessel to the highest heating body in the building).

If the calculation shows a pressure lower than 1 bar, set the pressure of the expansion vessel to 1 bar.

- Set the amount of pressure in the expansion vessel by releasing or adding dry nitrogen.
- Record the new value of the pressure p_0 on the data label.
- Open the closing valve of the expansion vessel carefully, open the vents and close the drain.


Water Volume and Expansion Vessel Pressure

Inside expansion vessel is included which is 8 liter capacity with 1 bar pre-pressure. That means, according to the volume-pressure graph, total water volume of 230 liter is supported as default. If total water volume is changed because of installation condition, the pre-pressure should be adjusted to secure proper operation.

If	Minimum water volume
The system contains a backup heater	20 L
The system does NOT contain a backup heater	80 L

* The internal water volume of the outdoor unit is NOT included

- Pre-pressure is adjusted by the total water volume. If the indoor is located at the highest position of the water circuit, adjustment is not required.
- To adjust pre-pressure, use nitrogen gas by certificated installer.



Adjusting pre-pressure of expansion vessel is as following :

Step 1. Refer "Volume-Height" table.

If installation scene is belong to Case A, go to Step 2.
 Otherwise, if it is Case B, do nothing. (pre-pressure adjustment is not required.)
 Otherwise, if it is Case C, go to Step 3.

Step 2. Adjust pre-pressure by following equation.

Pre-pressure [bar] = $(0.1 \times H + 0.3)$ [bar]
 where H : difference between unit and the highest water pipe
 0.3 : minimum water pressure to secure product operation

Step 3. Volume of expansion vessel is less than installation scene.

Please install additional expansion vessel at the external water circuit.

Volume-Height Table

	V < 230 liter	V ≥ 230 liter
H < 7 m	Case B	Case A
H ≥ 7 m	Case A	Case C

H : Difference between unit and the highest water pipe

V : total water volume of installation scene

Water Charging

For water charging, please follow below procedures.

For DHW Tank

- Step 1.** Open all hot water tap.
Step 2. Open the cold water supply valve to fill DHW Tank.
Step 3. Close all water taps after air is purged.

For space heating

- Step 1.** Open all valves of whole water circuit. Supplied water should be charged not only inside the indoor unit, but also in the under floor water circuit, sanitary water tank circuit, FCU water circuit, and any other water circuits controlled by the product.
Step 2. Connect supply water into drain valve and fill valve.



CAUTION

No water-leakage permitted at the drain and fill valve. Leakage-proof treatment which is described in previous section should be applied.

- Step 3.** Start to supply water. While supplying water, following should be kept.
- Pressure of supplying water should be 2.0 bar approximately.
 - For supplying water pressure, time to be taken from 0 bar to 2.0 bar should be more than 1 minute. Sudden water supply can yield water drain through safety valve.
 - Fully open the cap of air vent to assure air purging. If air is exist inside the water circuit, then performance degrade, noise at the water pipe, mechanical damage at the surface of electric heater coil (Air purge is located at the top of the heater.).
 - Use the "pump test run" function. (both a space heating line and a DHW line are open during the pump test run operation.)
- Step 4.** Stop water supplying when the pressure gauge located in front of the control panel indicates 2.0 bar.
- Step 5.** Close drain valve and fill valve. Then wait for 20~30 seconds to observe water pressure being stabilized.
- Step 6.** If following conditions are satisfactory, then go to step 7(pipe insulation). Otherwise, go to step 3.
- Pressure gauge indicates 2.0 bar. Note that sometimes pressure in decreased after step 5 due to water charging inside expansion vessel.
 - No air purging sound is heard or no water drop are popping out from air vent.



CAUTION

Keep the air vent of the water pipe open and keep the air vent of the pump closed. Otherwise, the pump may make noise.

Pipe Insulation

Purpose of water pipe insulation is :


- To prevent heat loss to external environment
- To prevent dew generation on the surface of the pipe in cooling operation
- Minimum insulation thickness recommendations ensure correct operation of the product, but local regulations may vary and must be followed.

* $\lambda = 0.04 \text{ W/mk}$

Water Piping length (m)	Minimum insulation Thickness(mm)
<20	20
20~30	30
30~40	40
40~50	50

NOTE

Before opening the Control Box, remove the harness shown below.



CAUTION

After finishing the work, Please connect the harness back again.

Water pump Capacity

The water pump is variable type which is capable to change flow rate, so it may be required to change default water pump capacity in case of noise by water flow. In most case, however, it is strongly recommended to set capacity as Maximum.

NOTE

- To secure enough water flow rate, do not set water pump capacity as Minimum.
It can lead unexpected flow rate error CH14.

Pressure Drop

NOTE

When installing the product, install additional pump in consideration of the pressure loss and pump performance.
If flow-rate is low, overloading of product can occur.


Capacity [kW]	Rated flow-rate [LPM]	Pump Head [m] (at rated flow-rate)	Product pressure drop [m] (Plate heat exchanger)	Serviceable Head [m]
9	25.9	6.1	0.4	5.7
7	20.1	7.3	0.3	7.0
5	15.8	7.5	0.2	7.3

※ Above data is valid at Rated flow-rate with delta-temperature of 5 Kelvin.

Performance curve

5, 7, 9 kW

MGQ62321902 : UPM3K GEO 20 - 75 CHBL



WARNING

Selecting a water flowrate outside the curves can cause damage to or malfunction of the unit.

Water Quality

Water quality should be complied with EN 98/83 EC Directives.

Detailed water quality condition can be found in EN 98/83 EC Directives.

CAUTION

- If the product is installed at existing hydraulic water loop, it is important to clean hydraulic pipes to remove sludge and scale.
- Installing sludge strainer in the water loop is very important to prevent performance degrade.
- Chemical treatment to prevent rust should be performed by installer.
- It is strongly recommended to install an additional filter on the heating water circuit. Especially to remove metallic particles from the heating piping, it is advised to use a magnetic or cyclone filter, which can remove small particles. Small particles may damage the unit and will NOT be removed by the standard filter of the heat pump system.

Frost protection by antifreeze

In areas of the country where entering water temperatures drop below 0 °C, the water pipe must be protected by using an approved antifreeze solution. Consult your AWHP unit supplier for locally approved solutions in your area. Calculate the approximate volume of water in the system. (Except the AWHP unit.) And add six liters to this total volume to allow for the water contained in AWHP unit.

Antifreeze type	Antifreeze mixing ratio					
	0 °C	-5 °C	-10 °C	-15 °C	-20 °C	-25 °C
Ethylene glycol	0 %	12 %	20 %	30 %	-	-
Propylene glycol	0 %	17 %	25 %	33 %	-	-
Methanol	0 %	6 %	12 %	16 %	24 %	30 %

If you use frost protection function, change DIP switch setting and input the temperature condition in Installation mode of remote controller. Refer to 'CONFIGURATION > DIP Switch Setting > DIP Switch Information > Option Switch 3' and 'INSTALLER SETTING > Antifreezing Temperature'.

CAUTION

- Use only one of the above antifreeze.
- If a antifreeze is used, pressure drop and capability degradation of the system can be occurred.
- If one of antifreezes is used, corrosion can be occurred. So please add corrosion inhibitor.
- Please check the concentration of the antifreeze periodically to keep same concentration.
- When the antifreeze is used (for installation or operation), take care to ensure that antifreeze must not be touched.
- Ensure to respect all laws and norms of your country about Anti-freeze usage.

ACCESSORIES INSTALLATION

THERMAV. can interface to various accessories to extend its functionality and to improve user convenience. In this chapter, specifications about supported 3rd party accessories and how to connect to **THERMAV.** is introduced.

The Product is designed to work with the following LG accessories. Regarding any other compatible accessories refer to Product Databook or ask your local dealer.

Accessories supported by LG Electronics

Item	Purpose	Model
Dry contact	To receive on & off external signal	PDRYCB000
	Dry contact For Thermostat	PDRYCB320
Meter Interface	To measure production / consumption power	PENKTH000
Wi-Fi Modem	To enable remote system operation from smartphone	PWFMDD200
Thermistor for 2 nd Circuit or E/heater	To interlock with 2 nd circuit operation and control temperature of main zone or To interlock with 3 rd party E/Heater and control temperature of water out 3 rd party E/Heater.	PRSTAT5K10
Extension Wire	To connect remote controller with Indoor PCB for communication	PZCWRC1
Cover Plate	To relocate remote controller from indoor unit	PDC-HK10
Remote air sensor	To control the unit using Room air as reference temperature	PQRSTA0
Extension cable	To extend Wi-Fi modem cable	PWYREW000
RS3 remote controller	To control unit with 2 remote controllers	PREMTW101
2-Remo Control Wire	The wire for 2 remo control	PZCWRC2
Mixing valve	3/4" DN20	OSHA-MV
Mixing valve	1" DN25	OSHA-MV1

Accessories supported by 3rd party Companies

Item	Purpose	Specification
Thermostat	To control by air temperature	• Heating-Only type (230 V AC) • Cooling/Heating type (230 V AC with Mode selection switch)
Mix Kit	To use mixing circuit	• Mixing valve • Mix pump
3 rd Party Boiler	To use auxiliary boiler.	
3 rd Party Controller	To connect external controller using modbus protocol	
2way valve and actuator	To control water flow for Fan Coil Unit	2 wire, NO(Normal Open) or NC(Normal Closed) type, 230 V AC
External Pump	To control the water flow at the rear of the buffer tank	
Smart Grid	To control operation mode depending on input signal from provider	
3 rd Party ESS	To control the operation mode according to the energy storage state	
Expansion Vessel for DHW tank	For DHW system - Integrable inside of unit	Ø CONNECTION : ¾" G Max. working pressure : 10 bar Pre-charged pressure : 3 bar Outer diameter : 200mm

Before Installation



WARNING

Followings should be kept before installation

- Main power must be turned off during installing accessories.
- 3rd party accessories should be comply with supported specification.
- Proper tools should be chosen for installation.
- Never do installation with wet hands.

Thermostat

Thermostat is generally used to control the product by air temperature. When thermostat is connected to the product, the product operation is controlled by the thermostat.


Installation condition

! CAUTION

- USE 220-240 V~ Thermostat
- Some electro-mechanical type thermostat has internal delay time to protect compressor. In that case, mode change can takes time more than user's expectation. Please read thermostat manual carefully if the unit does not response quickly.
- Setting temperature range by thermostat can be different with that of the unit. The heating or cooling set temperature should be chosen within the setting temperature range of the unit.
- It is highly recommended that the thermostat should be installed where space heating is mainly applied.

Following location should be avoid to secure proper operation :

- Height from floor is approximately 1.5 m.
- Thermostat can not be located where the area may be hidden when door is open.
- Thermostat can not be located where external thermal influence may be applied. (such as above heating radiator or open window)



Thermostat

General Information

The Heat Pump supports following thermostats.

Type	Power	Operating Mode	Supported
Mechanical (1)	230 V~	Heating Only (3)	Yes
		Heating / Cooling (4)	
		Heating / Cooling / DHW Heating (5)	
Electrical (2)	230 V~	Heating Only (3)	Yes
		Heating / Cooling (4)	
		Heating / Cooling / DHW Heating (5)	

- (1) There is no electric circuit inside the thermostat and electric power supply to the thermostat is not required.
- (2) Electric circuit such as display, LED, buzzer, etc is included in the thermostat and electric power supply is required.
- (3) Thermostat generates "Heating ON or Heating OFF" signal according to user's heating target temperature.
- (4) Thermostat generates both "Heating ON or Heating OFF" and "Cooling ON or Cooling OFF" signal according to user's heating and cooling target temperature.
- (5) For Hydrosplit IWT, Thermostat generates "Heating ON or Heating OFF", "Cooling ON or Cooling OFF", "DHW Heating ON or DHW Heating OFF" signal according to user's heating, cooling and DHW heating target temperature.



CAUTION

Choosing heating / cooling thermostat

- Heating / cooling thermostat must have "Mode Selection" feature to distinguish operation mode.
- Heating / cooling thermostat must be able to assign heating target temperature and cooling target temperature differently.
- If above conditions are not kept, the unit can not operation properly.
- Heating / cooling thermostat must send cooling or heating signal immediately when temperature condition is satisfied. No delay time while sending cooling or heating signal is permitted.


How to wire thermostat

Follow below procedures Step 1 ~ Step 3.

Step 1. Uncover front cover of the unit and open the control box.

Step 2. Identify the power specification of the thermostat. If it is 220-240 V~, go to Step 3.

Step 3. Find terminal block and connect wire as below.



WARNING

Mechanical type thermostat.

Do not connect wire (N) as mechanical type thermostat does not require electric power supply.



CAUTION

Do not connect external electric loads.

Wire (L) and (N) should be used only for operation electric type thermostat.

Never connect external electric loads such as valves, fan coil units, etc. If connected, Main PCB (Heater) can be seriously damaged.

(L) : Live signal from PCB to thermostat

(N) : Neutral signal from PCB to thermostat

(C) : Cooling signal from thermostat to PCB

(H) : Heating signal from thermostat to PCB

(D) : DHW Heating signal from thermostat to PCB

Final check

- DIP switch setting :
Set DIP switch No. 8 to 'ON'. Otherwise, the unit can not recognize the thermostat.
- Remote Controller :
 - 'Thermostat' text is displayed on the remote controller.
 - Button input is prohibited.

2nd Circuit

The 2nd circuit is a function that can separately control the circuit1 requiring high temperature and the circuit 2 requiring medium temperature, you need to prepare a separate Mix Kit. The mix kit must be installed in the circuit 2.

[Install Guide Mixing circuit Heating]

Circuit 1 \ Circuit 2	Floor (35°C)	Convactor (FCU, 45 °C)	Radiator (45 °C)	Radiator (55 °C)
Floor (35 °C)	○	○	○	○
Convactor (FCU, 45 °C)	○	○	○	○
Radiator (45 °C)	○	○	○	○
Radiator (55 °C)	○	○	○	○

[Install Guide Mixing circuit Cooling]

Circuit 1 \ Circuit 2	Floor (18 °C)	Convactor (FCU, 5 °C)
Floor (18 °C)	○	○
Convactor (FCU, 5 °C)	○	○

- ※ To use a floor combination during cooling operation, the flow through the floor of the flow must be blocked by the 2 way valve.
- ※ For detailed 2nd circuit remote control settings, refer to 'Mixing Circuit' under [Chapter 9]

NOTE


Circuit 1 = Direct circuit : Zone where the water temperature is Highest when heating
 Circuit 2 = Mixing circuit : The other zone

How to Wire Mixing Kit

Follow below procedures Step 1 ~ Step 3.

Step 1. Uncover front cover of the unit.

Step 2. Find terminal block and connect wire as below



(L) : Live signal from PCB to mix pump

(N) : Neutral signal from PCB to mix pump


(L1) : Live signal (for Normal* Closed type) from PCB to mixing valve

(L2) : Live signal (for Normal Open type) from PCB to mixing valve

(N1) : Neutral signal from PCB to mixing valve

*Closed = NOT Mixed

Step3. Insert the temperature sensor to 'CN_MIX_OUT' (Brown) of the main PCB as shown below. The sensor should be mounted correctly to discharge pipe of mix pump as shown below.



NOTE

- The location of the external pump may vary depending on the installer settings.
- Temperature sensor specification:
Type : Thermistor, NTC
Resistance at 25 °C : 5 kΩ
Minimum operating temperature range : -30 °C ~ 100 °C

[Thermistor for Mixing circuit]



Sensor



Sensor Holder



Sensor Connector

Follow below procedures step 1 ~ step 4.


Step 1. Install sensor connector to discharge pipe of mix pump.

(Welding must be performed to connect the sensor connector to the pipe)

Step 2. Check if the power of the unit is turned off.

Step 3. Fasten the sensor connector to the sensor holder as shown in the figure below.

Step 4. Insert harness into PCB(CN_MIX_OUT) fully and fix the thermal sensor into tube connector as shown below.



3rd Party Boiler

The product can be used by connecting an Auxiliary boiler. 3rd party boiler can be controlled by manually via RS3 remote controller or automatically itself by means of comparing the outside air temperature and the preset temperature.


How to wire 3rd party boiler

Follow below procedures step 1 ~ step 3.

Step 1. Check if the power of the unit is turned off.

Step 2. Disassemble front panels and Distinguish terminal block in Indoor PCB.

Step 3. Connect Power cable to terminal block fully.



3rd Party Controller

The product can also be linked to 3rd party controller. You can connect external controllers using Modbus protocol except for LG controller. If 3rd party controller is used, LG controller is not applied to AWHP simultaneously.

How to wire 3rd party controller


Follow below procedures step 1 ~ step 4.

Step 1. Check if the power of the unit is turned off.

Step 2. Disassemble front panels and distinguish control box(Indoor) of the unit.

Step 3. Check if the harness(White) is inserted fully to the indoor unit PCB.

Step 4. Connect the 3rd party controller to terminal block 4 completely. (including Meter interface module)




Meter Interface

This product can be used by connecting the meter interface module supplied in the field. The meter interface module can communicate with the wired remote controller. The meter interface module lets you know the amount of power generated by the product.

- For detailed installation method refer to meter interface Installation Manual.

How to wire Meter Interface

[Parts of Meter interface]



Meter interface body


Follow below procedures step 1 ~ step 4.

Step 1. Check if the power of the unit is turned off.

Step 2. Disassemble front panels and Distinguish control box(Indoor) of the unit.

Step 3. Check if the harness(White) is inserted fully to the indoor unit PCB.

Step 4. Connect the external pump to terminal block 4.



Central Controller

The product can communicate and control through the central controller. The following functions can be controlled in the central control linked state (Operation/Stop, Desired temperature, Hot water operation / stop, Warm water temperature, Full lock, Etc)

LG Central controller

Item	Purpose	Model
ACP 5	To control AWHP using LG central controller	PACEZA000
AC Smart 5		PACS5A000
ACP Ez Touch		PACP5A000

Accessories for Central controller

Item	Purpose	Model
PI485 Gateway	To connect LG Central Controller / Modbus	PP485A00T
Modbus RTU Gateway	To communicate and control BMS / 3 rd party controller directly.	PMBUSB00A

NOTE

- PI485 is required for central controller.


How to Installation PI485

Fix the PI485 PCB as shown in below images.

For detailed installation method refer to PI485 Installation Manual

Product Heating Capacity : 5 kW, 7 kW, 9 kW

U36A Chassis




- For detailed installation instructions, refer to the manual included in the accessories.

How to Installation Modbus gateway

Connect the Modbus gateway as shown in below diagram.

For detailed installation method refer to Modbus gateway Installation Manual.



Dry Contact

Dry Contact is a solution for automatic control of HVAC system at the owner's best. In simple words, it's a switch which can be used to turn the unit On/Off after getting the signal from external sources.

How to install dry contact

[Parts of Dry contact]



Dry Contact body




Cable(for connecting with IDU)

Follow below procedures step 1 ~ step 6.

Step 1. Check if the power of the unit is turned off.

Step 2. Disassemble front panels and distinguish terminal block in Indoor PCB.




Step 3. Before installing the dry contact PCB inside control box, Remove the marking label on control box for using the holes.

Step 4. Secure the dry contact PCB using the provided supporters in control box.

Step 5. Connect cable to the unit PCB(CN_CC) fully.

Step 6. Then, Insert harness to the dry contact PCB(CN_INDOOR) firmly as shown below.




NOTE


- For more information about installing Dry Contact, Please refer installation manual provided with Dry Contact.
- For system set-up, please read chapter 9.

[Setting of Contact Signal Input - PDRYCB320]

- For input contact closure only(No power input)



- For input contact voltage : DC 12 V, AC 24 V~



External Controller - Setting up programmable digital input operation

If you require to control depending on external digital input(ON/OFF), connect cable to indoor PCB(CN_EXT).




Follow below procedures step 1 ~ step 4.

Step 1. Check if the power of the unit is turned off.

Step 2. Disassemble front panels and distinguish control box(Indoor) of the unit

Step 3. Connect the external controller to PCB(CN_EXT) completely.

Step 4. Connect the cable and field installation part.



Remote Temperature Sensor


Remote temperature sensor can be installed any place a user wants to detect the temperature.

- The function is not available for some products.


Installation condition

Role and constraint while installation of remote air temperature sensor is very similar to that of thermostat.

- Distance between the unit and the remote air temperature sensor should be less than 15 m due to length of the connection cable of remote air temperature sensor.
- For other constraints, please refer to previous page where constraints about thermostat is described.



Thermostat



Remote Air Temperature Sensor

How to Install Remote Temperature Sensor

[Parts of Remote Temperature Sensor]



Remote sensor



Connection wire



Screw(to fix remote sensor)

Follow below procedures step 1 ~ step 6.


Step 1. Decide where the remote temperature sensor is Installed. Then, Determine the location and height of the fixing screws in fig. 1 (Interval between the screws : 60 mm)

Step 2. Check if the power of the unit is turned off.

Step 3. Disassemble front panels and distinguish control box(Indoor) of the unit.

Step 4. Insert temperature sensor into PCB(CN_ROOM) and fix the sensor firmly in fig. 2.


Step 5. The Connection wire does not matter if you change the color of the wire because of nonpolar.



[fig. 1]

[fig. 2]

Step 6. Integrate the remote temperature sensor with the screws as the order of arrows.



CAUTION

- Choose the place where the average temperature can be measured for the unit operates.
- Avoid direct sunlight.
- Choose the place where the cooling/heating devices do not affect the remote sensor.
- Choose the place where the outlet of the cooling fan do not affect the remote sensor.
- Choose the place where the remote sensor isn't affected when door is open.

NOTE

- For more information about installing Remote Temperature Sensor, Please refer installation manual provided with Remote Temperature Sensor.
- For system set-up, please read chapter 9.

External pump

External pump can be required when the room to take floor heating is too long or the pressure drop of heat emitter is too large to produce the required flow rate.

Also, the external pump shall be installed to assist water circulation when the buffer tank is installed.


How to wire external pump

Follow below procedures step 1 ~ step 3.

Step 1. Check if the power of the unit is turned off.

Step 2. Disassemble front panels and distinguish terminal block in Indoor PCB.

Step 3. Connect signal cable to terminal block fully.



Wi-fi Modem


Wi-fi modem enables remote system operation from smartphone. Available functions include selection of on/off, operation mode, DHW heating, temperature setup and weekly scheduling etc.

How to install Wi-fi Modem


[Parts of Wi-fi modem]




Wi-fi modem body



USB Cable



Extension Cable



Holder

Follow below procedures step 1 ~ step 6.


Step 1. Check if the power of the unit is turned off.

Step 2. Disassemble front panels and distinguish control box(Indoor) of the unit.

Step 3. Connect the USB cable to the indoor unit PCB (CN_WF ; Blue) until it clicks into place.

Step 4. Connect the Wi-Fi modem to the USB cable fully.

Step 5. Refer to the image below to install the Wi-Fi modem in the marked position.



Step 6. Secure the holder of Wi-fi modem on top cover of the product.

NOTE

- Please install the Wi-fi modem outside the product for smooth operation.
- Extension cable[PWYREW000] can be used if the length of the connecting cable is insufficient.

Energy State

This product provides energy states that enable customers to use as much as possible of their own renewable energy. It can shift setpoints depending on input signal from Energy Storage System (ESS) or from any other third-party device using Modbus RTU or Digital 230V inputs.

Available Energy States

There are 8 energy states available. 4 fixed and 4 customizable - each with the possibility to enhance Self-consumption of renewable energy.

Energy state	Command	Battery State of charge	Operation (standard setting)					
			Heating		Cooling		Domestic Hot Water	
			Setting	Range	Setting	Range	Setting	Range
1	Operation Off (Utility lock)	Low	Forced internal operation off	Fixed	Forced internal operation off	Fixed	Forced internal operation off	Fixed
2	Normal Operation	Normal	Maintain operation status	Fixed	Maintain operation status	Fixed	Maintain operation status	Fixed
3	Operation On Recommend	High	Increase 2 °C from target temperature	Fixed	Maintain operation Status	Fixed	Increase 5 °C from target temperature	Fixed
4	Operation On Recommend	Very High	Maintain operation status	Fixed	Maintain operation status	Fixed	DHW Target 80 °C	Fixed
5	Operation On Command	Very High	Increase from target temperature	0/+30 (Default : +5)	Decrease from target temperature	0/-30 (Default : -5)	Increase from target temperature	0/+50 (Default : +30)
6	Operation On Recommend	High	Increase from target temperature	0/+30 (Default : +2)	Decrease from target temperature	0/-30 (Default : -2)	Increase from target temperature	0/+50 (Default : +10)
7	Operation Save	Low	Decrease from target temperature	0/-30 (Default : -2)	Increase from target temperature	0/+30 (Default : +2)	Decrease from Target Temperature	0/-50 (Default : 0)
8	Operation Super Save	Very Low	Decrease from target temperature	0/-30 (Default : -5)	Increase from target temperature	0/+30 (Default : +5)	Decrease from Target Temperature	0/-50 (Default : 0)

Digital Input for energy saving (ESS, Smart Grid)

This product provides two digital inputs (ES1/ES2) that can be used to switch between energy states when not using Modbus RTU (CN_MODBUS).

Available Energy States

There are 8 energy states available in total. Four different states can be triggered using the 230V-inputs – by default Energy states 1-4.

With the digital input assignment in the menu 'Energy state/Digital input assignment' of the control panel, different Energy states can be selected for Signals 0:1 and 1:1.

0:0 is always linked with ES2 (Normal operation) and 1:0 is always linked with ES1 (Operation off/Utility lock).


How to set Digital input signal

Follow below procedures step 1 ~ step 3.

Step 1. Check if the power of the unit is turned off.

Step 2. Disassemble front panels and distinguish terminal block in Indoor PCB.

Step 3. Connect signal cable to terminal block in PCB (ES2, ES1) fully as shown below.



Energy state depending on input signal (ES1/ES2)

Input Signal		Output state	
ES1	ES2	Default	Range
0	0	ES2	fixed
1	0	ES1	
0	1	ES3	ES3-ES8
1	1	ES4	

2Way Valve

2way valve is required to control water flow while cooling operation. Role of 2way valve is to cut off water flow into under floor loop in cooling mode when fan coil unit is equipped for cooling operation.

General Information

THERMAV. supports following 2way valve.

Type	Power	Operating Mode	Supported
NO 2-wire (1)	230 V AC	Energize : Valve closing	Yes
		De-energize : Valve opening	
NC 2-wire (2)	230 V AC	Energize : Valve opening	Yes
		De-energize : Valve closing	

(1) : Normal Open type. When electric power is NOT supplied, the valve is open. (When electric power is supplied, the valve is closed.)


(2) : Normal Closed type. When electric power is NOT supplied, the valve is closed. (When electric power is supplied, the valve is open.)

How to Wire 2Way Valve

Follow below procedures Step 1 ~ Step 2.

Step 1. Uncover front cover of the unit.

Step 2. Find terminal block and connect wire as below.



CAUTION

Dew Condensation

- Wrong wiring can yield dew condensation on the floor. If radiator is connected at the under floor water loop, dew condensation can be occurred on the surface of the radiator.

WARNING

Wiring

- Normal Open type should be connected to wire (NO) and wire (N) for valve opening in cooling mode.
- Normal closed type should be connected to wire (NC) and wire (N) for valve closing in cooling mode.

(NO) : Live signal (for Normal Open type) from PCB to 2way valve.

(NC) : Live signal (for Normal Closed type) from PCB to 2way valve.


(N) : Neutral signal from PCB to 2way valve.

Final Check


- Flow direction :
 - Water should not flow into under floor loop in cooling mode.
 - To verify the flow direction, check temperature at the water inlet of the under floor loop.
 - If correctly wired, this temperatures should not be reached below 16 °C in cooling mode.

Domestic hot water expansion vessel – integrated into the unit


How to install DHW expansion vessel (Field Supply)



Step 1. Screw the hose to the dedicated port ③ inside of the unit.



Step 2. Place the vessel ① on top of the holder ④ and fasten the connection hose from below.



Final check

No.	Check point	Description
1	Connection of Water Inlet/Outlet	- Check if the shut-off valves should be assembled with Water inlet and outlet pipe of the unit - Check the location of the water inlet/outlet water pipe
2	Hydraulic pressure	- Check the pressure of supplying water by using pressure gauge inside the unit - Pressure of Supplying water should be Under 3.0 bar approximately - Pressure of Supplying tank water should be Under 10.0bar approximately
3	Water pump capacity	- To secure enough water flow rate, do not set water pump capacity as Minimum. - It can lead unexpected flow rate error CH14. (Refer to Chapter 4 'Water Piping and Water Circuit Connection')
4	Transmission line and power source wiring	- Check if Transmission line and power source wiring are separated from each other. - If it is not, electronic noise may occur from the power source.
5	The power cord specifications	- Check the power cord specifications (Refer to Chapter 4 'Connecting Cables')
6	2Way Valve	- Water should not flow into under floor loop in cooling mode. - To verify the flow direction, check temperature at the water inlet of the under floor loop. - If correctly wired, this temperatures should not be reached below 16 °C in cooling mode.
7	Air Vent	- Air-vent must be located highest level of Water pipe system - It should be installed at the point which is easy to service. - It takes some times to remove air in the water system if air purge is not performed sufficiently it may occur CH14 error. (refer to Chapter 4 'Water Charging')

CONFIGURATION

As **THERMAV** is designed to satisfy various installation environment, it is important to set up system correctly. If not configured correctly, improper operation or degrade of performance can be expected.

DIP Switch Setting





CAUTION

Turn off electric power supply before setting DIP switch

- Whenever adjusting DIP switch, turn off electric power supply to avoid electric shock.

General Information

Indoor PCB



OFF is selected



ON is selected

DIP Switch Information

Option Switch 2

Description	Setting		Default
Group control	1 	As Master	1 
	1 	As Slave	
Accessory installation information	  2 3	DHW integrated indoor unit + Outdoor unit is installed	2  3 
	  2 3		
	  2 3		
	  2 3	Reserved	
Cycle	4 	Heating Only	4 
	4 	Heating & Cooling	
Room Air Sensor	5 	Room Air Sensor is not installed	5 
	5 	Room Air Sensor is installed	
Selecting electric heater capacity	  6 7	Electric heater is not used	6  7 
	  6 7		
	  6 7		
	  6 7	Electric heater is used	
Thermostat installation information	8 	Thermostat is NOT installed	8 
	8 	Thermostat is installed	

Option Switch 1


Description	Setting		Default
MODBUS	1 	As Master (LG Extension Module)	1 
	1 	As Salve (3 rd Party Controller)	
MODBUS Function	2 	REGIN	2 
	2 	Unified Open Protocol	
ANTIFREEZE	8 	Antifreeze mode not use	8 
	8 	Antifreeze mode *	

※ Only the switch in the table has a function. Others have no function.

* Possibility to allow colder water temperature by setting.
Bridge at CN_ANTI_SW must be dis-connected to enable setting.

Outdoor PCB (5, 7, 9 kW)

U36A Chassis



DIP Switch Information

Description	Setting		Default
Low Noise Mode	2 	Always Mode - Maintain Low noise mode for target temperature	2 
	2 	Partial Mode - Escape low noise mode for target temperature	
Peak Control	3 	Max Mode	3 
	3 	Peak Control : To limit maximum current (Power saving)	
Defrost Mode	2  5 	Normal Defrost Mode - The same mode as the existing defrost logic	2  5 
	2  5 	Rapid Defrost Mode - Rapid defrost mode in adverse defrost conditions	

- ※ Only DIP-switch no. 2 and no.3 has a function. Others have no function.
- ※ When setting the on/off partial mode, Mode can be exited to secure capacity after operating for a certain time.

NOTE

* Input current value can be limited by DIP Switch operation.

Capacity	Mode	Peak Control Mode Running Current(A)
1Ø 5,7,9 kW	Cooling	13 / 14 / 15
	Heating	13 / 14 / 15

NOTE**Emergency Operation****• Definition of terms**

- Trouble : a problem which can stop system operation, and can be resumed temporarily under limited operation without certificated professional's assist.
- Error : problem which can stop system operation, and can be resumed ONLY after certificated professional's check.
- Emergency mode : temporary heating operation while system met Trouble.

• Objective of introducing 'Trouble'

- Not like air conditioning product, Air-to-Water heat pump is generally operation in whole winter season without any system stopping.
- If system found some problem, which is not critical to system operating for yielding heating energy, the system can temporarily continue in emergency mode operation with end user's decision.

• Classified Trouble

- Trouble is classified two levels according to the seriousness of the problem : Slight Trouble and Heavy trouble
- Slight Trouble : a problem is found inside the unit. In most case, this trouble is concerned with sensor problems. The outdoor unit is operating under emergency mode operation condition which is configured by DIP switch No. 4 of the unit PCB.
- Heavy trouble : a problem is found inside the outdoor unit. As the outdoor unit has problem, the emergency mode operation is performed by electric heater located in the unit.
- Option Trouble : a problem is found for option operation such as water tank heating. In this trouble, the troubled option is assumed as if it is not installed at the system.

• When the AWHP has any trouble,

- (1) If there is not a function to judge possibility of operation :

Once an error occurs mainly in indoor unit, AWHP stops. On the other hand, remote controller allows the product to activate On/ Off operation. (On : emergency operation)

- Slight / Heavy trouble : Heating Operable only
- Critical trouble : Full stop
- Treatment priority : Critical>Heavy>Slight

- (2) If there is a function to judge possibility of operation :

Depending on the status of slight / heavy / critical trouble, pop-up phrase is guided separately on display.

- Slight trouble : Heating/Cooling Operable
- Heavy trouble : Heating Operable only
- Critical trouble : Service center request

AWHP operates when user pressed OK button on pop-up window.

NOTE**• Duplicated trouble : Option trouble with slight or heavy trouble**

- If option trouble is occurred with slight (or heavy) trouble at the same time, the system puts higher priority to slight (or heavy) trouble and operates as if slight (or heavy) trouble is occurred.
- Therefore, sometimes DHW heating can be impossible in emergency operation mode. When DHW is not warming up while emergency operation, please check if DHW sensor and related wiring are all Ok.


• Emergency operation is not automatically restarted after main electricity power is reset.

- In normal condition, the product operating information is restored and automatically restarted after main electricity power is reset.
- But in emergency operation, automatic re-start is prohibited to protect the product.
- Therefore, user must restart the product after power reset when emergency operation has been running.

SERVICE SETTING

How to enter service setting

- To enter the menu displayed at the bottom, you need to enter the service setting menu as follows.
- In the menu screen, press [,<,>(left/right)] button to select the setting category, and press [OK] button to move to the setting list.
 - In the setting list, select the service setting category, and press [OK] button to move to the service setting list.



Service setting

- You can set the product service functions.
- Some functions may not be displayed/operated in some product types.

Menu	Description
Service contact	Check and input the service center phone number that you can call when there is service issue.
Model information	View product and capacity information
RMC Version Information	Check the remote controller model name and software version.
Open Source License	View the remote controller's open source license.

Service contact

Check and input the service center phone number that you can call when there is service issue.

- In the service setting list, select the service contact point and press [OK] button to move to the detail screen.
- While “edit” button is selected, press [OK] button to move to the edit screen, change it, and press [OK] button to change the service contact point.

Service	Back OK
Service Contact	>
Model Information	>
RMC Version Information	>
Open Source License	>



Service Contact	Back OK
Telephone +1544-7777	
Edit	



Service Contact	Back OK
Telephone	
+ 1 5 4 4 - 7 7 7 7	

Model information

Check product and capacity information to which the remote controller is connected.

- In the service setting list, select model information category, and press [OK] button to move to the detail screen.
- The unit capacity
 - $1 \text{ kWh} = 1 \text{ kBtu} \times 0.29307$
 - kWh is the result calculated based on Btu, There may be a small difference between calculated and actual capacity.
 - Ex) If the unit capacity is 18 kBtu, it is displayed as 5 kWh.

Service	Back OK
Service Contact	>
Model Information	>
RMC Version Information	>
Open Source License	>



Model Information	Back
Indoor Unit AWHP	
Outdoor Unit Single	
Capacity 16kW (54/55kBtu/h)	

RMC version information

View the remote controller software version.

- In the service setting list, select the RMC version information and press [OK] button to move to the detail screen

Service	 Back  OK
Service Contact	>
Model Information	>
RMC Version Information	>
Open Source License	>



RMC Version Information	 Back
SW Version ! 3.03.1a	

Open source license

View the remote controller's open source license.

- In the service setting list, select the open source license category, and press [OK] button to move to the detail screen.

Service	⏮ Back ⏭ OK
Service Contact	>
Model Information	>
RMC Version Information	>
Open Source License	>



Open Source License

Back

LGE Open Source Software Notice

Product Type	HVAC WIRED REMOTE CONTR
Model Number/Range	RS3 Wired Remote Controller

1/401

Those products identified by the Product Type and Model Range above from LG Electronics, Inc. ("LGE") contain the open source software detailed below. Please refer to the


INSTALLER SETTING

How to enter installer setting

CAUTION

The installer setting mode is the mode to set the remote controller's detail function. If the installer setting mode is incorrectly set, it may cause product failure, user's injury, or property damage. It must be set by the installation specialist with the installation license, and if it is installed or changed without installation license, all problems caused will be the responsibility of the installer, and may void the LG warranty.

- In the menu screen, press [←,→(left/right)] button to select the setting category, and press [^ (up)] button for 3 seconds to enter the password input screen for the installer setting.
- Input the password and press [OK] button to move to the installer setting list.



* Installer setting password

Main screen → menu → setting → service → RMC version information → SW Version

Example) SW version : 1.00.1 a

In the above case, the password is 1001.

NOTE

Some categories of the installer setting menu may not be available depending on the product function or the menu name may be different.

Installer setting

- You can set the product user functions.
- Some functions may not be displayed/operated in some product types.

Configuration

Function	Description
Select Temperature Sensor	Selection for setting temperature as air temperature or water temperature or air+water temperature.
Use Heating Tank Heater	Determine the delay time of the electric heater for the water tank.
Mixing Circuit	This function is to use mixing circuit function. Set enable/disable mixing circuit function and valve closing time and hysteresis.
Use External Pump	Set up to control an external water pump.
RMC master/slave	This function is to set master / slave to use two remote controllers in one indoor unit.
LG Therma V Configuration	This function can be set to save the environment settings of the product for use in LG Therma V Configurator through Micro SD card. (LG heating configurator)

General

Function	Description
Forced operation	Main water pump off After 20 consecutive hours, disable / enable the logic that drives the water pump by itself.
Pump Prerun/Overrun	Set to reach the optimum flow rate by circulating the heating water with the water pump before heat exchange. After the operation stop, additional water pump is activated to circulate the heating water.
Water Flow Control	Set water pump to control the water flow.
Energy Monitoring	Set up to use energy monitoring function of unit
Anti-Freezing Option 1	This function is to select whether to use Type1 or Type2 to prevent freezing when the remote control is turned off.
Password Reset	It is the function to reset (0000) the password when you forgot the password set in the remote controller.

Room Heating

Function	Description
Heating temp. setting	At the water control in heating mode, the control reference water temperature position setting.
Air heating set temp.	Adjusting range of 'Setting Air Temperature' in heating mode
Water heating set temp.	Adjusting range of 'Setting Leaving water Temperature' in heating mode.
Hysteresis Heating Water	Heating Water Outlet Temperature Hysteresis range setting
Hysteresis Room Air (Heating)	Heating air temperature Hysteresis range setting
Pump setting in heating	Set water pump on/off interval option during thermo off condition in heating mode
Heater on temperature	Setting outdoor air temperature where electric heater starts operation.
Screed drying	This function controls floor heating to a specific temperature for a certain period of time to cure floor cement.

Room Cooling

Function	Description
Cooling temp. setting	At the water control in cooling mode, the control reference water temperature position setting.
Air cooling set temp.	Adjusting range of 'Setting Air Temperature' in cooling mode.
Water cooling set temp.	Adjusting range of 'Setting Leaving Water Temperature' in cooling mode.
Water supply off temp. during cooling	Determine the leaving water temperature which blocks the flow into underfloor coil in cooling mode.
Hysteresis Cooling Water	Cooling Water Outlet Temperature Hysteresis range setting
Hysteresis Room Air (Cooling)	Cooling air temperature Hysteresis range setting
Pump setting in cooling	Set water pump on/off interval option during thermo off condition in cooling mode.

Auto Mode

Function	Description
Seasonal auto temp	Set the operating temperature in Seasonal Auto mode.

Domestic Hot Water

Function	Description
DHW set temp.	Setting DHW set temperature.
Tank disinfection setting 1	Setting start/maintain time for disinfection.
Tank disinfection setting 2	Setting disinfection temperature.
Tank setting1	Setting minimum and maximum temperature using heat pump cycle for DHW heating.
Tank setting2	Setting temperature hysteresis.
DHW time setting	Determine follow time duration : operation time of domestic hot water tank heating, stop time of domestic hot water tank heating, and delay time of DHW tank heater operating.
Recirculation time	Whether to use the recirculation function and set the water pump on/off interval option

Service

Function	Description
Pump test run	Main water pump test run.
Frost Protection Temp.	the function is to apply an offset to the freezing temperature of the freeze protection logic when using antifreeze mode.

Connectivity

Function	Description
Dry Contact Mode	Dry contact function is the function that can be used only when the dry contact devices is separately purchased and installed.
Central Control Address	Selection for setting temperature as air temperature or leaving water temperature or air+leaving water temperature.
CN_CC	It is the function to set whether to install (use) Dry Contact. (It is not a function for Dry Contact installation, but it is a function to set the usage of the unit's CN_CC port.)
Modbus Address	It is function to set the address of the Modbus device that is externally linked to the product. Modbus address setting function is available from indoor unit.
CN_EXT	Function to set external input and output control according to DI / DO set by customer using dry contact port of indoor unit. Determine the use of the contact port (CN_EXT) mounted on the indoor unit PCB.
3 rd Party Boiler	Configuration to control 3 rd party boiler.
Meter Interface	When installing the meter interface to measure energy / calorie in the product, set unit spec for each port.
Energy state	Select whether to use or not use the SG Mode function of the product, set the operation option value in SG1 step.
Thermostat control type	Setting Thermostat control type




Information

Function	Description
Pump operation time	Function to check the main water pump operation time.
IDU operation time	Function to check the IDU operation time.
Current Flow Rate	Function to check the current flow rate.
Data logging	Display error history of connected unit.

Select Temperature Sensor

The product can be operated according to air temperature or water temperature. The selection for setting temperature as air temperature or water temperature is determined.

- In the installer setting list, Select Temperature Sensor category, and press [OK] button to move to the detail screen.



Control Standard	Sensor Location	Temperature target	Required accessories
Water (Default)	-	Inlet or Outlet water temp.	-
Air	Remote Control	Room air temp. only	Cover plate PDC-HK10 or (PREMTW101 + PZCWRC2)
	Indoor unit		Remote room sensor PQRSTA0 ¹⁾
Air+Water	Remote control	Room air temp. and (Inlet or Outlet) water temp.	Cover plate PDC-HK10 or (PREMTW101 + PZCWRC2)
	Indoor unit		Remote room sensor PQRSTA0 ¹⁾


NOTE

1) Sensor must be enabled by DIP switch first, before setting is available.

Use Heating Tank Heater

This is a function to determine the delay time of the electric heater for water tank.

- In the installer setting list, Select Configuration category, and press [OK] button to move to the detail screen.



Function	Unit	Default	Value
Delay time	minute	30	10/20/30/40/50/60/90/120/1440

Mixing Circuit

Function to set whether or not to use an installed mixing circuit function using mixing kit.

Configuration Back OK OK

Select Temperature Sensor >

Use Heating Tank Heater >

Mixing Circuit >

Use External Pump < Not use >

BMC master/slave < Master >

Mixing Circuit Back OK OK

Mixing Circuit < Heat >

Valve Closing Time >

Hysteresis >

Cut-Off Temperature >

Pump setting in heating >

Value	Default
Not Use / Heat / Cool	Not Use

You can set valve closing time[s] and hysteresis temperature[°C] on screen by yourself.
Setting the cut-off temperature protects the water from flowing over the cut-off temperature in the mixing circuit during heating operation.

Valve Closing Time Back OK OK

Valve Closing Time

1 0 0

Hysteresis Back OK OK

Hysteresis

2

Cut-Off Temperature Back OK OK

Cut-Off Temperature

40

Value	Default	Range
Valve Closing Time	240 s	60 ~ 999 s
Hysteresis	2 °C	1 ~ 3 °C
Cut-Off Temperature	40 °C	20 ~ 65 °C

You can set the operation of the outdoor unit when only the mixing circuit is operating and the direct circuit is not operating.

Type1	Type2(Default)
Outdoor Operation	Outdoor Not Operation

Mixing Circuit

Back

OK

hysteresis

>

Cut-Off Temperature

>

Pump setting in heating

>

Pump setting in cooling

>

Comp. Operation

< Type2 >

Value	Default
Type 1 / Type 2	Type 2



CAUTION

Set Type 1 only at the installation site with a small load or no buffer tank.
When setting Type 1 in a site with a large load or a site with a buffer tank, overheating may occur in the direct circuit.

Installer setting function to set water mixing pump operation / delay time option in heating/cooling mode

Pump setting in heating [Back] [OK]

Type On Off

Time setting 3 3

Pump setting in cooling [Back] [OK]

Type On Off

Continuous Operation 3 3

Value	Default	Range
Type	Time Setting	Time Setting / Continuous Operation
On	3 min	1 ~ 60 min
Off	3 min	1 ~ 60 min

* When Continuous Operation is selected, On, Off is disabled.

Activating this function, It allows 2 circuits (Circuit 1, Circuit 2) temperature to be controlled, separately.


NOTE

When using the Mixing Circuit function, the external pump setting must be changed to 'Circuit 1'.

Use External Pump

This function can be set to control the external water pump.

- In the installer setting list, select Use External Pump category, and press [OK] button to move to the detail screen.
- Heating/Cooling
You can use this feature when you have installed a 3 Way valve to switch the water flow between the underfloor and the water tank. The external pump operates only in the direction of water flow in the underfloor.
- Circuit1
This function controls the external pump when operating the mixing circuit.
The external pump should be controlled according to Th/on and Th/off in Circuit1(Direct circuit).
Therefore, when using the mixing circuit, be sure to set the external pump to 'Circuit1'.



Value			
Not use (Default)	Use	Heat & Cool	Circuit1

RMC master/slave

This function can be select Master/Slave on remote controller to use 2 Remote Control environment

- In the Installer setting list, and select RMC master/slave setting category, and press [<,>(left/right)] button to following setting values.

Installer	Back OK OK
Configuration	>
General	>
Room Heating	>
Room Cooling	>





Configuration	Back OK OK
Use heating tank heater	>
Mixing Circuit	>
Use External Pump	< Not use >
RMC master/slave	< Master >
LG Therma V Configuration	>

Value	
Master (Default)	Slave

LG Therma V Configuration

This function can be set to save the installation settings of the product for use in LG Therma V Configurator through SD Card (LG heating configurator).

- In the Installer setting list, and select LG Therma V Configuration setting category, and press [OK] button to move to the detail screen.



Value	
Read Data (Default)	Save Data

NOTE

When saving the environment settings of the product in the micro SD Card, please be sure to save the file name as "RS3_AWHP_DATA"

Forced operation

- If the product is not used for a long time, the main water pump will be forced to operate for preventing pump failure and PHEX freezing.
- Water pump off After 20 consecutive hours, disable / enable the logic that drives the water pump by itself
- In the installer setting list, select Forced operation category, and press [OK] button to move to the detail screen

Installer	Back OK OK
Configuration	>
General	>
Room Heating	>
Room Cooling	>



General	Back OK OK
Forced operation	>
Pump Capacity	>
Pump Prerun/Overrun	>
Password Reset	>




Forced operation			Back OK OK
	Oper. Cycle	Oper. Time	
Use	20	10	

Type	Use (Default)	Not use
Oper. Cycle	20 ~ 180 hours (Default : 20 hours)	-
Oper. Time	1 ~ 10 min (Default : 10 min)	-

Pump Prerun/Overrun

Pump Prerun operates to ensure sufficient flow before the compressor is operated. This is a function that allows heat exchange to work smoothly.

Pump Overrun is a function to prevent water pump failure and to help mechanical life.



Value	Default	Setting Range
Prerun	1 min	1~10 min
Overrun	1 min	1~10 min

Water Flow Control

This function controls the water flow by controlling the water pump. Select the way to control the water pump and set the target value

- In the installer setting list, select Configuration category, and press [OK] button to move to the detail screen.

Optimal Flow Rate

The water pump is automatically controlled at the optimum flow rate required according to the desired temperature of the Main screen.

Pump Capacity

It operates with the capacity set for the water pump.

Fixed Flow Rate

The water pump is automatically controlled to maintain the set flow rate.

Fixed ΔT

Set the target ΔT (* ΔT = temperature difference between inlet and outlet water temperature)

The water pump is automatically controlled to maintain the set ΔT .

General	Back OK
Forced operation	>
Pump Prerun/Ovrrun	>
Water Flow Control	>
Password Reset	>



Water Flow Control	Back OK OK
Control Method	< Optimal Flow Rate >
Pump Capacity	>
Fixed Flow Rate	>
Fixed ΔT	>

Pump Capacity	Back OK OK
% > 100 <	

Fixed Flow Rate	Back OK OK
Heat Cool DHW > 46 46 46 <	


Fixed ΔT	Back OK OK
Heat Cool DHW > 5 5 5 <	

Flow Control Method			
Optimal Flow Rate (Default)	Pump Capacity	Fixed Flow Rate	Fixed ΔT

Energy Monitoring

This function can be set to use energy monitoring fuction of unit.

- Change setting values using [<,>(left/right)] button.



Value		Range	Default
Energy Monitoring		Use/Not Use	Use
Electric Heater Setting	Type	LG 1Ø / LG 3Ø / EXTERNAL	LG 1Ø
	Heater Capacity	1 kW ~ 10 kW	3 kW

Anti-Freezing Option 1

This function is to select whether to use Type1 or Type2 to prevent freezing when the remote control is turned off.

- Change setting values using [<,>(left/right)] button.

General	Back OK
Pump Priority/Overrun	>
Water Flow Control	>
Energy Monitoring	>
Anti-Freezing Option 1	< Type1 >
Password Reset	>

Value	
Type1(Default)	Type2



CAUTION




If the function is set to Type 2, there is a risk of freezing.

Function	Detection	Case	Operation
Type 1	Type 2 + Inlet Temp.	Air Temp. < Certain Level Inlet Temp. < Certain Level	Pump always ON
		Air Temp. < Certain Level Inlet Temp. > Certain Level	Pump intermittently On
		Air Temp. > Certain Level Inlet Temp. > Certain Level	Pump always OFF
Type 2	Air Temp.	Air Temp. < Certain Level	Pump intermittently On
		Air Temp. > Certain Level	Pump always OFF

Password Reset

It is the function to reset (0000) when you forgot the password set in the remote controller.

- In the installer setting list, select the password reset setting category, and press [OK] button to move to the detail screen.
- When you press “reset” button, a popup screen appears, and when you press “check” button, password reset starts, and the user password is changed to 0000.



Heating temp. setting

- At the water control in heating mode, the control reference water temperature position setting
- If the air / leaving water temperature selection setting is set to leaving water temperature
- Change setting values using [<,>(left/right)] button
- The function is not available for some products.

Installer	Back OK
Configuration	>
General	>
Room Heating	>
Room Cooling	>
Auto Mode	>






Room Heating	Back OK
Heating temp. setting	< Outlet >
Air heating set temp.	>
Water heating set temp.	>
TH on/off Variable, heating air	< Type0 >
TH / Cooling Mode	>

Value	
Outlet (Default)	Inlet

Air heating set temp.

Determine heating setting temperature range when air temperature is selected as setting temperature

- In the installer setting list, select Air heating set temp. category, and press [OK] button to move to the detail screen.



Value	Default	Range
Max.	30	30~24
Min.	16	22~16

* Upper / lower limit / default value is in °C

NOTE




It is possible to control the unit based on room air temperature by using either remote air temperature sensor or wired remote controller (RS3).

- Remote room air sensor is an accessory (PQRSTA0) and sold separately.
- DIP switch setting should be set properly in order to control the unit based on room air temperature.

Water heating set temp.

Determine heating setting temperature range when water temperature is selected as setting temperature.

- In the installer setting list, select Water heating set temp. category, and press [OK] button to move to the detail screen.



Value		Default	Range
Max.	Outlet	65	65 ~ 35
	Inlet	55	55 ~ 35
Min.	E/heater use	15	34 ~ 15
	E/heater Not use	20	34 ~ 20

* Value is in °C


NOTE

- When the E/heater is not used, the minimum temperature of the water temperature can be set from 34 °C to 20 °C and default value is 20 °C.

Hysteresis Heating Water

It is a function to adjust the heating water temperature Thermal On / Off temperature according to the field environment in order to offer optimized heating operation.

- In the Installer setting list, and select Hysteresis Heating Water category, and press [OK] button to move to the detail screen.



Type	Default	Range
Temp On	-2	0 ~ -9
Temp Off	2	4 ~ 0

Hysteresis Room Air(Heating)

It is a function to adjust the heating air temperature Thermal On / Off temperature according to the field environment in order to offer optimized heating operation.

- In the Installer setting list, and select Hysteresis Room Air(Heating) category, and press [OK] button to move to the detail screen.

Room Heating

Back OK

heating temp. setting

Outlet

Air heating set temp.

>

Water heating set temp.

>

Hysteresis Heating Water

>

Hysteresis Room Air(Heating)

>



Hysteresis Room Air(Heating)

Back OK

Temp On Temp Off

>

-0.5

<

1.5

>

Type	Default	Range
Temp On	-0.5	0 ~ -3
Temp Off	1.5	4 ~ 0

Pump setting in heating

- It is a function to help the water pump's mechanical life by putting the water pump's rest time.
- Installer setting function to set water pump on/off interval option during thermo off condition in heating mode.
- In the installer setting list, select Pump setting in heating category, and press [OK] button to move to the detail screen.

Installer

Back

OK

Configuration >

General >

Room Heating >

Room Cooling >

Auto Mode >



OK

Room Heating

Back

OK

TH on/off Variable, heating air < Type0 >

TH on/off Variable, heating water < Type0 >

Pump setting in heating >

Heater on temperature >

Screed drying >



OK

Pump setting in heating

Back

OK

Type

On

Off

Time setting

2

1

Type	On	Off
Time setting (Default)	1 ~ 60 min (Default : 2 min)	1 ~ 60 min (Default : 1 min)
Operation continue	-	-

Heater on temperature

Depending on local climatic conditions, it is necessary to change the temperature condition in which electric heater turns on / off.

- In the installer setting list, Heater on temperature category, and press [OK] button to move to the detail screen.

Installer		Back	OK
Configuration	>		
General	>		
Room Heating	>		
Room Cooling	>		
Auto Mode	>		



Room Heating		Back	OK
TH on/off variable, heating air < Type0 >			
TH on/off Variable, heating water	< Type0 >		
Pump setting in heating	>		
Heater on temperature	>		
Screed drying	>		



Heater on temperature		Back	OK
Heater on temperature			
^ -25 v			


Default	Range
-5	18~-25

* Upper / lower limit / default value is in °C

Screed drying

This function is a unique feature of AWHP that, when AWHP is installed in a new concrete structure, controls the specific temperature floor heating out temperature for a certain period of time to cure the floor cement.

- In the installer setting list, select Screed drying category, and press [OK] button to move to the detail screen.



How to display

Main Screen - Displays 'Screed drying' on the desired temperature display. The step in progress at the bottom of the display is displayed.

Setting value

- Start-up step: 1 ~ 11
- Maximum temperature : 35 °C ~ 55 °C (Default : 55 °C)
- Step 8 Holding time : 1 days ~ 30 days (Default : 7 days)

Function operation


- It is performed by the following procedure from the selected starting step.
- After all steps are completed, turn off the cement curing operation.

Step	1	2	3	4	5	6	7	8	9	10	11
Leaving Water target temperature[°C]	25	Max.T	Off	25	35	45	Max.T	Max.T	45	35	25
Duration [hours]	72	96	72	24	24	24	24	Holding time	72	72	72

※ If the upper limit setting value of the heating LW temperature is 55 °C or lower, it is set to 55 °C forcibly.

NOTE

- During Screed drying operation, button input except for installer function and temperature display is restricted.
- When the power is applied again after a power outage during product operation, the product operation state before power failure is remembered and the product is automatically operated.
- Screed drying operation stops when an error occurs / When error is cleared, restart cement Screed drying. (However, if the wired remote control is reset to the error occurrence state, it is compensated in the unit of one day)
- Upon releasing after an error, Screed drying operation may take up to 1 minute of waiting time after boot up. (The Screed drying operation status is judged as 1 minute cycle.)
- During Screed drying operation, installer function Screed drying operation is selectable.
- During Screed drying operation, starting operation, low noise mode off, low noise time setting off, hot water off, solar heat off.
- During Screed drying operation, simple, sleep, on, off, weekly, holiday, heater does not execute reservation operation.



Cooling temp. setting

- At the water control in cooling mode, the control reference water temperature position setting
- If the air / leaving water temperature selection setting is set to leaving water temperature
- Change setting values using [<,>(left/right)] button.
- The function is not available for some products.

Installer	Back	OK
General		
Room Heating		>
Room Cooling		>
Auto Mode		>
Domestic Hot Water		>



Room Cooling	Back	OK
Cooling temp. setting	<	Outlet >
Air cooling set temp.		>
Water cooling set temp.		>
Water supply off temp. during cooling		>

Value	
Outlet (Default)	Inlet

Air cooling set temp.

Determine cooling setting temperature range when air temperature is selected as setting temperature.

- In the installer setting list, select Air cooling set temp category, and press [OK] button to move to the detail screen.

Installer [Back] [OK]

- Configuration >
- General >
- Room Heating >
- Room Cooling >**



Room Cooling [Back] [OK]

- Cooling temp. setting < Outlet >
- Air cooling set temp. >**
- Water cooling set temp. >
- Water supply off temp. during cooling >



Air cooling set temp. [Back] [OK]

Max. 30

16

Value	Default	Range
Max.	30	30~24
Min.	18	22~16

* Upper / lower limit / default value is in °C

NOTE


It is possible to control the unit based on room air temperature by using either remote air temperature sensor or wired remote controller (RS3).

- Remote room air sensor is an accessory (PQRSTA0) and sold separately.
- DIP switch setting should be set properly in order to control the unit based on room air temperature.

Water cooling set temp.

Determine cooling setting temperature range when water temperature is selected as setting temperature.

- In the installer setting list, select water cooling set temp category, and press [OK] button to move to the detail screen.



Value		Default	Range	
			Outlet	Inlet
Min.	Max.	24	22~27	22~27
	FCU use	5	5~20	10~20
	FCU Not use	16	16~20	20

※ Value is in °C

※ When set to inlet temperature, the default value of Min. temp is set to the minimum value that can be set.

NOTE

Water condensation on the floor

- While cooling operation, it is very important to keep leaving water temperature higher than 16 °C. Otherwise, dew condensation can be occurred on the floor.
- If floor is in humid environment, do not set leaving water temperature below 18 °C.

NOTE

Water condensation on the radiator

- While cooling operation, cold water may not flow to the radiator. If cold water enters to the radiator, dew generation on the surface of the radiator can be occurred.

Water supply off temp. during cooling

Determine the leaving water temperature which blocks the flow into underfloor coil in cooling mode. This function is used for preventing condensation on the floor in cooling mode

- In the installer setting list, select Water supply off temp. during cooling category, and press [OK] button to move to the detail screen.

Installer [Back] [OK]

- Configuration >
- General >
- Room Heating >
- Room Cooling >**



Room Cooling [Back] [OK]

- Air cooling set temp. >
- Water cooling set temp. >
- Water supply off temp. during cooling >**
- TH on/off Variable, cooling air < Type0 >



Water supply off temp. during cooling [Back] [OK]

FCU Stop temp.

Use 16

Value	Default	Setting Range
FCU	Use	Use / Not use
Stop temp.	16	25 ~ 16

* Value is in °C

NOTE

- If the FCU is not used, the stop temp. cannot be set.
- Depending on FCU setting, the water cooling set temperature range is adjusted.

- Stop temp. : cut-off temperature. Stop temp. is valid when FCU is installed.
- FCU : determines if FCU is installed or not.
- Example : If FCU is set as 'Use', Stop temp. setting is disabled. However, if actually FCU is NOT installed in the water loop, the unit operates continuously in cooling mode until water temperature meets desired temperature. In this case, a condensed water may form on the floor caused by cold water in the underfloor coil.
- Example : If Stop temp. is set as '20' and FCU is set as 'Not use' and actually FCU is installed in the water loop, then the Stop temp. is used and the unit stops operation in cooling mode when the leaving water temperature is below 20 °C. As a result, the unit may not offer enough cooling since the cold water with desired temperature doesn't flow into the FCU.



CAUTION

FCU Installation

- If FCU is used, related 2way valve should be installed and connected to the Main PCB assembly 1.
- If FCU is set as 'Use' whereas FCU or 2way valve is NOT installed, the unit can do abnormal operation.

Hysteresis Cooling Water

It is a function to adjust the cooling water temperature Thermal On / Off temperature according to the field environment in order to offer optimized cooling operation.

- In the Installer setting list, and select Hysteresis Cooling Water setting category, and press [OK] button to move to the detail screen.

Room Cooling Back OK

water cooling set temp. >

Water supply off temp. during cooling >

Hysteresis Cooling Water >

Hysteresis Room Air(Cooling) >

Pump setting in cooling >



Hysteresis Cooling Water Back OK

Temp On Temp Off

>

0.5

<

-0.5

Type	Default	Range
Temp On	0.5	3 ~ 0
Temp Off	-0.5	0 ~ -3

Hysteresis Room Air(Cooling)

It is a function to adjust the cooling air temperature Thermal On / Off temperature according to the field environment in order to offer optimized cooling operation.

- In the Installer setting list, and select Hysteresis Room Air(Cooling) setting category, and press [OK] button to move to the detail screen.

Room Cooling

BackOK

water cooling set temp. ✓

Water supply off temp. during cooling >

Hysteresis Cooling Water >

Hysteresis Room Air(Cooling) >

Pump setting in cooling >



Hysteresis Room Air(Cooling)

BackOK

Temp On Temp Off

0.5-0.5

Type	Default	Range
Temp On	0.5	3 ~ 0
Temp Off	-0.5	0 ~ -3

Pump setting in cooling

- It is a function to help the water pump's mechanical life by putting the water pump's rest time.
- Installer setting function to set water pump on/off interval option during thermo off condition in cooling mode.
- In the installer setting list, select Pump setting in cooling category, and press [OK] button to move to the detail screen.

Installer	Back OK OK
General	>
Room Heating	>
Room Cooling	>
Auto Mode	>
Domestic Hot Water	>



OK

Room Cooling	Back OK OK
Water cooling set temp.	>
Water supply off temp. during cooling	>
TH on/off Variable, cooling air	< Type0 >
TH on/off Variable, cooling water	< Type0 >
Pump setting in cooling	>



OK

Pump setting in cooling	Back OK OK	
Type	On	Off
Time setting	2	1

Type	On	Off
Time setting (Default)	1 ~ 60 min (Default : 2 min)	1 ~ 60 min (Default : 1 min)
Operation continue	-	-

Seasonal auto temp.

It is the function to set the operation reference value in Seasonal Auto mode.

- In the installer setting list, select Seasonal auto temp category, and press [OK] button to move to the detail screen.


Auto Mode	
Seasonal auto temp	>

OK

Seasonal auto temp	
Mode	< Heat & Cool >
Outdoor Temp.	>
Target Temp.	>


Seasonal auto temp	
Mode	< Heat & Cool >
Outdoor Temp.	>
Target Temp.	>

OK



Seasonal auto temp	
Mode	< Heat & Cool >
Outdoor Temp.	>
Target Temp.	>

OK



Function	Description	Range	Default (Circuit1)	Default (Circuit2)	Boundary
Outdoor1,Heat (Out1)	Heating lower ambient temp	-25 ~ 35 °C	-10 °C		Out1 ≤ Out2-1
Outdoor2,Heat (Out2)	Heating higher ambient temp		18 °C		Out2 ≥ Out1 +1 Out2 ≤ Out3 -5
Outdoor3,Cool (Out3)	Cooling lower ambient temp	10 ~ 46 °C	30 °C		Out3 ≥ Out2 +5 Out3 ≤ Out4 -1
Outdoor4,Cool (Out4)	Cooling higher ambient temp		40 °C		Out4 ≥ Out3 +1
Water1,Heat (LW1)	Heating higher water temp	Use heater : LW STD : 15~65 °C EW STD : 15~55 °C Not use heater : LW STD : 20~65 °C EW STD : 20~55 °C	50 °C	35 °C	LW1 ≥ LW2
Water 2,Heat (LW2)	Heating lower water temp		40 °C	28 °C	LW1 ≥ LW2
Water3,Cool (LW3)	Cooling higher water temp	Use FCU & 5 °C IDU : LW STD : 5~27 °C EW STD : 10~27 °C Use FCU & 6 °C IDU : LW STD : 6~27 °C EW STD : 11~27 °C Not use FCU : LW STD : 16~27 °C EW STD : 20~27 °C	12 °C	18 °C	LW3 ≥ LW4
Water4,Cool (LW4)	Cooling lower water temp		10 °C	16 °C	LW3 ≥ LW4
Air 1, Heat (RA1)	Heating higher air temp	16 ~ 30 °C	21 °C		RA1 ≥ RA2
Air 2, Heat (RA2)	Heating lower air temp		19 °C		RA1 ≥ RA2
Air 3, Cool (RA3)	Cooling higher air temp	18 ~ 30 °C	21 °C		RA3 ≥ RA4
Air 4, Cool (RA4)	Cooling lower air temp		19 °C		RA3 ≥ RA4

- Setting range: Celsius

- Seasonal Auto Driving mode: Heating, Heating & Cooling




* If heating mode is selected, heating & cooling or cooling can not be selected.

- Depending on the air / outflow control selection value, the water / air related setting value is displayed on the screen (seasonal auto temp) .

DHW set temp.

Determine heating setting temperature range when DHW temperature is selected as setting temperature

- In the installer setting list, select DHW set temp. category, and press [OK] button to move to the detail screen.




Value	Default	Range
Max.	55	80~50
Min.	40	40~30

* Upper / lower limit / default value is in °C

Tank disinfection setting 1, 2

- Disinfection operation is special DHW tank operation mode to kill and to prevent growth of legionella inside the tank.
 - Disinfection active : Selecting enable or disable of disinfection operation.
 - Start date : Determining the date when the disinfection mode is running.
 - Start time : Determining the time when the disinfection mode is running.
 - Max temp. : Target temperature of disinfection mode.
 - Duration time : Duration of disinfection mode.



- In the installer setting list, select 'Domestic Hot Water' category, and press [OK] button to move to the tank disinfection setting screen.

Domestic Hot Water [Back] [OK]

DHW set temp. >

Tank disinfection setting 1 >

Tank disinfection setting 2 >

Tank setting1 >



Tank disinfection setting 1 [Back] [OK]

Disinfection active Start date Start time

Not use Fri. 23

Value	Default	Range
Disinfection active	Not use	Use / Not use
Start date	Fri.	Mon. ~ Sun.
Start time	23	23 ~ 00

Domestic Hot Water [Back] [OK]

DHW set temp. >

Tank disinfection setting 1 >

Tank disinfection setting 2 >

Tank setting1 >



Tank disinfection setting 2 [Back] [OK]

Max temp. Duration time Forced end time

70 10 1

Value	Default	Range
Max temp.	70	60 ~ 80
Duration time	10	60 ~ 5 (Change unit: 5)
Forced and time	1	1 ~ 12


NOTE

DHW heating should be enable

- If Disinfection active is set as 'Not use', that is 'disable disinfection mode', Start date and Start time is not used.

Tank setting 1




- In the installer setting list, select tank setting 1 category, and press [OK] button to move to the detail screen.



Value	Default	Range
Min temp	5 °C	30 ~ 1 °C
Comp. Limit Temp	55 °C	58 ~ 40 °C

Tank setting 2

- In the installer setting list, select tank setting 2 category, and press [OK] button to move to the detail screen.



Value	Default	Range
Hysteresis	3 °C	4 ~ 2 °C


NOTE

The Heating priority in IWT products is always 'DHW'.

• Tank setting 1, 2

Descriptions for each parameters are as following.

- Min temp. : temperature gap from Max outdoor temp.
- Comp. Limit Temp. : maximum temperature generated by AWHP compressor cycle.
- Example : If Min temp. is set as '5' and Comp. Limit Temp. is set as '48', then Session A (see the graph) will be started when the water tank temperature is below 43 °C.... If temperature is above 48 °C..., then Session B will be started.
- Hysteresis : temperature gap from target DHW temperature. This value is required to prevent frequent On and Off of electric heater.
- Example : If user's target temperature is set as '70' and Hysteresis is set as '3', then the electric heater will be turned off when the water temperature is above 73 °C. The electric heater will be turned on when the water temperature is below 70 °C.
- Example : If Heating priority is set as 'DHW', that means heating priority is on DHW heating, DHW is heated by AWHP compressor cycle and electric heater. In this case the under floor can not be heated while DHW heating. On the other hand, if the Heating priority is set as 'Floor heating', that means heating priority is on under floor heating, DHW tank is ONLY heated by electric heater. In this case the under floor heating is not stopped while DHW is heated.




NOTE

DHW heating does not operate when it is disabled.


DHW time setting

Determine following time duration : operation time of DHW tank heating, stop time of DHW tank heating, and delay time of DHW tank heater operating.

- Active time : This time duration defines how long time DHW tank heating can be continued.
- Stop time : This time duration defines how long time DHW tank heating can be stopped. It is also regarded as time gap between DHW tank heating cycle.
- Electric heater delay time : This time duration defines how long time electric heater will not be turned on in DHW heating operation. The electric heater delay time setting can be set in the **'Use Heating Tank Heater'** category.
- Example of timing chart :



①	Heat pump ON condition
②	Electric heater starts after delay time, if heat pump has not reached target temperature yet
③	Heat pump OFF even if hot water target is not reached
④	Hot water heating interrupted (Heat pump may commence with Heating or Cooling during Stop time)
⑤	Hot water heating re-starts
⑥	DHW heating is disabled (by reaching target temperature or by schedule or manually)



Value	Default	Range
Active time	30 min	5~95 min
Stop time	30 min	0~600 min

Recirculation time

- It is function to set recirculation water pump on/off interval option
- In the installer setting list, select Recirculation time category, and press [OK] button to move to the detail screen.

Domestic Hot Water		Back	OK
Tank setting1	>		
Tank setting2	>		
Heater priority	>		
DHW time setting	>		
Recirculation time	>		






Recirculation time		Back	OK
^ Not use v On 50 Off 20			

Value	Default	Range
DHW recirculation	Not use	Use / Not use
ON Time	10 min	5 ~ 60 min
OFF Time	20 min	5 ~ 60 min

Pump test run

The pump test run is the function to test run by operating the main water pump for one hour. This function can be used for air vents / flow sensors and others.



- In the installer setting list, Pump Test run category, and press [OK] button to move to the detail screen.
- Both a space heating line and a DHW line are open during the pump test run operation.




Frost Protection Temp.

Frost protection temperature setting is available in installer mode. It prevents frostbite from happening in the range of -25 to -5 degree celsius.

- Change setting values using [**<**, **>**(left/right)] button.



Default	Value
-5	-5 / -10 / -15 / -20 / -25





NOTE

To use this function, the antifreeze short pin (CN_ANTI_SW) must be open and Switch No.8 in option SW1 must be on.

Dry Contact Mode

Dry contact function is the function that can be used only when the dry contact devices is separately purchased and installed.

- Change setting values using [<,>(left/right)] button.
 - Setting up operation status when dry contact on
 - Auto : Automatically, Operation ON with release hard lock
 - Manual : Keep Operation OFF with release hard lock
- ※ Dry contact Off : Operation Off + Hard Lock



Value
Auto (Default)
manual

NOTE

For dry contact mode related detail functions, refer to the individual dry contact manual.

What is dry contact?

It means the contact point signal input when the hotel card key, human body detection sensor, etc. are interfacing with the unit.

Added system functionality by using external inputs (dry contacts and wet contacts).

Central Control Address

When connecting the central control, set the central control address of the unit.

- In the installer setting list, select Central Control Address category, and press [OK] button to move to the detail screen.

Installer	
Domestic Hot Water	>
Solar Thermal System	>
Service	>
Connectivity	>
Information	>



Connectivity	
Dry Contact Mode	< Auto >
Central Control Address	>
CN_CC	< D/C Automatic >
Smart Grid(SG)	>



Central Control Address	
Address Code(Hex)	
0	0

NOTE

Enter address code as hexadecimal value



Front: Central Control Gr. No.

Back side: Central control indoor the number

CN_CC

It is the function to set the usage of the unit's CN_CC port.

- Change setting values using [<,>(left/right)] button



Value	Description
D/C Automatic (Default)	When power is applied to the product, the unit when the contact point is on in Dry Contact installed state recognizes Dry Contact installation
D/C Not Installed	Do not use (install) Dry Contact
D/C Installed	Use (install) Dry Contact

NOTE

CN_CC is the device connected to the unit to recognize and control the external contact point.

Modbus Address

It is function to set the address of the Modbus device that is externally linked to the product. Modbus address setting function is available from indoor unit.

- In the installer setting list, select Modbus Address , and press [OK] button to move to the detail screen.

Installer		Back	OK
Domestic Hot Water			
Solar Thermal System			
Service			
Connectivity			
Information			



Connectivity		Back	OK
CN_CC			
Smart Grid(SG)			
Modbus Address			
CN_EXT			
3rd Party Boiler			



Modbus Address		Back	OK
Address Code(Hex)			
0 1			

NOTE

To use this function, switch No.1 of option switch 1 must be turned ON.

Modbus gateway memory map

NOTE

In case of Split IWT, RTU Gateway should be installed for using modbus and refer to the RTU Gateway installation manual for memory maps.

Baud Rate : 9 600 bps Stop Bit : 1 stop bit Parity : None Parity

Coil Register (0x01)

Register	Description	Value explanation
00001	Enable/Disable (Heating/Cooling)	0 : Operation OFF / 1 : Operation ON
00002	Enable/Disable (DHW)	0 : Operation OFF / 1 : Operation ON
00003	Silent Mode Set	0 : Silent mode OFF / 1 : Silent mode ON
00004	Trigger Disinfection operation	0 : Keep status / 1 : Operation start
00005	Emergency Stop	0 : Normal operation / 1 : Emergency stop
00006	Trigger Emergency Operation	0 : Keep status / 1 : Operation Start

Discrete Register (0x02)

Register	Description	Value explanation
10001	Water flow status	0 : Flow rate ok / 1 : Flow rate too low
10002	Water Pump status	0 : Water Pump OFF / 1 : Water Pump ON
10003	Ext. Water Pump status	0 : Water Pump OFF / 1 : Water Pump ON
10004	Compressor status	0 : Compressor OFF / 1 : Compressor ON
10005	Defrosting status	0 : Defrost OFF / 1 : Defrost ON
10006	DHW heating status (DHW Thermal On/Off)	0 : DHW inactive / 1 : DHW active
10007	DHW Tank disinfection status	0 : Disinfection inactive / 1 : Disinfection active
10008	Silent mode status	0 : Silent mode inactive / 1 : Silent mode active
10009	Cooling status	0 : No cooling / 1 : Cooling operation
10010	Solar pump status	0 : Solar pump OFF / 1 : Solar pump ON
10011	Backup heater (Step 1) status	0 : OFF / 1 : ON
10012	Backup heater (Step 2) status	0 : OFF / 1 : ON
10013	DHW boost heater status	0 : OFF / 1 : ON
10014	Error status	0 : no error / 1 : error state
10015	Emergency Operation Available (Space heating/cooling)	0 : Unavailable / 1 : Available
10016	Emergency Operation Available (DHW)	0 : Unavailable / 1 : Available
10017	Mix pump status	0 : Mix pump OFF / 1 : Mix pump ON

Holding Register (0x03)

Register	Description	Value explanation
40001	Operation Mode	0 : Cooling / 4 : Heating / 3 : Auto
40002	Control method (Circuit 1/2)	0 : Water outlet temp. control 1 : Water inlet temp. control 2 : Room air control
40003	Target temp (Heating/Cooling) Circuit 1	[0.1 °C ×10]
40004	Room Air Temp. Circuit 1	[0.1 °C ×10]
40005	Shift value(Target) in auto mode Circuit 1	1K
40006	Target temp (Heating/Cooling) Circuit 2	[0.1 °C ×10]
40007	Room Air Temp. Circuit 2	[0.1 °C ×10]
40008	Shift value(Target) in auto mode Circuit 2	1K
40009	DHW Target temp.	[0.1 °C ×10]
40010	Energy state input	0 : Not Use 1 : Forced off (equal to TB_SG1=close / TB_SG2=open) 2 : Normal operation (equal to TB_SG1=open / TB_SG2=open) 3 : On-recommendation (equal to TB_SG1=open / TB_SG2=close) 4 : On-command (equal to TB_SG1=close / TB_SG2=close) 5 : On-command step 2 (++) Energy Consumption compared to Normal) 6 : On-recommendation Step 1 (+ Energy Consumption compared to Normal) 7 : Energy Saving mode (- Energy Consumption compared to Normal) 8 : Super Energy saving mode (– Energy Consumption compared to Normal)

Input Register (0x04)

Register	Description	Value explanation
30001	Error Code	Error Code
30002	ODU operation Cycle	0 : Standby(OFF) / 1 : Cooling / 2 : Heating
30003	Water inlet temp.	[0.1 °C ×10]
30004	Water outlet temp.	[0.1 °C ×10]
30005	Backup heater outlet temp.	[0.1 °C ×10]
30006	DHW tank water temp.	[0.1 °C ×10]
30007	Solar collector temp.	[0.1 °C ×10]
30008	Room air temp. (Circuit 1)	[0.1 °C ×10]
30009	Current Flow rate	[0.1 LPM ×10]
30010	Flow temp. (Circuit 2)	[0.1 °C ×10]
30011	Room air temp. (Circuit 2)	[0.1 °C ×10]
30012	Energy State input	0 : Energy state 0; 1: Energy state 1....
30013	Outdoor Air temp.	[0.1 °C ×10]
39998	Product Group	0x8X (0x80, 0x83, 0x88, 0x89)
39999	Product Info.	Split : 0 / Monobloc : 3 / High Temp. : 4 / Medium Temp. : 5 / System Boiler : 6

CN_EXT

It is a function to control external input and output according to DI type set by customer using CN-EXT Port.

- In the installer setting list, select CN-EXT Port category, and press [OK] button to move to the detail screen.

Installer	Back OK OK
Domestic Hot Water	>
Solar Thermal System	>
Service	>
Connectivity	>
Information	>



Connectivity	Back OK OK
CN_CC	>
Smart Grid(SG)	>
Modbus Address	>
CN_EXT	>
3rd Party Boiler	>



CN_EXT	Back OK OK				
<table border="1"> <tr> <td>Not use</td> <td>Simple Operation</td> </tr> <tr> <td>Simple Dry Contact</td> <td>Single emergency stop</td> </tr> </table>		Not use	Simple Operation	Simple Dry Contact	Single emergency stop
Not use	Simple Operation				
Simple Dry Contact	Single emergency stop				

Value			
Not use (Default)	Simple Operation	Simple Dry Contact	Single emergency stop

3rd Party Boiler

Installer [Back] [OK] OK

Domestic hot water >

Solar Thermal System >

Service >

Connectivity >

Information >

OK



Connectivity [Back] [OK] OK

CN_CC < B/C Automatic >

Smart Grid(SG) >

Modbus Address >

CN_EXT >

3rd Party Boiler >

This function is to configure the 3rd party boiler to be controlled.

3rd Party Boiler [Back] [OK] OK

Mode Temp. Hysteresis

Not use Manual -7 4

3rd Party Boiler [Back] [OK] OK

Mode Temp. Hysteresis

Use Manual -7 4

If the status of this function is “Use”, you can choose control mode of boiler, Auto or Manual.

3rd Party Boiler [Back] [OK] OK

Mode Temp. Hysteresis

Use Auto -7 4

3rd Party Boiler [Back] [OK] OK

Mode Temp. Hysteresis

Use Manual -7 4

If the mode of this function is set to “Auto”, you can set temperature of the boiler and hysteresis, respectively.

3rd Party Boiler [Back] [OK] OK

Mode Temp. Hysteresis

Use Auto -7 4

Value	Default	Range
Temp.	-7	-25 ~ 25
Hysteresis	7	2 ~ 10

External boiler ON condition :

- If outdoor temperature $\leq$ external boiler operation temperature value (installer setting), turn off the indoor unit and operate the external boiler.

External boiler OFF condition :

- If External air temperature $\geq$ external boiler operation temperature value (installer setting) + Hysteresis (installer setting), turn off external boiler operation and operate indoor unit

Meter Interface

It is the function that can check the status of energy and power on screen. It collects and calculates power or calorie data to create data for energy monitoring and energy warning alarm pop-ups. This function can be activated in installer mode.

Installer Back OK

Domestic Hot Water >

Solar Thermal System >

Service >

Connectivity >

Information >

Connectivity Back OK

Smart Unit(SU) >

CN_EXT >

3rd Party Boiler >

Meter Interface >

Zone >

Meter Interface Back OK

Modbus Address >

Unit >

OK

Modbus Address Back OK

Modbus Address

Not use

Modbus Address Back OK

Modbus Address

B0

Modbus Address Back OK

Modbus Address

B1

There are 2 options, modbus address and unit, in this function. Activating the modbus address option, you choose one address(B0 or B1) or don't use. Then, you set the port and specification in range of 0000.0~9999.9[pulse/kW] as shown in the figure below.

Unit Back OK

Pulse/kWh

Port1 0 0 0 0 . 0

Unit Back OK

Pulse/kWh

Port1 1 1 1 1 . 1

Energy state

This function is to control the product according to the energy state. When the charged state of ESS is transmitted, it changes the target temperature of heating, cooling and DHW by setting value according to energy state.

Select either Signal Mode or Modbus Mode according to the connection type between the product and the ESS.

Select ThinQ Mode for wireless connection between the product and the ESS via ThinQ. This function is available only in Germany.

Connectivity	Back	OK
3rd Party Boiler	>	
Meter Interface	>	
Energy state	>	
Thermostat control type	>	

OK

Energy state	Back	OK
ESS use type	< Not use >	
Energy state definition	>	
Digital input assignment	>	

Value	Default
Not Use	Not use
Use Modbus	
Use Digital Input	
ThinQ	

Energy state definition	Back	OK
Energy state 5	>	
Energy state 6	>	
Energy state 7	>	
Energy state 8	>	

OK

Energy state 5	Back	OK
Heat Temp. Use 5	Cool Temp. -5	DHW Temp. 30

When Signal Mode of EES use type is selected, press the Digital Input Assignment button to set the energy state according to the input signal.

Digital input assignment

 Back
 OK

0:1
1:1

^

3

 v



4

Value	Input Signal		Output state	
	ES1	ES2	Default	Range
X	0	0	ES2	fixed
X	1	0	ES1	fixed
0:1	0	1	ES3	ES3-ES8
1:1	1	1	ES4	

Thermostat control type

It is a function to enable installer to control Water Pump Options using water flow sensor.

- In the Installer setting list, and select Connectivity category, and press [OK] button to move to the detail screen.






Type	
Heat & Cool (Default)	Heat & Cool / DHW

Pump operation time

It is a function to show the main water pump's operation time for check mechanical life.




- In the Installer setting list, and select Information category, and press [OK] button to move to the detail screen.



IDU operation time

It is a function to show the Indoor Unit's operation time for check mechanical life.

- In the Installer setting list, and select Information category, and press [OK] button to move to the detail screen.



Current flow rate

It is the function to check the current flow rate.

- In the installer setting list, select Current Flow Rate category, and press [OK] button to move to the detail screen. The current flow rate can be checked. (Range : 7 ~ 80 L/min)
- The function is not available for some products.

Installer	Back	OK
Domestic hot water		✓
Solar Thermal System		>
Service		>
Connectivity		>
Information		>



Information	Back	OK
Pump operation time		>
IDU operation time		>
Current Flow Rate		>
Data logging		>



Current Flow Rate	Back
80.0 L/min	

Data logging

This function is to check the operation and error history.

- In the installer setting list, select Data logging category, and press [OK] button to move to the detail screen.

Installer ⏮ Back OK	
Domestic Hot Water	✓
Solar Thermal System	>
Service	>
Connectivity	>
Information	>



Information ⏮ Back OK	
Pump operation time	>
IDU operation time	>
Current Flow Rate	>
Data logging	>



Data logging ⏮ Back				
Date	Time	Oper.	Settemp	In/Out
1970.01.01	00:10	Off	—	24° / 25°
1970.01.01	00:09	Off	—	24° / 25°
1970.01.01	00:09	Off	—	24° / 25°
1970.01.01	00:09	Off	—	24° / 25°
1970.01.01	00:09	Off	—	24° / 25°

NOTE

Error history lookup range: 50

Error history information

Item: date, time, mode (including Off), set temperature, incoming temperature, outgoing temperature, room temperature, Hot water operation / stop, Hot water set temperature, Hot water temperature, Outdoor unit On / Off, Error code

Number of Display: Within 50

- Save criteria ▾

▾ Error occurred, released ON / OFF of outdoor unit operation.

COMMISSIONING

If everything is going well until now, it is time to start the operation and to take advantages of **THERMA V**.

Before starting operation, pre-check points are described in this chapter. Some comments about maintenance and how to do troubleshooting are presented.

Check List before Starting Operation



CAUTION

Turn off the power before changing wiring or handling product.

No	Category	Item	Check Point
1	Electricity	Field wiring	• All switches having contacts for different poles should be wired tightly according to regional or national legislation. • Only qualified person can proceed wiring. • Wiring and local-supplied electric parts should be complied with European and regional regulations. • Wiring should be following the wiring diagram supplied with the product.
2		Protective devices	• Install ELB (earth leakage breaker) with 30 mA. • ELB inside the control box of the unit should be turned on before starting operation.
3		Earth wiring	• Earth should be connected. Do not earth to gas or city water pipe, metallic section of a building, surge absorber, etc.
4		Power supply	• Use dedicated power line.
5		Terminal block wiring	• Connections on the terminal block (inside the control box of the unit) should be tightened.
6	Water	Charged water pressure	• After water charging, the pressure gauge (in front of the unit) should indicate 2.0~2.5 bar. Do not exceed 3.0 bar.
7		Air purge	• During water charging, air should be taken out through the hole of the air purge. • If water does not splash out when the tip (at the top of the hole) is pressed, then air purging is not completed yet. If well purged, the water will splash out like fountain. • Be careful when testing air purge. Splashed water may make your dress wet.
8		Shut-off valve	• Two shut-off valves (located at the end of water inlet pipe and water outlet pipe of the unit) should be open.
9		By-pass valve	• By-pass valve should be installed and adjusted to secure enough water flow rate. If water flow rate is low, flow switch error (CH14) can be occurred.
10	Product Installation	Hang to the wall	• As the unit is hung on the wall, vibration or noise can be heard if the unit is not fixed tightly. • If the unit is not fixed tightly, it can fall down during operation.
11		Parts inspection	• There should be no apparently damaged parts inside the unit.
12		Refrigerant leakage	• Refrigerant leakage degrades the performance. If leakage found, contact qualified LG air conditioning installation person.
13		Drainage treatment	• While cooling operation, condensed dew can drop down to the bottom of the unit. In this case, prepare drainage treatment (for example, vessel to contain condensed dew) to avoid water drop.

To assure best performance of **THERMAV**, it is required to perform periodical check and maintenance. It is recommended to proceed following check list for once a year.



CAUTION

Turn off the power before proceeding maintenance.


No	Category	Item	Check Point
1	Water	Water pressure	• In normal state, the pressure gauge (in front of the unit) should indicate 2.0~2.5 bar. • If the pressure is less than 0.3 bar, please recharge the water.
2		Strainer (Water filter)	• Close the shut-off valves and disassemble strainer. Then wash the strainer to make it clean. • While disassembling the strainer, be careful for water flood out.
3		Safety valve	• Open the switch of the safety valve and check if water is flood out through the drain hose. • After checking, close the safety valve.
4	Electricity	Terminal block wiring	• Look and inspect if there is loosen or defected connection on the terminal block.

Starting Operation

Check before Starting Operation

1	Check to see whether there is any refrigerant leakage, and check whether the power or transmission cable is connected properly.
2	Confirm that 500 V megger shows 2.0 MΩ or more between power supply terminal block and ground. Do not operate in the case of 2.0 MΩ or less. NOTE: Never carry out mega ohm check over terminal control board. Otherwise the control board may break. Immediately after mounting the unit or after leaving it turned off for an extended length of time, the resistance of the insulation between the power supply terminal board and the ground may decrease to approx. 2.0 MΩ as a result of refrigerant accumulation in the internal compressor. If the insulation resistance is less than 2.0 MΩ, turn on the main power supply.
3	When the power is applied for the first time, operate the product after preheating for 2 hours. To protect the unit by increasing the oil temperature of the compressor.

Starting Operation flow chart



Airborne Noise Emission

The A-weighted sound pressure emitted by this product is below 70 dB.

** The noise level can vary depending on the site.

The figures quoted are emission level and are not necessarily safe working levels.

Whilst there is a correlation between the emission and exposure levels, this cannot be used reliably to determine whether or not further precautions are required.

Factor that influence the actual level of exposure of the workforce include the characteristics of the work room and the other sources of noise, i.e. the number of equipment and other adjacent processes and the length of time for which an operator exposed to the noise.

Also, the permissible exposure level can vary from country to country.


This information, however, will enable the user of the equipment to make a better evaluation of the hazard and risk.

Vacuum & Charge of Refrigerant

By default, the product was charged of refrigerant.
Vacuum and refrigerant charge, If there is leak refrigerant.

1. Vacuum

To work of vacuum action. when the leak of refrigerant.




When selecting a vacuum, you should select one which is capable of achieving 0.2 Torr of ultimate vacuum.

Degree of vacuum is expressed in Torr, micron,mmHg, and Pascal (Pa). The units correlate as follows:

	Unit	Standard atmospheric pressure	Perfect vacuum
Gauge Pressure	Pa	0	-1.033
Absolute Pressure	Pa	1.033	0
Torr	Torr	760	0
Micron	Micron	760 000	0
mmHg	mmHg	0	760
Pa	Pa	1 013.33	0


2. Charge of refrigerant

You should be charged after vacuum.
 You can see amount of refrigerant at quality label.
 Please to charge at cooling mode when there is not full charging.



3. Location of SVC port

1Ø : 5 kW, 7 kW, 9 kW



Decommissioning and Recycling


- Sort the packaging according to cardboard, wood and foil and dispose of it in appropriate containers.
- After the lifespan of the device ends it has to be disposed of in accordance with the legislation on waste electrical and electronic devices in force.

1. Extraction of Refrigerant

The indoor unit has to be connected to the outdoor unit holding the HFC refrigerant R32 which is a fluorinated greenhouse gas covered in the Kyoto protocol. You have to prevent leakage of the gas into the atmosphere. During a maintenance procedure or removal of the device, make sure that the gas is removed in accordance with the current regulations for the use of substances harmful to the ozone and fluorinated greenhouse gases.

2. Draining the unit (Heating system)

Use the drain valve below to drain the Heating system.




! CAUTION

Turn off the power supply of the heat pump before draining the unit.

- Turn off the unit
- Connect a hose to the drain cock and lead it into a sink.
- Open the air vent(s) at the highest level of the heating system
- Open the drain valve

3. Draining the DHW tank

Use the drain valve shown below to drain the Domestic hot water tank and circuit.



CAUTION

Turn off the power supply of the heat pump before draining the unit.

- Turn off the unit
- Close the Cold water supply line
- Connect a hose to the drain cock and lead it into a sink
- Open the drain valve
- Open the tap at the highest level of the DHW system.

Reset of the thermal protection of the electrical heater

The thermal protection of the electrical heater is an additional safeguard protecting the device in the following cases:


- The electrical relay, which turns on the electrical flow heater can be permanently short-circuited.
- At commissioning, air is in the system; this causes heating without heat extraction.

The easiest way to determine whether the thermal protection of the electrical heater is operative is to force the Backup heater to work using the Emergency mode (refer to the Owner's manual for more detail).

Determine if you can feel by hand the difference between the supply line and the return line. The electrical heater works if the supply line is warmer.

In case the electrical heater does not work because of one of the aforementioned reasons, the Safety thermostat has to be reset manually after the problem is resolved.

First you have to remove the front panel. Reset the safety thermostat by pressing the red button until you hear a "CLICK".



CAUTION

Resetting the device can only be performed by installers, authorized contractors for commission or authorized maintenance worker in a voltage-free state.

Troubleshooting

If **THERMAV** operates not properly or it does not start operation, please check following list.



CAUTION

Turn off the power before proceeding troubleshooting.

Troubleshooting for Problem while Operation

No	Problem	Reason	Solution
1	Heating or Cooling is not satisfactory.	• Setting target temperature is not proper.	• Set target temperature correctly. • Check if temperature is water-based or air-based. See "Remote sensor active" and "Temp. sensor selection" in Chapter6.
		• Charged water is not enough.	• Check pressure gauge and charge more water until pressure gauge is indication 2~2.5 Bar
		• Water flow rate is low.	• Check if strainer gathers too much particles. If so, strainer should be cleaned. • Check if pressure gauge indicates above 4 Bar • Check if water pipe is getting closed due to stacked particles or lime.
2	Although electric power supply is OK (remote controller displays information), the unit does not start working.	• Water inlet temperature is too high.	• If water inlet temperature is above 57 °C, the unit does not operated for the sake of system protection
		• Water inlet temperature is too low.	• If water inlet temperature is below 5 °C in cooling operation, the unit does not operated for the sake of system protection. Wait while unit warms up the water inlet temperature. • If water inlet temperature is below 15 °C in heating operation, the unit does not operated for the sake of system protection. Wait while unit warms up to 18 °C the water inlet temperature. • If you are not using the back up heater accessory (HA**1M E1), increase the water temperature with the external heat source (heater, boiler). If the problem persists, contact your dealer. • If you want to use the screed drying function, be sure to purchase and install back up hater accessories (HA**1M E1).
3	Water pump noise.	• Air purging is not completely finished.	• Open the cap of air purge and charge more water until pressure gauge is indicating 2~2.5 Bar • If water does not splash out when the tip(at the top of the hole) is pressed, then air purging is not completed yet. If well purged, the water will splash out like fountain.
		• Water pressure is low.	• Check if pressure gauge indicates above 0.3 Bar. • Check if the expansion tank and pressure gauge operates well.
4	Water is flood out through drain hose.	• Too much water is charged.	• Flood out water by opening the switch of the safety valve until pressure gauge is indicating 2~2.5 Bar.
		• Expansion tank is damaged.	• Replace the expansion tank
5	DHW is not hot.	• Thermal protector of water tank heater is activated.	• Open the side panel of the DHW tank and push the reset button of the thermal protector. (for more detail information, please refer to installation manual of DHW tank.
		• DHW Heating is disabled.	• Select DHW Heating Operation and identify if icon is displayed on the remote controller.

Troubleshooting for Error Code

Display code	Title	Cause of error	Check point & Normal condition
1	Problem in remote room air sensor	• Incorrect connection between sensor and PCB(Heater). • PCB(Heater) fault • Sensor fault	• Resistance: 10 kΩ at 25 centigrade (unplugged) → for Remote room air sensor • Resistance: 5 kΩ at 25 centigrade (unplugged) → for all sensors EXCEPT remote room air sensor • Voltage: 2.5 V DC at 25 centigrade (plugged) (for all sensors) • Refer resistance-temperature table to check in different temperature
2	Problem in refrigerant (inlet side) sensor		
6	Problem in refrigerant (outlet side) sensor		
8	Problem in water tank sensor		
16	Problems in sensors		
17	Problem in water-inlet sensor		
18	Problem in water-outlet sensor		
19	Problem in Electric heater outlet sensor		
10	Water pump Lock	Fault feedback signal detected From Indoor water pump (for 30 seconds)	• Water pump defect • If there is a leak in the water pipe system • Wiring defect • Main PCB(Indoor)/Harness defect
3	Bad communication between remote controller and unit.	• Incorrect connection between sensor and PCB(Heater) • PCB(Heater) fault • Sensor fault	• Wire connection between remote controller and Main PCB assembly(Heater) should be tight • Output voltage of PCB should be 12 V DC
5	Bad communication between Main PCB assembly(Heater) and Main PCB assembly(Inverter) of the unit.	• The connector for transmission is disconnected • The connecting wires are misconnected • The communication line is broken • Main PCB assembly(Inverter) is abnormal • Main PCB assembly(Heater) is abnormal	• Wire connection between remote control panel and Main PCB assembly(Heater) should be tight.
53			
9	PCB program (EEPROM) fault	• Electrical or mechanical damage a the EEPROM	• This error can not be permitted
14	Problem in flow sensor	Flow sensor • Water Pump ON. : If flow rate is not more than 7 LPM or not less than 80 LPM, detect it for 15 seconds. • Water Pump OFF. : If flow rate is not less than 7 LPM, detect it for 15 seconds.	Flow Sensor • Display the flow rate value that received from the indoor unit. (Range : 7 ~ 80 L/min)

Display code	Title	Cause of error	Check point & Normal condition
15	Water pipe overheated	- Abnormal operation of electric heater - Leaving water temperature is above 57 °C(R410A)/65 °C(R32)	If there is no problem in electric heater control, possible maximum leaving water temperature is 57 °C (R410A)/65 °C(R32)
20	Thermal fuse is damaged	- Thermal fuse is cut off by abnormal overheating of internal electric heater - Mechanical fault at thermal fuse - Wire is damaged	This error will not be happened if temperature of electric heater tank is below 80 °C
21	DC PEAK (IPM Fault)	- Instant over current - Over Rated current - Poor insulation of IPM	- An instant over current in the U,V,W phase - Comp lock - The abnormal connection of U,V,W - Over load condition - Overcharging of refrigerant Pipe length. - Outdoor Fan is stop - Poor insulation of compressor
22	Max. C/T	Input Over Current	- Malfunction of Compressor - Blocking of Pipe - Low Voltage Input - Refrigerant, Pipe length, Blocked...
23	DC Link High / Low Volt	- DC Link Voltage is above 420 V DC - DC Link Voltage is below 140 V DC	- Check CN_(L), CN_(N) Connection - Check Input Voltage - Check PCB DC Link voltage sensor parts
24	High pressure Error (Activation of pressure switch)	Compressor stop by operating high pressure switch	- High pressure switch failure - Fan failure of outdoor unit - Compressor check valve clogged - Deformation due to breakage of refrigerant pipe - Refrigerant overcharge - Poor outdoor EEV - Shielding (Indoor filter clogged during heating) - Bad outdoor unit board
26	DC Compressor Position	Compressor Starting fail error	- Check the connection of comp wire "U,V,W" - Malfunction of compressor - Check the component of "IPM", detection parts.
27	AC Input Instant over Current Error	PCB(Inverter) input current is over 100 A(peak) for 2 us	- Overload operation (Pipe clogging/Covering/EEV defect/Ref. overcharge) - Compressor damage (Insulation damage/Motor damage) - Input voltage abnormal (L,N) - Power line assemble condition abnormal - PCB assembly 1 Damage (input current sensing part)
29	Inverter compressor over current	(HM**1M U*3) Inverter Compressor input current is 30 A. (HM**3M U*3) Inverter Compressor input current is 24 A.	- Overload operation (Pipe clogging/Covering/EEV defect/Ref. overcharge) - Compressor damage(Insulation damage/Motor damage) - Input voltage low - ODU PCB assembly 1 damage

Display code	Title	Cause of error	Check point & Normal condition
32	High temperature in Discharge pipe of the inverter compressor	• Overload operation (Outdoor fan constraint, screened, blocked) • Refrigerant leakage (insufficient) • Poor INV Comp Discharge sensor • LEV connector displaced / poor LEV assembly	• Check outdoor fan constraint/ screened/ flow structure • Check refrigerant leakage • Check if the sensor is normal • Check the status of EEV assembly
35	Low Presser Error	Excessive decrease of low pressure	• Defective low pressure sensor • Defective unit fan • Refrigerant shortage/leakage • Deformation because of damage of refrigerant pipe • Defective unit EEV • Covering / clogging (unit covering during the cooling mode / unit filter clogging during heating mode) • SVC valve clogging • Defective unit PCB(Inverter) • Defective unit pipe sensor
41	Problem in D-pipe temperature sensor	• Open / Short • Soldered poorly • Internal circuit error	• Bad connection of thermistor connector • Defect of thermistor connector (Open/Short) • Defect of outdoor PCB(Inverter)
43	Problem in high pressure sensor	Abnormal value of sensor (Open/Short)	• Bad connection of connector PCB(Inverter) • Bad connection high pressure connector • Defect of high pressure connector (Open/Short) • Defect of connector PCB(Inverter) (Open/Short) • Defect of PCB(Inverter)
44	Problem in outdoor air temperature sensor	• Open / Short • Soldered poorly • Internal circuit error	• Bad connection of thermistor connector • Defect of thermistor connector (Open/Short) • Defect of outdoor PCB(Inverter)
45	Problem in Cond. middle pipe temperature sensor		
46	Problem in suction pipe temperature sensor		
48	Condenser out pipe temperature Error		
52	PCB Communication Error	Checking the communication state between Main PCB and Inverter PCB	• Generation of noise source interfering with communication
54	Open and Reverse Phase Error	Prevention of phase unbalance and prevention of reverse rotation of constant-rate compressor	Main power wiring fault

Display code	Title	Cause of error	Check point & Normal condition
60	PCB(Inverter) & Main EEPROM check sum error	EEPROM Access error and Check SUM error	• EEPROM contact defect/wrong insertion • Different EEPROM Version • ODU Inverter & Main PCB assembly 1 damage
61	High temperature in Cond. Pipe	• Overload operation (Outdoor fan constraint, screened, blocked) • Unit heat exchanger contaminated • EEV connector displaced / poor EEV assembly • Poor Cond. Pipe sensor assembly / burned	• Check outdoor fan constraint / screened / flow structure • Check if refrigerant overcharged • Check the status of EEV assembly • Check the status of sensor assembly / burn
62	Heat sink Temp, High error	Heat sink sensor detected high temp.(85 °C)	• Part no. : EBR37798101~09 - Check the Heat sink sensor: 10 kΩ / at 25 °C Unplugged) - Check the outdoor fan is driving rightly • Part no. : EBR37798112~21 - Check the soldered condition in the 22,23 pin of IPM, PFCM - Check the screw torque of IPM, PFCM - Check the spreadable condition of thermal grease on IPM, PFCM - Check the outdoor fan is driving rightly
65	Problem in Heat sink Temperature sensor	Abnormal value of sensor(Open/Short)	• Check if there is defect of thermistor connector (Open/Short) • Check defect of outdoor PCB(Inverter)
67	Fan lock error	Fan RPM is less than 10 for 5 seconds from start-up operation. Fan RPM is less than 40 in operation except for start-up operation	• Fan motor damage. • Assembly condition abnormal. • Jammed fan by surroundings.
114	Problem in Vapor injection inlet temperature sensor	• Open / short of outdoor unit sensor • Soldered poorly • Internal circuit error	• Bad connection of thermistor connector • Defect of thermistor connector (Open/Short) • Defect of outdoor PCB(Outdoor)
115	Problem in Vapor injection outlet temperature sensor		
231	Problem in Water pressure sensor	Water Pressure Sensor of indoor unit is damaged.	• Sensor mismatch on the main PCB of Indoor unit. • The main PCB of Indoor unit. • Sensor failure (Reason of major defect)
232	Problem in Flow sensor	Flow Sensor of indoor unit is damaged.	

Open Source Software Notice Information

To obtain the source code under GPL, LGPL, MPL, and other open source code licenses, that is contained in this product, Please visit <https://opensource.lge.com>.

In addition to the source code, all referred license terms, warranty disclaimers and copyright notice are available for download. LG Electronics will also provide open source code to you on CD-ROM for a charge covering the cost of performing such distribution (such as the cost of media, shipping, and handling) upon email request to opensource@lge.com. This offer is valid for three(3) years from the date on which you purchased the product.



LG Electronics Inc. Single Point of Contact (EU/UK) :
LG Electronics European Shared Service Center B.V.
Krijgsman 1, 1186 DM Amstelveen, The Netherlands

Manufacturer :
LG Electronics Tianjin Appliances Co.,Ltd.
No. 9 Jin Wei Road, Bei Chen District, Tianjin, 300402, P.R. China

UK Importer :
LG Electronics U.K. Ltd
Velocity 2, Brooklands Drive, Weybridge, KT13 0SL

Eco design requirement

- The information for Eco design is available on the following free access website.
<https://www.lg.com/global/support/cedoc/cedoc>