





Read this owner's manual thoroughly before operating the appliance and keep it handy for reference at all times.

EN ENGLISH



MFL70720806 Rev.04\_042020 www.lg.com

Copyright © 2019-2020 LG Electronics Inc. All Rights Reserved





# **TABLE OF CONTENTS**

This manual may contain images or content different from the model you purchased. This manual is subject to revision by the manufacturer.

| SAFEIT INSTRUCTIONS              |     |
|----------------------------------|-----|
| READ ALL INSTRUCTIONS BEFORE USE | 3   |
| WARNING                          | 3   |
| CAUTION                          | 9   |
|                                  |     |
| INSTALLATION                     |     |
| Before Installation              |     |
| Reversable Doors ( * )           |     |
| Leveling the Appliance           |     |
| Connecting the Appliance         |     |
| Moving the Appliance             | 12  |
| OPERATION                        | 13  |
| Parts and Functions              |     |
| Notes for Operation              |     |
| Control Panel                    |     |
| Icemaker                         |     |
| Folding Shelf ( * )              |     |
| Other Functions                  |     |
| SMART FUNCTIONS                  | 25  |
| LG ThinQ Application Features    |     |
| Smart Diagnosis                  |     |
| •                                |     |
| MAINTENANCE                      |     |
| Notes for Cleaning               | 23  |
| Cleaning the Door Basket         | 23  |
| Cleaning the Shelf               | 24  |
| Cleaning the Vegetable Drawer    | 24  |
| Cleaning the Water Dispenser     | 25  |
| TROUBLE CHOOTING                 | 0.0 |









# SAFETY INSTRUCTIONS

### READ ALL INSTRUCTIONS BEFORE USE

# **Safety Messages**

The following safety guidelines are intended to prevent unforeseen risks or damage from unsafe or incorrect operation of the appliance.

The guidelines are separated into 'WARNING' and 'CAUTION' as described below.



This symbol is displayed to indicate matters and operations that can cause risk. Read the part with this symbol carefully and follow the instructions in order to avoid risk.



## WARNING

This indicates that the failure to follow the instructions can cause serious injury or death.



## CAUTION

This indicates that the failure to follow the instructions can cause the minor injury or damage to the product.

## WARNING



### WARNING

To reduce the risk of explosion, fire, death, electric shock, injury or scalding to persons when using this product, follow basic precautions, including the following:

# **Technical Safety**

• This appliance is not intended for use by persons (including children) with reduced physical, sensory or mental capabilities, or lack of experience and knowledge, unless they have been given supervision or instruction concerning use of the appliance by a person responsible for their safety. Children should be supervised to ensure that they do not play with the appliance.





- If the power cord is damaged or the hole of the outlet socket is loose, do not use the power cord and contact an authorized service centre.
- · Do not damage the refrigerant circuit.
- Do not use mechanical devices or other means to accelerate the defrosting process.
- Keep ventilation openings, in the appliance enclosure or in the built-in structure, clear of obstruction.
- Do not use electrical appliances inside the refrigerator.
- The refrigerant and insulation blowing gas used in the appliance require special disposal procedures. Consult with service agent or a similarly qualified person before disposing of them.
- This appliance is intended to be used in household and similar applications only. It should not be used for commercial, or catering purposes, or in any mobile application such as a caravan or boat.
- Do not store explosive substances such as aerosol cans with a flammable propellant in this appliance.



This symbol alerts you to flammable materials that can ignite and cause a fire if you do not take care.

- This appliance contains a small amount of isobutane refrigerant (R600a), but it is also combustible. When transporting and installing the appliance, care should be taken to ensure that no parts of the refrigerating circuit are damaged.
- When positioning the appliance, ensure the supply cord is not trapped or damaged.
- Do not locate multiple portable outlet-sockets or portable power supplies at the rear of the appliance.
- Disconnect the power cord before cleaning the appliance or replacing the inside lamp (where fitted).
- Securely plug the power plug in the outlet socket after completely removing any moisture and dust.
- Never unplug the appliance by pulling on the power cable. Always grip the power plug firmly and pull straight out from the outlet socket.







- Do not spray water or inflammable substances (toothpaste, alcohol, thinner, benzene, flammable liquid, abrasive, etc.) over the interior or exterior of the appliance to clean it.
- Do not clean the appliance with brushes, cloths or sponges with rough surfaces or which are made of metallic material.
- Only qualified service personnel from LG Electronics service centre should disassemble, repair, or modify the appliance. Contact an LG Electronics customer information centre if you move and install the appliance in a different location.
- Do not use a hair drier to dry the inside of the appliance or place a candle inside to remove the odours.
- Do not tilt the appliance to pull or push it when transporting.
- Make sure not to get a body part such as a hand or foot stuck while moving the appliance.

### **Risk of Fire and Flammable Materials**

- If a leak is detected, avoid any naked flames or potential sources
  of ignition and air the room in which the appliance is standing for
  several minutes. In order to avoid the creation of a flammable gas
  air mixture if a leak in the refrigerating circuit occurs, the size of the
  room in which the appliance is used should correspond to the amount
  of refrigerant used. The room must be 1 m² in size for every 8 g of
  R600a refrigerant inside the appliance.
- Refrigerant leaking out of the pipes could ignite or cause an explosion.
- The amount of refrigerant in your particular appliance is shown on the identification plate inside the appliance.

### Installation

- This appliance should only be transported by two or more people holding the appliance securely.
- Install the appliance on a firm and level floor.





- Do not install the appliance in a damp and dusty place. Do not install or store the appliance in any outdoor area, or any area that is subject to weathering conditions such as direct sunlight, wind, rain, or temperatures below freezing.
- Do not place the appliance in direct sunlight or expose it to the heat from heating appliances such as stoves or heaters.
- Be careful not to expose the rear of the appliance when installing.
- Install the appliance in a place where is easy to unplug the power plug of the appliance.
- Be careful not to let the appliance door fall during assembly or disassembly.
- Be careful not to pinch, crush, or damage the power cable during assembly or disassembly of the appliance door.
- Do not plug the appliance into multiple outlet sockets, power boards, or an extension power cable.
- · Do not use an extension cord or double adapter.
- Be careful not to point the power plug up or let the appliance lean against the power plug.
- Do not connect a plug adapter or other accessories to the power plug.
- · Do not modify or extend the power cable.
- Ensure that the outlet socket is properly grounded, and that the earth pin on the power cord is not damaged or removed from the power plug. For more details on grounding, inquire at an LG Electronics customer information centre.
- This appliance is equipped with a power cord having an equipmentgrounding conductor and a grounding power plug. The power plug must be plugged into an appropriate outlet socket that is installed and grounded in accordance with all local codes and ordinances.
- Never start up an appliance showing any signs of damage. If in doubt, consult your dealer.
- Dispose of all packaging materials (such as plastic bags and styrofoam) away from children. The packaging materials can cause suffocation.







# **Operation**

- Do not use the appliance for any purpose (storage of medical or experimental materials or shipping) other than any domestic household food storage use.
- If water penetrates electrical parts of the appliance, disconnect power plug and contact an LG Electronics customer information centre.
- Unplug the power plug during a severe thunderstorm or lightening or when not in use for a long period of time.
- Do not touch the power plug or the appliance controls with wet hands.
- Do not bend the power cable excessively or place a heavy object on it.
- Immediately unplug the power plug and contact an LG Electronics customer information centre if you detect a strange sound, odour, or smoke coming from the appliance.
- Do not place hands or metallic objects inside the area emitting the cold air, cover or heat releasing grille on the back.
- Do not apply excessive force or impact to the back cover of the appliance.
- Be careful of nearby children when you open or close the appliance door. The door may bump the child and cause injury.
- Avoid the danger of children getting trapped inside the appliance. A child trapped inside the appliance can cause suffocation.
- Do not put animals, such as pets into the appliance.
- Do not place heavy or fragile objects, containers filled with liquid, combustible substances, flammable objects (such candles, lamps, etc.), or heating devices (such as stoves, heaters, etc.) on the appliance.
- Do not place any electronic appliance (such as heater and mobile phone) inside the appliance.
- If there is a gas leakage (isobutane, propane, natural gas, etc.), do not touch the appliance or power plug and ventilate the area immediately. This appliance uses a refrigerant gas (isobutane, R600a). Although it uses a small amount of the gas, it is still combustible gas. Gas leakage during appliance transport, installation or operation can cause fire, explosion or injury if sparks are caused.





- Do not use or store flammable or combustible substances (ether, benzene, alcohol, chemical, LPG, combustible spray, insecticide, air freshener, cosmetics, etc.) near the appliance.
- Fill with potable water only into icemaker or dispenser water tank.

### **Maintenance**

- Only qualified service personnel from LG Electronics service centre should disassemble, repair, or modify the appliance. Contact an LG Electronics customer information centre if you move and install the appliance in a different location.
- Disconnect the power cord before cleaning the appliance or replacing the inside lamp (where fitted).
- Securely plug the power plug in the outlet socket after completely removing any moisture and dust.
- Never unplug the appliance by pulling on the power cable. Always grip the power plug firmly and pull straight out from the outlet socket.
- Do not spray water or inflammable substances (toothpaste, alcohol, thinner, benzene, flammable liquid, abrasive, etc.) over the interior or exterior of the appliance to clean it.
- Do not clean the appliance with brushes, cloths or sponges with rough surfaces or which are made of metallic material.

# **Disposal**

 When discarding the appliance, remove the door gasket while leaving the shelves and baskets in place and keep children away from the appliance.







### CAUTION



### CAUTION

To reduce the risk of minor injury to persons, malfunction, or damage to the product or property when using this product, follow basic precautions, including the following:

# **Operation**

- Do not touch frozen food or the metal parts in the freezer compartment with wet or damp hands. It may cause frostbite.
- Do not place glass containers, bottles or cans (especially those containing carbonated drinks) in the freezer compartment, shelves or ice bin that will be exposed to temperatures below freezing.
- The tempered glass on the front side of the appliance door or the shelves can be damaged by an impact. If it is broken, do not touch it with hands.
- Do not hang from the appliance doors, storage room, shelf or climb up into it.
- Do not store an excessive amount of water bottles or containers for side dishes on the door baskets.
- Do not open or close the appliance door with excessive force.
- If the hinge of the appliance door is damaged or operates improperly, stop using the appliance and contact an authorized service centre.
- Prevent animals from nibbling on the power cable or water hose.
- Never eat frozen foods immediately after they have been taken out in the freezer compartment.
- · Do not use a thin crystal cup or chinaware when dispensing.
- Make sure not to get a hand or foot stuck upon opening or closing the appliance door or door in door.





### **Maintenance**

- Do not clean glass shelves or covers with warm water when they are cold. They may break if exposed to sudden temperature changes.
- Do not insert the shelves upside down. The shelves may fall.
- To remove frost from the appliance, contact an LG Electronics customer information centre.
- Dispose of the ice inside the ice bin in the freezer compartment during an extended power outage.









# **INSTALLATION**

# **Before Installation**

### **Dimensions and Clearances**

 Too small of a distance from adjacent items may result in the degradation of freezing capability and increased electricity costs. Allow over 50 mm of clearance from each adjacent wall when installing the appliance.





| -    | Size(mm)   |               |
|------|------------|---------------|
| Type | Bar Handle | Pocket Handle |
| Α    | 705        | 700           |
| В    | 1720/1850  | 1720/1850     |
| С    | 740        | 700           |
| D    | 595        | 595           |
| Е    | 665        | 665           |
| F    | 700        | 700           |
| G    | 1340       | 1340          |
| Н    | 1200       | 1160          |

### NOTE

 The height (B) of the appliance may differ from model to model.

### **Ambient Temperature**

- The appliance is designed to operate within a limited range of ambient temperatures, depending on the climate zone.
- The internal temperature could be affected by the location of the appliance, the ambient temperature, the frequency of door opening and so on.
- The climate class can be found on the rating label.

| Climate Class           | Ambient Temperature<br>Range °C |
|-------------------------|---------------------------------|
| SN (Extended Temperate) | +10 - +32                       |
| N (Temperate)           | +16 - +32                       |
| ST (Subtropical)        | +16 - +38                       |
| T (Tropical)            | +16 - +43 / +10 - +43*          |

<sup>\*</sup>Australia, India, Kenya

### NOTE

 The appliances rated from SN to T are intended to be used at an ambient temperature between 10 °C and 43 °C.

### **Accessories**

\*1:This feature is only available on some models.









- Cord Holder\*1
- 2 Cap Door\*1
- 3 Cap Hinge\*1









# Reversable Doors (\*)

Some models are fitted with reversible doors, so that they may open from either the left or right hand side to suit your kitchen design.

### NOTE

- Reversing the doors must be performed by the qualified personnel of LG Electronics. If not, the doors will not be covered by the warranty.
- (\*): Call the LG Electronics Customer Information Center to find out if your model has this feature.

# Leveling the Appliance

To avoid vibration, the unit must be leveled. If required, adjust the leveling screws to compensate for the uneven floor.

The front should be slightly higher than the rear to aid in door closing and therefore the unit will have a slight backward lean.

Leveling screws can be turned easily by tipping the cabinet slightly.

Turn the leveling screws counterclockwise to lower the unit, clockwise to raise it.

# **Connecting the Appliance**

After installing the appliance, connect the power plug into a socket outlet.

### NOTE

 After connecting the power supply cord (or plug) to the outlet, wait 3 or 4 hours before you put food into the appliance. If you add food before the appliance has cooled completely, your food may spoil.

# Moving the Appliance

- 1 Remove all food from inside the appliance.
- Pull the power plug out, insert and fix it into the power plug hook at the rear or on top of the appliance.
- 3 Tape parts such as shelves and the door handle to prevent from falling off while moving the appliance.
- 4 Move the appliance with more than two people carefully. When transporting the appliance over a long distance, keep the appliance upright.
- After installing the appliance, connect the power plug into a mains outlet socket and switch it on.








# **OPERATION**

# **Parts and Functions**





To set the freezer and fridge temperatures.

Water Dispenser Tank (\*)

This is where water is stored to supply the dispenser. It requires manual filling. (Non plumbed models only)

**3** Smart Diagnosis Unit

Using this function when contacting LG Electronics customer information centre to help make an accurate diagnosis when the appliance operates abnormally or a failure occurs.

A LED Lamp

The LED lamp inside the appliance lights up when you open the fridge door.





### Fridge Shelf

This is where refrigerated foods and other items are stored.

- The shelf height can be adjusted by inserting the shelf in another groove of different height.
- Store the foods with higher moisture content at the front of the shelf.
- The actual number of shelves will differ from model to model.

### 6 Folding Shelf (\*)

This is where refrigerated foods and high items are stored.

### Bottle Rack (\*)

This is where drinks tall bottles or containers are stored.



### CAUTION

 Do not store short bottles or containers. The items may fall and cause an injury or appliance damage.

### Fresh Vegetable Drawer (\*)

This is where fruits and vegetables are stored to help maintain freshness by adjusting the humidity controller.

### 9 Vegetable Drawer

This is where fruits and vegetables are stored to remain fresh for as long as possible.

• The actual number of drawers will differ from model to model.

### Fridge Door Basket

This is where small packages of refrigerated foods, drinks and sauce containers are stored.

### Movable Egg Tray (\*)

This is where eggs are stored.

You can move it to and use it at a desired position as needed. However, do not use it as the ice bin
or place it on the shelf on top of the fridge or the vegetables drawer.

### lcemaker (\*)

This is where ice is manually produced and stored.

### Freezer Drawer

This is for long-term storage of frozen items.

- The appearance or components of the appliance may differ from model to model.
- ( \* ): This feature varies depending on the model purchased.





# **Notes for Operation**

- Users should keep in mind that frost can form. If the door is not closed completely, if the humidity is high during the summer, or if the freezer door is opened frequently.
- Ensure there is sufficient space between food stored on the shelf or door basket to allow the door to close completely.
- Opening the door lets warm air enter the appliance, and may cause the internal temperature to rise.
- If you are leaving the appliance turned off for an extended period of time, remove all food and unplug the power cord. Clean the interior, and leave the doors slightly ajar to prevent mold from growing in the appliance.

# Suggestion for Energy Saving


- Ensure there is sufficient space between stored foods. This allows cold air to be circulated evenly and lowers electricity bills.
- Store hot food only after it has cooled in order to prevent dew or frost.
- When storing food in the freezer compartment, set the freezer temperature lower than the temperature indicated on the food.
- Do not put food near the temperature sensor of the fridge compartment. Keep a distance of at least 3 cm from the sensor.
- Note that a temperature rise after defrosting has a permissible range in the appliance specifications. If you wish to minimise the impact this may have on the food storage due to a temperature rise, seal or wrap the stored food in several layers.
- The automatic defrosting system in the appliance ensures that the compartment remains free of ice buildup under normal operating conditions.

### **Storing Foods Effectively**

- Store frozen food or refrigerated food inside sealed containers.
- Check the expiration date and label (storage instructions) before storing food in the appliance.
- Do not store food for a long period of time (more than four weeks) if it spoils easily at a low temperature.
- Place the refrigerated food or frozen food in each fridge or freezer compartment immediately after purchasing.
- Avoid refreezing any food which has been completely thawed. Freezing any food which has been completely thawed again will lower its taste and nutrition.
- Do not wrap and store vegetables with newspaper. Printing material of newspaper or other foreign substances may smear and contaminate food.
- Do not overfill the appliance. Cold air can not circulate properly if the appliance is overfilled.
- If you set an excessively low temperature for food, it may become frozen. Do not set a temperature lower than the required temperature for the food to be stored correctly.
- For more space, you can remove bottle rack, egg tray, ice tray and fresh converter drawer.







15



## Max Freezing Capacity

- The Express Freeze function will set the freezer to its maximum freezing capacity. This generally takes up to 24 hours and automatically switches off.
- If the maximum freezing capacity is to be used, Express Freeze must be switched on for seven hours before fresh produce is placed in the freezer compartment.

### **Maximum Storage**

- To get better air circulation, insert all drawers.
- If large quantities of food are to be stored, all the freezer drawers should be taken out of the appliance and the food should be stacked directly on the freezer shelves in the freezer compartment.

- To remove the drawers, first remove the food from the drawers. Then by using the drawer handles pull out the drawers carefully. Not doing so could cause injury or damage to the drawers.
- The shape of each drawer may be different, reinsert each drawer into the right position.










## **Control Panel**

### **Units and Functions**



- Fridge Temperature
  - This sets the fridge target temperature.
- Express Cool
  - This enables the Express Cool function.
- Freezer Temperature
  - This sets the freezer target temperature.

- Express Freeze
  - This enables the Express Freeze function.
- ♠ Eco Friendly
  - This controls the Power Save mode for lowering energy consumption.

- The actual control panel may differ from model to model.
- The control panel will turn off automatically for energy saving.
- If there is any finger or skin contact to the control panel while cleaning it, the button function may operate.







# **Setting the Temperature**

This sets the fridge temperature or freezer temperature.

- Press the Fridge button or Freezer button to adjust the temperature.
- The temperature can be adjusted.

Fridge : from 1 °C to 7 °CFreezer : from -15 °C to -23 °C

The initial temperature is set.

Fridge: 3 °CFreezer: -18 °C

 The actual inner temperature varies depending on the food status, as the indicated setting temperature is a target temperature, not actual temperature within the appliance.

### NOTE

- The default temperature setting may vary depending on the appliance.
- Wait until 3 or 4 hours have passed after connecting the appliance to the mains power before storing food in the appliance.

## **Setting Express Cool**

This function can quickly cool a large amount of food in the fridge compartment.

- When you press the Express Cool button for 3 seconds, the Express Cool icon lights on the control panel.
- The function is enabled and disabled in turn each time you press the button.
- The Express Cool function automatically terminates after a specific period (maximum 7 hours) has passed.

### **Setting Express Freeze**

This function can quickly freeze a large amount of ice or food in the freezer compartment.

- When you press the Express Freeze button for 3 seconds, the Express Freeze icon lights on the control panel.
- The function is enabled and disabled in turn each time you press the button.
- The Express Freeze function automatically terminates after a specific period (maximum 24 hours) has passed. Please be mindful that The Express freeze function may cause ice cream to become hard

# **Setting Eco Friendly**

- The function sets the appliance to the power saving mode to reduce energy consumption when you are away from home for a few days.
- Pressing the Eco Friendly button starts the operation with the lamp on, and pressing it again stops the operation.
- When the Eco Friendly mode is on, the other buttons will not operate. When you finish using the Eco Friendly mode, turn it off so that other buttons work and the refrigerator returns to its previous temperature setting.







### Water Dispenser (\*)

Press the lever of the water dispenser to dispense cold water.



## CAUTION

· Keep children away from the dispenser to prevent children playing with or damaging the controls.

### NOTE

- If the cup or glass opening rim is small, water may splash out of the glass or miss it completely.
- Use a cup or glass with a rim of over 68 mm in diameter when dispensing water.
- (\*): This feature varies depending on the model purchased.

# Water Dispenser tank (\*)

1 Open the cap (small cover) on the top of the water tank.



- 2 Fill the water tank with potable water and close the cap (small cover).
  - The water tank can hold up to 2.3 L.





# CAUTION

- · Children should not be allowed near the dispenser tank. If the child drops the water dispenser tank while it is completely filled with water, injury may occur. Do not fill the water tank with drinks other than water of fill with hot water.
- Do not apply excessive force or impact when removing or assembling the water dispenser tank. Doing so can cause appliance damage or injury.

- · Before using the water dispenser tank after installing the appliance, it should be washed before filling it with water.
- Check if the water dispenser tank has been placed on the appliance correctly. If it is not assembled correctly, water may leak from the tank into the appliance.
- If there is no water in the water dispenser tank. the water function of the dispenser cannot be used. Check if there is water in the water dispenser tank and then fill it with water if there is not.
- Sound from the water tank will be normal when supplying water to the dispenser. It is not a sign of malfunction.
- (\*): This feature varies depending on the model purchased.









### **Icemaker**

This is where ice is manually produced and stored.

### NOTE

 You can remove the ice tray or ice storage bin if you do not use it to create more space inside the freezer

### Making Ice

1 Hold the handle of the ice tray and pull it out.



2 Fill the ice tray with water up to the water level.



3 Place the ice tray back to its position carefully not to spill water on to the floor or shelf.

# **MARNING**

· Fill with potable water only.



### CAUTION

- Check whether there is any ice remaining in the ice tray before putting water into it.
- Do not close the freezer door using any sudden or aggressive motion after filling the ice tray with water.

### NOTE

- If the ice tray is overfilled, the ice may stick together and be difficult to remove.
- Press the Express Freeze button on the control panel to make ice quickly. Please be mindful that The Express freeze function may cause ice cream to become hard.

### **Taking Out Ice**

Rotate the ice separation handle on the icemaker clockwise



2 Lift the ice storage bin slightly to remove it.





# CAUTION

- If you open and close the freezer door frequently, it may take longer for water to freeze.
- The time it takes for water to freeze may vary according to the season.
- The temperature inside the appliance can take up to 24 hours to stabilize after initial installation. Water may take longer to freeze because of this.
- Be careful when handling the ice as the edges of the ice may be sharp.

- Do not store ice that has not frozen completely in the ice bin. Unfrozen water could cause the ice to clump together.
- When getting ice, remove the ice storage bin gently so that the slide stopper doesn't break.
- Fill the ice tray up to the water line. If water goes over the water line, it could spill into the ice storage bin, making it difficult to remove the ice already in the ice bin.









# Folding Shelf (\*)

Store taller items such as bottles and food by folding the front half of the shelf.

Lift the front side of the shelf and shift it on to the rear half shelf.



2 Lift the front side of the shelf and shift it under its rear half shelf. From this position, both sides of the shelf can be lifted up to free more space.



### NOTE

• ( \* ): This feature varies depending on the model purchased. Other Functions

## **Other Functions**

### **Door Open Alarm**

The alarm sounds 3 times in 30 second intervals if the fridge door is left open or not completely closed for one minute.

 Contact the LG Electronics customer information centre if the alarm sound continues every 30 seconds even after closing the door.

### **Failure Detection**

The appliance can automatically detect problems during the operation.

- If a problem is detected, the appliance may not operate and an error code is displayed even when any button is pressed.
- When this occurs, do not turn off the power and immediately contact the LG Electronics customer information centre. If you turn off the power, the repair technician from the LG Electronics customer information centre may have difficulty finding the problem.









# **SMART FUNCTIONS**

# LG ThinQ Application Features

This feature is only available on models with the 9 or  $\textcircled{9}_{1}$  logo.

The **LG ThinQ** application allows you to communicate with the appliance using a smartphone.

### **LG ThinQ Application Features**

Communicate with the appliance from a smart phone using the convenient smart features.

### **Smart Diagnosis**

 If you experience a problem while using the appliance, this smart diagnosis feature will help you diagnose the problem.

### NOTE

- The application is subject to change for appliance improvement purposes without notice to users.
- · Functions may vary by model.

### Installing the LG ThinQ Application

Search for the **LG ThinQ** application from the Google Play Store or Apple App Store on a smart phone.

- Follow instructions to download and install the application.
- Run the LG ThinQ application and follow the instructions in the application to register the appliance.

# **Smart Diagnosis**

This feature is only available on models with the s or  $\textcircled{e}_1$  logo.

Use this feature to help you diagnose and solve problems with your appliance.


### NOTE

- For reasons not attributable to LGE's negligence, the service may not operate due to external factors such as, but not limited to, Wi-Fi unavailability, Wi-Fi disconnection, local app store policy, or app unavailability.
- The feature may be subject to change without prior notice and may have a different form depending on where you are located.

# Using Audible Diagnosis to Diagnose Issues

Follow the instructions below to use the audible diagnosis method.

- Launch the LG ThinQ application and select the Smart Diagnosis feature in the menu.
   Follow the instructions for audible diagnosis provided in the LG ThinQ application.
- Open the fridge door.
- 2 Press the Eco Friendly button.
  - If the door has been open for longer than 60 seconds, close the door and repeat steps 1 and 2.
- 3 Hold the phone on the upper right speaker hole



- 4 Press and hold the Freezer button for 3 seconds while holding your holding your phone in front of the speaker.
- After the data transfer is complete, the diagnosis will be displayed in the application.

### NOTE

 For best results, do not move the phone while the tones are being transmitted.







# **MAINTENANCE**

# **Notes for Cleaning**


- When removing a shelf or drawer from inside the appliance, remove all stored foods from the shelf or drawer to prevent injury or damage to the appliance.
  - Otherwise, injury may occur due to the weight of stored foods.
- If cleaning the outside air vents of the appliance by means of vacuuming, then the power cord should be unplugged from the outlet to avoid any static discharge that can damage the electronics or cause an electric shock.
- Detach the shelves and drawers and clean them with water, and then dry them sufficiently, before replacing them. Do not immerse cold shelves under hot water. Doing so can cause the shelves to shatter and cause injury.
- Regularly wipe the door gaskets with a wet soft towel.
- Door basket spills and stains should be cleaned as they can compromise storage ability of the basket and could even be damaged.
- After cleaning, check if the power cable is damaged, warm or improperly plugged.
- Keep the air vents on the exterior of the appliance clean.
  - Blocked air vents can cause fire or appliance damage.
- When cleaning the inside or outside of the appliance, do not wipe it with a rough brush, toothpaste, or flammable materials. Do not use cleaning agents containing flammable substances.
  - This may cause discoloration or damage to the appliance.
  - Flammable substances: alcohol (ethanol, methanol, isopropyl alcohol, isobutyl alcohol, etc.), thinner, bleach, benzene, flammable liquid, abrasive, etc.
- For the appliance exterior, use a clean sponge or soft cloth and a mild detergent in warm water.
   Do not use abrasive or harsh cleaners. Dry thoroughly with a soft cloth.
- Never clean the shelves or containers in the dishwasher.
  - The parts may become deformed due to the heat.

 If the appliance is equipped with an LED lamp, do not remove the lamp cover and LED lamp in any attempt to repair or service it. Please, contact the LG Electronics customer information centre.

# **Cleaning the Door Basket**

# Removing the Fridge/Freezer Door Basket

Hold both edges of the basket and remove it by lifting it upward.




# Refitting the Fridge/Freezer Door Basket

1 Hold both edges of the door basket, gently push one edge to assemble, and then in the same manner assemble the other edge.



2 After assembling, tap the door basket gently to ensure it is horizontally secured.











# Cleaning the Shelf

### Removing the Fridge/Freezer Shelf

Remove the shelf by pulling it out while slightly lifting the rear edge of the fridge shelf.




# Refitting the Fridge/Freezer Shelf


Mount them in the reverse order of the removal process.

# Removing the Folding Shelf


Slightly Lift up the front of the sliding shelf and slide it inward.



2 Lift the rear half shelf up to remove it.



3 Hold the center of the frame shelf. Slightly lift up the frame shelf and pull it out.



## Refitting the Folding Shelf

Mount them in the reverse order of the removal process.




# CAUTION

- · Glass shelves are heavy. Use special care when removing them.
- Make sure that shelves are level from one side to the other. Failure to do so may result in the shelf falling or spilled food.
- · Never wash or submerge cold shelves in hot or warm water as they could shatter and cause injury.

# Cleaning the Vegetable Drawer

# Removing the Vegetable Drawer

Remove the contents of the drawer. Hold the handle of the vegetable drawer and pull it out completely but gently until it stops.










2 Lift the vegetable drawer up and remove it by pulling it out.



# **Refitting the Vegetable Drawer**

Insert the bottom of the vegetable drawer into its original position and gently push it back in while lowering it.



# **A** CAUTION

 Please note that injuries and product damage can be caused by the weight of stored foods when removing the vegetable drawer if they are not removed beforehand.

# Cleaning the Water Dispenser


# **Cleaning the Dispenser Tray**



The dispenser tray may become wet easily due to spilled ice or water. Wipe the entire area with a damp cloth.

# **Cleaning the Water Outlet**

Wipe the water outlet frequently with a clean cloth as it may get dirty easily. Please note that lint from a cloth may adhere to the outlet.









# TROUBLESHOOTING

| Symptoms   | Possible Cause & Solution  |
|--|--|
| There is no refrigeration or freezing.             | Is there a power interruption?  • Check the power of other appliances.   |
|  | Is the power plug unplugged from the outlet?  • Plug the power plug in the outlet properly.  |
| There is poor refrigeration or freezing.           | Is the fridge or freezer temperature set to its warmest setting?  • Set the fridge or freezer temperature to 'Medium'.   |
|  | Is the appliance in direct sunlight, or is it near a heat generating object such as cooking oven or heater?  • Check the installation area and reinstall it away from heat generating objects. |
|  | Did you store hot food without cooling it first?  • Cool the hot food first before putting it in the fridge or freezer compartment.  |
|  | Did you put in too much food?  • Maintain an appropriate space between food.   |
|  | Are the appliance doors completely closed?     Completely close the door and make sure that stored food is not obstructing in the door.  |
|  | Is there enough space around the appliance?  • Adjust the installation position to make enough space around the appliance.   |
| The appliance contains a bad smell.                | Is the fridge or freezer temperature set to 'Warm'?  • Set the fridge or freezer temperature to 'Medium'.  |
|  | Did you put in food with a strong smell?  • Store foods with strong smells in a sealed containers.   |
|  | Vegetables or fruit may have spoiled in the drawer?  Throw away rotten vegetables and clean the vegetable drawer. Do not store vegetables too long in the vegetable drawer.                    |
| The inside lamp in the appliance does not turn on. | Lamp failure     Close the door and re-open. If the lamp does not turn on, please contact the LG Electronics customer information centre. Do not attempt removal of the lamp.                  |







| Symptoms   | Possible Cause & Solution  |
|--|--|
|  | Is the appliance leaning forward?  |
|  | Adjust the front feet to raise the front side slightly.  |
|  | Were the shelves properly assembled?   |
| The appliance door is not closed tightly.  | Refit the shelves if needed.   |
|  | Did you close the door with excessive force?   |
|  | If you apply too much force or speed when closing the door, it may remain<br>briefly open before closing. Make sure that you do not slam the door closed.<br>Close without force.  |
|  | Did you open the door right after you closed it?   |
| It is difficult to open<br>the appliance door.   | If you try to open the appliance door within one minute after you closed it, you may have difficulties because of the pressure inside the appliance. Try to open the appliance door again in a few minutes so that the internal pressure stabilizes. |
|  | Did you store hot food without cooling it first?   |
|  | Cool the hot food first before putting it in the fridge or freezer compartment.  |
| There is condensation inside the appliance or on the bottom of the vegetable drawer cover. | Did you leave the appliance door open?   |
|  | Although the condensation will disappear soon after you close the appliance door, you can wipe it with a dry cloth.  |
|  | Do you open and close the appliance door too frequently?   |
|  | Condensation can form due to the temperature difference from the outside.  Wipe out the dampness with a dry cloth.   |
|  | Did you put warm or moist food inside without sealing it in a container?   |
|  | Store food in a covered or sealed container.   |
| Frost has formed in the freezer compartment.   | Doors may not be closed properly?  |
|  | Check if the food item inside the appliance is blocking the door and make sure that the door is tightly closed.  |
|  | Did you store hot food without cooling it first?   |
|  | Cool the hot food first before putting it in the fridge or freezer compartment.  |









| Symptoms   | Possible Cause & Solution   |
|--|---|
| Frost has formed in the freezer compartment.       | Is the air entry or exit of the freezer compartment blocked?  • Make sure that air entry or exit is not blocked so that the air can circulate inside.   |
|  | Is the freezer compartment overfilled?  |
|  | Maintain an appropriate space between items.  |
| Frost or condensation has formed inside or         | Did you open and close the appliance door frequently or is the appliance door improperly closed?  |
|  | Frost or condensation can form if the outside air penetrates inside the appliance.  |
| outside the appliance.                             | Is the installation environment humid?  |
|  | Condensation can appear on the exterior of the appliance if the installation area is too humid or on a humid day such as a rainy day. Wipe off any moisture with a dry cloth.   |
|  | Is the appliance installed on a weak floor or improperly leveled?   |
|  | Install the appliance on a solid and flat area.   |
|  | Does the rear of the appliance touch the wall?  |
| The appliance is noisy and generates               | Adjust the installation position to allow enough clearance around the appliance.  |
| abnormal sounds.                                   | Are objects scattered behind the appliance?   |
|  | Remove the scattered objects from behind the appliance.   |
|  | Is there an object on top of the appliance?   |
|  | Remove the object on top of the appliance.  |
| The side or front of the appliance is warm.        | There are anti condensation pipes fitted to these areas of the appliance to reduce condensation forming from around the door area.  |
|  | The heat releasing pipe to prevent condensation is installed on the front and side of the appliance. You may feel it particularly hot right after the appliance is installed or during the summer. You can be assured that this is not a problem and is quite normal. |
| There is water inside or outside of the appliance. | Is there water leakage around the appliance?  |
|  | Check if the water has leaked from a sink or another place.   |
|  | Is there water on the bottom of the appliance?  |
|  | Check if the water is from the thawed frozen food or a broken or dropped container.   |
| Water does not come out.                           | The water dispenser tank may be empty? (Non plumbed models only)  |
|  | Fill the water dispenser tank.  |











| Symptoms         | Possible Cause & Solution  |
|------------------|--|
| Clicking noises  | The defrost control will click when the automatic defrost cycle begins and ends. The thermostat control (or appliance control on some models) will also click when cycling on and off. |
|                  | Normal Operation   |
| Rattling noises  | Rattling noises may come from the flow of appliance, the water line on the back of the unit (for plumbed models only), or items stored on top of or around the appliance.              |
|                  | Normal Operation   |
|                  | Refrigerator is not resting evenly on the floor.   |
|                  | Floor is weak or uneven or leveling legs need to be adjusted. See the Door Alignment section.  |
|                  | The refrigerator with linear compressor was moved while operating.   |
|                  | Normal operation. If the compressor does not stop rattling after three minutes, turn the power to the appliance off and then on again.   |
| Whooshing noises | Evaporator fan motor is circulating air through the fridge and freezer compartments.   |
|                  | Normal Operation   |
|                  | Air is being forced over the condenser by the condenser fan.   |
|                  | Normal Operation   |
| Gurgling noises  | Refrigerant is flowing through the cooling system  |
|                  | Normal Operation   |
| Popping noises   | Contraction and expansion of the inside walls due to changes in temperature.   |
|                  | Normal Operation   |
| Vibrating        | If the side or back of the appliance is touching a cabinet or wall, some of the normal vibrations may make an audible sound.   |
|                  | To eliminate the noise, make sure that the sides and back do not make any contact with any wall or cabinet.  |





