



Please read this manual carefully before operating your set and retain it for future reference.

CM4550 (CM4550, CMS4550F, CMS4550W)

P/NO: MFL68941438\_REV1.0

### Safety Information



# CAUTION KOFELECTRICSHOCK



CAUTION: TO REDUCE THE RISK OF ELECTRIC SHOCK DO NOT REMOVE COVER (OR BACK) NO USER-SERVICEABLE PARTS INSIDE REFER SERVICING TO QUALIFIED SERVICE PERSONNEL.



This lightning flash with arrowhead symbol within an equilateral triangle is intended to alert the user to the presence of uninsulated dangerous voltage within the product's enclosure that may be of sufficient magnitude to constitute a risk of electric shock to persons.



The exclamation point within an equilateral triangle is intended to alert the user to the presence of important operating and maintenance (servicing) instructions in the literature accompanying the product.

**WARNING:** TO PREVENT FIRE OR ELECTRIC SHOCK HAZARD, DO NOT EXPOSE THIS PRODUCT TO RAIN OR MOISTURE.

**WARNING:** Do not install this equipment in a confined space such as a book case or similar unit.

**CAUTION:** Do not block any ventilation openings. Install in accordance with the manufacturer's instructions.

Slots and openings in the cabinet are provided for ventilation and to ensure reliable operation of the product and to protect it from over heating. The openings shall be never be blocked by placing the product on a bed, sofa, rug or other similar surface. This product shall not be placed in a built-in installation such as a bookcase or rack unless proper ventilation is provided or the manufacturer's instruction has been adhered to.



**CAUTION:** This product employs a Laser System. To ensure proper use of this product, please read this owner's manual carefully and retain it for future reference. Shall the unit require maintenance, contact an authorized service center.

Use of controls, adjustments or the performance of procedures other than those specified herein may result in hazardous radiation exposure.

To prevent direct exposure to laser beam, do not

#### **CAUTION** concerning the Power cord

try to open the enclosure.

Most appliances recommend they should be placed upon a dedicated circuit;

That is, a single outlet circuit which powers only that appliance and has no additional outlets or branch circuits. Check the specification page of this owner's manual to be certain. Do not overload wall outlets. Overloaded wall outlets, loose or damaged wall outlets, extension cords, frayed power cords, or damaged or cracked wire insulation are dangerous. Any of these conditions could result in electric shock or fire. Periodically examine the cord of your appliance, and if its appearance indicates damage or deterioration, unplug it, discontinue use of the appliance, and have the cord replaced with an exact replacement part by an authorized service center. Protect the power cord from physical or mechanical abuse, such as being twisted, kinked, pinched, closed in a door, or walked upon. Pay particular attention to plugs, wall outlets, and the point where the cord exits the appliance. The Power Plug is the disconnecting device. In case of an emergency, the Power Plug must remain readily accessible.

This device is equipped with a portable battery or accumulator.

Safety way to remove the battery or the battery from the equipment: Remove the old battery or battery pack, follow the steps in reverse order than the assembly. To prevent contamination of the environment and bring on possible threat to human and animal health, the old battery or the battery put it in the appropriate container at designated collection points. Do not dispose of batteries or battery together with other waste. It is recommended that you use local, free reimbursement systems batteries and accumulators. The battery shall not be exposed to excessive heat such as sunshine, fire or the like.

**CAUTION:** The apparatus shall not be exposed to water (dripping or splashing) and no objects filled with liquids, such as vases, shall be placed on the apparatus.

**CAUTION:** Do not use high voltage products around this product. (ex. Electrical swatter) This product may malfunction due to electrical shock.

#### Disposal of your old appliance



- When this crossed-out wheeled bin symbol is attached to a product it means the product is covered by the European Directive 2002/96/EC.
- All electrical and electronic products should be disposed of separately from the municipal waste stream via designated collection facilities appointed by the government or the local authorities.
- The correct disposal of your old appliance will help prevent potential negative consequences for the environment and human health.
- For more detailed information about disposal of your old appliance, please contact your city office, waste disposal service or the shop where you purchased the product.

#### Disposal of waste batteries/accumulators



- When this crossed-out wheeled bin symbol is attached to batteries/ accumulators of Your product it means they are covered by European Directive 2006/66/EC.
- This symbol may be combined with chemical symbols for mercury(Hg), cadmium(Cd) or lead(Pb) if the battery Contains more that 0.0005% of mercury,0.002% of cadmium or 0.004% of lead.
- 3. All batteries/accumulators should be disposed separately from the municipal waste stream via designated collection facilities appointed by the government or the local authorities.
- The correct disposal of your old batteries/accumulators will help to prevent potential negative consequences for the environment, animal and human health.
- For more detailed information about disposal of your old batteries/ accumulators, please contact your city office, waste disposal service or the shop where you purchased the product.

#### **Table of Contents**

#### 1 Getting Started

- 3 Safety Information
- 8 Unique Features
- 8 Accesories
- 9 Playable file Requirement
- 9 Music file requirement
- 9 Compatible USB Devices
- 9 USB device requirement
- 10 Remote control
- 12 Front Panel
- 14 Rear Panel

#### 2 Connecting

- 15 Connecting to speakers
- 15 Attaching the speakers to the unit
- 15 Attaching the subwoofer to the unit
- 16 Optional Equipment Connection
- 16 Antenna Connection
- 16 USB Connection
- 17 AUX IN Connection
- 17 PORT. IN Connection
- 17 Listening to the sound from your external device

#### 3 Operating

- 18 Basic Operations
- 18 CD/USB Operations
- 18 Auto Play
- 19 Other Operations
- 19 Programmed Playback
- 19 Deleting Programmed list
- 19 Displaying file information (ID3 TAG)
- 20 Searching for a folder and an MP3/ WMA file
- 20 Deleting an MP3/WMA file
- 21 Turn off the sound temporarily
- 21 DEMO
- 21 AUTO DJ playback
- 22 Using a BLUETOOTH® wireless technology
- 22 Listening to music stored on the BLUETOOTH devices
- 24 Using the Music Flow Bluetooth App
- 24 Install "Music Flow Bluetooth" App onto Your Bluetooth Device
- 26 Radio Operations
- 26 Listening to the radio
- 26 Improving poor FM reception
- 26 Presetting the Radio Stations
- 26 Deleting all the saved stations
- 27 Sound adjustment
- 27 Setting the surround mode
- 28 Setting the Clock
- 28 Setting the Clock through "Music Flow Bluetooth" App
- 28 Using your player as an alarm clock
- 29 Sleep Timer Setting
- 29 Dimmer
- 29 Auto power down
- 29 AUTO POWER On
- 30 Auto function change
- 30 LG Sound Sync

### 4 Troubleshooting

32 Troubleshooting

#### 5 Appendix

- 33 General specifications
- 34 Speaker specifications
- 35 Maintenance
- 35 Handling the Unit
- 35 Notes on Discs
- 35 Trademarks and Licenses

1

2

3

4

Э

# **Unique Features**

#### **BLUETOOTH®**

Listens to music stored on your **Bluetooth** device.

#### Portable In

Listens to music from your portable device. (MP3, Notebook, etc.)

#### **AUTO DJ**

Blends the end of one song into the beginning of another for seamless playback.

#### Music Flow Bluetooth

Music Flow Bluetooth is an app designed to let you take control of some of LG's latest Audio devices.

Refer to page 24-25


#### LG Sound Sync

Controls volume level of this unit by the remote control of your LG TV that is compatible with LG Sound Sync.

### **Accesories**

Please check and identify the supplied accessories.





Remote Control (1)

Batteries (2)



FM Antenna (1)

# Playable file Requirement

#### Music file requirement

MP3/WMA file compatibility with this unit is limited as follows.

- Sampling frequency: within 32 to 48 kHz (MP3), within 32 to 48 kHz (WMA)
- Bit rate: within 32 to 320 kbps (MP3), 40 to 192 kbps (WMA)
- Maximum files: Data CD: 999 / USB: 2000
- Maximum folders : Data CD : 99 / USB : 200
- File extensions : ".mp3"/".wma"
- Certain MP3/WMA files may not be played depending on the type or format of the file.
- CD-ROM file format: ISO 9660/JOLIET
- We recommend that you use Easy-CD Creator, which creates an ISO 9660 file system.

The DTS is not supported. In case of DTS audio format, audio is not output.

You have to set the disc format option to [Mastered] in order to make the discs compatible with the LG players when formatting rewritable discs. When setting the option to Live File System, you cannot use it on LG players.

(Mastered/Live File System : Disc format system for Windows Vista)


#### Compatible USB Devices

- MP3 Player : Flash type MP3 player.
- USB Flash Drive : Devices that support USB2.0 or USB1.1.
- The USB function of this unit does not support all USB devices.

#### USB device requirement

- Devices which require additional program installation when you have connected it to a computer, are not supported.
- Do not extract the USB device while in operation.
- For a large capacity USB, it may take longer than a few minute to be searched.
- To prevent data loss, back up all data.
- If you use a USB extension cable or USB hub, the USB device is not recognized.
- Using NTFS file system is not supported.
   (Only FAT(16/32) file system is supported.)
- This unit recognizes up to 2000 files.
- External HDD, Card readers, Locked devices, or hard type USB devices are not supported.
- USB port of the unit cannot be connected to PC. The unit cannot be used as a storage device.
- Some USB may not work with this unit.

#### Remote control



### . . . . . . . . . . . 1

(1) (Power): Switches the unit ON or OFF.

▲ (Open/Close): Opens and closes the disc tray.

#### PRESET FOLDER A/V

- Searches for a folder of MP3/WMA files. When a CD/USB containing MP3/WMA files in several folders is being played, press **PRESET-FOLDER**  $\Lambda/V$  to select the folder you want to play.
- Chooses a preset number for a radio station.

**FUNCTION**: Selects the function and input source.

**MUTE**: Mutes the sound.

**VOL +/-**: Adjusts speaker volume.


#### PROGRAM/MEMORY:

- Stores radio stations.
- Deletes all the saved stations
- Creates a programmed list you want to listen to.
- ★: The button is not available for any function.

**SLEEP**: Sets the system to turn off automatically at a specified time.

(Dimmer: The display window will be darkened by half.)

#### **Battery Installation**



Remove the battery cover on the rear of the Remote Control, and insert two (size AAA) batteries with **•** and **•** matched correctly.

**REPEAT(MENU)**: Listens to your tracks/files repeatedly or randomly.

#### Idd/▶► (Skip/Search):

- Skips fast backward or forward.
- Searches for a section within a track/file.

**TUNING -/+**: Selects the radio station.

#### ■ ENTER :

- Stops playback.
- Cancels DELETE function.

#### ►/II (Play/Pause):

- Starts or pauses playback.
- Selects STEREO/MONO.

**SOUND EFFECT**: Chooses sound impressions.

**AUTO DJ**: Selects the AUTO DJ mode. (For more information refer to page 21)

#### **DELETE:**

- Deletes MP3/WMA files.
- Deletes a song on the programmed list.

**0** to **9** numerical buttons : Selects numbered tracks, files, or preset number.

#### INFO:

- Sees informations about your music. An MP3 file often come with ID3 tag. The tag gives the Title, Artist, Album or Time information.
- Sees the address of connected **Bluetooth** device in **Bluetooth** mode.


**REGION EQ**: Chooses region equalizer.

**CLOCK**: Sets a clock and checks a time.

**ALARM**: With the ALARM function you can turn CD, USB play and Tuner reception on at a desired time.

**SET**: Confirms the setting.

# Front Panel



- 1 Display window
- 2 USB 1/ USB 2 Plays the audio files by connecting the USB device.
- 3 U/ (Power) Switches the unit ON or OFF.
- 4 ☐ (Stop)
  Stops playback
- Stops playback. **5 AUTO DJ**
- Selects the AUTO DJ mode. (For more information refer to page 21)
- **6 I**≪ (Skip/Search)
  - Searches backward.
  - Skips to the previous track/file.
- **7 DEMO**Demonstrates each of functions.
- 8 PORT. IN
- 9 Disc tray

#### 10 FUNCTION

Selects the function or input source.

#### **11** >||

#### ST./MO.

- Starts or pauses playback.
- Selects Stereo/Mono.
- 12 LG EQ

You can choose sound impressions.

- 13 >> (Skip/Search)
  - Searches forward.
  - Skips to the next track/file.
- 14 BASS BLAST

Selects BASS or STANDARD effect directly.


15 Master Volume

Adjusts volume of speaker.

**16** △ (Open/Close)

Opens or closes the disc tray.

# Rear Panel




- 1 POWER IN
- 2 ANTENNA (FM)
- 3 AUX IN (L/R) connectors
- 4 SPEAKERS terminal/cord

# Connecting to speakers

# Attaching the speakers to the unit


To connect the cable to the unit, press each plastic finger pad to open the connection terminals on the unit. Insert the wire and release the finger pad.

Connect the black stripe of each wire to the terminals marked - (minus) and the other end to the terminals marked + (plus).



# Attaching the subwoofer to the unit

Connect a woofer cord to the player.
When connecting a woofer cord to the player, insert the connector until it clicks.



Color	Speaker
Orange	Subwoofer
Red	Front R
White	Front L

### (<u>!</u>)

#### 


- Be careful to make sure children do not put their hands or any objects into the \*speaker duct.
  - \* Speaker duct : A hole for plentiful bass sound on speaker cabinet (enclosure)
- The speakers contain magnet parts, so color irregularity may occur on the TV screen or PC monitor screen. Please use the speakers far away from either TV screen or PC monitor.
- Do not connect any other speaker except subwoofer speaker to the subwoofer connection terminal on the rear of the unit.

# Optional Equipment Connection

#### **Antenna Connection**


Connect the supplied FM antenna for listening to the radio.

Connect the antenna to the antenna port on the back of the unit. Be sure to extend the FM wire antenna fully.



#### **USB** Connection

Connect a USB device (or MP3 player, etc.) to the USB ports on the unit.



Note

Removing the USB Device from the unit.


- Choose a different function/mode or press ■ ENTER on the remote control or □ on the unit twice in a row.
- 2. Remove the USB device from the unit.

2

#### **AUX IN Connection**

Connect an output of auxiliary device (Camcorder, TV, Player, etc) to the **AUX IN(L/R)** connector.


If your device has only one output for audio(mono), connect it to the left (white) audio jack on the unit.



To the audio output jacks of your component (Camcorder, TV, Player, etc.)

#### **PORT. IN Connection**

Connect an output (earphone or line out) of portable device (MP3 or PMP etc.) to the **PORT. IN** connector.



# Listening to the sound from your external device

The unit can be used to play the sound from many types of external device.

- Connect the external device to the AUX IN(L/R) or PORT. IN connector of the unit.
- 2. Turn the power on by pressing 1 on the remote control or 1/1 on the unit.
- 3. Select the AUX or PORTABLE function by pressing **FUNCTION**.
- 4. Turn the external device and start playing it.

# **Basic Operations**

#### **CD/USB Operations**

- 2. Select CD or USB function by pressing **FUNCTION**.

То	Do this
Stop	Press ■ ENTER on the remote control or □ on the unit.
Playback	Press ►/II on the remote control or ➤II on the unit.
Pause	During playback, press ►/II on the remote control or ➤II on the unit.
Searching for a section within a track/file	Press and hold I◀◀/▶▶I on the remote control or I≪/≫I on the unit during playback and release it at the point you want to listen to.
Selecting a track/file directly	Press <b>0</b> to <b>9</b> numerical buttons on the remote control to go to the desired file or track directly.
Skipping to the next/ previous track/file	- In stop status,  Press I◄◄/▶►I on the remote control or I≪/≫I on the unit to go to the next/previous track/file.  - During playback,  press ▶►I on the remote control or ➤I on the unit to go to the next track/file.  Playing less than 2 seconds, press I◄◄ on the remote control or I≪ on the unit to go to the previous track/file.  Playing after 3 seconds, press I◄◄ on the remote control or I≪ on the unit to go to the beginning of the track/file.
Playing repeatedly or randomly	Press <b>REPEAT(MENU)</b> on the remote control repeatedly. Refer to the note for details about the display change.



#### Note

• The display changes in the following order.

A CD AUDIO CD
RPT 1
R -
L RPT ALL
M RANDOM
OFF

\*DIR: Directory

- When you play Program list, only RPT 1 and RPT ALL are available.
- Even after restarting the unit or switching one function to another, you can listen to music from the point where it's last been played.
- If you leave the disc tray open for 5 minutes, it will close automatically.

#### **Auto Play**

AUDIO/MP3/WMA CD is played automatically after disc tray is open and then closed.

Automatically switches to the CD function if disc tray is open and then closed when there is no disc in tray.

# **Other Operations**

#### Programmed Playback

The program function enables you to store your favorite files from any disc or USB device.

A program can contain 20 tracks/files for each media. (CD, USB1,USB2) Possible to save a total of 60 tracks/files.

- Press PROGRAM/MEMORY on the remote control in stop status.
- Press I◀◀/▶▶I on the remote control to select a track/file.
- Press PROGRAM/MEMORY to save and select a next track/file.
- Repeat steps 2 3 to store other tracks/files. (You can modify the list by pressing PRESET-FOLDER ∧/V to select the program number.)
- 5. Press **PROGRAM/MEMORY** once again.

To play the programmed list, press ►/ II after you make the list.



#### Note

When making or modifying the programmed list. REPEAT mode is off.

#### **Deleting Programmed list**

Deleting function only works in the edit mode.

- Press PROGRAM/MEMORY on the remote control in stop status.
- Select a song by pressing PROGRAM/MEMORY or PRESET-FOLDER ∧/V repeatedly.
- 3. Press **DELETE** while a song is selected.




- Programmed list is cleared in the case below.
  - Removing the disc or the USB device.
  - Deleting music files in the USB device.
  - Unplugging the Power Cord.
- Program is switched off in the case below.
  - Changing to a different function.
- Turning off and on the unit.
- Operating the numeric buttons on the remote control.

# Displaying file information (ID3 TAG)

While playing an MP3 file containing file information, you can display the information by pressing **INFO**.

#### Searching for a folder and an MP3/WMA file

- 1. Press **PRESET-FOLDER**  $\Lambda/V$  on the remote control repeatedly until a desired folder appears in the display window.
- 2. Press ►/II to play it. The first file of the folder will be played.



• If there is no file in a folder, the folder will not appear.

- J FILE 2

- Folders will be presented as the following order: ROOT → FOLDER1 → FOLDER3 → FOLDER7 → FOLDER8 → FOLDER5 → FOLDER6
- File will be played from ♪ file No.1 to ♪ file No.14 one by one.
- \*ROOT: The first screen you can see when a computer recognize the USB/CD is "ROOT".

### Deleting an MP3/WMA file

You can delete file, folder or format by pressing **DELETE** on the remote control. This function is supported only in stop status. (USB only)

- 1. -Select the file you want to delete and press **DELETE** on the remote control.
  - -Select the folder you want to delete by pressing **PRESET·FOLDER**  $\Lambda/V$  on the remote control and press **DELETE** on the remote control
  - -Press and hold **DELETE** on the remote control to format the USB device.

Press **DELETE** on the remote control repeatedly during selecting the MP3/WMA file.

The display changes in the following order.

- DEL FILE: Deletes file - DEL DIR: Deletes folder - FORMAT: Formats USB

2. To delete file/folder or format, press ►/II on the remote control or > 11 on the unit.

If you want to exit the current mode, press **ENTER** on the remote control or press  $\square$  on the unit.

#### Caution .

- · Do not extract the USB device during operation. (play, delete, etc.)
- Regular back up is recommended to prevent data loss.
- The delete function may not be supported according to the USB status.

#### Turn off the sound temporarily

Press **MUTE** on the remote control to mute your sound.

You can mute your unit, for example, to answer the telephone, the "MUTE" will appear in the display window.

To cancel it, press **MUTE** again or change the volume level.

#### **DEMO**

In the power off state, press **DEMO** on the unit once. The unit will power on and display each function in the display window. To cancel the DEMO function, press **DEMO** once more.



#### Note

- While in DEMO, this unit will keep DEMO status even if you unplug the power cord connection.
- You can enjoy other functions during the DEMO, the DEMO will temporarily pause.
   Without input key in 10 sec, the DEMO will play back automatically.

#### AUTO DJ playback

Auto DJ blends the end of one song into the beginning of another for seamless playback. It equalizes volume across tracks for uninterrupted playback.

Press **AUTO DJ** on the remote control or unit repeatedly, the display changes as followings.

RANDOM (AUTO DJ RANDOM) -> RPT (AUTO DJ SEOUENTIAL) -> (AUTO DJ OFF)

Mode	Display Window	Description
OFF	- (AUTO DJ OFF)	-
RANDOM	RANDOM (AUTO DJ RANDOM)	The music is played randomly on this mode.
REPEAT	RPT (AUTO DJ SEQUENTIAL)	The music is played repeatedly on this mode.



#### Note

- AUTO DJ mode does not support searching for a section within a track/file or to play repeatedly or randomly.
- If you move to other functions or stop the music using ☐ on the unit (or ■ ENTER on the remote control) on AUTO DJ mode, AUTO DJ will be disable
- AUTO DJ is not supported in the music file whose length is less than 60 seconds.
- Only AUTO DJ SEQUENTIAL is selected when played programmed list.

# Using a BLUETOOTH® wireless technology

#### About BLUETOOTH

**Bluetooth** is wireless communication technology for short range connection.

The sound may be interrupted when the connection has interference from other electronic devices or you connect a **Bluetooth** device from a different room.

Connecting individual devices under **Bluetooth** wireless technology does not incur any charges. A mobile phone with **Bluetooth** wireless technology can be operated via the Cascade if the connection was made via **Bluetooth** wireless technology.

Available Devices: Mobile phone, MP3, Laptop, PDA

#### **BLUETOOTH Profiles**

In order to use **Bluetooth** wireless technology, devices must be able to interpret certain profiles. This unit is compatible with following profile. A2DP (Advanced Audio Distribution Profile)

#### Listening to music stored on the BLUETOOTH devices

#### Pairing your unit and BLUETOOTH device

Before you start the pairing procedure, make sure the **Bluetooth** feature is activated on your Bluetooth device. Refer to your Bluetooth device's user guide. Once a pairing operation is performed, it does not need to be performed again.

- 1. Press the **FUNCTION** button until the **Bluetooth** function is selected. "BT RFADY" appears on the display window.
- 2. Operate the **Bluetooth** device and perform the pairing operation. When searching for this unit with the **Bluetooth** device, a list of the devices. found may appear in the **Bluetooth** device display depending on the type of **Bluetooth** device. Your unit appears as "LG CM4550(XX)".



- · XX means the last two digits of **Bluetooth** address. For example, if your unit has a **Bluetooth** address such as 9C:02:98:4A:F7:08, you will see "LG CM4550(08)" on your Bluetooth device.
- Depending on the Bluetooth device type, some devices may have a different pairing process. Enter the PIN code (0000) as needed.
- You can connect this unit with up to 3 **Bluetooth** devices simultaneously using the same method as described above, only in the **Bluetooth** function.
- The multi pairing connection is only supported on Android or iOS devices. (Multi pairing connection may not be supported depending on the connected device specifications.)
- Removable/detachable **Bluetooth** device (Ex: Dongle etc.) will not support multi pairing.

3. When this unit has successfully connected with your **Bluetooth** device. "PAIRED" will be appear on the display window. After a short amount of time, the **Bluetooth** device name will be displayed.



#### Note

- "PAIRED" will momentarily appear on the display when you connect other devices for multi pairing
- If the device name is unavailable, "\_" will be displayed.
- 4 Listen to music

To play a music stored on your **Bluetooth** device, refer to your **Bluetooth** device's user quide.



#### Note

- When using **Bluetooth** technology, you have to make a connection between the unit and the **Bluetooth** device as close as possible and keep the distance. However, it may not work well in certain situations as described below:
  - There is a obstacle between the unit and the **Bluetooth** device
  - There is a device using same frequency with **Bluetooth** technology such as a medical equipment, a microwave or a wireless I AN device
- You should connect your **Bluetooth** device to this unit again when you restart it.
- Even if this unit connected up to 3 Bluetooth devices in the Bluetooth mode, you can play and control music by using only one of the connected devices.



#### Note

- When this unit connected with multiple Bluetooth devices, only one device which you are playing keeps **Bluetooth** connection when you change the function to the others.
- The sound may be interrupted when the connection has interference from other electronic devices.
- You cannot control the Bluetooth device with this unit.
- Depending on the type of the device, you may not be able to use the **Bluetooth** function
- You can enjoy wireless system using phone, MP3, Notebook, etc.
- The more distance between the unit and the Bluetooth device, the lower the sound quality becomes.
- Bluetooth connection will be disconnected when the unit is turned off or the **Bluetooth** device gets far from the unit.
- When **Bluetooth** connection is disconnected, connect the Bluetooth device to the unit again.
- When a **Bluetooth** device is not connected. "BT READY" appears on the display window.
- When you use Bluetooth function. adjust the volume to a proper level on the **Bluetooth** device.
- If it is not in **Bluetooth** function, only one device can be connected.
- If a **Bluetooth** device is connected when using LGTV. LGTV is disconnected and the **Bluetooth** device is connected.
- When you connect **Bluetooth** device (iOS device etc.) to this unit or operate the device, the volume level can be synchronized with each other.

# Using the Music Flow Bluetooth App



#### Note

Only Android OS is available to use "Music Flow Bluetooth" app with this unit.

#### About "Music Flow Bluetooth" App

"Music Flow Bluetooth" app brings a suite of new features to this unit.

To enjoy more features, you are recommended to download and install free "Music Flow Bluetooth"

#### Install "Music Flow Bluetooth" App onto Your Bluetooth **Device**

There are two ways to install "Music Flow Bluetooth" App onto your **Bluetooth** device.

#### Install "Music Flow Bluetooth" App through QR code

1. Install "Music Flow Bluetooth" app through QR code. Use the scanning software to scan the QR code.



- 2. Tap an icon for installation.
- 3. Tap an icon for downloading.



#### Note

- Make sure that your **Bluetooth** device is connected to the Internet.
- Make sure that your **Bluetooth** device has a scanning software application. If you don't have one, download one from "Google Android Market (Google Play Store)".
- Depending on area, QR code may not work.

#### Install "Music Flow Bluetooth" App through "Google Android Market (Google Play Store)"

- 1. Tap the "Google Android Market (Google Play Store)" icon.
- 2. In the search bar, type in the "Music Flow Bluetooth" and search it.
- 3. In the search result list, find and tap "Music Flow Bluetooth" to start downloading Bluetooth app.
- 4. Tap an icon for installation.
- 5. Tap an icon for downloading.



- Make sure that your **Bluetooth** device is connected to the Internet.
- Make sure that your **Bluetooth** device is equipped with "Google Android Market (Google Play Store)".

#### Activate Bluetooth with "Music Flow Bluetooth" App

"Music Flow Bluetooth" app helps to connect your **Bluetooth** device to this unit.

- Tap "Music Flow Bluetooth" app icon on the home screen to open "Music Flow Bluetooth" app, and go to the main menu.
- 2. Tap [Menu] and select the unit you want.
- 3. If you want to get more information to operate, tap [Setting] and turn on the User guide.



#### Note

- "Music Flow Bluetooth" app will be available in the software version as follow:
  - Android O/S: Ver 4.0.3 (or later)
- If you use "Music Flow Bluetooth" app for operation, there would be some differences between "Music Flow Bluetooth" app and the supplied remote control. Use the supplied remote control as necessary.
- Depending on the **Bluetooth** device, "Music Flow Bluetooth" app may not work.
- After connection of "Music Flow Bluetooth" app, music may be output from your device. In this case, try connecting procedure again.
- If you operate the other applications or change the settings on your **Bluetooth** device while using "Music Flow Bluetooth" app, "Music Flow Bluetooth" app may operate abnormally.
- When "Music Flow Bluetooth" app operates abnormally, check your **Bluetooth** device and the connection of "Music Flow Bluetooth" app and then try to connect again.
- Depending on the smart phone's operating system, you have some differences for "Music Flow Bluetooth" operation.
- Check Bluetooth setting on your Bluetooth device if "Music Flow Bluetooth" App connection does not work well.

# Radio Operations

Be sure that FM antenna is connected. (Refer to page 16)

#### Listening to the radio

- 1. Press FUNCTION until FM appears in the display window. The last received station is tuned in.
- 2. Auto tuning:

Press and hold TUNING -/+ on the remote control or **I**≪/≫**I** on the unit for about two seconds until the frequency indication starts to change, then release. Scanning stops when the unit tunes in a station.

Or

Manual tuning:

Press TUNING -/+ on the remote control or  $|\langle\langle\rangle\rangle$  on the unit repeatedly.

3. Adjust the volume by rotating volume knob on the unit or by pressing **VOL +/-** on the remote control repeatedly.

#### Improving poor FM reception

Press > II on the unit or ▶/III on the remote control. This will change the Tuner from stereo to mono and usually improve the reception.

#### Presetting the Radio Stations

You can preset 50 stations for FM. Before tuning, make sure to turn down the volume.

- 1. Press **FUNCTION** until FM appears in the display window.
- 2. Select the desired frequency by pressing TUNING -/+ on the remote control or  $|\langle\langle\rangle\rangle$  on the unit.
- 3. Press **PROGRAM/MEMORY** on the remote control. A preset number will blink in the display window.
- 4. Press **PRESET-FOLDER**  $\Lambda/V$  on the remote control to select the preset number you want.
- 5. Press PROGRAM/MEMORY on the remote control. The station is stored.
- 6. Repeat steps 2 to 5 to store other stations.
- 7. To listen to a preset station, press **PRESET-FOLDER**  $\Lambda/V$  or **0** to **9** numerical buttons on the remote control.

#### Deleting all the saved stations

- 1. Press and hold **PROGRAM/MEMORY** on the remote control for two seconds. "ERASEALL" will flash up on the unit display.
- 2. Press **PROGRAM/MEMORY** on the remote control to erase all the saved radio stations.

# Sound adjustment

#### Setting the surround mode

This system has a number of pre-set surround sound fields. You can select a desired sound mode by using **SOUND EFFECT** on the remote control.

The displayed items for the equalizer may be different depending on sound sources and effects.

On Display	Description
NATURAL	You can enjoy comfortable and natural sound.
Local Specialization equalizer (Optional)	Regionally optimized sound effect. (FORRO/FUNK/SERTANEJ/DANGDUT/ARABIC/PERSIAN/INDIA/REGUETON/MERENGUE/SALSA/SAMBA/CUMBIA/AFRO, AXE, TECNO BR)
AUTO EQ	Realizes the sound equalizer that is the most similar to the genre of which is included in the MP3 ID3 tag of song files.
POP CLASSIC JAZZ ROCK	This program lends an enthusiastic atmosphere to the sound, giving you the feeling you are at an actual rock, pop, jazz or classic concert.
BASS	Reinforces the treble, bass and surround sound effect.
FOOT BALL	You can enjoy the sound effect FOOTBALL STADIUM.
FLAT	Provides balanced sound.
BOOST	Boosts the mid-range for sound reinforcement.
TRE/BASS	Reinforces the treble and bass.
STANDARD	You can enjoy optimized sound.



#### Note -

- On some speakers, sound may not be heard or heard in low sound depending on the sound mode.
- Maybe you need to reset the sound mode, after switching the input, sometimes even after the sound track changed.
- By pressing **BASS BLAST** on the unit you can directly select the STANDARD or BASS effect.

# Setting the Clock

- 1 Turn the unit on
- Press and hold CLOCK.
- 3. Select time mode by pressing ► on the remote control.
  - AM 12:00 (for an AM and PM display) or 0:00 (for a 24 hour display)
- 4. Press **SET** to confirm your selection.
- 5. Select the hours by pressing ► on the remote control.
- 6. Press SET.
- 7. Select the minutes by pressing ► on the remote control.
- 8 Press SET

#### Setting the Clock through "Music Flow Bluetooth" App

Install "Music Flow Bluetooth" app on your Android device. (Refer to page 24)

Your unit's clock will be automatically synchronized with your device by activating **Bluetooth** connection through "Music Flow Bluetooth" app.

#### Using your player as an alarm clock

- 1. Turn the unit on.
- Press and hold ALARM.
- 3. Press ► on the remote control to change the hours and minutes and press SET to save.
- 4. Press ◄◄/▶▶ on the remote control to select function and press SET to save.
  - Press ► to select a memory No. when you select Tuner and then, press **SET**. If there is no memory No., this step is skipped.
- 5. Press ► on the remote control to change the volume and press **SET** to save. The clock icon "O" shows that the alarm is set.



#### Note

- If you set the clock time, you can check the time by pressing **CLOCK** even when the player is turned off.
- You can set alarm after you set the clock
- If you set the clock time and alarm, you can check the alarm icon "()" by pressing **CLOCK** even when the player is turned off.
- If you set the clock time and alarm, you can check the alarm icon "O" and setting information by pressing **ALARM** even when the unit is turned off.
- You can select ALARM on/off mode by pressing ALARM.

#### Sleep Timer Setting

Press **SLEEP** repeatedly to select delay time between 10 and 180 minutes. After the delay time, the unit will be turned off.

To cancel the sleep function, press **SLEEP** repeatedly until "SLEEP 10" appears, and then press **SLEEP** once again while "SLEEP 10" is displayed.



#### Note

- You can check the remaining time before the unit is turned off.
- Press **SLEEP**. The remaining time appears in the display window.

#### Dimmer

Press **SLEEP** once. The display window will be darkened by half. To cancel it, press **SLEEP** repeatedly until dim off.



#### Note -

All the LED turns off when Dimmer is being operated.

#### Auto power down

This unit will turn itself off to save electricity in the case were the main unit is not connected to an external device and is not used for 20 minutes.

The unit will also turn itself off after six hours if the Main unit has been connected to another device using the analog inputs.

#### How to disconnect the wireless network connection or the wireless device

Turn off the unit by pressing the power button for more than 5 seconds.

#### AUTO POWFR On

This unit automatically turns on by an input source : LG TV or Bluetooth

If you try to connect your **Bluetooth** device, this unit turns on and connect your **Bluetooth** device. You can play your music.



#### Note

- · Depending on the connected device, this function may not operate.
- Depending on the connected device, the unit turns on but **Bluetooth** function may not be connected.
- If you disconnect **Bluetooth** connection by this unit, some **Bluetooth** devices try to connect to the unit continually. Therefore it is recommended to disconnect the connection before turning off the unit.
- If you try to connect to the "Music Flow Bluetooth" app, Bluetooth function of this unit is turned on.
- If you turn on the unit using LGTV or **Bluetooth** function, proper function of this unit is turned on.
- If you have already paired with this unit, automatically this unit can turn on by an input source when this unit is turned off.
- If you turn off the unit by pressing the power button for more than 5 seconds, Auto Power On function is disabled To activate it turn on the unit

### Auto function change

This unit recognizes input signals such as **Bluetooth** and LGTV and then changes suitable function automatically.

#### When you try to connect Bluetooth device

When you try to connect your Bluetooth device to this unit, **Bluetooth** function is selected. Play your music on the Bluetooth device.

#### When LG TV is connected

When you turn on your LG TV connected by LG Sound Sync, this unit changes the function to LG TV. You can hear the sound from your TV.



#### Note

This function only works with devices that were previously connected.

# LG Sound Sync



You can control some functions of this unit by your TV's remote control with LG Sound Sync. It is compatible with LGTV that supports LG Sound Sync. Make sure your TV has the LG Sound Sync logo.

Controllable function by LGTV's remote control: Volume up/down, mute

Refer to the TV's instruction manual for the details of LG Sound Sync.



#### Note

- · You can also use the remote control of this unit while using LG Sound Sync. If you use TV's remote control again, the unit synchronizes with the TV.
- If the connection fails, check the conditions of this unit and your TV: power, function.
- Make sure of the condition of this unit and the connection in the cases below when usina LG Sound Svnc.
  - Turned off the unit.
  - Changing the function to the others.
  - Disconnecting the wireless connection caused by interference or a distance.
- The amount of time to turn off this unit is different depending on your TV.
- Details of TV setting menu vary depending on the manufacturers or models of your TV.
- If you connect LG Sound Sync when "Music Flow Bluetooth" app is connected, control through the app is available.
- If you turned off the unit directly by pressing (Power), LG Sound Sync will be disconnected. To use this function again, you should reconnect the TV and the unit.
- If an LGTV is connected when using Bluetooth. Bluetooth is disconnected and the LG TV is connected.
- If you try to change the function on using the LG TV function, volume will be change according to the LGTV volume level.

- 1. Turn on the unit by pressing (b) (Power) on the remote control
- Press FUNCTION until I G TV function is selected.
- 3. Set up the sound output of TV to listen to the sound through this unit:

TV setting menu → [Sound] → [TV Sound output] → [LG Sound Sync (Wireless)]

"PAIRED" appears on the display window for about 3 seconds and then you can see "LGTV" on the display window if connecting normally between this unit and your TV.

# **Troubleshooting**

Problem	Cause & Correction
The unit does not work properly.	<ul> <li>Turn off the power of this unit and the connected external device (TV, Woofer, DVD-player, Amplifier, etc.) and turn it on again.</li> <li>Disconnect the power cord of this unit and the connected external device (TV, Woofer, DVD-player, Amplifier, etc.) and then try connecting again.</li> <li>Previous setting may not be saved when device power is shut off.</li> </ul>
No Power.	<ul> <li>The power cord is not plugged in. Plug in the power cord.</li> <li>Check whether electricity failed. Check the condition by operating other electronic devices.</li> </ul>
No sound.	<ul> <li>Check whether you select right function. Press FUNCTION and check the selected function.</li> <li>Check to see if the Speakers are connected correctly. Speaker cables connected correctly.</li> </ul>
The unit does not start playback.	<ul> <li>An unplayable disc is inserted. Insert a playable disc.</li> <li>No disc is inserted. Insert a disc.</li> <li>The disc is dirty. Clean the disc. (Refer to page 35)</li> <li>The disc is inserted upside down. Place the disc with the label or printed side facing upwards.</li> </ul>
Radio stations cannot be tuned in properly.	<ul> <li>The antenna is positioned or connected poorly. Connect the antenna securely.</li> <li>The signal strength of the radio station is too weak. Tune to the station manually.</li> <li>No stations have been preset or preset stations have been cleared. (when being tuned by scanning preset channels) Preset some radio stations, see page 26 for details.</li> </ul>
The remote control does not work properly.	<ul> <li>The remote control is too far from the unit. Operate the remote control within about 23 ft (7 m).</li> <li>There is an obstacle in the path of the remote control and the unit. Remove the obstacle.</li> <li>The batteries in the remote control are exhausted. Replace the batteries with new ones.</li> </ul>
LG Sound Sync does not work.	<ul> <li>Check whether your LGTV supports LG Sound Sync.</li> <li>Check connection of LG Sound Sync.</li> <li>Check sound setting of your TV and this unit.</li> </ul>

# General specifications

General	
Power requirements	Refer to the main label.
	Refer to the main label.
Power consumption	Networked standby : 0.4 W (If all network ports are activated.)
Dimensions (W x H x D)	(206 x 308 x 284) mm
Net Weight (Approx.)	3.1 kg
Operating temperature	5 °C to 35 °C
Operating humidity	5 % to 90 %
Bus Power Supply	5 V === 500 mA

Inputs	
AUX IN	2.0 Vrms (1 kHz, 0 dB), 75 Ω, RCA jack (L, R)
Port In	1.2 Vrms (3.5 mm stereo jack)

Tuner	
FM Tuning Range	87.5 to 108.0 MHz or 87.50 to 108.00 MHz

Amplifier	
Total Output	700 W
Front	230 W X 2 (3 Ω at 1 kHz)
Subwoofer	240 W (3 Ω at 1 kHz)
THD	20 %

CD	
Frequency Response	100 to 20000 Hz
Signal-to-noise ratio	75 dB
Dynamic range	75 dB

# Speaker specifications

Front speaker		
Туре	2 Way 2 Speaker	
Impedance	3 Ω	
Rated Input Power	230 W	
Max. Input power	460 W	
Net Dimensions (W x H x D)	(266 x 306 x 263) mm	
Net Weight	3.1 kg	

Subwoofer speaker			
Туре	1 Way 1 Speaker		
Impedance	3 Ω		
Rated Input Power	240 W		
Max. Input power	480 W		
Net Dimensions (W x H x D)	(266 x 306 x 324) mm		
Net Weight	4.7 kg		

• Design and specifications are subject to change without notice.

#### **Maintenance**

#### Handling the Unit

#### When shipping the unit

Please save the original shipping carton and packing materials. If you need to ship the unit, for maximum protection, re-pack the unit as it was originally packed at the factory.

#### Keeping the exterior surfaces clean

Do not use volatile liquids such as insecticide spray near the unit.

Wiping with strong pressure may damage the surface.

Do not leave rubber or plastic products in contact with the unit for a long period of time.

#### Cleaning the unit

To clean the player, use a soft, dry cloth. If the surfaces are extremely dirty, use a soft cloth lightly moistened with a mild detergent solution. Do not use strong solvents such as alcohol, benzine, or thinner, as these might damage the surface of the unit.

#### Maintaining the Unit

The unit is a high-tech, precision device. If the optical pick-up lens and disc drive parts are dirty or worn, the picture quality could be diminished. For details, please contact your nearest authorized service center.

#### **Notes on Discs**

#### **Handling Discs**

Never stick paper or tape on the disc.

#### Storing Discs

After playing, store the disc in its case. Do not expose the disc to direct sunlight or sources of heat and never leave it in a parked car exposed to direct sunlight.

#### Cleaning Discs

Do not use strong solvents such as alcohol, benzine, thinner, commercially available cleaners, or anti-static spray intended for old vinyl records.

# Trademarks and Licenses



**Bluetooth®** wireless technology is a system which allows radio contact between electronic.

Connecting individual devices under *Bluetooth*\* wireless technology does not incur any charges. A mobile phone with *Bluetooth*\* wireless technology can be operated via the Cascade if the connection was made via *Bluetooth*\* wireless technology.

The *Bluetooth*® word mark and logos are owned by the Bluetooth SIG, Inc. and any use of such marks by LG Electronics is under license.

Other trademarks and trade names are those of their respective owners.

	Телефон	Режим работы	Интернет
Россия	8-800-200-7676	16.	
Беларусь	8-820-0071-1111	Круглосуточно	
Латвия	8-0200-201		
Литва	8-800-08-081	9:00 - 17:00 (ПнПт.)	
Эстония	800-9990		
Україна	0-800-303-000	8:00 - 21:00 (ПонП'ят) 8:30 - 18:30 (Суб., Нд.)	http://www.lg.com
Казахстан	8-8000-805-805	9:00-20:00 (ПнПят.) 9:00-18:00 (Суб., Вс.)	nup://www.ig.com
	2255 (GSM)		
Узбекистан	8 800 120 2222	9:00 - 18:30 (Пн Пят.) 9:00 - 15:00 (Суб., Вс.)	
Кыргызстан	800 0071 0005	Круглосуточно	
Молдова	00-800-0071-0005 (Только для стационарных телефонов)	Круглосуточно	





Символ «не для пищевой продукции» применяется в соответствие с техническим регламентом Таможенного союза «О безопасности упаковки» 005/2011 и указывает на то, что упаковка данного продукта не предназначена для повторного использования и подлежит утилизации. Упаковку данного продукта запрещается использовать для хранения пищевой продукции.

Символ Кедендік одақтың 005/2011 техникалық регламентіне сәйкес қолданылады және осы өнімнің қаптамасын екінші рет пайдалануға арналмағанын және жоюға жататынын көрсетеді. Осы өнімнің қаптамасын азық-түлік өнімдерін сақтау үшін пайдалануға тыйым салынады.



Символ «петля Мебиуса» указывает на возможность утилизации упаковки. Символ может быть дополнен обозначением материала упаковки в виде цифрового и/или буквенного обозначения. Символ қаптаманы жою мүмкіндігін көрсетеді. Символ сандық код және/немесе әріп белгілері түріндегі қаптама материалының белгісімен толықтырылуы мүмкін.

#### Российская Федерация

Импортер ООО "ЛГ Электроникс Рус"

Адрес импортера: 143160 Российская Федерация, Московская область, Рузский район, сельское поселение Дороховское,

86 км. Минского шоссе, д.9

Адрес производителя: ЛГ ЭЛЕКТРОНИКС (ХУЖОУ) ИНК., ЗАВОД ХАТАИ ЛГ Электроникс (Хужоу) Инк., завод Хатаи 516006,

Китай, пров. ГуанДонг, г. Хужоу, Промышленная зона Жонгкай, Индустриальный парк Хутаи,

ХуФенг Донг Уи Роуд, 13.

Сделано в Китае

#### Україна

Найменування та адреса імпортера ПІІ «ЛГ ЕЛЕКТРОНІКС Україна» вул. Басейна, 6, м. Київ, 01004, Тел 044 201-43-50

#### Қазақстан Республикасы

Импорттаушы АҚ "ЭЛ Джи Электроникс Алматы Қазақстан", 050061, Алматы қ., к. Көкорай, 2А

Өндірушінің мекенжайы: LG Electronics(Huizhou) Inc. Huitai Factory 516006, Қытай, ГуанДонг ауданы, Хужоу қаласы, Жонгкай өнеркәсіптік аймағы, Хутай Индустриялық саябағы, ХуФенг Донг Уи Роуд, 13.

Қазақстан Республикасы территориясында тұтынушылардан келіп түскен талаптар мен ұсыныстарды қарайтын және тауарды жөндеу мен техникалық қызмет көрсететін ұжым:

АҚ «Эл Джи Электроникс Алматы Казахстан», 050061, Қазақстан Республикасы, Алматы қ., Көкорай, 2А. Басқа сервис орталықтары жайында мағлұматты "Тұтынушыға қызмет көрсету орталығына" телефон шалу арқылы білуге болады.