

INSTALLATION MANUAL

LG Digital Signage (MONITOR SIGNAGE)

Please read this manual carefully before operating your set and retain it for future reference.

60UL3E
70UL3E

www.lg.com

Table of contents

3 Location and Function of Controls

- 3 Parts and Button
- 3 Basic functions

4 First Use Wizard

- 4 Language & Location

5 Installation Menu

- 5 Introduction
- 6 Public Display Settings
 - 6 - Public Display Settings
 - 6 - Power On Status
 - 7 - Volume
 - 7 - Key Management
 - 8 - Limited Mode
 - 9 - Power On Default
 - 9 - Aux Source Setting
 - 9 - Power Management
 - 9 - Factory Reset
- 10 Network
 - 10 - MAC Address
 - 10 - Network Setting
 - 11 - Wake On LAN
 - 11 - Server Setting
- 12 General
 - 12 - Configuration Setup
 - 14 - Set ID Setup
 - 14 - Power Saving
 - 15 - HCEC Setup
 - 16 - Clock Setup
 - 16 - Password Change
 - 16 - Lock Mode
 - 16 - Crestron
- 17 Signage Manager
- 24 - USB Download Menu

25 KEY CODES

26 EXTERNAL CONTROL DEVICE SETUP

- 26 RS-232C Setup
- 26 USB to Serial converter with USB Cable
- 26 RS-232C with RS-232C Cable
- 27 Set ID
- 28 Communication Parameters
- 28 Command reference list

29 TRANSMISSION / RECEIVING PROTOCOL

Location and Function of Controls

Parts and Button



Basic functions

	Power On (Press)
	Power Off ¹ (Press and Hold)
	Menu Control (Press ²)
	Menu Selection (Press and Hold ³)

- 1 All running apps will close.
- 2 You can access and adjust the menu by pressing the button when Signage is on.
- 3 You can use the function when you access menu control.


First Use Wizard

* Image shown may differ from your Signage.

Language & Location

(Depending upon model)

- Select the **Language** and **Country**. Some countries need to select the Time Zone.



LANGUAGE & LOCATION

Confirm your language and location settings.

Language ▾
English

Country ▾
United States

Timezone ▾
New York

EXIT


Installation Menu

* Image shown may differ from your Signage.

Introduction


The abundant functions for Signage linked with software installation can be projected on OSD as 'Installation Menu'.

The wide range of features can be performed simply on additional window to enhance the Signage's easy installation and convenient operation for System Integrators.



- 1 Press the Setting button for more than 5 seconds using the user remote control, banner will appear at top left on the screen.
- 2 Enter a four digit password and press **OK** button.
 - The initial password "1-1-0-5".

Public Display Settings



When 'Public Display Settings' is set to On (Work), all functions of Public Display Mode apply.

Public Display Settings

- Decide to work all functions of 'Public Display Settings' or not by setting 'Public Display Settings' as On (Work) or Off (Do Not Work).
- When 'Public Display Settings' is set to On (Work), all functions of Public Display Mode apply.
- When 'Public Display Settings' is set to Off (Do Not Work), all functions of Public Display Mode Do Not apply.
- When it is set to 'On', all items reserved at the Schedule list are deleted and the reservation function is not supported. (applied for the model offering the reservation function)

Power On Status

- Decide to select working status of Signage Set when turn on main power.
- You can set with PWR, STD, LST.
- PWR always make Signage set On status when turn on main power.
- STD make Stand-by status when turn on main power.
- LST make Signage Set work like previous power status. As same concept as Power Backup mode; If main power were turned off in Power On status, Signage Set would work in On status. If main power were turned off in Stand-by status, Signage Set would work in Stand-by status.
- If there Block All is both IR Operation and Local Key Operation from Key Management, In order to provide the Option that must be able to turn on the Signage in the Signage turned off situation, change the value of the PWR. (Reference the Key Management)

Volume

- Decide to apply volume policy of 'Start Volume', 'Maximum Volume' and 'Minimum Volume' as On (Work) or Off (Do Not Work).
- $(0 \leq \text{Min} \leq \text{Start} \leq \text{Max} \leq 100)$

Start Volume

- This entry sets the start volume level when is power on.
 - The level is specified as a number between minimum volume to maximum value. ($\text{Min} \leq \text{Start} \leq \text{Max}$)
 - The default setting is 'Off' (disabled).
 - When enabled, if the value is lower than the minimum specified in the minimum volume entry, the minimum volume entry must be used.
 - When enabled, if the value is larger than the maximum specified in the maximum volume entry, the maximum volume value must be used.

Maximum Volume

- This entry sets the maximum volume level the set. The level is specified as a number between 'Minimum Volume' to 100. ($\text{Min} \leq \text{Max} \leq 100$).
 - If the command volume up to higher than maximum volume' is received, that should be ignored.
 - The default value is 100.

Minimum Volume

- This entry sets the minimum volume level the set will produce.
 - The level is specified as a number between 0 to 'Maximum Volume'. ($0 \leq \text{Min} \leq \text{Max}$)
 - If the command volume down to lower than minimum volume is received, that should be ignored.
 - The default value is 0.

Key Management

- Manage key usability of Local(Front) Key and Remote Control. When selected to 'On', following 'IR Operation' and 'Local Key Operation' will be worked by below.

IR Operation

- Decide whether work the LG remote control or not.
 - When 'IR Operation' is set to 'Normal', all remote keys are available.
 - 'Use PWR Only' makes block all remote keys except power key.
 - When 'IR Operation' is set to 'Block All', all normal remote keys don't work.

Local Key Operation

- Decide to operate 'Local/Front Key' working behavior by setting 'Local Key Operation' as 'Normal', 'Use PWR Only' and 'Block All'.
 - When 'Local Key Operation' is set to 'Normal', all local keys are available.
 - 'Use PWR Only' makes block all local keys except power key.
 - When 'Local Key Operation' is set to 'Block All', all local keys don't work.

Limited Mode

- Configure Signage function's limitation. When selected to 'On', following sub-menus will be worked by below.

Menu Display

- Function to decide whether work with menu (including relevant menus too) of control key (On – Enter possible) or not (Off – Enter Impossible).
 - Although select Off (Enter impossible), the action that press a Menu button for 5 seconds to enter 'Installation Menu' is available.
 - When select On (Enter possible), Menu works.

OSD Display

- Decide to display OSD or not by setting 'OSD Display' as On (Display) or Off (Do not Display).
 - When 'OSD Display' is set to 'Off' (Do not Display), all OSD is not displayed except some exception.
 - Although select 'Off' (Do not Display), the action that press a Menu button for 5 seconds to enter 'Installation Menu' and entering service menu are available. (In-Start, Power-Only, Adjust, Installation Menu...)

System Provider Mode

- 'System Provider Mode' allows access to the menu system from the front panel or remote control but access is controlled as follows:
 - When value is 'On', Accessible Items on the menu system, others are not permissible. (Depending upon model)
 - » Input select screens
 - » Sleep timer
 - » Aspect Ratio
 - » 'Photo & Video' / Music' / 'Network' / 'Bluetooth' Menu.
 - » Input Manager

Power On Default

- Set to On (Work) or Off (Do Not Work).
- When 'Power On Default' is set to Off, it is not applied to the subordinate Input, A/V Setting, Aspect Ratio menu.
- When Power On Default is set to On, it can set by entering the subordinate menu.

Input

- Set whether it is turned on by the set input source or by the last stored input source.

A/V Setting

- If 'A/V Setting' is changed from 'Off' to 'On', A/V parameters that are set before entering 'Installation Menu' are applied whenever turn on power.

Aspect Ratio

- The aspect ratio determines the default aspect ratio that the set returns to on power up.

Aux Source Setting

- Set to On (Work) or Off (Do Not Work).
- The Auxiliary (Input) Source Setting feature will enable or disable for each external input.
- User cannot disable the current input's 'Aux Source Setting'.


Power Management

- The Power Management feature will turn off the Signage if no input control command is received from either the Local or IR Key within selected hours.
 - Activity on either of these inputs shall reset the 'Power Management' timer and prevent interruption of Signage viewing.
 - This entry can be set to a value which is corresponding to the desired hours (1 hour to 7 hours).
 - Default value is 'Off (disabled)'.

Factory Reset

- Change all settings to their default values.

Network



MAC Address

- Displays the MAC address (not customizable).

Network Setting

One-click network connection

- Connects easily to a wired network.
- This menu supports to connect to an available network.

To connect to a network through Set Expert

- For use in special circumstances such as in offices (in cases where a static IP is used).
 - 1 Select a network connection.
 - 2 When connecting via Wired, Configures the IP settings of the Signage set. You can set the IP address, subnet mask, gateway and DNS server.

Wake On LAN

- Sets the Wake On LAN function to Enable or Disable.
 - The Wake On LAN feature enables the Signage to receive software updates and/or be powered ON upon receipt of Wake Up Frame packets and/or Magic Packet data via the wired LAN. To facilitate use of this feature, note that the appropriate wired connection must be made. ('Wake up Frame' - Depending upon model)

Server Setting

(Depending upon model)

- Sets the information to connect to the external server.


CMS Server

- Sets the network information to connect to SuperSign CMS. (or other compatible solutions)

Control Server

- Sets the network information to connect to SuperSign Control. (or other compatible solutions)

General



Configuration Setup

On Timer Operation

- It is a mode to select 'Timer Power On' working one time or repeatedly.
- 'Once': 'Timer Power On' in the user menu operates only one time when the **Timer Power On** menu is set to **On**.
- 'Repeat': 'Timer Power On' operates repeatedly when the **Timer Power On** menu is set to **On**.

USB Auto Playback

(Depending upon model)

- When 'USB Auto Playback' is set to 'Movie', Signage finds and plays the USB's movie files located at the root(top) directory Movies if USB is plugged in.
- When 'USB Auto Playback' is set to 'Photo', Signage finds and plays the USB's photo files located at the root(top) directory Photos if USB is plugged in.
- If it reaches the last file, it starts the first file again.

15Min Auto Off

(Depending upon model)

- When '15Min Auto Off' is set to 'Enable', TV will turn off if there is no signal in 15Min.

Auto Sensing

- If 'Auto Sensing' is set to 'On', the input is automatically switched when the input signal that you set to "ON" is received.
- If 'Auto Sensing' is set to 'Disable', the input is not switched when the input signal is received.
 - SIMPLINK and Auto Sensing cannot work simultaneously. If SIMPLINK is set to On, Auto Sensing is automatically set to Disable.
 - If the signal is removed while Auto Sensing (automatic input switch) is enabled, the input returns to the previous setting.
If the several input are connected by enabling Auto Sensing and the automatic input returns to the previous setting.
If the several inputs are connected by enabling Auto Sensing and the automatic input switch is performed several times, the input returns to the previous setting only for the last input and does not repeat the operation for the rest.

DPM

(Depending upon model)

- You can configure the DPM (Display Power Management) function.
- If this option is not set to Off, the Signage set enters the DPM mode when there is no input signal.
- If you set this option to Off, the DPM function is disabled.

Sustain Aspect Ratio

(Depending upon model)

- Sustain Aspect Ratio sets the power mode of the HDMI Switching IC, which detects HDMI external input signals in the Signage Standby state after DPM Power Off turns off the Signage.
- If Sustain Aspect Ratio is set to ON, the HDMI Switching IC is supplied with power even in Standby state after DPM turns off the Signage.
- If Sustain Aspect Ratio is set to OFF, the HDMI Switching IC maintains low power mode in Standby state after DPM turns off the Signage.

Screen Saver

- When the currently displayed app has not received any user input for an hour, it will be replaced by a Screen Saver.
- If you turn this option 'Off', the current picture may create an afterimage burned onto your screen, possibly permanently.

Set ID Setup

Set ID Lock

- Set the 'Set ID' item in **GENERAL** Menu whether to activate or not.
- Set to On (Work) or Off (Do Not Work).

Set ID

- Set the 'Set ID' of Signage Set with 1~99.

Power Saving

Static Saving

- It is the item for setting the level to reduce the backlight control from the items for saving the consuming power, which is increased or decreased by 10 steps from 0 to 100. 100 makes the consuming power set to the same one from the Signage. 0 reduces the consuming power to the minimum. The default value is 100.
 - The value displayed at the OSD is not changed and only the actual setting value is converted to percentage based on the static saving value to set.
 - 0 ~ 30: HIGH, 40 ~ 60 : MID, 70 ~ 90 : LOW, 100 : OFF.

Keyless Off Hours

- Automatically Signage will be turned off if there is no key input for the preset time period.

HCEC Setup

CEC Mode

(Depending upon model)

- You will have 2 modes to choose [Default], [HCEC].
- If [Default] is selected, you can use SIMPLINK which is provided in LG Signage. Also you can enable and disable SIMPLINK through SIMPLINK MENU.

IR Decoding

- When 'IR Decoding' is set to 'Enable', the Signage decodes and changes it into a CEC Message and sends it to Command via the HDMI CEC Line. The default value is Disable.

Device ID

- Sets the ID of a device(Logical Address) connected to the CEC Line. You can choose 'All' and from '0 x 01' to '0 x 0E' (All, 0 x 01 ~ 0 x 0e).
- The default value is 'All'.

StandBy

- Set the sending and receiving scenario of OpStandBy(0 x 0c) command.
- This detailed scenario is described on the table below.

	Send	Receive
Send Only	O	X
Receive Only	X	O
All	O	O
Off	X	X

Clock Setup

Clock Source

- You can select 'Off', 'NTP', 'Admin'.
- NTP : Clock is synchronized using Network Time Protocol. It's only enabled when network cable is connected.
- Admin : It's automatically set to Admin when clock is updated by commercial protocols like TVLink-HCEC.
- Off : Clock is synchronized using any available clock source.
 - **Input** (Depending upon model)
 - » You can select 'Input' according to 'Clock Source'.
 - » Input is set to 'None', 'HCAP', 'Protocol', 'HTNG' automatically when Clock Source is 'Admin'.

Password Change

- To ensure more security, Password can be changed by installers' own design.
 - 1 Change password by using virtual keyboard.
 - 2 Input the password again for confirmation.

Lock Mode

- If 'Lock Mode' is 'Yes', the following features will be unavailable.

USB

- If it is set to 'Enable', USB devices do not work in relative features. (Exclude S/W update)

Factory Reset

- If it is set to 'Enable', User Menu ⇒ **General** ⇒ **Reset to Initial Settings** is disabled.


Crestron


(Depending upon model)

- This function enables synchronization with applications provided by Crestron.
- Server: This menu sets the server's IP address for the network connection with the server. (equipment provided by Crestron)
- Port (1024~65535): This menu sets the port for the network connection with the server. The default port number is 41794.
- IP ID (3-254): This menu sets a unique ID for synchronizing with the application.


Signage Manager

You can update files from USB to Signage through the Signage manager.






- Ez Download is a function that enables users to download the desired items all at once, such as EPK (software update file), TLL, Image, Micom.
 - Images and Software Update files should be copied into the folder named LG_DTV on the USB.
 - » TLL files should be copied to the root folder of the USB.
 - » If you press 'EZ Download' menu, EZ Download is launched.
 - » If ".DZM" file exist file will be selected previously download file.
- ⚠ • DZM file is created in USB after the download is complete.
 - If USB containing "DZM" is connected after Signage is turned on, Signage Manager will be automatically launched. Then, EZ Download is displayed and previously downloaded files are selected automatically.




- "Export Clone File" creates "TLL" file in USB root folder. "TLL" file can be used to "Import Clone File". While writing is in process, the user must not turn Signage off nor unplug the USB memory card. The following reference images might be slightly different.




- Once the internal Signage data is written to the USB memory card, the user can start "Import Clone File" process with the data file generated and stored in USB memory card. The user should not turn Signage off nor unplug the USB memory card while processing. The following reference images might be slightly different.

* Image shown may differ from your Signage.




- If there are more than two USB Memory Device, It is possible to select the USB.
- The download sequence is Image Download ⇒ Select Image(s) ⇒ Download.
- Image files should be in "LG_DTV" folder.
 - **Boot Logo Image**
 - » Boot Logo Image can download only one file.
 - » Boot Logo Image update function supports only JPG, JPEG, BMP format file of less than 8 MB file size.
 - » We recommend you that splash image resolution match the Signage's panel resolution.
 - » Max resolution of splash image : Full HD → 1920 x 1080, HD → 1360 x 768.
 - » Min resolution of splash image : 64 x 64.

► Update Signage Software



- This feature updates Signage software through the EPK file in USB.
- ".EPK" files should be in "LG_DTV" folder.
- The download sequence is Software Update ⇒ Update Signage Software ⇒ Select file(EPK) ⇒ UPDATE.

► Update Micom Software



- This feature updates Micom software through the txt file in USB.
- ".txt" files should be in "LG_DTV" folder.
- The download sequence is Software Update ⇒ Update Micom Software ⇒ Select file(txt) ⇒ UPDATE.

- An Installer can quickly set up and clone multiple Signage sets at a property. These cloned Signages will all have the same Master Signage Setup: Public Display Mode Installation Menu settings, User A/V settings. This newer procedure significantly decreases the installation time that would be necessary if the standard RS-232C method were used instead.

1 Overview USB Cloning Procedure

: Signage has the capability to support cloning internal Signage data with an external clone device called "USB Cloning", in order to copy Signage data accurately and quickly. The clone internal functions use a slightly different internal processes for the two types of signage. However, the UI of cloning feature remains the same in both. Regarding the demands over the current cloning feature for quicker cloning, better portability and etc., we would like to announce the cloning process via USB port, named as USB Cloning. USB cloning process is divided into 2 main processes. One is writing the previously saved Signage data into the Signage, and one another is reading of current Signage data into USB memory card. To avoid any confusion due to the words, it is clearly specified as "Import Clone File" and "Export Clone File" in the whole process.

2 Data To Be Cloned

: The data cloned are the same data cloned by previous USB Cloning. Details are explained in the following:

- Signage data includes :
 - A. Installer Menu settings
 - B. Main menu settings (Audio, Picture etc)

KEY CODES

- This feature is not available for all models.

Code (Hex)	Function	Note
08	 (POWER)	Remote control Button (Power On/Off)
C4	MONITOR ON	Remote control Button
C5	MONITOR OFF	Remote control Button
95	 ENERGY SAVING	Remote control Button
0B	INPUT 	Remote control Button
DC		Remote control Button
32	1/a/A	Remote control Button
10-19	Number Key 0-9 Alphabet buttons	Remote control Button
2F	CLEAR	Remote control Button
02		Remote control Button
03		Remote control Button
79	ARC	Remote control Button
99	AUTO	Remote control Button
09	MUTE 	Remote control Button
E0	Brightness (PAGE) 	Remote control Button
E1	Brightness (PAGE) 	Remote control Button
4D	PSM	Remote control Button
AA	INFO 	Remote control Button
5F	W.BAL	Remote control Button


Code (Hex)	Function	Note
43	SETTINGS	Remote control Button
3F	 S.MENU	Remote control Button
40		Remote control Button
41		Remote control Button
07		Remote control Button
06		Remote control Button
44	OK 	Remote control Button
28	 BACK	Remote control Button
5B	EXIT	Remote control Button
7E	 SIMPLINK	Remote control Button
7B	TILE	Remote control Button
72	PICTURE ID ON (Red)	Remote control Button
71	PICTURE ID OFF (Green)	Remote control Button
B1		Remote control Button
B0		Remote control Button
BA		Remote control Button
8F		Remote control Button
8E		Remote control Button
63	Yellow	Remote control Button
61	Blue	Remote control Button

- Key code 4C (0 x 4C) is available on ATSC/ISDB models which use major/minor channel. (For South Korea, Japan, North America, Latin America except Colombia models)

EXTERNAL CONTROL DEVICE SETUP

- * Image shown may differ from your signage.
- * Cable is not provided.
- * The connection interface may differ from your Signage.

RS-232C Setup




- Connect the USB to Serial converter/RS-232C input jack to an external control device (such as a computer or an A/V control system) to control the product's functions externally.
- Connect the serial port of the control device to the RS-232C jack on the product back panel.

! NOTE

- The type of control port on the signage can be different between model series.

USB to Serial converter with USB Cable


USB Type



- LG signage supports PL2303 chip-based (Vendor ID : 0 x 0557, Product ID : 0 x 2008) USB to serial converter which is not made nor provided by LG.
- It can be purchased from computer stores that carry accessories for IT support professionals.


RS-232C with RS-232C Cable

DE9 (D-Sub 9pin) Type



- You need to purchase the RS-232C (DE9, D-Sub 9 pin female-to-female type) to RS-232C cable required for the connection between the PC and the signage, which is specified in the manual.
- The connection interface may differ from your signage.

Connector type : D-Sub 9-pin male



RS-232C
(Serial port)

RS-232C configurations

7-Wire Configurations
(Standard RS-232C cable)

	PC	Signage
RXD	2 ● ————— ● 3	TXD
TXD	3 ● ————— ● 2	RXD
GND	5 ● ————— ● 5	GND
DTR	4 ● ————— ● 6	DTR
DSR	6 ● ————— ● 4	DSR
RTS	7 ● ————— ● 8	RTS
CTS	8 ● ————— ● 7	CTS
	D-Sub 9	D-Sub 9

3-Wire Configurations
(Not standard)

	PC	Signage	
RXD	2 ● ————— ● 3	TXD	TXD
TXD	3 ● ————— ● 2	RXD	RXD
GND	5 ● ————— ● 5	GND	GND
DTR	4	6	DTR
DSR	6	4	DSR
RTS	7	8	RTS
CTS	8	7	CTS
	D-Sub 9	D-Sub 9	

Set ID

For Set ID number, see “**Real data mapping (Hexadecimal : Decimal)**”.

Press **SETTINGS** to access the main menus.

Press the Navigation buttons to scroll to (* **[General]** ► **[Set ID]**) and press .

Scroll left or right to select a set ID number and select  **BACK**. The adjustment range is 1-99.

When you are finished, press **EXIT**.

Communication Parameters

- Baud rate : 9600 bps (UART)
- Data length : 8 bits
- Parity : None
- Stop bit : 1 bit
- Communication code : ASCII code
- Use a crossed (reverse) cable.

Command reference list

(Depending upon model)

	COMMAND1	COMMAND2	DATA (Hexadecimal)
1 Power	k	a	00 to 01
2 [Aspect Ratio]	k	c	(page 30)
3 Screen Mute	k	d	(page 30)
4 Volume Mute	k	e	00 to 01
5 Volume Control	k	f	00 to 64
6 [Contrast]	k	g	00 to 64
7 [Brightness]	k	h	00 to 64
8 [Color]	k	i	00 to 64
9 [Tint]	k	j	00 to 64
10 [Sharpness]	k	k	00 to 32
11 [OSD] Select	k	l	00 to 01
12 [Remote Control Lock Mode]	k	m	00 to 01
13 [Balance]	k	t	00 to 64
14 [Color Temperature]	x	u	00 to 64
15 [Equalizer]	j	v	(page 32)
16 [Energy Saving]	j	q	00 to 05
17 Auto Configuration	j	u	01
18 Key	m	c	Key Codes
19 Control Backlight	m	g	00 to 64
20 Input select	x	b	(page 32)

- During playing media, all commands except Power (ka) and Key (mc) are not executed and treated as NG. With RS232C cable, signage can communicate "ka command" in power-on or power-off status; but with USB-to-Serial converter cable, the command works only if signage is on.

TRANSMISSION / RECEIVING PROTOCOL

* (Depending upon Model)

Transmission

[Command1][Command2][][Set ID][][Data][Cr]

[Command 1] : First command to control the signage. (j, k, m or x)

[Command 2] : Second command to control the signage.

[Set ID] : You can adjust the set ID to choose desired signage ID number in option menu. Adjustment range is 1 to 99. When selecting Set ID '0', every connected set is controlled. Set ID is indicated as decimal (1 to 99) on menu and as Hexadecimal (0 x 0 to 0 x 63) on transmission/receiving protocol.

[Data] : To transmit command data (hexadecimal). Transmit 'FF' data to read status of command.

[Cr] : Carriage Return - ASCII code '0 x 0D'

[] : Space - ASCII code '0 x 20'

OK Acknowledgement

[Command2][][Set ID][][OK][Data][x]

* The set transmits ACK (acknowledgement) based on this format when receiving normal data. At this time, if the data is data read mode, it indicates present status data. If the data is data write mode, it returns the data of the PC computer.

Error Acknowledgement

[Command2][][Set ID][][NG][Data][x]

* The set transmits ACK (acknowledgement) based on this format when receiving abnormal data from non-viable functions or communication errors.

Data 00: Illegal Code

Real data mapping (Hexadecimal : Decimal)

* When you enter the [Data] in hexadecimal, refer to following conversion table.

00 : Step 0	32 : Step 50 (Set ID 50)	FE : Step 254
01 : Step 1 (Set ID 1)	33 : Step 51 (Set ID 51)	FF : Step 255
...	...	...
0A : Step 10 (Set ID 10)	63 : Step 99 (Set ID 99)	01 00 : Step 256
...	...	...
0F : Step 15 (Set ID 15)	C7 : Step 199	27 0E : Step 9998
10 : Step 16 (Set ID 16)	C8 : Step 200	27 0F : Step 9999
...	...	...

1 Power (Command: k a)

- To control power on or off of the set.

Transmission

[k][a][][Set ID][][Data][Cr]

Data 00 : [Off]

Data 01 : [On]

Ack

[a][][Set ID][][OK/NG][Data][x]

To show signage is power on or *Off

Transmission

[k][a][][Set ID][][FF][Cr]

Ack

[a][][Set ID][][OK/NG][Data][x]

- * Similarly, if other functions transmit 'FF' data based on this format, Acknowledgement feedback presents status about each function.
- * OK Ack., Error Ack. and other message may display on the screen when signage is power on.

2 [Aspect Ratio] (Command: k c) (Main Picture Size)

- To adjust the screen format. (Main picture format)
You can also adjust the screen format using the picture settings.

Transmission

[k][c][][Set ID][][Data][Cr]

Data 01 : [4:3] (Normal screen - Just Scan Off)

Data 02 : [16:9] (Wide screen - Just Scan Off)

Data 06 : [Original] (Just Scan Off)

Data 09 : [Just Scan]

Ack

[c][][Set ID][][OK/NG][Data][x]

- * Using the PC input, you select either 16:9 or 4:3 screen aspect ratio.
- * In DTV/HDMI/Component mode (high-definition), Just Scan is available.
- * Full wide mode may work differently based on model and is supported for DTV fully, and ATV, AV partially.

3 Screen Mute (Command: k d)

- To select screen mute on/off.

Transmission

[k][d][][Set ID][][Data][Cr]

Data 00 : Screen mute off (Picture on) / Video mute off

Data 01 : Screen mute on (Picture off)

Data 10 : Video mute on

Ack

[d][][Set ID][][OK/NG][Data][x]

- * In case of video mute on only, signage will display On Screen Display(OSD). But, in case of Screen mute on, signage will not display OSD.

4 Volume Mute (Command: k e)

- To control volume mute on/off. You can also adjust mute using the mute button on remote control.

Transmission

[k][e][][Set ID][][Data][Cr]

Data 00 : Volume mute on (Volume off)

Data 01 : Volume mute off (Volume on)

Ack

[e][][Set ID][][OK/NG][Data][x]

5 Volume Control (Command: k f)

- To adjust volume. You can also adjust volume with the volume buttons on remote control.

Transmission

[k][f][][Set ID][][Data][Cr]

Data Min : 00 to Max : 64

Ack

[f][][Set ID][][OK/NG][Data][x]

6 [Contrast] (Command: k g)

- To adjust screen contrast. You can also adjust contrast in the picture settings.

Transmission

[k][g][][Set ID][][Data][Cr]

Ack

[g][][Set ID][][OK/NG][Data][x]

7 [Brightness] (Command: k h)

- To adjust screen brightness. You can also adjust brightness in the picture settings.

Transmission

[k][h][][Set ID][][Data][Cr]

Data Min : 00 to Max : 64

Ack

[h][][Set ID][][OK/NG][Data][x]

8 [Color] (Command: k i)

- To adjust the screen color. You can also adjust colour in the picture settings.

Transmission

[k][i][][Set ID][][Data][Cr]

Data Min : 00 to Max : 64

Ack

[i][][Set ID][][OK/NG][Data][x]

9 [Tint] (Command: k j)

- To adjust the screen tint. You can also adjust colour in the picture settings.

Transmission

[k][j][][Set ID][][Data][Cr]

Data Red : 00 to Green : 64

Ack

[j][][Set ID][][OK/NG][Data][x]

10 [Sharpness] (Command: k k)

- To adjust the screen sharpness. You can also adjust sharpness in the picture settings.

Transmission

[k][k][][Set ID][][Data][Cr]

Data Min : 00 to Max : 32

Ack

[k][][Set ID][][OK/NG][Data][x]

11 OSD Select (Command: k l)

- To select OSD (On Screen Display) on/off when controlling remotely.

Transmission

[k][l][][Set ID][][Data][Cr]

Data 00 : [Off]

Data 01 : [On]

Ack

[l][][Set ID][][OK/NG][Data][x]

12 Remote Control Lock Mode (Command: k m)

- To lock the front panel controls on the signage and remote control.

Transmission

[k][m][][Set ID][][Data][Cr]

Data 00 : [Off]

Data 01 : [On]

Ack

[m][][Set ID][][OK/NG][Data][x]

* If you are not using the remote control, use this mode. When main power is off & on (plug-off and plug-in, after 20 - 30 seconds), external control lock is released.

* In the standby mode (DC off by off timer or 'ka', 'mc' command), and if key operation is on, signage will not turn on by power on key of IR & Local Key.

13 [Balance] (Command: k t)

- To adjust balance. You can also adjust balance in the audio settings.

Transmission

[k][t][][Set ID][][Data][Cr]

Data Min : 00 to Max : 64

Ack

[t][][Set ID][][OK/NG][Data][x]

14 [Color Temperature] (Command: x u)

- To adjust colour temperature. You can also adjust color temperature in the picture settings.

Transmission

[x][u][][Set ID][][Data][Cr]

Data Min : 00 to Max : 64

Ack


[u][][Set ID][][OK/NG][Data][x]

15 [Equalizer] (Command : j v)

- Adjust EQ of the set.

Transmission

[j][v][][Set ID][][Data][Cr]



7	6	5	Frequency	4	3	2	1	0	Step
0	0	0	1st Band	0	0	0	0	0	0(decimal)
0	0	1	2nd Band	0	0	0	0	1	1(decimal)
0	1	0	3rd Band	...	...	...	...	...	...
0	1	1	4th Band	1	0	0	1	1	19(decimal)
1	0	0	5th Band	1	0	1	0	0	20(decimal)

Ack

[v][][Set ID][][OK/NG][Data][x]

- * It depends on model, and can adjust when sound mode is EQ adjustable value.

16 [Energy Saving] (Command: j q)

(Depending upon model)

- To reduce the power consumption of the signage.
You can also adjust energy saving in picture settings.

Transmission

[j][q][][Set ID][][Data][Cr]

Data 00 : [Off]
Data 01 : [Minimum]
Data 02 : [Medium]
Data 03 : [Maximum]
Data 04 : [Auto]
Data 05 : [Screen off]

Ack

[q][][Set ID][][OK/NG][Data][x]

17 Auto Configuration (Command: j u) (Only RGB support model)

- To adjust picture position and minimize image shaking automatically. It works only in RGB (PC) mode.

Transmission

[j][u][][Set ID][][Data][Cr]

Data 01 : To set

Ack

[u][][Set ID][][OK/NG][Data][x]

18 Key (Command: m c)

- To send IR remote key code.

Transmission

[m][c][][Set ID][][Data][Cr]

Data : Key code - page 25

Ack

[c][][Set ID][][OK/NG][Data][x]

19 Control Backlight (Command: m g)

- To control the backlight.

Transmission

[m][g][][Set ID][][Data][Cr]

Data Min : 00 to Max : 64

Ack

[g][][Set ID][][OK/NG][Data][x]

20 Input select (Command: x b) (Main Picture Input)

- To select input source for main picture.

Transmission

[x][b][][Set ID][][Data][Cr]

Data 90 : HDMI1

Data 91 : HDMI2

Ack

[b][][Set ID][][OK/NG][Data][x]

- * This function depends on model and signal.

