



Colour Television

OWNER'S MANUAL

Please read this manual carefully before operating your set.

Retain it for future reference.

Record model number and serial number of the set.

See the label attached on the back cover and quote this information to your dealer when you require service.

Model number : _____

Serial number : _____

Contents

Installation	2	Audio adjustment	13
Connection of external equipment.....	3	Time setting	15
Location and function of controls	4	Option functions	15
Basic operation.....	8	Teletext (option)	17
On screen menus	8	Troubleshooting check list	19
Setting up TV stations	9		
Picture adjustment	12		

Installation

Power

This set operates on an AC mains supply, the voltage is as indicated on the label on the back cover. Never apply DC power to the set. In the event of thunderstorms or powercuts, please pull out the aerial and mains plugs.

Press the **POWER** button on the front panel or side panel to turn off the TV when the TV set is not being used for a long time. It is recommended to remove the plug from the wall outlet(Power point).

Disconnecting device from mains

Mains plug is the disconnecting device. The plug must remain readily operable

Warning

To prevent fire or shock hazard, do not expose the set to rain or moisture.

Do not place anything containing liquid on top of the set, this may cause a fire or could give an electric shock.

Service

Never remove the back cover of the set as this can expose you to very high voltage and other hazards. If the set does not operate properly, unplug it and call your dealer.

Aerial

Connect the aerial cable to the socket on the back cover. For the best reception an outdoor aerial should be used.

Location

Position your set so that no bright light or sunlight falls directly onto the screen. Care should be taken not to expose the set to any unnecessary vibration, moisture, dust or heat. Also ensure that the set is placed in a position to allow a free flow of air. Do not cover the ventilation openings on the back cover.

Connection of external equipment

You can connect additional equipment, such as VCRs, camcorders etc. to your set. What is shown here may be somewhat different from your set.

Aerial socket

1. Connect the RF out socket of the VCR to the aerial socket on the back of the set.
2. Connect the aerial cable to the RF aerial in socket of the VCR.
3. Store the VCR channel on the programme number 0 using the 'Manual programme tuning' section.
4. Select the programme number where the VCR channel is stored.
5. Press the **PLAY** button on the VCR.

Audio/Video in/out sockets (option)

1. Connect the audio/video out sockets of the VCR to audio/video in sockets of the set.
2. If the VCR is connected to the AV sockets on the set, press the **TV/AV** button to select **AV1, AV 2, or AV3**.
3. Press the **PLAY** button on the VCR. The VCR playback picture appears on the screen.

You can also record programmes received by the TV on video tape via audio/video out sockets.

Note :

If you have a mono VCR, connect the audio cable from the VCR to the **AUDIO L/MONO** socket of the set.

Euro scart socket(option)

1. Connect the Euro scart socket of the VCR to the Euro scart socket of the set.
2. Press the **PLAY** button on the VCR. If your VCR outputs a switching voltage when connected to Euro scart socket, the set will switch to **AV1** mode automatically. But if you want to keep on watching TV mode, press the **TV/AV** button to select TV.

Otherwise press the **TV/AV** button on the remote control handset to select **AV1**. The VCR playback picture appears on the screen. You can also record programmes received by the TV on video tape.

Note : Signal type **RGB**, i.e. the signals red, green

and blue can only be selected for the Euro scart socket. These signals are transmitted, for example, by a pay TV decoder, game machine or photo CD unit, etc.

Component in sockets (option)

1. Connect the COMPONENT video output sockets (Y Cb Cr, Y Pb Pr or Y B-Y R-Y) of the **COMPONENT** (480i/480p/576i/576p/720p/1080i/1080p) to the COMPONENT INPUT sockets (Y P_B P_R) on the set.
2. Connect the audio cable from the **COMPONENT** (480i/480p/576i/576p/720p/1080i/1080p) to **AUDIO IN** sockets of **COMPONENT**.
3. Press the **TV/AV** button to select **COMPONENT**.
4. Press the **PLAY** button on the **COMPONENT**. The **COMPONENT** playback picture appears on the screen.

HDMI (option)

1. Connect the HDMI output of the DVD or the digital set-top box to the HDMI jack on the set.
2. Press the **TV/AV** button to select **HDMI**.
3. Turn on the DVD or the digital set-top box. (Refer to the owner's manual for the DVD or the digital set-top box.)

Note :


- a. TV can receive the video and audio signal simultaneously with using a HDMI cable.
- b. If the digital set-top box supports Auto HDMI function, the output resolution of the source device will be automatically set to 1920x1080i.
- c. If the digital set-top box player does not support Auto HDMI function, you need to set the output resolution appropriately. To get the best picture quality, adjust the output resolution of the source device to 1920x1080i.
- d. The HDMI cable is not supplied with the set.

Location and function of controls

All the functions can be controlled with the remote control handset. Some functions can also be adjusted with the buttons on the front panel of the set.

Remote control handset

Before you use the remote control handset, please install the batteries. See the next page.



(With TELETEXT)

1. **POWER**
switches the set on from standby or off to standby.
2. **NUMBER BUTTONS**
Switches the set on from standby or directly select a number.
3. **ARC (Aspect Ratio Control)**
changes the picture format.
4. **TURBO PICTURE / SOUND BUTTON (option)**
selects Turbo picture/sound.
5. **▲ / ▼ (Programme Up/Down)**
selects a programme or a menu item.
switches the set on from standby.
6. **REW, PLAY, FF**
adjusts the volume.
7. **FAVOURITE**
adjusts menu settings.
8. **STOP**
OK
accepts your selection or displays the current mode.
9. **REC**
10. **I/II**
selects the language during dual language broadcast.
selects the sound output (option).
11. **SSM**
12. **LIST**
13. **PSM (Picture Status Memory)**
recalls your preferred picture setting.
14. **SLEEP**
sets the sleep timer.
15. **MAIN STILL/***
freezes motion of the picture.
16. **INDEX/***
17. **Q.VIEW**
18. **TEXT**
19. **MIXED, TIME, REVEAL, MODE, SIZE, STILL, UPDATE, *.**
20. **MUTE**
switches the sound on or off.
21. **TV/AV**
selects TV or AV mode.
switches the set on from standby.

Location and function of controls

14. MENU

selects a menu.

15. LIST

displays the programme table.

16. SSM (Sound Status Memory)

recalls your preferred sound setting.

17. EYE/* (option)

switches the eye function on or off.

18. Q.VIEW

returns to the previously viewed programme.

19. INDEX/* (option)

switches FRONT DISPLAY on or off.

20. FAVOURITE


selects a favourite programme.

* : No function


COLOURED BUTTONS : These buttons are used for teletext (only TELETEXT models) or programme edit.

Battery installation

The remote control handset is powered by two AA type batteries. To load the batteries, turn the remote control handset over and open the battery compartment. Install two batteries as indicated by the polarity symbols (+ and -) marked inside the compartment.



Note : To avoid damage from possible battery leakage, remove the batteries if you do not plan to use the remote control handset for an extended period of time.




(Without TELETEXT)


Location and function of controls

Front panel


29FS2 series




29FX6 series




29FS4 series




29FX5 series




29FX4 series




29FS6 series




29FC2 series



29FS7 series




29FA5 series




Location and function of controls


29FB5 series




29FC1 series



29Q9 series




29FG1/2 series




29FU1 series



29FU3 series



Side panel



1. **MAIN POWER (ON/OFF)**
switches the set on or off.

2. **POWER/STANDBY INDICATOR**
illuminates brightly when the set is in standby mode.
dims when the set is switched on.

3. **MENU**
selects a menu.

4. **OK**
accepts your selection or displays the current mode.
◀ / ▶ (Volume Down/Up)
adjusts the volume.
▲ / ▼ (Programme Up/Down)
adjusts menu settings.
selects a programme or a menu item.
switches the set on from standby.

5. **REMOTE CONTROL SENSOR**
Note : Only use the supplied remote control handset. (When you use others, they will not be able to function.)

6. **AUDIO/VIDEO IN SOCKETS (AV IN3) (option)**
Connect the audio/video out sockets of external equipment to these sockets.
S-VIDEO/AUDIO IN SOCKETS (S-AV)
Connect the video out socket of an S-VIDEO VCR to the **S-VIDEO** socket.
Connect the audio out sockets of the S-VIDEO VCR to the audio sockets as in **AV IN3** (option).

7. **TURBO SOUND / PICTURE (option)**
switches Turbo sound or Turbo picture function on or off.

Basic operation

On and off

1. Press the main power button to switch the set on.
2. If the set is in standby mode, press the **POWER**, **▲ / ▼**, **TV/AV** or **NUMBER** buttons on the remote control handset to switch it on fully.
3. Press the **POWER** button on the remote control handset.
The set reverts to standby mode.
4. Press the main power button again to switch the set off.

Note : If, while the set is switched on, the mains plug is disconnected the set will switch to standby or power on when the mains plug is replaced in the mains power socket.

Programme selection

You can select a programme number with the **▲ / ▼** or **NUMBER** buttons.

Volume adjustment

Press the **◀ / ▶** button to adjust the volume.

Q.VIEW

Press the **Q.View** button to view the last programme you were watching.

Mute function

Press the **MUTE** button. The sound is switched off and the display **---** appears.
You can cancel it by pressing the **MUTE**, **◀ / ▶**, **SSM,I/II** button.

On screen language selection (option)

The menu can be displayed on the screen in desired language. First select your language.

1. Press the **MENU** button and then **▲ / ▼** button to select the Option menu.
2. Press the **▶** button to select **Language**.
3. Press the **▶** button and then **▲ / ▼** button to select your desired language.
All the on screen displays will appear in the selected language.
Press the **OK** or **◀** button to select the Option menu.
4. Repeatedly press the **MENU** button to return to normal TV viewing.

On screen menus

The dialogue between you and your set takes place on screen with an operator menu. The buttons required for the operating steps are also displayed.

Menu selection

1. Press the **MENU** button and then **▲ / ▼** button to display each menu.
2. Press the **▶** button and then **▲ / ▼** button to select a menu item.
3. Press the **▶** button to display the sub menu or the pull-down menu.
4. Change the setting of an item in the sub or pull-down menu with the **◀ / ▶** or **▲ / ▼**.
You can move to the higher level menu with the **OK** or **◀** button and to move to the lower level menu press the **▶** button.

Note :

- a. In the teletext mode, menus are not displayed.
- b. In some models, the **Normal search** will not display, only the **Start** will display in the **Auto programme** menu.

Setting up TV stations

Up to 100 TV stations can be stored by programme numbers (0 to 99). Once you have preset the stations, you will be able to use the **▲** / **▼** or **NUMBER** buttons to scan the stations you programmed. Stations can be tuned using automatic or manual modes.

Note : In some models up to 200 TV stations can be stored.

Auto programme tuning

All stations that can be received are stored by this method. It is recommended that you use auto programme during installation of this set.

1. Press the **MENU** button to select the Set up menu.
2. Press the **►** button and then **▲** / **▼** button to select **Auto Tuning**.
3. Press the **►** button to display the **Auto Tuning** menu.



4. Press the **►** button. Select a TV system with the **▲** / **▼** button on the **System** pull-down menu;
BG : (Asia/New Zealand/M.East/Africa/Australia)
I : (Hong Kong/South Africa)
DK : (East Europe/China/Africa/CIS)
M : (USA/Korea/Philippines) (option)
5. Press the **◀** button.
6. Press the **▲** / **▼** button to select **Storage from**.
7. Press the **►** button. Select the beginning programme number with the **◀** / **►** button or **NUMBER** buttons on the **Storage from** pull-down menu. Any number under 10 is entered with a numeric '0' (or '00') in front of it, i.e. '05' (or '005') for 5.
8. Press the **OK** button.
9. Press the **▲** / **▼** button to select **search**.

Option: In some models, you can only select **To Start**.

Note :

If the programmed station has poor quality and sound, select the system again in the **Manual Tuning** menu.

10. Press the **►** button to begin auto tuning. All receivable stations are stored. The station name is stored for stations which broadcast VPS (Video Programme Service), PDC (Programme Delivery Control) or TELETEXT data. If no station name can be assigned to a station, the channel number is assigned and stored as **C** (VHF/UHF 01-69) or **S** (Cable 01-47), followed by a number.

To stop auto tuning, press the **MENU** button.

When auto tuning is completed, the **Programme edit** menu appears on the screen. See the 'Programme edit' section to edit the stored programme.

11. Repeatedly press the **MENU** button to return to normal TV viewing.

Manual tuning

Manual Tuning lets you manually tune and arrange the stations in whatever order you desire. Also you can assign a station name with five characters to each programme number.

1. Press the **MENU** button to select the Set up menu.
2. Press the **►** button and then **▲** / **▼** button to select **Manual Tuning**.
3. Press the **►** button to display the **Manual Tuning** menu.
4. Press the **▲** / **▼** button to select **Storage**.
5. Press the **►** button to select the programme number. Select the desired programme number (0 to 99) with the **◀** / **►** button or **NUMBER** buttons on the **Storage** pull-down menu. Any number under 10 is entered with a numeric '0' (or '00') in front of it, i.e. '05' (or '005') for 5.
6. Press the **OK** button.
7. Press the **▲** / **▼** button to select **System**.
8. Press the **►** button. Select a TV system with the **▲** / **▼** button on the **System** pull-down menu;
BG : (Asia/New Zealand/M.East/Africa/Australia)
I : (Hong Kong/South Africa)
DK : (East Europe/China/Africa/CIS)
M : (USA/Korea/Philippines) (option)
9. Press the **OK** or **◀** button.
10. Press the **▲** / **▼** button to select **Band**.
11. Press the **►** button. Press the **▲** / **▼** button to select **VHF/UHF** or **Cable** on the **Band** pull-down menu.
12. Press the **▲** / **▼** button to select **Channel**. If possible, select the channel number directly with the number buttons. Any number under 10 is entered with a numeric '0' (or '00') in front of it, i.e. '05' (or '005') for 5.
13. Press the **OK** or **◀** button.
14. Press the **▲** / **▼** button to select **Search**.
15. Press the **►** button. Press the **◀** / **►** button to commence searching on the **Search** pull-down menu. If a station is found the search will stop.
16. Press the **OK** button to store it. The display **Stored** will appear.
17. To store another station, repeat steps 4 to 15.
18. Repeatedly press the **MENU** button to return to normal TV viewing.

Setting up TV stations

Fine tuning

Normally fine tuning is only necessary if reception is poor.

1. Repeat the 'Manual Tuning' steps 1 to 3.
2. Press the **▲ / ▼** button to select **Fine**.
3. Press the **►** button.
4. Press the **◀ / ▶** button to fine tune for the best picture and sound on the **Fine** pull-down menu.
5. Press the **OK** button.
6. Repeatedly press the **MENU** button to return to normal TV viewing.

The finely tuned programme will be indicated by yellow number during programme selection.

Assigning a station name

1. Repeat the 'Manual Tuning' steps 1 to 3.
2. Press the **▲ / ▼** button to select **Name**.
3. Press the **►** button on the **Name** pull-down menu.



4. Press the **▲** button. You can use a blank, +, -, the numeric **0** to **9** and the alphabet **A** to **Z**. With the **▼** button you can select in the opposite direction.
5. Select the position by pressing the **◀ / ▶** button and then take your choice of the second character, and so on.
6. Press the **OK** button.
7. Repeatedly press the **MENU** button to return to normal TV viewing.

Programme Edit


This function enables you to delete or skip the stored programmes. You can also move some stations to other programme numbers or insert a blank station data into the selected programme number.

1. Press the **MENU** button to select the Set up menu.
2. Press the **►** button and then **▲ / ▼** button to select **Programme Edit**.
3. Press the **►** button to display the **Programme Edit** menu.

Deleting a programme

1. Select a programme to be deleted with the **▲ / ▼** or **◀ / ▶** button.
2. Press the **RED** button twice.

The selected programme is deleted, all the following programmes are shifted up one position.



Copying a programme

1. Select a programme to be copied with the **▲ / ▼** or **◀ / ▶** button.
2. Press the **GREEN** button.

All the following programmes are shifted down one position.

Moving a programme

1. Select a programme to be moved with the **▲ / ▼** or **◀ / ▶** button.
2. Press the **YELLOW** button.
3. Move the programme to the desired programme number with the **▲ / ▼** or **◀ / ▶** button.
4. Press the **YELLOW** button again to release this function.

Skipping a programme number

1. Select a programme number to be skipped with the **▲ / ▼** or **◀ / ▶** button.
2. Press the **BLUE** button. The skipped programme turns to blue.
3. Press the **BLUE** button again to release the skipped programme. When a programme number is skipped it means that you will be unable to select it using the **▲ / ▼** button during normal TV viewing. If you want to select the skipped programme, directly enter the programme number with the **NUMBER** buttons or select it in the programme edit or table menu.

Repeatedly press the **MENU** button to return to normal TV viewing.

Setting up TV stations

Favourite programme

This function lets you select your favourite programmes directly.

1. Press the **MENU** button to select the Set up menu.
2. Press the **►** button and then **▲** / **▼** button to select **Favourite Programme**.
3. Press the **►** button to display the **Favourite Programme** menu.



4. Press the **▲** / **▼** button to select -- -----.
5. Select a desired programme with the **◀** / **►** button or **NUMBER** buttons. Any number under 10 is entered with a numeric '0'(or '00') in front of it, i.e. '05'(or 005) for 5.
6. To store another programme, repeat steps 4 and 5.

You can store up to 8 programmes.

7. Press the **OK** button.
8. Repeatedly press the **MENU** button to return to normal TV viewing.

Repeatedly press the **FAVOURITE** button to select stored favourite programmes.

Calling the programme List

You can check the programmes stored in the memory by displaying the programme list.

Displaying programme list

Press the **LIST** button to display the **Programme list** menu.

The programme table appears on the screen. One programme table contains ten programmes as below.

Note :

- a. You may find some blue programmes. They have been set up to be skipped by auto programming or in the programme edit mode.
- b. Some programmes with the channel number shown in the programme table indicate there is no station name assigned.

Selecting a programme in the programme list
Select a programme with the **▲** / **▼** or **◀** / **►** button.

Then press the **OK** button.

The set switches to the chosen programme number.

Paging through a programme table

There are 10 (or 20) programme table pages which contain 100 (or 200) programmes.

Programme List				
0	C 01	5	S 69	
1	C 03	6	S 17	
2	C 12	7	S 22	
3	S 66	8	C 09	
4	S 67	9	C 11	
◀▶ OK MENU				

Pressing the **▲** / **▼** or **◀** / **►** button repeatedly turns the pages.


Press the **LIST** button to return to normal TV viewing.

Picture adjustment

Note: Picture menu options are not available for the RGB input source.

Picture Mode

1. Press the **MENU** button and then **▲ / ▼** button to select the Picture menu.
2. Press the **▶** button to select **Picture Mode**.
3. Press the **▶** button and then **▲ / ▼** button to select **Dynamic, Standard, Mild** or **Game**.
4. Press the **OK** or **◀** button.



5. Repeatedly press the **MENU** button to return to normal TV viewing.

You can also recall a desired picture (**Dynamic, Standard, Mild, Game** or **User**) with **PSM** button on the remote control. The picture **Dynamic, Standard, Mild** and **Game** are programmed for good picture reproduction at the factory and cannot be changed.

Colour Temperature

1. Press the **MENU** button and then **▲ / ▼** button to select the Picture menu.
2. Press the **▶** button to select **Colour Temperature**.
3. Press the **▶** button and then **▲ / ▼** button to select **Cool, Medium** or **Warm**.
4. Press the **OK** or **◀** button.
5. Repeatedly press the **MENU** button to return to normal TV viewing.

XD

You can enjoy the vivid and hi-definition picture with LG's excellent Digital Reality processor technology.

1. Press the **MENU** button and then **▲ / ▼** button to select the Picture menu.
2. Press the **▶** button and then **▲ / ▼** button to select **XD**.
3. Press the **▶** button and then **▲ / ▼** button to select **On** or **Off** on the **XD** pull-down menu.

4. Press the **OK** or **◀** button.
5. Repeatedly press the **MENU** button to return to normal TV viewing.

Note :

*Only in User mode, XD could be chosen on/off.
Other PSM XD is default in on status.*

VM (Velocity Modulation)

This is the function to enhance the sharpness of image edge.

1. Press the **MENU** button and then **▲ / ▼** button to select the Picture menu.
2. Press the **▶** button and then **▲ / ▼** button to select **VM**.
3. Press the **▶** button and then **▲ / ▼** button to adjust the **High, Middle, Low, Off**.
4. Press the **OK** button.
5. Repeatedly press the **MENU** button to return to normal TV viewing.

Cinema (option)

When you watch the movie, this function adjusts the set to the best picture appearance.

1. Press the **MENU** button and then **▲ / ▼** button to select the Picture menu.
2. Press the **▶** button and then **▲ / ▼** button to select **Cinema**.
3. Press the **▶** button and then **▲ / ▼** button to select **On** or **Off**.
4. Press the **OK** button.
5. Repeatedly press the **MENU** button to return to normal TV viewing.

Virtual HD (option)

1. Press the **MENU** button and then **▲ / ▼** button to select the Picture menu.
2. Press the **▶** button and then **▲ / ▼** button to select **Virtual HD**.
3. Press the **▶** button and then **▲ / ▼** button to select **100, Pro**.
4. Press the **OK** button.
5. Repeatedly press the **MENU** button to return to normal TV viewing.

Note :

*It's not available to use **100** for **Virtual HD** in NTSC signal.*

Picture adjustment

Picture adjustment

You can adjust contrast,brightness,colour,sharpness to the levels you prefer.

1. Repeat the 'Picture Mode' steps 1 to 2.
2. Press the **►** button and then **▲ / ▼** button to select **User**.
3. Press the **►** button and then **▲ / ▼** button to select **Contrast**, **Brightness**, **Colour**, **Sharpness** or **Tint**.
4. Press the **►** button and then **▲ / ▼** button to make appropriate adjustments on the each sub menu.
5. Press the **OK** button to store it for the picture **User**.
6. Repeatedly press the **MENU** button to return to normal TV viewing.

Turbo picture selection (option)

When this function is on, the picture will be more brilliant and distinct than normal picture.
Repeatedly press the **TURBO PICTURE** button to switch on or off.

Note : If you press the **PSM** button with the **Turbo** picture function, the **Turbo** picture function is automatically switched off.

Picture format

You can watch TV in various picture formats: 4:3, 16:9 (Wide).

In some models, you can watch TV in various picture formats: 4:3, 16:9 (Wide).

Repeatedly press the **ARC** button to select your desired picture format.

4:3

This picture format is 4 to 3 of general TV.

16:9

You can enjoy the cinema (the picture format of 16:9) or general TV programme through the 16:9 mode.

Audio adjustment

Sound Mode (Sound Status Memory)

You can select your preferred sound setting; Standard, Music, Movie or Sports and you can also adjust the sound frequency of equalizer.

1. Press the **MENU** button and then **▲ / ▼** button to select the Audio menu.
2. Press the **►** button to select **Sound mode**.
3. Press the **►** button and then **▲ / ▼** button to select a sound setting on the **Sound mode** pull-down menu.



Sound Frequency Adjustment

- a. Press the **►** button in **User** to display the **User** sub menu.
- b. Select a sound band by pressing the **◀ / ►** button.
- c. Make appropriate sound level with the **▲ / ▼** button.
- d. Press the **OK** button to store it for the sound **User**.

Repeatedly press the **MENU** button to return to normal TV viewing.

The sound **Standard**, **Music**, **Movie** and **Sports** are programmed for good sound reproduction at the factory and cannot be changed.

Sound adjustment

You can adjust balance, Auto Volume , DBS. Auto Volume automatically keeps on an equal volume level even if you change programmes. If you switch DBS to on, the set creates a dynamic bass sound.

1. Press the **MENU** button and then **▲ / ▼** button to select the Sound menu.
2. Press the **►** button and then **▲ / ▼** button to select the desired sound item **Auto Volume**, **DBS** or **Balance**.
3. Make desired adjustment with the **◀ / ►**, **▲ / ▼** or **OK** button on each pull-down menu.
4. Repeatedly press the **MENU** button to return to normal TV viewing.

Audio adjustment

X-WAVE (Wireless Sound) (option)

You can also listen to the sound through the FM receiver.

1. Press the **MENU** button and then **▲ / ▼** button to select the Audio menu.
2. Press the **▶** button and then **▲ / ▼** button to select **X-WAVE**.
3. Press the **▶** button and then **▲ / ▼** button to select **Set Frequency**.
4. Press the **▶** button to tune in a frequency on the X-wave menu.
5. Use the number **0** to **9** or press the **◀ / ▶** button to match the TV's frequency and the FM receiver's.

Note:

- If the reception is poor or weak, select a different frequency.*
- For best results, there should be no more than 5m (16.4ft) between the TV and FM Receiver.*
- In certain areas, the FM transmitter ability may be weak, such as near a broadcast tower.*
- The reception sensitivity may depend on the kinds of receiver (FM radio).*

Turbo sound selection (option)

When this function is on, the sound will be more emphasized and amplified than normal sound.
Repeatedly press the **TURBO SOUND** button to switch on or off.

Sound output selection

In AV mode, you can select output sound for the left and right loudspeakers.

Repeatedly press the **I/II** button to select the sound output.

L+R: Audio signal from audio L input is sent to left loud-speaker and audio signal from audio R input is sent to right loud-speaker.

L+L: Audio signal from audio L input is sent to left and right loud-speakers.

R+R: Audio signal from audio R input is sent to left and right loud-speakers

Stereo/Dual reception

When a programme is selected, the sound information for the station appears after the programme number and station name disappear.

Broadcast	On Screen Display
Mono	MONO
Stereo	STEREO
Dual	DUAL I

Mono sound selection

In stereo reception if the stereo signal is weak, you can switch to mono by pressing the **I/II** button twice. In mono reception the depth of sound is improved. To switch back to stereo, press the **I/II** button twice again.

Language selection for dual language broadcast

If a programme is received in two languages (dual language), you can switch to **DUAL I**, **DUAL II** or **DUAL I+II** by pressing the **I/II** button repeatedly. **DUAL I** sends the primary broadcast language to the loudspeakers.

DUAL II sends the secondary broadcast language to the loudspeakers.

DUAL I+II sends a separate language to each loudspeaker.


NICAM reception (option)

If your set is equipped with the receiver for NICAM reception, the high quality NICAM (Near Instantaneous Companding Audio Multiplex) digital sound can be received.

Sound output can be selected according to the type of received broadcast by pressing the **I/II** button repeatedly.

1. When NICAM mono is received, you can select **NICAM MONO** or FM MONO.
2. When NICAM stereo is received, you can select **NICAM STEREO** or FM MONO. If the stereo signal is weak, switch to FM mono.
3. When NICAM dual is received, you can select **NICAM DUAL I**, **NICAM DUAL II** or **NICAM DUAL I+II** or **MONO**. When FM mono is selected the display **MONO** appears on the screen.

Time Setting



Setting the clock

1. Press the **MENU** button and then **▲ / ▼** button to select the Time menu.
2. Press the **▶** button to select **Clock**.
3. Press the **▶** button and then **▲ / ▼** button to adjust the hour.
4. Press the **▶** button and then **▲ / ▼** button to adjust the minute.
5. Press the **OK** button.
6. Repeatedly press the **MENU** button to return to normal TV viewing.

Setting the On/Off time

By using this function, the set automatically switches on or off at a preset time. You must set the time correctly before using the on/off time function.

1. Press the **MENU** button and then **▲ / ▼** button to select the Time menu.
2. Press the **▶** button and then **▲ / ▼** button to select **Off time/On time**.
3. Press the **▶** button and then **▲ / ▼** button to

4. Press the **▶** button and then **▲ / ▼** button to adjust the minute.
5. **Only On time function** press the **▶** button and then **▲ / ▼** button to adjust programme number and volume level.
6. Press the **OK**.
7. Repeatedly press the **MENU** button to return to normal TV viewing.

Note :

- a. **On time** works only in standby mode.
- b. To view the remaining on/off time, select the Time menu.
- c. When you switch the main power off, the **Clock** is reset.

Auto sleep

If you select **On** on the **Auto sleep** pull-down menu, the set will automatically switch itself to standby mode approximately ten minutes after a TV station stops broadcasting.

1. Press the **MENU** button and then **▲ / ▼** button to select the Time menu.
2. Press the **▶** button and then **▲ / ▼** button to select **Auto sleep**.
3. Press the **▶** button and then **▲ / ▼** button to select **On** or **Off** on the **Auto sleep** pull-down menu.
4. Press the **OK** or **◀** button.
5. Repeatedly press the **MENU** button to return to normal TV viewing.

Option functions



TV and AV modes

Inputs can be set for TV or AV mode. AV mode is used when a video cassette recorder (VCR), or other equipment is connected to the set.

Note : When a VCR is connected via the aerial socket the set is used in TV mode. See the 'Connection of external equipment' section.

1. Press the **MENU** button and then **▲ / ▼** button to select the Option menu.
2. Press the **▶** button and then **▲ / ▼** button to select **Input**.

3. Press the **▶** button and then **▲ / ▼** button to select **TV**, **AV1**, **AV2**, **AV3**(option), **Component**(option), **HDMI** (option) on the **Input** pull-down menu.
AV1 : VCR connected to the Euro scart socket or **AV IN 1** sockets on the set
AV2 : VCR connected to the **AV IN 2** sockets on the set.
AV3 : VCR connected to the **AV IN 3** sockets on the set (option)
COMPONENT : DVD or SET-TOP Box connected to the **Component** sockets on the set (option).
HDMI : DVD or SET-TOP Box connected to the **HDMI** sockets on the set (option).
4. Repeatedly press the **MENU** button to return to normal TV viewing.

Alternatively you can select the TV or AV mode by pressing the **TV/AV** button.

Option functions

Key lock

The TV can be set so that the remote control handset is needed to control it. This feature can be used to prevent unauthorized viewing.

1. Press the **MENU** button and then **▲ / ▼** button to select the Option menu.
2. Press the **▶** button and then **▲ / ▼** button to select **Key lock**.
3. Press the **▶** button and then **▲ / ▼** button to select **On** or **Off** on the **Key lock** pull-down menu.
4. Press the **OK** or **◀** button.
5. Repeatedly press the **MENU** button to return to normal TV viewing.

With the lock on, the display **Key lock on** appears on the screen if any button on the front panel is pressed while viewing the TV.

Degaussing (option)

Due to the super large Tube in the set. The colour purity of the picture may be affected by other magnetic influences such as speakers. Stripes may appear on the screen or there may be colour patches.

1. Press the **MENU** button and then **▲ / ▼** button to select the Option menu.
2. Press the **▶** button and then **▲ / ▼** button to select **Degauss**.
3. Press the **▶** button and then **▲ / ▼** button to select **On** on the **Degauss** pull-down menu. After the degauss function works, **On** mode switches to **Off** mode automatically.
4. Repeatedly press the **MENU** button to return to normal TV viewing.

Note : If you cannot adjust the screen condition by degaussing, try it again after about 4 minutes.

Tilt (option)

The TV picture may tilt to the left or right if the TV set moves to another position. This function can be used to compensate the tilt.

1. Press the **MENU** button and then **▲ / ▼** button to select the Option menu.
2. Press the **▶** button and then **▲ / ▼** button to select **Tilt**.
3. Press the **▶** button and then **◀ / ▶** button of the panel control to adjust the tilt on the **Tilt** pull-down menu.

*On some models, adjust the tilt by using the **◀ / ▶** button of the remote control handset.*

4. Repeatedly press the **MENU** button to return to normal TV viewing.

XD Demo (option)

Use it to see the difference between XD demo on and XD Demo off.

1. Press the **MENU** button and then **▲ / ▼** button to select the Option menu.
2. Press the **▶** button and then **▲ / ▼** button to select **XD Demo**.
3. Press the **▶** button to begin **XD Demo**.
4. To stop **XD Demo**, press the **MENU** button.

Sleep timer

You don't have to remember to switch the set off before you go to sleep. The sleep timer automatically switches the set to standby after the preset time elapses.

Repeatedly press the **SLEEP** button to select the number of minutes. The display **---** will appear on the screen, followed by **10, 20, 30, 60, 90, 120, 180** and **240**. The timer begins to count down from the number of minutes selected.

Note :

- a. To view the remaining sleep time, press the **SLEEP** button once.
- b. To cancel the sleep time, repeatedly press the **SLEEP** button until the display **---** appears.
- c. When you switch the set off, the set releases the preset sleep time.

Teletext (option)

Teletext (or TOP text) is an optional function, therefore only a set with the teletext system can receive the teletext broadcast.

Teletext is a free service broadcast by most TV stations which gives up-to-the-minute information on news, weather, television programmes, share prices and many other topics.

The teletext decoder of this TV can support the SIMPLE, TOP and FASTEXT systems. SIMPLE (standard teletext) consists of a number of pages which are selected by directly entering the corresponding page number. TOP and FASTEXT are more modern methods allowing quick and easy selection of teletext information.

Switch on/off

Press the **TEXT** button to switch to teletext. The initial page or last page appears on the screen. Two page numbers, TV station name, date and time are displayed on the screen headline. The first page number indicates your selection, while the second shows the current page displayed. Press the **TEXT** or **TV/AV** button to switch off teletext. The previous mode reappears.

SIMPLE text

Page selection

1. Enter the desired page number as a three digit number with the NUMBER buttons. If during selection you press a wrong number, you must complete the three digit number and then re-enter the correct page number.
2. The **▲** / **▼** button can be used to select the preceding or following page.

Programming a colour button in LIST mode (option)

Press the **LIST** button to switch to LIST mode.

Four teletext page numbers of your choice can be colour coded and easily selected by pressing the corresponding coloured button on the remote control handset.

1. Press a coloured button.
2. Using the NUMBER buttons, select the page you wish to programme.
3. Press the **OK** button. Then the selected page is stored as the selected page number with

blinking once. From now on, you can select this page with the same coloured button.

4. The three other coloured buttons are programmed in the same way.

TOP text (option)

The user guide displays four fields-red, green, yellow and blue at the bottom of the screen. The yellow field denotes the next group and the blue field indicates the next block.

Block / group / page selection

1. With the blue button you can progress from block to block.
2. Use the yellow button to proceed to the next group with automatic overflow to the next block.
3. With the green button you can proceed to the next existing page with automatic overflow to the next group.
Alternatively the **▲** button can be used.
4. The red button permits to return to previous selection. Alternatively the **▼** button can be used.

Direct page selection

Corresponding to the SIMPLE teletext mode, you can select a page by entering it as a three digit number using the NUMBER buttons in TOP mode.

FASTEXT

The teletext pages are colour coded along the bottom of the screen and are selected by pressing the corresponding coloured button.

Page selection

1. Press the **LIST** button to select the index page.
2. You can select the pages which are colour coded along the bottom line with the same coloured buttons.
3. Corresponding to the SIMPLE teletext mode, you can select a page by entering its three digit page number with the NUMBER buttons in FASTEXT mode.
4. The **▲** / **▼** button can be used to select the preceding or following page.

Teletext (option)

Special teletext functions

REVEAL

Press this button to display concealed information, such as solutions of riddles or puzzles.
Press this button again to remove the information from the display.

SIZE

Selects double height text.
Press this button to enlarge the top half of the page.
Press this button again to enlarge the bottom half of the page.
Press this button again to return to the normal display.

UPDATE

Displays the TV picture on the screen while waiting for the new teletext page. The display  will appear at the top left hand corner of the screen. When the updated page is available then the display  will change to the page number.
Press this button to view the updated teletext page.

STILL

Stops the automatic page change which will occur if a teletext page consists of 2 or more sub pages. The number of sub pages and the sub page displayed is, usually, shown on the screen below the time. When this button is pressed the stop symbol is displayed at the top left-hand corner of the screen and the automatic page change is inhibited.

To continue press this button again.

MIX

Displays the teletext pages superimposed on the TV picture.
To switch the TV picture off press this button again.

TIME

When viewing a TV programme, press this button to display the time at the top right hand corner of the screen. Press this button again to remove the display. In the teletext mode, press this button to select a sub page number. The sub page number is displayed at the bottom of the screen. To hold or change the sub page, press the RED/GREEN, Δ / ∇ or NUMBER buttons.
Press again to exit this function.

Troubleshooting check list

Symptoms

No picture, no sound

Sound OK, poor picture

Picture OK, poor sound

Picture blurred


Lines or streaks in picture

Poor reception on some channels

No colour

Poor colour

Remote control does not work



Check these items and try to adjust these

The mains plug-(plugged in and switched on)

Is the TV switched on

Try another channel (weak signal)

Check aerial (plugged into TV?)

Check aerial (broken lead?)

Check aerial

Check for local interference

Adjust contrast

Adjust brightness

Adjust colour

Adjust volume

Check the batteries in remote control

Check Audio/Video sockets (VCR only)

