



OWNER'S MANUAL

VACUUM CLEANER



Before beginning installation, read these instructions carefully. This will simplify installation and ensure that the product is installed correctly and safely. Leave these instructions near the product after installation for future reference.

ENGLISH

A9T******



MFL05755703 Rev.00 012125



TABLE OF CONTENTS

This manual may contain images or content that may be different from the model you purchased.

This manual is subject to revision by the manufacturer.

SAFETY INSTRUCTIONS	
READ ALL INSTRUCTIONS BEFORE USE	3
WARNING	3
CAUTION	10
INSTALLATION	
Product Overview	12
Storing the Accessories	15
OPERATION	
Getting Started	18
Charging the Battery	20
Using the Mop Nozzle	21
Using the Nozzles and Tools	25
SMART FUNCTIONS	
Using LG ThinQ Application	28
Smart Diagnosis Function	
MAINTENANCE	
Cleaning the Appliance	31
Cleaning the Nozzles	
TROUBLESHOOTING	
Before Calling for Service	40

SAFETY INSTRUCTIONS

READ ALL INSTRUCTIONS BEFORE USE

The following safety guidelines are intended to prevent unforeseen risks or damage from unsafe or incorrect operation of the appliance. The guidelines are separated into 'WARNING' and 'CAUTION' as described below.

Safety Messages



This symbol is displayed to indicate matters and operations that can cause risk. Read the part with this symbol carefully and follow the instructions in order to avoid risk.



WARNING

This indicates that the failure to follow the instructions can cause serious injury or death.



CAUTION

This indicates that the failure to follow the instructions can cause the minor injury or damage to the product.

WARNING



WARNING

• To reduce the risk of explosion, fire, death, electric shock, injury or scalding to persons when using this product, follow basic precautions, including the following:

Technical Safety

• This appliance is not intended for use by persons (including children) with reduced physical, sensory or mental capabilities, or lack of experience and knowledge, unless they have been given supervision or instruction concerning use of the appliance by a person

responsible for their safety. Children should be supervised to ensure that they do not play with the appliance.

- Do not allow the appliance to be used as a toy. Close attention is necessary when used by or near children.
- Do not allow children to play with or hang on the appliance.
- Do not use the appliance with damaged power cord or plug. The cord must be replaced. If the appliance is not working as it should, has been dropped, damaged, left outdoors, or dropped into water, return it to an LG Electronics service centre.
- Do not pull or carry by cord, use cord as a handle, close a door on cord, or pull cord around sharp edges or corners. Do not run appliance over cord. Keep cord away from heated surfaces.
- Do not unplug by pulling on cord. To unplug, grasp the plug, not the cord.
- Place the cords from other appliances out of the area to be cleaned.

Battery

- Never use the battery, adapter, and the charging station from other appliances with this appliance. Use only the battery and the charging station provided by LG Electronics.
- Never use the battery, adapter, and the charging station from this appliance with other appliances.
- Unplug the power cord and remove the battery if the appliance will not be used for an extended period of time.
- Do not use modified or damaged batteries.
- Do not disassemble, remove or short-circuit the battery.
- When disposing of the battery or the appliance, remove the battery from the appliance and safely dispose of it.
- Have specifically designated battery packs replaced when it is no longer able to hold a charge.
- Refer to the Charging the Battery section instructions for the method of replacing the battery.

- When disposing of this appliance, follow regulations for disposal of rechargeable lithium-ion batteries.
- Follow all local ordinances and regulations when handling or disposing of the battery.
- Prevent unintentional starting. Ensure the switch is in the off position before connecting to the battery pack, picking up or carrying the appliance.
- Disconnect the battery pack from the appliance before making any adjustments, changing accessories, cleaning, serviing, or storing appliance.
- When battery pack is not in use, keep it away from other metal objects, like paper clips, coins, keys, nails, screws or other small metal objects, that can make a connection from one terminal to another.
- Under abusive conditions, liquid may be ejected from the battery. If this happens, avoid contact. If contact accidentally occurs, flush with water. If liquid contacts eyes, additionally seek medical help.
- If the appliance is to be stored unused for a long period, the batteries should be removed.
- Before removing the battery, you must turn off this appliance.
- When fitting the battery into the product body, insert it completely until it clicks.

Battery Specifications

- One or two batteries are provided, the number of batteries varies depending on the model purchased.
 - Model Name: EAC633822**
 - **Type**: Rechargeable Lithium-ion Battery
 - Rated Capacity: 2400 mAh

Installation

 To avoid an electrical shock or fire, do not install, charge or store the appliance where it may be exposed to water, rainfall or high humidity.

- Install, charge and store the appliance in a well-ventilated place.
- Avoid operating the appliance in areas where there is a risk of leakage of flammable gas, industrial oil or metallic dust.
- Do not store or install the appliance, power cord or plug near heating devices or open flames.
- Install the charging station on a firm, level surface.
- Do not use or store the appliance at temperatures below 5 °C or above 38 °C.
- Do not store or install the appliance where it is exposed to temperatures below freezing or exposed to outdoor weather conditions.
- When installing or moving the appliance, be careful not to pinch, crush, or damage the power cord or plug.

Operation

- Read all instructions before using the appliance, and save these instructions.
- Use only as described in this manual. Use only manufacturer's recommended attachment.
- This appliance is designed for normal indoor domestic use only. It is not to be used for any non-residential, commercial, or industrial application.
- Do not handle the power cord, plug, or appliance controls with wet hands.
- Wipe any moisture or dirt off the cord or plug with a dry cloth.
- Never attempt to operate this appliance if it is damaged, malfunctioning, partially disassembled, or has missing or broken parts, including a damaged cord or plug. Take it to an authorized LG Electronics service centre or dealer for assistance.
- Do not apply excessive force to the power cord to bend it, or place it under a heavy object as this will damage it.
- Do not use multiple-outlet adapters with this appliance. Make sure to use a power socket with a capacity of 10 A.

- Do not plug the appliance into a damaged or loose outlet.
- Make sure to unplug the power cord when the appliance is not to be used for an extended period of time.
- Do not damage, alter, excessively bend, twist, pull, pinch or heat the power cord.
- Before using the appliance, remove any wire or string on the floor.
- Avoid touching the prongs of the power plug with your finger(s) when unplugging the power cord.
- Do not cover the power cord with a rug or carpeting.
- Push the power plug firmly into the wall outlet so that it is not loose.
- If the product has been submerged, contact an LG Electronics service centre or dealer for instructions before resuming use.
- If the product makes a strange noise or emits an odour or smoke, discontinue use and contact an LG Electronics customer information centre.
- Only qualified technicians or service personnel from LG Electronics may disassemble, repair or modify the appliance.
- Never insert a sharp metallic object such as a pin, nail or knife in a hole or gap in the appliance or the charging station.
- Do not vacuum liquids with this appliance. Make sure that no water, beverage or detergent gets inside the appliance or the charging station.
- Do not allow the appliance to sweep up blades, thumb tacks, sawdust, sharp objects, or hot or cold ashes.
- Do not allow children to use the appliance.
- Do not let children or pets get close to the appliance when using, charging or storing.
- Do not insert the nozzle or tools in your mouth.
- Keep clothing and hair, fingers, or other parts of the body away from openings and moving parts.
- Do not operate the appliance with the suction inlet or outlet blocked.
- Do not use the appliance without the dust bin and filters in place.

- 9
- Do not use in an enclosed space where vapors are present from paint thinner, mothproofing substances, flammable dust or other explosive or toxic materials.
- Do not touch the charging terminals on the appliance or the charging station, or insert an electrified object inside the appliance or the station.
- Always store the appliance on the charging station when it is not in use.
- Do not lean the appliance on walls, chairs or tables.
- If the earth leakage breaker is tripped when the product is put on the charging station, immediately remove the appliance from the charging station. Contact an LG Electronics customer service centre.
- Use extra care when cleaning on stairs.
- Do not use or store a heating device or flammable substance(ether, benzene, alcohol, chemicals, combustible sprays, insecticide, air freshener or cosmetics) in close proximity to the appliance.
- Do not attempt to clean up a liquid substance (water, beverage), odourous substances (candy, chocolate, pet excrement), metallic objects (blades, pins), flammable substances, burning/ smoking(cigarettes, matches, or hot ashes), surfactants, or glass shards with this appliance.
- In the event of a gas leak(natural gas, propane gas, etc.), do not operate this or any other appliance. Open a window or door to ventilate the area immediately.
- Do not hold the charging station upside down with the battery in the charging station.
- Do not expose the appliance, and the battery in particular, to heat, a heating device or direct sunlight.
- Do not keep the appliance or its battery inside a vehicle which is exposed to direct sunlight.
- Never allow any water, beverage or detergent to get inside the battery.
- Do not apply physical impacts to the battery.

Maintenance

- Make sure to unplug the power cord when cleaning or maintaining the charging station.
- Do not wash the inlet port or the dust bin with water or detergent.
- Do not use detergents, polishes or air fresheners to clean the dust bin.
- Do not apply or spray a flammable substance (gasoline or thinner) or surfactants (detergent or bath soap) on the appliance.
- Wash hands after handling nozzles. The nozzles contain carbon fiber, and contact may cause minor skin irritation.

Disposal

- Keep packing materials out of the reach of children. Packaging materials can pose a suffocation risk for children.
- Destroy the carton, plastic bag, and other packing materials after the appliance is unpacked. Children might use them for play. Cartons covered with rugs, bedspreads, or plastic sheets can become airtight chambers.
- Dispose of this appliance according to local, state, and regional laws and regulations.
- Contact your local city council or the related government authority before disposing of this appliance.

Mop Nozzle

Do not vacuum sharp objects (glass pieces, wire, blades, pins, etc.)
with the mop nozzle attached. When cleaning the mop pads after
mopping, you could be injured by a sharp object embedded in the
mop.

CAUTION

A CAUTION

 To reduce the risk of injury to persons, malfunction, or damage to the product or property when using the appliance, follow basic safety precautions, including the following:

Operation

- This appliance has a built-in safety device to prevent damage from overheating. If the appliance becomes overheated after extended use, it may automatically turn off. If this occurs, leave the appliance in a cool, well-ventilated area for about an hour before turning on the power again.
- Do not subject the product to shocks or drop it.
- Do not install wet or damp filters.
- Always use a soft cloth to clean the appliance. Do not clean the product with a volatile or organic solvent(thinner or acetone).
- Do not clean the same spot repeatedly for an extended period of time. Doing so may damage the carpet or flooring surface.
- Keep fingers away from pinch points when assembling the appliance or the charging station.
- Do not apply force or any impact to the Cyclonic Mesh Filter.
- Do not remove the battery during operation.

Mop Nozzle

- Do not use the mop nozzle for any purpose(for example, polishing a car, cleaning windows) other than domestic floor cleaning.
- Do not use the mop nozzle to vacuum up liquids(water, beverage).
- When using the mop nozzle, always attach the mop pads.
- Do not clean a coated, rough or delicate floating floor and carpets with the mop nozzle.

- Do not use the mop nozzle to clean the same spot repeatedly for an extended period of time. The water injection at the mop nozzle may cause water to get into the dust inlet and damage the appliance.
- Do not step on the mop nozzle.
- Wet floors can pose a slip hazard. Allow floors to dry completely before allowing anyone to walk on them.
- Do not store the appliance by attaching the water tank filled with water to the mop nozzle.


INSTALLATION

Product Overview

The images in this guide may be different from the actual components and accessories, which are subject to change by the manufacturer without prior notice for product improvement purposes.

Front View

*1 This feature is only available on some models.



- 1 Product Body
- 2 Extension Pipe
- 3 Nozzle
- 4 Battery (Dual Battery*1)
- **5** Exhaust Filter
- **6** Pre-filter
- 7 Kompressor Lever
- 8 Cyclonic Mesh Filter


NOTE

• Use the vacuum cleaner only with the provided charging station. Using a charging station other than the one designed to be used with the vacuum cleaner may result in improper sealing of the product and failure to empty dust from the vacuum cleaner.

Accessories


*1 This accessory is only available on some models.

Included Accessories




- 1 Product Body
- 2 Extension Pipe
- 3 Pre-filter
- Battery (Dual Battery*1)

Basic Accessories



- Combination Tool
- 2 Crevice Tool


Nozzles



- 1 Dual Floor Max Nozzle*1
- 2 Wide Hard Floor Nozzle*1
- 3 Bedding Nozzle*1


4 Pet Nozzle*1

Tools



- 1 Hard Dirt Tool*1
- 2 Mattress Tool*1
- 3 Multi-angle Tool*1
- 4 Flexible Crevice Tool*1
- **5** Flexible Hose Extension*1
- 6 Accessory Bag*1

Mop Kit



- 1 Mop Nozzle*1
- 2 Mop Pads for General Cleaning*1

NOTE

 The mop pads, batteries, exhaust filter and the pre-filter will eventually need to be replaced.
 Contact an LG Electronics customer service centre.

Specifications

Appliance

Model	A9T*****	
Dimensions (Width X Depth X Height)	260 mm X 270 mm x 1120 mm	
Weight	Approximately 2.6 kg	
Power Consumption	370 W in Turbo Mode (Maximum 590 W) 120 W in Power Mode 68 W in Normal Mode	
Battery Run Time (Using two battery)	Using with the Nozzle*1 Up to 12 minutes in Turbo Mode Up to 40 minutes in Power Mode Up to 80 minutes in Normal Mode	Using with the Tool Up to 14 minutes in Turbo Mode Up to 60 minutes in Power Mode Up to 120 minutes in Normal Mode
Battery Run Time (Using one battery)	Using with the Nozzle*1 Up to 6 minutes in Turbo Mode Up to 20 minutes in Power Mode Up to 40 minutes in Normal Mode	Using with the Tool Up to 7 minutes in Turbo Mode Up to 30 minutes in Power Mode Up to 60 minutes in Normal Mode

- Dimensions are given for the assembled product body, extension pipe and nozzle.
- Suction power is an average of suction power with IEC 62885-2, 5.8 standard tested by an independent test lab. Individually measured data would be different from a lab test result.
- Battery run time is the result of using a fully charged battery according to the LG Electronics test standard. Results may be different depending on actual use environment and period of use.

Charging Station

Model	VDS-ST2**
Input	230 V~ 50 Hz
Output	28.3 V 1.15 A
Power Consumption	1700 W (Cleaning) 0.4 A (Charging)


Storing the Accessories

Assembling and Storing the Appliance Follow these steps to safely assemble the appliance.


1 Firmly attach the extension pipe **3**, nozzle **4**, or tool onto the product body **1**.

^{*1} The Nozzle contains the direct drive motor that rotates the nozzle cleaning head directly.

 To detach the extension pipe, press the extension pipe release button 2.



- **2** Put the product body on the charging station.
 - If the vacuum cleaner fits properly inside the charging station, the alarm will sound. Wait several seconds and if the alarm does not sound, reinsert the vacuum cleaner, making sure that the nozzle is horizontal.



Storing the Tools


Use the product to store the inlet and components provided with the vacuum cleaner.

The components may differ depending on the vacuum cleaner model.


Storing on Sides

1 Open the nozzle hook **①** on both sides of the product.

 To open the nozzle hooks, press on the right side. Be careful not to pinch fingers when opening.




2 Hang the nozzle on the nozzle hook.




Storage Inside

1 Open the left door of the product and insert the bedding nozzle or the pet nozzle **①** for storage.




2 Open the right door and insert the combination tool **2** and the crevice tool **3** for storage.



NOTE

- Before moving the product, unplug it and remove the vacuum cleaner, nozzles, and accessories.
- To carry the product, open both doors and hold the areas shown.



OPERATION

Getting Started

Before Using the Appliance

- Support the bottom of the appliance when cleaning an elevated surface.
- To avoid scratches on polished floors, keep tools and the brushes and rollers of the nozzles free from hair, grit, sand, or abrasive objects.
- Make sure that the exhaust filter or pre-filter is properly assembled before using the appliance.
- Close the dust bin cover properly before using the appliance. If the dust bin cover is left open, the suction strength may deteriorate and affect the cleaning results.
- Store the appliance in the charging station or place it flat on the floor when not in use. Leaning the appliance against a wall or chair can result in product damage or personal injury if the appliance falls.
- Environmental conditions such as temperature and humidity may cause static electricity to accumulate on the appliance. Please contact LG Electronics customer information centre if the problem persists.
- Make sure to remove any foreign object such as a sock or stocking before using the appliance.
 Any foreign object on the inlet port or extension pipe will prevent the appliance from functioning properly.
- Please use the product at normal room temperatures as the battery runtime may deteriorate severely if used at temperatures lower than 5 °C or higher than 38 °C for an extended period of time.
- The battery runtime is dependent on the surface type and the suction power.
- Follow manufacturer's recommendations when cleaning flooring, carpets, and rugs.
- Refer to the Specifications section for battery runtime details.


Assembling Attachments

Nozzles and tools can be attached to either the product body or the end of the extension pipe.

- Insert the fully charged battery into the cavity at the bottom of the handle on the product body and push the battery until it clicks.
 - If it is not properly inserted, the battery may fall out, causing product to malfunction or personal injury.




- 2 Attach the nozzles, tools, or extension pipe by sliding them onto the inlet 2 on the body until they click into place. The nozzles and tools can also be attached to the end of the extension pipe 2.
 - Detach the accessories by pressing the release button 3.



Adjust the extension pipe by pressing the length adjustment button 4 on the back of the pipe and sliding until it clicks into place at the desired length.


· The extension pipe extends in four steps.



- 4 Press the **Power** button to activate the **Normal** mode.
 - To turn off the appliance, press the **Power** button again.

Adjusting the Suction Power

Adjust the suction power using the suction power adjustment button on the handle.



Power Button

- Press the **Power** button to turn the appliance on or off.
- Press the **Power** button to activate **Normal** mode.

2 Suction Power Up (+) Button / Turbo Mode


- Press the + button to increase the suction power. (Normal—Power)
- Press and hold the + button for more than 3 seconds to activate Turbo mode from Normal and Power mode.

3 Suction Power Down (-) Button / Wi-Fi Mode

 Press the - button to decrease the suction power. (Turbo—Power—Normal) Press and hold the - button for 3 seconds to activate Wi-Fi and connect the appliance in the LG ThinO application.

Display

The handle of the appliance displays indicators for clogged objects, filter cleaning alerts, appliance connection status, and the remaining battery charge.



1 Clogged Objects Indicator

- This indicator lights up when the interior of the product body, extension pipe, inlets, nozzle, exhaust filter, pre-filter, or cyclonic mesh filter is clogged with foreign objects.
- If clogging persists, the motor will cycle and the appliance will shut off. Remove the foreign objects and clean the exhaust filter, pre-filter and cyclonic mesh filter following the steps in the Removing Foreign Objects section.

2 Filter Cleaning Cycle Alarm Indicator

 This indicator lights up when the appliance is used for a certain period of time. Clean the exhaust filter, pre-filter and cyclonic mesh filter if necessary.

Wi-Fi Indicator

 This indicator blinks when the appliance is connecting to the LG ThinQ application or home Wi-Fi network, and the indicator lights up when the connection is complete.

4 Battery Level Indicator

- The remaining battery level is displayed in 3 stages according to the remaining battery power.
- The battery level indicator blinks when the battery needs to be charged.

- As the product is charging, bars light up on the battery level indicator to indicate the level of charge.
- Once the battery is fully recharged, 3 bars will remain lighted on the battery level indicator.

Charging the Battery

Before Charging the Battery


- Make sure that the adapter is connected to both the charging station and the power outlet.
- Fully charging a single battery usually takes 4 hours. It will take twice as long to charge both the main and spare batteries.
- The battery will not be charged if the indoor temperature is below 5 °C. Only charge the battery when indoor temperatures are between 5 °C and 38 °C.
- The battery will eventually need to be replaced.
 Due to the battery characteristics, runtime is shortened after using the appliance repeatedly for an extended period.
- The last bar on the battery indicator begins to flash when the battery needs to be recharged.
 Use the appliance with a fully charged battery.
- To maintain battery life on dual-battery models, swap the positions of the two batteries periodically, between the main body and the spare charging station.

Charging the Vacuum Cleaner

Storing the appliance on the charging station automatically recharges the battery.

- 1 Press the **Power** button to turn the appliance off.
- **2** Put the product body on the charging station.
 - Make the extension pipe its shortest length before placing the vacuum onto the charger.
 - The appliance cannot be loaded onto the charging station if either the combination tool or the crevice tool is inserted. Use the

- charging station only after removing the combination tool or the crevice tool, if either happens to be fitted
- When the vacuum is properly placed on the charging station, the battery charge level is displayed on the status display with the beep sound. If you don't hear a beep, reload the appliance on the charging station.
- When the charging is complete, the status display turns off.



WARNING

 Make sure to securely fit the product body onto the charging station. If the appliance falls off the charging station, it could cause injuries, property damage or product damage.

Charging the Spare Battery


After the vacuum cleaner has finished charging, the spare battery will start charging.

One or two batteries are provided. The number of batteries varies depending on the model purchased.


1 Lift the front of the control panel located at the top of the charging station.



2 To insert, align the battery with the outline of the battery charger.



3 Press the battery down into the compartment.



NOTE

 The spare battery icon (==) in the status display flashes during charging and then lights up briefly and turns off to save energy when charging is complete. Insert the spare battery completely. If the spare battery is inserted correctly, the spare battery icon (
) flashes.

Using the Mop Nozzle


Before Using the Mop Nozzle

- The mop pads only rotate at one speed regardless of what suction power setting the product body is set to.
- To prevent product damage, the mop attachment plate will automatically stop if there are foreign objects stuck in the plate or if it is subjected to a strong impact. Turn the appliance off immediately and remove the foreign objects or obstructions before resuming use.
- If you hear a noise while mopping, the mop pad may have dropped off the mop attachment plate. Turn off the product immediately and reattach the mop to the attachment plate before resuming use.
- Do not use a soiled mop pad to clean floors.
- Use only authorized LG Electronics mop pads.
- Empty the dust bin and clean the exhaust filter and the pre-filter after using the mop nozzle.

Using the Wet Mop Pads

Press the **Power** button. You can use the only mop mode and not turn on the dust suction function.

 Press the + button to turn on the dust suction function.




 Press the — button once while pressing the + button once to turn off the dust suction function.

A CAUTION

- Do not assemble or disassemble the nozzle while the appliance is turned on. Doing so may result in injury.
- Set the water adjustment button to the STOP position when not using the appliance for an extended period of time. Failure to do so may result in product failure.
- Do not let the appliance stand on the floor while the wet mop pads are attached. Doing so may result in damage or swelling to wood flooring.
- Do not use on PVC or PU mat for infants or children. Friction can cause the motor to overheat.
- If you use the mop nozzle for a long time with the suction off, the motor may overheat (recommended duration of use: 80 minutes).
 When the moter overheats, the overheating prevention function is activated and the appliance is automatically turned off. Use the appliance after cooling the heat for about one hour in a cool, well-ventilated place.


Filling the Water Tank

1 Press the **PUSH** button **1** to remove the water tank from the mop nozzle.




2 Open the water inlet cap 2 of the water tank and fill the tank with water.


• Do not put liquid other than water and hot water in the water tank.



- 3 Close the water inlet cap tightly.
 - If the water inlet cap is not closed properly, water may leak.




- 4 Attach the water tank to the mop nozzle again.
 - Insert the 2 tabs 3 at the front of the water tank into the slots 4 on the top of the mop nozzle. Press down at the centre 5 to lock the tank in place.




Attaching the Mop Pads

- 1 Wet both sides of the mop pads with water then squeeze out any excess water before attaching the pads.
 - Do not attach pads while they are dripping wet.

• Attaching and using mop pads while they are dry may affect the cleaning results.



- 2 Place the mop nozzle upside down on the floor.
- 3 Align and attach the centre of the mop pad with the centre of the mop attachment plate.
 - Attach the Velcro on the mop pad to the mop plate. Attaching the mop pad upside down or improperly may affect the cleaning results.



4 Assemble the mop nozzle to the appliance.

Adjusting the Amount of Water

Slide the water adjustment slider button to adjust the amount of water released onto the mop pad to either **High Mode** or **Low Mode**.



High Mode: Slide the slider button to clean ingrained dirt or supply a large amount of water.



Low Mode: Slide the slider button to supply a small amount of water for cleaning wood or other flooring that can be damaged by too much water.



STOP: Position the slide button in the center. This stops the supply of water so you can go over areas that are already wet.

WARNING

 To avoid injury, do not attach the mop pad while the mop attachment plate is rotating.

A CAUTION

 Do not let the appliance stand on the floor while the wet mop pads are attached. Doing so may result in damage or swelling to wood flooring.

Using with the Mop Nozzle

- 1 Attach the water tank and mop pads to the mop nozzle.
- Slide the water adjustment slider button to adjust the amount of water released onto the mop pad to either High Mode or Low Mode.
- 3 Press the **Power** button to start cleaning.

Drying the Water Tank and Mop Pads

Drying the Water Tank


When cleaning is completed, make sure to empty the water tank and dry it before storing the mop nozzle.

A CAUTION


- Turn the water inlet caps to make sure they remain open when storing the water tank. If caps are closed and not properly dried, it may cause odour.
- Do not remove the water inlet caps from the water tank. Caps may tear.

A CAUTION

- Do not add detergent, vinegar or baking soda to the water tank when washing. It is not easily removed in the water tank, which may soil the floor.
- After cleaning, wipe off any remaining water on the water supply inlet ① on the mop nozzle with a soft cloth. The water could drip onto the floor and damage it.




- Do not pull or stretch the rubber gasket on the water supply inlet. Doing so may tear or damage it.
- Open the water inlet cap on the side of the water tank and empty the water tank. Shake the water tank to remove the remaining water.




2 Leave the water inlet cap open and allow the water tank to dry in a well-ventilated area out of direct sunlight for at least 24 hours.

 Keep the water tank after water is completely empty and dry. Moisture or residual water in the tank may cause odour.



NOTE

- If the water supply pipe inside the mop nozzle is filled with water, water may not come out properly when the mop nozzle is used. If water does not come out properly, follow the steps below.
 - 1 Attach a wet mop to the mop nozzle where the water tank is separated and set the amount of water to **High Mode**.



2 Place the mop nozzle on the floor, turn on the power, and let it run for about 1 minute.


Drying the Mop Pads

After using the mop pads, hand wash them and allow them to dry before storing them.

CAUTION

 Do not use as follows, as it may become deformed.

- Do not use bleach or fabric softener when washing the mop pads.
- Do not dry the pads in a clothes dryer.
- Do not boil the mop pad.
- Separate the mop pads from the mop attachment plate.
- **2** Hand wash the pads with a neutral detergent.
 - Storing mop pads in a damp state can result in an unpleasant odour. Set the pads in a well-ventilated area out of direct sunlight for at least 24 hours or until completely dry.



Using the Nozzles and Tools

Before Using the Nozzles and Tools

Some accessories are only available on some models.

Specialized attachments can help you clean more effectively. Tools and nozzles can be attached to the product body or the extension pipe.

- Adjust the suction power if the inlet gets stuck on the floor, carpet, or bedding.
- Each Nozzle is equipped with a motor and may make a sound when operating.

A CAUTION

 Do not use the Carpet Nozzle or Slim Hard Floor Nozzle on PVC or polyurethane mats for infants and children. The mat may stick to the nozzle, making it difficult to operate, causing damage to the mat or static electricity on the appliance. Clean mats using the crevice tool.

Dual Floor Max Nozzle

Use this nozzle to clean carpets, rugs or hard floor surfaces.

Wide Hard Floor Nozzle

Use this nozzle to clean hard floor surfaces.

 While cleaning, accidentally pressing the PUSH button on the nozzle may remove the brush. Please re- attach the brush again.

Pet Nozzle

It is suitable for soft surfaces and pet hair removal.




CAUTION

- Do not use the nozzle following surface. It may cause scratch or damage. Especially, do not clean a coated or lacquered floor. If used repeatedly, the coating may wear off.
 - Clothing, bedding
 - Leather cushioned sofas, cushions
 - Carpet
 - Vinyl flooring, tiles, marble, etc.

Bedding Nozzle

This nozzle lets you clean sheets and bedding more effectively. It removes dust in bedding using strong suction and a punching motion.


 Lower the suction level when vacuuming bedding such as duvet covers to avoid the thin fabric getting sucked into the nozzle.



Crevice Tool

Use this tool to remove dust from corners or narrow spaces.

- Use it for areas with static electricity such as mats.
- Use it with the **Turbo** mode to clean pet hair out of furniture, mats, or tight areas like corners.



Combination Tool

Can be used in either crevice mode or brush mode for cleaning corners or small gaps where dust and dirt gather.

· Crevice Mode


Use the tool in the crevice mode to clean flat surfaces such as sofas or mattresses.



Brush Mode


Use the tool in the brush mode to clean delicate surfaces such as frames or furniture.

- To convert modes, press the adjustment button **1** and push forward.




Hard Dirt Tool

Firm bristles remove solidified dirt from hard surfaces. Clean up hair or foreign objects that are entangled in carpets or rugs.



Mattress Tool


Use this tool to clean up dust and foreign objects from mattresses, delicate fabrics, and upholstery.



Flexible Crevice Tool

This tool is flexible and its length can be adjusted, making it especially useful for cleaning inside


vehicles or in narrow spaces under and behind furniture where an angled tool is needed.



Using the Brush


To convert the tool from crevice to brush mode, press in on the sides of the brush head **1** and pull the brush down.

 To convert back to the crevice mode, press in on the brush release button 2 and slide the brush up.



Adjusting the Length

To adjust the length of the tool, press and hold the release button ③ on the side of the tool. Pull or push on the brush head ④ to extend or retract the extension tube.



Multi-angle Tool


This tool has a soft brush that can be adjusted to a variety of angles, making it especially useful for cleaning vehicle consoles or the tops of furniture.



Flexible Hose Extension

Connect this flexible, extendable hose between the product body and the tools to clean hard to reach areas.

 The flexible hose extension cannot be used with the Nozzle.



Using the Kompressor Lever

Use the Kompressor lever to compress hair and fibers inside the dust bin after vacuuming and before emptying the dust bin.

- The vacuum must be turned off before using the Kompressor lever.
- Compressing the dust clears it off the interior walls of the dust bin and allows you to vacuum for longer periods before emptying the dust bin. It also makes cleaning the dust bin easier and less messy.
- The dust bin must be at least half full for the compression plate to be effective.
- Press the Kompressor lever down several times to compress the dust and clean off the interior walls of the dust bin.

SMART FUNCTIONS

Using LG ThinQ Application

The **LG ThinQ** application allows you to communicate with the appliance using a smartphone.

LG ThinQ Application Features

- · Setting the default mop operation
 - This function allows the setting of the default operation mode of the Mop Nozzle.
- · Cleaning History
 - Shows the cleaning history, such as monthly cleaning time, cleaning frequency, and cleaning mode, etc.

NOTE

- Assembled suction tool is displayed on the screen during cleaning.
- A notification is displayed on the screen if the pre-filter and the exhaust filter need cleaning.

Filter Cleaning Cycle Alarm

 After using the appliance for a centain period of time, a notification is displayed on the screen of your smartphone. Clean the exhaust filter or pre-filter, if necessary.

· Cleaning Mode

- The cleaning mode you are using is displayed on the screen of your smartphone.

· Filter Cleaning Guide

- Guide to cleaning the filters.

Smart Diagnosis™

 This function provides useful information for diagnosing and solving issues with the appliance based on the pattern of use.

NOTE

- In the following cases, you must update the network information for each appliance in the LG ThinQ application under Device Cards — Settings — Change Network.
 - wireless router is changed

- wireless router password is changed
- Internet service provider is changed
- This information is current at the time of publication. The application is subject to change for product improvement purposes without notice to users.

Installing LG ThinQ App and Connecting an LG Appliance

Models with QR Code

Scan the QR code attached to the product using the camera or a QR code reader app on your smartphone.



Models without QR Code

- Search for and install the LG ThinQ app from the Google Play Store or Apple App Store on a smartphone.
- 2 Run the LG ThinQ app and sign in with your existing account or create an LG account to sign in.
- **3** Touch the add (+) button on the **LG ThinQ** app to connect your LG appliance. Follow the

instructions in the app to complete the process.

NOTE

- You may be asked to provide a password to connect to the LG network (not your home network) during the Wi-Fi setup. The password is the last 4 characters of the network name, repeated twice, with no spaces. For example, if the network name appears as LG_XXXX_8b92, then you would enter 8b928b92 as your password. The password is case sensitive and the last 4 characters are unique to your appliance.
- To verify the Wi-Fi connection, check that the sicon on the control panel is lit.
- The appliance supports 2.4 GHz Wi-Fi networks only. To check your network frequency, contact your Internet service provider or refer to your wireless router manual.
- LG ThinQ is not responsible for any network connection problems or any faults, malfunctions, or errors caused by network connection.
- If the appliance is having trouble connecting to the Wi-Fi network, it may be too far from the router. Purchase a Wi-Fi repeater (range extender) to improve the Wi-Fi signal strength.
- The Wi-Fi connection may not connect or may be interrupted because of the home network environment.
- The network connection may not work properly depending on the Internet service provider.
- The surrounding wireless environment can make the wireless network service run slowly.
- If the appliance cannot be connected due to problems with the wireless signal transmission, unplug the appliance and wait about a minute before trying again.
- If the firewall on your wireless router is enabled, disable the firewall or add an exception to it.
- The wireless network name (SSID) should be a combination of English letters and numbers. (Do not use special characters.)
- Smartphone user interface (UI) may vary depending on the mobile operating system (OS) and the manufacturer.

 If the security protocol of the router is set to WEP, network setup may fail. Change the security protocol (WPA2 is recommended) and connect the product again.

Connecting the Appliance to LG ThinQ

Wi-Fi Indicator 🛜 Status

Indicator Status	Description
Blinking	The appliance is connecting.
ON	The appliance has finished connecting. The appliance is connected to Wi-Fi.
OFF	The appliance has been disconnected.

Connecting the Appliance Initially

Select your appliance on menu by pressing the **Add** a **Product** (+) button. Follow instructions in the **LG** ThinQ to connect your appliance.

Connecting Additional Users

Remove the appliance from the charging station. Follow the instructions under **Connecting the Appliance Initially**.

NOTE

- The usage history will be reset if you delete a connected appliance in LG ThinQ.
- If the Wi-Fi signal is weak, the appliance may be temporarily disconnected to the application.
 When the Wi-Fi signal moves to the normal position, the appliance is connected to the application again.

Turning Wi-Fi On/Off on the Appliance

Disconnecting from Wi-Fi

To save energy, turn off the Wi-Fi function by pressing the **Wi-Fi** button for 3 seconds while the appliance is charging on the charging station.

Reconnecting to Wi-Fi

Follow the steps below on the appliance.

- 1 Press and hold the **Wi-Fi** button for 3 seconds until the **♠** icon blinks in the display.
- 2 Press the **Wi-Fi** button for 3 seconds again.
 - After the icon turns off, wait for a while and turn it on again.
 - The time before the icon turns on may vary depending on the network environment.

Wireless LAN Module Specifications

Model	LCW-007
Frequency Range	2412 to 2472 MHz
Output Power (Max.)	IEEE 802.11b: 17.59 dBm
	IEEE 802.11g: 17.39 dBm
	IEEE 802.11n(HT20): 16.64 dBm
	IEEE 802.11n(HT40): 17.05 dBm

Wireless function S/W version: V 1.0

Open Source Software Notice Information

To obtain the source code that is contained in this product, under GPL, LGPL, MPL, and other open source licenses that have the obligation to disclose source code, and to access all referred license terms, copyright notices and other relevant

documents, please visit https://opensource.lge.com.

LG Electronics will also provide open source code to you on CD-ROM for a charge covering the cost of performing such distribution (such as the cost of media, shipping, and handling) upon email request to opensource@lge.com.

This offer is valid to anyone in receipt of this information for a period of three years after our last shipment of this product.

Smart Diagnosis Function

Use this feature to help you diagnose and solve problems with your appliance.

NOTE

- For reasons not attributable to LGE's negligence, the service may not operate due to external factors such as, but not limited to, Wi-Fi unavailability, Wi-Fi disconnection, local app store policy, or app unavailability.
- The feature may be subject to change without prior notice and may have a different form depending on where you are located.

Using LG ThinQ to Diagnose Issues

If you experience a problem with your Wi-Fi equipped appliance, it can transmit troubleshooting data to a smartphone using the **LG ThinQ** application.

 Launch the LG ThinQ application and select the Smart Diagnosis feature in the menu. Follow the instructions provided in the LG ThinQ application.

MAINTENANCE

Cleaning the Appliance

Before Cleaning the Appliance

To maintain the optimum suction power, the cyclonic mesh filter, the exhaust filter and the prefilter should be cleaned regularly and washed under running water at least once a month.

- Turn off the power before cleaning the appliance.
- The frequency of cleaning varies depending on the usage environment and usage time. In a dusty environment, clean frequently.

A WARNING

- Never wash the Nozzle, rotating brush or product body with water. Water could reach the motor and cause electric shock or fire.
- Do not use the cleaner without any of the filter fitted as this will allow foreign objects to enter the motor. Doing so may cause electric shock, fire or product damage.
- Do not insert fingers or sharp objects into the motor. Doing so could cause product damage, personal injury or electric shock.

A CAUTION


- Do not apply force or allow impacts to the cyclonic mesh filter. Doing so could deform the filter, compromise product performance, or cause the product to malfunction.
- If the Kompressor lever does not return to the top, remove the cyclonic mesh filter from the dust bin and clean it. A clogged or dirty filter may cause poor cleaning results.

Removing Foreign Objects

If the appliance is clogged with foreign objects, the suction power changes, the motor cycles repeatedly, and the foreign objects clogging alarm icon blinks.

If clogging persists, the appliance will turn off automatically to prevent damage. Separate the battery from the product body and remove the foreign objects before resuming use of the appliance.

- Check the inside of the product body, above the Kompressor working plate, the extension pipe, inlets, exhaust filter, pre-filter and cyclonic mesh filter for foreign objects.
- If the inlets are not completely blocked, the foreign objects clogging alarm indicator may not light up.
- If the sound of the appliance becomes loud or the cleaning performance is poor, check for foreign objects.




Cleaning the Dust Bin

Empty and clean the dust bin after every use.

 If the dust bin is completely full of dust or the filter is clogged, the suction power will be reduced.


A CAUTION

- Do not use the appliance without the cyclonic mesh filter installed. Doing so could damage the appliance.
- 1 Remove the battery from the product body before cleaning the dust bin.
- 2 Push down the Kompressor lever ① several times to collect and compact the dust from the outside of the cyclonic mesh filter and the interior walls of the dust bin.
 - Foreign objects which become lodged in the cyclonic mesh filter may be difficult to dislodge with the Kompressor lever. Remove the cyclonic mesh filter and use the cleaning brush, etc. to clean it.




- Press the dust bin cover release button 2 to open the dust bin cover. Shake the dust bin to empty it.
 - Be careful as dust or foreign objects may spill out when opening the dust bin. Empty the dust bin into a wastebasket or where dust and foreign objects can be easily removed.

 The dust bin can be wrapped in a plastic bag to contain the dust when emptying the dust bin.



WARNING

- If the Kompressor lever does not slide down smoothly, foreign objects may be trapped between the dust bin and the cyclonic mesh filter. Clean the dust bin and cyclonic mesh filter to avoid product damage.
- Do not force the Kompressor lever down if foreign objects are caught around the working plate of the Kompressor system. Doing so may cause product damage.
- 4 Insert the crevice tool 4 into the cyclonic mesh filter 3 and turn it counterclockwise to remove the filter.




- **5** Wash the cyclonic mesh filter under running water.
 - To avoid odour and the malfunction of the motor, allow the cyclonic mesh filter to dry completely in a well-ventilated area out of


direct sunlight for at least 24 hours before reassembling.



- **6** Use the combination tool **5** to clean out dust or foreign objects inside the dust bin.
 - Do not wash the product body or motor with water.




- 7 Turn the product body over and lift the Kompressor lever up to clean the inside of the working plate with the cleaning brush, etc.
 - Do not push the Kompressor lever down hard. The working plate may be damaged.



8 Turn the product body over again and shake it while pressing down the lever to remove the dust.

9 Turn the product body over, lift the Kompressor lever **6** up, and clean the inside of the working plate with the cleaning towel.




Cleaning the Filters

Clean the exhaust filter and the pre-filter when the filter cleaning icon 🗟 lights up.

 Clean the filters more frequently if the appliance is used regularly or in areas with a lot of dust.


A CAUTION

- Do not use the appliance without the exhaust filter and pre-filter installed. Doing so could result in product damage.
- 1 Remove the battery from the product body.
- 2 Rotate the exhaust filter 1 to the unlocked position 2 to separate it from the product body.




3 Grip the exhaust filter cover **3** and the exhaust filter **1** using both hands and rotate the exhaust filter cover while pressing the **PUSH**

button in order to separate it from the exhaust filter.



4 Lift out the pre-filter 4 from the product body.



- **5** Use the combination tool **6** to clean any dust off the motor.
 - · Do not wash the motor with water.




- 6 Clean filters by regularly brushing the dust off and wash them in running water at least once a month.
 - To avoid odour and the malfunction of the motor, allow the exhaust filter to dry completely in a well-ventilated area out of


direct sunlight for at least 24 hours before reassembling.




Align the lock position of the exhaust filter cover with the letter "H" of the PUSH button on the exhaust filter.



Push and insert the exhaust filter cover into the exhaust filter and rotate it to reassemble it and prevent it from falling out.



9 Insert the dried pre-filter and rotate the exhaust filter to the locked position **6** to reassemble it on the product body.



Cleaning the Nozzles

Clean the nozzle and rotating brush regularly.


A CAUTION

- Always separate the nozzle from the product body or remove the battery before cleaning. If the nozzle starts to operate during cleaning, it could cause an injury.
- Keep fingers away from pinch points when assembling the nozzle on the appliance or the rotating brush on the nozzle.
- Do not use the rotating brush as a wet mop. It may cause product damage.
- Do not rinse or submerge the rotating brush or nozzle in water. It may cause product damage.


Cleaning the Dual Floor Max

Clean the brush and roller heads before each use.

 If the brush contains foreign objects, the brush may not spin or a noise may occur during operation. 1 Press the nozzle release button 1 to remove the nozzle from the extension pipe or product body.




Turn the nozzle upside down. Press the button on the nozzle and turn the cover lock clockwise.



3 Pull the brush cover forward and pull the main brush out.




4 With the left button of the sub-brush pressed, pull the sub-brush out.




5 Attach the crevice tool to the product body and use the vacuum to remove foreign objects and

dust from the main brush, sub-brush and the bottom of the nozzle.



- **6** Use a damp towel or cloth to remove any remaining foreign objects and dust from both the brush and the bottom of the nozzle.
 - Carefully use a tweezers to remove foreign objects from the nozzle rollers.
 - Do not rinse or submerge the rotating brush or nozzle in water.
 - Use a wet towel or cloth to clean both the rotating brush and nozzle.





7 Slide the brushes back into the nozzle and rotate the cover back into place. Turn the cover lock clockwise to lock the cover.


Cleaning the Wide Hard Floor Nozzle

A CAUTION

- Be careful not to injure your fingers when using a screwdriver.
- 1 Press the nozzle release button 1 to remove the nozzle from the extension pipe or product body.




2 Turn the nozzle upside down and remove the rotating brush while holding down the **PUSH** button on the nozzle.




NOTE


 When removing the rotating brush from the nozzle, part of the edge of the rotating brush may detach. Reassemble the rotating brush by holding the rotating brush and the detached part of the edge and pushing them in until a click is heard.




3 Attach the crevice tool to the product body and use the vacuum to remove foreign objects and dust from the brush and the bottom of the nozzle.




- 4 Use a damp towel or cloth to remove any remaining foreign objects and dust from the brush and the bottom of the nozzle.
 - Do not wash the rotating brush and the nozzle with water or immerse them in water.
 - Use a wet towel or cloth and to clean the rotating brush and nozzle.



5 Remove foreign objects, debris and hair from all Rollers of the nozzles using tweezers.



6 You can clean the inside of the small roller by inserting a flat-head screwdriver into the groove and removing the fixing part.




Reassemble the small roller and the fixing part and make sure that they are properly attached.




When holding both ends of the rotating brush and pulling it out, the rotating brush and part of the edge will separate. If hair is wrapped


around the edge of the rotating brush, remove the rotating brush and clean it.



Reassemble the rotating brush and the part of the edge and insert the end of the rotating brush into the groove at the end of the nozzle.



10 Slide the brush back into the nozzle until it clicks into place.




Cleaning the Pet Nozzle


1 Press the nozzle release button **1** to remove the nozzle from the extension pipe or product body.




2 Remove the rotating brush while holding down the **PUSH** button on the nozzle.




3 Attach the crevice tool to the product body and use the vacuum to remove foreign objects and dust from the brush and the bottom of the nozzle.




4 Use a damp towel or cloth to remove any remaining foreign objects and dust from the brush and the bottom of the nozzle. Remove foreign objects, debris and hair from all Rollers of the nozzles using tweezers.



5 Insert the left side of the brush 2 into the groove 3 inside the nozzle.




6 Press the cover of the brush to lock the brush until a clicking sound is heard.



Cleaning the Bedding Nozzle


- 1 Press the nozzle release button to remove the nozzle from the extension pipe or product body and turn the nozzle upside down.
- 2 Attach the crevice tool to the product body and use the vacuum to remove foreign objects and dust from the bottom of the nozzle. Use a damp towel or cloth to remove any remaining foreign objects and dust from the bottom of the nozzle. Remove foreign objects, debris and hair from all Rollers of the nozzles using tweezers.



Cleaning the Mop Nozzle

- 1 Press the nozzle release button to remove the mop nozzle from the extension pipe and turn the nozzle upside down.
- Use a damp towel or cloth to remove any remaining foreign objects and dust from the bottom of the mop nozzle. Remove foreign

objects, debris and hair from all Rollers of the nozzles using tweezers.



TROUBLESHOOTING

Before Calling for Service

Operation

Symptoms	Possible Cause & Solution
The appliance does not operate.	Battery is fully discharged.
	Charge the battery.
	Appliance is turned off.
	Press the Power button to turn on the appliance.
Suction power is too weak.	Dust bin is full of dust.
	Empty the dust bin.
	Filters are clogged.
	Clean the pre-filter and the exhaust filter.
	Inlet is clogged.
	Remove any foreign objects from inside the product body or the extension pipe.
	Foreign object is on rotating brush, or in inlet port.
	Remove any foreign objects (thread, hair) from the rotating brush or the inlet port.
The product body does	Power cord is unplugged.
not appear to be charging.	Plug the power cord securely into the outlet.
	Foreign object is on the charging terminals.
	Remove dirt or foreign objects from the charging terminals with a dry cloth.
Hot air is coming from	Motor is cooling.
the product body.	If the appliance is running normally, the hot air is a result of the motor
	cooling and is not a sign of malfunction.
The Kompressor lever does not return.	cooling and is not a sign of malfunction. Foreign objects which become lodged in the cyclonic mesh filter may be difficult to dislodge with the Kompressor lever.
-	Foreign objects which become lodged in the cyclonic mesh filter may be
does not return. A strange odour is	Foreign objects which become lodged in the cyclonic mesh filter may be difficult to dislodge with the Kompressor lever.
A strange odour is coming from the	Foreign objects which become lodged in the cyclonic mesh filter may be difficult to dislodge with the Kompressor lever. • Remove the cyclonic mesh filter and use the cleaning brush, etc. to clean it.
does not return. A strange odour is	Foreign objects which become lodged in the cyclonic mesh filter may be difficult to dislodge with the Kompressor lever. Remove the cyclonic mesh filter and use the cleaning brush, etc. to clean it. Appliance was purchased within the last 3 months.
A strange odour is coming from the	Foreign objects which become lodged in the cyclonic mesh filter may be difficult to dislodge with the Kompressor lever. Remove the cyclonic mesh filter and use the cleaning brush, etc. to clean it. Appliance was purchased within the last 3 months. The cleaner may emit a smell of rubber for about 3 months after purchase.

Symptoms	Possible Cause & Solution
A strange odour is coming from the appliance.	Foreign object is on the filter.
	The filter may emit an odour if it has not been cleaned for some time. Clean the pre-filter and exhaust filter regularly.
	Pre-filter, Exhaust Filter or the Cyclonic Mesh Filter were installed while damp or wet.
	Wash the filters with running water. To avoid odour, allow the pre-filter to dry completely in a well-ventilated area out of direct sunlight for at least 24 hours before reassembling.
	Exhaust filter was installed while damp or wet.
	Wash the exhaust filter with running water. To avoid odour, allow the exhaust filter to dry completely in a well-ventilated area out of direct sunlight for at least 24 hours before reassembling.
The appliance makes	Vacuum cleaner is running in Turbo mode.
too much noise.	The motor may be louder at the higher suction power settings. This is normal.
The appliance turns off	Battery is not fully charged.
unexpectedly or by itself after the motor speed fluctuates repeatedly.	The battery must be fully charged before cleaning. If the problem persists when the battery is fully charged and the pipes and attachments are clear from obstructions, contact an LG customer information centre for service.
	Foreign object is in the product body, extension pipe, inlet port or nozzle.
	Remove any foreign objects from the product body, extension pipe, inlet port or nozzle.
	Filters are clogged.
	Clean the pre-filter and the exhaust filter.
The rotating brush does not rotate.	Brush is improperly installed.
	Remove the brush, clean it if necessary and attach it again.
	Foreign object is on rotating brush.
	Remove any foreign objects from the rotating brush.

Mop Nozzle

Symptoms	Possible Cause & Solution
The mop pad attachment plate does not rotate.	 Mop pads are improperly installed. Remove the mop pads, clean them if necessary and attach them again.

Symptoms	Possible Cause & Solution
The mop pad attachment plate does not rotate.	Mop nozzle is pressed too hard against the floor.
	The mop attachment plate stops automatically to protect the product. This is not a failure. Attach the mop pads securely to the mop attachment plate and press the power button to resume use.
	Foreign object is between mop attachment plate and mop pads.
	Remove foreign objects from the mop nozzle attachment plate and press the power button to resume use.
There is no water	Water tank is empty.
coming out of the mop nozzle.	Fill the water tank. Remove the battery or detach the nozzle before filling the water tank.
	Water tank is improperly attached to mop nozzle.
	Properly attach the water tank to the mop nozzle. Remove the battery or detach the nozzle before properly securing the water tank to the nozzle.
	Water supply adjustment button is set to STOP.
	Press the High or Low water adjustment button all the way down. The water will not come out if the button is set to STOP .
	The water outlet was clogged by hard water scale or other foreign substances.
	Use a sharp pin to remove the blockage.
There is moisture in	Water tank is not allowed to dry completely after use.
the water tank.	Empty the water tank, set it out of direct sunlight, and allow it to dry completely after use.
A strange odour is	Foreign object is on the dust inlet of the mop nozzle.
coming from the appliance.	Wet dust in the mop nozzle may result in odour. Make sure to wipe the dust inlet of the mop nozzle with a wet wipe after each use.
Mop pads make the	Mop pads are not cleaned properly after use.
floor dirty.	Clean the mop pads thoroughly after each use. Using soiled mop pads may make the floor dirtier.
The appliance makes too much noise.	This is the sound generated when the pump at the inlet of the mop is operating.
	This is normal.
	The mop pads were improperly attached on the plates.
	Align and attach the centre of the mop pad with the centre of the mop attachment plate.

Wi-Fi

Symptoms	Possible Cause & Solution
Your home appliance and smartphone are not connected to the Wi-Fi network.	Battery is fully discharged.
	Charge the battery, then register your appliance on LG ThinQ.
	The password for the Wi-Fi that you are trying to connect to is incorrect.
	Find the Wi-Fi network connected to your smartphone and remove it, then register your appliance on LG ThinQ .
	Mobile data for your smartphone is turned on.
	Turn off the Mobile data of your smartphone and register the appliance using the Wi-Fi network.
	The wireless network name (SSID) is set incorrectly.
	The wireless network name (SSID) should be a combination of English letters and numbers. (Do not use special characters.)
	The router frequency is not 2.4 GHz.
	Only a 2.4 GHz router frequency is supported. Set the wireless router to 2.4 GHz and connect the appliance to the wireless router. To check the router frequency, check with your Internet service provider or the router manufacturer.
	The distance between the appliance and the router is too far.
	If the distance between the appliance and the router is too far, the signal may be weak and the connection may not be configured correctly. Move the location of the router so that it is closer to the appliance.

Additional Information

EAC - Eurasian Conformity Mark



The Eurasian Conformity mark (EAC) is a certification mark to indicate that the product conforms to all technical regulations of the Eurasian Customs Union procedures.

Information of the Packaging Materials



The symbol "not for food products" is applied in accordance with the technical regulations of the Customs Union "On the safety of packaging" 005/2011 and indicates that the packaging of this product is not intended for reuse and is recyclable. It is prohibited to use the packaging of this product for storage of food products.



The symbol "Moebius loop" indicates the possibility of recycling the package. The symbol can be supplemented by the designation of the packaging material in the form of a digital and / or letter designation.

Information of the Production Date

Production date indicated on the label located inside the battery cavity at the bottom of the handle on the product body.

Format of Date: MM/YYYY

LG Customer Support Service

Information on certification of our devices, data on the certificate number and its validity period, you can get in the LG Customer Support Service by free phones.

