

# OWNER'S MANUAL LED LCD Monitor (LED Monitor\*)

\*LG LED Monitors are LCD Monitors with LED Backlighting.

Please read this manual carefully before operating your set and retain it for future reference.

#### LED LCD MONITOR MODEL

32MP58HQ

# **CONTENTS**

## 3 LICENSE

## 4 ASSEMBLING AND PREPAR-ING

- 4 Unpacking
- 6 Parts and buttons
- 6 How to Use the Joystick Button
- 7 Input Connector
- 8 Moving and Lifting the Monitor
- 9 Setting up the Monitor set
- 9 Attaching the Stand Base
- 10 Detaching the Stand Base
- 11 Mounting on a table
- 12 Using the cable holder
- 13 Installing the wall mount
- 14 Mounting on a wall

# 15 USING THE MONITOR SET

- 15 Connecting to a PC
- 15 D-SUB connection
- 15 HDMI connection
- 16 Connecting to AV Devices
- 16 HDMI connection
- 17 Connecting to External Devices
- 17 Peripheral device connection

# 18 CUSTOMIZING SETTINGS

- 19 Customizing settings
- 19 Menu Settings
- 19 - Quick Settings
- 21 Picture
- 24 -General
- 25 Auto Configuration
- 26 Reset
- 27 - Picture Mode

## 28 TROUBLESHOOTING

## **30** SPECIFICATIONS

- 31 Preset Modes (Resolution)
- 31 Indicator

#### **32 PROPER POSTURE**

32 Proper posture for using the Monitor set.

# **LICENSE**

Each model has different licenses. Visit www.lg.com for more information on the license.



The terms HDMI and HDMI High-Definition Multimedia Interface, and the HDMI Logo are trademarks or registered trademarks of HDMI Licensing Administrator, Inc.

The following content is only applied to the monitor which is sold in Europe market and which needs to meet the ErP Directive:


<sup>\*</sup> This monitor is set to be turned off automatically in 4 hours after you turned on display if there is no adjustment to display.

<sup>\*</sup> To make this setting be disabled, change the option to 'Off' in OSD menu of "Automatic Standby".

# **ASSEMBLING AND PREPARING**

# **Unpacking**

Check your product box for the following items. If there are any missing accessories, contact the local dealer where you purchased your product. The illustrations in this manual may differ from the actual product and accessories.





#### **CAUTION** -


- Do not use any unapproved accessories to ensure the safety and product life span.
- Any damages or injuries by using unapproved accessories are not covered by the warranty.



#### NOTE -

- The accessories supplied with your product may vary depending on the model.
- Product specifications or contents in this manual may be changed without prior notice due to upgrade
  of product functions.

## **Parts and buttons**



- Off: power is off

## How to Use the Joystick Button

You can easily control the functions of the monitor by pressing the joystick button or moving it left/right with your finger.

#### **Basic Functions**

	ø	Power on	Press the joystick button once with your finger to turn on the monitor.
		Power off	Press and hold the joystick button once with your finger to turn off the monitor.
	<b>4/</b> ▶	Volume Control	You can control the volume by moving the joystick button left/right.




#### NOTE -

• The joystick button is located at the bottom of the monitor.

# **Parts and buttons**


# **Input Connector**



# **Moving and Lifting the Monitor**

When moving or lifting the monitor, follow these instructions to prevent the monitor from being scratched or damaged and to ensure safe transportation regardless of its shape or size.

- It is advisable to place the monitor in the original box or packing material before attempting to move it.
- Before moving or lifting the monitor, disconnect the power cord and all cables.
- Hold the top and bottom of the monitor frame firmly. Do not hold the panel itself.



 When holding the monitor, the screen should face away from you to prevent it being scratched.



- When moving the monitor, avoid any strong shock or vibrations to the product.
- When moving the monitor, keep it upright, never turn the monitor on its side or tilt it sideways.



#### CAUTION

 As far as possible, avoid touching the monitor screen. This may result in damage to the screen or some of the pixels used to create images.



# **Setting up the Monitor set**

# **Attaching the Stand Base**


1 1 Please put a soft cloth on a low table or box to protect the screen of the monitor.



Please put the monitor on the soft cloth with the screen facing down.



2 Please grab the Stand body in one hand, and push it in the direction of the arrow to hinge body. After assembling, you must check if the Stand body latched in or not.




3 1 Please push the Stand Base in the direction of the arrow as shown below and assemble together.




Stand Base

- 2 Please use a driver(-) or coin to insert thumb screw and turn right arrow direction lock.
  - \* It is necessary to thoroughly tighten it with **Thumb Screw**, or the monitor will shake.




- 4 Please set the Monitor upright, and install the necessary cable.
  - \* Must use one type input cable. Don't use more than two types cable together.



# **Detaching the Stand Base**

1 Please remove the cable installed to the monitor.




2 1 Please put a soft cloth on a low table or box to protect the screen of the monitor.




2 Please put the monitor on the soft cloth with the screen facing down.




31Please use the driver(-) or coin insert thumb screw and turn left arrow direction unlock.




Please pull the Stand Base in the direction of the arrow as shown below and disassemble as shown below.



4 After fixing the monitor in one hand, remove the Stand body by pulling it strongly in the direction of the arrow as shown below.



\* If it is difficult to remove, you can push the Latch with a small flat-head screw driver or a flat-headed tool and disassemble as shown below.






#### **CAUTION**

- Illustrations in this document represent typical procedures, so they may look different from the actual product.
- Do not carry the monitor upside down by just holding the stand base. This may cause the monitor to fall off the stand and could result in personal injury.
- When lifting or moving the monitor, do not touch the monitor screen. The force applied to the monitor screen may cause damage to it.
- If you use the monitor panel without the stand base, its joystick button may cause the moni-tor to become unstable and fall, resulting in damage to the monitor or human injury. In addition, this may cause the joystick button to malfunction.


## Mounting on a table

1 Lift and tilt the Monitor set into its upright position on a table.


Leave a 100 mm space from the wall for proper ventilation.



2 Connect the AC-DC Adapter and Power Cord to a wall outlet.



or




3 Press the joystick button on the bottom of the monitor to turn on the monitor.



#### **CAUTION**

Unplug the power cord before moving the Monitor to another location. Otherwise electric shock may occur.

## Using the cable holder




# WARNING -

When you adjust the angle, do not hold the bottom of the Monitor set frame as shown on the following illustration, as may injure your fingers.






Do not touch or press the screen when adjusting the angle of the monitor.




Do not hold this set like below picture. Monitor screen can detach from stand base and injure your body.



# 0

#### NOTE


Tilt from +10 to -5 degrees up or down to adjust the angle of the Monitor set to suit your view.



#### Using the Kensington security system

The Kensington security system connector is located at the back of the Monitor set. For more information of installation and using, refer to the manual supplied with the Kensington security system or visit <a href="http://www.kensington.com">http://www.kensington.com</a>.

Connect the Kensington security system cable between the Monitor set and a table.




# NOTE

The Kensington security system is optional. You can obtain it from most electronics stores.

## Installing the wall mount


Before installing the wall mount, please separate the stand hinge first as below.

- 1 Place the screen face down. To protect the screen from scratches, cover the surface with a soft cloth.
- 2 Detach the screw cover as below.
- 3 Remove the screws and separate the stand hinge.



## Mounting on a wall

For proper ventilation, allow a clearance of 100 mm on each side and from the wall. Detailed instructions are available from your dealer, see the optional Tilt Wall Mounting Bracket Installation and Setup Guide.




If you intend to mount the Monitor set to a wall, attach Wall mounting interface (optional parts) to the back of the set.

When you install the Monitor set using a wall mounting interface (optional parts), attach it carefully so it will not drop.

- 1 If you use screw longer than standard, the monitor might be damaged internally.
- 2 If you use improper screw, the product might be damaged and drop from mounted position. In this case, LG Electronics is not responsible for it.

Wall Mount (A X B)	200 x 100
Standard screw	M4 x L10
Number of screws	4
Wall Mount Plate (Optional)	LSW140B


Wall Mount (A X B)





#### **CAUTION**

- Disconnect the power cord first, and then move or install the Monitor set. Otherwise electric shock may occur.
- If you install the Monitor set on a ceiling or slanted wall, it may fall and result in severe injury.
- Use only an authorized LG wall mount and contact the local dealer or qualified personnel.
- Do not over tighten the screws as this may cause damage to the Monitor set and void your warranty.
- Use only screws and wall mounts that meet the VESA standard. Any damages or injuries by misuse or using an improper accessory are not covered by the warranty.
- Screw length from outer surface of back cover should be under 8mm.





- Use the screws that are listed on the VESA standard screw specifications.
- The wall mount kit will include an installation manual and necessary parts.
- The wall mount bracket is optional. You can obtain additional accessories from your local dealer.
- The length of screws may differ depending on the wall mount. Be sure to use the proper length.
- For more information, refer to the instructions supplied with the wall mount.


# **USING THE MONITOR SET**

# Connecting to a PC

 Your Monitor set supports Plug & Play\*.
 \*Plug & Play: A PC recognizes a connected device that users connect to a PC and turn on, without device configuration or user intervention.

#### **D-SUB** connection


Transmits analog video from your PC to the Monitor set. Connect the PC and the Monitor set with the supplied D-sub 15 pin signal cable as shown in the following illustrations.





#### NOTE

When using a D-Sub signal input cable connector for Macintosh




Mac adapter

For Apple Macintosh use, a separate plug adapter is needed to change the 15 pin high density (3 row) D-SUB VGA connector on the supplied cable to a 15 pin 2 row connector.

#### **HDMI** connection

Transmits the digital video and audio signals from your PC to the Monitor set. Connect the PC and the Monitor set with the HDMI cable as shown in the following illustrations.





- If you use HDMI PC, it can cause compatibility problem.
- Use a certified cable with the HDMI logo attached. If you do not use a certified HDMI cable, the screen may not display or a connection error may occur.
- Recommended HDMI cable types
- High-Speed HDMI<sup>®</sup>/<sup>™</sup> Cable
- High-Speed HDMI<sup>®</sup>/<sup>™</sup> Cable with Ethernet



#### **CAUTION**

- Connect the signal input cable and tighten it by turning the screws clockwise.
- screws clockwise.
  Do not press the screen with your finger for a long time as this may result in temporary distortion on the screen.
- Avoid displaying a fixed image on the screen for a long period of time to prevent image burn. Use a screensaver if possible.




#### NOTE

- When you want to use two PC in our Monitor, please connect the signal cable(D-SUB/ HDMI) respectively in Monitor set.
- If you turn the Monitor set on while it is cold, the screen may flicker. This is normal.
- Some red, green, or blue spots may appear on the screen. This is normal.

# **Connecting to AV Devices**

#### **HDMI** connection

Transmits the digital video and audio signals from your AV devices to the monitor. Connect your AV device to the monitor with the HDMI cable as illustrated below.






- If you use HDMI PC, it can cause compatibility problem.
- Use a certified cable with the HDMI logo attached. If you do not use a certified HDMI cable, the screen may not display or a connection error may occur.
- Recommended HDMI cable types
- High-Speed HDMI<sup>®</sup>/<sup>™</sup> Cable
- High-Speed HDMI®/™ Cable with Ethernet

# **Connecting to External Devices**

## Peripheral device connection

Connect peripheral devices to the monitor using headphone ports.





#### **NOTE**

- · Peripheral devices are sold separately.
- Cables with angled plugs may have clearance issues, use straight plugs when possible.







Straight Type




#### NOTE

 Headphones or speakers may not work normally, depending on the server PC settings.

# **CUSTOMIZING SETTINGS**

# **Activating the Main Menu**

- 1 Press the joystick button on the bottom of the monitor.
- 2 Move the joystick up/down (▲/▼) and left/right(◄/►) to set the options.
- 3 Press the joystick button once more to exit the main



Button	Menu Status		Description
	Main menu disabled  Main menu enabled		Enables the main menu.
			Exits the main menu. (Holding down the button to turn off the monitor: You can turn off the monitor this way at any time, including when the OSD is on.)
	•	Main menu disabled	Adjusts the monitor volume level. Enables the main menu.
		Main menu enabled	Enters the menu features.
	•	Main menu disabled	Adjusts the monitor volume level. Enables the main menu.
		Main menu enabled	Operates the Input change.
		Main menu disabled	Enables the main menu.
		Main menu enabled	Enters the picture mode feature.
	•	Main menu disabled	Enables the main menu.
E +		Main menu enabled	Turns off the monitor.

#### **Main Menu Features**




Main Menu	Description	
Menu	Configures the screen settings.	
Picture Mode	Select picture mode to achieve the best display effect.	
Input	You can operate the change of input signals.  • When two input signals over are connected and select the input menu, input signal(D-SUB/HDMI) will be changed sequentially.  • When only one signal is connected, it is automatically detected. The default setting is D-SUB.	
Monitor off	Turns off the monitor.	
Exit	Exits the main menu.	

# **Customizing settings**

## **Menu Settings**

### -Quick Settings

- 1 To view the **OSD menu**, press the **joystick button** at the bottom of the monitor and then enter the **Menu**.
- 2 Go to Quick Settings > Brightness by moving the joystick.
- 3 Configure the options following the instructions that appear in the bottom right corner.
- 4 To return to the upper menu or set other menu items, move the joystick to ◀ or pressing (◉ / OK) it.
- 5 If you want to exit the OSD menu, move the joystick to ◀ until you exit.



Each option is described below.

Menu > Quick Settings	Description			
Brightness	A divista the			
Contrast	Adjusts the C	color contrast and brightness of the screen.		
Volume	Adjusts the v	volume.		
	NOTE  • Jog joystick button down ( ) in the Volume menu will enable/disable the Mute function.			
Ratio	Adjusts the screen ratio.			
	Wide	Displays the video in wide-screen, regardless of the video signal input.		
	Original	Displays a video according to the input video signal aspect ratio.		
SMART ENERGY SAVING	High Enables SMART ENERGY SAVING you can save energy with this energy- high eff function.			
Low Enables SMART ENERGY SAVING you can save energy with thi efficient function.		Enables SMART ENERGY SAVING you can save energy with this energy- low efficient function.		
	Off Disables SMART ENERGY SAVING .			

<sup>\*</sup> SMART ENERGY SAVING: Conserve energy by using luminance compensation algorithm.




- The display may look the same for Wide, Original options at the recommended resolution (1920 x 1080).
- · The ratio is disabled in the interlaced signal.



- The value of energy saving data may differ depending on panel and panel suppliers.
- If you select the option of SMART ENERGY SAVING is High or Low, monitor luminance become lower or higher depend on source.

#### -Picture

- 1 To view the **OSD menu**, press the **joystick button** at the bottom of the monitor and then enter the **Menu**.
- 2 Go to Picture by moving the joystick.
- 3 Configure the options following the instructions that appear in the bottom right corner.
- 4 To return to the upper menu or set other menu items, move the joystick to ◀ or pressing (♠ / OK) it.
- 5 If you want to exit the OSD menu, move the joystick to ◀ until you exit.



Each option is described below.

Menu > Picture		Description		
Picture Mode Custom		Allows the user to adjust each element. The color mode of the main menu can be adjusted.		
	Reader 1	It is a mode that the screen is adjusted to the best for the newspaper. If you want screen more bright, you can control brightness in Menu OSD.		
	Reader 2	It is a mode that the screen is adjusted to the best for the cartoon. If you want screen more bright, you can control brightness in Menu OSD.		
	Photo	Optimizes the screen to view photos.		
	Cinema	Optimizes the screen to improve the visual effects of a video.		
	Color weakness	This mode is for users who cannot distinguish between red and green. It enables users with color weakness to easily distinguish between the two colors.		
	Game	Optimizes the screen for gameplay.		




- This is subsidiary for color weakness user. Therefore if you feel uncomfortable with the screen, please turn off this function.
- This function can't distinguish some colors in some images.

Picture Adjust	SUPER RESOLU- TION+	High	Optimized picture quality is displayed when a user wants crystal clear images. It is effective forhigh quality video or game.		
		Middle	The optimized picture quality is displayed when a user wants images between low and highmodes for comfortable viewing. It is effective for UCC or SD video.		
		Low	The optimized picture quality is displayed when a user wants smooth and natural images. It iseffective for slow-moving pictures or still images.		
		Off	Select this option for everyday viewing. SUPER RESOLUTION+ is turned off in this mode.		
	Sharpness	Adjusts the	sharpness of the screen.		
	Black Level	Offset: a	Sets the offset level (for HDMI only).  • Offset: as a reference for a video signal, this is the darkest color the monitor can display.		
		High	Keeps the current contrast ratio of the screen.		
		Low	Lowers the black levels raises the write levels from the current contrast ratio of the screen.		
	Response Time	Sets a response time for displayed pictures based on the speed of the screen. For a normal environment, it is recommended that you use Normal. For a fast-moving picture, it is recommended that you use High.  Setting to High may cause image sticking.			
		High	Sets the response time to High.		
		Middle	Sets the response time to Middle.		
		Low	Sets the response time to Low.		
		Off	Sets the response time to Off.		
	Overscan	To select the range of output image for DTV timing in HDMI inpu (only for HDMI input)Recommend overscan function to turn on v connect AV equipment.			
	DFC	Adjusts the brightness automatically according to the screen.			
	Black Stabilizer	scenes. Increasing tarea on the game scree Reducing the	ontrol the black contrast to have better visibility in dark the Black Stabilizer value brightens the low gray level screen. (You can easily distinguish objects on dark		

Color Adjust	Gamma	Likewise, the	e gamma value, the darker the image becomes. lower the gamma value, the lighter the image ou do not need to adjust the gamma settings, select
	Color Temp	Warm: Sets t Medium: Set	ctory default picture color. he screen color to a reddish tone. s the screen color between a red and blue tone. e screen color to a bluish tone.
		Custom	
		Red Green Blue	You can customize the picture color using Red, Green, and Blue colors.
	Six Color	and saturation Hue, Green_ Cyan_Satura	er requirements for colors through adjusting the color of the six colors(Red_Hue, Red_Saturation, Green_Saturation, Blue_Hue, Blue_Saturation, Cyan_Hue, tion, Magenta_Hue, Magenta_Saturation, Yellow_Saturation) and saving the settings.
		*Saturation: A the value, les	tone of the screen. djusts the saturation of the screen colors. The lower s saturated and bright the colors become. The higher more saturated and dark the colors become.
	Reset	Returns the color settings to the default settings.	
Display	Horizontal	To move image left and right.	
	Vertical	To move image up and down.	
	Clock	To minimize any vertical bars or stripes visible on the scree background. The horizontal screen size will also change.	
	Phase		focus of the display. This item allows you to remove I noise and clear or sharpen the image of characters.

#### -General

- 1 To view the OSD menu, press the joystick button at the bottom of the monitor and then enter the Menu.
- 2 Go to General by moving the joystick.
- 3 Configure the options following the instructions that appear in the bottom right corner.
- 4 To return to the upper menu or set other menu items, move the joystick to ◀ or pressing (◉ / OK) it.
- 5 If you want to exit the OSD menu, move the joystick to **⋖** until you exit.




Each option is described below.

Menu > General	Description			
Language	To choose the language in which the control names are displayed.			
Power LED	Turns the power	indicator on the front side of the monitor on/off.		
	On	The power indicator is automatically turned on.		
	Off	The power indicator is turned off.		
Automatic Standby		omatically turns off the monitor when there is no movement on the screen for You can set a timer for the auto-off function. (Off, 4 H, 6 H, and 8 H)		
Resolution		e desired resolution. This option is enabled only when the screen resolution on is set to the following (D-SUB only).		
	The function is enabled only when the screen resolution on your computer is set to the following, except that the PC output wrong resolution.  1024x768, 1280x768, 1360x768, 1366x768, Off			
	1280x960, 1600x900,Off			
	1440x900, 1600x900,Off			
OSD Lock	Prevents incorrect key input.			
	On Key input is disabled.			
	All functions except for the OSD Lock mode and the Exit button for Brightness, Contrast, Volume, Input, and General are disabled.			
	Off	Key input is enabled.		

## -Auto Configuration

- 1 To view the **OSD menu**, press the **joystick button** at the bottom of the monitor and then enter the **Menu**.
- 2 Go to Auto Configuration by moving the joystick.
- 3 Configure the options following the instructions that appear in the bottom right corner.
- 4 To return to the upper menu or set other menu items, move the joystick to ◀ or pressing (◉ / OK) it.
- 5 If you want to exit the OSD menu, move the joystick to ◀ until you exit.



Each option is described below.

Menu > Auto Configuration	Description	
Do you want to Auto Configuration?		
Yes	Operate the Auto Configuration for optimal display in D-SUB.	
Cancel	Cancel the select.	




#### **NOTE**

• This function will be enable only in analog input.

#### -Reset

- 1 To view the OSD menu, press the joystick button at the bottom of the monitor and then enter the Menu.
- 2 Go to Reset by moving the joystick.
- 3 Configure the options following the instructions that appear in the bottom right corner.
- 4 To return to the upper menu or set other menu items, move the joystick to ◀ or pressing (⑨ / OK) it.
- 5 If you want to exit the OSD menu, move the joystick to **⋖** until you exit.




Each option is described below.

Menu > Reset	Description
Do you want to reset your settings?	
Reset	Returns to the default settings.
Cancel	Cancel the select.

## -Picture Mode

- 1 Press the joystick button on the bottom of the monitor.
- 2 Go to **Picture Mode** by moving the joystick button to ▲.
- 3 Configure the options following the instructions that appear in the bottom.



Each option is described below.

Joystick Button > Picture Mode	Description		
Picture Mode	Custom	Allows the user to adjust each element. The color mode of the main menu can be adjusted.	
	Reader 1	It is a mode that the screen is adjusted to the best for the newspaper. If you want screen more bright, you can control brightness in Menu OSD.	
Reader 2		It is a mode that the screen is adjusted to the best for the cartoon. If you want screen more bright, you can control brightness in Menu OSD.	
	Photo	Optimizes the screen to view photos.	
	Cinema	Optimizes the screen to improve the visual effects of a video.	
	Color weak- ness	This mode is for users who cannot distinguish between red and green. It enables users with color weakness to easily distinguish between the two colors.	
	Game	Optimizes the screen for gameplay.	

# **TROUBLESHOOTING**

## Check the following before calling for service.

No image appears	
Is the power cord of the display connected?	Check and see if the power cord is connected properly to the power outlet.
Is the power indicator light on?	Press the Power button.
Is the power indicator flickering?	<ul> <li>If the display is in power saving mode, try moving the mouse or pressing any key on the keyboard to bring up the screen.</li> <li>Try to turn on the PC.</li> </ul>
Do you see an "OUT OF RANGE" message on the screen?	This message appears when the signal from the PC (video card) is out of horizontal or vertical frequency range of the display. See the 'Specifications' section of this manual and configure your display again.
Do you see a "NO SIGNAL" message on the screen?	This is displayed when the signal cable between the PC and the monitor is missing or disconnected. Check the cable and reconnect it.

Can 't you control some functions in OSD?		
	You can unlock the OSD controls at any time by entering the OSD	
OSD?	lock menu and changing items to off.	

Display image is incorrect	
Display Position is incorrect.	Enter the Auto Configuration function and select the "Yes" item to automatically adjust your display image to the ideal setting.
On the screen background, vertical bars or stripes are visible.	Enter the Auto Configuration function and select the "Yes" item to automatically adjust your display image to the ideal setting.
Any horizontal noise appearing in any image or characters are not clearly portrayed.	<ul> <li>Enter the Auto Configuration function and select the "Yes" item to automatically adjust your display image to the ideal setting.</li> <li>Check Control Panel ► Display ► Settings and adjust the display to the recommended resolution or adjust the display image to the ideal setting. Set the color setting higher than 24 bits (true color).</li> </ul>



#### CAUTION -

- Check Control Panel ➤ Display ➤ Settings and see if the frequency or the resolution were changed. If yes, readjust the video card to the recommend resolution.
- If the recommended resolution (optimal resolution) is not selected, letters may be blurred and the screen may be dimmed, truncated or biased. Make sure to select the recommend resolution.
- The setting method can differ by computer and O/S (Operation System), and resolution mentioned above may not be supported by the video card performance. In this case, please ask to the computer or the video card manufacturer.

Display image is incorrect	
The screen color is mono or abnormal.	<ul> <li>Check if the signal cable is properly connected and use a screwdriver to fasten if necessary.</li> <li>Make sure the video card is properly inserted in the slot.</li> <li>Set the color setting higher than 24 bits (true color) at Control Panel Settings.</li> </ul>
The screen blinks.	Check if the screen is set to interlace mode and if yes, change it to the recommend resolution.

Do you see an "Unrecognized monitor, Plug&Play (VESA DDC) monitor found" message?		
Have you installed the display driver?	<ul> <li>Be sure to install the display driver from our web site: http://www.lg.com.</li> <li>Make sure to check if the video card supports Plug&amp;Play function.</li> </ul>	

The screen is flickering.	
Did you select the recommended resolution?	<ul> <li>If the selected resolution is HDMI 1080i 60/50 Hz, the screen may be flickering. Change the resolution to the recommended resolution 1080P.</li> </ul>

# **SPECIFICATIONS**

#### 32MP58HQ

Display	Screen Type	Flat Panel Active matrix-TFT LCD Anti-Glare coating		
	Pixel Pitch	0.36375 mm x 0.36375 mm (Pixel Pitch)		
Resolution	Max	1920 x 1080 @ 60 Hz		
	Recommend	VESA 1920 x 1080 @ 60 Hz		
Power Consumption	On Mode : 34.9 W Typ. (Outgoing condition) * Sleep Mode ≤ 0.3 W ** Off Mode ≤ 0.3 W			
Power Input	19 V 2.0 A or 19 V	: 1.6 A		
AC-DC Adapter	Type ADS-45SN-19-3 19040G, manufactured by SHENZHEN HONOR ELECTRONIC or Type LCAP21C, manufactured by LIEN CHANG ELECTRONIC ENTERPRISE or Type LCAP26B-E, manufactured by LIEN CHANG ELECTRONIC ENTERPRISE OUTPUT: 19 V === 2.1 A			
	Type ADS-40SG-19-3 19032G, manufactured by SHENZHEN HONOR ELECTRONIC or Type ADS-40FSG-19 19032GPG-1, manufactured by SHENZHEN HONOR ELECTRONIC or Type ADS-40FSG-19 19032GPBR-1, manufactured by SHENZHEN HONOR ELECTRONIC or Type ADS-40FSG-19 19032GPCU-1, manufactured by SHENZHEN HONOR ELECTRONIC or Type ADS-40FSG-19 19032GPCU-1, manufactured by SHENZHEN HONOR ELECTRONIC or Type ADS-32FSG-19 19032EPCU-1L, manufactured by SHENZHEN HONOR ELECTRONIC or Type LCAP21A, manufactured by LIEN CHANG ELECTRONIC ENTERPRISE or Type LCAP26A-A, manufactured by LIEN CHANG ELECTRONIC ENTERPRISE or Type LCAP26A-E, manufactured by LIEN CHANG ELECTRONIC ENTERPRISE or Type LCAP26A-B, manufactured by LIEN CHANG ELECTRONIC ENTERPRISE or Type LCAP26A-B, manufactured by LIEN CHANG ELECTRONIC ENTERPRISE or Type LCAP26A-B, manufactured by LIEN CHANG ELECTRONIC ENTERPRISE Or Type LCAP26A-B, manufactured by LIEN CHANG ELECTRONIC ENTERPRISE OT Type LCAP26A-B, manufactured by LIEN CHANG ELECTRONIC ENTERPRISE OT Type LCAP26A-B, manufactured by LIEN CHANG ELECTRONIC ENTERPRISE OT Type LCAP26A-B, manufactured by LIEN CHANG ELECTRONIC ENTERPRISE OT Type LCAP26A-B, manufactured by LIEN CHANG ELECTRONIC ENTERPRISE OT Type LCAP26A-B, manufactured by LIEN CHANG ELECTRONIC ENTERPRISE OT Type LCAP26A-B, manufactured by LIEN CHANG ELECTRONIC ENTERPRISE			
Dimensions	With Stand 726.6 mm x 491.9 mm x 204.8 mm			
(Width x Height x Depth)	Without Stand	726.6 mm x 430.1 mm x 94.1 mm		
Weight	6.5 kg			
Tilt Range	-5° to 10°			
Environmental conditions	Operating Temperature Operating Humidity	0 °C to 40 °C ≤ 80 %		
	Storage Temperature Storage Humidity	-20 °C to 60 °C ≤ 85 %		
Sync Input	Horizontal Frequency	equency 30 kHz to 83 kHz (Automatic)		
Vertical Frequency 56 Hz to 63 Hz (D-SUB)		56 Hz to 63 Hz (D-SUB)		
		56 Hz to 61 Hz (HDMI)		
	Input Form Separate Sync. Digital			
		put 15 pin D-SUB Connector,HDMI Connector		
Video Input	Signal Input	15 pin D-SUB Connector,HDMI Connector		
Video Input	Signal Input Input Form	15 pin D-SUB Connector, HDMI Connector RGB Analog (0.7 Vp-p/ 75 ohm), Digital		

Product specifications shown above may be changed without prior notice due to upgrade of product

The power consumption level can be different by operating condition and monitor setting.

<sup>\*</sup> The On mode power consumption is measured with LGE test standard (Full White pattern , Maximum resolution).

<sup>\*\*</sup> The monitor goes to the Sleep Mode in a couple of minutes(Max 5 minutes).

# **Preset Modes (Resolution)**

# **D-SUB/HDMI PC Timing**

Display Modes (Resolution)	Horizontal Frequency(kHz)	Vertical Frequency(Hz)	Polarity(H/V)	
640 x 480	31.469	60	-/-	
800 x 600	37.879	60	+/+	
1024 x 768	48.363	60	-/-	
1280 x 1024	63.981	60	+/+	
1680 x 1050	65.290	60	-/+	
1920 x 1080	67.5	60	+/+	Recommend Mode

# **HDMI Timing(Video)**


Factory support mode (Preset Mode)	Horizontal Frequency(kHz)	Vertical Frequency(Hz)	НДМІ
480P	31.50	60	0
576P	31.25	50	0
720P	37.50	50	0
720P	45.00	60	0
1080P	56.25	50	0
1080P	67.50	60	O Recommend Mode

# **Indicator**

Mode	LED Color
On Mode	White
Sleep Mode	Blinking White
Off Mode	Off

# PROPER POSTURE

# Proper posture for using the Monitor set.





Make sure to read the Safety Precautions before using the product.

The model and serial number of the product are located on the back and on one side of the product.

Record them below in case you ever need service.

MODEL	
SERIAL	