





Read this owner's manual thoroughly before operating the appliance and keep it handy for reference at all times.

EN ENGLISH



MFL69905434 Rev.02_042120

www.lg.com

Copyright © 2019-2020 LG Electronics Inc. All Rights Reserved





TABLE OF CONTENTS

This manual may contain images or content different from the model you purchased.

This manual is subject to revision by the manufacturer.

SAFETT INSTRUCTIONS	
READ ALL INSTRUCTIONS BEFORE USE	
WARNING	
CAUTION	!
INICTALL ATION	4.
INSTALLATION	
Before Installation	
Dimensions and Clearances	
Ambient Temperature	
Removing the Door	
Refitting the Door	
Adjusting the Height of the Door	
Connecting the Appliance	1
Moving the Appliance	1
OPERATION	1
Parts and Functions	1
Notes for Operation	1
Using Control Panel	2
lcemaker*	2
Door in Door*	24
Fresh Vegetable Drawer*	2
InstaView Function*	20
Other Functions	20
SMART FUNCTIONS	27
LG ThinQ Application	
Smart Diagnosis	
·	
MAINTENANCE	
Notes for Cleaning	30
Cleaning the Condenser Cover	
Cleaning the Door Basket	
Cleaning the Shelf	
Cleaning the Vegetable Drawer	3
TROUBLESHOOTING	33









SAFETY INSTRUCTIONS

READ ALL INSTRUCTIONS BEFORE USE

Safety Messages

The following safety guidelines are intended to prevent unforeseen risks or damage from unsafe or incorrect operation of the appliance.

The guidelines are separated into 'WARNING' and 'CAUTION' as described below.



This symbol is displayed to indicate matters and operations that can cause risk. Read the part with this symbol carefully and follow the instructions in order to avoid risk.



WARNING

This indicates that the failure to follow the instructions can cause serious injury or death.



CAUTION

This indicates that the failure to follow the instructions can cause the minor injury or damage to the product.

WARNING



WARNING

To reduce the risk of explosion, fire, death, electric shock, injury or scalding to persons when using this product, follow basic precautions, including the following:

Technical Safety

This appliance is not intended for use by persons (including children) with reduced physical, sensory or mental capabilities, or lack of experience and knowledge, unless they have been given supervision or instruction concerning use of the appliance by a person responsible for their safety. Children should be supervised to ensure that they do not play with the appliance.





- If the power cord is damaged or the hole of the outlet socket is loose, do not use the power cord and contact an authorized service centre.
- Do not damage the refrigerant circuit.
- Do not use mechanical devices or other means to accelerate the defrosting process.
- Keep ventilation openings, in the appliance enclosure or in the built-in structure, clear of obstruction.
- Do not use electrical appliances inside the refrigerator.
- The refrigerant and insulation blowing gas used in the appliance require special disposal procedures. Consult with service agent or a similarly qualified person before disposing of them.
- This appliance is intended to be used in household and similar applications only. It should not be used for commercial, or catering purposes, or in any mobile application such as a caravan or boat.
- Do not store explosive substances such as aerosol cans with a flammable propellant in this appliance.



This symbol alerts you to flammable materials that can ignite and cause a fire if you do not take care.

- This appliance contains a small amount of isobutane refrigerant (R600a), but it is also combustible. When transporting and installing the appliance, care should be taken to ensure that no parts of the refrigerating circuit are damaged.
- When positioning the appliance, ensure the supply cord is not trapped or damaged.
- Do not locate multiple portable outlet-sockets or portable power supplies at the rear of the appliance.
- Disconnect the power cord before cleaning the appliance or replacing the inside lamp (where fitted).
- Securely plug the power plug in the outlet socket after completely removing any moisture and dust.
- Never unplug the appliance by pulling on the power cable. Always grip the power plug firmly and pull straight out from the outlet socket.





- Do not spray water or inflammable substances (toothpaste, alcohol, thinner, benzene, flammable liquid, abrasive, etc.) over the interior or exterior of the appliance to clean it.
- Do not clean the appliance with brushes, cloths or sponges with rough surfaces or which are made of metallic material.
- Only qualified service personnel from LG Electronics service centre should disassemble, repair, or modify the appliance. Contact an LG Electronics customer information centre if you move and install the appliance in a different location.
- Do not use a hair drier to dry the inside of the appliance or place a candle inside to remove the odours.
- Do not tilt the appliance to pull or push it when transporting.
- Make sure not to get a body part such as a hand or foot stuck while moving the appliance.

Risk of Fire and Flammable Materials

- If a leak is detected, avoid any naked flames or potential sources
 of ignition and air the room in which the appliance is standing for
 several minutes. In order to avoid the creation of a flammable gas
 air mixture if a leak in the refrigerating circuit occurs, the size of the
 room in which the appliance is used should correspond to the amount
 of refrigerant used. The room must be 1 m² in size for every 8 g of
 R600a refrigerant inside the appliance.
- Refrigerant leaking out of the pipes could ignite or cause an explosion.
- The amount of refrigerant in your particular appliance is shown on the identification plate inside the appliance.

Installation

- This appliance should only be transported by two or more people holding the appliance securely.
- Install the appliance on a firm and level floor.





- Do not install the appliance in a damp and dusty place. Do not install or store the appliance in any outdoor area, or any area that is subject to weathering conditions such as direct sunlight, wind, rain, or temperatures below freezing.
- Do not place the appliance in direct sunlight or expose it to the heat from heating appliances such as stoves or heaters.
- Be careful not to expose the rear of the appliance when installing.
- Install the appliance in a place where is easy to unplug the power plug of the appliance.
- Be careful not to let the appliance door fall during assembly or disassembly.
- Be careful not to pinch, crush, or damage the power cable during assembly or disassembly of the appliance door.
- Do not plug the appliance into multiple outlet sockets, power boards, or an extension power cable.
- Do not use an extension cord or double adapter.
- Be careful not to point the power plug up or let the appliance lean against the power plug.
- Do not connect a plug adapter or other accessories to the power plug.
- Do not modify or extend the power cable.
- Ensure that the outlet socket is properly grounded, and that the earth pin on the power cord is not damaged or removed from the power plug. For more details on grounding, inquire at an LG Electronics customer information centre.
- This appliance is equipped with a power cord having an equipmentgrounding conductor and a grounding power plug. The power plug must be plugged into an appropriate outlet socket that is installed and grounded in accordance with all local codes and ordinances.
- Never start up an appliance showing any signs of damage. If in doubt, consult your dealer.
- Dispose of all packaging materials (such as plastic bags and styrofoam) away from children. The packaging materials can cause suffocation.





Operation

- Do not use the appliance for any purpose (storage of medical or experimental materials or shipping) other than any domestic household food storage use.
- If water penetrates electrical parts of the appliance, disconnect power plug and contact an LG Electronics customer information centre.
- Unplug the power plug during a severe thunderstorm or lightening or when not in use for a long period of time.
- Do not touch the power plug or the appliance controls with wet hands.
- Do not bend the power cable excessively or place a heavy object on it.
- Immediately unplug the power plug and contact an LG Electronics customer information centre if you detect a strange sound, odour, or smoke coming from the appliance.
- Do not place hands or metallic objects inside the area emitting the cold air, cover or heat releasing grille on the back.
- Do not apply excessive force or impact to the back cover of the appliance.
- Be careful of nearby children when you open or close the appliance door. The door may bump the child and cause injury.
- Avoid the danger of children getting trapped inside the appliance. A child trapped inside the appliance can cause suffocation.
- Do not put animals, such as pets into the appliance.
- Do not place heavy or fragile objects, containers filled with liquid, combustible substances, flammable objects (such candles, lamps, etc.), or heating devices (such as stoves, heaters, etc.) on the appliance.
- Do not place any electronic appliance (such as heater and mobile phone) inside the appliance.





- If there is a gas leakage (isobutane, propane, natural gas, etc.), do not touch the appliance or power plug and ventilate the area immediately. This appliance uses a refrigerant gas (isobutane, R600a). Although it uses a small amount of the gas, it is still combustible gas. Gas leakage during appliance transport, installation or operation can cause fire, explosion or injury if sparks are caused.
- Do not use or store flammable or combustible substances (ether, benzene, alcohol, chemical, LPG, combustible spray, insecticide, air freshener, cosmetics, etc.) near the appliance.
- Fill with potable water only into icemaker or dispenser water tank.

Maintenance

- Only qualified service personnel from LG Electronics service centre should disassemble, repair, or modify the appliance. Contact an LG Electronics customer information centre if you move and install the appliance in a different location.
- Disconnect the power cord before cleaning the appliance or replacing the inside lamp (where fitted).
- Securely plug the power plug in the outlet socket after completely removing any moisture and dust.
- Never unplug the appliance by pulling on the power cable. Always grip the power plug firmly and pull straight out from the outlet socket.
- Do not spray water or inflammable substances (toothpaste, alcohol, thinner, benzene, flammable liquid, abrasive, etc.) over the interior or exterior of the appliance to clean it.
- Do not clean the appliance with brushes, cloths or sponges with rough surfaces or which are made of metallic material.

Disposal

 When discarding the appliance, remove the door gasket while leaving the shelves and baskets in place and keep children away from the appliance.







CAUTION



CAUTION

To reduce the risk of minor injury to persons, malfunction, or damage to the product or property when using this product. follow basic precautions, including the following:

Operation

- Do not touch frozen food or the metal parts in the freezer compartment with wet or damp hands. It may cause frostbite.
- Do not place glass containers, bottles or cans (especially those containing carbonated drinks) in the freezer compartment, shelves or ice bin that will be exposed to temperatures below freezing.
- The tempered glass on the front side of the appliance door or the shelves can be damaged by an impact. If it is broken, do not touch it with hands.
- Do not hang from the appliance doors, storage room, shelf or climb up into it.
- Do not store an excessive amount of water bottles or containers for side dishes on the door baskets.
- Do not open or close the appliance door with excessive force.
- If the hinge of the appliance door is damaged or operates improperly. stop using the appliance and contact an authorized service centre.
- Prevent animals from nibbling on the power cable or water hose.
- Never eat frozen foods immediately after they have been taken out in the freezer compartment.
- Do not use a thin crystal cup or chinaware when dispensing.
- Make sure not to get a hand or foot stuck upon opening or closing the appliance door or door in door.









Maintenance

- Do not clean glass shelves or covers with warm water when they are cold. They may break if exposed to sudden temperature changes.
- Do not insert the shelves upside down. The shelves may fall.
- To remove frost from the appliance, contact an LG Electronics customer information centre.
- Dispose of the ice inside the ice bin in the freezer compartment during an extended power outage.
- If the appliance is equipped with an LED lamp, do not remove lamp cover and LED lamp in any attempt to repair or service it. Please, contact an LG Electronics customer information centre.










INSTALLATION

Before Installation

Dimensions and Clearances

Too small of a distance from adjacent items may result in the degradation of freezing capability and increased electricity costs. Allow over 50 mm of clearance from each adjacent wall when installing the appliance.



-	Size
A	912 mm
В	1790 mm
С	738 mm
D	615 mm
E	690 mm
F	738 mm
G	1180 mm
Н	1750 mm

Ambient Temperature

- The appliance is designed to operate within a limited range of ambient temperatures, depending on the climate zone.
- The internal temperature could be affected by the location of the appliance, the ambient temperature, the frequency of door opening and so on.
- The climate class can be found on the rating label

Climate Class	Ambient Temperature Range °C
SN (Extended Temperate)	+10 - +32
N (Temperate)	+16 - +32
ST (Subtropical)	+16 - +38
T (Tropical)	+16 - +43 / +10 - +43*

*Australia, India, Kenya

NOTE

 The appliances rated from SN to T are intended to be used at an ambient temperature between 10 °C and 43 °C.

Accessories

*This feature is only available on some models.





- Spanner A*
- 2 Spanner B*







Removing the Door

When it is necessary to move the appliance through a narrow opening, removing the doors is the recommended procedure.

A


WARNING

 Disconnect the power cord, house fuse or circuit breaker before installing or servicing the appliance. Failure to follow these instructions may result in death, fire or electric shock.


If your entrance door is too narrow for the appliance to pass through, remove the appliance doors and pass the appliance laterally.

[For both freezer and fridge]

1 Remove the screw of the hinge cover on top of the appliance by rotating it counterclockwise.



While pressing (1) hook of the link of the electrical connectors, remove the link by pulling it in both directions.



3 Remove the hinge lever by tapping the end of it toward the outside edge of the cabinet.




A CAUTION

- When removing the upper hinge, be sure to support the door as it will fall forwards. It is recommended that two or more people carry out the door removal and refitting.
- 4 Lift the upper hinge fixed between the appliance and the appliance door and then remove it.



Remove the freezer and fridge compartment door by lifting it upward. At this time, the door should be lifted enough for the steel pipe to be completely pulled out.



Refitting the Door

Mount the doors in the reverse sequence of their removal once the appliance has been passed through all access doors.









Adjusting the Height of the Door

If the door of the appliance is not level, adjust the difference in the height of appliance door using the following method.

NOTE

 Because the hinge pin may fall out, do not adjust the height of the appliance door more than 5 mm.

[Method1]

*Reference



1 Turn the keeper nut clockwise using the spanner.



To loosen the nut

Adjust the difference in the height of the appliance door by rotating the adjustment hinge pin clockwise or counterclockwise with an 8 mm spanner.



3 Fasten the keeper nut by turning it counterclockwise.




To tighten the nut

If it is impossible to adjust the height of the appliance door through the above method, level the door according to the following guide.

[Method2]


If the freezer compartment door is lower than the fridge compartment door

Level the door by inserting flat(-type) driver into groove of the left height adjusting screw and rotate it clockwise.



If the freezer compartment door is higher than the fridge compartment door

Level the door by inserting flat(-type) driver into groove of the right height adjusting screw and rotate it clockwise.











Connecting the Appliance

After installing the appliance, connect the power plug into a socket outlet.

NOTE

 After connecting the power supply cord (or plug) to the outlet, wait 2 or 3 hours before you put food into the appliance. If you add food before the appliance has cooled completely, your food may spoil.

Moving the Appliance

- 1 Remove all food from inside the appliance.
- Pull the power plug out, insert and fix it into the power plug hook at the rear or on top of the appliance.
- 3 Tape parts such as shelves and the door handle to prevent from falling off while moving the appliance.
- 4 Move the appliance with more than two people carefully. When transporting the appliance over a long distance, keep the appliance upright.
- After installing the appliance, connect the power plug into a socket out to switch on the appliance.










OPERATION

Parts and Functions

- (*) means that this feature varies depending on the model purchased.
- The appearance or components of the appliance may differ from model to model.

Exterior



Control Panel

To set the freezer and fridge temperatures.

Door-in-Door*

The Door in Door is a double layered door system. It can be opened individually or together with the main door. You can conveniently locate and access your favourite snacks or food items.

Door-in-Door Lever*

This lever opens Door in Door.

InstaView Door in Door*


The InstaView Door in Door compartment allows for easy access to commonly used food items. .





Interior

• The top shelf of the freezer(1) will reach the set temperature the most quickly.











LED Lamp

The LED lamps inside the appliance light up when you open the door.

♠ Freezer Shelf*

This is where frozen foods such as meat, fish, and ice cream can be stored.

Carried Research Carried Research

This is where ice is manually produced and stored.

Freezer Drawer*

This is for long-term storage of frozen items.

Freezer Door Basket

This is where small packages of frozen food can be stored.

• Do not store ice cream or food which will be stored for a long period of time within these baskets.

Smart Diagnosis Unit

Use this function when contacting LG Electronics customer information centre to help make an accurate diagnosis when the appliance operates abnormally or a failure occurs.

Door in Door*

This is where foods which are taken out frequently such as beverages and snacks are stored.

Bottle Rack[⋆]

This is where drinks tall bottles or containers are stored.

A CAUTION

 Do not store short bottles or containers. The items may fall and cause an injury or appliance damage.

Fridge Shelf

This is where refrigerated foods and other items are stored.

- The shelf height can be adjusted by inserting the shelf in another groove of different height.
- Store the foods with higher moisture content at the front of the shelf.
- The actual number of shelves will differ from model to model.

Pure N Fresh*

• This function reduces and removes odors inside the fridge compartment.





Snack Drawer*

This is where small packages of refrigerated foods are stored.

Temperature Sensor

This sensor senses the temperature of the fridge compartment.

• Maintain the distance between the sensor and food to accurately sense the temperature.

This is where fruits and vegetables are stored to help maintain freshness by adjusting the humidity controller.

Fridge Door Basket

This is where small packages of refrigerated foods, drinks and sauce containers are stored.

Vegetable Drawer

This is where fruits and vegetables are stored to remain fresh for as long as possible.

• The actual number of drawers will differ from model to model.







Notes for Operation

- Users should keep in mind that frost can form. If the door is not closed completely, if the humidity is high during the summer, or if the freezer door is opened frequently.
- Ensure there is sufficient space between food stored on the shelf or door basket to allow the door to close completely.
- Opening the door lets warm air enter the appliance, and may cause the internal temperature to rise.
- If you are leaving the appliance turned off for an extended period of time, remove all food and unplug the power cord. Clean the interior, and leave the doors slightly ajar to prevent mold from growing in the appliance.

Suggestion for Energy Saving

- Ensure there is sufficient space between stored foods. This allows cold air to be circulated evenly and lowers electricity bills.
- Store hot food only after it has cooled in order to prevent dew or frost.
- When storing food in the freezer compartment, set the freezer temperature lower than the temperature indicated on the food.
- Do not put food near the temperature sensor of the fridge compartment. Keep a distance of at least 3 cm from the sensor.
- Note that a temperature rise after defrosting has a permissible range in the appliance specifications. If you wish to minimise the impact this may have on the food storage due to a temperature rise, seal or wrap the stored food in several layers.
- The automatic defrosting system in the appliance ensures that the compartment remains free of ice buildup under normal operating conditions.









Storing Foods Effectively

- Store frozen food or refrigerated food inside sealed containers.
- Check the expiration date and label (storage instructions) before storing food in the appliance.
- Do not store food for a long period of time (more than four weeks) if it spoils easily at a low temperature.
- Place the refrigerated food or frozen food in each fridge or freezer compartment immediately after purchasing.
- Avoid refreezing any food which has been completely thawed. Freezing any food which has been completely thawed again will lower its taste and nutrition.
- Do not wrap and store vegetables with newspaper. Printing material of newspaper or other foreign substances may smear and contaminate food
- Do not overfill the appliance. Cold air can not circulate properly if the appliance is overfilled.
- If you set an excessively low temperature for food, it may become frozen. Do not set a temperature lower than the required temperature for the food to be stored correctly.
- If there are chill compartments in the appliance, do not store vegetables and fruits with higher moisture content in the chill compartments as they may freeze due to the lower temperature.

Max Freezing Capacity

- The Express Freeze function will set the freezer to its maximum freezing capacity.
- This generally takes up to 24 hours and automatically switches off.
- If the maximum freezing capacity is to be used, Express Freeze must be switched on for seven hours before fresh produce is placed in the freezer compartment.

Maximum Storage

- To get better air circulation, insert all drawers.
- If large quantities of food are to be stored, all the freezer drawers shall be taken out of the appliance and the food shall be stacked directly on the freezer shelves in the freezer compartment.

NOTE

- To remove the drawers, first pick the food out of drawers. Then use the handle of drawers, pull out the drawers carefully. It may cause injury.
- The shape of each drawer may be different, insert in the right position.








Using Control Panel

Units and Functions






2 Freezer Temperature

• This sets the freezer target temperature.

• This sets the fridge target temperature.

Pure N Fresh*

• This sets the Pure N Fresh function.



Express Freeze

• This sets Express Freeze functions.

A * Wi-Fi

 This sets the appliance to connect to your home's Wi-Fi network.

6 * Lock

• This locks the buttons on the control panel.

NOTE

- (*) means that this feature varies depending on the model purchased.
- The actual control panel may differ from model to model.
- The control panel will turn off automatically for energy saving.
- If there is any finger or skin contacts to the control panel while cleaning it, the button function may
 operate.









Setting the Temperature

This sets the fridge temperature or freezer temperature.

- Press the Fridge button or Freezer button to adjust the temperature.
- The temperature can be adjusted.
 - Fridge: from 1 °C to 7 °C
 - Freezer: from -24 °C to -14 °C
- The actual inner temperature varies depending on the food status, as the indicated setting temperature is a target temperature, not actual temperature within the appliance.

NOTE

- The default temperature setting may vary depending on the appliance.
- Wait until two or three hours have passed after connecting the appliance to the outlet before storing food in the appliance.
- For ice making in normal climates, the freezer temperature should be set to -19 °C or colder.

Setting Express Freeze

The function can quickly freeze a large amount of ice or frozen foods.

- When you press the Express Freeze button, the Express Freeze icon lights on the control panel.
- The function is enabled and disabled in turn each time you press the button.
- The Express Freeze function automatically terminates after a specific period has passed.

Setting and Resetting Lock

This locks the buttons on the control panel.

- Press and hold the Lock button for 3 seconds . When the Lock function is set, all buttons are locked.
- When you press the Lock button for 3 seconds, the Lock/Unlock icon on the control panel lights. The function is enabled and disabled in turn each time you press the button.
- If you press a button other than lock when the lock is set, the button will not function.
- When you press a button other than lock when the lock is set, the Lock/Unlock icon on the control panel will flash 3 times.

 To change a setting, first press the Lock button for three seconds to disable the function.


Icemaker*

This is where ice is manually produced and stored.

Making Ice

<Type 1>

1 Hold the handle of ice tray and pull it out.



2 Fill the ice tray with water so that all the cubes are equally full.



3 Place the ice tray back to its position carefully not to spill water on the floor.

A CAUTION

 Be careful not to spill water when inserting the ice tray after filling with water.

<Type 2>

Fill the icetray with water so that all the cubes are equally full. And place it in the freezer compartment.









Taking Out Ice

<Type 1>

Rotate the ice separation handle on the icemaker clockwise.



2 Lift the ice storage bin slightly and remove.



<Type 2>

Hold the icetray at its ends and twist gently.



CAUTION

- . If you open and close the freezer door frequently, it may take longer for water to be frozen.
- · The time for water to be frozen may vary according to the season. Until 24 hours after initial installation, the temperature inside the appliance may not be stabilized so that it may take longer for water to be frozen.
- . Make sure to be careful as the edges of the ejected ice may be sharp.

NOTE

- (*) means that this feature varies depending on the model purchased.
- If ice cannot be detached easily, rotate the ice separation handle of the icemaker once again.
- Please note that ice may stick together if you rotate the ice separation handle of the icemaker before the water has completely frozen.
- It takes approximately three hours for water at the temperature of -20 °C to be frozen completely.
- When placing the ice storage bin back to its original position after using, make sure to check if it is inserted all the way in.
- The proper storage amount of the ice storage bin is the amount of ice made three times. If more than the amount of ice made for three times is stored, the ice storage bin may not come out and will become stuck. Do not store more than three ejected ice trays of ice in the ice storage bin.

Removing the Icemaker*

Hold both edges of the freezer door basket on top of the icemaker and remove it by pulling it up.



Hold both edges of ice tray compartment and remove it by pulling it up.











A CAUTION


- Remove in this order. Removing the ice tray first may cause damage.
- When separating the icemaker, hold and remove it properly to prevent the ice tray from falling off.

NOTE

• (*) means that this feature varies depending on the model purchased.

Cleaning the Ice Tray

1 Hold the handle of ice tray and pull it out to remove.



2 After cleaning, remove it back to its original position.




CAUTION

 When cleaning, wipe all components with a wet towel except for the ice tray and dry them off completely before using. Failure to do so may cause malfunctions.

Door in Door*

Pull the lever at the bottom of the door upwards until the door in door opens.

There is plenty of storage space inside the door in door and its surrounding baskets, allowing you to store food in an organized manner.



Removing the Case from the Door in Door

Hold the case from inside the door in door with both hands and remove it by lifting it upward.



Refitting the Door in Door Case

Mount them in the reverse order of the removal process.











Removing the Baskets from the Door in Door

1 Hold both edges of the basket and remove it by lifting it upward.



2 Lift the fixed basket up as shown in (1) and remove it by pulling it out as shown in (2).



Refitting the Baskets to the Door in Door

Mount them in the reverse order of the removal process.

NOTE


• (*) means that this feature varies depending on the model purchased.

Fresh Vegetable Drawer*

The Humidity in the vegetable crisper drawer can be controlled by sliding the lever in either direction.

If moved to the left side, the air guide will be open and allow air to circulate through the drawer for reduced humidity. And if moved to the right side, the air guide will be closed and will maintain any humidity that is currently in the crisper drawer.

The closed state is recommended for storing vegetables, and open state is recommended for storing fruit.



NOTE

 (*) means that this feature varies depending on the model purchased.








InstaView Function*

The InstaView function on the Door-in-Door lets you see if you're running low on frequently used items like beverages and snacks, without opening the refrigerator door.



- 1 Knock twice on the glass to turn the LED light inside the Door-in-Door on or off.
- 2 The LED light turns off automatically after ten seconds.
- The InstaView Door-in-Door function is disabled when the right refrigerator door and the left freezer door are open, for two seconds after closing the door, and when the ice dispenser is in use.
- Knock near the centre of the glass. Knocking near the edges of the glass may not activate the InstaView Door-in-Door function properly.
- Knock hard enough that the knocking sound is audible.
- The InstaView Door-in-Door function may activate if a loud noise occurs near the refrigerator.

NOTE

 (*) means that this feature varies depending on the model purchased.

Other Functions

Door Open Alarm

The alarm sounds 3 times in 30 second intervals if the door (fridge compartment, freezer compartment, door in door) is left open or not completely closed for one minute.

 Contact the LG Electronics customer information centre if the alarm sound continues even after closing the door.

Failure Detection

The appliance can automatically detect problems during the operation.

- If a problem is detected, the appliance may not operate and an error code is displayed even when any button is pressed.
- When this occurs, do not turn off the power and immediately contact the LG Electronics customer information centre. If you turn off the power, the repair technician from the LG Electronics customer information centre may have difficulty finding the problem.









SMART FUNCTIONS

LG ThinQ Application

This feature is only available on models with Wi-Fi.

The **LG ThinQ** application allows you to communicate with the appliance using a smartphone.

LG ThinQ Application Features

Communicate with the appliance from a smartphone using the convenient smart features.

Smart Diagnosis

 If you experience a problem while using the appliance, this smart diagnosis feature will help you diagnose the problem.

Settings

 Allows you to set various options on the appliance and in the application.

NOTE

- If you change your wireless router, internet service provider, or password, delete the registered appliance from the LG ThinQ application and register it again.
- The application is subject to change for appliance improvement purposes without notice to users.
- · Functions may vary by model.

Before Using LG ThinQ Application

- 1 Check the distance between the appliance and the wireless router (Wi-Fi network).
 - If the distance between the appliance and the wireless router is too far, the signal strength becomes weak. It may take a long time to register or installation may fail.
- Turn off the Mobile data or Cellular Data on your smartphone.



3 Connect your smartphone to the wireless router.



NOTE

- To verify the Wi-Fi connection, check that **Wi- Fi** so icon on the control panel is lit.
- The appliance supports 2.4 GHz Wi-Fi networks only. To check your network frequency, contact your Internet service provider or refer to your wireless router manual.
- LG ThinQ is not responsible for any network connection problems or any faults, malfunctions, or errors caused by network connection.
- If the appliance is having trouble connecting to the Wi-Fi network, it may be too far from the router. Purchase a Wi-Fi repeater (range extender) to improve the Wi-Fi signal strength.
- The Wi-Fi connection may not connect or may be interrupted because of the home network environment.
- The network connection may not work properly depending on the Internet service provider.
- The surrounding wireless environment can make the wireless network service run slowly.
- The appliance cannot be registered due to problems with the wireless signal transmission.
 Unplug the appliance and wait about a minute before trying again.
- If the firewall on your wireless router is enabled, disable the firewall or add an exception to it.
- The wireless network name (SSID) should be a combination of English letters and numbers. (Do not use special characters.)
- Smartphone user interface (UI) may vary depending on the mobile operating system (OS) and the manufacturer.
- If the security protocol of the router is set to WEP, you may fail to set up the network.
 Please change it to other security protocols (WPA2 is recommended) and register the product again.









Installing LG ThinQ

Search for the **LG ThinQ** application from the Google Play Store or Apple App Store on a smart phone. Follow instructions to download and install the application.

Connecting to Wi-Fi

The **Wi-Fi** button, when used with the **LG ThinQ** application, allows the appliance to connect to a home Wi-Fi network. The ♠ icon shows the status of the appliance's network connection. The icon illuminates when the appliance is connected to the Wi-Fi network

Initial Appliance Registration

Run the **LG ThinQ** application and follow the instructions in the application to register the appliance.

Re-registering the Appliance or Registering Another User

Press and hold the **Wi-Fi** button for 3 seconds to temporarily turn it off. Run the **LG ThinQ** application and follow the instructions in the application to register the appliance.

NOTE

• To disable the Wi-Fi function, press and hold the **Wi-Fi** button for 3 seconds. The $\widehat{\widehat{}}$ icon will be turned off.

RF Radiation Exposure Statement

 This equipment shall be installed and used at a minimum distance of 20 cm from the human body.

Open Source Software Notice Information

To obtain the source code under GPL, LGPL, MPL, and other open source licenses, that is contained in this product, please visit http://opensource.lge.com

In addition to the source code, all referred license terms, warranty disclaimers and copyright notices are available for download.

LG Electronics will also provide open source code to you on CD-ROM for a charge covering the cost of performing such distribution (such as the cost of media, shipping, and handling) upon email request to opensource@lge.com. This offer is valid for a period of three years after our last shipment of this product. This offer is valid to anyone in receipt of this information.

Smart Diagnosis

This feature is only available on models with the g or \textcircled{g}_1 logo.

Use this feature to help you diagnose and solve problems with your appliance.

NOTE

- For reasons not attributable to LGE's negligence, the service may not operate due to external factors such as, but not limited to, Wi-Fi unavailability, Wi-Fi disconnection, local app store policy, or app unavailability.
- The feature may be subject to change without prior notice and may have a different form depending on where you are located.

Using LG ThinQ to Diagnose Issues

If you experience a problem with your Wi-Fi equipped appliance, it can transmit troubleshooting data to a smartphone using the **LG ThinQ** application.

 Launch the LG ThinQ application and select the Smart Diagnosis feature in the menu.
 Follow the instructions provided in the LG ThinQ application.








Using Audible Diagnosis to Diagnose Issues

Follow the instructions below to use the audible diagnosis method.

- Launch the LG ThinQ application and select the Smart Diagnosis feature in the menu.
 Follow the instructions for audible diagnosis provided in the LG ThinQ application.
- 1 Press the **Lock** button to activate the lock function.
 - If the display has been locked for over 5 minutes, you must deactivate the lock and then reactivate it.



2 Open the fridge door and then hold the phone on the upper right speaker hole.



- 3 Press and hold the Freezer button for three seconds or longer while continuing to hold your phone to the speaker.
- 4 After the data transfer is complete, the diagnosis will be displayed in the application.

NOTE

 For best results, do not move the phone while the tones are being transmitted.









MAINTENANCE


Notes for Cleaning

- When removing a shelf or drawer from inside the appliance, remove all stored foods from the shelf or drawer to prevent injury or damage to the appliance.
 - Otherwise, injury may occur due to the weight of stored foods.
- If cleaning the outside air vents of the appliance by means of vacuuming, then the power cord should be unplugged from the outlet to avoid any static discharge that can damage the electronics or cause an electric shock.
- Detach the shelves and drawers and clean them with water, and then dry them sufficiently, before replacing them.
- Regularly wipe the door gaskets with a wet soft towel
- Door basket spills and stains should be cleaned as they can compromise storage ability of the basket and could even be damaged.
- After cleaning, check if the power cable is damaged, warm or improperly plugged.
- Keep the air vents on the exterior of the appliance clean.
 - Blocked air vents can cause fire or appliance damage.
- When cleaning the inside or outside of the appliance, do not wipe it with a rough brush, toothpaste, or flammable materials. Do not use cleaning agents containing flammable substances.
 - This may cause discoloration or damage to the appliance.
 - Flammable substances: alcohol (ethanol, methanol, isopropyl alcohol, isobutyl alcohol, etc.), thinner, bleach, benzene, flammable liquid, abrasive, etc.

- For the appliance exterior, use a clean sponge or soft cloth and a mild detergent in warm water.
 Do not use abrasive or harsh cleaners. Dry thoroughly with a soft cloth.
- Never clean the shelves or containers in the dishwasher
 - The parts may become deformed due to the heat

Cleaning the Condenser Cover

Use a vacuum cleaner with a brush to clean the condenser cover and vents. Do not remove the panel covering the condenser coil area.









Cleaning the Door Basket

Removing the Fridge/Freezer Door Basket

Hold both edges of the basket and remove it by lifting it upward.




Refitting the Fridge/Freezer Door Basket

1 Hold both edges of the door basket, gently push one edge to assemble, and then in the same manner assemble the other edge.



2 After assembling, tap the door basket gently to fix it horizontally.



Cleaning the Shelf

Removing the Fridge/Freezer Shelf

Remove the shelf by pulling it out.



Refitting the Fridge/Freezer Shelf

Remove the shelf by pulling it out while slightly lifting the rear edge of the fridge shelf.

Cleaning the Vegetable Drawer

Removing the Vegetable Drawer

1 Remove the contents of the drawer. Hold the handle of the vegetable drawer and pull it out completely until it outward gently until it stops.









2 Lift the vegetable drawer up and remove it by pulling it out.



Refitting the Vegetable Drawer

1 If the vegetable drawer has a cover, lift it.



Insert the bottom of the vegetable drawer into its original position and gently push it back in while lowering it.



A CAUTION

 Please note that injuries can be caused by the weight of stored foods when removing the vegetable drawer.









TROUBLESHOOTING

Symptoms	Reason & Solution
There is no refrigeration or freezing.	Is there a power interruption?
	Check the power of other appliances.
	If the power plug unplugged from the outlet?
	Plug the power plug in the outlet properly.
	Is the fridge or freezer temperature set to its warmest setting?
	Set the fridge or freezer temperature to 'Medium'.
	Is the appliance in direct sunlight, or is it near a heat generating object such as cooking oven or heater?
	Check the installation area and reinstall it away from heat generating objects.
There is poor	Did you store hot food without cooling it first?
refrigeration or	Cool the hot food first before putting it in the fridge or freezer compartment.
freezing.	Did you put in too much food?
	Maintain an appropriate space between food.
	Are the appliance doors completely closed?
	Completely close the door and make sure that stored food is not obstructing in the door.
	Is there enough space around the appliance?
	Adjust the installation position to make enough space around the appliance.
	Is the fridge or freezer temperature set to 'Warm'?
	Set the fridge or freezer temperature to 'Medium'.
The appliance contains	Did you put in food with a strong smell?
a bad smell.	Store foods with strong smells in a sealed containers.
	Vegetables or fruit may have spoiled in the drawer?
	Throw away rotten vegetables and clean the vegetable drawer. Do not store vegetables too long in the vegetable drawer.
The inside lamp in the	Does the inside lamp in the appliance turn off?
appliance does not turn on.	 It is not possible for customers to replace the inside lamp in the appliance as they are not serviceable. If the inside lamp does not turn on, please contact the LG Electronics customer information centre.
The appliance door is not closed tightly.	Is the appliance leaning forward?
	Adjust the front feet to raise the front side slightly.
	Were the shelves properly assembled?
	Refit the shelves if needed.
	Did you close the door with excessive force?
	If you apply too much force or speed when closing the door, it may remain briefly open before closing. Make sure that you do not slam the door closed. Close without force.









Symptoms	Reason & Solution
It is difficult to open the appliance door.	Did you open the door right after you closed it?
	 If you try to open the appliance door within one minute after you closed it, you may have difficulties because of the pressure inside the appliance. Try to open the appliance door again in a few minutes so that the internal pressure stabilizes.
	Did you store hot food without cooling it first?
	Cool the hot food first before putting it in the fridge or freezer compartment.
	Did you leave the appliance door open?
There is condensation inside the appliance	Although the condensation will disappear soon after you close the appliance door, you can wipe it with a dry cloth.
or on the bottom of the vegetable drawer	Do you open and close the appliance door too frequently?
cover.	Condensation can form due to the temperature difference from the outside. Wipe out the dampness with a dry cloth.
	Did you put warm or moist food inside without sealing it in a container?
	Store food in a covered or sealed container.
	Doors may not be closed properly?
Frost has formed in the freezer compartment.	Check if the food item inside the appliance is blocking the door and make sure that the door is tightly closed.
	Did you store hot food without cooling it first?
	Cool the hot food first before putting it in the fridge or freezer compartment.
Frost has formed in the freezer compartment.	Is the air entry or exit of the freezer compartment blocked?
	Make sure that air entry or exit is not blocked so that the air can circulate inside.
	Is the freezer compartment overfilled?
	Maintain an appropriate space between items.
Frost or condensation	Did you open and close the appliance door frequently or is the appliance door improperly closed?
	Frost or condensation can form if the outside air penetrates inside the appliance.
outside the appliance.	Is the installation environment humid?
	Condensation can appear on the exterior of the appliance if the installation area is too humid or on a humid day such as a rainy day. Wipe off any moisture with a dry cloth.











Symptoms	Reason & Solution
The appliance is noisy and generates abnormal sounds.	Is the appliance installed on a weak floor or improperly levelled? • Install the appliance on a solid and flat area.
	Does the rear of the appliance touch the wall? • Adjust the installation position to allow enough clearance around the appliance.
	Are objects scattered behind the appliance?
	Remove the scattered objects from behind the appliance.
	Is there an object on top of the appliance?
	Remove the object on top of the appliance.
The side or front of the appliance is warm.	There are anti condensation pipes fitted to these areas of the appliance to reduce condensation forming from around the door area.
	The heat releasing pipe to prevent condensation is installed on the front and side of the appliance. You may feel it particularly hot right after the appliance is installed or during the summer. You can be assured that this is not a problem and is quite normal.
There is water inside or outside of the appliance.	Is there water leakage around the appliance?
	Check if the water has leaked from a sink or another place.
	Is there water on the bottom of the appliance? • Check if the water is from the thawed frozen food or a broken or dropped container.







Symptoms	Reason & Solution
	Did you install the appliance recently?
	The ice maker produces ice normally when approximately 48 hours have passed after the appliance is installed.
	Did you connect the water supply pipe to the appliance and open the supply valve? • Connect the water supply pipe to the appliance and open the supply valve
	completely.
	Is the water supply hose bent?
	If the water supply hose is bent, the water flow could be compromised.
	Have you dispensed a large amount of ice recently?
	It takes approximately 24 hours to produce more ice in the automatic icemaker. Please wait.
The automatic icemaker does	Did you set the ice maker switch or the automatic icemaker button on the control panel to ON?
not produce ice or produces a small amount of ice.	Press I on the automatic icemaker switch or set ON for the automatic icemaker button on the control panel. (For more details on how to use, visit LG electronics website or use your smart device.)
	Is the temperature of the freezer compartment set too high?
	If the set temperature is too warm, ice will be produced slowly or not at all. Set the Freezer temperature to -18 °C for normal operation of the automatic icemaker.
	Have you been opening the appliance door frequently?
	If you open the appliance door frequently, cold air will escape, lowering the speed of ice production. Do not open and close the appliance door frequently.
	Is the appliance door completely closed?
	If the appliance door is not completely closed, the temperature of the freezer compartment will increase, slowing down the ice production speed. Close the appliance door completely.
	Is there ice in the ice bin?
	Check whether there is ice in the ice bin.
Ice is not dispensed.	Is the ice clumped in the ice bin?
	Separate the ice bin and shake it. Discard the remaining clumped ice after shaking the ice bin.
Ice is not dispensed.	Unable to hear the sound of ice coming out?
	In the control panel, select the modes for cubed ice and crushed ice alternately to dispense the ice.
Water does not come	Is the water supply valve closed? (For plumbed models only)
out.	Open the water supply valve.







Symptoms	Reason & Solution
бутрюто	Is the taste of water different when comparing it with the taste of water
	from the previous water purifier?
	 Has the purified water or cold water not been used for an extended period of time?
	Has it been a long time since you installed and replaced the filter?
	If an expired filter is used, the purification performance may decline. It is recommended to replace the filter according to the filter replacement period.
Matantastas atuanas	Have you flushed out the filter properly in the initial stage after installing it?
Water tastes strange.	When you install or replace the filter for the first time, you need to remove air and activated carbon residue from inside the filter. Use the appliance after dispensing and discharging approximately 5 litres of purified water from the dispenser by pressing the water dispensing lever. (Activated carbon is harmless to humans.)
	Has the purified water or cold water not been used for an extended period of time?
	The taste of old water may change due to bacterial growth. Use the product after dispensing and discharging approximately 5 litres (approximately three minutes) from the water dispenser.
Clicking noises	The defrost control will click when the automatic defrost cycle begins and ends. The thermostat control (or appliance control on some models) will also click when cycling on and off.
	Normal Operation
	Rattling noises may come from the flow of appliance, the water line on the back of the unit (for plumbed models only), or items stored on top of or around the appliance.
	Normal Operation
Dettling noises	Appliance is not resting evenly on the floor.
Rattling noises	Floor is weak or uneven or levelling legs need to be adjusted. See the Door Alignment section.
	Appliance with linear compressor was moved while operating.
	Normal operation. If the compressor does not stop rattling after three minutes, turn the power to the appliance off and then on again.
Whooshing noises	Evaporator fan motor is circulating air through the fridge and freezer compartments.
	Normal Operation
	Air is being forced over the condenser by the condenser fan.
	Normal Operation
Gurgling noises	Appliance flowing through the cooling system
	Normal Operation
Popping noises	Contraction and expansion of the inside walls due to changes in temperature.
	Normal Operation









Symptoms	Reason & Solution
Vibrating	If the side or back of the appliance is touching a cabinet or wall, some of the normal vibrations may make an audible sound.
	To eliminate the noise, make sure that the sides and back do not make any contact with any wall or cabinet.
	The password for the Wi-Fi that you are trying to connect to is incorrect.
Your home appliance and smartphone is not connected to the Wi-Fi network.	Find the Wi-Fi network connected to your smartphone and remove it, then register your appliance on LG ThinQ.
	Mobile data for your smartphone is turned on.
	Turn off the Mobile data of your smartphone and register the appliance using the Wi-Fi network.
	The wireless network name (SSID) is set incorrectly.
	The wireless network name (SSID) should be a combination of English letters and numbers. (Do not use special characters.)
	The router frequency is not 2.4 GHz.
	Only a 2.4 GHz router frequency is supported. Set the wireless router to 2.4 GHz and connect the appliance to the wireless router. To check the router frequency, check with your Internet service provider or the router manufacturer.
	The distance between the appliance and the router is too far.
	If the distance between the appliance and the router is too far, the signal may be weak and the connection may not be configured correctly. Move the location of the router so that it is closer to the appliance.







