

OWNER'S MANUAL

IPS LED Monitor

(LED Monitor*)

* LG LED Monitor applies LCD screen with LED backlights.

Please read this manual carefully before operating your set and retain it for future reference.

38WK95C 38BK95C

TABLE OF CONTENTS

LICENSE	3
ASSEMBLING AND PREPARIN	IG 4
- Product Composition	4
- Supported Drivers and Software	5
- Product and Button Description	6
How to Use the Joystick Button	
Input Connector	
- Moving and Lifting the Monitor	8
- Installing the Monitor	10
Assembling the Stand	
Installing on a Table	
Adjusting the Stand Height	
Adjusting the Angle	
Tidying up Cables	
Using the Kensington Lock	
Detaching the Stand Body	
Installing the Wall Mount Plate	
Installing on the Wall	

USING THE MONITOR 20
- Connecting to a PC20
HDMI Connection
DisplayPort Connection
USB-C connection
- Connecting AV Devices23
HDMI Connection
- Connecting Peripherals23
USB Cable connection
Connecting Headphones

LISING THE MONITOR

USER SETTINGS	25
- Activating the Main Menu	25
Main Menu Features	
- User Settings	27
Menu Settings	
TROUBLESHOOTING	39
PRODUCT SPECIFICATION	42
- Factory Support Mode	44
- HDMI Timing (Video)	45
- Power LED	45
- Wireless module (WB1NP6) Specifications.	45
- Beep Guide	46

WARNING: This product contains chemicals known to the State of California to cause cancer and birth defects or other reproductive harm. Wash hands after handling.

LICENSE

Each model has different licenses. Visit www.lq.com for more information on the license.



The terms HDMI and HDMI High-Definition Multimedia Interface, and the HDMI Logo are trademarks or registered trademarks of HDMI Licensing Administrator, Inc. in the United States and other countries.



The SuperSpeed USB Trident logo is a registered trademark of USB Implementers Forum, Inc.



The *Bluetooth* [®] word mark and logos are registered trademarks owned by Bluetooth SIG, Inc. and any use of such marks by LG Electronics Inc. is under license. Other trademarks and trade names are those of their respective owners.

USB Type- C^{TM} and USB- C^{TM} are trademarks of USB Implementers Forum.


The following content is only applied to the monitor which is sold in Europe market and which needs to meet the ErP Directive:

- * This monitor is set to be turned off automatically in 4 hours after you turned on display if there is no adjustment to display.
- * To make this setting be disabled, change the option to 'Off' in OSD menu of "Automatic Standby".

ASSEMBLING AND PREPARING

Product Composition

Please check whether all the components are included in the box before using the product. If there are any missing components, contact the retailer where you purchased the product. Note that the product and related components may look different from those shown here.





- Always use genuine LG components to ensure safety and product performance.
- The product warranty will not cover damage or injury caused by the use of unauthorized components.
- It is recommend that use the supplied components.
- If you use generic cables not certified by LG, the screen may not display or there
 may be image noises.



NOTE


- The components may look different from those illustrated here.
- Without prior notice, all product information and specifications contained in this manual are subject to change to improve the performance of the product.
- To purchase optional accessories, visit an electronics store or an online shopping site, or contact the retailer from which you purchased the product.
- The power cord provided may differ depending upon the region.

Supported Drivers and Software

You can download and install the latest version from the LGE website (www.lg.com).

Drivers and Software	Installation Priority	38WK95C 38BK95C	
Monitor Driver	Recommended	0	
ASM Driver	Required	X	
OnScreen Control	Recommended	0	
Dual Controller	Optional	0	
True Color Pro	Optional	X	

Product and Button Description



How to Use the Joystick Button

You can easily control the functions of the monitor by pressing the joystick button or moving it left/right with your finger.


Basic Functions

	@	Power on	Press the joystick button once with your finger to turn on the monitor.
		Power off	Press and hold the joystick button once with your finger to turn off the monitor.
8	⋖/ ▶	Volume Control	You can control the volume by moving the joystick button left/right.



• The joystick button is located at the bottom of the monitor.


Input Connector



Moving and Lifting the Monitor

When moving or lifting the monitor, follow these instructions to prevent the monitor from being scratched or damaged and to ensure safe transportation, regardless of its shape or size.

- Place the monitor in the original box or packing material before attempting to move it.
- Before moving or lifting the monitor, disconnect the power cord and all other cables.
- Hold the bottom and side of the monitor frame firmly. Do not hold the panel itself.





- When holding the monitor, the screen should face away from you to prevent it from being scratched.
- When transporting the monitor, do not expose the monitor to shock or excessive vibration.
- When moving the monitor, keep it upright and never turn the monitor on its side or tilt it sideways.




CAUTION

- · Avoid touching the monitor screen as much as possible.
- This may result in damage to the screen or some of the pixels used to create images.




If you use the monitor panel without the stand base, its joystick button may cause
the monitor to become unstable and fall, resulting in damage to the monitor or
human injury. In addition, this may cause the joystick button to malfunction.




Installing the Monitor

Assembling the Stand








• To protect the screen, place the screen face down on the screen pad which is inside the box.




2












· Press the stand until the button reaches the top.







- Illustrations in this document represent typical procedures, so they may look different from the actual product.
- Do not apply foreign substances (oils, lubricants, etc.) to the screw parts when assembling the product. (Doing so may damage the product.)
- Applying excessive force when tightening screws may cause damage to the monitor. Damage caused in this way will not be covered by the product warranty.
- Do not carry the monitor upside down by just holding the base. This may cause the monitor to fall off the stand and could result in personal injury.
- When lifting or moving the monitor, do not touch the monitor screen. The force applied to the monitor screen may cause damage to it.

Installing on a Table

1 Lift the monitor and place it on the table in an upright position. Place the monitor at least 100 mm (3.94 inches) away from the wall to ensure sufficient ventilation.



2 Connect the power adapter to the monitor and then plug the power cord into the wall outlet.




3 Press the joystick button on the bottom of the monitor to turn on the monitor.



• Unplug the power cord before moving or installing the monitor. There is risk of electric shock.

Cautions When Connecting Power Cord




100-240 V ~


- Make sure to use the power cord that is provided in the product package and connect it to a grounded power outlet.
- If you need another power cord, please contact your local dealer or the nearest retail store.

Adjusting the Stand Height


- 1 Place the monitor mounted on the stand base in an upright position.
- 2 Handle the monitor with both hands for safety.



Max 100.0 mm (3.94 inches)








• When adjusting the screen height, do not place your hand on the stand body to avoid injury to your fingers.

Adjusting the Angle


- 1 Place the monitor mounted on the stand base in an upright position.
- 2 Adjust the angle of the screen.

The angle of the screen can be adjusted forward or backward from -5° to 15° for a comfortable viewing experience.






To avoid injury to the fingers when adjusting the screen, do not hold the lower part
of the monitor's frame as illustrated below.




 Be careful not to touch or press the screen area when adjusting the angle of the monitor.






 The left or right side of the monitor head can be slightly rotated up or down (up to 3°). Adjust the horizontal level of the monitor head.



Tidying up Cables

Arrange the cables using the cable holder as shown in the illustration.




Using the Kensington Lock

The connector for the Kensington security system is located at the bottom of the monitor.

For more information on installation and usage, refer to the Kensington lock owner's manual or visit the website at http://www.kensington.com.

Connect the monitor to a table using the Kensington security system cable.





 The Kensington security system is optional. You can obtain optional accessories from most electronics stores.

Detaching the Stand Body

- 1 Place the monitor's screen face down. To protect the screen from scratches, cover the surface with a soft cloth.
- 2 Remove the stand from the monitor by pressing the button on the bottom center of the back of the monitor.



Installing the Wall Mount Plate

This monitor meets the specifications for the wall mount plate or other compatible devices.

- 1 Place the screen face down. To protect the monitor panel (screen), cover the surface with a soft cloth or the monitor protection pad included in the product package.
- 2 Remove the four screws tightened on the back of the monitor.
- 3 Place the wall mount plate onto the monitor and align it with the screw holes.
- 4 Tighten the four screws using a screwdriver to fix the plate to the monitor.




NOTE

- The wall mount plate is sold separately.
- For more information on installation, refer to the wall mount plate's installation guide.
- Be careful not to apply too much force while mounting the wall mount plate as it may cause damage to the screen.

Installing on the Wall

Install the monitor at least 100 mm (3.94 inches) away from the wall and leave about 100 mm (3.94 inches) of space at each side of the monitor to ensure sufficient ventilation. Detailed installation instructions can be obtained from your local retail store. Alternatively, please refer to the manual for how to install and set up a tilting wall mounting bracket.



To install the monitor to a wall, attach a wall mounting bracket (optional) to the back of the monitor.

Make sure that the wall mounting bracket is securely fixed to the monitor and to the wall.

- 1 If you use screws longer than the standard length, it may damage the inside of the product.
- 2 A non-VESA standard screw may damage the product and cause the monitor to fall. LG Electronics is not liable for any accidents relating to the use of nonstandard screws.

Wall Mount (mm)	100 x 100
Standard screw	M4 x L10
Required Screws	4
Wall Mount Plate (Optional)	LSW 149




- · Use the screws specified by VESA standards.
- The wall mount kit includes the installation guide and all necessary parts.
- The wall mounting bracket is optional. You can obtain optional accessories from your local dealer.
- The length of the screw may differ for each wall mounting bracket. Be sure to use the proper length.
- For more information, please refer to the user manual for the wall mounting bracket.



CAUTION

- Unplug the power cord before moving or installing the monitor to avoid electric shock.
- Installing the monitor on the ceiling or on a slanted wall may result in the monitor falling off, which could lead to injury. Use an authorized LG wall mount and contact the local dealer or qualified personnel.
- Applying excessive force when tightening screws may cause damage to the monitor. Damage caused in this way will not be covered by the product warranty.

- Use the wall mounting bracket and screws that conform to VESA standards.
 Damage caused by the use or misuse of inappropriate components will not be covered by the product warranty.
- When measured from the back of the monitor, the length of each installed screw must be 8 mm (0.3 inches) or less.



USING THE MONITOR

 The following instructions are based on the 38UC99 model. Illustrations in this manual may differ from the actual product.

Press the joystick button, go to $\textbf{Settings} \rightarrow \textbf{Input}$, and then select the input option.



CAUTION

- Do not press the screen for a prolonged time. This may cause image distortion.
- Do not display a still image on the screen for a prolonged time. This may cause image retention. Use a screensaver if possible.



NOTE


- When connecting the power cord to the outlet, use a grounded (3-hole) power strip or a grounded power outlet.
- The monitor may flicker when turned on in an area where the temperature is low.
 This is normal.
- · Sometimes red, green, or blue spots may appear on the screen. This is normal.

Connecting to a PC

- · This monitor supports the *Plug and Play feature.
- * Plug and Play: A feature that allows you to add a device to your computer without having to reconfigure anything or install any manual drivers.

HDMI Connection

Transmits digital video and audio signals from your PC to the monitor. Connect your PC to the monitor using the HDMI cable as shown in the illustration below.






- Make sure to use the supplied HDMI cable of the product. Otherwise, this may cause the device to malfunction.
- Connecting your PC to the monitor using the HDMI cable may cause device compatibility issues.
- Using a DVI to HDMI / DP (DisplayPort) to HDMI cable may cause compatibility issues.
- Use a certified cable with the HDMI logo attached. If you do not use a certified HDMI cable, the screen may not display or a connection error may occur.
- Recommended HDMI cable types
 - High-Speed HDMI®/™ cable
 - High-Speed HDMI®/TM cable with Ethernet

DisplayPort Connection

Transmits digital video and audio signals from your PC to the monitor. Connect the monitor to your PC using the DisplayPort cable as shown in the illustration below.






NOTE

- There may be no video or audio output depending on the DP (DisplayPort) version of the PC.
- Make sure to use the supplied DisplayPort cable of the product. Otherwise, this
 may cause the device to malfunction.
- For using Mini DP to DP (Mini DisplayPort to DisplayPort) cable, it is recommended that you use DisplayPort 1.2 cable.


USB-C connection

Transmits digital video and audio signals and USB data from your PC to the monitor. Connect the monitor to your PC using the USB-C cable as shown in the illustration below. Press the menu button and then select the input option from the input menu.






- PD (Power Delivery), DP Alternate Mode (DP over USB-C) and USB Data are supported via USB-C Port.
- Features may not work properly depending on the connected device's specifications and the environment.
- USB-C port is not for the Monitor Power source but for a PC power source.
 Connect Adapter to supply power to the Monitor.



Connecting AV Devices

HDMI Connection

HDMI transmits digital video and audio signals from your AV device to the monitor. Connect your AV device to the monitor using the HDMI cable as shown in the illustration below





- Make sure to use the supplied HDMI cable of the product. Otherwise, this may cause the device to malfunction.
- Using a DVI to HDMI / DP (DisplayPort) to HDMI cable may cause compatibility issues.
- Use a certified cable with the HDMI logo attached. If you do not use a certified HDMI cable, the screen may not display or a connection error may occur.
- · Recommended HDMI cable types
 - High-Speed HDMI®/™ cable
 - High-Speed HDMI®/™ cable with Ethernet


Connecting Peripherals

USB Cable connection

The USB port on the product functions as a USB hub.

Please connect the **USB C-C cable** or **USB C-C cable + USB C-A gender** to the PC. To use USB 3.0, connect the **USB C-C cable + USB C-A gender** of the product to the PC.

Peripheral devices connected to the USB IN port can be controlled from the PC.





- Make sure to install the most recent Windows OS service pack before using the product.
- · Peripheral devices are sold separately.
- · A keyboard, mouse, or USB device can be connected to the USB port.
- · The charging speed may vary depending on the device.
- To use USB Downstream port of monitor, user must connect Upstream port of monitor to Host PC using USB C-C or USB C-A cable.
- When the USB C-C cable is connected between Upstream port of monitor and Host PC, the Downstream port of monitor support USB 2.0 device.
- When the USB C-A cable is connected between Upstream port of monitor and Host PC, the Downstream port of monitor support USB 3.0 device.
 However, Host PC must support USB 3.0 function.




Cautions When Using a USB Device

- A USB device with an automatic recognition program installed, or that uses its own driver, may not be recognized.
- Some USB devices may not be supported or may not work properly.
- It is recommended to use a USB hub or hard disk drive with power supplied. (If the power supply is not adequate, the USB device may not be recognized properly.)

Connecting Headphones

Connect peripherals to the monitor via the headphones port. Connect as illustrated.





NOTE

- · Peripheral devices are sold separately.
- If you use angled earphones, it may cause a problem with connecting another external device to the monitor. Therefore, it is recommended to use straight earphones.





Straight

 Depending on the audio settings of the PC and external device, headphones and speaker functions may be limited.


USER SETTINGS



- Your monitor's OSD (On Screen Display) may differ slightly from that shown in this manual.
- When **Beep Guide** is activated, pressing the joystick button will take you to **Settings** right away.

Activating the Main Menu

- 1 Press the joystick button on the bottom of the monitor.
- 2 Move the joystick up/down (▲ / ▼) and left/right (◄ / ►) to set the options.
- 3 Press the joystick button once more to exit the main menu.



Button	Menu Status		Description	
	Main menu enabled		Enables the main menu.	
			Exits the main menu. (Holding down the button to turn off the monitor. You can turn off the monitor this way at any time, including when the OSD is on.)	
	•	Main menu disabled	Adjusts the monitor volume level.	
		Main menu enabled	Enters the Input features.	
	•	Main menu disabled	Adjusts the monitor volume level.	
		Main menu enabled	Enters the Settings feature.	
		Main menu disabled	Enters the Accessibility menu.	
		Main menu enabled	Turns off the monitor.	
	•	Main menu disabled	Enters the Accessibility menu.	
•		Main menu enabled	Enters the Game feature.	

Main Menu Features



Main Menu	Description
Input	Sets input mode.
Power Off	Turns off the monitor.
Settings	Configures the screen settings.
Game	Sets the game mode for gaming.
Exit	Exits the main menu.

User Settings

Menu Settings

- 1 To view the settings menu, press the joystick button at the bottom of the monitor and then enter the **settings**.
- 2 Configure the options by moving the joystick up/down/left/right.
- 3 To return to the upper settings or set other settings items, move the joystick to ◀ or press (憑).
- 4 If you want to exit the settings menu, move the joystick to ◀ until you exit.
- When you enter the menu, instructions on how to use the button will appear in the bottom right corner of the screen.





• Your monitor's OSD (On Screen Display) may differ slightly from that shown in this manual.

Each option is described below.

Settings > Quick Settings	Description			
Brightness	A !:			
Contrast	Adjusts the col	or contrast and brightness of the screen.		
Volume	Adjusts the vol	ume level.		
	NOTE			
	 You can adjust 	t Mute / Unmute by moving the joystick button to ▼ in the Volume menu.		
	The available	minimum and maximum volumes for Bluetooth Audio depend on the monitor's OSD volume.		
Color Temp	Custom	The user can adjust it to red, green, or blue by customization.		
	Warm	Sets the screen color to a reddish tone.		
	Medium Sets the screen color between a red and blue tone.			
	Cool Sets the screen color to a bluish tone.			
Screen Off	Turns off the monitor's backlight and plays only the audio from the connected input or Bluetooth device. The audio continues to play even after the screen turns off.			
	NOTE			
	To turn the screen back on, press the joystick button on the bottom of the monitor.			
Bluetooth Audio	Reconnects to previously connected Bluetooth devices or disconnects from already connected Bluetooth devices.			
	NOTE			
	The monitor can only reconnect if it was previously connected to a Bluetooth device.			

Each option is described below.

Settings > Input	Description				
Main Input List	Selects the ir	nput mode.			
Aspect Ratio	Adjusts the a	spect ratio of the screen.			
	Full Wide	Displays the video in widescreen, regardless of the video signal input.			
	Original	Displays video according to the aspect ratio of the video signal input.			
	1:1	The aspect ratio is not adjusted from the original.			
	Cinema1	Enlarges the screen with an aspect ratio of 21:9. (at 1080p)			
	Cinema2	Cinema2 Enlarges the screen with an aspect ratio of 21:9, including the black box at the bottom for subtitles. (at 1080p)			
	NOTE				
	• The display may look the same for Full Wide , Original , and 1:1 options at the recommended resolution (3840 x 1600).				
	There is no 1:1, Cinema1, Cinema2 menu on FreeSync Mode.				
	(Go to Picture → Game Adjust → FreeSync , to set FreeSync On or Off)				
PBP	Displays the screens of two input modes on one monitor.				
Main/Sub Screen Change	Toggles between the main screen and sub screen in PBP mode.				
Main/Sub Sound Change	Toggles between the audio of the main screen and sub screen in PBP mode.				

[PBP]

Settings > Input		Description					
Input List	Main Input List	D: 1 .1					
	Sub Input List	Displays the screens of two input modes on one monitor.					
	DBD	Connection	Sub Screen (Right)				
	PBP	Connection	HDMI 1	HDMI 2	DisplayPort	USB-C	
		HDMI 1	X	Х	0	0	
	Main Screen	HDMI 2	X	Х	0	0	
	(Left)	DisplayPort	0	0	Х	Х	
		USB-C	0	0	X	Χ	
Aspect Ratio	Adjusts the aspect ratio of the screen.						
	Main Aspect Ratio	Full Wide	Displays the video to fit the PBP screen, regardless of the video signal input.				
		Original	Displays the video in the aspect ratio of the video signal input on the PBP screen.				
	Sub Aspect Ratio	Full Wide	Displays the video to fit the PBP screen, regardless of the video signal input.				
		Original	Displays the video in the a	spect ratio of the video sig	gnal input on the PBP screen.		
PBP	You can disable the feature that displays images from two input modes simultaneously on one monitor.						
Main/Sub Screen Change	Toggles between the main screen and sub screen in PBP mode.						
Main/Sub Sound Change	Toggles between the audio of the main screen and sub screen in PBP mode.						



- If not using the PBP feature, Main/Sub Screen Change and Main/Sub Sound Change are deactivated.
- If using the PBP feature, the HDR function will be disabled.

Each option is described below.

Settings > Picture		Description		
Picture Mode	Custom	Allows the user to adjust each element. The color mode of the main menu can be adjusted.		
	Reader	Optimizes the screen for viewing documents. You can brighten the screen in the OSD menu.		
	Photo	Optimizes the screen for photos.		
	Cinema	Optimizes the screen for video.		
	HDR Effect	Optimizes the screen for high dynamic range.		
	Dark Room 1	This mode adjusts the brightness to the optimal level for working in a dark environment.		
	Dark Room 2 This mode sets the brightness to a lower level than Dark Room 1.			
	Color Weakness	This mode is for users who cannot distinguish between red and green. It enables users with color weakness to easily distinguish between the two colors.		
	FPS Game 1	This mode is optimized for FPS games.		
	FPS Game 2	It has a higher Black Stabilizer value than FPS Game 1. It is suitable for very dark FPS games.		
	RTS Game	RTS Game This mode is optimized for RTS Game.		
	Custom (Game) In this mode, users can customize various elements including game-related options.			
	NOTE If the Picture Mod	e is changed in the DP (DisplayPort) input, the screen may flicker or the resolution of your PC screen may be affected.		

Picture Mode on HDR signal.

Settings > Picture		Description		
Picture Mode	HDR Vivid	Optimized the screen for HDR vivid colors.		
	HDR Standard	Optimized the screen for HDR.		
	HDR Game	Optimized the screen for HDR Games.		
	HDR Cinema	Optimized the screen for HDR video.		



NOTE

- HDR content may not be operated properly depending on the Windows10 OS setting. Please check the HDR On / Off setting of Windows.
- When the HDR function is turned on, the characters or picture quality may be poor according to Graphic card performance.
- While the HDR function is on, screen flickering or cracking may occur when changing the monitor input or power on/off according to Graphic card performance.

Settings > Picture	Description				
Picture Adjust	Brightness	Adjusts the color contrast and brightness of the screen.			
	Contrast				
	Sharpness	Adjusts the sharpness of the screen.			
	SUPER RESOLUTION+	High	Optimizes the screen for crystal clear images. Best for high-definition video or games.		
		Middle	Optimizes the screen for comfortable viewing, with images at the middle level between the low and high modes. Best for UCC or SD videos.		
		Low	Optimizes the screen for smooth and natural images. Best for still images or images with less movement.		
		Off	Displays in the most common setting. Disables SUPER RESOLUTION+ .		
		NOTE - Because this is a function to increase the sharpness of low resolution pictures, it is not recommended to use the function for normal text or for desktop icons. Doing so may result in unnecessarily high sharpness.			
	Black Level	Sets the offset level (for HDMI only).			
		Offset: as a reference for a video signal, this is the darkest color the monitor can display.			
		High	Keeps the current contrast ratio of the screen.		
		Low	Lowers the black levels and raises the white levels from the current contrast ratio of the screen.		
	DFC	On	Adjusts the brightness automatically according to the screen.		
		Off	Disables the DFC feature.		

Settings > Picture	Description				
Game Adjust	Response Time	Sets a response time for displayed pictures based on the speed of the screen. For a normal environment, it is recommended that you use Fast . For a fast-moving picture, it is recommended that you use Faster . Setting to Faster may cause image sticking.			
		Faster	Sets the response time to faster.		
		Fast	Sets the response time to fast.		
		Normal	Sets the response time to normal.		
		Off	Does not use the response time improvement feature.		
	FreeSync	Provides seamless and natural images by synchronizing the vertical frequency of the input signal with that of the output signal. CAUTION Supported Interface: DisplayPort, HDMI Supported Graphic Card: A graphic card that supports AMD's FreeSync is necessary. Supported Version: Make sure to update the graphic card to the latest driver. For more information and requirement, refer to AMD website at http://www.amd.com/FreeSync .			
		On	FreeSync function on. NOTE When FreeSync function is On, the brightness is reduced. FreeSync function off.		
	Black Stabilizer	You can cont Increasing th game screen	crol the black contrast to have better visibility in dark scenes. e Black Stabilizer value brightens the low gray level area on the screen. (You can easily distinguish objects on dark		

Settings > Picture	Description			
Color Adjust	Gamma	Mode 1, Mode 2, Mode 3	The higher the gamma value, the darker the image becomes. Likewise, the lower the gamma value, the lighter the image becomes.	
		Mode 4	If you do not need to adjust the gamma settings, select Mode 4.	
	Color Temp	Custom	The user can adjust it to red, green, or blue by customization.	
		Warm	Sets the screen color to a reddish tone.	
		Medium	Sets the screen color to between a red and blue tone.	
		Cool	Sets the screen color to a bluish tone.	
	Red	You can customize the picture color using Red , Green , and Blue colors.		
	Green			
	Blue			
	Six Color	Meets the user requirements for colors by adjusting the hue and saturation of the six colors (red, green, blue, cyan, magenta, and yellow) and then saving the settings.		
		Hue	Adjusts the tone of the screen colors.	
		Saturation	Adjusts the saturation of the screen colors. The lower the value, the less saturated and brighter the colors become. The higher the value, the more saturated and darker the colors become.	
Screen Off	Turns off the monitor's backlight and plays only the audio from the connected input or Bluetooth device.			
Picture Reset	Returns picture to the default settings.			

Each option is described below.

Settings > Sound	Description		
Volume	Adjusts the volume level.		
	NOTE • You can adjust Mute / Unmute by moving the joystick button to in the Volume menu.		
	The available minimum and maximum volumes for Bluetooth Audio depend on the monitor's OSD volume.		
Bluetooth Audio	On	Connects to a previously connected Bluetooth device.	
	Off	Disconnects from an already connected Bluetooth device.	



- If there is no input signal while a Bluetooth device is connected, a message is displayed for 10 minutes.
- If there is no input signal while a Bluetooth device is streaming, the monitor will not enter the power-saving mode and remain off.

Each option is described below.

Settings > General	Description					
Language	Sets the menu screen to the desired language.					
SMART ENERGY	Conserve ene	Conserve energy by using luminance compensation algorithm.				
SAVING	High	Saves energy using the high-efficiency SMART ENERGY SAVING feature.				
	Low	Saves energy using the low-efficiency SMART ENERGY SAVING feature.				
	Off	Disables the SMART ENERGY SAVING feature.				
Power LED	On	The power LED turns on automatically.				
	Off	The power LED turns off.				
Automatic Standby	Feature that automatically turns off the monitor when there is no movement on the screen for a period of time. You can set a timer for the auto-off function. (Off, 4 H, 6 H, and 8 H)					
HDMI Compatibility	HDMI Compa	atibility Mode feature can recognize the legacy equipment that does not support HDMI 2.0.				
Mode	On	Enables HDMI Compatibility Mode.				
	Off	Disables HDMI Compatibility Mode.				
	NOTE • If the connected device does not support HDMI Compatibility Mode, the screen or sound may not work properly. • When HDMI Compatibility Mode is on, HDR function is not supported. • Some older graphics cards do not support HDMI 2.0, but you can select HDMI 2.0 resolution in the control panel of window. This may cause the screen to appear abnormally.					
DisplayPort 1.2	Enables or disables DisplayPort 1.2 .					
	NOTE • Be sure to configure this option according to the DisplayPort version supported by your graphic card. Set this option to Disable if your graphic card does not support DisplayPort 1.2.					

Settings > General	Description					
Buzzer	This feature lets you set the sound generated from Buzzer when your monitor powers on.					
	On	Enables your monitor's Buzzer .				
	Off	Disables your monitor's Buzzer .				
OSD Lock	This featu	re disables the configuration and adjustment of menus.				
	On	Enables OSD Lock.				
	Off	Disables OSD Lock.				
	NOTE • All features are disabled except Brightness, Contrast, Volume in Quick Settings, Input,Information and OSD Lock in General.					
Deep Sleep Mode	When Deep sleep mode is enabled, power consumption is minimized while the monitor is in standby mode.					
	On	Enables Deep sleep Mode.				
	Off	Disables Deep sleep Mode.				
	NOTE					
	USB HUB functions will not work in standby mode while Deep sleep Mode is enabled in standby mode.					
Information	The display information will be shown the Model, Serial Number, Total Power On Time, Resolution.					
Reset	Do you want to reset your settings?					
	No	Cancel the reset.				
	Yes	Restores the default settings.				



• Saving Data depends on the Panel. These values vary by panel and vendor. If the option of SMART ENERGY SAVING is set High or Low, monitor luminance becomes higher or lower depending upon the source.

TROUBLESHOOTING

Nothing is displayed on the screen.					
Is the monitor's power cord plugged in?	Check if the power cord is correctly plugged into the power outlet.				
Is the power LED on?	Check the power cable connection and press the power button.				
Is the power on and the power LED displaying white?	Check that the connected input is enabled (Settings > Input).				
Is the power LED blinking?	 If the monitor is in sleep mode, move the mouse, or press any key on the keyboard, to switch the display on. Check if the computer is turned on.				
Is the OUT OF RANGE message being displayed?	This occurs when signals transferred from the PC (graphic card) are out of the horizontal or vertical frequency range of the monitor. Please see the Product Specification section of this manual to set the appropriate frequency.				
Is the No Signal message being displayed?	This is displayed when the signal cable between the PC and the monitor is missing or disconnected. Check the cable and reconnect it.				
The screen may not be displayed properly when configuring DisplayPort 1.2 in a Mac product.	DisplayPort 1.2 may not be supported depending upon the Mac product. Please contact the manufacturer.				

The OSD Lock message is being displayed.				
Are some functions not available when	Are some functions not available when • The OSD is locked. Go to Settings > General and set OSD Lock to Off .			
you press the Menu button?				

The screen retains an image.			
Does image sticking occur even when the	Displaying a still image for a prolonged time may cause damage to the screen, resulting in the retention of the image.		
monitor is turned off?	To extend the lifetime of the monitor, use a screensaver.		

Screen display is unstable and shaky. / Images displayed on the monitor leave shadow trails.					
Did you select the appropriate resolution?	• If the selected resolution is HDMI 1080i 60/50 Hz (interlaced), the screen may be flickering. Change the resolution to 1080p or				



NOTE

- Vertical Frequency: In order to display an image, the screen must be refreshed dozens of times per second, like a fluorescent lamp. The number of times the screen is refreshed
 per second is called vertical frequency, or refresh rate, and is represented by Hz.
- Horizontal Frequency: The time it takes to display one horizontal line is called the horizontal cycle. If 1 is divided by the horizontal interval, the result is the number of horizontal lines displayed per second. This is called horizontal frequency and is represented by kHz.
- Check if the graphic card's resolution or frequency is within the range allowed by the monitor and set it to the recommended (optimal) resolution **Control Panel** > **Display** > **Settings** in Windows. (The settings may differ depending on the operating system (OS) you use.)
- · Not setting the graphic card to the recommended (optimal) resolution may result in blurred text, a dimmed screen, a truncated display area or misalignment of the display.
- The setting methods may be different depending on the computer or operating system, and some resolutions may not be available depending on the performance of the graphic card. If this is the case, contact the manufacturer of the computer or graphic card for assistance.
- Some graphic cards may not support 3840 x 1600 resolution. If the resolution cannot be displayed, contact the manufacturer of your graphic card.

the recommended resolution

The display color is abnormal.				
Does the display appear discolored (16 colors)?	• Set the color to 24 bit (true color) or higher. In Windows, go to Control Panel > Display > Settings > Color Quality . (The settings may differ depending on the operating system (OS) you use.)			
Does the display color appear unstable or monochrome?	Check if the signal cable is connected properly. Reconnect the cable or reinsert the PC's graphic card.			
Are there spots on the screen?	When using the monitor, pixilated spots (red, green, blue, white, or black) may appear on the screen. This is normal for an LCD screen. It is not an error, nor is it related to the monitor's performance.			

Do you see an "Unrecognized monitor, Plug and Play (VESA DDC) monitor found" message?			
Have you installed the display driver?	Be sure to install the display driver from our web site: http://www.lg.com.		
Make sure to check if the graphics card supports Plug and Play function.			

No sound from the headphone port.				
Are images displayed using DP (DisplayPort) or HDMI input without	 Make sure that the headphone port connections are made properly. Try increasing the volume with the joystick. 			
sound?	• Set the audio output of the PC to the monitor you are using. On Microsoft Windows, go to Control Panel > Hardware and Sound > Sound > set the Monitor as default device . (The settings may differ depending on the operating system (OS) you use.)			

PRODUCT SPECIFICATION

LCD Screen	Туре	TFT (Thin Film Transistor) LCD (Liquid Crystal Display) Screen				
	Color Depth	HDMI	8-bit/10-bit color is supported.			
		DP (DisplayPort)	8-bit / 10-bit color is supported.			
	Pixel Pitch	0.22908 mm x 0.22908 mm				
Resolution	Max Resolution	3840 x 1600 @ 75 Hz				
	Recommended Resolution	3840 x 1600 @ 60 Hz				
Video Signal	Horizontal Frequency	30 kHz to 130 kHz				
	Vertical Frequency	56 Hz to 75 Hz				
	Synchronization	Separate Sync.				
Input Connector H/P (), HDMI IN 1/2, DP (DisplayPort) IN, USB (\$\$<->) 1/2, USB-C (UPSTREAM \$\$<->)			•) 1/2, USB-C (UPSTREAM SS<)			
Power Sources Power Rating		19 V 7.7 A				
	Power Consumption (Typical)	Operating Mode: 70 W (Typical, USB excluded) (Outgoing condition)* Off Mode: ≤ 0.3 W				
AC/DC Adapter	DA-180C19 type, manufactured by APD Output: 19 V = 9.48 A ACC-LATP1 type, manufactured by SHENZHEN HONOR ELECTRONIC Output: 19.5 V = 10.8 A					

Environmental	Operating Conditions	Temperature	0 °C to 40 °C (32 °F to 104 °F)		
Conditions		Humidity	Less than 80 %		
	Storing Conditions	Temperature	-20 °C to 60 °C (-4 °F to 140 °F)		
		Humidity	Less than 85 %		
Dimensions	Monitor Size (Width x Height x Depth)				
	With Stand	897.2 mm x 596.3 mm x 234.9 mm (35.3 inches x 23.5 inches x 9.2 inches)			
	Without Stand	897.2 mm x 394.0 mm x 91.5 mm (35.3 inches x 15.5 inches x 3.6 inches)			
Weight (Without	With Stand	9.2 kg (20.3 lbs)	9.2 kg (20.3 lbs)		
Packaging)	Without Stand	7.7 kg (16.9 lbs)			

Specifications are subject to change without notice.

The ~ symbol means alternating current, and the symbol ___ means direct current.

^{*} The Operating Mode of Power Consumption is measured with LGE test standard. (Full White pattern, Maximum resolution)

^{**} In case of USB-C input, the power consumption of Sleep Mode may vary depending on the connected device.

Factory Support Mode

(Preset Mode, HDMI/ DisplayPort/ USB-C PC)

Preset Mode	Horizontal Frequency (kHz)	Vertical Frequency (Hz)	Polarity (H/V)	Remarks
640 x 480	31.469	59.94	-/-	
800 x 600	37.879	60.317	+/+	
1024 x 768	48.363	60.0	-/-	
1152 x 864	54.347	60.05	+/+	
1280 x 720	45	60	+/+	
1280 x 1024	63.981	60.02	+/+	
1600 x 900	60.00	60.00	+/+	
1680 x 1050	65.29	59.954	-/+	
1920 x 1080	67.50	60	+/-	
1920 x 1080	83.894	74.973	+/-	
3440 x 1440	110.77	75.05	+/-	
3840 x 1600	50.39	29.99	+/-	
3840 x 1600	102.23	59.99	+/-	
3840 x 1600	102.24	60	+/-	
3840 x 1600	128.69	75	+/-	

HDMI Timing (Video)

Preset Mode	Horizontal Frequency (kHz)	Vertical Frequency (Hz)
640 x 480p	31.47	60
720 x 480p	31.47	60
720 x 576p	31.25	50
1280 x 720p	45	60
1280 x 720p	37.5	50
1920 x 1080p	67.5	60
1920 x 1080p	56.25	50
3840 x 2160p	135	60

Power LED

Mode	LED Color
On Mode	White (For a few seconds)
Sleep Mode (Standby Mode)	Off
Off Mode	Off

Wireless module (WB1NP6) Specifications

Bluetooth		
Frequency range	Output power (Max.)	
2400 to 2483.5 MHz	10 dBm	

- As band channels can vary per country, the user cannot change or adjust the operating frequency. This product is configured for the regional frequency table.
- For consideration of the user, this device should be installed and operated with a minimum distance of 20 cm (7.8 inches) between the device and the body.
- FCC ID: BEJ9QK-DMWB1NP6 / IC: 2703H-DMWB1NP6

Beep Guide

Menu	Location
Quick Settings	1
Quick Settings - Brightness	11
Quick Settings - Brightness	1 1 1 Slider
Quick Settings - Contrast	1 2
Quick Settings - Contrast	1 2 1 Slider
Quick Settings - Volume	13
Quick Settings - Volume	1 3 1 Slider
Quick Settings - Color Temp	1 4
Quick Settings - Color Temp - Custom	141
Quick Settings - Color Temp - Warm	1 4 2
Quick Settings - Color Temp - Medium	143
Quick Settings - Color Temp - Cool	1 4 4
Quick Settings - Screen Off	15
Quick Settings - Screen Off - No	151
Quick Settings - Screen Off - Yes	152
Quick Settings - Bluetooth Audio	16
Quick Settings - Bluetooth Audio - On	161
Quick Settings - Bluetooth Audio - Off	162
Input (PBP Off)	2
Input (PBP Off) - Input List	2 1

Menu	Location
Input (PBP Off) - Input List - HDMI 1	211
Input (PBP Off) - Input List - HDMI 2	212
Input (PBP Off) - Input List - DisplayPort	213
Input (PBP Off) - Input List - USB-C	214
Input (PBP Off) - Aspect Ratio	2 2
Input (PBP Off) - Aspect Ratio - Full Wide	221
Input (PBP Off) - Aspect Ratio - Original	222
Input (PBP Off) - Aspect Ratio - Just Scan	223
Input (PBP Off) - Aspect Ratio - Cinema 1	224
Input (PBP Off) - Aspect Ratio - Cinema 2	225
Input (PBP Off) - PBP	23
Input (PBP Off) - PBP - Off	2 3 1
Input (PBP Off) - PBP - On	232
Input (PBP Off) - Main/Sub Screen Change	2 4
Input (PBP Off) - Main/Sub Sound Change	2 5
Input (PBP On)	2

Menu	Location
Input (PBP On) - Input List	2 1
Input (PBP On) - Input List - Main Input	211
Input (PBP On) - Input List - Main Input - HDMI 1	2111
Input (PBP On) - Input List - Main Input - HDMI 2	2112
Input (PBP On) - Input List - Main Input - DisplayPort	2113
Input (PBP On) - Input List - Main Input - USB-C	2114
Input (PBP On) - Input List - Sub Input	212
Input (PBP On) - Input List - Sub Input - HDMI 1	2121
Input (PBP On) - Input List - Sub Input - HDMI 2	2122
Input (PBP On) - Input List - Sub Input - DisplayPort	2123
Input (PBP On) - Input List - Sub Input - USB-C	2124
Input (PBP On) - Aspect Ratio	2 2
Input (PBP On) - Aspect Ratio - Main Aspect Ratio	221

Menu	Location
Input (PBP On) - Aspect Ratio - Main Aspect Ratio - Full Wide	2211
Input (PBP On) - Aspect Ratio - Main Aspect Ratio - Original	2212
Input (PBP On) - Aspect Ratio - Sub Aspect Ratio	222
Input (PBP On) - Aspect Ratio - Sub Aspect Ratio - Full Wide	2221
Input (PBP On) - Aspect Ratio - Sub Aspect Ratio - Original	2222
Input (PBP On) - PBP	23
Input (PBP On) - PBP - Off	231
Input (PBP On) - PBP - Off - HDMI 1	2311
Input (PBP On) - PBP - Off - HDMI 2	2312
Input (PBP On) - PBP - Off - DisplayPort	2313
Input (PBP On) - PBP - Off - USB-C	2314
Input (PBP On) - PBP - On	232
Input (PBP On) - Main/Sub Screen Change - On	2 4 Yes
Input (PBP On) - Main/Sub Sound Change - On	2 5 Yes
Picture	3
Picture - Picture Mode	3 1
Picture - Picture Mode - Custom	311

Menu	Location
Picture - Picture Mode - Reader	312
Picture - Picture Mode - Photo	313
Picture - Picture Mode - Reader	314
Picture - Picture Mode - Photo	315
Picture - Picture Mode - Cinema	316
Picture - Picture Mode - HDR Effect	317
Picture - Picture Mode - Dark Room1	318
Picture - Picture Mode - Dark Room2	319
Picture - Picture Mode - Color Weakness	3 1 10
Picture - Picture Mode - FPS Game1	3 1 11
Picture - Picture Mode - FPS Game2	3 1 12
Picture - Picture Mode - RTS Game	3 1 13
Picture - Picture Mode - Custom(Game)	3 1 14
Picture - Picture Adjust	3 2
Picture - Picture Adjust - Brightness	3 2 1
Picture - Picture Adjust - Brightness	3 2 1 1 Slider
Picture - Picture Adjust - Contrast	322
Picture - Picture Adjust - Contrast	3 2 2 1 Slider
Picture - Picture Adjust - Sharpness	323

Menu	Location
Picture - Picture Adjust - Sharpness	3 2 3 1 Slider
Picture - Picture Adjust - SUPER RESOLUTION+	324
Picture - Picture Adjust - SUPER RESOLUTION+ - High	3241
Picture - Picture Adjust - SUPER RESOLUTION+ - Middle	3242
Picture - Picture Adjust - SUPER RESOLUTION+ - Low	3243
Picture - Picture Adjust - SUPER RESOLUTION+ - Off	3244
Picture - Picture Adjust - Black Level	3 2 5
Picture - Picture Adjust - Black Level - High	3 2 5 1
Picture - Picture Adjust - Black Level - Low	3252
Picture - Picture Adjust - DFC	326
Picture - Picture Adjust - DFC - On	3 2 6 1
Picture - Picture Adjust - DFC - Off	3262
Picture - Game Adjust	3 3
Picture - Game Adjust - Response Time	331
Picture - Game Adjust - Response Time - Faster	3311

Menu	Location
Picture - Game Adjust - Response Time - Fast	3312
Picture - Game Adjust - Response Time - Normal	3313
Picture - Game Adjust - Response Time - Off	3 3 1 4
Picture - Game Adjust - FreeSync	332
Picture - Game Adjust - FreeSync - On	3321
Picture - Game Adjust - FreeSync - Off	3322
Picture - Game Adjust - Black Stabilizer	333
Picture - Game Adjust - Black Stabilizer	3 3 3 1 Slider
Picture - Color Adjust	3 4
Picture - Color Adjust - Gamma	3 4 1
Picture - Color Adjust - Gamma - Mode 1	3 4 1 1
Picture - Color Adjust - Gamma - Mode 2	3412
Picture - Color Adjust - Gamma - Mode 3	3413
Picture - Color Adjust - Gamma - Mode 4	3414
Picture - Color Adjust - Color Temp	3 4 2

Menu	Location
Picture - Color Adjust - Color Temp - Custom	3421
Picture - Color Adjust - Color Temp - Warm	3422
Picture - Color Adjust - Color Temp - Medium	3423
Picture - Color Adjust - Color Temp - Cool	3 4 2 4
Picture - Color Adjust - Red	3 4 3
Picture - Color Adjust - Red	3 4 3 1 Slider
Picture - Color Adjust - Green	3 4 4
Picture - Color Adjust - Green	3 4 4 1 Slider
Picture - Color Adjust - Blue	3 4 5
Picture - Color Adjust - Blue	3 4 5 1 Slider
Picture - Color Adjust - Six Color	3 4 6
Picture - Color Adjust - Six Color - Red Hue	3 4 6 1
Picture - Color Adjust - Six Color - Red Hue	3 4 6 1 1 Slider
Picture - Color Adjust - Six Color - Red Saturation	3 4 6 2

Menu	Location
Picture - Color Adjust - Six Color - Red Saturation	3 4 6 2 1 Slider
Picture - Color Adjust - Six Color - Green Hue	3463
Picture - Color Adjust - Six Color - Green Hue	3 4 6 3 1 Slider
Picture - Color Adjust - Six Color - Green Saturation	3464
Picture - Color Adjust - Six Color - Green Saturation	3 4 6 4 1 Slider
Picture - Color Adjust - Six Color - Blue Hue	3465
Picture - Color Adjust - Six Color - Blue Hue	3 4 6 5 1 Slider
Picture - Color Adjust - Six Color - Blue Saturation	3466
Picture - Color Adjust - Six Color - Blue Saturation	3 4 6 6 1 Slider
Picture - Color Adjust - Six Color - Cyan Hue	3467
Picture - Color Adjust - Six Color - Cyan Hue	3 4 6 7 1 Slider
Picture - Color Adjust - Six Color - Cyan Saturation	3468

Menu	Location		
Picture - Color Adjust - Six Color - Cyan Saturation	3 4 6 8 1 Slider		
Picture - Color Adjust - Six Color - Magenta Hue	3469		
Picture - Color Adjust - Six Color - Magenta Hue	3 4 6 9 1 Slider		
Picture - Color Adjust - Six Color - Magenta Saturation	3 4 6 10		
Picture - Color Adjust - Six Color - Magenta Saturation	3 4 6 10 1 Slider		
Picture - Color Adjust - Six Color - Yellow Hue	3 4 6 11		
Picture - Color Adjust - Six Color - Yellow Hue	3 4 6 11 1 Slider		
Picture - Color Adjust - Six Color - Yellow Saturation	3 4 6 12		
Picture - Color Adjust - Six Color - Yellow Saturation	3 4 6 12 1 Slider		
Picture - Screen Off	3 5		
Picture - Screen Off - No	351		
Picture - Screen Off - Yes	352		
Picture - Picture Reset	3 6		
Picture - Picture Reset - No	3 6 1		
Picture - Picture Reset - Yes	362		

Menu	Location		
Sound	4		
Sound - Volume	4 1		
Sound - Volume	4 1 1 Slider		
Sound - Bluetooth Audio	4 2		
Sound - Bluetooth Audio - On	421		
Sound - Bluetooth Audio - Off	422		
General	5		
General - Language	5 1		
General - Language - English	511		
General - Language - German	512		
General - Language - French	513		
General - Language - Spanish	514		
General - Language - Italian	515		
General - Language - Swdish	516		
General - Language - Finnish	517		
General - Language - Portuguese	518		
General - Language - Portuguese (Brazil)	519		
General - Language - Polish	5 1 10		
General - Language - Russian	5111		
General - Language - Greek	5 1 12		
General - Language - Ukrainian	5 1 13		

Menu	Location		
General - Language - Chinese	5 1 14		
General - Language - Traditional Chinese	5 1 15		
General - Language - Japanese	5 1 16		
General - Language - Korean	5 1 17		
General - Language - Hindi	5 1 18		
General - SMART ENERGY SAVING	5 2		
General - SMART ENERGY SAVING - High	5 2 1		
General - SMART ENERGY SAVING - Low	5 2 2		
General - SMART ENERGY SAVING - Off	5 2 3		
General - Power LED	5 3		
General - Power LED - On	5 3 1		
General - Power LED - Off	5 3 2		
General - Automatic Standby	5 4		
General - Automatic Standby - Off	5 4 1		
General - Automatic Standby - 4H	5 4 2		
General - Automatic Standby - 6H	5 4 3		
General - Automatic Standby - 8H	5 4 4		
General - HDMI Compatiblity Mode	5 5		
General - HDMI Compatiblity Mode - On	5 5 1		
General - HDMI Compatiblity Mode - Off	5 5 2		

Menu	Location	
General - DisplayPort 1.2	5 6	
General - DisplayPort 1.2 - Enable	5 6 1	
General - DisplayPort 1.2 - Disable	562	
General - Buzzer	5 7	
General - Buzzer - On	5 7 1	
General - Buzzer - Off	572	
General - OSD Lock	58	
General - OSD Lock - On	5 8 1	
General - OSD Lock - Off	582	
General - Deep Sleep Mode	5 9	
General - Deep Sleep Mode - On	5 9 1	
General - Deep Sleep Mode - Off	5 9 2	
General - Information	5 10 1	
General - Reset	5 11	
General - Reset - No	5 11 1	
General - Reset - Yes	5 11 2	



Cunn	lior's [Declara	ntion	of Ca	nforn	nit
JUUU	nei s i	Jeciai	111011	טו עט	шош	mu

Trade Name LG

E-mail

Responsible Party LG Electronics USA, Inc.

Address 111 Sylvan Avenue, North Building,

Englewood Cliffs,NJ 07632 lg.environmental@lge.com

The model and serial number of the product are located on the back and on one side of the product.

Record them below in case you ever need service.

Model ______
Serial No. _____

To obtain the source code under GPL, LGPL, MPL, and other open source licenses, that is contained in this product, please visit http://opensource.lge.com.

In addition to the source code, all referred license terms, warranty disclaimers and copyright notices are available for download.

LG Electronics will also provide open source code to you on CD-ROM for a charge covering the cost of performing such distribution (such as the cost of media, shipping, and handling) upon email request to <code>opensource@lge.com</code>. This offer is valid for three (3) years from the date on which you purchased the product.