



Please read this manual carefully before operating your set and retain it for future reference.

MODEL OM4560

Safety Information



CAUTION

RISK OF ELECTRIC SHOCK DO NOT OPEN



CAUTION: TO REDUCE THE RISK OF ELECTRIC SHOCK DO NOT REMOVE COVER (OR BACK) NO USER-SERVICEABLE PARTS INSIDE REFER SERVICING TO OUALIFIED SERVICE PERSONNEL.



This lightning flash with arrowhead symbol within an equilateral triangle is intended to alert the user to the presence of uninsulated dangerous voltage within the product's enclosure that may be of sufficient magnitude to constitute a risk of electric shock to persons.



The exclamation point within an equilateral triangle is intended to alert the user to the presence of important operating and maintenance (servicing) instructions in the literature accompanying the product.

WARNING: TO PREVENT FIRE OR ELECTRIC SHOCK HAZARD, DO NOT EXPOSE THIS PRODUCT TO RAIN OR MOISTURE.

CAUTION: The apparatus should not be exposed to water (dripping or splashing) and no objects filled with liquids, such as vases, should be placed on the apparatus.

WARNING: Do not install this equipment in a confined space such as a book case or similar unit.

CAUTION: Do not use high voltage products around this product. (ex. Electrical swatter) This product may malfunction due to electrical shock

CLASS 1 LASER PRODUCT KLASSE 1 LASER PRODUKT LUOKAN 1 LASER LAITE KLASS 1 LASER APPARAT KLASS 1 CLASSE 1 PRODUIT LASER
KELAS 1 PRODUK LASER

CAUTION: This product employs a Laser System. To ensure proper use of this product, please read this owner's manual carefully and retain it for future reference. Shall the unit require maintenance, contact an authorized service center.

Use of controls, adjustments or the performance of procedures other than those specified herein may result in hazardous radiation exposure. To prevent direct exposure to laser beam, do not try to open the enclosure

CAUTION: Do not block any ventilation openings. Install in accordance with the manufacturer's instructions.

Slots and openings in the cabinet are provided for ventilation and to ensure reliable operation of the product and to protect it from over heating. The openings shall be never be blocked by placing the product on a bed, sofa, rug or other similar surface. This product should not be placed in a builtin installation such as a bookcase or rack unless proper ventilation is provided or the manufacturer's instruction has been adhered to

CAUTION concerning the Power Cord

Most appliances recommend they be placed upon a dedicated circuit;

That is, a single outlet circuit which powers only that appliance and has no additional outlets or branch circuits. Check the specification page of this owner's manual to be certain. Do not overload wall outlets. Overloaded wall outlets, loose or damaged wall outlets, extension cords, frayed power cords, or damaged or cracked wire insulation are dangerous. Any of these conditions could result in electric shock or fire. Periodically examine the cord of your appliance, and if its appearance indicates damage or deterioration, unplug it, discontinue use of the appliance, and have the cord replaced with an exact replacement part by an authorized service center. Protect the power cord from physical or mechanical abuse, such as being twisted, kinked, pinched, closed in a door, or walked upon. Pay particular attention to plugs, wall outlets, and the point where the cord exits the appliance

The Power Plug is the disconnecting device. In case of an emergency, the Power Plug must remain readily accessible.

This device is equipped with a portable battery or accumulator.

Safety way to remove the battery or the battery from the equipment: Remove the old battery or battery pack, follow the steps in reverse order than the assembly. To prevent contamination of the environment and bring on possible threat to human and animal health, the old battery or the battery put it in the appropriate container at designated collection points. Do not dispose of batteries or battery together with other waste. It is recommended that you use local, free reimbursement systems batteries and accumulators. The battery shall not be exposed to excessive heat such as sunshine, fire or the like

CAUTION: No naked flame sources, such as lighted candles, should be placed on the apparatus.

POWER: This unit operates on a mains supply of 200-240V~, 50/60Hz.

Wiring: This unit is supplied with a BS 1363 approved main plug. When replacing the fuse, always use of the same rating approved to BS 1362. Never use this plug with the fuse cover omitted. To obtain a replacement fuse cover contact your dealer. If the type of plug supplied is not suitable for the mains sockets in your home, then the plug should be removed and a suitable type fitted. Please refer to the wiring instructions below:

Warning: A mains plug removed from the mains lead of this unit must be destroyed. A mains plug with bared wires is hazardous if inserted in a mains socket. Do not connect either wire to the earth pin, marked with the letter E or with the earth symbol $\stackrel{\bot}{=}$ or coloured green or green and yellow. If any other plug is fitted, use same rating of fuse in the plug.

Important: The wires in this mains lead are coloured in accordance with the following codes:

- BLUE: NEUTRAL, BROWN: LIVE - As the colours of the wires in the mains lead of this unit may not correspond with the coloured marking identifying the terminals in your plug, proceed as follows: The wire which is coloured blue must be connected to the terminal which is marked with the letter N or coloured black. The wire which is coloured brown must be connected to the terminal which is marked with the letter L or coloured red.

Table of Contents

1 Getting Started

- 2 Safety Information
- 6 Unique Features
- 6 Accessories
- 7 Playable file Requirement
- 7 Music file requirement
- 7 Compatible USB Devices
- 7 USB device requirement
- 8 Remote control
- 10 Front panel
- 11 Rear panel

2 Connecting

- 12 Optional Equipment Connection
- 12 AUX IN Connection
- 12 AUX OUT Connection
- 13 USB Connection
- 13 Antenna Connection

3 Operating

- 14 Basic Operations
- 14 CD/USB Operations
- 14 Auto Play
- 15 Selecting a folder and an MP3/WMA file
- 15 Deleting an MP3/WMA file
- 16 Playback Effect
- 16 AUTO DJ
- 16 Using BLUETOOTH® wireless technology
- 17 Listening to music stored on the BLUETOOTH devices
- 18 Using the Music Flow Bluetooth App
- 18 Install "Music Flow Bluetooth" App onto
 Your Bluetooth Device
- 19 Activate Bluetooth with "Music Flow Bluetooth" App
- 20 Radio Operations
- 20 Listening to the radio
- 20 Presetting the Radio Stations
- 20 Deleting all the saved stations
- 21 Sound adjustment
- 21 Setting the sound mode
- 22 Advanced Operations
- 22 Recording to USB
- 24 Programmed Playback

- 25 Other Operations
- 25 Turn off the sound temporarily
- 25 Displaying file information (ID3 TAG)
- 25 DEMO
- 25 Using Microphone
- 25 VOCAL CANCELLER
- 26 KEY CHANGER
- 26 LIGHTING
- 26 Setting the Clock
- 26 Setting the Clock through "Music Flow Bluetooth" App
- 27 Using your player as an alarm clock
- 27 Sleep Timer Setting
- 27 Dimmer
- 28 AUTO POWER On
- 29 Auto function change
- 29 LG Sound Sync
- 30 WIRELESS PARTY LINK Connection

4 Troubleshooting

32 Troubleshooting

5 Appendix

- 33 Maintenance
- 33 Notes on Discs
- 33 Handling the Unit
- 34 General specifications
- 35 Trademarks and Licenses

Unique Features

BLUETOOTH®

Listens to music stored on your ${\bf Bluetooth}$ device.

AUTO DJ

Blends the end of one song into the beginning of another for seamless playback.

USB Direct Recording

Records music to your USB device.

Music Flow Bluetooth


Music Flow Bluetooth is an App designed to let you take control of some of LG's latest Audio devices. Refer to page 18.


LG Sound Sync

Controls volume level of this unit by the remote control of your LG TV that is compatible with LG Sound Sync.

Accessories

Please check and identify the supplied accessories.





Remote Control (1)

Batteries (2)



FM Antenna (1)

Playable file Requirement

Music file requirement

MP3/WMA file compatibility with this unit is limited as follows.

- Sampling frequency: within 32 to 48 kHz (MP3), within 32 to 48 kHz (WMA)
- Bit rate: within 32 to 320 kbps (MP3), 40 to 192 kbps (WMA)
- Maximum files: Data CD: 999 / USB: 2000
- Maximum folders: Data CD: 99 / USB: 200
- File extensions : ".mp3"/ ".wma"
- Certain MP3/WMA files may not be played depending on the type or format of the file.
- CD-ROM file format: ISO 9660/ JOLIET
- We recommend that you use Easy-CD Creator, which creates an ISO 9660 file system.

The DTS is not supported. In case of DTS audio format, audio is not output.

You have to set the disc format option to [Mastered] in order to make the discs compatible with the LG players when formatting rewritable discs. When setting the option to Live File System, you cannot use it on LG players.

(Mastered/Live File System : Disc format system for Windows Vista)


Compatible USB Devices

- MP3 Player: Flash type MP3 player.
- USB Flash Drive : Devices that support USB2.0 or USB1.1.
- The USB function of this unit does not support all USB devices.

USB device requirement

- Devices which require additional program installation when you have connected it to a computer, are not supported.
- · Do not extract the USB device while in operation.
- For a large capacity USB, it may take longer than a few minute to be searched.
- To prevent data loss, back up all data.
- If you use a USB extension cable or USB hub, the USB device is not recognized.
- Using NTFS file system is not supported. (Only FAT(16/32) file system is supported.)
- · This unit recognizes up to 2000 files.
- External HDD, Card readers, Locked devices, or hard type USB devices are not supported.
- USB port of the unit cannot be connected to PC.
 The unit cannot be used as a storage device.
- Some USB may not work with this unit.

Remote control



Replacement of battery



Remove the battery cover on the rear of the Remote Control, and insert two (size AAA) batteries with \bigoplus and \bigoplus matched correctly.

(Power): Switches the unit ON or OFF.

♠ (Open/Close): Opens and closes the disc tray.

VOL +/-: Adjusts speaker volume.

F (Function): Selects the function and input source.

PRESET FOLDER A/V:

- Searches for a folder of MP3/WMA files. When a CD/USB containing MP3/WMA files in several folders is being played, press
 - **PRESET.FOLDER** Λ/V to select the folder you want to play.
- Chooses a preset number for a radio station.

PROGRAM/MEMORY:

- Stores radio stations.
- Deletes all the saved stations.
- Creates a programmed list you want to listen to.

AUTO DJ: Selects the AUTO DJ mode. (For more information refer to page 16)

DELETE:

- Deletes MP3/WMA files. (USB only).
- Deletes a song on the programmed list.

REPEAT : Listens to your tracks/files repeatedly or randomly.

TUNING-/+: Selects the radio stations.

Idd/▶►I (Skip/Search):

- Skips Fast backward or Forward.
- Searches for a section within a track/file.

►/II (Play/Pause):

- Starts or pauses playback.

■ (Stop):

- Stops playback or recording.
- Cancels DELETE function.

SOUND EFFECT: Chooses sound impressions.

REGION EQ: Chooses region equalizer.

INFO

- Sees informations about your music. An MP3 file often come with ID3 tag. The tag gives the Title, Artist, Album or Time information.
- Sees the name of connected all Bluetooth device in Bluetooth mode.
- In status of WIRELESS PARTY LINK Connection, device name of SLAVE unit appears in the MASTER unit and Device name of MASTER unit appears in the SLAVE unit.

0 to 9 numerical buttons : Selects numbered tracks, files, or preset number.

CLOCK: Sets a clock and checks a time.

ALARM : With the ALARM function you can turn CD, USB play and Tuner reception on at a desired time.

VOICE CANCELLER: You can enjoy the function while playing the music, by reducing singer vocal of music in the various source.

SLEEP: Sets the system to turn off automatically at a specified time.


(Dimmer : The display window will be darkened by half)

SET: Confirms the setting.

KEY CHANGER (#/ b): Changes the key to suit your vocal range.

USB REC: USB direct recording. ★: This button is not available.

Front panel



- (b/| (Power): Switches the unit ON or OFF.

 MIC +/-: Adjusts Microphone volume.
- 2 F / WIRELESS LINK:
 - Selects the function and input source.
 - Press and hold for 3 seconds to select WIRELESS PARTY LINK mode.

REGION EQ / BASS BLAST

- Chooses sound impressions.
- Press and hold for 3 seconds to select BASS (BASS BLAST) effect directly.

VOICE CANCELLER

You can enjoy the function while playing the music, by reducing singer vocal of music in the various source.

USB REC / DEMO

- Records to USB.
- Shows Demo mode
- 3 MIC 1 : Connect a microphone.
- 4 Display window
- **5** △: Opens and closes the disc tray.

6 USB Port : You can play or record sound files by connecting the USB device.

7 (</>>

- Skips Fast backward or Forward.
- Searches for a section within a track/ file.
- : Stops playback or cancels DELETE function.


>/||

- Starts or pauses playback.
- 8 VOL +/-: Adjusts speaker volume.

LIGHTING / PARTY LINK

- Turns on/off the lighting effects.
- Press and hold for 3 seconds to select PARTY LINK mode.

Rear panel



- 1 Power cord
- 2 ANTENNA (FM)


3 AUX IN (L/R) AUX OUT (L/R)

Optional Equipment Connection

AUX IN Connection

Connect an output of auxiliary device (Camcorder, TV, Player, etc.) to the **AUX IN** (L/R) connector.


If your device has only one output for audio (mono), connect it to the left audio jack on the unit.



AUX OUT Connection

Connect an input of auxiliary device to the **AUX OUT** (L/R) connector.

If your device has only one input for audio(mono), connect it to the left audio jack on the unit.



PARTY LINK

You can connect two units to play music together. The name of function about sound expansion between the compatible products wired or wirelessly was changed to PARTY LINK or WIRELESS PARTY LINK

- Connect AUX OUT connector on a unit to the AUX IN connector on the other unit using Audio cable.
- Press and hold LIGHTING / PARTY LINK on the unit for 3 seconds connected through AUX OUT and then select LINK ON.
 - "LINK ON" appears in the display window and change to "DELAY time" soon.
- Press I≪/≫I to adjust Delay setting.
 When "LINK ON" and "DELAY time" are displayed in the display window, you can adjust the delay time.
- 4. Press **LIGHTING / PARTY LINK** to save the Delay setting.

2




Note -

- This function is available on CD, USB or BT (Bluetooth) Function.
- The initial Delay is 30 ms. If you want to change the Delay time, press I≪/≫I.
 The connected device's Delay may differ. If Audio Sync is not matched, adjust Delay of PARTY LINK to synchronize sound.
- It is available to adjust the Delay from 0 ms to 200 ms. Synchronizing tempo is not available depending on devices.
- Delay value is saved and PARTY LINK is turned off when the unit turns off.
- You can select LINK ON/LINK OFF mode by pressing and holding LIGHTING / PARTY LINK for 3 seconds on the unit.
- VOICE CANCELLER setting is not synchronized with MASTER unit.

USB Connection

Connect a USB device (or MP3 player, etc.) to the USB ports on the unit.



•

Note -


Removing the USB device from the unit:

- Choose a different function/mode or press ■ on the remote control or □ on the unit twice in a row.
- 2. Remove the USB device from the unit.

Antenna Connection

Connect the supplied FM antenna for listening to the radio.

Connect the FM wire antenna to the FM antenna connector.





Note

Be sure to fully extend the FM wire antenna.

Basic Operations

CD/USB Operations

- Insert the disc by pressing on the remote control or on the unit Or connect the USB device to the USB port.
- 2. Select CD or USB function by pressing **F / WIRELESS LINK**.

| То | Do this |
|---|---|
| Stop | Press ■ on the remote control or ☐ on the unit. |
| Playback | Press ►/II on the remote control or >/II on the unit. |
| Pause | Press ►/II on the remote control or >/II on the unit during playback. |
| Searching for a section within a track/ file | Press ◄◄/▶►I on the remote control or I≪/≫I on the unit during playback and release it at the point you want to listen to. |
| Selecting a track/file directly | Press 0 to 9 numerical buttons on the remote control to go to the desired file or track directly. |
| Skipping to the next/ previous track/file | - In stop status, Press I ✓ / ▶ I on the remote control or I ✓ / ≫ I on the unit to go to the next/previous track/file. - During Playback, Press ▶ I on the remote control or ≫ I on the unit to go to the next track/file. Playing less than 2 seconds, press I ✓ on the remote control or I ✓ on the unit to go to the previous track/file. |
| | Playing after 3 seconds, press I◀◀ on the remote control or I≪ on the unit to go to the beginning of the track/file. |
| Playing repeatedly or randomly | Press REPEAT on the remote control repeatedly. Refer to the note for details about the display change. |



Note

• The display changes in the following order.

| MP3/WMA CD | AUDIO CD |
|------------|---------------------------------------|
| RPT 1 | RPT 1 |
| RPT DIR | - |
| RPT ALL | RPT ALL |
| RANDOM | RANDOM |
| OFF | OFF |
| | RPT 1 RPT DIR RPT ALL RANDOM |

*DIR: Directory


- When you play the programmed list, only RPT 1 and RPT ALL are available.
- Even after restarting the unit or switching one function to another, you can listen to music from the point where it's last been played.
- If you leave the disc tray open for 5 minutes, it will close automatically.

Auto Play

- AUDIO/MP3/WMA CD is played automatically after Disc tray is open and then closed.
- Automatically switches to the CD function if Disc tray is open and then closed when there is no disc in Disc tray.

Selecting a folder and an MP3/WMA file

- 1. Press PRESET.FOLDER ∧/V on the remote control repeatedly until a desired folder appears.
- 2. Press ▶/II to play it. The first file of folder will play.



• If there is no file in a folder, the folder will not

FILE 12

♪ FILE 13

♪ FILE 14

• Folders will be presented as the following

OLDER 5

OLDER 6

- INFILE 1

FILE 2

ROOT → FOLDER 1 → FOLDER 3 → FOLDER 7 → FOLDER 8 → FOLDER 5 → FOLDER 6

- File will be played from ♪ file No.1 to ♪ file No.14 one by one.
- Files and folders will be presented in order recorded and may be presented differently according to the record circumstances.
- *ROOT: The first screen you can see when a computer recognize the USB is "ROOT".

Deleting an MP3/WMA file

You can delete file, folder or format by pressing **DELETE**. This function is supported only in stop status. (USB only)

- 1. -Select the file you want to delete and press DELETE.
 - -Select the folder you want to delete by pressing **PRESET.FOLDER** Λ/V on the remote control and press DELETE.
 - -Press and hold **DELETE** to format the USB device.

Or

Press **DELETE** repeatedly during selecting the MP3/WMA file.

The display changes in the following order.

- DEL FILE: Deletes file
- DEL DIR: Deletes folder
- FORMAT: Formats USB
- 2. To delete file/folder or format, press ►/II on the remote control or press >/|| on the unit. If you want to exit the current mode, press
 - on the remote control or press □ on the unit.



Caution

- · Do not extract the USB device during operation. (play, delete, etc.)
- · Regular back up is recommended to prevent data loss.
- The delete function may not be supported according to the USB status. (lock, etc.)

Playback Effect

AUTO DJ

Auto DJ blends the end of one song into the beginning of another for seamless playback. It equalizes volume across tracks/files for uninterrupted playback.

Press AUTO DJ on the remote control repeatedly, the display changes as followings. AUTO DJ RANDOM -> AUTO DJ SEQUENTIAL -> AUTO DJ OFF

| Mode | Display Window | Description |
|--------|-----------------------|--|
| OFF | AUTO DJ OFF | - |
| RANDOM | AUTO DJ RANDOM | The music is played randomly on this mode. |
| REPEAT | AUTO DJ SEQUENTIAL | The music is played repeatedly on this mode. |

Note

- AUTO DJ mode does not support searching for a section within a track/file or to play repeatedly or randomly.
- If you move to other functions or stop the music using
 □ on the unit (or
 ■ on the remote control) on AUTO DJ mode, AUTO DJ will be disable.
- AUTO DJ is not supported in the music file whose length is less than 60 seconds.
- · During recording, AUTO DJ is not available.
- Only AUTO DJ SEQUENTIAL is selected when played the programmed list.

Using BLUETOOTH® wireless technology

About BLUETOOTH

Bluetooth is wireless communication technology for short range connection.

The sound may be interrupted when the connection interfered by the other electronic wave or you connect the bluetooth in the other rooms.

Connecting individual devices under **Bluetooth** wireless technology does not incur any charges. A mobile phone with **Bluetooth** wireless technology can be operated via the Cascade if the connection was made via **Bluetooth** wireless technology. Available Devices: Mobile phone, MP3, Laptop, PDA.

BLUETOOTH Profiles

In order to use **Bluetooth** wireless technology, devices must be able to interpret certain profiles. This unit is compatible with following profile.

A2DP (Advanced Audio Distribution Profile)

Codec: SBC

Listening to music stored on the **BLUETOOTH** devices

Pairing your unit and Bluetooth device

Before you start the pairing procedure, make sure the Bluetooth feature is activated on your Bluetooth device. Refer to your Bluetooth device's user guide. Once a pairing operation is performed, it does not need to be performed again.

- 1. Select the Bluetooth function by using F / WIRELESS LINK on the unit until BT function is selected
 - "BT READY" appears on the display window.
- 2. Operate the **Bluetooth** device and perform the pairing operation. When searching for this unit with the Bluetooth device, a list of the devices found may appear in the **Bluetooth** device display depending on the type of Bluetooth device. Your unit appears as "LG OM4560(XX)".



Note

- · XX means the last two digits of Bluetooth address. For example, if your unit has a Bluetooth address such as 9C:02:98:4A:F7:08, you will see "LG OM4560(08)" on your Bluetooth device.
- · Depending on the Bluetooth device type, some devices may have a different pairing process. Enter the PIN code (0000) as needed.
- You can connect this unit with up to 3 Bluetooth devices simultaneously using the same method as described above, only in the Bluetooth function.
- · The multi pairing connection is only supported on Android or iOS devices. (Multi pairing connection may not be supported depending on the connected device specifications.)
- Removable/detachable Bluetooth devices (Ex: Dongle etc.) will not support multi pairing.
- You can connect only one Bluetooth device in the MASTER unit. You cannot connect Bluetooth device to the SLAVE unit.

3. When this unit is successfully connected with your Bluetooth device, "PAIRED" will be appear on the display window and change to **Bluetooth** device name soon. Then "BT" will be appear on the display window.



Note

- "PAIRED" will momentarily appear on the display when you connect other devices for multi pairing.
- If the device name is unavailable, "_" will be displayed.
- 4. Listen to music.

To play a music stored on your Bluetooth device, refer to your Bluetooth device's user guide.



Note

 When using Bluetooth® technology, you have to make a connection between the unit and the bluetooth device as close as possible and keep the distance.

However, it may not work well in certain situations as described below:

- There is a obstacle between the unit and the bluetooth device.
- There is a device using same frequency with Bluetooth® technology such as a medical equipment, a microwave or a wireless LAN device.
- You should connect your bluetooth device to this unit again when you restart it.
- Even if this unit connected up to 3 Bluetooth devices in the Bluetooth mode, you can play and control music by using only one of the connected devices.



Note

- When this unit connected with multiple Bluetooth devices, only one device which you are playing keeps Bluetooth connection when you change the function to the others.
- The sound may be interrupted when the connection has interference from other electronic devices.
- You may not control the Bluetooth device with this unit.
- Depending on the type of the device, you may not be able to use the Bluetooth function.
- You can enjoy wireless system using phone, MP3, Notebook, etc.
- The more distance between the unit and the bluetooth device, the lower the sound quality becomes.
- Bluetooth connection will be disconnected when the unit is turned off or the Bluetooth device gets far from the unit.
- When Bluetooth connection is disconnected, connect the bluetooth device to the unit again.
- When a Bluetooth device is not connected, "BT READY" appears on the display window.
- When you use the BT function, adjust the volume to a proper level on the Bluetooth device.
- If it is not in the BT function, only one device can be connected.
- If a Bluetooth device is connected when using LG TV, LG TV is disconnected and the Bluetooth device is connected.
- When you connect Bluetooth device (iOS device etc.) to this unit or operate the device, the volume level can be synchronized with each other.

Using the Music Flow Bluetooth App



Note -

- Only Android OS is available to use "Music Flow Bluetooth" app with this unit.
- It is recommended to use the latest version of app.

About "Music Flow Bluetooth" App

"Music Flow Bluetooth" app brings a suite of new features to this unit.

To enjoy more features, you are recommended to download and install free "Music Flow Bluetooth" app.

Install "Music Flow Bluetooth" App onto Your Bluetooth Device

There are two ways to install "Music Flow Bluetooth" App onto Your **Bluetooth** Device.

Install "Music Flow Bluetooth" App through QR code

 Install "Music Flow Bluetooth" app through QR code. Use the scanning software to scan the QR code.



- 2. Tap an icon for installation.
- 3. Tap an icon for downloading.



Note -

- Make sure that your Bluetooth device is connected to the Internet.
- Make sure that your Bluetooth device has a scanning software application. If you don't have one, download one from "Google Android Market (Google Play Store)".
- Depending on the area, QR code may not work.

Install "Music Flow Bluetooth" App through "Google Android Market (Google Play Store)"

- Tap the "Google Android Market (Google Play Store)" icon.
- 2. In the search bar, type in the "Music Flow Bluetooth" and search it.
- 3. In the search result list, find and tap "Music Flow Bluetooth" to start downloading Bluetooth app.
- 4. Tap an icon for installation.
- 5. Tap an icon for downloading.



Note

- Make sure that your Bluetooth device is connected to the Internet.
- Make sure that your Bluetooth device is equipped with "Google Android Market (Google Play Store)".

Activate Bluetooth with "Music Flow Bluetooth" App

"Music Flow Bluetooth" app helps to connect your **Bluetooth** device to this unit.

- Tap "Music Flow Bluetooth" app icon on the home screen to open "Music Flow Bluetooth" app, and go to the main menu.
- 2. Tap [Menu] and select the unit you want.
- 3. If you want to get more information to operate, tap [Help] on the [Setting] menu.



Note

- "Music Flow Bluetooth" app will be available in the software version as follow;
 - Android O/S: Ver 4.0.3 (or later)
- If you use "Music Flow Bluetooth" app for operation, there would be some differences between "Music Flow Bluetooth" app and the supplied remote control. Use the supplied remote control as necessary.
- Depending on the Bluetooth device, "Music Flow Bluetooth" app may not work.
- After connection of "Music Flow Bluetooth" app, music may be output from your device. In this case, try connecting procedure again.
- If you operate the other applications or change the settings on your Bluetooth device while using "Music Flow Bluetooth" app, "Music Flow Bluetooth" app may operate abnormally.
- When "Music Flow Bluetooth " app operates abnormally, check your Bluetooth device and the connection of "Music Flow Bluetooth" app and then try to connect again.
- Depending on the smart phone's operating system, you have some differences for "Music Flow Bluetooth" operation.
- Check Bluetooth setting on your Bluetooth device if "Music Flow Bluetooth" app connection does not work well.

Radio Operations

Be sure that FM antenna is connected. (Refer to page 13)

Listening to the radio

- Press F / WIRELESS LINK repeatedly until FM appears in the display window.
 The last received station is tuned in.
- Auto tuning:
 Press and hold TUNING-/+ on the remote control or I≪/≫I on the unit for about two seconds until the frequency indication starts to change, then release. Scanning stops when the unit tunes

Or

Manual tuning:

in a station.

Press **TUNING-/+** on the remote control or **| \(/ >> |** on the unit repeatedly.

Adjust the volume by pressing VOL +/- on the unit or remote control repeatedly.

Presetting the Radio Stations

You can preset 50 stations for FM.

Before tuning, make sure to turn down the volume.

- Press F / WIRELESS LINK until FM appears in the display window.
- Select the desired frequency by pressing TUNING -/+ on the remote control or
 | <
 | > | on the unit.
- Press PROGRAM/MEMORY on the remote control. A preset number will blink in the display window.
- Press PRESET.FOLDER ∧/V on the remote control to select the preset number you want.
- Press PROGRAM/MEMORY on the remote control. The station is stored.
- 6. Repeat steps 2 to 5 to store other stations.
- To listen a preset station, press
 PRESET.FOLDER \(\Lambda/\text{V}\) or 0 to 9 numerical buttons on the remote control.

Deleting all the saved stations

- Press and hold PROGRAM/MEMORY on the remote control for two seconds. "ERASEALL" will flash up on the unit display.
- Press PROGRAM/MEMORY on the remote control to erase all the saved radio stations.

Sound adjustment

Setting the sound mode

This system has a number of pre-set surround sound fields. The displayed items for the Equalizer may be different depending on sound sources and effects.

You can select a desired sound mode by using **SOUND EFFECT** on the remote control.

| On Display | Description |
|--------------------------------|---|
| POP CLASSIC JAZZ ROCK | This program lends an enthusiastic atmosphere to the sound, giving you the feeling you are at an actual rock, pop, jazz or classic concert. |
| BASS (BASS BLAST) | Reinforces the treble, bass and surround sound effect. |
| FOOT BALL | You can enjoy the sound effect FOOTBALL STADIUM. |
| STANDARD | You can enjoy optimized sound. |

You can select a desired sound mode by using **REGION EQ** on the remote control.

| On Display | Region | Description |
|--|------------------|--------------------------|
| FUNK, REGUETON, SAMBA, BANDA, MERENGUE, AXE, SALSA, SERTANEJ, CUMBIA, TECNO BR, FORRO | Latin America | Optimized sound effect |
| ARABIC | Middle East | for the music genre |
| DONGDUT | Indonesia | prefered in each region. |
| AFRO | Africa | |
| INDIA | India | |



Note

By pressing and holding REGION EQ / BASS BLAST for 3 seconds on the unit you can directly select BASS (BASS BLAST) effect.

Advanced Operations

Recording to USB

You can record a various sound source to USB. (CD, AUX, Tuner)

- 1. Connect the USB device to the unit.
- 2. Press F / WIRELESS LINK to select a function you want to record.

One track/file recording - You can record to USB after playing a track/file you want. All tracks/files recording - You can record to USB in full stop status. Programmed list recording - After showing the Programmed list, you can record it to USB.

- 3. Start the recording by pressing USB REC/DEMO.
- 4. To stop recording, press \(\bar{\pi} \) on the unit or on the remote control.

Pausing recording

(Refer to page 24)

During recording, press > ■ on the unit or ►/■ on the remote control to pause recording. Press it again to restart recording. (Tuner/AUX only)



Note

- · You can control recorded MIC sound according to MIC volume when you record in AUDIO CD X1 speed REC.
- VOICE CANCELLER or KEY CHANGER will be reset, if you use recording function during operating VOICE CANCELLER or KEY CHANGER
- VOICE CANCELLER or KEY CHANGER can not be operated during recording.

To select recording bit rate and speed

- 1. Press and hold **USB REC/DEMO** for 3 seconds.
- 2. Press ► on the remote control or **|**</>> on the unit to select a bit rate.
- 3 Press USB REC/DEMO to set
- 4. Press ◄◄/▶▶ on the remote control or || on the unit to select a desired recording speed. (AUDIO CD only)

X1 SPFFD

- You can listen to music while recording it.

X2 SPEED

- You can just record the music file.
- 5. Press **USB REC/DEMO** to finish the setting.

The making of unauthorized copies of copyprotected material, including computer programs, files, broadcasts and sound recordings, may be an infringement of copyrights and constitute a criminal offense. This equipment should not be used for such purposes.

> Be responsible Respect copyrights

•

Note

- You can check the recording percentage rate for the USB record on the display window during the recording. (MP3/WMA, CD Only)
- During recording MP3/WMA, there is no sound.
- For stable recording, the output sound level goes down on its own when you record music from CD to USB.
- When you stop recording during playback, the file that has been recorded at that time will be stored. (Except MP3/WMA files)
- Do not remove the USB device or turn off the unit during USB recording. If does not, an incomplete file may be made and not deleted on PC.
- If USB recording does not work, the message like "NO USB", "ERROR", "USB FULL", "NOT SUPPORT" or "FILE MAX" is displayed on the display window.
- Multi card reader device or External HDD can not be used for USB recording.
- A file is recorded by about 512 Mbyte when you record for a long term.

1

Note -

- You can control recorded MIC sound according to MIC volume.
- You may not store more than 2000 files.
- You can not record in AUTO DJ mode.
- On CD function, sound of MIC is recorded only during AUDIO CD X1 speed REC. It is recorded AUDIO CD source too.
- In case of the unsupported MP3/WMA file, the file recording may be stopped.
- · It'll be stored as follows.

| AUDIO CD | MP3/WMA |
|--|--------------------------------|
| CD_REC - TRACK_0001 - TRACK_0002 | ABC(File name) DEF(File name) |
| AUX | Tuner |
| OTHERS_REC - AUDIO_0001 - AUDIO_0002 | TUNER_REC - AUDIO_0001_107-7FM |

Tuner: The current recording frequency is shown.

Programmed Playback

The program function enables you to store your favorite files from any disc or USB device.

A program can contain 20 tracks/files for each media. (CD, USB) Possible to save a total of 40 tracks/files.

Making Programmed list

It is supported only on stop status.

- 1. Press PROGRAM/MEMORY on the remote control.
- 2. Press ► on the remote control to select a track/file.
- 3. Press PROGRAM/MEMORY on the remote control to save and select a next track/file.
- 4. Repeat steps 2 3 to store other tracks/files. (You can modify the list by pressing **PRESET.FOLDER** Λ/V on the remote control to select the program number.)
- 5. Press PROGRAM/MEMORY on the remote control once again.

To play the programmed list, press ►/ II after you make the list.



Note

When making or modifying the programmed list, REPEAT mode is off.

Deleting Programmed list

Deleting function only works in the edit mode.

- 1. Press PROGRAM/MEMORY on the remote control in stop status.
- 2. Select a song by pressing **PROGRAM/MEMORY** or PRESET.FOLDER Λ/V on the remote control repeatedly.
- Press DELETE while a song is selected.



Note

- · Program is switched off in the case below.
 - Changing to a different function.
 - Turning off and on the unit.
 - Operating the numeric buttons on the remote control.
- · Programmed list is cleared in the case below.
- Removing the disc or the USB device.
- Deleting or recording music files in the USB device.
- Unplugging the Power Cord.

Other Operations

Turn off the sound temporarily

Press on the remote control to mute your sound.

You can mute your unit, for example, to answer the telephone, the "MUTE" will appear in the display window.

To cancel it, press **4** again or change the volume level.

Displaying file information (ID3 TAG)

While playing an MP3 file containing file information, you can display the information by pressing **INFO**.

DEMO

In the power off state, press **USB REC/DEMO** on the unit once. The unit will power on and display the each of functions in the display window. To cancel the DEMO function, press **USB REC/DEMO** once more.



Note

- While in DEMO, this unit will keep DEMO status even if you unplug the power cord connection.
- You can enjoy other functions during the DEMO, the DEMO will temporarily pause.
 - Without input key in 10 sec, the DEMO will play back automatically.

Using Microphone

- 1. Connect your microphone to the MIC jack.
- 2. Play the music you want.
- Sing along with the accompaniment. Adjust the microphone volume by pressing MIC +/- on the unit.



Note

- When not using the microphone, set the microphone volume to minimum by pressing MIC - or turn off the MIC and remove the microphone from the MIC jack.
- If the microphone is set too near the speaker, a howling sound may be produced. In this case, move the microphone away from the speaker or decrease the sound level by using the MIC -.
- If sound through the microphone is extremely loud, it may be distorted. In this case, set the microphone volume to minimum by pressing MIC -.

VOICE CANCELLER

You can enjoy the function while playing the music, by reducing singer vocal of music in the various source.

Press the **VOICE CANCELLER**, and "ON" will appear in display window.

To cancel it, press VOICE CANCELLER again.

The quality of the **VOICE CANCELLER** may be different depending on the recording conditions of music files.



Note

- This function is available CD, USB or BT (Bluetooth) Function.
- If the function is not available, "NOT SUPPORT" appears in the display window.
- This function is available to use only when a microphone is connected.
- If a microphone is not connected, "NOT SUPPORT" appears in the display window.
- To initialize it, change the Function or disconnect the microphone.
- It is not available on the MONO source.
- This function may not be initialized depending on the status of connected devices.

KEY CHANGER

You can adjust the key to 9 steps (4 steps higher, 4 steps lower and the original key).

- · To sharp the key one by one, press the KEY CHANGER(#) on the remote control repeatedly during playback.
- To flatten the key one by one, press the KEY CHANGER(b) on the remote control repeatedly during playback.



Note

- This function is available CD. USB or BT (Bluetooth) Function.
- · If a microphone is not connected, "NOT SUPPORT" appears in the display window.
- · To initialize it, change the Function, disconnect the microphone or change the music.
- This function may not be initialized depending on the status of connected devices.

LIGHTING

The function is to create a Club like atmosphere by operating speaker lighting.

 Press LIGHTING / PARTY LINK on the unit. The mode changes each time you press it: OFF \rightarrow SPARKLE \rightarrow VOLCANO \rightarrow POLICE \rightarrow THUNDER → PSYCHE → CAOS → OFF



Note

- · Lighting function is available in all functions.
- · Lighting mode retains its previous mode when you first press LIGHTING / PARTY LINK, press again to change modes.
- · Operation may be different depending on the played music, connected device or setting status.

Setting the Clock

- 1. Turn the unit on.
- Press and hold CLOCK.
- 3. Select time mode by pressing ► on the remote control.
 - AM 12:00 (for an AM and PM display) or 0:00 (for a 24 hour display)
- 4. Press SET to confirm your selection.
- 5. Select the hours by pressing ► on the remote control.
- Press SET.
- 7. Select the minutes by pressing ► on the remote control.
- 8 Press SFT

Setting the Clock through "Music Flow Bluetooth" App

Install "Music Flow Bluetooth" app on your Android device. (Refer to page 18)

Your unit's clock will be automatically synchronized with your device by activating Bluetooth connection through "Music Flow Bluetooth" app.

Using your player as an alarm clock

- 1. Turn the unit on.
- Press and hold ALARM.
- 3. Press ► on the remote control to change the hours and minutes and press SET. to
- 4. Press ◄◄/▶▶ on the remote control to select function and press SET to save.
 - Press ► on the remote control to select a memory No. when you select Tuner and then, press SET.

If there is no memory No., this step is skipped.

5. Press ► on the remote control to change the volume and press SET to save.



Note

- If you set the clock time, you can check the time by pressing CLOCK even when the player is turned off.
- You can set alarm after you set the clock
- If you set the clock time and alarm, you can check the setting information by pressing ALARM even when the unit is turned off.
- You can select ALARM ON/OFF mode by pressing ALARM.

Sleep Timer Setting

Press **SLEEP** repeatedly to select delay time between 10 and 180 minutes. After the delay time, the unit will be turned off.

To cancel the sleep function, press **SLEEP** repeatedly until "SLEEP 10" appears, and then press SLEEP once again while "SLEEP 10" is displayed.



Note

- · You can check the remaining time before the unit is turned off.
- Press **SLEEP**. The remaining time appears in the display window.

Dimmer

Press SLEEP once. The display window will be darkened by half. To cancel it, press SLEEP repeatedly until dim off.



Note

All the LED turns off when Dimmer is being operated.

AUTO POWER On

This unit automatically turns on by an input source: LG TV or **Bluetooth**

If you try to connect your **Bluetooth** device, this unit turns on and connects your **Bluetooth** device. You can play your music.



Note

- Depending on the connected device, this function may not operate.
- Depending on the connected device, the unit turns on but Bluetooth function may not be connected.
- If you disconnect Bluetooth connection by this unit, some Bluetooth devices try to connect to the unit continually. Therefore it is recommended to disconnect the connection before turning off the unit.
- If you try to connect to the "Music Flow Bluetooth" app, Bluetooth function of this unit is turned on.
- If you turn on the unit using LG TV or Bluetooth function, proper function of this unit is turned on.
- If you have already paired with this unit, automatically this unit can turn on by an input source when this unit is turned off.
- If you turn off the unit by pressing the power button for more than 5 seconds, Auto Power On function is disabled. To activate it, turn on the unit.

Auto function change

This unit recognizes input signals such as **Bluetooth** and LG TV and then changes suitable function automatically.

When you try to connect Bluetooth device

When you try to connect your **Bluetooth** device to this unit, Bluetooth function is selected. Play your music on the **Bluetooth** device.

When LG TV is connected

When you turn on your LG TV connected by LG Sound Sync, this unit changes the function to LG TV. You can hear the sound from your TV.



Note

- This function is not available during recording or deleting.
- This function only works with devices that were previously connected.

LG Sound Sync



You can control some functions of this unit by your TV's remote control with LG Sound Sync. It is compatible with LG TV that supports LG Sound Sync. Make sure your TV has the LG Sound Sync logo.

Controllable function by LG TV's remote control : Volume up/down, mute

Refer to the TV's instruction manual for the details of LG Sound Sync.

- 1. Turn on the unit by pressing ()/(Power).
- Press F / WIRELESS LINK until LG TV function is selected.
- 3. Set up the sound output of TV to listen to the sound through this unit:
 - TV setting menu [Sound] -> [TV Sound output] -> [LG Sound Sync (Wireless)]
 - "PAIRED" appears on the display window for about 3 seconds and then you can see "LG TV" on the display window if the TV and this unit are connected normally.

0

Note


- You can also use the remote control of this unit while using LG Sound Sync. If you use TV's remote control again, the unit synchronizes with the TV
- If the connection fails, check the conditions of this unit and your TV: power, function.
- Make sure of the condition of this unit and the connection in the cases below when using LG Sound Sync.
 - Turn off the unit.
 - Changing to a different function.
 - Disconnecting the wireless connection caused by interference or a distance.
- If you try to change the function on using the LG TV function, volume will be change according to the LG TV volume level.
- Details of TV setting menu vary depending on the manufacturers or models of your TV.
- If you connect LG Sound Sync when "Music Flow Bluetooth" app is connected, control through the app is available.
- If you turned off the unit directly by pressing \(\begin{align*} \left(| \text{Power} \), LG Sound Sync will be disconnected. To use this function again, you should reconnect the TV and the unit.
- If an LG TV is connected when using Bluetooth, Bluetooth is disconnected and the LG TV is connected.

WIRELESS PARTY LINK Connection

The output sound of **(A)** (MASTER) unit is expanded to **(B)** (SLAVE) unit.

It is compatible with unit that supports WIRELESS PARTY LINK.

The name of function about sound expansion between the compatible products wired or wirelessly was changed to PARTY LINK or WIRELESS PARTY LINK.



- Press and hold F / WIRELESS LINK on the unit for 3 seconds. PARTY LINK MODE SELECT appears in the display window.
- 2. Press **|≪/≫|** on the unit to select MASTER or SI AVF

- A unit: Selects MASTER.

- B unit: Selects SLAVE.

Two units try to connect with each other.

 When this unit is successfully connected each other, "Slave Device Name CONNECTED" appears in the MASTER unit. "CONNECTED TO Master Device Name" appears in the SLAVE unit and change to SLAVE soon.



Note

- If you using the LG Sound Sync, this function is not available. If you connect the LG TV Function, "NOT SUPPORT" appears in the display window.
- You can use microphone in the SLAVE unit only. In case of SLAVE unit, some functions are supported only.
- You can connect only one **Bluetooth** device in the MASTER unit. You cannot connect Bluetooth device to the SLAVE unit.
- When WIRELESS PARTY LINK is disconnected, SLAVE unit is changed to BT function.
- If the connection is failed, "FAILED" appears in the display window.
- Mute function is synchronized with each other.
- WIRELESS PARTY LINK connection will be disconnected when you turn off the unit or press and hold the F / WIRELESS LINK on the unit for 3 seconds.
- When WIRELESS PARTY LINK is connected, you can not connect the PARTY LINK.
- WIRELESS PARTY LINK connection is only supported on Android or iOS devices. (WIRELESS PARTY LINK connection may not be supported depending on the connected device specifications or OS.)
- Removable/detachable Bluetooth devices (ex. Dongle etc.) will not support WIRELESS PARTY LINK connection.
- When WIRELESS PARTY LINK is connected, Blutooth connection is not available in status of recording or deleting.

Troubleshooting

| Problem | Cause & Solution |
|---|--|
| The unit does not work properly. | Turn off the power of this unit and the connected external device (TV, Woofer, DVD-player, Amplifier, etc.) and turn it on again. Disconnect the power cord of this unit and the connected external device (TV, Woofer, DVD-player, Amplifier, etc.) and then try connecting again. Previous setting may not be saved when device power is shut off. |
| No Power. | The power cord is not plugged in. Plug in the power cord. Check whether electricity failed. Check the condition by operating other electronic devices. |
| No sound. | Check whether you select right function. Press F / WIRELESS LINK and check the selected function. |
| The unit does not start playback. | An unplayable disc is inserted. Check the playable disc. No disc is inserted. Insert a disc. The disc is dirty. Clean the disc. (Refer to page 33) The disc is inserted upside down. Place the disc with the label or printed side facing upwards. |
| Radio stations cannot be tuned in properly. | The antenna is positioned or connected poorly. Connect the antenna securely. The signal strength of the radio station is too weak. Tune to the station manually. No stations have been preset or preset stations have been cleared (when tuning by scanning preset channels). Preset some radio stations, see page 20 for details. |
| The remote control does not work properly. | The remote control is too far from the unit. Operate the remote control within about 7 m. There is an obstacle in the path of the remote control and the unit. Remove the obstacle. The batteries in the remote control are exhausted. Replace the batteries with new ones. |
| No speaker light | Check the speaker light effects by pressing LIGHTING / PARTY LINK. |
| LG Sound Sync does not work. | Check whether your LG TV supports LG Sound Sync. Check connection of LG Sound Sync. Check sound setting of your TV and this unit. |

Maintenance

Notes on Discs

Handling Discs

Never stick paper or tape on the disc.

Storing Discs

After playing, store the disc in its case. Do not expose the disc to direct sunlight or sources of heat and never leave it in a parked car exposed to direct sunlight.

Cleaning Discs

Fingerprints and dust on the disc can cause poor picture quality and sound distortion. Before playing, clean the disc with a clean cloth. Wipe the disc from the center to out.

Do not use strong solvents such as alcohol, benzine, thinner, commercially available cleaners, or anti-static spray intended for old vinyl records.

Handling the Unit

When shipping the unit

Please save the original shipping carton and packing materials. If you need to ship the unit, for maximum protection, re-pack the unit as it was originally packed at the factory.

Keeping the exterior surfaces clean

Do not use volatile liquids such as insecticide spray near the unit. Wiping with strong pressure may damage the surface. Do not leave rubber or plastic products in contact with the unit for a long period of time.

Cleaning the unit

To clean the player, use a soft, dry cloth. If the surfaces are extremely dirty, use a soft cloth lightly moistened with a mild detergent solution. Do not use strong solvents such as alcohol, benzine, or thinner, as these might damage the surface of the unit.

Maintaining the Unit

The unit is a high-tech, precision device. If the optical pick-up lens and disc drive parts are dirty or worn, the picture quality could be diminished. For details, please contact your nearest authorized service center.

General specifications

| General | |
|------------------------|---------------------------------------|
| Power requirements | Refer to the main label. |
| | Refer to the main label. |
| Power consumption | Networked standby : 0.5 W |
| | (If all network ports are activated.) |
| Dimensions (W x H x D) | Approx. 451.5 mm x 311 mm x 302.5 mm |
| Net Weight (Approx.) | Approx. 7.5 kg |
| Operating temperature | 5 °C to 35 °C |
| Operating humidity | 5 % to 90 % |

| Inputs / Outputs | |
|----------------------------|--|
| Analog audio in (AUX IN) | 2.0 Vrms (1 kHz, 0 dB), 600 Ω, RCA jack (L, R) |
| Analog audio out (AUX OUT) | 2.0 Vrms (1 kHz, 0 dB), 600 Ω, RCA jack (L, R) |
| Microphone | Sensitivity 15 mV (1 kHz), 6.3 mm jack x 1 |

| Tuner | |
|-----------------|--|
| FM Tuning Range | 87.5 to 108.0 MHz or 87.50 to 108.00 MHz |

| Amplifier (RMS Output power) | |
|------------------------------|---|
| Total | 220 W x 1 (3 Ω at 1 kHz, 25 % THD) |

| System | |
|------------------------|-------------------------|
| Frequency Response | 80 Hz to 20 kHz |
| Signal-to-noise ratio | More than 75 dB (1 kHz) |
| Dynamic range | More than 80 dB |
| Bus Power Supply (USB) | 5 V === 500 mA |

• Design and specifications are subject to change without notice.

Trademarks and Licenses

Bluetooth®

Bluetooth wireless technology is a system which allows radio contact between electronic devices.

Connecting individual devices under **Bluetooth** wireless technology does not incur any charges. A mobile phone with **Bluetooth** wireless technology can be operated via the Cascade if the connection was made via **Bluetooth** wireless technology.

The **Bluetooth®** word mark and logos are owned by the Bluetooth SIG, Inc. and any use of such marks by LG Electronics is under license.

Other trademarks and trade names are those of their respective owners.

