



# **PCS200S Pro:Centric® Server**

## **Installation & Setup Quick Reference | Warranty**

The latest product information and documentation is available online at:  
**[www.lg.com](http://www.lg.com)**





## **WARNING**

**RISK OF ELECTRIC SHOCK  
DO NOT OPEN**



### **WARNING:**

**TO REDUCE THE RISK OF ELECTRIC SHOCK DO NOT REMOVE COVER (OR BACK). NO USER-SERVICEABLE PARTS INSIDE. REFER TO QUALIFIED SERVICE PERSONNEL.**



The lightning flash with arrowhead symbol, within an equilateral triangle, is intended to alert the user to the presence of uninsulated "dangerous voltage" within the product's enclosure that may be of sufficient magnitude to constitute a risk of electric shock to persons.



The exclamation point within an equilateral triangle is intended to alert the user to the presence of important operating and maintenance (servicing) instructions in the literature accompanying the appliance.

## **Conformity Notice**



LG Electronics hereby declares that this product is in compliance with the following Directives.

EMC Directive 2004/108/EC  
LOW VOLTAGE Directive 2006/95/EC  
ErP Directive 2009/125/EC  
RoHS Directive 2011/65/EU

European representative:  
LG Electronics Inc. Krijgsman 1, 1186 DM  
Amstelveen, The Netherlands

## **WEEE**



### **Disposal of your old appliance**

1. When this crossed-out wheeled bin symbol is attached to a product it means the product is covered by the European Directive 2002/96/EC.
2. All electrical and electronic products should be disposed of separately from the municipal waste stream via designated collection facilities appointed by the government or the local authorities.
3. The correct disposal of your old appliance will help prevent potential negative consequences for the environment and human health.
4. For more detailed information about disposal of your old appliance, please contact your city office, waste disposal service or the shop where you purchased the product.

# IMPORTANT SAFETY INSTRUCTIONS

- Please read these safety precautions carefully before using the product.
- In this manual, the illustration may be somewhat different from your product because it is just example.
- Manufacturer and installer cannot provide service related to human safety as the applicable wireless device has possibility of electric wave interference.



## WARNING

If you ignore the warning message, you may be seriously injured or there is a possibility of accident or death.



## CAUTION

If you ignore the caution message, you may be slightly injured or the product may be damaged.

1. Read these instructions.
2. Keep these instructions.
3. Heed all warnings.
4. Follow all instructions.
5. Do not use this apparatus near water.
6. Clean only with dry cloth.
7. Do not block any ventilation openings. Install in accordance with the manufacturer's instructions.
8. Do not install near any heat sources, such as radiators, heat registers, stoves, or other apparatus (including amplifiers) that produce heat.
9. Do not defeat the safety purpose of the polarized or grounding-type plug. A polarized plug has two blades with one wider than the other. A grounding-type plug has two blades and a third grounding prong. The wide blade or the third prong are provided for your safety. If the provided plug does not fit into your outlet, consult an electrician for replacement of the obsolete outlet.
10. Protect the power cord from being walked on or pinched, particularly at plugs, convenience receptacles, and the point where it exits from the apparatus.
11. Only use attachments/accessories specified by the manufacturer.
12. Use only with the cart, stand, tripod, bracket, or table specified by the

manufacturer or sold with the apparatus. When a cart is used, use caution when moving the cart/apparatus combination in order to avoid injury from tip-over.

13. Refer all servicing to qualified service personnel. Servicing is required when the apparatus has been damaged in any way, such as power-supply cord or plug is damaged, liquid has been spilled or objects have fallen into the apparatus, the apparatus has been exposed to rain or moisture, does not operate normally, or has been dropped.
14. **Power Sources**  
This product should be operated only from the type of power source indicated on the marking label. If you are not sure of the type of power supply to your INSTALLATION, consult your product dealer or local power company.
15. **Overloading**  
Do not overload wall power outlets and extension cords as this can result in a risk of fire or electric shock.
16. **Disconnect Device**  
The AC mains plug is used as the disconnect device. The disconnect device must remain readily operable.

(Continued on next page)

# IMPORTANT SAFETY INSTRUCTIONS

---

(Continued from previous page)

## 17. Object and Liquid Entry

Never push objects of any kind into this product through openings as they may touch dangerous voltage points or short-out parts that could result in a fire or electric shock. Never spill liquid of any kind on the product. Do not use liquid cleaners or aerosol cleaners.

## 18. Outdoor Use



**Warning:** To prevent fire or shock hazards, do not expose this product to rain or moisture.

## 19. Wet Location

Do not use this product near water or moisture or in an area, such as a basement, that might become flooded. The apparatus shall not be exposed to dripping or splashing and no objects filled with liquids, such as vases, shall be placed on the apparatus.

## 20. Test Equipment

In some cases, LG has supplied or recommended the use of test equipment and devices for the setup and testing of the equipment. The operation and maintenance of test equipment is described in their associated instruction manuals. Please refer to these manuals for explicit instructions regarding the safe use and handling of the equipment.

## 21. Damage Requiring Service

Unplug this product from the wall power outlet and refer servicing to qualified service personnel under the following conditions:

- If the power-supply cord or plug is damaged.
- If liquid has been spilled, or objects have fallen into the product.
- If the product has been exposed to rain or water.
- If the product does not operate normally by following the operating instructions. Adjust only those controls that are covered by the operating instructions, as an improper

adjustment of other controls may result in damage and will often require extensive work by a qualified technician to restore the product to its normal operation.

- If the product has been dropped or the cabinet has been damaged.
- If the product exhibits a distinct change in performance.



**Caution:** Refer all servicing to qualified service personnel.

## 22. Servicing



**Caution:** These servicing instructions are for use by qualified service personnel only. To reduce the risk of electrical shock, do not perform any servicing other than that described in the operating instructions unless you are qualified to do so.

## 23. Replacement Parts

When replacement parts are required, be sure the service technician uses replacement parts specified by the manufacturer or that have the same characteristics as the original parts. Unauthorized substitutions may result in fire, electric shock, or other hazards.

## 24. Safety Check

Upon completion of any service or repairs to this product, ask the service technician to perform safety checks to determine that the product is in proper operating condition.

## 25. Handling Notice



**Caution:** Only qualified service personnel should handle and install this unit. A series of screws with lock washers are used to secure the top and bottom covers of the unit. Use caution when handling the unit as the lock washers may have rough edges.

# IMPORTANT SAFETY INSTRUCTIONS

---

**Do NOT run your fingers over the top and bottom covers of the unit.**

- 26. Do not block any of the ventilation openings. Install in accordance with the manufacturer's instructions.**  
- The product can be deformed or fire can break out due to overheating inside the product.
- 27. Do not place the product in a built-in installation such as bookcase or rack.**  
- Ventilation required.
- 28. DISCONNECTING DEVICE FROM MAINS**  
- Mains plug is the disconnecting device. The plug must remain readily operable.
- 29. Do not place anything containing liquid on top of the product such as flowerpot, cup, cosmetics or candle.**  
- This may cause a fire hazard.

**PCS200S Rack Installation** (also see pages 11 to 12)

To install the PCS200S in a rack:

- Carefully slide the PCS200S into a standard 19-inch equipment rack.
- When mounting in the rack, make sure to use the appropriate hardware. **ALL FOUR MOUNTING SCREWS MUST BE USED.**
- This equipment is not designed to support other devices. **Do NOT stack other equipment on the top of the PCS200S.**
- Rear cabling must be dressed and supported so that the weight of the cabling is not a strain on the PCS200S connectors.
- **MOUNTING OF THE EQUIPMENT IN THE RACK SHOULD BE SUCH THAT A HAZARDOUS CONDITION IS NOT ACHIEVED DUE TO UNEVEN MECHANICAL LOADING.**

## **Rack-mount Considerations**

### **A. Elevated Operating Ambient**

If installed in a closed or multi-unit rack assembly, the operating ambient temperature of the rack environment may be greater than room ambient. Therefore, consideration should be given to installing the equipment in an environment compatible with the maximum ambient temperature (T<sub>ma</sub>) specified by the manufacturer. See specifications information in this document.

### **B. Reduced Air Flow**

Installation of the equipment in a rack should be such that the amount of air flow required for safe operation of the equipment is not compromised. To ventilate the system normally and avoid overheating, leave at least 1 inch (2.5 cm) on each side (including top and bottom) of the PCS200S. Do NOT stack other equipment on the top of the PCS200S. Also, ensure that the unit's AC power adapter is never stacked or bundled with other AC power adapters. Each adapter should have adequate ventilation and should be isolated from other heat sources.

### **C. Circuit Overloading**

Consideration should be given to the connection of the equipment to the supply circuit and the effect that overloading of the circuits might have on overcurrent protection and supply wiring.

### **D. Reliable Earthing**

Maintain reliable earthing of rack-mounted equipment. Particular attention should be given to supply connections other than direct connections to the branch circuit (e.g. use of power strips).

### **E. Mains Outlet Earthing**

The apparatus with Class I construction must be connected to a mains socket outlet with a protective earthing connection.

# PCS200S Product Description

---

The LG PCS200S Pro:Centric® server is a stand-alone, remotely-controlled processor and controller for the Pro:Centric system. The server can be used to capture data from an Internet source, assemble the data as display pages, and output the pages in DTV format over ASI, RF, or IP.

## Features

- Three output options: ASI, RF, or IP
  - ASI output: The PCS200S generates one channel for GEM data only or multiplexed GEM/site data.
  - RF output: Both QAM-B (6 MHz) and DVB-C (7 MHz or 8 MHz) modulations are supported. The PCS200S generates one 256-QAM or 64-QAM RF channel for GEM/site data.
  - IP output: The PCS200S generates two multicast streams for GEM/site data.
- Customer may work with content provider to create Pro:Idiom® encrypted content on a SATA solid state drive (SSD) for RF or IP video playout channels
  - RF output: In addition to the GEM/site data channel, the PCS200S generates up to seven contiguous 256-QAM or 64-QAM RF channels for video playout. Each of these channels supports either two or three program streams multiplexed on each channel. This capability provides output of up to 21 programs of video content.
  - IP output: In addition to two multicast streams for GEM/site data, the PCS200S generates 21 multicast data streams for video playout. Each data stream supports one program. This capability provides output of up to 21 programs of video content.
- Provides remote management capability over Ethernet
- Small, lightweight chassis
- 19-inch rack-mountable
- 1U height profile to minimize rack space usage

An Internet browser-based Admin Client graphical user interface (GUI), provided for system integrator (SI) partners and lodging/institution administrators, facilitates support and maintenance of the Pro:Centric system. The Admin Client enables users to remotely manage system backups, output configuration, software updates, portal/information section content, TV configuration settings, etc.

Note: Design and specifications subject to change without prior notice.

Check the following items before you begin PCS200S installation and setup procedures.

**Note:** Once the PCS200S hardware is installed and the initial setup is completed, output parameters are configured in the Pro:Centric server Admin Client. Along with this document, it is recommended that you have a copy of the **Pro:Centric Server Admin Client User Guide** readily available.

## PCS200S

- \_\_\_ Unpack the PCS200S Pro:Centric server unit and all accessories.

<p><b>PCS200S Accessories:</b></p> <ul style="list-style-type: none"><li>• AC Power Cord and Adapter</li><li>• Four M3 x 5 mm screws for (optional) SATA SSD assembly</li><li>• Four lock washers for (optional) SATA SSD assembly</li></ul>
--

- \_\_\_ Select the location for mounting the PCS200S. Ensure adequate ventilation is available.
- \_\_\_ Obtain the necessary attachment hardware to mount the PCS200S chassis in its targeted location.
- \_\_\_ Plan and install the necessary cabling and network (Ethernet) and AC power access for the PCS200S. You also will need the following to connect a PC directly to the PCS200S for system setup purposes: FTDI TTL-USB cable (P/N TTL-232R-5V-AJ).

## SATA Solid State Drive (Optional)

- \_\_\_ To provide additional media/video playout channels, a customer-supplied SATA solid state drive may be installed in the SSD slot on the PCS200S rear panel. The solid state drive used must be UL listed, FCC compliant, and/or other applicable agency-recognized/ listed. (Maximum current draw = +5V DC @ 2.0 Amps)

---

Refer to the **PCS200S Pro:Centric Server Installation & Setup Guide** for further installation and configuration information.

Product documentation is available online at: [www.lg.com](http://www.lg.com).

# Setup Information

---

## Video Channel Assignments for RF Output (QAM-B) with Solid State Drive

Each input program is limited to one-half or one-third of the output channel bitrates (Mbps), which in turn are dependent on the modulation format. 256-QAM modulation supports up to 38.8 Mbps, and 64-QAM modulation supports up to 26.97 Mbps.

- \_\_\_ Create a channel assignment plan for the installation site, or modify an existing plan to incorporate the RF output of the PCS200S. Ensure that up to eight contiguous CATV broadcast channels are allocated for the PCS200S RF output. The PCS200S uses a 256-QAM or 64-QAM modulation format, thereby occupying approximately 48 MHz of frequency spectrum.

The RF start channel is user-assigned during system setup (in the Admin Client), and the remaining channels (up to seven) are then automatically assigned per EIA-542 STD CATV frequency allocation standards. For example, if the RF start channel assignment is channel 2, the seven remaining channels will be 3, 4, 5, 6, 95, 96, and 97. Refer to EIA-542 STD CATV frequency allocation tables for further information as required.

The highest available RF channel number for the PCS200S is 135. Thus, to allocate all eight channels available for PCS200S RF output, the RF start channel must be set no higher than 128.

- \_\_\_ Find a location on the frequency spectrum that is free of existing noise.

## Video Channel Assignments for RF Output (DVB-C) with Solid State Drive

Each input program is limited to one-half or one-third of the output channel bitrates (Mbps), which in turn are dependent on the modulation format. 256-QAM modulation supports up to 45.05 Mbps (7 MHz bandwidth) or 50.87 Mbps (8 MHz bandwidth), and 64-QAM modulation supports up to 33.79 Mbps (7 MHz bandwidth) or 38.15 Mbps (8 MHz bandwidth).

- \_\_\_ Create a channel assignment plan for the installation site, or modify an existing plan to incorporate the RF output of the PCS200S. Ensure that up to eight contiguous CATV channel frequencies are allocated for the PCS200S RF output. The PCS200S uses a 256-QAM or 64-QAM modulation format, thereby occupying approximately 56 MHz or 64 MHz (depending on channel bandwidth) of frequency spectrum.

The RF start channel frequency is user-assigned, in KHz, during system setup (in the Admin Client), and the remaining channel frequencies (up to seven) are then automatically assigned in accordance with the specified bandwidth. For example, if the RF start channel frequency assignment is 57000 KHz with a 7 MHz bandwidth, the seven remaining channel frequencies will be 64000 KHz, 71000 KHz, 78000 KHz, 85000 KHz, 92000 KHz, 99000 KHz, and 106000 KHz.

The highest available RF channel frequency for the PCS200S is 861000 KHz.

- \_\_\_ Find a location on the frequency spectrum that is free of existing noise.



## Video Channel Assignments for IP Output with Solid State Drive

Each IP stream is limited to 19.4 Mbps.

- \_\_\_ The PCS200S outputs IPv4 multicast streams. Ensure the institution's IP network and room receivers support IPv4 multicast and that the network is capable of selectively routing multicast traffic. Refer to vendor equipment documentation for further information.
- \_\_\_ Create a channel assignment plan for the installation site, or modify an existing plan to incorporate the IP output of the PCS200S. Ensure that up to 23 unused and unreserved IPv4 multicast addresses, within the designated range 224.0.0.0 to 239.255.255.255, are allocated for the PCS200S IP output.  
The IP start channel is user-assigned during system setup (in the Admin Client), and the remaining channel assignments are then automatically incremented. For example, if the IP start channel assignment is 227.0.0.40, the remaining channels will be 227.0.0.41, 227.0.0.42, etc.
- \_\_\_ Reserve one User Datagram Protocol (UDP) port for the multicast data streams. You can use the system default (1234) or another unassigned port number, for example, 50000, 50001, etc. The port must avoid conflict with other protocols in use.

**Note:** Refer to the IANA IPv4 Multicast Address Space Registry and/or the IANA Service Name and Transport Protocol Port Number Registry for further IP address/port information as required.


## ASI Output (Optional)

ASI output supports up to 19.4 Mbps each for GEM and site data (total of 38.8 Mbps).

- \_\_\_ If the system is using ASI output, install the modulator and upconverter that will receive the ASI output signal from the PCS200S. Refer to the manufacturer's documentation.

# Rear and Front Panel Overviews

## PCS200S Rear View



### Disconnect Device

The AC mains plug is used as the disconnect device. The disconnect device must remain readily operable.



### RF OUT (0 dBmV) Connector


Reserved for service technician use only. When not in use, this connector must remain terminated with attached terminator accessory.



### USB Port

Reserved for service technician use only.

## PCS200S Front View



### Ventilation

Air flow must not be obstructed. To ventilate the system normally and avoid overheating, leave at least 1 inch (2.5 cm) on each side (including top and bottom) of the PCS200S. Do NOT stack other equipment on the top of the PCS200S.




### Screws with Lock Washers

Only qualified service personnel should handle and install the PCS200S. A series of screws with lock washers are used to secure the top and bottom covers of the PCS200S. Use caution when handling the unit as the lock washers may have rough edges. Do NOT run your fingers over the top and bottom covers of the unit.


## Typical Rack Installation

1. To avoid causing electrostatic (ESD) damage to the PCS200S during installation, attach an antistatic wrist strap to a properly grounded rack/object and put it on.
2. (Optional) As shipped, the PCS200S mounting brackets are attached flush with the front of the unit (see diagram a). If desired, the mounting brackets may be detached from the unit and reattached, for example, so that they are flush with the rear of the unit (see diagram b). If you wish to change the location/orientation of the mounting brackets, carefully remove each of the four (M4 x 10 mm) screws and attendant washers (one flat and one lock washer per screw) holding each bracket in place. Then, use the same screws and washers to reattach the mounting brackets in the desired location.
3. Carefully slide the chassis into a standard 19-inch equipment rack.
4. Use all four mounting screws to secure the chassis to the rack.

(a)




(b)



Use flat washer and lock washer with each M4 x 10 mm mounting bracket screw.

# Rack Installation (Cont.)

---



## Rack-mount Considerations

### A. Elevated Operating Ambient

If installed in a closed or multi-unit rack assembly, the operating ambient temperature of the rack environment may be greater than room ambient. Therefore, consideration should be given to installing the equipment in an environment compatible with the maximum ambient temperature ( $T_{ma}$ ) specified by the manufacturer (see Specifications information in this document).

### B. Reduced Air Flow

Installation of the equipment in a rack should be such that the amount of air flow required for safe operation of the equipment is not compromised. To ventilate the system normally and avoid overheating, leave at least 1 inch (2.5 cm) on each side (including top and bottom) of the PCS200S. Do NOT stack other equipment on the top of the PCS200S. Also, ensure that the unit's AC power adapter is never stacked or bundled with other AC power adapters. Each adapter should have adequate ventilation and should be isolated from other heat sources.

### C. Circuit Overloading

Consideration should be given to the connection of the equipment to the supply circuit and the effect that overloading of the circuits might have on overcurrent protection and supply wiring.

### D. Reliable Earthing

Maintain reliable earthing of rack-mounted equipment. Particular attention should be given to supply connections other than direct connections to the branch circuit (e.g., use of power strips).


### E. Mains Outlet Earthing

The apparatus with Class I construction must be connected to a mains socket outlet with a protective earthing connection.

Refer to the following diagrams, and complete the system installation as described on pages 14 to 18.

**Caution:** Do NOT make system connections until instructed to do so during the system installation procedure. In some instances, configuration steps must be performed before physical connections are made.


## Typical Setup Flow Chart for PCS200S with ASI Output




# System Setup (Cont.)

---


Typical Setup Flow Chart for PCS200S with RF Output



## Typical Setup Flow Chart for PCS200S with IP Output



## VPN Network Connections Overview



# System Setup (Cont.)

---

## Typical System Installation

(see also Typical Setup Flow Charts and VPN Network Connections Overview diagrams)

1. (Optional) To provide capacity for additional media/video playout channels, install a SATA solid state drive (customer-supplied) in the SSD slot on the PCS200S rear panel. See Reference section, "Using an SSD Storage Device with the PCS200S," for further information.
2. If your system is using ASI output, make the following two connections; otherwise, go to step 3.



- Connect a 75 ohm BNC-to-BNC coaxial cable between ASI OUT on the PCS200S and ASI IN on the modulator.
- Connect an RF coaxial cable between IF OUT on the modulator and IF IN on the upconverter.

**Note: The BNC cable must be less than 30 feet (9.2 meters) in length.**

3. To enable remote management, connect one end of a CAT5 RJ-45 Ethernet cable to the Control Port on the PCS200S rear panel, and connect the other end of the cable to the institution's network.
4. Connect the PCS200S power supply to the POWER connector on the PCS200S rear panel. Then, plug the AC power cord into a powered AC line receptacle. When power is applied, the PWR (Power) LED on the PCS200S front panel will initially flash red and then turn green (blinking during boot-up).

The boot-up process for the PCS200S may take up to two minutes. When boot-up is complete, the PWR LED on the PCS200S front panel will light continuously green.

5. Once the PWR LED is lit continuously (no longer blinking), use the FTDI TTL-232R-5V-AJ cable to connect a PC to the Service Port on the PCS200S rear panel.
6. Using HyperTerminal or an equivalent terminal emulation program on the PC, configure the serial port as follows: Bits per second/ baud = 115200; Data bits = 8; Parity = None; Stop bits = 1; Flow Control = None

**Note:** To avoid configuration errors, make sure the keyboard settings on the terminal emulator assign the backspace character to Ctrl + H (ASCII 8).

Once the connection is established, you should see a login prompt. (If the login prompt is not automatically displayed, press **Enter** to refresh the screen.)

7. At the `login as:` prompt, type **admin** and press **Enter**. Then, at the `password:` prompt, type **Password4Partners** (case-sensitive) and press **Enter**.

(Continued on next page)



(Continued from previous page)



**Note:** After the system setup is complete, it is highly recommended that you use the “pwd” command available from the PCS200S Main Menu to change the admin user password from its default value. Refer to the extended Installation & Setup Guide for further information.

8. At the `Command >` prompt, type **info** and press **Enter**. (You can press **Enter** at any PCS200S command prompt to view current menu, if desired.)

The initial System Information display identifies PCS200S, default configuration settings, including the Control Port IP address and the output configuration, for example:

```
PCS200S Pro:Centric Server v6.7
Copyright (c) 2010 - 2014 Zenith Electronics LLC

SN:                201-12301011
Hardware ID:       2
OS version:        Linux 3.4.0-zenith-pcs200+
OS release:        #112 SMP Mon Aug 19 10:38:49 CDT 2013
Ctrl MAC:          00:0C:63:40:36:14
Ctrl IP:           10.166.60.92
Feat MAC:          00:0C:63:40:36:15
Feat IP:           n/a
VPN IP:            n/a
RF config:         Mode 3, 256-QAM-B, RF: 6 MHz, 5.36 MSps, ASI: 38.81
RF channel:        75
Channels:          1
Local time:        Tue May 20 14:42:02 EDT 2014
```

Mbps

9. Check the Ctrl IP (Control Port IP address) field in the System Information display. By default, the PCS200S uses DHCP; thus, the DHCP server, if configured, assigns an IP address to the Control Port once the PCS200S successfully connects to the network.
  - If the Ctrl IP field shows an IP address, the PCS200S is up and running on the network. If you wish to configure a static IP address for the Control Port and/or if you need to configure a static IP address for the Feature Port (for IP output purposes), continue with step 10. Otherwise, you can go to step 11 at this time.
  - If the network is configured for DHCP but the Ctrl IP field is blank, refer to “Network Setup” troubleshooting information on page 23.
  - If the network is not configured for DHCP, you will need to configure a static IP address for the PCS200S Control Port as described in step 10.

(Continued on next page)

# System Setup (Cont.)

---

(Continued from previous page)

10. This step describes how to set a static IP address for the Control Port and/or Feature Port.



**Caution: Setting a static IP address for the Control Port (for remote management purposes) is optional. However, if you will be using IP output from the PCS200S, you MUST configure the Feature Port as described in step (c) below.**

- a) At the `Command >` prompt, type **setip** and press **Enter**. The system will display the current network configuration, followed by the Network Configuration Menu.  
Use the Network Configuration Menu commands indicated below and follow the system prompts to configure the port(s). Refer to the extended Installation & Setup Guide for further information on the commands.
- b) Use the “eth0” and “dns” commands to configure the Control Port, as necessary.
- c) Use the “eth1” command to configure the Feature Port, if required, for PCS200S IP output.

Note that the Feature Port MUST be configured with a static IP address that is on a different subnet than the Control Port IP address. Also, make sure the Feature Port speed (default: 1000 Mbps) is appropriate for your system. If necessary, at the prompt for the port speed, change the value to 100 Mbps.

- d) When you are finished with network configuration, type **exit** at the Network Configuration Menu `>` prompt. The system will display an overview of the new network configuration and then prompt for confirmation to save the changes:

`Do you want to save the new configuration? [y/n]:`

Type **y** or **n** and press **Enter**, as appropriate.

**Note:** Review the New Network Configuration overview carefully before you confirm the configuration settings. Ensure each of the addresses was entered correctly.

**Note:** If you changed the configuration of the port(s), you will be prompted to reset the system. You may wait to reset the system until you are directed to do so in step 13.

(Continued on next page)

(Continued from previous page)

11. (Optional) Set the date and time on the PCS200S.

By default, the PCS200S is synchronized with an NTP server and configured for the US Eastern time zone. If the PCS200S is connected to the Internet, the NTP client will periodically update the time setting on the PCS200S. You can set the time zone as required. If the PCS200S is not connected to the Internet, you also have the option to disable NTP synchronization and specify date and time data manually.

Use the PCS200S “tz” and/or “time” commands (available from the `Command >` prompt), as necessary, to set the date and time on the PCS200S.

- Use the “tz” command and follow the system prompts to change the time zone.
- Use the “time” command and follow the system prompts to change the NTP configuration or manually configure the date and time parameters on the PCS200S.

Refer to the extended Installation & Setup Guide for further information on these commands.

**Note:** If you changed the time zone and/or the NTP configuration, you will be prompted to reset the system. You may wait to reset the system until you are directed to do so in step 13.

12. If a SATA solid state drive is installed (see step 1), the drive's file system must be properly formatted. If the drive was previously formatted for use with another PCS200S, you do not need to reformat the drive. Otherwise, at the `Command >` prompt, type **format** and press **Enter**. Then, follow the system prompts to initiate the formatting.



**Caution:** This operation deletes any files that are currently present on the drive. Refer to the extended Installation & Setup Guide for further information.

13. If you made any configuration changes in steps 10 and 11 that require a system reset, at the `Command >` prompt, type **reset** and press **Enter**.

The reset process may take up to two minutes, after which the PCS200S resumes normal operation.

14. Make the appropriate connection to the RF distribution system or IP distribution network depending on the PCS200S output option to be used.

(Continued on next page)

# System Setup (Cont.)

---

(Continued from previous page)

- ASI output: Connect the RF output on the upconverter to the RF distribution center combiner, and balance the RF signal so that the Pro:Centric signal level at the TV(s) is between 0 to +7 dBmV.
- RF output: Connect RF OUT on the PCS200S to the RF distribution center combiner, and balance the RF signal so that the Pro:Centric signal level at the TV(s) is between 0 to +7 dBmV.
- IP output: Connect a CAT5E or better Ethernet cable between the Feature Port on the PCS200S rear panel and the institution's IP distribution network.



**Caution (ASI/RF Output only):** For proper system performance, the Pro:Centric signal level at the TV input (ANTENNA IN) must be between 0 to +7 dBmV. Note that additional equipment may be required to adjust the signal level.



**Caution:** When not in use, the RF OUT (0 dBmV) connector must remain terminated with attached terminator accessory.

15. Configure the ASI/RF or IP output parameters in the Pro:Centric server Admin Client "RF/IP Configuration" screen. Refer to the ***Pro:Centric Server Admin Client User Guide*** for further information.  
**Note:** By default, the server output is enabled for 256-QAM-B modulation (RF output), with the data channel set to 75.
16. Check one or more room receivers to make sure all content is properly mapped and available.

# Reference: Using an SSD Storage Device with the PCS200S

---

To provide capacity for additional media/video playback channels, a (customer-supplied) SATA solid state drive may be installed in the SSD slot on the PCS200S rear panel. This section describes how to install the drive and also provides information on the required formatting.

## Install the Solid State Drive

You will need to have available the four M3 x 5 mm screws and attendant washers (one lock washer per screw) shipped with the PCS200S. These will be used to attach the solid state drive to the PCS200S SSD drive tray assembly.



**Caution: The Pro:Centric server is NOT designed to be hot-swappable!!! Power to the PCS200S must be removed before the solid state drive is inserted or removed.**



**Caution: The solid state drive used must be UL listed, FCC compliant, and/or other applicable agency-recognized/listed. (Maximum current draw = +5V DC @ 2.0 Amps)**



**Caution: The solid state drive must be inserted and removed by qualified service personnel only.**

1. Log in to the PCS200S command line interface and use the “shut” command to shut down the system in an orderly manner. Refer to the extended Installation & Setup Guide for further information on this command.
2. Put on a properly grounded, antistatic wrist strap to avoid causing electrostatic (ESD) damage both to the solid state drive and the PCS200S.
3. Unpack the solid state drive unit.
4. Remove the PCS200S AC power cord from the AC line receptacle from which it is receiving power.
5. Disengage the SSD slot cover from the PCS200S rear panel by turning the thumbscrew on each side of the cover counterclockwise (use a Phillips screwdriver if necessary). Then, slowly, slide out the SSD drive tray assembly.



**Caution: As shipped, the cabling/SATA connector for the solid state drive is connected by zip tie to the rear end of the SSD drive tray assembly. Use scissors or a similar tool to remove the zip tie, taking care not to damage the cables.**

6. Place the solid state drive onto the drive tray, and use the four M3 x 5 mm screws and washers to attach it to the drive tray assembly. You may attach the drive either from the bottom or from the sides (see diagram a on following page).
7. Plug the PCS200S SATA connector/cabling into the solid state drive (see diagram b on following page).

(Continued on next page)

# Reference: Using an SSD Storage Device with the PCS200S (Cont.)

(Continued from previous page)


8. Slide the drive tray assembly back into the PCS200S. Then, engage and tighten the thumb-screw on each side of the slot cover securely.




**Note:** It is recommended that you use a Phillips screwdriver to secure the thumbscrews on the SSD slot cover.

9. Plug the PCS200S AC power cord back into its powered AC line receptacle to restore power. After it is powered back on, the PCS200S resumes normal operation.

(a)



(b)



Attach the four M3 x 5 mm screws and washers either at the sides or the bottom of the drive tray assembly.

## Format the Solid State Drive



**Caution:** In order to use the solid state drive for video playout, you **MUST** format the file system. Note that during formatting, any files that are currently loaded on the solid state drive will be deleted.

Log in to the PCS200S command line interface and use the “format” command to format the drive’s file system. Refer to the extended Installation & Setup Guide for further information on this command. All additional video playout configuration is performed in the Pro:Centric server Admin Client (see the *Pro:Centric Server Admin Client User Guide*).

**Note:** If the drive was previously formatted for use with another PCS200S server, you do not need to reformat the file system.

This section provides introductory PCS200S installation and setup troubleshooting information. Refer to the extended Installation & Setup Guide for additional troubleshooting information.

## Equipment Setup Review

- Make sure all connectors and connections are tight and secure on all entertainment system components.
- Check the PCS200S LED: Under standard operating conditions, i.e., when the PCS200S is booted and operating normally, the PWR (Power) LED on the PCS200S front panel is continuously lit green. If there is a hardware fault, the PWR LED will turn and stay red.

**Note:** When power is first applied to the PCS200S, the PWR LED initially flashes red and then turns green (blinking during boot-up).

## Network Setup

If the network is configured for DHCP but the PCS200S has not been assigned an IP address, i.e., the Ctrl IP field in the PCS200S System Information display is blank:

1. Check the Control Port connector on the rear panel of the PCS200S. Make sure the cable connection is tight and secure.
2. Observe the green LED on the Control Port. Once the PCS200S is connected to the network, the LED will be lit continuously.
3. Contact the network administrator to verify the network status and check that the DHCP server is working properly.

# Specifications

---

## Dimensions

Height:	42.977 mm
Width:	482.6 mm (for EIA standard 19-inch rack mount)
Depth:	215.9 mm
Weight:	2.56 kg (rack-only weight)

## Environmental Storage Conditions

Temperature:	-20° to 70° Celsius
	-4° to 158° Fahrenheit
Humidity:	95% non-condensing

## Environmental Operating Conditions

Temperature (Tma):	0° to 40° Celsius
	32° to 104° Fahrenheit
Humidity:	95% non-condensing

## Electrical

RF Out Connectors (2)*:	75 Ohm, Type 'F'
Frequency:	VHF/UHF 54-865 MHz
RF Output Span:	Up to 8 Contiguous Channels (typically 48-64 MHz)
RF Output Frequency Range:	54 MHz to 865 MHz
Active Output Level at RF Out jacks:	-1 dBm (+47.75 dBmV) Typical
Test Output Level:	-47.75 dBm (+1 dBmV) Typical
Frequency Accuracy:	±5 ppm
Impedance at ASI Out jack:	75 Ohms
Level at ASI Out jack:	800 mv
DC Input:	+19V DC @ 2.2 Amps
Ethernet Connector (Control Port):	10/100/1000BaseT, RJ-45
Ethernet Connector (Feature Port):	100/1000BaseT Full Duplex, RJ-45
USB Port*:	USB 2.0
Solid State Drive:	UL listed, FCC compliant, and/or other applicable agency-recognized/listed (Maximum current draw = +5V DC @ 2.0 Amps)

\* RF OUT (0 dBmV) connector and USB port reserved for service technician use only.

Note: Design and specifications subject to change without prior notice.



### Modulation Specifications

Standard:	ITU-T J.83 Annex B (QAM-B)	
Constellations:	64-QAM, 256-QAM	
Symbol Rate:	64-QAM	5.056941 MBaud
	256-QAM	5.360537 MBaud
Interleaving:	Fixed I = 128, J = 1	

Standard:	EN 300 429 V1.2.1 (DVB-C)	
Constellations:	64-QAM, 256-QAM	
Symbol Rate:	64-QAM	6.9 MBaud
	64-QAM	6.111 MBaud
	256-QAM	6.9 MBaud
	256-QAM	6.111 MBaud

# Open Source Software Notice

Product Type	Pro:Centric Server
Model Number/Range	PCS200S

Those products identified by the Product Type and Model Range above from LG Electronics, Inc. (“LGE”) contain the open source software detailed below. Please refer to the indicated open source licences for the terms and conditions of their use.

Components	License
bash, busybox, das u-boot, dev, e2fsprogs, ethtool, gawk, grep, hotplug, iptables, linux kernel, lrzsz, lzo, merge, module-init-tools, mtd-utils, net-tools, ntfs-3g, ntpclient, openvpn, pciutils, procinfo, procps, screen, skell, sysconfig, syslogd, time, usbutils	GPL 2.0
eglibc, ffmpeg, gmp, Java SwingLabs, libelf, libusb, LIVE555 Streaming Media, openRTSP, termcap	LGPL 2.0/2.1

The source code and other important information for the above may be obtained free of charge from LGE at <http://opensource.lge.com>. LGE will also provide open source code to you on CD-ROM for a charge covering the cost of performing such distribution (such as the cost of media, shipping and handling) upon e-mail request to [opensource@lge.com](mailto:opensource@lge.com). This offer is valid for three (3) years from the date on which you purchased the product.

Please be informed that LG Electronics products may contain open source software listed in the table below.

Components	License
Apache Ant, Apache Commons EL, Apache Commons FileUpload, Apache Commons IO, Apache Commons Logging, Apache Commons Modeling, Apache Commons Net, Apache Derby, Apache HttpComponents, Apache Jakarta, Apache James, Apache Tomcat 6.0, httpd	Apache License v2.0
flex, portmap, tcp-wrappers	BSD License
libcurl	Curl License
dhcp, expat	MIT License
openssh	OpenSSH License
OpenSSL	OpenSSL License
sudo	sudo License
zlib	zlib/libpng License

# LG PCS200S Pro:Centric Server Warranty

**Broadcast Products** Welcome to the LG family! We believe that you will be pleased with your new PCS200S Pro: Centric Server. Please read this warranty carefully, it is a "LIMITED WARRANTY". This warranty gives you specific legal rights.

## LG's RESPONSIBILITY

**Warranty Term** 1 year parts and labour from date of purchase or delivery date.

**Parts** New or remanufactured replacements for factory-defective parts may be used. Such replacement parts have a warranty for the remaining portion of the original warranty period.

**Warranty Service** Warranty service is provided by LG. Customer pays for shipping charges to LG; LG pays for return shipping Charge's to return PCS200S Pro: Centric Server to customer. Call **0844 248 6655** for further information.

**Not Covered** This warranty covers manufacturing defects and does not cover installation, adjustment of customer controls, Installation or repair of antenna systems, cable converters or cable company-supplied equipment; it also does not cover damage due to misuse, abuse, negligence, acts of God or other causes beyond the control of LG.

Any alteration of the product after manufacture voids this warranty in its entirety.

**THIS WARRANTY IS IN LIEU OF ANY OTHER WARRANTY, EXPRESSED OR IMPLIED, INCLUDING WITHOUT LIMITATION, ANY WARRANTY OF MERCHANTABILITY OR FITNESS FOR A PARTICULAR PURPOSE, AND LG SHALL NOT BE LIABLE FOR ANY CONSEQUENTIAL, INDIRECT, OR INCIDENTAL DAMAGES OF ANY KIND, INCLUDING LOST REVENUES OR PROFITS IN CONNECTION WITH THIS PRODUCT.**

## OWNER'S RESPONSIBILITY

**Effective Warranty Date** Warranty begins on the date of delivery of the PCS200S Pro: Centric Server.  
**For your convenience, keep the dealer's dated bill of sale or delivery ticket, as evidence of the purchase date.**

**Installation Guide** Read the Installation & Setup Guide carefully so that you will understand the operation of the PCS200S Pro: Centric Server along with how to adjust the settings.

**Warranty Service** **For warranty service information, call 0844 248 6655.** Parts and labour for service work carried out are LG's responsibility (See above) will be provided without charge. Other service is at the owner's expense. If you have any problem in obtaining satisfactory warranty service, call **0844 248 6655**.  
You must provide the model number, serial number and date of purchase or date of original installation.

For Customer Support/Service, please call:

**0844 248 6655**

[www.lg.com](http://www.lg.com)



**Pro:Centric®**



Pro:Centric is a registered trademark of LG Electronics Inc. Java is a trademark of Oracle.  
All other trademarks or registered trademarks are the property of their respective owners.

