عربي

ENGLISH

Life's Good

USER GUIDE

LG-M700A

Copyright ©2017 LG Electronics Inc. All rights reserved.

www.lg.com

MFL70264901 (1.1)

حول دليل المستخدم هذا

شكرًا لاختيارك هذا المنتج من LG. ونرجو منك قراءة دليل المستخدم هذا بعناية قبل استخدام الجهاز للمرة الأولى لضمان استخدامه بطريقة مناسبة وآمنة.

- استخدم دائمًا ملحقات LG الأصلية. ولقد صُممت العناصر المرفقة لهذا الجهاز فقط وقد لا تكون متوافقة مع الأجهزة الأخرى.
- هذا الجهاز غير مناسب لمن يعاني من إعاقة بصرية حيث إن لوحة مفاتيحه ذات شاشة تعمل باللمس.
- تعتمد الأوصاف على الإعدادات الافتراضية للجهاز.
- تخضع التطبيقات الافتراضية المتوفرة بهذا الجهاز للتحديث وقد يتم إلغاء دعمها دون إشعار سابق. وإذا كانت لديك أية استفسارات بشأن أي تطبيق متوفر بالجهاز، فيرجى الاتصال بمركز خدمة LG. أما فيما يتعلق بالتطبيقات المثبتة بواسطة المستخدم، يرجى الاتصال بمزود الخدمة المعني.
- قد يؤدي تعديل نظام تشغيل الجهاز أو تثبيت برامج من مصادر غير رسمية إلى إلحاق ضرر بالجهاز وتلف البيانات أو فقدانها. ومثل هذه الإجراءات قد يترتب عليها انتهاك اتفاقية ترخيص LG وإلغاء الضمان.
- قد تختلف بعض المحتويات والرسومات التوضيحية من جهاز لآخر تبعًا للمنطقة أو مزود الخدمة أو إصدار البرامج أو إصدار نظام التشغيل، كما أنها تكون عرضة للتغيير دون إشعار سابق.
- البرامج والمقاطع الصوتية والخلفيات والصور وأية وسائط أخرى مرفقة بجهازك مرخصة للاستخدام المحدود؛ فإذا استخرجتها واستخدمتها لأغراض تجارية أو غيرها، فإنك بذلك تنتهك قوانين حقوق النشر. وبصفتك مستخدمًا، فإنك تتحمل المسؤولية كاملة عن الاستخدام غير القانوني للوسائط.
- يجوز فرض رسوم إضافية على خدمات البيانات، كالرسائل والتحميل والتنزيل والمزامنة التلقائية وخدمات تعيين المواقع. ولتجنب مثل هذه الرسوم، اختر خطة بيانات مناسبة لاحتياجاتك. واتصل بمزود الخدمة للاطلاع على مزيد من التفاصيل.
- تمت كتابة هذا الدليل باللغة المحلية لكل بلد. قد يختلف المحتوى بشكل بسيط وفقًا للغة المستخدمة.

ملاحظات إرشادية

تحذير: الحالات التي قد تسبب إصابة للمستخدم أو أطراف أخرى.

تنبيه: الحالات التي قد تسبب إصابة طفيفة أو تلفًا للجهاز.

ملاحظة: ملاحظات أو معلومات إضافية.

المحتويات

5 إرشادات لاستخدام آمن وفعال

01

الميزات المصممة لغرض خاص

12 ميزات الكاميرا
15 ميزات المعرض
17 إنشاء تجميع لخلفيات الشاشة
18 التعرّف على الوجه
21 ميزة تعدد المهام
22 المشاركة السريعة

02

الوظائف الأساسية

24 مكونات المنتج وملحقاته
25 نظرة عامة على الأجزاء
27 التشغيل أو إيقاف التشغيل
28 تركيب بطاقة SIM
30 إدخال بطاقة الذاكرة
31 إخراج بطاقة الذاكرة
31 البطارية
33 شاشة اللمس
36 الشاشة الرئيسية
44 قفل الشاشة
46 تشفير بطاقة الذاكرة
47 أخذ لقطات شاشة
48 إدخال نص
53 عدم الإزعاج

03

التطبيقات المفيدة

55 تثبيت التطبيقات وإزالة تثبيتها
56 مهملات التطبيقات
56 الهاتف
60 الرسائل
61 الكاميرا
73 المعرض
78 الاسماء
80 QuickMemo+
82 الساعة
83 التقويم
84 مهام
84 موسيقى
85 الآلة الحاسبة
85 البريد الإلكتروني
87 المسجل الصوتي
87 راديو FM
87 بث الشبكة
88 إدارة الملفات
88 LG Mobile Switch
88 التنزيلات
89 LG SmartWorld
89 RemoteCall Service
90 Chrome
90 تطبيقات Google

04

الإعدادات

93 الإعدادات
93 الشبكات
102 الصوت و الإشعار
103 إعدادات الشاشة
104 عامة

05

الملحق

112 إعدادات لغة LG
112 LG Bridge
113 تحديث برامج الهاتف
115 الأسئلة المتداولة
118 دليل مكافحة السرقة
119 معلومات حول القواعد التنظيمية (رقم معرّف التنظيم، العلامات الإلكترونية، إلخ)
119 قطع من الزجاج المقسى
119 نسبة العرض إلى الارتفاع
120 المزيد من المعلومات

إرشادات لاستخدام آمن وفعال

يرجى قراءة هذه الإرشادات البسيطة. عدم التقيّد بهذه الإرشادات قد يكون أمراً خطراً أو غير قانوني.

في حال حدوث خطأ، تم تضمين أداة برنامج في الجهاز من شأنها تجميع سجل الخطأ. تجمع هذه الأداة البيانات الخاصة بالخطأ فقط، مثل قوة الإشارة وموضع معرّف الخلية لدى انقطاع المكالمة المفاجئ والتطبيقات التي تم تحميلها. يستخدم السجل فقط للمساعدة في تحديد سبب الخطأ. تجدر الإشارة إلى أن هذه السجلات مشفرة ويمكن الوصول إليها من قبل مركز تصليح معتمد من LG فقط في حال احتجت إلى إعادة جهازك لتصليحه.

التعرّض لطاقة التردد اللاسلكي

معلومات حول التعرّض للموجات اللاسلكية ومعدل الامتصاص المحدّد (SAR).

صُمم هذا الجهاز بحيث يفي بمتطلبات السلامة القابلة للتطبيق والتي تتعلق بالتعرّض للموجات اللاسلكية. وتستند هذه المتطلبات إلى إرشادات علمية تتضمّن هوامش سلامة مصمّمة لضمان السلامة لكل الأشخاص، دون أخذ العمر والصحة بعين الاعتبار.

- تستخدم إرشادات التعرض للموجات اللاسلكية وحدة قياس معروفة بمعدل الامتصاص المحدّد أو SAR. وتجري اختبارات SAR باستخدام أساليب قياسية فيما ينفذ الجهاز عملية الإرسال بأعلى مستوى طاقة مسموح به في كل نطاقات التردد المستخدمة.
- ونظرًا إلى إمكانية وجود فروقات في مستويات SAR بين مختلف طرازات الجهاز من LG، إلا أنها كلها مصممة بحيث تفي بالإرشادات المتعلقة بالتعرّض للموجات اللاسلكية.
- حد SAR الذي توصي به اللجنة الدولية للحماية من الإشعاع غير المؤين International Commission on Non-Ionizing Radiation Protection (ICNIRP) هو 2 واط/كجم وهو حد مقسّم على نحو متناسب إلى 10 جرامات من النسيج العضوي.
- تبلغ أعلى قيمة لـ SAR لهذا الطراز عند اختباره للاستخدام على الأذن 0.384 واط/كجم (10 جرامات) وعند الاستخدام على الجسم 1.540 واط/كجم (10 جرامات).
- يفي هذا الجهاز بإرشادات التعرض للتردد اللاسلكي (RF) عند استخدامه في موضع الاستخدام العادي على الأذن أو عند وضعه على بعد 5 مم على الأقل من الجسم. عند استخدام علبة حمل أو مشبك للحزام أو حامل لتشغيل الجهاز أثناء حمله على الجسم، يجب ألا تحتوي على أي معدن ويجب وضع المنتج على بعد 5 مم على الأقل من الجسم. ومن أجل إرسال ملفات البيانات أو الرسائل، يتطلّب هذا الجهاز اتصالاً نوعيّاً عالي الجودة بالشبكة. في بعض الحالات، يجوز أن يتم تأخير إرسال ملفات البيانات أو الرسائل إلى أنْ يُصبح هذا الاتصال متاحاً. احرص على اتباع التعليمات المتعلّقة بالمسافات الفاصلة المشار إليها أعلاه إلى أنْ يتمّ اكتمال الإرسال.

العناية بالمنتج وصيانته

- استخدم الملحقات المتوفرة في العلبة فقط والتي تكون معتمدة من قبل LG. لا يغطي ضمان LG أي ضرر أو عطل ناتج من استخدام ملحقات الجهات الخارجية.
- قد تختلف بعض المحتويات والصور عن جهازك من دون إشعار مسبق.
- لا تقم بتفكيك الوحدة. اعمل على نقل الوحدة إلى تقني صيانة مؤهل عندما تكون بحاجة إلى إصلاحها.
- قد تتضمن الإصلاحات المشمولة بالكفالة، وفقاً لـ LG، لوحات أو قطع الغيار سواء كانت جديدةً أو مجددةً، على أن تتمتع بوظائف موازية لوظائف الأجزاء التي تم استبدالها.
- ضع هذه الوحدة في مكان بعيد عن الأجهزة الإلكترونية مثل أجهزة التلفزيون، والراديو، وأجهزة الكمبيوتر الشخصي.
- يجب إبقاء الوحدة بعيدة عن مصادر السخونة مثل أجهزة التدفئة أو الأفران المنزلية.
- تجنب إسقاط الوحدة.
- لا تعرّض هذه الوحدة للاهتزاز الميكانيكي أو الصدمات.
- أوقف تشغيل الجهاز في أي منطقة تطلب منك قوانين خاصة القيام بذلك. على سبيل المثال، لا تستخدم الجهاز في المستشفيات إذ قد يؤثر ذلك في المعدات الطبية الحساسة.
- لا تمسك الجهاز عندما تكون يداك رطبتَين أثناء شحنه. فقد يتسبّب ذلك بحدوث صدمة كهربائية أو إلحاق ضرر بالغ به.
- يجب عدم شحن الهاتف بالقرب من مواد قابلة للاشتعال إذ قد يصبح الهاتف ساخناً وقد يؤدي ذلك إلى اندلاع حريق.
- استخدم قطعة قماش جافة لتنظيف الوحدة من الخارج (لا تستخدم مواد مذيبة كالبنزين أو التينر أو الكحول).
- لا تشحن الجهاز عندما يكون موضوعًا على أثاث ناعم.
- يجب شحن الجهاز في منطقة ذات تهوية جيدة.
- لا تعرّض هذه الوحدة للدخان أو الغبار الزائد.
- لا تضع الجهاز بالقرب من بطاقات الائتمان أو تذاكر النقل؛ فقد يؤثر ذلك في المعلومات الموجودة على الأشرطة المغناطيسية.
- لا تضغط على الشاشة بواسطة غرض حاد إذ قد يؤدي ذلك إلى إلحاق الضرر بالجهاز.
- لا تعرّض الجهاز للسوائل أو الرطوبة.
- استخدم الملحقات مثل سماعات الأذن بحذر. لا تلمس الهوائي من دون وجود سبب يدعوك إلى ذلك.
- لا تستخدم الزجاج المكسور أو تلمسه أو تحاول إزالته أو إصلاحه إذا كان مكسورًا أو متحولاً إلى شظايا أو متحطمًا. لا تشمل الكفالة تلف الشاشة الزجاجية نتيجة سوء الاستخدام.

- هذا الجهاز عبارة عن جهاز إلكتروني يولّد الحرارة أثناء الاستخدام العادي. قد تؤدي ملامسة الجهاز للبشرة مباشرة ولفترة طويلة في غياب التهوية المناسبة إلى عدم الشعور بالراحة أو التسبب بحروق طفيفة. لذا، استخدم الجهاز بعناية أثناء التشغيل أو بعده على الفور.
- إذا تبلل الجهاز، فافصله فورًا عن الطاقة ليجفّ بشكل كامل. لا تحاول تسريع عملية التجفيف باستخدام مصدر حرارة خارجي مثل فرن أو مايكروويف أو مجفف شعر.
- يرجى الحرص على عدم ملامسة المنتج للمياه. لا تستخدم المنتج أو تشحنه وهو مبلّل. عندما يصبح المنتج مبلّلاً، يتغيّر لون المؤشر الخاص بالضرر الذي يلحقه السائل بالمنتج. تجدر الإشارة إلى أن ذلك سيمنعك من تلقي أي خدمة تصليح مجانية يتم توفيرها بموجب الكفالة.

التشغيل الفعّال للجهاز

الأجهزة الإلكترونية

قد تتعرّض كل الأجهزة للتشويش، مما قد يؤثر في أدائها.

- لا تستخدم الجهاز بالقرب من الأجهزة الطبية من دون طلب إذن للقيام بذلك. يرجى استشارة طبيبك لمعرفة ما إذا كان تشغيل جهازك يؤدي إلى حدوث تشويش على الجهاز الطبي.
- توصي الشركات المصنّعة لجهاز ضبط النبض بإبقاء مسافة 15 سم كحد أدنى بين أجهزة أخرى وجهاز ضبط النبض لتجنب أي تشويش محتمل مع هذا الأخير.
- قد يصدر هذا الجهاز نورًا ساطعًا أو وامضًا.
- قد تتسبب بعض الأجهزة بإعاقة عمل الأدوات المساعدة للسمع.
- قد يؤثر الحد الأدنى من التشويش على أجهزة التلفزيون والراديو والكمبيوتر الشخصي.
- استخدم الجهاز في مكان تتراوح فيه درجة الحرارة بين 0 درجة مئوية و 35 درجة مئوية، إذا أمكن. فقد يؤدي تعريض الجهاز لدرجات حرارة مرتفعة أو منخفضة جدًا إلى إلحاق الضرر به أو تعطله أو حتى إلى حدوث انفجار.

السلامة على الطرقات

تحقق من القوانين والأنظمة المتعلقة باستخدام الأجهزة في المنطقة عند قيادة مركبة.

- لا تستخدم جهازًا محمولاً باليد أثناء القيادة.
- عليك دوماً تركيز كامل الانتباه على القيادة.
- توقّف عند جانب الطريق قبل إجراء مكالمة أو الإجابة على المكالمة إذا كانت ظروف القيادة تستدعي ذلك.
- قد تؤثر طاقة RF على بعض الأنظمة الإلكترونية في المركبة مثل أجهزة الستيريو ومعدات السلامة في السيارة.

- عندما تكون المركبة مزودة بكيس هوائي، عليك عدم إعاقة عمله بواسطة تجهيزات لاسلكية مثبتة أو محمولة. فقد يبطل ذلك عمل الكيس الهوائي أو قد يتسبب ذلك بإصابات خطيرة بسبب أداء غير صحيح.
- إذا كنت تستمع إلى الموسيقى أثناء تنقلك، فتأكد من كون مستوى الصوت معقولاً بحيث تكون مدركاً لما يحيط بك. هذا الأمر يعتبر ملحاً خصوصاً بالقرب من الطرقات.

تجنّب إلحاق الضرر بسمعك



لتفادي إلحاق الضرر بالسمع، لا تستمع إلى مستويات صوت عالية لفترات طويلة.

قد يؤدي تعرّضك إلى أصوات عالية لفترات وقت طويلة إلى إلحاق الضرر بسمعك. ونوصي بالتالي بألا تقوم بتشغيل الهاتف أو إيقافه عندما يكون قريباً من أذنك. كما نوصي بضبط صوت الموسيقى والمكالمات على مستوى معقول.

- عند استخدام سماعات الرأس، اخفض مستوى الصوت إذا كنت لا تسمع الأشخاص الذين يتحدثون بالقرب منك أو في حالة تمكُّن الشخص الجالس بجوارك من سماع ما تنصت إليه.

- قد يؤدي ضغط الصوت المرتفع من سماعات الأذن وسماعات الرأس إلى فقدان السمع.

القطع الزجاجية

بعض أجزاء جهازك مصنوعة من الزجاج. وهذا الزجاج قد ينكسر إذا سقط الجهاز على سطح صلب أو تعرض لاصطدام شديد. في حال انكسر الزجاج، لا تلمسه أو تحاول إزالته. توقف عن استخدام الجهاز حتى يتم استبدال الزجاج بواسطة مزود خدمة معتمد.

مناطق التفجير

لا تستخدم الجهاز في الأماكن حيث تكون عمليات التفجير جارية. التزم بالقيود، واتبع الأنظمة أو القوانين.

مناطق تتّسم أجواؤها بالقابلية للانفجار

- لا تستخدم الجهاز في محطة لإعادة التزوّد بالوقود.
- لا تستخدم الهاتف بالقرب من الوقود أو المواد الكيميائية.
- لا تنقل غازًا أو سائلاً قابلاً للاشتعال أو مواد متفجرة أو تخزّنها في الحجرة نفسها في المركبة حيث تضع الجهاز أو ملحقاته.

في الطائرة

باستطاعة الأجهزة اللاسلكية أن تتسبّب بحدوث تشويش في الطائرة.

- أوقف تشغيل الجهاز قبل الصعود على متن أي طائرة.
- لا تستعمله على الأرض من دون الحصول على إذن من قِبل طاقم الطائرة.

الأطفال

ضع الجهاز في مكان آمن بعيدًا عن متناول الأطفال. فهو يحتوي على أجزاء صغيرة قد تنفصل عنه وتتسبّب بالاختناق.

مكالمات الطوارئ

قد لا تكون مكالمات الطوارئ متوفرةً على كل شبكات الهاتف المحمول. وبالتالي عليك ألا تعتمد أبدًا على جهازك فقط لإجراء مكالمات الطوارئ. راجع موفر الخدمة المحلي لديك لمزيد من المعلومات.

معلومات حول البطارية والعناية بها

- لست بحاجة إلى إفراغ البطارية بشكل كامل قبل إعادة شحنها. وبخلاف أنظمة البطاريات الأخرى، ليس هناك من تأثير للذاكرة من شأنه تخفيض أداء البطارية.
- استخدم بطاريات وشواحن LG فقط. فشواحن LG مصمّمة لإطالة فترة عمل البطارية.
- لا تعمل على تفكيك البطارية أو تعريضها لحدوث تماس.
- استبدل البطارية عندما يصبح أداؤها غير مقبول. فمن الممكن إعادة شحن حزمة البطارية مئات المرات قبل أن تصبح بحاجة إلى الاستبدال.
- أعد شحن البطارية في حال عدم استخدامها لفترة طويلة وذلك لزيادة فترة صلاحية استخدامها.
- لا تعرّض شاحن البطارية لنور الشمس المباشر أو لا تستخدمه في أماكن عالية الرطوبة، مثل الحمام.
- لا تترك البطارية في الأماكن الساخنة أو الباردة، فقد يؤدي ذلك إلى تراجع في أداء البطارية.
- هناك خطر الانفجار إذا تمّ استبدال البطارية بنوع خاطئ. يجب التخلص من البطاريات المستخدمة وفقًا للإرشادات.
- قم دائماً بفصل الشاحن عن المقبس على الحائط بعد شحن الجهاز بالكامل لتفادي استهلاك الشاحن طاقة غير ضرورية.
- إن عمر البطارية الفعلي يتوقف على تكوين الشبكة و إعدادات المنتج وأنماط الاستخدام والبطارية والأوضاع البيئية.
- احرص على عدم احتكاك البطارية بأغراض حادّة الأطراف كأنياب الحيوانات أو الأظافر. فقد يسبب هذا الأمر حريقاً.

تأمين المعلومات الشخصية

- تأكد من حماية معلوماتك الشخصية لمنع تسريب البيانات أو إساءة استخدام معلومات حساسة.
- احرص على نسخ البيانات المهمة احتياطيًا دومًا عند استخدام الجهاز. فشركة LG غير مسؤولة عن أي فقدان للبيانات.
- تأكد من نسخ كل البيانات احتياطيًا ومن إعادة ضبط الجهاز عند التخلص منه لمنع أي إساءة استخدام للمعلومات الحساسة.
- اقرأ شاشة الأذونات بعناية أثناء تنزيل التطبيقات.
- احذر من استخدام التطبيقات التي يمكنها الوصول إلى وظائف متعددة أو إلى معلوماتك الشخصية.
- تحقق من حساباتك الشخصية بانتظام. إذا وجدت أي إشارة إلى إساءة استخدام معلوماتك الشخصية، فاطلب من موفر الخدمة لديك حذف معلومات حسابك أو تغييرها.
- إذا فقدت جهازك أو تعرض للسرقة، فقم بتغيير كلمة مرور حسابك لتأمين معلوماتك الشخصية.
- لا تستخدم تطبيقات من مصادر غير معروفة.

إشعار لاستبدال البطارية

- لسلامتك، لا تزِل البطارية المثبتة في المنتج. إذا كنت بحاجة إلى استبدال البطارية، فقم بأخذها إلى أقرب فرع للصيانة أو وكيل معتمد من LG Electronics للمساعدة.
- بطارية Li-Ion هي مكون خطر يمكن أن يتسبب في الإصابة.
- استبدال البطارية من قبل شخص غير مؤهل يمكن أن يُسبب ضررًا على الجهاز الخاص بك.

01

الميزات المصممة لغرض خاص


ميزات الكاميرا

كاميرا الزاوية العريضة

يمكنك التقاط صور أو تسجيل مقاطع فيديو بنطاق أوسع من مجال البصر الفعلي باستخدام الكاميرا الأمامية ذات الزاوية المتسعة.

قم بتشغيل تطبيق الكاميرا، ثم اضغط على [ ] / [ ] للتبديل بين الزاوية العريضة والزاوية القياسية.

الكاميرا الأمامية



- انظر بدء تشغيل الكاميرا للحصول على تفاصيل.

وضع الكاميرا مربع

يمكنك التقاط صور أو تسجيل مقاطع فيديو متعددة على شكل عمل تصويري عن طريق استخدام الكاميرا الأمامية والخلفية. يمكن حفظ الصور ومقاطع الفيديو باستخدام تخطيطات مختلفة.


1. قم بتشغيل تطبيق الكاميرا، ثم اضغط **أساسي** ([A]) > **مربع** ([ ]).
2. اضغط **الوضع** وحدد وضع الكاميرا المرغوب فيه.
3. لالتقاط صورة، المس [ ]. لتسجيل فيديو، المس [ ].

إلتقاط Snap

يمكنك التقاط صورة أو تسجيل فيديو ومعاينته على الفور.

1 في وضع مربع، اضغط **الوضع** > .

2 اضغط لالتقاط صورة. لتسجيل فيديو، المس .




التقاط شبكي

يمكنك التقاط ما يصل إلى 4 صور مرتبة ضمن مربّع.

1 في وضع مربع، اضغط **الوضع** > .

2 اضغط على لالتقاط الصور بطريقة متزامنة أو تسلسلية وفقًا لترتيب التخطيط المعروض.

3 اضغط للحفظ.



لقطة المطابقة

يمكنك التقاط صورتين في الوقت نفسه أو كل واحدة على حدة.

1 في وضع مربع، اضغط **الوضع** > .

2 اضغط على / لالتقاط صورة في الوقت نفسه أو على حدة.

- اضغط على > لاستخدام صورة من المعرض كاللقطة الأولى.

3 اضغط على لالتقاط الصور.

4 اضغط للحفظ (إذا لزم الأمر).



التقاط دليلي


يمكنك التقاط صور بإتباع شكل صورة أخرى.

1 في وضع مربع، اضغط **الوضع** > .

2 حدد من الأشكال الموجودة على الجانب الأيمن لاختيار واحدة ترغب في اتباعها.

3 المس لالتقاط صورة.

- استخدم الشريط المنزلق للتحكم في شفافية الخلفية.



التسجيل الثابت

يمكنك استخدام ميزة التسجيل الثابت لتقليل عدم الوضوح الناتج عن الحركة أثناء تسجيل فيديو.


قم بتشغيل تطبيق الكاميرا، ثم المس **أساسي** (Ⓐ) أو **مربع** (◻) > ⚙ > **التسجيل الثابت** .

- انظر بدء تشغيل الكاميرا للحصول على تفاصيل.

ميزات المعرض

الزر العائم

للانتقال بسرعة إلى الشاشة الرئيسية أثناء عرض المعرض في الاتجاه الأفقي، المس مع الاستمرار ◀، وحرك إصبعك لأعلى تجاه ●، ثم حرره.



- يمكنك تحريك موضع الزر العائم عن طريق سحبه أفقيًا إلى الجزء السفلي من الشاشة.

المحتوى ذو الصلة

يمكنك تعديل المحتوى ذي الصلة وتخصيصه في المعرض.

1 أثناء عرض معاينة صورة، اضغط .

2 عند ظهور الأيقونة المرتبطة بالتاريخ الذي التقطت فيه الصورة، اضغط على الشاشة.



- يمكنك عرض الصور المرتبطة بالتاريخ الذي اخترته.



- يمكن أن يكون المحتوى ذو الصلة مرتبطًا بما يصل إلى أربع مجموعات من "الذكريات، التاريخ، الأماكن، وضع الكاميرا".

- اضغط لحفظ المحتوى ذي الصلة كمقطع فيديو.
- اضغط ⋮ للوصول إلى الخيارات الإضافية.

إنشاء GIF

يمكنك إنشاء ملف GIF بسهولة باستخدام فيديو مُسجل.

1 في نقطة البدء المطلوبة أثناء مشاهدة الفيديو، اضغط ⋮ > **إنشاء GIF**.

2 حدد طول ملف GIF الذي تريد إنشاءه.

- يتم إنشاء ملف GIF للوقت المُحدد بدءًا من الوقت الحالي.
- بالنسبة لمقاطع الفيديو التي تقل عن 5 ثوان، يتم إنشاء صور GIF تلقائيًا للوقت المتبقي.

- ميزة إنشاء ملف GIF متوفرة؛ لتمكين المستخدم من إجراء نشاط ابتكاري. إذا قمت بانتهاك القوانين المتعلقة بحقوق النشر وقوانين التشهير باستخدام ميزة إنشاء ملف GIF، فربما ستكون تحت طائلة المساءلة المدنية والجنائية. تأكد من عدم تكرار أو نقل أعمال الآخرين دون إذنهم. لا تقبل شركة LG Electronics أن تتحمل أدنى مسؤولية عن أفعال المستخدم.

إنشاء تجميع لخلفيات الشاشة

يمكنك إنشاء صورة تجميع خاصة بك لعرضها كشاشة قفل.

يمكنك تحديد صور تجميع متعددة كخلفية شاشة تتغير في كل مرة تقوم فيها بتشغيل أو إيقاف الشاشة.

1 اضغط ◯ > **الإعدادات** > **إعدادات الشاشة** > **تأمين الشاشة** > **خلفية الشاشة** > **تجميع خلفيات الشاشة** .

2 اضغط + وحدد الصور التي ترغب في عرضها كصورة تجميع.

3 قم بتحرير عرض الشرائح حسب رغبتك واضغط **ضبط الخلفية**.



التعرّف على الوجه

معاينة التعرّف على الوجه

يمكنك تحرير قفل الشاشة باستخدام بيانات الوجه المحفوظة.

- قد تكون هذه الميزة حساسة جدًا في ما يتعلق بالأمان أكثر من أقفال الشاشة الأخرى مثل النقش و رمز PIN وكلمة المرور.
- عند استخدام وجه مشابه لوجهك أو صورة لك، يمكن تحرير قفل الشاشة.
- تكون بيانات الوجه التي تم التعرّف عليها مخزّنة بأمان في الجهاز.
- عند تحديد التعرّف على الوجه لقفل الشاشة، عليك إدخال النقش أو و رمز PIN أو كلمة المرور التي تم استخدامها لتسجيل الوجه من دون استخدام ميزة التعرّف على الوجه مباشرةً بعد تشغيل الجهاز. بناءً على ذلك، احرص على ألا تنسى القيمة المحددة.
- إذا تعذّر على الجهاز اكتشاف وجهك أو إذا نسيت القيمة المحددة للتسجيل، فيرجى زيارة أقرب مركز لخدمة العملاء من LG مع أخذ الجهاز معك وإبراز بطاقة التعريف.

الاحتياطات عند التعرّف على الوجه

قد تنخفض دقة التعرّف على الوجه في الحالات التالية. لزيادة دقته، تحقق مما يلي قبل استخدام الجهاز.

- إذا كان وجهك مغطىً بقبعة أو نظارات أو قناع أو إذا كانت ملامح وجهك مختلفة بشكل ملحوظ بسبب كثرة مستحضرات التجميل أو اللحية.
- إذا كانت هناك بصمات أصابع أو مواد غريبة على الجهة الأمامية لعدسة الكاميرا أو إذا تعذّر على الجهاز اكتشاف وجهك بسبب الضوء الساطع جدًا أو الظلام الحالك.

تسجيل بيانات الوجه

قبل استخدام ميزة التعرّف على الوجه، قم بتسجيل بيانات الوجه على الجهاز.

1 اضغط على ◯ > **الإعدادات** > **إعدادات الشاشة** > **تأمين الشاشة** > **إختر قفل الشاشة** > **السماح بـ بصمة الوجه**.

- لاستخدام هذه الميزة، يجب أن يكون قد تم ضبط قفل الشاشة باستخدام النقش أو رمز PIN أو كلمة مرور.
- عندما يكون قفل الشاشة غير مضبوط، سجّل البيانات باتباع التعليمات التي تظهر على الشاشة. راجع *إعداد قفل الشاشة* للحصول على التفاصيل.

2 ارفع الجهاز ليصبح مقابل عينيك.

3 سجّل وجهك باتباع التعليمات التي تظهر على الشاشة.

- سجّل وجهك في غرفة لا يكون فيها الضوء ساطع جدًا أو في غرفة مظلمة جدًا.
- ضع وجهك كله داخل خطوط الإرشاد على الشاشة، ثم قم بتعديل موضعه عبر تحريكه ببطء للأعلى أو الأسفل أو اليسار أو اليمين.

4 عند الانتهاء من تسجيل الوجه، اضغط على **موافق**.

إلغاء قفل الشاشة باستخدام وجهك

يمكنك تحرير قفل الشاشة باستخدام وجهك بدلاً من استخدام النقش أو رمز PIN أو كلمة المرور.

1 اضغط على ◯ > **الإعدادات** > **إعدادات الشاشة** > **تأمين الشاشة** > **إختر قفل الشاشة**.

2 ألغِ قفل الشاشة وفقًا للطريقة المحددة.

3 اسحب ◯ لتنشيط ميزة التعرّف على الوجه.

تحسين ميزة التعرّف على الوجه

يمكنك إضافة بيانات الوجه في ظروف مختلفة لتحسين التعرّف على الوجه.

1 اضغط على ◯ > **الإعدادات** > **إعدادات الشاشة** > **تأمين الشاشة** > **بصمة الوجه**.

2 ألغِ قفل الشاشة وفقًا للطريقة المحددة.

3 حدد **تحسين التعرّف على الوجه**.

4 سجّل وجهك باتباع التعليمات التي تظهر على الشاشة.

5 عند الانتهاء من تسجيل الوجه، اضغط على **موافق**.

حذف بيانات الوجه

يمكنك حذف بيانات الوجه المسجلة وتسجيلها مجددًا في حال لم تعمل ميزة التعرّف على الوجه بشكل صحيح.

1 اضغط على ◯ > **الإعدادات** > **إعدادات الشاشة** > **تأمين الشاشة** > **بصمة الوجه**.

2 ألغِ قفل الشاشة وفقًا للطريقة المحددة.

3 حدد **حذف بصمة الوجه** لحذف بيانات الوجه.

إلغاء قفل الشاشة باستخدام وجهك عندما تكون الشاشة متوقفة عن التشغيل

عندما تكون الشاشة متوقفة عن التشغيل، ارفع الجهاز وانظر إلى الجهة الأمامية من الشاشة. عندها، سيتمكن الجهاز من التعرّف على وجهك وبالتالي إلغاء قفل الشاشة.

لإلغاء تنشيط هذه الميزة، اتبع التعليمات أدناه.

1 اضغط على ◯ > **الإعدادات** > **إعدادات الشاشة** > **تأمين الشاشة** > **بصمة الوجه**.

2 ألغِ قفل الشاشة وفقًا للطريقة المحددة.

3 اسحب **السماح ببصمة الوجه عند إيقاف تشغيل الشاشة** ◯ لإلغاء تنشيط الميزة.

- تتوفر ميزة التعرّف على الوجه فقط عندما تكون الشاشة مقفلة.

إلغاء قفل الشاشة بالتعرّف على الوجه، ثم تمرير الإصبع عليها

عندما تكون الشاشة متوقفة عن التشغيل، يمكنك إلغاء قفلها عبر التعرّف على الوجه، ثم تمرير الإصبع عليها.

1 اضغط على ◯ > **الإعدادات** > **إعدادات الشاشة** > **تأمين الشاشة** > **بصمة الوجه**.

2 ألغِ قفل الشاشة وفقًا للطريقة المحددة.

3 اسحب **مرر إصبعك لإلغاء القفل بعد التعرّف على الوجه** ◯ لتنشيط الميزة.

تحسين ميزة التعرّف على الوجه

يمكنك منع إلغاء قفل الجهاز باستخدام الصور أو مقاطع الفيديو.

1 اضغط على ◯ > **الإعدادات** > **إعدادات الشاشة** > **تأمين الشاشة** > **بصمة الوجه**.

2 ألغِ قفل الشاشة وفقًا للطريقة المحددة.

3 اسحب **بصمة وجه متقدمة** ◯ لتنشيط الميزة.

- قد تنخفض سرعة التعرّف على الوجه عند تنشيط هذه الميزة.


ميزة تعدد المهام


النوافذ المتعددة

يمكنك استخدام تطبيقين في نفس الوقت من خلال فصل الشاشة إلى نوافذ متعددة.

بينما تستخدم أحد التطبيقات، المس مع الاستمرار ▢ من أزرار اللمس في الشاشة الرئيسية، ثم حدد تطبيقًا من قائمة التطبيقات المستخدمة حديثًا.

- يمكنك استخدام تطبيقين معروضين على الشاشة الرئيسية في الوقت نفسه.
- لإيقاف ميزة "النوافذ المتعددة"، المس مع الاستمرار ▣.





- ميزة النوافذ المتعددة غير مدعومة من جانب بعض التطبيقات بما في ذلك التطبيقات التي تم تنزيلها.

شاشة المعاينة

توفر شاشة المعاينة لك معاينة لتطبيقاتك المستخدمة حديثًا.

لعرض قائمة بالتطبيقات المستخدمة حديثًا، المس ▢ على الشاشة الرئيسية، ثم المس التطبيق المعروض.


- المس تطبيقًا مع الاستمرار واسحبه إلى أعلى الشاشة لبدء تشغيله من خلال النوافذ المتعددة. يمكنك أيضًا الضغط على ▣ في مقدمة كل تطبيق.

المشاركة السريعة

يمكنك مشاركة صورة أو فيديو باستخدام التطبيق الذي تريده مباشرةً بعد التقاط الصورة أو تسجيل الفيديو.

1 المس ◯ > لالتقاط صورة أو تسجيل فيديو.

2 المس أيقونة التطبيق التي تظهر على الشاشة للمشاركة باستخدام هذا التطبيق.
ويمكنك أيضًا سحب الأيقونة إلى الاتجاه المعاكس لرؤية التطبيقات الأخرى التي يمكنك استخدامها لمشاركة الصور ومقاطع الفيديو لديك.



• قد يختلف التطبيق الذي تعرضه أيقونة المشاركة السريعة تبعًا لنوع وتكرار الوصول إلى التطبيقات المثبتة على الجهاز.

02

الوظائف الأساسية

مكونات المنتج وملحقاته


العناصر التالية مرفقة مع جهازك.

- الجهاز
- سماعة الرأس استيريو
- كيبل USB
- الشاحن
- دليل البدء السريع
- دبوس الإخراج

- قد تكون العناصر المذكورة أعلاه اختيارية.
- قد تختلف العناصر المرفقة بالجهاز وأي ملحقات متوفرة وفقًا للمنطقة ومزود الخدمة.
- استخدم دائمًا ملحقات أصلية من إنتاج LG Electronics؛ فاستخدام ملحقات من إنتاج جهات تصنيع أخرى قد يؤثر على أداء الجهاز من حيث الاتصال مسببًا خللاً وظيفيًا. قد لا يتم تغطية هذا الأمر بواسطة خدمة الإصلاح الخاصة بشركة LG.

- إذا فقدت أيًا من هذه العناصر الأساسية، فاتصل بالوكيل الذي اشتريت منه جهازك.
- لشراء عناصر أساسية إضافية، اتصل بمركز خدمة عملاء LG.
- لشراء عناصر اختيارية، اتصل بمركز خدمة عملاء LG لمعرفة الموزعين الموجودين.
- بعض العناصر في صندوق المنتج عرضة للتغيير دون إشعار.
- مظهر الجهاز ومواصفاته عرضة للتغيير دون إشعار.
- قد تتباين مواصفات الجهاز تبعًا للمنطقة أو مزود الخدمة.
- تأكد من استخدام ملحقات أصلية من إنتاج LG Electronics. فاستخدام ملحقات من إنتاج أطراف أخرى قد يتسبب في تلف الجهاز أو حدوث خلل وظيفي.

نظرة عامة على الأجزاء



• مستشعر التقارب/الضوء المحيط

- مستشعر التقارب: أثناء إجراء مكالمة، يقوم مستشعر التقارب بإيقاف تشغيل الشاشة وتعطيل الوظائف التي تعمل باللمس عندما يكون الجهاز قريبًا من جسم بشري. ثم يعاود تشغيل الشاشة وتمكين وظائف اللمس عندما يكون الجهاز خارج نطاق معين.
- مستشعر الضوء المحيط: يقوم مستشعر الضوء المحيط بتحليل كثافة الضوء المحيط عند تشغيل وضع التحكم في السطوع التلقائي.

• مفاتيح مستوى الصوت

- لضبط مستوى صوت نغمات الرنين أو المكالمات أو الإشعارات.
- أثناء استخدام الكاميرا، اضغط برفق على مفتاح مستوى الصوت لالتقاط صورة. ولالتقاط صورًا متتابعة، اضغط مع الاستمرار على مفتاح مستوى الصوت.
- اضغط على مفتاح خفض مستوى الصوت مرتين (-) لتشغيل تطبيق الكاميرا عندما تكون الشاشة مقفلة أو تم إيقاف تشغيلها. واضغط على مفتاح رفع مستوى الصوت (+) مرتين لتشغيل +Capture.

• مفتاح القفل/التشغيل

- اضغط لفترة وجيزة على المفتاح عندما تريد تشغيل الشاشة أو إيقاف تشغيلها.
- اضغط مع الاستمرار على المفتاح عندما تريد تحديد خيار التحكم في الطاقة.

- إن هذا الجهاز مزوّد ببطارية غير قابلة للإزالة. لا تحاول إزالة الغطاء الخلفي.
- قد يتم تقييد الوصول إلى بعض الوظائف اعتمادًا على مواصفات الجهاز.
- لا تضع أجسامًا ثقيلة على الجهاز أو تجلس عليه. وقد يؤدي عدم الالتزام بذلك إلى تلف شاشة اللمس.
- قد تتداخل الملحقات أو الغطاء الذي يقي الشاشة مع مستشعر التقارب.
- إذا ابتل جهازك أو استُخدم في مكان رطب، فقد لا تعمل شاشة اللمس أو الأزرار بشكل مناسب.

التشغيل أو إيقاف التشغيل

التشغيل

عند إيقاف التشغيل، اضغط مع الاستمرار على مفتاح القفل/التشغيل.

- عند تشغيل الجهاز لأول مرة، فلابد من إجراء التكوين الأولي. وقد يستغرق التمهيد المبدئي وقتًا أطول من المعتاد.

إيقاف التشغيل

اضغط مع الاستمرار على مفتاح القفل/التشغيل، ثم حدد **إيقاف التشغيل**.

خيارات التحكم في الطاقة

اضغط مع الاستمرار على مفتاح القفل/التشغيل، ثم حدد خيارًا.


- **إيقاف التشغيل**: لإيقاف تشغيل الجهاز.
- **إيقاف تشغيل الطاقة وإعادة التشغيل**: لإعادة تشغيل الجهاز.
- **تشغيل وضع الرحلات الجوية**: لحظر الوظائف المرتبطة بالاتصالات عن بُعد، بما في ذلك إجراء المكالمات الهاتفية والمراسلات وتصفح الإنترنت. وستظل الوظائف الأخرى متوفرة.

تركيب بطاقة SIM


أدخل بطاقة SIM (وحدة تعريف المشترك) الموفرة بواسطة موفر الخدمة لديك لبدء استخدام جهازك.

- توخ الحذر عند استخدام دبوس الإخراج لأنه يحتوي على طرف حاد.


1 أدخل دبوس الإخراج في الفتحة الموجودة بدرج البطاقة.




2 اسحب درج البطاقة للخارج.



3 ضع بطاقة SIM بدرج البطاقة بحيث تكون الوصلات ذهبية اللون متجهة لأسفل.
ضع بطاقة SIM الرئيسية في درج بطاقة SIM رقم 1 وبطاقة SIM الثانوية في درج بطاقة SIM رقم 2.



4 أعد إدخال درج البطاقة في الفتحة.



- يدعم هذا الجهاز بطاقات Nano SIM فقط.
- لأداء خالٍ من المشكلات، يوصى باستخدام الجهاز مع نوع مناسب من بطاقات SIM. احرص دائمًا على استخدام بطاقات SIM المصممة بالمصنع والتي يقدمها المشغل.
- إذا أدخلت درج البطاقة في جهازك وهو مبلل، فقد يتسبب ذلك في تلف جهازك. تأكد دائمًا من أن درج البطاقة جاف.

احتياطات عند استخدام بطاقة SIM

- تجنب فقدان بطاقة SIM. فإن LG لا تتحمل أي مسؤولية عن الأضرار أو المشكلات الأخرى التي قد تحدث بسبب فقدان أو نقل بطاقة SIM.
- توخ الحذر من إتلاف بطاقة SIM عند إدخالها أو إخراجها.

إدخال بطاقة الذاكرة


أدخل بطاقة الذاكرة في جهازك.

يمكن للجهاز دعم بطاقة microSD تصل سعتها إلى 2 تيرابايت. وفقًا لنوع بطاقة الذاكرة والشركة المصنّعة لها، قد تكون بعض بطاقات الذاكرة غير متوافقة مع جهازك.

1 أدخل دبوس الإخراج في الفتحة الموجودة بدرج البطاقة.

2 اسحب درج البطاقة للخارج.

3 ضع بطاقة الذاكرة بدرج البطاقة بحيث تكون الوصلات ذهبية اللون متجهة لأسفل.



4 أعد إدخال درج البطاقة في الفتحة.

- قد لا تكون بعض بطاقات الذاكرة متوافقة بصورة كاملة مع الجهاز. إذا استخدمت بطاقة غير متوافقة، فقد تؤدي لإتلاف الجهاز أو بطاقة الذاكرة، أو لإتلاف البيانات المخزنة عليها.

- إن بطاقة الذاكرة عنصر اختياري يتم بيعه بشكل منفصل.
- قد تؤدي كتابة البيانات ومحوها بصورة متكررة إلى تقليل عمر بطاقات الذاكرة.

إخراج بطاقة الذاكرة

قم بإلغاء تحميل بطاقة الذاكرة قبل إخراجها للحفاظ على سلامتها.

1 المس ◯ > **الإعدادات** > **عامة** > **التخزين** > ⏏.

2 أدخل دبوس الإخراج في الفتحة الموجودة بدرج البطاقة.

3 اسحب درج البطاقة للخارج وقم بإخراج بطاقة الذاكرة.


⚠ • لا تخرج بطاقة الذاكرة أثناء قيام الجهاز بنقل المعلومات أو الوصول إليها. قد يؤدي هذا الأمر إلى فقد البيانات أو تلفها، أو إلى الإضرار ببطاقة الذاكرة أو الجهاز. LG غير مسؤولة عن الخسائر الناتجة عن سوء الاستخدام أو الاستخدام غير الصحيح لبطاقات الذاكرة، والتي تتضمن فقد البيانات.

البطارية

شحن البطارية

قبل استخدام الجهاز، اشحن البطارية تمامًا.

قم بتوصيل أحد طرفي كبل الشحن بالشاحن، وأدخل طرفه الآخر في المنفذ المخصص له، ثم قم بتوصيل الشاحن بمقبس كهربائي.



- يحظر الشحن عندما يكون الجهاز أو كبل الشحن مبللاً أو رطبًا. قد يتسبب ذلك في نشوب حريق أو حدوث صدمة كهربائية أو إصابة جسدية أو تلف الجهاز.
- تأكد من استخدام كبل USB المرفق مع جهازك.
- تأكد من استخدام كبل شحن وشاحن معتمد من إنتاج LG. وقد يؤدي شحن البطارية باستخدام شاحن من إنتاج طرف آخر إلى انفجارها أو تلف الجهاز.
- قد يؤدي استخدام الجهاز أثناء شحنه إلى التعرض لصدمة كهربائية. ولاستخدام الجهاز، توقف عن شحنه.
- إن هذا الجهاز مزوّد ببطارية غير قابلة للإزالة. لا تحاول إزالة الغطاء الخلفي.

- افصل الشاحن عن المقبس الكهربائي بعد اكتمال شحن الجهاز. فهذا يحول دون استهلاك الطاقة بشكل غير ضروري.
- هناك طريقة أخرى لشحن البطارية وهي بتوصيل كبل USB بين الجهاز والكمبيوتر المكتبي أو الكمبيوتر المحمول. قد تستغرق هذه الطريقة وقتًا أطول من توصيل المحول بمقبس التيار الكهربائي الجداري.
- لا تشحن البطارية باستخدام موزع USB غير قادر على الحفاظ على الفولتية المقدرة؛ فقد يفشل الشحن أو يتوقف دون قصد.

احتياطات عند استخدام الجهاز

- تأكد من عدم ملامسة أي جسم معدني أو مياه للمحيط الداخلي للجهاز.
- تأكد من استخدام كبل USB المتوفر، ولا تستخدم شواحن أو كبلات USB تابعة لجهات خارجية مع جهازك. ولا يشمل الضمان المحدود المقدم من شركة LG استخدام الملحقات التابعة لشركات أخرى.
- قد يؤدي عدم الالتزام بالإرشادات الواردة في هذا الدليل والاستخدام الصحيح إلى إتلاف الجهاز.

استخدام البطارية بشكل فعال

قد يقل عمر البطارية إذا احتفظت بالعديد من التطبيقات والوظائف قيد التشغيل في وقت واحد وباستمرار.

قم بإلغاء العمليات التي تتم في الخلفية لزيادة عمر البطارية.

لتقليل استهلاك البطارية، اتبع النصائح التالية:

- أوقف تشغيل **Bluetooth®** أو وظيفة شبكة Wi-Fi عند عدم استخدامهما.
- اضبط مهلة الشاشة على أقصر وقت ممكن.
- قم بتقليل سطوع الشاشة.


- قم بتعيين قفل الشاشة عند عدم استخدام الجهاز.
- تحقق من تفاصيل استخدام البطارية وأغلق أي تطبيقات يتم تنزيلها تؤدي إلى استنزاف البطارية.

شاشة اللمس

يمكنك الاطلاع على كيفية التحكم في جهازك باستخدام إيماءات شاشة اللمس.


اللمس

المس بطرف إصبعك برفق لتحديد تطبيق أو خيار أو تشغيله.




اللمس مع الاستمرار

المس مع الاستمرار لعدة ثوانٍ لعرض قائمة تتضمن خيارات متاحة.




الضغط المزدوج

المس مرتين بسرعة لتصغير صفحة ويب أو خريطة أو تكبيرها.




سحب

المس عنصرًا مع الاستمرار، كتطبيق أو عنصر واجهة استخدام، ثم حرّك إصبعك بثبات إلى موقع آخر. ويمكنك استخدام هذه الإيماءة لنقل عنصر.




السحب

المس الشاشة بإصبعك وحركها بسرعة دون إيقاف مؤقت. يمكنك استخدام هذه الإيماءة للتمرير عبر قائمة، وصفحة ويب، والصور، والشاشات، وغيرها.



ضم الإصبعين وفردهما

ضم إصبعيك لتصغير صورة أو خريطة. وللتكبير، قم بفردهما.



- لا تعرِّض شاشة اللمس لصدمة مادية شديدة؛ فقد يتلف بسببها مستشعر اللمس.

- قد تتعطل شاشة اللمس إذا استخدمت الجهاز بالقرب من مواد موصلة أو معدنية أو ممغنطة.
- إذا استخدمت الجهاز في وجود أضواء ساطعة، كضوء الشمس المباشر، فقد لا تكون الشاشة مرئية تبعًا لموضعك. واستخدم الجهاز في موقع به ظل أو مكان ذي إضاءة غير ساطعة جدًا أو ساطعة بمقدار يكفي لقراءة الكتب.
- لا تضغط على الشاشة بشدة.
- المس الخيار الذي تريده بطرف إصبعك برفق.
- قد لا يعمل التحكم في اللمس بطريقة صحيحة عند لمس الشاشة أثناء ارتداء قفاز أو باستخدام طرف ظفرك.
- قد لا يعمل التحكم في اللمس بشكل مناسب إذا كانت الشاشة رطبة أو مبتلة.
- قد لا تعمل شاشة اللمس بطريقة صحيحة إذا كان الغطاء الذي يقيها أو الملحق الذي تم شرائه من متجر عام عادي أو على الإنترنت متصلاً بالجهاز.
- قد يؤدي عرض صورة ثابتة لفترات زمنية طويلة إلى ظهور صور تلوية أو احتراق الصورة. أوقف تشغيل الشاشة عند عدم استخدام الجهاز لفترة طويلة.

الشاشة الرئيسية

نظرة عامة على الشاشة الرئيسية

الشاشة الرئيسية هي نقطة البداية التي من خلالها يمكنك الوصول إلى مختلف الوظائف والتطبيقات على جهازك. المس ◯ على أي شاشة للانتقال مباشرةً إلى الشاشة الرئيسية.

يمكنك إدارة جميع التطبيقات وعناصر واجهة الاستخدام من الشاشة الرئيسية. اسحب الشاشة ناحية اليسار أو اليمين لعرض جميع التطبيقات المثبتة في الحال.

تخطيط الشاشة الرئيسية

يمكنك عرض جميع التطبيقات وتنظيم عناصر واجهة الاستخدام والمجلدات في الشاشة الرئيسية.



- قد تختلف الشاشة الرئيسية تبعًا لاختلاف مزود الخدمة أو إصدار البرنامج.

- **شريط الحالة**: لعرض رموز الحالات والوقت ومستوى البطارية.
- **عنصر واجهة استخدام للطقس**: اعرض معلومات الطقس والوقت لمنطقة معيّنة.
- **عنصر واجهة استخدام للبحث في Google**: تمكّن من إجراء البحث في Google عن طريق إدخال كلمات أساسية منطوقة أو مكتوبة.

- **مجلد**: لإنشاء المجلدات وتجميع التطبيقات وفقًا لتفضيلاتك.
- **أيقونة الصفحة**: اعرض العدد الإجمالي للّوحات الشاشة الرئيسية. المس أيقونة الصفحة المطلوبة للانتقال إلى الصفحة التي حددتها. ويتم تمييز الأيقونة التي تعكس اللوحة الحالية.
- **منطقة الوصول السريع**: لتثبيت التطبيقات الرئيسية أسفل الشاشة حتى يمكن الوصول إليها من أي صفحة من صفحات الشاشة الرئيسية.
- **أزرار اللمس في الشاشة الرئيسية**


- ◁ : للعودة إلى الشاشة السابقة. أغلق لوحة المفاتيح أو النوافذ المنبثقة.
- ○ : المسه للانتقال إلى الشاشة الرئيسية. لتشغيل البحث في Google، المس مع الاستمرار.
- □ : المس لعرض قائمة بالتطبيقات المستخدمة مؤخرًا أو لتشغيل تطبيق من القائمة. لحذف جميع التطبيقات المستخدمة مؤخرًا، المس **مسح الكل**. لاستخدام تطبيقين في نفس الوقت من خلال ميزة النوافذ المتعددة، المس الأيقونة مع الاستمرار أثناء استخدام تطبيق.
- : اختر بطاقة SIM التي سوف تستخدمها. اضغط مع الاستمرار لتكوين إعدادات بطاقة SIM ثنائية.

تحرير أزرار اللمس بالشاشة الرئيسية

يمكنك إعادة ترتيب أزرار اللمس بالشاشة الرئيسية أو إضافة الوظائف متكررة الاستخدام إلى منطقة أزرار اللمس بالشاشة الرئيسية.

المس ○ > **الإعدادات** > **إعدادات الشاشة** > **أزرار اللمس في الشاشة الرئيسية** > **مجموعة الأزرار** وقم بتخصيص الإعدادات.

- تتوفر العديد من الوظائف، مثل لوحة الإشعارات و+Capture. ويمكن إضافة خمسة عناصر كحد أقصى.



رموز الحالة

في حالة وجود إشعار لرسالة غير مقروءة أو حدث بالتقويم أو تنبيه، يعرض شريط الحالة رمز الإشعار المقابل. ويمكنك التحقق من حالة الجهاز عن طريق عرض رموز الإشعارات المعروضة على شريط الحالة.


	لا توجد إشارة
	جاري إرسال البيانات عبر الشبكة
	تم ضبط التنبيه
	وضع الاهتزاز قيد التشغيل
	Bluetooth قيد التشغيل
	الاتصال بالكمبيوتر من خلال USB
	مستوى البطارية
	وضع الرحلات الجوية فعال
	المكالمات الفائتة
	Wi-Fi متصل
	الوضع "صامت" قيد التشغيل
	GPS قيد التشغيل
	نقطة الاتصال الفعّالة قيد التشغيل
	لا توجد بطاقة SIM

- قد تظهر بعض هذه الرموز بشكل مختلف أو لا تظهر على الإطلاق تبعًا لحالة الجهاز. راجع الرموز وفقًا للبيئة الفعلية والمنطقة التي تستخدم بها الجهاز وموفر الخدمة لديك.
- قد تختلف الرموز المعروضة تبعًا للمنطقة أو مزودي الخدمات.

لوحة الإشعارات

يمكنك فتح لوحة الإشعارات عن طريق سحب شريط الحالة لأسفل بالشاشة الرئيسية.

- لفتح قائمة أيقونات الوصول السريع، اسحب لوحة الإشعارات لأسفل أو المس ⌄.
- لإعادة ترتيب الأيقونات أو إضافتها أو إزالتها، المس **تحرير**.
- إذا لمست الرمز مع الاستمرار، فستظهر شاشة الإعدادات الخاصة بالوظيفة المقابلة.



تبديل اتجاه الشاشة

يمكنك ضبط اتجاه الشاشة ليتغير تلقائيًا وفقًا للاتجاه الفعلي للجهاز.

من لوحة الإشعارات، المس **تدوير الشاشة تلقائيا** من قائمة رموز الوصول السريع.

أو بدلاً من ذلك إلمس ◯ > **الإعدادات** > **إعدادات الشاشة** وقم بتنشيط **تدوير الشاشة تلقائياً**.




تحرير الشاشة الرئيسية

في الشاشة الرئيسية، المس مساحة فارغة مع الاستمرار، ثم حدد الإجراء المطلوب من بين الإجراءات أدناه.

- لإعادة ترتيب صفحات الشاشة الرئيسية، المس إحدى اللوحات مع الاستمرار ثم اسحبها إلى موضع آخر.
- لإضافة عناصر واجهة استخدام إلى الشاشة الرئيسية، المس مع الاستمرار منطقة فارغة بالشاشة الرئيسية، ثم حدد **عناصر واجهة الاستخدام**.
- لتغيير سمة، المس مع الاستمرار منطقة فارغة بالشاشة الرئيسية، ثم حدد **سمة**.

  أو بدلاً من ذلك إلمس ◯ > **الإعدادات** > **إعدادات الشاشة** > **سمة**، ثم حدد سمة تنطبق على الجهاز.

- لتكوين إعدادات الشاشة الرئيسية، المس مع الاستمرار منطقة فارغة بالشاشة الرئيسية، ثم حدد **إعدادات الشاشة الرئيسية**. انظر إعدادات الشاشة الرئيسية لمعرفة التفاصيل.
- لعرض التطبيقات التي تم إلغاء تثبيتها أو مُعاد تثبيتها، المس مع الاستمرار في اللمس أي منطقة فارغة بالشاشة الرئيسية، ثم حدد **مهملات التطبيقات**. انظر مهملات التطبيقات لمعرفة التفاصيل.
- لتغيير الشاشة الافتراضية، المس مع الاستمرار منطقة فارغة من الشاشة الرئيسية، وانتقل إلى الشاشة المطلوبة، ثم اضغط ، ثم اضغط الشاشة مرة أخرى.




عرض الخلفية

يمكنك عرض فقط صورة الخلفية عن طريق إخفاء التطبيقات وعناصر واجهة الاستخدام بالشاشة الرئيسية.

افرد إصبعيك على الشاشة الرئيسية.

- للرجوع إلى الشاشة الأصلية التي تظهر بها التطبيقات وعناصر واجهة الاستخدام، قم بضم إصبعيك على الشاشة الرئيسية أو المس ◁.



تحريك التطبيقات على الشاشة الرئيسية

على الشاشة الرئيسية، المس أحد التطبيقات مع الاستمرار ثم اسحبه إلى موضع آخر.

- للاحتفاظ بالتطبيقات الأكثر استخدامًا أسفل الشاشة الرئيسية، المس أحد التطبيقات مع الاستمرار ثم اسحبه إلى قسم منطقة الوصول السريع الموجودة بالأسفل.
- لإزالة رمز من منطقة الوصول السريع، اسحبه إلى الشاشة الرئيسية.

استخدام المجلدات من الشاشة الرئيسية

إنشاء مجلدات

على الشاشة الرئيسية، المس أحد التطبيقات مع الاستمرار ثم اسحبه فوق تطبيق آخر.

- يتم إنشاء مجلد جديد وإضافة التطبيقات إليه.

تحرير المجلدات

في الشاشة الرئيسية، المس مجلدًا ثم قم بأحد الإجراءات التالية.

- لتحرير اسم المجلد ولونه، المس اسم المجلد.
- لإضافة تطبيقات، المس تطبيقًا مع الاستمرار، ثم اسحبه إلى المجلد وقم بتحريره.
- لإزالة تطبيق من المجلد، المس التطبيق مع الاستمرار ثم اسحبه إلى خارج المجلد. إذا كان التطبيق الذي تم إزالته هو التطبيق الوحيد الموجود في المجلد، فيتم إزالة المجلد تلقائيًا.
- يمكنك أيضًا إضافة تطبيقات أو إزالتها بعد لمس + في المجلد.

إعدادات الشاشة الرئيسية

يمكنك تخصيص إعدادات الشاشة الرئيسية.

1 المس ◯ > **الإعدادات** > **إعدادات الشاشة** > **الشاشة الرئيسية**.

2 قم بتخصيص الإعدادات التالية:

- **تحديد الشاشة الرئيسية**: لتحديد وضع الشاشة الرئيسية.
- **خلفية الشاشة**: لتغيير خلفية الشاشة الرئيسية.
- **تأثيرات الشاشة**: لتحديد تأثير لتطبيقه عند تغيير صفحة الشاشة الرئيسية.
- **أشكال الرمز**: اختر ما إذا كنت تريد الأيقونات بحواف مربعة أم دائرية.
- **فرز التطبيقات حسب**: لضبط كيفية فرز التطبيقات في الشاشة الرئيسية.
- **الشبكة**: لتغيير وضع ترتيب التطبيقات بالشاشة الرئيسية.
- **إخفاء التطبيقات**: حدد التطبيقات التي تريد إخفاءها من الشاشة الرئيسية.
- **تكرار حلقي مستمر**: يسمح بالتمرير المستمر للشاشة الرئيسية (التكرار مرة أخرى إلى الشاشة الأولى بعد الوصول إلى الشاشة الأخيرة).
- **بحث**: البحث عن طريق سحب الشاشة الرئيسية لأسفل.

قفل الشاشة

نظرة عامة على قفل الشاشة

تتوقف شاشة الجهاز عن التشغيل وتغلق نفسها إذا ضغطت على مفتاح القفل/التشغيل.
ويحدث هذا أيضًا بعد ترك الجهاز خاملاً لفترة زمنية محددة.
إذا ضغطت على مفتاح القفل/التشغيل عند عدم ضبط قفل الشاشة، فستظهر الشاشة الرئيسية تلقائيًا.
لضمان الأمان ولمنع الوصول غير المرغوب فيه إلى جهازك، اضبط قفل الشاشة.

- يحول قفل الشاشة دون إدخال أية بيانات غير ضرورية بفعل لمس شاشة الجهاز؛ نوصي بتنشيط قفل الشاشة عند عدم استخدام الجهاز.

إعداد قفل الشاشة

تتوفر العديد من الخيارات لتكوين إعدادات قفل الشاشة.

1 المس ◯ > **الإعدادات** > **إعدادات الشاشة** > **تأمين الشاشة** > **إختر قفل الشاشة** ثم حدد الطريقة التي تفضلها.

2 قم بتخصيص الإعدادات التالية:

- **بلا**: لإلغاء تنشيط وظيفة قفل الشاشة.
- **مسح**: اسحب على الشاشة لفتح قفل الشاشة.
- **النقش**: ارسم نقشاً لفتح قفل الشاشة.
- **رمز PIN**: أدخل كلمة مرور رقمية لفتح قفل الشاشة.
- **كلمة المرور**: أدخل كلمة مرور رقمية أبجدية لفتح قفل الشاشة.
- **السماح بـ بصمة الوجه**: لإلغاء قفل الشاشة عبر التعرّف على الوجه.

- إذا حاولت فتح قفل الجهاز بصورة غير صحيحة 5 مرات، فسيتم منع تشغيل الشاشة لمدة 30 ثانية.

إعدادات بدء تشغيل آمن

عند تحديد النقش أو رمز PIN أو كلمة المرور كطريقة قفل الشاشة، فيمكنك تكوين الجهاز ليتم قفله في أي وقت يتم فيه فتح الجهاز لغرض تأمين البيانات.

- ولا يمكنك استخدام أي وظيفة من وظائف الجهاز باستثناء الاتصال بخدمات الطوارئ حتى تقوم أنت بإلغاء قفل الجهاز.
- في حالة نسيان كلمة مرور فك التشفير، فلا يمكنك استعادة البيانات المشفَّرة والمعلومات الشخصية.

إعدادات قفل الشاشة

يمكنك تخصيص إعدادات قفل الشاشة التالية.

1 المس ◯ > **الإعدادات** > **إعدادات الشاشة** > **تأمين الشاشة**.

2 قم بتخصيص الإعدادات التالية:

- **إختر قفل الشاشة**: لتحديد طريقة قفل الشاشة.
- **بصمة الوجه**: لإلغاء قفل شاشة القفل عبر التعرّف على الوجه. راجع التعرّف على الوجه للحصول على التفاصيل.
- **Smart Lock**: حدد عناصر موثوق بها وبالتالي في حالة حدوث واحد منها، يتم فتح قفل الجهاز تلقائيًا.
- **خلفية الشاشة**: قم بتغيير خلفية شاشة القفل.
- **الساعة**: حدد موضع الساعة على الشاشة المقفلة.
- **اختصارات**: لإضافة اختصار تطبيق ومن ثمّ الوصول إليه مباشرة من شاشة القفل بعد سحب اختصار التطبيق بالشاشة.
- **تأثيرات الشاشة**: لتعيين تأثيرات التنقل عبر الشاشة المطلوب تطبيقها عند فتح قفل الشاشة.
- **معلومات الاتصال للهاتف المفقود**: لعرض معلومات جهة الاتصال بالطوارئ على شاشة القفل.
- **مؤقت الاغلاق**: لتعيين الفترة الزمنية للخمول التي يتم بعدها قفل الجهاز تلقائيًا.
- **يقفل زر الطاقة على الفور**: لقفل الشاشة فور الضغط على مفتاح القفل/التشغيل.

- قد تختلف عناصر الإعداد المتوفرة تبعًا لطريقة قفل الشاشة المحددة.

تشغيل الشاشة

يمكنك تشغيل الشاشة أو إيقاف تشغيلها عن طريق لمسها مرتين.

- لا يتوفر هذا الخيار إلا على الشاشة الرئيسية التي تقدمها LG. وقد لا تعمل بشكل مناسب على مشغل مخصص أو على الشاشة الرئيسية المثبتة بواسطة المستخدم.
- استخدم طرف إصبعك عند لمس الشاشة. ولا تستخدم ظفرك.
- لاستخدام ميزة تشغيل/ أيقاف الشاشة، تأكد من عدم حظر مستشعر التقارب/الضوء بملصق أو بأية مادة غريبة أخرى.

تشغيل الشاشة

المس الشاشة من المنتصف مرتين.

- قد يؤدي لمس الجزء العلوي أو السفلي من الشاشة إلى خفض معدل التعرف.

إيقاف تشغيل الشاشة

اضغط مرتين على المساحة الفارغة بالشاشة الرئيسية وشاشة القفل.

بدلاً من ذلك، المس مرتين مساحة فارغة على شريط الحالة.

تشفير بطاقة الذاكرة

يمكنك تشفير البيانات المحفوظة على بطاقة الذاكرة وحمايتها. لا يمكن الوصول إلى البيانات المشفرة في بطاقة الذاكرة من جهاز آخر.

1 المس ◯ > **الإعدادات** > **عامة** > **الحماية** > **تشفير وحدة تخزين بطاقة SD**.

2 اقرأ النظرة العامة المعروضة على الشاشة والخاصة بتشفير بطاقة الذاكرة ثم المس **إستمرار** للمتابعة.

3 حدد خيارًا ثم المس **التشفير**.

- **تشفير ملف جديد**: لتشفير البيانات المحفوظة على بطاقة الذاكرة فقط بعد تشفيرها.
- **التشفير الكامل** : لتشفير جميع البيانات المحفوظة حاليًا على بطاقة الذاكرة.
- **استثناء ملفات الوسائط**: لتشفير جميع الملفات، باستثناء ملفات الوسائط كالموسيقى والصور ومقاطع الفيديو.

- لتشفير بطاقة الذاكرة، تأكد من تعيين قفل الشاشة باستخدام رمز PIN أو كلمة مرور.
- بمجرد بدء تشفير بطاقة الذاكرة، تصبح بعض الوظائف غير متاحة.
- إذا تم إيقاف تشغيل الجهاز أثناء تقدم التشفير، فستفشل عملية التشفير، وقد تتلف بعض البيانات. ولذلك، تحقق من أن مستوى طاقة البطارية كافٍ قبل بدء التشفير.
- لا يمكن الوصول إلى الملفات المشفرة إلا من الجهاز الذي شُفِّرَت به.
- لا يمكن استخدام بطاقة الذاكرة المشفرة على جهاز آخر من إنتاج LG. قم بتهيئة بطاقة الذاكرة المشفرة لاستخدامها على هاتف محمول آخر.
- يمكنك تنشيط تشفير وحدة تخزين بطاقة SD حتى في حالة عدم تركيب بطاقة الذاكرة في الجهاز. أي بطاقة ذاكرة يتم تركيبها بعد تنفيذ عملية التشفير، سيتم تشفيرها تلقائيًا.

أخذ لقطات شاشة

يمكنك التقاط صورًا للشاشة الحالية التي تستعرضها.

عبر اختصار

اضغط مع الاستمرار على مفتاح القفل/التشغيل ومفتاح خفض مستوى الصوت (-) في الوقت نفسه لمدة ثانيتين على الأقل.

- يمكن عرض لقطات الشاشة من مجلد **Screenshots** الموجود في **المعرض**.

عبر +Capture

في الشاشة حيث تريد أخذ لقطة شاشة، اسحب شريط الحالة لأسفل، ثم المس .

- عند إيقاف تشغيل الشاشة أو قفلها، يمكنك الوصول إلى **+Capture** بالضغط على مفتاح رفع مستوى الصوت (+) مرتين. لاستخدام هذه الميزة، المس ◯ > **الإعدادات** > **عامة** ثم قم بتشغيل **مفتاح الاختصار**.
- انظر كتابة ملاحظات على لقطة الشاشة لمعرفة التفاصيل.

إدخال نص


استخدام Smart keyboard

يمكنك استخدام Smart keyboard لإدخال نص وتحريره.

يمكنك استخدام Smart keyboard لعرض نص أثناء الكتابة دون الحاجة إلى التبديل بين الشاشة ولوحة المفاتيح التقليدية. ويتيح لك هذا العثور على الأخطاء بسهولة وتصحيحها عند الكتابة.

نقل المؤشر

يمكنك استخدام Smart keyboard لنقل المؤشر إلى الموضع الذي تريده. عند كتابة نص، المس مع الاستمرار مفتاح المسافة، ثم اسحب لليمين أو اليسار.




- قد لا يتم دعم هذه الوظيفة في بعض اللغات.

اقتراح كلمات

تقوم Smart keyboard تلقائيًا بتحليل أنماط الاستخدام لاقتراح الكلمات التي يتكرر استخدامها أثناء الكتابة. وكلما طال استخدامك للجهاز، كانت الاقتراحات أكثر دقة.

أدخل النص، ثم المس إحدى الكلمات المقترحة أو اسحب الجانب الأيمن أو الأيسر من لوحة المفاتيح إلى أعلى برفق.

- يتم إدخال الكلمة المحددة تلقائيًا، ولذا فإنك لست بحاجة إلى كتابة كل حرف من الكلمة يدويًا.




تغيير تخطيط لوحة مفاتيح الهاتف

يمكنك إضافة مفاتيح أو حذفها أو إعادة ترتيبها بالصف السفلي من لوحة المفاتيح.

1 المس ◯ > **الإعدادات** > **عامة** > **اللغة ولوحة المفاتيح** > **لوحة مفاتيح LG** > **ارتفاع وتخطيط لوحة المفاتيح** > **تخطيط لوحة مفاتيح الهاتف**.

بدلاً من ذلك، المس ⋮ على لوحة المفاتيح ثم المس **ارتفاع وتخطيط لوحة المفاتيح** > **تخطيط لوحة مفاتيح الهاتف**.

2 المس مفتاحًا بالصف السفلي، ثم اسحبه إلى موضع آخر.




- لا يتوفر هذا الخيار إلا على لوحات مفاتيح QWERTY و QWERTZ و AZERTY.
- قد لا يتم دعم هذه الوظيفة في بعض اللغات.

تخصيص ارتفاع لوحة المفاتيح

يمكنك تخصيص ارتفاع لوحة المفاتيح لإضفاء مزيد من الراحة على يديك أثناء الكتابة.

1 المس ◯ > **الإعدادات** > **عامة** > **اللغة ولوحة المفاتيح** > **لوحة مفاتيح LG** > **ارتفاع وتخطيط لوحة المفاتيح** > **ارتفاع لوحة المفاتيح**.
بدلاً من ذلك، المس ⋯ على لوحة المفاتيح ثم المس **ارتفاع وتخطيط لوحة المفاتيح** > **ارتفاع لوحة المفاتيح**.

2 اضبط ارتفاع لوحة المفاتيح.



تحديد وضع لوحة المفاتيح الأفقي

يمكنك تحديد وضع لوحة المفاتيح الأفقي من بين العديد من الخيارات.

1 المس ◯ > **الإعدادات** > **عامة** > **اللغة ولوحة المفاتيح** > **لوحة مفاتيح LG** > **ارتفاع وتخطيط لوحة المفاتيح** > **نوع لوحة المفاتيح في العرض الأفقي**.
بدلاً من ذلك، المس ⋯ على لوحة المفاتيح ثم المس **ارتفاع وتخطيط لوحة المفاتيح** > **نوع لوحة المفاتيح في العرض الأفقي**.

2 حدد وضع لوحة مفاتيح.

تقسيم لوحة المفاتيح

يمكنك تقسيم لوحة المفاتيح إلى جزأين ووضع أحدهما على أحد جانبي الشاشة عندما تكون الشاشة في وضع أفقي.

المس ◯ > **الإعدادات** > **عامة** > **اللغة ولوحة المفاتيح** > **لوحة مفاتيح LG** > **ارتفاع وتخطيط لوحة المفاتيح** > **تقسيم لوحة المفاتيح**.

بدلاً من ذلك، المس ⋯ على لوحة المفاتيح ثم المس **ارتفاع وتخطيط لوحة المفاتيح** > **تقسيم لوحة المفاتيح**.

- قم بتدوير الجهاز إلى الوضع الأفقي لتقسيم لوحة المفاتيح على الجانبين. لدمج أو فصل لوحة المفاتيح، ضم إصبعيك أو قم بفردهما على لوحة المفاتيح.



وضع التشغيل بيد واحدة

يمكنك نقل لوحة المفاتيح إلى أحد جانبي الشاشة حتى يمكنك استخدامها بيد واحدة.

1 المس ◯ > **الإعدادات** > **عامة** > **اللغة ولوحة المفاتيح** > **لوحة مفاتيح LG** > **ارتفاع وتخطيط لوحة المفاتيح** > **تشغيل بيد واحدة**.

بدلاً من ذلك، المس ⋯ على لوحة المفاتيح ثم المس **ارتفاع وتخطيط لوحة المفاتيح** > **تشغيل بيد واحدة**.

2 اضغط على السهم المعروض بجوار لوحة المفاتيح لنقلها في الاتجاه الذي تريده.



إدخال نص باستخدام صوت

في لوحة المفاتيح، المس ⋯ مع الاستمرار ثم حدد .

- لتحسين التعرف على أوامر الصوت، تحدث بوضوح.
- لإدخال نص باستخدام الصوت، تأكد من أن جهازك متصل بشبكة.
- لتحديد اللغة المخصصة لميزة التعرف على الصوت، المس > **اللغات** في شاشة التعرف على الصوت.
- قد لا يتم دعم هذه الوظيفة، أو ربما تختلف اللغات المدعومة وفقًا لمنطقة الخدمة.

إضافة لغات إلى لوحة المفاتيح

يمكنك توفير لغات إضافية للإدخال في لوحة المفاتيح.

1 المس ◯ > **الإعدادات** > **عامة** > **اللغة ولوحة المفاتيح** > **لوحة مفاتيح LG** > **تحديد اللغات**.

2 حدد اللغات التي تريد جعلها متوفرة.

النسخ واللصق

يمكنك قص أو نسخ نص من تطبيق، ثم تلصقه بعد ذلك في التطبيق نفسه. أو، يمكنك تشغيل تطبيقات أخرى ولصق النص فيها.

1 المس مع الاستمرار حول النص الذي تريد نسخه أو لصقه.

2 اسحب / لتحديد المنطقة المطلوب النسخ أو القص بها.

3 حدد إما **قص** أو **نسخ**.

- تتم إضافة النص المقصوص أو المنسوخ إلى الحافظة تلقائيًا.

4 المس مع الاستمرار نافذة إدخال النص، ثم حدد **إلصاق**.

- في حالة عدم وجود عنصر لقصه أو نسخه، لن يظهر خيار **إلصاق**.

Clip Tray

إذا قمت بنسخ أو قص صورة أو نص، فسيتم حفظه تلقائيًا بـ Clip Tray ويمكن لصقه بمكان آخر في أي وقت.

1 في لوحة المفاتيح، المس ⚙ مع الاستمرار ثم حدد 📋.
بدلاً من ذلك، المس نافذة إدخال النص مع الاستمرار، ثم حدد **CLIP TRAY**.

2 حدد عنصرًا من Clip Tray ثم قم بلصقه.

- يمكن حفظ 20 عنصرًا كحد أقصى بـ Clip Tray.
- المس 📌 لقفل العناصر المحفوظة كي لا يتم حذفها حتى عند تجاوز الكمية القصوى. ويمكن قفل عشرة عناصر كحد أقصى. ولحذف العناصر المقفلة، افتح قفلها أولاً.
- المس 🗑 لحذف العناصر المحفوظة بـ Clip Tray.

- قد لا يتم دعم clip tray بواسطة بعض التطبيقات التي يتم تنزيلها.

عدم الإزعاج

يمكنك تحديد الإشعارات أو كتمها لتجنب الإزعاج لفترة زمنية محددة.

1 المس ◯ > **الإعدادات** > **الصوت و الإشعار** > **عدم الإزعاج** وبعد ذلك اسحب ⬭ لتنشيط هذه الميزة.

2 المس **الأصوات والاهتزازات** وحدد الوضع الذي تريده:

- **الأولوية فقط**: لتلقي إشعارات بالاهتزاز أو الصوت لتطبيقات محددة. حتى في حالة تشغيل الأولوية فقط، تظل التنبيهات مسموعة.
- **الصمت التام**: لتعطيل كل من الصوت والاهتزاز.

03

التطبيقات المفيدة

تثبيت التطبيقات وإزالة تثبيتها

تثبيت التطبيقات

يمكنك الوصول إلى متجر التطبيقات للبحث عن تطبيقات وتنزيلها.

- يمكنك استخدام SmartWorld أو متجر Play أو متجر التطبيقات المتوفر لدى مزود الخدمة.

- قد تتطلب بعض متاجر التطبيقات أن يتم إنشاء حساب وتسجيل الدخول من خلاله.
- قد تتطلب بعض التطبيقات دفع رسوم.
- إذا استخدمت بيانات الهاتف المحمول، فقد يتم فرض رسوم على استخدامها تبعًا لخطة التسعير.
- قد لا يتم دعم SmartWorld تبعًا للمنطقة أو مزود الخدمة.

إزالة تثبيت التطبيقات

يمكنك إزالة تثبيت التطبيقات التي لم تعد بحاجة إلى استخدامها من جهازك.

إزالة التثبيت بإيماءة اللمس مع الاستمرار

على الشاشة الرئيسية، المس التطبيق مع الاستمرار لإزالة تثبيته، ثم اسحبه باتجاه **حذف** في أعلى الشاشة.

يمكنك لمس التطبيق مع الاستمرار ثم تحريره، ومن ثم اضغط ⊗ لإلغاء التثبيت.

- إذا كان إلغاء تثبيت التطبيقات قد تم في غضون 24 ساعة بدءًا من الآن، فيمكنك إعادة تثبيتها. انظر مهملات التطبيقات لمعرفة التفاصيل.

إزالة التثبيت باستخدام قائمة الإعدادات

المس ◯ > **الإعدادات** > **عامة** > **التطبيقات** وحدد تطبيقًا، ثم المس **إلغاء التثبيت**.

إزالة تثبيت التطبيقات من متجر التطبيقات

لإزالة تثبيت أحد التطبيقات، يمكنك الوصول إلى متجر التطبيقات الذي قمت بتنزيل التطبيق منه ثم إزالة تثبيته.

- لا يمكن إزالة تثبيت بعض التطبيقات بواسطة المستخدمون.

مهملات التطبيقات

يمكنك عرض التطبيقات التي تم إلغاء تثبيتها في الشاشة الرئيسية. يمكنك أيضًا إعادة تثبيت التطبيقات التي تم إلغاء تثبيتها خلال 24 ساعة من الآن.

1 اضغط ◯ > **الإدارة** > **مهملات التطبيقات**.

يمكنك لمس منطقة فارغة من الشاشة الرئيسية مع الاستمرار، ومن ثم اضغط **مهملات التطبيقات**.

2 قم بتنشيط الوظيفة التي تريدها:

- **استعادة**: لإعادة تثبيت التطبيق المحدد.
- 🗑 : لإزالة التطبيقات التي تم إلغاء تثبيتها بصفة دائمة من الجهاز.

- يتم إزالة التطبيقات تلقائيًا التي تم إلغاء تثبيتها من الجهاز بعد 24 ساعة من إلغاء تثبيتها. إذا أردت إعادة تثبيت التطبيقات التي تم إلغاء تثبيتها، يجب عليك تنزيلها مرة أخرى من متجر التطبيقات.
- يتم تنشيط هذه الميزة في الشاشة الرئيسية الافتراضية فقط. إذا قمت بإلغاء تثبيت تطبيقات أثناء استخدام شاشة EasyHome أو مشغل تطبيقات آخر، يتم إزالتها على الفور وبصفة دائمة من الجهاز.

الهاتف

المكالمة الصوتية

قم بإجراء مكالمة هاتفية باستخدام إحدى الطرق المتوفرة، كإدخال رقم هاتف يدويًا وإجراء مكالمة من قائمة الأسماء أو قائمة المكالمات الأخيرة.

إجراء مكالمة من لوحة الاتصال

1 المس ◯ > > **اتصال**.

2 قم بإجراء مكالمة باستخدام طريقة من اختيارك:

- أدخل رقم هاتف ثم المس .
- المس رقم الاتصال السريع مع الاستمرار.
- ابحث عن اسم عن طريق لمس الحرف الأول من الاسم الموجود في قائمة الاسماء، ثم المس .

- لإدخال "+" عند إجراء مكالمة دولية، المس الرقم 0 مع الاستمرار.
- انظر إضافة اسماء لمعرفة تفاصيل كيفية إضافة أرقام الهاتف إلى قائمة الاتصال السريع.

إجراء مكالمة من قائمة الاسماء

1 المس ◯ > > **الاسماء**.

2 من قائمة الاسماء، حدد اسم ثم المس .

الرد على مكالمة

للرد على مكالمة، اسحب في شاشة المكالمات الواردة.

- عندما تكون سماعة الرأس استيريو متصلة، يمكنك إجراء المكالمات باستخدام زر الاتصال/الإنهاء الموجود بسماعة الرأس.
- لإنهاء مكالمة بالضغط على مفتاح القفل/التشغيل، اضغط ◯ > **الإعدادات** > **الشبكات** > **إعدادات المكالمات** > **عام** > **الرد على المكالمات وإنهائها**، ثم قم بتشغيل **إنهاء المكالمات باستخدام مفتاح التشغيل**.

رفض مكالمة

لرفض مكالمة واردة، اسحب عبر شاشة المكالمات الواردة.

- لإرسال رسالة رفض، اسحب خيار رسالة الرفض عبر الشاشة.
- لإضافة رسالة رفض أو تحريرها، المس > **الإعدادات** > **الشبكات** > **إعدادات المكالمات** > **عام** > **حظر المكالمات و الرفض برسالة** > **الرفض برسالة**.
- عند ورود مكالمة، اضغط على مفتاح رفع مستوى الصوت (+) أو خفض مستوى الصوت (-) أو القفل/التشغيل لكتم صوت نغمة الرنين أو الاهتزاز أو تحويل المكالمة لوضع الانتظار.

التحقق من مكالمة واردة أثناء استخدام أحد التطبيقات

عند استقبال مكالمة أثناء استخدام أحد التطبيقات، يظهر إشعار منبثق في الجزء العلوي من الشاشة. يمكنك استقبال المكالمة أو رفضها أو إرسال رسالة من الشاشة المنبثقة.



- اضغط > **الإعدادات** > **الشبكات** > **إعدادات المكالمات** > **عام** > **المزيد** ثم اضغط **نافذة منبثقة للمكالمة الواردة** لإلغاء تنشيطها.

عرض المكالمات الفائتة

إذا فاتتك مكالمة، فسيقوم شريط الحالة الموجود أعلى الشاشة بعرض .

لعرض تفاصيل مكالمة فائتة، اسحب شريط الحالة لأسفل. وبدلاً من ذلك، المس > **السجلات**.

الوظائف التي يمكن الوصول إليها أثناء إجراء مكالمة

أثناء إجراء مكالمة، يمكنك الوصول إلى مجموعة متنوعة من الوظائف عن طريق لمس أزرار الشاشة:

- **الاسماء**: لعرض قائمة الاسماء أثناء إجراء مكالمة.
- **إنهاء**: لإنهاء مكالمة.
- **لوحة طلب**: لعرض لوحة الطلب أو إخفائها.
- **مكبر الصوت**: لتشغيل وظيفة السماعة الخارجية.
- **كتم الصوت**: لكتم صوتك حتى لا يسمعه طرف آخر.
- **Bluetooth**: لتحويل المكالمة إلى جهاز Bluetooth تم إقرانه وتوصيله بجهازك.
- : للوصول إلى خيارات اتصال إضافية.

- قد تتباين عناصر الإعدادات المتوفرة تبعًا للمنطقة أو مزود الخدمة.

إجراء اتصال ثلاثي الاتجاهات

يمكنك الاتصال باسم آخر أثناء إجراء مكالمة.

1 المس > **إضافة مكالمة** أثناء إجراء مكالمة.

2 أدخل رقم هاتف ثم المس .

- تظهر المكالمتان على الشاشة في الوقت نفسه، وتوضع المكالمة الأولى قيد الانتظار.

3 ولبدء مكالمة جماعية، المس > **دمج المكالمات**.

- قد يتم مطالبتك بدفع رسوم على كل مكالمة. استشر مزود الخدمة الخاص بك لمزيد من المعلومات.

عرض سجلات المكالمات

لعرض سجلات المكالمات الأخيرة، المس ◯ > > **السجلات**. وعندئذٍ يمكنك استخدام الوظائف التالية:

- لعرض السجلات المفصلة للمكالمات، حدد سجلات المكالمات. للاتصال بالاسم المحدد، المس .
- لحذف سجلات المكالمات، المس ⋮ > **حذف**.

- قد تختلف مدة المكالمة المعروضة عن رسوم المكالمة. استشر مزود الخدمة الخاص بك لمزيد من المعلومات.

تكوين خيارات الاتصال

يمكنك تكوين خيارات الاتصال المختلفة.

1 المس ◯ > > **اتصال** أو **السجلات**.

2 المس ⋮ > **إعدادات المكالمات** ثم قم بتكوين الخيارات التي تلائم تفضيلاتك.

الرسائل

إرسال رسالة

يمكنك إنشاء رسائل وإرسالها إلى الأسماء الموجودة لديك باستخدام تطبيق الرسائل.

- قد يتم فرض رسوم إضافية على إرسال الرسائل للخارج. استشر مزود الخدمة الخاص بك لمزيد من المعلومات.

1 المس ◯ > .

2 المس .

3 حدد مستلمًا وأنشئ رسالة.

- لإرفاق ملفات، المس .
- للوصول إلى عناصر القائمة الاختيارية، المس ⋮.

4 المس **إرسال** لإرسال الرسالة.

قراءة رسالة

يمكنك عرض الرسائل التي تم تبادلها مرتّبة حسب الاسم.

1 المس ◯ > .

2 حدد اسم من قائمة الرسائل.

تكوين إعدادات الرسائل

يمكنك تغيير إعدادات الرسائل لملائمة تفضيلاتك.

1 المس ◯ > .

2 المس ⋮ > **الإعدادات** من قائمة الرسائل.

الكاميرا

بدء تشغيل الكاميرا

يمكنك التقاط صورة أو تسجيل فيديو لإظهار التقدير لكل لحظاتك الثمينة.


المس ◯ > .

- قبل التقاط صورة أو تسجيل فيديو، امسح عدسة الكاميرا بقطعة قماش ناعمة.
- وكن حريصًا ألا تتعرض عدسة الكاميرا للتلطيخ من خلال أصابعك أو مادة غريبة أخرى.
- إذا كان مستوى البطارية أقل من 5%، فاشحنها قبل استخدام الكاميرا.
- قد تكون الصور المضمنة في دليل المستخدم هذا مختلفة عن تلك الموجودة في الجهاز الفعلي.
- يمكن عرض الصور ومقاطع الفيديو أو تحريرها من المعرض. انظر نظرة عامة على المعرض لمعرفة التفاصيل.

تغيير وضع الكاميرا

يمكنك تحديد وضع الكاميرا الذي يناسب بيئتك كي تتمكن من التقاط صورة أو تسجيل فيديو بطريقة مريحة وسهلة.

على شاشة الكاميرا، اضغط الوضع أساسي وحدد الوضع المرغوب فيه.



الوضع أساسي

يمكنك التقاط صور أو تسجيل مقاطع فيديو عن طريق التحديد من بين مختلف أوضاع وخيارات الكاميرا.

1 قم بتشغيل تطبيق الكاميرا، ثم اضغط **أساسي** (A).

2 لالتقاط صورة، المس . لتسجيل فيديو، المس .



التقاط صورة

1 حدد وضع الكاميرا، ثم المس الهدف لتركيز بؤرة الكاميرا عليه.

2 المس لالتقاط صورة.

- يمكنك أيضًا الضغط على مفتاح خفض مستوى الصوت (-) أو رفع مستوى الصوت (+) لالتقاط صورة.

- عند إيقاف تشغيل الشاشة أو قفلها، ابدأ تشغيل الكاميرا بالضغط على مفتاح خفض مستوى الصوت (-) مرتين. اضغط > **الإعدادات** > **عامة** > **مفتاح الاختصار**.

تسجيل فيديو

1 حدد وضع الكاميرا، ثم المس الهدف لتركيز بؤرة الكاميرا عليه.

2 المس .

- لالتقاط صورة أثناء تسجيل الفيديو، المس .
- لإيقاف تسجيل الفيديو مؤقتًا، المس . لاستئناف تسجيل الفيديو، المس .

3 المس لإنهاء تسجيل الفيديو.

تخصيص خيارات الكاميرا

يمكنك تخصيص مجموعة متنوعة من خيارات الكاميرا لملائمة تفضيلاتك.

ما عليك سوى لمس على الشاشة.

- تتباين الخيارات المتوفرة تبعًا للكاميرا المحددة (الكاميرا الأمامية أو الخلفية) ووضع الكاميرا المحدد.

حجم الصورة	حدد قيمًا لحجم ونسبة العرض إلى الارتفاع الخاصة بالتقاط الصور.
دقة الفيديو	حدد قيمًا لحجم ودقة تسجيل مقاطع الفيديو.
HDR	للحصول على صور بألوان حية، وإضافة مؤثرات لإضفاء المزيد من الجودة حتى في حالة التقاطها في مواجهة الضوء. يتم توفير هذه الوظائف من خلال ميزة النطاق الديناميكي المرتفع (HDR) المزودة في الكاميرا.
المؤقت	لضبط المؤقت لالتقاط الصور تلقائيًا بعد فترة زمنية محددة.
لاقط الإبتسامة	لالتقاط الصور عن طريق الأوامر الصوتية.
التسجيل الثابت	تقليل ضبابية الحركة أثناء تسجيل فيديو.
إرفاق المواقع	حفظ الصورة من خلال بيانات موقع GPS.
الشبكة	لعرض شبكات الموجه حتى يمكنك التقاط صور أو تسجيل مقاطع فيديو اعتمادًا على الخطوط المرجعية الأفقية والرأسية.
التخزين	حدد ما إذا كنت ترغب في تخزين الصور ومقاطع الفيديو في وحدة تخزين داخلية أو بطاقة SD. (يتوفر عند إدخال بطاقة الذاكرة.)
عرض بسيط	إخفاء جميع القوائم من شاشة الكاميرا.
مساعدة	توفير المساعدة لجميع قوائم الكاميرا.

خيارات إضافية بالكاميرا الأمامية

لقطة ذاتية	تخصيص إعدادات الصور الذاتية. • التقاط إيماءة اليد: لالتقاط صورة باستخدام ميزة التقاط إيماءة اليد. • التقاط الصور تلقائياً: التقاط عندما تحدد الكاميرا وجهًا.
عرض الإيماءة	لاختيار إذا كنت ستستخدم عرض الإيماءة لعرض الصورة بعد التقاطها مباشرةً.
عكس الصورة	حفظ الصور بشكل معكوس بعد التقاط الصور الذاتية.

• عند استخدام الكاميرا الأمامية، يمكنك ضبط عامل التصفية ولون البشرة.

أوضاع الكاميرا المتنوعة

بانوراما

يمكنك إنشاء صورة بانورامية عن طريق تحريك الكاميرا في اتجاه واحد لتصوير الهدف ودمج اللقطات المتتالية في عرض أكبر.

1 في الوضع أساسي اضغط **الوضع** > .

2 المس ثم حرك الكاميرا ببطء في اتجاه واحد.

- حرِّك الجهاز باتباع اتجاه السهم الوارد في الإرشادات.

3 المس للتوقف عن التقاط الصور البانورامية.




الطعام

يمكنك التقاط صورة باستخدام شريط التمرير الخاص بالتحكم في الجانب الأيمن من الشاشة.

1 في الوضع أساسي، اضغط **الوضع** > .

2 لالتقاط صورة، المس .

- اسحب شريط تمرير الألوان الموجود على الشاشة لضبط مستوى توازن اللون الأبيض وحدد أفضل لون.
- إذا كان شريط التمرير غير مرئيًا، اضغط لضبط مستوى توازن اللون الأبيض.



وضع الكاميرا مربع

يمكنك التقاط صور أو تسجيل مقاطع فيديو متعددة على شكل عمل تصويري عن طريق استخدام الكاميرا الأمامية والخلفية. يمكن حفظ الصور ومقاطع الفيديو باستخدام تخطيطات مختلفة.

1 قم بتشغيل تطبيق الكاميرا، ثم اضغط **أساسي** () > **مربع** ().

2 اضغط **الوضع** وحدد وضع الكاميرا المرغوب فيه.

3 لالتقاط صورة، المس . لتسجيل فيديو، المس .

تخصيص خيارات الكاميرا

يمكنك تخصيص مجموعة متنوعة من خيارات الكاميرا لملائمة تفضيلاتك.

ما عليك سوى لمس على الشاشة.

- تتباين الخيارات المتوفرة تبعًا للكاميرا المحددة (الكاميرا الأمامية أو الخلفية) ووضع الكاميرا المحدد.

حجم الصورة	حدد قيمًا لحجم ونسبة العرض إلى الارتفاع الخاصة بالتقاط الصور.
دقة الفيديو	حدد قيمًا لحجم ودقة تسجيل مقاطع الفيديو.
HDR	للحصول على صور بألوان حية، وإضافة مؤثرات لإضفاء المزيد من الجودة حتى في حالة التقاطها في مواجهة الضوء. يتم توفير هذه الوظائف من خلال ميزة النطاق الديناميكي المرتفع (HDR) المزودة في الكاميرا.
المؤقت	لضبط المؤقت لالتقاط الصور تلقائيًا بعد فترة زمنية محددة.
لاقط الإبتسامة	لالتقاط الصور عن طريق الأوامر الصوتية.
التسجيل الثابت	تقليل ضبابية الحركة أثناء تسجيل فيديو.
إرفاق المواقع	حفظ الصورة من خلال بيانات موقع GPS.
الشبكة	لعرض شبكات الموجه حتى يمكنك التقاط صور أو تسجيل مقاطع فيديو اعتمادًا على الخطوط المرجعية الأفقية والرأسية.
التخزين	حدد ما إذا كنت ترغب في تخزين الصور ومقاطع الفيديو في وحدة تخزين داخلية أو بطاقة SD. (يتوفر عند إدخال بطاقة الذاكرة.)
مساعدة	توفير المساعدة لجميع قوائم الكاميرا.

خيارات إضافية بالكاميرا الأمامية

لقطة ذاتية	تخصيص إعدادات الصور الذاتية. • التقاط إيماءة اليد: لالتقاط صورة باستخدام ميزة التقاط إيماءة اليد. • التقاط الصور تلقائياً: التقاط عندما تحدد الكاميرا وجهًا.
عكس الصورة	حفظ الصور بشكل معكوس بعد التقاط الصور الذاتية.

• عند استخدام الكاميرا الأمامية، يمكنك ضبط عامل التصفية ولون البشرة.

ميزات مفيدة أخرى في تطبيق الكاميرا

الصور المتلاحقة

يمكنك أخذ لقطات متلاحقة لإنشاء صور متحركة.

في الوضع أساسي، المس مع الاستمرار.

- يتم أخذ لقطات متتالية بسرعة ثابتة أثناء الضغط المستمر على .

- يمكن التقاط عدد من الصور المتتابعة يصل إلى ثلاثين (30) صورة.

عرض بسيط

في الوضع أساسي، اضغط > **عرض بسيط** لإخفاء القوائم بشاشة الكاميرا. المس لعرضها.

AE/AF lock


يمكنك إصلاح مستوى التعرض الحالي وموضع التركيز من خلال لمس الشاشة مع الاستمرار في الوضع أساسي. لإيقاف تشغيل الميزة، المس منطقة فارغة بالشاشة.



التبديل بين الكاميرتين

يمكنك التبديل بين الكاميرا الأمامية والخلفية لاختيار الكاميرا التي تلائم بيئتك.

على شاشة الكاميرا، المس أو اسحب الشاشة في أي اتجاه للتبديل بين الكاميرا الأمامية والخلفية.



- استخدم الكاميرا الأمامية لالتقاط صور ذاتية. انظر لقطة ذاتية للحصول على تفاصيل.

التبديل بين عدسات الكاميرا ذات الزاوية القياسية وتلك ذات الزاوية المتسعة

قم بالتبديل بين العدسات ذات الزاوية القياسية وتلك ذات الزاوية الواسعة للكاميرا الأمامية لالتقاط صور أو تسجيل مقاطع فيديو تلائم تفضيلاتك.

- المس / للتبديل بين الكاميرا القياسية والكاميرا عريضة الزاوية.

التكبير أو التصغير

يمكنك استخدام التكبير أو التصغير في شاشة الكاميرا أثناء التقاط صورة أو تسجيل فيديو.

- على شاشة الكاميرا، قم بضم أو فرد إصبعيك على شاشة الكاميرا للتكبير أو التصغير، ثم استخدم شريط التمرير +/- المعروض.

- لا تتوفر ميزة التكبير/التصغير عند استخدام الكاميرا الأمامية في وضع الصور الذاتية.

لقطة ذاتية

يمكنك استخدام الكاميرا الأمامية لعرض وجهك على الشاشة والتقاط صورة ذاتية له.


التقاط إيماءة اليد

يمكنك التقاط صور ذاتية باستخدام الإيماءات.

ما عليك سوى إظهار كف يدك أمام الكاميرا الأمامية ثم إطباق قبضتك.

يمكنك أيضًا قبض يديك، ثم فتحها باتجاه الكاميرا الأمامية.

- سيتم التقاط الصورة خلال ثلاث ثوانٍ.



- لاستخدام هذه الميزة، قم بالتبديل إلى وضع الكاميرا الأمامية، ثم المس ⚙ > **لقطة ذاتية** > **التقاط إيماءة اليد**.
- تأكد من أن راحة يدك وقبضتها موجودتان ضمن الخط المرجعي حتى يمكن للكاميرا اكتشافهما.
- قد لا تتوفر هذه الميزة عند استخدام بعض ميزات الكاميرا.

لقطات تسلسلية مع فواصل زمنية

يمكنك التقاط لقطات تسلسلية مع فواصل زمنية للصور الذاتية.

أثناء استخدام الكاميرا الأمامية، يمكنك إظهار كف يدك أمام الكاميرا الأمامية ثم إطباق قبضتك مرتين سريعًا.

- يتم التقاط أربع صور خلال فاصل زمني يصل إلى ثانيتين تقريبًا بعد تأخير المؤقت لمدة ثلاث ثوانٍ.

- اضغط ⚙ > **لقطة ذاتية** > **التقاط إيماءة اليد** لاستخدام هذه الميزة.

التقاط الصور تلقائياً


يمكنك استخدام ميزة اكتشاف الوجه لالتقاط صور ذاتية بطريقة مريحة وسهلة. يمكنك ضبط الجهاز وبالتالي عندما تنظر إلى الشاشة، تكتشف الكاميرا الأمامية وجهك وتلتقط صورة ذاتية تلقائيًا.

- عندما تكتشف الكاميرا الأمامية وجهك، يظهر إطار الدليل باللون الأبيض. وفي حالة توقف الهدف الموجود داخل إطار الدليل عن الحركة، فإن لون إطار الدليل يتحول إلى الأزرق، وبعدها تلتقط الكاميرا الصورة.

- المس ⚙ > **لقطة ذاتية** > **التقاط الصور تلقائياً** لتمكين ميزة "التقاط الصور تلقائيًا".

عرض الإيماءة

بعد التقاط صورة ذاتية باستخدام الكاميرا الأمامية، يمكنك معاينة الصورة الذاتية مباشرةً عن طريق وضع الشاشة بالقرب من وجهك.



- المس ⚙ > **عرض الإيماءة** لتمكين ميزة "عرض الإيماءة".
- يتم عرض معاينة واحدة فقط في كل مرة يتم فيها التقاط صورة.
- إذا قمت بتدوير الجهاز أثناء عرض شاشة المعاينة، تتبدل الشاشة إلى وضع الكاميرا.

عكس الصورة

قبل التقاط صورة باستخدام الكاميرا الأمامية، اضغط على ⚙ > **عكس الصورة**. يتم عكس الصورة أفقيًا.

- عند استخدام الكاميرا الأمامية، يمكنك تغيير كيفية التقاط الصور الذاتية في خيارات الكاميرا. انظر تخصيص خيارات الكاميرا لمعرفة التفاصيل.

المعرض

نظرة عامة على المعرض

يمكنك عرض الصور والفيديوهات المحفوظة على جهازك وإدارتها.

1 المس ◯ > .


- يتم عرض الصور ومقاطع الفيديو المحفوظة حسب المجلد.

2 المس أحد المجلدات واختر ملفًا.

- اعرض الملف المحدد في وضع ملء الشاشة.
- أثناء عرض صورة، اسحب لليسار أو اليمين لعرض الصورة السابقة أو التالية.
- أثناء عرض فيديو، اسحب لليسار أو اليمين لإرجاع فيديو أو التقديم السريع له.

- قد لا يتم دعم بعض تنسيقات الملفات اعتمادًا على البرامج المثبتة.
- قد لا يتم فتح بعض الملفات بسبب الترميز.
- قد تتسبب الملفات التي تتجاوز الحد الأقصى للحجم في حدوث أخطاء.


عرض الصور



- لعرض عناصر القائمة، المس الشاشة برفق. لإخفاء عناصر القائمة، المس الشاشة مرة أخرى.

الزر العائم

للانتقال بسرعة إلى الشاشة الرئيسية أثناء عرض المعرض في الاتجاه الأفقي، المس مع الاستمرار ◁، وحرك إصبعك لأعلى تجاه ○، ثم حرره.



• يمكنك تحريك موضع الزر العائم بسحبه أفقيًا إلى الجزء السفلي من الشاشة.

كتابة مذكرة على الصورة

1 أثناء عرض صورة، المس ✎.

2 اكتب مذكرة على الصورة واضغط **حفظ**.

• قد لا تدعم بعض الصور ميزة المذكرة.

المحتوى ذو الصلة

يمكنك تعديل المحتوى ذي الصلة وتخصيصه في المعرض.

1 أثناء عرض معاينة صورة، اضغط .

2 عند ظهور الأيقونة المرتبطة بالتاريخ الذي التقطت فيه الصورة، اضغط على الشاشة.



- يمكنك عرض الصور المرتبطة بالتاريخ الذي اخترته.



- يمكن أن يكون المحتوى ذو الصلة مرتبطًا بما يصل إلى أربع مجموعات من "الذكريات، التاريخ، الأماكن، وضع الكاميرا".

- اضغط لحفظ المحتوى ذي الصلة كمقطع فيديو.
- اضغط للوصول إلى الخيارات الإضافية.

تحرير الصور

1 أثناء عرض صورة، المس .

2 استخدم مجموعة متنوعة من المؤثرات والأدوات لتحرير الصورة.

3 المس **حفظ** لحفظ التغييرات.

- يتم كتابة التغييرات على الملف الأصلي.
- لحفظ الصورة المحررة كملف آخر، المس > **حفظ نسخة**.

تشغيل فيديو




- لضبط مستوى الصوت، اسحب الجانب الأيمن من شاشة الفيديو لأعلى أو أسفل.
- لضبط سطوع الشاشة، اسحب الجانب الأيسر من الشاشة لأعلى أو لأسفل.

تحرير مقاطع الفيديو

1 أثناء عرض فيديو، المس .

2 استخدم مجموعة متنوعة من المؤثرات وأدوات التحرير لتحرير الفيديو.



3 المس **حفظ** لحفظ التغييرات.

إنشاء GIF

يمكنك إنشاء ملف GIF بسهولة باستخدام فيديو مُسجل.

1 في نقطة البدء المطلوبة أثناء مشاهدة الفيديو، اضغط ⋮ > **إنشاء GIF**.

2 حدد طول ملف GIF الذي تريد إنشاءه.

- يتم إنشاء ملف GIF للوقت المُحدد بدءًا من الوقت الحالي.
- بالنسبة لمقاطع الفيديو التي تقل عن 5 ثوان، يتم إنشاء صور GIF تلقائيًا للوقت المتبقي.

⚠ • ميزة إنشاء ملف GIF متوفرة؛ لتمكين المستخدم من إجراء نشاط ابتكاري. إذا قمت بانتهاك القوانين المتعلقة بحقوق النشر وقوانين التشهير باستخدام ميزة إنشاء ملف GIF، فربما ستكون تحت طائلة المساءلة المدنية والجنائية. تأكد من عدم تكرار أو نقل أعمال الآخرين دون إذنهم. لا تقبل شركة LG Electronics أن تتحمل أدنى مسؤولية عن أفعال المستخدم.

الملفات ذات الصلة

يمكنك ربط ملفات بصور ومقاطع فيديو ملتقطة في نفس الموقع أو التاريخ.

1 حدد الصور ومقاطع الفيديو المحفوظة واضغط 🔗.

2 حدد المجلد المطلوب، ثم اضغط ▶ لإنشاء مقطع فيديو.

حذف الملفات

يمكنك حذف ملفات باستخدام أحد الخيارات التالية:

- المس باستمرار أحد الملفات من قائمة الملفات، ثم المس **حذف**.
- المس 🗑 من قائمة الملفات، واحذف الملفات المطلوبة.
- تنتقل الملفات المحذوفة بصورة تلقائية إلى **المهملات** ويمكن استعادتها إلى المعرض خلال 7 أيام.
- في المعرض، المس ☰ > **المهملات**. المس 🗑 لحذف الملفات نهائيًا. في هذه الحالة، لا يمكن استعادة الملفات.

مشاركة الملفات

يمكنك مشاركة ملفات باستخدام أحد الخيارات التالية:

- أثناء عرض صورة، المس لمشاركة الملف باستخدام الطريقة التي تريدها.
- أثناء عرض فيديو، > **مشاركة** لمشاركة الملف باستخدام الطريقة التي تريدها.
- المس من قائمة الملفات لتحديد ملفات ومشاركتها باستخدام الطريقة التي تريدها.

الاسماء

نظرة عامة على الاسماء

يمكنك حفظ الاسماء وإدارتها.

اضغط > **أساسيات** > **الاسماء**.

إضافة اسماء

إضافة اسماء جديدة

1 في شاشة قائمة الاسماء، المس +.

2 أدخل تفاصيل الاسم، ثم المس **حفظ**.

استيراد الاسماء

يمكنك استيراد اسماء من جهاز تخزين آخر.

1 في شاشة قائمة الأسماء، المس > **التحكم في الاسماء** > **استيراد**.

2 حدد الموقعين المصدر والهدف للاسم الذي تريد استيراده، ثم المس **موافق**.

3 حدد الأسماء والمس **استيراد**.

إضافة اسماء إلى قائمة أرقام الاتصال السريع

1 في شاشة قائمة الاسماء، المس > **الاتصال السريع**.

2 المس **إضافة اسم** من أرقام الاتصال السريع.

3 حدد اسم.

البحث عن اسماء

يمكنك البحث عن الاسماء باستخدام أحد الخيارات التالية:

- على شاشة قائمة الاسماء، أدخل اسم في مربع البحث.
- قم بالتمرير في قائمة الاسماء لأعلى أو لأسفل.
- من فهرس شاشة قائمة الاسماء، المس الحرف الأول من الاسم.

قائمة الاسماء

تحرير الاسماء

1 في شاشة قائمة الاسماء، حدد اسم.

2 على شاشة تفاصيل الاسماء، المس لتحرير التفاصيل.

3 المس **حفظ** لحفظ التغييرات.

حذف الاسماء

يمكنك حذف الأسماء باستخدام أحد الخيارات التالية:

- في شاشة قائمة الأسماء، المس مع الاستمرار اسمًا تريد حذفه، ثم المس **حذف الاسم**.
- المس ⋮ > **حذف** على شاشة قائمة الأسماء.

إضافة مفضلة

يمكنك تسجيل اسماء متكررة الاستخدام كمفضلة.

1 في شاشة قائمة الاسماء، حدد اسم.

2 على شاشة تفاصيل الاسماء، المس ☆.

إنشاء مجموعات

1 في شاشة قائمة الاسماء، المس **المجموعات** > ⋮ > **مجموعة جديدة**.

2 أدخل اسمًا جديدًا للمجموعة.

3 المس **إضافة أعضاء** لتحديد اسماء، ثم المس **إضافة**.

4 المس **حفظ** لحفظ المجموعة الجديدة.

QuickMemo+

نظرة عامة على QuickMemo+

يمكنك تدوين ملاحظات مبتكرة باستخدام مجموعة متنوعة من الخيارات التي تخص هذه الميزة المتقدمة بالمفكرة، كإدارة الصور ولقطات الشاشة، والتي لا تكون مدعومة بالمفكرة التقليدية.

إنشاء ملاحظة

1 اضغط ◯ > **QuickMemo+**.

2 المس + لتنشئ ملاحظة.

- ✓ : لحفظ ملاحظة.
- ↩ : للتراجع عن آخر إجراء.
- ↪ : للرجوع إلى آخر إجراء لم تقم به.
- T : لإدخال ملاحظة باستخدام لوحة المفاتيح.
- ✎ : لكتابة الملاحظات يدويًا.
- ◇ : لمسح الملاحظات المكتوبة بخط اليد.
- ◌ : للتكبير أو التصغير، وتدوير أو محو أجزاء من الملاحظة المكتوبة بخط اليد.
- ⋮ : الوصول إلى الخيارات الإضافية.

3 المس ✓ لحفظ الملاحظة.

كتابة ملاحظات على الصور

1 اضغط ◯ > **QuickMemo+**.

2 المس 📷 لالتقاط صورة، ثم المس **موافق**.

- يتم إرفاق الصورة تلقائيًا بالمفكرة.

3 المس T أو ✎ لكتابة ملاحظات على الصورة.

- اكتب الملاحظات يدويًا على الصورة.
- أدخل النص أسفل الصورة.

4 المس ✓ لحفظ الملاحظة.

كتابة ملاحظات على لقطة الشاشة

1 أثناء عرض الشاشة التي تريد التقاط صورة لها، اسحب شريط الحالة لأسفل ثم المس .

- تظهر لقطة الشاشة كخلفية للمفكرة. تظهر أدوات الذاكرة أعلى الشاشة.

2 يمكنك تدوين الملاحظات كيفما تشاء.

- اكتب الملاحظات يدويًا على الصورة.

3 المس ثم احفظ الملاحظات في الموقع الذي تريده.

- يمكنك عرض الملاحظات المحفوظة إما في **+QuickMemo** أو **المعرض**.
- لحفظ الملاحظات بنفس المكان في كل مرة، حدد خانة الاختيار **استخدم الافتراضي لهذا الإجراء.** ثم اختر تطبيقًا.

إدارة المجلدات

يمكنك عرض المذكرات عن طريق تجميعها حسب النوع.

1 اضغط > **+QuickMemo**.

2 في أعلى الشاشة، المس ثم حدد عنصر قائمة:

- **جميع المذكرات**: لعرض جميع الملاحظات المحفوظة في +QuickMemo.
- **مذكراتي**: لعرض الملاحظات المنشأة بواسطة +QuickMemo.
- **+Capture**: لعرض الملاحظات المنشأة بواسطة +Capture.
- **صورة مذكرة**: لعرض الملاحظات المنشأة بواسطة .
- **المهملات**: لعرض الملاحظات المحذوفة.
- **فئة جديدة**: لإضافة فئات.
- : لإضافة فئات أو إعادة ترتيبها أو حذفها. ولتغيير اسم فئة، المس الفئة.

- قد لا تظهر بعض المجلدات عند تشغيل +QuickMemo للمرة الأولى. ويتم تمكين المجلدات المعطلة وتظهر عندما تحتوي على ملاحظة واحدة مرتبطة على الأقل.

الساعة

التنبيه

يمكنك ضبط تنبيه لتشغيله في وقت محدد.

1 اضغط ◯ > **أساسيات** > **الساعة** > **التنبيه**.

2 المس ⊕ لإضافة تنبيه جديد.

3 قم بتكوين إعدادات التنبيه ثم المس **حفظ**.

- إذا حددت تنبيهًا تم ضبطه مسبقًا، فيمكنك تحريره.
- لحذف تنبيه، المس 🗑 بأعلى الشاشة. أو بدلاً من ذلك، المس التنبيه مع الاستمرار.

الساعة العالمية

يمكنك عرض الوقت الحالي لمدن عبر العالم.

1 اضغط ◯ > **أساسيات** > **الساعة** > **الساعة العالمية**.

2 المس ⊕ لإضافة مدينة.

المؤقت

يمكنك ضبط المؤقت لتشغيل تنبيه بعد فترة زمنية محددة.

1 اضغط ◯ > **أساسيات** > **الساعة** > **المؤقت**.

2 اضبط الوقت ثم المس **بدء**.

- لإيقاف المؤقت مؤقتًا، المس **توقف**. ولاستئنافه، المس **استئناف**.
- لإعادة ضبط إعدادات المؤقت، اضغط ↺.

3 المس **إيقاف** لإيقاف تنبيه المؤقت.

ساعة الإيقاف

يمكنك استخدام ساعة الإيقاف لتسجيل وقت الدورة.

1 اضغط ◯ > **أساسيات** > **الساعة** > **ساعة الإيقاف**.

2 المس **بدء** لبدء ساعة الإيقاف.

- لتسجيل وقت الدورة، المس **الدورة**.

3 المس **توقف** لإيقاف ساعة الإيقاف مؤقتًا.

- لاستئناف ساعة الإيقاف، المس **استئناف**.
- لمسح كافة السجلات وإعادة بدء ساعة الإيقاف، اضغط **إعادة ضبط**.

التقويم

نظرة عامة على التقويم

يمكنك استخدام التقويم لإدارة الأحداث والمهام.

إضافة أحداث

1 اضغط ◯ > **أساسيات** > **التقويم**.

2 حدد تاريخًا ثم المس ⊕.

3 أدخل تفاصيل الحدث، ثم المس **حفظ**.

- إذا لمست تاريخًا من التقويم وكان التاريخ يحتوي على أحداث، فستظهر نافذة منبثقة تعرض قائمة بالأحداث. والمس حدثًا من النافذة المنبثقة لعرض التفاصيل الخاصة به.

مزامنة الأحداث

المس ⋮ > **التقويمات المطلوب مزامنتها**، وحدد التقويم الذي تريد مزامنته.

- عند حفظ الأحداث الخاصة بك من الجهاز على حساب Google، يتم مزامنتها تلقائيًا مع تقويم Google أيضًا. بعد ذلك، يمكنك مزامنة أجهزة أخرى مع تقويم Google كي يكون لدى تلك الأجهزة الأحداث ذاتها الموجودة على جهازك وبالتالي يمكنك إدارة الأحداث على تلك الأجهزة.

مهام

يمكنك تسجيل المهام بجهازك لإدارة الجداول بسهولة.

1 اضغط ◯ > **أساسيات** > **مهام**.

2 المس ⊕ لإضافة مهمة.

3 أدخل تفاصيل المهمة، ثم المس **حفظ**.

موسيقى

يمكنك تشغيل وإدارة الأغاني أو الألبومات الموسيقية.

1 اضغط ◯ > **أساسيات** > **موسيقى**.

2 حدد فئة.

3 حدد ملف موسيقى.



- قد لا يتم دعم بعض تنسيقات الملفات اعتمادًا على البرامج المثبتة.
- قد تتسبب الملفات التي تتجاوز الحد الأقصى للحجم في حدوث أخطاء.
- يقوم مالكو حقوق النشر الدوليون بحماية ملفات الموسيقى أو تتم حمايتها بموجب قوانين حقوق النشر. لذا فإنه يلزمك الحصول على إذن قانوني قبل نسخ ملف موسيقى. ولتنزيل ملف موسيقى أو نسخه، ينبغي أولاً التحقق من قوانين حقوق النشر الخاصة بالبلد المعني.

الآلة الحاسبة

يمكنك استخدام نوعين من الحاسبات: الحاسبة البسيطة والحاسبة العلمية.

1 اضغط ◯ > **أساسيات** > **الآلة الحاسبة**.

2 استخدم لوحة المفاتيح لإجراء عملية حسابية.

- لاستخدام الحاسبة العلمية، اسحب شريط التمرير باللون الأخضر والموجود في الجانب الأيمن من الشاشة إلى اليسار.
- لإعادة إجراء حساب، المس الزر **حذف** مع الاستمرار.

البريد الإلكتروني

نظرة عامة على البريد الإلكتروني

يمكنك تسجيل حساب بريد إلكتروني بجهازك ثم التحقق من رسائل البريد الإلكتروني وإرسالها من جهازك.

- إذا استخدمت بيانات الهاتف المحمول، فقد يتم فرض رسوم على استخدامها تبعًا لخطة التسعير. استشر مزود الخدمة الخاص بك لمزيد من المعلومات.

تسجيل حسابات البريد الإلكتروني

عندما تستخدم تطبيق البريد الإلكتروني لأول مرة، قم بتسجيل حساب البريد الإلكتروني الخاص بك.

1 اضغط ◯ > **أساسيات** > **البريد الإلكتروني**.

2 حدد مزود خدمة البريد الإلكتروني.

3 أدخل عنوان بريدك الإلكتروني وكلمة المرور ثم المس **التالي** لتسجيل حسابك.

- لتسجيل حساب بريد إلكتروني يدويًا، اضغط **الإعداد اليدوي** (إذا لزم الأمر).

إدارة حسابات البريد الإلكتروني

لعرض إعدادات حساب بريدك الإلكتروني أو تحريرها، المس ⋮ > **الإعدادات**.

- لإضافة حساب، المس **إضافة حساب**.
- لحذف حساب، المس ⋮ > **إزالة الحساب**.

فتح حساب بريد إلكتروني آخر

في حالة تسجيل العديد من حسابات البريد الإلكتروني وكنت تريد عرض حساب آخر، فالمس ☰ ثم حدد حسابًا آخر من قائمة الحسابات.

تحقق من البريد الإلكتروني

1 المس ☰ ثم حدد صندوق بريد.

2 حدد بريدًا إلكترونيًا من قائمة البريد الإلكتروني.

- تظهر رسالة البريد الإلكتروني.

إرسال بريد إلكتروني

1 المس ⊕.

2 أدخل عنوان البريد الإلكتروني الخاص بالمستلم.

3 أدخل الموضوع والرسالة.

- لإرفاق ملفات، المس 📎.
- للوصول إلى عناصر القائمة الاختيارية، المس ⋮.

4 المس ➤ لإرسال البريد الإلكتروني.

المسجل الصوتي

يمكنك تسجيل وحفظ صوتك أو أصوات الآخرين من أحداث مهمة. ويمكن تشغيل الملفات الصوتية المسجلة أو مشاركتها.

1 المس ◯ > **أساسيات** > **المسجل الصوتي**.

2 المس ●.

- لإيقاف التسجيل مؤقتًا، المس ⏸.
- لإدخال إشارة مرجعية أثناء تسجيل صوت، اضغط على 🔖.

3 المس ■ لإنهاء التسجيل.

- يتم حفظ الملف تلقائيًا وتظهر شاشة ما قبل الاستماع.

4 المس ▶ لتشغيل الصوت المسجل.

- إذا لمست ☰، فستظهر الملفات الصوتية المسجلة. ويمكنك تشغيل الملفات الصوتية المسجلة من القائمة.

راديو FM

يمكنك الاستماع إلى راديو FM.

اضغط ◯ > **أساسيات** > **راديو FM**.

- لاستخدام هذا التطبيق، قم أولاً بتوصيل سماعة الرأس بالجهاز؛ وعندئذٍ ستعمل السماعة بمثابة هوائي لاسلكي.
- قد لا يتم دعم هذه الوظيفة تبعًا للمنطقة.

بث الشبكة

يمكنك عرض بيانات بث النصوص في الوقت الفعلي في حالات الطوارئ مثل الأعاصير والفيضانات والزلازل.

اضغط ◯ > **أساسيات** > **بث الشبكة**.

إدارة الملفات

يمكنك عرض الملفات المحفوظة على جهازك أو على Cloud وإدارتها.

1 اضغط ◯ > **الإدارة** > **إدارة الملفات**.

2 المس ☰ وحدد موقع التخزين المرغوب فيه.

LG Mobile Switch

انقل البيانات بسهولة من جهاز مستخدم إلى جهاز جديد باستخدام LG Mobile Switch.

1 اضغط ◯ > **الإدارة** > **LG Mobile Switch**.
بدلاً من ذلك، المس ◯ > **الإعدادات** > **عامة** > **نسخ إحتياطي وإعادة الضبط** > **LG Mobile Switch**.

2 اتبع الإرشادات المعروضة على الشاشة لتحديد طريقة النقل المطلوبة.

⚠ • قد تؤدي إعادة ضبط جهازك إلى حذف الملفات الاحتياطية المحفوظة في وحدة التخزين. تأكد من نسخ وتخزين ملفات النسخ الاحتياطي على جهاز الكمبيوتر الشخصي الخاص بك.

📝 • لن يتم نسخ البيانات الموجودة بحساب Google احتياطيًا. وعندما تقوم بمزامنة حسابك على Google، يتم تخزين تطبيقات Google وأسماء Google وتقويم Google وبيانات تطبيق مذكرة Google والتطبيقات التي تم تنزيلها من متجر Play على تطبيق Drive تلقائيًا.
• اشحن البطارية تمامًا قبل نقل البيانات لتجنب إيقاف التشغيل غير المقصود أثناء العملية.

التنزيلات

يمكنك عرض أو حذف أو مشاركة الملفات التي تم تنزيلها عبر الإنترنت أو التطبيقات.

اضغط ◯ > **الإدارة** > **التنزيلات**.

LG SmartWorld

يمكنك تنزيل مجموعة متنوعة من الألعاب والمحتويات الصوتية والتطبيقات والخطوط التي توفرها LG Electronics. ما عليك سوى تخصيص جهازك ليلائم تفضيلاتك، وذلك باستخدام خلفيات الشاشة الرئيسية والخطوط.

- إذا استخدمت بيانات الهاتف المحمول، فقد يتم فرض رسوم على استخدامها تبعًا لخطة التسعير.
- قد لا يتم دعم هذه الميزة تبعًا للمنطقة أو مزود الخدمة.

1 اضغط ◯ > **الخدمات** > **SmartWorld**.

2 المس ⋮ > **تسجيل الدخول**، ثم قم بتسجيل الدخول.

3 حدد عناصر المحتوى لتنزيلها.

تنزيل تطبيق SmartWorld

إذا لم يتم تثبيت تطبيق SmartWorld، فاتبع الخطوات التالية لتنزيله.

1 اضغط ◯ > **الإعدادات** > **عامة** > **حول الهاتف** > **عام** > **مركز التحديث** > **تحديث التطبيق**.

2 من القائمة، حدد **SmartWorld** ثم المس **تنزيل**.

RemoteCall Service

يمكن تشخيص جهازك عن بُعد لحل المشكلات. أولاً، قم بإجراء مكالمة هاتفية مع مركز خدمة عملاء LG كما يلي:

- لاستخدام هذه الوظيفة، يتعين عليك أولاً الموافقة على استخدامها.
- إذا استخدمت بيانات الهاتف المحمول، فقد يتم فرض رسوم على استخدامها تبعًا لخطة التسعير.

1 اضغط ◯ > **الخدمات** > **RemoteCall Service**.

2 اتصل بأحد مراكز خدمة عملاء LG.

3 بعد الاتصال، اتبع إرشادات مسؤول الخدمة لإدخال رقم وصول مؤلف من ستة أرقام.
- يتم الاتصال بجهازك عن بُعد وتبدأ خدمة الدعم عن بُعد.

Chrome

سجل الدخول إلى Chrome وقم باستيراد علامة التبويب المفتوحة والإشارات المرجعية وبيانات شريط العنوان من جهاز كمبيوتر إلى جهازك.

تطبيقات Google

يمكنك استخدام تطبيقات Google عن طريق تعيين حساب Google. وعندئذٍ ستظهر نافذة تسجيل حساب Google تلقائيًا عندما تستخدم تطبيق Google لأول مرة. وإذا لم يكن لديك حساب على Google، فأنشئ حسابًا من جهازك. وللاطلاع على كيفية استخدام تطبيق، انظر المساعدة الواردة في التطبيق.

- قد لا تعمل بعض التطبيقات تبعًا للمنطقة أو مزود الخدمة.

مستندات

يمكنك إنشاء المستندات أو تحرير المستندات المنشأة عبر الإنترنت أو من أي جهاز آخر. كما يمكنك مشاركة المستندات مع آخرين وتحريرها.

Drive

يمكنك تحميل الملفات وحفظها وفتحها ومشاركتها وتنظيمها من جهازك. ويمكن الوصول إلى الملفات التي يمكن الوصول إليها من التطبيقات من أي مكان آخر سواء عند الاتصال بالإنترنت أو من دونه.

Duo

قم بإجراء مكالمة فيديو مع أفراد عائلتك وأصدقائك وأي شخص آخر يستخدم هذا التطبيق.

Gmail

سجل حساب بريدك الإلكتروني على Google بجهازك للتحقق من رسائل البريد الإلكتروني أو إرسالها.

Google

استخدم Google للبحث عن صفحات الويب والصور والأخبار والمزيد عن طريق إدخال كلمات أساسية أو نطقها.

خرائط

اكتشف موقعك أو موقع أحد الأماكن على الخريطة، واعرض المعلومات الجغرافية الخاصة به.

الصور

اعرض الصور أو الألبومات المحفوظة على جهازك وشاركها.

أفلام وتليفزيون Play

استخدم حسابك على Google لاستئجار أفلام أو شرائها. ويمكنك شراء المحتوى وتشغيله من أي مكان.

موسيقى Play

اشترِ ملفات موسيقى من متجر Play. ويمكنك تشغيل ملفات الموسيقى المحفوظة على جهازك.

جداول البيانات

يمكنك إنشاء جداول بيانات أو تحرير جداول البيانات المنشأة عبر الإنترنت أو من أي جهاز آخر. كما يمكنك مشاركة جداول البيانات مع آخرين وتحريرها.

عروض تقديمية

يمكنك إنشاء مواد عرض تقديمي أو تحرير مواد العرض التقديمي المنشأة عبر الإنترنت أو من أي جهاز آخر. كما يمكنك مشاركة هذه المواد مع آخرين وتحريرها.

YouTube

ابحث عن مقاطع فيديو وقم بتشغيلها. ويمكنك تحميل مقاطع فيديو على YouTube لمشاركتها مع أشخاص من أنحاء العالم.

04

الإعدادات

الإعدادات

يمكنك تخصيص إعدادات الجهاز وفقًا لتفضيلاتك.

المس ◯ > **الإعدادات**.

- المس 🔍 وأدخل كلمة أساسية في مربع البحث للوصول إلى عنصر الإعداد.
- المس ⋮ لتغيير وضع العرض. يفترض دليل المستخدم هذا أنك تستخدم عرض التبويب.

الشبكات

بطاقة SIM ثنائية

يمكنك تكوين إعدادات بطاقة SIM ثنائية.

1 على شاشة الإعدادات، المس **الشبكات** > **بطاقة SIM ثنائية**.

2 قم بتخصيص الوظائف التالية:

- **SIM 1**: قم بتغيير اسم وأيقونة بطاقة SIM 1.
- **SIM 2**: قم بتغيير اسم وأيقونة بطاقة SIM 2.
- **سمة لون بطاقة SIM**: قم بتغيير سمات اللون لبطاقات SIM.
- **ميزة تقليل التكلفة**: قم بتنشيط أو إلغاء تنشيط ميزة تقليل التكلفة. في ميزة تقليل التكلفة، إذا قمت بإجراء مكالمة لإحدى الاسماء التي يتم تعيين SIM محددة لها، فإن SIM هذه تستخدم لإجراء المكالمة حتى إذا كانت SIM الأخرى نشطة، على سبيل المثال، تستخدم "بيانات شبكة المحمول".
- **بيانات الهاتف المحمول**: حدد بطاقة SIM التي تريد استخدامها لخدمة بيانات شبكة المحمول. كما يمكنك أيضًا إيقاف تشغيل هذه الوظيفة.
- **بيانات التجوال**: حدد هذا الخيار لتمكين الجهاز من استخدام بيانات شبكة المحمول عند التجوال خارج منطقة الشبكة المنزلية الخاصة بك.

Wi-Fi

يمكنك الاتصال بالأجهزة القريبة عبر شبكة Wi-Fi.

الاتصال بشبكة Wi-Fi

1 على شاشة الإعدادات، المس **الشبكات** > **Wi-Fi**.

2 اضغط لتنشيطه.

- تظهر شبكات Wi-Fi المتوفرة تلقائيًا.

3 حدد شبكة.

- قد تحتاج إلى إدخال كلمة مرور للشبكة Wi-Fi.
- ويتخطى الجهاز هذه العملية لشبكات Wi-Fi التي سبق الوصول إليها. وإذا لم تكن تريد الاتصال بإحدى شبكات Wi-Fi تلقائيًا، فالمسها مع الاستمرار ثم المس **نسيان الشبكة**.

إعدادات شبكة Wi-Fi

على شاشة الإعدادات، المس **الشبكات** > **Wi-Fi**.

- **التحويل إلى بيانات الجوال**: إذا تم تنشيط وظيفة اتصال بيانات المحمول ولكن لا يستطيع الجهاز الاتصال بالإنترنت من خلال اتصال Wi-Fi، يتصل الجهاز بالإنترنت تلقائيًا عن طريق الاتصال ببيانات المحمول.
- : لتخصيص إعدادات شبكة Wi-Fi.

Wi-Fi Direct

يمكنك توصيل جهازك بأجهزة أخرى تدعم Wi-Fi Direct لمشاركة البيانات معها مباشرة. ولن تكون بحاجة إلى نقطة وصول. ويمكنك توصيل أكثر من جهازين باستخدام Wi-Fi Direct.


1 على شاشة الإعدادات، المس **الشبكات** > **Wi-Fi** > ⋮ > **خيارات Wi-Fi المتقدمة** > **Wi-Fi Direct**.

- تظهر الأجهزة القريبة التي تدعم Wi-Fi Direct تلقائيًا.

2 حدد جهازًا.

- يتم الاتصال عندما يقبل الجهاز طلب الاتصال.

- قد تُستنزف البطارية بصورة أسرع عند استخدام Wi-Fi Direct.



Bluetooth

يمكنك توصيل جهازك بأجهزة قريبة تدعم Bluetooth لتبادل البيانات معها. فقط قم بتوصيل جهازك بسماعة Bluetooth ولوحة مفاتيح؛ فهذا يتيح لك التحكم في الجهاز بطريقة أكثر سهولة.

الإقران مع جهاز آخر

1 على شاشة الإعدادات، المس **الشبكات** > **Bluetooth**.

2 اضغط لتنشيطه.

- تظهر الأجهزة المتوفرة تلقائيًا.
- لتحديث قائمة الأجهزة، المس **بحث**.

- يتم عرض فقط الأجهزة المعيّنة كمرئية بالقائمة.

3 حدد جهازًا من القائمة.

4 اتبع الإرشادات التي تظهر على الشاشة لإجراء المصادقة.

- يتم تخطي هذه الخطوة بالنسبة للأجهزة التي سبق الوصول إليها.

إرسال البيانات عبر Bluetooth

1 حدد ملفًا.

- يمكنك إرسال ملفات وسائط متعددة أو اسماء.

2 المس > **Bluetooth**.

3 حدد جهاز هدف للملف.

- يتم إرسال الملف بمجرد قبول الجهاز الهدف له.

- قد تختلف عمليات مشاركة الملفات تبعًا للملف.

بيانات الهاتف المحمول

يمكنك تشغيل بيانات الهاتف المحمول أو إيقاف تشغيلها. كما يمكنك إدارة استخدامك لها.

تشغيل بيانات الهاتف المحمول.

1 على شاشة الإعدادات، المس **الشبكات** > **بيانات الهاتف المحمول**.

2 اضغط لتنشيطه.

تخصيص إعدادات بيانات الهاتف المحمول

1 على شاشة الإعدادات، المس **الشبكات** > **بيانات الهاتف المحمول**.

2 قم بتخصيص الإعدادات التالية:

- **بيانات الهاتف المحمول**: قم بتعيينه لاستخدام اتصالات البيانات على شبكات المحمول.
- **تحديد استخدام بيانات الجوال**: لتعيين حد لاستخدام بيانات الهاتف المحمول لحظرها إذا تم بلوغ الحد.
- : لتخصيص إعدادات بيانات الهاتف المحمول.

إعدادات المكالمات

يمكنك تخصيص إعدادات الاتصال، كخيارات المكالمات الدولية والمكالمات الصوتية.

- قد لا يتم دعم بعض الميزات تبعًا للمنطقة أو مزود الخدمة.

1 على شاشة الإعدادات، المس **الشبكات** > **إعدادات المكالمات**.

2 قم بتخصيص الإعدادات.

الربط


اتصال USB

يمكنك توصيل الجهاز بجهاز آخر عبر USB ومشاركة بيانات الهاتف المحمول.

1 قم بتوصيل جهازك بالأجهزة الأخرى عبر كيبل USB.

2 في شاشة الإعدادات، اضغط **الشبكات** > **الربط** > **اتصال USB** ثم اضغط لتنشيطه.

- يستخدم هذا الخيار بيانات الهاتف المحمول، وقد يتم فرض رسوم على استخدامها تبعًا لخطة التسعير. استشر مزود الخدمة الخاص بك لمزيد من المعلومات.
- عند التوصيل بجهاز كمبيوتر، قم بتنزيل برنامج تشغيل USB من الموقع *www.lg.com* وتثبيته على جهاز الكمبيوتر.
- لا يمكنك إرسال أو تلقي الملفات بين جهازك والكمبيوتر أثناء تشغيل اتصال USB. لذا يتعين عليك إيقاف اتصال USB لإرسال أو استلام الملفات.
- أنظمة التشغيل التي تدعم الربط هي Window XP أو أعلى أو Linux.



نقطة Wi-Fi المحمولة

يمكنك ضبط جهازك ليعمل كموجه لاسلكي بحيث يمكن للأجهزة الأخرى الاتصال بالإنترنت عبر استخدام بيانات هاتفك المحمول.


1 في شاشة الإعدادات، اضغط **الشبكات** > **الربط** > **نقطة Wi-Fi المحمولة** ثم اضغط لتنشيطه.

2 المس **قم بضبط نقطة الاتصال Wi-Fi**، وأدخل معرف Wi-Fi (SSID) وكلمة المرور.

3 قم بتشغيل Wi-Fi على الجهاز الآخر ثم حدد اسم شبكة الجهاز من قائمة Wi-Fi.

4 أدخل كلمة مرور الشبكة.

- يستخدم هذا الخيار بيانات الهاتف المحمول، وقد يتم فرض رسوم على استخدامها تبعًا لخطة التسعير. استشر مزود الخدمة الخاص بك لمزيد من المعلومات.
- تتوفر المزيد من المعلومات على موقع الويب التالي:
  http://www.android.com/tether#wifi



ربط Bluetooth

يمكن لجهاز متصل عن طريق Bluetooth أن يقوم بالاتصال بالإنترنت عبر استخدام اتصال بيانات هاتفك المحمول.

1 في شاشة الإعدادات، اضغط **الشبكات** > **الربط** > **ربط Bluetooth** ثم اضغط لتنشيطه.

2 قم بتشغيل Bluetooth على الجهازين لإقرانهما.

- يستخدم هذا الخيار بيانات الهاتف المحمول، وقد يتم فرض رسوم على استخدامها تبعًا لخطة التسعير. استشر مزود الخدمة الخاص بك لمزيد من المعلومات.
- تتوفر المزيد من المعلومات على موقع الويب التالي:
  http://www.android.com/tether#Bluetooth_tethering

مساعدة

يمكنك عرض تعليمات عن استخدام الربط بالإنترنت ونقاط الاتصال.

على شاشة الإعدادات، المس **الشبكات** > **الربط** > **مساعدة**.

المزيد

وضع الرحلات الجوية

يمكنك إيقاف وظائف بيانات الهاتف المحمول والمكالمة. وعندما يكون هذا الوضع قيد التشغيل، تظل الوظائف التي لا تتضمن بيانات، كتشغيل الموسيقي والألعاب، متاحة.

1 على شاشة الإعدادات، المس **الشبكات** > **المزيد** > **وضع الرحلات الجوية**.

2 المس **تشغيل** على شاشة التأكيد.

شبكات الهاتف

يمكنك تخصيص إعدادات شبكات الهاتف المحمول.

1 على شاشة الإعدادات، المس **الشبكات** > **المزيد** > **شبكات الهاتف**.

2 قم بتخصيص الإعدادات التالية:

- **وضع الشبكة**: لتحديد نوع الشبكة.
- **أسماء نقاط الوصول**: لعرض نقطة الوصول أو تغييرها لاستخدام خدمات بيانات الهاتف المحمول. ولتغيير نقطة الوصول، حدد خيارًا من قائمة نقاط الوصول.
- **مشغلو الشبكة**: للبحث عن مشغلي الشبكة والاتصال بالشبكة تلقائيًا.

VPN

يمكنك الاتصال بشبكة ظاهرية آمنة، مثل intranet. كما يمكنك إدارة الشبكات الظاهرية الخاصة المتصلة.

إضافة شبكة ظاهرية خاصة (VPN)

1 على شاشة الإعدادات، المس **الشبكات** > **المزيد** > **VPN**.

2 المس **إضافة VPN**.

- تكون هذه الميزة متاحة في حالة تنشيط قفل الشاشة فقط. إذا تم إلغاء وظيفة قفل الشاشة، فستظهر شاشة الإشعار. اضغط **تغيير** من شاشة الإشعار لتنشيط قفل الشاشة. انظر إعداد قفل الشاشة لمعرفة التفاصيل.

3 أدخل تفاصيل الشبكة الظاهرية الخاصة (VPN)، ثم المس **حفظ**.

تكوين إعدادات الشبكة الظاهرية الخاصة (VPN)

1 حدد شبكة ظاهرية خاصة (VPN) من قائمة **شبكات VPN**.

2 أدخل تفاصيل حساب مستخدم VPN ثم المس **اتصال**.

- لحفظ تفاصيل الحساب، حدد خانة الاختيار **حفظ معلومات الحساب**.

طباعة

يمكنك توصيل جهازك بطابعة Bluetooth وطباعة الصور أو المستندات الموجودة على الجهاز.

1 على شاشة الإعدادات، المس **الشبكات** > **المزيد** > **طباعة**.

- إذا كانت الطابعة المطلوبة غير موجودة في القائمة، فقم بتثبيت برنامج تشغيل الطابعة من متجر التطبيقات.

2 اضغط لتنشيطه.

3 حدد طابعة من شاشة قائمة الطابعات.

- لإضافة طابعة، المس ⋮ > **إضافة طابعة**.
- للبحث عن اسم طابعة، المس ⋮ > **بحث**.
- المس ⋮ > **الإعدادات** من شاشة قائمة الطابعات.

4 حدد ملفًا ثم المس ⋮ > **طباعة**.

- تتم طباعة المستند.

• إذا لم يكن لديك حساب على Google، فالمس **إضافة حساب** لإنشاء حساب.

الصوت و الإشعار

يمكنك تخصيص إعدادات الصوت والاهتزاز والإشعار.

في شاشة الإعدادات، المس **الصوت و الإشعار** وقم بتخصيص الإعدادات التالية:

- **أوضاع الصوت**: قم بتغيير وضع الصوت إلى **الصوت** أو **اهتزاز فقط** أو **صامت**.
- **مستوى الصوت**: لضبط مستوى الصوت لعناصر عديدة.
- **نغمة رنين SIM1/نغمة رنين SIM2**: لتحديد نغمة رنين للمكالمات الواردة. ولإضافة نغمات رنين أو حذفها.
- **معرف الرنين**: لإنشاء نغمة رنين للمكالمة الواردة من اسم معين.
- **صوت مع اهتزاز**: لضبط الجهاز على الاهتزاز وتشغيل نغمة رنين في آن واحد.
- **نوع اهتزاز SIM1/نوع اهتزاز SIM2**: يمكنك تحديد نوع الاهتزاز عند استقبال المكالمات.
- **عدم الإزعاج**: لضبط الوقت والنطاق ونوع التطبيق لاستلام رسائل الإشعار. ويمكنك استلام رسائل الإشعار في أيام محددة من الأسبوع فقط.
- **تأمين الشاشة**: لعرض رسائل إشعار على شاشة القفل أو إخفائها. يمكنك أيضًا إخفاء المعلومات الخاصة.
- **تطبيقات**: حدد التطبيقات التي يمكنها إظهار رسائل الإشعارات على الشاشة، وقم بتعيين أولويات تلك التطبيقات فيما يتعلق برسائل الإشعارات.
- **المزيد** > **صوت إشعار SIM1 /صوت إشعار SIM2**: لتحديد نغمة رنين الإشعار. ولضبط الموسيقى المحفوظة على الجهاز كنغمة رنين للإشعار.
- **المزيد** > **تأثيرات الصوت**: لتحديد مؤثر صوتي لتشغيله عندما تلمس لوحة الطلب أو لوحة المفاتيح، أو لتحديد خيار أو قفل الشاشة أو فتح قفلها.

إعدادات الشاشة

يمكنك تخصيص الإعدادات التفصيلية لكل نوع من أنواع الشاشات.

في شاشة الإعدادات، المس **إعدادات الشاشة** وقم بتخصيص الإعدادات التالية:

- **الشاشة الرئيسية**: لتخصيص إعدادات الشاشة الرئيسية. انظر *إعدادات الشاشة الرئيسية* لمعرفة التفاصيل.
- **تأمين الشاشة**: لتخصيص إعدادات شاشة القفل. انظر *إعدادات قفل الشاشة* لمعرفة التفاصيل.
- **سمة**: تحديد سمة شاشة لجهازك.
- **أزرار اللمس في الشاشة الرئيسية**: لإعادة ترتيب أزرار اللمس بالشاشة الرئيسية أو لتغيير ألوان الخلفية.
- **نوع الخط**: لتغيير الخط.
- **حجم الخط**: لتغيير حجم الخط.
- **نص عريض**: لجعل النص على الشاشة غامقًا.
- **تغيير حجم التطبيق**: ضبط حجم شاشة التطبيقات.
- **حجم العرض**: ضبط العناصر المعروضة على الشاشة بحجم مناسب لك. قد يتغير مكان بعض العناصر.
- **عرض مريح**: قم بضبط الجهاز لتقليل كمية الضوء الأزرق الخارج من الشاشة لتقليل تعرض العين للإجهاد.
- **السطوع**: استخدم الشريط المنزلق لتغيير سطوع شاشة الجهاز. ولضبط سطوع الشاشة تلقائيًا وفقًا لشدة الضوء المحيط، المس المفتاح **تلقائي**.
- **تلقائي**: قم بتعيين الجهاز كي يتم ضبط سطوع الشاشة تلقائيًا وفقًا لشدة الضوء المحيط.
- **تدوير الشاشة تلقائياً**: لتدوير الشاشة تلقائيًا وفقًا لاتجاه الجهاز.
- **مهلة الشاشة**: لإيقاف الشاشة تلقائيًا عند ترك الجهاز خاملاً لفترة زمنية محددة.
- **المزيد** > **تشغيل الشاشة**: يمكنك تشغيل الشاشة أو إيقاف تشغيلها عن طريق لمسها مرتين.
- **المزيد** > **شاشة التوقف**: لعرض شاشة توقف عند اتصال الجهاز بشاحن أو بحامل. حدد نوع شاشة التوقف لعرضها.

عامة

اللغة ولوحة المفاتيح

يمكنك تخصيص إعدادات اللغة ولوحة المفاتيح على جهازك.

1 على شاشة الإعدادات، المس **عامة** > **اللغة ولوحة المفاتيح**.

2 قم بتخصيص الإعدادات التالية:

- **اللغة**: حدد اللغة التي سيتم تطبيقها على الجهاز.
- **لوحة المفاتيح الحالية**: لعرض لوحة المفاتيح المستخدمة حاليًا. ويمكنك تحديد لوحة مفاتيح لاستخدامها عند إدخال نص.
- **لوحة مفاتيح LG**: لتخصيص إعدادات لوحة مفاتيح LG.
- **الكتابة بالصوت من Google**: لتكوين خيارات إملاء النصوص بواسطة Google.
- **تحويل النص إلى الكلام**: لتكوين إعدادات مخرجات تحويل النص إلى كلام منطوق.
- **سرعة المؤشر**: لضبط سرعة مؤشر الفأرة أو لوحة التتبع.
- **عكس الأزرار**: لتبديل زر الفأرة الأيمن كي يقوم بتنفيذ إجراءات المعالجة المباشرة الرئيسية.

الموقع

يمكنك تخصيص كيفية استخدام المعلومات الخاصة بموقعك من خلال تطبيقات معينة.

1 على شاشة الإعدادات، المس **عامة** > **الموقع**.

2 قم بتخصيص الإعدادات التالية:

- **الوضع**: لتحديد طريقة لتقديم معلومات الموقع.
- **طلب الموقع الحديث** : لعرض التطبيقات التي طلبت معلومات الموقع مؤخرًا.
- **طاقة منخفضة لتقدير الموقع**: لتعيين موقع الجهاز عن طريق خفض استهلاك الطاقة.
- **سجلّ المواقع في Google**: لتكوين إعدادات محفوظات موقع Google.
- **ميزة «مشاركة الموقع» من Google**: قم بمشاركة موقعك في الوقت الحقيقي مع الآخرين.

الحسابات والمزامنة

يمكنك إضافة الحسابات أو إدارتها بما في ذلك حساب Google. كما يمكنك مزامنة تطبيقات معينة أو معلومات المستخدم تلقائيًا.

1 على شاشة الإعدادات، المس **عامة** > **الحسابات والمزامنة**.

2 قم بتخصيص الإعدادات التالية:

- **مزامنة البيانات تلقائيا**: لمزامنة جميع المعلومات المسجلة تلقائيًا.
- **الحسابات**: لعرض قائمة بالحسابات المسجلة. ولعرض تفاصيل حساب ما أو تغييرها، المس الحساب.
- **إضافة حساب**: لإضافة حسابات.

إمكانية الوصول

يمكنك إدارة مكونات الوصول الإضافية المثبتة على جهازك.

1 على شاشة الإعدادات، المس **عامة** > **إمكانية الوصول**.

2 قم بتخصيص الإعدادات التالية:

- **الرؤية** > **TalkBack**: لضبط الجهاز بحيث يمكنه الإشعار بحالة الشاشة أو الإجراءات عبر الصوت.
- **الرؤية** > **إشعارات الرسائل/المكالمات الصوتية**: لضبط الجهاز على قراءة معلومات المتصل أو محتويات الرسالة عبر الكلام المنطوق.
- **الرؤية** > **حجم الخط**: لتغيير حجم الخط.
- **الرؤية** > **نص عريض**: لجعل النص على الشاشة غامقًا.
- **الرؤية** > **حجم العرض**: ضبط العناصر المعروضة على الشاشة بحجم مناسب لك. قد يتغير مكان بعض العناصر.
- **الرؤية** > **التكبير/التصغير باللمس**: لتكبير الشاشة أو تصغيرها عن طريق لمسها ثلاث مرات.
- **الرؤية** > **تكبير/تصغير النافذة**: التكبير أو التصغير داخل نافذة وعكس الألوان.
- **الرؤية** > **مؤشر فأرة كبير**: تكبير مؤشر الفأرة.
- **الرؤية** > **شاشة التباين المرتفع**: قم بتبديل لون الخلفية إلى اللون الأسود للحصول على شاشة ذات تباين مرتفع.
- **الرؤية** > **عكس لون الشاشة**: لزيادة تباين لون الشاشة للأشخاص الذين يعانون من ضعف البصر.

- **الرؤية > ضبط لون الشاشة**: لضبط لون الشاشة.
- **الرؤية > التدرج الرمادي**: لتبديل وضع الشاشة إلى وضع التدرج الرمادي.
- **الرؤية > إنهاء المكالمات باستخدام مفتاح التشغيل**: لإنهاء مكالمة بالضغط على مفتاح القفل/التشغيل.
- **سماع > الشرح**: لتشغيل خدمة الترجمة عند تشغيل مقاطع فيديو لضعاف السمع.
- **سماع > تنبيهات الفلاش**: ضبط الجهاز بحيث يمكنه إصدار وميض عند تلقي مكالمات واردة والرسائل ووجود تنبيهات.
- **سماع > كتم جميع الأصوات**: لكتم جميع الأصوات وخفض مستوى الصوت على جهاز الاستقبال.
- **سماع > قناة صوتية**: لتحديد نوع الصوت.
- **سماع > ضبط اتزان الصوت**: لضبط توازن مخرجات الصوت. استخدم الشريط المنزلق لتغيير التوازن.
- **الإعاقة الحركية والصعوبات المعرفية > Touch assistant**: لتشغيل لوحة اللمس لتسهيل استخدام الأزرار والإيماءات.
- **الإعاقة الحركية والصعوبات المعرفية > الإدخال باللمس**: أدخل النص عن طريق لمس الشاشة مع الاستمرار أو قم بتعديله من خلال لمس الشاشة فقط.
- **الإعاقة الحركية والصعوبات المعرفية > لوحة المفاتيح المادية**: لتخصيص إعدادات لوحة المفاتيح.
- **الإعاقة الحركية والصعوبات المعرفية > النقر تلقائياً على الفأرة**: النقر تلقائيًا على مؤشر الفأرة في حالة عدم وجود حركة.
- **الإعاقة الحركية والصعوبات المعرفية > المس باستمرار من أجل المكالمات**: للرد على المكالمات أو رفضها عن طريق اللمس المستمر لزر الاتصال بدلاً من سحبه.
- **الإعاقة الحركية والصعوبات المعرفية > مهلة الشاشة**: لإيقاف الشاشة تلقائيًا عند ترك الجهاز خاملاً لفترة زمنية محددة.
- **الإعاقة الحركية والصعوبات المعرفية > لمس مناطق التحكم**: لتحديد منطقة اللمس بحيث يمكن التحكم في جزء معين من الشاشة عن طريق الإدخال باللمس.
- **اختصار لمزايا إمكانية الوصول**: للوصول سريعًا إلى الوظائف التي يتكرر استخدامها عن طريق لمس ◯ ثلاث مرات.
- **تدوير الشاشة تلقائياً**: لتغيير اتجاه الشاشة تلقائيًا وفقًا للوضع الفعلي للجهاز.
- **الوصول عبر مفتاح التحويل**: لإنشاء مجموعات مفاتيح للتحكم في جهازك.

مفتاح الاختصار

يمكنك استخدام مفاتيح مستوى الصوت لتشغيل التطبيقات مباشرة عند إيقاف تشغيل الشاشة أو قفلها.

1 على شاشة الإعدادات، المس **عامة** > **مفتاح الاختصار**.

2 اضغط لتنشيطه.

- اضغط على مفتاح خفض مستوى الصوت مرتين (-) لتشغيل تطبيق الكاميرا عندما تكون الشاشة مقفلة أو تم إيقاف تشغيلها. واضغط على مفتاح رفع مستوى الصوت (+) مرتين لتشغيل Capture+.

خدمات Google

يمكنك استخدام إعدادات Google لإدارة إعدادات تطبيقات وحساب Google الخاصة بك.

على شاشة الإعدادات، المس **عامة** > **خدمات Google**.

الحماية

1 على شاشة الإعدادات، المس **عامة** > **الحماية**.

2 قم بتخصيص الإعدادات التالية:

- **قفل المحتويات**: اضبط طريقة لقفل الملفات في QuickMemo+.
- **تشفير وحدة تخزين بطاقة SD**: لتشفير بطاقة الذاكرة لمنع استخدامها على جهاز آخر. انظر تشفير بطاقة الذاكرة لمعرفة التفاصيل.
- **بدء تشغيل آمن**: يتيح حماية جهازك باستخدام قفل عند تشغيله. انظر إعدادات بدء تشغيل آمن لمعرفة التفاصيل.
- **إعداد قفل بطاقة SIM**: لقفل بطاقة USIM أو فتح قفلها أو لتغيير كلمة المرور (رمز PIN).
- **جعل كلمات المرور مرئية**: لعرض كلمة المرور أثناء إدخالها.
- **مديرو الهاتف**: للسماح بامتيازات تقييد التحكم في الجهاز أو استخدامه على تطبيقات خاصة.
- **مصادر غير معروفة**: للسماح بتثبيت تطبيقات من بين تطبيقات غير تابعة لمتجر Play.
- **حماية بيانات الاعتماد**: لعرض نوع المخزن الذي سيتم حفظ شهادة الأمان به.
- **إدارة الشهادة**: لإدارة شهادة الأمان المحفوظة بالجهاز.
- **Trust agents**: لعرض التطبيقات العميلة الموثوقة المثبتة على الجهاز.

- **تثبيت الشاشة**: لتثبيت شاشة التطبيقات بحيث يمكن استخدام التطبيق النشط حاليًا فقط.
- **الوصول إلى الاستخدام**: لعرض تفاصيل استخدام التطبيقات على الجهاز.

التاريخ والوقت

يمكنك تخصيص إعدادات التاريخ والوقت على جهازك.

1 على شاشة الإعدادات، المس **عامة** > **التاريخ والوقت**.

2 قم بتخصيص الإعدادات.

التخزين

يمكنك عرض وإدارة التخزين الداخلي على الجهاز أو مساحة التخزين على بطاقة الذاكرة.

1 على شاشة الإعدادات، المس **عامة** > **التخزين**.

2 قم بتخصيص الإعدادات التالية:

- **تخزين الجهاز**: لعرض إجمالي مساحة التخزين والمساحة المتوفرة في التخزين الداخلي على الجهاز. ويمكنك عرض قائمة بالتطبيقات قيد الاستخدام وبسعة التخزين الخاصة بكل تطبيق.
- **وحدة تخزين نقالة**: لعرض إجمالي مساحة التخزين والمساحة المتوفرة ببطاقة الذاكرة. يظهر هذا الخيار فقط عند إدخال بطاقة الذاكرة. ولإخراج بطاقة الذاكرة، المس ⏏.

البطارية وتوفير الطاقة

يمكنك عرض معلومات البطارية الحالية أو تشغيل وضع توفير الطاقة.

1 على شاشة الإعدادات، المس **عامة** > **البطارية وتوفير الطاقة**.

2 قم بتخصيص الإعدادات التالية:

- **استخدام البطارية**: لعرض تفاصيل استخدام البطارية. ولعرض مزيد من التفاصيل، حدد عنصرًا محددًا.
- **النسبة المئوية للبطارية موجودة على شريط الحالة**: لعرض مستوى طاقة البطارية المتبقية كنسبة مئوية على شريط الحالة.
- **توفير الطاقة**: لتقليل استهلاك طاقة البطارية عن طريق خفض إعدادات الجهاز كسطوع الشاشة والسرعة وشدة الاهتزاز. يعرض شريط الحالة عندما يكون وضع توفير الطاقة قيد التشغيل.
- **توفيرالبطارية أثناء تشغيل الألعاب**: لضبط جودة الفيديو لتقليل استهلاك طاقة البطارية عند تشغيل ألعاب.

الذاكرة

يمكنك عرض متوسط استخدام الذاكرة خلال فترة زمنية معينة عندما تكون الذاكرة قيد التشغيل بواسطة تطبيق.

1 على شاشة الإعدادات، المس **عامة** > **الذاكرة**.

2 المس ▼ لضبط فترة الوقت لاسترداد البيانات.

Smart Doctor

يمكنك استخدام Smart Doctor لتشخيص حالة الجهاز وتحسينها.

على شاشة الإعدادات، المس **عامة** > **Smart Doctor**.

التطبيقات

يمكنك عرض قائمة بالتطبيقات المثبتة. قم بإيقاف تشغيل التطبيقات أو حذفها، إذا لزم الأمر.

1 على شاشة الإعدادات، المس **عامة** > **التطبيقات**.

2 حدد تطبيقًا وقم بتنفيذ الإجراءات.

نسخ إحتياطي وإعادة الضبط

يمكنك نسخ البيانات المحفوظة على جهازك إلى حساب أو جهاز آخر احتياطيًا؛ فأعد ضبط الجهاز إذا لزم الأمر.

1 على شاشة الإعدادات، المس **عامة** > **نسخ إحتياطي وإعادة الضبط**.

2 قم بتخصيص الإعدادات التالية:

- **LG Mobile Switch**: نقل البيانات والرسائل المحفوظة والصور والشاشات الرئيسية والبيانات الأخرى بسهولة إلى جهاز جديد. انظر *LG Mobile Switch* لمعرفة التفاصيل.
- **النسخ الاحتياطي والاستعادة**: لنسخ بيانات جهازك احتياطيًا أو استعادة البيانات على جهازك من نسخة احتياطية.
- **نسخ احتياطي لبياناتي**: لنسخ بيانات التطبيق وكلمة مرور Wi-Fi والإعدادات الأخرى إلى خادم Google احتياطيًا.
- **الحساب الاحتياطي**: لعرض الحساب الاحتياطي الحالي قيد الاستخدام.
- **استعادة تلقائية**: لاستعادة الإعدادات والبيانات الاحتياطية تلقائيًا عند إعادة تثبيت التطبيق.

- **إعادة ضبط إعدادات الشبكة**: لإعادة ضبط Wi-Fi وBluetooth وإعدادات الشبكة الأخرى.
- **إعادة ضبط بيانات الشركة المصنعة**: لإعادة ضبط جميع الإعدادات الخاصة بالجهاز وحذف البيانات.

- ستؤدي إعادة ضبط جهازك إلى حذف جميع البيانات الموجودة به. ما عليك سوى إدخال اسم جهازك وحساب Google والمعلومات الأولية الأخرى مرة ثانية.

حول الهاتف

يمكنك عرض المعلومات المتعلقة بجهازك كالاسم والحالة وتفاصيل البرنامج والمعلومات القانونية.

على شاشة الإعدادات، المس **عامة** > **حول الهاتف** لعرض المعلومات.

التنظيم والسلامة

يمكنك عرض العلامات التنظيمية والمعلومات المتعلقة بها على جهازك.

على شاشة الإعدادات، المس **عامة** > **التنظيم والسلامة**.

05

الملحق

إعدادات لغة LG

حدد اللغة التي ترغب في استخدامها على جهازك.

- المس ◯ > **الإعدادات** > **عامة** > **اللغة ولوحة المفاتيح** > **اللغة** > **إضافة لغة**، وحدد لغة.
  - المس ☰ مع الاستمرار واسحبها إلى أعلى قائمة اللغات لتعيينها كلغة افتراضية.

LG Bridge

نظرة عامة على LG Bridge

LG Bridge هو تطبيق يساعدك على إدارة الصور والموسيقى ومقاطع الفيديو والمستندات المحفوظة على هاتف LG الذكي من الكمبيوتر الخاص بك بطريقة مريحة. يمكنك عمل نسخة احتياطية من الاسماء والصور وغيرها من البيانات على كمبيوتر أو تحديث برامج الجهاز.

- انظر تعليمات LG Bridge لمعرفة التفاصيل.
- قد تختلف الميزات المدعومة وفقًا للجهاز.
- برنامج تشغيل LG USB هو برنامج ضروري لتوصيل هاتف LG الذكي بالكمبيوتر ويتم تثبيته عندما تقوم بتثبيت LG Bridge.

وظائف LG Bridge

- يمكنك عمل نسخة احتياطية للبيانات على كمبيوتر أو استعادة البيانات من كمبيوتر إلى الجهاز عبر اتصال كيبل USB.
- يمكنك تحديث برامج الجهاز من كمبيوتر عبر اتصال كيبل USB.

تثبيت LG Bridge على كمبيوتر

1 انتقل إلى موقع *www.lg.com* من الكمبيوتر الخاص بك.

2 تحديد المنطقة.

3 انقر فوق **الدعم** > **البرمجيات والتحديثات**.

4 أدخل اسم جهازك.
أو
حدد بحسب فئة المنتج.

5 انتقل إلى **مزامنة الكمبيوتر الشخصي** > **LG Bridge** لتنزيل ملف الإعداد.

- انتقل إلى **تفاصيل** لعرض الحد الأدنى من متطلبات تثبيت تطبيق LG Bridge.

تحديث برامج الهاتف

تحديث برنامج هاتف LG المحمول من الإنترنت.

لمزيد من المعلومات حول استخدام هذه الوظيفة، يرجى زيارة *http://www.lg.com/common/index.jsp* وتحديد بلدك ولغتك.

تتيح هذه الميزة تحديث البرامج الثابتة على هاتفك بشكل ملائم إلى إصدارات أحدث من الإنترنت دون الحاجة إلى زيارة مركز الخدمة. ولا تتوفر هذه الميزة إلا عندما تتيح LG إصدارات أحدث من البرامج الثابتة لجهازك.

لأن تحديث برامج الهاتف المحمول الثابتة يتطلب عناية كاملة من المستخدم بشأن مدة عملية التحديث، يرجى منك فحص جميع الإرشادات والملاحظات التي تظهر مع كل خطوة قبل المتابعة. ويرجى أيضًا العلم بأن إزالة كيبل USB أثناء الترقية قد يحدث بسببه تلف خطير لهاتفك المحمول.

- تحتفظ LG بحقها في عدم توفير تحديثات البرامج الثابتة إلا للطرز المحددة ولا تضمن توفر إصدارات أحدث للبرامج الثابتة الخاصة بجميع طرز الهاتف المحمول.

تحديث برنامج هاتف LG المحمول عبر البث الهوائي (OTA)

تتيح هذه الميزة لك تحديث برامج الهاتف بطريقة مريحة إلى إصدار أحدث عبر OTA دون الحاجة إلى توصيل كيبل USB. ولا تتوفر هذه الميزة إلا عندما تتيح LG إصدارات أحدث من البرامج الثابتة لجهازك.

لتحديث برنامج الهاتف،

الإعدادات > **عامة** > **حول الهاتف** > **عام** > **مركز التحديث** > **تحديث البرنامج** > **تحقق الآن من التحديث**.

- قد يتم فقدان بياناتك الشخصية – بما في ذلك معلومات حساب Google وأية حسابات أخرى، وبيانات التطبيق/النظام وإعداداته، وأية تطبيقات تم تنزيلها، وترخيص DRM - الموجودة بمخزن الهاتف الداخلي أثناء عملية تحديث برامج الهاتف. ومن ثم فإن LG توصيك بنسخ بياناتك الشخصية احتياطيًا قبل تحديث برامج هاتفك. ولا تتحمل LG أية مسؤولية عن فقدان بياناتك الشخصية.
- تعتمد هذه الميزة على المنطقة أو مزود الخدمة.

الأسئلة المتداولة

يسرد هذا الفصل بعض المشكلات التي قد تواجهها عند استخدام هاتفك. وقد تتطلب بعض هذه المشكلات الاتصال بمزود الخدمة لأن ذلك سيكون أفضل من أن تقوم بحلها بنفسك.

خطأ في بطاقة SIM

تأكد من إدخال بطاقة SIM بالطريقة الصحيحة.

لا يوجد اتصال بالشبكة أو انقطع الاتصال بها

الإشارة ضعيفة. انتقل إلى نافذة أو مكان مفتوح.

أنت خارج نطاق تغطية شبكة شركة الاتصالات. انتقل إلى مكان آخر وتحقق من الشبكة.

إمكانية إجراء المكالمات غير متوفرة

شبكة جديدة غير مصرّح لها.

تحقق من عدم ضبط حظر المكالمات للرقم الذي تتلقى منه المكالمة.

تحقق من عدم ضبط حظر المكالمات للرقم الذي تطلبه.

يتعذّر تشغيل الجهاز

عندما تفرغ البطارية بالكامل، لن يعمل الجهاز.

اشحن البطارية بالكامل قبل تشغيل الجهاز.

خطأ في الشحن

تأكد من أن الجهاز قيد الشحن على درجة حرارة عادية.

تحقق من الشاحن ومن اتصاله بالجهاز.

استخدم فقط الملحقات المتوفرة في العلبة والمعتمدة من قبل LG.

تفرغ طاقة البطارية بشكل أسرع كلما مرّ وقت أطول على شرائها

عندما تعرّض الجهاز أو البطارية لدرجات حرارة منخفضة أو مرتفعة جدًا، فقد يتقلص عمر البطارية الافتراضي.

سيزيد استهلاك طاقة البطارية عند استخدام ميزات أو تطبيقات معيّنة مثل GPS أو الألعاب أو الإنترنت.

إن البطارية قابلة للاستهلاك وسيتقلص عمرها الافتراضي مع مرور الوقت.

تظهر رسائل الأخطاء عند تشغيل الكاميرا

اشحن البطارية.

وفّر مساحة فارغة في الذاكرة عبر نقل الملفات إلى كمبيوتر أو حذفها من الجهاز.

لإعادة تشغيل الجهاز.

في حال استمرار حدوث مشاكل عند استخدام تطبيق الكاميرا بعد اتباع هذه النصائح، فاتصل بمركز خدمة LG Electronics.

جودة الصورة رديئة

قد تختلف جودة الصور بحسب البيئة المحيطة وتقنيات التصوير الفوتوغرافي التي تستخدمها.

إذا كنت تلتقط الصور ومقاطع الفيديو، فستكون جودة العدسة ذات الزاوية القياسية أفضل من جودة العدسة ذات الزاوية الواسعة.

إذا كنت تلتقط الصور في مناطق مظلمة أو في الليل أو في الداخل، فقد تصبح الصورة مشوّشة أو قد تخرج عن نطاق بؤرة التركيز.

في حال واجهتك أي مشاكل، فأعِد ضبط الخيارات.

شاشة اللمس تستجيب ببطء أو بشكل غير صحيح

إذا قمت بتثبيت واقٍ لحماية الشاشة أو ملحقات اختيارية على شاشة اللمس، فقد لا تعمل هذه الأخيرة بشكل صحيح.

إذا كنت ترتدي قفازات أو لم تكن يداك نظيفتين عند لمس شاشة اللمس أو إذا ضغطت على الشاشة باستخدام أغراض حادة أو بأطراف أصابعك، فقد تتعطل شاشة اللمس.

قد تتعطل شاشة اللمس عند استخدامها في أماكن رطبة أو عند تعرضها للماء.

أعِد تشغيل الجهاز لمسح أي أخطاء مؤقتة في البرامج.

في حال تم خدش شاشة اللمس أو تعرضها للضرر، فيرجى زيارة أحد مراكز خدمة LG Electronics.

التعليق أو التجميد

إعادة تشغيل الجهاز

في حال تجمّدت شاشة الجهاز أو توقف الجهاز عن الاستجابة، فقد تحتاج إلى إغلاق التطبيقات أو إيقاف تشغيله، ثم تشغيله من جديد.

تشغيل الجهاز

يمكن إعادة تشغيل الجهاز لإعادة ضبطه في حال تجمّدت الشاشة أو توقفت الأزرار أو شاشة اللمس أو الجهاز عن الاستجابة.

لإعادة تشغيل الجهاز، ما عليك سوى الضغط باستمرار على مفتاحَي خفض مستوى الصوت والطاقة حتى يعود إلى العمل.

إعادة ضبط الجهاز

إذا لم تنجح الطرق المذكورة أعلاه في حلّ المشكلة، فقم بإعادة ضبط بيانات الشركة المصنّعة.

على شاشة الإعدادات، اضغط على عامة > نسخ احتياطي وإعادة الضبط > إعادة ضبط بيانات الشركة المصنعة.

* تقوم هذه الطريقة بإعادة ضبط كل إعدادات الجهاز وحذف البيانات. قبل إعادة ضبط بيانات الشركة المصنعة، لا تنسَ إجراء نسخ احتياطي لكل البيانات المهمة المخزّنة في الجهاز.
* إذا قمت بتسجيل حساب Google على الجهاز، فعليك تسجيل الدخول إلى حساب Google نفسه بعد إعادة ضبط الجهاز.

لم يتم تحديد موقع جهاز Bluetooth

احرص على أن تكون ميزة Bluetooth اللاسلكية نشطة على الجهاز.

احرص على أن تكون ميزة Bluetooth اللاسلكية نشطة على الجهاز الذي تريد الاتصال به.

احرص على أن يكون جهازك والجهاز الآخر الذي يعمل بتقنية Bluetooth ضمن الحد الأقصى لنطاق Bluetooth (10 أمتار).

إذا لم تحلّ النصائح أعلاه مشكلتك، فاتصل بمركز خدمة LG Electronics.

لا يتم إنشاء اتصال عندما تقوم بإنشاء اتصال بين الجهاز والكمبيوتر

احرص على أن يكون كيبل USB الذي تستخدمه متوافقًا مع الجهاز.

احرص على أن يكون برنامج التشغيل الصحيح مثبّتًا ومحدثًا على الكمبيوتر.

يتسبب التطبيق الذي تم تنزيله بحدوث الكثير من الأخطاء

ثمة مشاكل في التطبيق.

أزِل التطبيق وأعِد تثبيته.

دليل مكافحة السرقة

قم بإعداد جهازك لمنع الأشخاص الآخرين من استخدامه إذا كان قد تمت إعادة ضبطه على الإعدادات الافتراضية للمصنع دون إذن منك. فعلى سبيل المثال، إذا سُرق جهازك أو فُقد أو مُسحت بياناته، فإنه يمكن لأي شخص يعرف حسابك على Google أو معلومات شاشة القفل أن يستخدمه.

وكل ما تحتاج إليه لتتأكد أن جهازك محمي هو:

- ضبط قفل الشاشة: إذا فُقد جهازك أو سُرق لكنك كنت قد ضبطت قفل الشاشة، فإنه لا يمكن مسح بيانات الجهاز باستخدام قائمة الإعدادات إلا في حالة فتح قفل الشاشة.
- إضافة حساب Google على جهازك: إذا تم مسح بيانات جهازك لكن حسابك على Google موجود به، فلا يمكن للجهاز إنهاء عملية الإعداد حتى يتم إدخال معلومات حساب Google مرة أخرى.

بعد حماية جهازك، سيتعين عليك فتح قفل الشاشة أو إدخال كلمة مرور Google إذا كنت بحاجة إلى إعادة ضبط بيانات الشركة المصنعة ويضمن لك هذا أن تقوم أو يقوم شخص تثق به بعملية إعادة الضبط.

- لا تنسَ حسابك على Google وكلمة المرور التي أضفتها إلى جهازك قبل إعادة ضبط إعدادات الشركة المصنعة. وإذا لم تستطع توفير معلومات الحساب أثناء عملية الإعداد، فلن تكون قادرًا على استخدام الجهاز مطلقاً بعد إعادة ضبط بيانات الشركة المصنعة.

معلومات حول القواعد التنظيمية (رقم معرّف التنظيم، العلامات الإلكترونية، إلخ)

للحصول على تفاصيل حول القواعد التنظيمية، انتقل إلى **الإعدادات** > **عامة** > **التنظيم والسلامة**.

قطع من الزجاج المقسى

قطع الزجاج المقسى في هذا الجهاز غير دائمة وقد تتلف مع مرور الوقت.

- في حالة سقوط جهازك على سطح أو جسم صلب وتعرضه لتأثير كبير، يمكن أن يتلف الزجاج المقسى.
  في حالة حدوث ذلك، توقف عن استخدام جهازك على الفور واتصل بمركز خدمة عملاء LG.
- يمكنك شراء أغطية واقية لحماية جهازك من التلف من السوق.
  لاحظ أن هذه الأغطية الواقية ليست ضمن خدمة الضمان التي توفرها شركة LG Electronics وسلامتها غير مضمونة.

نسبة العرض إلى الارتفاع

يستخدم هذا الجهاز نسبة العرض إلى الارتفاع 18:9.

- قد لا تدعم بعض البرامج التي تم تنزيلها نسبة العرض إلى الارتفاع 18:9.
  في هذه الحالة، حدد النسبة المثالية لعرض وارتفاع الشاشة وفقًا للتطبيق أو استشر موفر التطبيق للحصول على مزيد من المعلومات.

المزيد من المعلومات

معلومات حول إشعار البرامج المفتوحة المصدر

للحصول على التعليمات البرمجية المصدر بموجب GPL و LGPL و MPL وتراخيص مفتوحة المصدر أخرى يتضمنها هذا المنتج، يرجى زيارة الموقع *http://opensource.lge.com*.

بالإضافة إلى التعليمات البرمجية المصدر، تتوفر كل أحكام الترخيص وإشعارات إخلاء المسؤولية وإشعارات حقوق النشر للتنزيل.

ستوفر LG Electronics أيضًا التعليمات البرمجية المصدر على قرص مضغوط بتكلفة تغطي هذا التوزيع (مثل تكلفة الوسائط والشحن والاستخدام) عند طلبها بإرسال بريد إلكتروني إلى *opensource@lge.com*. إن هذا العرض صالح لمدة ثلاث (3) سنوات اعتبارًا من تاريخ شراء المنتج.

علامات تجارية

- حقوق النشر © لعام 2017 مملوكة لشركة LG Electronics Inc. جميع الحقوق محفوظة. LG وشعار LG هما علامتان تجاريتان مسجلتان لشركة LG Group والكيانات التابعة لها.
- ™Google، و™Google Maps، و™Gmail، و™YouTube، و™Duo و ™Google Play هي علامات تجارية لشركة Google, Inc.
- ®Bluetooth هي علامة تجارية مسجلة لشركة Bluetooth SIG, Inc. عالميًا.
- ®Wi-Fi وشعار Wi-Fi هما علامتان تجاريتان مسجلتان لـ Wi-Fi Alliance.
- جميع العلامات التجارية وحقوق النشر ملك لأصحابها المعنيين.

بيان التوافق

تعلن **LG Electronics** بموجبه أن المنتج **LG-M700A** يتوافق مع المتطلبات الأساسية والأحكام الأخرى ذات الصلة الخاصة بالتوجيه **2014/53/EU**. يمكن العثور على نسخة من إعلان التوافق على العنوان التالي *http://www.lg.com/global/declaration*

التخلص من الأجهزة القديمة الخاصة بك



1. جميع الأجهزة الكهربائية والإلكترونية يجب التخلص منها بشكل منفصل عن النفايات المنزلية عبر منشآت التجميع المخصصة والمحددة من قبل الحكومة أو السلطات المحلية.
2. سيساعد التخلص من جهازك القديم بشكل صحيح في الحد من التبعات السلبية المحتملة للبيئة وصحة الإنسان.
3. لمزيد من المعلومات المفصلة حول التخلص من جهازك القديم، يرجى الاتصال بمكتب الشركة في مدينتك أو خدمة التخلص من النفايات أو بالمحل الذي اشتريت منه المنتج.

التخلص من البطاريات/المراكم التالفة



1. قد يتحد هذا الرمز مع الرموز الكيميائية مثل الزئبق (Hg) أو الكادميوم (Cd) أو الرصاص (Pb) إذا كانت البطارية تحتوي على أكثر من 0.0005% زئبق أو 0.002% كادميوم أو رصاص 0.004%.
2. يجب التخلص من جميع البطاريات/المراكم بشكل منفصل عن النفايات المنزلية عبر منشآت التجميع المخصصة والمحددة من قبل الحكومة أو السلطات المحلية.
3. سيساعد التخلص من البطاريات/المراكم القديمة بشكل صحيح في الحد من التبعات السلبية المحتملة للبيئة وصحة الإنسان والحيوان.
4. لمزيد من المعلومات المفصلة حول التخلص من البطاريات/المراكم القديمة يرجى الاتصال بمكتب الشركة في مدينتك أو خدمة التخلص من النفايات أو بالمحل الذي اشتريت منه المنتج.

About this user guide

Thank you for choosing this LG product. Please carefully read this user guide before using the device for the first time to ensure safe and proper use.

- Always use genuine LG accessories. The supplied items are designed only for this device and may not be compatible with other devices.
- This device is not suitable for people who have a visual impairment due to the touchscreen keyboard.
- Descriptions are based on the device default settings.
- Default apps on the device are subject to updates, and support for these apps may be withdrawn without prior notice. If you have any questions about an app provided with the device, please contact an LG Service Centre. For user-installed apps, please contact the relevant service provider.
- Modifying the device's operating system or installing software from unofficial sources may damage the device and lead to data corruption or data loss. Such actions will violate your LG licence agreement and void your warranty.
- Some content and illustrations may differ from your device, depending on the area, service provider, software version, or OS version, and are subject to change without prior notice.
- Software, audio, wallpaper, images, and other media supplied with your device are licenced for limited use. If you extract and use these materials for commercial or other purposes, you may be infringing copyright laws. As a user, you are fully responsible for the illegal use of media.
- Additional charges may incur for data services, such as messaging, uploading,downloading, auto-syncing and location services. To void additional charges, select a data plan suitable to your needs. Contact your service provider to obtain additional details.
- This guide is written in the local languages for each country. Depending on the language used, content may slightly differ.

Instructional notices

WARNING: Situations that could cause injury to the user and third parties.

CAUTION: Situations that may cause minor injury or damage to the device.

NOTE: Notices or additional information.

Table of contents

5 Guidelines for safe and efficient use

01

Custom-designed Features

13 Camera features
16 Gallery features
18 Making collage wallpapers
19 Face recognition
23 Multi-tasking feature
24 quick share

02

Basic Functions

26 Product components and accessories
27 Parts overview
29 Turning the power on or off
30 Installing the SIM card
32 Inserting the memory card
33 Removing the memory card
34 Battery
36 Touch screen
39 Home screen
48 Screen lock
52 Memory card encryption
53 Taking screenshots
54 Entering text
59 Do not disturb

03

Useful Apps

61 Installing and uninstalling apps
62 App trash
62 Phone
66 Messaging
67 Camera
79 Gallery
84 Contacts
86 QuickMemo+
88 Clock
90 Calendar
90 Tasks
91 Music
92 Calculator
92 E-mail
94 Audio Recorder
94 FM Radio
94 Cell Broadcast
95 File Manager
95 LG Mobile Switch
95 Downloads
96 LG SmartWorld
96 RemoteCall Service
97 Chrome
97 Google apps

04

Settings

101 Settings
101 Networks
111 Sound & notification
112 Display
113 General

05

Appendix

122 LG Language Settings
122 LG Bridge
123 Phone software update
125 FAQ
129 Anti-Theft Guide
130 Regulatory information (Regulation ID number, E-labeling, etc.)
130 Tempered glass parts
130 Aspect ratio
131 More information

Guidelines for safe and efficient use

Please read these simple guidelines. Not following these guidelines may be dangerous or illegal.

Should a fault occur, a software tool is built into your device that will gather a fault log. This tool gathers only data specific to the fault, such as signal strength, cell ID position in sudden call drop and applications loaded. The log is used only to help determine the cause of the fault. These logs are encrypted and can only be accessed by an authorised LG Repair centre should you need to return your device for repair.

Exposure to radio frequency energy

Radio wave exposure and Specific Absorption Rate (SAR) information.

This device has been designed to comply with applicable safety requirements for exposure to radio waves. These requirements are based on scientific guidelines that include safety margins designed to assure the safety of all persons, regardless of age and health.

- The radio wave exposure guidelines employ a unit of measurement known as the Specific Absorption Rate, or SAR. Tests for SAR are conducted using standardised methods with the device transmitting at its highest certified power level in all used frequency bands.
- While there may be differences between the SAR levels of various LG device models, they are all designed to meet the relevant guidelines for exposure to radio waves.
- The SAR limit recommended by the International Commission on Non-Ionizing Radiation Protection (ICNIRP) is 2 W/kg averaged over 10 g of tissue.
- The highest SAR value for this model tested for use at the ear is 0.384 W/kg (10 g) and when worn on the body is 1.540 W/kg (10 g).
- This device meets RF exposure guidelines when used either in the normal use position against the ear or when positioned at least 5 mm away from the body. When a carry case, belt clip or holder is used for body-worn operation, it should not contain metal and should position the product at least 5 mm away from your body. In order to transmit data files or messages, this device requires a quality connection to the network. In some cases, transmission of data files or messages may be delayed until such a connection is available. Ensure the above separation distance instructions are followed until the transmission is completed.

Product care and maintenance

- Use only in-box accessories which are authorised by LG. LG does not guarantee any damage or failure which is caused by third party accessories.
- Some contents and illustrations may differ from your device without prior notice.
- Do not disassemble this unit. Take it to a qualified service technician when repair work is required.
- Repairs under warranty, at LG's discretion, may include replacement parts or boards that are either new or reconditioned, provided that they have functionality equal to that of the parts being replaced.
- Keep away from electrical appliances such as TVs, radios and personal computers.
- The unit should be kept away from heat sources such as radiators or cookers.
- Do not drop.
- Do not subject this unit to mechanical vibration or shock.
- Switch off the device in any area where you are required to by special regulations. For example, do not use your device in hospitals as it may affect sensitive medical equipment.
- Do not handle the device with wet hands while it is being charged. It may cause an electric shock and can seriously damage your device.
- Do not charge a handset near flammable material as the handset can become hot and create a fire hazard.
- Use a dry cloth to clean the exterior of the unit (do not use solvents such as benzene, thinner or alcohol).
- Do not charge the device when it is on soft furnishings.
- The device should be charged in a well ventilated area.
- Do not subject this unit to excessive smoke or dust.
- Do not keep the device next to credit cards or transport tickets; it can affect the information on the magnetic strips.
- Do not tap the screen with a sharp object as it may damage the device.
- Do not expose the device to liquid or moisture.
- Use accessories like earphones cautiously. Do not touch the antenna unnecessarily.

- Do not use, touch or attempt to remove or fix broken, chipped or cracked glass. Damage to the glass display due to abuse or misuse is not covered under the warranty.
- Your device is an electronic device that generates heat during normal operation. Extremely prolonged, direct skin contact in the absence of adequate ventilation may result in discomfort or minor burns. Therefore, use care when handling your device during or immediately after operation.
- If your device gets wet, immediately unplug it to dry off completely. Do not attempt to accelerate the drying process with an external heating source, such as an oven, microwave or hair dryer.
- Please ensure that the product does not get in contact with liquid. Do not use or recharge the product if it is wet. Once the product becomes wet, the liquid damage indicator changes color. Please note that this will limit you from receiving any free-of-charge repair services provided under warranty.

Efficient device operation

Electronics devices

All devices may receive interference, which could affect performance.

- Do not use your device near medical equipment without requesting permission. Please consult your doctor to determine if operation of your device may interfere with the operation of your medical device.
- Pacemaker manufacturers recommend that you leave at least 15 cm of space between other devices and a pacemaker to avoid potential interference with the pacemaker.
- This device may produce a bright or flashing light.
- Some hearing aids might be disturbed by devices.
- Minor interference may affect TVs, radios, PCs etc.
- Use your device in temperatures between 0 °C and 35 °C, if possible. Exposing your device to extremely low or high temperatures may result in damage, malfunction, or even explosion.

Road safety

Check the laws and regulations on the use of devices in the area when you drive.

- Do not use a hand-held device while driving.
- Give full attention to driving.
- Pull off the road and park before making or answering a call if driving conditions so require.
- RF energy may affect some electronic systems in your vehicle such as car stereos and safety equipment.
- When your vehicle is equipped with an air bag, do not obstruct with installed or portable wireless equipment. It can cause the air bag to fail or cause serious injury due to improper performance.
- If you are listening to music whilst out and about, please ensure that the volume is at a reasonable level so that you are aware of your surroundings. This is of particular importance when near roads.

Avoid damage to your hearing



To prevent possible hearing damage, do not listen at high volume levels for long periods.

Damage to your hearing can occur if you are exposed to loud sound for long periods of time. We therefore recommend that you do not turn on or off the handset close to your ear. We also recommend that music and call volumes are set to a reasonable level.

- When using headphones, turn the volume down if you cannot hear the people speaking near you, or if the person sitting next to you can hear what you are listening to.

- Excessive sound pressure from earphones and headphones can cause hearing loss.

Glass Parts

Some parts of your device are made of glass. This glass could break if your device is dropped on a hard surface or receives a substantial impact. If the glass breaks, do not touch or attempt to remove it. Stop using your device until the glass is replaced by an authorised service provider.

Blasting area

Do not use the device where blasting is in progress. Observe restrictions and follow any regulations or rules.

Potentially explosive atmospheres

- Do not use your device at a refueling point.
- Do not use near fuel or chemicals.
- Do not transport or store flammable gas, liquid or explosives in the same compartment of your vehicle as your device or accessories.

In aircraft

Wireless devices can cause interference in aircraft.

- Turn your device off before boarding any aircraft.
- Do not use it on the ground without permission from the crew.

Children

Keep the device in a safe place out of the reach of small children. It includes small parts which may cause a choking hazard if detached.

Emergency calls

Emergency calls may not be available on all mobile networks. Therefore you should never depend solely on your device for emergency calls. Check with your local service provider.

Battery information and care

- You do not need to completely discharge the battery before recharging. Unlike other battery systems, there is no memory effect that could compromise the battery's performance.
- Use only LG batteries and chargers. LG chargers are designed to maximise the battery life.
- Do not disassemble or short-circuit the battery.
- Replace the battery when it no longer provides acceptable performance. The battery pack may be recharged hundreds of times before it needs replacing.
- Recharge the battery if it has not been used for a long time to maximise usability.
- Do not expose the battery charger to direct sunlight or use it in high humidity, such as in the bathroom.
- Do not leave the battery in hot or cold places, as this may deteriorate battery performance.
- Risk of explosion if battery is replaced by an incorrect type. Dispose of used batteries according to the instructions.
- Always unplug the charger from the wall socket after the device is fully charged to save unnecessary power consumption of the charger.
- Actual battery life will depend on network configuration, product settings, usage patterns, battery and environmental conditions.
- Make sure that no sharp-edged items such as animal's teeth or claws, come into contact with the battery. This could cause a fire.

Securing personal information

- Make sure to protect your personal information to prevent data leakage or misuse of sensitive information.
- Always back up important data while using the device. LG is not responsible for any data loss.
- Make sure to back up all data and reset the device when disposing of the device to prevent any misuse of sensitive information.
- Read the permission screen carefully while downloading applications.
- Be cautious using the applications that have access to multiple functions or to your personal information.
- Check your personal accounts regularly. If you find any sign of misuse of your personal information, ask your service provider to delete or change your account information.
- If your device is lost or stolen, change the password of your account to secure your personal information.
- Do not use applications from unknown sources.

Notice for Battery replacement

- For your safety, do not remove the battery incorporated in the product. If you need to replace the battery, take it to the nearest authorized LG Electronics service point or dealer for assistance.
- Li-Ion Battery is a hazardous component which can cause injury.
- Battery replacement by non-qualified professional can cause damage to your device.

01

Custom-designed Features


Camera features

Wide-angle camera

You can take photos or record videos with a wider range than your actual field of vision by using the wide-angle on the front camera.

Launch the Camera app, then tap [ ] / [ ] to switch between the standard and wide-angle.

Front camera



• See *Starting the camera* for details.

SQUARE camera mode

You can take multiple photos or videos in the form of a collage by using the front and rear cameras. Photos and videos can be saved with different layouts.

1 Launch the Camera app, then tap **AUTO** ( ) > **SQUARE** ( ).

2 Tap **MODE** and select the desired camera mode.


3 To take a photo, tap [ ]. To record a video, tap ■.

Snap shot

You can take a photo or record a video and preview it right away.

1 In the SQUARE mode, tap **MODE** > .

2 Tap to take photo. To record a video, tap .




Grid shot

You can take up to 4 photos organised in a square.

1 In the SQUARE mode, tap **MODE** > .

2 Tap to take photos simultaneously or sequentially depending on the displayed layout order.

3 Tap to save.



Match shot

You can take 2 photos at the same time or separately.

1 In the SQUARE mode, tap **MODE** > .

2 Tap / to take a photo at the same time or separately.
- Tap > to use a photo from Gallery as the first shot.

3 Tap to take photos.

4 Tap to save (if necessary).



Guide shot


You can take photos by following the pose of another photo.

1 In the SQUARE mode, tap **MODE** > .

2 Select from the poses on the right to choose the one you want to follow.

3 Tap to take a photo.

- Use the slide bar to control the background transparency.



Steady recording

You can use the Steady recording feature to minimise motion blur while recording a video.


Launch the Camera app, then tap **AUTO** (Ⓐ) or **SQUARE** (⊙) > ⚙ > **Steady recording** ⬭.

- See *Starting the camera* for details.

Gallery features

Floating button

To quickly move to the Home screen while viewing the Gallery in landscape orientation, touch and hold ◁, move your finger upward to ○, then release it.



- You can move the floating button's position by dragging it horizontally along the bottom part of the screen.

Related content

You can edit and customise related content in the Gallery.

1 While viewing a picture preview, tap .

2 When the icon related with the date you took the photo appears, touch the screen.



- You can view the photos related with the date you chose.



- Related content can be related to up to four combinations of 'Memories, Date, Place, Camera mode'

- Tap to save the related content as a video.
- Tap ⋮ to access additional options.

Making a GIF

You can easily make a GIF file using recorded video.

1 At the desired starting point while watching the video, tap ⋮ > **Create GIF**.

2 Select the length of the GIF you want to create.
- GIF is generated for the time selected from the current time.
- For videos less than 5 seconds, GIF images are automatically generated for the remaining time.

⚠ • The GIF making feature is provided for the user's creative activity. If you infringe other's copyright or defamation laws by using the GIF making feature, you may be liable for civil and criminal liability. Be sure to not duplicate or transfer work of others without permission. LG Electronics cannot accept any liability for the user's action.

Making collage wallpapers

You can make your own collage image to display it as a lock screen.

You can select multiple collage images as a wallpaper that changes each time you turn on or off the screen.

1 Tap ◯ > **Settings** > **Display** > **Lock screen** > **Wallpaper** > **Collage Wallpapers**.

2 Tap + and select the images you want to display as a collage.

3 Edit the slideshow as desired and tap **SET WALLPAPER**.



Face recognition

Face recognition overview

You can release the screen lock by using the saved facial data.

- This feature may be more vulnerable to security than the other screen locks such as Pattern, PIN, and Password.
- When a similar face or your photo image is used, the screen lock can be released.
- The recognised facial data is securely stored in your device.
- When the face recognition is selected for screen lock, you must enter the Pattern, PIN, or Password that has been used for face registration without directly using the face recognition after the power is turned on. Accordingly, be careful not to forget the specified value.
- If the device cannot detect your face, or you forgot the value specified for registration, visit the nearest LG Customer Service Centre with your device and ID card.

Precautions for face recognition

Face recognition accuracy may decrease in the following cases. To increase its accuracy, check the following before using the device.

- Whether your face is covered with a hat, eyeglasses, or mask, or your face is significantly different due to heavy makeup or beard.
- Whether there are fingerprints or foreign substances on the front of the camera lens, or your device cannot detect your face due to a too bright or dark light.

Registering facial data

Before use of the face recognition feature, register your facial data on your device.

1 Tap ◯ > **Settings** > **Display** > **Lock screen** > **Select screen lock** > **Allow face recognition**.

- To use this feature, the screen lock must have been set with a Pattern, PIN, or Password.
- When the screen lock is not set, register the data by following the onscreen instructions. See *Setting a screen lock* for details.

2 Raise your device in the front of your eyes.

3 Register your face by following on-screen instructions.
- Register your face in a room that is not too bright or dark.
- Position your entire face inside the guideline on the screen, and then adjust it by slowly moving up, down, left, or right.

4 When the face registration is done, tap **OK**.

Unlocking the screen with your face

You can release the screen lock with your face instead of Pattern, PIN, or Password.

1 Tap ◯ > **Settings** > **Display** > **Lock screen** > **Select screen lock**.

2 Unlock the screen according to the specified method.

3 Drag ⬭ to activate the face recognition feature.

Improving the face recognition

You can add facial data in various conditions to improve face recognition.

1 Tap ◯ > **Settings** > **Display** > **Lock screen** > **Face Recognition**.

2 Unlock the screen according to the specified method.

3 Select **Improve face recognition**.

4 Register your face by following on-screen instructions.

5 When the face registration is done, tap **OK**.

Deleting facial data

You can delete the registered facial data and register it again if the face recognition does not work properly.

1 Tap ◯ > **Settings** > **Display** > **Lock screen** > **Face Recognition**.

2 Unlock the screen according to the specified method.

3 Select **Delete face** to delete the facial data.

Unlocking the screen with your face when the screen is turned off

With the screen turned off, raise your device and look at the front of the screen. The device can detect your face and the screen is unlocked.

To deactivate this feature, follow the instruction below.

1 Tap ◯ > **Settings** > **Display** > **Lock screen** > **Face Recognition**.

2 Unlock the screen according to the specified method.

3 Drag **Allow when screen is off** to deactivate the feature.

- Face recognition feature is available only when the screen is locked.

Unlocking the screen with face recognition and then screen swiping

With the screen turned off, you can unlock the screen by performing face recognition and then swiping the screen.

1 Tap ◯ > **Settings** > **Display** > **Lock screen** > **Face Recognition**.

2 Unlock the screen according to the specified method.

3 Drag **Swipe to unlock after face recognized** to activate the feature.

Enhancing the face recognition

You can prevent your device from being unlocked by photos, images, or videos.

1 Tap ◯ > **Settings** > **Display** > **Lock screen** > **Face Recognition**.

2 Unlock the screen according to the specified method.

3 Drag **Advanced face recognition** to activate the feature.

- Face recognition speed may decrease when you activate this feature.

Multi-tasking feature


Multi window

You can use two apps at the same time by separating the screen into the multiple windows.

While using an app, touch and hold ☐ from the Home touch buttons, then select an app from the recently used apps list.

- You can use two apps displayed on the main screen at the same time.
- To stop the Multi window feature, touch and hold ⊟.





- The Multi window feature is not supported by some apps, including downloaded apps.

Overview screen

The Overview screen provides a preview of your recently used apps.

To view the list of recently used apps, tap ☐ on the Home, then tap the displayed app.


- Touch and hold an app and drag it to the top of the screen to start the app with the Multi window feature. You can also tap ⊟ at the top of each app.

quick share

You can share a photo or video to the app you want immediately after taking it.

1 Tap ◯ > , then take a photo or record a video.

2 Tap the app icon that appears on the screen to share it using that app. You can also swipe the icon towards the opposite direction to see what other apps you can use to share your photos and videos.



- The app displayed by the quick share icon may vary, depending on the type and frequency of access to the apps installed on the device.

02

Basic Functions

Product components and accessories


The following items are included with your device.

- Device
- Stereo headset
- USB cable
- Charger
- Quick Start Guide
- Ejection pin

- The items described above may be optional.
- The items supplied with the device and any available accessories may vary depending on the area and service provider.
- Always use genuine LG Electronics accessories. Using accessories made by other manufacturers may affect your device's call performance or cause malfunctions. This may not be covered by LG's repair service.

- If any of these basic items are missing, contact the dealer from which you purchased your device.
- To purchase additional basic items, contact an LG Customer Service Centre.
- To purchase optional items, contact an LG Customer Service Centre for available dealers.
- Some items in the product box are subject to change without notice.
- The appearance and specifications of your device are subject to change without notice.
- Device specifications may vary depending on the area or service provider.
- Be sure to use authentic accessories provided by LG Electronics. Using third-party accessories may damage the device or cause malfunctions.

Parts overview



- Proximity/Ambient light sensor
  - Proximity sensor: During a call, the proximity sensor turns off the screen and disables touch functionality when the device is in close proximity to the human body. It turns the screen back on and enables touch functionality when the device is outside a specific range.
  - Ambient light sensor: The ambient light sensor analyses the ambient light intensity when the auto-brightness control mode is turned on.
- Volume keys
  - Adjust the volume for ringtones, calls or notifications.
  - While using the Camera, gently press a Volume key to take a photo. To take continuous photos, press and hold the Volume key.
  - Press the Volume Down (-) key twice to launch the Camera app when the screen is locked or turned off. Press the Volume Up (+) key twice to launch Capture+.
- Power/Lock key
  - Briefly press the key when you want to turn the screen on or off.
  - Press and hold the key when you want to select a power control option.

- This device has a non-removable battery. Do not attempt to remove the back cover.
- Some functions may be restricted for access, depending on the device specifications.
- Do not put heavy objects on the device or sit on it. Failure to do so may damage the touch screen.
- Screen-protective film or accessories may interfere with the proximity sensor.
- If your device is wet or is being used in a humid place, the touch screen or buttons may not function properly.

Turning the power on or off

Turning the power on

When the power is turned off, press and hold the Power/Lock key.

- When the device is turned on for the first time, initial configuration takes place. The first booting time for the smart phone may be longer than usual.

Turning the power off

Press and hold the Power/Lock key, then select **Power off**.

Power control options

Press and hold the Power/Lock key, then select an option.


- **Power off**: Turn off the device.
- **Power off and restart**: Restart the device.
- **Turn on Airplane mode**: Block telecommunication-related functions, including making phone calls, messaging and browsing the Internet. Other functions remain available.

Installing the SIM card


Insert the SIM (Subscriber Identity Module) card provided by your service provider to start using your device.

⚠ • Be careful with the ejection pin since it has a sharp edge.


1 Insert the ejection pin into the hole on the card tray.




2 Pull out the card tray.



3 Put the SIM card on the card tray with the gold-coloured contacts facing downwards.
Put the primary SIM card on the SIM card tray 1 and the secondary SIM card on the SIM card tray 2.



4 Insert the card tray back into the slot.



- This device supports only Nano SIM cards.
- For problem-free performance, it is recommended to use the device with the correct type of SIM card. Always use a factory-made SIM card supplied by the operator.
- If you insert the card tray into your device while the card tray is wet, your device may be damaged. Always make sure the card tray is dry.

Precautions when using the SIM card

- Do not lose your SIM card. LG is not responsible for damage and other issues caused by loss or transfer of a SIM card.
- Be careful not to damage the SIM card when you insert or remove it.

Inserting the memory card


Insert the memory card into your device.

The device can support up to a 2 TB microSD card. Depending on the memory card manufacturer and type, some memory card may not be compatible with your device.

1 Insert the ejection pin into the hole on the card tray.

2 Pull out the card tray.

3 Put the memory card on the card tray with the gold-coloured contacts facing downwards.



4 Insert the card tray back into the slot.

- Some memory cards may not be fully compatible with the device. If you use an incompatible card, it may damage the device or the memory card, or corrupt the data stored in it.

- The memory card is an optional item and is sold separately.
- Frequent writing and erasing of data may shorten the memory card lifespan.

Removing the memory card

Unmount the memory card before removing it for safety.

1 Tap ◯ > **Settings** > **General** > **Storage** > ⏏.

2 Insert the ejection pin into the hole on the card tray.

3 Pull out the card tray and remove the memory card.


- Do not remove the memory card while the device is transferring or accessing information. This may cause data to be lost or corrupted, or may damage the memory card or the device. LG is not responsible for losses that result from the abuse or improper use of memory cards, including the loss of data.

Battery

Charging the battery

Before using the device, fully charge the battery.

Connect one end of the charging cable to the charger, insert the other end of the cable into the cable port, and then plug the charger into a power socket.



- Do not charge while the device or charging cable is wet or contains moisture. This can cause fire, electric shock, injury or damage to device.
- Make sure to use the USB cable provided with your device.
- Make sure to use an LG-approved charger and charging cable. Charging the battery with a third-party charger may cause the battery to explode or may damage the device.
- Using the device when it is charging may cause electric shock. To use the device, stop charging it.
- This device has a non-removable battery. Do not attempt to remove the back cover.

- Remove the charger from the power socket after the device is fully charged. This prevents unnecessary power consumption.
- Another way to charge the battery is by connecting a USB cable between the device and a desktop or laptop computer. This may take a longer time than plugging the adapter to a wall outlet.
- Do not charge the battery by using a USB hub that is unable to maintain the rated voltage. Charging may fail or unintentionally stop.

Precautions when using the device

- Ensure that the inside of the device does not make contact with a metallic object or water.
- Make sure to use the USB cable provided; do not use third party USB cables or chargers with your device. The LG limited warranty does not cover the use of third party accessories.
- Failure to follow the instructions in this guide and improper use may damage the device.

Using the battery efficiently

Battery lifespan may decrease if you keep many apps and functions running simultaneously and continuously.

Cancel background operations to increase battery life.

To minimise battery consumption, follow these tips:


- Turn off the **Bluetooth®** or Wi-Fi network function when not using them.
- Set the screen timeout to as short a time as possible.
- Minimise the screen brightness.
- Set a screen lock when the device is not used.
- Check the battery usage details and close any downloaded apps that are draining the battery.

Touch screen

You can familiarise yourself with how to control your device by using touch screen gestures.


Tapping

Lightly tap with your fingertip to select or run an app or option.




Touching and holding

Touch and hold for several seconds to display a menu with available options.




Double-tapping

Tap twice quickly to zoom in or out on a web page or map.




Dragging

Touch and hold an item, such as an app or widget, then move your finger to another location in a controlled motion. You can use this gesture to move an item.




Swiping

Touch the screen with your finger and move it quickly without pausing. You can use this gesture to scroll through a list, a web page, photos, screens, and more.



Pinching and spreading

Pinch two fingers to zoom out such as on a photo or map. To zoom in, spread your fingers apart.



⚠ • Do not expose the touch screen to excessive physical shock. You might damage the touch sensor.

- A touch screen failure may occur if you use the device near a magnetic, metallic or conductive material.
- If you use the device under bright lights, such as direct sunlight, the screen may not be visible, depending on your position. Use the device in a shady location or a location with an ambient light that is not too bright and bright enough to read books.
- Do not press the screen with excessive force.
- Gently tap with your fingertip on the option you want.
- Touch control may not work properly if you tap while wearing a glove or by using the tip of your fingernail.
- Touch control may not work properly if the screen is moist or wet.
- The touch screen may not function properly if a screen-protective film or accessory purchased from a third party store is attached to the device.
- Displaying a static image for extended periods of time may result in afterimages or screen burn-in. Turn off the screen when you do not use the device for a long time.

Home screen


Home screen overview

The Home screen is the starting point for accessing various functions and apps on your device. Tap ◯ on any screen to directly go to the Home screen.

You can manage all apps and widgets on the Home screen. Swipe the screen left or right to view all installed apps at a glance.

Home screen layout

You can view all apps and organise widgets and folders on the Home screen.



- The Home screen may vary, depending on the service provider or software version.

- **Status bar**: View status icons, the time and the battery level.
- **Weather widget**: View the information of weather and time for a specific area.
- **Google search widget**: Perform a Google search by inputting spoken or written keywords.
- **Folder**: Create folders to group apps by your preferences.
- **Page icon**: Display the total number of Home screen canvases. Tap the desired page icon to go to the page you selected. The icon reflecting the current canvas will be highlighted.


- **Quick access area**: Fix main apps at the bottom of the screen so that they can be accessed from any Home screen canvas.
- **Home touch buttons**
  - ◁ : Return to the previous screen. Close the keypad or pop-up windows.
  - ◯ : Tap to go to the Home screen. To launch Google search, touch and hold.
  - □ : Tap to view a list of recently used apps or run an app from the list. To delete all the recently used apps, tap **CLEAR ALL**. To use two apps at the same time with the Multi window feature, touch and hold the button while using an app.
  - : Choose which SIM card you are going to use. Touch and hold to configure the Dual SIM card settings.

Editing the Home touch buttons

You can rearrange the Home touch buttons or add frequently used functions to the Home touch buttons area.

Tap ◯ > **Settings** > **Display** > **Home touch buttons** > **Button combination** and customise the settings.

- Several functions, including Notification panel and Capture+, are provided. A maximum of five items can be added.



Status icons

When there is a notification for an unread message, calendar event or alarm, the status bar displays the corresponding notification icon. Check your device's status by viewing notification icons displayed on the status bar.


	No signal
	Data is being transmitted over the network
	Alarm is set
	Vibrate mode is on
	Bluetooth is on
	Connected to a computer via USB
	Battery level
	Airplane mode is on
	Missed calls
	Wi-Fi is connected
	Mute mode is on
	GPS is on
	Hotspot is on
	No SIM card

- Some of these icons may appear differently or may not appear at all, depending on the device's status. Refer to the icons according to the actual environment and area in which you are using the device and your service provider.
- Displayed icons may vary, depending on the area or service provider.

Notifications panel

You can open the notifications panel by dragging the status bar downward on the main screen.

- To open the quick access icons list, drag the notifications panel downwards or tap ⌄.
- To rearrange, add, or remove icons, tap **EDIT**.
- If you touch and hold the icon, the settings screen for the corresponding function appears.



Switching the screen orientation

You can set the screen orientation to automatically switch according to the device's physical orientation.

On the notification panel, tap **Rotation** from the quick access icon list.

You can also tap ◯ > **Settings** > **Display** and activate **Auto-rotate screen**.




Editing the Home screen

On the Home screen, touch and hold on an empty space, then select the desired action from below.

- To rearrange the Home screen canvases, touch and hold on a canvas, then drag it to another location.
- To add a widget to the Home screen, touch and hold on a blank area of the Home screen, then select **Widgets**.
- To change a theme, touch and hold on a blank area of the Home screen, then select **Theme**.

  You can also tap ◯ > **Settings** > **Display** > **Theme**, then select a theme to apply to the device.

- To configure the Home screen settings, touch and hold on a blank area of the Home screen, then select **Home screen settings**. See *Home screen settings* for details.
- To view or reinstall the uninstalled apps, touch and hold on a blank area of the Home screen, then select **App trash**. See *App trash* for details.
- To change the default screen, touch and hold on a blank area of the Home screen, move to desired screen, tap , then tap the screen once more.




Viewing the background theme

You can view only the background image by hiding the apps and widgets on the Home screen.

Spread two fingers apart on the Home screen.

- To return to the original screen, which displays apps and widgets, pinch your fingers on the Home screen or tap ◁.



Moving apps on the Home screen

On the Home screen, touch and hold an app, then drag it to another location.

- To keep frequently used apps at the bottom of the Home screen, touch and hold an app, then drag it to the quick access area at the bottom.
- To remove an icon from the quick access area, drag the icon to the Home screen.

Using folders from the Home screen

Creating folders

On the Home screen, touch and hold an app, then drag it over another app.

- A new folder is created and the apps are added to the folder.

Editing folders

On the Home screen, tap a folder and do one of the following actions.

- To edit the folder name and colour, tap the folder name.
- To add apps, touch and hold an app, then drag it over the folder and release it.
- To remove an app from the folder, touch and hold the app and drag it to outside the folder. If the removed app is the only one app that existed in the folder, the folder is removed automatically.
- You can also add or remove apps after tapping + in the folder.

Home screen settings

You can customise Home screen settings.

1 Tap ◯ > **Settings** > **Display** > **Home screen**.

2 Customise the following settings:

- **Select Home**: Select a Home screen mode.
- **Wallpaper**: Change the Home screen background wallpaper.
- **Screen swipe effect**: Select an effect to apply when the Home screen canvas switches.
- **Icon shape**: Choose if you want icons to have square or rounded corners.
- **Sort apps by**: Set how apps are sorted on the Home screen.

- **Grid**: Change the app arrangement mode for the Home screen.
- **Hide apps**: Select which apps you want to hide from the Home screen.
- **Continuous loop**: Enable to allow continuous Home screen scrolling (loop back to first screen after the last screen).
- **Search**: Search by swiping down on the Home screen.

Screen lock

Screen lock overview

Your device's screen turns off and locks itself if you press the Power/Lock key. This also happens after the device is left idle for a specified period of time.

If you press the Power/Lock key when a screen lock is not set, the Home screen appears immediately.

To ensure security and prevent unwanted access to your device, set a screen lock.



- Screen lock prevents unnecessary touch input on the device screen and reduces battery consumption. We recommend that you activate the screen lock while not using the device.

Setting a screen lock

There are several options available for configuring the screen lock settings.

1 Tap ◯ > **Settings** > **Display** > **Lock screen** > **Select screen lock** and then select the method you prefer.

2 Customise the following settings:

- **None**: Deactivate the screen lock function.
- **Swipe**: Swipe on the screen to unlock the screen.
- **Pattern**: Draw a pattern to unlock the screen.
- **PIN**: Enter a numeric password to unlock the screen.
- **Password**: Enter an alphanumeric password to unlock the screen.
- **Allow face recognition**: Unlock the screen by recognising your face.



- If you incorrectly attempt to unlock the device 5 times, the screen is blocked for 30 seconds.

Secure start-up settings

When you select Pattern, PIN or Password as a screen lock method, you can configure your device to be locked whenever turning on the device in order to secure your data.

- You cannot use all functions, except for emergency calls until you unlock the device.
- If you forget your decryption password, you cannot restore encrypted data and personal information.

Lock screen settings

You can customise the following lock screen settings.

1 Tap ◯ > **Settings** > **Display** > **Lock screen**.

2 Customise the following settings:

- **Select screen lock**: Select a screen lock method.
- **Face Recognition**: Unlock the lock screen by recognising your face. See *Face recognition overview* for details.
- **Smart Lock**: Select trusted items so that if one of them occurs, the device is automatically unlocked.
- **Wallpaper**: Change the lock screen background wallpaper.
- **Clock**: Select the position of the clock on the locked screen.
- **Shortcuts**: Add an app shortcut and directly access the app from the lock screen by dragging the app shortcut on the screen.
- **Screen swipe effect**: Set screen transition effects to apply when the screen is unlocked.
- **Contact info for lost phone**: Display emergency contact information on the lock screen.
- **Lock timer**: Set the amount of idle time after which the device automatically locks.
- **Power key instantly locks**: Instantly lock the screen when the Power/Lock key is pressed.



- Available setting items may vary, depending on the selected screen lock method.

KnockON

You can turn the screen on or off by double-tapping the screen.

- This option is available only on the Home screen provided by LG. It may not function properly on a custom launcher or on the Home screen installed by the user.
- When tapping the screen, use your fingertip. Do not use a fingernail.
- To use the KnockON feature, make sure that the proximity/light sensor is not blocked by a sticker or any other foreign substance.

Turning on the screen

Double-tap the middle of the screen.

- Tapping the top or bottom of the screen may decrease the recognition rate.

Turning off the screen

Double-tap on an empty space on the Home screen and Lock screen.

You can also double-tap an empty space on the status bar.

Memory card encryption

You can encrypt and protect data saved on the memory card. The encrypted data in the memory card cannot be accessed from another device.

1 Tap ◯ > **Settings** > **General** > **Security** > **Encrypt SD card**.

2 Read the on-screen overview of memory card encryption and then tap **CONTINUE** to continue.

3 Select an option and tap **ENCRYPT NOW**.

- **New data encryption**: Encrypt only data that is saved on the memory card after encryption.
- **Full encryption**: Encrypt all the data currently saved on the memory card.
- **Exclude media files**: Encrypt all files, except for media files such as music, photos and videos.

- To encrypt the memory card, make sure that a screen lock is set using a PIN or password.
- Once memory card encryption starts, some functions are not available.
- If the device is turned off while encryption is underway, the encryption process will fail, and some data may be damaged. Therefore, be sure to check if the battery level is sufficient before starting encryption.
- Encrypted files are accessible only from the device where the files were encrypted.
- The encrypted memory card cannot be used on another LG device. To use the encrypted memory card on another mobile device, format the card.
- You can activate memory card encryption even when no memory card is installed into the device. Any memory card that is installed after encryption will automatically be encrypted.

Taking screenshots

You can take screenshots of the current screen you are viewing.

Via a shortcut

Press and hold the Power/Lock key and the Volume Down (-) key at the same time for at least two seconds.

- Screenshots can be viewed from the **Screenshots** folder in the **Gallery**.

Via Capture+

On the screen where you want to take a screenshot, drag the status bar downwards, then tap .

- When the screen is turned off or locked, you can access **Capture+** by pressing the Volume Up (+) key twice. To use this feature, tap ◯ > **Settings** > **General** and turn on **Shortcut keys**.
- See *Writing notes on a screenshot* for details.

Entering text


Using the Smart keyboard

You can use the Smart keyboard to enter and edit text.

With the Smart keyboard, you can view text as you type without bothering to alternate between the screen and a conventional keyboard. This allows you to easily find and correct errors when typing.

Moving the cursor

With the Smart keyboard, you can move the cursor to the exact position you want. When typing text, touch and hold on the space bar and then drag left or right.




- This function may not be supported for some languages.

Suggesting words

Smart keyboard automatically analyses your usage patterns to suggest frequently used words as you type. The longer you use your device, the more precise the suggestions are.

Enter text, then tap a suggested word or gently drag the left or right side of the keyboard upwards.

- The selected word is automatically entered. You do not need to manually type every letter of the word.




Changing the QWERTY keyboard layout

You can add, delete or rearrange keys on the bottom row of the keyboard.

1 Tap ◯ > **Settings** > **General** > **Language & keyboard** > **LG Keyboard** > **Keyboard height and layout** > **QWERTY keyboard layout**.
You can also tap ⚙ on the keyboard and tap **Keyboard height and layout** > **QWERTY keyboard layout**.

2 Tap a key on the bottom row, then drag it to another position.




- This option is available on the QWERTY, QWERTZ and AZERTY keyboards.
- This function may not be supported for some languages.

Customising the keyboard height

You can customise the keyboard height to maximise hand comfort when typing.

1 Tap ◯ > **Settings** > **General** > **Language & keyboard** > **LG Keyboard** > **Keyboard height and layout** > **Keyboard height**.
You can also tap ⚙ on the keyboard and tap **Keyboard height and layout** > **Keyboard height**.

2 Adjust the keyboard height.



Selecting a landscape keyboard mode

You can select a landscape keyboard mode from several choices.

1 Tap ◯ > **Settings** > **General** > **Language & keyboard** > **LG Keyboard** > **Keyboard height and layout** > **Keyboard type in landscape**.
You can also tap ⚙ on the keyboard and tap **Keyboard height and layout** > **Keyboard type in landscape**.

2 Select a keyboard mode.

Splitting the keyboard

You can split the keyboard in half and place each piece on either side of the screen when the screen is in landscape mode.

Tap ◯ > **Settings** > **General** > **Language & keyboard** > **LG Keyboard** > **Keyboard height and layout** > **Split keyboard**.

You can also tap ⚙ on the keyboard and tap **Keyboard height and layout** > **Split keyboard**.

- Rotate the device to landscape mode to split the keyboard to both sides. To merge or split the keyboard, pinch together or spread apart your fingers on the keyboard.




One-handed operation mode

You can move the keyboard to one side of the screen so that you can use the keyboard with one hand.

1 Tap ◯ > **Settings** > **General** > **Language & keyboard** > **LG Keyboard** > **Keyboard height and layout** > **One-handed operation**.
You can also tap ⚙ on the keyboard and tap **Keyboard height and layout** > **One-handed operation**.

2 Press the arrow displayed next to the keyboard to move the keyboard in the direction you want.



Entering text by using voice

On the keyboard, touch and hold and then select .

- To maximise the voice command recognition, speak clearly.
- To enter text with your voice, make sure that your device is connected to a network.
- To select the language for voice recognition, tap > **Languages** on the voice recognition screen.
- This function may be not supported, or the supported languages may differ depending on the service area.

Adding languages to the keyboard

You can make additional languages available for keyboard input.

1 Tap > **Settings** > **General** > **Language & keyboard** > **LG Keyboard** > **Select languages**.

2 Select the languages you want to make available.

Copy and Paste

You can cut or copy text from an app, and then paste the text into the same app. Or, you can run other apps and paste the text into them.

1 Touch and hold around the text you want to copy or cut.

2 Drag / to specify the area to copy or cut.

3 Select either **CUT** or **COPY**.

- Cut or copied text is automatically added to the clipboard.

4 Touch and hold the text input window, then select **PASTE**.

- If there is no item that has been copied or cut, the **PASTE** option will not appear.

Clip Tray

If you copy or cut an image or text, it is automatically saved to the clip tray and can be pasted to any space at any time.

1 On the keyboard, touch and hold and select .
You can also touch and hold the text input window, then select **CLIP TRAY**.

2 Select and paste an item from the clip tray.
- A maximum of 20 items can be saved to the clip tray.
- Tap to lock saved items in order not to delete them, even when the maximum quantity is exceeded. A maximum of ten items can be locked. To delete locked items, unlock them first.
- Tap to delete the items saved to the clip tray.

- The clip tray may not be supported by some downloaded apps.

Do not disturb

You can limit or mute notifications to avoid disturbances for a specific period of time.

1 Tap > **Settings** > **Sound & notification** > **Do not disturb** and then tap to activate it.

2 Tap **Sounds and vibrations** and select the mode you want:
- **Priority only**: Receive sound or vibrate notifications for the selected apps. Even when Priority only is turned on, alarms still sound.
- **Total silence**: Disable both the sound and vibration.

03

Useful Apps

Installing and uninstalling apps

Installing apps

Access an app store to search and download apps.

- You can use SmartWorld, Play Store or the app store provided by your service provider.

- Some app stores may require you to create an account and sign in.
- Some apps may charge fees.
- If you use mobile data, you may be charged for data usage, depending on your pricing plan.
- SmartWorld may not be supported depending on the area or service provider.

Uninstalling apps

Uninstall apps that you no longer use from your device.

Uninstalling with the touch and hold gesture

On the Home screen, touch and hold the app to uninstall, then drag it over **Delete** at the top of the screen.

You can touch and hold the app and release it, then tap ⊗ to uninstall.

- If apps were uninstalled within 24 hours from now, you can reinstall them. See *App trash* for details.

Uninstalling by using the settings menu

Tap ◯ > **Settings** > **General** > **Apps**, select an app, then tap **Uninstall**.

Uninstalling apps from the app store

To uninstall an app, access the app store from which you download the app and uninstall it.

- Some apps cannot be uninstalled by users.

App trash

You can view the uninstalled apps on the Home screen. You can also reinstall apps which were uninstalled within 24 hours from now.

1 Tap ◯ > **Management** > **App trash**.
You can also touch and hold an empty area of the Home screen, then tap **App trash**.

2 Activate the desired function:
- **Restore**: Reinstall the selected app.
- 🗑 : Remove the uninstalled apps permanently from the device.

- Uninstalled apps are automatically removed from the device 24 hours after they were uninstalled. If you want to reinstall the uninstalled apps, you must download them again from the app store.
- This feature is activated on the default Home screen only. If you uninstall apps while using the EasyHome screen or other launcher, they are immediately and permanently removed from the device.

Phone

Voice call

Make a phone call by using one of the available methods, such as manually entering a phone number and making a call from the contact list or the list of recent calls.

Making a call from the keypad

1 Tap ◯ > > **Dial**.

2 Make a call by using a method of your choice:

- Enter a phone number and tap .
- Touch and hold a speed dial number.
- Search for a contact by tapping the initial letter of a contact name in the contact list, and then tap .

- To enter "+" when making an international call, touch and hold number 0.
- See *Adding contacts* for details on how to add phone numbers to the speed dial list.

Making a call from the contact list

1 Tap ◯ > > **Contacts**.

2 From the contact list, select a contact and tap .

Answering a call

To answer a call, drag on the incoming call screen.

- When the stereo headset is connected, you can make calls by using the call/end button on the headset.
- To end a call simply by pressing the Power/Lock key, tap ◯ > **Settings** > **Networks** > **Call** > **Common** > **Answer and end calls**, then turn on **End call with the Power key**.


Rejecting a call

To reject an incoming call, drag across the incoming call screen.

- To send a rejection message, drag the rejection message option across the screen.
- To add or edit a rejection message, tap > **Settings** > **Networks** > **Call** > **Common** > **Call blocking & Decline with message** > **Decline with message**.
- When a call is coming in, press the Volume Up (+), Volume Down (-) or Power/Lock key to mute ringtone or vibration, or to hold the call.

Checking an incoming call while using an app

When a call comes in while using an app, a pop-up notification can be displayed at the top of the screen. You can receive the call, reject the call, or send message from the pop-up screen.



- Tap > **Settings** > **Networks** > **Call** > **Common** > **More** and then tap **Incoming voice call pop-up** to deactivate it.

Viewing missed calls

If there is a missed call, the status bar at the top of the screen displays .

To view missed call details, drag the status bar downwards. You can also tap > > **Call logs**.

Functions accessible during a call

During a call, you can access a variety of functions by tapping the on-screen buttons:

- **Contacts**: View the contact list during a call.
- **End**: End a call.
- **Dialpad**: Display or hide the dial pad.
- **Speaker**: Turn on the speakerphone function.
- **Mute**: Mute your voice so that your voice cannot be heard by the other party.
- **Bluetooth**: Switch the call to a Bluetooth device that is paired and connected.
- : Access additional call options.

- Available settings items may vary depending on the area or service provider.

Making a three-way calling

You can make a call to another contact during a call.

1 During a call, tap > **Add call**.

2 Enter a phone number and tap .
   - The two calls are displayed on the screen at the same time, and the first call is put on hold.

3 To start a conference call, tap **Merge calls**.

- You may be charged a fee for each call. Consult with your service provider for more information.

Viewing call records

To view recent call records, tap ◯ > > **Call logs**. Then, you can use the following functions:

- To view detailed call records, select a call record. To make a call to the selected contact, tap .
- To delete call records, tap ⋮ > **Delete**.

- The displayed call duration may differ from the call charge. Consult with your service provider for more information.

Configuring call options

You can configure various call options.

1 Tap ◯ > > **Dial** or **Call logs**.

2 Tap ⋮ > **Call settings** and then configure the options to suit your preferences.

Messaging

Sending a message

You can create and send messages to your contacts using the Messaging app.

- Sending messages abroad may incur additional charges. Consult with your service provider for more information.

1 Tap ◯ > .

2 Tap .

3 Specify a recipient and create a message.
   - To attach files, tap .
   - To access optional menu items, tap ⋮.

4 Tap **Send** to send the message.

Reading a message

You can view exchanged messages organised by contact.

1 Tap ◯ > .

2 Select a contact from the message list.

Configuring messaging settings

You can change messaging settings to suit your preferences.

1 Tap ◯ > .

2 Tap ⋮ > **Settings** from the message list.

Camera

Starting the camera

You can take a photo or record a video to cherish all of your memorable moments.


Tap ◯ > .

- Before taking a photo or recording a video, wipe the camera lens with a soft cloth.
- Be careful not to stain the camera lens with your fingers or other foreign substance.
- If the battery level is lower than 5%, charge the battery before using the camera.
- Images included in this user guide may be different from the actual device.
- Photos and videos can be viewed or edited from the Gallery. See *Gallery overview* for details.

Changing the camera mode

You can select a camera mode that suits your environment to take a photo or record a video easily and conveniently.

On the camera screen, tap AUTO mode and select the desired mode.



AUTO mode

You can take photos or record videos by selecting a variety of camera modes and options.

1 Launch the Camera app, then tap **AUTO** (Ⓐ).

2 To take a photo, tap ◎. To record a video, tap ▭.



Taking a photo

1 Select a camera mode and tap the subject to focus the camera on.

2 Tap to take a photo.

- You can also press the Volume Down (-) or Volume Up (+) key to take a photo.

- When the screen is turned off or locked, start the camera by pressing the Volume Down (-) key twice. Tap > **Settings** > **General** > **Shortcut keys**.

Recording a video

1 Select a camera mode and tap the subject to focus the camera on.

2 Tap .

- To take a photo while recording a video, tap .
- To pause the video recording, tap . To resume the video recording, tap .

3 Tap to end the video recording.

Customising the camera options

You can customise a variety of camera options to suit your preferences.

Tap on the screen.

- Available options vary depending on the selected camera (front or rear camera) and the selected camera mode.

Photo size	Select values for aspect ratio and size for taking photos.
Video resolution	Select values for resolution and size for recording videos.
HDR	Obtain photos in vivid colours and get compensated effects even when they are taken against the light. These functions are provided by the high dynamic range (HDR) technology equipped in the camera.
Timer	Set the timer to automatically take photos after a specified period of time.
Cheese shutter	Take photos with voice commands.
Steady recording	Minimise motion blur while recording a video.
Tag locations	Save the image with GPS location data.
Grid	Display guide grids so that you can take photos or record videos based on the horizontal and vertical reference lines.
Storage	Select if you want to store the pictures and videos in the Internal storage or SD card. (Available when the memory card is inserted.)
Simple view	Hide all menus from the camera screen.
Help	Provide Help for each camera menu.

Additional options on the front camera

Selfie shot	Customise selfie shot settings. • Gesture shot: Shoot using the Gesture shot feature. • Auto shot: Shoot when the camera detects a face.
Gesture view	Choose whether to use Gesture view to view the taken photo immediately after taking a photo.
Save as flipped	Save as flipped images after taking selfies.

• When using the front camera, you can adjust the filter and skin tone.

Various camera modes

Panorama

You can create a panoramic photo by moving the camera in one direction to photograph and stitch continuous shots of a wide view.

1 In the AUTO mode, tap **MODE** > .

2 Tap and then slowly move the camera in one direction.
- Move the device by following the direction of the arrow in the guideline.

3 Tap to stop capturing the panoramic.



Food

You can take a photo using the control slide bar on the right of the screen.

1 In the AUTO mode, tap **MODE** > .

2 To take a photo, tap .

- Drag the colour slide bar on the screen to adjust the white balance and select the best colour.
- If the slide bar is invisible, tap to adjust the white balance.



SQUARE camera mode

You can take multiple photos or videos in the form of a collage by using the front and rear cameras. Photos and videos can be saved with different layouts.

1 Launch the Camera app, then tap **AUTO** ( ) > **SQUARE** ( ).

2 Tap **MODE** and select the desired camera mode.

3 To take a photo, tap . To record a video, tap .

Customising the camera options

You can customise a variety of camera options to suit your preferences.

Tap on the screen.

- Available options vary depending on the selected camera (front or rear camera) and the selected camera mode.

Photo size	Select values for aspect ratio and size for taking photos.
Video resolution	Select values for resolution and size for recording videos.
HDR	Obtain photos in vivid colours and get compensated effects even when they are taken against the light. These functions are provided by the high dynamic range (HDR) technology equipped in the camera.
Timer	Set the timer to automatically take photos after a specified period of time.
Cheese shutter	Take photos with voice commands.
Steady recording	Minimise motion blur while recording a video.
Tag locations	Save the image with GPS location data.
Grid	Display guide grids so that you can take photos or record videos based on the horizontal and vertical reference lines.
Storage	Select if you want to store the pictures and videos in the Internal storage or SD card. (Available when the memory card is inserted.)
Help	Provide Help for each camera menu.

Additional options on the front camera

Selfie shot	Customise selfie shot settings. • Gesture shot: Shoot using the Gesture shot feature. • Auto shot: Shoot when the camera detects a face.
Save as flipped	Save as flipped images after taking selfies.

• When using the front camera, you can adjust the filter and skin tone.

Other useful features in the Camera app

Burst shot

You can take continuous shots of photos to create moving pictures.

In the AUTO mode, touch and hold .

• Continuous shots are taken at a fast speed while is held down.

• Up to thirty (30) continuous photos can be taken.

Simple view

In the AUTO mode, tap > **Simple view** to hide menus on the camera screen. Tap to display them.

AE/AF lock


You can fix the current exposure level and focus position by touching and holding the screen in the AUTO mode. To turn off the feature, tap a blank area on the screen.



Switching between cameras

You can switch between the front and rear cameras to suit your environment.

On the camera screen, tap or drag the screen in any direction to switch between the front and rear cameras.



- Use the front camera to take selfies. See *Selfie shot* for details.

Switching between standard and wide-angle cameras

Switch between the standard and wide-angle on the front camera to take photos or record videos to suit your preferences.

- Tap / to switch between the standard and wide-angle camera.

Zoom in or out

You can use zoom in or out on the camera screen while taking a photo or recording a video.

- On the camera screen, pinch or spread two fingers to zoom in or out, then use the displayed +/- slide bar.

> - The zoom feature is not available when using the front camera in selfie mode.

Selfie shot

You can use the front camera to view your face on the screen and take selfies.

Gesture shot


You can take selfies by using gestures.

Show your palm to the front camera and then clench your fist.

You can also clench your fist and then open it towards the front camera.

- In three seconds, a photo is taken.





- To use this feature, switch to the front camera mode, then tap > **Selfie shot** > **Gesture shot**.
- Make sure that your palm and fist are within the reference line so that the camera can detect them.
- This feature may not be available while using some of the camera features.

Interval shot

You can take selfies at an interval.

While using the front camera, you can show your palm to the camera, then clench your fist twice quickly.

- Four photos are taken at about two seconds interval after a timer delay of three seconds.

- Tap > **Selfie shot** > **Gesture shot** to use this feature.

Auto shot


You can use the face detection feature to take selfies easily and conveniently. You can set the device so that, when you look at the screen, the front camera detects your face and takes a selfie automatically.

- The white coloured guide frame appears when the front camera detects your face. If the subject within the guide frame stops moving, the guide frame colour turns blue, then the camera takes a photo.

- Tap > **Selfie shot** > **Auto shot** to enable the Auto shot feature.

Gesture view

After taking a selfie with the front camera, you can preview the selfie immediately by placing the screen close to your face.



- Tap ⚙ > **Gesture view** to enable the Gesture view feature.
- Only one preview is available each time a photo is taken.
- If you rotate the device while in preview screen, the screen switches to camera mode.

Save as flipped

Before taking a photo with the front camera, tap ⚙ > **Save as flipped**. The image is flipped horizontally.

- When using the front camera, you can change how selfies are taken in the camera options. See *Customising the camera options* for details.

Gallery

Gallery overview

You can view and manage photos and videos saved on your device.

1 Tap ◯ > .


- Saved photos and videos are displayed by folder.

2 Tap a folder and select a file.

- View the selected file in full-screen mode.
- While viewing a photo, swipe left or right to view the previous or next photo.
- While viewing a video, swipe left or right to rewind or fast-forward the video.

- Some file formats may not be supported, depending on the installed software.
- Some files may not be opened due to encoding.
- Files that exceed the size limit may cause an error.


Viewing photos



- To display the menu items, gently tap the screen. To hide the menu items, tap the screen again.

Floating button

To quickly move to the Home screen while viewing the Gallery in landscape orientation, touch and hold ◁, move your finger upward to ○, then release it.



- You can move the floating button's position by dragging it horizontally along the bottom part of the screen.

Writing a memo on the photo

1 While viewing a photo, tap ✎.

2 Write a memo on the photo and tap **SAVE**.

- Some photos may not support the photo memo feature.

Related content

You can edit and customise related content in the Gallery.

1 While viewing a picture preview, tap .

2 When the icon related with the date you took the photo appears, touch the screen.



- You can view the photos related with the date you chose.



- Related content can be related to up to four combinations of 'Memories, Date, Place, Camera mode'

- Tap to save the related content as a video.
- Tap to access additional options.


Editing photos

1 While viewing a photo, tap .

2 Use a variety of effects and tools to edit the photo.

3 Tap **SAVE** to save changes.
   - The changes are overwritten to the original file.
   - To save the edited photo as another file, tap > **Save copy**.

Playing a video



- To adjust the sound volume, drag the right side of the video screen up or down.
- To adjust the screen brightness, drag the left side of the screen up or down.

Editing videos

1 While viewing a video, tap ✎.

2 Use a variety of effects and edit tools to edit the video.



3 Tap **SAVE** to save changes.

Making a GIF

You can easily make a GIF file using recorded video.

1 At the desired starting point while watching the video, tap ⋮ > **Create GIF**.

2 Select the length of the GIF you want to create.
- GIF is generated for the time selected from the current time.
- For videos less than 5 seconds, GIF images are automatically generated for the remaining time.

⚠ • The GIF making feature is provided for the user's creative activity. If you infringe other's copyright or defamation laws by using the GIF making feature, you may be liable for civil and criminal liability. Be sure to not duplicate or transfer work of others without permission. LG Electronics cannot accept any liability for the user's action.

Related files

You can relate files by photos and videos taken with the same location or date.

1 Select the saved photos and videos and tap 🔗.

2 Select a desired folder, then tap ▶ to create a video.

Deleting files

You can delete files by using one of the following options:

- Touch and hold a file from the file list, then tap **Delete**.
- Tap 🗑 from the file list and delete the desired files.
- Deleted files are automatically moved to **Trash** and they can be restored to the Gallery within 7 days.
- On the Gallery, tap ☰ > **Trash**. Tap 🗑 to completely delete the files. In this case, the files cannot be restored.

Sharing files

You can share files by using one of the following options:

- While viewing a photo, tap to share the file by using the method you want.
- While viewing a video, > **Share** to share the file by using the method you want.
- Tap from the file list to select files and share them using the method you want.

Contacts

Contacts overview

You can save and manage contacts.

Tap > **Essentials** > **Contacts**.

Adding contacts

Adding new contacts

1 On the contact list screen, tap .

2 Enter contact details and tap **SAVE**.

Importing contacts

You can import contacts from another storage device.

1 On the contact list screen, tap > **Manage contacts** > **Import**.

2 Select the source and target locations of the contact you want to import, and then tap **OK**.

3 Select the contacts and tap **IMPORT**.

Adding contacts to the speed dial list

1 On the contact list screen, tap ⋮ > **Speed dial**.

2 Tap **Add contact** from a speed dial number.

3 Select a contact.

Searching for contacts

You can search for contacts by using one of the following options:

- On the contact list screen, enter a contact name in the search box.
- Scroll the contact list up or down.
- From the index of the contact list screen, tap the initial letter of a contact.

Contacts list

Editing contacts

1 On the contact list screen, select a contact.

2 On the contact detail screen, tap ✎ and edit details.

3 Tap **SAVE** to save changes.

Deleting contacts

You can delete contacts by using one of the following options:

- On the contact list screen, touch and hold a contact you want to delete, then tap **Delete contact**.
- Tap ⋮ > **Delete** on the contact list screen.

Adding favourites

You can register frequently used contacts as favourites.

1 On the contact list screen, select a contact.

2 On the contact detail screen, tap ☆.

Creating groups

1 On the contact list screen, tap **Groups** > ⋮ > **New group**.

2 Enter a new group name.

3 Tap **Add members**, select contacts, then tap **ADD**.

4 Tap **SAVE** to save the new group.

QuickMemo+

QuickMemo+ overview

You can make creative notes by using a variety of options on this advanced notepad feature, such as image management and screenshots, which are not supported by the conventional notepad.

Creating a note

1 Tap ◯ > **QuickMemo+**.

2 Tap + to create a note.

- ✓ : Save a note.
- ↩ : Undo the last action.
- ↪ : Redo the last action you undid.
- T : Enter a note by using the keypad.
- ✎ : Write notes by hand.
- ◇ : Erase handwritten notes.
- ◌ : Zoom in or out, rotate or erase the parts of a handwritten note.
- ⋮ : Access additional options.

3 Tap ✓ to save the note.

Writing notes on a photo

1 Tap ◯ > **QuickMemo+**.

2 Tap 📷 to take a photo, then tap **OK**.
- The photo is automatically attached into the notepad.

3 Tap T or ✎ to write notes on the photo.
- Write notes by hand on the photo.
- Enter text below the photo.

4 Tap ✓ to save the note.

Writing notes on a screenshot

1 While viewing the screen you want to capture, drag the status bar downwards and then tap ✎.
- The screenshot appears as the notepad background theme. Memo tools appear at the top of the screen.

2 Take notes as desired.
- Write notes by hand on the photo.

3 Tap ✓ and save the notes to the location you want.
- Saved notes can be viewed in either **QuickMemo+** or **Gallery**.
- To save notes in the same location all the time, select the **Use as default app** checkbox and select an app.

Managing folders

You can view notes grouped by type.

1 Tap ◯ > **QuickMemo+**.

2 At the top of the screen, tap ☰ and select a menu item:
- **All memos**: View all notes saved in QuickMemo+.
- **My memos**: View notes created by QuickMemo+.
- **Capture+**: View notes created by Capture+.

- **Photo memos**: View notes created by .
- **Trash**: View deleted notes.
- **New category**: Add categories.
- : Rearrange, add or delete categories. To change the name of a category, tap the category.

- Some folders do not appear when launching QuickMemo+ for the first time. Disabled folders are enabled and appear when they contain at least one related note.

Clock

Alarm

You can set an alarm to trigger it at a specified time.

1 Tap > **Essentials** > **Clock** > **Alarm**.

2 Tap to add a new alarm.

3 Configure the alarm settings and tap **SAVE**.

- If you select a previously set alarm, you can edit the alarm.
- To delete an alarm, tap at the top of the screen. You can also touch and hold the alarm.

World clock

You can view the current time in cities around the world.

1 Tap > **Essentials** > **Clock** > **World clock**.

2 Tap and add a city.

Timer

You can set the timer to trigger an alarm after a specified period of time.

1 Tap ◯ > **Essentials** > **Clock** > **Timer**.

2 Set the time and tap **Start**.

- To suspend the timer, tap **Pause**. To resume the timer, tap **Resume**.
- To reset the timer settings, tap ↺.

3 Tap **Stop** to stop the timer alarm.

Stopwatch

You can use the stopwatch to record a lap time.

1 Tap ◯ > **Essentials** > **Clock** > **Stopwatch**.

2 Tap **Start** to initiate the stopwatch.

- To record a lap time, tap **Lap**.

3 Tap **Pause** to suspend the stopwatch.

- To resume the stopwatch, tap **Resume**.
- To clear all the records and restart the stopwatch, tap **Reset**.

Calendar

Calendar overview

You can use the calendar to manage events and tasks.

Adding events

1 Tap ◯ > **Essentials** > **Calendar**.

2 Select a date and then tap ⊕.

3 Enter event details and tap **SAVE**.

- If you tap a date from the calendar and the date contains events, a pop-up window appears showing a list of the events. Tap an event from the pop-up window to view the event details.

Syncing events

Tap ⋮ > **Calendars to sync**, and select a calendar to sync.

- When your events are saved from the device to your Google account, they are automatically synced with the Google calendar, too. Then, you can sync other devices with the Google calendar in order to make those devices have the same events that your device has and to manage your events on those devices.

Tasks

You can register tasks to your device to easily manage schedules.

1 Tap ◯ > **Essentials** > **Tasks**.

2 Tap ⊕ to add a task.

3 Enter task details and then tap **SAVE**.


Music

You can play and manage songs or music albums.

1 Tap ◯ > **Essentials** > **Music**.

2 Select a category.

3 Select a music file.



- Some file formats may not be supported, depending on the installed software.
- Files that exceed the size limit may cause an error.
- Music files may be protected by international copyright owners or copyright laws. You may have to obtain legal permission before copying a music file. To download or copy a music file, first check the copyright law for the relevant country.

Calculator

You can use two types of calculators: the simple calculator and the scientific calculator.

1 Tap ◯ > **Essentials** > **Calculator**.

2 Use the keypad to make a calculation.

- To use scientific calculator, drag the green coloured slide bar located in the right side of the screen to the left.
- To restart a calculation, touch and hold the **DEL** button.

E-mail

E-mail overview

You can register an email account to your device and then you can check and send emails from your device.

- If you use mobile data, you may be charged for data usage depending on your pricing plan. Consult with your service provider for more information.

Registering email accounts

When you use the email app for the first time, register your email account.

1 Tap ◯ > **Essentials** > **E-mail**.

2 Select an email service provider.

3 Enter your email address and password and then tap **NEXT** to register your account.

- To manually register an email account, tap **MANUAL SETUP** (if necessary).

Managing email accounts

To view or edit your email account settings, tap ⋮ > **Settings**.

- To add an account, tap **Add account**.
- To delete an account, tap ⋮ > **Remove account**.

Opening another email account

If several email accounts are registered and you want to view another account, tap ☰ and select another one from the account list.

Checking email

1 Tap ☰ and select a mail box.

2 Select an email from the email list.
   - The email message appears.

Sending email

1 Tap ⊕.

2 Enter the recipient's email address.

3 Enter a subject and message.
   - To attach files, tap 📎.
   - To access optional menu items, tap ⋮.

4 Tap ▷ to send the email.

Audio Recorder

You can record and save your voice or others' voices from important events. Recorded voice files can be played back or shared.

1 Tap ◯ > **Essentials** > **Audio Recorder**.

2 Tap ⏺.

- To pause recording, tap ⏸.
- To insert a bookmark while making a voice recording, tap ⏺.

3 Tap ⏹ to end recording.

- The file is saved automatically and the pre-listen screen appears.

4 Tap ▶ to play the recorded voice.

- If you tap ☰, recorded voice files appear. You can play a recorded voice file from the list.

FM Radio

You can listen to FM radio.

Tap ◯ > **Essentials** > **FM Radio**.

- To use this app, first connect earphones to the device. The earphones function as the radio antenna.
- This function may not be supported depending on the area.

Cell Broadcast

You can view real-time text broadcasts on emergency situations, such as typhoons, floods and earthquakes.

Tap ◯ > **Essentials** > **Cell Broadcast**.

File Manager

You can view and manage files saved on your device or cloud.

1 Tap ◯ > **Management** > **File Manager**.

2 Tap ☰ and select the desired storage location.

LG Mobile Switch

Easily transfer data from a used device to a new device via LG Mobile Switch.

1 Tap ◯ > **Management** > **LG Mobile Switch**.
You can also tap ◯ > **Settings** > **General** > **Backup & reset** > **LG Mobile Switch**.

2 Follow the on-screen instructions to select a desired method for transfer.

⚠ • Resetting your device may delete backup files saved in storage. Make sure to copy and store the important backup files to your PC.

📝 • Data in a Google account will not be backed up. When you synchronise your Google account, Google apps, Google contacts, Google calendar, Google memo app data and apps downloaded from the Play Store are stored on the Drive app automatically.

• Fully charge the battery before transferring data to avoid unintentional powering off during the process.

Downloads

You can view, delete or share files downloaded via the Internet or apps.

Tap ◯ > **Management** > **Downloads**.

LG SmartWorld

You can download a variety of games, audio content, apps and fonts provided by LG Electronics. Customise your device to suit your preferences by using Home themes and fonts.

- If you use mobile data, you may be charged for data usage depending on your pricing plan.
- This feature may not be supported depending on the area or service provider.

1 Tap ◯ > **Services** > **SmartWorld**.

2 Tap ⋮ > **Sign in**, then sign in.

3 Select and download the desired content items.

Downloading SmartWorld app

If the SmartWorld app is not installed, follow these steps to download it.

1 Tap ◯ > **Settings** > **General** > **About phone** > **Common** > **Update centre** > **App Updates**.

2 From the list, select **SmartWorld** and tap **Download**.

RemoteCall Service

Your device can be remotely diagnosed for resolving issues. First, make a phone call to an LG Customer Service Centre as follows:

- To use this function, first you must agree to usage of the function.
- If you use mobile data, you may be charged for data usage depending on your pricing plan.

1 Tap ◯ > **Services** > **RemoteCall Service**.

2 Connect a call to an LG Customer Service Centre.

3 After the call connects, follow the service associate's instructions to enter a six-digit access number.
   - Your device is remotely connected and the remote support service starts.

Chrome

Sign in to Chrome and import opened tabs, bookmarks and address bar data from a computer to your device.

Google apps

You can use Google apps by setting a Google account. The Google account registration window appears automatically when you use a Google app for the first time. If you do not have a Google account, create one from your device. For details on how to use an app, see the Help in the app.



- Some apps may not work depending on the area or service provider.

Docs

Create documents or edit documents created online or from another device. Share and edit documents together with others.

Drive

Upload, save, open, share and organise files from your device. Files accessible from apps can be accessed from anywhere, including online and offline environments.

Duo

Make a video call with your family, friends and anyone else who uses the app.

Gmail

Register your Google email account to your device to check or send email.

Google

Use the Google to search for web pages, images, news and more by entering or speaking keywords.

Maps

Find your location or the location of a place on the map. View geographical information.

Photos

View or share photos or albums saved on your device.

Play Movies & TV

Use your Google account to rent or purchase movies. Purchase content and play it anywhere.

Play Music

Purchase music files from the Play Store. Play music files saved on your device.

Sheets

Create spreadsheets or edit spreadsheets created online or from another device. Share and edit spreadsheets together with others.

Slides

Create presentation material or edit presentation material created online or from another device. Share and edit presentation material together with others.

YouTube

Search and play videos. Upload videos on YouTube to share them with people around the world.

Google Assistant

Your device has the Google Assistant built in. Ask it questions. Tell it to do things. It's your own personal Google. Touch and hold the ◯ and then you will see "Hi, how can I help?", after which you can say your voice command.

- The Google Assistant is not available in all languages.

04

Settings

Settings

You can customise the device settings in accordance with your preferences.

Tap ◯ > **Settings**.

- Tap 🔍 and enter a keyword in the search box to access a setting item.
- Tap ⋮ to change the view mode. This user guide assumes that you are using the Tab view.

Networks

Dual SIM card

You can configure Dual SIM card settings.

1 On the settings screen, tap **Networks** > **Dual SIM card**.

2 Customise the following functions:

- **SIM card 1**: Change the name and icon of the SIM card 1.
- **SIM card 2**: Change the name and icon of the SIM card 2.
- **SIM card colour theme**: Change the colour themes for the SIM cards.
- **Cost save mode**: Activate or deactivate the cost save mode. In the cost save mode, if you make a call to a contact to which a specific SIM is assigned, this SIM is used for the call even if the other SIM is active, for example, it is using mobile data.
- **Mobile data**: Select a SIM card you want to use for mobile data service. You can also turn off this function.
- **Data roaming**: Select this option to enable the device to use mobile data when you are roaming outside your local network area.

Wi-Fi

You can connect to nearby devices over a Wi-Fi network.

Connecting to a Wi-Fi network

1 On the settings screen, tap **Networks** > **Wi-Fi**.

2 Tap to activate it.
- Available Wi-Fi networks appear automatically.

3 Select a network.
- You may need to enter the network's Wi-Fi password.
- The device skips this process for previously accessed Wi-Fi networks. If you do not want to automatically connect to a certain Wi-Fi network, touch and hold the network and then tap **Forget network**.

Wi-Fi network settings

On the settings screen, tap **Networks** > **Wi-Fi**.

- **Switch to mobile data**: If the mobile data connection function is activated but the device cannot connect to the Internet via Wi-Fi connection, the device automatically connects to the Internet via the mobile data connection.
- ⋮ : Customise Wi-Fi network settings.


Wi-Fi Direct

You can connect your device to other devices that support Wi-Fi Direct to share data directly with them. You do not need an access point. You can connect with more than two devices by using Wi-Fi Direct.

1 On the settings screen, tap **Networks** > **Wi-Fi** > ⋮ > **Advanced Wi-Fi** > **Wi-Fi Direct**.
   - Nearby devices that support Wi-Fi Direct automatically appear.

2 Select a device.
   - Connection occurs when the device accepts the connection request.

- The battery may drain faster when using Wi-Fi Direct.



Bluetooth

You can connect your device to nearby devices that support Bluetooth to exchange data with them. Connect your device to a Bluetooth headset and a keyboard. This makes it easier to control the device.

Pairing with another device

1 On the settings screen, tap **Networks** > **Bluetooth**.

2 Tap to activate it.
- Available devices appear automatically.
- To refresh the device list, tap **SEARCH**.

- Only devices set as visible are displayed on the list.

3 Select a device from the list.

4 Follow the on-screen instructions to perform authentication.

- This step is skipped for previously accessed devices.

Sending data via Bluetooth

1 Select a file.
- You can send multimedia files or contacts.

2 Tap > **Bluetooth**.

3 Select a target device for the file.
- The file is sent as soon as the target device accepts it.

- File sharing processes may differ, depending on the file.

Mobile data

You can turn on or off mobile data. You can also manage mobile data usage.

Turning on mobile data

1 On the settings screen, tap **Networks** > **Mobile data**.

2 Tap to activate it.

Customising mobile data settings

1 On the settings screen, tap **Networks** > **Mobile data**.

2 Customise the following settings:

- **Mobile data**: Set to use data connections on mobile networks.
- **Limit mobile data usage**: Set a limit for mobile data usage to block mobile data if the limit is reached.
- ⋮ : Customise mobile data settings.

Call

You can customise call settings, such as voice call and international call options.

- Some features may not be supported depending on the area or service provider.

1 On the settings screen, tap **Networks** > **Call**.

2 Customise the settings.

Tethering


USB tethering

You can connect the device to another device via USB and share mobile data.

1 Connect your device and other devices via USB cable.

2 On the settings screen, tap **Networks** > **Tethering** > **USB tethering** and then tap to activate it.

- This option uses mobile data and may incur data usage fees, depending on your pricing plan. Consult with your service provider for more information.
- When connecting to a computer, download the USB driver from *www.lg.com* and install it on the computer.
- You cannot send or receive files between your device and a computer while USB tethering is turned on. Turn off USB tethering to send or receive files.
- Operating systems that support tethering are Window XP or higher, or Linux.



Wi-Fi hotspot

You can set the device as a wireless router so that other devices can connect to the Internet by using your device's mobile data.


1 On the settings screen, tap **Networks** > **Tethering** > **Wi-Fi hotspot** and then tap to activate it.

2 Tap **Set up Wi-Fi hotspot**, and enter the Wi-Fi name (SSID) and password.

3 Turn on Wi-Fi on the other device, and select the name of the device network on the Wi-Fi list.

4 Enter the network password.

- This option uses mobile data and may incur data usage fees, depending on your pricing plan. Consult with your service provider for more information.
- More information is available at this web site: *http://www.android.com/tether#wifi*



Bluetooth tethering

A Bluetooth-connected device can connect to the Internet by using your device's mobile data.

1 On the settings screen, tap **Networks** > **Tethering** > **Bluetooth tethering** and then tap to activate it.

2 Turn on Bluetooth on both devices and pair them.

- This option uses mobile data and may incur data usage fees, depending on your pricing plan. Consult with your service provider for more information.
- More information is available at this web site: *http://www.android.com/tether#Bluetooth_tethering*

Help

You can view help on using tethering and hotspots.

On the settings screen, tap **Networks** > **Tethering** > **Help**.

More

Airplane mode

You can turn off the call and mobile data functions. When this mode is on, functions that do not involve data, such as games and music playback, remain available.

1 On the settings screen, tap **Networks** > **More** > **Airplane mode**.

2 Tap **TURN ON** in the confirmation screen.

Mobile networks

You can customise the mobile networks settings.

1 On the settings screen, tap **Networks** > **More** > **Mobile networks**.

2 Customise the following settings:

- **Network mode**: Select a network type.
- **Access Point Names**: View or change the access point for using mobile data services. To change the access point, select a choice from the access point list.
- **Network operators**: Search for network operators and connect automatically to a network.

VPN

You can connect to a safe virtual network, such as an intranet. You can also manage connected virtual private networks.

Adding VPN

1 On the settings screen, tap **Networks** > **More** > **VPN**.

2 Tap **Add VPN**.

- This feature is available only when the screen lock is activated. If the screen lock is deactivated, a notification screen appears. Tap **CHANGE** from the notification screen to activate the screen lock. See *Setting a screen lock* for details.

3 Enter VPN details and tap **SAVE**.

Configuring VPN settings

1 Tap a VPN from the **VPNS** list.

2 Enter the VPN user account details and tap **CONNECT**.

- To save the account details, select the **Save account information** checkbox.

Printing

You can connect your device to a Bluetooth printer and print photos or documents saved on the device.

1 On the settings screen, tap **Networks** > **More** > **Printing**.

- If the desired printer is not in the list, install the printer driver from the app store.

2 Tap to activate it.

3 Select a printer from the printer list screen.
- To add a printer, tap ⋮ > **Add printer**.
- To search for a printer name, tap ⋮ > **Search**.
- Tap ⋮ > **Settings** from the printer list screen.

4 Select a file and tap ⋮ > **Print**.
- The document prints.

- If you do not have a Google account, tap **ADD ACCOUNT** to create an account.

Sound & notification

You can customise sound, vibrate and notification settings.

On the settings screen, tap **Sound & notification** and customise the following settings:

- **Sound profile**: Change the sound mode to **Sound**, **Vibrate only**, or **Silent**.
- **Volume**: Adjust the sound volume for various items.
- **SIM1 ringtone/SIM2 ringtone**: Select a ringtone for incoming calls. Add or delete ringtones.
- **Ringtone ID**: Create a ringtone for an incoming call from a particular contact.
- **Sound with vibration**: Set the device to vibrate and play a ringtone simultaneously.
- **SIM1 vibration type/SIM2 vibration type**: You can select the type of vibration when receiving calls.
- **Do not disturb**: Set the time, range and app type to receive notification messages. Receive notification messages only on particular days of the week.
- **Lock screen**: Display or hide a notification message on the lock screen. You can also hide private information.
- **Apps**: Select the apps that can show their notification messages on the screen, and set the priorities of those apps in regard to notification messages.
- **More** > **SIM1 notification sound/SIM2 notification sound**: Select a notification ringtone. Set music saved on the device as a notification ringtone.
- **More** > **Sound effects**: Select a sound effect to play when you tap the dialpad or keyboard, select an option, or lock or unlock the screen.

Display

You can customise detailed settings for each screen type.

On the settings screen, tap **Display** and customise the following settings:

- **Home screen**: Customise settings for the Home screen. See *Home screen settings* for details.
- **Lock screen**: Customise lock screen settings. See *Lock screen settings* for details.
- **Theme**: Select a screen theme for your device.
- **Home touch buttons**: Rearrange Home touch buttons or change their background colours.
- **Font type**: Change the font face.
- **Font size**: Change the font size.
- **Bold text**: Bold the text on the screen.
- **App scaling**: Adjust the screen size of apps.
- **Display size**: Set the items on the screen to a size easy for you to see. Some items may change position.
- **Comfort view**: Set the device to reduce amount of blue light on screen to reduce eye strain.
- **Brightness**: Use the slide bar to change the device's screen brightness. To automatically adjust screen brightness according to ambient light intensity, tap the **Auto** switch.
- **Auto**: Set the device so that the screen brightness is automatically adjusted in accordance with the ambient light intensity.
- **Auto-rotate screen**: Automatically rotate the screen according to the device's orientation.
- **Screen timeout**: Automatically turn off the screen when the device is left idle for a specified period of time.
- **More** > **KnockON**: Turn the screen on or off by tapping the screen twice.

- **More** > **Screen saver**: Display a screen saver when the device is connected to the holder or charger. Select a screen saver type to display.

General

Language & keyboard

You can customise language and keyboard settings for your device.

1 On the settings screen, tap **General** > **Language & keyboard**.

2 Customise the following settings:

- **Language**: Select a language to apply for the device.
- **Current keyboard**: View the keyboard currently in use. Select a keyboard to use when entering text.
- **LG Keyboard**: Customise the LG keyboard settings.
- **Google voice typing**: Configure the options for text dictation by Google.
- **Text-to-speech output**: Configure the settings for text-to-speech output.
- **Pointer speed**: Adjust the pointer speed of a mouse or trackpad.
- **Reverse buttons**: Reverse the right mouse button to perform primary direct-manipulation actions.

Location

You can customise how your location information is used by particular apps.

1 On the settings screen, tap **General** > **Location**.

2 Customise the following settings:

- **Mode**: Select a method to provide your location information.

- **RECENT LOCATION REQUEST**: View apps that recently requested location information.
- **Low power location estimation**: Estimate the device location by using low power consumption.
- **Google Location History**: Configure the Google location history settings.
- **Google Location Sharing**: Share your real-time location with others.

Accounts & sync

You can add or manage accounts, including a Google account. You can also sync particular apps or user information automatically.

1 On the settings screen, tap **General** > **Accounts & sync**.

2 Customise the following settings:
- **Auto-sync data**: Sync all the registered accounts automatically.
- **ACCOUNTS**: View a list of registered accounts. To view or change details of an account, tap the account.
- **ADD ACCOUNT**: Add accounts.

Accessibility

You can manage accessibility plug-ins installed on your device.

1 On the settings screen, tap **General** > **Accessibility**.

2 Customise the following settings:
- **Vision** > **TalkBack**: Set the device to notify screen status or actions via voice.
- **Vision** > **Message/call voice notifications**: Set the device to read the caller information or message content via voice.
- **Vision** > **Font size**: Change the font size.
- **Vision** > **Bold text**: Bold the text on the screen.
- **Vision** > **Display size**: Set the items on the screen to a size easy for you to see. Some items may change position.

- **Vision** > **Touch zoom**: Zoom in or out by tapping the screen three times.
- **Vision** > **Window zoom**: Zoom in or out within a window and invert the colour.
- **Vision** > **Large mouse pointer**: Magnify the mouse pointer.
- **Vision** > **High contrast screen**: Turn the background colour into black for a high contrast screen.
- **Vision** > **Screen colour inversion**: Increase the display colour contrast for people with low vision.
- **Vision** > **Screen colour adjustment**: Adjust the display colour.
- **Vision** > **Grayscale**: Switch the screen to grayscale mode.
- **Vision** > **End call with the Power key**: End a call by pressing the Power/Lock key.
- **Hearing** > **Captions**: Turn on the subtitle service when playing videos for the hearing impaired.
- **Hearing** > **Flash alerts**: Set the device to notify you with a blinking light for incoming calls, messages and alarms.
- **Hearing** > **Mute all sounds**: Mute all sounds and lower volume on the receiver.
- **Hearing** > **Audio channel**: Select the audio type.
- **Hearing** > **Sound balance**: Adjust the audio output balance. Use the slide bar to change the balance.
- **Motor & cognition** > **Touch assistant**: Turn on the touch board to make buttons and gestures easier to use.
- **Motor & cognition** > **Touch input**: Enter text by touching and holding the screen or modify it by simply touching the screen.
- **Motor & cognition** > **Physical keyboard**: Customise the keyboard settings.
- **Motor & cognition** > **Auto mouse click**: Automatically click the mouse pointer in case of no movement.
- **Motor & cognition** > **Touch and hold for calls**: Answer or decline calls by touching and holding the call button instead of dragging it.

- **Motor & cognition** > **Screen timeout**: Turn off the screen automatically when the device is left idle for a specified period of time.
- **Motor & cognition** > **Touch control areas**: Limit the touch area so that only a particular portion of the screen can be controlled by touch input.
- **Accessibility features shortcut**: Quickly access a frequently used function by tapping ◯ three times.
- **Auto-rotate screen**: Automatically change the screen orientation according to the physical position of the device.
- **Switch Access**: Create key combinations to control your device.

Shortcut keys

You can use the volume keys to directly launch apps when the screen is turned off or locked.

1 On the settings screen, tap **General** > **Shortcut keys**.

2 Tap ◯ to activate it.
- Press the Volume Down (-) key twice to launch the Camera app when the screen is locked or turned off. Press the Volume Up (+) key twice to launch Capture+.

Google services

You can use Google settings to manage your Google apps and account settings.

On the settings screen, tap **General** > **Google services**.

Security

1 On the settings screen, tap **General** > **Security**.

2 Customise the following settings:

- **Content lock**: Set the method to lock files in the QuickMemo+.
- **Encrypt SD card**: Encrypt the memory card to prevent use on another device. See *Memory card encryption* for details.
- **Secure start-up**: Protect your device with a lock when it powers on. See *Secure start-up settings* for details.
- **Set up SIM card lock**: Lock or unlock the USIM card, or change the password (PIN).
- **Make passwords visible**: Display a password as you enter it.
- **Phone administrators**: Allow privileges to restrict the control or use of the device to particular apps.
- **Unknown sources**: Allow the installation of apps from non-Play Store apps.
- **Credential protection**: View the type of the storage where the security certificate will be saved.
- **Certificate management**: Manage the security certificate saved on the device.
- **Trust agents**: View and use trust agents installed on the device.
- **Screen pin**: Fix the app screen so that only the currently active app can be used.
- **Usage access**: View details on usage of apps on the device.

Date & time

You can customise date and time settings for your device.

1 On the settings screen, tap **General** > **Date & time**.

2 Customise the settings.

Storage

You can view and manage internal storage on the device or storage space of the memory card.

1 On the settings screen, tap **General** > **Storage**.

2 Customise the following settings:

- **DEVICE STORAGE**: View the total storage space and free space in the device's internal storage. View a list of apps in use and the storage capacity for each app.
- **PORTABLE STORAGE**: View the total storage space and free space in the memory card. This option appears only when a memory card is inserted. To unmount the memory card, tap ⏏.

Battery & power saving

You can view the current battery information or turn on power-saving mode.

1 On the settings screen, tap **General** > **Battery & power saving**.

2 Customise the following settings:

- **Battery usage**: View the battery usage details. To view more details, select a specific item.
- **Battery percentage on status bar**: Display the remaining battery level as a percentage on the status bar.
- **Battery saver**: Reduce battery consumption by cutting down some device settings, such as the display brightness, speed and vibration intensity. The status bar displays when power-saving mode is on.
- **Game battery saver**: Adjust the video quality to reduce battery consumption when playing games.

Memory

You can view the average amount of memory usage over a certain period of time and the memory occupied by an app.

1 On the settings screen, tap **General** > **Memory**.

2 Tap ▾ to set a time slot to retrieve data.

Smart Doctor

You can use Smart Doctor to diagnose the device's condition and optimise it.

On the settings screen, tap **General** > **Smart Doctor**.

Apps

You can view a list of installed apps. Stop apps from running or delete apps, if necessary.

1 On the settings screen, tap **General** > **Apps**.

2 Select an app and perform actions.

Backup & reset

You can back up data saved on your device to another device or account. Reset the device, if necessary.

1 On the settings screen, tap **General** > **Backup & reset**.

2 Customise the following settings:

- **LG Mobile Switch**: Easily transfer data the saved messages, images, home screens and other data to a new device. See *LG Mobile Switch* for details.
- **Backup & restore**: Back up your device data or restore data to your device from a backup.
- **Back up my data**: Back up your app data, Wi-Fi password and other settings to the Google server.
- **Backup account**: View the current backup account in use.

- **Automatic restore**: Automatically restore backup settings and data when reinstalling an app.
- **Network settings reset**: Reset Wi-Fi, Bluetooth and other network settings.
- **Factory data reset**: Reset all settings for the device and delete data.



- Resetting your device deletes all data on it. Enter your device name, Google account and other initial information again.

About phone

You can view information about your device, such as the name, status, software details and legal information.

On the settings screen, tap **General** > **About phone** and view information.

Regulatory & Safety

You can view regulatory marks and related information on your device.

On the settings screen, tap **General** > **Regulatory & Safety**.

05

Appendix

LG Language Settings

Select a language to use on your device.

- Tap ◯ > **Settings** > **General** > **Language & keyboard** > **Language** > **ADD LANGUAGE**, and select a language.
  - Touch and hold ☰ and drag it to the top of the language list to set it as a default language.

LG Bridge

LG Bridge overview

LG Bridge is an app that helps you manage the photos, music, videos and documents saved on your LG smartphone from your computer conveniently. You can back up contacts, photos and more to the computer or update the device software.

- See LG Bridge help for details.
- The supported features may vary depending on the device.
- LG USB driver is a necessary program to connect your LG smartphone with the computer and is installed when you install LG Bridge.

LG Bridge functions

- Back up data from the device to a computer or restore data from a computer to the device via USB cable connection.
- Update the device software from a computer via USB cable connection.

Installing LG Bridge on a computer

1 Go to *www.lg.com* from your computer.

2 Select your region.

3 Click **Support** > **Software & Firmware**.

4 Enter the name of your device.
OR
Select by the Product Category.

5 Go to **PC Sync** > **LG Bridge** to download the setup file.
- Go to **Details** to view the minimum requirements for installing LG Bridge.

Phone software update

LG Mobile phone software update from the Internet

For more information about using this function, please visit *http://www.lg.com/common/index.jsp*, select your country and language.

This feature allows you to conveniently update the firmware on your phone to a newer version from the Internet without needing to visit a service centre. This feature will only be available if and when LG makes a newer firmware version available for your device.

Because the mobile phone firmware update requires the user's full attention for the duration of the update process, please make sure you check all instructions and notes that appear at each step before proceeding. Please note that removing the USB cable during the upgrade may seriously damage your mobile phone.

- LG reserves the right to make firmware updates available only for selected models at its own discretion and does not guarantee the availability of the newer version of the firmware for all handset models.

LG Mobile Phone software update via Over-the-Air (OTA)

This feature allows you to conveniently update your phone's software to a newer version via OTA, without connecting a USB cable. This feature will only be available if and when LG makes a newer firmware version available for your device.

To perform the phone software update,

Settings > **General** > **About phone** > **Common** > **Update centre** > **Software Update** > **Check now for update**.

- Your personal data from internal phone storage—including information about your Google account and any other accounts, your system/application data and settings, any downloaded applications and your DRM licence—might be lost in the process of updating your phone's software. Therefore, LG recommends that you backup your personal data before updating your phone's software. LG does not take responsibility for any loss of personal data.
- This feature depends on the area or service provider.

FAQ

This chapter lists some problems you might encounter when using your device. Some problems require you to call your service provider, but most are easy to fix yourself.

SIM card error

Make sure the SIM card is correctly inserted.

No network connection or dropped network

Signal is weak. Move to a window or an open area.

You are outside the carrier network area. Move and check the network.

Calls are not available

New network not authorized.

Make sure you have not set call barring for the incoming number.

Make sure you have not set call barring for the number you are dialing.

Device cannot be turned on

When the battery is completely discharged, your device will not turn on.

Fully charge the battery before turning on the device.

Charging error

Make sure device is charging at a normal temperature.

Check the charger and its connection to the device.

Use only in-box accessories which are authorized by LG.

The battery depletes faster than when first purchased

When you expose the device or the battery to very cold or hot temperatures, the battery life may be reduced.

Battery consumption will increase when you use certain features or apps, such as GPS, games or the Internet.

The battery is consumable and the battery life will get shorter over time.

Error messages appear when launching the camera

Charge the battery.

Free some memory by transferring files to a computer or deleting files from your device.

Restart the device.

If you are still having trouble with the camera app after trying these tips, contact a LG Electronics Service Center.

The photo quality is poor

The quality of your photos may vary, depending on the surroundings and the photography techniques you use.

If you take photos and videos, standard angle quality is better than wide-angle.

If you take photos in dark areas, at night or indoors, image noise may occur or images may be out of focus.

If you have any problems, reset the options.

The touch screen responds slowly or incorrectly

If you attach a screen protector or optional accessories to the touch screen, the touch screen may not function properly.

If you are wearing gloves, if your hands are not clean while touching the touch screen or if you tap the screen with sharp objects or your fingertips, the touch screen may malfunction.

The touch screen may malfunction in humid conditions or when exposed to water.

Restart your device to clear any temporary software bugs.

If the touch screen is scratched or damaged, visit a LG Electronics Service Center.

Hangs or freezes

Restart the device

If your device freezes or hangs, you may need to close apps or turn the device off and then on again.

Perform a boot-up

A soft reset may be used to reset the device if the screen freezes, or the buttons, touch screen or device are no longer responding.

To perform a soft reset of your device, simply press and hold the Volume Down and Power keys until the device restarts.

Reset the device

If the methods above do not solve your problem, perform a factory data reset.

On the settings screen, tap General > Backup & reset > Factory data reset.

* This method resets all settings for the device and deletes data. Before performing the factory data reset, remember to make back-up copies of all important data stored in the device.
* If you registered a Google account to the device, you must sign in to the same Google account after resetting the device.

Bluetooth device is not located

Make sure the Bluetooth wireless feature is activated on your device.

Make sure the Bluetooth wireless feature is activated on the device you wish to connect to.

Make sure your device and the other Bluetooth device are within the maximum Bluetooth range (10 m).

If the tips above do not solve your problem, contact a LG Electronics Service Center.

A connection is not established when you connect the device to a computer

Make sure the USB cable you are using is compatible with your device.

Make sure you have the proper driver installed and updated on your computer.

Downloaded application causes a lot of errors

Application has problems.

Remove and reinstall the application.

Anti-Theft Guide

Set up your device to prevent other people from using it if it's been reset to factory settings without your permission. For example, if your device is lost, stolen, or wiped, only someone with your Google account or screen lock information can use the device.

All you need to make sure your device is protected is:

- Set a screen lock: If your device is lost or stolen but you have a screen lock set, the device can't be erased using the Settings menu unless your screen is unlocked.
- Add your Google account on your device: If your device is wiped but you have your Google account on it, the device can't finish the setup process until your Google account information is entered again.

After your device is protected, you'll need to either unlock your screen or enter your Google account password if you need to do a factory reset. This ensures that you or someone you trust is doing the reset.



- Do not forget your Google account and password you had added to your device prior to performing a factory reset. If you can't provide the account information during the setup process, you won't be able to use the device at all after performing the factory reset.

Regulatory information (Regulation ID number, E-labeling, etc.)

For regulatory details, go to **Settings** > **General** > **Regulatory & Safety**.

Tempered glass parts

Tempered glass parts of this device are not permanent and they may wear out over time.

- If you drop your device on a hard surface or subject it to severe impact, the tempered glass may be damaged.

  If this happens, stop using your device immediately and contact an LG Customer Service Centre.
- You can purchase protective cases to protect your device from damage on the market.

  Note that these protective cases are not covered under the warranty service provided by LG Electronics and safety is not guaranteed.

Aspect ratio

This device uses 18:9 aspect ratio.

- Some downloaded apps may not support 18:9 aspect ratio.

  In this case, select the most optimal screen ratio for the app or consult the app provider for more information.

More information

Open Source Software Notice Information

To obtain the source code under GPL, LGPL, MPL, and other open source licenses, that is contained in this product, please visit *http://opensource.lge.com*.

In addition to the source code, all referred license terms, warranty disclaimers and copyright notices are available for download.

LG Electronics will also provide open source code to you on CD-ROM for a charge covering the cost of performing such distribution (such as the cost of media, shipping, and handling) upon email request to *opensource@lge.com*. This offer is valid for three (3) years from the date on which you purchased the product.

Trademarks

- Copyright ©2017 LG Electronics Inc. All rights reserved. LG and the LG logo are registered trademarks of LG Group and its related entities.
- Google™, Google Maps™, Gmail™, YouTube™, Duo™ and Google Play™ store are trademarks of Google, Inc.
- Bluetooth® is a registered trademark of Bluetooth SIG, Inc. worldwide.
- Wi-Fi® and the Wi-Fi logo are registered trademarks of the Wi-Fi Alliance.
- All other trademarks and copyrights are the property of their respective owners.

DECLARATION OF CONFORMITY

Hereby, **LG Electronics** declares that this **LG-M700A** product is in compliance with the essential requirements and other relevant provisions of Directive **2014/53/EU**.

A copy of the Declaration of Conformity can be found at *http://www.lg.com/global/declaration*

Disposal of your old appliance



1. All electrical and electronic products should be disposed of separately from the municipal waste stream via designated collection facilities appointed by the government or the local authorities.
2. The correct disposal of your old appliance will help prevent potential negative consequences for the environment and human health.
3. For more detailed information about disposal of your old appliance, please contact your city office, waste disposal service or the shop where you purchased the product.

Disposal of waste batteries/accumulators



1. This symbol may be combined with chemical symbols for mercury (Hg), cadmium (Cd) or lead (Pb) if the battery contains more than 0.0005% of mercury, 0.002% of cadmium or 0.004% of lead.
2. All batteries/accumulators should be disposed separately from the municipal waste stream via designated collection facilities appointed by the government or the local authorities.
3. The correct disposal of your old batteries/accumulators will help to prevent potential negative consequences for the environment, animal and human health.
4. For more detailed information about disposal of your old batteries/accumulators, please contact your city office, waste disposal service or the shop where you purchased the product.



CE