
Pagination & Folding



Printing Specifications

Material	Cover	Woodfree 80 g/㎡					
	Inner	Woodfree 80 g/㎡	**Note**				
Coating	Cover	Uncoated			**CHOI EUN NA**		
	Inner	Uncoated					
Color	Cover	1 color (Black)			**Prepared**	**Description**	Manual
	Inner	1 color (Black)			2018-07-25		
Size		148 x 210 mm (A5 size_Folded size)			**Checked**	**P/No.**	MFL70363022
Binding Method		**Only folding**					
Book Binding		Folding 3 times			**Appoved**	**Ver.**	1.0
Completed total pages		8					

LG
Life's Good

ENGLISH

SIMPLE MANUAL

Mini Hi-Fi System

Please read this manual carefully before operating your set and retain it for future reference.
To view the instructions of advanced features, visit http://www.lg.com and then download Owner's Manual.
Some of the content in this manual may differ from your unit.

MODEL
CK57


MFL70363022

www.lg.com

Copyright © 2018 LG Electronics Inc. All Rights Reserved.



Front Panel



1 USB 1 Port
You can play sound files by connecting the USB device.

2 Display window

3 ⏻ (Standby)
Turns the power on or off.

USB REC / DEMO
- Records to USB.
- To stop Recording, press and hold for 3 seconds.
- In power off status, if you press **USB REC / DEMO**, show DEMO mode.

⏮ (Skip/Search)
- Skips backward.
- Searches for a section within a track/file.
- Selects the radio stations.

☐ (Stop)
Stops playback or cancels DELETE function.

4 **SOUND EFFECT / SEARCH**
- Chooses sound impressions.
- Searches a folder or a file.
- Selects the lighting effects.

5 **REGION EQ / BASS BLAST (or BASS BLAST+)**
- Chooses region equalizer.
- Press and hold to select BASS (or BASS+) effect directly.

SEARCH
Moves to folder or file in selection mode.

OK
Selects a folder when searching a file.

6 **LIGHTING**
Selects lighting mode.

VOICE CANCELLER
You can reduce the vocal tones during music playback from various input sources.

7 **PORTABLE IN** jack

MIC (Microphone) jack

8 Disc tray

9 USB 2 Port
You can play sound files by connecting the USB device.

10 (Remote sensor)

11 **F** (Function)
Selects the function and input source.

WIRELESS LINK
- Selects MAIN or OTHER on WIRELESS PARTY LINK mode.
- Enable or disable WIRELESS PARTY LINK mode.

⏭ (Skip/Search)
- Skips forward.
- Searches for a section within a track/file.
- Selects the radio stations.

⏏ (Open/Close)
Opens and closes the disc tray.

12 **MASTER VOL.** (Volume) **/ MULTI**
- Adjust speaker volume.
- Adjust microphone volume.
- Selects vocal effects.

13 **VOCAL EFFECTS**
Selects VOCAL EFFECTS mode.

MIC VOL (Microphone volume)
Selects microphone volume mode.


ECHO
Selects ECHO mode.

14 **KEY CHANGER (♭/♯)**
Changes the key to suit your vocal range.

15 **AUTO DJ**
Selects the AUTO DJ mode.

⏯ (Play/Pause)
- Starts or pauses playback.
- Selects stereo/mono.

Rear Panel



1 Power cord


2 **SPEAKERS** connector

3 **SPEAKER LIGHTING SYSTEM**
Connect the speaker lighting cables.

4 **AUX IN (L/R)**
Connect an auxiliary device.

5 **ANTENNA** (FM/AM)

Speaker Connection




Additional Information

Specifications

Power Requirements	Refer to the main label on the unit.
Power Consumption	Refer to the main label on the unit.
Dimensions (W x H x D)	Approx. 350 mm x 166 mm x 276 mm
Bus Power Supply (USB)	5 V ⎓ 500 mA
Amplifier (Total RMS output power)	1,100 W RMS

Design and specifications are subject to change without notice.

Replacement of battery



Due to the environment government regulations about import and batteries destruction in Colombia, this model will not bring the batteries of remote control included.

Controller App

Download the **Music Flow Bluetooth** App to your device. (Android only)

LG Sound Sync (Wireless)



For more information, download the online owner's manual. **http://www.lg.com**

LG
Life's Good

LG
Life's Good

MANUAL SIMPLE

MINI COMPONENTE

Lea este manual detenidamente antes de utilizar su equipo y guárdelo para futuras consultas.
Para ver las instrucciones de las características avanzadas, visite http://www.lg.com y descargue el Manual del propietario. Ciertos contenidos de este manual pueden no coincidir con los de su unidad.

MODELO
CK57

MFL70363022


www.lg.com

Copyright © 2018 LG Electronics Inc. Todos los derechos reservados.

ESPAÑOL



Panel frontal



1 Puerto USB 1
Puede reproducir archivos conectando el dispositivo USB.

2 Ventana de visualización

3 ⏻ (Modo espera)
Enciende o apaga.

USB REC / DEMO
- Graba al USB.
- Para detener la Grabación, pulse y mantenga presionado durante 3 segundos.
- En estado apagado, si presiona **USB REC / DEMO**, se muestra el modo DEMO.

⏮ (Saltar/Buscar)
- Salta hacia atrás.
- Busca una sección dentro de una pista/archivo.
- Selecciona las estaciones de radio.

□ (Parar)
Detiene la reproducción o cancela la función DELETE.

4 **SOUND EFFECT / SEARCH**
- Selecciona los efectos de sonido.
- Busca un archivo o carpeta.
- Selecciona los efectos de iluminación.

5 **REGION EQ / BASS BLAST (o BASS BLAST+)**
- Elige el ecualizador de la región.
- Pulse y mantenga para seleccionar directamente el efecto BASS (o BASS+).

SEARCH
Se desplaza a la carpeta y archivo en el modo de selección.

OK
Selecciona una carpeta cuando busca un archivo.

6 **LIGHTING**
Selecciona el modo de iluminación.

VOICE CANCELLER
Puede reducir los tonos vocales durante la reproducción de m ´ suica de varias fuentes de entrada.

7 Clavija **PORTABLE IN** (ENTRADA PORTÁTIL)

Clavija **MIC** (Micrófono)

8 Bandeja de discos

9 Puerto USB 2
Puede reproducir archivos conectando el dispositivo USB.

10 (Sensor remoto)

11 **F** (Función)
Selecciona la función y fuente de entrada.

WIRELESS LINK
- Selecciona MAIN (PRINCIPAL) u OTHER (OTRO) en el modo WIRELESS PARTY LINK.
- Activa o desactiva el modo WIRELESS PARTY LINK.

⏭ (Saltar/Buscar)
- Salta hacia delante.
- Busca una sección dentro de una pista/archivo.
- Selecciona las estaciones de radio.

⏏ (Abrir/Cerrar)
Abre y cierra la bandeja de discos.

12 **MASTER VOL.** (Volumen) **/ MULTI**
- Ajusta el volumen de la bocina.
- Ajusta el volumen del micrófono.
- Selecciona los efectos vocales.

13 **VOCAL EFFECTS**
Selecciona el modo VOCAL EFFECTS .

MIC VOL (Volumen micrófono)
Selecciona el modo de volumen del micrófono.


ECHO
Selecciona el modo ECHO.

14 **KEY CHANGER (♭/#)**
Cambia la clave para adecuarla al rango vocal.

15 **AUTO DJ**
Selección del modo AUTO DJ.

⏯ (Reproducir/Pausa)
- Inicia o pausa la reproducción.
- Selecciona Estéreo/Monoaural.

Panel Trasero



1 Cable de alimentación


2 Conector **SPEAKERS**

3 **SPEAKER LIGHTING SYSTEM**
Conecte los cables de iluminación de la bocina.

4 **AUX IN (L/R)**
Conecte un dispositivo auxiliar.

5 **ANTENNA** (FM/AM)

Conexión de las bocinas




Información adicional

Especificaciones

Requisitos de alimentación eléctrica	Consulte la etiqueta principal de la unidad
Consumo de energía	Consulte la etiqueta principal de la unidad
Dimensiones (An x Al x F)	Aprox. 350 mm x 166 mm x 276 mm
Suministro de energía de bus (USB)	5 V ⎓ 500 mA
Amplificador (potencia de salida valor cuadrático medio total)	1 100 W Eficaz

El diseño y las especificaciones están sujetos a cambios sin previo aviso.

Sustitución de la batería



Por regulaciones de tipo ambiental respecto a la importación y destrucción de baterías en Colombia, este modelo no incluye las pilas del control remoto.

Aplicación del controlador

Descargue la aplicación **Music Flow Bluetooth** a su dispositivo. (Sólo Android)

LG Sound Sync (inalámbrico)



Para más información, descargue el manual del propietario. **http://www.lg.com**

LG
Life's Good