עברית

ENGLISH

LG
Life's Good

USER GUIDE

LG-H410YK

www.lg-mobile.co.il

MFL69407901 (1.0)

ברוכים הבאים!

תודה על שבחרת ב-LG. קרא בעיון מדריך למשתמש זה לפני שימוש ראשון במכשיר, כדי להבטיח שימוש בטוח ונכון.

- השתמש תמיד באביזרים מקוריים של LG. הפריטים שסופקו עוצבו אך ורק עבור מכשיר זה, וייתכן שהם לא יהיו תואמים למכשירים אחרים.
- מכשיר זה אינו מתאים ללקויי ראייה מפני שלוח המקשים שלו נמצא במסך המגע.
- התיאורים מבוססים על הגדרות ברירת המחדל של המכשיר.
- יישומי ברירת מחדל כפופים לעדכונים, ותמיכה עבור יישומים אלה עלולה להיפסק ללא הודעה מראש. אם יש לך שאלות כלשהן בנוגע ליישום שסופק עם המכשיר, פנה אל מרכז השירות של LG. עבור יישומים שהותקנו על-ידי המשתמש, פנה אל ספק השירות הרלוונטי.
- שינוי מערכת ההפעלה של המכשיר או התקנת תוכנה ממקורות בלתי רשמיים עלולים לגרום נזק למכשיר ולהוביל לפגיעה בנתונים או לאובדן נתונים. פעולות כאלה יהוו הפרה של הסכם הרישיון שלך עם LG ויביאו לביטול האחריות.
- חלק מהתוכן והאיורים עשויים להיות שונים ממה שנראה בהתקן שלך, בהתאם לאזור, לספק השירות, לגרסת התוכנה או לגרסת מערכת ההפעלה, והם נתונים לשינויים ללא הודעה מראש.

הודעות הכוללות הוראות

⚠ אזהרה	מצבים שעלולים לגרום פציעה לך ולאחרים
זהירות!	מצבים שעלולים לגרום נזק למכשיר או לציוד אחר
הערה	הודעה או מידע נוסף
עצה!	טיפים בעת שימוש בפונקציה

תוכן העניינים

הנחיות לשימוש בטוח ויעיל 5

הודעה חשובה..... 13

היכרות עם הטלפון 16

פריסת הטלפון..... 16

התקנת כרטיס SIM או USIM והסוללה. 18

טעינת הסוללה 20

הכנסת כרטיס זיכרון..... 21

הוצאת כרטיס הזיכרון..... 22

שינוי השיטה של נעילת המסך..... 22

המסך הראשי..... 23

עצות בנוגע למסך המגע..... 23

מסך ראשי 24

התאמה אישית של המסך הראשי 25

חזרה ליישומים שהיו בשימוש לאחרונה. 26

לוח ההתראות..... 26

מקלדת וירטואלית..... 29

תכונות מיוחדות 30

תצלום בתנועת יד 30

הגדרת חשבון Google..... 31

יצירת חשבון Google..... 31

כניסה לחשבון Google..... 31

התחברות לרשתות ולמכשירים 33

Wi-Fi..... 33

Bluetooth..... 34

Wi-Fi Direct 35

העברת נתונים בין מחשב ומכשיר 36

שיחות..... 37

ביצוע שיחה 37

התקשרות לאנשי הקשר 37

מענה לשיחה ודחיית שיחה..... 37

ביצוע שיחה נוספת..... 38

צפייה ביומני השיחות..... 38

הגדרות שיחה 38

אנשי קשר 39

חיפוש איש קשר 39

הוספת איש קשר חדש..... 39

אנשי קשר מועדפים 39

יצירת קבוצה..... 40

הודעות 41

שליחת הודעה..... 41

תצוגת שיחה..... 42

שינוי הגדרות שליחת ההודעות שלך.... 42

מצלמה ווידאו..... 43

אפשרויות מצלמה בתצוגה המקדימה .. 43

הגדרת הרזולוציה 44

לאחר שצילמת תמונה..... 44

הקלטת וידאו..... 44

לאחר הקלטת וידאו..... 45

גלריה 45

מולטימדיה 48

נגן מוסיקה..... 48

כלי שירות..... 50

שעון 50

מחשבון..... 51
לוח שנה..... 52
הקלטה קולית 52
חיפוש קולי 52
הורדות 53
רדיו FM..... 53

דפדפן אינטרנט..... 54
Internet 54
Chrome 55

הגדרות..... 56
רשתות אלחוטיות 56
התקן..... 58
אישי..... 62
מערכת 65

עדכון תוכנת הטלפון..... 68
עדכון תוכנת הטלפון..... 68

אודות מדריך למשתמש זה..... 70
אודות מדריך למשתמש זה..... 70
סימנים מסחריים..... 71

אביזרים 72

פתרון בעיות..... 73

שאלות נפוצות 76

הנחיות לשימוש בטוח ויעיל

הקפד לקרוא הנחיות פשוטות אלה. אי עמידה בהנחיות אלו עלולה להיות מסוכנת או בלתי חוקית.
למקרה של תקלה, המכשיר שלך מכיל כלי תוכנה שיאסוף יומן תקלות. כלי זה אוסף רק נתונים ספציפיים לתקלה, כגון עוצמת אות, מיקום מזהה התא בעת ניתוק פתאומי של השיחה ויישומים שנטענו. היומן משמש רק לסיוע בזיהוי הגורם לתקלה. יומנים אלה מוצפנים, ורק מרכז תיקונים מוסמך של LG יוכל לגשת אליהם במקרה שתצטרך למסור את המכשיר לתיקון.

חשיפה לאנרגיית תדר רדיו

מידע על חשיפה לגלי רדיו ושיעור ספיגה סגולית (SAR).
טלפון נייד זה מדגם LG-H410YK תוכנן לעמוד בדרישות הבטיחות הרלוונטיות לחשיפה לגלי רדיו. דרישות אלו מבוססות על קווים מנחים מדעיים, ואלה כוללים שולי בטיחות המיועדים להבטיח את בטיחותם של כל בני האדם, בלא קשר לגילם או למצב בריאותם.

- הנחיות החשיפה לגלי רדיו משתמשות ביחידת מידה הנקראת "שיעור ספיגה סגולית" (SAR). בדיקות SAR מבוצעות באמצעות שיטות מתוקננות, כאשר הטלפון משדר ברמת העוצמה המרבית המאושרת עבורו בכל תחומי התדרים שבשימוש.
- אף כי עשויים להיות הבדלים בין רמות ה-SAR של דגמי טלפונים שונים של LG, כל הטלפונים מתוכננים לעמוד בהנחיות המתאימות של חשיפה לגלי רדיו.
- מגבלת ה-SAR המומלצת על-ידי הוועדה הבין-לאומית להגנה מפני קרינה בלתי מיינת (ICNIRP) היא ממוצע של 2 ואט/ק"ג על כל 10 גר' של רקמה.
- ערך ה-SAR הגבוה ביותר עבור דגם טלפון זה שנמדד לשימוש באוזן הוא 0.254 ואט/ק"ג (10 גר'), וכאשר הוא נישא על הגוף, ערך זה עומד על 0.557 ואט/ק"ג (10 גר').

- מכשיר זה עומד בהנחיות החשיפה ל-RF כשמשתמשים בו בתנוחת השימוש הרגילה ליד האוזן או כשהוא ממוקם לפחות 1.5 ס"מ מהגוף. כאשר נעשה שימוש בנרתיק נשיאה או בתפס או מנשא לחגורה, אסור שתהיה בהם מתכת כלשהי, והמרחק בין המכשיר לגוף צריך להיות לפחות 1.5 ס"מ. כדי לשדר קובצי נתונים או הודעות, מכשיר זה מחייב חיבור איכותי לרשת. במקרים מסוימים עלול שידור קבצי נתונים או הודעות להיות מושהה עד שחיבור כזה יהיה זמין. הקפד על שמירת הוראות המרחק המינימלי המוזכרות לעיל עד לסיום השידור.

טיפול במוצר ותחזוקה

⚠ אזהרה
הקפד להשתמש בסוללות, במטענים ובאביזרים מקוריים של LG, המאושרים לשימוש בדגם טלפון ספציפי זה. השימוש בסוגים אחרים עשוי לבטל את האישור או האחריות החלים על הטלפון ועלול להיות מסוכן.

- אין לפרק יחידה זו. כאשר נדרש תיקון, פנה לטכנאי שירות מוסמך.
- תיקונים במסגרת האחריות, לפי שיקול דעתה של LG, עשויים לכלול חלקים או לוחות חלופיים, חדשים או מחודשים, ובלבד שהם מצוידים בפונקציונליות זהה לזו של החלקים המוחלפים.
- אין לקרב את המכשיר למכשירים חשמליים כגון טלוויזיות, מכשירי רדיו ומחשבים אישיים.
- יש לשמור את היחידה הרחק ממקורות חום כדוגמת רדיאטורים או תנורי בישול.
- אין להפיל את היחידה.
- אין לאפשר זעזוע מכני או חבטה.
- יש לכבות את הטלפון בכל מקום שבו נדרש הדבר על-ידי תקנות מיוחדות. לדוגמה, אין להשתמש בטלפון בבתי חולים, שכן הפעלתו עלולה להשפיע על פעולת מכשור רפואי רגיש.
- אין לאחוז בטלפון בידיים רטובות בזמן הטענתו. אחיזה במצב כזה עלולה לגרום להתחשמלות ולהסב נזק כבד לטלפון.

- אין לטעון את הטלפון ליד חומר דליק, מכיוון שהמכשיר עלול להתחמם ולעלות באש.
- יש להשתמש במטלית יבשה לניקוי חלקו החיצוני של המכשיר (אין להשתמש בחומרים ממסים כגון בנזן, מדלל או אלכוהול).
- אין לטעון את הטלפון כאשר הוא נמצא על-גבי מצעים או ריפוד.
- יש לטעון את הטלפון באזור מאוורר היטב.
- אין לחשוף יחידה זו לכמות מוגזמת של עשן או אבק.
- אין להחזיק את הטלפון בסמוך לכרטיסי אשראי או כרטיסי נסיעה; הנתונים בפס המגנטי עלולים להיפגם.
- אין להקיש על המסך באמצעות חפצים חדים, שכן הדבר עלול לגרום נזק לטלפון.
- אין לחשוף את הטלפון לנוזלים או ללחות.
- יש לנקוט זהירות בשימוש באביזרים, כמו אוזניות. אין לגעת באנטנה שלא לצורך.
- אם זכוכית המכשיר שבורה או סדוקה, אל תגע בה או תנסה להסיר אותה ואל תשתמש במכשיר. האחריות אינה מכסה נזקים שנגרמו לתצוגת הזכוכית כתוצאה מפגיעה ושימוש לרעה.
- הטלפון שלך הוא מכשיר אלקטרוני המייצר חום במהלך הפעלה רגילה. בהיעדר אוורור הולם, מגע ישיר וממושך מאוד של העור עלול לגרום לאי-נוחות או לכוויות קלות. לפיכך, יש לנקוט זהירות בהחזקת הטלפון במהלך ההפעלה או מיד אחריה.
- אם הטלפון נרטב, נתק אותו מיד והנח לו להתייבש לגמרי. אל תנסה להאיץ את תהליך הייבוש בעזרת מקור חום חיצוני, כמו תנור, מיקרוגל או מייבש שיער.
- הנוזלים שחדרו לטלפון ישנו את צבע תווית המוצר שבתוך המכשיר. כתב האחריות אינו מכסדה נזק למכשיר כתוצאה מחשיפה לנוזלים.

תפעול יעיל של הטלפון

מכשירים אלקטרוניים

כל הטלפונים הניידים עלולים לספוג הפרעות שישפיעו לרעה על ביצועיהם.

- אין להשתמש בטלפון הנייד בסמוך לציוד רפואי ללא קבלת רשות. יש להימנע מהנחת הטלפון מעל לקוצב לב, למשל בכיס החזה.
- טלפונים ניידים עלולים להפריע לעזרי שמיעה מסוימים.
- הפרעה משנית עלולה להשפיע על מכשירי טלוויזיה, מכשירי רדיו, מחשבים וכולי.
- השתמש בטלפון שלך בטמפרטורות שבין 0 ºC ו-40 ºC, אם ניתן. חשיפת הטלפון לטמפרטורות נמוכות או גבוהות באופן קיצוני עלולה לגרום לנזק, לתקלות או אפילו לפיצוץ.

בטיחות בדרכים

בדוק את החוקים והתקנות הנוגעים לשימוש בטלפונים ניידים באזורים שבהם אתה נוהג.

- אין להחזיק את הטלפון ביד בזמן נהיגה.
- יש להפנות את מלוא תשומת הלב לנהיגה.
- רד לשול הדרך וחנה לפני ביצוע שיחה או מענה לשיחה, בהתאם לתנאי הדרך.
- אנרגיית תדר רדיו עשויה להשפיע על מערכות אלקטרוניות מסוימות בכלי רכב, כדוגמת מערכות סטריאו וציוד בטיחות.
- אם המכונית מצוידת בכרית אוויר מתנפחת, אין לחסום אותה על-ידי התקנה של ציוד אלחוטי נישא. הדבר עלול לגרום לכשל של הכרית או לפציעה חמורה עקב ביצועים לא נאותים שלה.
- אם אתה מאזין למוסיקה בעת תנועה, ודא שהעוצמה היא ברמה סבירה, כך שתמשיך להיות מודע לסביבתך. הדבר חשוב במיוחד בקרבת כבישים.

מנעו נזק לשמיעתכם



כדי למנוע נזק אפשרי לשמיעה, אל תאזין בעוצמות קול גבוהות לאורך זמן.

חשיפה לעוצמות קול גבוהות במשך פרקי זמן ארוכים עלולה להזיק לשמיעה. לכן אנו ממליצים שלא תדליק או תכבה את המכשיר סמוך לאוזנך. מומלץ גם להגדיר את עוצמת הקול של המוסיקה והשיחה לרמה סבירה.

- כאשר אתה משתמש באוזניות, הנמך את עוצמת הקול אם אינך מצליח לשמוע את האנשים שבסביבתך מדברים, או אם האדם שלצדך יכול לשמוע את מה שאתה שומע באוזניות.

הערה

- עוצמת קול מופרזת מאוזניות פנימיות ואוזניות חיצוניות עלולה לגרום לאובדן שמיעה.

חלקי זכוכית

חלקים מסוימים של ההתקן הנייד עשויים מזכוכית. זכוכית זו עלולה להישבר אם המכשיר ייפול על משטח קשה או יקבל מכה חזקה. אם הזכוכית נשברת, אל תנסה לגעת בה או להסיר אותה. יש להפסיק להשתמש בהתקן הנייד עד להחלפת הזכוכית על-ידי ספק שירות מורשה.

סביבה שבה מבוצעות עבודות עם חומרי נפץ

אין להשתמש בטלפון באזורים שבהם מתבצעות פעולות פיצוץ. שים לב להגבלות ועמוד בכל התקנות או הכללים.

סביבה שבה קיימת סבירות לפיצוץ

- אין להשתמש בטלפון באזורי תדלוק.
- אין להשתמש בו בסמוך לדלק או לכימיקלים.
- אין להוביל או לאחסן גז דליק, נוזלים דליקים או חומרי נפץ בתא הרכב המכיל את הטלפון הנייד או את אביזריו.

כלי טיס

התקנים אלחוטיים עלולים לגרום להפרעה במטוס.

- יש לכבות את הטלפון הנייד לפני העלייה למטוס.
- אין להשתמש בו על הקרקע ללא קבלת רשות מאנשי הצוות.

ילדים

יש לשמור על הטלפון במקום בטוח, מחוץ להישג ידם של ילדים קטנים. המכשיר כולל חלקים זעירים העלולים להוות סכנת חנק אם ינותקו מהטלפון.

שיחות חירום

רק רשתות סלולריות מסוימות מאפשרות לבצע שיחות חירום. לפיכך, בשום מקרה אין לסמוך רק על הטלפון לביצוע שיחות חירום. בדקו את הנושא עם חברת הסלולר המקומית.

מידע לגבי הסוללה והטיפול בה

- אין צורך לפרוק את הסוללה במלואה לפני טעינתה מחדש. בניגוד למערכות סוללה אחרות, אין השפעת זיכרון שעלולה לפגום בביצועי הסוללה.
- יש להשתמש אך ורק בסוללות ובמטענים של LG. מטעני LG מיועדים להארכת חיי הסוללה.
- אין לפרק או לקצר את הסוללה.
- יש לשמור על ניקיון מגעי המתכת של הסוללה.

- יש להחליף את הסוללה כאשר היא אינה מפיקה עוד רמת ביצועים סבירה. ניתן לטעון מחדש את מארז הסוללה מאות פעמים לפני שיהיה צורך להחליפו.
- כדי להשיג שמישות סוללה מרבית, יש לטעון אותה מחדש אם לא הייתה בשימוש במשך זמן רב.
- אין לחשוף את מטען הסוללה לאור שמש ישיר או להשתמש בו בתנאי לחות גבוהה, כמו חדר אמבטיה.
- אין להשאיר את הסוללה במקומות חמים או קרים, שכן הדבר עלול לפגום בביצועיה.
- קיימת סכנת התפוצצות אם הסוללה הוחלפה בסוג סוללה שאינו מתאים.
- השלך סוללות משומשות על פי הוראות היצרן. יש למחזר, אם אפשר. אין להשליך אותן כאשפה ביתית.
- אם עליך להחליף סוללה, קח אותה למרכז השירות המורשה הקרוב של LG Electronics או לספק לצורך קבלת סיוע.
- יש לנתק תמיד את המטען מהשקע לאחר שהטלפון נטען במלואו כדי למנוע בזבוז מיותר של חשמל מצד המטען.
- אורך חיי הסוללה בפועל תלוי בתצורת הרשת, בהגדרות המוצר, באופי השימוש, בתנאי הסוללה ובתנאים הסביבתיים.
- הקפד שלא ייווצר מגע בין הסוללה לבין פריטים חדים כגון שיניים או ציפורניים של בעל חיים. מגע כזה עלול לגרום לשריפה.

פרטי הודעה על תוכנת קוד פתוח

באתר בקרו אנא, זה במסמך הכלולים אחרים פתוח קוד ורישיונות MPL, LGPL, GPL תחת המקור קוד את להשיג מנת על http://opensource.lge.com.

להורדה זמינים, זה במסמך שמופיעים יוצרים זכויות לגבי והערות אחריות ויתור כתבי, הרישוי מונחי כל, המקור לקוד בנוסף.

דמי, האחסון אמצעי מחיר, לדוגמה, זו פעולה של הביצוע עלות במחיר תקליטור על-גבי מקור קוד תספק LG Electronics חברת שנים (3) שלוש למשך תקפה זו הצעה opensource@lge.com. לכתובת אלקטרוני בדואר בקשה תשלחו אם, וטיפול משלוח המוצר של הרכישה ממועד.

כיצד לעדכן את ההתקן

גש אל מהדורות קושחה עדכניות, פונקציות תוכנה חדשות ושיפורים.

- **בחר את עדכון התוכנה בתפריט ההגדרות של ההתקן.**
- **עדכן את ההתקן על-ידי חיבורו למחשב.** למידע נוסף אודות השימוש בפונקציה זו, בקר בכתובת http://www.lg.com/common/index.jsp בחר את המדינה והשפה שלך.

הצהרת תאימות

בזאת, **LG Electronics** מצהירה שהמוצר **LG-H410YK** תואם לדרישות היסודיות ולתנאים הרלוונטיים האחרים של הנחיה **1999/5/EC**. ניתן למצוא עותק של הצהרת התאימות בכתובת **http://www.lg.com/global/declaration**

הודעה חשובה

אנא קרא מידע זה לפני תחילת השימוש בטלפון!

לפני שתיקח את הטלפון לנקודת שירות או שתתקשר לנציג שירות, אנא בדוק אם חלק מהבעיות שבהן נתקלת מתוארות בסעיף זה.

1. זיכרון הטלפון

כאשר השטח הפנוי בזיכרון הטלפון קטן מ-10MB, הטלפון לא יכול לקבל הודעות חדשות. מומלץ לבדוק את זיכרון הטלפון ולמחוק חלק מהנתונים, כגון יישומים או הודעות, כדי לפנות נפח זיכרון.

כדי להסיר התקנה של יישום:

1 לחץ על ○ והקש על ⋮⋮⋮ > ⚙ > **יישומים**.

2 לאחר שיופיעו כל היישומים, גלול ובחר את היישום שאת התקנתו ברצונך להסיר.

3 הקש על **הסר התקנה**.

2. מיטוב חיי הסוללה

הארך את חיי הסוללה על-ידי כיבוי תכונות שאין צורך בפעולה רציפה שלהן ברקע. תוכל לפקח על המידה שבה יישומים ומשאבי מערכת צורכים כוח סוללה.

הארכת חיי הסוללה של הטלפון:

- כבה תקשורת רדיו שאינה בשימוש. אם אינך משתמש ב-Wi-Fi, חיבור Bluetooth או GPS, כבה אותם.
- הפחת את בהירות המסך וקבע פרק זמן קצר יותר לכיבוי אוטומטי של המסך.
- בטל את הסנכרון האוטומטי של Gmail, לוח שנה, אנשי קשר ויישומים אחרים.

- חלק מהיישומים שתוריד עשויים לצרוך כוח סוללה.
- בזמן השימוש ביישומים שהורדו, בדוק את רמת הטעינה של הסוללה.

3. לפני התקנת יישום או מערכת הפעלה בקוד פתוח

⚠ אזהרה

- אם אתה מתקין או משתמש במערכת הפעלה שונה מזו שסיפק היצרן, הדבר עלול לגרום לתפקוד לקוי של הטלפון. בנוסף, האחריות על הטלפון תתבטל.
- כדי להגן על הטלפון ועל הנתונים האישיים שלך, הורד יישומים ממקורות מהימנים בלבד, כגון Play Store™. התקנה שגויה של יישומים בטלפון עלולה לגרום לטלפון לפעול בצורה לא תקינה או להתרחשות שגיאה חמורה. יש להסיר מהטלפון את היישומים הללו ואת כל ההגדרות והנתונים הקשורים אליהם.

4. פתיחת יישומים ומעבר ביניהם

קל לבצע ריבוי-משימות במערכת Android; ניתן להפעיל יותר מיישום אחד בו-זמנית. אין צורך לצאת מיישום לפני פתיחת יישום אחר. ניתן להשתמש בכמה יישומים פתוחים ולעבור ביניהם. מערכת Android מנהלת את היישומים, ועוצרת ומפעילה אותם בהתאם לצורך כדי להבטיח שיישומים לא פעילים לא יצרכו משאבים שלא לצורך.

1 לחץ על □. תוצג רשימה של יישומים שהיו בשימוש לאחרונה.

2 הקש על היישום שאליו ברצונך לגשת. פעולה זו אינה מפסיקה את פעולתו של היישום הקודם ברקע. הקפד להקיש על ◁ כדי לצאת מהיישום לאחר השימוש בו.


- כדי לסגור יישום מרשימת היישומים שהיו בשימוש לאחרונה, החלק ימינה או שמאלה את התצוגה המקדימה של היישום. כדי לנקות את כל היישומים, הקש על **נקה הכל**.

5. כאשר המסך קופא

אם המסך קופא או שהטלפון אינו מגיב כשאתה מנסה לתפעל אותו, הוצא את הסוללה והכנס אותה מחדש. לאחר מכן הפעל מחדש את הטלפון.

היכרות עם הטלפון

פריסת הטלפון



מקש אחורה	חזרה למסך הקודם. סוגר גם פריטים קופצים, כגון תפריטים, תיבות דו-שיח ומקלדת וירטואלית.
מקש הבית	חזרה למסך הבית מכל מסך.
מקש יישומים אחרונים	מציג יישומים שהיו בשימוש לאחרונה. אם תקיש ותחזיק בלחצן זה, הוא יביא לפתיחת תפריט של אפשרויות זמינות.
מקש QuickButton	• לחץ כדי להשתמש ביישום או בתכונה שהוקצו קודם לכן. • לחץ לחיצה ארוכה כדי להגדיר את QuickButton.
מקש ניתוק/ הפעלה	• הפעלה/כיבוי של הטלפון על-ידי לחיצה ממושכת על מקש זה. • לחץ לחיצה קצרה כדי לסיים יישום נוכחי ולחזור למסך הראשי מכל מסך.

הערה: חיישן קרבה

• בעת קבלת שיחות וביצוע שיחות, חיישן הקרבה מכבה אוטומטית את התאורה האחורית ונועל את המסך כאשר הוא חש שהטלפון קרוב לאוזן. תכונה זו מאריכה את חיי הסוללה ומונעת את הפעלת מסך המגע שלא בכוונה במהלך השיחה.


אזהרה

הנחת עצם כבד על הטלפון או ישיבה עליו עלולות לגרום לפגיעה בפונקציות של הצג ומסך המגע. אין לכסות את חיישן הקרבה במגיני מסך או בכל סוג אחר של ציפוי מגן. הדבר עלול לגרום לתקלה בחיישן.


התקנת כרטיס SIM או USIM והסוללה

הכנס את כרטיס SIM או USIM שקיבלת מספק שירותי הטלפון הנייד, וכן את הסוללה הכלולה.

1 כדי להסיר את המכסה האחורי, החזק את הטלפון היטב ביד אחת. ביד השנייה משוך והסר את המכסה האחורי בעזרת ציפורן האגודל כמוצג באיור להלן.



2 החלק את כרטיס SIM אל תוך החריץ של כרטיס SIM כפי שמוצג באיור. ודא שאזור מגעי הזהב של הכרטיס פונה מטה.




⚠ אזהרה

אין להכניס כרטיס זיכרון לחריץ של כרטיס SIM. אם קרה שכרטיס זיכרון נתקע בחריץ של כרטיס SIM, מסור את המכשיר למרכז שירות של LG על מנת להוציא את כרטיס הזיכרון.


הערה

- כרטיסי microSIM בלבד פועלים עם המכשיר.

3 הכנס את הסוללה.



4 כדי להחזיר את המכסה למכשיר, ישר את המכסה האחורי מעל תא הסוללה ❶ ולחץ אותו מטה עד שייכנס למקומו בנקישה ❷.




טעינת הסוללה

טען את הסוללה לפני השימוש הראשון. השתמש במטען כדי לטעון את הסוללה. ניתן גם להשתמש במחשב כדי לטעון את הסוללה, על-ידי חיבור הטלפון אליו באמצעות כבל ה-USB.

⚠ אזהרה

השתמש אך ורק במטענים, סוללות וכבלים המאושרים על-ידי LG. אם תשתמש במטענים, סוללות וכבלים שאינם מאושרים, הדבר עלול לגרום לעיכוב בטעינת הסוללה. לחלופין, הדבר עלול לגרום לסוללה להתפוצץ או לגרום נזק למכשיר, וזה אינו מכוסה במסגרת האחריות.

מחבר המטען ממוקם בתחתית הטלפון. הכנס את המטען, וחבר אותו לשקע חשמל.



הערה

- אל תפתח את המכסה האחורי במהלך טעינת הטלפון.

הכנסת כרטיס זיכרון

המכשיר תומך בכרטיס microSD בנפח 32GB לכל היותר. בהתאם ליצרן ולסוג של כרטיס הזיכרון, ייתכן שכרטיסי זיכרון מסוימים לא יהיו תואמים למכשיר.

⚠ אזהרה


ייתכן שכרטיסי זיכרון מסוימים לא יהיו תואמים באופן מלא למכשיר. שימוש בכרטיס שאינו תואם עלול לגרום נזק למכשיר או לכרטיס הזיכרון, או לפגום בנתונים המאוחסנים בו.

הערה

- כתיבה ומחיקה של נתונים לעתים תכופות יביאו לקיצור החיים של כרטיסי זיכרון.

1 הסר את המכסה האחורי.

2 הכנס כרטיס זיכרון כשהמגעים המוזהבים פונים כלפי מטה.



3 החזר את המכסה האחורי למקומו.

הוצאת כרטיס הזיכרון

לפני הוצאת כרטיס הזיכרון, תחילה בטל את טעינתו להוצאה בטוחה.

1 לחץ על ○ והקש על ⋯ > ⚙ > **אחסון** > **ביטול טעינת כרטיס SD**.

2 הסר את המכסה האחורי ומשוך החוצה את כרטיס הזיכרון.

⚠ אזהרה

אין להוציא את כרטיס הזיכרון בזמן שהמכשיר מעביר מידע או מבצע גישה למידע. פעולה זו עלולה לגרום פגיעה או אובדן נתונים, או לגרום נזק לכרטיס הזיכרון או למכשיר. אין LG אחראית לאובדן הנובע משימוש לא נכון בכרטיסי זיכרון פגומים, לרבות אובדן נתונים.

שינוי השיטה של נעילת המסך

באפשרותך לשנות את האופן שבו אתה נועל את המסך כדי למנוע מאחרים לגשת אל המידע האישי שלך.

1 לחץ על ○ והקש על tap ⋯ > ⚙ > **נעילת מסך** > **בחר נעילת מסך**.

2 בחר את נעילת המסך הרצויה מבין 'ללא', PIN ו'סיסמה'.

המסך הראשי

עצות בנוגע למסך המגע

להלן מספר עצות בנושא ניווט בטלפון.


- **הקש או גע** – הקשה באצבע יחידה בוחרת פריטים, קישורים, קיצורי דרך ואותיות במקלדת שעל המסך.
- **גע והחזק** – גע והחזק בפריט במסך על-ידי הקשה עליו ואי-הרמה של האצבע עד שתתרחש פעולה.
- **גרור** – גע והחזק בפריט לרגע ולאחר מכן, מבלי להרים את האצבע, הזז את האצבע על המסך עד שתגיע למיקום היעד. ניתן לגרור פריטים במסך הראשי כדי לשנות את מיקומם.
- **החלקה רגילה או החלקה מהירה** – כדי לבצע החלקה רגילה או החלקה מהירה, הזז את האצבע במהירות על-גבי שטח המסך, מבלי להשהות את האצבע כשאתה נוגע במסך לראשונה (כדי לא לגרור פריט בטעות).
- **הקשה כפולה** – הקש פעמיים כדי להגדיל את התצוגה של דף אינטרנט או מפה.
- **צבוט כדי לשנות את גודל התצוגה** – השתמש באצבע המורה ובאגודל בתנועת צביטה או פריסה כדי להקטין או להגדיל את התצוגה כשאתה משתמש בדפדפן או במפות, או כשאתה צופה בתמונות.
- **סובב את המסך** – ביישומים ותפריטים רבים, כיוון המסך מתאים את עצמו לכיוון הפיזי של המכשיר.

הערה

- אין צורך ללחוץ חזק מדי, מסך המגע רגיש דיו כדי לחוש במגע קל אך החלטי.
- השתמש בקצה האצבע כדי להקיש על האפשרות הרצויה. היזהר שלא להקיש על אף מקש אחר.

מסך ראשי

המסך הראשי הוא נקודת ההתחלה עבור פונקציות ויישומים רבים. הוא מאפשר לך להוסיף פריטים, כגון קיצורי דרך ליישומים ווידג'טים של Google, כדי להעניק לך גישה מיידית למידע וליישומים. זהו לוח ברירת המחדל והוא נגיש מכל תפריט על-ידי הקשה על ○.



1. **שורת המצב**
2. **וידג'ט**
3. **סמלי יישומים**
4. **אזור לחצנים מהירים**

1. מציגה את המידע על מצב הטלפון, כולל שעה, עוצמת אות, מצב הסוללה וסמלי התראות.
2. וידג'טים הם יישומים עצמאיים שניתן לגשת אליהם ממגירת היישומים או במסך הראשי. שלא כמו קיצור דרך, וידג'ט יכול לפעול כיישום במסך.
3. הקש על סמל (יישום, תיקייה וכו') כדי לפתוח אותו ולהשתמש בו.
4. מספק גישה בנגיעה אחת לפונקציה בכל לוח של מסך ראשי.

מסך ראשי מורחב

מערכת ההפעלה מספקת לוחות מרובים של מסך ראשי כדי לאפשר עוד שטח להוספת סמלים, וידג'טים ועוד.

- החלק את האצבע לשמאל או לימין על פני המסך הראשי כדי לגשת אל לוחות נוספים.

התאמה אישית של המסך הראשי

באפשרותך להתאים אישית את המסך הראשי על-ידי הוספת יישומים ווידג'טים ועל-ידי שינוי טפטים.

הוספת פריטים במסך הראשי

1 לחץ על ⬭ והקש על ⋯
2 הקש על הכרטיסייה הרצויה מ**יישומים** או **וידג'טים**.
3 גרור פריט למיקום הרצוי והרם את האצבע.

עצה! כדי לשנות את הטפט מהמסך הראשי, הקש והחזק את החלק הריק של המסך הראשי. אז ההודעה **בחר טפט מתוך** מופיעה.

הסרת פריט מהמסך הראשי

- כשאתה במסך הראשי, גע ברציפות בסמל שברצונך להסיר > גרור אותו אל 🗑.

הוספת יישום ל'אזור לחצנים מהירים'

- מהמסך 'יישומים' או במסך הראשי, גע ברציפות בסמל יישום וגרור אותו ל'אזור לחצנים מהירים'. לאחר מכן שחרר אותו במיקום הרצוי.

הסרת יישום מ'אזור לחצנים מהירים'

- גע ברציפות בלחצן המהיר הרצוי, וגרור אותו אל 🗑.

הערה

- הלחצן **יישומים** ⋯ אינו ניתן להסרה.

התאמה אישית של סמלי יישומים במסך הראשי

1 גע ברציפות בסמל יישום עד שתבוטל נעילתו מהמיקום הנוכחי שלו, ולאחר מכן שחרר אותו. סמל העריכה ✎ מופיע בפינה הימנית העליונה של היישום.
2 הקש על סמל היישום שוב ובחר בעיצוב ובגודל הרצויים עבור הסמל.
3 הקש על **אישור** כדי לשמור את השינוי.


חזרה ליישומים שהיו בשימוש לאחרונה

1 לחץ על ▢. תוצג רשימה של יישומים שהיו בשימוש לאחרונה.
2 הקש על תצוגה מקדימה של יישום כדי לפתוח אותו.
- או -
הקש על ◁ כדי לחזור למסך הקודם.

לוח ההתראות


התראות מדווחות לך על הגעת הודעות חדשות, אירועים בלוח השנה והתראות, וכן על אירועים מתמשכים, לדוגמה, כאשר אתה בשיחה.
כשמגיעה התראה, הסמל שלה מופיע בחלק העליון של המסך. סמלים של התראות ממתינות מופיעים משמאל, וסמלי מערכת, כגון Wi-Fi ועוצמת סוללה מופיעים מימין.

הערה
- האפשרויות הזמינות עשויות להשתנות בהתאם לאזור או לספק השירות.



פתיחת לוח ההתראות

החלק כלפי מטהמשורת המצב או לחץ לחיצה ארוכה על כדי לפתוח את חלונית ההתראות. כדי לסגור את חלונית ההתראות, החלק מעלה את המסך או הקש על ◁.



1 **אזור ההגדרות המהירות**

2 **התראות**

3 **נקה**

1. הקש על כל אחד ממקשי ההגדרות המהירות כדי להפעיל/להשבית אותו. הקש והחזק את המקש הרצוי כדי לגשת ישירות אל תפריט ההגדרות עבור הפונקציה. להצגת מקשי החלפה נוספים, החלק שמאלה או ימינה. הקש על כדי להסיר, להוסיף או לשנות את הסדר של מקשי ההגדרות המהירות.
2. ההתראות הנוכחיות מפורטות, כל אחת עם תיאור קצר. הקש על התראה כדי להציג אותה.
3. הקש כדי לנקות את כל ההתראות.

סמלי מחוונים בשורת המצב

סמלי מחוונים מופיעים בשורת המצב בחלקו העליון של המסך כדי לדווח על שיחות שלא נענו, הודעות חדשות, אירועים בלוח השנה, סטטוס המכשיר ועוד.



הסמלים המוצגים בחלקו העליון של המסך מספקים מידע על סטטוס המכשיר. הטבלה שלהלן מציגה אחדים מהסמלים הנפוצים ביותר.

סמל	תיאור
	לא הוכנס כרטיס SIM
	אין אות רשת זמין
	מצב טיסה מופעל
	מחובר לרשת Wi-Fi
	האוזניות הקוויות מחוברות
	מתבצעת שיחה
	שיחה שלא נענתה
	Bluetooth מופעל
	התראת מערכת
	הוגדרה התראה
	קיימת הודעה קולית חדשה

סמל	תיאור
	שיר מושמע כעת
	ללא הפרעות, אפילו לא שעון מעורר
	מצב רטט מופעל
	הסוללה טעונה במלואה
	הסוללה נטענת
	הטלפון מחובר למחשב באמצעות כבל USB
	הורדת נתונים
	העלאת נתונים
	GPS פועל
	הנתונים מסתנכרנים
	בחר שיטת קלט

קיימת הודעת טקסט או מולטימדיה חדשה	נקודה חמה ב-Wi-Fi פעילה

הערה

- מיקום הסמל בשורת המצב עשוי להשתנות בהתאם לפונקציה או לשירות.

מקלדת וירטואלית

ניתן להזין טקסט גם באמצעות המקלדת הווירטואלית. המקלדת הווירטואלית מופיעה במסך כאשר אתה מקיש על שדה זמין להזנת טקסט.

שימוש בלוח המקשים והזנת טקסט

הקש פעם אחת כדי להפוך את האות הבאה שתקליד לאות רישית. הקש פעמיים כדי שכל האותיות יהיו רישיות.

הקש כדי לעבור אל הגדרות המקלדת. הקש והחזק כדי לשנות את שיטת הזנת הטקסט.

הקש כדי להזין רווח.

הקש כדי ליצור שורה חדשה.

הקש כדי למחוק את התו הקודם.

הזנת אותיות עם סימני הטעמה

כאשר אתה בוחר ב'צרפתית' או 'ספרדית' כשפת הזנת טקסט, באפשרותך להזין תווים מיוחדים הקיימים בצרפתית או בספרדית (למשל "á").

לדוגמה, כדי להזין "á", גע ברציפות במקש "a" עד שמקש ההגדלה יתרחב ויציג תווים של שפות שונות. כעת בחר את התו המיוחד הרצוי.

תכונות מיוחדות

תצלום בתנועת יד

התכונה 'תצלום בתנועת יד' מאפשרת לך לצלם תמונה בעזרת תנועת יד באמצעות המצלמה הקדמית.


כדי לצלם תמונה

קיימות שתי שיטות לשימוש בתכונה 'תצלום בתנועת יד'.

- הרם את ידך, כשכף היד פתוחה, עד שהמצלמה הקדמית תזהה אותה ותופיע תיבה במסך. לאחר מכן סגור את ידך לאגרוף כדי להפעיל את הטיימר, שיעניק לך זמן להתכונן.

- או -

- הרם את ידך, כשכף היד באגרוף, עד שהמצלמה הקדמית תזהה אותה ותופיע תיבה במסך. לאחר מכן פתח את האגרוף כדי להפעיל את הטיימר, שיעניק לך זמן להתכונן.



הגדרת חשבון Google

בפעם הראשונה שתפתח יישום של Google בטלפון, תתבקש להיכנס עם חשבון ה-Google הקיים שלך. אם אין לך חשבון Google, תתבקש ליצור חשבון.

יצירת חשבון Google

1 לחץ על ○ והקש על ⋮⋮⋮ > ⚙ > **חשבונות וסנכרון**.
2 הקש על **הוסף חשבון** > **Google** > **לחלפין, צור חשבון חדש**.
3 הזן את שמך הפרטי ושם המשפחה שלך, ולאחר מכן הקש על **הבא**.
4 הזן שם משתמש והקש על **הבא**. הטלפון יקיים תקשורת עם שרתי Google ויבדוק את זמינות שם המשתמש.
5 הזן את הסיסמה שלך והקש על **הבא**.
6 פעל בהתאם להוראות והזן את פרטי החובה ופרטי הרשות הנוגעים לחשבון. המתן כאשר השרת ייצור את החשבון.

כניסה לחשבון Google

1 לחץ על ○ והקש על ⋮⋮⋮ > ⚙ > **חשבונות וסנכרון**.
2 לחץ על **הוסף חשבון** > **Google**.
3 הזן את כתובת הדוא"ל שלך והקש על **הבא**.
4 לאחר הכניסה תוכל להשתמש ב-Gmail ובשירותי Google דרך הטלפון.
5 לאחר שהגדרת את חשבון Google שלך, הטלפון יסתנכרן באופן אוטומטי עם חשבון Google שלך באינטרנט (אם יש חיבור נתונים זמין).

לאחר הכניסה, הטלפון שלך יסתנכרן עם שירותי Google שלך, כגון Gmail, אנשי קשר ויומן Google. תוכל גם להשתמש במפות, להוריד יישומים מחנות Play, לגבות את ההגדרות שלך לשרתי Google, וליהנות משירותים אחרים של Google בטלפון.

חשוב

- יישומים מסוימים, כגון לוח השנה, פועלים רק עם חשבון ה-Google הראשון שתוסיף. אם אתה מתכנן להשתמש ביותר מחשבון Google אחד עם הטלפון, הקפד להיכנס תחילה לחשבון שבו תרצה להשתמש ביישומים מסוג זה. לאחר הכניסה יבוצע סנכרון מול הטלפון של אנשי הקשר, ההודעות ב-Gmail, האירועים בלוח השנה וכל שאר המידע שלך ביישומים ושירותים אלה באינטרנט. אם לא תיכנס לחשבון Google במהלך ההתקנה, תתבקש להיכנס או ליצור חשבון Google בפעם הראשונה שתפעיל יישום שמצריך חשבון כזה, כגון Gmail או חנות Play.
- אם יש לך חשבון ארגוני, דרך החברה שלך או ארגון אחר, ייתכן שלמחלקת ה-IT יהיו הוראות מיוחדות בנוגע לאופן הכניסה לחשבון זה.

התחברות לרשתות ולמכשירים

Wi-Fi

באפשרותך להשתמש בגישה לאינטרנט מהיר בזמן שאתה בטווח כיסוי נקודת הגישה (AP) האלחוטית.

התחברות לרשתות Wi-Fi

1 לחץ על ○ והקש על ⋯ > ⚙ > **Wi-Fi**.

2 הקש על ⊙ כדי להפעיל את ה-Wi-Fi והתחל בסריקה לאיתור רשתות Wi-Fi זמינות.

3 הקש על רשת כדי להתחבר אליה.

- אם הרשת מאובטחת עם סמל מנעול, יהיה עליך להזין מפתח אבטחה או סיסמה.

4 שורת המצב מציגה סמלים המציינים את מצב ה-Wi-Fi.

הערה

- אם אתה מחוץ לאזור ה-Wi-Fi או שהגדרת את Wi-Fi ככבוי, ייתכן שהמכשיר יתחבר באופן אוטומטי לאינטרנט באמצעות נתונים סלולריים, מה שעלול לגרור חיובים עבור שימוש בנתונים.

עצה! כיצד להשיג את כתובת ה-MAC

לחץ על ○ והקש על ⋯ > ⚙ > **Wi-Fi** > ⋮ > **Wi-Fi מתקדם** > **כתובת MAC**.

Bluetooth

Bluetooth היא טכנולוגיית תקשורת לטווח קצר המאפשרת לך להתחבר באופן אלחוטי למספר התקני Bluetooth, כגון אוזנייה ודיבורית לרכב, וכן מחשבי כף-יד, מחשבים, מדפסות והתקנים אלחוטיים התומכים ב-Bluetooth.

הערה

- LG אינה אחראית לאובדן, יירוט או שימוש לרעה של נתונים שנשלחו או נקלטו באמצעות התכונה Bluetooth.
- ודא תמיד שאתה משתף ומקבל נתונים ממכשירים מהימנים המאובטחים כיאות.
- מכשולים בין המכשירים עלולים להקטין את מרחק הקליטה.
- חלק מהמכשירים, ובמיוחד אלה שלא נבדקו ואושרו על-ידי Bluetooth SIG, עלולים לא להתאים למכשירים שלך.

שיוך הטלפון שלך להתקן Bluetooth אחר

1 לחץ על ○ והקש על ⋮⋮⋮ > ⚙ > **Bluetooth**.

2 הקש על ⊙ כדי להפעיל את Bluetooth והתחל לחפש התקני Bluetooth זמינים.

- אם ברצונך לזהות בנוסף את ההתקנים הגלויים בטווח, הקש על **חיפוש**.

3 בחר מהרשימה את המכשיר שאליו ברצונך לשייך את הטלפון שלך. לאחר שהשיוך בוצע בהצלחה, הטלפון שלך יתחבר להתקן השני.

הערה

- שיוך בין שני התקני Bluetooth הוא תהליך חד-פעמי. לאחר שהשיוך נוצר, ההתקנים ימשיכו לזהות את השותפות ביניהם ויחליפו מידע.

עצה! עיין בתיעוד הנלווה להתקן Bluetooth למידע על מצב התאמה וקוד סיסמה (בדרך כלל 0 0 0 0 – ארבעה אפסים).

שליחת נתונים באמצעות Bluetooth

1 בחר קובץ או פריט כגון איש קשר או קובץ מדיה.
2 בחר באפשרות לשליחת נתונים דרך Bluetooth.
3 חיפוש מכשיר המותאם לשימוש Bluetooth ושיוך אליו.

הערה

- עקב תכונות ומפרטים שונים של התקנים אחרים התואמים ל-Bluetooth, התצוגה והתפעול עשויים להיות שונים, וייתכן שפונקציות, כגון העברה או החלפה, לא יהיו אפשריות בכל ההתקנים התואמים ל-Bluetooth.

קבלת נתונים באמצעות Bluetooth

1 לחץ על ○ והקש על ⋯ > ⚙ > **Bluetooth**.
2 הקש על ⊙ כדי להפעיל את Bluetooth.
3 אתה תקבל בקשה לקבל ניסיון שיוך מהתקן שולח. הקפד לבחור באפשרות **קבל**.

Wi-Fi Direct

Wi-Fi Direct מספק חיבור ישיר בין התקנים מאופשרי Wi-Fi מבלי לחייב נקודת גישה.

הפעלת Wi-Fi Direct

1 לחץ על ○ והקש על ⋯ > ⚙ > **Wi-Fi**.
2 הקש על ⋮ > **Wi-Fi מתקדם** > **Wi-Fi Direct**.

הערה

- כשאתה נמצא בתפריט זה, המכשיר שלך גלוי להתקנים גלויים סמוכים אחרים של Wi-Fi Direct.

העברת נתונים בין מחשב ומכשיר

ניתן להעתיק או להעביר נתונים בין מחשב לבין המכשיר.

העברת נתונים

1 חבר את המכשיר למחשב באמצעות כבל ה-USB שקיבלת עם הטלפון.

2 פתח את חלונית ההתראות, הקש על סוג החיבור הנוכחי ובחר באפשרות **התקני מדיה (MTP)**.

3 במחשב יקפוץ חלון, שיאפשר לך להעביר את הנתונים הרצויים.

הערה

- יש להתקין את LG Android Platform Driver במחשב כדי שהוא יוכל לזהות את הטלפון.
- בדוק את הדרישות עבור השימוש ב**התקני מדיה (MTP)**.

פריטים	דרישה
מערכת הפעלה	Microsoft Windows XP SP3, Vista או גרסה מתקדמת יותר
גרסת Window Media Player	Windows Media Player 10 ומעלה

שיחות

ביצוע שיחה

1 לחץ על ⊙ והזן את המספר באמצעות החייגן. למחיקת ספרה, לחץ על C.
2 לאחר הזנת המספר הרצוי, לחץ על ⌐ כדי לבצע את השיחה.
3 לסיום השיחה, לחץ על ⌐.

עצה! כדי להזין "+" לביצוע שיחות בינלאומיות, לחץ לחיצה ארוכה על הסמל 0+.

התקשרות לאנשי הקשר

1 הקש על ⊙ > כדי לפתוח את אנשי הקשר.
2 גלול ברשימת אנשי הקשר. כמו כן ניתן להזין את שם איש הקשר בשדה 'חיפוש'.
3 ברשימה המוצגת, הקש על איש הקשר שאליו ברצונך לחייג.

מענה לשיחה ודחיית שיחה

- לחץ על ⌐ כדי לענות לשיחה נכנסת.
- לחץ פעם אחת על ⌐ כדי לעבור למצב שקט, ופעמיים כדי לדחות שיחה נכנסת..

הערה

- הקש על אם ברצונך לשלוח הודעה למתקשר.

ביצוע שיחה נוספת

1 במהלך השיחה הראשונה שלך, הקש על ⋮ > **הוסף שיחה** והזן את המספר.
2 לחץ על ( ) כדי לבצע את השיחה.
3 שתי השיחות יוצגו במסך השיחות. השיחה הראשונה שלך תינעל ותועבר למצב המתנה.
4 לחץ על ( ) כדי לעבור משיחה לשיחה. לחלופין, הקש על האפשרות ⋮ **מיזוג שיחות** כדי להתחיל שיחת ועידה.
5 כדי לסיים את כל השיחות, לחץ על ( ).

הערה
- תחויב עבור כל שיחה שתבצע.

צפייה ביומני השיחות

1 לחץ על ( ) > ( ).
2 הצג רשימה של כל השיחות שחויגו, שהתקבלו ושלא נענו.

עצה!
- הקש על כל אחד מהפריטים ביומן השיחות כדי להציג את התאריך, השעה ומשך השיחה.
- הקש על ⋮ > **מחק הכל** כדי למחוק את כל הפריטים המוקלטים.

הגדרות שיחה

באפשרותך לקבוע את התצורה של הגדרות שיחת טלפון, כגון העברת שיחות, וכן תכונות מיוחדות אחרות שספק השירות שלך מציע.

1 לחץ על ( ) > ( ).
2 הקש על ⋮ > **הגדרות שיחה** וקבע את התצורה של האפשרויות הרצויות.

אנשי קשר

באפשרותכם להוסיף אנשי קשר לטלפון ולסנכרן אותם עם אנשי הקשר בחשבון Google שלכם או בחשבונות אחרים שתומכים בסנכרון אנשי קשר.

חיפוש איש קשר

1 הקש על ○ > כדי לפתוח את אנשי הקשר.
2 הקש על **חפש אנשי קשר** והזן את שם איש הקשר באמצעות המקלדת.

הוספת איש קשר חדש

1 לחץ על ○ והזן את המספר של איש הקשר החדש.
2 הקש על ⋮ > **הוסף לאנשי קשר** > **איש קשר חדש**.
3 אם ברצונך להוסיף תמונה לאיש הקשר החדש, הקש על סמל התמונה. בחר באפשרות **צלם** או **בחר מתוך האלבומים**.
4 הזן את המידע הרצוי עבור איש הקשר.
5 הקש על **שמירה**.

אנשי קשר מועדפים

באפשרותך לסווג אנשי קשר שאליהם אתה מתקשר לעתים קרובות כמועדפים.

הוספת איש קשר למועדפים

1 הקש על ○ > כדי לפתוח את אנשי הקשר.
2 הקש על איש קשר כדי להציג את פרטיו.
3 הקש על הכוכב בצד ימין למעלה במסך. הכוכב יהפוך לצהוב.

הסרת איש קשר מרשימת המועדפים

1 לחץ על ○ > 👤 והקש על הכרטיסייה **מועדפים**.
2 בחר באיש קשר כדי להציג את פרטיו.
3 הקש על הכוכב הצהוב בצד ימין למעלה במסך. הכוכב יהפוך ללבן ואיש הקשר יוסר מהמועדפים שלך.

יצירת קבוצה

1 לחץ על ○ > 👤 והקש על הכרטיסייה **קבוצות**.
2 הקש על ⋮ > **קבוצה חדשה**.
3 הזן שם לקבוצה החדשה. תוכל גם להגדיר צלצול ייחודי עבור הקבוצה שזה עתה נוצרה.
4 הקש על **הוסף חברים** כדי להוסיף אנשי קשר לקבוצה והקש על **הוסף**.
5 הקש על **שמירה** כדי לשמור את הקבוצה.

הערה

- אם תמחק קבוצה, אנשי הקשר שהוקצו לקבוצה זו לא יאבדו. הם יישארו ברשימת אנשי הקשר שלך.

הודעות

הטלפון שלך משלב שליחת הודעות טקסט ומולטימדיה בתפריט יחיד, אינטואיטיבי וקל לשימוש.

שליחת הודעה

1 לחץ על ○ > ✉ והקש על **חיבור חדש**.

2 הזן שם של איש קשר או מספר להתקשרות בשדה **אל**. תוך כדי הזנת שם איש הקשר יופיעו אנשי קשר מתאימים. אתה יכול להקיש על נמען מוצע ולהוסיף יותר מאיש קשר אחד.

הערה

- ייתכן שתחויב עבור כל הודעת טקסט שאתה שולח. התייעץ בנושא זה עם ספק השירות שלך.

3 הקש על שדה הטקסט והתחל להזין את הודעתך.

4 הקש על ⋮ כדי לפתוח את התפריט 'אפשרויות'. בחר מבין האפשרויות הזמינות.

עצה!באפשרותך להקיש על **צרף** כדי לצרף להודעה את הקובץ שברצונך לשתף.

5 הקש על **שלח** כדי לשלוח את ההודעה.

עצה!

- המגבלה של 160 תווים עשויה להשתנות ממדינה למדינה בהתאם לאופן הקידוד של הודעת הטקסט והשפה שבה נעשה שימוש בהודעה.
- אם נוסף קובץ תמונה, וידאו או שמע להודעת טקסט, הוא יומר באופן אוטומטי להודעת מולטימדיה ואתה תחויב בהתאם.

הערה

• כאשר אתה מקבל הודעת טקסט במהלך שיחה, תהיה על כך הודעה שניתן לשמוע.

תצוגת שיחה

הודעות שהוחלפו עם צד אחר יוצגו בסדר כרונולוגי כדי שתוכל לראות ולאתר בקלות את השיחות שלך.

שינוי הגדרות שליחת ההודעות שלך

הגדרות שליחת ההודעות בטלפון נקבעו מראש כדי לאפשר לך לשלוח הודעות באופן מיידי. תוכל לשנות את ההגדרות על-פי העדפותיך.

• לחץ על ○ > ✉ והקש על ⋮ > **הגדרות**.

מצלמה ווידאו

אפשרויות מצלמה בתצוגה המקדימה

אתה יכול להשתמש במצלמה או במצלמת הווידאו כדי לצלם תמונות וסרטוני וידאו ולשתף אותם.

- לחץ על > .



1. **הגדרות** – הקש כדי להגדיר את הרזולוציה של התמונה וסרטון הווידאו.
2. **גלריה** – הקש כדי להציג את התמונה האחרונה או סרטון הווידאו האחרון שהקלטת.
3. **הקלט** – הקש כדי להתחיל הקלטה.
4. **צלם** – הקש כדי לצלם תמונה.
5. **החלף מצלמה** – הקש כדי להחליף בין עדשת המצלמה האחורית ועדשת המצלמה הקדמית.

הערה הקפד לנקות את הכיסוי המגן של העדשה בעזרת מטלית מיקרופייבר לפני צילום תמונות. כיסוי עדשה עם כתמים מהאצבעות עלול לגרום לתמונות מטושטשות עם אפקט "הילה".

הגדרת הרזולוציה

1 בתצוגה המקדימה של המצלמה, לחץ לחיצה ארוכה על ▢.
2 הגדר את הרזולוציה.

צילום תמונה

1 לחץ על ○ > 📷.
2 צור מסגרת לנושא שלך במסך.
3 הקש על 📷 כדי לצלם תמונה. התמונה שלך תישמר באופן אוטומטי ב'גלריה'.

לאחר שצילמת תמונה

הקש על התמונה הממוזערת של התמונה כדי להציג את התמונה האחרונה שצילמת.

✎	הקש כדי לערוך את התצלום.
⋖	הקש כדי לפתוח את אפשרויות השיתוף הזמינות.
🗑	הקש כדי למחוק את התצלום.
⋮	הקש כדי לגשת אל אפשרויות נוספות.

הקלטת וידאו

1 לחץ על ○ > 📷.
2 צור מסגרת לנושא שלך במסך.
3 הקש על 🎥 כדי להתחיל להקליט את הווידאו.
4 אורך ההקלטה מוצג בראש המסך.

הערה

- הקש על 📷 כדי לצלם תמונות בזמן הקלטת וידאו.

5 הקש על כדי להשהות הקלטת וידאו. תוכל לחדש את ההקלטה שוב על-ידי הקשה על .

- או -

הקש על כדי לעצור את ההקלטה. הווידאו שלך יישמר באופן אוטומטי ב'גלריה'.

לאחר הקלטת וידאו

הקש על התמונה הממוזערת של סרטון הווידאו במסך כדי להציג את סרטון הווידאו האחרון שהקלטת.

	הקש כדי לפתוח את אפשרויות השיתוף הזמינות (כגון 'שליחת הודעות' או Bluetooth) לצורך שיתוף.
	הקש כדי למחוק את הווידאו.
	הקש כדי לגשת אל אפשרויות נוספות.

גלריה

היישום 'גלריה' מציג את התמונות וסרטוני הווידאו באחסון שלך, כולל אלה שצילמת בעזרת היישום 'מצלמה' ואלה שהורדת מהאינטרנט או ממיקומים אחרים.

1 לחץ על והקש על > כדי להציג את התמונות המאוחסנות במיקום האחסון.

2 הקש על אלבום כדי לפתוח אותו ולהציג את תוכנו. (התמונות וסרטוני הווידאו באלבום מוצגים בסדר כרונולוגי.)

3 הקש על תמונה באלבום כדי להציג אותה.

הערה

- בהתאם לתוכנה המותקנת, ייתכן שלא תהיה תמיכה עבור חלק מתבניות הקבצים.
- ייתכן שחלק מהקבצים לא יפעלו כראוי עקב הקידוד שלהם.

הצגת תמונות

ה'גלריה' מציגה את התמונות שלך בתיקיות. כאשר יישום, כגון דוא"ל, שומר תמונה, תיקיית ההורדה נוצרת באופן אוטומטי כדי להכיל את התמונה. בדומה לכך, לכידת צילום מסך יוצרת באופן אוטומטי את תיקיית צילומי המסך.

תמונות מוצגות לפי התאריך שבו הן נוצרו. בחר תמונה כדי להציג אותה במסך מלא. גלול שמאלה או ימינה כדי להציג את התמונה הבאה או הקודמת.

הגדלה או הקטנה של התצוגה


השתמש באחת השיטות הבאות כדי להגדיל תצוגת תמונה:

- הקש פעמיים בנקודה כלשהי כדי להגדיל את התצוגה.
- הזז שתי אצבעות בתנועת פריסה במקום כלשהו באפשרות ההגדלה של התמונה. צבוט את התמונה או הקש עליה פעמיים כדי להקטין.

אפשרויות וידאו

1 לחץ על ○ והקש על ⋮⋮⋮ > .

2 בחר בסרטון הווידאו שברצונך לצפות בו.



1 ▶ / ⏸	הקש כדי להשהות/להמשיך את הפעלת הווידאו.
2 ⏩	הקש כדי להריץ 10 שניות קדימה.
3 ⏪	הקש כדי להריץ 10 שניות אחורה.
4 🔊	הקש כדי לכוונן את עוצמת הקול של הווידאו.

5 /	הקש כדי לנעול/לבטל את נעילת המסך.
6 ⋮	הקש כדי לגשת אל אפשרויות נוספות.

הערה

- בזמן הפעלת וידאו, החלק את הצד הימני של המסך מעלה או מטה כדי לכוונן את הצליל.
- בזמן הפעלת וידאו, החלק את הצד השמאלי של המסך מעלה או מטה כדי לכוונן את הבהירות.
- בזמן הפעלת וידאו, החלק את אצבעך משמאל לימין (או להיפך) כדי להריץ קדימה ואחורה.

עריכת תמונות

בעת הצגת תצלום, הקש על .

מחיקת תמונות/סרטוני וידאו

השתמש באחת השיטות הבאות:

- בזמן שאתה בתוך תיקייה, הקש על , בחר בתמונות/סרטוני הווידאו ולאחר מכן הקש על **מחק**.
- בעת הצגת תצלום, הקש על .

הגדרת טפט

בעת הצגת תמונה, הקש על ⋮ > **הגדרת תמונה בתור** כדי להגדיר את התמונה כטפט או להקצות אותה לאיש קשר.

הערה

- בהתאם לתוכנה המותקנת, ייתכן שלא תהיה תמיכה עבור חלק מתבניות הקבצים.
- אם גודל הקובץ חורג מכמות הזיכרון הפנוי, עלולה להתרחש שגיאה בעת פתיחת קבצים.

מולטימדיה

נגן מוסיקה

הטלפון שלך כולל נגן מוסיקה שמאפשר להשמיע את כל הרצועות האהובות עליך.


השמעת שיר

1 לחץ על ○ והקש על ⋮⋮⋮ > ♫.

2 הקש על הכרטיסייה **שירים**.

3 בחר בשיר שברצונך להשמיע.

4 לרשותך האפשרויות הבאות.



1	⏸	הקש כדי להשהות את ההפעלה.
	▶	הקש כדי לחדש את ההפעלה.
2	⏭	הקש כדי לדלג לרצועה הבאה באלבום, ברשימת ההשמעה או ברשימת ההשמעה בסדר אקראי. הקש והחזק כדי להעביר קדימה.

3		הקש כדי להפעיל מחדש את הרצועה הנוכחית או לדלג אל הרצועה הקודמת באלבום, ברשימת ההשמעה או ברשימת ההשמעה בסדר אקראי. הקש והחזק כדי להריץ אחורה.
4		הקש כדי לכוונן את עוצמת הקול.
5		הקש כדי לפתוח את ספריית המוסיקה.
6		הקש כדי להפעיל את רשימת ההשמעה הנוכחית במצב אקראי (הרצועות מופעלות בסדר אקראי).
7		הקש כדי להחליף בין האפשרויות 'חזור על כל השירים', 'חזור על השיר הנוכחי' ו'החזרה מושבתת'.
8		הקש כדי להוסיף שיר למועדפים שלך.
9		הקש כדי לפתוח את רשימת ההשמעה הנוכחית.
10		הקש כדי לגשת אל אפשרויות נוספות.

הערה

- בהתאם לתוכנה המותקנת, ייתכן שלא תהיה תמיכה עבור חלק מתבניות הקבצים.
- אם גודל הקובץ חורג מכמות הזיכרון הפנוי, עלולה להתרחש שגיאה בעת פתיחת קבצים.
- זכויות היוצרים של קובצי מוסיקה עשויות להיות מוגנות על-ידי אמנות בינלאומיות וחוקי זכויות יוצרים לאומיים. לפיכך ייתכן שתצטרך להשיג אישור או רישיון כדי לשכפל או להעתיק מוסיקה. במדינות מסוימות, החוק המקומי אוסר על העתקה פרטית של חומרים המוגנים בזכויות יוצרים. לפני הורדה או העתקה של הקובץ, בדוק את החוקים הלאומיים של המדינה הרלוונטית ביחס לשימוש בחומרים מסוג זה.

כלי שירות

שעון

היישום 'שעון' מעניק לך גישה אל הפונקציות 'שעון מעורר', 'טיימר', 'שעון עולמי' ו'שעון עצר'. גש אל פונקציות אלה על-ידי הקשה על הכרטיסיות שבראש המסך או על-ידי החלקה אופקית על פני המסך.

- לחץ על ○ והקש על ⋮⋮⋮ > .

שעון מעורר

הכרטיסייה 'שעון מעורר' מאפשרת לך להגדיר התראות.

1 לחץ על ○ והקש על הכרטיסייה ⋮⋮⋮ > > **שעון מעורר**.

2 הקש על + כדי להוסיף התראה חדשה.

3 כוונן את ההגדרות בהתאם לצורך והקש על **שמירה**.

הערה

- אתה יכול גם להקיש על התראה קיימת כדי לערוך אותה.

טיימר

הכרטיסייה 'טיימר' יכולה להתריע בפניך בעזרת אות נשמע בחלוף פרק זמן מסוים.

1 לחץ על ○ והקש על הכרטיסייה ⋮⋮⋮ > > **טיימר**.

2 הגדר את השעה הרצויה בטיימר.

3 הקש על **התחל** כדי להפעיל את הטיימר.

4 הקש על **הפסק** כדי להפסיק את הטיימר.

שעון עולמי

הכרטיסייה 'שעון עולמי' מאפשרת לך לבדוק בקלות את השעה הנוכחית בערים אחרות בעולם.

1 לחץ על ○ והקש על הכרטיסייה ⋯ >  > **שעון עולמי**.

2 הקש על + ובחר את העיר הרצויה.

שעון עצר

הכרטיסייה 'שעון עצר' מאפשרת לך להשתמש בטלפון שלך כשעון עצר.

1 לחץ על ○ והקש על הכרטיסייה ⋯ >  > **שעון עצר**.

2 הקש על **התחל** כדי להפעיל את שעון העצר.

- הקש על **הקפה** כדי לתעד את זמני ההקפות.

3 הקש על **הפסק** כדי להפסיק את שעון העצר.

מחשבון

היישום 'מחשבון' מאפשר לך לבצע חישובים מתמטיים באמצעות מחשבון רגיל.

1 לחץ על ○ והקש על ⋯ > .

2 הקש על מקשי הספרות כדי להזין מספרים.

3 לביצוע חישובים פשוטים, הקש על הפונקציה שברצונך לבצע (+, -, x או ÷), ולאחר מכן =.

הערה

- כדי לבדוק את ההיסטוריה, הקש על ⋮ > **היסטוריית חישובים**.

לוח שנה

היישום 'לוח שנה' מאפשר לך לעקוב אחר זמני האירועים שלך.

1 לחץ על ○ והקש על ⋯ > .

2 הקש על התאריך שברצונך להוסיף לו אירוע. לאחר מכן הקש על ⋮ > **אירוע חדש**.

הקלטה קולית

היישום 'הקלטה קולית' מקליט קבצי שמע שבהם תוכל להשתמש במגוון דרכים.

הקלטת צלילים או קול

1 לחץ על ○ והקש על ⋯ > .

2 הקש על ● כדי להתחיל בהקלטה.

3 הקש על ■ כדי לסיים את ההקלטה.

4 הקש על ▶ כדי להאזין להקלטה.

הערה

- הקש על ☰ כדי לגשת אל ההקלטות שלך. תוכל להאזין להקלטות שנשמרו.

חיפוש קולי

השתמש ביישום זה כדי לחפש דפי אינטרנט באמצעות קולך.

1 לחץ על ○ והקש על ⋯ > .

2 אמור מילת מפתח או ביטוי כשהאפשרות **מאזין...** מופיעה על המסך. בחר אחת ממילות המפתח המוצעות שיופיעו.

הערה

- ייתכן שתכונה זו לא תהיה זמינה, בהתאם לאזור או לספק השירות.

הורדות

השתמש ביישום זה כדי לראות אילו קבצים הורדו ביישומים.

- לחץ על ○ והקש על ⋮⋮⋮ > .

הערה

- ייתכן שתכונה זו לא תהיה זמינה, בהתאם לאזור או לספק השירות.

רדיו FM

הטלפון שלך כולל רדיו FM מובנה המאפשר לך להאזין לתחנות האהובות עליך כשאתה בתנועה.

- לחץ על ○ והקש על ⋮⋮⋮ > .

עצה! עליך לחבר את האוזניות כדי להשתמש בהן כאנטנה.

הערה

- ייתכן שתכונה זו לא תהיה זמינה, בהתאם לאזור או לספק השירות.

דפדפן אינטרנט

Internet

האינטרנט מעניק לך עולם מהיר וצבעוני של משחקים, מוסיקה, חדשות, ספורט, בידור והרבה יותר, היישר לטלפון הנייד שלך.

הערה

- יחולו חיובים נוספים בעת התחברות לשירותים אלה והורדת תוכן. בדקו את תעריפי העברת הנתונים אצל ספק הרשת שלכם.

- לחץ על ○ והקש על ⋯ > .

הצגת דפי אינטרנט

הקש על שדה הכתובת, הזן את כתובת האינטרנט והקש על **בצע** במקלדת.

פתיחת דף

כדי לעבור אל דף חדש, הקש על  > +.

כדי לעבור לדף אינטרנט אחר, הקש על , גלול מעלה או מטה והקש על הדף כדי לבחור אותו.

חיפוש באינטרנט באופן קולי

הקש על שדה הכתובת ולאחר מכן הקש על 🎤. כאשר תתבקש לעשות זאת, אמור מילת מפתח ובחר באחת ממילות המפתח שמופיעות.

הערה

- ייתכן שתכונה זו לא תהיה זמינה, בהתאם לאזור או לספק השירות.

סימניות

כדי לסמן את דף האינטרנט הנוכחי שלך, הקש על ⋮ > **הוסף סימניה** > **שמור**.
כדי לפתוח דף אינטרנט שסומן בסימניה, הקש על ⋮ > **סימניות** ובחר בסימניה הרצויה.

היסטוריה

הקש על הכרטיסייה ⋮ > **סימניות** > **היסטוריה** כדי לפתוח רשימה של דפי אינטרנט שבהם ביקרת לאחרונה. כדי לנקות את כל ההיסטוריה שלך, הקש על > **כן**.

Chrome

השתמש ב-Chrome כדי לחפש מידע ולגלוש בדפי אינטרנט.

- לחץ על ○ והקש על התיקייה ⋯ > **Google** > .

הערה

- ייתכן שיישום זה לא יהיה זמין, בהתאם לאזור ולספק השירות.

הצגת דפי אינטרנט

הקש על שדה הכתובת ולאחר מכן הזן כתובת אינטרנט או קריטריון חיפוש.

פתיחת דף

כדי לפתוח דף חדש, הקש על ⋮ > **כרטיסייה חדשה**.
כדי לעבור לדף אינטרנט אחר, הקש על ⋮ > **כרטיסיות אחרונות** והקש על הדף כדי לבחור אותו.

הגדרות

היישום 'הגדרות' מכיל את מרבית הכלים להתאמה אישית ולקביעת התצורה של הטלפון. כל ההגדרות ביישום 'הגדרות' מתוארות בסעיף זה.

כדי לפתוח את היישום הגדרות

- לחץ על ○ והקש על ⋮⋮⋮ > ⚙.

רשתות אלחוטיות

< Wi-Fi >

מפעיל את ה-Wi-Fi כדי להתחבר לרשתות Wi-Fi זמינות.

< Bluetooth >

מפעיל או משבית את התכונה האלחוטית של Bluetooth כדי להשתמש ב-Bluetooth.

< נתונים ניידים >

מציג את השימוש בנתונים ואת מגבלת השימוש בנתונים ניידים.

< הגדרות שיחה >

תפריט זה מאפשר לך לקבוע הגדרות שיחה שונות.

תא קולי

מאפשר לבחור את שירות התא הקולי של הספק שלך.

מספרים קבועים מראש

מאפשר לך לנהל וליצור רשימה של מספרים שאליהם ניתן להתקשר מהטלפון. לצורך כך תזדקק לקוד PIN2 שניתן להשיגו אצל מפעיל השירות שלך. אם תוכנה זו תופעל, מהטלפון שלך ניתן יהיה להתקשר רק למספרים הכלולים ברשימת המספרים הקבועים מראש.

דחיית שיחות

מאפשר להגדיר את פונקציית דחיית השיחות.

דחה שיחה ושלח הודעה
דחה עם הודעה – כשברצונך לדחות שיחה, באפשרותך לשלוח הודעה מהירה באמצעות פונקציה זו. אפשרות זו שימושית כאשר אתה נדרש לדחות שיחה במהלך פגישה.
מענה לשיחה
בחר את השיטה כדי לענות על שיחה.
העברת שיחה
מאפשר לבחור מתי להעביר שיחות.
מענה אוטומטי
הגדר את משך הזמן לפני שדיבורית מחוברת תענה באופן אוטומטי לשיחה נכנסת.
רטט חיבור
רטט כשהצד השני משיב לשיחה.
שמור מספרים לא מוכרים
מאפשר להוסיף מספרים לא ידועים לאנשי קשר לאחר שיחה.
חסימת שיחה
נועל שיחות נכנסות, יוצאות או בינלאומיות.
משך שיחה
מאפשר להציג את משך השיחה עבור סוגי שיחות שונים.
הגדרות נוספות
מאפשר לשנות את הגדרות השיחה הנוספות.

< שיתוף אינטרנט >
שיתוף באמצעות USB
מאפשר לשתף את חיבור האינטרנט עם המחשב באמצעות כבל USB.
נקודה חמה ניידת ב- Wi-Fi
ניתן להשתמש בטלפון גם כדי לספק חיבור פס רחב נייד. צור נקודה חמה ושתף את החיבור.
שיתוף אינטרנט ב-Bluetooth
מאפשר להתחבר להתקנים אחרים באמצעות Bluetooth.

עזרה

מציג מידע עזרה לגבי שיתוף אינטרנט באמצעות USB, נקודה חמה ניידת ב-Wi-Fi, ושיתוף אינטרנט ב-Bluetooth.

< עוד >

מצב טיסה

ממצב טיסה מאפשר להשתמש במרבית התכונות בטלפון שלך, כגון משחקים ומוסיקה, כאשר אתה נמצא באזור שבו אסור לבצע או לקבל שיחות, או להשתמש בנתונים. כאשר אתה מגדיר את הטלפון ל'מצב טיסה', הוא לא יוכל לבצע או לקבל שיחות, או לגשת אל נתונים מקוונים.

רשתות ניידות

תפריט זה מאפשר לך לקבוע הגדרות שונות לרשתות ניידות.

VPN

מהטלפון, אתה יכול להוסיף, להגדיר ולנהל רשתות פרטיות וירטואליות (VPN) המאפשרות לך להתחבר ולגשת אל משאבים בתוך רשת מקומית מאובטחת, כגון רשת הארגון שלך.

התקן

< צליל והתראה >

פרופילי צליל

מאפשר לך להגדיר את פרופילי הצליל של הטלפון. בחר מבין האפשרויות **צליל**, **רטט בלבד**.

עוצמה

התאם את הגדרות עוצמת הקול של הטלפון כך שיתאימו לצרכים ולסביבה שלך.

צלצול

מאפשר לך להגדיר את הרינגטונים עבור שיחות. תוכל גם להוסיף צלצול על-ידי הקשה על + בפינה הימנית העליונה של המסך.

צליל עם רטט

סמן אפשרות זו כדי להגדיר שהטלפון ירטוט בנוסף לצלצול בעת קבלת שיחות.

סוג רטט

מאפשר לך לבחור את סוג הרטט.

הפרעות

מאפשר לך להגדיר לוח זמנים למניעת הפרעות של התראות. אתה יכול לקבוע שתכונות מסוימות יורשו להפריע לך כאשר התכונה 'עדיפות בלבד' מוגדרת.

יישומים

מאפשר לך למנוע מיישומים להציג התראות, או להגדיר שיישומים יציגו התראות כאשר 'נא לא להפריע' מוגדר ל'עדיפות בלבד'.

נורית הודעה

הקש על המתג כדי להפעיל או להשבית אותו. האפשרות 'פועל' מפעילה את אור ה-LED עבור ההתראות שתבחר, בצבע שתגדיר עבור כל אחת.

צליל התראה

מאפשר לך להגדיר את צליל ההתראה. תוכל גם להוסיף צליל התראה על-ידי הקשה על + בפינה הימנית העליונה של המסך.

רטט בעת הקשה

סמן אפשרות זו כדי שהטלפון ירטוט בעת לחיצה על לחצני המגע במסך הראשי ובמהלך אינטראקציות אחרות עם ממשק המשתמש.

אפקטים קוליים

הקש כדי להגדיר את צלילי המגע של מקשי החיוג, צלילי מקשים ומגע, צליל ביטול נעילת מסך וצליל תיקיות.

התראות קוליות על הודעות/שיחות

מאפשר למכשיר להקריא את השיחה הנכנסת ואת אירוע ההודעה באופן אוטומטי.

< תצוגה >

סוג גופן

בחר את סוג הגופן הרצוי.

גודל גופן

בחר את גודל הגופן הרצוי.

בהירות

כוונן את בהירות המסך באמצעות המחוון.

סיבוב מסך אוטומטי
הגדר שינוי כיוון אוטומטי בעת סיבוב הטלפון.
כיבוי מסך אוטומטי
הגדר את השהיית הזמן לפני שהמסך יכבה באופן אוטומטי.
חלום בהקיץ
בחר את שומר המסך שיוצג כאשר הטלפון ישן בעת עגינה ו/או טעינה.
תאורת לוח מקשים
הוסף סימן ביקורת כדי להפעיל את תאורת לוח המקשים ולהגדיר את משך התאורה.
כיול חיישן תנועה
מאפשר לך לשפר את הדיוק של ההטיה והמהירות של החיישן.

< מסך ראשי >

בחר בית
בחר את ערכת הנושא הרצויה של המסך הראשי. בחר מבין האפשרויות **בית** (פריסה רגילה של Android) או **EasyHome** (גירסה מפושטת עבור משתמשים שמכירים פחות טוב את הניווט ב-Android).
טפט
מגדיר את הטפט לשימוש במסך הראשי.
אפקט בהחלפת מסכים
בחר את סוג האפקט שברצונך שיוצג בעת החלקה ממסך ראשי אחד לבא אחריו.
לאפשר לולאות מסך בית
סמן כדי לאפשר גלילה רציפה של המסך הראשי (גלילה בחזרה למסך הראשון לאחר המסך האחרון).
עזרה
מציג מידע עזרה למסך הראשי.

< מסך נעילה >

בחר נעילת מסך
הגדר סוג נעילת מסך כדי לאבטח את הטלפון.

< אחסון >

אתה יכול לפקח על הזיכרון שבשימוש ועל הזיכרון הפנימי הזמין במכשיר.

< חיסכון בחשמל ובסוללה >

ניצול סוללה

הצג את ניצול הסוללה.

אחוז הסוללה בשורת המצב

הוסף סימן ביקורת כדי להציג את אחוז רמת הסוללה בשורת המצב לצד סמל הסוללה.

חיסכון בחשמל

הקש על המתג 'חיסכון בחשמל' כדי להפעיל או להשבית אותו. מגדיר את רמת אחוז הטעינה שמפעילה באופן אוטומטי את התכונה 'חיסכון בחשמל'. בחר מבין האפשרויות **מיד**, **5% סוללה** ו-**15% סוללה**.

עזרה

מציג מידע על פריטי חיסכון באנרגיית הסוללה.

חיסכון חכם בצריכת חשמל

הקש על המתג כדי להפעיל או להשבית אותו. חסוך בחשמל באמצעות צמצום פעולות לא נחוצות כשהמסך כבוי.

< יישומים >

מאפשר לך להציג פרטים על היישומים המותקנים בטלפון, לנהל את הנתונים שלהם ולכפות עליהם עצירה.

< אפליקצית ברירת מחדל להודעות >

תפריט זה מאפשר לך לבחור באיזה יישום הודעות להשתמש כיישום ברירת המחדל שלך להודעות.

< סגירת יישום תוך היפוך >

תפריט זה מאפשר לך לבחור כיצד היישום הנוכחי יפעל כשסוגרים באמצעות היפוך.

אישי

< מיקום >

הפעל שירות מיקום; הטלפון יקבע את המיקום המשוער שלך באמצעות Wi-Fi ורשתות ניידות. כאשר תבחר באפשרות זו, תישאל אם אתה מסכים לאפשר ל-Google להשתמש במיקומך בעת אספקת שירותים אלה.

מצב

מגדיר כיצד נקבע המידע על המיקום הנוכחי שלך.

מצלמה

סימן ביקורת המאפשר לתייג תמונות או סרטוני וידאו עם המיקומים שלהם.

xהיסטוריית מיקומים ב-Google

מאפשר לך לבחור את הגדרות מידע המיקום שלך כפי שיהיה נגיש ל-Google ומוצריה.

< אבטחה >

השתמש בתפריט 'אבטחה' כדי לקבוע כיצד לסייע באבטחת הטלפון והנתונים שבו.

הצפן טלפון

מאפשר לך להצפין נתונים בטלפון למטרת אבטחה. תידרש להזין PIN או סיסמה כדי לבטל את הצפנת הטלפון בכל פעם שתפעיל אותו.

הצפן אחסון כרטיס SD

הצפן אחסון כרטיס SD ושמור את הנתונים במצב לא זמין למכשירים אחרים.

הגדר נעילת כרטיס SIM

מגדיר את קוד ה-PIN לנעילת כרטיס ה-SIM, ומאפשר לשנות את ה-PIN.

הקלדת סיסמה גלויה

סמן אפשרות זו כדי להציג לזמן קצר כל תו בסיסמה בזמן שאתה מזין אותו, כדי שתוכל לראות מה אתה מזין.

מנהלי התקנים

הצג או הפסק מנהלי התקנים.

מקורות לא מוכרים

אפשר התקנה של יישומים שאינם מה-Play Store.

אמת יישומים
הזהר או אל תאפשר התקנה של יישומים העלולים לגרום נזק.
סוג אחסון
חומרה מגובה.
תעודת ניהול
- **אישורים מהימנים** – סמן אפשרות זו כדי לאפשר ליישומים לגשת למאגר המוצפן של אישורים מאובטחים בטלפון שלך, לסיסמאות קשורות ואישורים אחרים. אתה משתמש באחסון אישורים כדי ליצור מספר סוגים של חיבורי VPN ו-Wi-Fi. אם לא הגדרת סיסמה עבור אחסון האישורים המאובטחים, הגדרה זו מעומעמת.
- **התקן מהאחסון** – הקש כדי להתקין אישור מאובטח.
- **נקה אישורים** – מוחק את כל האישורים המאובטחים והאישורים הקשורים ומוחק את הסיסמה של האחסון המאובטח.

Trust agents
בחר יישומים לשימוש מבלי לבטל את נעילת המסך.
קביעת מסך
אתה יכול לאפשר למכשיר להציג אך ורק מסך של יישום מסוים באמצעות קביעת מסך.
יישומים עם גישה לשימוש
מאפשר להציג מידע על שימוש ביישומים בטלפון.

< חשבונות וסנכרון >
השתמש בתפריט ההגדרות של 'חשבונות וסנכרון' כדי להוסיף, להסיר ולנהל את חשבון Google שלך וחשבונות נתמכים אחרים. תוכל להשתמש בהגדרות אלו גם כדי להחליט אם כל היישומים יוכלו לשלוח, לקבל ולסנכרן נתונים בלוחות הזמנים שלהם, ובאיזה אופן, ואם כל היישומים יוכלו לסנכרן נתוני משתמש באופן אוטומטי. ייתכן ש-Gmail™, 'לוח שנה' ויישומים אחרים מכילים הגדרות משלהם לשליטה באופן סנכרון הנתונים; עיין בסעיפים הנוגעים ליישומים אלה לקבלת פרטים. הקש על **הוסף חשבון** כדי להוסיף חשבון חדש.

< שפה וקלט >

בחר את השפה עבור הטקסט בטלפון ועבור קביעת התצורה של המקלדת במסך, לרבות מילים שהוספת למילון.

שפה

בחר שפה לשימוש בטלפון.

ברירת מחדל

מאפשר לך לבחור את סוג המקלדת שתהווה ברירת מחדל.

מקלדת LG

הקש על סמל ההגדרות כדי לשנות את הגדרות המקלדת של Google.

הקלדה קולית של Google

סמן כדי לבחור הקלדה קולית של Google כדי להזין נתונים. הקש על סמל ההגדרות כדי לשנות את הגדרות הקול של Google.

חיפוש קולי

הקש כדי להגדיר את הגדרות החיפוש הקולי.

פלט המרת טקסט לדיבור

הקש כדי להגדיר את המנוע המועדף או הגדרות כלליות לפלט המרת טקסט לדיבור.

מהירות מצביע

התאם את מהירות המצביע.

המרת לחצנים

המר את לחצני העכבר כדי להשתמש בלחצן הימני כעיקרי.

< גיבוי ואיפוס >

שנה את ההגדרות לניהול ההגדרות והנתונים שלך.

LG Backup

מבצע גיבוי של כל המידע בהתקן ומשחזר אותו במקרה של אובדן נתונים או החלפה.

גבה את הנתונים שלי

גבה נתוני יישומים, סיסמאות Wi-Fi והגדרות אחרות לשרתי Google.

חשבון גיבוי
מציג את החשבון שמשמש כעת לגיבוי מידע.
שחזור אוטומטי
בעת התקנת יישום מחדש, שחזר הגדרות ונתונים שגובו.
שחזור נתוני היצרן
איפוס ההגדרות לערכי ברירות המחדל שהגדיר היצרן ומחיקת כל הנתונים. אם תאפס את הטלפון בצורה כזו, תתבקש להזין מחדש את אותו מידע שהזנת בפעם הראשונה שהפעלת את Android.

מערכת

< QuickButton >
בחר יישומים אשר ברצונך לקבל גישה מהירה אליהם באמצעות **מקש QuickButton**.

< תאריך ושעה >
הגדר את ההעדפות שלך בנוגע לאופן התצוגה של התאריך והשעה.

< נגישות >
השתמש בהגדרות הנגישות כדי לקבוע את התצורה של כל יישומי ה-plug-in לנגישות שהתקנת בטלפון.

ראייה

- **TalkBack** - מאפשר לך להגדיר את פונקציית ה-Talkback המסייעת לאנשים עם ליקויי ראייה באמצעות משוב ורבאלי.
- **התראות קוליות על הודעות/שיחות** – הקש על כדי להפעיל או להשבית אפשרות זו. 'פועל' מאפשר לך לשמוע התראות אוטומטיות נאמרות עבור שיחות נכנסות והודעות.
- **גווני מסך** – סמן אפשרות זו כדי להגדיר את המסך לניגודיות כהה יותר.
- **גודל גופן** – מגדיר את גודל הגופן.
- **שינוי גודל תצוגה במגע** – מאפשר לך להגדיל ולהקטין את התצוגה על-ידי הקשה משולשת על המסך.

- **היפוך צבעי המסך** – סמן אפשרות זו כדי להפוך את צבעי המסך והתוכן.
- **התאמה אישת של צבעי המסך** – מאפשר לך להפוך את הצבעים של המסך והתוכן.
- **מסנן צבע מסך** – מאפשר לך לשנות את הצבעים של המסך והתוכן.

שמיעה

- **כתובית** – מאפשר לך לבצע התאמה אישית של הגדרות כתוביות עבור בעלי שמיעה לקויה.
- **נורית הודעה** – מאפשר לך להפעיל את אור ה-LED עבור שיחות נכנסות והודעות.
- **כבה את כל הצלילים** – סמן אפשרות זו כדי לכבות את כל צלילי המכשיר.
- **סוג אודיו** – מגדיר את סוג האודיו.
- **איזון קול** – מגדיר את ניתוב השמע. הזז את המחוון בפס המחוון כדי להגדיר זאת.

תנועה ותודעה

- **זמן משוב מגע** – מגדיר את זמן התגובה ללחיצה על מקשים.
- **Touch assistant** – מציג לוח מגע עם גישה קלה לפעולות נפוצות.
- **כיבוי מסך אוטומטי** – מגדיר את משך הזמן לפני שהמסך כבה באופן אוטומטי.
- **אזורי בקרת מגע** – מאפשר לך לבחור אזור במסך להגבלת הפעלת מגע לאותו אזור בלבד במסך.

קיצור דרך לתכונות הנגישות

מאפשר לך לגשת אל תכונות נבחרות במהירות בעת לחיצה משולשת על לחצן הבית.

סיבוב מסך אוטומטי

סמן אפשרות זו כדי לאפשר לטלפון לסובב את המסך לפי הכיוון הפיזי של הטלפון (לאורך או לרוחב).

שינוי אופן גישה

מאפשר לך לקיים אינטראקציה עם המכשיר באמצעות מתג אחד או יותר הפועלים כמו מקשי מקלדת. תפריט זה עשוי להיות שימושי עבור משתמשים עם מגבלות תנועה המונעות מהם לקיים אינטראקציה ישירות עם המכשיר.

< אודות הטלפון >

הצג מידע משפטי, בדוק את מצב הטלפון ואת גירסאות התוכנה, ובצע עדכון תוכנה.

עדכון תוכנת הטלפון

עדכון תוכנת הטלפון

עדכון תוכנת הטלפון הנייד של LG מהאינטרנט

למידע נוסף אודות השימוש בפונקציה זו, בקר בכתובת http://www.lg.com/common/index.jsp ← בחר את המדינה והשפה שלך.

תכונה זו מאפשרת לך לעדכן בנוחות את הקושחה של הטלפון לגרסה חדשה יותר מהאינטרנט, ללא צורך לבקר במרכז שירות. תכונה זו תהיה זמינה רק אם LG תייצר גרסת קושחה חדשה שתהיה זמינה למכשיר שלך.

מאחר שעדכון הקושחה של הטלפון הנייד דורש את תשומת לבו המלאה של המשתמש במשך כל תהליך העדכון, הקפד לקרוא את כל ההוראות וההערות שיופיעו בכל שלב לפני שתתקדם הלאה. חשוב לזכור שהסרת כבל ה-USB או הסוללה במהלך השדרוג עלולה לגרום נזק חמור לטלפון הנייד.

הערה

- LG שומרת על זכותה, על פי שיקול דעתה הבלעדי, להפוך עדכוני קושחה לזמינים עבור דגמים נבחרים בלבד ואינה ערבה לזמינות הגירסה החדשה של הקושחה לכל דגמי הטלפון.

עדכון תוכנת הטלפון הנייד של LG באמצעות Over-the-Air (OTA)

תכונה זו מאפשרת לך לעדכן בנוחות את תוכנת הטלפון לגרסה חדשה יותר דרך OTA, מבלי להתחבר באמצעות כבל נתונים USB. תכונה זו תהיה זמינה רק אם LG תייצר גרסת קושחה חדשה שתהיה זמינה למכשיר שלך.

תחילה עליך לבדוק את גרסת התוכנה בטלפון הנייד: **הגדרות** > **אודות הטלפון** > **מרכז עדכונים** > **עדכון תוכנה** > **חפש עדכונים כעת**.

הערה

- הנתונים האישיים שלך משטח האחסון הפנימי בטלפון—לרבות פרטי חשבון Google וכל חשבון אחר, נתונים והגדרות של המערכת/היישומים שלך, יישומים שהורדו ורישיון ה-DRM שלך—עשויים ללכת לאיבוד בתהליך עדכון התוכנה של הטלפון. לפיכך, LG ממליצה לך לגבות את הנתונים האישיים שלך לפני שתעדכן את תוכנת הטלפון. LG לא תישא באחריות לאובדן נתונים אישיים כלשהם.
- תכונה זו תלויה בספק שירותי הרשת, באזור ובמדינה שלך.

אודות מדריך למשתמש זה

אודות מדריך למשתמש זה

- לפני השימוש במכשיר, אנא קרא בעיון מדריך זה. הדבר מבטיח שתשתמש בטלפון שלך בצורה נכונה ובטוחה.
- חלק מהתמונות ומצילומי המסך המופיעים במדריך זה עשויים להיראות שונים בטלפון שלך.
- התוכן שלך עשוי להיות שונה מהמוצר הסופי או מתוכנה שסופקה על-ידי ספקי שירות או מפעילים. תוכן זה כפוף לשינויים ללא הודעה מראש. לקבלת הגירסה העדכנית של מדריך זה, בקר באתר האינטרנט של LG בכתובת www.lg-mobile.co.il.
- היישומים בטלפון שלך והפונקציות שלהם עשויים להשתנות בהתאם למדינה, לאזור או למפרטי החומרה. LG לא תישא באחריות לבעיות ביצועים הנובעות משימוש ביישומים שפותחו על-ידי ספקים פרט ל-LG.
- LG לא תישא באחריות לבעיות ביצועים או חוסר תאימות הנובעות מהגדרות רישום ערוכות או מתוכנת מערכת הפעלה ששונתה. כל ניסיון להתאים אישית את מערכת ההפעלה שלך עלול לגרום למכשיר או ליישומים שלו לפעול באופן שגוי.
- תוכנות, שמע, טפטים, תמונות ופריטי מדיה אחרים שסופקו יחד עם המכשיר שלך מורשים לשימוש מוגבל. אם תחלץ חומר זה ותשתמש בו למטרות מסחריות או אחרות, אתה עלול להפר חוקי זכויות יוצרים. כמשתמש, אתה נושא באחריות מלאה ובלעדית לשימוש לא חוקי במדיה.
- חיובים נוספים עשויים לחול עבור שירותי נתונים, כגון שליחת הודעות, העלאה, הורדה, סינכרון אוטומטי ושירותי מיקום. כדי להימנע מחיובים נוספים, בחר תוכנית נתונים המתאימה לצרכיך. פנה אל ספק השירות לקבלת פרטים נוספים.

סימנים מסחריים

- Copyright ©2015 LG Electronics, Inc. כל הזכויות שמורות. LG והסמל של LG הם סימנים מסחריים רשומים של LG Group ושל החברות הקשורות אליה. כל הסימנים המסחריים האחרים הם רכושם של בעליהם בהתאמה.
- Google™, Google Maps™, Gmail™, YouTube™', Hangouts™ ו-Play Store™ הם סימנים מסחריים של Google, Inc.
- Bluetooth® הוא סימן מסחרי רשום של Bluetooth SIG, Inc. ברחבי העולם.
- Wi-Fi® והלוגו של Wi-Fi הם סימנים מסחריים רשומים של Wi-Fi Alliance.
- כל יתר הסימנים המסחריים וזכויות היוצרים הם רכושם של בעליהם בהתאמה.

אביזרים

האביזרים הבאים זמינים לשימוש עם הטלפון שלך. **(האביזרים המתוארים להלן עשויים להיות אופציונליים.)**

- מתאם נסיעות
- מדריך להתחלה מהירה
- אוזניות סטריאו
- כבל USB
- סוללה

הערה

- השתמש תמיד באביזרים מקוריים של LG. הפריטים שסופקו עוצבו אך ורק עבור מכשיר זה, וייתכן שהם לא יהיו תואמים למכשירים אחרים.
- הפריטים שסופקו עם המכשיר וכל האביזרים הזמינים עשויים להשתנות בהתאם לאזור או לספק השירות.

פתרון בעיות

בפרק זה מוצגות מספר בעיות שאתה עלול להיתקל בהן במהלך השימוש בטלפון. בעיות מסוימות יצריכו פנייה לספק השירות, אך את רובן תוכל לפתור בקלות בעצמך.

הודעה	גורמים אפשריים	אפשרויות לתיקון הבעיה
שגיאת כרטיס SIM או USIM	אין כרטיס SIM או USIM בטלפון, או שהוא הוכנס בצורה לא נכונה.	ודא שכרטיס ה-SIM או ה-USIM הוכנס כהלכה.
אין חיבור לרשת/החיבור חלש	האות חלש או שאתה נמצא מחוץ לטווח הרשת של ספק השירות.	התקרב לחלון או צא לאזור פתוח. בדוק את מפת הכיסוי של מפעיל הרשת הסלולרית.
	המפעיל החיל שירותים חדשים.	בדוק אם גילו של כרטיס ה-SIM או ה-USIM עולה על 6~12 חודשים. אם כן, החלף את כרטיס ה-SIM או ה-USIM בסניף הקרוב ביותר של ספק הרשת שלך. פנה אל ספק השירות.
הקודים אינם תואמים	כדי לשנות קוד אבטחה, יש להזין את הקוד החדש שוב כדי לאשר אותו.	אם שכחת את הקוד, פנה אל ספק השירות.
	שני הקודים שהזנת אינם זהים זה לזה.	

הודעה	גורמים אפשריים	אפשרויות לתיקון הבעיה
לא ניתן להגדיר יישומים	הוא לא נתמך על-ידי ספק השירות או שנדרש רישום עבורו.	פנה אל ספק השירות.
לא ניתן לבצע שיחות	שגיאת חיוג	רשת חדשה לא מאושרת.
	הוכנס כרטיס SIM או USIM חדש.	בדוק אם קיימות מגבלות חדשות.
	הגעת למגבלת החיוב ששולם מראש.	צור קשר עם חברת הסלולר או אפס את המגבלה בעזרת PIN2.
לא ניתן להפעיל את הטלפון	מקש הדלקה/כיבוי נלחץ מהר מדי.	לחץ על מקש ההפעלה/כיבוי למשך שתי שניות לפחות.
	הסוללה לא נטענה.	טען את הסוללה. בדוק את מחוון הטעינה בתצוגה.
שגיאת טעינה	הסוללה לא נטענה.	טען את הסוללה.
	הטמפרטורה החיצונית גבוהה או נמוכה מדי.	ודא שהטלפון נטען בטמפרטורה הרגילה.
	בעיית מגעים	בדוק את המטען ואת החיבור שלו לטלפון.
	אין מתח	חבר את המטען לשקע אחר.
	המטען פגום	החלף את המטען.
	מטען לא מתאים	השתמש רק באביזרים מקוריים של LG.
המספר לא מורשה.	פונקציית מספר קבוע מראש פועלת.	בדוק את התפריט 'הגדרות' ונטרל את הפונקציה.

הודעה	גורמים אפשריים	אפשרויות לתיקון הבעיה
לא ניתן לקבל/לשלוח הודעות SMS ותמונות	הזיכרון מלא	מחק חלק מההודעות השמורות בטלפון.
הקבצים אינם נפתחים	אין תמיכה בתבנית הקובץ	בדוק את תבניות הקובץ הנתמכות.
המסך אינו נדלק כאשר מתקבלת שיחה.	בעיה בחיישן הקרבה	אם אתה משתמש בנרתיק או כיסוי להגנה, ודא שהוא אינו מכסה את האזור שסביב חיישן הקרבה. ודא שהאזור שמסביב לחיישן הקרבה נקי.
אין צליל	מצב רטט	בדוק את מצב ההגדרות בתפריט הצלילים כדי לוודא שאינך במצב רטט או ללא הפרעות.
ניתוק או קפיאה	בעיה של נתק בתוכנה	נסה לעדכן את התוכנה דרך אתר האינטרנט.

שאלות נפוצות

קטגוריה	שאלה	תשובה
התקני Bluetooth	אילו פונקציות זמינות דרך Bluetooth?	באפשרותך לחבר התקן שמע של Bluetooth, כגון אוזניית סטריאו/מונו או דיבורית.
גיבוי אנשי קשר	איך ניתן לגבות את אנשי הקשר?	נתוני אנשי קשר ניתנים לסנכרון בין הטלפון וחשבון Google שלך.
סנכרון	האם יש אפשרות להגדיר סינכרון חד כיווני עם Gmail?	קיים סנכרון דו כיווני בלבד.
כניסה ל-Gmail	האם עליי להיכנס ל-Gmail בכל פעם שברצוני לגשת אל Gmail?	לאחר שנכנסת ל-Gmail, אין צורך להיכנס ל-Gmail שוב.
חשבון Google	האם ניתן לסנן הודעות דוא"ל?	לא, הטלפון לא תומך בסינון הודעות דוא"ל.
צלצול	האם יש מגבלת גודל קובץ לשימוש בקובצי MP3 כרינגטונים?	אין מגבלה על גודל הקובץ.
שעת ההודעה	הטלפון לא מציג את שעת קבלת ההודעה עבור הודעות שהתקבלו לפני 24 שעות. כיצד אוכל להציג את השעה?	פתח את השיחה והקש והחזק בהודעה הרצויה. לאחר מכן הקש על **פרטים**.
ניווט	האם ניתן להתקין בטלפון יישום ניווט אחר?	ניתן להתקין ולהשתמש בכל יישום שזמין ב-Play Store™ ותואם לחומרה.

קטגוריה	שאלה	תשובה
המתן והשהה	האם ניתן לשמור איש קשר שבוצעו עליו פעולות המתן והשהה?	אם העברת איש קשר באמצעות הפונקציות 'המתן' ו'השהה' שנשמרו במספר, לא תוכל להשתמש בתכונות אלה. עליך לשמור כל מספר שוב. כיצד לשמור עם פונקציות 'המתן' ו'השהה': 1. לחץ על ○ וחייג את המספר. 2. הקש על ⋮ > **הוסף השהייה של 2 שניות** או על **הוסף המתנה**.
אבטחה	מהן פונקציות האבטחה של הטלפון?	ניתן להגדיר את הטלפון כך שהוא ידרוש הזנת קוד PIN או סיסמה ה כתנאי לגישה או לשימוש בטלפון.
זיכרון	האם אדע שהזיכרון שלי מלא?	כן, תקבל התראה.
תמיכה בשפה	האם ניתן לשנות את השפה של הטלפון?	לטלפון יש יכולות רב-לשוניות. כדי לשנות את השפה: 1. לחץ על ○ והקש על ⋯ > ⚙ > **שפה וקלט** > **שפה**. 2. הקש על השפה הרצויה.
VPN	כיצד מגדירים VPN?	תצורת הגישה ל-VPN שונה מחברה לחברה. כדי לקבוע תצורה של גישה ל-VPN בטלפון, עליך לקבל את המידע ממנהל הרשת בחברה שלך.
כיבוי אוטומטי של המסך	המסך שלי כבה לאחר 15 שניות בלבד. איך ניתן לשנות את פרק הזמן עד לכיבוי אור הרקע במסך?	1. לחץ על ○ והקש על ⋯ > ⚙ > **תצוגה** > **כיבוי מסך אוטומטי**. 2. הקש על פרק הזמן המועדף עד לכיבוי התאורה האחורית של המסך.

קטגוריה	שאלה	תשובה
Wi-Fi ורשת ניידת	כאשר גם Wi-Fi וגם רשת ניידת זמינים, באיזה שירות ישתמש הטלפון?	בעת שימוש בנתונים, ייתכן שברירת המחדל של הטלפון תהיה חיבור ה-Wi-Fi (אם קישוריות Wi-Fi מוגדרת בטלפון שלך כמופעלת). עם זאת, לא מתקבלת התראה על כך שהטלפון עבר מקישוריות אחת לאחרת. כדי לדעת איזה חיבור נתונים משמש כעת, הבט בסמל של הרשת הניידת או בסמל Wi-Fi המוצג בראש המסך.
המסך הראשי	האם אפשר להסיר יישום מהמסך הראשי?	כן. פשוט הקש והחזק את הסמל עד שיופיע סמל פח האשפה בקצה העליון ובמרכז המסך. ואז, מבלי להרים את האצבע, גררו את הסמל לפח האשפה.
יישום	הורדתי יישום שגרם הרבה שגיאות. איך אפשר להסיר אותו?	1. לחץ על ○ והקש על ⋯ > ⚙ > **יישומים** > **שהורדו**. 2. הקש על היישום, ולאחר מכן הקש על **הסר התקנה**.
מטען	האם ניתן לטעון את הטלפון באמצעות כבל נתונים של USB מבלי להתקין את מנהל ההתקן הדרוש של USB?	כן, הטלפון נטען באמצעות כבל ה-USB בין אם מנהלי ההתקנים הדרושים מותקנים ובין אם לא.
התראה	האם ניתן להשתמש בקובצי מוסיקה להתראה?	כן. לאחר שמירת קובץ מוסיקה כרינגטון, באפשרותך להשתמש בו להתראה. 1. גע ברציפות בשיר ברשימת ספרייה. בתפריט שנפתח, הקש על **הגדר כצלצול** > **רינגטון טלפון** או **רינגטון של הקבוצה**. 2. במסך 'הגדרת שעון מעורר', בחר את השיר כרינגטון.

קטגוריה	שאלה	תשובה
התראה	האם ההתראות ישמעו בכל מקרה, או שגם ההתראות יכובו כאשר הטלפון מכובה?	לא, אין תמיכה בכך.
התראה	אם עוצמת הצלצול הוגדרה כ'רטט', האם אשמע את ההתראה?	ההתראה מתוכנתת להישמע אפילו בתרחישים אלו.

Welcome!

Thank you for choosing LG. Please carefully read this user guide before using the device for the first time to ensure safe and proper use.

- Always use genuine LG accessories. The supplied items are designed only for this device and may not be compatible with other devices.
- This device is not suitable for people who have a visual impairment due to the touchscreen keyboard.
- Descriptions are based on the device's default settings.
- Default apps on the device are subject to updates and support for these apps may be withdrawn without prior notice. If you have any questions about an app provided with the device, please contact a LG Service Centre. For user-installed apps, please contact the relevant service provider.
- Modifying the device's operating system or installing software from unofficial sources may damage the device and lead to data corruption or data loss. Such actions will violate your LG licence agreement and void your warranty.
- Some contents and illustrations may differ from your device depending on the region, service provider, software version, or OS version, and are subject to change without prior notice.

Instructional notices

⚠ **WARNING**	situations that could cause injury to yourself or others
Caution!	situations that could cause damage to the device or other equipment
NOTE	notice or additional information
TIP!	tips for when using the function

Table of contents

Guidelines for safe and efficient use 4

Important notice 12

Getting to know your phone 15

Phone layout.....15
Installing the SIM or USIM card and battery.....17
Charging the battery 19
Inserting a memory card.....20
Removing the memory card.....21
Changing the screen lock method.....21

Your Home screen.....22

Touch screen tips 22
Home screen 23
Customizing the Home screen 24
Returning to recently-used applications .25
Notifications panel 25
On-screen keyboard 28

Special Features 29

Gesture shot 29

Google account setup.....30

Creating your Google account.....30
Signing into your Google account.....30

Connecting to Networks and Devices....32

Wi-Fi 32
Bluetooth.....33
Wi-Fi Direct 34
Transferring data between a PC and the device.....35

Calls 36

Making a call 36
Calling your contacts 36
Answering and rejecting a call 36
Making a second call 37
Viewing your call logs 37
Call settings.....37

Contacts.....38

Searching for a contact.....38
Adding a new contact 38
Favourites contacts.....38
Creating a group.....39

Messaging.....40

Sending a message 40
Conversation view 41
Changing your messaging settings 41

Camera and Video.....42

Camera options on the viewfinder.....42
Setting the resolution.....43
Once you have taken a photo.....43
Recording a video 43
After recording a video.....44
Gallery.....44

Multimedia 47
Music 47

Utilities 49
Clock 49
Calculator 50
Calendar 51
Voice Recorder 51
Voice Search 51
Downloads 52
FM Radio 52

Web Browser 53
Internet 53
Chrome 54

Settings 55
WIRELESS NETWORKS 55
DEVICE 57
PERSONAL 60
SYSTEM 64

Phone software update 66
Phone software update 66

About this user guide 68
About this user guide 68
Trademarks 69

Accessories 70

Troubleshooting 71

FAQ 74

Guidelines for safe and efficient use

Please read these simple guidelines. Not following these guidelines may be dangerous or illegal.

Should a fault occur, a software tool is built into your device that will gather a fault log. This tool gathers only data specific to the fault, such as signal strength, cell ID position in sudden call drop and applications loaded. The log is used only to help determine the cause of the fault. These logs are encrypted and can only be accessed by an authorised LG Repair centre should you need to return your device for repair.

Exposure to radio frequency energy

Radio wave exposure and Specific Absorption Rate (SAR) information.

This mobile phone model LG-H410YK has been designed to comply with applicable safety requirements for exposure to radio waves. These requirements are based on scientific guidelines that include safety margins designed to assure the safety of all persons, regardless of age and health.

- The radio wave exposure guidelines employ a unit of measurement known as the Specific Absorption Rate, or SAR. Tests for SAR are conducted using standardised methods with the phone transmitting at its highest certified power level in all used frequency bands.
- While there may be differences between the SAR levels of various LG phone models, they are all designed to meet the relevant guidelines for exposure to radio waves.
- The SAR limit recommended by the International Commission on Non-Ionizing Radiation Protection (ICNIRP) is 2 W/kg averaged over 10 g of tissue.
- The highest SAR value for this model phone tested for use at the ear is 0.254 W/kg (10 g) and when worn on the body is 0.557 W/Kg (10 g).

- This device meets RF exposure guidelines when used either in the normal use position against the ear or when positioned at least 1.5 cm away from the body. When a carry case, belt clip or holder is used for body-worn operation, it should not contain metal and should position the product at least 1.5 cm away from your body. In order to transmit data files or messages, this device requires a quality connection to the network. In some cases, transmission of data files or messages may be delayed until such a connection is available. Ensure the above separation distance instructions are followed until the transmission is completed.

Product care and maintenance

⚠ WARNING

Always use genuine LG batteries, chargers and accessories approved for use with this particular phone model. The use of any other types may invalidate any approval or warranty applying to the phone and may be dangerous.

- Do not disassemble this unit. Take it to a qualified service technician when repair work is required.
- Repairs under warranty, at LG's discretion, may include replacement parts or boards that are either new or reconditioned, provided that they have functionality equal to that of the parts being replaced.
- Keep away from electrical appliances such as TVs, radios and personal computers.
- The unit should be kept away from heat sources such as radiators or cookers.
- Do not drop.
- Do not subject this unit to mechanical vibration or shock.
- Switch off the phone in any area where you are required to by special regulations. For example, do not use your phone in hospitals as it may affect sensitive medical equipment.
- Do not handle the phone with wet hands while it is being charged. It may cause an electric shock and can seriously damage your phone.

- Do not charge a handset near flammable material as the handset can become hot and create a fire hazard.
- Use a dry cloth to clean the exterior of the unit (do not use solvents such as benzene, thinner or alcohol).
- Do not charge the phone when it is on soft furnishings.
- The phone should be charged in a well ventilated area.
- Do not subject this unit to excessive smoke or dust.
- Do not keep the phone next to credit cards or transport tickets; it can affect the information on the magnetic strips.
- Do not tap the screen with a sharp object as it may damage the phone.
- Do not expose the phone to liquid or moisture.
- Use accessories like earphones cautiously. Do not touch the antenna unnecessarily.
- Do not use, touch or attempt to remove or fix broken, chipped or cracked glass. Damage to the glass display due to abuse or misuse is not covered under the warranty.
- Your phone is an electronic device that generates heat during normal operation. Extremely prolonged, direct skin contact in the absence of adequate ventilation may result in discomfort or minor burns. Therefore, use care when handling your phone during or immediately after operation.
- If your phone gets wet, immediately unplug it to dry off completely. Do not attempt to accelerate the drying process with an external heating source, such as an oven, microwave or hair dryer.
- The liquid in your wet phone, changes the colour of the product label inside your phone. Damage to your device as a result of exposure to liquid is not covered under your warranty.

Efficient phone operation

Electronics devices

All mobile phones may receive interference, which could affect performance.

- Do not use your mobile phone near medical equipment without requesting permission. Avoid placing the phone over pacemakers, for example, in your breast pocket.
- Some hearing aids might be disturbed by mobile phones.
- Minor interference may affect TVs, radios, PCs etc.
- Use your phone in temperatures between 0 ºC and 40 ºC, if possible. Exposing your phone to extremely low or high temperatures may result in damage, malfunction, or even explosion.

Road safety

Check the laws and regulations on the use of mobile phones in the area when you drive.

- Do not use a hand-held phone while driving.
- Give full attention to driving.
- Pull off the road and park before making or answering a call if driving conditions so require.
- RF energy may affect some electronic systems in your vehicle such as car stereos and safety equipment.
- When your vehicle is equipped with an air bag, do not obstruct with installed or portable wireless equipment. It can cause the air bag to fail or cause serious injury due to improper performance.
- If you are listening to music whilst out and about, please ensure that the volume is at a reasonable level so that you are aware of your surroundings. This is of particular importance when near roads.

Avoid damage to your hearing



To prevent possible hearing damage, do not listen at high volume levels for long periods.

Damage to your hearing can occur if you are exposed to loud sound for long periods of time. We therefore recommend that you do not turn on or off the handset close to your ear. We also recommend that music and call volumes are set to a reasonable level.

- When using headphones, turn the volume down if you cannot hear the people speaking near you, or if the person sitting next to you can hear what you are listening to.

NOTE

- Excessive sound pressure from earphones and headphones can cause hearing loss.

Glass Parts

Some parts of your mobile device are made of glass. This glass could break if your mobile device is dropped on a hard surface or receives a substantial impact. If the glass breaks, do not touch or attempt to remove it. Stop using your mobile device until the glass is replaced by an authorised service provider.

Blasting area

Do not use the phone where blasting is in progress. Observe restrictions and follow any regulations or rules.

Potentially explosive atmospheres

- Do not use your phone at a refueling point.
- Do not use near fuel or chemicals.
- Do not transport or store flammable gas, liquid or explosives in the same compartment of your vehicle as your mobile phone or accessories.

In aircraft

Wireless devices can cause interference in aircraft.

- Turn your mobile phone off before boarding any aircraft.
- Do not use it on the ground without permission from the crew.

Children

Keep the phone in a safe place out of the reach of small children. It includes small parts which may cause a choking hazard if detached.

Emergency calls

Emergency calls may not be available on all mobile networks. Therefore you should never depend solely on your phone for emergency calls. Check with your local service provider.

Battery information and care

- You do not need to completely discharge the battery before recharging. Unlike other battery systems, there is no memory effect that could compromise the battery's performance.
- Use only LG batteries and chargers. LG chargers are designed to maximise the battery life.
- Do not disassemble or short-circuit the battery.
- Keep the metal contacts of the battery clean.

- Replace the battery when it no longer provides acceptable performance. The battery pack may be recharged hundreds of times before it needs replacing.
- Recharge the battery if it has not been used for a long time to maximise usability.
- Do not expose the battery charger to direct sunlight or use it in high humidity, such as in the bathroom.
- Do not leave the battery in hot or cold places, as this may deteriorate battery performance.
- There is risk of explosion if the battery is replaced with an incorrect type.
- Dispose of used batteries according to the manufacturer's instructions. Please recycle when possible. Do not dispose as household waste.
- If you need to replace the battery, take it to the nearest authorised LG Electronics service point or dealer for assistance.
- Always unplug the charger from the wall socket after the phone is fully charged to save unnecessary power consumption of the charger.
- Actual battery life will depend on network configuration, product settings, usage patterns, battery and environmental conditions.
- Make sure that no sharp-edged items such as animal's teeth or nails, come into contact with the battery. This could cause a fire.

Open Source Software Notice Information

To obtain the source code under GPL, LGPL, MPL, and other open source licenses, that is contained in this product, please visit http://opensource.lge.com.

In addition to the source code, all referred license terms, warranty disclaimers and copyright notices are available for download.

LG Electronics will also provide open source code to you on CD-ROM for a charge covering the cost of performing such distribution (such as the cost of media, shipping, and handling) upon email request to opensource@lge.com. This offer is valid for three (3) years from the date on which you purchased the product.

HOW TO UPDATE YOUR DEVICE

Access to latest firmware releases, new software functions and improvements.

- **Select the software update in settings menu on your device.**
- **Update your device by connecting it to your PC.** For more information about using this function, please visit http://www.lg.com/common/index.jsp select country and language.

DECLARATION OF CONFORMITY

Hereby, **LG Electronics** declares that this **LG-H410YK** product is in compliance with the essential requirements and other relevant provisions of Directive **1999/5/EC**. A copy of the Declaration of Conformity can be found at **http://www.lg.com/global/declaration**

Important notice

Please read this before you start using your phone!

Please check to see whether any problems you encountered with your phone are described in this section before taking the phone in for service or calling a service representative.

1. Phone memory

When there is less than 10MB of space available in your phone memory, your phone cannot receive new messages. You may need to check your phone memory and delete some data, such as applications or messages, to make more memory available.

To uninstall applications:

1 Press and tap > > **Apps**.

2 Once all applications appear, scroll to and select the application you want to uninstall.

3 Tap **Uninstall**.

2. Optimizing battery life

Extend your battery's power by turning off features that you do not need to run constantly in the background. You can monitor how applications and system resources consume battery power.

Extending your phone's battery life:

- Turn off radio communications when you are not using. If you are not using Wi-Fi, Bluetooth or GPS, turn them off.
- Reduce screen brightness and set a shorter screen timeout.
- Turn off automatic syncing for Gmail, Calendar, Contacts and other applications.

- Some applications you download may consume battery power.
- While using downloaded applications, check the battery charge level.

3. Before installing an open source application and OS

⚠ WARNING

- If you install and use an OS other than the one provided by the manufacturer it may cause your phone to malfunction. In addition, your phone will no longer be covered by the warranty.
- To protect your phone and personal data, only download applications from trusted sources, such as Play Store™. If there are improperly installed applications on your phone, the phone may not work normally or a serious error may occur. You must uninstall those applications and all associated data and settings from the phone.

4. Opening and switching applications

Multitasking is easy with Android; you can keep more than one application running at the same time. There is no need to quit an application before opening another. Use and switch between several open applications. Android manages each application, stopping and starting them as needed to make sure that idle applications don't consume resources unnecessarily.

1 Press □. A list of recently used applications will be displayed.

2 Tap the application you want to access. This does not stop the previous app from running in the background. Make sure to press ◁ to back out of an app after using it.


- To close an app from the recent apps list, swipe the app preview to the left or right. To clear all apps, tap **Clear all**.

5. When the screen freezes

If the screen freezes or the phone does not respond when you try to operate it, remove the battery and reinsert it. Then power the phone back on.

Getting to know your phone

Phone layout



Back Key	Returns to the previous screen. Also closes pop-up items, such as menus, dialog boxes and the on-screen keyboard.
Home Key	Returns to the Home screen from any screen.
Recent Apps Key	Displays recently used applications. If you touch and hold this button, it opens a menu of available options.
QuickButton Key	• Press to use an app or a feature previously assigned. • Press and hold to set up the QuickButton setting.
End/ Power Key	• Turn your phone on/off by pressing and holding this key. • Short press to finish a current app and return to the Home screen from any screen.

NOTE: Proximity Sensor

- When receiving and making calls, the proximity sensor automatically turns the backlight off and locks the touch screen by sensing when the phone is near your ear. This extends battery life and prevents you from unintentionally activating the touch screen during calls.


⚠ WARNING

Placing a heavy object on the phone or sitting on it can damage the display and touch screen functions. Do not cover the proximity sensor with screen protectors or any other type of protective film. This could cause the sensor to malfunction.


Installing the SIM or USIM card and battery

Insert the SIM or USIM card provided by the mobile telephone service provider, and the included battery.

1 To remove the back cover, hold the phone firmly in one hand. With your other hand, lift off the back cover with your thumbnail as shown in the figure below.



2 Slide the SIM card into the SIM card slot as shown in the figure. Make sure the gold contact area on the card is facing downward.




⚠ WARNING

Do not insert a memory card into the SIM card slot. If a memory card happens to be lodged in the SIM card slot, take the device to a LG Service Centre to remove the memory card.


NOTE

- Only the microSIM cards work with the device.

3 Insert the battery.



4 To replace the cover onto the device, align the back cover over the battery compartment ❶ and press it down until it clicks into place ❷.




Charging the battery

Charge the battery before using it for first time. Use the charger to charge the battery. A computer can also be used to charge the battery by connecting the phone to it using the USB cable.

⚠ WARNING

Use only LG-approved chargers, batteries and cables. If you use unapproved chargers, batteries or cables, it may cause battery charging delay. Or this can cause the battery to explode or damage the device, which are not covered by the warranty.

The charger connector is located at the bottom of the phone. Insert the charger and plug it into a power outlet.



NOTE

- Do not open the back cover while your phone is charging.

Inserting a memory card

Your device supports up to a 32GB microSD card. Depending on the memory card manufacturer and type, some memory cards may not be compatible with your device.

⚠ WARNING


Some memory cards may not be fully compatible with the device. Using an incompatible card may damage the device or the memory card, or corrupt the data stored in it.

NOTE

- Frequent writing and erasing of data shortens the lifespan of memory cards.

1 Remove the back cover.

2 Insert a memory card with the gold-coloured contacts facing downwards.



3 Replace the back cover.

Removing the memory card

Before removing the memory card, first unmount it for safe removal.

1 Press ○ and tap ⋯ > ⚙ > **Storage** > **Unmount SD card**.

2 Remove the back cover and pull out the memory card.

> ⚠ **WARNING**
> Do not remove the memory card while the device is transferring or accessing information. Doing so can cause data to be lost or corrupted or damage to the memory card or device. It is not responsible for losses that result from the misuse of damaged memory cards, including the loss of data.

Changing the screen lock method

You can change the way that you lock the screen to prevent others accessing your personal information.

1 Press ○ and tap ⋯ > ⚙ > **Lock screen** > **Select screen lock**.

2 Select a desired screen lock from None, PIN and Password.

Your Home screen

Touch screen tips

Here are some tips on how to navigate on your phone.


- **Tap or touch** – A single finger tap selects items, links, shortcuts and letters on the on-screen keyboard.
- **Touch and hold** – Touch and hold an item on the screen by tapping it and not lifting your finger until an action occurs.
- **Drag** – Touch and hold an item for a moment and then, without lifting your finger, move your finger on the screen until you reach the target position. You can drag items on the Home screen to reposition them.
- **Swipe or slide** – To swipe or slide, quickly move your finger across the surface of the screen, without pausing when you first tap it (so you don't drag an item instead).
- **Double-tap** – Double-tap to zoom on a webpage or a map.
- **Pinch-to-Zoom** – Use your index finger and thumb in a pinching or spreading motion to zoom in or out when using the browser, Maps, or when viewing pictures.
- **Rotate the screen** – From many applications and menus, the screen orientation adjusts to the device's physical orientation.

NOTE

- Do not press too hard; the tap screen is sensitive enough to pick up a light, yet firm tap.
- Use the tip of your finger to tap the option you want. Be careful not to tap any other buttons.

Home screen

The Home screen is the starting point for many applications and functions. It allows you to add items like app shortcuts and Google widgets to give you instant access to information and applications. This is the default canvas and accessible from any menu by pressing ○.



1 Status Bar

2 Widget

3 Application Icons

4 Quick Button Area

1. Shows the phone's status information, including the time, signal strength, battery status and notification icons.
2. Widgets are self-contained applications that can be accessed through the Apps drawer or on the Home screen. Unlike a shortcut, a Widget can function as an on-screen application.
3. Tap an icon (application, folder, etc.) to open and use it.
4. Provides one-touch access to the function in any Home screen canvas.

Extended Home screen

The operating system provides multiple Home screen canvases to provide more space for adding icons, widgets and more.

- Slide your finger left or right across the Home screen to access additional canvases.

Customizing the Home screen

You can customise your Home screen by adding apps and widgets and changing wallpapers.

Adding items on your Home screen

1 Press  and tap 

2 Tap the desired tab from **Apps** or **Widgets**.

3 Drag an item to the desired location and lift your finger.

TIP! To change the wallpaper from the Home screen, touch and hold the empty part of the Home screen. Then **Select wallpaper from** appears.

Removing an item from the Home screen

- While on the Home screen, touch and hold the icon you want to remove > drag it to .

Adding an app to the Quick Button Area

- From the Apps screen or on the Home screen, touch and hold an application icon and drag it to the Quick Button Area. Then release it in the desired location.

Removing an app from the Quick Button Area

- Touch and hold the desired Quick Button, drag it to .

NOTE

- The **Apps Button**  cannot be removed.

Customizing app icons on the Home screen

1 Touch and hold an application icon until it unlocks from its current position, then release it. The editing icon  appears in the upper-right corner of the application.

2 Tap the application icon again and select the desired icon design and size.

3 Tap **OK** to save the change.

Returning to recently-used applications

1 Press ▢. App list of recently used applications will be displayed.

2 Tap an app preview to open the application.

- OR -

Press ◁ to return to your previous screen.


Notifications panel

Notifications alert you to the arrival of new messages, calendar events and alarms, as well as ongoing events, such as when you are on a call.

When a notification arrives, its icon appears at the top of the screen. Icons for pending notifications appear on the left, and system icons, such as Wi-Fi and battery strength are shown on the right.


NOTE

- The available options may vary depending on the region or service provider.



Opening the notifications panel

Swipe down from the status or press and hold ✱ to open the notifications panel. To close the notifications panel, swipe the screen upwards or tap ◁.



1 Quick Settings Area

2 Notifications

3 Clear

1. Tap each quick setting button to toggle it on/off. Touch and hold the desired button to directly access the settings menu for the function. To see more toggle buttons, swipe left or right. Tap ⚙ to remove, add or rearrange quick setting buttons.
2. Current notifications are listed, each with a brief description. Tap a notification to view it.
3. Tap to clear all the notifications.

Indicator icons on the Status Bar

Indicator icons appear on the status bar at the top of the screen to report missed calls, new messages, calendar events, device status and more.



The icons displayed at the top of the screen provide information about the status of the device. The icons listed in the table below are some of the most common ones.

Icon	Description
	No SIM card inserted
	No network signal available
	Airplane mode is on
	Connected to a Wi-Fi network
	Wired headset connected
	Call in progress
	Missed call
	Bluetooth is on
	System warning
	An alarm is set
	New voicemail available
	New text or multimedia message

Icon	Description
	A song is currently playing
	No interruptions, not even alarms
	Vibrate mode is on
	Battery fully charged
	Battery is charging
	The phone is connected to a PC via a USB cable
	Downloading data
	Uploading data
	GPS is on
	Data is synchronizing
	Choose input method
	Wi-Fi hotspot is active

NOTE

- The icon's location in the status bar may differ according to the function or service.

On-screen keyboard

You can enter text using the on-screen keyboard. The on-screen keyboard appears on the screen when you tap an available text entry field.

Using the keypad and entering text

Tap once to capitalise the next letter you type. Double-tap for all caps.

Tap to go to the keyboard settings. Touch and hold to change entering text method.

Tap to enter a space.

Tap to create a new line.

Tap to delete the previous character.

Entering accented letters

When you select French or Spanish as the text entry language, you can enter special French or Spanish characters (e.g. "á").

For example, to input "á", touch and hold the "a" key until the zoom-in key expands and displays characters from different languages. Then select the special character you want.

Special Features

Gesture shot

The Gesture shot feature allows you to take a picture with a hand gesture using the front camera.


To take a photo

There are two methods for using the Gesture shot feature.

- Raise your hand, with an open palm, until the front camera detects it and a box appears on the screen. Then close your hand into a fist to start the timer, allowing you time to get ready.

- OR -

- Raise your hand, in a clenched fist, until the front camera detects it and a box appears on the screen. Then unclench your fist to start the timer, allowing you time to get ready.



Google account setup

The first time you open a Google application on your phone, you will be required to sign in with your existing Google account. If you do not have a Google account, you will be prompted to create one.

Creating your Google account

1 Press and tap > > **Accounts & sync**.
2 Tap **Add account** > **Google** > **Or create a new account**.
3 Enter your first and last name, then tap **NEXT**.
4 Enter a username and tap **NEXT**. Your phone will communicate with Google servers and check for username availability.
5 Enter your password and tap **NEXT**.
6 Follow the instructions and enter the required and optional information about the account. Wait while the server creates your account.

Signing into your Google account

1 Press and tap > > **Accounts & sync**.
2 Tap **Add account** > **Google**.
3 Enter your email address and tap **NEXT**.
4 After signing in, you can use Gmail and take advantage of Google services on your phone.
5 Once you have set up your Google account, your phone will automatically synchronise with your Google account on the web (if a data connection is available).

After signing in, your phone will sync with your Google services, such as Gmail, Contacts, and Google Calendar. You can also use Maps, download applications from Play Store, back up your settings to Google servers, and take advantage of other Google services on your phone.

IMPORTANT

- Some applications, such as Calendar, work only with the first Google Account you add. If you plan to use more than one Google Account with your phone, be sure to sign into the one you want to use with such applications first. When you sign in, your contacts, Gmail messages, Calendar events, and other information from these applications and services on the web are synchronised with your phone. If you don't sign into a Google Account during setup, you will be prompted to sign in or to create a Google Account the first time you start an application that requires one, such as Gmail or Play Store.
- If you have an enterprise account through your company or other organization, your IT department may have special instructions on how to sign into that account.

Connecting to Networks and Devices

Wi-Fi

You can use high-speed Internet access while within the coverage of the wireless access point (AP).

Connecting to Wi-Fi networks

1 Press ○ and tap ⋯ > ⚙ > **Wi-Fi**.

2 Tap OFF ON to turn Wi-Fi on and start scanning for available Wi-Fi networks.

3 Tap a network to connect to it.

- If the network is secured with a lock icon, you will need to enter a security key or password.

4 The status bar displays icons that indicate Wi-Fi status.

NOTE

- If you are out of the Wi-Fi zone or have set Wi-Fi to Off, the device may automatically connect to the Web using mobile data, which may incur data charges.

TIP! How to obtain the MAC address

Press ○ and tap ⋯ > ⚙ > **Wi-Fi** > ⋮ > **Advanced Wi-Fi** > **MAC address**.

Bluetooth

Bluetooth is a short-range communications technology that allows you to connect wirelessly to a number of Bluetooth devices, such as headsets and hands-free car kits, and Bluetooth-enabled handhelds, computers, printers, and wireless devices.

NOTE

- LG is not responsible for the loss, interception or misuse of data sent or received via the Bluetooth feature.
- Always make sure that you share and receive data with devices that are trusted and properly secured.
- If there are obstacles between the devices, the operating distance may be reduced.
- Some devices, especially those that are not tested or approved by Bluetooth SIG, may be incompatible with your device.

Pairing your phone with another Bluetooth device

1 Press ○ and tap ⋯ > ⚙ > **Bluetooth**.

2 Tap OFF ON to turn Bluetooth on and start scanning for available Bluetooth devices.
   - If you want to detect the visible devices in range additionally, tap **Search**.

3 Choose the device you want to pair with from the list. Once the paring is successful, your phone connects to the other device.

NOTE

- Pairing between two Bluetooth devices is a one-time process. Once a pairing has been created, the devices will continue to recognise their partnership and exchange information.

TIP! Please consult documentation included with Bluetooth device for information on pairing mode and passcode (typically 0 0 0 0 – four zeroes).

Sending data via Bluetooth

1 Select a file or item such as a contact or media file.

2 Select the option for sending data via Bluetooth.

3 Search for and pair with a Bluetooth-enabled device.

NOTE

- Due to different specifications and features of other Bluetooth-compatible devices, display and operations may be different, and functions such as transfer or exchange may not be possible with all Bluetooth compatible devices.

Receiving data via Bluetooth

1 Press ○ and tap ⋯ > ⚙ > **Bluetooth**.

2 Tap OFF ON to turn Bluetooth on.

3 You will receive a request to accept a pairing attempt from the sending device. Be sure to select **Accept**.

Wi-Fi Direct

Wi-Fi Direct provides a direct connection between Wi-Fi enabled devices without requiring an access point.

Turning on Wi-Fi Direct

1 Press ○ and tap ⋯ > ⚙ > **Wi-Fi**.

2 Tap ⋮ > **Advanced Wi-Fi** > **Wi-Fi Direct**.

NOTE

- When in this menu, your device is visible to other visible Wi-Fi Direct devices nearby.

Transferring data between a PC and the device

You can copy or move data between a PC and the device.

Transferring data

1 Connect your device to a PC using the USB cable that came with your phone.

2 Open the Notifications panel, tap the current connection type, and select **Media device (MTP)**.

3 A window will pop-up on your PC, allowing you to transfer the desired data.

NOTE

- The LG Android Platform Driver is required to be installed on your PC to be able to detect the phone.
- Check the requirements for using **Media device (MTP)**.

Items	Requirement
OS	Microsoft Windows XP SP3, Vista or higher
Window Media Player version	Windows Media Player 10 or higher

Calls

Making a call

1 Press ○ and enter the number using the dialer. To delete a digit, press C.
2 After entering the desired number, press ☎ to place the call.
3 To end the call, press ☎.

TIP! To enter "+" to make international calls, press and hold 0+␣.

Calling your contacts

1 Press ○ > 👤 to open your contacts.
2 Scroll through the contact list. You can also enter the contact's name in the Search field.
3 In the list that is displayed, tap the contact you want to call.

Answering and rejecting a call

- Press ☎ to answer the incoming call.
- Press ☎ once to make silent mode and twice to decline an incoming call.

NOTE

- Tap 💬 if you want to send a message to the caller.

Making a second call

1 During your first call, tap ⋮ > **Add call** and enter the number.
2 Press  to place the call.
3 Both calls are displayed on the call screen. Your initial call is locked and put on hold.
4 Press  to toggle between calls. Or tap ⋮ > **Merge calls** to start a conference call.
5 To end all calls, press .

NOTE
- You are charged for each call you make.

Viewing your call logs

1 Press  > .
2 View a list of all dialed, received and missed calls.

TIP!
- Tap any call log entry to view the date, time and duration of the call.
- Tap ⋮ > **Delete all** to delete all of the recorded items.

Call settings

You can configure phone call settings, such as call forwarding, as well as other special features offered by your carrier.

1 Press  > .
2 Tap ⋮ > **Call settings** and configure the desired options.

Contacts

You can add contacts on your phone and synchronise them with the contacts in your Google Account or other accounts that support syncing contacts.

Searching for a contact

1 Press ○ > ▣ to open your contacts.

2 Tap **Search contacts** and enter the contact name using the keyboard.

Adding a new contact

1 Press ○ and enter the new contact's number.

2 Tap ⋮ > **Add to Contacts** > **New contact**.

3 If you want to add a picture to the new contact, tap the image icon. Choose **Take photo** or **Select from Albums**.

4 Enter the desired information for the contact.

5 Tap **Save**.

Favourites contacts

You can classify frequently called contacts as favourites.

Adding a contact to your favourites

1 Press ○ > ▣ to open your contacts.

2 Tap a contact to view its details.

3 Tap the star at the top right of the screen. The star turns yellow.

Removing a contact from your favourites list

1 Press ○ > 👤 and tap **Favourites** tab.

2 Choose a contact to view its details.

3 Tap the yellow star at the top right of the screen. The star turns a white colour and the contact is removed from your favourites.

Creating a group

1 Press ○ > 👤 and tap **Groups** tab.

2 Tap ⋮ > **New group**.

3 Enter a name for the new group. You can also set a distinct ringtone for the newly created group.

4 Tap **Add members** to add contacts to the group and tap **Add**.

5 Tap **Save** to save the group.

NOTE

- If you delete a group, the contacts assigned to that group will not be lost. They will remain in your contact list.

Messaging

Your phone combines text and multimedia messaging into one intuitive, easy to use menu.

Sending a message

1 Press ○ > ✉ and tap **New compose**.

2 Enter a contact name or contact number into the **To** field. As you enter the contact name, matching contacts appear. You can tap a suggested recipient and add more than one contact.

NOTE

- You may be charged for each text message you send. Please consult with your service provider.

3 Tap the text field and start entering your message.

4 Tap ⋮ to open the options menu. Choose from any of the available options.

TIP! You can tap **Attach** to attach the file that you want to share with message.

5 Tap **Send** to send your message.

TIP!

- The 160-character limit may vary from country to country depending on how the text message is coded and the language used in the message.
- If an image, video, or audio file is added to a text message, it will be automatically converted into a multimedia message and you will be charged accordingly.

NOTE

- When you get a text message during a call, there will be an audible notification.

Conversation view

Messages exchanged with another party are displayed in chronological order so that you can conveniently see and find your conversations.

Changing your messaging settings

Your phone's messaging settings are predefined to allow you to send messages immediately. You can change the settings based on your preferences.

- Press ○ > ✉ and tap ⋮ > **Settings**.

Camera and Video

Camera options on the viewfinder

You can use the camera or camcorder to take and share pictures and videos.

- Press ○ > .



1. **Setting** – Tap to set the resolution of your picture and video.
2. **Gallery** – Tap to view the last photo or video you recorded.
3. **Record** – Tap to start recording.
4. **Capture** – Tap to take a photo.
5. **Swap camera** – Tap to swap between the rear camera lens and the front camera lens.

NOTE Be sure to clean the protective lens cover with a microfiber cloth before taking pictures. A lens cover with smudges from fingers can cause blurry pictures with a "halo" effect.

Setting the resolution

1 In the camera viewfinder, press and hold ▢.

2 Set the resolution.

Taking a photo

1 Press ○ > 📷.

2 Frame your subject on the screen.

3 Tap 📷 to take a photo. Your picture will be automatically saved to the Gallery.

Once you have taken a photo

Tap the image thumbnail on the screen to view the last photo you took.

✎	Tap to edit the photo.
⋖	Tap to open the available sharing options.
🗑	Tap to delete the photo.
⋮	Tap to access additional options.

Recording a video

1 Press ○ > 📷.

2 Frame your subject on the screen.

3 Tap 🎥 to start recording the video.

4 The length of the recording is displayed on the top of the screen.

NOTE

- Tap 📷 to take pictures while recording video.

5 Tap ⏸ to pause recording video. You can resume recording again by tapping ●.
- OR -
Tap ■ to stop recording. Your video will be automatically saved to the Gallery.

After recording a video

Tap the video thumbnail on the screen to view the last video you recorded.

	Tap to open the available sharing options (such as Messaging or Bluetooth) to share.
	Tap to delete the video.
	Tap to access additional options.

Gallery

The Gallery application presents the pictures and videos in your storage, including those you've taken with the Camera application and those you downloaded from the web or other locations.

1 Press ○ and tap ⋯ >  to view the images stored in the storage.
2 Tap an album to open it and view its contents. (The pictures and videos in the album are displayed in chronological order.)
3 Tap a picture in an album to view it.

NOTE

- Depending on the software installed, some file formats may not be supported.
- Some files may not play properly due to their encoding.

Viewing pictures

The Gallery displays your pictures in folders. When an application, such as E-mail, saves a picture, the download folder is automatically created to contain the picture. Likewise, capturing a screenshot automatically creates the Screenshots folder.

Pictures are displayed by the date they were created. Select a picture to view it full screen. Scroll left or right to view the next or previous image.

Zooming in and out


Use one of the following methods to zoom in on an image:

- Double-tap anywhere to zoom in.
- Spread two fingers apart on any place in the picture zoom in. Pinch in or double-tap the image to zoom out.

Video options

1 Press and tap > .

2 Select the video you want to watch.



1	/	Tap to pause/resume video playback.
2		Tap to fast-forward 10 seconds.
3		Tap to rewind 10 seconds.
4		Tap to adjust the video volume.

5	/	Tap to lock/unlock the screen.
6	⋮	Tap to access additional options.

NOTE

- While playing a video, slide the right side of the screen up or down to adjust the sound.
- While playing a video, slide the left side of the screen up or down to adjust the brightness.
- While playing a video, slide your finger from left to right (or vice versa) to fast-forward and rewind.

Editing photos

While viewing a photo, tap .

Deleting photos/videos

Use one of the following methods:

- While in a folder, tap , select the photos/videos and then tap **Delete**.
- While viewing a photo, tap .

Setting wallpaper

While viewing a photo, tap ⋮ > **Set image as** to set the image as wallpaper or assign it to a contact.

NOTE

- Depending on the software installed, some file formats may not be supported.
- If the file size exceeds the available memory, an error can occur when you open files.

Multimedia

Music

Your phone has a music player that lets you play all your favourite tracks.


Playing a song

1 Press ○ and tap ⋯ > .

2 Tap the **Songs** tab.

3 Select the song you want to play.

4 The following options are available.



1	⏸	Tap to pause playback.
	▶	Tap to resume playback.
2	⏭	Tap to skip to the next track in the album, playlist or shuffle list. Touch and hold to fast-forward.
3	⏮	Tap to restart the current track or skip to the previous track in the album, playlist or shuffle list. Touch and hold to rewind.

❹		Tap to adjust the volume.
❺		Tap to open the music library.
❻		Tap to play the current playlist in shuffle mode (tracks are played in random order).
❼		Tap to toggle through repeat all songs, repeat current song and repeat off.
❽		Tap to add the song to your favourites.
❾		Tap to open the current playlist.
❿		Tap to access additional options.

NOTE

- Depending on the software installed, some file formats may not be supported.
- If the file size exceeds the available memory, an error can occur when you open files.
- Music file copyrights may be protected by international treaties and national copyright laws. Therefore, it may be necessary to obtain permission or a licence to reproduce or copy music. In some countries, national laws prohibit private copying of copyrighted material. Before downloading or copying the file, please check the national laws of the relevant country concerning the use of such material.

Utilities

Clock

The Clock app gives you access to the Alarms, Timer, World clock and Stopwatch functions. Access these functions by tapping the tabs across the top of the screen or swiping horizontally across the screen.

- Press ○ and tap ⋮⋮⋮ > .

Alarms

The Alarms tab allows you to set alarms.

1 Press ○ and tap ⋮⋮⋮ >  > **Alarms** tab.

2 Tap + to add a new alarm.

3 Adjust the settings as necessary and tap **Save**.

NOTE

- You can also tap an existing alarm to edit it.

Timer

The Timer tab can alert you with an audible signal when a set amount of time has passed.

1 Press ○ and tap ⋮⋮⋮ >  > **Timer** tab.

2 Set the desired time on the timer.

3 Tap **Start** to start the timer.

4 Tap **Stop** to stop the timer.

World clock

The World clock tab allows you to easily check the current time in other cities around the world.

1 Press ○ and tap ⋯ >  > **World clock** tab.

2 Tap + and select the desired city.

Stopwatch

The Stopwatch tab allows you to use your phone as a stopwatch.

1 Press ○ and tap ⋯ >  > **Stopwatch** tab.

2 Tap **Start** to initiate the stopwatch.

- Tap **Lap** to record lap times.

3 Tap **Stop** to stop stopwatch.

Calculator

The Calculator app allows you to perform mathematical calculations using a standard calculator.

1 Press ○ and tap ⋯ > .

2 Tap the number buttons to enter numbers.

3 For simple calculations, tap the function you want to perform (+, –, x or ÷) followed by =.

NOTE

- To check the history, tap ⋮ > **Calculation history**.

Calendar

The Calendar app allows you to track your schedule of events.

1 Press ▭ and tap ⋯ > WED 29.

2 Tap the date you want to add an event to. Then tap ⋮ > **New event**.

Voice Recorder

The Voice Recorder app records audible files for you to use in a variety of ways.

Recording a sound or voice

1 Press ▭ and tap ⋯ > .

2 Tap ● to begin recording.

3 Tap ■ to end the recording.

4 Tap ▶ to listen to the recording.

NOTE

- Tap ≡ to access your recordings. You can listen to your saved recordings.

Voice Search

Use this application to search webpages using voice.

1 Press ▭ and tap ⋯ > .

2 Say a keyword or phrase when **Listening...** appears on the screen. Select one of the suggested keywords that appear.

NOTE

- This application may not be available depending on the region or service provider.

Downloads

Use this application to see what files have been downloaded through the applications.

- Press ▭ and tap ⋯ > .

NOTE

- This application may not be available depending on the region or service provider.

FM Radio

Your phone has a built-in FM Radio so you can tune in to your favourite stations and listen on the go.

- Press ▭ and tap ⋯ > .

TIP! You must plug in your earphones in order to use them as an antenna.

NOTE

- This application may not be available depending on the region or service provider.

Web Browser

Internet

The internet gives you a fast, full colour world of games, music, news, sports, entertainment, and much more, right on your mobile phone.

NOTE

- Additional charges apply when connecting to these services and downloading content. Check data charges with your network provider.

- Press and tap > .

Viewing webpages

Tap the address field, enter the web address and tap **Go** on the keyboard.

Opening a page

To go to a new page, tap 1 > +.

To go to another webpage, tap 2, scroll up or down, and tap the page to select it.

Searching the web by voice

Tap the address field and then tap . When prompted, say a keyword and select one of the suggested keywords that appear.

NOTE

- This feature may not be available depending on the region or service provider.

Bookmarks

To bookmark the current webpage, tap ⋮ > **Add bookmark** > **Save**.

To open a bookmarked webpage, tap ⋮ > **Bookmarks** and select the desired bookmark.

History

Tap ⋮ > **Bookmarks** > **History** tab to open a list of recently visited webpages. To clear all of your history, tap 🗑 > **Yes**.

Chrome

Use Chrome to search for information and browse webpages.

- Press ○ and tap ⋯ > **Google** folder > .

NOTE

- This application may not be available depending on your region and service provider.

Viewing webpages

Tap the address field, and then enter a web address or search criteria.

Opening a page

To open a new page, tab ⋮ > **New tab**.

To go to another webpage, tap ⋮ > **Recent tabs** and tap the page to select it.

Settings

The Settings application contains most of the tools for customizing and configuring your phone. All of the settings in the Settings application are described in this section.

To open the Settings application

- Press and tap > .

WIRELESS NETWORKS

< Wi-Fi >

Turns on Wi-Fi to connect to available Wi-Fi networks.

< Bluetooth >

Turns the Bluetooth wireless feature on or off to use Bluetooth.

< Mobile data >

Displays the data usage and mobile data usage limit.

< Call >

This menu allows you to configure various call settings.

Voicemail

Allows you to select your carrier's voicemail service.

Fixed dialing numbers

Allows you to manage and compile a list of numbers that can be called from your phone. You need your PIN2, which is available from your operator. If activated, only numbers in the fixed dial list can be called from your phone.

Call reject

Allows you to set the call decline function.

Decline with message

When you want to decline a call, you can send a quick message using this function. This is useful if you need to decline a call during a meeting.

Answer call

Choose the method to answer a call.

Call forwarding

Allows you to choose when to forward calls.

Auto answer

Set the time before a connected hands-free device automatically answers an incoming call.

Connection vibration

Vibrates your phone when the other party answers the call.

Save unknown numbers

Allows you to add unknown numbers to contacts after a call.

Call barring

Locks incoming, outgoing or international calls.

Call duration

Allows you to view the call duration for various types of calls.

Additional settings

Allows you to change the additional call settings.

< Tethering >

USB tethering

Allows you to share the internet connection with your computer via a USB cable.

Wi-Fi hotspot

You can also use your phone to provide a mobile broadband connection. Create a hotspot and share your connection.

Bluetooth tethering

Allows you to connect to other devices via Bluetooth.

Help

Displays Help information about USB tethering, Wi-Fi hotspot, and Bluetooth tethering.

< More >

Airplane mode

Airplane Mode (flight mode) allows you to use many of your phone's features, such as games, and music, when you are in an area where making or receiving calls or data use is prohibited. When you set your phone to Airplane Mode, it cannot send or receive any calls or access online data.

Mobile networks

This menu allows you to configure various mobile network settings.

VPN

From your phone, you can add, set up, and manage virtual private networks (VPNs) that allow you to connect and access resources inside a secured local network, such as your corporate network.

DEVICE

< Sound & notification >

Sound profile

Allows you to set your phone's sound profile. Choose from **Sound**, **Vibrate only**.

Volume

Adjust the phone's volume settings to suit your needs and environment.

Ringtone

Allows you to set the ringtones for calls. You can also add a ringtone by tapping + in the upper-right corner of the screen.

Sound with vibration

Checkmark to set the phone to vibrate in addition to the ringtone when you receive calls.

Vibration type

Allows you to choose the type of vibration.

Interruptions

Allows you to set a schedule when to prevent interruptions from notifications. You can set to allow certain features to interrupt when Priority only is set.

Apps

Allows you to prevent apps from displaying notifications or set apps to show notifications with priority when Do not disturb is set to Priority only.

Notification LED

Tap the switch to toggle it On or Off. On activates the LED light for the notifications you select, in the colour you set for each.

Notification sound

Allows you to set the notification sound. You can also add a notification sound by tapping + in the upper-right corner of the screen.

Vibrate on tap

Checkmark to vibrate when tapping the Home touch buttons and during other UI interactions.

Sound effects

Tap to set the dial pad touch sounds, key and touch sounds, screen unlock sound and folder sound.

Message/call voice notifications

Allows the device to read out the incoming call and the message event automatically.

< Display >

Font type

Select the desired font type.

Font size

Select the desired font size.

Brightness

Adjust the screen brightness by using the slider.

Auto-rotate screen

Set to switch orientation automatically when you rotate the phone.

Screen timeout

Set the time delay before the screen automatically turns off.

Daydream

Select the screen saver to display when the phone is sleeping while docked and/or charging.

Keypad light

Checkmark to turn on Keypad light and set the Keypad light duration.

Motion sensor calibration

Allows you to improve the accuracy of the tilt and speed of the sensor.

< Home screen >

Select Home

Select the desired Home theme. Choose from **Home** (standard Android layout) or **EasyHome** (simplified version for users less familiar with Android navigation).

Wallpaper

Sets the wallpaper to use on your Home screen.

Screen swipe effect

Choose the desired type of effect to display when you swipe from one Home screen canvas to the next.

Allow Home screen looping

Checkmark to allow continuous Home screen scrolling (loop back to first screen after last screen).

Help

Displays help information for the Home screen.

< Lock screen >

Select screen lock

Set a screen lock type to secure your phone.

< Storage >

You can monitor the used and available internal memory in the device.

< Battery & power saving >

Battery usage

View battery usage.

Battery percentage on status bar

Checkmark to display the battery level percentage on the Status Bar next to the Battery icon.

Battery saver

Tap the Battery Saver switch to toggle it on or off. Sets the battery charge percent level that automatically turns on Battery Saver. Chooser from **Immediately**, **5% battery**, and **15% battery**.

Help

Displays battery saving items information.

Smart power saver

Tap the switch to toggle it on or off. Save the battery by reducing unnecessary actions when the screen is off.

< Apps >

Allows you to view details about the apps installed on your phone, manage their data, and force them to stop.

< Default message app >

This menu allows you to choose what messaging app to use as your default messaging app.

< App on flip close >

This menu allows you to choose how current app is acted when the flip is closed.

PERSONAL

< Location >

Turn on location service, your phone determines your approximate location using Wi-Fi and mobile networks. When you select this option, you're asked whether you consent to allowing Google to use your location when providing these services.

Mode

Sets the how your current location information is determined.

Camera

Checkmark to tag photos or videos with their locations.

Google Location History

Allows you to choose your location information settings as accessed by Google and its products.

< Security >

Use the Security menu to configure how to help secure your phone and its data.

Encrypt phone

Allows you to encrypt data on the phone for security. You will be required to enter a PIN or password to decrypt your phone each time you power it on.

Encrypt SD card storage

Encrypt SD card storage and keep data unavailable for other devices.

Set up SIM card lock

Sets the PIN to lock your SIM card and allows you to change the PIN.

Password typing visible

Checkmark to briefly show each character of passwords as you enter them so that you can see what you enter.

Phone administrators

View or deactivate phone administrators.

Unknown sources

Allow installation of non-Play Store applications.

Verify apps

Disallow or warn before installation of apps that may cause harm.

Storage type

Hardware-backed.

Certificate management

- **Trusted credentials** – Checkmark to allow applications to access your phone's encrypted store of secure certificates and related passwords and other credentials. You use credential storage to establish some types of VPN and Wi-Fi connections. If you have not set a password for the secure credential storage, this setting is dimmed.
- **Install from storage** – Tap to install a secure certificate.
- **Clear credentials** – Deletes all secure certificates and related credentials and erases the secure storage's own password.

Trust agents

Select apps to use without unlocking screen.

Screen pin

You can enable your device to only show a certain app's screen using screen pin.

App usage access

Allows you to view usage information of apps on your phone.

< Accounts & sync >

Use the Accounts & sync settings menu to add, remove, and manage your Google and other supported accounts. You also use these settings to control how and whether all applications send, receive, and sync data on their own schedules and whether all applications can synchronize user data automatically.

Gmail™, Calendar, and other applications may also have their own settings to control how they synchronize data; see the sections on those applications for details. Tap **Add account** to add new account.

< Language & input >

Select the language for the text on your phone and for configuring the on-screen keyboard, including words that you've added to its dictionary.

Language

Choose a language to use on your phone.

Default

Allows you to select the default keyboard type.

LG Keyboard

Tap the Settings icon to change the LG Keyboard settings.

Google voice typing

Checkmark to select Google voice typing to enter data. Tap the Settings icon to change the Google voice settings.

Voice Search

Tap to configure the Voice Search settings.

Text-to-speech output

Tap to set the preferred engine or general settings for text-to-speech output.

Pointer speed

Adjust the pointer speed.

Reverse buttons

Reverse the mouse buttons to use primary button on right.

< Backup & reset >

Change the settings for managing your settings and data.

LG Backup

Backs up all information on the device and restores it in the event of data loss or replacement.

Back up my data

Back up app data, Wi-Fi passwords, and other settings to Google servers.

Backup account

Displays the account that is currently being used to back up information.

Automatic restore

When reinstalling an app, restore backed up settings and data.

Factory data reset

Reset your settings to the factory default values and delete all your data. If you reset the phone this way, you are prompted to re-enter the same information as when you first started Android.

SYSTEM

< QuickButton >

Select apps you wish to get quick access to using **QuickButton Key**.

< Date & time >

Set your preferences for how the date and time is displayed.

< Accessibility >

Use the Accessibility settings to configure accessibility plug-ins you have installed on your phone.

Vision

- **TalkBack** – Allows you to set up the TalkBack function which assists people with impaired vision by providing verbal feedback.
- **Message/call voice notifications** – Tap 

to toggle it On or Off. On allows you to hear automatic spoken alerts for incoming calls and messages.
- **Screen shade** – Checkmark to set the screen to a darker contrast.
- **Font size** – Sets the font size.
- **Touch zoom** – Allows you to zoom in and out by triple-tapping the screen.
- **Screen colour inversion** – Checkmark to invert the colours of the screen and content.
- **Screen colour adjustment** – Allows you to invert the colours of screen and content.
- **Screen colour filter** – Allows you to change the colours of screen and content.

Hearing

- **Captions** – Allows you to customise caption settings for those with hearing impairments.
- **Notification LED** – Allows you to activate the LED light for incoming calls and notifications.
- **Turn off all sounds** – Checkmark to turn off all device sounds.
- **Audio type** – Sets the audio type.

- **Sound balance** – Sets the audio route. Move the slider on the slide bar to set it.

Motor & cognition

- **Touch feedback time** – Sets the touch feedback time.
- **Touch assistant** – Show a touch board with easy access to common actions.
- **Screen timeout** – Sets the amount of time before the backlight turns off automatically.
- **Touch control areas** – Allows you to select an area of the screen to limit touch activation to just that area of the screen.

Accessibility features shortcut

Allow you to access selected features quickly when triple-tapping the Home button.

Auto-rotate screen

Checkmark to allow the phone to rotate the screen depending on the physical phone orientation (portrait or landscape).

Switch Access

Allows you to interact with your device using one or more switches that work like keyboard keys. This menu can be helpful for users with mobility limitations that prevent them from interacting directly with the your device.

< About phone >

View legal information, check phone status and software versions, and perform a software update.

Phone software update

Phone software update

LG Mobile phone software update from the Internet

For more information about using this function, please visit http://www.lg.com/common/index.jsp → select your country and language.

This feature allows you to conveniently update the firmware on your phone to a newer version from the Internet without needing to visit a service centre. This feature will only be available if and when LG makes a newer firmware version available for your device.

Because the mobile phone firmware update requires the user's full attention for the duration of the update process, please make sure you check all instructions and notes that appear at each step before proceeding. Please note that removing the USB data cable during the upgrade may seriously damage your mobile phone.

NOTE

- LG reserves the right to make firmware updates available only for selected models at its own discretion and does not guarantee the availability of the newer version of the firmware for all handset models.

LG Mobile Phone software update via Over-the-Air (OTA)

This feature allows you to conveniently update your phone's software to a newer version via OTA, without connecting using a USB data cable. This feature will only be available if and when LG makes a newer firmware version available for your device.

You should first check the software version on your mobile phone: **Settings** > **About phone** > **Update Center** > **Software Update** > **Check now for update**.

NOTE

- Your personal data from internal phone storage—including information about your Google account and any other accounts, your system/application data and settings, any downloaded applications and your DRM licence—might be lost in the process of updating your phone's software. Therefore, LG recommends that you backup your personal data before updating your phone's software. LG does not take responsibility for any loss of personal data.
- This feature depends on your network service provider, region and country.

About this user guide

About this user guide

- Before using your device, please carefully read this guide. This ensures that you use your phone safely and correctly.
- Some of the images and screenshots provided in this guide may appear differently on your phone.
- Your content may differ from the final product or from software supplied by service providers or carriers. This content is subject to change without prior notice. For the latest version of this guide, please visit the LG website at www.lg-mobile.co.il.
- Your phone's applications and their functions may vary by country, region or hardware specifications. LG cannot be held liable for any performance issues resulting from the use of applications developed by providers other than LG.
- LG cannot be held liable for performance or incompatibility issues resulting from edited registry settings or modified operating system software. Any attempt to customise your operating system may cause the device or its applications to work incorrectly.
- Software, audio, wallpaper, images, and other media supplied with your device are licensed for limited use. If you extract and use these materials for commercial or other purposes, you may be infringing copyright laws. As a user, you are fully are entirely responsible for the illegal use of media.
- Additional charges may apply for data services, such as messaging, uploading,downloading, auto-syncing and location services. To avoid additional charges, select a data plan suitable to your needs. Contact your service provider to obtain additional details.

Trademarks

- Copyright ©2015 LG Electronics, Inc. All rights reserved. LG and the LG logo are registered trademarks of LG Group and its related entities. All other trademarks are the property of their respective owners.
- Google™, Google Maps™, Gmail™, YouTube™, Hangouts™ and Play Store™ are trademarks of Google, Inc.
- Bluetooth® is a registered trademark of Bluetooth SIG, Inc. worldwide.
- Wi-Fi® and the Wi-Fi logo are registered trademarks of the Wi-Fi Alliance.
- All other trademarks and copyrights are the property of their respective owners.

Accessories

These accessories are available for use with the your phone. **(Items described below may be optional.)**

- Travel adaptor
- Quick Start Guide
- Stereo headset
- USB cable
- Battery

NOTE

- Always use genuine LG accessories. The supplied items are designed only for this device and may not be compatible with other devices.
- The items supplied with the device and any available accessories may vary depending on the region or service provider.

Troubleshooting

This chapter lists some problems you might encounter when using your phone. Some problems require you to call your service provider, but most are easy to fix yourself.

Message	Possible causes	Possible corrective measures
SIM or USIM card error	There is no SIM or USIM card in the phone or it is inserted incorrectly.	Make sure that the SIM or USIM card is correctly inserted.
No network connection/ Dropped network	Signal is weak or you are outside the carrier network.	Move toward a window or into an open area. Check the network operator coverage map.
	Operator applied new services.	Check whether the SIM or USIM card is more than 6~12 months old. If so, change your SIM or USIM card at your network provider's nearest branch. Contact your service provider.
Codes do not match	To change a security code, must need to confirm the new code by re-entering it.	If you forget the code, contact your service provider.
	The two codes you entered do not match.	

Message	Possible causes	Possible corrective measures
No applications can be set	Not supported by service provider or registration required.	Contact your service provider.
Calls not available	Dialing error	New network not authorised.
	New SIM or USIM card inserted.	Check for new restrictions.
	Pre-paid charge limit reached.	Contact service provider or reset limit with PIN2.
Phone cannot be turned on	On/Off key pressed too briefly.	Press the On/Off key for at least two seconds.
	Battery is not charged.	Charge battery. Check the charging indicator on the display.
Charging error	Battery is not charged.	Charge battery.
	Outside temperature is too hot or cold.	Make sure phone is charging at a normal temperature.
	Contact problem	Check the charger and its connection to the phone.
	No voltage	Plug the charger into a different outlet.
	Charger defective	Replace the charger.
	Wrong charger	Use only original LG accessories.

Message	Possible causes	Possible corrective measures
Number not allowed.	The Fixed dialling number function is on.	Check the Settings menu and turn the function off.
Impossible to receive/ send SMS & photos	Memory full	Delete some messages from your phone.
Files do not open	Unsupported file format	Check the supported file formats.
The screen does not turn on when I receive a call.	Proximity sensor problem	If you use a protection tape or case, make sure it has not covered the area around the proximity sensor. Make sure that the area around the proximity sensor is clean.
No sound	Vibration mode	Check the settings status in the sound menu to make sure you are not in vibration or no interruptions mode.
Hangs up or freezes	Intermittent software problem	Try to perform a software update through the website.

FAQ

Category	Question	Answer
Bluetooth Devices	What functions are available via Bluetooth?	You can connect a Bluetooth audio device, such as a Stereo/Mono headset or car kit.
Contacts Backup	How can I back up Contacts?	Contacts data can be synchronised between your phone and your Google account.
Synchronisation	Is it possible to set up one-way sync with Gmail?	Only two-way synchronisation is available.
Gmail Log-In	Do I have to log into Gmail whenever I want to access Gmail?	Once you have logged into Gmail, there is no need to log into Gmail again.
Google Account	Is it possible to filter emails?	No, the phone does not support email filtering.
Ringtone	Is there a file size limit for using MP3 files as ringtones?	There is no file size limit.
Message Time	My phone does not display the time of receipt for messages older than 24 hrs. How can I view the time?	Open the conversation and touch and hold the desired message. Then tap **Details**.
Navigation	Is it possible to install another navigation application on my phone?	Any application that is available at Play Store™ and is compatible with the hardware can be installed and used.

Category	Question	Answer
Wait and Pause	Is it possible to save a contact with Wait and Pause in the numbers?	If you transferred a contact using the Wait & Pause functions saved into the number, you cannot use those features. You must save each number again. How to save with Wait and Pause: 1. Press ○ and dial the number. 2. Tap ⋮ > **Add 2-sec pause** or **Add wait**.
Security	What are the phone's security functions?	You can set the phone to require a PIN or a Password to be entered before the phone can be accessed or used.
Memory	Will I know when my memory is full?	Yes, you will receive a notification.
Language Support	Is it possible to change my phone's language?	The phone has multilingual capabilities. To change the language: 1. Press ○ and tap ⋯ > ⚙ > **Language & input** > **Language**. 2. Tap the desired language.
VPN	How do I set up a VPN?	VPN access configuration is different for each company. To configure VPN access on your phone, you must obtain the details from your company's network administrator.
Screen time out	My screen turns off after only 15 seconds. How can I change the amount of time for the backlight to turn off?	1. Press ○ and tap ⋯ > ⚙ > **Display** > **Screen timeout**. 2. Tap the preferred screen backlight timeout time.

Category	Question	Answer
Wi-Fi & mobile network	When the Wi-Fi and mobile networks are both available, which service does my phone use?	When using data, your phone may default to the Wi-Fi connection (if Wi-Fi connectivity on your phone is set to On). However, there is no notification when your phone switches from one to the other. To know which data connection is being used, view the mobile network or Wi-Fi icon at the top of your screen.
Home screen	Is it possible to remove an application from the Home screen?	Yes. Just touch and hold the icon until the trash can icon appears at the top and centre of the screen. Then, without lifting your finger, drag the icon to the trash can.
Application	I downloaded an application and it causes a lot of errors. How do I remove it?	1. Press ○ and tap ⋯ > ⚙ > **Apps** > **DOWNLOADED**. 2. Tap the application, then tap **Uninstall**.
Charger	Is it possible to charge my phone using a USB data cable without installing the necessary USB driver?	Yes, the phone is charged through the USB cable regardless of whether the necessary drivers are installed.
Alarm	Can I use music files for my alarm?	Yes. After saving a music file as a ringtone, you can use it as an alarm. 1. Touch and hold a song in a library list. In the menu that opens, tap **Set as ringtone** > **Phone ringtone** or **Caller ringtones**. 2. On the Alarm Clock Setting screen, select the song as a ringtone.

Category	Question	Answer
Alarm	Will my alarm be audible or will it go off if the phone is turned off?	No, this is not supported.
Alarm	If my ringer volume is set to vibrate, will I hear my alarm?	Your alarm is programmed to be audible even in these scenarios.



CE0168