עברית

ENGLISH



USER GUIDE

LG-M250Y

www.lg-mobile.co.il

MFL69871001 (1.0)

אודות מדריך למשתמש זה

תודה שבחרת מוצר זה של LG. קרא בעיון מדריך למשתמש זה לפני השימוש במכשיר בפעם הראשונה, כדי להבטיח שימוש בטוח והולם.

- השתמש תמיד באביזרים מקוריים של LG. הפריטים שסופקו מיועדים למכשיר זה בלבד וייתכן שהם לא תואמים למכשירים אחרים.
- מכשיר זה אינו מתאים לאנשים לקויי ראייה מפני שהמקלדת שלו נמצאת במסך המגע.
- התיאורים מבוססים על הגדרות ברירת המחדל של המכשיר.
- יישומי ברירת המחדל במכשיר כפופים לעדכונים, וייתכן שהתמיכה ביישומים אלה תופסק ללא כל הודעה מראש. אם יש לך שאלות כלשהן על יישום שסופק עם המכשיר, פנה למרכז השירות של LG. עבור יישומים שהותקנו על-ידי המשתמש, פנה לספק השירות הרלוונטי.
- שינוי מערכת ההפעלה של המכשיר או התקנת תוכנה ממקורות לא רשמיים עלול לגרום נזק למכשיר ולגרום להרס נתונים או לאובדן נתונים. פעולות אלה יפרו את הסכם הרישיון של LG ויבטלו את האחריות שלך.
- תכנים ואיורים מסוימים עשויים להיראות שונים מאלה שבמכשיר, בהתאם לאזור, לספק השירות, לגרסת התוכנה ולגרסת מערכת ההפעלה, והם כפופים לשינוי ללא הודעה מוקדמת.
- תוכנות, שמע, טפטים, תמונות ופריטי מדיה אחרים שסופקו יחד עם המכשיר שלך מורשים לשימוש מוגבל. אם תחלץ חומר זה ותשתמש בו למטרות מסחריות או אחרות, אתה עלול להפר חוקי זכויות יוצרים. כמשתמש, אתה נושא באחריות מלאה לשימוש לא חוקי במדיה.
- ייתכן שיחולו חיובים נוספים תמורת שירותי נתונים, כגון שליחת הודעות, העלאה, הורדה, סנכרון אוטומטי ושירותי מיקום. כדי למנוע חיובים נוספים, בחר תוכנית נתונים מתאימה לצרכיך. פנה אל ספק השירות לקבלת פרטים נוספים.

הודעות מנחות



אזהרה: מצבים שעלולים לגרום לפציעה של המשתמש ושל גורמי צד שלישי.



זהירות: מצבים שעלולים לגרום לפציעה קלה או לנזק למכשיר.



הערה: הערות או מידע נוסף.

תוכן העניינים

5 הנחיות לשימוש בטוח ויעיל

01

תכונות הניתנות להתאמה אישית

13 מצלמה בזווית רחבה
14 התכונה 'ריבוי משימות'
16 שיתוף מהיר

02

פונקציות בסיסיות

18 רכיבי מוצרים ואביזרים
19 סקירה כללית של החלקים
21 הדלקה או כיבוי
22 התקנת כרטיס ה-SIM והסוללה
24 הכנסת כרטיס הזיכרון
25 הוצאת כרטיס הזיכרון
25 טעינת הסוללה
27 מסך המגע
30 מסך ראשי
37 נעילת מסך
40 הצפנת כרטיס זיכרון
41 יצירת צילומי מסך
42 הזנת טקסט
47 נא לא להפריע

03

יישומים שימושיים

49 התקנה והסרת התקנה של יישומים
50 היישומים שהוסרו
51 טלפון
55 הודעות
56 מצלמה
63 גלריה
66 נגן מוסיקה
67 דוא"ל
68 לוח שנה
70 QuickMemo+
72 מחשבון
73 שעון
74 הורדות
74 מנהל הקבצים
74 רדיו FM
75 הקלטה קולית
75 אנשי קשר
77 LG SmartWorld
78 משימות
78 LG Backup
79 Evernote
79 פייסבוק
79 Instagram
79 Chrome
80 יישומי Google

04

הגדרות טלפון

83 הגדרות
83 רשתות
92 צליל והתראה
93 תצוגה
94 כללי

05

נספח

103 הגדרות השפה של LG
103 LG Bridge
104 עדכון תוכנת הטלפון
106 שאלות נפוצות
109 מדריך למניעת גניבה
110 מידע נוסף

הנחיות לשימוש בטוח ויעיל

הקפד לקרוא הנחיות פשוטות אלה. אי עמידה בהנחיות אלו עלולה להיות מסוכנת או בלתי חוקית.

למקרה של תקלה, המכשיר שלך מכיל כלי תוכנה שיאסוף יומן תקלות. כלי זה אוסף רק נתונים ספציפיים לתקלה, כגון עוצמת אות, מיקום מזהה התא בעת ניתוק פתאומי של השיחה ויישומים שנטענו. היומן משמש רק לסיוע בזיהוי הגורם לתקלה. יומנים אלה מוצפנים, ורק מרכז תיקונים מוסמך של LG יוכל לגשת אליהם במקרה שתצטרך למסור את המכשיר לתיקון.

חשיפה לאנרגיית תדר רדיו

מידע על חשיפה לגלי רדיו ושיעור ספיגה סגולית (SAR).

מכשיר זה תוכנן לעמוד בדרישות הבטיחות הרלוונטיות לחשיפה לגלי רדיו. דרישות אלו מבוססות על קווים מנחים מדעיים, ואלה כוללים שולי בטיחות המיועדים להבטיח את בטיחותם של כל בני האדם, בלא קשר לגילם או למצב בריאותם.

- הנחיות החשיפה לגלי רדיו משתמשות ביחידת מידה הנקראת "שיעור ספיגה סגולית" (SAR). בדיקות SAR מבוצעות באמצעות שיטות מתוקננות, כאשר המכשיר משדר ברמת העוצמה המרבית המאושרת עבורו בכל תחומי התדרים שבשימוש.
- אף כי עשויים להיות הבדלים בין רמות ה-SAR של דגמי מכשירים שונים של LG, כולם מתוכננים לעמוד בהנחיות המתאימות של חשיפה לגלי רדיו.
- מגבלת ה-SAR המומלצת על-ידי הוועדה הבין-לאומית להגנה מפני קרינה בלתי מיינת (ICNIRP) היא ממוצע של 2 ואט/ק"ג על כל 10 גר' של רקמה.
- ערך ה-SAR הגבוה ביותר עבור דגם זה שנמדד לשימוש באוזן הוא 0.541 ואט/ק"ג (10 גר'), וכאשר הוא נישא על הגוף, ערך זה עומד על 1.310 ואט/ק"ג (10 גר').

- מכשיר זה עומד בהנחיות החשיפה ל-RF כשמשתמשים בו בתנוחת השימוש הרגילה ליד האוזן או כשהוא ממוקם לפחות 5 מ"מ מהגוף. כאשר נעשה שימוש בנרתיק נשיאה או בתפס או מנשא לחגורה, אסור שתהיה בהם מתכת כלשהי, והמרחק בין המכשיר לגוף צריך להיות לפחות 5 מ"מ. כדי לשדר קובצי נתונים או הודעות, מכשיר זה מחייב חיבור איכותי לרשת. במקרים מסוימים עלול שידור קבצי נתונים או הודעות להיות מושהה עד שחיבור כזה יהיה זמין. הקפד על שמירת הוראות המרחק המינימלי המוזכרות לעיל עד לסיום השידור.

טיפול במוצר ותחזוקה

- הקפד להשתמש בסוללות, במטענים ובאביזרים מקוריים של LG, המאושרים לשימוש בדגם מכשיר ספציפי זה. שימוש בסוגים אחרים עלול לבטל את תוקף האישור או האחריות החלים על המכשיר ועלול להיות מסוכן.
- חלק מהתוכן והאיורים עשויים להיראות שונה מהמכשיר שברשותך, והם כפופים לשינוי ללא הודעה מראש.
- אין לפרק יחידה זו. כאשר נדרש תיקון, פנה לטכנאי שירות מוסמך.
- תיקונים במסגרת האחריות, לפי שיקול דעתה של LG, עשויים לכלול חלקים או לוחות חלופיים, חדשים או מחודשים, ובלבד שהם מצוידים בפונקציונליות זהה לזו של החלקים המוחלפים.
- אין לקרב את המכשיר למכשירים חשמליים כגון טלוויזיות, מכשירי רדיו ומחשבים אישיים.
- יש לשמור את היחידה הרחק ממקורות חום כדוגמת רדיאטורים או תנורי בישול.
- אין להפיל את היחידה.
- אין לאפשר זעזוע מכני או חבטה.
- יש לכבות את המכשיר בכל מקום שבו נדרש הדבר על-ידי תקנות מיוחדות. לדוגמה, אין להשתמש במכשיר בבתי חולים, שכן הפעלתו עלולה להשפיע על פעולת מכשור רפואי רגיש.

- אין לאחוז במכשיר בידיים רטובות בזמן טעינתו. אחיזה במצב כזה עלולה לגרום להתחשמלות ולהסב נזק כבד למכשיר.
- אין לטעון את הטלפון ליד חומר דליק, מכיוון שהמכשיר עלול להתחמם ולעלות באש.
- יש להשתמש במטלית יבשה לניקוי חלקו החיצוני של המכשיר (אין להשתמש בחומרים ממסים כגון בנזן, מדלל או אלכוהול).
- אין לטעון את המכשיר כאשר הוא נמצא על-גבי מצעים או ריפוד.
- יש לטעון את המכשיר באזור מאוורר היטב.
- אין לחשוף יחידה זו לכמות מוגזמת של עשן או אבק.
- אין להחזיק את המכשיר בסמוך לכרטיסי אשראי או כרטיסי נסיעה; הנתונים בפס המגנטי עלולים להיפגם.
- אין להקיש על המסך באמצעות חפצים חדים, שכן הדבר עלול לגרום נזק למכשיר.
- אין לחשוף את המכשיר לנוזלים או ללחות.
- יש לנקוט זהירות בשימוש באביזרים, כמו אוזניות. אין לגעת באנטנה שלא לצורך.
- אם זכוכית המכשיר שבורה או סדוקה, אל תיגע בה או תנסה להסיר אותה ואל תשתמש במכשיר. האחריות אינה מכסה נזקים שנגרמו לתצוגת הזכוכית כתוצאה מפגיעה ושימוש לרעה.
- המכשיר שלך הוא מכשיר אלקטרוני המייצר חום במהלך הפעלה רגילה. בהיעדר אוורור הולם, מגע ישיר וממושך מאוד של העור עלול לגרום לאי-נוחות או לכוויות קלות. לפיכך, יש לנקוט זהירות בהחזקת המכשיר במהלך ההפעלה או מיד אחריה.
- אם המכשיר נרטב, נתק אותו מיד והנח לו להתייבש לגמרי. אל תנסה להאיץ את תהליך הייבוש בעזרת מקור חום חיצוני, כמו תנור, מיקרוגל או מייבש שיער.
- הנוזלים שחדרו למכשיר ישנו את צבע תווית המוצר שבתוך המכשיר. כתב האחריות אינו מכסדה נזק למכשיר כתוצאה מחשיפה לנוזלים.

הפעלה יעילה של המכשיר

מכשירים אלקטרוניים

כל המכשירים עלולים לספוג הפרעות שישפיעו לרעה על ביצועיהם.

- אין להשתמש בטלפון הנייד בסמוך לציוד רפואי ללא קבלת רשות. בדוק עם הרופא אם תפעול הטלפון עלול להפריע לתפעולו של ההתקן הרפואי.
- יצרנים של קוצבי לב ממליצים להשאיר רווח של 15 ס"מ בין קוצב הלב לבין התקנים אחרים כדי למנוע הפרעה אפשרית לקוצב הלב.
- התקן זה עשוי להפיק אור חזק או מהבהב.
- מכשירים עלולים להפריע לעזרי שמיעה מסוימים.
- הפרעה משנית עלולה להשפיע על מכשירי טלוויזיה, מכשירי רדיו, מחשבים וכולי.
- השתמש במכשיר שלך בטמפרטורות שבין 0 ºC ו-40 ºC, אם ניתן. חשיפת המכשיר לטמפרטורות נמוכות או גבוהות באופן קיצוני עלולה לגרום נזק, תקלות ואפילו פיצוץ.

בטיחות בדרכים

בדוק את החוקים והתקנות לגבי שימוש במכשירים באזורים שבהם אתה נוהג.

- אין להחזיק את המכשיר ביד בזמן נהיגה.
- יש להפנות את מלוא תשומת הלב לנהיגה.
- רד לשול הדרך וחנה לפני ביצוע שיחה או מענה לשיחה, בהתאם לתנאי הדרך.
- אנרגיית תדר רדיו עשויה להשפיע על מערכות אלקטרוניות מסוימות בכלי רכב, כדוגמת מערכות סטריאו וציוד בטיחות.
- אם המכונית מצוידת בכרית אוויר מתנפחת, אין לחסום אותה על-ידי התקנה של ציוד אלחוטי נישא. הדבר עלול לגרום לכשל של הכרית או לפציעה חמורה עקב ביצועים לא נאותים שלה.
- אם אתה מאזין למוסיקה בעת תנועה, ודא שהעוצמה היא ברמה סבירה, כך שתמשיך להיות מודע לסביבתך. הדבר חשוב במיוחד בקרבת כבישים.

מנעו נזק לשמיעתכם



כדי למנוע נזק אפשרי לשמיעה, אל תאזין בעוצמות קול גבוהות לאורך זמן.

חשיפה לעוצמות קול גבוהות במשך פרקי זמן ארוכים עלולה להזיק לשמיעה. לכן אנו ממליצים שלא תדליק או תכבה את המכשיר סמוך לאוזנך. מומלץ גם להגדיר את עוצמת הקול של המוסיקה והשיחה לרמה סבירה.

- כאשר אתה משתמש באוזניות, הנמך את עוצמת הקול אם אינך מצליח לשמוע את האנשים שבסביבתך מדברים, או אם האדם שלצדך יכול לשמוע את מה שאתה שומע באוזניות.

- עוצמת קול מופרזת מאוזניות פנימיות ואוזניות חיצוניות עלולה לגרום לאובדן שמיעה.

חלקי זכוכית

חלקים מסוימים של המכשיר עשויים מזכוכית. זכוכית זו עלולה להישבר אם המכשיר ייפול על משטח קשה או יקבל מכה חזקה. אם הזכוכית נשברת, אל תנסה לגעת בה או להסיר אותה. יש להפסיק להשתמש במכשיר עד להחלפת הזכוכית על-ידי ספק שירות מורשה.

סביבה שבה מבוצעות עבודות עם חומרי נפץ

אל תשתמש במכשיר באזורים שבהם מתבצעות פעולות פיצוץ. שים לב להגבלות ועמוד בכל התקנות או הכללים.

סביבה שבה קיימת סבירות לפיצוץ

- אין להשתמש במכשיר באזורי תדלוק.
- אין להשתמש בו בסמוך לדלק או לכימיקלים.
- אין להוביל או לאחסן גז דליק, נוזלים דליקים או חומרי נפץ בתא הרכב המכיל את המכשיר או את אביזריו.

כלי טיס

התקנים אלחוטיים עלולים לגרום להפרעה במטוס.

- יש לכבות את המכשיר לפני העלייה למטוס.
- אין להשתמש בו על הקרקע ללא קבלת רשות מאנשי הצוות.

ילדים

יש לשמור על המכשיר במקום בטוח, מחוץ להישג ידם של ילדים קטנים. המכשיר כולל חלקים זעירים העלולים להוות סכנת חנק אם ינותקו מהטלפון.

שיחות חירום

רק רשתות סלולריות מסוימות מאפשרות לבצע שיחות חירום. לפיכך, בשום מקרה אין לסמוך רק על המכשיר לביצוע שיחות חירום. בדוק את הנושא עם חברת הסלולר המקומית.

מידע לגבי הסוללה והטיפול בה

- אין צורך לפרוק את הסוללה במלואה לפני טעינתה מחדש. בניגוד למערכות סוללה אחרות, אין השפעת זיכרון שעלולה להשפיע על ביצועי הסוללה.
- יש להשתמש אך ורק בסוללות ובמטענים של LG. מטעני LG מיועדים למרב את חיי הסוללה.
- אין לפרק או לקצר את הסוללה.
- יש לשמור על ניקיון מגעי המתכת של הסוללה.
- יש להחליף את הסוללה כאשר היא אינה מפיקה עוד רמת ביצועים סבירה. ניתן לטעון מחדש את מארז הסוללה מאות פעמים לפני שיהיה צורך להחליפו.
- כדי למרב את שמישות הסוללה, טענו אותה מחדש אם לא הייתה בשימוש במשך זמן רב.
- אין לחשוף את מטען הסוללה לאור שמש ישיר או להשתמש בו בתנאי לחות גבוהה, כמו חדר אמבטיה.
- אין להשאיר את הסוללה במקומות חמים או קרים, שכן הדבר עלול לפגום בביצועיה.
- סכנת התפוצצות אם הסוללה הוחלפה בסוג סוללה שאינו מתאים. השלך סוללות משומשות בהתאם להוראות.

- אם עליך להחליף סוללה, קח אותה למרכז השירות המורשה הקרוב של LG Electronics או לספק לצורך קבלת סיוע.
- יש לנתק תמיד את המטען מהשקע לאחר שהמכשיר נטען במלואו כדי למנוע בזבוז מיותר של חשמל מצד המטען.
- אורך חיי הסוללה בפועל תלוי בתצורת הרשת, בהגדרות המוצר, באופי השימוש, בתנאי הסוללה ובתנאים הסביבתיים.
- הקפד שלא ייווצר מגע בין הסוללה לבין פריטים חדים כגון שיניים או ציפורניים של בעל חיים. מגע כזה עלול לגרום לשריפה.

אבטחת הפרטים האישיים

- הקפד להגן על הפרטים האישיים שלך כדי למנוע דליפת נתונים או שימוש לרעה במידע רגיש.
- הקפד תמיד לגבות נתונים חשובים בזמן השימוש במכשיר. LG אינה נושאת באחריות לאובדן נתונים כלשהו.
- בעת השלכת המכשיר, הקפד לגבות את כל הנתונים ולאפס אותו כדי למנוע שימוש לרעה במידע רגיש.
- קרא בעיון את מסך ההרשאות במהלך הורדת יישומים.
- נקוט משנה זהירות כאשר אתה משתמש ביישומים שיש להם גישה לפונקציות מרובות או לפרטים האישיים שלך.
- בדוק באופן סדיר את החשבונות האישיים שלך. אם תגלה סימן כלשהו לשימוש לרעה בפרטים האישיים שלך, בקש מספק השירות למחוק או לשנות את פרטי החשבון שלך.
- אם המכשיר שלך אבד או נגנב, שנה את הסיסמה של החשבון כדי לאבטח את הפרטים האישיים שלך.
- אין להשתמש ביישומים שמקורם אינו ידוע.

01

תכונות הניתנות להתאמה אישית


מצלמה בזווית רחבה

באפשרותך לצלם תמונות או להקליט סרטוני וידאו עם טווח רחב יותר משדה הראייה שלך בפועל על-ידי שימוש בזווית הרחבה שבמצלמה הקדמית.

הפעל את היישום 'מצלמה', ולאחר מכן הקש על / כדי להחליף בין הזווית הרגילה והרחבה.

מצלמה קדמית

סמל זווית רגילה



סמל זווית רחבה



• לפרטים, ראה *התחלת המצלמה*.

התכונה 'ריבוי משימות'


ריבוי-חלונות

ניתן להשתמש בשני יישומים במקביל על-ידי חלוקת המסך לחלונות מרובים.

בזמן השימוש ביישום, הקש הקשה ממושכת על ▢ בלחצני התצוגה ולאחר מכן בחר יישום מרשימת היישומים שהיו בשימוש לאחרונה.

- ניתן להשתמש בשני יישומים שמוצקים במסך הראשי בו-זמנית.
- כדי להפסיק להשתמש בתכונת ריבוי-חלונות, הקש הקשה ממושכת על ▣.





- תוכל להשתמש בתכונה זו ביישום שתומך בתכונת ריבוי-חלונות.
- תכונת ריבוי-חלונות אינה נתמכת על-ידי יישומים מסוימים, כולל יישומים שהורדת.

מסך סקירה כללית

מסך 'סקירה כללית' מספק תצוגה מקדימה של היישומים שהיו בשימוש לאחרונה.

כדי להציג את רשימת היישומים שהיו בשימוש לאחרונה, הקש על ☐ במסך הראשי ולאחר מכן הקש על היישום המוצג.

- הקש הקשה ממושכת על יישום וגרור אותו לחלק העליון של המסך כדי להפעיל את היישום עם תכונת ריבוי-חלונות. ניתן גם להקיש על ⊟ בראש כל אחד מהיישומים.


שיתוף מהיר

תוכל לשתף תמונה או סרטון וידאו עם היישום הרצוי מיד לאחר הצילום.

1 הקש על ◯ > , ולאחר מכן צלם תמונה או הקלט סרטון וידאו.

2 הקש על סמל היישום שמופיע במסך כדי לשתף אותו באמצעות יישום זה.

באפשרותך גם להחליק את הסמל לכיוון ההפוך כדי לראות באילו יישומים אחרים תוכל להשתמש כדי לשתף את התמונות וסרטוני הווידאו שלך.



• היישום שסמל 'שיתוף מהיר' מציג עשוי להשתנות בהתאם לסוג ולתדירות הגישה שלך אל היישומים המותקנים במכשיר.

02

פונקציות בסיסיות

רכיבי מוצרים ואביזרים


הפריטים הבאים נכללים במכשיר שלך.

- מכשיר
- סוללה
- אוזניות סטריאו
- כבל USB
- מטען
- מדריך להתחלה מהירה

⚠
- הפריטים המתוארים לעיל עשויים להיות אופציונליים.
- הפריטים הכלולים באריזת המכשיר והזמינות של כל אביזר עשויים להשתנות בהתאם לאזור ולספק השירות.
- השתמש תמיד באביזרים מקוריים של LG Electronics. השימוש באביזרים המיוצרים על-ידי יצרנים אחרים עלול להשפיע על ביצועי השיחות של המכשיר או לגרום לתקלות. ייתכן ששירות התיקונים של LG אינו מכסה דבר זה.

- אם אחד מהפריטים הבסיסיים הללו חסרים, פנה למשווק שממנו רכשת את המכשיר.
- כדי לרכוש פריטים בסיסיים נוספים, פנה למרכז שירות לקוחות של LG.
- כדי לרכוש פריטים אופציונליים, פנה למרכז שירות לקוחות של LG לקבלת רשימה של משווקים זמינים.
- פריטים מסוימים בקופסת המוצר כפופים לשינוי ללא הודעה מוקדמת.
- המראה והמפרטים של המכשיר כפופים לשינוי ללא הודעה מוקדמת.
- מפרט המכשיר עשוי להשתנות, בהתאם לאזור ולספק השירות.
- הקפד להשתמש באביזרים מקוריים שסופקו על ידי LG Electronics. השימוש באביזרים של צד שלישי עלול לגרום נזק למכשיר או לגרום לתקלות.

סקירה כללית של החלקים



- חיישן קרבה/תאורת סביבה
  - חיישן קרבה: במהלך שיחה, חיישן הקרבה מכבה את המסך ומשבית את פונקציונליות המגע כאשר המכשיר צמוד לגוף. הוא מפעיל בחזרה את המסך והופך את פונקציונליות המגע לזמינה כאשר המכשיר נמצא מחוץ לטווח ספציפי.
  - חיישן תאורת הסביבה: חיישן תאורת הסביבה מנתח את עוצמת תאורת הסביבה כאשר מצב בקרת בהירות אוטומטית מופעל.
- מקשי עוצמת קול
  - כוונן את עוצמת הקול של רינגטונים, שיחות או התראות.
  - בזמן השימוש במצלמה, לחץ בעדינות על מקש עוצמת הקול כדי לצלם תמונה. כדי לצלם כמה תמונות ברצף, לחץ לחיצה ארוכה על מקש עוצמת הקול.
  - לחץ פעמיים על מקש החלשת עוצמת הקול (-) כדי להפעיל את היישום **מצלמה** כאשר המסך נעול או כבוי. לחץ פעמיים על מקש הגברת עוצמת הקול (+) כדי להפעיל את **Capture+**.
- מקש הפעלה/נעילה
  - לחץ לחיצה קצרה על המקש כאשר ברצונך להפעיל או לכבות את המסך.
  - לחץ לחיצה ארוכה על המקש כאשר ברצונך לבחור אפשרות בקרת צריכת חשמל.

- ייתכן שהגישה לפונקציות מסוימות תהיה מוגבלת, בהתאם למפרטי המכשיר.
- אל תניח חפצים כבדים על המכשיר ואל תשב עליו. אחרת, עלול להיגרם נזק למסך המגע.
- כיסוי מגן למסך או אביזרים אחרים עלולים להפריע לפעולתו של חיישן הקרבה.
- אם המכשיר רטוב או שאתה משתמש בו במקום לח, ייתכן שמסך המגע או הלחצנים לא יפעלו כראוי.

הדלקה או כיבוי

הדלקת המכשיר

כאשר המכשיר כבוי, לחץ לחיצה ארוכה על מקש הפעלה/נעילה.

- כאשר תפעיל את המכשיר בפעם הראשונה, תתבצע קביעת תצורה ראשונית. זמן האתחול הראשון של הטלפון החכם עשוי להיות ארוך מן הרגיל.

כיבוי המכשיר

לחץ לחיצה ארוכה על מקש הפעלה/נעילה ולאחר מכן בחר **כיבוי**.

אפשרויות בקרת צריכת חשמל


לחץ לחיצה ממושכת על מקש הפעלה/נעילה ולאחר מכן בחר אפשרות.

- **כיבוי**: כבה את המכשיר.
- **כיבוי והפעלה מחדש**: הפעל מחדש את המכשיר.
- **הפעל מצב טיסה**: חסום פונקציות הקשורות לטלקומוניקציה, כולל ביצוע שיחות טלפון, העברת הודעות וגלישה באינטרנט. פונקציות אחרות נשארות זמינות.


התקנת כרטיס ה-SIM והסוללה

הכנס את כרטיס ה-SIM שקיבלת מספק שירותי המכשיר וכן את הסוללה הכלולה.


1 כדי להסיר את המכסה האחורי, החזק את המכשיר היטב ביד אחת. ביד השנייה, משוך והסר את המכסה האחורי בעזרת ציפורן האגודל כמוצג באיור.




2 החלק את כרטיס SIM אל תוך החריץ של כרטיס SIM כפי שמוצג באיור. ודא שאזור מגעי הזהב של הכרטיס פונה מטה.



3 הכנס את הסוללה.



4 כדי להחזיר את המכסה למכשיר, ישר את המכסה האחורי מעל תא הסוללה ולחץ אותו מטה עד שייכנס למקומו בנקישה.



- מכשיר זה תומך בכרטיסי Nano SIM בלבד.
- כדי להבטיח ביצועים נטולי בעיות, מומלץ להשתמש בטלפון אם כרטיס SIM מהסוג הנכון. השתמש תמיד בכרטיס SIM מקורי שסופק על-ידי המפעיל.

אמצעי זהירות בעת שימוש בכרטיס ה-SIM

- אל תאבד את כרטיס ה-SIM.

LG אינה נושאת באחריות לנזקים ולבעיות שייגרמו כתוצאה מאובדן או העברה של כרטיס ה- SIM.

- הקפד שלא לגרום נזק לכרטיס ה-SIM כאשר אתה מכניס או מוציא אותו.


הכנסת כרטיס הזיכרון

הכנס את כרטיס הזיכרון למכשיר.

המכשיר יכול לתמוך בכרטיס microSD בנפח של עד 2 TB. בהתאם ליצרן ולסוג של כרטיס הזיכרון, ייתכן שכרטיסי זיכרון מסוימים לא יתאימו למכשיר שלך.

1 הסר את המכסה האחורי.

2 הכנס כרטיס זיכרון כשהמגעים המוזהבים פונים כלפי מטה.



3 החזר את המכסה האחורי למקומו.

- ייתכן שכרטיסי זיכרון מסוימים לא יהיו תואמים באופן מלא למכשיר. שימוש בכרטיס לא תואם עלול לגרום נזק למכשיר או לכרטיס הזיכרון או לשיבוש הנתונים המאוחסנים בו.

- כתיבה ומחיקה של נתונים בתכיפות גבוהה עלולות לקצר את חיי השירות של כרטיס הזיכרון.

הוצאת כרטיס הזיכרון

להוצאת כרטיס הזיכרון באופן בטוח, בטל תחילה את הטעינה שלו.

1 הקש על ◯ > **הגדרות** > **כללי** > **אחסון** > ⏏.


2 הסר את המכסה האחורי ומשוך את כרטיס הזיכרון.

⚠
- אין להוציא את כרטיס הזיכרון בזמן שהמכשיר מעביר נתונים או ניגש למידע. אי הקפדה על כך עלולה לגרום לאובדן או לגרום לשיבוש הנתונים או לנזק לכרטיס הזיכרון או למכשיר עצמו. LG אינה אחראית להפסדים שייגרמו עקב שימוש לרעה או שימוש לא נאות בכרטיסי זיכרון, לרבות אובדן נתונים.

טעינת הסוללה

לפני השימוש במכשיר, טען את הסוללה במלואה.

חבר קצה אחד של כבל הטעינה למטען, הכנס את הקצה השני של המטען ליציאת הכבל ולאחר מכן חבר את המטען לשקע חשמל.



⚠
- הקפד להשתמש בכבל ה-USB שסופק עם המכשיר.
- הקפד להשתמש במטען, בסוללה ובכבל טעינה שאושרו על-ידי LG. טעינת הסוללה באמצעות מטען של צד שלישי עלולה לגרום להתפוצצות הסוללה או לנזק למכשיר.
- שימוש במכשיר כאשר הוא נטען עלול לגרום להתחשמלות. כדי להשתמש במכשיר, הפסק את טעינתו.

- הוצא את המטען משקע החשמל לאחר שהמכשיר נטען במלואו. הדבר ימנע צריכת חשמל מיותרת.
- ניתן לטעון את הסוללה בדרך נוספת, על-ידי חיבור כבל USB בין המכשיר לבין מחשב שולחני או מחשב נייד. טעינה בדרך זו עשויה להמשך יותר זמן מאשר טעינה בדרך הרגילה.
- אין לטעון את הסוללה באמצעות רכזת USB שאינה תומכת במתח הנקוב. הטעינה עלולה להיכשל או להיפסק באופן לא מכוון.

אמצעי זהירות בעת שימוש במכשיר

- בעת החלפת הסוללה, נקוט משנה זהירות כדי להבטיח שחומרים זרים או מים לא יחדרו למכשיר.
- ודא שהחלק הפנימי של ההתקן לא בא במגע עם חפץ מתכתי או מים.
- הקפד להשתמש בכבל ה-USB המסופק עם המוצר, אל תחבר את המכשיר לכבלי USB או למטענים של חברות צד שלישי. האחריות המוגבלת של LG אינה מכסה שימוש באביזרים של צד שלישי.
- אם לא תפעל על-פי ההוראות המפורטות במדריך זה או אם תשתמש במכשיר לא כהלכה, הדבר עשוי לגרום לו נזק.

שימוש יעיל בסוללה

חיי הסוללה עשויים להתקצר אם תשאיר מספר רב של יישומים ופונקציות במצב פעיל לאורך זמן.

כבה את הפעולות ברקע כדי להאריך את חיי הסוללה.

כדי למזער את צריכת הסוללה, פעל בהתאם לעצות הבאות:


- כבה את הפונקציות Bluetooth® או Wi-Fi כאשר אינך משתמש בהן.
- הגדר זמן קצוב קצר ככל האפשר לכיבוי המסך.
- מזער את בהירות המסך.
- הגדר נעילת מסך שתופעל כאשר המכשיר לא בשימוש.
- בדוק את פרטי השימוש בסוללה וסגור את היישומים שהורדת שמרוקנים את הסוללה.

מסך המגע

תוכל ללמוד כיצד לשלוט במכשיר שברשותך על-ידי שימוש במחוות מסך המגע.


הקשה

הקש קלות עם קצה האצבע כדי לבחור או להפעיל יישום או אפשרות.




הקשת הקשה ממושכת

הקש הקשה ממושכת למשך כמה שניות כדי להציג תפריט עם אפשרויות זמינות.




הקשה כפולה

הקש פעמיים במהירות כדי להגדיל או להקטין דף אינטרנט או מפה.




גרירה

גע בפריט, כגון יישום או וידג'ט, ולאחר מכן הזז את האצבע למיקום אחר בתנועה מבוקרת. תוכל להשתמש במחווה זו כדי להזיז פריט.




החלקה


גע במסך באצבעך והזז אותה במהירות מבלי לעצור. באפשרותך להשתמש במחווה זו כדי לגלול ברשימה, בדף אינטרנט, בתמונות, במסכים ועוד.



צביטה או פריסה

צבוט בשתי אצבעות כדי להקטין את התצוגה של תמונה או מפה. כדי להגדיל, פרוס את האצבעות כדי להרחיק זו מזו.





- אין לחשוף את מסך המגע לזעזוע פיזי קיצוני. הדבר עלול לגרום נזק לחיישן המגע.

- תקלה של מסך המגע עלולה להתרחש אם תשתמש במכשיר בקרבת חומרים מגנטיים, מתכתיים או מוליכים.
- אם אתה משתמש במכשיר בתנאי תאורה בוהקת, כגון אור שמש ישיר, ייתכן שהמסך לא יהיה גלוי, בהתאם למיקום שלך. השתמש במכשיר במיקום מוצל או במיקום עם תאורת סביבה שאינה בוהקת מדי אך מוארת במידה שמספיקה לקרוא ספרים.
- אל תפעיל כוח רב מדי בעת לחיצה על המסך.
- הקש בעדינות עם קצה האצבע על האפשרות הרצויה.
- ייתכן שבקרת המגע לא תפעל כראוי אם תקיש על המסך עם הציפורן או כשאתה לובש כפפות.
- ייתכן שבקרת המגע לא תפעל כראוי כאשר המסך לח או רטוב.
- ייתכן שמסך המגע לא יפעל כראוי אם יש על המסך ציפוי מגן או שחיברת אל המכשיר אביזר שנרכש בחנות מקוונת או פיזית שאינה מתמחה.

מסך ראשי

סקירה כללית של המסך הראשי


המסך הראשי הוא נקודת המוצא שממנה ניתן לגשת לפונקציות וליישומים השונים במכשיר. הקש על ○ בכל מסך כדי לעבור היישר אל המסך הראשי.

תוכל לנהל את כל היישומים והווידג'טים במסך הראשי. החלק את המסך לשמאל או לימין כדי להציג במבט מהיר את כל היישומים המותקנים.

כדי לחפש יישום, השתמש בחיפוש של Google.

פריסת המסך הראשי

ניתן להציג את כל היישומים ולארגן וידג'טים ותיקיות במסך הראשי.



- המסך הראשי עשוי להשתנות, בהתאם לספק השירות או לגרסת התוכנה שברשותך.

- **שורת המצב**: הצג את סמלי המצב, השעה ורמת הטעינה של הסוללה.


- **וידג'ט מזג אוויר**: הצג את נתוני מזג האוויר והשעה עבור אזור מסוים.
- **וידג'ט חיפוש ב-Google**: בצע חיפוש ב-Google על-ידי הזנת מילות מפתח מדוברות או כתובות.
- **תיקייה**: צור תיקיות כדי לקבץ יישומים על פי העדפותיך.
- **סמל דף**: הצג את המספר הכולל של לוחות המסך הראשי. הקש על סמל הדף הרצוי כדי לעבור אל הדף שבחרת. הסמל שמשקף את הלוח הנוכחי יסומן.
- **אזור הגישה המהירה**: קבע יישומים ראשיים בתחתית המסך כך שתוכל לגשת אליהם מכל אחד מהלוחות של המסך הראשי.
- **לחצני תצוגה**
  - ◁ : חזור למסך הקודם. סגור את לוח המקשים או את החלונות המוקפצים.
  - ○ : הקש כדי לעבור למסך הראשי. כדי להפעיל את החיפוש של Google, הקש הקשה ממושכת.
  - □ : הקש כדי להציג רשימה של היישומים שהיו בשימוש לאחרונה או הפעל יישום מתוך הרשימה. כדי למחוק את כל היישומים שהיו בשימוש לאחרונה, הקש על **נקה הכל**. כדי להשתמש בשני יישומים בו-זמנית עם תכונת החלונות המרובים, הקש הקשה ממושכת על הסמל בזמן השימוש ביישום.

עריכת לחצני התצוגה

תוכל לסדר מחדש את לחצני התצוגה או להוסיף פונקציות בשימוש נפוץ לאזור לחצני התצוגה.

הקש על ○ > **הגדרות** > **תצוגה** > **לחצני תצוגה** > **שילוב לחצנים** והתאם אישית את ההגדרות.

- כמה פונקציות, כולל QSlide, לוח התראה ו-Capture+, מסופקות. ניתן להוסיף חמישה פריטים לכל היותר.



סמלי מצב

כאשר מופעלת התראה על הודעה שלא נקראה, אירוע בלוח השנה או התראה של שעון מעורר, בשורת המצב מוצג סמל ההתראה התואם. בדוק את מצב המכשיר על-ידי צפייה בסמלי ההתראות המוצגים בשורת המצב.


	אין אות
	נתונים משודרים כרגע דרך הרשת
	התראה מוגדרת
	מצב רטט מופעל
	Bluetooth מופעל
	מחובר למחשב דרך USB
	רמת הסוללה
	מצב טיסה מופעל
	שיחות שלא נענו
	Wi-Fi מחובר
	מצב השתק מופעל
	GPS מופעל
	נקודה חמה מופעלת
	כרטיס SIM חסר

- ייתכן שכמה מהסמלים הללו ייראו שונים או לא יופיעו כלל, בהתאם למצב המכשיר שלך. עיין בסמלים בהתאם לסביבה שבה אתה משתמש בפועל במכשיר שלך.
- הסמלים המוצגים עשויים להשתנות, בהתאם לאזור או לספק השירות.

חלונית ההתראות

תוכל לפתוח את לוח ההתראות על-ידי גרירת שורת המצב כלפי מטה במסך הראשי.

- כדי לפתוח את רשימת הסמלים לגישה מהירה, גרור את לוח ההתראות כלפי מטה או הקש על ⌄.
- כדי לסדר מחדש, להוסיף או להסיר סמלים, הקש על **ערוך**.
- אם תקיש הקשה ארוכה על הסמל, מסך ההגדרות של הפונקציה המתאימה יופיע.



שינוי כיוון המסך

תוכל להגדיר שכיוון המסך ישתנה באופן אוטומטי, בהתאם לכיוון הפיזי של המכשיר.

בלוח ההתראות, הקש על **סיבוב** ברשימת סמלי הגישה המהירה.

לחלופין, הקש על ◯ > **הגדרות** > **תצוגה** והפעל את **סיבוב מסך אוטומטי**.



עריכת המסך הראשי

במסך הראשי, הקש הקשה ממושכת על אזור ריק ובחר את הפעולה הרצויה.

- כדי לסדר מחדש את הלוחות של המסך הראשי, הקש הקשה ארוכה על לוח ולאחר מכן גרור אותו למיקום אחר.
- כדי להוסיף וידג'ט למסך הראשי, הקש הקשה ממושכת על אזור ריק במסך הבית ולאחר מכן בחר **וידג'טים**.
- כדי לשנות ערכת נושא, הקש הקשה ממושכת על אזור ריק במסך הבית ולאחר מכן בחר **ערכת נושא**.

  לחלופין, הקש על ◯ > **הגדרות** > **תצוגה** > **ערכת נושא** ולאחר מכן בחר את ערכת הנושא שברצונך להחיל על המכשיר.
- כדי לקבוע את תצורת ההגדרות של המסך הראשי, הקש הקשה ממושכת על אזור ריק במסך הבית ולאחר מכן בחר **הגדרות מסך בית**. לפרטים, ראה *הגדרות מסך בית*.
- כדי להציג או להתקין מחדש את היישומים שהוסרו, גע והחזק אזור ריק במסך הבית, ולאחר מכן בחר באפשרות **היישומים שהוסרו**. לפרטים, ראה *היישומים שהוסרו*.

צפייה בערכת הנושא של הרקע

תוכל להציג את תמונת הרקע בלבד על-ידי הסתרת היישומים והווידג'טים במסך הראשי.

הרחק את שתי האצבעות על המסך הראשי.

- כדי לחזור אל מסך היישומים והווידג'טים המקורי, בצע תנועת צביטה במסך הראשי או הקש על ◁.



הזזת יישומים במסך הראשי

במסך הראשי, הקש הקשה ארוכה על יישום ולאחר מכן גרור אותו למיקום אחר.

- כדי להשאיר יישומים בשימוש נפוץ בתחתית המסך הראשי, לחץ לחיצה ארוכה על יישום וגרור אותו לאזור הגישה המהירה שבתחתית המסך.
- כדי להסיר סמל מאזור הגישה המהירה, גרור אותו אל המסך הראשי.

שימוש בתיקיות מתוך המסך הראשי

יצירת תיקיות

במסך הראשי, הקש הקשה ארוכה על יישום ולאחר מכן גרור אותו מעל יישום אחר.

- פעולה זו תיצור תיקייה חשה והיישום יתווסף אליה.

עריכת תיקיות

במסך הראשי, הקש על תיקייה ובצע אחת מהפעולות הבאות.

- כדי לערוך את שם וצבע התיקייה, הקש על שם התיקייה.
- כדי להוסיף יישומים, הקש הקשה ממושכת על יישום ולאחר מכן גרור אותו מעל התיקייה כדי לשחרר אותו.
- כדי להסיר יישום מהתיקייה, הקש הקשה ארוכה על היישום וגרור אל מחוץ לתיקייה. אם היישום שהסרת הוא היישום היחיד שהיה בתיקייה, התיקייה תוסר באופן אוטומטי.
- באפשרותך גם להוסיף או להסיר יישומים לאחר הקשה על + בתיקייה.

הגדרות מסך בית

תוכל להתאים אישית את הגדרות המסך הראשי.

1 הקש על ◯ > **הגדרות** > **תצוגה** > **מסך ראשי**.

2 התאם אישית את ההגדרות הבאות:

- **בחר בית**: בחר מצב של המסך הראשי.
- **טפט**: שנה את טפט הרקע של המסך הראשי.
- **אפקט בהחלפת מסכים**: בחר אפקט שיוחל כאשר לוח המסך הראשי מתחלף.
- **סדר את היישומים לפי**: הגדר כיצד יתבצע מיון של יישומים במסך הראשי.
- **רשת**: שנה את מצב סידור היישומים עבור המסך הראשי.
- **הסתר יישומים**: בחר אילו יישומים ברצונך להסתיר ממסך הבית.

נעילת מסך

סקירה כללית של נעילת המסך

מסך המכשיר נכבה וננעל כאשר לוחצים על מקש הפעלה/נעילה. בנוסף, המסך נכבה וננעל לאחר שהמכשיר לא היה פעיל במשך פרק זמן שצוין.

אם תלחץ על מקש הפעלה/נעילה כאשר לא מוגדרת נעילת מסך, המסך הראשי יופיע באופן מידי.

כדי להבטיח שהמכשיר יהיה מאובטח ולמנוע גישה לא רצויה למכשיר, הגדר נעילת מסך.

- נעילת מסך מונעת קלט מגע מיותר על מסך המכשיר ומצמצמת את צריכת הסוללה. אנו ממליצים להפעיל את נעילת המסך כאשר אינך משתמש במכשיר.

קבע הגדרות נעילת מסך

לרשותך מספר אפשרויות שונות לנעילת המסך.

1 הקש על ◯ > **הגדרות** > **תצוגה** > **מסך נעילה** > **בחירת נעילת מסך** ולאחר מכן בחר את השיטה המועדפת עליך.

2 התאם אישית את ההגדרות הבאות:

- **ללא**: ביטול פונקציית נעילת המסך.
- **החלקה**: החלק על המסך כדי לבטל את נעילת המסך.
- **Knock Code**: הקש על המרווחים במסך בתבנית מסוימת כדי לבטל את נעילת המסך.
- **תבנית**: צייר תבנית לביטול נעילת המסך.
- **קוד PIN** : הזן סיסמה מספרית לביטול נעילת המסך.
- **סיסמה**: הזן סיסמה אלפאנומרית לביטול נעילת המסך.

- אם תנסה לבטל את נעילת המכשיר 5 פעמים באופן שגוי, המסך ייחסם למשך 30 שניות.

הגדרות אתחול מאובטח

כאשר אתה בוחר Knock Code, תבנית, קוד PIN או סיסמה כשיטה לנעילת מסך, אתה יכול להגדיר את המכשיר כך שיינעל בכל הפעלה שלו כדי לאבטח נתונים.

- לא תוכל להשתמש בכל הפונקציות, למעט שיחת החירום, עד אשר תבטל את נעילת המכשיר.
- אם תשכח את הסיסמה לביטול הצפנה, לא תוכל לשחזר נתונים מוצפנים ומידע אישי.

הגדרות נעילת מסך

תוכל להתאים אישית את הגדרות נעילת המסך.

1 הקש על ◯ > **הגדרות** > **תצוגה** > **מסך נעילה**.

2 התאם אישית את ההגדרות הבאות:

- **בחירת נעילת מסך**: בחר שיטה לנעילת מסך.
- **Smart Lock**: בחר פריטי 'טריגר', שההתרחשות של אחד מהם תגרום לביטול אוטומטי של נעילת המכשיר.
- **טפט**: שנה את טפט הרקע של מסך הנעילה.
- **שעון**: בחר את סוג התצוגה של השעון שיוצג על המסך הנעול.
- **קיצורי דרך**: הוסף קיצור דרך יישום וגש ישירות ליישום מתוך מסך הנעילה על-ידי גרירת קיצור הדרך של היישום על המסך.
- **פרטי יצירת קשר עבור טלפון שאבד**: הצג פרטי יצירת קשר למצב חירום במסך הנעילה.
- **זמן לנעילה**: הגדר את משך הזמן ללא פעילות, שלאחריו המכשיר יינעל באופן אוטומטי.
- **נעילה באמצעות לחצן ההפעלה**: נעל באופן מידי את המסך בעת לחיצה על מקש הפעלה/נעילה.

- פריטי ההגדרה הזמינים עשויים להשתנות, בהתאם לשיטת נעילת המסך שנבחרה.

KnockOn

ניתן להקיש הקשה כפולה על המסך כדי להפעיל או לכבות אותו.

- אפשרות זו זמינה אך ורק במסך הראשי שסופק על-ידי LG. היא לא תפעל כראוי במפעיל מותאם אישית או במסך ראשי שהותקן על-ידי המשתמש.
- בעת הקשה על המסך, השתמש בקצה האצבע. אל תשתמש בציפורן.
- כדי להשתמש בתכונה KnockON, ודא שחיישן הקרובה/תאורה לא נחסם על-ידי מדבקה או כל חומר זר אחר.

הפעלת המסך

הקש פעמיים באמצע המסך

- הקשה על החלק העליון או התחתון של המסך עשויה להקטין את שיעור זיהוי הפעולה.

כיבוי המסך

הקש פעמיים על שטח ריק במסך הראשי.

לחלופין, הקש הקשה כפולה על שטח ריק בשורת המצב.

Knock Code

תוכל לבטל את נעילת המסך על ידי יצירת Knock Code משלך. כאשר המסך כבוי, תוכל לגשת ישירות למסך הראשי על-ידי הקשה על המסך ברצף שצוין.

- תוכל להשתמש ב-Knock Code יחד עם התכונה KnockOn.
- הקפד להשתמש בקצה האצבע בעת הקשה על המסך.

יצירת Knock Code

1 הקש על ◯ > **הגדרות** > **תצוגה** > **מסך נעילה** > **בחירת נעילת מסך** > **Knock Code**.

2 הקש על הריבועים בתבנית הרצויה לך כדי ליצור Knock Code ולאחר מכן הקש על **הבא**.

3 לאימות, הזן שוב את ה- Knock Code ולאחר מכן הקש על **אשר**.

ביטול נעילת המסך עם Knock Code

בטל את נעילת המסך על ידי הזנת ה-Knock Code שיצרת.

הזן את ה-Knock Code במסך המגע כאשר המסך כבוי.

- תוכל להזין Knock Code גם כאשר מסך הנעילה מופעל.

הצפנת כרטיס זיכרון

ניתן להצפין את הנתונים השמורים בכרטיס הזיכרון כדי להגן עליהם. לא ניתן לגשת לנתונים המוצפנים בכרטיס הזיכרון ממכשיר אחר.

1 הקש על ◯ > **הגדרות** > **כללי** > **אבטחה** > **הצפן אחסון כרטיס SD**.

2 קרא את הסקירה הכללית של הצפנת כרטיס הזיכרון המוצגת על המסך ולאחר מכן הקש על **המשך** כדי להמשיך.

3 בחר אפשרות והקש על **הצפן כעת**.

- **הצפנת קובץ חדש**: הצפן רק את הנתונים שנשמרו בכרטיס הזיכרון לאחר ההצפנה.
- **הצפנה מלאה**: הצפן את כל הנתונים השמורים כעת בכרטיס הזיכרון.
- **ללא קבצי מדיה**: הצפן את כל הקבצים, למעט קובצי מדיה כמו מוסיקה, תמונות וסרטוני וידאו.

- כדי להצפין את כרטיס הזיכרון, ודא שסוג נעילת המסך הוא קוד PIN או סיסמה.
- לאחר שיחל תהליך הצפנת כרטיס הזיכרון, פונקציות מסוימות לא יהיו זמינות.
- כיבוי המכשיר תוך כדי תהליך ההצפנה יגרום לכישלון התהליך ועלול לגרום נזק לנתונים מסוימים. לכן הקפד לוודא שהסוללה טעונה ברמה מספקת לפני שאתה מתחיל בתהליך ההצפנה.
- הקבצים המוצפנים יהיו נגישים רק מהמכשיר שבו הקבצים הוצפנו.
- לא ניתן להשתמש בכרטיס הזיכרון המוצפן במכשיר אחר של LG. כדי להשתמש בכרטיס הזיכרון המוצפן במכשיר נייד אחר, אתחל את הכרטיס.
- ניתן להפעיל הצפנת כרטיס זיכרון אפילו כאשר אין כרטיס זיכרון בתוך המכשיר. כל כרטיס זיכרון שיותקן לאחר ההצפנה יוצפן באופן אוטומטי.

יצירת צילומי מסך

באפשרותך לצלם תמונה של המסך הנוכחי שמוצג במכשיר.

באמצעות קיצור דרך

לחץ לחיצה ארוכה (לפחות שתי שניות) על מקש ההפעלה/נעילה ועל מקש החלשת עוצמת הקול (-) במקביל.

- תוכל לראות תמונות מסך דרך התיקייה **Screenshots** ב-**גלריה**.

באמצעות +Capture

במסך שבו ברצונך ליצור צילום מסך, גרור את שורת המצב כלפי מטה ולאחר מכן הקש על .


- כאשר המסך כבוי או נעול, קבל גישה אל **+Capture** בשתי לחיצות על מקש הגברת עוצמת הקול (+). כדי להשתמש בתכונה זו, הקש על ◯ > **הגדרות** > **כללי** והפעל את **מקש קיצור דרך**.
- לפרטים, ראה *כתיבת הערות על צילום מסך*.

הזנת טקסט

שימוש במקלדת החכמה


תוכל להשתמש במקלדת Smart כדי להזין ולערוך טקסט.

באמצעות מקלדת Smart, תוכל להציג טקסט תוך כדי הקלדה, בלי שתצטרך לעבור בין המסך למקלדת קונבנציונלית. הדבר יאפשר לך לאתר בקלות שגיאות ולתקן אותן תוך כדי הקלדה.



הזזת הסמן

מקלדת Smart מאפשרת לך להזיז את הסמן למיקום המדויק שאתה רוצה. בעת הקלדת טקסט, הקש הקשה ממושכת על מקש הרווח ולאחר מכן גרור שמאלה או ימינה.




• אפשרות זו זמינה רק במקלדות QWERTY.

הצעת מילים

מקלדת Smart מנתחת באופן אוטומטי את דפוסי השימוש שלך כדי להציע מילים בשימוש נפוץ תוך כדי הקלדה. ככל שתשתמש יותר במכשיר, כך ההצעות יהיו מדויקות יותר.

הזן טקסט והקש על מילה מוצעת; לחלופין, גרור מעלה בעדינות את הצד השמאלי או הימני של מקש הרווח.

- המילה שנבחרה תוזן באופן אוטומטי. אינך צריך להקליד באופן ידני כל אות של המילה.




שינוי הפריסה של מקלדת QWERTY

תוכל להוסיף, למחוק או לסדר מחדש מקשים בשורה התחתונה של המקלדת.

1 הקש על ◯ > **הגדרות** > **כללי** > **שפה ומקלדת** > **מקלדת LG** > **גובה ופריסת המקלדת** > **פריסת המקלדת QWERTY**.
לחלופין, הקש על ⚙ במקלדת והקש על **גובה ופריסת המקלדת** > **פריסת המקלדת QWERTY**.

2 הקש על מקש בשורה התחתונה ולאחר מכן גרור אותו למיקום אחר.




- אפשרות זו זמינה אך ורק במקלדות QWERTY, QWERTZ ו-AZERTY.
- ייתכן ששפות מסוימות אינן תומכות בפונקציה זו.

התאמה אישית של גובה המקלדת

תוכל להתאים אישית את גובה המקלדת כדי להבטיח שתוכל להקליד בנוחות.

1 הקש על ◯ > **הגדרות** > **כללי** > **שפה ומקלדת** > **מקלדת LG** > **גובה ופריסת המקלדת** > **גובה המקלדת**.
לחלופין, הקש על ⚙ במקלדת והקש על **גובה ופריסת המקלדת** > **גובה המקלדת**.

2 כוונן את גובה המקלדת.



בחירת מצב מקלדת לרוחב

תוכל לבחור מצב מקלדת לרוחב מבין כמה אפשרויות.

1 הקש על ◯ > **הגדרות** > **כללי** > **שפה ומקלדת** > **מקלדת LG** > **גובה ופריסת המקלדת** > **סוג מקלדת לרוחב**.
לחלופין, הקש על ⚙ במקלדת והקש על **גובה ופריסת המקלדת** > **סוג מקלדת לרוחב**.

2 בחר מצב מקלדת.

פיצול המקלדת

תוכל לפצל את המקלדת לשניים ולמקם את שני החלקים בשני צדי המסך כאשר המסך נמצא במצב לרוחב.

הקש על ◯ > **הגדרות** > **כללי** > **שפה ומקלדת** > **מקלדת LG** > **גובה ופריסת המקלדת** > **פיצול המקלדת**.

לחלופין, הקש על ⚙ במקלדת והקש על **גובה ופריסת המקלדת** > **פיצול המקלדת**.

- סובב את המכשיר למצב 'לרוחב' כדי לפצל את המקלדת לשני הצדדים. כדי למזג או לפצל את המקלדת, בצע באצבעותיך תנועת צביטה או פריסה על המקלדת.



מצב תפעול ביד אחת

תוכל להזיז את המקלדת לצד אחד של המסך כך שתוכל להשתמש במקלדת ביד אחת.

1. הקש על ◯ > **הגדרות** > **כללי** > **שפה ומקלדת** > **מקלדת LG** > **גובה ופריסת המקלדת** > **תפעול ביד אחת**.
   לחלופין, הקש על ⚙ במקלדת והקש על **גובה ופריסת המקלדת** > **תפעול ביד אחת**.
2. לחץ על החץ המוצג לצד המקלדת כדי להזיז את המקלדת בכיוון הרצוי.



הזן טקסט באמצעות הקול

במקלדת, הקש הקשה ארוכה על ⚙ ובחר 🎤.

- כדי לאפשר זיהוי מיטבי של פקודות קוליות, דבר בצורה ברורה.
- כדי להזין טקסט בדיבור, ודא שהמכשיר מחובר לרשת.
- כדי לבחור את השפה שתוגדר לזיהוי קולי, הקש על ⚙ > **שפות** במסך הזיהוי הקולי.
- התמיכה בפונקציה זו או רשימת השפות הנתמכות הם בהתאם לאזור השירות.

הוספת שפות למקלדת

באפשרותך להפוך שפות נוספות לזמינות לקלט המקלדת.

1 הקש על ◯ > **הגדרות** > **כללי** > **שפה ומקלדת** > **מקלדת LG** > **בחר שפות**.

2 בחר את השפות שברצונך להפוך לזמינות.

העתקה והדבקה

באפשרותך להעתיק או לגזור טקסט מתוך יישום ולהדביק אותו באותו יישום. לחלופין, אתה יכול להפעיל יישומים אחרים ולהדביק את הטקסט בתוכם.

1 הקש הקשה ארוכה ליד הטקסט שברצונך להעתיק או לגזור.

2 גרור את ◗ / ◖ כדי לציין את האזור שברצונך להעתיק או לגזור.

3 בחר **גזור** או **העתק**.
- הטקסט שנגזר או הועתק נוסף באופן אוטומטי ללוח.

4 הקש הקשה ארוכה על חלון הזנת הקלט ולאחר מכן בחר **הדבק**.

- אם אין פריט שהועתק או נגזר, האפשרות **הדבק** לא תופיע.

אחסון זמני

כאשר אתה מעתיק או גוזר תמונה או טקסט, הם נשמרים באופן אוטומטי במגש קליפים, וניתן להדביק אותם בכל שטח פנוי בכל עת.

1 במקלדת, הקש הקשה ארוכה על ⋯ ⚙ ובחר ▤.
לחלופין, הקש הקשה ארוכה על חלון הזנת הקלט ולאחר מכן בחר **אחסון זמני**.

2 בחר והדבק פריט מתוך מגש הקליפים.

- ניתן לשמור 20 פריטים לכל היותר במגש הקליפים.
- הקש על 📌 כדי לנעול פריטים שמורים על מנת להבטיח שהם לא יימחקו גם לאחר שבוצעה חריגה מהכמות המרבית המותרת. ניתן לנעול עשרה פריטים לכל היותר. כדי למחוק פריטים נעולים, תחילה בטל את נעילתם.
- הקש על 🗑 כדי למחוק את הפריטים השמורים במגש הקליפים.

- ייתכן שיישומים מסוימים שהורדת לא יתמכו במגש הזמני.

נא לא להפריע

תוכל להגביל או להשתיק התראות כדי למנוע הפרעות במשך פרק זמן מסוים.

1 הקש על ⚙ > **הגדרות** > **צליל והתראה** > **נא לא להפריע** ולאחר מכן גרור את ⬭ כדי להפעיל אותו.

2 הקש על **צלילים ורטט** ובחר את המצב הרצוי:

- **עדיפות בלבד**: קבל התראות קוליות או התראות ברטט עבור היישומים שנבחרו. התראות ימשיכו להישמע גם כאשר הפונקציה **עדיפות בלבד** מופעלת.
- **שקט מוחלט**: השבת את הקול והרטט.

03

יישומים
שימושיים

התקנה והסרת התקנה של יישומים

התקנת יישומים

היכנס לחנות יישומים כדי לחפש ולהוריד יישומים.

- תוכל להשתמש בחנויות כמו **SmartWorld**, **חנות Play** או חנות היישומים של ספק השירות שלך.

- ייתכן שחנויות יישומים מסוימות ידרשו ממך ליצור חשבון ולהיכנס לחשבון זה.
- יישומים מסוימים עשויים לגבות תשלום.
- אם אתה משתמש בנתונים לנייד, ייתכן שתחויב בתשלום בגין השימוש בנתונים, בהתאם לתוכנית המחירים שלך.
- התמיכה בפונקציה **SmartWorld** אינה מובטחת ותלויה באזור או בספק השירות.

הסרת התקנה של יישומים

הסר את ההתקנה של יישומים שאינך משתמש בהם עוד מהמכשיר שלך.

הסרת התקנה עם מחוות ההקשה הממושכת

במסך הראשי, הקש הקשה ארוכה על היישום כדי להסיר את התקנתו ולאחר מכן גרור אותו מעל האפשרות **הסר התקנה** בחלק העליון של המסך.

באפשרותך גם להקיש הקשה ממושכת על היישום ולאחר מכן להקיש על יישום או על וידג'ט שאליהם ⊗ מצורף כדי להסיר את ההתקנה.

- תוכל להתקין מחדש יישומים שהסרת אם חלפו מאז ההסרה פחות מ-24 שעות. לפרטים, ראה *היישומים שהוסרו*.

הסרת התקנה באמצעות תפריט ההגדרות

הקש על ◯ > **הגדרות** > **כללי** > **יישומים**, בחר יישום ולאחר מכן הקש על **הסר התקנה**.

הסרת התקנה של יישומים מחנות היישומים

כדי להסיר התקנה של יישום, עבור לחנות היישומים שממנה הורדת אותו, והסר את התקנתו.

- יישומים מסוימים אינם ניתנים להסרה על-ידי המשתמשים.

היישומים שהוסרו

תוכל לראות את היישומים שהוסרו במסך הבית. באפשרותך גם להתקין מחדש יישומים שהסרת, אם חלפו מאז ההסרה פחות מ-24 שעות.

1 הקש על ◯ > **היישומים שהוסרו**.

2 הפעל את הפונקציה הרצויה:

- **התקן מחדש**: התקן מחדש את היישום הרצוי.
- 🗑 : הסר מהמכשיר לצמיתות את היישומים שביטלת את התקנתם.

- יישומים שתסיר יימחקו מהמכשיר באופן אוטומטי 24 שעות לאחר הסרתם. אם תרצה להתקין מחדש יישומים שהוסרו, תצטרך להוריד אותם מחדש מחנות היישומים.
- תכונה זו מופעלת רק במסך הראשי שהוגדר כברירת מחדל. אם תסיר יישומים דרך מסך EasyHome או מפעיל יישומים אחר, הם יוסרו מהמכשיר באופן מידי ולצמיתות.

טלפון

שיחה קולית

בצע שיחת טלפון על-ידי שימוש באחת השיטות הזמינות, כמו הזנה ידנית של מספר טלפון וביצוע שיחה מרשימת אנשי הקשר או מרשימת השיחות האחרונות.

ביצוע שיחה מהמקלדת

1 הקש על ◯ > > **חייג**.

2 בצע שיחה באמצעות שיטה לבחירתך:

- הזן מספר טלפון ולאחר מכן הקש על .
- הקש הקשה ממושכת על מספר חיוג מהיר.
- חפש איש קשר על-ידי הקשה על האות הראשונה בשמו ברשימת אנשי הקשר, ולאחר מכן הקש על .

- כדי להזין את התו "+" לצורך שיחה בינלאומית, הקש הקשה ממושכת על הספרה 0.
- ראה *הוספת אנשי קשר* כדי ללמוד כיצד להוסיף מספרי טלפון לרשימת מספרי החיוג המהיר.

ביצוע שיחה מרשימת אנשי הקשר

1 הקש על ◯ > > **אנשי קשר**.

2 ברשימת אנשי הקשר, בחר איש קשר והקש על .

מענה לשיחה

כדי לענות לשיחה, גרור את אל מחוץ לעיגול במסך השיחה הנכנסת.

- כאשר אוזניות סטריאו מחוברות, תוכל לבצע שיחת באמצעות הלחצן חייג/סיום באוזניות.
- כדי לסיים שיחה על-ידי הקשה פשוטה על מקש הפעלה/נעילה, הקש על ◯ > **הגדרות** > **רשתות** > **הגדרות שיחה** > **מענה וסיום שיחות**, ולאחר מכן הפעל את **סיים שיחות באמצעות מקש ההפעלה**.

דחיית שיחה

כדי לדחות שיחה נכנסת, גרור את על מסך השיחה הנכנסת.

- כדי לשלוח הודעת דחייה, גרור את אפשרות הודעת הדחייה על המסך.
- כדי להוסיף או לערוך הודעת דחייה, הקש על ◯ > **הגדרות** > **רשתות** > **הגדרות שיחה** > **חסימת שיחה ודחייתה עם הודעה** > **דחה שיחה ושלח הודעה**.
- כאשר נכנסת שיחה, לחץ על לחצן הגברת העוצמה (+), על לחצן הנמכת העוצמה (-) או על לחצן ההפעלה/נעילה כדי להשתיק את הרינגטון או הרטט, או כדי להעביר את השיחה להמתנה.

צפייה בשיחות שלא נענו

במקרה של שיחה שלא נענתה, הסמל יופיע בשורת המצב, בחלק העליון של המסך.

כדי להציג את פרטי השיחה שלא נענתה, גרור את שורת המצב כלפי מטה. לחלופין, הקש על ◯ > > **יומן שיחות**.

הפונקציות הנגישות במהלך שיחה

במהלך שיחה, תוכל לגשת למגוון פונקציות על-ידי הקשה על הלחצנים המוצגים על המסך:

- **אנשי קשר**: הצג את רשימת אנשי הקשר במהלך שיחה.
- **ניתוק**: סיים שיחה.
- **מקשים**: הצג או הסר את מקשי החיוג.
- **רמקול**: הפעל את פונקציית הרמקול.
- **השתק**: השתק את הקול כדי שהצד השני לא ישמע את קולך.
- **Bluetooth**: העבר את השיחה למכשיר Bluetooth משויך ומחובר.
- ⋮ : גישה לאפשרויות שיחה נוספות.

- פריטי ההגדרה הזמינים עשויים להשתנות בהתאם לאזור או לספק השירות.

ביצוע שיחה בת שלושה משתתפים

במהלך שיחה, תוכל להתקשר לאיש קשר נוסף.

1 במהלך שיחה, הקש על ⋮ > **הוסף שיחה**.

2 הזן מספר טלפון ולאחר מכן הקש על .

- שתי השיחות יוצגו במסך במקביל והשיחה הראשונה תעבור להמתנה.

3 כדי להתחיל שיחת ועידה, הקש על **מיזוג שיחות**.

- ייתכן שתחויב בתשלום עבור כל שיחה. לקבלת מידע נוסף, פנה לספק השירות שלך.

צפייה ברשומות שיחה

כדי להציג רשומות שיחה אחרונות, הקש על ◯ > > **יומן שיחות**. לאחר מכן, תוכל להשתמש בפונקציות הבאות:

- כדי להציג רשומות שיחה מפורטות, בחר איש קשר. כדי לבצע שיחה לאיש קשר שנבחר, הקש על .
- כדי למחוק את כל רשומות השיחה, הקש על ⋮ > **מחק**.

- משך השיחה המוצג עשוי להיות שונה ממשך השיחה המשמש לחיוב. לקבלת מידע נוסף, פנה לספק השירות שלך.

הגדרת אפשרויות שיחה

באפשרותך בחור באפשרויות שיחה שונות.

1 הקש על ◯ > > **חייג** או על **יומן שיחות**.

2 הקש על ⋮ > **הגדרות שיחה** ובחר אפשרויות בהתאם להעדפותיך.

הודעות

שליחת הודעה

באפשרותך ליצור ולשלוח הודעות לאנשי הקשר שלך באמצעות היישום 'הודעות'.

• שליחת הודעות לחו"ל עלולה להיות כרוכה בתשלום נוסף. לקבלת מידע נוסף, פנה לספק השירות שלך.

1 הקש על ◯ > .

2 הקש על +.

3 ציין נמען וצור הודעה.

• כדי לצרף קבצים, הקש על .

• כדי לגשת לפריטי תפריט אופציונליים, הקש על ⋮.

4 הקש על **שלח** כדי לשלוח את ההודעה.

קריאת הודעה

תוכל להציג את חליפת ההודעות שלך עם כל איש קשר.

1 הקש על ◯ > .

2 בחר איש קשר מרשימת ההודעות.

קביעת ההגדרות להעברת הודעות

באפשרותך לשנות את הגדרות העברת ההודעות בהתאם להעדפותיך.

1 הקש על ◯ > .

2 הקש על ⋮ > **הגדרות** ברשימת ההודעות.


מצלמה

התחלת המצלמה

תוכל לצלם תמונה או סרטון וידאו כדי להנציח את כל הרגעים החשובים שלך.

הקש על ◯ > .

- לפני שאתה מצלם תמונה או מקליט סרטון וידאו, נקה את עדשת המצלמה במטלית רכה.
- היזהר שלא להכתים את עדשת המצלמה באצבעותיך או באמצעות חומר זר אחר.
- אם רמת הסוללה נמוכה מ-5 %, טען את הסוללה לפני השימוש במצלמה.
- התמונות הנכללות במדריך למשתמש זה עשויות להיות שונות מאלה שנמצאות במכשיר בפועל.
- ניתן לצפות בתמונות ובסרטוני וידאו ולערוך אותם ב**גלריה**. לפרטים, ראה *סקירה כללית של הגלריה*.



צילום תמונה

1 הקש על מושא הצילום כדי למקד בו את המצלמה.

2 הקש על כדי לצלם תמונה.

- תוכל גם ללחוץ על מקש הנמכת עוצמה (-) או הגברת עוצמה (+) כדי לצלם תמונה.

• כאשר המסך כבוי או נעול, הפעל את המצלמה בשתי לחיצות מהירות על מקש החלשת עוצמת הקול (-). כדי להפעיל את הפונקציה הקש על ◯ > **הגדרות** > **כללי** והפעל את **מקש קיצור דרך**.

הקלטת סרטון וידאו

1 הקש על מושא הצילום כדי למקד בו את המצלמה.

2 הקש על ▭.

- כדי לצלם תמונה תוך כדי צילום סרטון וידאו, הקש על ◯.
- כדי להשהות את הצילום של סרטון וידאו, הקש על ||. כדי לחדש את צילום הווידאו, הקש על ●.

3 הקש על □ כדי לסיים את צילום סרטון הווידאו.

התאמה אישית של אפשרויות המצלמה

תוכל להתאים אישית מגוון אפשרויות מצלמה כדי להתאימה לצרכיך.

הקש על ⚙ על המסך.

• האפשרויות הזמינות משתנות בהתאם למצלמה הנבחרת (מצלמה קדמית או אחורית) ולמצב המצלמה שנבחר.

גודל תמונה	בחר ערכים ליחס הרוחב-גובה ולגודל בעת צילום תמונות.
רזולוציית הווידאו	בחר ערכים לרזולוציה ולגודל בעת הקלטת סרטוני וידאו.
HDR	קבל תמונות בצבעים מלאי חיים ואפקטים של פיצוי אפילו אם הפריטים צולמו מול האור. פונקציות אלה כלולות בטכנולוגיית HDR (טווח דינמי גבוה) הכלולה במצלמת המכשיר.
טיימר	הגדר את הטיימר לצילום אוטומטי של תמונות לאחר פרק זמן שצוין.

צמצם קולי	צלם תמונות עם פקודות קוליות.
תייג מיקומים	שמור את התמונה עם נתוני מיקום GPS.
רשת	הצג קווים מנחים כך שתוכל לצלם תמונות או סרטוני וידאו בהתבסס על קווי ייחוס אופקיים ואנכיים.
אחסון	בחר אחסון פנימי או כרטיס זיכרון. (אפשרות זו זמינה כאשר הוכנס כרטיס זיכרון.)
תצוגה פשוטה	הסתר את כל התפריטים ממסך המצלמה.

אפשרויות נוספות במצלמה הקדמית

צילום סלפי	התאם אישית את ההגדרות של צילום סלפי. • צילום בתנועת יד: צלם באמצעות התכונה 'צילום בתנועת יד'. • צילום אוטומטי: צלם כאשר המצלמה מזהה פנים.
שמור הפוך	שמור תמונות הפוכות לאחר צילום תמונות סלפי.

צילום רציף

תוכל לצלם צילומים רציפים של תמונות כדי ליצור תמונות נעות.
במסך של המצלמה, לחץ לחיצה ארוכה על [מצלמה].

- צילומים רציפים מצולמים במהירות מהירה כאשר [מצלמה] מוחזק לחוץ.

- ניתן לצלם עד שלושים (30) תמונות ברצף.

תצוגה פשוטה

הקש על ⚙ > **תצוגה פשוטה** כדי להסתיר תפריטים במסך של המצלמה. תפריטים במסך המצלמה. הקש על ⎆ כדי להציג אותם.

AE/AF lock


ניתן לתקן את רמת החשיפה ומיקום המיקוד הקיימים על-ידי נגיעה ארוכה במסך של המצלמה כאשר המסך דולק. כדי לכבות את התכונה, הקש על האזור הריק של המסך.



מעבר בין המצלמות

באפשרותך לעבור מהמצלמה הקדמית לאחורית וחזרה בהתאם לסביבה.

במסך המצלמה, הקש על 🔄 או גרור את המסך בכיוון כלשהו כדי לעבור בין המצלמה הקדמית למצלמה האחורית.



- השתמש במצלמה הקדמית לצילום תמונות סלפי. לפרטים, ראה צילום סלפי.

מעבר בין מצלמה רגילה למצלמה בזווית רחבה

עבור בין הזווית הרגילה לזווית הרחבה במצלמה הקדמית כדי לצלם תמונות או להקליט סרטוני וידאו בהתאם להעדפותיך.

- הקש על / כדי להחליף בין המצלמה הרגילה למצלמה בזווית רחבה.
- דרך נוספת להחליף בין הזווית הרגילה לרחבה היא לצבוט בעזרת האצבעות או להרחיב ביניהן.

זום להתקרבות או התרחקות מהאובייקט המצולם

באפשרותך להשתמש בתכונת ההגדלה או ההקטנה במסך המצלמה בעת צילום תמונה או הקלטת סרטון וידאו.

- במסך המצלמה, קרב או הרחק את אצבעותיך כדי להתרחק או להתקרב אל האובייקט המצולם, ולאחר מכן השתמש בפס ההחלקה +/- המוצג.

- תכונת הזום אינה זמינה בעת שימוש במצלמה הקדמית במצב סלפי.

צילום סלפי

תוכל להשתמש במצלמה הקדמית כדי להציג את פניך על המסך ולצלם סלפי.

צילום בתנועת יד

תוכל לצלם תמונות סלפי באמצעות מחוות.

הצג את כף ידך למצלמה הקדמית ולאחר מכן סגור אותה לאגרוף. תוכל גם לסגור אגרוף ולאחר מכן לפתוח אותו לכיוון המצלמה הקדמית.

- בתוך שלוש שניות תצולם תמונה.





- כדי להשתמש בתכונה זו, עבור למצב המצלמה הקדמית ולאחר מכן הקש על ⚙ > **צילום סלפי** > **צילום בתנועת יד**.
- ודא שכף היד והאגרוף שלך נכללים בתוך קו הייחוס כך שהמצלמה תוכל לזהות אותם.
- ייתכן שתמונה זו אינה זמינה בעת שימוש בכמה מתכונות המצלמה.

צילום אוטומטי

אתה יכול להיעזר בתכונת זיהוי הפנים כדי לצלם תמונות סלפי בקלות ובנוחות. ניתן להגדיר את המכשיר כך, שכאשר אתה מביט במסך המצלמה הקדמית מזהה את פרצופך ומצלמת סלפי באופן אוטומטי.

- המסגרת המנחה הלבנה מופיעה כאשר המצלמה הקדמית מזהה את פניך. אם הנושא בתוך המסגרת המנחה מפסיק לנוע, צבע המסגרת המנחה הופך לכחול והמצלמה מצלמת את התמונה.




- הקש על ⚙ > **צילום סלפי** > **צילום אוטומטי** כדי להפעיל את התכונה 'צילום אוטומטי'.

צילום אינטרוולי

תוכל לצלם תמונות סלפי במרווחי זמן קבועים.

בעת שימוש במצלמה הקדמית, לחץ לחיצה ארוכה על 📷. לחלופין, הצג את כף ידך למצלמה ולאחר מכן צור אגרוף פעמיים במהירות.

- ארבע תמונות מצולמות במרווחים של כשתי שניות לאחר השהיית טיימר של שלוש שניות.



שמור הפוך

לפני שתצלם תמונה עם המצלמה הקדמית, הקש על ⚙ > **שמור הפוך**. התמונה תסתובב בכיוון ההופכי.

- בעת שימוש במצלמה הקדמית, תוכל לשנות את האופן שבו תמונות סלפי מצולמות באפשרויות המצלמה. לפרטים, ראה *התאמה אישית של אפשרויות המצלמה* .

גלריה

סקירה כללית של הגלריה

תוכל להציג ולנהל תמונות וסרטוני וידאו שנשמרו במכשיר.

1 הקש על ◯ > .


- תמונות וסרטוני וידאו שנשמרו מוצגים לפי תיקיות.

2 הקש על תיקייה ובחר קובץ.

- הצג את הקובץ שנבחר במצב מסך מלא.
- בעת צפייה בתמונה, החלק שמאלה או ימינה כדי להציג את התמונה הקודמת או התמונה הבאה.
- בעת צפייה בסרטון וידאו, החלק שמאלה או ימינה כדי להריץ אחורה או להריץ קדימה את הסרטון.

- ייתכן שחלק מתבניות הקבצים אינן נתמכות, בהתאם לתוכנות המותקנות.
- ייתכן שקבצים מסוימים לא ייפתחו עקב קידוד.
- קבצים שחורגים ממגבלת הגודל עלולים לגרום לשגיאה.

הצגת תמונות



- כדי להציג את פריטי התפריט, הקש בעדינות על המסך. כדי להסתיר את פריטי התפריט, הקש שוב על המסך.

עריכת תמונות

1 תוך כדי הצגת תמונה, הקש על ✎.

2 ערוך את התמונה בעזרת מגוון של אפקטים וכלי עריכה.

3 הקש על ✓ כדי להחיל שינויים.

4 הקש על **שמור** כדי לשמור שינויים.

- התמונה הערוכה תחליף את הקובץ המקורי.
- כדי לשמור את התמונה שנערכה כקובץ אחר, הקש על ⋮ > **שמור עותק**.

הפעלת קובץ וידאו



קבל גישה לאפשרויות נוספות.

פתח באמצעות QSlide.

כוונן את עוצמת הקול.

הרץ את סרטון הווידאו לאחור.

הוסף למועדפים או הסר מהמועדפים שלך.

נעל את המסך או בטל את נעילתו.

הרץ קדימה את סרטון הווידאו.

השהה או הפעל את סרטון הווידאו.

- כדי לכוונן את עוצמת הקול, גרור את הצד הימני של מסך הווידאו למעלה או למטה.
- כדי לכוונן את בהירות המסך, גרור את הצד השמאלי של מסך הווידאו מעלה או מטה.

מחיקת קבצים

תוכל למחוק קבצים באמצעות אחת משתי האפשרויות הבאות:

- הקש הקשה ממושכת על קובץ ברשימה, ולאחר מכן הקש על **מחק**.
- הקש על 🗑 ברשימת הקבצים ומחק את הקבצים הרצויים.
- קבצים שנמחקו מועברים באו**סל מיחזור** לפח האשפה וניתן לשחזר אותם לגלריה בתוך 7 ימים.
- בגלריה, הקש על ☰ > **סל מיחזור**. הקש על 🗑 כדי למחוק לחלוטין את הקבצים. במקרה זה, לא ניתן לשחזר את הקבצים.

שיתוף קבצים

תוכל לשתף קבצים באמצעות אחת משתי האפשרויות הבאות:

- תוך כדי הצגת תמונה או סרטון וידאו, הקש על ⋖ כדי לשתף את הקובץ בשיטה הרצויה.
- ברשימת הקבצים, הקש על ⋖ כדי לבחור קובץ ולשתף אותו בשיטה הרצויה.


נגן מוסיקה

תוכל להשמיע ולנהל שירים או אלבומי מוסיקה.

1 הקש על ◯ > **LG** > **נגן מוסיקה**.

2 בחר קטגוריה.

3 בחר קובץ מוסיקה.



עבור לרשימת ההשמעה.

חפש קובצי מוסיקה.

קבל גישה לאפשרויות נוספות.

חזור למסך הקודם.

הוסף או מחק מועדפים.

הפעל בסדר אקראי.

בחר מצב חזרה.

כוונן את עוצמת הקול.

פתח את ספריית המוסיקה.

הקש כדי להפעיל מתחילת הקובץ הנוכחי / הקש פעמיים כדי להפעיל את הקובץ הקודם / הקש הקשה ממושכת.

הקש כדי להפעיל את הקובץ הבא / הקש הקשה ממושכת כדי להריץ קדימה.

השהה או הפעל.

- ייתכן שחלק מתבניות הקבצים אינן נתמכות, בהתאם לתוכנות המותקנות.
- קבצים שחורגים ממגבלת הגודל עלולים לגרום לשגיאה.
- קובצי מוסיקה עשויים להיות מוגנים על-ידי בעלים בינלאומיים של זכויות יוצרים או חוקי זכויות יוצרים. ייתכן שתצטרך להשיג אישור משפטי לפני העתקת קובץ מוסיקה. כדי להוריד או להעתיק קובץ מוסיקה, תחילה בדוק את חוק זכויות היוצרים עבור המדינה הרלוונטית.
- מודל זה תומך בהפעלת שמע Hi-Fi. קובצי שמע מסוג Hi-Fi מציגים את סמל Hi-Fi.

דוא"ל

סקירה כללית של דוא"ל

תוכל לרשום חשבון דוא"ל במכשיר שלך ולאחר מכן תוכל לבדוק ולשלוח הודעות דוא"ל מהמכשיר.

- אם אתה משתמש בנתונים לנייד, ייתכן שתחויב בתשלום בגין השימוש בנתונים, בהתאם לתוכנית המחירים שלך. לקבלת מידע נוסף, פנה לספק השירות שלך.

רישום חשבונות דוא"ל

כאשר תשתמש ביישום הדוא"ל בפעם הראשונה, תתבקש לרשום את חשבון הדוא"ל שלך.

1. הקש על ◯ > **דוא"ל**.
2. בחר ספק שירותי דוא"ל.
3. הזן את כתובות הדוא"ל ואת הסיסמה, ולאחר מכן הקש על **הבא** כדי לרשום את החשבון שלך.
   - כדי לרשום באופן ידני חשבון דוא"ל או כדי לרשום חשבונות דוא"ל שלא נמצאו ברשימה, הקש על **הגדרה ידנית**.

ניהול חשבונות דוא"ל

כדי להציג או לערוך את הגדרות חשבון הדוא"ל שלך, הקש על ⋮ > **הגדרות**.

- כדי להוסיף חשבון, הקש על **הוסף חשבון**.
- כדי למחוק חשבון, הקש על ⋮ > **הסר חשבון**.

פתיחת חשבון דוא"ל נוסף

אם יש כמה חשבונות דוא"ל רשומים וברצונך להציג חשבון נוסף, הקש על ☰ ובחר חשבון אחר מרשימת החשבונות.

בדיקת דוא"ל

1 הקש על ☰ ובחר תיבת דואר.

2 בחר דוא"ל מרשימת הדוא"ל.

• הודעת הדוא"ל תופיע.

שליחת דוא"ל

1 הקש על ⊕.

2 הזן את כתובת הדוא"ל של הנמען.

3 הזן נושא והודעה

• כדי לצרף קבצים, הקש על 📎.

• כדי לגשת לפריטי תפריט אופציונליים, הקש על ⋮.

4 הקש על ➤ כדי לשלוח את הדוא"ל.

לוח שנה

סקירה כללית של לוח השנה

תוכל להשתמש בלוח השנה כדי לנהל אירועים ומשימות.

הוספת אירועים

1 הקש על ◯ > **לוח שנה**.

2 בחר תאריך ולאחר מכן הקש על ⊕.

3 הזן פרטי אירוע והקש על **שמור**.

• אם תקיש על תאריך בלוח השנה והתאריך מכיל אירועים, יופיע חלון מוקפץ שמציג רשימה של האירועים. הקש על אירוע בחלון המוקפץ כדי להציג את פרטי האירוע.

סנכרון אירועים

הקש על ⋮ > **לוחות שנה לסינכרון** ובחר את לוח השנה שברצונך לסנכרן.

- בעת שמירת אירועים מהמכשיר שלך אל חשבון Google, מתבצע סינכרון אוטומטי שלהם גם עם לוח השנה של Google. בהמשך תוכל לסנכרן מכשירים אחרים מול לוח השנה של Google כדי שגם באותם מכשירים האירועים יהיו זהים לאלה השמורים במכשיר שלך; לאחר הסינכרון תוכל לנהל את האירועים שלך דרך אותם מכשירים.

Event pocket

תוכל להשתמש ב-Event Pocket כדי ליצור אירועים.

הקש על כדי לפתוח את ה-Event Pocket ולאחר מכן גרור תוכן לתאריך בלוח השנה.

- : נהל תמונות, טקסט, מזכרים ואירועים שנשמרו באופן זמני. תוכל גם לשתף טקסט, תמונות ומזכרים מיישום אחר ולשמור אותם בכיס. אם תקיש על **כיס** בעת יצירת אירוע, האירוע יישמר באופן זמני בכיס.
- : נהל משימות שאין להן תאריך יעד, כמו למשל אירועים.

QuickMemo+

QuickMemo+ overview

תוכל להוסיף הערות יצירתיות על-ידי שימוש במגוון אפשרויות בתכונות מתקדמות אלה של פנקס רשימות, כגון ניהול תמונות וצילומי מסך, שאינה נתמכת על-ידי פנקס הרשימות הקונבנציונלי.

יצירת הערה

1 הקש על ◯ > **QuickMemo+**.

2 הקש על ⊕ כדי ליצור הערה.

- ✓ : שמור הערה.
- ↩ : בטל את הפעולה האחרונה.
- ↪ : בצע שוב את הפעולה האחרונה שביטלת.
- T : הזן הערה על-ידי שימוש בלוח המקשים.
- ✎ : כתוב הערות באופן ידני.
- ◇ : מחק הערות שנכתבו בכתב יד.
- ⌾ : הגדל או הקטן תצוגה, סובב או מחק חלקים מהערה בכתב יד.
- ⋮ : קבל גישה לאפשרויות נוספות, כולל שיתוף הערות ונעילתן, שינוי הסגנון של פנקס רשימות והוספת תוכן.

3 הקש על ✓ כדי לשמור את ההערה.

כתיבת הערות על תמונה

1 הקש על ◯ > **QuickMemo+**.

2 הקש על 📷 כדי לצלם תמונה ולאחר מכן הקש על **אישור**.
- התמונה מצורפת באופן אוטומטי לפנקס הרשימות.

3 הקש על T או על ✎ כדי לכתוב הערות על התמונה.
- כתוב הערות על התמונה בכתב יד.
- הזן טקסט מתחת לתמונה.

4 הקש על ✓ כדי לשמור את ההערה.

כתיבת הערות על צילום מסך

1 תוך הצגת המסך שברצונך לצלם, גרור את שורת המצב כלפי מטה והקש על ✂.
- צילום המסך נראה עמו ערכת נושא ברקע של פנקס הרשימות. כלי מזכר מופיעים בחלקו העליון של המסך.

2 רשום הערות כרצונך.
- כתוב הערות על התמונה בכתב יד.

3 הקש על ✓ ושמור את ההערות במיקום הרצוי לך.
- ניתן להציג הערות שמורות ב-**QuickMemo+** או ב-**גלריה**.
- כדי לשמור הערות באותו מיקום כל הזמן, סמן את התיבה **השתמש כברירת מחדל לפעולה זו** ובחר יישום.

ניהול תיקיות

תוכל להציג הערות בחלוקה לפי סוג ההערה.

1 הקש על ◯ > **+QuickMemo**.

2 בחלק העליון של המסך, הקש על ☰ ובחר פריט תפריט:

- **כל התזכירים**: הצג את כל ההערות שנשמרו ב-**+QuickMemo**.
- **התזכירים שלי**: הצג הערות שנוצרו על-ידי **+QuickMemo**.
- **מזכר תצלום**: הצג הערות שנוצרו על-ידי 📷.
- **+Capture**: הצג הערות שנוצרו על-ידי 🖊.
- **סל מיחזור**: הצג הערות שנמחקו.
- **קטגוריה חדשה**: הוסף קטגוריות.
- ⚙ : סדר מחדש, הוסף או מחק קטגוריות. כדי לשנות שם של קטגוריה, הקש על הקטגוריה.

- תיקיות מסוימות לא מופיעות בעת הפעלת +QuickMemo בפעם הראשונה. תיקיות מושבתות מופעלות ומופיעות כאשר הן מכילות הערה קשורה אחת לפחות.

מחשבון

ניתן להשתמש בשני סוגי מחשבונים: המחשבון הפשוט והמחשבון המדעי.

1 הקש על ◯ > **כלים** > **מחשבון**.

2 השתמש בלוח המקשים כדי לבצע חישוב.

- כדי להשתמש במחשבון מדעי, גרור שמאלה את פס ההחלקה הרוק שנמצא בצד הימני של המסך.
- כדי להפעיל מחדש חישוב, הקש הקשה ממושכת על לחצן **DEL**.

שעון

התראה

תוכל להגדיר התראה שתופעל במועד שצוין.

1 הקש על ◯ > **שעון** > **התראה**.

2 הקש על + כדי להוסיף התראה חדשה.

3 קבע את הגדרות ההתראה והקש על **שמור**.

- אם תבחר התראה שהוגדרה בעבר, תוכל לערוך אותה.
- כדי למחוק התראה, הקש על 🗑 בראש המסך. לחלופין, הקש הקשה ארוכה על ההתראה.

שעון עולמי

תוכל להציג את השעה הנוכחית בערים ברחבי העולם.

1 הקש על ◯ > **שעון** > **שעון עולמי**.

2 הקש על + והוסף עיר.

טיימר

תוכל להגדיר טיימר כדי להפעיל התראה לאחר פרק זמן שצוין.

1 הקש על ◯ > **שעון** > **טיימר**.

2 הגדר את הזמן והקש על **התחל**.

- כדי להשהות את הטיימר, הקש על **השהה**. כדי לחדש את פעולת הטיימר, הקש על **המשך**.
- כדי לאפס את הגדרות הטיימר, הקש על **איפוס**.

3 הקש על **הפסק** כדי להפסיק את התראת הטיימר.

שעון עצר

תוכל להשתמש בשעון העצר כדי לתעד את משך הזמן שחלף.

1 הקש על ◯ > **שעון** > **שעון עצר**.

2 הקש על **התחל** כדי להפעיל את שעון העצר.
- כדי לתעד זמן הקפה, הקש על **הקפה**.

3 הקש על **השהה** כדי להשהות את שעון העצר.
- כדי לחדש את פעולת שעון העצר, הקש על **המשך**.
- כדי לנקות את כל ההקלטות ולהפעיל שעון עצר חדש, הקש על **איפוס**.

הורדות

תוכל להציג, למחוק או לשתף קבצים שהורדת מהאינטרנט או יישומים.

הקש על ◯ > **כלים** > **הורדות**.

מנהל הקבצים

תוכל להציג ולנהל קבצים שנשמרו במכשיר שלך או בענן.

1 הקש על ◯ > **כלים** > **מנהל הקבצים**.

2 הקש על ☰ ובחר במיקום האחסון הרצוי.

רדיו FM

תוכל להאזין לרדיו FM.

הקש על ◯ > **כלים** > **רדיו FM**.

- כדי להשתמש ביישום זה, תחילה חבר אוזנייה למכשיר. האוזנייה הופלת לאנטנת הרדיו.
- התמיכה באפשרות זו תלויה באזור.

הקלטה קולית

תוכל להקליט ולשמור את קולך או קולות של אחרים באירועים חשובים. קובצי הקול המוקלטים יופעלו או ישותפו.

1 הקש על ◯ > **כלים** > **הקלטה קולית**.

2 הקש על ⊙.

• כדי להשהות הקלטה, הקש על ⏸.

3 הקש על ▫ כדי לסיים את ההקלטה.

• הקובץ נשמר באופן אוטומטי ומוצג מסך להאזנה.

4 הקש על ▷ כדי להפעיל את הקול המוקלט.

• כדי לשמור את פרטי המיקום של ההקלטה, הקש על **מיקום**.
• כדי להוסיף **אירוע**, הקש על אירוע והוסף אירוע לתאריך הרצוי.
• אם תקיש על ≡, קובצי הקול המוקלטים יופיעו. תוכל להפעיל קובץ קול מוקלט מהרשימה.

אנשי קשר

סקירה כללית של אנשי קשר

באפשרותך לשמור ולנהל אנשי קשר.

הקש על ◯ > **LG** > **אנשי קשר**.

הוספת אנשי קשר

הוספת אנשי קשר חדשים

1 במסך של רשימת אנשי הקשר, הקש על +.

2 הזן פרטי יצירת קשר והקש על **שמור**.

ייבוא אנשי קשר

תוכל לייבא אנשי קשר מהתקן אחסון אחר.

1 במסך של רשימת אנשי הקשר, הקש על ⋮ > **ניהול אנשי קשר** > **ייבוא**.

2 בחר את מיקומי המקור והיעד של איש הקשר שברצונך לייבא ולאחר מכן הקש על **אישור**.

3 בחר את אנשי הקשר והקש על **ייבוא**.

הוספת אנשי קשר לרשימת מספרי החיוג המהיר

1 במסך של רשימת אנשי הקשר, הקש על ⋮ > **חיוג מהיר**.

2 הקש על **הוסף איש קשר** ממספר חיוג מהיר.

3 בחר איש קשר.

חיפוש אנשי קשר

תוכל לחפש אנשי קשר באמצעות אחת משתי האפשרויות הבאות:

- במסך רשימת אנשי הקשר, הזן שם איש קשר בתיבת החיפוש.
- גלול מעלה או מטה ברשימת אנשי הקשר.
- באינדקס של מסך רשימת אנשי הקשר, הקש על האות הראשונה של איש קשר.

רשימת אנשי קשר

עריכת אנשי קשר

1 במסך רשימת אנשי הקשר, בחר באיש הקשר הרצוי.

2 במסך פרטי איש הקשר, הקש על ✎ וערוך את הפרטים.

3 הקש על **שמור** כדי לשמור שינויים.

מחיקת אנשי קשר

תוכל למחוק אנשי קשר באמצעות אחת משתי האפשרויות הבאות:

- במסך רשימת אנשי הקשר, הקש הקשה ממושכת על איש קשר שברצונך למחוק ולאחר מכן הקש על **מחק איש קשר**.

• הקש על ⋮ > **מחק** במסך של רשימת אנשי הקשר.

הוספת מועדפים

באפשרותך לרשום אנשי קשר בשימוש נפוץ כמועדפים.

1 במסך רשימת אנשי הקשר, בחר באיש הקשר הרצוי.

2 במסך פרטי איש הקשר, הקש על ☆.

יצירת קבוצות

1 במסך של רשימת אנשי הקשר, הקש על **קבוצות** > ⋮ > **קבוצה חדשה**.

2 הזן שם קבוצה חדשה.

3 הקש על **הוסף חברים**, בחר אנשי קשר ולאחר מכן הקש על **הוסף**.

4 הקש על **שמור** כדי לשמור את הקבוצה החדשה.

LG SmartWorld

תוכל להוריד מגוון משחקים, תכני שמע, יישומים וגופנים המסופקים על-ידי LG Electronics. התאם אישית את המכשיר שלך כדי להתאימו להעדפותיך באמצעות ערכות הנושא והגופנים של המסך הראשי.

- אם אתה משתמש בנתונים לנייד, ייתכן שתחויב בתשלום בגין השימוש בנתונים, בהתאם לתוכנית המחירים שלך.
- ייתכן שלא תהיה תמיכה בתכונה זו, התמיכה נקבעת בהתאם לאזור או לספק השירות.

1 הקש על ◯ > **LG** > **SmartWorld**.

2 הקש על ⋮ > **חשבון LG** והיכנס.

3 בחר פריטי תוכן והורד אותם.

מוריד את SmartWorld.

אם היישום **SmartWorld** לא מותקן, בצע את הפעולות הבאות להורדתו.

1 הקש על ◯ > **הגדרות** > **כללי** > **אודות הטלפון** > **מרכז עדכונים** > **עדכוני אפליקציות**.

2 ברשימה, בחר **SmartWorld** והקש על **הורד**.

משימות

תוכל לרשום משימות במכשיר שלך כדי לנהל בקלות לוחות זמנים.

1 הקש על ◯ > **LG** > **משימות**.

2 הקש על ⊕ כדי להוסיף משימה.

3 הזן פרטי משימה ולאחר מכן הקש על **שמור**.

LG Backup

תוכל לגבות, לשחזר ולהעביר נתונים שנשמרו במכשיר שלך.

1 הקש על ◯ > **כלי ניהול** > **LG Backup**.
לחלופין, הקש על ◯ > **הגדרות** > **כללי** > **גיבוי ואיפוס** > **LG Backup**.

2 פעל לפי ההנחיות שבמסך כדי לבחור אם לגבות נתונים בתיקיית הגיבוי הקיימת במכשיר או להעתיק אותם אל מכשירים אחרים.

⚠ • איפוס המכשיר עלול למחוק קובצי גיבוי שנשמרו בשטח אחסון פנימי. כדי למזער את אובדן הנתונים, העתק קובצי חשובים מתיקיית הגיבוי של LG בשטח האחסון הפנימי למחשב או להתקן אחסון חיצוני.

- הנתונים בחשבון Google לא יגובו. כאשר תסנכרן את חשבון Google, יישומי Google, אנשי הקשר של Google, לוח השנה של Google, תזכירים של Google, נתוני היישומים והיישומים שהורדת מחנות Play יאוחסנו ביישום הכונן באופן אוטומטי.
- קובצי גיבוי נשמרים עם סיומת הקובץ lbf.* בתיקייה LG Backup בכרטיס הזיכרון או באחסון הפנימי.
- טען את הסוללה במלואה לפני שתגבה או תשחזר נתונים כדי למנוע כיבוי לא מכוון באמצע התהליך.

Evernote

תוכל לכתוב ולאסוף מידע חשוב ולאחר מכן לשתף זאת עם מכשירים אחרים שתומכים ב-**Evernote**.

הקש על ◯ > **מומלץ** > **Evernote**.

פייסבוק

באפשרותך להשתמש בשירות רשתות חברתיות כדי לעדכן, להציג ולשתף פוסטים, תמונות וסרטוני וידאו עם אנשי הקשר המקוונים שלך.

הקש על ◯ > **מומלץ** > **פייסבוק**.

Instagram

השתמש בשירות רשתות חברתיות כדי ללכוד ולשתף את התמונות וסרטוני הווידאו שלך. תוכל גם להחיל אפקטי מסנן כדי להפוך את התמונות וסרטוני הווידאו שלך ליצירתיים ומעניינים יותר.

הקש על ◯ > **מומלץ** > **Instagram**.

Chrome

היכנס ל-Chrome ויבא כרטיסיות פתוחות, סימניות ונתוני שורת כתובת ממחשב למכשיר שלך.

יישומי Google

כדי להשתמש ביישומי Google, הגדר חשבון Google. חלון הרישום של חשבון Google יופיע באופן אוטומטי כאשר תשתמש ביישום של Google בפעם הראשונה. אם אין לך חשבון Google, צור חשבון במכשיר שלך. לפרטים בנוגע לאופן השימוש ביישום, עיין בעזרה שסופקה ביישום.

- ייתכן שיישומים מסוימים לא יפעלו, בהתאם לאזור ולספק השירות.

Docs

צור מסמכים או ערוך מסמכים שנוצרו באינטרנט או במכשיר אחר. שתף וערוך מסמכים עם אחרים.

Drive

העלה, שמור, פתח, שתף וסדר קבצים במכשיר שלך. ניתן לגשת לקבצים הנגישים מהיישומים מכל מקום, כולל סביבות מקוונות ולא מקוונות.

Duo

ערוך שיחת וידאו עם בני משפחה, חברים וכל אחד אחר שמשתמש ביישום.

Gmail

רשום את חשבון הדוא"ל של Google במכשיר שלך כדי לבדוק אם הגיע דוא"ל או כדי לשלוח דוא"ל.

Google

השתמש ב-Google כדי לחפש דפי אינטרנט, תמונות, חדשות ועוד על-ידי הזנת מילות מפתח או אמירתן בקול רם.

מפות

חפש את המיקום שלך או את המיקום של מקום על המפה. הצג מידע גיאוגרפי.

תמונות

הצג או שתף תמונות או אלבומים השמורים במכשיר שלך.

סרטים Play

השתמש בחשבון Google כדי לשכור או לרכוש סרטים. קנה תוכן והפעל אותו בכל מקום.

מוזיקה Play

קנה קובצי מוסיקה מ-**חנות Play**. הפעל קובצי מוסיקה שנשמרו במכשיר שלך.

Sheets

צור גיליונות אלקטרוניים או ערוך גיליונות אלקטרוניים שנוצרו באינטרנט או במכשיר אחר. שתף וערוך גיליונות אלקטרוניים עם אחרים.

Slides

צור חומרים למצגת או ערוך חומרים למצגת שנוצרו באינטרנט או במכשיר אחר. שתף וערוך חומרים למצגת עם אחרים.

YouTube

חפש והפעל סרטונים. העלה סרטוני וידאו ל-YouTube כדי לשתף אותם עם אנשים ברחבי העולם.

04

הגדרות טלפון

הגדרות

תוכל להתאים אישית את הגדרות המכשיר על פי העדפותיך.
הקש על ◯ > **הגדרות**.

- הקש על 🔍 והזן מילת מפתח בתיבת החיפוש כדי לגשת לפריט הגדרה.
- הקש על ⋮ כדי לשנות את מצב התצוגה. מדריך למשתמש זה מניח שאתה משתמש ב**תצוגת לשוניות**.

רשתות

Wi-Fi

תוכל להתחבר למכשירים סמוכים או באמצעות רשת Wi-Fi.

התחברות לרשת Wi-Fi

1 במסך ההגדרות, הקש על **רשתות** > **Wi-Fi**.

2 גרור את ◯ כדי להפעיל אפשרות זו.

- רשתות ה-Wi-Fi הזמינות יופיעו באופן אוטומטי.

3 בחר רשת.

- ייתכן שתצטרך להזין את סיסמת ה-Wi-Fi של הרשת.
- המכשיר מדלג על תהליך זה עבור רשתות Wi-Fi שבוצעה אליהם גישה בעבר. אם אינך רוצה להתחבר באופן אוטומטי לרשת Wi-Fi מסוימת, הקש הקשה ארוכה על הרשת ולאחר מכן הקש על **שכח רשת**.

הגדרות רשת Wi-Fi

במסך ההגדרות, הקש על **רשתות** > **Wi-Fi**.

- **עבור לנתונים ניידים**: אם תופעל פונקציית הנתונים הניידים אך המכשיר לא יצליח להתחבר לאינטרנט באמצעות Wi-Fi, המכשיר יתחבר לאינטרנט באופן אוטומטי באמצעות פונקציית הנתונים הניידים.
- ⋮ : התאם אישית את ההגדרות של רשת Wi-Fi.

Wi-Fi Direct

תוכל לחבר את ההתקן שלך להתקנים אחרים שתומכים ב-Wi-Fi Direct כדי לשתף נתונים ישירות איתם. אינך צריך נקודת גישה. תוכל להתחבר עם יותר משני מכשירים באמצעות Wi-Fi Direct.


1 במסך ההגדרות, הקש על **רשתות** > **Wi-Fi** > ⋮ > **Wi-Fi מתקדם** > **Wi-Fi Direct**.

- מכשירים סמוכים שתומכים ב- Wi-Fi Direct יופיעו באופן אוטומטי.

2 בחר התקן.

- החיבור מתרחש כאשר המכשיר מקבל את בקשת החיבור.

- בעת שימוש ב-Wi-Fi Direct, הסוללה עשויה להתרוקן מהר יותר.



Bluetooth

תוכל לחבר את המכשיר שלך למכשירים סמוכים שתומכים ב-Bluetooth כדי להחליף איתם נתונים. חבר את המכשיר לאוזניית Bluetooth ולמקלדת. בדרך זו תוכל לשלוט בקלות רבה יותר במכשיר.

שיוך עם מכשיר אחר

1 במסך ההגדרות, הקש על **רשתות** > **Bluetooth**.

2 גרור את כדי להפעיל אפשרות זו.

- המכשירים הזמינים מופיעים באופן אוטומטי.
- כדי לרענן את רשימת המכשירים, הקש על **חיפוש**.

- רק מכשירים שמוגדרים כגלויים מוצגים ברשימה.

3 בחר מכשיר מהרשימה.

4 פעל לפי ההוראות שעל המסך כדי לבצע את האימות.

- המערכת מדלגת על שלב זה עבור מכשירים שבוצעה אליהם גישה בעבר.

שליחת נתונים דרך חיבור Bluetooth

1 בחר קובץ.

- תוכל לשלוח קובצי מולטימדיה או אנשי קשר.

2 הקש על > **Bluetooth**.

3 בחר מכשיר יעד עבור הקובץ.

- הקובץ יישלח ברגע שמכשיר היעד יקבל אותו.

- תהליכי שיתוף הקבצים עשויים להשתנות, בהתאם לקובץ.

נתונים ניידים

תוכל להפעיל או לקבל נתונים לניד. תוכל גם לנהל את השימוש בנתונים לנייד.

הפעלת נתונים לנייד

1 במסך ההגדרות, הקש על **רשתות** > **נתונים ניידים**.

2 גרור את כדי להפעיל אפשרות זו.

התאמה אישית של הגדרות הנתונים לנייד

1 במסך ההגדרות, הקש על **רשתות** > **נתונים ניידים**.

2 התאם אישית את ההגדרות הבאות:

- **נתונים ניידים**: הגדר שימוש ברשתות סלולריות לצורך חיבורי נתונים.
- **הגבל שימוש בנתונים ניידים**: הגדר מגבלה לשימוש בנתונים לנייד כדי לחסום נתונים לנייד אם הגעת למגבלה.
- ⋮ : התאם אישית את ההגדרות הנתונים לנייד.

הגדרות שיחה

תוכל להתאים אישית את הגדרות השיחה, כגון אפשרויות שיחה קולית ושיחה בינלאומית.

- ייתכן שחלק מהפונקציות אינן נתמכות, בהתאם לאזור ולספק השירות.

1 במסך ההגדרות, הקש על **רשתות** > **הגדרות שיחה**.

2 התאם אישית את ההגדרות.

שיתוף אינטרנט


שיתוף באמצעות USB

תוכל לחבר את המכשיר למכשיר אחר דרך USB ולשתף נתונים לנייד.

1 חבר את המכשיר והמכשירים האחרים באמצעות כבל USB.

2 במסך ההגדרות, הקש על **רשתות** > **שיתוף אינטרנט** > **שיתוף באמצעות USB** ולאחר מכן החלק על כדי להפעיל אפשרות זו.

- אפשרות זו משתמשת בנתונים לנייד, ועשויה להיות כרוכה בתשלום, בהתאם לתוכנית המחירים שלך. לקבלת מידע נוסף, פנה לספק השירות שלך.
- בעת התחברות למחשב, הורד את מנהל התקן ה-USB מהאתר *www.lg-mobile.co.il* והתקן אותו במחשב.
- לא ניתן להעביר קבצים בין המכשיר למחשב כאשר חיבור לאינטרנט באמצעות USB מופעל. כבה את החיבור לאינטרנט באמצעות USB כדי לשלוח או לקבל קבצים.
- מערכות הפעלה שתומכות בחיבור לאינטרנט הן Window XP ואילך, או Linux.



נקודה חמה ניידת ב- Wi-Fi

תוכל להגדיר את המכשיר כנתב אלחוטי כך שהמכשירים האחרים יוכלו להתחבר לאינטרנט באמצעות חיבור הנתונים לנייד של המכשיר.


1 במסך ההגדרות, הקש על **רשתות** > **שיתוף אינטרנט** > **נקודה חמה ניידת ב- Wi-Fi** ולאחר מכן החלק על כדי להפעיל אפשרות זו.

2 הקש על **הגדרת נקודה חמה של Wi-Fi** והזן (SSID) שם Wi-Fi וסיסמה.

3 הפעל את Wi-Fi במכשיר השני ובחר את השם של רשת המכשיר ברשימת ה-Wi-Fi.

4 הזן את סיסמת הרשת.

- אפשרות זו משתמשת בנתונים לנייד, ועשויה להיות כרוכה בתשלום, בהתאם לתוכנית המחירים שלך. לקבלת מידע נוסף, פנה לספק השירות שלך.
- לרשותך מידע נוסף באתר אינטרנט זה: *http://www.android.com/tether#wifi*




שיתוף אינטרנט ב-Bluetooth

ניתן לחבר מכשיר עם חיבור Bluetooth לאינטרנט דרך חיבור הנתונים לנייד במכשיר שלך.

1 במסך ההגדרות, הקש על **רשתות** > **שיתוף אינטרנט** > **שיתוף אינטרנט ב-Bluetooth** ולאחר מכן החלק על כדי להפעיל אפשרות זו.

2 הפעל את Bluetooth בשני המכשירים ושייך אותם.

- אפשרות זו משתמשת בנתונים לנייד, ועשויה להיות כרוכה בתשלום, בהתאם לתוכנית המחירים שלך. לקבלת מידע נוסף, פנה לספק השירות שלך.
- לרשותך מידע נוסף באתר אינטרנט זה: *http://www.android.com/tether#Bluetooth_tethering*



עזרה

תוכל להציג את העזרה בנושא קשירה ונקודות חמות.

במסך ההגדרות, הקש על **רשתות** > **שיתוף אינטרנט** > **עזרה**.

עוד

מצב טיסה

תוכל לכבות את פונקציות השיחה והנתונים לנייד. כאשר מצב זה מופעל, פונקציות שאינן כוללות נתונים, כמו הפעלת משחקים ומוסיקה, הופכות ללא זמינות.

1 במסך ההגדרות, הקש על **רשתות** > **עוד** > **מצב טיסה**.

2 הקש על **הפעל** במסך האישור.

רשתות ניידות

תוכל להתאים אישית את הגדרות הנתונים לנייד.

1 במסך ההגדרות, הקש על **רשתות** > **עוד** > **רשתות ניידות**.

2 התאם אישית את ההגדרות הבאות:

- **נתונים ניידים**: הפעל או כבה נתונים לנייד.
- **נדידת נתונים**: גלוש באינטרנט, השתמש בדוא"ל, בהודעות מולטימדיה ובשירותים אחרים בחו"ל.
- **סוג רשת**: בחרו סוג רשת.
- **שמות נקודות גישה**: הצג או שנה את נקודת הגישה לשימוש בשירותי נתונים לנייד. כדי לשנות את נקודת הגישה, בחר אפשרות מתוך רשימת נקודות הגישה.
- **מפעילי רשת סלולרית**: חפש מפעילי רשת סלולרית והתחבר באופן אוטומטי לרשת.

VPN

תוכל להתחבר לרשת וירטואלית בטוחה, כמו אינטראנט. תוכל גם לנהל רשתות פרטיות וירטואליות מחוברות.

הוספת VPN

1 במסך ההגדרות, הקש על **רשתות** > **עוד** > **VPN**.

- ⚠ זכור, שביטול נעילת המסך יגרום למחיקת כל פרטי ה-VPN השמורים במכשיר.

2 הקש על **הוסף VPN**.

- תכונה זו זמינה רק כאשר נעילת המסך מופעלת. אם נעילת המסך מבוטלת, מופיע מסך התראות. הקש על **הגדרות** במסך ההתראות כדי להפעיל את נעילת המסך. לפרטים, ראה *קבע הגדרות נעילת מסך*.

3 הזן פרטי VPN והקש על **שמור**.

קביעת ההגדרות של VPN

1 הקש על VPN ברשימה **רשתות VPN**.

2 הזן את פרטי חשבון המשתמש של VPN והקש על **התחבר**.

- כדי לשמור את פרטי החשבון, סמן את התיבה **שמור פרטי חשבון**.

הדפסה

תוכל לחבר את המכשיר למדפסת Bluetooth ולהדפיס תמונות או מסמכים השמורים במכשיר.

1 במסך ההגדרות, הקש על **רשתות** > **עוד** > **הדפסה**.

- אם המדפסת הרצויה אינה מצוינת ברשימה, התקן את מנהל ההתקן של המדפסת מחנות היישומים.

2 גרור את כדי להפעיל אפשרות זו.

3 בחר מדפסת במסך רשימת המדפסות.

- כדי להוסיף מדפסת, הקש על ⋮ > **הוסף מדפסת**.
- כדי לחפש שם מדפסת, הקש על ⋮ > **חפש**.
- הקש על ⋮ > **הגדרות** במסך רשימת המדפסות.

4 בחר קובץ והקש על ⋮ > **הדפס**.

- המסמך מודפס.

- אם אין לך חשבון Google, הקש על **הוסף חשבון** כדי ליצור חשבון.

צליל והתראה

תוכל להתאים אישית את הגדרות הקול, הרטט וההתראות.

במסך ההגדרות, הקש על **צליל והתראה** והתאם אישית את ההגדרות הבאות:

- **פרופילי צליל**: שנה את מצב הצליל **צליל**, **רטט בלבד** או **שקט**.
- **עוצמה**: התאם את עוצמת הצליל של פריטים שונים.
- **צלצול**: בחר רינגטון לשיחות נכנסות. הוסף או מחק רינגטונים.
- **צלצול מותאם**: צור רינגטון לשיחה נכנסת מאיש קשר מסוים.
- **צליל עם רטט**: קבע כי המכשיר יפעיל רטט וישמיע רינגטון בו-זמנית.
- **סוג רטט**: תוכל לבחור סוג רטט או ליצור תבנית רטט משלך.
- **נא לא להפריע**: הגדר את השעה, הטווח וסוג היישום לקבלת הודעות של התראות. קבל הודעות של התראות בימים מסוימים בשבוע בלבד.
- **מסך נעילה**: הצג או הסתר הודעת התראה במסך הנעילה. תוכל גם להסתיר מידע פרטי.
- **יישומים**: בחר את היישומים שיורשו להציג התראות במסך וקבע סדר עדיפות ביניהם בהקשר עם התראות והודעות.
- **עוד** > **צליל התראה**: בחר רינגטון להתראה. הגדר מוסיקה שנשמרה במכשיר כרינגטון להתראה.
- **עוד** > **אפקטים קוליים**: בחר אפקט קול שיושמע כאשר תקיש על מקש החיוג או על המקלדת, כאשר תבחר אפשרות או כאשר תנעל או תבטל נעילה של המסך.
- **עוד** > **התראות קוליות על הודעות/שיחות**: הגדר את המכשיר כך שיקריא בקול את פרטי המתקשר או ההודעה.

תצוגה

תוכל להתאים אישית הגדרות מפורטות לכל סוג מסך.

במסך ההגדרות, הקש על **תצוגה** והתאם אישית את ההגדרות הבאות:

- **מסך ראשי**: התאם אישית את הגדרות המסך הראשי. לפרטים, ראה *הגדרות מסך בית*.
- **מסך נעילה**: התאם אישית את הגדרות מסך הנעילה. לפרטים, ראה *הגדרות נעילת מסך*.
- **ערכת נושא**: בחר ערכת נושא של מסך עבור ההתקן שלך.
- **לחצני תצוגה**: סדר מחדש את לחצני המגע של המסך הראשי או שנה את צבעי הרקע שלהם. הסתר את לחצני המגע של המסך הראשי על המסך.
- **סוג גופן**: שנה את סוג הגופן.
- **גודל גופן**: שנה את גודל הגופן.
- **טקסט מודגש**: הדגש את הטקסט על במסך.
- **בהירות**: השתמש במחוון כדי לשנות את בהירת המסך של המכשיר. כדי לכוונן באופן אוטומטי את בהירות המסך בהתאם לעוצמת תאורת הסביבה, הקש על **אוטומטי**.
- **אוטומטי**: הגדר את המכשיר כך שבהירות המסך תותאם באופן אוטומטי לעוצמת התאורה בסביבה.
- **תצוגה נוחה**: הגדר את המכשיר להפחתת כמות האור הכחול על המסך כדי לצמצם את מאמץ העיניים.
- **סיבוב מסך אוטומטי**: סובב באופן אוטומטי את המסך בהתאם לכיוון המכשיר.
- **כיבוי מסך אוטומטי**: כבה באופן אוטומטי את המסך כאשר המכשיר לא היה פעיל במשך פרק זמן שצוין.
- **עוד** > **גודל תצוגה**: הגדל או הקטן את המסך.
- **עוד** > **KnockOn**: הפעל או כבה את המסך על-ידי הקשה על המסך פעמיים.
- **עוד** > **שומר מסך**: הצג שומר מסך כאשר המכשיר מחובר למחזיק או למטען. בחר את סוג שומר המסך שיוצג.

- **עוד** > **כיול חיישן תנועה**: תקן את הזווית והמהירות של חיישן התנועה כדי לשפר את דיוק ההטיה ומהירות הפעולה של החיישן.

- כאשר תתקן את חיישן התנועה, הקפד להניח את המכשיר על משטח שטוח. אם לא תעשה זאת, תתרחש שגיאה הקשורה לפונקציות חיישן התנועה, כמו סיבוב מסך אוטומטי.

כללי

שפה ומקלדת

תוכל להתאים אישית את הגדרות השפה והמקלדת עבור המכשיר שלך.

1 במסך ההגדרות, הקש על **כללי** > **שפה ומקלדת**.

2 התאם אישית את ההגדרות הבאות:

- **שפה**: בחר שפה והחל אותה על המכשיר.
- **מקלדת נוכחית**: הצג את המקלדת שנמצאת כעת בשימוש. בחר מקלדת לשימוש בעת הזנת טקסט.
- **מקלדת LG**: התאם אישית את הגדרות מקלדת LG.
- **הקלדת קולית של Google**: בחר אפשרויות להכתבת טקסט מאת Google.
- **פלט המרת טקסט לדיבור**: בחר את ההגדרות לפלט טקסט-לדיבור.
- **מהירות מצביע**: כוונן את מהירות המצביע של העכבר או של לוח המעקב.
- **המרת לחצנים**: הגדר ביצוע פעולות ראשיות בתפעול ישיר דרך הלחצן הימני של העכבר.

מיקום

באפשרותך להתאים אישית את האופן שבו יישומים מסוימים יעשו שימוש בפרטי המיקום שלך.

1 במסך ההגדרות, הקש על **כללי** > **מיקום**.

2 התאם אישית את ההגדרות הבאות:

- **מצב**: בחר שיטה לאספקת פרטי המיקום שלך.
- **בקשת מיקום האחרונה**: הצג יישומים שביקשו לאחרונה פרטי מיקום.
- **היסטוריית המיקומים של Google**: קבע הגדרות היסטוריית מיקום של Google.

חשבונות וסנכרון

תוכל להוסיף או לנהל חשבונות, כולל חשבון Google. תוכל גם לסנכרן יישומים או פרטי משתמש מסוימים באופן אוטומטי.

1 במסך ההגדרות, הקש על **כללי** > **חשבונות וסנכרון**.

2 התאם אישית את ההגדרות הבאות:

- **לסנכרן נתונים באופן אוטומטי**: סנכרן את כל החשבונות הרשומים באופן אוטומטי.
- **חשבונות**: הצג רשימה של החשבונות הרשומים. כדי להציג או לשנות פרטים של חשבון, הקש על החשבון.
- **הוסף חשבון**: הוסף חשבונות.

נגישות

תוכל לנהל יישומי Plug-in של נגישות המותקנים במכשיר שלך.

1 במסך ההגדרות, הקש על **כללי** > **נגישות**.

2 התאם אישית את ההגדרות הבאות:

- **ראייה** > **TalkBack**: הגדר את המכשיר כך שיודיע על סטטוס המסך או על פעולות באמצעות קול.
- **ראייה** > **התראות קוליות על הודעות/שיחות**: הגדר את המכשיר כך שיקריא בקול את פרטי המתקשר או ההודעה.
- **ראייה** > **גודל גופן**: שנה את גודל הגופן.
- **ראייה** > **טקסט מודגש**: הדגש את הטקסט על במסך.
- **ראייה** > **גודל תצוגה**: הגדל או הקטן את המסך.
- **ראייה** > **שינוי גודל תצוגה במגע**: הגדל או הקטן את התצוגה על-ידי הקשה על המסך שלוש פעמים.
- **ראייה** > **חלון זום**: הגדל או הפוך חלק מהמסך.
- **ראייה** > **סמן עכבר גדול**: הגדל את סמן העכבר.
- **ראייה** > **מסך בעל ניגודיות גבוהה**: הפוך את צבע הרקע לשחור כדי להשיג מסך בניגודיות גבוהה.
- **ראייה** > **היפוך צבעי המסך**: הגבר את ניגודיות הצבע בתצוגה לטובת אנשים עם לקות ראייה.
- **ראייה** > **התאמה אישית של צבעי המסך**: כוונן את צבע התצוגה.
- **ראייה** > **גווני אפור**: העבר את המסך למצב גווני אפור.
- **ראייה** > **סיים שיחות באמצעות מקש ההפעלה**: סיים שיחה על-ידי לחיצה על מקש הפעלה/נעילה.
- **שמיעה** > **כתובית**: הפעל את שירות הכתוביות בעת הקרנת סרטוני וידאו לאנשים כבדי שמיעה.
- **שמיעה** > **התראות פלש**: הגדר את המכשיר כך שיודיע על שיחות נכנסות ועל התראות באמצעות נורית מהבהבת.
- **שמיעה** > **כבה את כל הצלילים**: השתק את כל הצלילים והנמך את עוצמת הקול במקלט.
- **שמיעה** > **סוג אודיו**: בחר את סוג השמע.

- **שמיעה** > **איזון קול**: כוונן את איזון פלט השמע. השתמש במחוון כדי לשנות את האיזון.
- **תנועה ותודעה** > **Touch assistant**: הפעל את לוח המגע כדי להקל את השימוש בלחצנים ובמחוות.
- **תנועה ותודעה** > **קלט בנגיעה**: כדי להזין טקסט, הקש הקשה ממושכת על המסך או שנה אותו על-ידי נגיעה במסך.
- **תנועה ותודעה** > **מקלדת פיזית**: התאם אישית את הגדרות המקלדת.
- **תנועה ותודעה** > **לחיצת עכבר אוטומטי**: לחץ באופן אוטומטי על סמן העכבר במקרה שאין תנועה.
- **תנועה ותודעה** > **לחץ לחיצה ממושכת לשיחות**: השב לשיחות או דחה שיחות על-ידי הקשת הקשה ממושכת על לחצן השיחה במקום לגרור אותו.
- **תנועה ותודעה** > **כיבוי מסך אוטומטי**: כבה באופן אוטומטי את המסך כאשר המכשיר לא היה פעיל במשך פרק זמן שצוין.
- **תנועה ותודעה** > **אזורי בקרת מגע**: הגבל את אזור המגע כך שניתן יהיה לשלוט חלק מסוים של המסך בלבד באמצעות קלט המגע.
- **קיצור דרך לתכונות הנגישות**: קבל במהירות גישה לפונקציות בשימוש נפוץ על-ידי הקשה על ◯ שלוש פעמים.
- **סיבוב מסך אוטומטי**: שנה באופן אוטומטי את כיוון המסך בהתאם למצב הפיזי של המכשיר.
- **שינוי אופן גישה**: צור צירופי מקשים שיסייעו לך לשלוט במכשיר שלך.

מקש קיצור דרך

תוכל להשתמש במקשי עוצמת הקול כדי להפעיל יישירות יישומים כאשר המסך כבוי או נעול.

1 במסך ההגדרות, הקש על **כללי** > **מקש קיצור דרך**.

2 גרור את כדי להפעיל אפשרות זו.

- לחץ פעמיים על מקש החלשת עוצמת הקול (-) כדי להפעיל את היישום **מצלמה** כאשר המסך נעול או כבוי. לחץ פעמיים על מקש הגברת עוצמת הקול (+) כדי להפעיל את **Capture+**.

שירותי Google

תוכל להשתמש בהגדרות Google לניהול יישומי Google שברשותך והגדרות החשבון שלך.

במסך ההגדרות, הקש על **כללי** > **שירותי Google**.

אבטחה

1 במסך ההגדרות, הקש על **כללי** > **אבטחה**.

2 התאם אישית את ההגדרות הבאות:

- **נעילת תוכן**: הגדר את השיטה לנעילת קבצים ב **QuickMemo+**.
- **הצפן אחסון כרטיס SD**: הצפן את כרטיס הזיכרון כדי למנוע שימוש במכשיר אחר. לפרטים, ראה *הצפנת כרטיס זיכרון*.
- **אתחול מאובטח**: הגן על המכשיר שלך בעזרת מנעול בעת שהוא מופעל. לפרטים, ראה *הגדרות הפעלה מאובטחת*.
- **הגדר נעילת כרטיס SIM**: נעל או בטל נעילה של כרטיס ה-USIM, או שנה את הסיסמה (PIN).
- **הקלדת סיסמה גלויה**: הצג סיסמה בזמן שאתה מזין אותה.
- **מנהלי התקנים**: אפשר הרשאות להגבלת השליטה או השימוש במכשיר עבור יישומים מסוימים.
- **מקורות לא מוכרים**: אפשר התקנה של יישומים מיישומים שאינם מחנות Play.

- **הגנה על אישורים**: הצג את סוג האחסון שבו אישור האבטחה יישמר.
- **תעודת ניהול**: נהל את אישור האבטחה השמור בהתקן.
- **Trust agents**: הצג והשתמש בסוכנים אמינים המותקנים במחשב.
- **קביעת מסך**: תקן את מסך היישום כדי לאפשר שימוש ביישום הפעיל כעת בלבד.
- **גישה לשימוש**: הצג פרטים על השימוש ביישומים במכשיר.

תאריך ושעה

תוכל להתאים אישית את הגדרות התאריך והשעה עבור המכשיר שלך.

1 במסך ההגדרות, הקש על **כללי** > **תאריך ושעה**.

2 התאם אישית את ההגדרות.

אחסון

תוכל להציג ולנהל את האחסון הפנימי במכשיר או בשטח האחסון של כרטיס הזיכרון.

1 במסך ההגדרות, הקש על **כללי** > **אחסון**.

2 התאם אישית את ההגדרות הבאות:

- **אחסון בהתקן**: הצג את שטח האחסון הכולל ופנה שטח באחסון הפנימי של המכשיר. הצג רשימה של יישומים שנמצאים בשימוש ואת קיבולת האחסון עבור כל יישום.
- **אחסון נייד**: הצג את שטח האחסון הכולל ואת השטח הפנוי בכרטיס הזיכרון. אפשרות זו מופיעה רק כאשר הוכנס כרטיס זיכרון. כדי לבטל טעינה של כרטיס זיכרון, הקש על ⏏.

חיסכון בחשמל ובסוללה

תוכל להציג את פרטי הסוללה הנוכחית או להפעיל מצב חיסכון בחשמל.

1 במסך ההגדרות, הקש על **כללי** > **חיסכון בחשמל ובסוללה**.

2 התאם אישית את ההגדרות הבאות:

- **ניצול סוללה**: הצג את \בפרטי השימוש בסוללה. כדי להציג פרטים נוספים, בחר פריט ספציפי.
- **אחוז הסוללה בשורת המצב**: הצג את רמת טעינת הסוללה שנותרה כאחוז בשורת המצב.
- **חיסכון בחשמל**: הקטן את צריכת הסוללה על-ידי ביטול הגדרות מכשיר מסוימות, כמו בהירות התצוגה, המהירות ועוצמת הרטט. בשורת המצב מופיע כאשר מצב חיסכון בחשמל מופעל.

זיכרון

תוכל להציג את הסכום הממוצע של השימוש בזיכרון לאורך פרק זמן מסוים ואת הזיכרון שהיה בשימוש על-ידי היישום.

1 במסך ההגדרות, הקש על **כללי** > **זיכרון**.

2 הקש על ▾ כדי להגדיר משבצת זמן לאחזור נתונים.

יישומים

תוכל להציג רשימה של יישומים מותקנים. בעת הצורך, עצור יישומים פועלים או מחק יישומים.

1 במסך ההגדרות, הקש על **כללי** > **יישומים**.

2 בחר יישום ובצע פעולות.

גיבוי ואיפוס

תוכל לגבות נתונים השמורים במכשיר שלך במכשיר או בטאבלט אחר של LG. אפס את המכשיר, בעת הצורך.

1 במסך ההגדרות, הקש על **כללי** > **גיבוי ואיפוס**.

2 התאם אישית את ההגדרות הבאות:

- **LG Backup**: גבה או שחזר את רשימת השולחים החסומים, ההודעות, התמונות, המסכים הראשיים ונתונים אחרים שנשמרו במכשיר. לפרטים, ראה *LG Backup* .
- **גבה את הנתונים שלי**: גבה את נתונים היישום שלך, את סיסמאות Wi-Fi והגדרות אחרות לשרת Google.
- **חשבון גיבוי**: הצג את חשבון הגיבוי הנוכחי שנמצא בשימוש.
- **שחזור אוטומטי**: שחזר באופן אוטומטי הגדרות גיבוי ונתונים בעת התקנה מחדש של יישום.
- **איפוס הגדרות רשת**: אפס את Wi-Fi, Bluetooth והגדרות רשת אחרות.
- **שחזור נתוני היצרן**: אפס את כל ההגדרות עבור המכשיר ומחק נתונים.

- פעולת איפוס המכשיר מוחקת את כל הנתונים השמורים בו. הזן את שם המכשיר, את חשבון Google ופרטים התחלתיים אחרים פעם נוספת.

אודות הטלפון

תוכל להציג מידע אודות המכשיר, כמו שם, הסטטוס, פרטי התוכנה ומידע משפטי.

במסך ההגדרות, הקש על **כללי** > **אודות הטלפון** והצג מידע.

05

נספח

הגדרות השפה של LG

בחר את השפה שתשמש במכשיר שלך.

- הקש על ◯ > **הגדרות** > **כללי** > **שפה ומקלדת** > **שפה** > **הוספת שפה** ובחר שפה.
  - הקש הקשה ממושכת על ☰ וגרור אותה לחלק העליון של רשימת השפות כדי להגדיר אותה כשפת ברירת מחדל.

LG Bridge

LG Bridge - סקירה כללית

LG Bridge הוא יישום המסייע לך בניהול נוח של תמונות, מוסיקה, סרטוני וידאו ומסמכים השמורים בטלפון החכם של LG דרך המחשב שלך. באמצעות היישום תוכל לגבות אנשי קשר, תמונות ופריטים נוספים במחשב ואף לעדכן את תוכנת המכשיר.

- לפרטים, עיין בעזרה של LG Bridge.
- זמינות של תכונות נתמכות אינה אחידה ותלויה במכשיר.
- מנהל התקן USB של LG נחוץ לך כדי לחבר טלפון חכם של LG אל המחשב והוא יותקן יחד עם LG Bridge.

הפונקציות הכלולות ביישום LG Bridge

- נהל דרך המחשב שלך את הקבצים השמורים במכשיר באמצעות חיבור Wi-Fi או חיבור נתונים ניידים.
- גבה נתונים מהמכשיר במחשב שלך או שחזר אותם מהמחשב באמצעות כבל USB.
- עדכן את תוכנת המכשיר דרך המחשב שלך באמצעות כבל USB.

התקנת LG Bridge במחשב

1 במחשב שלך, עבור אל *www.lg-mobile.co.il*.

2 בשורת החיפוש, הקלד את שם המכשיר שברשותך.

3 לחץ על **Download Centre** > **LG Bridge** והורד את קובץ ההתקנה.

- לחץ על **פרטים** כדי להציג את דרישות המינימום להתקנת LG Bridge.

עדכון תוכנת הטלפון

עדכון תוכנת הטלפון הנייד של LG מהאינטרנט

למידע נוסף אודות השימוש בפונקציה זו, בקר בכתובת *http://www.lg.com/common/index.jsp* בחר את המדינה והשפה שלך.

תכונה זו מאפשרת לך לעדכן בנוחות את הקושחה של הטלפון לגרסה חדשה יותר מהאינטרנט, ללא צורך לבקר במרכז שירות. תכונה זו תהיה זמינה רק אם LG תייצר גרסת קושחה חדשה שתהיה זמינה למכשיר שלך.

מאחר שעדכון הקושחה של הטלפון הנייד דורש את תשומת לבו המלאה של המשתמש במשך כל תהליך העדכון, הקפד לקרוא את כל ההוראות וההערות שיופיעו בכל שלב לפני שתתקדם הלאה. חשוב לזכור שניתוק כבל ה-USB במהלך השדרוג עלול לגרום נזק חמור לטלפון הנייד.

- LG שומרת על זכותה, על פי שיקול דעתה הבלעדי, להפוך עדכוני קושחה לזמינים עבור דגמים נבחרים בלבד ואינה ערבה לזמינות הגירסה החדשה של הקושחה לכל דגמי הטלפון.

עדכון תוכנת הטלפון הנייד של LG באופן אלחוטי (OTA)

תכונה זו מאפשרת לך לעדכן בנוחות את תוכנת הטלפון לגרסה חדשה יותר בשיטת OTA, מבלי לחבר כבל USB. תכונה זו תהיה זמינה רק אם LG תייצר גרסת קושחה חדשה שתהיה זמינה למכשיר שלך.

תחילה בדוק את גרסת התוכנה בטלפון הנייד:

הקש על ◯ > **הגדרות** > **כללי** > **אודות הטלפון** > **מרכז עדכונים** > **עדכון תוכנה** > **חפש עדכונים כעת**.

- הנתונים האישיים שלך משטח האחסון הפנימי בטלפון—לרבות פרטי חשבון Google וכל חשבון אחר, נתונים והגדרות של המערכת/היישומים שלך, יישומים שהורדו ורישיון ה-DRM שלך—עשויים ללכת לאיבוד בתהליך עדכון התוכנה של הטלפון. לפיכך, LG ממליצה לך לגבות את הנתונים האישיים שלך לפני שתעדכן את תוכנת הטלפון. LG לא תישא באחריות לאובדן נתונים אישיים כלשהם.
- הזמינות של תכונה זו תלויה באזור ובספק השירות.

שאלות נפוצות

בפרק זה מוצגות מספר בעיות שאתה עלול להיתקל בהן במהלך השימוש בטלפון. בעיות מסוימות יצריכו פנייה לספק השירות, אך את רובן תוכל לפתור בקלות בעצמך.

הודעה	סיבות אפשריות	אפשרויות לתיקון הבעיה
שגיאת כרטיס SIM	אין כרטיס SIM בטלפון או שהוא הוכנס בצורה לא נכונה.	ודאו שכרטיס ה-SIM הוכנס כראוי.
אין חיבור לרשת/ החיבור חלש	האות חלש או שאתה נמצא מחוץ לטווח הרשת של ספק השירות.	התקרב לחלון או צא לאזור פתוח. בדוק את מפת הכיסוי של מפעיל הרשת הסלולרית.
	המפעיל החיל שירותים חדשים.	בדוק אם גילו של כרטיס ה-SIM עולה על 6-12 חודשים. אם כן, החלף את כרטיס ה-SIM או ה-USIM בחנות הקרובה ביותר של ספק הרשת. פנה אל ספק השירות.
הקודים אינם תואמים	כדי לשנות קוד אבטחה, הזן שוב את הקוד החדש כדי לאשרו.	אם שכחת את הקוד, פנה אל ספק השירות.
	שני הקודים שהזנו אינם תואמים	
לא ניתן להגדיר יישומים	הם לא נתמכים על-ידי ספק השירות או שנדרש רישום עבורם.	פנה אל ספק השירות.
יישום שהורדתי קורים לשגיאות רבות.	הסר את היישום.	1. הקש על ◯ > **הגדרות**. 2. הקש על **כללי** > **יישומים**. 3. הקש על היישום > **הסר התקנה**.

הודעה	סיבות אפשריות	אפשרויות לתיקון הבעיה
לא ניתן לבצע שיחות	טעות בחיוג	רשת חדשה לא מאושרת.
	הוכנס כרטיס SIM חדש.	בדוק אם קיימות מגבלות חדשות.
	הגעת למגבלת החיוב ששולם מראש.	צור קשר עם חברת הסלולר או אפס את המגבלה בעזרת PIN2.
לא ניתן להפעיל את הטלפון	מקש הדלקה/כיבוי נלחץ מהר מדי.	לחץ על מקש ההפעלה/כיבוי למשך שתי שניות לפחות.
	הסוללה לא נטענה.	טען את הסוללה. בדוק את מחוון הטעינה בתצוגה.
שגיאת טעינה	הסוללה לא נטענה.	טען את הסוללה.
	הטמפרטורה החיצונית גבוהה או נמוכה מדי.	ודא שהטלפון נטען בטמפרטורה הרגילה.
	בעיית מגעים	בדוק את המטען ואת החיבור שלו לטלפון.
	אין מתח	חברו את המטען לשקע אחר.
	המטען פגום	החלף את המטען.
	מטען לא מתאים	השתמש רק באביזרים מקוריים של LG.
המספר אסור.	פונקציית מספר קבוע מראש פועלת.	בדוק את התפריט 'הגדרות' ונטרל את הפונקציה.
לא ניתן לקבל/לשלוח הודעות SMS ותמונות	הזיכרון מלא	בחר נתונים מסוימים, כמו יישומים או הודעות מהטלפון שלך, כדי לפנות זיכרון.

הודעה	סיבות אפשריות	אפשרויות לתיקון הבעיה
הקבצים אינם נפתחים	אין תמיכה בתבנית הקובץ	בדוק את תבניות הקובץ הנתמכות.
המסך אינו נדלק כאשר מתקבלת שיחה.	בעיה בחיישן הקרבה	אם אתה משתמש בנרתיק או כיסוי להגנה, ודא שהוא אינו מכסה את האזור שסביב חיישן הקרבה. ודא שהאזור שמסביב לחיישן הקרבה נקי.
אין צליל	מצב רטט	בדוק את מצב ההגדרות בתפריט הצליל כדי לוודא שאינך במצב רטט או במצב 'ללא הפרעות'.
ניתוק או קפיאה	בעיה של נתק בתוכנה	אם המסך קופא או שהטלפון אינו מגיב כשמנסים להפעיל אותו, הוצא את הסוללה והכנס אותה בחזרה. לאחר מכן הפעל שוב את הטלפון. לחלופין, נסה לעדכן את התוכנה דרך אתר האינטרנט.

מדריך למניעת גניבה

הגדר את המכשיר שלך כך שאנשים אחרים לא יוכלו להשתמש בו אם הוא יאופס להגדרות היצרן ללא רשותך. לדוגמה, אם המכשיר אבד, נגנב או נמחק, רק אדם בעל חשבון Google או בעל פרטי נעילת מסך יוכל להשתמש במכשיר.

כל שעליך לעשות כדי לוודא שהמכשיר שלך מוגן הוא:

- להגדיר נעילת מסך: אם המכשיר אבד או נגנב, אך הגדרת נעילת מסך, לא תהיה אפשרות למחוק את המכשיר באמצעות תפריט 'הגדרות', כל עוד נעילת המסך לא תבוטל.
- הוסף את חשבון Google שלך למכשיר: אם המכשיר שלך נמחק אך הגדרת בו את חשבון Google שלך, לא תהיה אפשרות לסיים את תהליך ההגדרה של המכשיר עד שהפרטים של חשבון Google יוזנו שוב.

לאחר שהמכשיר יהיה מוגן, תצטרך לבטל את נעילת המסך או להזין את הסיסמה של חשבון Google אם עליך לבצע איפוס להגדרות היצרן. הדבר יבטיח שאתה או מישהו שאתה סומך עליו תבצעו את האיפוס.

- אל תשכח את חשבון Google והסיסמה שהוספת למכשיר לפני ביצוע האיפוס להגדרות היצרן. אם אינך יכול לספק את פרטי החשבון במשך תהליך ההגדרה, לא תוכל להשתמש כלל במכשיר לאחר ביצוע האיפוס להגדרות היצרן.

מידע נוסף

פרטי הודעה על תוכנת קוד פתוח

אנא בקרו באתר *http://opensource.lge.com* על מנת להשיג את קוד המקור תחת MPL, LGPL, GPL , קוד פתוח ורשיונות אחרים.

בנוסף לקוד המקור, זמינים להורדה תנאי הרשיון, אחריות, כתבי ויתור וזכויות יוצרים.

LG Electronics תספק קוד מקור על גבי התקליטור, תמורת תשלום המכסה הוצאות של ביצוע ואחסון.

לבקשה ניתן לפנות לכתובת הדואר האלקטרוני : *opensource@lge.com*. הצעה זו תקפה למשך (3) שנים ממועד הרכישה.

סימנים מסחריים

- Copyright ©2017 LG Electronics, Inc. כל הזכויות שמורות. LG והסמל של LG הם סימנים מסחריים רשומים של LG Group ושל החברות הקשורות אליה.
- ™Google, ™Google Maps, ™Gmail, ™YouTube, ™Duo ו-Play ™Store הם סימנים מסחריים של Google, Inc.
- ®Bluetooth הוא סימן מסחרי רשום של . Bluetooth SIG, Inc ברחבי העולם.
- ®Wi-Fi והלוגו של Wi-Fi הם סימנים מסחריים רשומים של Wi-Fi Alliance.
- כל יתר הסימנים המסחריים וזכויות היוצרים הם רכושם של בעליהם בהתאמה.

הצהרת תאימות

בזאת, **LG Electronics** מצהירה שהמוצר **LG-M250Y** תואם לדרישות היסודיות ולתנאים ה רלוונטיים האחרים של הנחיה **2014/53/EU**. ניתן למצוא עותק של הצהרת התאימות בכתובת *http://www.lg.com/global/declaration*

About this user guide

Thank you for choosing this LG product. Please carefully read this user guide before using the device for the first time to ensure safe and proper use.

- Always use genuine LG accessories. The supplied items are designed only for this device and may not be compatible with other devices.
- This device is not suitable for people who have a visual impairment due to the touchscreen keyboard.
- Descriptions are based on the device default settings.
- Default apps on the device are subject to updates, and support for these apps may be withdrawn without prior notice. If you have any questions about an app provided with the device, please contact an LG Service Centre. For user-installed apps, please contact the relevant service provider.
- Modifying the device's operating system or installing software from unofficial sources may damage the device and lead to data corruption or data loss. Such actions will violate your LG licence agreement and void your warranty.
- Some content and illustrations may differ from your device, depending on the area, service provider, software version, or OS version, and are subject to change without prior notice.
- Software, audio, wallpaper, images, and other media supplied with your device are licenced for limited use. If you extract and use these materials for commercial or other purposes, you may be infringing copyright laws. As a user, you are fully responsible for the illegal use of media.
- Additional charges may incur for data services, such as messaging, uploading,downloading, auto-syncing and location services. To void additional charges, select a data plan suitable to your needs. Contact your service provider to obtain additional details.

Instructional notices



WARNING: Situations that could cause injury to the user and third parties.



CAUTION: Situations that may cause minor injury or damage to the device.



NOTE: Notices or additional information.

Table of contents

5 Guidelines for safe and efficient use

01

Custom-designed Features

13 Wide-angle camera
14 Multi-tasking feature
16 quick share

02

Basic Functions

18 Product components and accessories
19 Parts overview
21 Turning the power on or off
22 Installing the SIM card and battery
24 Inserting the memory card
25 Removing the memory card
25 Charging the battery
27 Touch screen
30 Home screen
37 Screen lock
40 Memory card encryption
41 Taking screenshots
42 Entering text
48 Do not disturb

03

Useful Apps

50 Installing and uninstalling apps
51 Uninstalled apps
52 Phone
56 Messaging
57 Camera
64 Gallery
67 Music
68 E-mail
70 Calendar
71 QuickMemo+
73 Calculator
74 Clock
75 Downloads
75 File Manager
75 FM Radio
76 Voice Recorder
76 Contacts
78 LG SmartWorld
79 Tasks
79 LG Backup
80 Evernote
80 Facebook
80 Instagram
80 Chrome
80 Google apps

04

Phone Settings

84 Settings
84 Networks
93 Sound & notification
94 Display
95 General

05

Appendix

104 LG Language Settings
104 LG Bridge
105 Phone software update
107 FAQ
110 Anti-Theft Guide
111 More information

Guidelines for safe and efficient use

Please read these simple guidelines. Not following these guidelines may be dangerous or illegal.

Should a fault occur, a software tool is built into your device that will gather a fault log. This tool gathers only data specific to the fault, such as signal strength, cell ID position in sudden call drop and applications loaded. The log is used only to help determine the cause of the fault. These logs are encrypted and can only be accessed by an authorised LG Repair centre should you need to return your device for repair.

Exposure to radio frequency energy

Radio wave exposure and Specific Absorption Rate (SAR) information.

This device has been designed to comply with applicable safety requirements for exposure to radio waves. These requirements are based on scientific guidelines that include safety margins designed to assure the safety of all persons, regardless of age and health.

- The radio wave exposure guidelines employ a unit of measurement known as the Specific Absorption Rate, or SAR. Tests for SAR are conducted using standardised methods with the device transmitting at its highest certified power level in all used frequency bands.
- While there may be differences between the SAR levels of various LG device models, they are all designed to meet the relevant guidelines for exposure to radio waves.
- The SAR limit recommended by the International Commission on Non-Ionizing Radiation Protection (ICNIRP) is 2 W/kg averaged over 10 g of tissue.
- The highest SAR value for this model tested for use at the ear is 0.541 W/kg (10 g) and when worn on the body is 1.310 W/kg (10 g).

- This device meets RF exposure guidelines when used either in the normal use position against the ear or when positioned at least 5 mm away from the body. When a carry case, belt clip or holder is used for body-worn operation, it should not contain metal and should position the product at least 5 mm away from your body. In order to transmit data files or messages, this device requires a quality connection to the network. In some cases, transmission of data files or messages may be delayed until such a connection is available. Ensure the above separation distance instructions are followed until the transmission is completed.

Product care and maintenance

- Always use genuine LG batteries, chargers and accessories approved for use with this particular device model. The use of any other types may invalidate any approval or warranty applying to the device and may be dangerous.
- Some contents and illustrations may differ from your device without prior notice.
- Do not disassemble this unit. Take it to a qualified service technician when repair work is required.
- Repairs under warranty, at LG's discretion, may include replacement parts or boards that are either new or reconditioned, provided that they have functionality equal to that of the parts being replaced.
- Keep away from electrical appliances such as TVs, radios and personal computers.
- The unit should be kept away from heat sources such as radiators or cookers.
- Do not drop.
- Do not subject this unit to mechanical vibration or shock.
- Switch off the device in any area where you are required to by special regulations. For example, do not use your device in hospitals as it may affect sensitive medical equipment.
- Do not handle the device with wet hands while it is being charged. It may cause an electric shock and can seriously damage your device.
- Do not charge a handset near flammable material as the handset can become hot and create a fire hazard.

- Use a dry cloth to clean the exterior of the unit (do not use solvents such as benzene, thinner or alcohol).
- Do not charge the device when it is on soft furnishings.
- The device should be charged in a well ventilated area.
- Do not subject this unit to excessive smoke or dust.
- Do not keep the device next to credit cards or transport tickets; it can affect the information on the magnetic strips.
- Do not tap the screen with a sharp object as it may damage the device.
- Do not expose the device to liquid or moisture.
- Use accessories like earphones cautiously. Do not touch the antenna unnecessarily.
- Do not use, touch or attempt to remove or fix broken, chipped or cracked glass. Damage to the glass display due to abuse or misuse is not covered under the warranty.
- Your device is an electronic device that generates heat during normal operation. Extremely prolonged, direct skin contact in the absence of adequate ventilation may result in discomfort or minor burns. Therefore, use care when handling your device during or immediately after operation.
- If your device gets wet, immediately unplug it to dry off completely. Do not attempt to accelerate the drying process with an external heating source, such as an oven, microwave or hair dryer.
- The liquid in your wet device, changes the colour of the product label inside your device. Damage to your device as a result of exposure to liquid is not covered under your warranty.

Efficient device operation

Electronics devices

All devices may receive interference, which could affect performance.

- Do not use your mobile phone near medical equipment without requesting permission. Please consult your doctor to determine if operation of your phone may interfere with the operation of your medical device.
- Pacemaker manufacturers recommend that you leave at least 15 cm of space between other devices and a pacemaker to avoid potential interference with the pacemaker.
- This device may produce a bright or flashing light.
- Some hearing aids might be disturbed by devices.
- Minor interference may affect TVs, radios, PCs etc.
- Use your device in temperatures between 0 °C and 40 °C, if possible. Exposing your device to extremely low or high temperatures may result in damage, malfunction, or even explosion.

Road safety

Check the laws and regulations on the use of devices in the area when you drive.

- Do not use a hand-held device while driving.
- Give full attention to driving.
- Pull off the road and park before making or answering a call if driving conditions so require.
- RF energy may affect some electronic systems in your vehicle such as car stereos and safety equipment.
- When your vehicle is equipped with an air bag, do not obstruct with installed or portable wireless equipment. It can cause the air bag to fail or cause serious injury due to improper performance.
- If you are listening to music whilst out and about, please ensure that the volume is at a reasonable level so that you are aware of your surroundings. This is of particular importance when near roads.

Avoid damage to your hearing



To prevent possible hearing damage, do not listen at high volume levels for long periods.

Damage to your hearing can occur if you are exposed to loud sound for long periods of time. We therefore recommend that you do not turn on or off the handset close to your ear. We also recommend that music and call volumes are set to a reasonable level.

- When using headphones, turn the volume down if you cannot hear the people speaking near you, or if the person sitting next to you can hear what you are listening to.

- Excessive sound pressure from earphones and headphones can cause hearing loss.

Glass Parts

Some parts of your device are made of glass. This glass could break if your device is dropped on a hard surface or receives a substantial impact. If the glass breaks, do not touch or attempt to remove it. Stop using your device until the glass is replaced by an authorised service provider.

Blasting area

Do not use the device where blasting is in progress. Observe restrictions and follow any regulations or rules.

Potentially explosive atmospheres

- Do not use your device at a refueling point.
- Do not use near fuel or chemicals.
- Do not transport or store flammable gas, liquid or explosives in the same compartment of your vehicle as your device or accessories.

In aircraft

Wireless devices can cause interference in aircraft.

- Turn your device off before boarding any aircraft.
- Do not use it on the ground without permission from the crew.

Children

Keep the device in a safe place out of the reach of small children. It includes small parts which may cause a choking hazard if detached.

Emergency calls

Emergency calls may not be available on all mobile networks. Therefore you should never depend solely on your device for emergency calls. Check with your local service provider.

Battery information and care

- You do not need to completely discharge the battery before recharging. Unlike other battery systems, there is no memory effect that could compromise the battery's performance.
- Use only LG batteries and chargers. LG chargers are designed to maximise the battery life.
- Do not disassemble or short-circuit the battery.
- Keep the metal contacts of the battery clean.
- Replace the battery when it no longer provides acceptable performance. The battery pack may be recharged hundreds of times before it needs replacing.
- Recharge the battery if it has not been used for a long time to maximise usability.
- Do not expose the battery charger to direct sunlight or use it in high humidity, such as in the bathroom.
- Do not leave the battery in hot or cold places, as this may deteriorate battery performance.

- Risk of explosion if battery is replaced by an incorrect type. Dispose of used batteries according to the instructions.
- If you need to replace the battery, take it to the nearest authorised LG Electronics service point or dealer for assistance.
- Always unplug the charger from the wall socket after the device is fully charged to save unnecessary power consumption of the charger.
- Actual battery life will depend on network configuration, product settings, usage patterns, battery and environmental conditions.
- Make sure that no sharp-edged items such as animal's teeth or nails, come into contact with the battery. This could cause a fire.

Securing personal information

- Make sure to protect your personal information to prevent data leakage or misuse of sensitive information.
- Always back up important data while using the device. LG is not responsible for any data loss.
- Make sure to back up all data and reset the device when disposing of the device to prevent any misuse of sensitive information.
- Read the permission screen carefully while downloading applications.
- Be cautious using the applications that have access to multiple functions or to your personal information.
- Check your personal accounts regularly. If you find any sign of misuse of your personal information, ask your service provider to delete or change your account information.
- If your device is lost or stolen, change the password of your account to secure your personal information.
- Do not use applications from unknown sources.

01


Custom-designed Features

Wide-angle camera

You can take photos or record videos with a wider range than your actual field of vision by using the wide-angle on the front camera.

Launch the Camera app, then tap [ ] / [ ] to switch between the standard and wide-angle.

Front camera



- See *Starting the camera* for details.


Multi-tasking feature


Multi-Window

You can use two apps at the same time by separating the screen into the multiple windows.

While using an app, touch and hold ☐ from the Home touch buttons, then select an app from the recently used apps list.

- You can use two apps displayed on the main screen at the same time.
- To stop the Multi-Window feature, touch and hold ⊟.





- You can use this feature in an app that supports the Multi-Window feature.
- The Multi-Window feature is not supported by some apps, including downloaded apps.

Overview screen

The Overview screen provides a preview of your recently used apps.

To view the list of recently used apps, tap ☐ on the Home, then tap the displayed app.


- Touch and hold an app and drag it to the top of the screen to start the app with the Multi-Window. You can also tap ⊟ at the top of each app.

quick share

You can share a photo or video to the app you want immediately after taking it.

1 Tap ◯ > , then take a photo or record a video.

2 Tap the app icon that appears on the screen to share it using that app. You can also swipe the icon towards the opposite direction to see what other apps you can use to share your photos and videos.



- The app displayed by the quick share icon may vary, depending on the type and frequency of access to the apps installed on the device.

02

Basic Functions

Product components and accessories


The following items are included with your device.


- Device
- Battery
- Stereo headset
- USB cable
- Charger
- Quick Start Guide

- The items described above may be optional.
- The items supplied with the device and any available accessories may vary depending on the area and service provider.
- Always use genuine LG Electronics accessories. Using accessories made by other manufacturers may affect your device's call performance or cause malfunctions. This may not be covered by LG's repair service.

- If any of these basic items are missing, contact the dealer from which you purchased your device.
- To purchase additional basic items, contact an LG Customer Service Centre.
- To purchase optional items, contact an LG Customer Service Centre for available dealers.
- Some items in the product box are subject to change without notice.
- The appearance and specifications of your device are subject to change without notice.
- Device specifications may vary depending on the area or service provider.
- Be sure to use authentic accessories provided by LG Electronics. Using third-party accessories may damage the device or cause malfunctions.

Parts overview





- Proximity/Ambient light sensor
  - Proximity sensor: During a call, the proximity sensor turns off the screen and disables touch functionality when the device is in close proximity to the human body. It turns the screen back on and enables touch functionality when the device is outside a specific range.
  - Ambient light sensor: The ambient light sensor analyses the ambient light intensity when the auto-brightness control mode is turned on.
- Volume keys
  - Adjust the volume for ringtones, calls or notifications.
  - While using the Camera, gently press a Volume key to take a photo. To take continuous shots of photos, press and hold the Volume key.
  - Press the Volume Down (-) key twice to launch the **Camera** app when the screen is locked or turned off. Press the Volume Up (+) key twice to launch **Capture+**.
- Power/Lock key
  - Briefly press the key when you want to turn the screen on or off.
  - Press and hold the key when you want to select a power control option.

- Some functions may be restricted for access, depending on the device specifications.

- Do not put heavy objects on the device or sit on it. Failure to do so may damage the touch screen.
- Screen-protective film or accessories may interfere with the proximity sensor.
- If your device is wet or is being used in a humid place, the touch screen or buttons may not function properly.

Turning the power on or off

Turning the power on

When the power is turned off, press and hold the Power/Lock key.

- When the device is turned on for the first time, initial configuration takes place. The first booting time for the smart phone may be longer than usual.

Turning the power off

Press and hold the Power/Lock key, then select **Power off**.

Power control options


Press and hold the Power/Lock key, then select an option.

- **Power off**: Turn off the device.
- **Power off and restart**: Restart the device.
- **Turn on Airplane mode**: Block telecommunication-related functions, including making phone calls, messaging and browsing the Internet. Other functions remain available.


Installing the SIM card and battery

Insert the SIM card provided by the device service provider, and the included battery.


1 To remove the back cover, hold the device firmly in one hand. With your other hand, lift off the back cover with your thumbnail as shown in the figure.




2 Slide the SIM card into the SIM card slot as shown in the figure. Make sure the gold contact area on the card is facing downward.



3 Insert the battery.



4 To replace the cover onto the device, align the back cover over the battery compartment and press it down until it clicks into place.



- This device supports only Nano SIM cards.
- For problem-free performance, it is recommended to use the phone with the correct type of SIM card. Always use a factory-made SIM card supplied by the operator.

Precautions when using the SIM card

- Do not lose your SIM card. LG is not responsible for damage and other issues caused by loss or transfer of a SIM card.
- Be careful not to damage the SIM card when you insert or remove it.


Inserting the memory card

Insert the memory card into your device.

The device can support up to a 2 TB microSD card. Depending on the memory card manufacturer and type, some memory card may not be compatible with your device.

1 Remove the back cover.

2 Insert a memory card with the gold-coloured contacts facing downwards.



3 Replace the back cover.

- Some memory cards may not be fully compatible with the device. If you use an incompatible card, it may damage the device or the memory card, or corrupt the data stored in it.

- Frequent writing and erasing of data may shorten the memory card lifespan.

Removing the memory card

Unmount the memory card before removing it for safety.

1 Tap ◯ > **Settings** > **General** > **Storage** > ⏏.


2 Remove the back cover and pull out the memory card.

⚠ • Do not remove the memory card while the device is transferring or accessing information. This may cause data to be lost or corrupted, or may damage the memory card or the device. LG is not responsible for losses that result from the abuse or improper use of memory cards, including the loss of data.

Charging the battery

Before using the device, fully charge the battery.

Connect one end of the charging cable to the charger, insert the other end of the cable into the cable port, and then plug the charger into a power socket.



- Make sure to use the USB cable provided with your device.
- Make sure to use an LG-approved charger, battery and charging cable. Charging the battery with a third-party charger may cause the battery to explode or may damage the device.
- Using the device when it is charging may cause electric shock. To use the device, stop charging it.

- Remove the charger from the power socket after the device is fully charged. This prevents unnecessary power consumption.
- Another way to charge the battery is by connecting a USB cable between the device and a desktop or laptop computer. This may take a longer time than charging the battery in the common way.
- Do not charge the battery by using a USB hub that is unable to maintain the rated voltage. Charging may fail or unintentionally stop.

Precautions when using the device

- When replacing the battery, take extra care to ensure that no foreign substances or water enter the device.
- Ensure that the inside of the device does not make contact with a metallic object or water.
- Make sure to use the USB cable provided; do not use third party USB cables or chargers with your device. The LG limited warranty does not cover the use of third party accessories.
- Failure to follow the instructions in this guide and improper use may damage the device.

Using the battery efficiently

Battery lifespan may decrease if you keep many apps and functions running simultaneously and continuously.

Cancel background operations to increase battery life.

To minimise battery consumption, follow these tips:

- Turn off the Bluetooth® or Wi-Fi network function when not using them.


- Set the screen timeout to as short a time as possible.
- Minimise the screen brightness.
- Set a screen lock when the device is not used.
- Check the battery usage details and close any downloaded apps that are draining the battery.

Touch screen

You can familiarise yourself with how to control your device by using touch screen gestures.


Tapping

Lightly tap with your fingertip to select or run an app or option.




Touching and holding

Touch and hold for several seconds to display a menu with available options.




Double-tapping

Tap twice quickly to zoom in or out on a web page or map.




Dragging

Tap an item, such as an app or widget, then move your finger to another location in a controlled motion. You can use this gesture to move an item.




Swiping


Tap the screen with your finger and move it quickly without pausing. You can use this gesture to scroll through a list, a web page, photos, screens, and more.



Pinching and spreading

Pinch two fingers to zoom out such as on a photo or map. To zoom in, spread your fingers apart.





- Do not expose the touch screen to excessive physical shock. You might damage the touch sensor.

- A touch screen failure may occur if you use the device near a magnetic, metallic or conductive material.
- If you use the device under bright lights, such as direct sunlight, the screen may not be visible, depending on your position. Use the device in a shady location or a location with an ambient light that is not too bright and bright enough to read books.
- Do not press the screen with excessive force.
- Gently tap with your fingertip on the option you want.
- Touch control may not work properly if you tap while wearing a glove or by using the tip of your fingernail.
- Touch control may not work properly if the screen is moist or wet.
- The touch screen may not function properly if a screen-protective film or accessory purchased from a third party store is attached to the device.

Home screen

Home screen overview

The Home screen is the starting point for accessing various functions and apps on your device. Tap ◯ on any screen to directly go to the Home screen.

You can manage all apps and widgets on the Home screen. Swipe the screen left or right to view all installed apps at a glance.

To search for an app, use Google search.

Home screen layout

You can view all apps and organise widgets and folders on the Home screen.



- The Home screen may vary, depending on the service provider or software version.


- **Status bar**: View status icons, the time and the battery level.
- **Weather widget**: View the information of weather and time for a specific area.
- **Google search widget**: Perform a Google search by inputting spoken or written keywords.
- **Folder**: Create folders to group apps by your preferences.
- **Page icon**: Display the total number of Home screen canvases. Tap the desired page icon to go to the page you selected. The icon reflecting the current canvas will be highlighted.
- **Quick access area**: Fix main apps at the bottom of the screen so that they can be accessed from any Home screen canvas.
- **Home touch buttons**
  - ◁ : Return to the previous screen. Close the keypad or pop-up windows.
  - ◯ : Tap to go to the Home screen. To launch Google search, touch and hold.
  - □ : Tap to view a list of recently used apps or run an app from the list. To delete all the recently used apps, tap **CLEAR ALL**. To use two apps at the same time with the Multi-Window feature, touch and hold the button while using an app.

Editing the Home touch buttons

You can rearrange the Home touch buttons or add frequently used functions to the Home touch buttons area.

Tap ◯ > **Settings** > **Display** > **Home touch buttons** > **Button combination** and customise the settings.

- Several functions, including QSlide, Notification panel and Capture+, are provided. A maximum of five items can be added.



Status icons

When there is a notification for an unread message, calendar event or alarm, the status bar displays the corresponding notification icon. Check your device's status by viewing notification icons displayed on the status bar.

	No signal
	Data is being transmitted over the network
	Alarm is set
	Vibrate mode is on
	Bluetooth is on
	Connected to a computer via USB
	Battery level
	Airplane mode is on
	Missed calls


	Wi-Fi is connected
	Mute mode is on
	GPS is on
	Hotspot is on
	No SIM card

- Some of these icons may appear differently or may not appear at all, depending on the device's status. Refer to the icons according to the actual environment in which you are using the device.
- Displayed icons may vary, depending on the area or service provider.

Notifications panel

You can open the notifications panel by dragging the status bar downward on the main screen.

- To open the quick access icons list, drag the notifications panel downwards or tap ⌄.
- To rearrange, add, or remove icons, tap **EDIT**.
- If you touch and hold the icon, the settings screen for the corresponding function appears.




Switching the screen orientation

You can set the screen orientation to automatically switch, according to the device's physical orientation.

On the notification panel, tap **Rotation** from the quick access icon list.

You can also tap ◯ > **Settings** > **Display** and activate **Auto-rotate screen**.



Editing the Home screen

On the Home screen, touch and hold on an empty space, then select the desired action from below.

- To rearrange the Home screen canvases, touch and hold on a canvas, then drag it to another location.
- To add a widget to the Home screen, touch and hold on a blank area of the Home screen, then select **Widgets**.
- To change a theme, touch and hold on a blank area of the Home screen, then select **Theme**.


  You can also tap ◯ > **Settings** > **Display** > **Theme**, then select a theme to apply to the device.
- To configure the Home screen settings, touch and hold on a blank area of the Home screen, then select **Home screen settings**. See *Home screen settings* for details.
- To view or reinstall the uninstalled apps, touch and hold on a blank area of the Home screen, then select **Uninstalled apps**. See *Uninstalled apps* for details.

Viewing the background theme

You can view only the background image by hiding the apps and widgets on the Home screen.

Spread two fingers apart on the Home screen.

- To return to the original screen, which displays apps and widgets, pinch your fingers on the Home screen or tap ◁.



Moving apps on the Home screen

On the Home screen, touch and hold an app, then drag it to another location.

- To keep frequently used apps at the bottom of the Home screen, touch and hold an app, then drag it to the quick access area at the bottom.
- To remove an icon from the quick access area, drag the icon to the Home screen.

Using folders from the Home screen

Creating folders

On the Home screen, touch and hold an app, then drag it over another app.

- A new folder is created and the apps are added to the folder.

Editing folders

On the Home screen, tap a folder and do one of the following actions.

- To edit the folder name and colour, tap the folder name.
- To add apps, touch and hold an app, then drag it over the folder and release it.
- To remove an app from the folder, touch and hold the app and drag it to outside the folder. If the removed app is the only one app that existed in the folder, the folder is removed automatically.
- You can also add or remove apps after tapping + in the folder.

Home screen settings

You can customise Home screen settings.

1 Tap ◯ > **Settings** > **Display** > **Home screen**.

2 Customise the following settings:

- **Select Home**: Select a Home screen mode.
- **Wallpaper**: Change the Home screen background wallpaper.
- **Screen swipe effect**: Select an effect to apply when the Home screen canvas switches.
- **Sort apps by**: Set how apps are sorted on the Home screen.
- **Grid**: Change the app arrangement mode for the Home screen.
- **Hide apps**: Select which apps you want to hide from the Home screen.

Screen lock

Screen lock overview

Your device's screen turns off and locks itself if you press the Power/Lock key. This also happens after the device is left idle for a specified period of time.

If you press the Power/Lock key when a screen lock is not set, the Home screen appears immediately.

To ensure security and prevent unwanted access to your device, set a screen lock.

- Screen lock prevents unnecessary touch input on the device screen and reduces battery consumption. We recommend that you activate the screen lock while not using the device.

Configuring screen lock settings

There are several options available for configuring the screen lock settings.

1 Tap ◯ > **Settings** > **Display** > **Lock screen** > **Select screen lock** and then select the method you prefer.

2 Customise the following settings:

- **None**: Deactivate the screen lock function.
- **Swipe**: Swipe on the screen to unlock the screen.
- **Knock Code**: Tap the spaces of the screen in accordance with a pattern to unlock the screen.
- **Pattern**: Draw a pattern to unlock the screen.
- **PIN**: Enter a numeric password to unlock the screen.
- **Password**: Enter an alphanumeric password to unlock the screen.

- If you incorrectly attempt to unlock the device 5 times, the screen is blocked for 30 seconds.

Secure start-up settings

When you select Knock Code, Pattern, PIN or Password as a screen lock method, you can configure your device to be locked whenever turning on the device in order to secure your data.

- You cannot use all functions, except for emergency calls until you unlock the device.
- If you forget your decryption password, you cannot restore encrypted data and personal information.

Lock screen settings

You can customise the following lock screen settings.

1 Tap ◯ > **Settings** > **Display** > **Lock screen**.

2 Customise the following settings:

- **Select screen lock**: Select a screen lock method.
- **Smart Lock**: Select trusted items so that if one of them occurs, the device is automatically unlocked.
- **Wallpaper**: Change the lock screen background wallpaper.
- **Clock**: Select the display type of the clock to display on the locked screen.
- **Shortcuts**: Add an app shortcut and directly access the app from the lock screen by dragging the app shortcut on the screen.
- **Contact info for lost phone**: Display emergency contact information on the lock screen.
- **Lock timer**: Set the amount of idle time after which the device automatically locks.
- **Power key instantly locks**: Instantly lock the screen when the Power/Lock key is pressed.



- Available setting items may vary, depending on the selected screen lock method.

KnockON

You can turn the screen on or off by double-tapping the screen.

- This option is available only on the Home screen provided by LG. It may not function properly on a custom launcher or on the Home screen installed by the user.
- When tapping the screen, use your fingertip. Do not use a fingernail.
- To use the KnockON feature, make sure that the proximity/light sensor is not blocked by a sticker or any other foreign substance.

Turning on the screen

Double-tap the middle of the screen.

- Tapping the top or bottom of the screen may decrease the recognition rate.

Turning off the screen

Double-tap on an empty space on the Home screen.

You can also double-tap an empty space on the status bar.

Knock Code

You can unlock the screen by creating your own Knock Code. When the screen is off, you can directly access the Home screen by tapping the screen in a specified sequence.

- You can use your Knock Code together with the KnockOn feature.
- Make sure to use your fingertip when tapping the screen.

Creating a Knock Code

1 Tap ◯ > **Settings** > **Display** > **Lock screen** > **Select screen lock** > **Knock Code**.

2 Tap the squares in a pattern of your choice to create a Knock Code and tap **NEXT**.

3 Input the created Knock Code again for verification, then tap **CONFIRM**.

Unlocking the screen with a Knock Code

Unlock the screen by inputting the Knock Code you have created.

Input your Knock Code on the touch screen when the screen is turned off.

- It is also possible to enter a Knock Code when the lock screen is turned on.

Memory card encryption

You can encrypt and protect data saved on the memory card. The encrypted data in the memory card cannot be accessed from another device.

1 Tap ◯ > **Settings** > **General** > **Security** > **Encrypt SD card**.

2 Read the on-screen overview of memory card encryption and then tap **CONTINUE** to continue.

3 Select an option and tap **ENCRYPT NOW**.

- **New data encryption**: Encrypt only data that is saved on the memory card after encryption.
- **Full encryption**: Encrypt all the data currently saved on the memory card.
- **Exclude media files**: Encrypt all files, except for media files such as music, photos and videos.

- To encrypt the memory card, make sure that a screen lock is set using a PIN or password.
- Once memory card encryption starts, some functions are not available.
- If the device is turned off while encryption is underway, the encryption process will fail, and some data may be damaged. Therefore, be sure to check if the battery level is sufficient before starting encryption.
- Encrypted files are accessible only from the device where the files were encrypted.
- The encrypted memory card cannot be used on another LG device. To use the encrypted memory card on another mobile device, format the card.
- You can activate memory card encryption even when no memory card is installed into the device. Any memory card that is installed after encryption will automatically be encrypted.

Taking screenshots

You can take screenshots of the current screen you are viewing.

Via a shortcut

Press and hold the Power/Lock key and the Volume Down (-) key at the same time for at least two seconds.

- Screenshots can be viewed from the **Screenshots** folder in the **Gallery**.

Via Capture+

On the screen where you want to take a screenshot, drag the status bar downwards, then tap .


- When the screen is turned off or locked, you can access **Capture+** by pressing the Volume Up (+) key twice. To use this feature, tap > **Settings** > **General** and turn on **Shortcut keys**.
- See *Writing notes on a screenshot* for details.

Entering text

Using the Smart keyboard


You can use the Smart keyboard to enter and edit text.

With the Smart keyboard, you can view text as you type without bothering to alternate between the screen and a conventional keyboard. This allows you to easily find and correct errors when typing.



Moving the cursor

With the Smart keyboard, you can move the cursor to the exact position you want. When typing text, touch and hold on the space bar and then drag left or right.




- This option is available only on the QWERTY keyboard.

Suggesting words

Smart keyboard automatically analyses your usage patterns to suggest frequently used words as you type. The longer you use your device, the more precise the suggestions are.

Enter text, then tap a suggested word or gently drag the left or right side of the space bar upwards.

- The selected word is automatically entered. You do not need to manually type every letter of the word.




Changing the QWERTY keyboard layout

You can add, delete or rearrange keys on the bottom row of the keyboard.

1 Tap ◯ > **Settings** > **General** > **Language & keyboard** > **LG Keyboard** > **Keyboard height and layout** > **QWERTY keyboard layout**.
You can also tap ⚙ on the keyboard and tap **Keyboard height and layout** > **QWERTY keyboard layout**.

2 Tap a key on the bottom row, then drag it to another position.




- This option is available on the QWERTY, QWERTZ and AZERTY keyboards.
- This function may not be supported for some languages.

Customising the keyboard height

You can customise the keyboard height to maximise hand comfort when typing.

1 Tap ◯ > **Settings** > **General** > **Language & keyboard** > **LG Keyboard** > **Keyboard height and layout** > **Keyboard height**.
You can also tap ⚙ on the keyboard and tap **Keyboard height and layout** > **Keyboard height**.

2 Adjust the keyboard height.



Selecting a landscape keyboard mode

You can select a landscape keyboard mode from several choices.

1 Tap ◯ > **Settings** > **General** > **Language & keyboard** > **LG Keyboard** > **Keyboard height and layout** > **Keyboard type in landscape**.
You can also tap ⚙ on the keyboard and tap **Keyboard height and layout** > **Keyboard type in landscape**.

2 Select a keyboard mode.


Splitting the keyboard

You can split the keyboard in half and place each piece on either side of the screen when the screen is in landscape mode.

Tap ◯ > **Settings** > **General** > **Language & keyboard** > **LG Keyboard** > **Keyboard height and layout** > **Split keyboard**.

You can also tap ⚙ on the keyboard and tap **Keyboard height and layout** > **Split keyboard**.

- Rotate the device to landscape mode to split the keyboard to both sides. To merge or split the keyboard, pinch together or spread apart your fingers on the keyboard.



One-handed operation mode

You can move the keyboard to one side of the screen so that you can use the keyboard with one hand.

1 Tap ◯ > **Settings** > **General** > **Language & keyboard** > **LG Keyboard** > **Keyboard height and layout** > **One-handed operation**.
You can also tap ⚙ on the keyboard and tap **Keyboard height and layout** > **One-handed operation**.

2 Press the arrow displayed next to the keyboard to move the keyboard in the direction you want.



Entering text by using voice

On the keyboard, touch and hold and then select .

- To maximise the voice command recognition, speak clearly.
- To enter text with your voice, make sure that your device is connected to a network.
- To select the language for voice recognition, tap > **Languages** on the voice recognition screen.
- This function may be not supported, or the supported languages may differ depending on the service area.

Adding languages to the keyboard

You can make additional languages available for keyboard input.

1 Tap > **Settings** > **General** > **Language & keyboard** > **LG Keyboard** > **Select languages**.

2 Select the languages you want to make available.

Copy and Paste

You can cut or copy text from an app, and then paste the text into the same app. Or, you can run other apps and paste the text into them.

1 Touch and hold around the text you want to copy or cut.

2 Drag / to specify the area to copy or cut.

3 Select either **CUT** or **COPY**.
   - Cut or copied text is automatically added to the clipboard.

4 Touch and hold the text input window, then select **PASTE**.

- If there is no item that has been copied or cut, the **PASTE** option will not appear.

Clip Tray

If you copy or cut an image or text, it is automatically saved to the clip tray and can be pasted to any space at any time.

1 On the keyboard, touch and hold and select .
You can also touch and hold the text input window, then select **CLIP TRAY**.

2 Select and paste an item from the clip tray.
   - A maximum of 20 items can be saved to the clip tray.
   - Tap to lock saved items in order not to delete them, even when the maximum quantity is exceeded. A maximum of ten items can be locked. To delete locked items, unlock them first.
   - Tap to delete the items saved to the clip tray.

- The clip tray may not be supported by some downloaded apps.

Do not disturb

You can limit or mute notifications to avoid disturbances for a specific period of time.

1 Tap ◯ > **Settings** > **Sound & notification** > **Do not disturb** and then drag ◯ to activate it.

2 Tap **Sounds and vibrations** and select the mode you want:

- **Priority only**: Receive sound or vibrate notifications for the selected apps. Even when **Priority only** is turned on, alarms still sound.
- **Total silence**: Disable both the sound and vibration.

03

Useful Apps

Installing and uninstalling apps

Installing apps

Access an app store to search and download apps.

- You can use **SmartWorld**, **Play Store** or the app store provided by your service provider.

- Some app stores may require you to create an account and sign in.
- Some apps may charge fees.
- If you use mobile data, you may be charged for data usage, depending on your pricing plan.
- **SmartWorld** may not be supported depending on the area or service provider.

Uninstalling apps

Uninstall apps that you no longer use from your device.

Uninstalling with the touch and hold gesture

On the Home screen, touch and hold the app to uninstall, then drag it over **Uninstall** at the top of the screen.

You can also touch and hold the app, then tap an app or widget that ⊗ is attached to uninstall.

- If apps were uninstalled within 24 hours from now, you can reinstall them. See *Uninstalled apps* for details.

Uninstalling by using the settings menu

Tap ◯ > **Settings** > **General** > **Apps**, select an app, then tap **Uninstall**.

Uninstalling apps from the app store

To uninstall an app, access the app store from which you download the app and uninstall it.

- Some apps cannot be uninstalled by users.

Uninstalled apps

You can view the uninstalled apps on the Home screen. You can also reinstall apps which were uninstalled within 24 hours from now.

1 Tap ◯ > **Uninstalled apps**.

2 Activate the desired function:

- **Reinstall**: Reinstall the selected app.
- 🗑 : Remove the uninstalled apps permanently from the device.

- Uninstalled apps are automatically removed from the device 24 hours after they were uninstalled. If you want to reinstall the uninstalled apps, you must download them again from the app store.
- This feature is activated on the default Home screen only. If you uninstall apps while using the EasyHome screen or other launcher, they are immediately and permanently removed from the device.

Phone

Voice call

Make a phone call by using one of the available methods, such as manually entering a phone number and making a call from the contact list or the list of recent calls.

Making a call from the keypad

1 Tap ◯ > > **Dial**.

2 Make a call by using a method of your choice:

- Enter a phone number and tap .
- Touch and hold a speed dial number.
- Search for a contact by tapping the initial letter of a contact name in the contact list, and then tap .

- To enter "+" when making an international call, touch and hold number 0.
- See *Adding contacts* for details on how to add phone numbers to the speed dial list.

Making a call from the contact list

1 Tap ◯ > > **Contacts**.

2 From the contact list, select a contact and tap .

Answering a call

To answer a call, drag to the outside of the circle on the incoming call screen.

- When the stereo headset is connected, you can make calls by using the call/end button on the headset.
- To end a call simply by pressing the Power/Lock key, tap > **Settings** > **Networks** > **Call** > **Answer and end calls**, then turn on **End calls with the Power key**.

Rejecting a call

To reject an incoming call, drag across the incoming call screen.

- To send a rejection message, drag the rejection message option across the screen.
- To add or edit a rejection message, tap > **Settings** > **Networks** > **Call** > **Call blocking & Decline with message** > **Decline with message**.
- When a call is coming in, press the Volume Up (+), Volume Down (-) or Power/Lock key to mute ringtone or vibration, or to hold the call.

Viewing missed calls

If there is a missed call, the status bar at the top of the screen displays .

To view missed call details, drag the status bar downwards. You can also tap > > **Call logs**.

Functions accessible during a call

During a call, you can access a variety of functions by tapping on-screen buttons:

- **Contacts**: View the contact list during a call.
- **End**: End a call.
- **Dialpad**: Display or hide the dial pad.
- **Speaker**: Turn on the speakerphone function.
- **Mute**: Mute your voice so that your voice cannot be heard by the other party.
- **Bluetooth**: Switch the call to a Bluetooth device that is paired and connected.
- ⋮ : Access additional call options.

> • Available settings items may vary depending on the area or service provider.

Making a three-way calling

You can make a call to another contact during a call.

1 During a call, tap ⋮ > **Add call**.

2 Enter a phone number and tap .

- The two calls are displayed on the screen at the same time, and the first call is put on hold.

3 To start a conference call, tap **Merge calls**.

> • You may be charged a fee for each call. Consult with your service provider for more information.

Viewing call records

To view recent call records, tap ◯ > > **Call logs**. Then, you can use the following functions:

- To view detailed call records, select a contact. To make a call to the selected contact, tap .
- To delete call records, tap ⋮ > **Delete**.

- The displayed call duration may differ from the call charge. Consult with your service provider for more information.

Configuring call options

You can configure various call options.

1 Tap ◯ > > **Dial** or **Call logs**.

2 Tap ⋮ > **Call settings** and then configure the options to suit your preferences.

Messaging

Sending a message

You can create and send messages to your contacts using the Messaging app.

- Sending messages abroad may incur additional charges. Consult with your service provider for more information.

1 Tap ◯ > .

2 Tap .

3 Specify a recipient and create a message.
   - To attach files, tap .
   - To access optional menu items, tap ⋮.

4 Tap **Send** to send the message.

Reading a message

You can view exchanged messages organised by contact.

1 Tap ◯ > .

2 Select a contact from the message list.

Configuring messaging settings

You can change messaging settings to suit your preferences.

1 Tap ◯ > .

2 Tap ⋮ > **Settings** from the message list.

Camera

Starting the camera

You can take a photo or record a video to cherish all of your memorable moments.

Tap ◯ > .

- Before taking a photo or recording a video, wipe the camera lens with a soft cloth.
- Be careful not to stain the camera lens with your fingers or other foreign substance.
- If the battery level is lower than 5%, charge the battery before using the camera.
- Images included in this user guide may be different from the actual device.
- Photos and videos can be viewed or edited from the **Gallery**. See *Gallery overview* for details.



Taking a photo

1 Tap the subject to focus the camera on.

2 Tap to take a photo.

- You can also press the Volume Down (-) or Volume Up (+) key to take a photo.

- When the screen is turned off or locked, start the camera by pressing the Volume Down (-) key twice. To activate this function, tap > **Settings** > **General** > **Shorcut keys** and turn on **Open Capture+/ Camera.**

Recording a video

1 Tap the subject to focus the camera on.

2 Tap .

- To take a photo while recording a video, tap .
- To pause the video recording, tap . To resume the video recording, tap .

3 Tap to end the video recording.

Customising the camera options

You can customise a variety of camera options to suit your preferences.

Tap on the screen.

- Available options vary depending on the selected camera (front or rear camera) and the selected camera mode.

Photo size	Select values for aspect ratio and size for taking photos.
Video resolution	Select values for resolution and size for recording videos.

HDR	Obtain photos in vivid colours, and get compensated effects even when they are taken against the light. These functions are provided by the high dynamic range (HDR) technology equipped in the camera of the device.
Timer	Set the timer to automatically take photos after a specified period of time.
Cheese shutter	Take photos with voice commands.
Tag locations	Save the image with GPS location data.
Grid	Display guide grids to so that you can take photos or record videos based on the horizontal and vertical reference lines.
Storage	Select any of Internal storage and SD card. (Available when the memory card is inserted.)
Simple view	Hide all menus from the camera screen.

Additional options on the front camera

Selfie shot	Customise selfie shot settings. • Gesture shot: Shoot using the Gesture shot feature. • Auto shot: Shoot when the camera detects a face.
Save as flipped	Save as flipped images after taking selfies.

Burst shot

You can take continuous shots of photos to create moving pictures.

On the camera screen, touch and hold .

- Continuous shots are taken at a fast speed while is held down.

- Up to thirty (30) continuous photos can be taken.

Simple view

Tap > **Simple view** to hide menus on the camera screen. Tap to display them.

AE/AF lock


You can fix the current exposure level and focus position by touching and holding the screen on the camera screen. To turn off the feature, tap a blank area on the screen.



Switching between cameras

You can switch between the front and rear cameras to suit your environment.

On the camera screen, tap or drag the screen in any direction to switch between the front and rear cameras.



- Use the front camera to take selfies. See *Selfie shot* for details.

Switching between standard and wide-angle cameras

Switch between standard and wide-angle on the front camera to take photos or record videos to suit your preferences.

- Tap / to switch between the standard and wide-angle camera.

Zoom in or out

You can use zoom in or out on the camera screen while taking a photo or recording a video.

- On the camera screen, pinch or spread two fingers to zoom in or out, then use the displayed +/- slide bar.

- The zoom feature is not available when using the front camera in selfie mode.

Selfie shot

You can use the front camera to view your face on the screen and take selfies.

Gesture shot

You can take selfies by using gestures.

Show your palm to the front camera and then clench your fist.

You can also clench your fist and then open it towards the front camera.

- In three seconds, a photo is taken.





- To use this feature, switch to the front camera mode, then tap ⚙ > **Selfie shot** > **Gesture shot**.
- Make sure that your palm and fist are within the reference line so that the camera can detect them.
- This feature may not available while using some of the camera features.

Auto shot

You can use the face detection feature to take selfies easily and conveniently. You can set the device so that, when you look at the screen, the front camera detects your face and takes a selfie automatically.

- The white coloured guide frame appears when the front camera detects your face. If the subject within the guide frame stops moving, the guide frame colour turns blue, then the camera takes a photo.




- Tap > **Selfie shot** > **Auto shot** to enable the Auto shot feature.

Interval shot

You can take selfies at an interval.

While using the front camera, touch and hold . You can also show your palm to the camera, then clench your fist twice quickly.

- Four photos are taken at about two seconds interval after a timer delay of three seconds.



Save as flipped

Before taking a photo with the front camera, tap > **Save as flipped**. The image is flipped horizontally.

- When using the front camera, you can change how selfies are taken in the camera options. See *Customising the camera options* for details.

Gallery

Gallery overview

You can view and manage photos and videos saved on your device.

1 Tap > .
   - Saved photos and videos are displayed by folder.

2 Tap a folder and select a file.
   - View the selected file in full-screen mode.
   - While viewing a photo, swipe left or right to view the previous or next photo.
   - While viewing a video, swipe left or right to rewind or fast-forward the video.

- Some file formats may not be supported, depending on the installed software.
- Some files may not be opened due to encoding.
- Files that exceed the size limit may cause an error.

Viewing photos



- To display the menu items, gently tap the screen. To hide the menu items, tap the screen again.

Editing photos


1 While viewing a photo, tap ✎.

2 Use a variety of effects and tools to edit the photo.

3 Tap ✓ to apply changes.

4 Tap **SAVE** to save changes.
   - The changes are overwritten to the original file.
   - To save the edited photo as another file, tap ⋮ > **Save copy**.

Playing a video



- To adjust the sound volume, drag the right side of the video screen up or down.
- To adjust the screen brightness, drag the left side of the video screen up or down.

Deleting files

You can delete files by using one of the following options:

- Touch and hold a file from the file list, then tap **Delete**.
- Tap from the file list and delete the desired files.
- Deleted files are automatically moved to **Trash** and they can be restored to the Gallery within 7 days.
- On the Gallery, tap > **Trash**. Tap to completely delete the files. In this case, the files cannot be restored.

Sharing files

You can share files by using one of the following options:

- While viewing a photo or video, tap to share the file by using the method you want.
- Tap from the file list to select files and share them using the method you want.


Music

You can play and manage songs or music albums.

1 Tap ◯ > **LG** > **Music**.

2 Select a category.

3 Select a music file.



- Some file formats may not be supported, depending on the installed software.
- Files that exceed the size limit may cause an error.
- Music files may be protected by international copyright owners or copyright laws. You may have to obtain legal permission before copying a music file. To download or copy a music file, first check the copyright law for the relevant country.
- This model supports Hi-Fi audio playback. Hi-Fi audio files display the Hi-Fi icon.

E-mail

E-mail overview

You can register an email account to your device and then you can check and send emails from your device.



- If you use mobile data, you may be charged for data usage depending on your pricing plan. Consult with your service provider for more information.

Registering email accounts

When you use the email app for the first time, register your email account.

1. Tap ◯ > **E-mail**.
2. Select an email service provider.
3. Enter your email address and password and then tap **NEXT** to register your account.
   - To manually register an email account or to register email accounts not found in the list, tap **MANUAL SETUP**.

Managing email accounts

To view or edit your email account settings, tap ⋮ > **Settings**.

- To add an account, tap **Add account**.
- To delete an account, tap ⋮ > **Remove account**.

Opening another email account

If several email accounts are registered and you want to view another account, tap ☰ and select another one from the account list.

Checking email

1 Tap ☰ and select a mail box.

2 Select an email from the email list.
   - The email message appears.

Sending email

1 Tap +.

2 Enter the recipient's email address.

3 Enter a subject and message.
   - To attach files, tap 📎.
   - To access optional menu items, tap ⋮.

4 Tap ▷ to send the email.

Calendar

Calendar overview

You can use the calendar to manage events and tasks.

Adding events

1 Tap ◯ > **Calendar**.

2 Select a date and then tap ⊕.

3 Enter event details and tap **Save**.

- If you tap a date from the calendar and the date contains events, a pop-up window appears showing a list of the events. Tap an event from the pop-up window to view the event details.

Syncing events

Tap ⋮ > **Calendars to sync**, and select a calendar to sync.

- When your events are saved from the device to your Google account, they are automatically synced with the Google calendar, too. Then, you can sync other devices with the Google calendar in order to make those devices have the same events that your device has and to manage your events on those devices.

Event pocket

You can use the event pocket to create events.

Tap to open the event pocket and then drag content to a date in the calendar.

- : Manage images, text, memos and temporarily saved events. You can also share text, images and memos from another app and save them to the pocket. If you tap **Pocket** when creating an event, the event is temporarily saved to the pocket.

- : Manage tasks that have no deadline, such as events.

QuickMemo+

QuickMemo+ overview

You can make creative notes by using a variety of options on this advanced notepad feature, such as image management and screenshots, which are not supported by the conventional notepad.

Creating a note

1 Tap > **QuickMemo+**.

2 Tap to create a note.
- : Save a note.
- : Undo the last action.
- : Redo the last action you undid.
- : Enter a note by using the keypad.
- : Write notes by hand.
- : Erase handwritten notes.
- : Zoom in or out, rotate or erase the parts of a handwritten note.
- : Access additional options, including sharing and locking notes, changing the note pad style and inserting content.

3 Tap to save the note.

Writing notes on a photo

1 Tap ◯ > **QuickMemo+**.

2 Tap 📷 to take a photo, then tap **OK**.
- The photo is automatically attached into the notepad.

3 Tap T or ✎ to write notes on the photo.
- Write notes by hand on the photo.
- Enter text below the photo.

4 Tap ✓ to save the note.

Writing notes on a screenshot

1 While viewing the screen you want to capture, drag the status bar downwards and then tap ✎.
- The screenshot appears as the notepad background theme. Memo tools appear at the top of the screen.

2 Take notes as desired.
- Write notes by hand on the photo.

3 Tap ✓ and save the notes to the location you want.
- Saved notes can be viewed in either **QuickMemo+** or **Gallery**.
- To save notes in the same location all the time, select the **Use as default app** checkbox and select an app.

Managing folders

You can view notes grouped by the type of the notes.

1 Tap ◯ > **QuickMemo+**.

2 At the top of the screen, tap ☰ and select a menu item:

- **All memos**: View all notes saved in **QuickMemo+**.
- **My memos**: View notes created by **QuickMemo+**.
- **Photo memos**: View notes created by 📷.
- **Capture+**: View notes created by ✂.
- **Trash**: View deleted notes.
- **New category**: Add categories.
- ⚙ : Rearrange, add or delete categories. To change the name of a category, tap the category.

> - Some folders do not appear when launching QuickMemo+ for the first time. Disabled folders are enabled and appear when they contain at least one related note.

Calculator

You can use two types of calculators: the simple calculator and the scientific calculator.

1 Tap ◯ > **Tools** > **Calculator**.

2 Use the keypad to make a calculation.

- To use scientific calculator, drag the green coloured slide bar located in the right side of the screen to the left.
- To restart a calculation, touch and hold the **DEL** button.

Clock

Alarm

You can set an alarm to trigger it at a specified time.

1 Tap ◯ > **Clock** > **Alarm**.

2 Tap + to add a new alarm.

3 Configure the alarm settings and tap **SAVE**.

- If you select a previously set alarm, you can edit the alarm.
- To delete an alarm, tap 🗑 at the top of the screen. You can also touch and hold the alarm.

World clock

You can view the current time in cities around the world.

1 Tap ◯ > **Clock** > **World clock**.

2 Tap + and add a city.

Timer

You can set the timer to trigger an alarm after a specified period of time.

1 Tap ◯ > **Clock** > **Timer**.

2 Set the time and tap **Start**.
- To suspend the timer, tap **Pause**. To resume the timer, tap **Resume**.
- To reset the timer settings, tap **Reset**.

3 Tap **Stop** to stop the timer alarm.

Stopwatch

You can use the stopwatch to record a lap time.

1 Tap ◯ > **Clock** > **Stopwatch**.

2 Tap **Start** to initiate the stopwatch.
- To record a lap time, tap **Lap**.

3 Tap **Pause** to suspend the stopwatch.
- To resume the stopwatch, tap **Resume**.
- To clear all the records and newly start the stopwatch, tap **Reset**.

Downloads

You can view, delete or share files downloaded via the Internet or apps.

Tap ◯ > **Tools** > **Downloads**.

File Manager

You can view and manage files saved on your device or cloud.

1 Tap ◯ > **Tools** > **File Manager**.

2 Tap ☰ and select the desired storage location.

FM Radio

You can listen to FM radio.

Tap ◯ > **Tools** > **FM Radio**.

- To use this app, first connect earphones to the device. The earphones function as the radio antenna.
- This function may not be supported depending on the area.

Voice Recorder

You can record and save your voice or others' voices from important events. Recorded voice files can be played back or shared.

1 Tap ◯ > **Tools** > **Voice Recorder**.

2 Tap ⊙.

- To pause recording, tap ⏸.

3 Tap ⏹ to end recording.

- The file is saved automatically and the pre-listen screen appears.

4 Tap ▷ to play the recorded voice.

- To save the location details of recording, tap **Location**.
- To tag a current event information on the recording, tap **Event**. Then select the event you want.
- If you tap ≡, recorded voice files appear. You can play a recorded voice file from the list.

Contacts

Contacts overview

You can save and manage contacts.

Tap ◯ > **LG** > **Contacts**.

Adding contacts

Adding new contacts

1 On the contact list screen, tap +.

2 Enter contact details and tap **SAVE**.

Importing contacts

You can import contacts from another storage device.

1 On the contact list screen, tap ⋮ > **Manage contacts** > **Import**.

2 Select the source and target locations of the contact you want to import, and then tap **OK**.

3 Select the contacts and tap **IMPORT**.

Adding contacts to the speed dial list

1 On the contact list screen, tap ⋮ > **Speed dial**.

2 Tap **Add contact** from a speed dial number.

3 Select a contact.

Searching for contacts

You can search for contacts by using one of the following options:

- On the contact list screen, enter a contact name in the search box.
- Scroll the contact list up or down.
- From the index of the contact list screen, tap the initial letter of a contact.

Contacts list

Editing contacts

1 On the contact list screen, select a contact.

2 On the contact detail screen, tap ✎ and edit details.

3 Tap **SAVE** to save changes.

Deleting contacts

You can delete contacts by using one of the following options:

- On the contact list screen, touch and hold a contact you want to delete, then tap **Delete contact**.

- Tap ⋮ > **Delete** on the contact list screen.

Adding favourites

You can register frequently used contacts as favourites.

1 On the contact list screen, select a contact.

2 On the contact detail screen, tap ☆.

Creating groups

1 On the contact list screen, tap **Groups** > ⋮ > **New group**.

2 Enter a new group name.

3 Tap **Add members**, select contacts, then tap **ADD**.

4 Tap **SAVE** to save the new group.

LG SmartWorld

You can download a variety of games, audio content, apps and fonts provided by LG Electronics. Customise your device to suit your preferences by using Home themes and fonts.

- If you use mobile data, you may be charged for data usage depending on your pricing plan.
- This feature may not be supported depending on the area or service provider.

1 Tap ◯ > **LG** > **SmartWorld**.

2 Tap ⋮ > **Sign in**, then sign in.

3 Select and download content items.

Downloading SmartWorld app

If **SmartWorld** app is not installed, follow these steps to download it.

1 Tap ◯ > **Settings** > **General** > **About phone** > **Update Center** > **App Updates**.

2 From the list, select **SmartWorld** and tap **Download**.

Tasks

You can register tasks to your device to easily manage schedules.

1 Tap ◯ > **LG** > **Tasks**.

2 Tap ⊕ to add a task.

3 Enter task details and then tap **SAVE**.

LG Backup

You can back up, restore and move the data saved on your device.

1 Tap ◯ > **Management** > **LG Backup**.
You can also tap ◯ > **Settings** > **General** > **Backup & reset** > **LG Backup**.

2 Follow the on-screen instructions to select whether to back up data in the preset backup folder on the device or to copy data to other devices.

⚠ • Resetting your device may delete backup files saved in internal storage. To minimise data loss, copy important backup files from the LG Backup folder in the internal storage to a computer or external storage.

• Data in a Google account will not be backed up. When you synchronise your Google account, Google apps, Google contacts, Google calendar, Google memo app data and apps downloaded from Play store are stored on the Drive app automatically.

• Backup files are saved with the file extension *.lbf under the LG Backup folder on the memory card or internal storage.

• Fully charge the battery before backing up or restoring data to avoid unintentional powering off during the process.

Evernote

You can write and collect important information and then share them with other devices that support **Evernote**.

Tap ◯ > **Recommended** > **Evernote**.

Facebook

You can use a social networking service to update, view and share posts, photos and videos with your online contacts.

Tap ◯ > **Recommended** > **Facebook**.

Instagram

Use a social networking service to capture and share your photos and videos. You can also apply filter effects to make your photos and videos more creative and interesting.

Tap ◯ > **Recommended** > **Instagram**.

Chrome

Sign in to Chrome and import opened tabs, bookmarks and address bar data from a computer to your device.

Google apps

You can use Google apps by setting a Google account. The Google account registration window appears automatically when you use a Google app for the first time. If you do not have a Google account, create one from your device. For details on how to use an app, see the Help in the app.



• Some apps may not work depending on the area or service provider.

Docs

Create documents or edit documents created online or from another device. Share and edit documents together with others.

Drive

Upload, save, open, share and organise files from your device. Files accessible from apps can be accessed from anywhere, including online and offline environments.

Duo

Make a video call with your family, friends and anyone else who uses the app.

Gmail

Register your Google email account to your device to check or send email.

Google

Use the Google to search for web pages, images, news and more by entering or speaking keywords.

Maps

Find your location or the location of a place on the map. View geographical information.

Photos

View or share photos or albums saved on your device.

Play Movies & TV

Use your Google account to rent or purchase movies. Purchase content and play it anywhere.

Play Music

Purchase music files from the **Play Store**. Play music files saved on your device.

Sheets

Create spreadsheets or edit spreadsheets created online or from another device. Share and edit spreadsheets together with others.

Slides

Create presentation material or edit presentation material created online or from another device. Share and edit presentation material together with others.

YouTube

Search and play videos. Upload videos on YouTube to share them with people around the world.

04

Phone Settings

Settings

You can customise the device settings in accordance with your preferences.

Tap ◯ > **Settings**.

- Tap 🔍 and enter a keyword in the search box to access a setting item.
- Tap ⋮ to change the view mode. This user guide assumes that you are using the **Tab view**.

Networks

Wi-Fi

You can connect to nearby devices over a Wi-Fi network.

Connecting to a Wi-Fi network

1. On the settings screen, tap **Networks** > **Wi-Fi**.
2. Drag ⬭ to activate it.
   - Available Wi-Fi networks appear automatically.
3. Select a network.
   - You may need to enter the network's Wi-Fi password.
   - The device skips this process for previously accessed Wi-Fi networks. If you do not want to automatically connect to a certain Wi-Fi network, touch and hold the network and then tap **Forget network**.

Wi-Fi network settings

On the settings screen, tap **Networks** > **Wi-Fi**.

- **Switch to mobile data**: If the mobile data connection function is activated but the device cannot connect to the Internet via Wi-Fi connection, the device automatically connects to the Internet via the mobile data connection.
- ⋮ : Customise Wi-Fi network settings.


Wi-Fi Direct

You can connect your device to other devices that support Wi-Fi Direct to share data directly with them. You do not need an access point. You can connect with more than two devices by using Wi-Fi Direct.

1 On the settings screen, tap **Networks** > **Wi-Fi** > ⋮ > **Advanced Wi-Fi** > **Wi-Fi Direct**.
   - Nearby devices that support Wi-Fi Direct automatically appear.

2 Select a device.
   - Connection occurs when the device accepts the connection request.

- The battery may drain faster when using Wi-Fi Direct.



Bluetooth

You can connect your device to nearby devices that support Bluetooth to exchange data with them. Connect your device to a Bluetooth headset and a keyboard. This makes it easier to control the device.

Pairing with another device

1 On the settings screen, tap **Networks** > **Bluetooth**.

2 Drag to activate it.
- Available devices appear automatically.
- To refresh the device list, tap **SEARCH**.

- Only devices set as visible are displayed on the list.

3 Select a device from the list.

4 Follow the on-screen instructions to perform authentication.

- This step is skipped for previously accessed devices.

Sending data via Bluetooth

1 Select a file.
- You can send multimedia files or contacts.

2 Tap > **Bluetooth**.

3 Select a target device for the file.
- The file is sent as soon as the target device accepts it.

- File sharing processes may differ, depending on the file.

Mobile data

You can turn on or off mobile data. You can also manage mobile data usage.

Turning on mobile data

1 On the settings screen, tap **Networks** > **Mobile data**.

2 Drag to activate it.

Customising mobile data settings

1 On the settings screen, tap **Networks** > **Mobile data**.

2 Customise the following settings:

- **Mobile data**: Set to use data connections on mobile networks.
- **Limit mobile data usage**: Set a limit for mobile data usage to block mobile data if the limit is reached.
- ⋮ : Customise mobile data settings.

Call

You can customise call settings, such as voice call and international call options.

- Some features may not be supported depending on the area or service provider.

1 On the settings screen, tap **Networks** > **Call**.

2 Customise the settings.

Tethering


USB tethering

You can connect the device to another device via USB and share mobile data.

1 Connect your device and other devices via USB cable.

2 On the settings screen, tap **Networks > Tethering > USB tethering** and then drag to activate it.

- This option uses mobile data and may incur data usage fees, depending on your pricing plan. Consult with your service provider for more information.
- When connecting to a computer, download the USB driver from *www.lg-mobile.co.il* and install it on the computer.
- You cannot send or receive files between your device and a computer while USB tethering is turned on. Turn off USB tethering to send or receive files.
- Operating systems that support tethering are Window XP or higher, or Linux.



Wi-Fi hotspot

You can set the device as a wireless router so that other devices can connect to the Internet by using your device's mobile data.


1 On the settings screen, tap **Networks** > **Tethering** > **Wi-Fi hotspot** and then drag to activate it.

2 Tap **Set up Wi-Fi hotspot**, and enter the Wi-Fi name (SSID) and password.

3 Turn on Wi-Fi on the other device, and select the name of the device network on the Wi-Fi list.

4 Enter the network password.

- This option uses mobile data and may incur data usage fees, depending on your pricing plan. Consult with your service provider for more information.
- More information is available at this web site: *http://www.android.com/tether#wifi*




Bluetooth tethering

A Bluetooth-connected device can connect to the Internet by using your device's mobile data.

1 On the settings screen, tap **Networks > Tethering > Bluetooth tethering** and then drag to activate it.

2 Turn on Bluetooth on both devices, and pair them.

- This option uses mobile data and may incur data usage fees, depending on your pricing plan. Consult with your service provider for more information.
- More information is available at this web site: *http://www.android.com/tether#Bluetooth_tethering*



Help

You can view help on using tethering and hotspots.

On the settings screen, tap **Networks > Tethering > Help**.

More

Airplane mode

You can turn off the call and mobile data functions. When this mode is on, functions that do not involve data, such as games and music playback, remain available.

1 On the settings screen, tap **Networks > More > Airplane mode**.

2 Tap **TURN ON** in the confirmation screen.

Mobile networks

You can customise mobile data settings.

1 On the settings screen, tap **Networks** > **More** > **Mobile networks**.

2 Customise the following settings:

- **Mobile data**: Turn mobile data on or off.
- **Data roaming**: Browse the web, use emails, multimedia messages and other data services overseas.
- **Network mode**: Select a network type.
- **Access Point Names**: View or change the access point for using mobile data services. To change the access point, select a choice from the access point list.
- **Network operators**: Search for network operators and connect automatically to a network.

VPN

You can connect to a safe virtual network, such as an intranet. You can also manage connected virtual private networks.

Adding VPN

1 On the settings screen, tap **Networks** > **More** > **VPN**.

- Be cautious that if the screen lock is unlocked, all VPN information saved on the device are erased.

2 Tap **Add VPN**.

- This feature is available only when the screen lock is activated. If the screen lock is deactivated, a notification screen appears. Tap **SETTINGS** from the notification screen to activate the screen lock. See *Configuring screen lock settings* for details.

3 Enter VPN details and tap **SAVE**.

Configuring VPN settings

1 Tap a VPN from the **VPNS** list.

2 Enter the VPN user account details and tap **CONNECT**.

- To save the account details, select the **Save account information** checkbox.

Printing

You can connect your device to a Bluetooth printer and print photos or documents saved on the device.

1 On the settings screen, tap **Networks** > **More** > **Printing**.

- If the desired printer is not in the list, install the printer driver from the app store.

2 Drag to activate it.

3 Select a printer from the printer list screen.

- To add a printer, tap ⋮ > **Add printer**.
- To search for a printer name, tap ⋮ > **Search**.
- Tap ⋮ > **Settings** from the printer list screen.

4 Select a file and tap ⋮ > **Print**.

- The document prints.

- If you do not have a Google account, tap **ADD ACCOUNT** to create an account.

Sound & notification

You can customise sound, vibrate and notification settings.

On the settings screen, tap **Sound & notification** and customise the following settings:

- **Sound profile**: Change the sound mode to **Sound**, **Vibrate only**, or **Silent**.
- **Volume**: Adjust the sound volume for various items.
- **Ringtone**: Select a ringtone for incoming calls. Add or delete ringtones.
- **Ringtone ID**: Create a ringtone for an incoming call from a particular contact.
- **Sound with vibration**: Set the device to vibrate and play a ringtone simultaneously.
- **Vibration type**: You can select a vibration type or make your own vibration pattern.
- **Do not disturb**: Set the time, range and app type to receive notification messages. Receive notification messages only on particular days of the week.
- **Lock screen**: Display or hide a notification message on the lock screen. You can also hide private information.
- **Apps**: Select the apps that can show their notification messages on the screen, and set the priorities of those apps in regard to notification messages.
- **More > Notification sound**: Select a notification ringtone. Set music saved on the device as a notification ringtone.
- **More > Sound effects**: Select a sound effect to play when you tap the dialpad or keyboard, select an option, or lock or unlock the screen.
- **More > Message/call voice notifications**: Set the device to read the caller information or message content via voice.

Display

You can customise detailed settings for each screen type.

On the settings screen, tap **Display** and customise the following settings:

- **Home screen**: Customise settings for the Home screen. See *Home screen settings* for details.
- **Lock screen**: Customise lock screen settings. See *Lock screen settings* for details.
- **Theme**: Select a screen theme for your device.
- **Home touch buttons**: Rearrange Home touch buttons or change their background colours. Hide Home touch buttons on the screen.
- **Font type**: Change the font face.
- **Font size**: Change the font size.
- **Bold text**: Bold the text on the screen.
- **Brightness**: Use the slide bar to change the device's screen brightness. To automatically adjust screen brightness according to ambient light intensity, tap the **Auto** switch.
- **Auto**: Set the device so that the screen brightness is automatically adjusted in accordance with the ambient light intensity.
- **Comfort view**: Set the device to reduce amount of blue light on screen to reduce eye strain.
- **Auto-rotate screen**: Automatically rotate the screen according to the device's orientation.
- **Screen timeout**: Automatically turn off the screen when the device is left idle for a specified period of time.
- **More > Display size**: Zoom in or out the screen.
- **More > KnockON**: Turn on or off the screen by tapping the screen twice.
- **More > Screen saver**: Display a screen saver when the device is connected to the holder or charger. Select a screen saver type to display.

- **More > Motion sensor calibration**: Correct the angle and speed of the motion sensor to improve the tilt accuracy and speed of the sensor.

> - When correcting the motion sensor, make sure to place the device on a flat surface. Failure to do so may cause an error with the motion sensor functions, such as automatic screen rotation.

General

Language & keyboard

You can customise language and keyboard settings for your device.

1 On the settings screen, tap **General > Language & keyboard**.

2 Customise the following settings:

- **Language**: Select a language to apply for the device.
- **Current keyboard**: View the keyboard currently in use. Select a keyboard to use when entering text.
- **LG Keyboard**: Customise the LG keyboard settings.
- **Google voice typing**: Configure the options for text dictation by Google.
- **Text-to-speech output**: Configure the settings for text-to-speech output.
- **Pointer speed**: Adjust the pointer speed of a mouse or trackpad.
- **Reverse buttons**: Reverse the right mouse button to perform primary direct-manipulation actions.

Location

You can customise how your location information is used by particular apps.

1 On the settings screen, tap **General** > **Location**.

2 Customise the following settings:

- **Mode**: Select a method to provide your location information.
- **RECENT LOCATION REQUEST**: View apps that recently requested location information.
- **Google Location History**: Configure the Google location history settings.

Accounts & sync

You can add or manage accounts, including a Google account. You can also sync particular apps or user information automatically.

1 On the settings screen, tap **General** > **Accounts & sync**.

2 Customise the following settings:

- **Auto-sync data**: Sync all the registered accounts automatically.
- **ACCOUNTS**: View a list of registered accounts. To view or change details of an account, tap the account.
- **ADD ACCOUNT**: Add accounts.

Accessibility

You can manage accessibility plug-ins installed on your device.

1 On the settings screen, tap **General** > **Accessibility**.

2 Customise the following settings:

- **Vision** > **TalkBack**: Set the device to notify screen status or actions via voice.
- **Vision** > **Message/call voice notifications**: Set the device to read the caller information or message content via voice.
- **Vision** > **Font size**: Change the font size.
- **Vision** > **Bold text**: Bold the text on the screen.
- **Vision** > **Display size**: Zoom in or out the screen.
- **Vision** > **Touch zoom**: Zoom in or out by tapping the screen three times.
- **Vision** > **Window zoom**: Magnify or reverse a part of the screen.
- **Vision** > **Large mouse pointer**: Magnify the mouse pointer.
- **Vision** > **High contrast screen**: Turn the background colour into black for a high contrast screen.
- **Vision** > **Screen colour inversion**: Increase the display colour contrast for people with low vision.
- **Vision** > **Screen colour adjustment**: Adjust the display colour.
- **Vision** > **Grayscale**: Switch the screen to grayscale mode.
- **Vision** > **End calls with the Power key**: End a call by pressing the Power/Lock key.
- **Hearing** > **Captions**: Turn on the subtitle service when playing videos for the hearing impaired.
- **Hearing** > **Flash alerts**: Set the device to notify you with a blinking light for incoming calls and alarms.

- **Hearing > Turn off all sounds**: Mute all sounds and lower volume on the receiver.
- **Hearing > Audio type**: Select the audio type.
- **Hearing > Sound balance**: Adjust the audio output balance. Use the slide bar to change the balance.
- **Motor & cognition > Touch assistant**: Turn on the touch board to make buttons and gestures easier to use.
- **Motor & cognition > Touch input**: Enter text by touching and holding the screen or modify it by simply touching the screen.
- **Motor & cognition > Physical keyboard**: Customise the keyboard settings.
- **Motor & cognition > Auto mouse click**: Automatically click the mouse pointer in case of no movement.
- **Motor & cognition > Touch and hold for calls**: Answer or decline calls by touching and holding the call button instead of dragging it.
- **Motor & cognition > Screen timeout**: Turn off the screen automatically when the device is left idle for a specified period of time.
- **Motor & cognition > Touch control areas**: Limit the touch area so that only a particular portion of the screen can be controlled by touch input.
- **Accessibility features shortcut**: Quickly access a frequently used function by tapping ◯ three times.
- **Auto-rotate screen**: Automatically change the screen orientation according to the physical position of the device.
- **Switch Access**: Create key combinations to control your device.

Shortcut keys

You can use the volume keys to directly launch apps when the screen is turned off or locked.

1 On the settings screen, tap **General** > **Shortcut keys**.

2 Drag  to activate it.

- Press the Volume Down (-) key twice to launch the **Camera** app when the screen is locked or turned off. Press the Volume Up (+) key twice to launch **Capture+**.

Google services

You can use Google settings to manage your Google apps and account settings.

On the settings screen, tap **General** > **Google services**.

Security

1 On the settings screen, tap **General** > **Security**.

2 Customise the following settings:

- **Content lock**: Set the method to lock files in **Gallery** or **QuickMemo+**.
- **Encrypt SD card**: Encrypt the memory card to prevent use on another device. See *Memory card encryption* for details.
- **Secure start-up**: Protect your device with a lock when it powers on. See *Secure start-up settings* for details.
- **Set up SIM card lock**: Lock or unlock the USIM card, or change the password (PIN).
- **Password typing visible**: Display a password as you enter it.
- **Phone administrators**: Allow privileges to restrict the control or use of the device to particular apps.
- **Unknown sources**: Allow the installation of apps from non-Play Store apps.

- **Credential protection**: View the type of the storage where the security certificate will be saved.
- **Certificate management**: Manage the security certificate saved on the device.
- **Trust agents**: View and use trust agents installed on the device.
- **Screen pin**: Fix the app screen so that only the currently active app can be used.
- **Usage access**: View details on usage of apps on the device.

Date & time

You can customise date and time settings for your device.

1 On the settings screen, tap **General** > **Date & time**.

2 Customise the settings.

Storage

You can view and manage internal storage on the device or storage space of the memory card.

1 On the settings screen, tap **General** > **Storage**.

2 Customise the following settings:
- **DEVICE STORAGE**: View the total storage space and free space in the device's internal storage. View a list of apps in use and the storage capacity for each app.
- **PORTABLE STORAGE**: View the total storage space and free space in the memory card. This option appears only when a memory card is inserted. To unmount the memory card, tap ⏏.

Battery & power saving

You can view the current battery information or turn on power-saving mode.

1 On the settings screen, tap **General** > **Battery & power saving**.

2 Customise the following settings:

- **Battery usage**: View the battery usage details. To view more details, select a specific item.
- **Battery percentage on status bar**: Display the remaining battery level as a percentage on the status bar.
- **Battery saver**: Reduce battery consumption by cutting down some device settings, such as the display brightness, speed and vibration intensity. The status bar displays when power-saving mode is on.

Memory

You can view the average amount of memory usage over a certain period of time and the memory occupied by an app.

1 On the settings screen, tap **General** > **Memory**.

2 Tap to set a time slot to retrieve data.

Apps

You can view a list of installed apps. Stop apps from running or delete apps, if necessary.

1 On the settings screen, tap **General** > **Apps**.

2 Select an app and perform actions.

Backup & reset

You can back up data saved on your device to another device or account. Reset the device, if necessary.

1 On the settings screen, tap **General** > **Backup & reset**.

2 Customise the following settings:

- **LG Backup**: Back up or restore the blocked sender list, messages, images, home screens and other data saved on the device. See *LG Backup* for details.
- **Back up my data**: Back up your app data, Wi-Fi password and other settings to the Google server.
- **Backup account**: View the current backup account in use.
- **Automatic restore**: Automatically restore backup settings and data when reinstalling an app.
- **Network settings reset**: Reset Wi-Fi, Bluetooth and other network settings.
- **Factory data reset**: Reset all settings for the device and delete data.



- Resetting your device deletes all data on it. Enter your device name, Google account and other initial information again.

About phone

You can view information about your device, such as the name, status, software details and legal information.

On the settings screen, tap **General** > **About phone** and view information.

05

Appendix

LG Language Settings

Select a language to use on your device.

- Tap ◯ > **Settings** > **General** > **Language & keyboard** > **Language** > **ADD LANGUAGE**, and select a language.
  - Touch and hold ☰ and drag it to the top of the language list to set it as a default language.

LG Bridge

LG Bridge overview

LG Bridge is an app that helps you manage the photos, music, videos and documents saved on your LG smartphone from your computer conveniently. You can back up contacts, photos and more to the computer or update the device software.

- See LG Bridge help for details.
- The supported features may vary depending on the device.
- LG USB driver is a necessary program to connect your LG smartphone with the computer and is installed when you install LG Bridge.

LG Bridge functions

- Manage the files on the device from a computer via Wi-Fi connection or mobile data connection.
- Back up data from the device to a computer or restore data from a computer to the device via USB cable connection.
- Update the device software from a computer via USB cable connection.

Installing LG Bridge on a computer

1 Go to *www.lg-mobile.co.il* from your computer.

2 In the search bar, enter the name of your device.

3 Click **Download Centre > LG Bridge**, and download the setup file.

- Click **Details** to view the minimum requirements for installing LG Bridge.

Phone software update

LG Mobile phone software update from the Internet

For more information about using this function, please visit *http://www.lg.com/common/index.jsp*, select your country and language.

This feature allows you to conveniently update the firmware on your phone to a newer version from the Internet without needing to visit a service centre. This feature will only be available if and when LG makes a newer firmware version available for your device.

Because the mobile phone firmware update requires the user's full attention for the duration of the update process, please make sure you check all instructions and notes that appear at each step before proceeding. Please note that removing the USB cable during the upgrade may seriously damage your mobile phone.

- LG reserves the right to make firmware updates available only for selected models at its own discretion and does not guarantee the availability of the newer version of the firmware for all handset models.

LG Mobile Phone software update via Over-the-Air (OTA)

This feature allows you to conveniently update your phone's software to a newer version via OTA, without connecting a USB cable. This feature will only be available if and when LG makes a newer firmware version available for your device.

First check the software version on your mobile phone:

Tap ◯ > **Settings** > **General** > **About phone** > **Update Center** > **Software Update** > **Check now for update**.

- Your personal data from internal phone storage—including information about your Google account and any other accounts, your system/application data and settings, any downloaded applications and your DRM licence—might be lost in the process of updating your phone's software. Therefore, LG recommends that you backup your personal data before updating your phone's software. LG does not take responsibility for any loss of personal data.
- This feature depends on the area or service provider.

FAQ

This chapter lists some problems you might encounter when using your phone. Some problems require you to call your service provider, but most are easy to fix yourself.

Message	Possible causes	Possible corrective measures
SIM card error	There is no SIM card in the phone or it is inserted incorrectly.	Make sure the SIM card is correctly inserted.
No network connection/ Dropped network	Signal is weak or you are outside the carrier network.	Move toward a window or into an open area. Check the network operator coverage map.
	Operator applied new services.	Check whether the SIM card is more than 6-12 months old. If so, change your SIM or USIM card at your network provider's nearest branch. Contact your service provider.
Codes do not match	To change a security code, confirm the new code by re-entering it.	If you forget the code, contact your service provider.
	The two codes you entered do not match	
No applications can be set	Not supported by service provider or registration required.	Contact your service provider.
Downloaded application causes a lot of errors.	Remove the application.	1. Tap ◯ > **Settings**. 2. Tap **General** > **Apps**. 3. Tap the app > **Uninstall**.

Message	Possible causes	Possible corrective measures
Calls not available	Dialling error	New network not authorised.
	New SIM card inserted.	Check for new restrictions.
	Pre-paid charge limit reached.	Contact service provider or reset the limit with PIN2.
Phone cannot be turned on	On/Off key pressed too briefly.	Press the On/Off key for at least two seconds.
	Battery is not charged.	Charge battery. Check the charging indicator on the display.
Charging error	Battery is not charged.	Charge battery.
	Outside temperature is too hot or cold.	Make sure phone is charging at a normal temperature.
	Contact problem	Check the charger and its connection to the phone.
	No voltage	Plug the charger into a different outlet.
	Charger defective	Replace the charger.
	Wrong charger	Use only original LG accessories.
Number not allowed.	The Fixed dialling number function is on.	Check the Settings menu and turn the function off.
Impossible to receive/ send SMS & photos	Memory full	Delete some data, such as applications or messages from your phone to make more memory available.

Message	Possible causes	Possible corrective measures
Files do not open	Unsupported file format	Check the supported file formats.
The screen does not turn on when I receive a call.	Proximity sensor problem	If you use a protection tape or case, make sure it has not covered the area around the proximity sensor. Make sure that the area around the proximity sensor is clean.
No sound	Vibration mode	Check the settings status in the sound menu to make sure you are not in vibration or no interruptions mode.
Hangs up or freezes	Intermittent software problem	If the screen freezes or the phone does not respond when you try to operate it, remove the battery and reinsert it. Then power the phone back on. Alternatively, try to perform a software update through the website.

Anti-Theft Guide

Set up your device to prevent other people from using it if it's been reset to factory settings without your permission. For example, if your device is lost, stolen, or wiped, only someone with your Google account or screen lock information can use the device.

All you need to make sure your device is protected is:

- Set a screen lock: If your device is lost or stolen but you have a screen lock set, the device can't be erased using the Settings menu unless your screen is unlocked.
- Add your Google account on your device: If your device is wiped but you have your Google account on it, the device can't finish the setup process until your Google account information is entered again.

After your device is protected, you'll need to either unlock your screen or enter your Google account password if you need to do a factory reset. This ensures that you or someone you trust is doing the reset.



- Do not forget your Google account and password you had added to your device prior to performing a factory reset. If you can't provide the account information during the setup process, you won't be able to use the device at all after performing the factory reset.

More information

Open Source Software Notice Information

To obtain the source code under GPL, LGPL, MPL, and other open source licenses, that is contained in this product, please visit *http://opensource.lge.com*.

In addition to the source code, all referred license terms, warranty disclaimers and copyright notices are available for download.

LG Electronics will also provide open source code to you on CD-ROM for a charge covering the cost of performing such distribution (such as the cost of media, shipping, and handling) upon email request to *opensource@lge.com*. This offer is valid for three (3) years from the date on which you purchased the product.

Trademarks

- Copyright ©2017 LG Electronics, Inc. All rights reserved. LG and the LG logo are registered trademarks of LG Group and its related entities.
- Google™, Google Maps™, Gmail™, YouTube™, Duo™ and Play Store™ are trademarks of Google, Inc.
- Bluetooth® is a registered trademark of Bluetooth SIG, Inc. worldwide.
- Wi-Fi® and the Wi-Fi logo are registered trademarks of the Wi-Fi Alliance.
- All other trademarks and copyrights are the property of their respective owners.

DECLARATION OF CONFORMITY

Hereby, **LG Electronics** declares that this **LG-M250Y** product is in compliance with the essential requirements and other relevant provisions of Directive **2014/53/EU**.

A copy of the Declaration of Conformity can be found at *http://www.lg.com/global/declaration*



CE