עברית

ENGLISH



USER GUIDE

LG-K520K

www.lg-mobile.co.il

MFL69524101 (1.0)

אודות מדריך למשתמש זה

תודה שבחרת מוצר זה של LG. קרא בעיון מדריך למשתמש זה לפני השימוש במכשיר בפעם הראשונה, כדי להבטיח שימוש בטוח והולם.

- השתמש תמיד באביזרים מקוריים של LG. הפריטים שסופקו מיועדים למכשיר זה בלבד וייתכן שהם לא תואמים למכשירים אחרים.
- מכשיר זה אינו מתאים לאנשים לקויי ראייה מפני שהמקלדת שלו נמצאת במסך המגע.
- התיאורים מבוססים על הגדרות ברירת המחדל של המכשיר.
- יישומי ברירת המחדל במכשיר כפופים לעדכונים, וייתכן שהתמיכה ביישומים אלה תופסק ללא כל הודעה מראש. אם יש לך שאלות כלשהו על יישום שסופק עם המכשיר, פנה למרכז שירות של LG. עבור יישומים שהותקנו על-ידי המשתמש, פנה לספק השירות הרלוונטי.
- שינוי מערכת ההפעלה של המכשיר או התקנת תוכנה ממקורות לא רשמיים עלול לגרום נזק למכשיר ולגרום להרס נתונים או לאובדן נתונים. פעולות אלה יפרו את הסכם הרישיון של LG ויבטלו את האחריות שלך.
- תכנים ואיורים מסוימים עשויים להיראות שונים מאלה שבמכשיר, בהתאם לאזור, לספק השירות, לגרסת התוכנה ולגרסת מערכת ההפעלה, והם כפופים לשינוי ללא הודעה מוקדמת.
- תוכנות, שמע, טפטים, תמונות ופריטי מדיה אחרים שסופקו יחד עם המכשיר שלך מורשים לשימוש מוגבל. אם תחלץ חומר זה ותשתמש בו למטרות מסחריות או אחרות, אתה עלול להפר חוקי זכויות יוצרים. כמשתמש, אתה נושא באחריות מלאה לשימוש לא חוקי במדיה.
- ייתכן שיחולו חיובים נוספים תמורת שירותי נתונים, כגון שליחת הודעות, העלאה, הורדה, סנכרון אוטומטי ושירותי מיקום. כדי למנוע חיובים נוספים, בחר תוכנית נתונים מתאימה לצרכיך. פנה אל ספק השירות לקבלת פרטים נוספים.

הודעות מנחות

אזהרה: מצבים שעלולים לגרום לפציעה של המשתמש ושל גורמי צד שלישי.

זהירות: מצבים שעלולים לגרום לפציעה קלה או לנזק למכשיר.

הערה: הערות או מידע נוסף.

תוכן העניינים

5 הנחיות לשימוש בטוח ויעיל

01

תכונות הניתנות להתאמה אישית

13 שיתוף מהיר
14 תצוגה ממוזערת
15 חלון כפול
16 QuickMemo+
18 QSlide
19 Pen Pop
20 שיתוף תוכן
21 נא לא להפריע
22 צלצול מותאם

02

פונקציות בסיסיות

24 רכיבי מוצרים ואביזרים
25 סקירה כללית של החלקים
27 הדלקה או כיבוי
28 התקנת כרטיס ה-SIM והסוללה
31 טעינת הסוללה
32 מיטוב חיי הסוללה
33 הכנסת כרטיס הזיכרון
34 מסך המגע
37 מסך ראשי
43 נעילת מסך
46 הצפנת המכשיר
47 הצפנת כרטיס זיכרון
48 יצירת צילומי מסך
49 הזנת טקסט

03

יישומים שימושיים

57 התקנה והסרת התקנה של יישומים
58 טלפון
61 הודעות
62 מצלמה
67 גלריה
70 מנהל הקבצים
70 מזג אויר
70 מחשבון
71 משימות
71 הקלטה קולית
71 הורדות
72 רדיו FM
72 שעון
74 נגן מוסיקה
75 דוא"ל
76 אנשי קשר
78 לוח שנה
79 Evernote
79 שירות התראות חירום
80 LG Backup
80 יישומים שהוסרו לאחרונה
81 יישומי Google

04

Phone Settings (הגדרות טלפון)

84 הגדרות
84 רשתות
93 צליל והתראה
94 תצוגה
95 כללי

05

נספח

105 עדכון תוכנת הטלפון
107 שאלות נפוצות
110 מדריך למניעת גניבה
111 מידע נוסף

הנחיות לשימוש בטוח ויעיל

הקפד לקרוא הנחיות פשוטות אלה. אי עמידה בהנחיות אלו עלולה להיות מסוכנת או בלתי חוקית.

למקרה של תקלה, המכשיר שלך מכיל כלי תוכנה שיאסוף יומן תקלות. כלי זה אוסף רק נתונים ספציפיים לתקלה, כגון עוצמת אות, מיקום מזהה התא בעת ניתוק פתאומי של השיחה ויישומים שנטענו. היומן משמש רק לסיוע בזיהוי הגורם לתקלה. יומנים אלה מוצפנים, ורק מרכז תיקונים מוסמך של LG יוכל לגשת אליהם במקרה שתצטרך למסור את המכשיר לתיקון.

חשיפה לאנרגיית תדר רדיו

מידע על חשיפה לגלי רדיו ושיעור ספיגה סגולית (SAR).

טלפון נייד זה מדגם LG-K520K תוכנן לעמוד בדרישות הבטיחות הרלוונטיות לחשיפה לגלי רדיו. דרישות אלו מבוססות על קווים מנחים מדעיים, ואלה כוללים שולי בטיחות המיועדים להבטיח את בטיחותם של כל בני האדם, בלא קשר לגילם או למצב בריאותם.

- הנחיות החשיפה לגלי רדיו משתמשות ביחידת מידה הנקראת "שיעור ספיגה סגולית" (SAR). בדיקות SAR מבוצעות באמצעות שיטות מתוקננות, כאשר הטלפון משדר ברמת העוצמה המרבית המאושרת עבורו בכל תחומי התדרים שבשימוש.
- אף כי עשויים להיות הבדלים בין רמות ה-SAR של דגמי טלפונים שונים של LG, כל הטלפונים מתוכננים לעמוד בהנחיות המתאימות של חשיפה לגלי רדיו.
- מגבלת ה-SAR המומלצת על-ידי הוועדה הבין-לאומית להגנה מפני קרינה בלתי מיינית (ICNIRP) היא ממוצע של 2 ואט/ק"ג על כל 10 גר' של רקמה.
- ערך ה-SAR הגבוה ביותר עבור דגם טלפון זה שנמדד לשימוש באוזן הוא 0.465 ואט/ק"ג (10 גר'), וכאשר הוא נישא על הגוף, ערך זה עומד על 1.150 ואט/ק"ג (10 גר').

- מכשיר זה עומד בהנחיות החשיפה ל-RF כשמשתמשים בו בתנוחת השימוש הרגילה ליד האוזן או כשהוא ממוקם לפחות 5 מ"מ מהגוף. כאשר נעשה שימוש בנרתיק נשיאה או בתפס או מנשא לחגורה, אסור שתהיה בהם מתכת כלשהי, והמרחק בין המכשיר לגוף צריך להיות לפחות 5 מ"מ. כדי לשדר קובצי נתונים או הודעות, מכשיר זה מחייב חיבור איכותי לרשת. במקרים מסוימים עלול שידור קבצי נתונים או הודעות להיות מושהה עד שחיבור כזה יהיה זמין. הקפד על שמירת הוראות המרחק המינימלי המוזכרות לעיל עד לסיום השידור.

טיפול במוצר ותחזוקה

- הקפד להשתמש בסוללות, במטענים ובאביזרים מקוריים של LG, המאושרים לשימוש בדגם טלפון ספציפי זה. השימוש בסוגים אחרים עשוי לבטל את האישור או האחריות החלים על הטלפון ועלול להיות מסוכן.
- חלק מהתוכן והאיורים עשויים להיראות שונה מהמכשיר שברשותך, והם כפופים לשינוי ללא הודעה מראש.
- אין לפרק יחידה זו. כאשר נדרש תיקון, פנה לטכנאי שירות מוסמך.
- תיקונים במסגרת האחריות, לפי שיקול דעתה של LG, עשויים לכלול חלקים או לוחות חלופיים, חדשים או מחודשים, ובלבד שהם מצוידים בפונקציונליות זהה לזו של החלקים המוחלפים.
- אין לקרב את המכשיר למכשירים חשמליים כגון טלוויזיות, מכשירי רדיו ומחשבים אישיים.
- יש לשמור את היחידה הרחק ממקורות חום כדוגמת רדיאטורים או תנורי בישול.
- אין להפיל את היחידה.
- אין לאפשר זעזוע מכני או חבטה.
- יש לכבות את הטלפון בכל מקום שבו נדרש הדבר על-ידי תקנות מיוחדות. לדוגמה, אין להשתמש בטלפון בבתי חולים, שכן הפעלתו עלולה להשפיע על פעולת מכשור רפואי רגיש.
- אין לאחוז בטלפון בידיים רטובות בזמן הטענתו. אחיזה במצב כזה עלולה לגרום להתחשמלות ולהסב נזק כבד לטלפון.
- אין לטעון את הטלפון ליד חומר דליק, מכיוון שהמכשיר עלול להתחמם ולעלות באש.

- יש להשתמש במטלית יבשה לניקוי חלקו החיצוני של המכשיר (אין להשתמש בחומרים ממסים כגון בנזן, מדלל או אלכוהול).
- אין לטעון את הטלפון כאשר הוא נמצא על-גבי מצעים או ריפוד.
- יש לטעון את הטלפון באזור מאוורר היטב.
- אין לחשוף יחידה זו לכמות מוגזמת של עשן או אבק.
- אין להחזיק את הטלפון בסמוך לכרטיסי אשראי או כרטיסי נסיעה; הנתונים בפס המגנטי עלולים להיפגם.
- אין להקיש על המסך באמצעות חפצים חדים, שכן הדבר עלול לגרום נזק לטלפון.
- אין לחשוף את הטלפון לנוזלים או ללחות.
- יש לנקוט זהירות בשימוש באביזרים, כמו אוזניות. אין לגעת באנטנה שלא לצורך.
- אם זכוכית המכשיר שבורה או סדוקה, אל תיגע בה או תנסה להסיר אותה ואל תשתמש במכשיר. האחריות אינה מכסה נזקים שנגרמו לתצוגת הזכוכית כתוצאה מפגיעה ושימוש לרעה.
- הטלפון שלך הוא מכשיר אלקטרוני המייצר חום במהלך הפעלה רגילה. בהיעדר אוורור הולם, מגע ישיר וממושך מאוד של העור עלול לגרום לאי-נוחות או לכוויות קלות. לפיכך, יש לנקוט זהירות בהחזקת הטלפון במהלך ההפעלה או מיד אחריה.
- אם הטלפון נרטב, נתק אותו מיד והנח לו להתייבש לגמרי. אל תנסה להאיץ את תהליך הייבוש בעזרת מקור חום חיצוני, כמו תנור, מיקרוגל או מייבש שיער.
- הנוזלים שחדרו לטלפון ישנו את צבע תווית המוצר שבתוך המכשיר. כתב האחריות אינו מכסה נזק למכשיר כתוצאה מחשיפה לנוזלים.

תפעול יעיל של הטלפון

מכשירים אלקטרוניים

כל הטלפונים הניידים עלולים לספוג הפרעות שישפיעו לרעה על ביצועיהם.

- אין להשתמש בטלפון הנייד בסמוך לציוד רפואי ללא קבלת רשות. יש להימנע מהנחת הטלפון מעל לקוצב לב, למשל בכיס החזה.
- טלפונים ניידים עלולים להפריע לעזרי שמיעה מסוימים.
- הפרעה משנית עלולה להשפיע על מכשירי טלוויזיה, מכשירי רדיו, מחשבים וכולי.
- השתמש בטלפון שלך בטמפרטורות שבין 0 ºC ו-40 ºC, אם ניתן. חשיפת הטלפון לטמפרטורות נמוכות או גבוהות באופן קיצוני עלולה לגרום לנזק, לתקלות או אפילו לפיצוץ.

בטיחות בדרכים

בדוק את החוקים והתקנות הנוגעים לשימוש בטלפונים ניידים באזורים שבהם אתה נוהג.

- אין להחזיק את הטלפון ביד בזמן נהיגה.
- יש להפנות את מלוא תשומת הלב לנהיגה.
- רד לשול הדרך וחנה לפני ביצוע שיחה או מענה לשיחה, בהתאם לתנאי הדרך.
- אנרגיית תדר רדיו עשויה להשפיע על מערכות אלקטרוניות מסוימות בכלי רכב, כדוגמת מערכות סטריאו וציוד בטיחות.
- אם המכונית מצוידת בכרית אוויר מתנפחת, אין לחסום אותה על-ידי התקנה של ציוד אלחוטי נישא. הדבר עלול לגרום לכשל של הכרית או לפציעה חמורה עקב ביצועים לא נאותים שלה.
- אם אתה מאזין למוסיקה בעת תנועה, ודא שהעוצמה היא ברמה סבירה, כך שתמשיך להיות מודע לסביבתך. הדבר חשוב במיוחד בקרבת כבישים.

מנעו נזק לשמיעתכם



כדי למנוע נזק אפשרי לשמיעה, אל תאזין בעוצמות קול גבוהות לאורך זמן.

חשיפה לעוצמות קול גבוהות במשך פרקי זמן ארוכים עלולה להזיק לשמיעה. לכן אנו ממליצים שלא תדליק או תכבה את המכשיר סמוך לאוזנך. מומלץ גם להגדיר את עוצמת הקול של המוסיקה והשיחה לרמה סבירה.

- כאשר אתה משתמש באוזניות, הנמך את עוצמת הקול אם אינך מצליח לשמוע את האנשים שבסביבתך מדברים, או אם האדם שלצדך יכול לשמוע את מה שאתה שומע באוזניות.

- עוצמת קול מופרזת מאוזניות פנימיות ואוזניות חיצוניות עלולה לגרום לאובדן שמיעה.

חלקי זכוכית

חלקים מסוימים של ההתקן הנייד עשויים מזכוכית. זכוכית זו עלולה להישבר אם המכשיר ייפול על משטח קשה או יקבל מכה חזקה. אם הזכוכית נשברת, אל תנסה לגעת בה או להסיר אותה. יש להפסיק להשתמש בהתקן הנייד עד להחלפת הזכוכית על-ידי ספק שירות מורשה.

סביבה שבה מבוצעות עבודות עם חומרי נפץ

אין להשתמש בטלפון באזורים שבהם מתבצעות פעולות פיצוץ. שים לב להגבלות ועמוד בכל התקנות או הכללים.

סביבה שבה קיימת סבירות לפיצוץ

- אין להשתמש בטלפון באזורי תדלוק.
- אין להשתמש בו בסמוך לדלק או לכימיקלים.
- אין להוביל או לאחסן גז דליק, נוזלים דליקים או חומרי נפץ בתא הרכב המכיל את הטלפון הנייד או את אביזריו.

כלי טיס

התקנים אלחוטיים עלולים לגרום להפרעה במטוס.

- יש לכבות את הטלפון הנייד לפני העלייה למטוס.
- אין להשתמש בו על הקרקע ללא קבלת רשות מאנשי הצוות.

ילדים

יש לשמור על הטלפון במקום בטוח, מחוץ להישג ידם של ילדים קטנים. המכשיר כולל חלקים זעירים העלולים להוות סכנת חנק אם ינותקו מהטלפון.

שיחות חירום

רק רשתות סלולריות מסוימות מאפשרות לבצע שיחות חירום. לפיכך, בשום מקרה אין לסמוך רק על הטלפון לביצוע שיחות חירום. בדקו את הנושא עם חברת הסלולר המקומית.

מידע לגבי הסוללה והטיפול בה

- אין צורך לפרוק את הסוללה במלואה לפני טעינתה מחדש. בניגוד למערכות סוללה אחרות, אין השפעת זיכרון שעלולה להשפיע על ביצועי הסוללה.
- יש להשתמש אך ורק בסוללות ובמטענים של LG. מטעני LG מיועדים למרב את חיי הסוללה.
- אין לפרק או לקצר את הסוללה.
- יש לשמור על ניקיון מגעי המתכת של הסוללה.
- יש להחליף את הסוללה כאשר היא אינה מפיקה עוד רמת ביצועים סבירה. ניתן לטעון מחדש את מארז הסוללה מאות פעמים לפני שיהיה צורך להחליפו.
- כדי למרב את שמישות הסוללה, טענו אותה מחדש אם לא הייתה בשימוש במשך זמן רב.
- אין לחשוף את מטען הסוללה לאור שמש ישיר או להשתמש בו בתנאי לחות גבוהה, כמו חדר אמבטיה.
- אין להשאיר את הסוללה במקומות חמים או קרים, שכן הדבר עלול לפגום בביצועיה.

- סכנת התפוצצות אם הסוללה הוחלפה בסוג סוללה שאינו מתאים. השלך סוללות משומשות בהתאם להוראות.
- אם עליך להחליף סוללה, קח אותה למרכז השירות המורשה הקרוב של LG Electronics או לספק לצורך קבלת סיוע.
- יש לנתק תמיד את המטען מהשקע לאחר שהטלפון נטען במלואו כדי למנוע בזבוז מיותר של חשמל מצד המטען.
- אורך חיי הסוללה בפועל תלוי בתצורת הרשת, בהגדרות המוצר, באופי השימוש, בתנאי הסוללה ובתנאים הסביבתיים.
- הקפד שלא ייווצר מגע בין הסוללה לבין פריטים חדים כגון שיניים או ציפורניים של בעל חיים. מגע כזה עלול לגרום לשריפה.

01

תכונות הניתנות להתאמה אישית

שיתוף מהיר


תוכל לשתף תמונה או סרטון וידאו עם היישום הרצוי מיד לאחר הצילום.

1 הקש על ◯ > , ולאחר מכן צלם תמונה או הקלט סרטון וידאו.

2 גרור את סמל Quick Share המופיע מיד לאחר צילום התמונה או הסרטון ובחר את היישום שבאמצעותו תשתף את מה שצילמת.

לחלופין, לחץ לחיצה ארוכה על סמל Preview שיופיע לאחר שתצלם תמונה או סרטון וידאו וגרור אותו אל סמל Quick Share.

- היישום שסמל Quick Share מציג עשוי להשתנות בהתאם לסוג ולתדירות הגישה שלך אל היישומים המותקנים במכשיר.






תצוגה ממוזערת

כדי לכווץ את המסך לשימוש ביד אחת, החלק שמאלה או ימינה על פני הלחצנים 'הקודם', 'בית' ו-Overview.

- ✕ : סגור את התצוגה הממוזערת.
- ◥ : שנה את גודלה של התצוגה הממוזערת.



חלון כפול

פונקציית החלון הכפול מפצלת את המסך כדי לאפשר ריבוי משימות, אינטראקציות ב'גרור ושחרר', קישור אוטומטי ויישומים שהיו בשימוש לאחרונה.

הפעלת החלון הכפול

1 הקש על ◯ > **הגדרות** > **כללי** > **חלון כפול**.

2 החלק על ⬭ כדי להפעיל אותו.

- סמן את תיבת הסימון 'פתח באופן אוטומטי', כדי שפונקציית החלון הכפול תיפתח באופן אוטומטי בעת הקשה על קישור במסך המלא או בעת הקשה על תמונה המצורפת להודעת דוא"ל.

שימוש בחלון הכפול

1 הקש על ◯ > □ > **חלון כפול**.

- כשאתה צופה ביישום, תוכל להקיש על □ > **חלון כפול** כדי להגדיר באופן אוטומטי את היישום הזה בחלון העליון, ולאחר מכן בחר את היישום השני.

2 הקש על סמל היישום שבו ברצונך להשתמש. היישום הראשון שעליו תקיש ייפתח בחלון בחלק העליון של המסך. היישום השני ייפתח בחלון התחתון.

3 הקש על חלון כדי לבחור בו ולהשתמש בו.

- תיבה כחולה מופיעה מסביב לחלון שנבחר, עם ידית כחולה בצורת חצי עיגול בין החלונות.
- גרור את הידית הכחולה כדי לשנות את גודלי החלונות (אחד גדול יותר ואחד קטן יותר).

QuickMemo+

סקירה כללית של QuickMemo+

תוכל להוסיף הערות יצירתיות על-ידי שימוש במגוון אפשרויות בתכונה מתקדמת זו של פנקס רשימות, כגון ניהול תמונות וצילומי מסך, שאינה נתמכת על-ידי פנקס הרשימות הקונבנציונלי.

יצירת הערה

1 הקש על ◯ > **QuickMemo+**.

2 הקש על ⊕ כדי ליצור הערה.

- ✓ : שמור הערה.
- ↩ : בטל את הפעולה האחרונה.
- ↪ : בצע שוב את הפעולה האחרונה שביטלת.
- T : הזן הערה על-ידי שימוש בלוח המקשים.
- ✎ : כתוב הערות באופן ידני.
- ◇ : מחק הערות שנכתבו בכתב יד.
- ◌ : הגדל או הקטן תצוגה, סובב או מחק חלקים מהערה בכתב יד.
- ⋮ : קבל גישה לאפשרויות נוספות, כולל שיתוף הערות ונעילתן, שינוי הסגנון של פנקס רשימות והוספת תוכן.

3 הקש על ✓ כדי לשמור את ההערה.

כתיבת הערות על צילום מסך

1 תוך הצגת המסך שברצונך לצלם, גרור את שורת המצב כלפי מטה והקש על .

- צילום המסך נראה עמו ערכת נושא ברקע של פנקס הרשימות. כלי מזכר מופיעים בחלקו העליון של המסך.

2 רשום הערות על המסך שצילמת.

- כדי לחתוך ולשמור חלק מהמסך, הקש על וסמן חלק באמצעות כלי החיתוך.
- כדי לצרף צילום מסך לפנקס רשימות, הקש על .

3 הקש על ושמור את ההערות במיקום הרצוי לך.

- ניתן להציג הערות שמורות ב-**QuickMemo+** או ב-**גלריה**.
- כדי לשמור הערות באותו מיקום כל הזמן, סמן את התיבה **השתמש כברירת מחדל לפעולה זו** ובחר יישום.

ניהול תיקיות

תוכל להציג הערות בחלוקה לפי סוג ההערה.

1 הקש על > **QuickMemo+**.

2 בחלק העליון של המסך, הקש על ובחר פריט תפריט:

- **כל התזכירים**: הצג את כל ההערות שנשמרו ב-**QuickMemo+**.
- **התזכירים שלי**: הצג הערות שנוצרו על-ידי **QuickMemo+**.
- **Capture+**: הצג הערות שנוצרו על-ידי **Capture+**.
- **פח אשפה**: הצגת הערות שנמחקו.
- **קטגוריה חדשה**: הוסף קטגוריות.
- : סדר מחדש, הוסף או מחק קטגוריות. כדי לשנות שם של קטגוריה, הקש על הקטגוריה.

- תיקיות מסוימות לא מופיעות בעת הפעלת QuickMemo+ בפעם הראשונה. תיקיות מושבתות מופעלות ומופיעות כאשר הן מכילות הערה קשורה אחת לפחות.

QSlide

ניתן להפעיל יישומים באמצעות QSlide כדי להשתמש בהם בזמן שיישומים אחרים כבר פועלים. לדוגמה, השתמש במחשבון או בלוח השנה כאשר סרטון וידאו מופעל.

בזמן שיישום פועל, הקש על ⋮ > **QSlide**.

• ייתכן שתכונה זו אינה נתמכת בחלק מהיישומים.

- : כדי לעבור למצב מסך מלא, השבת את מצב QSlide.
- : כוונן את מידת האטימות של חלון QSlide. כאשר חלון QSlide שקוף, הוא לא מגיב לקלט מגע.
- : סגור את חלון QSlide.
- : התאם את הגודל של חלון QSlide.

Pen Pop

התכונה 'חלון קופץ לעט' מאפשרת לך לגשת בקלות ובמהירות לאפשרויות ליצירת תזכורת. שלוף את העט, ו'חלון קופץ לעט' ייפתח.

הגדרת 'חלון קופץ לעט'

הקש על ◯ > **הגדרות** > **כללי** > **עט**.

אפשרויות 'חלון מוקפץ לעט'

- : הסתר/הצג את אפשרויות 'חלון מוקפץ לעט'.
- : פתח את Pop Memo כדי לכתוב תזכורת.
- : פתח את +Capture והשתמש בתמונת המסך הנוכחית בתזכורת.
- : פתח את Pop Scanner כדי לצלם תמונה באמצעות המצלמה ולהשתמש בה בתזכורת.
- : פתח את +QuickMemo וצפה בתזכורות הנוכחיות.
- : הוסף קיצור דרך ליישום לפי בחירתך.

- ניתן לשנות את קיצור הדרך המותאם אישית על ידי נגיעה ממושכת בסמל באפשרויות 'חלון קופץ לעט'.

שיתוף תוכן

הפעלת תוכן

אתה יכול להפעיל תוכן מהמכשיר בטלוויזיה. הפעל תוכן שמור כגון תמונות, מוסיקה וסרטוני וידאו.

1 חבר את הטלפון והטלוויזיה לאותה רשת Wi-Fi לפני הפעלת התוכן.

2 בחר **הרץ את התוכן** בתצוגת הפרטים ב'גלריה', 'נגן מוסיקה' כדי לבחור מכשיר להפעלה.

• עבור Chromecast, יש לעדכן את שירותי Google Play.

שליחה או קבלה של קבצים

ניתן לשלוח ולקבל קבצים במהירות בין טלפונים וטאבלטים של LG.

1 כדי לקבל קבצים, גרור כלפי מטה את שורת המצב והפעל 'שיתוף קבצים'. עבור מכשירים שאינם תומכים בשיתוף קבצים, הפעל את **SmartShare Beam** ב**הגדרות** > **רשתות** > **שתף והתחבר** > **שיתוף קבצים**.

2 ניתן לשלוח קבצים במהירות רבה יותר כששני המכשירים מחוברים לאותה רשת Wi-Fi. ניתן לשלוח קבצים לטלפונים ולטאבלטים התואמים ל-DLNA גם אם אלה אינם מכשירים של LG.

שליחת קבצים למכשיר אחר

1 בחר קובץ והקש על > **SmartShare Beam**.לחלופין, הקש על ברשימת הקבצים ובחר את הקבצים ולאחר מכן הקש על **שתף** > **SmartShare Beam**.

2 בחר מכשיר מרשימת המכשירים הסמוכים התומכים ב-SmartShare Beam.

• הקובץ נשלח למכשיר.

שימוש במכשירים סמוכים

תוכל להפעיל מהמכשיר שלך מוסיקה ופונקציות אחרות השמורות במכשיר מחובר.

1 ביישום **גלריה** או **נגן מוסיקה**, בחר ☰ > **מכשירים סמוכים**.

2 בחר מכשיר מרשימת המכשירים.

- אם המכשיר הרצוי לא נראה ברשימת המכשירים, בדוק ש-DLNA מופעל ולאחר מכן הקש על **חפש התקנים בקרבת מקום**.

3 הפעל תוכן שנשמר במכשיר שנבחר.

נא לא להפריע

תוכל להגביל או להשתיק התראות כדי למנוע הפרעות במשך פרק זמן מסוים.

1 הקש על ◯ > **הגדרות** > **צליל והתראה** > **נא לא להפריע** ולאחר מכן החלק את ⬭ כדי להפעיל את האפשרות.

2 הקש על **צלילים ורטט** ובחר את המצב הרצוי:

- **עדיפות בלבד**: קבל התראות קוליות או התראות ברטט עבור היישומים שנבחרו. התראות ימשיכו להישמע גם כאשר הפונקציה **עדיפות בלבד** מופעלת.
- **שקט מוחלט**: השבת את הקול והרטט.

צלצול מותאם

תוכל להגדיר את המכשיר כך שישמיע רינגטון שחובר באופן אוטומטי עבור כל שיחה נכנסת מאנשי הקשר שנבחרו. פונקציה זו שימושית משום שתדע לפי הצלצול בדיוק מי מתקשר אליך.

1 הקש על ◯ > **הגדרות** > **צליל והתראה** > **צלצול מותאם** ולאחר מכן החלק את ◯ כדי להפעיל את האפשרות.

2 הקש על **עריכת רינגטונים עבור** ובחר באפשרות הרצויה.

- רינגטון ברירת המחדל מושמע לשיחות נכנסות מאנשי קשר פרט לאיש הקשר שנבחר.

02

פונקציות בסיסיות

רכיבי מוצרים ואביזרים


ודא שאף אחד מהפריטים הבאים לא חסרים:

- מכשיר
- סוללה
- אוזניות סטריאו
- כבל USB
- מטען
- מדריך להתחלה מהירה

- השתמש תמיד באביזרים מקוריים של LG Electronics. השימוש באביזרים המיוצרים על-ידי יצרנים אחרים עלול להשפיע על ביצועי השיחות של המכשיר או לגרום לתקלות. ייתכן ששירות התיקונים של LG אינו מכסה דבר זה.

- אם אחד מהפריטים הבסיסיים הללו חסרים, פנה למשווק שממנו רכשת את המכשיר.
- כדי לרכוש פריטים בסיסיים נוספים, פנה למרכז שירות הלקוחות של LG.
- כדי לרכוש פריטים אופציונליים, פנה למרכז שירות הלקוחות של LG לקבלת רשימה של משווקים זמינים.
- פריטים מסוימים בקופסת המוצר כפופים לשינוי ללא הודעה מוקדמת.
- המראה והמפרטים של המכשיר כפופים לשינוי ללא הודעה מוקדמת.

סקירה כללית של החלקים



- **חיישן קרבה/אור סביבה**
  - חיישן קרבה: במהלך שיחה, חיישן הקרבה מכבה את המסך ומשבית את פונקציונליות המגע כאשר המכשיר צמוד לגוף. הוא מפעיל בחזרה את המסך והופך את פונקציונליות המגע לזמינה כאשר המכשיר נמצא מחוץ לטווח ספציפי.
  - חיישן תאורת הסביבה: חיישן תאורת הסביבה מנתח את עוצמת תאורת הסביבה כאשר מצב בקרת בהירות אוטומטית מופעל.
- **לחצני עוצמת קול**
  - כוונן את עוצמת הקול של רינגטונים, שיחות או התראות.
  - לחץ בעדינות על מקש עוצמת הקול כדי לצלם תמונה. כדי לצלם כמה תמונות ברצף, לחץ לחיצה ארוכה על מקש עוצמת הקול.
  - לחץ פעמיים על מקש החלשת עוצמת הקול (-) כדי להפעיל את היישום **מצלמה** כאשר המסך נעול או כבוי. לחץ פעמיים על מקש הגברת עוצמת הקול (+) כדי להפעיל את **Capture+**.
- **מקש הפעלה/נעילה**
  - לחץ לחיצה קצרה על המקש כאשר ברצונך להפעיל או לכבות את המסך.
  - לחץ לחיצה ארוכה על המקש כאשר ברצונך לבחור אפשרות בקרת צריכת חשמל.

- ייתכן שהגישה לפונקציות מסוימות תהיה מוגבלת, בהתאם למפרטי המכשיר.
- אל תניח חפצים כבדים על המכשיר ואל תשב עליו. אחרת, עלול להיגרם נזק לתכונת מסך המגע.
- כיסוי מגן למסך או אביזרים אחרים עלולים להפריע לפעולתו של חיישן הקרבה.
- אם המכשיר רטוב או שאתה משתמש בו במקום לח, ייתכן שחיישן המגע או הלחצנים לא יפעלו כראוי.

הדלקה או כיבוי

הדלקת המכשיר

כאשר המכשיר כבוי, לחץ לחיצה ארוכה על מקש ההפעלה/נעילה.

- כאשר תפעיל את המכשיר בפעם הראשונה, תתבצע קביעת תצורה ראשונית. זמן האתחול הראשון של הטלפון החכם עשוי להיות ארוך מן הרגיל.

כיבוי המכשיר

לחץ לחיצה ארוכה על מקש הפעלה/נעילה ולאחר מכן בחר **כיבוי**.

אפשרויות בקרת צריכת חשמל

הקש הקשה ממושכת על מקש הפעלה/נעילה ולאחר מכן בחר אפשרות.

- **כיבוי**: כבה את המכשיר.
- **כיבוי והפעלה מחדש**: הפעל מחדש את המכשיר.
- **הפעל מצב טיסה**: חסום פונקציות הקשורות לטלקומוניקציה, כולל ביצוע שיחות טלפון, העברת הודעות וגלישה באינטרנט. פונקציות אחרות נשארות זמינות.


התקנת כרטיס ה-SIM והסוללה

הכנס את כרטיס ה-SIM שקיבלת מספק שירותי המכשיר וכן את הסוללה הכלולה.


- אין להכניס כרטיס זיכרון לחריץ של כרטיס SIM. אם קרה שכרטיס זיכרון נתקע בחריץ של כרטיס SIM, מסור את המכשיר למרכז שירות של LG על מנת להוציא את כרטיס הזיכרון.

- כרטיסי Nano SIM בלבד פועלים עם המכשיר.


1 כדי להסיר את המכסה האחורי, החזק את המכשיר היטב ביד אחת. ביד השנייה, משוך והסר את המכסה האחורי בעזרת ציפורן האגודל כמוצג באיור.




2 החלק את כרטיס SIM אל תוך החריץ של כרטיס SIM כפי שמוצג באיור. ודא שאזור מגעי הזהב של הכרטיס פונה מטה.



3 הכנס את הסוללה.



4 כדי להחזיר את המכסה למכשיר, ישר את המכסה האחורי מעל תא הסוללה ולחץ אותו מטה עד שייכנס למקומו בנקישה.




טעינת הסוללה

טען את הסוללה לפני השימוש הראשון. השתמש במטען כדי לטעון את הסוללה. ניתן גם להשתמש במחשב כדי לטעון את הסוללה, על-ידי חיבור המכשיר אליו באמצעות כבל ה-USB.

- השתמש אך ורק במטענים, סוללות וכבלים המאושרים על-ידי LG. אם תשתמש במטענים, סוללות או כבלים שאינם מאושרים, הדבר עלול לגרום לעיכוב בטעינת הסוללה. לחלופין, הדבר עלול לגרום לסוללה להתפוצץ או לגרום נזק למכשיר, וזה אינו מכוסה במסגרת האחריות.

מחבר המטען ממוקם בתחתית המכשיר. הכנס את המטען וחבר אותו לשקע חשמל.



- אל תפתח את המכסה האחורי במהלך טעינת המכשיר.

מיטוב חיי הסוללה

הארך את כוח הסוללה על-ידי כיבוי תכונות שאין צורך בפעולה רציפה שלהן ברקע. תוכל לפקח על המידה שבה יישומים ומשאבי מערכת צורכים כוח סוללה.

הארכת חיי הסוללה של המכשיר

- כבה תקשורת רדיו כשאינך משתמש בה. אם אינך משתמש ב-Wi-Fi, בחיבור Bluetooth® או ב-GPS, כבה אותם.
- הפחת את בהירות המסך וקבע פרק זמן קצר יותר לכיבוי אוטומטי של המסך.
- בטל את הסנכרון האוטומטי של Gmail, לוח שנה, אנשי קשר ויישומים אחרים.
- חלק מהיישומים שתוריד עשויים לצרוך כוח סוללה.
- בזמן השימוש ביישומים שהורדת, בדוק את רמת הטעינה של הסוללה.

הכנסת כרטיס הזיכרון


המכשיר תומך בכרטיס microSD בנפח 128GB לכל היותר. בהתאם ליצרן ולסוג של כרטיס הזיכרון, ייתכן שכרטיסי זיכרון מסוימים לא יהיו תואמים למכשיר.

- ייתכן שכרטיסי זיכרון מסוימים לא יהיו תואמים באופן מלא למכשיר. אם תשתמש בכרטיס שאינו תואם, עלול להיגרם נזק למכשיר או לכרטיס הזיכרון, או לנתונים המאוחסנים בו.

- אם תכתוב ותמחוק נתונים בתדירות גבוהה מדי, אורך החיים של כרטיסי הזיכרון יתקצר.

1 הסר את המכסה האחורי.

2 הכנס כרטיס זיכרון כשהמגעים המוזהבים פונים כלפי מטה.




3 החזר את המכסה האחורי למקומו.

מסך המגע

תוכל ללמוד כיצד לשלוט במכשיר שברשותך על-ידי שימוש במחוות מסך המגע.


הקשה

הקש קלות עם קצה האצבע כדי לבחור או להפעיל יישום או אפשרות.




הקשת הקשה ממושכת

הקש הקשה ממושכת כמה שניות כדי להפעיל פונקציה מוסתרת.




הקשה כפולה

הקש פעמיים במהירות כדי להגדיל או להקטין תצוגה של תמונה או מפה.




החלקה

הקש הקשה ארוכה על פריט, לדוגמה, יישום או וידג'ט, ולאחר מכן החלק אותו למקום אחר. תוכל להשתמש במחווה זו כדי להזיז פריט.




החלקה מהירה


הקש בעדינות הקשה ממושכת על המסך ולאחר מכן החלק במהירות שמאלה או ימינה כדי לעבור במהירות ללוח אחר.



צביטה או פריסה

צבוט בשתי אצבעות כדי להקטין את התצוגה, למשל בתמונה או במפה. כדי להגדיל את התצוגה, פרוס את אצבעותיך.





- אין לחשוף את מסך המגע לזעזוע פיזי קיצוני. הדבר עלול לגרום נזק לחיישן המגע.

- תקלה של מסך המגע עלולה להתרחש אם תשתמש במכשיר בקרבת חומרים מגנטיים, מתכתיים או מוליכים.
- אם אתה משתמש במכשיר בתנאי תאורה בוהקת, כגון אור שמש ישיר, ייתכן שהמסך לא יהיה גלוי, בהתאם למיקום שלך. השתמש במכשיר במיקום מוצל או במיקום עם תאורת סביבה שאינה בוהקת מדי אך מוארת במידה שמספיקה לקרוא ספרים.
- אל תפעיל כוח רב מדי בעת לחיצה על המסך.
- הקש בעדינות עם קצה האצבע על האפשרות הרצויה.
- ייתכן שבקרת המגע לא תפעל כראוי אם תקיש על המסך עם הציפורן או כשאתה לובש כפפות.
- ייתכן שבקרת המגע לא תפעל כראוי כאשר המסך לח או רטוב.
- ייתכן שמסך המגע לא יפעל כראוי אם יש על המסך ציפוי מגן או שחיברת אל המכשיר אביזר שנרכש בחנות מקוונת או פיזית שאינה מתמחה.

מסך ראשי

סקירה כללית של המסך הראשי


המסך הראשי הוא נקודת המוצא שממנה ניתן לגשת לפונקציות וליישומים השונים במכשיר. הקש על ○ בכל מסך כדי לעבור היישר אל המסך הראשי.

תוכל לנהל את כל היישומים והווידג'טים במסך הראשי. החלק את המסך לשמאל או לימין כדי להציג במבט מהיר את כל היישומים המותקנים.

כדי לחפש יישום, השתמש בחיפוש של Google.

פריסת המסך הראשי

ניתן להציג את כל היישומים ולארגן וידג'טים ותיקיות במסך הראשי.



- המסך הראשי עשוי להשתנות, בהתאם לספק השירות או לגרסת התוכנה שברשותך.

- **שורת המצב**: הצג את סמלי המצב, השעה ורמת הטעינה של הסוללה.
- **וידג'ט**: הוסף וידג'טים למסך הראשי כדי לגשת במהירות למידע דרוש בלי שתצטרך להפעיל יישומים בזה אחר זה.
- **תיקייה**: צור תיקיות כדי לקבץ יישומים על פי העדפותיך.
- **סמל עמוד**: הצג את המספר הכולל של לוחות המסך הראשי והלוח המוצג כעת מודגש.
- **אזור הגישה המהירה**: קבע יישומים ראשיים בתחתית המסך כך שתוכל לגשת אליהם מכל אחד מהלוחות של המסך הראשי.
- **מקשי מגע במסך הראשי**
  - ◁ : חזור למסך הקודם. סגור את לוח המקשים או את החלונות המוקפצים.
  - ○ : הקש כדי לעבור למסך הראשי. כדי להפעיל את **Google**, הקש הקשה ארוכה.
  - □ : הצג רשימה של היישומים שהיו בשימוש לאחרונה או הפעל יישום מתוך הרשימה. השתמש באפשרות **נקה הכל** כדי למחוק את כל היישומים שהיו בשימוש לאחרונה. ביישומים מסוימים, לחיצה ארוכה על הלחצן תציג לפניך אפשרויות נוספות.

עריכת לחצני המסך הראשי

תוכל לסדר מחדש את לחצני המסך הראשי או להוסיף פונקציות בשימוש נפוץ ללחצני המסך הראשי.

הקש על ○ > **הגדרות** > **תצוגה** > **לחצני תצוגה** > **שילוב לחצנים** והתאם אישית את ההגדרות.

- כמה פונקציות, כולל QSlide, לוח התראה או +Capture, מסופקות. ניתן להוסיף חמישה פריטים לכל היותר.

סמלי מצב

כאשר מופעלת התראה על הודעה שלא נקראה, אירוע בלוח השנה או התראה של שעון מעורר, בשורת המצב מוצג סמל ההתראה התואם. בדוק את מצב המכשיר על-ידי צפייה בסמלי ההתראות המוצגים בשורת המצב.

- : אין אות
- : נתונים משודרים כרגע דרך הרשת
- : התראה מוגדרת
- : מצב רטט מופעל
- : Bluetooth מופעל
- : מחובר למחשב דרך USB
- : רמת הסוללה
- : מצב טיסה פעיל
- : שיחות שלא נענו
- : רשת Wi-Fi פועלת
- : מצב השתק מופעל
- : GPS מופעל
- : נקודה חמה מופעלת
- : כרטיס SIM חסר

- ייתכן שכמה מהסמלים הללו ייראו שונים או לא יופיעו כלל, בהתאם למצב המכשיר שלך. עיין בסמלים בהתאם לסביבה שבה אתה משתמש בפועל במכשיר שלך.
- הסמלים המוצגים עשויים להשתנות, בהתאם לאזור או לספקי השירות.


חלונית ההתראות

תוכל לפתוח את לוח ההתראות על-ידי גרירת שורת המצב כלפי מטה.

השתמש בסמלי הגישה המהירה בלוח ההתראות כדי להפעיל או לכבות פונקציה בקלות ובמהירות.

גרור שמאלה או ימינה ברשימת סמלי הגישה המהירה כדי לבחור את סמל הפונקציה הרצוי.

- אם תקיש הקשה ארוכה על הסמל, מסך ההגדרות של הפונקציה המתאימה יופיע.



הגדרות בלוח ההתראות

תוכל לבחור פריטים להצגה בלוח ההתראות.

הקש על ✎ בלוח ההתראות.

- כדי לסדר מחדש את סמלי הגישה המהירה, הקש הקשה ארוכה על סמל ולאחר מכן גרור אותו למיקום אחר.
- בחר סמלים שברצונך להציג ברשימה.

שינוי כיוון המסך

תוכל להגדיר שכיוון המסך ישתנה באופן אוטומטי, בהתאם לכיוון המכשיר.

בלוח ההתראות, הקש על **סיבוב** ברשימת סמלי הגישה המהירה.

לחלופין, הקש על ◯ > **הגדרות** > **תצוגה** > **סיבוב מסך אוטומטי** ולאחר מכן החלק על ◯ כדי להפעיל אותו.

עריכת המסך הראשי

במסך הראשי, הקש הקשה ממושכת על אזור ריק ולאחר מכן הפעל את הפונקציה הרצויה.

- כדי לסדר מחדש את הלוחות של המסך הראשי, הקש הקשה ארוכה על לוח ולאחר מכן גרור אותו למיקום אחר.
- כדי להוסיף וידג'טים למסך הראשי, הקש על **וידג'טים** וגרור וידג'ט למסך הראשי.
- כדי לשנות את ערכת הנושא של רקע המסך הראשי, הקש על **הגדרות מסך בית** ובחר **ערכת נושא**.
- כדי לשנות את הגדרות המסך הראשי, הקש על **הגדרות מסך בית** והתאם אישית את האפשרויות. לפרטים, ראה *הגדרות מסך בית*.

צפייה בערכת הנושא של הרקע

תוכל להציג את תמונת הרקע בלבד על-ידי הסתרת היישומים והווידג'טים במסך הראשי.

הרחק את שתי האצבעות בזמן שאתה לוחץ על המסך הראשי.

- כדי לחזור אל מסך היישומים והווידג'טים המקורי, בצע תנועת צביטה במסך הראשי.

הזזת יישומים במסך הראשי

במסך הראשי, הקש הקשה ארוכה על יישום ולאחר מכן גרור אותו למיקום אחר.

- כדי לשמור יישומים שבהם אתה משתמש לעתים קרובות בתחתית המסך הראשי, הקש והחזק את היישום ולאחר מכן גרור אותו לאזור הגישה המהירה בתחתית המסך.
- כדי להסיר סמל מאזור הגישה המהירה, גרור את הסמל למסך הראשי.

שימוש בתיקיות מתוך המסך הראשי

יצירת תיקיות

במסך הראשי, הקש הקשה ארוכה על יישום ולאחר מכן גרור אותו מעל יישום אחר.

- פעולה זו תיצור תיקייה חשה והיישום יתווסף אליה.

עריכת תיקיות

במסך הראשי, הקש על תיקייה ולאחר מכן הפעל את הפונקציה הרצויה.

- כדי לערוך את שם וצבע התיקייה, הקש על שם התיקייה.
- כדי להסיר יישום מהתיקייה, הקש הקשה ארוכה על היישום וגרור אל מחוץ לתיקייה. אם היישום שהסרת הוא היישום היחיד שהיה בתיקייה, התיקייה תוסר באופן אוטומטי.

הגדרות המסך הראשי

תוכל להתאים אישית את הגדרות המסך הראשי.

1 הקש על ◯ > **הגדרות** > **תצוגה** > **מסך ראשי**.

2 התאם אישית הגדרות:

- **בחר בית**: בחר מצב של המסך הראשי.
- **טפט**: שנה את ערכת הנושא של רקע המסך הראשי.
- **אפקט בהחלפת מסכים**: בחר אפקט שיוחל כאשר לוח המסך הראשי מתחלף.

- **ערכת נושא**: בחר את ערכת הנושא של המסך שברצונך להחיל.
- **סדר את היישומים לפי**: הגדר כיצד יתבצע מיון של יישומים במסך הראשי.
- **רשת**: שנה את מצב סידור היישומים עבור המסך הראשי.
- **הסתר יישומים**: בחר או בטל את הבחירה ביישומים שברצונך להסתיר במסך הראשי.

נעילת מסך

סקירה כללית של נעילת המסך

מסך המכשיר נכבה וננעל כאשר לוחצים על מקש הפעלה/נעילה. בנוסף, המסך נכבה וננעל לאחר שהמכשיר לא היה פעיל במשך פרק זמן שצוין.

אם תלחץ על מקש הפעלה/נעילה כאשר לא מוגדרת נעילת מסך, המסך הראשי יופיע באופן מידי.

כדי להבטיח שהמכשיר יהיה מאובטח ולמנוע גישה לא רצויה למכשיר, הגדר נעילת מסך.

- נעילת מסך מונעת קלט מגע מיותר על מסך המכשיר ומצמצמת את צריכת הסוללה. אנו ממליצים להפעיל את נעילת המסך כאשר אינך משתמש במכשיר.

קבע הגדרות נעילת מסך

לרשותך מספר אפשרויות שונות לנעילת המסך.

1 הקש על ◯ > **הגדרות** > **תצוגה** > **מסך נעילה** > **בחירת נעילת מסך** ולאחר מכן בחר את השיטה המועדפת עליך.

2 התאם אישית את הגדרות הנעילה:

- **ללא**: ביטול פונקציית נעילת המסך.
- **החלקה**: החלק על המסך כדי לבטל את נעילת המסך.

- **Knock Code**: הקש על המרווחים במסך בתבנית מסוימת כדי לבטל את נעילת המסך.
- **תבנית**: צייר תבנית לביטול נעילת המסך.
- **קוד PIN** : הזן סיסמה מספרית לביטול נעילת המסך.
- **סיסמה**: הזן סיסמה אלפאנומרית לביטול נעילת המסך.

- כדי להגדיר נעילת מסך באמצעות תבנית, תחילה צור חשבון Google או קוד PIN לגיבוי. אם הזנת ברצף תבנית שגויה יותר פעמים מהמותר, בטל את נעילת המסך בעזרת קוד ה-PIN לגיבוי או דרך חשבון Google.
- אם מוגדרת נעילת מסך באמצעות Knock code, תבנית, קוד PIN או סיסמה ואתה מזין קוד Pin או תבנית שגויים מספר פעמים גבוה יותר מהמספר שהוגדר, הזנת הסיסמה נחסמת למשך 30 שניות.
- עיין בדף הבית של LG Mobile בכתובת *www.lg-mobile.co.il* כדי לאתחל מסך נעול.

הגדרות נעילת מסך

תוכל להתאים אישית את הגדרות נעילת המסך.

1 הקש על ◯ > **הגדרות** > **תצוגה** > **מסך נעילה**.

2 התאם אישית הגדרות:

- **בחירת נעילת מסך**: בחר שיטה לנעילת מסך. אם אינך מעוניין להשתמש בנעילת מסך, הקש על **ללא**.
- **Smart Lock**: בחר פריטי 'טריגר', שההתרחשות של אחד מהם תגרום לביטול אוטומטי של נעילת המכשיר.
- **אפקט החלקת מסך**: הגדר אפקטי מעבר של המסך שיוחלו כאשר נעילת המסך תבוטל. אפשרות זו תופיע אם שיטת נעילת המסך שנבחרה היא 'החלקה'.
- **טפט**: שנה את תמונת הרקע של מסך הנעילה.
- **קיצורי דרך**: הוסף קיצור דרך יישום וגש ישירות ליישום מתוך מסך הנעילה על-ידי גרירת היישום אל מחוץ למעגל הגדול. אפשרות זו תופיע אם שיטת נעילת המסך שנבחרה היא 'החלקה'.

- **פרטי יצירת קשר עבור טלפון שאבד**: הצג פרטי יצירת קשר למצב חירום במסך הנעילה.
- **שעון עצר לנעילה**: הגדר את משך הזמן ללא פעילות, שלאחריו המכשיר יינעל באופן אוטומטי.
- **נעילה באמצעות לחצן ההפעלה**: נעל באופן מידי את המסך בעת לחיצה על מקש הפעלה/נעילה.

- פריטי ההגדרה הזמינים עשויים להשתנות, בהתאם לשיטת נעילת המסך שנבחרה.

הפעל מסך

ניתן להקיש הקשה כפולה על המסך כדי להפעיל או לכבות אותו.

- אפשרות זו זמינה אך ורק במסך הראשי שסופק על-ידי LG. היא לא תפעל כראוי במפעיל מותאם אישית או במסך ראשי שהותקן על-ידי המשתמש.
- בעת הקשה על המסך, השתמש בקצה האצבע. אל תשתמש בציפורן.
- כדי להשתמש בתכונה KnockON, ודא שחיישן הקרובה/תאורה לא נחסם על-ידי מדבקה או כל חומר זר אחר.

הפעלת המסך

הקש פעמיים באמצע המסך

- הקשה על החלק העליון או התחתון של המסך עשויה להקטין את שיעור זיהוי הפעולה.

כיבוי המסך

הקש פעמיים על שורת המצב, על אזור ריק במסך הראשי או על מסך הנעילה.

Knock Code

תוכל לבטל את נעילת המסך על ידי יצירת Knock Code משלך. כאשר המסך נעול, תוכל לגשת ישירות למסך הראשי על-ידי הקשה על המסך ברצף שצוין.

- תוכל להשתמש ב-Knock Code יחד עם התכונה KnockOn.
- אם הזנת ברצף Knock Code שגוי יותר פעמים מהמותר, בטל את הנעילה בעזרת קוד ה-PIN לגיבוי או דרך חשבון Google.
- הקפד להשתמש בקצה האצבע בעת הקשה על המסך.

יצירת Knock Code

1 הקש על ◯ > **הגדרות** > **תצוגה** > **מסך נעילה** > **בחירת נעילת מסך** > **Knock Code**.

2 הקש על הריבועים בתבנית הרצויה לך כדי ליצור Knock Code ולאחר מכן הקש על **הבא**.

3 לאימות, הזן שוב את ה- Knock Code ולאחר מכן הקש על **אשר**.

4 הגדר קוד PIN לגיבוי למקרה שתשכח את ה-Knock Code.

ביטול נעילת המסך עם Knock Code

בטל את נעילת המסך על ידי הזנת ה-Knock Code שיצרת.

הזן את ה-Knock Code במסך המגע כאשר המסך כבוי.

- תוכל להזין Knock Code גם כאשר מסך הנעילה מופעל.

הצפנת המכשיר

הצפנת המכשיר שלך

ניתן לקרוא, לכתוב ולהעתיק נתונים גם כאשר מוגדרת הצפנה מכשיר. בהגדרות הנעילה של המכשיר תוכל לקבוע שעם הפעלתו, הוא יציג בקשה להזנת פרטי הזיהוי של המשתמש.

אמצעי זהירות להצפנת המכשיר

תוכל להשתמש בנעילת הטלפון הנייד במסך הנעילה כדי להגדיל את רמת ההגנה על המכשיר.

- אם הזנת ברצף סיסמה שגויה יותר פעמים מהמותר כאשר נעילת הטלפון הנייד מופעלת, יתבצע במכשיר אתחול אוטומטי.
- אם שכחת את סיסמת הפענוח שלך, יהיה עליך לאתחל את המכשיר כדי להשתמש בו. האתחול ימחק את כל הנתונים שנשמרו לפני האתחול.
- עצירת ההצפנה לפני השלמתה עלולה לגרום נזק לנתונים. לדוגמה, אין להוציא או להכניס סוללה כאשר ההצפנה מתבצעת. המתן עד לסיום התהליך.

הצפנת כרטיס זיכרון

ניתן להצפין את הנתונים השמורים בכרטיס הזיכרון כדי להגן עליהם. לא ניתן לגשת לנתונים המוצפנים בכרטיס הזיכרון ממכשיר אחר.

1 הקש על ◯ > **הגדרות** > **כללי** > **אבטחה** > **הצפן אחסון כרטיס SD**.

2 קרא את הסקירה הכללית של הצפנת כרטיס הזיכרון המוצגת על המסך ולאחר מכן הקש על **המשך** כדי להמשיך.

3 בחר אפשרות והקש על **הצפן כעת**:

- **הצפנת קובץ חדש**: הצפן רק את הנתונים שנשמרו בכרטיס הזיכרון לאחר ההצפנה.
- **הצפנה מלאה**: הצפן את כל הנתונים השמורים כעת בכרטיס הזיכרון.
- **ללא קבצי מדיה**: הצפן את כל הקבצים, למעט קובצי מדיה כמו מוסיקה, תמונות וסרטוני וידאו.

- כדי להצפין את כרטיס הזיכרון, ודא שסוג נעילת המסך הוא קוד PIN או סיסמה.
- לאחר שיחל תהליך הצפנת כרטיס הזיכרון, פונקציות מסוימות לא יהיו זמינות.
- כיבוי המכשיר תוך כדי תהליך ההצפנה יגרום לכישלון התהליך ועלול לגרום נזק לנתונים מסוימים. לכן הקפד לוודא שהסוללה טעונה ברמה מספקת לפני שאתה מתחיל בתהליך ההצפנה.
- הקבצים המוצפנים יהיו נגישים רק מהמכשיר שבו הקבצים הוצפנו.
- לא ניתן להשתמש בכרטיס הזיכרון המוצפן במכשיר אחר של LG. כדי להשתמש בכרטיס הזיכרון המוצפן במכשיר נייד אחר, אתחל את הכרטיס.
- ניתן להפעיל הצפנת כרטיס זיכרון אפילו כאשר אין כרטיס זיכרון בתוך המכשיר. כל כרטיס זיכרון שיותקן לאחר ההצפנה יוצפן באופן אוטומטי.

יצירת צילומי מסך

באפשרותך לצלם תמונה של המסך הנוכחי שמוצג במכשיר.

באמצעות קיצור דרך

לחץ לחיצה ארוכה (לפחות שתי שניות) על מקש ההפעלה/נעילה ועל מקש החלשת עוצמת הקול (-) במקביל.

- תוכל לראות תמונות מסך דרך התיקייה **Screenshots** ב-**גלריה**.

באמצעות +Capture

במסך שבו ברצונך ליצור צילום מסך, גרור את שורת המצב כלפי מטה ולאחר מכן הקש על **+Capture**.


- כאשר המסך כבוי או נעול, קבל גישה אל **+Capture** בשתי לחיצות על מקש הגברת עוצמת הקול (+). ראשית, הקש על ◯ > **הגדרות** > **כללי** והפעל את **מקש קיצור דרך**.
- לפרטים, ראה *כתיבת הערות על צילום מסך*.

הזנת טקסט

שימוש במקלדת Smart

תוכל להשתמש במקלדת Smart כדי להזין ולערוך טקסט.


באמצעות מקלדת Smart, תוכל להציג טקסט תוך כדי הקלדה, בלי שתצטרך לעבור בין המסך למקלדת קונבנציונלית. הדבר יאפשר לך לאתר בקלות שגיאות ולתקן אותן תוך כדי הקלדה.



הזזת הסמן

מקלדת Smart מאפשרת לך להזיז את הסמן למיקום המדויק שאתה רוצה.

כאשר תקליד טקסט, הקש הקשה ארוכה על מקש הרווח וגרור שמאלה או ימינה, עד שהסמן יזוז למיקום הרצוי לך בטקסט.




• אפשרות זו זמינה רק במקלדות QWERTY.

הצעת מילים

מקלדת Smart מנתחת באופן אוטומטי את דפוסי השימוש שלך כדי להציע מילים בשימוש נפוץ תוך כדי הקלדה. ככל שתשתמש יותר במכשיר, כך ההצעות יהיו מדויקות יותר.

הזן טקסט והקש על מילה מוצעת; לחלופין, גרור מעלה בעדינות את הצד השמאלי או הימני של מקש הרווח.

- המילה שנבחרה תוזן באופן אוטומטי. אינך צריך להקליד באופן ידני כל אות של המילה.




שינוי הפריסה של מקלדת QWERTY

תוכל להוסיף, למחוק או לסדר מחדש מקשים בשורה התחתונה של המקלדת.

1 הקש על ◯ > **הגדרות** > **כללי** > **שפה ומקלדת** > **מקלדת LG** > **גובה ופריסת המקלדת** > **פריסת המקלדת QWERTY**.
לחלופין, הקש על ⚙ במקלדת והקש על **גובה ופריסת המקלדת** > **פריסת המקלדת QWERTY**.

2 הקש על מקש בשורה התחתונה ולאחר מכן גרור אותו למיקום אחר.




- אפשרות זו זמינה אך ורק במקלדות QWERTY, QWERTZ ו-AZERTY.
- ייתכן ששפות מסוימות אינן תומכות בפונקציה זו.

התאמה אישית של גובה המקלדת

תוכל להתאים אישית את גובה המקלדת כדי להבטיח שתוכל להקליד בנוחות.

1 הקש על ◯ > **הגדרות** > **כללי** > **שפה ומקלדת** > **מקלדת LG** > **גובה ופריסת המקלדת** > **גובה המקלדת**.
לחלופין, הקש על ⚙ במקלדת ולאחר מכן הקש על **גובה ופריסת המקלדת** > **גובה המקלדת**.

2 כוונן את גובה המקלדת.



בחירת מצב מקלדת לרוחב

תוכל לבחור מצב מקלדת לרוחב מבין כמה אפשרויות.

1 הקש על ◯ > **הגדרות** > **כללי** > **שפה ומקלדת** > **מקלדת LG** > **גובה ופריסת המקלדת** > **סוג מקלדת לרוחב**.
לחלופין, הקש על ⚙ במקלדת והקש על **גובה ופריסת המקלדת** > **סוג מקלדת לרוחב**.

2 בחר מצב מקלדת.


פיצול המקלדת

תוכל לפצל את המקלדת לשניים ולמקם את שני החלקים בשני צדי המסך כאשר המסך נמצא במצב לרוחב.

הקש על ◯ > **הגדרות** > **כללי** > **שפה ומקלדת** > **מקלדת LG** > **גובה ופריסת המקלדת** > **פיצול המקלדת**.

לחלופין, הקש על ⚙ במקלדת והקש על **גובה ופריסת המקלדת** > **פיצול המקלדת**.


- סובב את המכשיר למצב 'לרוחב' כדי לפצל את המקלדת לשני הצדדים. כדי למזג או לפצל את המקלדת, בצע באצבעותיך תנועת צביטה או פריסה על המקלדת.



מצב תפעול ביד אחת

תוכל להזיז את המקלדת לצד אחד של המסך כך שתוכל להשתמש במקלדת ביד אחת.

1. הקש על ◯ > **הגדרות** > **כללי** > **שפה ומקלדת** > **מקלדת LG** > **גובה ופריסת המקלדת** > **תפעול ביד אחת**.
   לחלופין, הקש על ⚙ במקלדת והקש על **גובה ופריסת המקלדת** > **תפעול ביד אחת**.
2. לחץ על החץ המוצג לצד המקלדת כדי להזיז את המקלדת בכיוון הרצוי.



הזן טקסט באמצעות הקול

במקלדת, הקש הקשה ארוכה על ⚙ ובחר 🎤.

- כדי לשפר את זיהוי הפקודות הקוליות, דבר באופן ברור.
- כדי להזין טקסט בדיבור, ודא שהמכשיר מחובר לרשת.

שינוי המקלדת

תוכל לשנות את שפת הקלט וסוג המקלדת לכל שפה.

1. הקש על ◯ > **הגדרות** > **כללי** > **שפה ומקלדת** > **מקלדת LG** > **בחר שפה**.
2. בחר שפה והתאם אישית את סוג המקלדת.

העתקה והדבקה

באפשרותך להעתיק או לגזור טקסט מתוך יישום ולהדביק אותו באותו יישום. לחלופין, אתה יכול להפעיל יישומים אחרים ולהדביק את הטקסט בתוכם.

1. הקש הקשה ארוכה ליד הטקסט שברצונך להעתיק או לגזור.
2. גרור את / כדי לציין את האזור שברצונך להעתיק או לגזור.
3. בחר **גזור** או **העתק**.
   - הטקסט שנגזר או הועתק נוסף באופן אוטומטי ללוח.
4. הקש הקשה ארוכה על חלון הזנת הקלט ולאחר מכן בחר **הדבק**.

- אם אין פריט שהועתק או נגזר, האפשרות **הדבק** לא תופיע.

מגש זמני

כאשר אתה מעתיק או גוזר תמונה או טקסט, הם נשמעים באופן אוטומטי בלוח וניתן להדביק אותם בכל מקום בכל עת.

1 במקלדת, הקש הקשה ארוכה על ⚙ ובחר 📋.
לחלופין, הקש הקשה ארוכה על חלון הזנת הקלט ולאחר מכן בחר **מגש זמני**.

2 בחר והדבק פריט מתוך הלוח.

- הקש על 📌 כדי לנעול פריטים שמורים על מנת להבטיח שהם לא יימחקו גם לאחר שבוצעה חריגה מהכמות המרבית המותרת. ניתן לנעול עשרה פריטים לכל היותר. כדי למחוק פריטים נעולים, תחילה בטל את נעילתם.
- הקש על 🗑 כדי למחוק את הפריטים השמורים בלוח.

- ייתכן שהלוח אינו נתמך על-ידי יישומים מסוימים שהמשתמש הוריד.

03

יישומים
שימושיים

התקנה והסרת התקנה של יישומים

התקנת יישומים

היכנס לחנות יישומים כדי לחפש ולהוריד יישומים.

- תוכל להשתמש בחנויות כמו **תונח Play** או חנות היישומים של ספק השירות שלך.

- ייתכן שחנויות יישומים מסוימות ידרשו ממך ליצור חשבון ולהיכנס לחשבון זה.
- יישומים מסוימים עשויים לגבות תשלום.
- אם אתה משתמש בנתונים לנייד, ייתכן שתחויב בתשלום בגין השימוש בנתונים, בהתאם לתוכנית המחירים שלך.

הסרת התקנה של יישומים

הסר את ההתקנה של יישומים שאינך משתמש בהם עוד מהמכשיר שלך.

- יישומים מסוימים אינם ניתנים להסרה על-ידי המשתמשים.

הסרת התקנה עם מחוות ההקשה הממושכת

במסך הראשי, הקש הקשה ארוכה על היישום כדי להסיר את התקנתו ולאחר מכן גרור אותו מעל האפשרות **הסר התקנה** בחלק העליון של המסך.

הסרת התקנה באמצעות תפריט ההגדרות

הקש על ◯ > **הגדרות** > **כללי** > **יישומים**, בחר יישום ולאחר מכן הקש על **הסר התקנה**.

הסרת התקנה של יישומים מחנות היישומים

כדי להסיר התקנה של יישום, עבור לחנות היישומים שממנה הורדת אותו, והסר את התקנתו.

טלפון

שיחה קולית

בצע שיחת טלפון על-ידי שימוש באחת השיטות הזמינות, כמו הזנה ידנית של מספר טלפון או ביצוע שיחה מרשימת אנשי הקשר או מרשימת השיחות האחרונות.

ביצוע שיחה מהמקלדת

1 הקש על ◯ > > **חייג**.

2 בצע שיחה באמצעות שיטה לבחירתך:

- הזן מספר טלפון ולאחר מכן הקש על .
- הקש הקשה ממושכת על מספר חיוג מהיר.
- חפש איש קשר על-ידי הקשה על האות הראשונה בשמו ברשימת אנשי הקשר, ולאחר מכן הקש על .

- כדי להזין את התו "+" לצורך שיחה בינלאומית, הקש הקשה ממושכת על הספרה 0.
- ראה *הוספת אנשי קשר לרשימת מספרי החיוג המהיר* כדי ללמוד כיצד להוסיף מספרי טלפון לרשימת מספרי החיוג המהיר.

ביצוע שיחה מרשימת אנשי הקשר

1 הקש על ◯ > > **אנשי קשר**.

2 ברשימת אנשי הקשר, בחר איש קשר והקש על

מענה לשיחה

כדי לענות לשיחה, גרור את אל מחוץ לעיגול במסך השיחה הנכנסת.

- כאשר אוזניות סטריאו מחוברות, תוכל לבצע שיחת באמצעות הלחצן חייג/סיום באוזניות.
- כדי לסיים שיחה על-ידי הקשה פשוטה על מקש הפעלה/נעילה, הקש על ◯ > **הגדרות** > **רשתות** > **הגדרות שיחה** > **מענה וסיום שיחות**, ולאחר מכן הפעל את

סיים שיחות באמצעות מקש ההפעלה.

דחיית שיחה

כדי לדחות שיחה נכנסת, גרור את אל מחוץ לעיגול במסך השיחה הנכנסת.

- כדי לשלוח הודעת דחייה, גרור את הודעת הדחייה אל מחוץ לעיגול.
- כדי להוסיף או לערוך הודעת דחייה, הקש על > **הגדרות** > **רשתות** > **הגדרות שיחה** > **סירוב ודחיית שיחות** > **דחה שיחה ושלח הודעה**.
- כאשר נכנסת שיחה, לחץ על לחצן הפחתת עוצמת הקול (-) או על לחצן ההפעלה/נעילה כדי להשתיק את הרינגטון או הרטט, או כדי להעביר את השיחה להמתנה.

צפייה בשיחות שלא נענו

במקרה של שיחה שלא נענתה, הסמל יופיע בשורת המצב, בחלק העליון של המסך.

כדי להציג את פרטי השיחה שלא נענתה, גרור את שורת המצב כלפי מטה. לחלופין, הקש על > > **יומן שיחות**.

הפונקציות הנגישות במהלך שיחה

במהלך שיחה, תוכל לגשת למגוון פונקציות על-ידי הקשה על הלחצנים המוצגים על המסך:

- **אנשי קשר**: הצג את רשימת אנשי הקשר במהלך שיחה.
- **ניתוק**: סיים שיחה.
- **מקשים**: הצג או הסר את מקשי החיוג.
- **רמקול**: הפעל את פונקציית הרמקול.
- **השתק**: השתק את הקול כדי שהצד השני לא ישמע את קולך.
- **Bluetooth**: העבר את השיחה למכשיר Bluetooth משויך ומחובר.
- : קבל גישה לאפשרויות שיחה רבות.

• פריטי ההגדרה הזמינים עשויים להשתנות בהתאם לאזור או לספק השירות.

ביצוע שיחה בת שלושה משתתפים

במהלך שיחה, תוכל להתקשר לאיש קשר נוסף.

1 במהלך שיחה, הקש על ⋮ > **הוסף שיחה**.

2 הזן מספר טלפון ולאחר מכן הקש על .

• שתי השיחות יוצגו במסך במקביל והשיחה הראשונה תעבור להמתנה.

3 כדי לעבור לשיחה אחרת, הקש על מספר אחר על המסך.

כדי להתחיל שיחת ועידה, הקש על .

• ייתכן שתחויב בתשלום עבור כל שיחה. לקבלת מידע נוסף, פנה לספק השירות שלך.

צפייה ברשומות שיחה

כדי להציג רשומות שיחה אחרונות, הקש על ◯ > > **יומן שיחות**. לאחר מכן, תוכל להשתמש בפונקציות הבאות:

• כדי להציג רשומות שיחה מפורטות, בחר איש קשר. כדי לבצע שיחה לאיש קשר שנבחר, הקש על .

• כדי למחוק את כל רשומות השיחה, הקש על ⋮ > **מחק הכל**.

• משך השיחה המוצג עשוי להיות שונה ממשך השיחה המשמש לחיוב. לקבלת מידע נוסף, פנה לספק השירות שלך.

הגדרת אפשרויות שיחה

באפשרותך בחור באפשרויות שיחה שונות.

1 הקש על ◯ > > **חייג** או על **יומן שיחות**.

2 הקש על ⋮ > **הגדרות שיחה** ולאחר מכן הגדר את האפשרויות בהתאם להעדפותיך.

הודעות

שליחת הודעה

באמצעות היישום Messages תוכל ליצור הודעות ולשלוח אותן לאנשי קשר נבחרים או לכל אנשי הקשר.

- שליחת הודעות לחו"ל עלולה להיות כרוכה בתשלום נוסף. לקבלת מידע נוסף, פנה לספק השירות שלך.

1 הקש על ◯ > .

2 הקש על .

3 ציין נמען וצור הודעה.

- כדי לצרף קבצים, הקש על .
- כדי לגשת לפריטי תפריט אופציונליים, הקש על ⋮.

4 הקש על **שלח** כדי לשלוח את ההודעה.

קריאת הודעה

תוכל להציג את חליפת ההודעות שלך עם כל איש קשר.

1 הקש על ◯ > .

2 בחר איש קשר מרשימת ההודעות.

קביעת ההגדרות להעברת הודעות

באפשרותך לשנות את הגדרות העברת ההודעות בהתאם להעדפותיך.

1 הקש על ◯ > .

2 הקש על ⋮ > **הגדרות** ברשימת ההודעות.

מצלמה

התחלת המצלמה

תוכל לצלם תמונה או סרטון וידאו כדי להנציח רגעים חשובים.

הקש על ◯ > .

- לפני שאתה מצלם, נקה את עדשת המצלמה במטלית מיקרופייבר. מגע של אצבע בעדשת המצלמה עלולה לגרום לתמונות מטושטשות.
- אם רמת הסוללה נמוכה מ-5 %, טען את הסוללה לפני השימוש במצלמה.
- התמונות הנכללות במדריך למשתמש זה עשויות להיות שונות מאלה שנמצאות במכשיר בפועל.
- ניתן לצפות בתמונות ובסרטוני וידאו ולערוך אותם ב**גלריה**. לפרטים, ראה *סקירה כללית של הגלריה*.

מעבר בין המצלמות

באפשרותך לעבור מהמצלמה הקדמית לאחורית וחזרה בהתאם לסביבת הצילום.

במסך המצלמה, הקש על או גרור את המסך כלפי מעלה או כלפי מטה, לשמאל או לימין, כדי לעבור בין המצלמה הקדמית למצלמה האחורית.

- השתמש במצלמה הקדמית לצילום תמונות סלפי. לפרטים, ראה *צילום תמונות סלפי*.

מצב אוטומטי

תוכל לצלם תמונות או להקליט סרטוני וידאו על-ידי בחירת מגוון מצבי צילום ואפשרויות.



צילום תמונה

1 בחר מצב צילום והקש על העצם שבו ברצונך למקד את המצלמה.

2 הקש על כדי לצלם תמונה.

לחלופין, הקש על מקש עוצמת קול.

- כאשר המסך כבוי או נעול, הפעל את המצלמה בשתי לחיצות מהירות על מקש החלשת עוצמת הקול (-). כדי להפעיל פונקציה זו, הקש על > **הגדרות** > **כללי** והפעל את **מקש קיצור דרך**.

הקלטת סרטון וידאו

1 בחר מצב צילום והקש על העצם שבו ברצונך למקד את המצלמה.

2 הקש על .

- כדי לצלם תמונה תוך כדי צילום סרטון וידאו, הקש על .
- כדי להשהות את הצילום של סרטון וידאו, הקש על ||. כדי לחדש את צילום הווידאו, הקש על .

3 הקש על כדי לסיים את צילום סרטון הווידאו.

פנורמה

תוכל ליצור תמונה פנורמית על ידי הזזת המצלמה בכיוון אחד כדי לצלם ולחבר יחד צילומים רציפים של נוף רחב.

1 במצב אוטומטי, הקש על **מצב** > .

2 הקש על ולאחר מכן הזז בקצב איטי את המצלמה בכיוון אחד.
- הזז את המכשיר בכיוון החץ שמופיע בהנחיה.

3 הקש על כדי לסיים את הצילום.

צילום רציף

תוכל לצלם צילומים רציפים של תמונות כדי ליצור תמונות נעות.

במסך המצב האוטומטי, לחץ לחיצה ארוכה על .
- צילומים רציפים מצולמים במהירות מהירה כאשר מוחזק לחוץ.

- ניתן לצלם עד שלושים (30) תמונות ברצף.

התאמה אישית של אפשרויות במצלמה

תוכל להתאים אישית מגוון אפשרויות מצלמה כדי להתאימה לצרכיך.

במצב אוטומטי, הקש על .

- האפשרויות הזמינות משתנות בהתאם למצלמה הנבחרת (מצלמה קדמית או אחורית) ולמצב הצילום שנבחר.

16:9	בחר יחס תצוגה לתמונות או איכות תמונה לסרטוני וידאו.
HDR AUTO	קבל תמונות או סרטונים בצבעים חיים ואפקטים של פיצוי אפילו אם הפריטים צולמו מול האור. פונקציות אלה כלולות בטכנולוגיית HDR (טווח דינמי גבוה) הכלולה במצלמת המכשיר.
OFF	הגדר את הטיימר לצילום אוטומטי של תמונות לאחר פרק זמן שצוין.
OFF	צלם תמונות עם פקודות קוליות. (האפשרויות הזמינות: Cheese, Smile, Whisky, Kimchi, LG)

הצג קווים מנחים כך שתוכל לצלם תמונות או סרטוני וידאו בהתבסס על קווי ייחוס אופקיים ואנכיים.	
הגדר את המיקומים שבהם תרצה לשמור תמונות וסרטוני וידאו. אפשרויות אלה מופיעות כאשר הוכנס כרטיס זיכרון חיצוני. : שמור באחסון הפנימי. : שמור באחסון החיצוני.	/
היפוך תמונות. אפשרויות אלה מופיעות בעת שימוש במצלמה הקדמית. : אל תהפוך את התמונה. : הפוך את התמונה בכיוון אופקי.	/
התאם אישית את הגדרות הצילום האוטומטי. אפשרויות אלה מופיעות בעת שימוש במצלמה הקדמית. : צלם באמצעות תכונת הצילום מבוסס המחוות. : צלם כאשר המצלמה מזהה פנים.	/

צילום תמונות סלפי

תוכל להשתמש במצלמה הקדמית כדי להציג את פניך על המסך ולצלם סלפי.

- בעת שימוש במצלמה הקדמית, צילומי סלפי מבוצעים כברירת מחדל באמצעות צילום בתנועת יד. לפרטים, ראה *התאמה אישית של אפשרויות במצלמה* .

צילום בתנועת יד

תוכל לצלם תמונות סלפי באמצעות מחוות.

הצג את כף ידך למצלמה הקדמית ולאחר מכן סגור אותה לאגרוף.

- בתוך שלוש שניות תצולם תמונה.

- כדי להשתמש בפונקציה זו, ודא שהאפשרות [✋] נבחרה באפשרויות המצלמה.
- דרך חלופית לצילום מבוסס מחוות היא לסגור את כף היד לאגרוף ולאחר מכן לפתוח אותה לכיוון המצלמה הקדמית.
- ודא שכף היד והאגרוף שלך נכללים בתוך קו הייחוס כך שהמצלמה תוכל לזהות אותם.
- ייתכן שהגישה לפונקציות מסוימות תהיה מוגבלת במהלך צילום תצוגות מרובות.

צילום אינטרוולי

תוכל לצלם תמונות סלפי ברצף.

כשאתה משתמש במצלמה הקדמית, הקש והחזק את [📷]. לחלופין, הצג את כף ידך למצלמה ולאחר מכן כווץ את אגרופך פעמיים במהירות.

- המכשיר יצלם ארבע תמונות במרווח של שלוש שניות זו מזו.

- כדי להשתמש בפונקציה זו, ודא שהאפשרות [✋] נבחרה באפשרויות המצלמה.

צילום תמונות באופן אוטומטי

כאשר אתה עובר למצלמה הקדמית, המצלמה מזהה את תווי הפנים שלך ומבצעת צילום אוטומטי של תמונת סלפי.

- כדי שתוכל להשתמש בפונקציה זו, הקפד לבחור באפשרות [😊] תחת אפשרויות המצלמה.

גלריה

סקירה כללית של הגלריה

תוכל להציג ולנהל תמונות וסרטוני וידאו שנשמרו במכשיר.

1 הקש על ◯ > .

• תמונות וסרטוני וידאו שנשמרו מוצגים לפי תיקיות.

2 הקש על תיקייה ובחר קובץ.

• הצג את הקובץ שנבחר במצב מסך מלא.


• החלק לשמאל או לימין על התמונה או הסרטון שבמסך כדי להציג את הקובץ הקודם או הבא.

• ייתכן שחלק מתבניות הקבצים אינן נתמכות, בהתאם לתוכנות המותקנות.

• ייתכן שקבצים מסוימים לא ייפתחו עקב קידוד.

• קבצים שחורגים ממגבלת הגודל עלולים לגרום לשגיאה.

הצגת תמונות



עריכת תמונות

1 תוך כדי הצגת תמונה, הקש על ✎.


2 ערוך את התמונה בעזרת מגוון של אפקטים וכלי עריכה.

3 הקש על ✓ כדי להחיל שינויים.

4 הקש על **שמור** כדי לשמור שינויים.

- התמונה הערוכה תחליף את הקובץ המקורי.
- כדי לשמור את התמונה שנערכה כקובץ אחר, הקש על ⋮ > **שמור עותק**.

הפעלת קובץ וידאו



- כדי לכוונן את עוצמת הקול, גרור את הצד הימני של מסך הווידאו למעלה או למטה.
- כדי לכוונן את בהירות המסך, גרור את צדו השמאלי של מסך הווידאו למעלה או למטה.

מחיקת קבצים

תוכל למחוק קבצים באמצעות אחת משתי האפשרויות הבאות:

- הקש הקשה ממושכת על קובץ ברשימה, ולאחר מכן הקש על **מחק**.
- ברשימת הקבצים, הקש על 🗑 ובחר קובץ.

שיתוף קבצים

תוכל לשתף קבצים באמצעות אחת משתי האפשרויות הבאות:

- תוך כדי הצגת תמונה או סרטון וידאו, הקש על ⋖ כדי לשתף את הקובץ בשיטה הרצויה.
- ברשימת הקבצים, הקש על ⋖ כדי לבחור קובץ ולשתף אותו בשיטה הרצויה.

מנהל הקבצים

תוכל להציג ולנהל קבצים שנשמרו במכשיר שלך.

1 הקש על ◯ > **כלים** > **מנהל הקבצים**.

2 הקש על ☰ ובחר במיקום האחסון הרצוי.

מזג אויר

תוכל להציג את פרטי מזג האוויר לאזור מסוים.

1 הקש על ◯ > **כלים** > **מזג אויר**.

2 הקש על + והוסף את העיר הרצויה.

- במסך פרטי מזג האוויר, הקש על 〉 / 〈, או גרור את המסך לשמאל או לימין כדי להציג את מזג האוויר בערים אחרות.

מחשבון

ניתן להשתמש בשני סוגי מחשבונים: המחשבון הפשוט והמחשבון המדעי.

1 הקש על ◯ > **מחשבון**.

2 השתמש בלוח המקשים כדי לבצע חישוב.

- כדי להשתמש במחשבון המדעי, הקש על ⋮ > **מחשבון מדעי**.
- כדי להציג את היסטוריית החישובים, הקש על ⋮ > **היסטוריית חישובים**.

3

משימות

תוכל לרשום משימות במכשיר שלך כדי לנהל בקלות לוחות זמנים.

1 הקש על ◯ > **משימות**.

2 הקש על ⊕ כדי להוסיף משימה.

3 הזן פרטי משימה ולאחר מכן הקש על **שמור**.

הקלטה קולית

תוכל להקליט ולשמור את קולך או קולות של אחרים באירועים חשובים. קובצי הקול המוקלטים יופעלו או ישותפו.

1 הקש על ◯ > **כלים** > **הקלטה קולית**.

2 הקש על ⊙.

- כדי להשהות הקלטה, הקש על ⏸.

3 הקש על ⊡ כדי לסיים את ההקלטה.

- הקובץ נשמר באופן אוטומטי ומוצג מסך להאזנה.

4 הקש על ▷ כדי להפעיל את הקול המוקלט.

- כדי לשמור את פרטי המיקום של ההקלטה, הקש על **מיקום**.
- כדי להוסיף אירוע, הקש על **אירוע** והוסף אירוע לתאריך הרצוי.
- אם תקיש על ≡, קובצי הקול המוקלטים יופיעו. תוכל להפעיל קובץ קול מוקלט מהרשימה.

הורדות

תוכל להציג, למחוק או לשתף קבצים שהורדת מהאינטרנט או יישומים.

הקש על ◯ > **כלים** > **הורדות**.

רדיו FM

תוכל להאזין לרדיו FM.

הקש על ◯ > **כלים** > **רדיו FM**.

- כדי להשתמש ביישום זה, תחילה חבר אוזנייה למכשיר. האוזנייה הופלת לאנטנת הרדיו.
- התמיכה באפשרות זו תלויה באזור.

שעון

התראה

תוכל להגדיר התראה שתופעל במועד שצוין.

1. הקש על ◯ > **שעון** > **התראה**.
2. הקש על + כדי להוסיף התראה חדשה.
3. קבע את הגדרות ההתראה והקש על **שמור**.

- אם תבחר התראה שהוגדרה בעבר, תוכל לערוך אותה.
- כדי למחוק התראה, הקש על 🗑 בראש המסך. לחלופין, הקש הקשה ארוכה על ההתראה.

שעון עולמי

תוכל להציג את השעה הנוכחית בערים ברחבי העולם.

1. הקש על ◯ > **שעון** > **שעון עולמי**.
2. הקש על + והוסף עיר.

טיימר

תוכל להגדיר טיימר כדי להפעיל התראה לאחר פרק זמן שצוין.

1 הקש על ◯ > **שעון** > **טיימר**.

2 הגדר את הזמן והקש על **התחל**.

- כדי להשהות את הטיימר, הקש על **הפסק**. כדי לחדש את פעולת הטיימר, הקש על **המשך**.
- כדי לאפס את הגדרות הטיימר, הקש על **איפוס**.

3 הקש על **הפסק** כדי להפסיק את התראת הטיימר.

שעון עצר

תוכל להשתמש בשעון העצר כדי לתעד את משך הזמן שחלף.

1 הקש על ◯ > **שעון** > **שעון עצר**.

2 הקש על **התחל** כדי להפעיל את שעון העצר.

- כדי לתעד זמן הקפה, הקש על **הקפה**.

3 הקש על **הפסק** כדי להשהות את שעון העצר.

- כדי לחדש את פעולת שעון העצר, הקש על **המשך**.
- כדי למחוק את כל רישומי שעון העצר, הקש על **איפוס**.

נגן מוסיקה

תוכל להפעיל ולנהל קובצי מוסיקה שנשמרו במכשיר שלך.

1 הקש על ◯ > **נגן מוסיקה**.

2 בחר קטגוריה.

3 בחר קובץ מוסיקה.



- ייתכן שחלק מתבניות הקבצים אינן נתמכות, בהתאם לתוכנות המותקנות.
- קבצים שחורגים ממגבלת הגודל עלולים לגרום לשגיאה.
- קובצי מוסיקה עשויים להיות מוגנים על-ידי בעלים בינלאומיים של זכויות יוצרים או חוקי זכויות יוצרים. ייתכן שתצטרך להשיג אישור משפטי לפני העתקת קובץ מוסיקה. כדי להוריד או להעתיק קובץ מוסיקה, תחילה בדוק את חוק זכויות היוצרים עבור המדינה הרלוונטית.

דוא"ל

סקירה כללית של דוא"ל

תוכל לרשום חשבון דוא"ל במכשיר שלך ולאחר מכן תוכל לבדוק ולשלוח הודעות דוא"ל מהמכשיר.

- אם אתה משתמש בנתונים לנייד, ייתכן שתחויב בתשלום בגין דמי השימוש בנתונים, בהתאם לתוכנית המחירים שלך. לקבלת מידע נוסף, פנה לספק השירות שלך.

רישום חשבונות דוא"ל

כאשר תשתמש ביישום הדוא"ל בפעם הראשונה, תתבקש לרשום את חשבון הדוא"ל שלך.

1. הקש על ◯ > **דוא"ל**.
2. בחר ספק שירותי דוא"ל.
3. הזן את כתובות הדוא"ל ואת הסיסמה, ולאחר מכן הקש על **הבא** כדי לרשום את החשבון שלך.
   - כדי לרשום באופן ידני חשבון דוא"ל או כדי לרשום חשבונות דוא"ל שלא נמצאו ברשימה, הקש על **הגדרה ידנית**.

ניהול חשבונות דוא"ל

כדי להציג או לערוך את הגדרות חשבון הדוא"ל שלך, הקש על ⋮ > **הגדרות**.

- כדי להוסיף חשבון, הקש על **הוסף חשבון** .
- כדי למחוק חשבון, הקש על ⋮ > **הסר חשבון**.

פתיחת חשבון דוא"ל נוסף

אם יש כמה חשבונות דוא"ל רשומים וברצונך להציג חשבון נוסף, הקש על ☰ ובחר חשבון אחר מרשימת החשבונות.

בדיקת דוא"ל

1 הקש על ☰ ובחר תיבת דואר.

2 בחר דוא"ל מרשימת הדוא"ל.

• הודעת הדוא"ל תופיע.

שליחת דוא"ל

1 הקש על ⊕.

2 הזן את כתובת הדוא"ל של נמען.

3 הזן נושא והודעה

• כדי לצרף קבצים, הקש על 📎.

• כדי לגשת לפריטי תפריט אופציונליים, הקש על ⋮.

4 הקש על ➤ כדי לשלוח את הדוא"ל.

אנשי קשר

סקירה כללית של אנשי קשר

באפשרותך לשמור ולנהל אנשי קשר.

הקש על ◯ > **אנשי קשר**.

הוספת אנשי קשר

הוספת אנשי קשר חדשים

1 במסך של רשימת אנשי הקשר, הקש על +.

2 הזן פרטי יצירת קשר והקש על **שמור**.

ייבוא אנשי קשר

תוכל לייבא אנשי קשר מהתקן אחסון אחר.

1 במסך של רשימת אנשי הקשר, הקש על ⋮ > **עוד** > **ניהול אנשי קשר** > **ייבוא**.

2 בחר את מיקומי המקור והיעד של איש הקשר שברצונך לייבא ולאחר מכן הקש על **אישור**.

3 בחר אנשי קשר והקש על **ייבוא**.

הוספת אנשי קשר לרשימת מספרי החיוג המהיר

1 במסך של רשימת אנשי הקשר, הקש על ⋮ > **חיוג מהיר**.

2 הקש על **הוסף איש קשר** ממספר חיוג מהיר.

3 בחר איש קשר.

חיפוש אנשי קשר

תוכל לחפש אנשי קשר באמצעות אחת משתי האפשרויות הבאות:

- במסך רשימת אנשי הקשר, הזן שם איש קשר בתיבת החיפוש.
- גלול מעלה או מטה ברשימת אנשי הקשר.
- באינדקס של מסך רשימת אנשי הקשר, הקש על האות הראשונה של איש קשר.

רשימת אנשי קשר

עריכת אנשי קשר

1 במסך רשימת אנשי הקשר, בחר באיש הקשר הרצוי.

2 במסך פרטי איש הקשר, הקש על ✎ וערוך את הפרטים.

3 הקש על **שמור** כדי לשמור שינויים.

מחיקת אנשי קשר

1 במסך רשימת אנשי הקשר, לחץ לחיצה ארוכה על איש הקשר הרצוי.

2 הקש על **מחק איש קשר**.

הוספת מועדפים

באפשרותך לרשום אנשי קשר בשימוש נפוץ כמועדפים.

1 במסך רשימת אנשי הקשר, בחר באיש הקשר הרצוי.

2 במסך פרטי איש הקשר, הקש על ☆.

יצירת קבוצות

1 במסך של רשימת אנשי הקשר, הקש על **קבוצות** > ⋮ > **קבוצה חדשה**.

2 הזן שם קבוצה חדשה.

3 הקש על **הוסף חברים**, בחר אנשי קשר ולאחר מכן הקש על **הוסף**.

4 הקש על **שמור** כדי לשמור את הקבוצה החדשה.

לוח שנה

סקירה כללית של לוח השנה

תוכל להשתמש בלוח השנה כדי לנהל אירועים ומשימות.

הוספת אירועים

1 הקש על ◯ > **לוח שנה**.

2 בחר תאריך ולאחר מכן הקש על ⊕.

3 הזן פרטי אירוע והקש על **שמור**.

- אם תקיש על תאריך בלוח השנה והתאריך מכיל אירועים, יופיע חלון מוקפץ שמציג רשימה של האירועים. הקש על אירוע בחלון המוקפץ כדי להציג את פרטי האירוע.

סנכרון אירועים

הקש על ⋮ > **לוחות שנה מוצגים** > ⋮ > **לוחות שנה לסינכרון** ובחר את לוח השנה שברצונך לסנכרן.

- בעת שמירת אירועים מהמכשיר שלך אל חשבון Google, מתבצע סינכרון אוטומטי שלהם גם עם לוח השנה של Google. בהמשך תוכל לסנכרן מכשירים אחרים מול לוח השנה של Google כדי שגם באותם מכשירים האירועים יהיו זהים לאלה השמורים במכשיר שלך; לאחר הסינכרון תוכל לנהל את האירועים שלך דרך אותם מכשירים.

Event pocket

תוכל להשתמש ב-Event Pocket כדי ליצור אירועים.

הקש על כדי לפתוח את ה-Event Pocket ולאחר מכן גרור תוכן לתאריך בלוח השנה.

- : נהל תמונות, טקסט, הערות ואירועים שנשמרו באופן זמני. תוכל גם לשתף טקסט, תמונות והערות מיישום אחר ולשמור אותם בארגז האירועים. אם תקיש על **כיס** בעת יצירת אירוע, האירוע יישמר באופן זמני ב-Event Pocket.
- : נהל משימות שאין להן תאריך יעד, כמו למשל אירועים.

Evernote

תוכל לכתוב ולאסוף מידע חשוב ולאחר מכן לשתף זאת עם מכשירים אחרים שתומכים ב-**Evernote**.

הקש על > **Evernote**.

שירות התראות חירום

תוכל להציג שידורי טקסט בזמן במצבי חירום, כגון סופות טייפון, שיטפונות ורעידות אדמה.

הקש על > **כלים** > **שירות התראות חירום**.

LG Backup

תוכל לגבות, לשחזר ולהעביר נתונים שנשמרו במכשיר שלך.

1 הקש על ◯ > **כלי ניהול** > **LG Backup**.
לחלופין, הקש על ◯ > **הגדרות** > **כללי** > **גיבוי ואיפוס** > **LG Backup**.

2 פעל לפי ההנחיות שבמסך כדי לבחור אם לגבות נתונים בתיקיית הגיבוי הקיימת במכשיר או להעתיק אותם אל מכשירים אחרים.

- אתחול המכשיר עשוי למחוק קובצי גיבוי שנשמרו בשטח אחסון פנימי. כדי למזער את אובדן הנתונים, העתק קובצי חשובים מתיקיית הגיבוי של LG בשטח האחסון הפנימי למחשב או להתקן אחסון חיצוני.

- הנתונים בחשבון Google לא יגובו. כאשר תסנכרן את חשבון Google, יישומי Google, אנשי הקשר של Google, לוח השנה של Google, תזכירים של Google, נתוני היישומים והיישומים שהורדת מחנות Play יאוחסנו ביישום הכונן באופן אוטומטי.
- קובצי גיבוי נשמרים עם סיומת הקובץ lbf.* בתיקייה LG Backup בכרטיס הזיכרון או באחסון הפנימי.
- טען את הסוללה במלואה לפני שתגבה או תשחזר נתונים כדי למנוע כיבוי לא מכוון באמצע התהליך.

יישומים שהוסרו לאחרונה

באפשרותך להציג ולהתקין מחדש יישומים שהוסרו ב-24 השעות האחרונות.

1 הקש על ◯ > **יישומים שהוסרו לאחרונה**. לחלופין, הקש על ◯ > הקש והחזק מקום ריק ולאחר מכן בחר **היישומים שהוסרו**.

2 הקש על 🗑 או **התקן מחדש** את היישומים הרצויים.

יישומי Google

כדי להשתמש ביישומי Google, הגדר חשבון Google. חלון הרישום של חשבון Google יופיע באופן אוטומטי כאשר תשתמש ביישום של Google בפעם הראשונה. אם אין לך חשבון Google, צור חשבון במכשיר שלך. לפרטים בנוגע לאופן השימוש ביישום, עיין בעזרה שסופקה ביישום.

- ייתכן שיישומים מסוימים לא יפעלו, בהתאם לאזור ולספק השירות.

Drive

העלה, שמור, פתח, שתף וסדר קבצים במכשיר שלך. ניתן לגשת לקבצים הנגישים מהיישומים מכל מקום, כולל סביבות מקוונות ולא מקוונות.

Docs

צור מסמכים או ערוך מסמכים שנוצרו באינטרנט או במכשיר אחר. שתף וערוך מסמכים עם אחרים.

חיפוש קולי

כדי לחפש מידע ב-Google, אמור מילת מפתח בקול במקום להקליד אותה.

מפות

חפש את המיקום שלך או את המיקום של מקום על המפה. הצג מידע גיאוגרפי.

תמונות

הצג או שתף תמונות או אלבומים השמורים במכשיר שלך.

Slides

צור חומרים למצגת או ערוך חומרים למצגת שנוצרו באינטרנט או במכשיר אחר. שתף וערוך חומרים למצגת עם אחרים.

Hangouts

החלף הודעות. בצע שיחת וידאו עם אדם או קבוצה.

Chrome

היכנס ל-Chrome ויבא כרטיסיות פתוחות, סימניות ונתוני שורת כתובת ממחשב למכשיר שלך.

Gmail

רשום את חשבון הדוא"ל של Google במכשיר שלך כדי לבדוק אם הגיע דוא"ל או כדי לשלוח דוא"ל.

Sheets

צור גיליונות אלקטרוניים או ערוך גיליונות אלקטרוניים שנוצרו באינטרנט או במכשיר אחר. שתף וערוך גיליונות אלקטרוניים עם אחרים.

וטלוויזיה סרטים Play

השתמש בחשבון Google כדי לשכור או לרכוש סרטים. קנה תוכן והפעל אותו בכל מקום.

YouTube

חפש והפעל סרטונים. העלה סרטוני וידאו ל-YouTube כדי לשתף אותם עם אנשים ברחבי העולם.

מוזיקה Play

קנה קובצי מוסיקה מ-**חנות Play**. הפעל קובצי מוסיקה שנשמרו במכשיר שלך.

04

Phone Settings
(הגדרות טלפון)

הגדרות

תוכל להתאים אישית את הגדרות המכשיר על פי העדפותיך.
הקש על ◯ > **הגדרות**.

- הקש על 🔍 והזן מילת מפתח בתיבת החיפוש כדי לגשת לפריט הגדרה.
- הקש על ⋮ כדי לשנות את מצב התצוגה. מדריך למשתמש זה מניח שאתה משתמש ב**תצוגת לשוניות**.

רשתות

Wi-Fi

תוכל להתחבר למכשירים סמוכים או באמצעות רשת Wi-Fi.

התחברות לרשת Wi-Fi

1 במסך ההגדרות, הקש על **רשתות** > **Wi-Fi**.
2 גרור את ◯ כדי להפעיל אפשרות זו.
- רשתות ה-Wi-Fi הזמינות יופיעו באופן אוטומטי.

3 בחר רשת.
- ייתכן שתצטרך להזין את סיסמת ה-Wi-Fi של הרשת.
- המכשיר מדלג על תהליך זה עבור רשתות Wi-Fi שבוצעה אליהם גישה בעבר. אם אינך רוצה להתחבר באופן אוטומטי לרשת Wi-Fi מסוימת, הקש הקשה ארוכה על הרשת ולאחר מכן הקש על **שכח רשת**.

הגדרות רשת Wi-Fi

במסך ההגדרות, הקש על **רשתות** > **Wi-Fi**.

- **עבור לנתונים ניידים**: אם תופעל פונקציית הנתונים הניידים אך המכשיר לא יצליח להתחבר לאינטרנט באמצעות Wi-Fi, המכשיר יתחבר לאינטרנט באופן אוטומטי באמצעות פונקציית הנתונים הניידים.
- ⋮ : התאם אישית את ההגדרות של רשת Wi-Fi

Wi-Fi Direct

תוכל לחבר את ההתקן שלך להתקנים אחרים שתומכים ב-Wi-Fi Direct כדי לשתף נתונים ישירות איתם. אינך צריך נקודת גישה. תוכל להתחבר עם יותר משני מכשירים באמצעות Wi-Fi Direct.

1 במסך ההגדרות, הקש על **רשתות** > **Wi-Fi** > ⋮ > **Wi-Fi מתקדם** > **Wi-Fi Direct**.
   - מכשירים סמוכים שתומכים ב- Wi-Fi Direct יופיעו באופן אוטומטי.
2 בחר התקן.
   - החיבור מתרחש כאשר המכשיר מקבל את בקשת החיבור.

- בעת שימוש ב-Wi-Fi Direct, הסוללה עשויה להתרוקן מהר יותר.

Bluetooth

תוכל לחבר את המכשיר שלך למכשירים סמוכים שתומכים ב-Bluetooth כדי להחליף איתם נתונים. חבר את המכשיר לאוזניית Bluetooth ולמקלדת. בדרך זו תוכל לשלוט בקלות רבה יותר במכשיר.

שיוך עם מכשיר אחר

1 במסך ההגדרות, הקש על **רשתות** > **Bluetooth**.

2 גרור את כדי להפעיל אפשרות זו.

- המכשירים הזמינים מופיעים באופן אוטומטי.
- כדי לרענן את רשימת המכשירים, הקש על **חיפוש**.

- רק מכשירים שבהם אפשרות החיפוש מופעלת מוצגים ברשימה.

3 בחר מכשיר מהרשימה.

4 פעל לפי ההוראות שעל המסך כדי לבצע את האימות.

- המערכת מדלגת על שלב זה עבור מכשירים שבוצעה אליהם גישה בעבר.

שליחת נתונים דרך חיבור Bluetooth

1 בחר קובץ.

- תוכל לשלוח קובצי מולטימדיה או אנשי קשר.

2 הקש על > **Bluetooth**.

3 בחר מכשיר יעד עבור הקובץ.

- הקובץ יישלח ברגע שמכשיר היעד יקבל אותו.

- תהליכי שיתוף הקבצים עשויים להשתנות, בהתאם לקובץ.

נתונים ניידים

תוכל להפעיל או לקבל נתונים לניד. תוכל גם לנהל את השימוש בנתונים לנייד.

הפעלת נתונים לנייד

1 במסך ההגדרות, הקש על **רשתות** > **נתונים ניידים**.

2 גרור את כדי להפעיל אפשרות זו.

התאמה אישית של הגדרות הנתונים לנייד

1 במסך ההגדרות, הקש על **רשתות** > **נתונים ניידים**.

2 התאם אישית את ההגדרות הבאות:

- **נתונים ניידים**: הגדר שימוש ברשתות סלולריות לצורך חיבורי נתונים.
- **הגבל שימוש בנתונים ניידים**: הגדר מגבלה לשימוש בנתונים לנייד כדי לחסום נתונים לנייד אם הגעת למגבלה.
- ⋮ : התאם אישית את ההגדרות הנתונים לנייד.

הגדרות שיחה

תוכל להתאים אישית את הגדרות השיחה, כגון אפשרויות שיחה קולית ושיחה בינלאומית.

- ייתכן שחלק מהפונקציות אינן נתמכות, בהתאם לאזור ולספק השירות.

1 במסך ההגדרות, הקש על **רשתות** > **הגדרות שיחה**.

2 התאם אישית את ההגדרות.

- **תא קולי**: שנה את מספר ההודעות בתא הקולי ואת הגדרות ההתראות.
- **סירוב ודחיית שיחות** > **דחה שיחה ושלח הודעה**: הגדר הודעת טקסט שתישלח בעת דחיית שיחה. נהל הודעות לדחיית שיחה.

- **סירוב ודחיית שיחות** > **דחה שיחות :מ**: חסום שיחות נכנסות ממספרים מסוימים או נהל מספרים חסומים.
- **סירוב ודחיית ודחה שיחות** > **מספר פרטי**: חסום שיחות נכנסות ממספרים בלתי מזוהים.
- **מענה וסיום שיחות** > **סיים שיחות באמצעות מקש ההפעלה**: לחץ על מקש הפעלה/נעילה כדי לסיים שיחות.
- **מענה וסיום שיחות** > **מענה אוטומטי**: הגדר כדי לענות לשיחה באופן אוטומטי לאחר פרק זמן מסוים בעת חיבור למכשיר עם דיבורית.
- **עוד** > **חלונית שיחה נכנסת**: הגדר הצגה של חלונית כשנכנסת שיחה בזמן שאתה משתמש ביישום.
- **עוד** > **רטט חיבור**: הגדר את המכשיר כך שירטוט כשהצד השני עונה לשיחה.
- **עוד** > **מחוות**: השתמש במחווה כדי לדחות שיחות. השתק את הרינגטון המושמע כשנכנסת שיחה.
- **עוד** > **מספרים קבועים מראש**: הגבל את השיחות היוצאות למספרים עם הקידומות שתציין בלבד.
- **עוד** > **שמור מספרים לא מוכרים**: הוסף מספר טלפון חדש לאנשי הקשר ושמור אותו לאחר שיחה.
- **עוד** > **העברת שיחה**: הגדר מתי תתבצע העברת שיחות.
- **עוד** > **חסימת שיחה**: הגבל שיחות נכנסות, שיחות יוצאות או שיחות בינלאומיות.
- **עוד** > **משך שיחה**: הצג פרטים על משך השיחה.
- **עוד** > **הגדרות נוספות**: בצע התאמה אישית של הגדרות שיחה נוספות.

שיתוף קבצים

תוכל לשלוח ולקבל קבצים בין המכשיר שלך למכשירים או טאבלטים אחרים של LG.

• לפרטים, ראה *שליחה או קבלה של קבצים*.

1 במסך ההגדרות, הקש על **רשתות** > **שתף והתחבר** > **שיתוף קבצים**.

2 התאם אישית את ההגדרות הבאות:

- **LG Stylus2**: שנה את שם המכשיר.
- **שמור ב**: הגדר את תיקיית היעד לשמירת קבצים שנשלחו ממכשירים אחרים.
- **שיתוף קבצים**: אפשר קבלה של קבצים שנשלחו ממכשירים אחרים.
- **SmartShare Beam**: שתף קבצים עם מכשירים אחרים דרך SmartShare Beam.

שרת מדיה

תוכל לשתף תוכן מדיה במכשיר שלך עם מכשירים סמוכים שתומכים ב-DLNA.

1 במסך ההגדרות, הקש על **רשתות** > **שתף והתחבר** > **שרת מדיה**.

2 התאם אישית את ההגדרות הבאות:

- **שיתוף תוכן**: שתף תוכן במכשיר עם מכשירים סמוכים.
- **LG Stylus2**: הגדר את שם המכשיר שלך.
- **תוכן לשיתוף**: בחר את סוג תוכן המדיה כדי לשתף עם מכשירים אחרים.
- **מכשירים מורשים**: הצג רשימה של מכשירים שמורשים לגשת לתוכן במכשיר.
- **התקנים לא מורשים** : הצג רשימה של מכשירים שאינם מורשים לגשת לתוכן במכשיר.

LG AirDrive

תוכל להשתמש בחשבון LG ממחשב כדי לנהל קבצים שנשמרו במכשיר. אינך צריך חיבור USB.

1 במסך ההגדרות, הקש על **רשתות** > **שתף והתחבר** > **LG AirDrive**.

2 השתמש בחשבון LG יחיד כדי להיכנס ל-LG Bridge במחשב ול-**LG AirDrive** במכשיר.

- ניתן להוריד את תוכנת LG Bridge מאתר *www.lg-mobile.co.il*.

3 נהל קבצים במכשיר מהמחשב.

הדפסה

ניתן להדפיס את התוכן של מסכים מסוימים (כגון דפי אינטרנט המוצגים ב-Chrome) במדפסת המחוברת לאותה רשת Wi-Fi שאליה מחובר מכשיר Android שלך.

שיתוף באמצעות USB

תוכל לחבר את המכשיר למכשיר אחר דרך USB ולשתף נתונים לנייד.

1 חבר את המכשיר והמכשירים האחרים באמצעות כבל USB.

2 במסך ההגדרות, הקש על **רשתות** > **שיתוף אינטרנט** > **שיתוף באמצעות USB** ולאחר מכן החלק על כדי להפעיל אפשרות זו.

- אפשרות זו משתמשת בנתונים לנייד, ועשויה להיות כרוכה בתשלום, בהתאם לתוכנית המחירים שלך. לקבלת מידע נוסף, פנה לספק השירות שלך.
- כאשר תתחבר למחשב, הורד את מנהל התקן ה-USB מהכתובת *www.lg-mobile.co.il* למחשב.
- לא ניתן להעביר קבצים בין המכשיר למחשב כאשר חיבור לאינטרנט באמצעות USB מופעל. כבה את החיבור לאינטרנט באמצעות USB כדי לשתף קבצים.
- מערכות הפעלה שתומכות בחיבור לאינטרנט הן Window XP ואילך, או Linux.

נקודה חמה ניידת ב- Wi-Fi

תוכל להגדיר את המכשיר כנתב אלחוטי כך שהמכשירים האחרים יוכלו להתחבר לאינטרנט באמצעות חיבור הנתונים לנייד של המכשיר.

1 במסך ההגדרות, הקש על **רשתות** > **שיתוף אינטרנט** > **נקודה חמה ניידת ב- Wi-Fi** ולאחר מכן החלק על כדי להפעיל אפשרות זו.

2 הקש על **הגדרת נקודה חמה של Wi-Fi** והזן מזהה Wi-Fi (SSID) וסיסמה.

3 הפעל את Wi-Fi במכשיר השני ובחר את השם של רשת המכשיר ברשימת ה-Wi-Fi.

4 הזן את סיסמת הרשת.

- אפשרות זו משתמשת בנתונים לנייד, ועשויה להיות כרוכה בתשלום, בהתאם לתוכנית המחירים שלך. לקבלת מידע נוסף, פנה לספק השירות שלך.
- לרשותך מידע נוסף באתר אינטרנט זה: *http://www.android.com/tether#wifi*

שיתוף אינטרנט ב-Bluetooth

ניתן לחבר מכשיר עם חיבור Bluetooth לאינטרנט דרך חיבור הנתונים לנייד במכשיר שלך.

1 במסך ההגדרות, הקש על **רשתות** > **שיתוף אינטרנט** > **שיתוף אינטרנט ב-Bluetooth** ולאחר מכן החלק על כדי להפעיל אפשרות זו.

2 הפעל את Bluetooth בשני המכשירים ושייך אותם.

- אפשרות זו משתמשת בנתונים לנייד, ועשויה להיות כרוכה בתשלום, בהתאם לתוכנית המחירים שלך. לקבלת מידע נוסף, פנה לספק השירות שלך.
- מידע נוסף זמין באתר אינטרנט זה: *http://www.android.com/tether#Bluetooth_tethering*

מצב טיסה

תוכל לכבות את פונקציות השיחה והנתונים לנייד. כאשר מצב זה מופעל, פונקציות שאינן כוללות נתונים, כמו הפעלת משחקים ומוסיקה, הופכות ללא זמינות.

1 במסך ההגדרות, הקש על **רשתות** > **עוד** > **מצב טיסה**.

2 הקש על **הפעל** במסך האישור.

רשתות ניידות

תוכל להתאים אישית את הגדרות הנתונים לנייד.

1 במסך ההגדרות, הקש על **רשתות** > **עוד** > **רשתות ניידות**.

2 התאם אישית את ההגדרות הבאות:

- **נתונים ניידים**: הפעל או כבה נתונים לנייד.
- **נדידת נתונים**: גלוש באינטרנט, השתמש בדוא"ל, בהודעות מולטימדיה ובשירותים אחרים בחו"ל.
- **סוג רשת**: בחרו סוג רשת.
- **שמות נקודות גישה**: הצג או שנה את נקודת הגישה לשימוש בשירותי נתונים לנייד. כדי לשנות את נקודת הגישה, בחר אפשרות מתוך רשימת נקודות הגישה.
- **מפעילי רשת סלולרית**: חפש מפעילי רשת סלולרית והתחבר באופן אוטומטי לרשת.

VPN

תוכל להתחבר לרשת וירטואלית בטוחה, כמו IntraNet. תוכל גם לנהל רשתות פרטיות וירטואליות מחוברות.

הוספת VPN

1 במסך ההגדרות, הקש על **רשתות** > **עוד** > **VPN**.

- אם המסך לא נעול, מופיע מסך התראות. הקש על **הגדרות** במסך ההתראות ונעל את המסך. לפרטים, ראה *קבע הגדרות נעילת מסך*.

2 הקש על **הוסף רשת VPN**.

3 הזן פרטי VPN והקש על **שמור**.

קביעת ההגדרות של VPN

1 הקש על VPN ברשימה **VPNS**.

2 הזן את פרטי חשבון המשתמש של VPN והקש על **התחבר**.

- כדי לשמור את פרטי החשבון, סמן את התיבה **שמור פרטי חשבון**.

צליל והתראה

תוכל להתאים אישית את הגדרות הקול, הרטט וההתראות.

במסך ההגדרות, הקש על **צליל והתראה** והתאם אישית את ההגדרות הבאות:

- **פרופילי צליל**: במצבי צליל, עבור בין צליל, מצב שקט ומצב רטט בלבד.
- **עוצמה**: התאם את עוצמת הצליל של פריטים שונים.
- **צלצול**: בחר רינגטון לשיחות נכנסות. הוסף או מחק רינגטונים.
- **צלצול מותאם**: צור רינגטון לשיחה נכנסת מאיש קשר מסוים. לפרטים, ראה *צלצול מותאם*.
- **צליל עם רטט**: קבע כי המכשיר יפעיל רטט וישמיע רינגטון בו-זמנית.
- **סוג רטט**: תוכל לבחור סוג רטט או ליצור תבנית רטט משלך.
- **נא לא להפריע**: הגדר את השעה, הטווח וסוג היישום לקבלת הודעות של התראות. קבל הודעות של התראות בימים מסוימים בשבוע בלבד. לפרטים, ראה *נא לא להפריע*.
- **מסך נעילה**: הצג או הסתר הודעת התראה במסך הנעילה. תוכל גם להסתיר מידע פרטי.
- **יישומים**: בחר את היישומים שיורשו להציג התראות במסך וקבע סדר עדיפות ביניהם בהקשר עם התראות והודעות.

- **נורית הודעה**: ציין את סטטוס המכשיר באמצעות נוריות LED.
- **עוד** > **צליל התראה**: בחר רינגטון להתראה. הגדר מוסיקה שנשמרה במכשיר כרינגטון להתראה.
- **עוד** > **רטט בעת הקשה**: קבע שהמכשיר יפעיל רטט כאשר תקיש על פריטים מסוימים על המסך.
- **עוד** > **אפקטים קוליים**: בחר אפקט קול שישמע כאשר תקיש על מקש חיוג, כאשר תבחר אפשרות או כאשר תנעל או תבטל נעילה של המסך.
- **עוד** > **התראות קוליות על הודעות/שיחות**: הגדר את המכשיר כך שיקריא בקול את פרטי המתקשר או ההודעה.

תצוגה

תוכל להתאים אישית הגדרות מפורטות לכל סוג מסך.

במסך ההגדרות, הקש על **תצוגה** והתאם אישית את ההגדרות הבאות:

- **מסך ראשי**: התאם אישית את הגדרות המסך הראשי. לפרטים, ראה *מסך ראשי*.
- **מסך נעילה**: התאם אישית את הגדרות מסך הנעילה. לפרטים, ראה *נעילת מסך*.
- **לחצני תצוגה**: סדר מחדש את לחצני המגע של המסך הראשי או שנה את צבעי הרקע שלהם. הסתר את לחצני המגע של המסך הראשי על המסך.
- **סוג גופן**: שנה את סוג הגופן.
- **גודל גופן**: שנה את גודל הגופן.
- **טקסט מודגש**: הדגש את הטקסט על במסך.
- **בהירות**: השתמש במחוון כדי לשנות את בהירת המסך של המכשיר.
- **אוטומטי**: הגדר את המכשיר כך שבהירות המסך תותאם באופן אוטומטי לעוצמת התאורה בסביבה.
- **Reader mode**: הפחת את כמות התאורה הכחולה במסך כדי להפחית מאמץ בעיניים.

- **סיבוב מסך אוטומטי**: סובב באופן אוטומטי את המסך בהתאם לכיוון המכשיר.
- **כיבוי מסך אוטומטי**: כבה באופן אוטומטי את המסך כאשר המכשיר לא היה פעיל במשך פרק זמן שצוין.
- **עוד** > **חלום בהקיץ**: הצג שומר מסך כאשר המכשיר מחובר למחזיק או נטען. בחר את סוג שומר המסך שיוצג.
- **עוד** > **כיול חיישן תנועה**: תקן את הזווית והמהירות של חיישן התנועה כדי לשפר את דיוק ההטיה ואת המהירות של החיישן.

- כאשר תתקן את חיישן התנועה, הקפד להניח את המכשיר על משטח שטוח. אם לא תעשה זאת, יופיעו שגיאות הקשורות לחיישן התנועה, כמו סיבוב מסך אוטומטי.

כללי

שפה ומקלדת

תוכל להתאים אישית את הגדרות השפה והמקלדת עבור המכשיר שלך.

1 במסך ההגדרות, הקש על **כללי** > **שפה ומקלדת**.

2 התאם אישית את ההגדרות הבאות:

- **שפה**: בחר שפה והחל אותה על המכשיר.
- **מקלדת נוכחית**: הצג את סוג המקלדת שנמצאת כעת בשימוש. בחר מקלדת לשימוש בעת הזנת טקסט.
- **מקלדת LG**: התאם אישית את הגדרות המקלדת של LG.
- **הקלדת קולית של Google**: בחר אפשרויות להכתבת טקסט מאת Google.
- **פלט המרת טקסט לדיבור**: בחר את ההגדרות לפלט טקסט-לדיבור.
- **מהירות מצביע**: כוונן את מהירות המצביע של העכבר או של לוח העקיבה.

- **המרת לחצנים**: הגדר ביצוע פעולות ראשיות בתפעול ישיר דרך הלחצן הימני של העכבר.

מיקום

תוכל להתאים אישית את ההגדרות כדי לגשת לפרטי המיקום שלך מיישום מסוים.

1 במסך ההגדרות, הקש על **כללי** > **מיקום**.

2 התאם אישית את ההגדרות הבאות:

- **מצב**: בחר שיטה לאספקת פרטי המיקום שלך.
- **בקשת מיקום האחרונה**: הצג יישומים שביקשו לאחרונה פרטי מיקום.
- **מצלמה**: שמור את פרטי המיקום בעת צילום תמונות או סרטוני וידאו.
- **היסטוריית מיקומים ב-Google**: קבע הגדרות היסטוריית מיקום של Google.

חשבונות וסנכרון

תוכל להוסיף או לנהל חשבונות, כולל חשבון Google. תוכל גם לסנכרן יישומים או פרטי משתמש מסוימים באופן אוטומטי.

1 במסך ההגדרות, הקש על **כללי** > **חשבונות וסנכרון**.

2 התאם אישית את ההגדרות הבאות:

- **לסנכרן נתונים באופן אוטומטי**: סנכרן את כל החשבונות הרשומים באופן אוטומטי.
- **חשבונות**: הצג רשימה של החשבונות הרשומים. כדי להציג או לשנות פרטים של חשבון, הקש על החשבון.
- **הוסף חשבון**: הוסף חשבונות.

נגישות

תוכל לנהל יישומי Plug-in של נגישות המותקנים במכשיר שלך.

1 במסך ההגדרות, הקש על **כללי** > **נגישות**.

2 התאם אישית את ההגדרות הבאות:

- **ראייה** > **TalkBack**: הגדר את המכשיר כך שיודיע על סטטוס המסך או על פעולות באמצעות קול.
- **ראייה** > **התראות קוליות על הודעות/שיחות**: הגדר שהמכשיר יקריא את תוכן השיחות או ההודעות באופן קולי.
- **ראייה** > **גודל גופן**: שנה את גודל הגופן.
- **ראייה** > **טקסט מודגש**: הדגש את הטקסט על במסך.
- **ראייה** > **שינוי גודל תצוגה במגע**: הגדל או הקטן את התצוגה על-ידי הקשה על המסך שלוש פעמים.
- **ראייה** > **היפוך צבעי המסך**: הגבר את ניגודיות הצבע בתצוגה לטובת אנשים עם לקות ראייה.
- **ראייה** > **התאמה אישית של צבעי המסך**: כוונן את צבע התצוגה.
- **ראייה** > **גווני אפור**: העבר את המסך למצב גווני אפור.
- **ראייה** > **סיים שיחות באמצעות מקש ההפעלה**: סיים שיחה על-ידי לחיצה על מקש הפעלה/נעילה.
- **שמיעה** > **כתובית**: הפעל את שירות הכתוביות בעת הקרנת סרטוני וידאו לאנשים כבדי שמיעה.
- **שמיעה** > **נורית הודעה**: ציין את סטטוס המכשיר באמצעות נוריות LED.
- **שמיעה** > **התראות פלש**: הגדר את המכשיר כך שיודיע על שיחות נכנסות ועל התראות באמצעות נורית מהבהבת.
- **שמיעה** > **כבה את כל הצלילים**: השתק את כל הצלילים והנמך את עוצמת הקול במקלט.
- **שמיעה** > **סוג אודיו**: בחר את סוג השמע.
- **שמיעה** > **איזון קול**: כוונן את איזון פלט השמע. השתמש במחוון כדי לשנות את האיזון.
- **תנועה ותודעה** > **Touch assistant**: הפעל את לוח המגע

כדי להקל את השימוש בלחצנים ובמחוות.

- **תנועה ותודעה** > **הקישו והחזיקו - השהיה**: כוונן את הזמן המוקצה לקלט מגע.
- **תנועה ותודעה** > **לחץ לחיצה ממושכת לקבלת שיחות**: השב לשיחות או דחה שיחות על-ידי הקשת הקשה ממושכת על לחצן השיחה במקום לגרור אותו.
- **תנועה ותודעה** > **כיבוי מסך אוטומטי**: כבה באופן אוטומטי את המסך כאשר המכשיר לא היה פעיל במשך פרק זמן שצוין.
- **תנועה ותודעה** > **אזורי בקרת מגע**: הגבל את אזור המגע כך שניתן יהיה לשלוט חלק מסוים של המסך בלבד באמצעות קלט המגע.
- **קיצור דרך לתכונות הנגישות**: קבל במהירות גישה לפונקציות בשימוש נפוץ על-ידי הקשה על ◯ שלוש פעמים.
- **סיבוב מסך אוטומטי**: שנה באופן אוטומטי את כיוון המסך בהתאם למצב הפיזי של המכשיר.
- **שינוי אופן גישה**: צור צירופי מקשים שיסייעו לך לשלוט במכשיר שלך.

תצוגה ממוזערת

הפעל תפריט זה כדי לכווץ את המסך לשימוש ביד אחת על-ידי החלקה שמאלה או ימינה על פני לחצני המגע של המסך הראשי. ראה *תצוגה ממוזערת* לקבלת פרטים.

במסך ההגדרות, הקש על **כללי** > **תצוגה ממוזערת**.

מקש קיצור דרך

תוכל להשתמש במקשי עוצמת הקול כדי להפעיל ישירות יישומים כאשר המסך כבוי או נעול.

1 במסך ההגדרות, הקש על **כללי** > **מקש קיצור דרך**.

2 גרור את ◯ כדי להפעיל אפשרות זו.

- לחץ פעמיים על מקש החלשת עוצמת הקול (-) כדי להפעיל את היישום **מצלמה** כאשר המסך נעול או כבוי. לחץ פעמיים על מקש הגברת עוצמת הקול (+) כדי להפעיל את **Capture+**.

שירותי Google

תוכל להשתמש בהגדרות Google לניהול יישומי Google שברשותך והגדרות החשבון שלך.

במסך ההגדרות, הקש על **כללי** > **שירותי Google**.

אבטחה

1 במסך ההגדרות, הקש על **כללי** > **אבטחה**.

2 התאם אישית את ההגדרות הבאות:

- **נעילת תוכן**: הגדר את השיטה לנעילת קבצים ב **QuickMemo+**.
- **הצפן טלפון**: הגדר את סיסמת המכשיר לפרטיות. צור קוד PIN או סיסמה שתוזן בכל פעם שהמכשיר מופעל. לפרטים, ראה *הצפנת המכשיר שלך*.
- **הצפן אחסון כרטיס SD**: הצפן את כרטיס הזיכרון כדי למנוע שימוש במכשיר אחר. לפרטים, ראה *הצפנת כרטיס זיכרון*.
- **הגדר נעילת כרטיס SIM**: נעל או בטל נעילה של כרטיס ה-USIM, או שנה את הסיסמה (PIN).
- **הקלדת סיסמה גלויה**: הצג סיסמה בזמן שאתה מזין אותה.
- **מנהלי התקנים**: אפשר הרשאות להגבלת השליטה או השימוש במכשיר עבור יישומים מסוימים.
- **מקורות לא מוכרים**: אפשר התקנה של יישומים מיישומים שאינם מחנות Play.
- **אמת יישומים**: חסום את ההתקנה של יישומים מזיקים. הצג הודעת אזהרה כאשר יישום מזיק מותקן.
- **סוג אחסון**: הצג את סוג האחסון שבו אישור האבטחה יישמר.
- **תעודת ניהול**: נהל את אישור האבטחה השמור בהתקן.
- **Trust agents**: הצג והשתמש בסוכנים אמינים המותקנים במחשב.
- **קביעת מסך**: תקן את מסך היישום כדי לאפשר שימוש ביישום הפעיל כעת בלבד.
- **גישה לשימוש עבור היישומים**: הצג פרטים על השימוש ביישומים במכשיר.

Quick Cover View

בעזרת כיסוי Quick Cover אתה יכול לבדוק שיחות נכנסות ולעצור את השעון המעורר/הטיימר כשהכיסוי סגור. כדי לבטל נעילה עם הכיסוי, נעילת המסך חייבת להיות מוגדרת כ'החלק'.

במסך ההגדרות, הקש על **כללי** > **Quick Cover View**.

עט

השתמש בהגדרות העט כדי להגדיר אפשרויות כשהעט נשלף. ראה *Pen Pop* לקבלת פרטים.

במסך ההגדרות, הקש על **כללי** > **עט**.

- **פתח לאחר ההסרה**: בחר תכונה שתופעל באופן אוטומטי כשהעט נשלף מהמכשיר.
- **קיצורי דרך של יישומים**: הגדר יישומים שאתה משתמש בהם לעתים קרובות.
- **Screen-off Memo**: צור הערות במסך הכבוי כשהעט נשלף.
- **זיהוי העט**: קבל התראה באמצעות צליל או רטט כשהעט נשלף או מוכנס.
- **Pen Keeper**: קבל התראה באמצעות צליל או התראה חזותית כשהמכשיר זז בזמן שהעט אינו נמצא בתוכו.

חלון כפול

מאפשר לך להגדיר את התכונה 'חלון כפול'. ראה *חלון כפול* לקבלת פרטים.

במסך ההגדרות, הקש על **כללי** > **חלון כפול**.

- **פתיחה אוטומטית**: סמן אפשרות זו כדי שתוכל להקיש על קישור במסך המלא או בקבצים מצורפים להודעות דוא"ל כדי לפתוח 'חלון כפול'.
- **עזרה**: הצג טיפים לשימוש ב'חלון כפול'.

תאריך ושעה

תוכל להתאים אישית את הגדרות התאריך והשעה עבור המכשיר שלך.

1 במסך ההגדרות, הקש על **כללי** > **תאריך ושעה**.

2 התאם אישית את ההגדרות.

אחסון ו-USB

תוכל להציג ולנהל את האחסון הפנימי במכשיר או בשטח האחסון של כרטיס הזיכרון.

1 במסך ההגדרות, הקש על **כללי** > **אחסון ו-USB**.

2 התאם אישית את ההגדרות הבאות:

- **אחסון פנימי**: הצג את שטח האחסון הכולל ופנה שטח באחסון הפנימי של המכשיר. הצג רשימה של יישומים שנמצאים בשימוש ואת קיבולת האחסון עבור כל יישום.
- **אחסון נייד**: הצג את שטח האחסון הכולל ואת השטח הפנוי בכרטיס הזיכרון. אפשרות זו מופיעה רק כאשר הוכנס כרטיס זיכרון. כדי לבטל טעינה של כרטיס זיכרון, הקש על ⏏.

חיסכון בחשמל ובסוללה

תוכל להציג את פרטי הסוללה הנוכחית או להפעיל מצב חיסכון בחשמל.

1 במסך ההגדרות, הקש על **כללי** > **חיסכון בחשמל ובסוללה**.

2 התאם אישית את ההגדרות הבאות:

- **ניצול סוללה**: הצג את \בפרטי השימוש בסוללה. כדי להציג פרטים נוספים, בחר פריט ספציפי.
- **אחוז הסוללה בשורת המצב**: הצג את רמת טעינת הסוללה שנותרה כאחוז בשורת המצב.

- **חיסכון בחשמל**: הקטן את צריכת הסוללה על-ידי ביטול הגדרות מכשיר מסוימות, כמו בהירות התצוגה, המהירות ועוצמת הרטט. בשורת המצב מופיע כאשר מצב חיסכון בחשמל מופעל.

זיכרון

תוכל להציג את הסכום הממוצע של השימוש בזיכרון לאורך פרק זמן מסוים ואת הזיכרון שהיה בשימוש על-ידי היישום.

1 במסך ההגדרות, הקש על **כללי** > **זיכרון**.

2 הקש על כדי להגדיר משבצת זמן לאחזור נתונים.

יישומים

תוכל להציג רשימה של יישומים מותקנים. כבה או מחק יישומים, בעת הצורך.

1 במסך ההגדרות, הקש על **כללי** > **יישומים**.

2 בחר יישום ובצע פעולות.

גיבוי ואיפוס

תוכל לגבות נתונים השמורים במכשיר שלך במכשיר או בטאבלט אחר של LG. אפס את המכשיר, בעת הצורך.

1 במסך ההגדרות, הקש על **כללי** > **גיבוי ואיפוס**.

2 התאם אישית את ההגדרות הבאות:

- **LG Backup**: גבה ושחזר את כל הנתונים השמורים במכשיר. לפרטים, ראה *LG Backup*.
- **גבה את הנתונים שלי**: גבה את נתונים היישום שלך, את סיסמאות Wi-Fi והגדרות אחרות לשרת Google.
- **חשבון גיבוי**: הצג את חשבון הגיבוי הנוכחי שנמצא בשימוש.
- **שחזור אוטומטי**: שחזר באופן אוטומטי הגדרות גיבוי ונתונים בעת התקנה מחדש של יישום.
- **איפוס הגדרות רשת**: אפס את Wi-Fi, Bluetooth והגדרות רשת אחרות.

- **שחזור נתוני היצרן**: אפס את כל ההגדרות עבור המכשיר ומחק נתונים.

- פעולת איפוס המכשיר מוחקת את כל הנתונים השמורים בו. הזן את שם המכשיר, את חשבון Google ופרטים התחלתיים אחרים פעם נוספת.

אודות הטלפון

תוכל להציג מידע אודות המכשיר, כמו שם, הסטטוס, פרטי התוכנה ומידע משפטי.

במסך ההגדרות, הקש על **כללי** > **אודות הטלפון** והצג מידע.

05

נספח

עדכון תוכנת הטלפון

עדכון תוכנת הטלפון הנייד של LG מהאינטרנט

למידע נוסף אודות השימוש בפונקציה זו, בקר בכתובת *http://www.lg.com/common/index.jsp* בחר את המדינה והשפה שלך.

תכונה זו מאפשרת לך לעדכן בנוחות את הקושחה של הטלפון לגרסה חדשה יותר מהאינטרנט, ללא צורך לבקר במרכז שירות. תכונה זו תהיה זמינה רק אם LG תייצר גרסת קושחה חדשה שתהיה זמינה למכשיר שלך.

מאחר שעדכון הקושחה של הטלפון הנייד דורש את תשומת לבו המלאה של המשתמש במשך כל תהליך העדכון, הקפד לקרוא את כל ההוראות וההערות שיופיעו בכל שלב לפני שתתקדם הלאה. חשוב לזכור שניתוק כבל ה-USB במהלך השדרוג עלול לגרום נזק חמור לטלפון הנייד.

- LG שומרת על זכותה, על פי שיקול דעתה הבלעדי, להפוך עדכוני קושחה לזמינים עבור דגמים נבחרים בלבד ואינה ערבה לזמינות הגירסה החדשה של הקושחה לכל דגמי הטלפון.

עדכון תוכנת הטלפון הנייד של LG באופן אלחוטי (OTA)

תכונה זו מאפשרת לך לעדכן בנוחות את תוכנת הטלפון לגרסה חדשה יותר בשיטת OTA, מבלי לחבר כבל USB. תכונה זו תהיה זמינה רק אם LG תייצר גרסת קושחה חדשה שתהיה זמינה למכשיר שלך.

תחילה בדוק את גרסת התוכנה בטלפון הנייד:

הגדרות > **כללי** > **אודות הטלפון** > **מרכז עדכונים** > **עדכון תוכנה** > **חפש עדכונים כעת**.

- הנתונים האישיים שלך משטח האחסון הפנימי בטלפון—לרבות פרטי חשבון Google וכל חשבון אחר, נתונים והגדרות של המערכת/היישומים שלך, יישומים שהורדו ורישיון ה-DRM שלך—עשויים ללכת לאיבוד בתהליך עדכון התוכנה של הטלפון. לפיכך, LG ממליצה לך לגבות את הנתונים האישיים שלך לפני שתעדכן את תוכנת הטלפון. LG לא תישא באחריות לאובדן נתונים אישיים כלשהם.
- הזמינות של תכונה זו תלויה באזור ובספק השירות.

שאלות נפוצות

בפרק זה מוצגות מספר בעיות שאתה עלול להיתקל בהן במהלך השימוש בטלפון. בעיות מסוימות יצריכו פנייה לספק השירות, אך את רובן תוכל לפתור בקלות בעצמך.

הודעה	סיבות אפשריות	אפשרויות לתיקון הבעיה
שגיאת כרטיס SIM	אין כרטיס SIM בטלפון או שהוא הוכנס בצורה לא נכונה.	ודאו שכרטיס ה-SIM הוכנס כראוי.
אין חיבור לרשת/ החיבור חלש	האות חלש או שאתה נמצא מחוץ לטווח הרשת של ספק השירות.	התקרב לחלון או צא לאזור פתוח. בדוק את מפת הכיסוי של מפעיל הרשת הסלולרית.
	המפעיל החיל שירותים חדשים.	בדוק אם גילו של כרטיס ה-SIM עולה על 12~6 חודשים. אם כן, החלף את כרטיס ה-SIM או ה-USIM בחנות הקרובה ביותר של ספק הרשת. פנה אל ספק השירות.
הקודים אינם תואמים	כדי לשנות קוד אבטחה, הזן שוב את הקוד החדש כדי לאשרו.	אם שכחת את הקוד, פנה אל ספק השירות.
	שני הקודים שהזנו אינם תואמים	
לא ניתן להגדיר יישומים	הם לא נתמכים על-ידי ספק השירות או שנדרש רישום עבורם.	פנה אל ספק השירות.
יישום שהורדתי קורים לשגיאות רבות.	הסר את היישום.	1. הקש על ◯ > **הגדרות**. 2. הקש על **כללי** > **יישומים**. 3. הקש על היישום > **הסר התקנה**.

הודעה	סיבות אפשריות	אפשרויות לתיקון הבעיה
לא ניתן לבצע שיחות	טעות בחיוג	רשת חדשה לא מאושרת.
	הוכנס כרטיס SIM חדש.	בדוק אם קיימות מגבלות חדשות.
	הגעת למגבלת החיוב ששולם מראש.	צור קשר עם חברת הסלולר או אפס את המגבלה בעזרת PIN2.
לא ניתן להפעיל את הטלפון	מקש הדלקה/כיבוי נלחץ מהר מדי.	לחץ על מקש ההפעלה/כיבוי למשך שתי שניות לפחות.
	הסוללה לא נטענה.	טען את הסוללה. בדוק את מחוון הטעינה בתצוגה.
שגיאת טעינה	הסוללה לא נטענה.	טען את הסוללה.
	הטמפרטורה החיצונית גבוהה או נמוכה מדי.	ודא שהטלפון נטען בטמפרטורה הרגילה.
	בעיית מגעים	בדוק את המטען ואת החיבור שלו לטלפון.
	אין מתח	חברו את המטען לשקע אחר.
	המטען פגום	החלף את המטען
	מטען לא מתאים	השתמש רק באביזרים מקוריים של LG.
המספר אסור.	פונקציית מספר קבוע מראש פועלת.	בדוק את התפריט 'הגדרות' ונטרל את הפונקציה.
לא ניתן לקבל/לשלוח הודעות SMS ותמונות	הזיכרון מלא	בחר נתונים מסוימים, כמו יישומים או הודעות מהטלפון שלך, כדי לפנות זיכרון.

הודעה	סיבות אפשריות	אפשרויות לתיקון הבעיה
הקבצים אינם נפתחים	אין תמיכה בתבנית הקובץ	בדוק את תבניות הקובץ הנתמכות.
המסך אינו נדלק כאשר מתקבלת שיחה.	בעיה בחיישן הקרבה	אם אתה משתמש בנרתיק או כיסוי להגנה, ודא שהוא אינו מכסה את האזור שסביב חיישן הקרבה. ודא שהאזור שמסביב לחיישן הקרבה נקי
אין צליל	מצב רטט	בדוק את מצב ההגדרות בתפריט הצליל כדי לוודא שאינך במצב רטט או במצב 'ללא הפרעות'.
ניתוק או קפיאה	בעיה של נתק בתוכנה	אם המסך קופא או שהטלפון אינו מגיב כשמנסים להפעיל אותו, הוצא את הסוללה והכנס אותה בחזרה. לאחר מכן הפעל שוב את הטלפון. לחלופין, נסה לעדכן את התוכנה דרך אתר האינטרנט.

מדריך למניעת גניבה

הגדר את המכשיר שלך כך שאנשים אחרים לא יוכלו להשתמש בו אם הוא יאופס להגדרות היצרן ללא רשותך. לדוגמה, אם המכשיר אבד, נגנב או נמחק, רק אדם בעל חשבון Google או בעל פרטי נעילת מסך יוכל להשתמש במכשיר.

כל שעליך לעשות כדי לוודא שהמכשיר שלך מוגן הוא:

- להגדיר נעילת מסך: אם המכשיר אבד או נגנב, אך הגדרת נעילת מסך, לא תהיה אפשרות למחוק את המכשיר באמצעות תפריט 'הגדרות', כל עוד נעילת המסך לא תבוטל.
- הוסף את חשבון Google שלך למכשיר: אם המכשיר שלך נמחק אך הגדרת בו את חשבון Google שלך, לא תהיה אפשרות לסיים את תהליך ההגדרה של המכשיר עד שהפרטים של חשבון Google יוזנו שוב.

לאחר שהמכשיר יהיה מוגן, תצטרך לבטל את נעילת המסך או להזין את הסיסמה של חשבון Google אם עליך לבצע איפוס להגדרות היצרן. הדבר יבטיח שאתה או מישהו שאתה סומך עליו תבצעו את האיפוס.

- אל תשכח את חשבון Google והסיסמה שהוספת למכשיר לפני ביצוע האיפוס להגדרות היצרן. אם אינך יכול לספק את פרטי החשבון במשך תהליך ההגדרה, לא תוכל להשתמש כלל במכשיר לאחר ביצוע האיפוס להגדרות היצרן.

מידע נוסף

פרטי הודעה על תוכנת קוד פתוח

אנא בקרו באתר *http://opensource.lge.com* על מנת להשיג את קוד המקור תחת MPL, LGPL, GPL, קוד פתוח ורשיונות אחרים.

בנוסף לקוד המקור, זמינים להורדה תנאי הרשיון, אחריות, כתבי ויתור וזכויות יוצרים.

LG Electronics תספק קוד מקור על גבי התקליטור, תמורת תשלום המכסה הוצאות של ביצוע ואחסון.

לבקשה ניתן לפנות לכתובת הדואר האלקטרוני : *opensource@lge.com*.

הצעה זו תקפה למשך (3) שנים ממועד הרכישה.

סימנים מסחריים

- Copyright© 2016 LG Electronics, Inc. כל הזכויות שמורות. LG והסמל של LG הם סימנים מסחריים רשומים של LG Group ושל החברות הקשורות אליה.
- ™Google, ™Google Maps, ™Gmail, ™YouTube, ™Hangoutsו ™Play Store- הם סימנים מסחריים של Google, Inc.
- ®Bluetooth הוא סימן מסחרי רשום של Bluetooth SIG, Inc. ברחבי העולם.
- ®Wi-Fi והלוגו של Wi-Fi הם סימנים מסחריים רשומים של Wi-Fi Alliance.
- כל יתר הסימנים המסחריים וזכויות היוצרים הם רכושם של בעליהם בהתאמה.

הצהרת תאימות

בזאת, **LG Electronics** מצהירה שהמוצר **LG-K520K** תואם לדרישות היסודיות ולתנאים הרלוונטיים האחרים של הנחיה **1999/5/EC**.

ניתן למצוא עותק של הצהרת התאימות בכתובת *http://www.lg.com/global/declaration*

About this user guide

Thank you for choosing this LG product. Please carefully read this user guide before using the device for the first time to ensure safe and proper use.

- Always use genuine LG accessories. The supplied items are designed only for this device and may not be compatible with other devices.
- This device is not suitable for people who have a visual impairment due to the touchscreen keyboard.
- Descriptions are based on the device default settings.
- Default apps on the device are subject to updates, and support for these apps may be withdrawn without prior notice. If you have any questions about an app provided with the device, please contact a LG Service Centre. For user-installed apps, please contact the relevant service provider.
- Modifying the device's operating system or installing software from unofficial sources may damage the device and lead to data corruption or data loss. Such actions will violate your LG licence agreement and void your warranty.
- Some content and illustrations may differ from your device, depending on the region, service provider, software version, or OS version, and are subject to change without prior notice.
- Software, audio, wallpaper, images, and other media supplied with your device are licenced for limited use. If you extract and use these materials for commercial or other purposes, you may be infringing copyright laws. As a user, you are fully responsible for the illegal use of media.
- Additional charges may incur for data services, such as messaging, uploading,downloading, auto-syncing and location services. To void additional charges, select a data plan suitable to your needs. Contact your service provider to obtain additional details.

Instructional notices



WARNING: Situations that could cause injury to the user and third parties.



CAUTION: Situations that may cause minor injury or damage to the device.



NOTE: Notices or additional information.

Table of contents

5 Guidelines for safe and efficient use

01

Custom-designed Features

13 Quick Share
14 Mini view
15 Dual window
16 QuickMemo+
18 QSlide
19 Pen Pop
20 Content sharing
22 Do not disturb
22 Ringtone ID

02

Basic Functions

24 Product components and accessories
25 Parts overview
27 Turning on or off the power
28 Installing the SIM card and battery
31 Charging the battery
32 Optimizing battery life
33 Inserting the memory card
34 Touch screen
37 Home screen
43 Screen lock
48 Device encryption
49 SD card encryption
50 Taking screenshots
51 Entering text

03

Useful Apps

60 Installing and uninstalling apps
61 Phone
65 Messaging
66 Camera
72 Gallery
75 File Manager
75 Weather
75 Calculator
75 Tasks
76 Voice Recorder
76 Downloads
76 FM Radio
77 Clock
78 Music
79 E-mail
80 Contacts
82 Calendar
83 Evernote
83 Cell Broadcast
84 LG Backup
84 Recently uninstalled apps
85 Google apps

04

Phone Settings

88 Settings
88 Networks
98 Sound & notification
99 Display
100 General

05

Appendix

110 Phone software update
112 FAQ
115 Anti-Theft Guide
116 More information

Guidelines for safe and efficient use

Please read these simple guidelines. Not following these guidelines may be dangerous or illegal.

Should a fault occur, a software tool is built into your device that will gather a fault log. This tool gathers only data specific to the fault, such as signal strength, cell ID position in sudden call drop and applications loaded. The log is used only to help determine the cause of the fault. These logs are encrypted and can only be accessed by an authorised LG Repair centre should you need to return your device for repair.

Exposure to radio frequency energy

Radio wave exposure and Specific Absorption Rate (SAR) information.

This mobile phone model LG-K520K has been designed to comply with applicable safety requirements for exposure to radio waves. These requirements are based on scientific guidelines that include safety margins designed to assure the safety of all persons, regardless of age and health.

- The radio wave exposure guidelines employ a unit of measurement known as the Specific Absorption Rate, or SAR. Tests for SAR are conducted using standardised methods with the phone transmitting at its highest certified power level in all used frequency bands.
- While there may be differences between the SAR levels of various LG phone models, they are all designed to meet the relevant guidelines for exposure to radio waves.
- The SAR limit recommended by the International Commission on Non-Ionizing Radiation Protection (ICNIRP) is 2 W/kg averaged over 10 g of tissue.
- The highest SAR value for this model phone tested for use at the ear is 0.465 W/kg (10 g) and when worn on the body is 1.150 W/kg (10 g).

- This device meets RF exposure guidelines when used either in the normal use position against the ear or when positioned at least 5 mm away from the body. When a carry case, belt clip or holder is used for body-worn operation, it should not contain metal and should position the product at least 5 mm away from your body. In order to transmit data files or messages, this device requires a quality connection to the network. In some cases, transmission of data files or messages may be delayed until such a connection is available. Ensure the above separation distance instructions are followed until the transmission is completed.

Product care and maintenance

- Always use genuine LG batteries, chargers and accessories approved for use with this particular phone model. The use of any other types may invalidate any approval or warranty applying to the phone and may be dangerous.
- Some contents and illustrations may differ from your device without prior notice.
- Do not disassemble this unit. Take it to a qualified service technician when repair work is required.
- Repairs under warranty, at LG's discretion, may include replacement parts or boards that are either new or reconditioned, provided that they have functionality equal to that of the parts being replaced.
- Keep away from electrical appliances such as TVs, radios and personal computers.
- The unit should be kept away from heat sources such as radiators or cookers.
- Do not drop.
- Do not subject this unit to mechanical vibration or shock.
- Switch off the phone in any area where you are required to by special regulations. For example, do not use your phone in hospitals as it may affect sensitive medical equipment.
- Do not handle the phone with wet hands while it is being charged. It may cause an electric shock and can seriously damage your phone.
- Do not charge a handset near flammable material as the handset can become hot and create a fire hazard.

- Use a dry cloth to clean the exterior of the unit (do not use solvents such as benzene, thinner or alcohol).
- Do not charge the phone when it is on soft furnishings.
- The phone should be charged in a well ventilated area.
- Do not subject this unit to excessive smoke or dust.
- Do not keep the phone next to credit cards or transport tickets; it can affect the information on the magnetic strips.
- Do not tap the screen with a sharp object as it may damage the phone.
- Do not expose the phone to liquid or moisture.
- Use accessories like earphones cautiously. Do not touch the antenna unnecessarily.
- Do not use, touch or attempt to remove or fix broken, chipped or cracked glass. Damage to the glass display due to abuse or misuse is not covered under the warranty.
- Your phone is an electronic device that generates heat during normal operation. Extremely prolonged, direct skin contact in the absence of adequate ventilation may result in discomfort or minor burns. Therefore, use care when handling your phone during or immediately after operation.
- If your phone gets wet, immediately unplug it to dry off completely. Do not attempt to accelerate the drying process with an external heating source, such as an oven, microwave or hair dryer.
- The liquid in your wet phone, changes the colour of the product label inside your phone. Damage to your device as a result of exposure to liquid is not covered under your warranty.

Efficient phone operation

Electronics devices

All mobile phones may receive interference, which could affect performance.

- Do not use your mobile phone near medical equipment without requesting permission. Avoid placing the phone over pacemakers, for example, in your breast pocket.
- Some hearing aids might be disturbed by mobile phones.
- Minor interference may affect TVs, radios, PCs etc.
- Use your phone in temperatures between 0 °C and 40 °C, if possible. Exposing your phone to extremely low or high temperatures may result in damage, malfunction, or even explosion.

Road safety

Check the laws and regulations on the use of mobile phones in the area when you drive.

- Do not use a hand-held phone while driving.
- Give full attention to driving.
- Pull off the road and park before making or answering a call if driving conditions so require.
- RF energy may affect some electronic systems in your vehicle such as car stereos and safety equipment.
- When your vehicle is equipped with an air bag, do not obstruct with installed or portable wireless equipment. It can cause the air bag to fail or cause serious injury due to improper performance.
- If you are listening to music whilst out and about, please ensure that the volume is at a reasonable level so that you are aware of your surroundings. This is of particular importance when near roads.

Avoid damage to your hearing



To prevent possible hearing damage, do not listen at high volume levels for long periods.

Damage to your hearing can occur if you are exposed to loud sound for long periods of time. Make sure that you do not turn on or off the handset close to your ear. Also, make sure that music and call volumes are set to a reasonable level.

- When using headphones, turn the volume down if you cannot hear the people speaking near you, or if the person sitting next to you can hear what you are listening to.



- Excessive sound pressure from earphones and headphones can cause hearing loss.

Glass Parts

Some parts of your mobile device are made of glass. This glass could break if your mobile device is dropped on a hard surface or receives a substantial impact. If the glass breaks, do not touch or attempt to remove it. Stop using your mobile device until the glass is replaced by an authorised service provider.

Blasting area

Do not use the phone where blasting is in progress. Observe restrictions and follow any regulations or rules.

Potentially explosive atmospheres

- Do not use your phone at a refueling point.
- Do not use near fuel or chemicals.
- Do not transport or store flammable gas, liquid or explosives in the same compartment of your vehicle as your mobile phone or accessories.

In aircraft

Wireless devices can cause interference in aircraft.

- Turn your mobile phone off before boarding any aircraft.
- Do not use it on the ground without permission from the crew.

Children

Keep the phone in a safe place out of the reach of small children. It includes small parts which may cause a choking hazard if detached.

Emergency calls

Emergency calls may not be available on all mobile networks. Therefore you should never depend solely on your phone for emergency calls. Check with your local service provider.

Battery information and care

- You do not need to completely discharge the battery before recharging. Unlike other battery systems, there is no memory effect that could compromise the battery's performance.
- Use only LG batteries and chargers. LG chargers are designed to maximise the battery life.
- Do not disassemble or short-circuit the battery.
- Keep the metal contacts of the battery clean.
- Replace the battery when it no longer provides acceptable performance. The battery pack may be recharged hundreds of times before it needs replacing.
- Recharge the battery if it has not been used for a long time to maximise usability.
- Do not expose the battery charger to direct sunlight or use it in high humidity, such as in the bathroom.
- Do not leave the battery in hot or cold places, as this may deteriorate battery performance.

- Risk of explosion if battery is replaced by an incorrect type. Dispose of used batteries according to the instructions.
- If you need to replace the battery, take it to the nearest authorised LG Electronics service point or dealer for assistance.
- Always unplug the charger from the wall socket after the phone is fully charged to save unnecessary power consumption of the charger.
- Actual battery life will depend on network configuration, product settings, usage patterns, battery and environmental conditions.
- Make sure that no sharp-edged items such as animal's teeth or nails, come into contact with the battery. This could cause a fire.

01

Custom-designed Features


Quick Share


You can take a picture or record a video and then share it through an app.

1 Tap ◯ > , then take a photo or record a video.

2 On the photo or video screen, tap and hold the preview icon, then drag over the Quick Share icon.
Alternatively, drag the Quick Share icon from the preview screen and select an app to share the photo.

- The app displayed by the Quick Share icon may vary, depending on the type and frequency of access of the app installed on the device.






Mini view

To shrink the screen for use with one hand, swipe left or right across the Back, Home and Overview buttons.

- ✕ : Close the Mini view.
- : Adjust the size of the Mini view.



Dual window

The Dual window function splits the screen to enable multi-tasking, drag and drop interaction, auto-linking, and recently used apps.

Activating the Dual window

1 Tap ◯ > **Settings** > **General** > **Dual window**.

2 Swipe ⬭ to activate it.

- Checkmark the Auto-open checkbox to automatically open the Dual window function when you tap a link on the full screen or tap an email image attachment.

Using the Dual window

1 Tap ◯ > ☐ > **Dual window**.

- While viewing an app, you can tap the ☐ > **Dual window** to automatically set that app in the top window, then select the second app.

2 Tap the app icon you want to use. The first app you tap opens in a window at the top of the screen. The second app opens in the bottom window.

3 Tap a window to select and use it.

- A blue box appears around the selected window with a blue semicircle handle between the windows.
- Drag the blue handle to change the window sizes (one larger and one smaller).

QuickMemo+

QuickMemo+ overview

You can make creative notes by using a variety options on this advanced feature of notepad, such as image management and screenshots, which are not supported by the conventional notepad.

Creating a note

1 Tap ◯ > **QuickMemo+**.

2 Tap + to create a note.

- ✓ : Save a note.
- ↩ : Undo the last action.
- ↪ : Redo the last action you undid.
- T : Enter a note by using the keypad.
- ✎ : Write notes by hand.
- ◇ : Erase handwritten notes.
- ◌ : Edit or erase parts of a handwritten note.
- ⋮ : Access additional options, including sharing and locking notes, changing the notepad style and inserting content.

3 Tap ✓ to save the note.

Writing notes on a screenshot

1 Drag the status bar downwards and then tap .
   - The screenshot appears as the notepad background theme. Memo tools appear at the top of the screen.

2 Take notes on the screen to capture.
   - To crop and save a portion of the screen, tap and specify a portion with the crop tool.
   - To attach a screenshot to the notepad, tap .

3 Tap and save the notes to the location you want.
   - Saved notes can be viewed in either **QuickMemo+** or **Gallery**.
   - To save notes in the same location all the time, select the **Use as default app** checkbox and select an app.

Managing folders

You can group notes by the note type.

1 Tap > **QuickMemo+**.

2 At the top of the screen, tap and select a menu item:
   - **All memos**: View notes saved in **QuickMemo+**.
   - **My memos**: View notes created by **QuickMemo+**.
   - **Capture+**: View notes created by .
   - **Trash**: View deleted notes.
   - **New category**: Add categories.
   - : Rearrange, add or delete categories. To change the name of a category, tap the category.

- Some folders do not appear when launching QuickMemo+ for the first time. Disabled folders are enabled and appear when they contain at least one related note.

QSlide

You can display several apps simultaneously on the same screen and switch between them.

For example, use the calculator or calendar when a video is playing.

When an app is running, tap ⋮ > **QSlide**.

- This feature may not be supported by some apps.

- : Turn off the QSlide mode to switch to full-screen mode.
- : Adjust the opacity of the QSlide window. If the QSlide window is transparent, it will not respond to touch inputs.
- : Close the QSlide window.
- : Adjust the size of the QSlide window.

Pen Pop

The Pen Pop feature allows you to quickly and easily access options to create a memo. Pull the pen out and Pen Pop opens.

Setting up Pen Pop

Tap ◯ > **Settings** > **General** > **Pen**.

Pen Pop options

- : Hide/display the Pen Pop options.
- : Open the Pop Memo to write a memo.
- : Open the Capture+ and use the current screen image in a memo.
- : Open the Pop Scanner to capture a photo with the camera and use it in a memo.
- : Open the QuickMemo+ and view current memos.
- : Add a shortcut to the app of your choice.

> • You can change the personalized shortcut by touching and holding icon in the Pen Pop options.

Content sharing

Playing content

You can play content from your device on TV. Play saved content such as photos, music, and videos.

1 Connect phone and TV to the same Wi-Fi network before playing.

2 Select **Play content** on detail view in Gallery, Music to select device to play.



• For Chromecast, Google Play services should be up to date.

Sending or receiving files

You can quickly send and receive files between LG phones and tablets.

1 To receive files, drag down status bar and turn on File sharing. For devices that do not support File sharing, turn on **SmartShare Beam** in **Settings** > **Networks** > **Share & connect** > **File sharing**.

2 You can send files faster when both devices are connected to the same Wi-Fi network. You can send files to DLNA-compatible phones and tablets regardless if it is a LG device.

Sending files to another device

1 Select a file and tap > **SmartShare Beam**. Alternatively, tap from the file list and select files then tap **SHARE** > **SmartShare Beam**.

2 Select a device from the list of nearby devices that support SmartShare Beam.
   - The file is sent to the device.

Using nearby devices

You can play music, and other functions saved on a connected device from your device.

1 From the **Gallery** or **Music** app, select > **Nearby devices**.

2 Select a device from the device list.
   - If the desired device is not seen on the device list, check that DLNA is turned on, then tap **Search nearby devices**.

3 Play content saved on the selected device.

Do not disturb

You can limit or mute notifications to avoid disturbances for a specific period of time.

1 Tap ◯ > **Settings** > **Sound & notification** > **Do not disturb** > **Sound and vibrations**.

2 Select and turn on the mode you want:

- **Priority only**: Receive sound or vibrate notifications for the selected apps. When **Priority only** is turned off, alarms always go off.
- **Total silence**: Disable both the sound and vibration.

Ringtone ID

You can set the device to play an automatically created ringtone for an incoming call from a selected contact.

1 Tap ◯ > **Settings** > **Sound & notification** > **Ringtone ID** and then swipe ⬭ to activate it.

2 Tap **Compose ringtones for** and select the desired option.

- The default ringtone plays for incoming calls from contacts except for the selected contact.

02

Basic Functions

Product components and accessories


Make sure that none of the following items are missing:

- Device
- Battery
- Stereo headset
- USB cable
- Charger
- Quick Start Guide

- Always use genuine LG Electronics accessories. Using accessories made by other manufacturers may affect your device's call performance or cause malfunctions. Any issues resulting from usage of accessories made by other manufacturers may not be covered by LG's repair service.

- If any of these basic items are missing, contact the dealer from which you purchased your device.
- To purchase additional basic items, contact the LG Customer Support Centre.
- To purchase optional items, contact the LG Customer Support Centre for available dealers, and then purchase online.
- Some items in the product box are subject to change without notice.
- The appearance and specifications of your device are subject to change without notice.
- The number of supplied batteries is indicated on the label attached on the product box.

Parts overview



- **Proximity/Ambient light sensor**
  - Proximity sensor: The proximity light sensor turns off the screen and disables touch functionality when the device is in close proximity to the human body. It turns the screen back on and enables touch functionality when the device is outside a specific range.
  - Ambient light sensor: The ambient light sensor analyses the ambinent light intensity when the auto-brightness control mode is turned on.
- **Volume keys**
  - Adjust the volume for ringtones, calls or notifications.
  - Gently press a volume key to take a photo. To take continuous shots of photos, press and hold the volume key.
  - Press the volume down (-) key twice to launch the **Camera** app when the screen is locked or turned off. Press the volume up (+) key twice to launch **Capture+**.
- **Power/Lock key**
  - Briefly press the key when you want to turn on or off the screen.
  - Press and hold the key when you want to select a power control option.

- Some functions may be restricted for access, depending on the device specifications.
- Do not put heavy objects on the device or sit on it, as this may damage the screen.
- Screen-protective film or accessories may interfere with the proximity sensor.
- If your device is wet or is being used in a humid place, the touch sensor or buttons may not function properly.

Turning on or off the power

Turning on the power

When the power is turned off, press and hold the Power/Lock key.

- When the device is turned on for the first time, initial configuration takes place. The first booting time for the smart phone may be longer than usual.

Turning off the power

Press and hold the Power/Lock key, then select **Power off**.

Power control options

Tap and hold the Power/Lock key, then select an option.

- **Power off**: Turn off the device.
- **Power off and restart**: Restart the device.
- **Turn on Airplane mode**: Block telecommunication-related functions, including making phone calls, messaging and browsing the Internet. Other functions remain available.


Installing the SIM card and battery

Insert the SIM card provided by the device service provider, and the included battery.


- Do not insert a memory card into the SIM card slot. If a memory card happens to be lodged in the SIM card slot, take the device to a LG Service Centre to remove the memory card.

- Only the Nano SIM cards work with the device.


1 To remove the back cover, hold the device firmly in one hand. With your other hand, lift off the back cover with your thumbnail as shown in the figure.




2 Slide the SIM card into the SIM card slot as shown in the figure. Make sure the gold contact area on the card is facing downward.



3 Insert the battery.



4 To replace the cover onto the device, align the back cover over the battery compartment and press it down until it clicks into place.




Charging the battery

Charge the battery before using it for first time. Use the charger to charge the battery. A computer can also be used to charge the battery by connecting the device to it using the USB cable.

- Use only LG-approved chargers, batteries and cables. If you use unapproved chargers, batteries or cables, it may cause battery charging delay. Or this can cause the battery to explode or damage the device, which are not covered by the warranty.

The charger connector is located at the bottom of the device. Insert the charger and plug it into a power outlet.



- Do not open the back cover while your device is charging.

Optimizing battery life

Extend your battery's power by turning off features that you do not need to run constantly in the background. You can monitor how applications and system resources consume battery power.

Extending your device battery life

- Turn off radio communications when you are not using. If you are not using Wi-Fi, Bluetooth® or GPS, turn them off.
- Reduce screen brightness and set a shorter screen timeout.
- Turn off automatic syncing for Gmail, Calendar, Contacts and other applications.
- Some applications you download may consume battery power.
- While using downloaded applications, check the battery charge level.

Inserting the memory card


Your device supports up to a 128GB microSD card. Depending on the memory card manufacturer and type, some memory cards may not be compatible with your device.

- Some memory cards may not be fully compatible with the device. If you use an incompatible card, it may damage the device or the memory card, or corrupt the data stored in it.

- If you write and erase data too frequently, it will shorten the lifespan of memory cards.

1 Remove the back cover.

2 Insert a memory card with the gold-coloured contacts facing downwards.




3 Replace the back cover.

Touch screen

You can familiarise yourself with how to control your device by using touch screen gestures.


Tapping

Lightly tap with your fingertip to select or run an app or option.




Tapping and holding

Tap and hold for several seconds to run a hidden function.




Double-tapping

Tap twice quickly to zoom in or out on a picture or map.




Swiping

Tap and hold an item, such as an app or widget, then swipe it to another location. You can use this gesture to move an item.




Flicking

Gently tap and hold on the screen, then flick left or right to quickly move to another panel.



Pinching and spreading

Pinch two fingers to zoom out, such as on a photo or map. To zoom in, spread your fingers apart.



- Do not expose the touch screen to excessive physical shock. You might damage the touch sensor.

- A touch screen failure may occur if you use the device near a magnetic, metallic or conductive material.
- If you use the device under bright lights, such as direct sunlight, the screen may not be visible, depending on your position. Use the device in a shady location or a location with an ambient light that is not too bright and bright enough to read books.
- Do not press the screen with excessive force.
- Gently tap with your fingertip on the option you want.
- Touch control may not work properly if you tap while wearing a glove on or by using the tip of your fingernail.
- Touch control may not work properly if the screen is moist or wet.
- The touch screen may not function properly if a screen-protective film or accessory is attached to the device.

Home screen


Home screen overview

The Home screen is the starting point for accessing various functions and apps on your device. Tap ◯ on any screen. This immediately redirects you to the Home screen.

There is a list of apps on the Home screen. You can run apps directly from the Home screen without needing to open the app screens. Drag the Home screen left or right. Available apps appear. User-installed apps as well as default apps can be run from the list of apps.

Home screen layout

You can add frequently used apps, widgets and folders to the Home screen. This simplifies the steps used to access them.



- The Home screen may vary, depending on the service provider or software version.

- **Status bar**: View status icons, the time and the battery level.
- **Widgets**: Add widgets to the Home screen to quickly access necessary information without bothering to run apps one by one.
- **Folder**: Create folders to group apps according to particular criteria.
- **Page icon**: View the total number of Home screen canvases and the currently displayed canvas which is highlighted.
- **Quick access area**: Fix main apps at the bottom of the screen so that they can be accessed from any Home screen canvas.
- **Home touch buttons**
  - ◁: Return to the previous screen. Close the keypad or pop-up windows.
  - ◯: Tap to go to the Home screen. To launch **Google**, tap and hold.
  - □: View a list of recently used apps or run an app from the list. Use the **Clear all** option to delete all recently used apps. In some apps, tapping and holding the button will access additional options.

Editing Home touch buttons

You can rearrange Home touch buttons or add frequently used functions to Home touch buttons.

Tap ◯ > **Settings** > **Display** > **Home touch buttons** and customise settings.

- Several functions, including QSlide, the Notification or Capture+, are provided. A maximum of five items can be added.

Status icons

When there is a notification for an unread message, calendar event or alarm, the status bar displays the corresponding notification icon. Check your device's status by viewing notification icons displayed on the status bar.

- : No signal
- : Data is being transmitted over network
- : Alarm is set
- : Vibrate mode is on
- : Bluetooth is on
- : Connected to a computer via USB
- : Battery level
- : Flight mode is on
- : Missed calls
- : Wi-Fi is on
- : Mute mode is on
- : GPS is on
- : Hotspot is on
- : No SIM card

- Some of these icons may appear differently or may not appear at all, depending on the device's status. Refer to the icons according to the actual environment in which you are using the device.
- Displayed icons may vary, depending on the area or service providers.


Notifications panel

You can open the notifications panel by dragging the status bar downwards.

Use quick access icons in the notifications panel to easily and quickly turn a function on or off.

Drag left or right on the list of quick access icons to select the function icon you want.

- If you tap and hold the icon, the settings screen for the corresponding function appears.



Notification panel settings

You can select items to display on the notification panel.

Tap ⚙ on the notification panel.

- To rearrange quick access icons, tap and hold an icon, then drag it to another position.
- Select icons you want to display on the list.

Switching the screen orientation

You can set the screen orientation to automatically switch, according to the device's orientation.

On the notification panel, tap **Rotation** from the quick access icon list.

Alternatively, tap ◯ > **Settings** > **Display** > **Auto-rotate screen** and then swipe ⬭ to activate it.

Editing the Home screen

On the Home screen, tap and hold on an empty space, then start the desired function.

- To rearrange the Home screen canvases, tap and hold on a canvas, then drag it to another location.
- To add widgets to the Home screen, tap **Widgets** and drag a widget to the Home screen.
- To change the Home screen background theme, tap **Home screen settings** and select a **Theme**.
- To change Home screen settings, tap **Home screen settings** and customise options. See *Home screen settings* for details.

Viewing the background theme

You can view only the background image by hiding apps and widgets on the Home screen.

Spread two fingers apart while holding down on the Home screen.

- To return to the original screen which displays apps and widgets, pinch your fingers on the Home screen.

Moving apps on the Home screen

On the Home screen, tap and hold an app, then drag it to another location.

- To keep frequently used apps at the bottom of the Home screen, tap and hold an app, then drag it to the Quick access area at the bottom.
- To remove an icon from the Quick access area, drag the icon to the Home screen.

Using folders from the Home screen

Creating folders

On the Home screen, tap and hold an app, then drag it over another app.

- A new folder is created and the app is added to the folder.

Editing folders

On the Home screen, tap a folder and then run the desired function.

- To edit the folder name and colour, tap the folder name input field.
- To remove an app from the folder, tap and hold the app and drag it to outside the folder. If only one app is left in the folder, the folder disappears automatically.

Home screen settings

You can customise Home screen settings.

1 Tap ◯ > **Settings** > **Display** > **Home screen**.

2 Customise settings:

- **Select Home**: Select a Home screen mode.
- **Wallpaper**: Change the Home screen background theme.
- **Screen swipe effect**: Select an effect to apply when the Home screen canvas switches.
- **Theme**: Sets the screen theme for your device. You can download new themes from LG SmartWorld.
- **Sort apps by**: Change the app order for the Home screen.
- **Grid**: Change the app arrangement mode for the Home screen.
- **Hide apps**: You can select apps to hide.

Screen lock

Screen lock overview

Your device's screen turns off and locks itself if you press the Power/Lock key. This also happens after the device is left idle for a specified period of time.

If you press the Power/Lock key when a screen lock is not set, the Home screen appears immediately.

To ensure security and prevent unwanted access to your device, set a screen lock.



- Screen lock prevents unnecessary touch input on the device screen and reduces battery consumption. This mode also lowers battery consumption.

Configuring lock screen settings

There are several options available for configuring lock screen settings.

1 Tap ◯ > **Settings** > **Display** > **Lock screen** > **Select screen lock** and then select the method you prefer.

2 Customise lock settings:

- **Swipe** : Slide on the screen to unlock the screen.
- **Knock Code** : Tap on spaces one after another on the screen to unlock the screen.
- **Pattern** : Draw a pattern to unlock the screen.
- **PIN** : Enter a numeric password to unlock the screen.
- **Password** : Enter an alphanumeric password to unlock the screen.



- To set screen lock using a pattern, first create a Google account or backup PIN. If you enter an incorrect pattern more than a specified number of times consecutively, unlock by using your backup PIN or Google account.
- If screen lock is set using a Knock code, Pattern, PIN or Password and you enter an incorrect pin or pattern more than a specified number of times, password entry is blocked for 30 seconds.
- You can initiallise the locked screen by referring to the LG mobile homepage at *www.lg-mobile.co.il*.

Lock screen settings

You can customise lock screen settings.

1 Tap ◯ > **Settings** > **Display** > **Lock screen**.

2 Customise settings:

- **Select screen lock**: Select a screen lock method. If you do not want to use screen lock, tap **None**.
- **Smart Lock**: Specify trusted devices or places to automatically unlock the screen for those devices or places.
- **Screen swipe effect**: Set screen transition effects to apply when the screen is unlocked. This option appears when the screen lock method is set to swipe.
- **Wallpaper**: Change the lock screen background theme.
- **Shortcuts**: Add an app shortcut and directly access the app from the lock screen by dragging the app outside the large circle. This option appears if the screen lock method is set to swipe.
- **Contact info for lost phone**: Display emergency contact information on the lock screen.
- **Lock timer**: Set the amount of time remaining before the device becomes idle and then the screen automatically locks.
- **Power key instantly locks**: Instantly lock the screen when the Power/Lock key is pressed.



- Available setting items may vary, depending on the selected screen lock method.

KnockON

You can turn on or off the screen by double-tapping the screen.

- This option is available only on the Home screen provided by LG. It may not function properly on a custom launcher or on the Home screen installed by the user.
- When tapping the screen, use your fingertip. Do not use a fingernail.
- To use the KnockON feature, make sure that the proximity/light sensor is not blocked by a sticker or any other foreign substance.

Turning on the screen

Double-tap the middle of the screen.

- Tapping the top or bottom of the screen may decrease the recognition rate.

Turning off the screen

Double-tap the status bar, an empty area on the Home screen or the Lock screen.

Knock Code

You can unlock the screen by creating your own Knock Code. When the screen is locked, you can directly access the Home screen by tapping the screen in a specified sequence.

- You can use your Knock Code, together with the KnockOn feature.
- If you enter an incorrect Knock Code more than a specified number of times consecutively, unlock the device by using your backup PIN or Google account.
- Make sure to use your fingertip when tapping the screen.

Creating a Knock Code

1 Tap ◯ > **Settings** > **Display** > **Lock screen** > **Select screen lock** > **Knock Code**.

2 Tap the squares in a pattern of your choice to create a Knock Code and tap **NEXT**.

3 Input the created Knock Code again for verification, then tap **CONFIRM**.

4 Set a backup PIN to use when the Knock Code is forgotten.

Unlocking the screen with a Knock Code

Unlock the screen by inputting the Knock Code you have created.

Input your Knock Code on the touch screen when the screen is turned off.

- It is also possible to enter a Knock Code when the lock screen is turned on.

Device encryption

Encrypting your device

It is possible to read, write and copy data even when device encryption is set. It is also possible to display a user confirmation prompt when the power is turned on by using lock settings while in lock screen mode.

Precautions for device encryption

You can use the mobile phone lock on the lock screen to increase your device's protection level.

- If mobile phone lock is turned on and an incorrect password is entered more than a specified number of times, the device will automatically initialise.
- If you forget your decryption password, initialise the device. Initialisation will delete all data saved before initialisation.
- Stopping encryption before it is complete may damage data. For example, do not remove or insert the battery while encryption is in progress. Wait until the process is complete.

SD card encryption

You can encrypt and protect data saved on the SD card. The encrypted data in the SD card cannot be accessed from another device.

1 Tap ◯ > **Settings** > **General** > **Security** > **Encrypt SD card storage**.

2 Read the on-screen overview of SD card encryption and then tap **CONTINUE** to continue.

3 Select an option and tap **ENCRYPT NOW**:

- **New data encryption**: Encrypt only data that is saved on the SD card after encryption.
- **Full encryption**: Encrypt all the data currently saved on the SD card.
- **Exclude media files**: Encrypt all files, except for media files such as music, photos and videos.



- To encrypt the SD card, make sure that screen lock is set using a PIN or password.
- Once SD card encryption starts, some functions are restricted to access.
- If you turn off the power while encryption is underway, the encryption process will fail, and some data may be damaged.
- Encrypted files are accessible only from the device where the files were encrypted.
- The encrypted SD card cannot be used on another LG device. To use the encrypted SD card on another mobile device, initialise the card.
- You can perform SD card encryption on your device even when it does not contain an SD card installed. Any SD card that is installed after encryption will automatically be encrypted.

Taking screenshots

You can take screenshots of the current screen you are viewing.

Via a shortcut

Press and hold the Power/Lock key and the volume down (-) key simultaneously for at least two seconds.

- Screenshots can be viewed from the **Screenshots** folder under **Gallery**.

Via Capture+

On the screen where you want to take a screenshot, drag the status bar downwards, then tap **Capture+**.

- When the screen is turned off or locked, you can access **Capture+** by pressing the volume up (+) key twice. First tap **Settings** > **General** and then turn on **Shortcut key**.
- See *Writing notes on a screenshot* for details.

Entering text

Using Smart keyboard

You can use Smart keyboard to enter and edit text.


With Smart keyboard, you can view text as you type without bothering to alternate between the screen and a conventional keyboard. This allows you to easily find and correct errors when typing.



Moving the cursor

With Smart keyboard, you can move the cursor to the exact position you want.

When typing text, tap and hold on the space bar and then drag left or right until the cursor moves to the position you want in the text.




- This option is available only on the QWERTY or single vowel layout keyboard.

Suggesting words

Smart keyboard automatically analyses your usage patterns to suggest frequently used words as you type. The longer you use your device, the more precise the suggestions are.

Enter text, then tap a suggested word or gently drag the left or right side of the keyboard upwards.

- The selected word is automatically entered. You do not need to manually type every letter of the word.




Changing the QWERTY keyboard layout

You can add, delete or rearrange keys on the bottom row of the keyboard.

1 Tap ◯ > **Settings** > **General** > **Language & keyboard** > **LG Keyboard** > **Keyboard height and layout** > **QWERTY keyboard layout**.

Alternatively, tap ⚙ on the keyboard and tap **Keyboard height and layout** > **QWERTY keyboard layout**.

2 Tap a key on the bottom row, then drag it to another position.




- This option is available on the QWERTY, QWERTZ and AZERTY keyboards.
- This option may not be supported for some languages.

Customising the keyboard height

You can customise the keyboard height to maximise hand comfort when typing.

1 Tap ◯ > **Settings** > **General** > **Language & keyboard** > **LG Keyboard** > **Keyboard height and layout** > **Keyboard height**.
Alternatively, tap ⚙ on the keyboard and tap **Keyboard height and layout** > **Keyboard height**.

2 Adjust the keyboard height.



Selecting a landscape keyboard mode

You can select a landscape keyboard mode from several choices.

1 Tap ◯ > **Settings** > **General** > **Language & keyboard** > **LG Keyboard** > **Keyboard height and layout** > **Keyboard type in landscape**.
Alternatively, tap ⚙ on the keyboard and tap **Keyboard height and layout** > **Keyboard type in landscape**.


2 Select a keyboard mode.

Splitting the keyboard

You can split the keyboard in half and place each piece on either side of the screen when the screen is in landscape mode.

1 Tap ◯ > **Settings** > **General** > **Language & keyboard** > **LG Keyboard** > **Keyboard height and layout** > **Split keyboard**.
Alternatively, tap ⚙ on the keyboard and tap **Keyboard height and layout** > **Split keyboard**.

2 On the keyboard, spread your fingers apart horizontally.
- To merge the split keyboard, pinch your fingers together on the keyboard.




One-handed operation mode

You can move the keyboard to one side of the screen so that you can use the keyboard with one hand.

1 Tap ◯ > **Settings** > **General** > **Language & keyboard** > **LG Keyboard** > **Keyboard height and layout** > **One-handed operation**.
Alternatively, tap ⚙ on the keyboard and tap **Keyboard height and layout** > **One-handed operation**.

2 Drag the keyboard left or right according to the direction of the desired keyboard arrangement.
Alternatively, press the arrow displayed next to the keyboard to move the keyboard in the direction you want.



Entering text by using voice

On the keyboard, tap and hold ⚙ and then select 🎤.

- To maximise the voice command recognition, speak clearly.
- To enter text by using your voice, make sure that your device is connected to a network.

Changing the keyboard

You can change the input language. You can also change the keyboard type for each language.

1 Tap ◯ > **Settings** > **General** > **Language & keyboard** > **LG Keyboard** > **Select languages**.

2 Select a language and customise the keyboard type.

Copy and Paste

You can cut, copy, or paste text between apps.

1 Tap and hold around the text you want to copy or cut.

2 Drag / to specify the area to copy or cut.

3 Select either **CUT** or **COPY**.

- Cut or copied text is automatically added to the clip tray.

4 Tap and hold the text input window, then select **PASTE**.

- If there is no item that has been copied or cut, the **PASTE** option will not appear.

Clip Tray

If you copy or cut an image or text, it is automatically saved to the clip tray and can be pasted to any space at any time.

1 On the keyboard, tap and hold and select .
Alternatively, tap and hold the text input window, then select **CLIP TRAY**.

2 Select and paste an item from the clip tray.

- Tap to lock saved items in order to not delete them; even when the maximum quantity is exceeded. A maximum of ten items can be locked. To delete locked items, unlock them first.
- Tap to delete the items saved to the clip tray.

- The clip tray may not be supported by some apps downloaded by the user.

03

Useful Apps

Installing and uninstalling apps

Installing apps

Access an app store to search and download apps.

- You can use **Play Store** and the app store provided by your mobile service provider.

- Some app stores may require you to create an account and sign in.
- Some apps may charge fees.
- If you use mobile data, you may be charged for data usage, depending on your pricing plan.

Uninstalling apps

Uninstall apps that you no longer use from your device.

- Some apps cannot be uninstalled by users.

Uninstalling with the tap and hold gesture

On the Home screen, tap and hold the app to uninstall, then drag it over **Uninstall** at the top of the screen.

Uninstalling by using the settings menu

Tap ◯ > **Settings** > **General** > **Apps**, select an app, then tap **Uninstall**.

Uninstalling apps from the app store

To uninstall an app, access the app store from which you download the app and uninstall it.

Phone

Voice call

Make a phone call by using one of the available methods, such as manually entering a phone number or making a call from the contact list or the list of recent calls.

Making a call from the keypad

1 Tap ◯ > > **Dial**.

2 Make a call by using a method of your choice:

- Enter a phone number and tap .
- Tap and hold a speed-dial number.
- Search for a contact by tapping the initial letter of a contact name in the contact list, and then tap .

- To enter "+" when making an international call, tap and hold number 0.
- See *Adding contacts to the speed dial list* for details on how to add phone numbers to the speed dial list.

Making a call from the contact list

1 Tap ◯ > > **Contacts**.

2 From the contact list, select a contact and tap .

Answering a call

To answer a call, drag to the outside of the circle on the incoming call screen.

- When the stereo headset is connected, you can make calls by using the call/end button on the headset.
- To end a call simply by pressing the Power/Lock key, tap > **Settings** > **Networks** > **Call** > **Answer and end calls**, then turn on **End calls with the Power key**.

Rejecting a call

To reject an incoming call, drag to the outside of the circle on the incoming call screen.

- To send a rejection message, drag the rejection message to the outside of the circle.
- To add or edit a rejection message, tap > **Settings** > **Networks** > **Call** > **Decline and reject calls** > **Decline with message**.
- When a call is coming in, you can press the volume down (-) key to switch to mute mode. To switch to hold mode, press the Power/Lock key.

Viewing missed calls

If there is a missed call, the status bar at the top of the screen displays .

To view missed call details, drag the status bar downwards. Alternatively, tap > > **Call logs**.

Functions accessible during a call

During a call, you can access a variety of functions by tapping on-screen buttons:

- **Contacts**: Move directly to the contact list from the call screen. It is possible to view the contact list during a call.
- **End**: End a call.
- **Dialpad**: Display or hide the dial pad.
- **Speaker**: Turn on the speakerphone function.
- **Mute**: Mute your voice so that your voice cannot be heard by the other party.
- **Bluetooth**: Use a Bluetooth device to make calls. Make sure that a Bluetooth device is connected.
- ⋮ : Access many call options.



- Available setting items may vary, depending on the area and service provider.

Making a three-way calling

You can make a call to another contact during a call.

1 During a call, tap ⋮ > **Add call**.

2 Enter a phone number and tap .

- The two call screens are displayed at the same time, and the first call is put on hold.

3 To switch to another call, tap another number on the screen.
To start a conference call, tap .



- You may be charged a fee for each call.

Viewing call records

To view recent call records, tap ◯ > > **Call logs**. Then, you can use the following functions:

- To view detailed call records, select a contact. To make a call to the selected contact, tap .
- To delete call records, tap ⋮ > **Delete all**.

- The displayed call duration may differ from the call charge. Contact your mobile service provider for details on call charges.

Configuring call options

You can configure call options.

1 Tap ◯ > > **Dial** or **Call logs**.

2 Tap ⋮ > **Call settings** and then configure options to suit your preferences.

Messaging

Sending a message

You can send messages.

- Sending messages abroad may incur additional charges.

1 Tap ◯ > .

2 Tap .

3 Specify a recipient and create a message.
   - To attach files, tap .
   - To access optional menu items, tap ⋮.

4 Tap **Send** to send the message.

Reading a message

You can view exchanged messages may be contact.

1 Tap ◯ > .

2 Select a contact from the message list.

Configuring messaging settings

You can change messaging settings to suit your preferences.

1 Tap ◯ > .

2 Tap ⋮ > **Settings** from the message list.

Camera

Starting the camera

You can take and save photos or videos to your device.

Tap ◯ > .

- Before taking a photo, wipe the camera lens with a microfibre cloth. If your finger touches the camera lens, you may get blurry photos.
- If the battery level is lower than 5 %, charge the battery before using the camera.
- Images included in this user guide may be different from the actual device.
- Photos and videos can be viewed or edited from **Gallery**. See *Gallery overview* for details.

Switching between cameras

You can switch between front and rear camera.

On the camera screen, tap or drag the screen either up or down or left or right to switch between front and rear camera.

- Use front camera to take selfies. See *Taking selfies* for details.

Auto mode

You can take photos or record videos by selecting a variety of shooting modes and options.



Taking a photo

1 Select a shooting mode, and tap the subject to focus the camera on.

2 Tap to take a photo.
Alternatively, press a volume key.

- When the screen is turned off or locked, start the camera by pressing the volume down (-) key twice. To activate this function, tap > **Settings** > **General** and turn on **Shortcut key**.

Recording a video

1 Select a shooting mode, and tap the subject to focus the camera on.

2 Tap .
- To take a photo during video recording, tap .
- To pause video recording, tap . To resume video recording, tap .

3 Tap to end video recording.

Panorama

You can create a panoramic photo by moving the camera in one direction to photograph and stitch continuos shots of for a wide view.

1 On the auto mode screen, tap **MODE** > .

2 Tap and then slowly move the camera in one direction.
- Move the device by following the direction of the arrow in the guideline.

3 Tap to end shooting.

Burst shot

You can take continuous shots of photos to create moving pictures.

On the auto mode screen, tap and hold .
- Continuous shots are taken at a fast speed while is held down.

Configuring camera options

You can customise a variety of camera options to suit your preferences.

On the auto mode screen, tap ⚙.

- Available options vary, depending on the selected shooting mode.

16:9	Select an aspect ratio for photos or a picture quality for videos.
HDR AUTO	Obtain photos with backlight corrected.
OFF	Set the timer to automatically take photos after a specified period of time.
OFF	Take photos with voice commands. (Available choices: Cheese, Smile, Whisky, Kimchi, LG)
	Display guide grids so that you can take photos based on the horizontal and vertical reference lines.
/	Set the save destination for photos and videos. These options appear when an external SD card is inserted. : Save to the internal storage. : Save to the external storage.
/	Flip images. These options appear when using the front camera. : Do not flip the image. : Flip the image horizontally.
[ ] / [ ]	Customise auto-shooting settings. These options appear when using the front camera. [ ]: Shoot using the Gesture shot feature. [ ]: Shoot when the camera detects a face.

Taking selfies

You can use the front camera to view your face on the screen and take selfies.

- When using the front camera, selfies default to gesture shot. To change selfie-taking methods, see *Configuring camera options* for details.

Gesture shot

You can take selfies by using gestures.

Show your palm to the front camera and then clench your fist.

- In three seconds, a photo is taken.

- To use this function, make sure that [✋] is selected under camera options.
- An alternative way to take gesture shots is to clench your fist and then open it towards the front camera.
- Make sure that your palm and fist are within the reference line so that the camera can detect them.
- Access to some functions may be restricted during multi-view shooting.

Interval shot

You can take continuous selfies.

While using the front camera, tap and hold . Alternatively, show your palm to the camera, then clench your fist twice quickly.

- Four photos are taken at three second interval.

> • To use this function, make sure that [ ] is selected under camera options.

Taking photos automatically

When you switch to the front camera, the front camera detects your face and takes a selfie automatically.

> • To use this function, make sure that [ ] is selected under camera options.

Gallery

Gallery overview

You can view and manage photos and videos saved on your device.

1 Tap ◯ > .


- Saved photos and videos are displayed by the folder.

2 Select a file.

- View the selected file in full-screen mode.
- Drag left or right on the displayed photo or video screen to view the previous or next file.

- Some file formats may not be supported, depending on the installed software.
- Some files may not be opened due to encoding.
- Files that exceed the size limit may cause an error.

Viewing photos



Editing photos

1 On the photo screen, tap ✎.


2 Use a variety of effects and tools to edit the photo.

3 Tap ✓ to apply changes.

4 Tap **SAVE** to save changes.

- The edited photo overwrites the original file.
- To save the edited photo as another file, tap ⋮ > **Save copy**.

Playing a video



- To adjust the sound volume, drag the right side of the video screen up or down.
- To adjust the screen brightness, drag the left side of the video screen up or down.

Deleting files

You can delete a file by using one of the following options:

- Tap and hold a file from the file list, then tap **Delete**.
- Tap from the file list, then select a file.

Sharing files

You can share a file by using one of the following options:

- On the photo or video screen, tap to share the file by using the method you want.
- Tap from the file list to select a file and share the file by using the method you want.

File Manager

You can view and manage files saved on your device.

1 Tap ◯ > **Tools** > **File Manager**.

2 Tap ☰ and select a storage space.

Weather

You can view the weather information for a particular area.

1 Tap ◯ > **Tools** > **Weather**.

2 Tap + and add the city you want.

- On the detailed weather screen, tap 〈 / 〉, or drag the screen left or right to view the weather for other cities.

Calculator

You can use two types of calculators: the simple calculator and the scientific calculator.

1 Tap ◯ > **Calculator**.

2 Use the keypad to make a calculation.

- To use the scientific calculator, tap ⋮ > **Scientific calculator**.
- To view calculation history, tap ⋮ > **Calculation history**.

Tasks

You can register tasks to your device to easily manage schedules.

1 Tap ◯ > **Tasks**.

2 Tap ⊕ to add a task.

3 Enter task details and then tap **SAVE**.

Voice Recorder

You can record and save your voice or others' voices from important events. Recorded voice files can be played back or shared.

1 Tap ◯ > **Tools** > **Voice Recorder**.

2 Tap ⊙.

- To pause recording, tap ⏸.
- To save the location details of recording, tap **Location**.
- To add an event, tap **Event** and add an event to the date you want.

3 Tap ⏹ to end recording.

- The file is saved automatically and the pre-listen screen appears.

4 Tap ▷ to play the recorded voice.

- If you tap ≡, recorded voice files appear. You can play a recorded voice file from the list.

Downloads

You can view, delete or share files downloaded via Internet or apps.

Tap ◯ > **Tools** > **Downloads**.

FM Radio

You can listen to FM radio.

Tap ◯ > **Tools** > **FM Radio**.

- To use this app, first connect a headset to the device. The headset becomes the radio antenna.
- This option may not be supported, depending on the area.

Clock

Alarm

You can set an alarm to trigger it at a specified time.

1 Tap ◯ > **Clock** > **Alarm**.

2 Tap + to add a new alarm.

3 Configure the alarm settings and tap **SAVE**.

- If you select a previously set alarm, you can edit the alarm.
- To delete an alarm, tap 🗑 at the top of the screen. Alternatively, tap and hold the alarm.

World clock

You can view the current time in cities around the world.

1 Tap ◯ > **Clock** > **World clock**.

2 Tap + and add a city.

Timer

You can set the timer to trigger an alarm after a specified period of time.

1 Tap ◯ > **Clock** > **Timer**.

2 Set the time and tap **Start**.

- To suspend the timer, tap **Stop**. To resume the timer, tap **Resume**.
- To initialise the timer settings, tap **Reset**.

3 Tap **Stop** to stop the timer alarm.

Stopwatch

You can use the stopwatch to record a lap time.

1 Tap ◯ > **Clock** > **Stopwatch**.

2 Tap **Start** to initiate the stopwatch.
- To record a lap time, tap **Lap**.

3 Tap **Stop** to suspend the stopwatch.
- To resume the stopwatch, tap **Resume**.
- To delete all the stopwatch records, tap **Reset**.


Music

You can play and manage music files saved on your device.

1 Tap ◯ > **Music**.

2 Select a category.

3 Select a music file.



- Some file formats may not be supported, depending on the installed software.
- Files that exceed the size limit may cause an error.
- Music files may be protected by international copyright owners or copyright laws. You may have to obtain legal permission before copying a music file. To download or copy a music file, first check the copyright law for the relevant country.

E-mail

E-mail overview

You can register an email account to your device and then you can check and send emails from your device.

- If you use mobile data, you may be charged for data usage fee depending on your pricing plan.

Registering email accounts

When you use the email app for the first time, register your email account.

1 Tap ◯ > **E-mail**.

2 Select an email service provider.

3 Enter your email address and password and then tap **NEXT** to register your account
   - To manually register an email account or to register email accounts not found in the list, tap **MANUAL SETUP**.

Managing email accounts

To view or edit your email account settings, tap ⋮ > **Settings**.

- To add an account, tap **Add account**.
- To delete an account, tap ⋮ > **Remove account**.

Opening another email account

If several email accounts are registered and you want to view another account, tap ☰ and select another one from the account list.

Checking email

1 Tap ☰ and select a mail box.

2 Select an email from the email list.

- The email message appears.

Sending email

1 Tap ⊕.

2 Enter the email address of a recipient.

3 Enter a subject and message.

- To attach files, tap 📎.
- To access optional menu items, tap ⋮.

4 Tap ➤ to send the email.

Contacts

Contacts overview

You can save and manage contacts.

Tap ◯ > **Contacts**.

Adding contacts

Adding new contacts

1 On the contact list screen, tap +.

2 Enter contact details and tap **SAVE**.

Importing contacts

You can import a contact from another storage device.

1 On the contact list screen, tap ⋮ > **More** > **Manage contacts** > **Import**.

2 Select the source and target locations of the contact you want to import, and then tap **OK**.

3 Select a contact and tap **IMPORT**.

Adding contacts to the speed dial list

1 On the contact list screen, tap ⋮ > **Speed dial**.

2 Tap **Add contact** from a speed-dial number.

3 Select a contact.

Searching for contacts

You can search for contacts by using one of the following options:

- On the contact list screen, enter a contact name in the search box.
- Drag the contact list up or down.
- From the index of the contact list screen, tap the initial letter of a contact.

Contacts list

Editing contacts

1 On the contact list screen, select a contact from the contact list.

2 On the contact detail screen, tap ✎ and edit details.

3 Tap **SAVE** to save changes.

Deleting contacts

1 On the contact list screen, tap and hold a contact from the contact list.

2 Tap **Delete contact**.

Adding favourites

You can register frequently used contacts as favourites.

1 On the contact list screen, select a contact from the contact list.

2 On the contact detail screen, tap ☆.

Creating groups

1 On the contact list screen, tap **Groups** > ⋮ > **New group**.

2 Enter a new group name.

3 Tap **Add members**, select contacts, then tap **ADD**.

4 Tap **SAVE** to save the new group.

Calendar

Calendar overview

You can use the calendar to manage events and tasks.

Adding events

1 Tap ◯ > **Calendar**.

2 Select a date and then tap ⊕.

3 Enter event details and tap **SAVE**.

- If you tap a date from the calendar and the date contains events, a pop-up window appears showing a list of the events. Tap an event from the pop-up window to view the event details.

Syncing events

Tap ⋮ > **Calendars to display** > ⋮ > **Calendars to sync**.

- Device events saved under your Google account are synced with the Google calendar. This allows you to manage events from devices other than your device.

Event pocket

You can use the event pocket to create events.

Tap to open the event pocket and then drag content to a date in the calendar.

- : Manage images, text, notes and temporarily saved events. You can also share text, images and notes from another app and save them to the event box. If you tap **POCKET** when creating an event, the event is temporarily saved to the event pocket.
- : Manage tasks that have no deadline, such as events.

Evernote

You can write and collect important information and then share them with other devices that support **Evernote**.

Tap ◯ > **Evernote**.

Cell Broadcast

You can view real-time text broadcasts on emergency situations, such as typhoons, floods and earthquakes.

Tap ◯ > **Cell Broadcast**.

LG Backup

You can back up, restore and move data saved on your device.

1 Tap ◯ > **Management** > **LG Backup**.
Alternatively, tap ◯ > **Settings** > **General** > **Backup & reset** > **LG Backup**.

2 Follow the on-screen instructions to store the data on your device, or share the date to other devices.

- Initialising your device may delete backup files saved in internal storage. To minimise data loss, copy important backup files from the LG Backup folder in the internal storage to a computer or external storage.

- Data in a Google account will not be backed up. When you synchronise your Google account, Google apps, Google contacts, Google calendar, Google memo app data and apps downloaded from Play store are stored on the Drive app automatically.
- Backup files are saved with the file extension *.lbf under the LG Backup folder on the SD card or internal storage.
- Fully charge the battery before backing up or restoring data to avoid unintentional powering off during the process.

Recently uninstalled apps

You can view and reinstalled apps that have been uninstalled in the past 24 hours.

1 Tap ◯ > **Recently uninstalled apps**.
Alternatively, tap ◯ > tap and hold on an empty space, then select an **Uninstalled apps**.

2 Tap 🗑 or **Reinstall** the apps you want reinstalled.

Google apps

You can use Google apps by setting a Google account. The Google account registration window appears automatically when you use a Google app for the first time. If you do not have a Google account, create one from your device. For details on how to use an app, see the Help in the app.



- Some apps may not work, depending on the area and service provider.

Drive

Upload, save, open, share and organise files from your device. Files accessible from apps can be accessed from anywhere, including online and offline environments.

Docs

Create documents or edit documents created online or from another device. Share and edit documents together with others.

Voice Search

Search information on Google by saying a keyword, instead of typing a keyword.

Maps

Find your location or the location of a place on the map. View geographical information.

Photos

View or share photos or albums saved on your device.

Slides

Create presentation material or edit presentation material created online or from another device. Share and edit presentation material together with others.

Hangouts

Exchange messages. Make a video call with an individual or a group.

Chrome

Sign in to Chrome and import opened tabs, bookmarks and address bar data from a computer to your device.

Gmail

Register your Google email account to your device to check or send email.

Sheets

Create spreadsheets or edit spreadsheets created online or from another device. Share and edit spreadsheets together with others.

Play Movies & TV

Use your Google account to rent or purchase movies. Purchase content and play it anywhere.

YouTube

Search and play videos. Upload videos on YouTube to share them with people around the world.

Play Music

Purchase music files from **Play Store**. Play music files saved on your device.

04

Phone Settings

Settings

You can customise your device settings.

Tap ◯ > **Settings**.

- Tap 🔍 and enter a keyword in the search box to access a setting item.
- Tap ⋮ to change the view mode. This user guide assumes that you are using the **Tab view**.

Networks

Wi-Fi

You can connect to nearby devices over a Wi-Fi network.

Connecting to a Wi-Fi network

1 On the settings screen, tap **Networks** > **Wi-Fi**.

2 Swipe  to activate it.
- Available Wi-Fi networks appear automatically.

3 Select a network.
- You may need to enter the network's Wi-Fi password.
- The device skips this process for previously accessed Wi-Fi networks. If you do not want to automatically connect to a certain Wi-Fi network, tap and hold the network and then tap **Forget network**.

Wi-Fi network settings

On the settings screen, tap **Networks** > **Wi-Fi**.

- **Switch to mobile data**: If a Wi-Fi network is disconnected when mobile data is set to on, mobile data automatically takes the place of the Wi-Fi connection. Using mobile data may incur data charges.
- ⋮: Customise Wi-Fi network settings.

Wi-Fi Direct

You can connect your device to other devices that support Wi-Fi Direct to share data directly with them. You do not need an access point. You can connect with more than two devices by using Wi-Fi Direct.

1 On the settings screen, tap **Networks** > **Wi-Fi** > ⋮ > **Advanced Wi-Fi** > **Wi-Fi Direct**.
   - Nearby devices that support Wi-Fi Direct automatically appear.

2 Select a device.
   - Connection occurs when the device accepts the connection request.

- The battery may drain faster when using Wi-Fi Direct.

Bluetooth

You can connect your device to nearby devices that support Bluetooth to exchange data with them. Connect your device to a Bluetooth headset and a keyboard. This makes it easier to control the device.

Pairing with another device

1 On the settings screen, tap **Networks** > **Bluetooth**.

2 Swipe to activate it.

- Available devices appear automatically.
- To refresh the device list, tap **SEARCH**.

- Only devices with the searching option enabled are displayed on the list.

3 Select a device from the list.

4 Follow the on-screen instructions to perform authentication.

- This step is skipped for previously accessed devices.

Sending data via Bluetooth

1 Select a file.

- You can send multimedia files or contacts.

2 Tap > **Bluetooth**.

3 Select a target device for the file.

- The file is sent as soon as the target device accepts it.

- File sharing processes may differ, depending on the file.

Mobile data

You can turn on or off mobile data. You can also manage mobile data usage.

Turning on mobile data

1 On the settings screen, tap **Networks** > **Mobile data**.

2 Swipe to activate it.

Customising mobile data settings

1 On the settings screen, tap **Networks** > **Mobile data**.

2 Customise settings:

- **Mobile data**: Set to use data connections on mobile networks.
- **Limit mobile data usage**: Set a limit for mobile data usage to block mobile data if the limit is reached.
- ⋮ : Customise mobile data settings.

Call

You can customise call settings, such as voice call and international call options.

- Some features may not be supported, depending on the device manufacturer or service provider.

1 On the settings screen, tap **Networks** > **Call**.

2 Customise settings:

- **Voicemail**: Change the number of voicemail messages and notification settings.
- **Decline and reject calls** > **Decline with message**: Set a text message to send when rejecting calls. Manage rejection messages.

- **Decline and reject calls** > **Reject calls from**: Block incoming calls from particular numbers, or manage blocked numbers.
- **Decline and reject calls** > **Private numbers**: Block incoming calls from unidentified numbers.
- **Answer and end calls** > **End calls with the Power key**: End a call when the Power/Lock key is pressed.
- **Answer and end calls** > **Auto answer**: Set to automatically answer a call after a certain length of time when connected to a hands-free device.
- **More** > **Incoming voice call pop-up**: Set to display pop-up window for an incoming call while using an app.
- **More** > **Connection vibration**: Set the device to vibrate when the other party answers your call.
- **More** > **Gestures**: Use a gesture to reject calls. Mute the incoming call ringtone.
- **More** > **Fixed dialing numbers**: Restrict outgoing calls only to numbers with specified prefixes.
- **More** > **Save unknown numbers**: Add and save a new phone number to contacts after a call.
- **More** > **Call forwarding**: Set when to forward calls.
- **More** > **Call barring**: Restrict incoming or outgoing calls or international calls.
- **More** > **Call duration**: View call time details.
- **More** > **Additional settings**: Customise additional call settings.

File sharing

You can send and receive files between your device and other LG devices or tablets.



- See *Sending or receiving files* for details.

1 On the settings screen, tap **Networks** > **Share & connect** > **File sharing**.

2 Customise settings:

- **LG Stylus2**: Change the device name.
- **Save to**: Set the destination folder to save files sent from other devices.
- **File Sharing**: Permit receipt of files sent from other devices.
- **SmartShare Beam**: Share files with other devices via SmartShare Beam.

Media server

You can share media content on your device with nearby devices that support DLNA.

1 On the settings screen, tap **Networks** > **Share & connect** > **Media server**.

2 Perform actions:

- **Content sharing**: Share content on your device with nearby devices.
- **LG Stylus2**: Set your device's name.
- **Content to share**: Select the type of media content to share with other devices.
- **Allowed devices**: View a list of devices permitted to access content on your device.
- **Not-allowed devices**: View a list of devices not permitted to access content on your device.

LG AirDrive

You can use your LG account from a computer to manage files saved on the device. You do not need a USB connection.

1 On the settings screen, tap **Networks** > **Share & connect** > **LG AirDrive**.

2 Use a single LG account to sign in to LG Bridge on the computer and **LG AirDrive** on the device.
- LG Bridge software can be downloaded from *www.lg-mobile.co.il*.

3 Manage files on the device from the computer.

Printing

You can print the content of certain screens (such as web pages displayed in Chrome) to a printer connected to the same Wi-Fi network as your Android device.

USB tethering

You can connect the device to another device via USB and share mobile data.

1 On the settings screen, tap **Networks** > **Tethering** > **USB tethering** and then swipe to activate it.

2 Connect your device and other devices via USB cable.

- This option uses mobile data and may incur data usage fees, depending on your pricing plan.
- When you connect to your computer, download the USB driver from *www.lg-mobile.co.il to the computer*.
- You cannot send of receive files between your device and a computer while USB tethering is turned on. Turn off USB tethering to share files.
- Operating systems that support tethering are Window XP or higher, or Linux.

Wi-Fi hotspot

You can set the device as a wireless router so that other devices can connect to the internet by using your device's mobile data.

1 On the settings screen, tap **Networks** > **Tethering** > **Wi-Fi hotspot** and then swipe to activate it.

2 Enter Wi-Fi ID(SSID) and password.

3 Turn on Wi-Fi on the other device, and select the name of the device network on the Wi-Fi list.

4 Enter the network password.

- This option uses mobile data and may incur data usage fees, depending on your pricing plan.
- More informartion is available at this web site: *http://www.android.com/tether#wifi*

Bluetooth tethering

A bluetooth-connected device can connect to the internet by using your device's mobile data.

1 On the settings screen, tap **Networks** > **Tethering** > **Bluetooth tethering** and then swipe to activate it.

2 Turn on Bluetooth on both devices, and pair them.

- This option uses mobile data and may incur data usage fees, depending on your pricing plan.
- More informartion is available at this web site: *http://www.android.com/tether#Bluetooth_tethering*

Airplane mode

You can turn off the call and mobile data functions. When this mode is on, functions that do not involve data, such as games and music playback, remain available.

1 On the settings screen, tap **Networks** > **More** > **Airplane mode**.

2 Swipe to activate it.

3 Tap **TURN ON** in the confirmation screen.

Mobile networks

You can customise mobile data settings.

1 On the settings screen, tap **Networks** > **More** > **Mobile networks**.

2 Customise settings:

- **Mobile data**: Turn mobile data on or off.
- **Data roaming**: Browse the web, use emails, multimedia messages and other data services overseas.
- **Network mode**: Select a network type.
- **Access point names**: View or change the access point for using mobile data services. To change the access point, select a choice from the access point list.
- **Network operators**: Search for network operators and connect automatically to a network.

VPN

You can connect to a safe virtual network, such as an IntraNet. You can also manage connected virtual private networks.

Adding VPN

1 On the settings screen, tap **Networks** > **More** > **VPN**.

- If the screen is not locked, a notification screen appears. Tap **SETTINGS** from the notification screen and lock the screen. See *Configuring lock screen settings* for details.

2 Tap **Add VPN network**.

3 Enter VPN details and tap **SAVE**.

Configuring VPN settings

1 Tap a VPN from the **VPNS** list.

2 Enter the VPN user account details and tap **CONNECT**.

- To save the account details, select the **Save account information** checkbox.

Sound & notification

You can customise sound, vibrate and notification settings.

On the settings screen, tap **Sound & notification** and customise settings:

- **Sound profile**: Set the device to sound, mute or vibrate mode.
- **Volume**: Adjust the sound volume.
- **Ringtone**: Select a ringtone for incoming calls. Add or delete ringtones.
- **Ringtone ID**: Set the device to automatically create a ringtone for an incoming call from a particular contact. See *Ringtone ID* for details.
- **Sound with vibration**: Set the device to vibrate and play a ringtone simultaneously.
- **Vibration type**: Select or create a vibration pattern.
- **Do not disturb**: Set the time, range and app type to receive notification messages. Receive notification messages only on particular days of the week. See *Do not disturb* for details.
- **Lock screen**: Display or hide a notification message on the lock screen.
- **Apps**: Select an app to show notification messages, and set the priority for the notifications.
- **Notification LED**: Indicate device status via LED.
- **More** > **Notification sound**: Select a notification ringtone. Set music saved on the device as a notification ringtone.
- **More** > **Vibrate on tap**: Set the device to vibrate when you tap certain items on screen.
- **More** > **Sound effects**: Select a sound effect to play when you tap the dial pad, select an option, or lock or unlock the screen.
- **More** > **Message/call voice notifications**: Set the device to read the content of calls or messages via voice.

Display

You can customise detailed settings for each screen type.

On the settings screen, tap **Display** and customise settings:

- **Home screen**: Customise settings for the Home screen. See *Home screen* for details.
- **Lock screen**: Customise lock screen settings. See *Screen lock* for details.
- **Home touch buttons**: Rearrange Home touch buttons or change their background colours. Hide Home touch buttons on the screen.
- **Font type**: Change the font face.
- **Font size**: Change the font size.
- **Bold text**: Bold the text on the screen.
- **Brightness**: Use the slide bar to change the device's screen brightness. To automatically adjust screen brightness according to ambient light intensity, swipe the automatic brightness switch.
- **Reader mode**: Reduce amount of blue light on screen to reduce eye strain.
- **Auto-rotate screen**: Automatically rotate the screen according to the device's orientation.
- **Screen timeout**: Automatically turn off the screen when the device is left idle for a specified period of time.
- **More** > **Daydream**: Display a screen saver when the device is connected to the holder or charging. Select a screen saver type to display.
- **More** > **Motion sensor calibration**: Correct the angle and speed of the motion sensor to improve the tilt accuracy and speed of the sensor.



- When correcting the motion sensor, make sure to place the device on a flat surface. Failure to do so may cause motion sensor related errors, such as automatic screen rotation.

General

Language & keyboard

You can customise language and keyboard settings for your device.

1 On the settings screen, tap **General** > **Language & keyboard**.

2 Customise settings:

- **Language**: Set the display language for the device.
- **Current keyboard**: View the keyboard type currently in use. Select a keyboard to use when entering text. You can also set a keyboard you have added as active keyboard.
- **LG Keyboard**: Customise LG keyboard settings. This option is available when an LG keyboard is selected as the active keyboard.
- **Google voice typing**: Turn on dictation. This converts voice to text.
- **Text-to-speech output**: Turn on TTS mode, which reads text via voice.
- **Pointer speed**: Adjust the pointer speed of a mouse or trackpad.
- **Reverse buttons**: Let the right mouse button perform primary direct-manipulation actions.

Location

You can customise settings to access your location information from a particular app.

1 On the settings screen, tap **General** > **Location**.

2 Customise settings:

- **Mode**: Select a method to provide your location information.
- **RECENT LOCATION REQUEST**: View apps that recently requested location information.
- **Camera**: Save location information when taking photos or videos.
- **Google Location History**: Permit Google services to collect your location information.

Accounts & sync

You can add or manage accounts, including a Google account. You can also sync particular apps or user information automatically.

1 On the settings screen, tap **General** > **Accounts & sync**.

2 Customise settings:

- **Auto-sync data**: Sync all the registered accounts automatically.
- **ACCOUNTS**: View a list of registered accounts. To view or change details of an account, tap the account.
- **ADD ACCOUNT**: Add accounts.

Accessibility

You can manage accessibility plug-ins installed on your device.

1 On the settings screen tap **General** > **Accessibility**.

2 Customise settings:

- **Vision** > **TalkBack**: Set the device to notify screen status or actions via voice.
- **Vision** > **Message/call voice notifications**: Set the device to read the call or message content via voice.
- **Vision** > **Font size**: Change the font size.
- **Vision** > **Bold text**: Bold the text on the screen.
- **Vision** > **Touch zoom**: Zoom in or out by tapping the screen three times.
- **Vision** > **Screen colour inversion**: Increase the display colour contrast for people with poor eyesight.
- **Vision** > **Screen colour adjustment**: Adjust the display colour.
- **Vision** > **Grayscale**: Switch the screen to greyscale mode.
- **Vision** > **End calls with the Power key**: End a call by pressing the Power/Lock key.
- **Hearing** > **Captions**: Turn on the subtitle service when playing videos for the hearing impaired.
- **Hearing** > **Notification LED**: Indicate device status via LED.
- **Hearing** > **Flash alerts**: Set the device to notify with a blinking light for incoming calls and notifications.
- **Hearing** > **Turn off all sounds**: Turn off all sounds and lower volume on receiver.
- **Hearing** > **Audio type**: Select the audio type.
- **Hearing** > **Sound balance**: Adjust the audio output balance. Use the slide bar to change the balance.
- **Motor & cognition** > **Touch assistant**: Turn on the touch board to make buttons and gestures easier to use.

- **Motor & cognition** > **Touch and hold delay**: Adjust the touch input time.
- **Motor & cognition** > **Touch and hold for calls**: Answer or decline calls by tapping and holding the call button instead of dragging it.
- **Motor & cognition** > **Screen timeout**: Turn off the screen automatically when the device is left idle for a specified period of time.
- **Motor & cognition** > **Touch control areas**: Limit the touch area so that only a particular portion of the screen can be controlled by touch input.
- **Accessibility features shortcut**: Quickly access a frequently used function by tapping ◯ three times.
- **Auto-rotate screen**: Automatically switch the screen orientation according to the device.
- **Switch Access**: Create key combinations to control your device.

Mini view

Turn on this menu to shrink the screen for use with one hand by swiping left or right across the Home touch buttons. See *Mini view* for details.

On the settings screen, tap **General** > **Mini view**.

Shortcut key

You can use the volume keys to directly launch apps when the screen is turned off or locked.

1 On the settings screen, tap **General** > **Shortcut key**.

2 Swipe ◯ to activate it.
- Press the volume down (-) key twice to launch the **Camera** app when the screen is locked or turned off. Press the volume up (+) key twice to launch **Capture+**.

Google services

You can use Google Settings to manage your Google apps and account settings.

On the settings screen, tap **General** > **Google services**.

Security

1 On the settings screen, tap **General** > **Security**.

2 Customise settings:

- **Content lock**: Set the method to lock files in **QuickMemo+**.
- **Encrypt phone**: Set the device password for privacy. Create a PIN or password to enter each time the device is turned on. See *Encrypting your device* for details.
- **Encrypt SD card storage**: Encrypt the SD card to prevent use on another device. See *SD card encryption* for details.
- **Set up SIM card lock**: Lock or unlock the USIM card, or change the password (PIN).
- **Password typing visible**: Display a password as you enter it.
- **Phone administrators**: Allow privileges to restrict the control or use of the device to particular apps.
- **Unknown sources**: Allow the installation of apps from non-Play Store apps.
- **Verify apps**: Block the installation of harmful apps. Display a warning message when a harmful app is installed.
- **Storage type**: View the storage type where the security certificate will be saved.
- **Certificate management**: Manage the security certificate saved on the device.
- **Trust agents**: View and use trust agents installed on the device.
- **Screen pin**: Fix the app screen so that only the currently active app can be used.
- **Usage access for apps**: View details on usage of apps on the device.

Quick Cover View

With Quick Cover case, you can check incoming calls and stop the alarm/timer when the cover is closed. To unlock with the cover, the screen lock must be set to Swipe.

On the settings screen, tap **General** > **Quick Cover View**.

Pen

Use the Pen settings to configure option when the pen is removed. See *Pen Pop* for details.

On the settings screen, tap **General** > **Pen**.

- **Open when removed**: Select a feature that will automatically start when the pen is removed from the device.
- **App shortcut**: Set frequently used apps.
- **Screen-off Memo**: Create notes on the turned-off screen when the pen is removed.
- **Pen detection**: Be notified by sound or vibration when the pen is removed or inserted.
- **Pen Keeper**: Be notified by sound or visual notification when the device is moved with the pen removed.

Dual window

Allows you to configure the Dual Window feature. See *Dual window* for details.

On the settings screen, tap **General** > **Dual window**.

- **Auto-open**: Checkmark to allow you to tap a link on the full screen or attachments from emails to open Dual window.
- **Help**: Display tips for using Dual window.

Date & time

You can customise date and time settings for your device.

1 On the settings screen, tap **General** > **Date & time**.

2 Customise settings.

Storage & USB

You can view and manage internal storage on the device or storage space of the SD card.

1 On the settings screen, tap **General** > **Storage & USB**.

2 Customise settings:

- **Internal storage**: View the total storage space and free space in the device's internal storage. View a list of apps in use and the storage capacity for each app.
- **PORTABLE STORAGE**: View the total storage space and free space in the SD card. This option appears only when a SD card is inserted. To unmount the SD card, tap ⏏.

Battery & power saving

You can view the current battery information or turn on power-saving mode.

1 On the settings screen, Tap **General** > **Battery & power saving**.

2 Customise settings:

- **Battery usage**: View the battery usage details. To view more details, select a specific item.
- **Battery percentage on status bar**: Display the remaining battery level as a percentage on the status bar.
- **Battery saver**: Reduce battery consumption by cutting down some device settings, such as the display brightness, speed and vibration intensity. The status bar displays when power-saving mode is on.

Memory

You can view the average amount of memory usage over a certain period of time and the memory occupied by an app.

1 On the settings screen, tap **General** > **Memory**.

2 Tap ▼ to set a time slot to retrieve data.

Apps

You can view a list of installed apps. Shut down or delete apps, if necessary.

1 On the settings screen, tap **General** > **Apps**.

2 Select an app and perform actions.

Backup & reset

You can back up data saved on your device to another device or account. Reset the device, if necessary.

1 On the settings screen, tap **General** > **Backup & reset**.

2 Customise settings:

- **LG Backup**: Back up and restore all data saved on the device. See *LG Backup* for details.
- **Back up my data**: Back up your app data, Wi-Fi password and other settings to the Google server.
- **Backup account**: View the current backup account in use.
- **Automatic restore**: Automatically restore backup settings and data when reinstalling an app.
- **Network settings reset**: Reset Wi-Fi, Bluetooth and other network settings.
- **Factory data reset**: Reset all settings for the device and delete data.

- Resetting your device deletes all data on it. Enter your device name, Google account and other initial information again.

About phone

You can view information about your device, such as the name, status, software details and legal information.

On the settings screen, tap **General** > **About phone** and view information.

05

Appendix

Phone software update

LG Mobile phone software update from the Internet

For more information about using this function, please visit *http://www.lg.com/common/index.jsp*, select your country and language.

This feature allows you to conveniently update the firmware on your phone to a newer version from the Internet without needing to visit a service centre. This feature will only be available if and when LG makes a newer firmware version available for your device.

Because the mobile phone firmware update requires the user's full attention for the duration of the update process, please make sure you check all instructions and notes that appear at each step before proceeding. Please note that removing the USB cable during the upgrade may seriously damage your mobile phone.

- LG reserves the right to make firmware updates available only for selected models at its own discretion and does not guarantee the availability of the newer version of the firmware for all handset models.

LG Mobile Phone software update via Over-the-Air (OTA)

This feature allows you to conveniently update your phone's software to a newer version via OTA, without connecting using a USB cable. This feature will only be available if and when LG makes a newer firmware version available for your device.

First check the software version on your mobile phone:

Settings > **General** > **About phone** > **Update Center** > **Software Update** > **Check now for update**.

- Your personal data from internal phone storage—including information about your Google account and any other accounts, your system/application data and settings, any downloaded applications and your DRM licence—might be lost in the process of updating your phone's software. Therefore, LG recommends that you backup your personal data before updating your phone's software. LG does not take responsibility for any loss of personal data.
- This feature depends on your network service provider, region and country.

FAQ

This chapter lists some problems you might encounter when using your phone. Some problems require you to call your service provider, but most are easy to fix yourself.

Message	Possible causes	Possible corrective measures
SIM card error	There is no SIM card in the phone or it is inserted incorrectly.	Make sure the SIM card is correctly inserted.
No network connection/ Dropped network	Signal is weak or you are outside the carrier network.	Move toward a window or into an open area. Check the network operator coverage map.
	Operator applied new services.	Check whether the SIM card is more than 6~12 months old. If so, change your SIM or USIM card at your network provider's nearest branch. Contact your service provider.
Codes do not match	To change a security code, confirm the new code by re-entering it.	If you forget the code, contact your service provider.
	The two codes you entered do not match	
No applications can be set	Not supported by service provider or registration required.	Contact your service provider.
Downloaded application causes a lot of errors.	Remove the application.	1. Tap ◯ > **Settings**. 2. Tap the **General** > **Apps**. 3. Tap the app > **Uninstall**.

Message	Possible causes	Possible corrective measures
Calls not available	Dialling error	New network not authorised.
	New SIM card inserted.	Check for new restrictions.
	Pre-paid charge limit reached.	Contact service provider or reset limit with PIN2.
Phone cannot be turned on	On/Off key pressed too briefly.	Press the On/Off key for at least two seconds.
	Battery is not charged.	Charge battery. Check the charging indicator on the display.
Charging error	Battery is not charged.	Charge battery.
	Outside temperature is too hot or cold.	Make sure phone is charging at a normal temperature.
	Contact problem	Check the charger and its connection to the phone.
	No voltage	Plug the charger into a different outlet.
	Charger defective	Replace the charger
	Wrong charger	Use only original LG accessories.
Number not allowed.	The Fixed dialling number function is on.	Check the Settings menu and turn the function off.
Impossible to receive/ send SMS & photos	Memory full	Delete some data, such as applications or messages from your phone to make more memory available.

Message	Possible causes	Possible corrective measures
Files do not open	Unsupported file format	Check the supported file formats.
The screen does not turn on when I receive a call.	Proximity sensor problem	If you use a protection tape or case, make sure it has not covered the area around the proximity sensor. Make sure that the area around the proximity sensor is clean
No sound	Vibration mode	Check the settings status in the sound menu to make sure you are not in vibration or no interruptions mode.
Hangs up or freezes	Intermittent software problem	If the screen freezes or the phone does not respond when you try to operate it, remove the battery and reinsert it. Then power the phone back on. Alternatively, try to perform a software update through the website.

Anti-Theft Guide

Set up your device to prevent other people from using it if it's been reset to factory settings without your permission. For example, if your device is lost, stolen, or wiped, only someone with your Google account or screen lock information can use the device.

All you need to make sure your device is protected is:

- Set a screen lock: If your device is lost or stolen but you have a screen lock set, the device can't be erased using the Settings menu unless your screen is unlocked.
- Add your Google account on your device: If your device is wiped but you have your Google account on it, the device can't finish the setup process until your Google account information is entered again.

After your device is protected, you'll need to either unlock your screen or enter your Google account password if you need to do a factory reset. This ensures that you or someone you trust is doing the reset.



- Do not forget your Google account and password you had added to your device prior to performing a factory reset. If you can't provide the account information during the setup process, you won't be able to use the device at all after performing the factory reset.

More information

Open Source Software Notice Information

To obtain the source code under GPL, LGPL, MPL, and other open source licences, that is contained in this product, please visit *http://opensource.lge.com*.

In addition to the source code, all referred license terms, warranty disclaimers and copyright notices are available for download.

LG Electronics will also provide open source code to you on CD-ROM for a charge covering the cost of performing such distribution (such as the cost of media, shipping, and handling) upon email request to *opensource@lge.com*. This offer is valid for three (3) years from the date on which you purchased the product.

Trademarks

- Copyright© 2016 LG Electronics, Inc. All rights reserved. LG and the LG logo are registered trademarks of LG Group and its related entities.
- Google™, Google Maps™, Gmail™, YouTube™, Hangouts™ and Play Store™ are trademarks of Google, Inc.
- Bluetooth® is a registered trademark of Bluetooth SIG, Inc. worldwide.
- Wi-Fi® and the Wi-Fi logo are registered trademarks of the Wi-Fi Alliance.
- All other trademarks and copyrights are the property of theirrespective owners.

Declaration of conformity

Hereby, **LG Electronics** declares that this **LG-K520K** product is in compliance with the essential requirements and other relevant provisions of Directive **1999/5/EC**.

A copy of the Declaration of Conformity can be found at *http://www.lg.com/global/declaration*



CE0168