



USER GUIDE

LG G6⁺

LG-H870DSU

Copyright ©2017 LG Electronics Inc. All rights reserved.

אודות מדריך למשתמש זה

תודה שבחרת מוצר זה של LG. קרא בעיון מדריך למשתמש זה לפני השימוש במכשיר בפעם הראשונה, כדי להבטיח שימוש בטוח והולם.

- השתמש תמיד באביזרים מקוריים של LG. הפריטים שסופקו מיועדים למכשיר זה בלבד וייתכן שהם לא תואמים למכשירים אחרים.
- מכשיר זה אינו מתאים לאנשים לקויי ראייה מפני שהמקלדת שלו נמצאת במסך המגע.
- התיאורים מבוססים על הגדרות ברירת המחדל של המכשיר. יישומי ברירת המחדל במכשיר כפופים לעדכונים, וייתכן שהתמיכה ביישומים אלה תופסק ללא כל הודעה מראש. אם יש לך שאלות כלשהן על יישום שסופק עם המכשיר, פנה למרכז השירות של LG. עבור יישומים שהותקנו על-ידי המשתמש, פנה לספק השירות הרלוונטי.
- שינוי מערכת ההפעלה של המכשיר או התקנת תוכנה ממקורות לא רשמיים עלול לגרום נזק למכשיר ולגרום להרס נתונים או לאובדן נתונים. פעולות אלה יפרו את הסכם הרישיון של LG ויבטלו את האחריות שלך.
- תכנים ואיורים מסוימים עשויים להיראות שונים מאלה שבמכשיר, בהתאם לאזור, לספק השירות, לגרסת התוכנה ולגרסת מערכת ההפעלה, והם כפופים לשינוי ללא הודעה מוקדמת.
- תוכנות, שמע, טפטים, תמונות ופריטי מדיה אחרים שסופקו יחד עם המכשיר שלך מורשים לשימוש מוגבל. אם תחלץ חומר זה ותשתמש בו למטרות מסחריות או אחרות, אתה עלול להפר חוקי זכויות יוצרים. כמשתמש, אתה נושא באחריות מלאה לשימוש לא חוקי במדיה.
- ייתכן שיחולו חיובים נוספים תמורת שירותי נתונים, כגון שליחת הודעות, העלאה, הורדה, סנכרון אוטומטי ושירותי מיקום. כדי למנוע חיובים נוספים, בחר תוכנית נתונים מתאימה לצרכיך. פנה אל ספק השירות לקבלת פרטים נוספים.

הודעות מנחות

אזהרה: מצבים שעלולים לגרום לפציעה של המשתמש ושל גורמי צד שלישי.



זהירות: מצבים שעלולים לגרום לפציעה קלה או לנזק למכשיר.



הערה: הערות או מידע נוסף.



02

פונקציות בסיסיות

רכיבי מוצרים ואביזרים	38
סקירה כללית של החלקים	39
הדלקה או כיבוי	41
התקנת כרטיס ה-SIM	42
הכנסת כרטיס הזיכרון	44
הוצאת כרטיס הזיכרון	45
סוללה	46
מסך המגע	48
מסך ראשי	51
נעילת מסך	59
הצפנת כרטיס זיכרון	63
יצירת צילומי מסך	64
הזנת טקסט	65
שיתוף תוכן	70
נא לא להפריע	73

01

תכונות הניתנות להתאמה אישית

הערות בנושא תכונות של עמידות במים	13
תכונות הקלטת וידאו	15
תכונות גלריה	20
יצירת טפט קולאז'	23
תכונות הקלטת שמע	24
זיהוי טביעת אצבע	27
זיהוי פנים	30
התכונה 'ריבוי משימות'	34
Always-on display	35
שיתוף מהיר	36

04

הגדרות

הגדרות	124
רשתות	124
צליל והתראה	137
תצוגה	138
כללי	139

05

נספח

הגדרות השפה של LG	149
LG Bridge	149
עדכון תוכנת הטלפון	150
מדריך למניעת גניבה	152
פרטי הודעה על תוכנת קוד פתוח	153
מידע בנושאי תקינה (מספר הזיהוי של התקן, תיוג אלקטרוני וכולי)	153
סימנים מסחריים	153
הצהרת תאימות	154
מידע נוסף	154
שאלות נפוצות	156

03

יישומים שימושיים

התקנה והסרת התקנה של יישומים	75
יישום סל המיחזור	76
טלפון	76
הודעות	80
מצלמה	81
גלריה	101
אנשי קשר	106
QuickMemo+	108
שעון	110
לוח שנה	111
משימות	113
נגן מוסיקה	113
מחשבון	114
LG Health	114
דוא"ל	116
רדיו FM	117
מנהל הקבצים	118
LG Mobile Switch	118
LG Friends Manager	118
הורדות	119
LG SmartWorld	119
שירות התראות חירום	120
Instagram	120
פייסבוק	120
Evernote	120
Chrome	120
יישומי Google	121

הנחיות לשימוש בטוח ויעיל

הקפד לקרוא הנחיות פשוטות אלה. אי עמידה בהנחיות אלו עלולה להיות מסוכנת או בלתי חוקית.

למקרה של תקלה, המכשיר שלך מכיל כלי תוכנה שיאסוף יומן תקלות. כלי זה אוסף רק נתונים ספציפיים לתקלה, כגון עוצמת אות, מיקום מזהה התא בעת ניתוק פתאומי של השיחה ויישומים שנטענו. היומן משמש רק לסיוע בזיהוי הגורם לתקלה. יומנים אלה מוצפנים, ורק מרכז תיקונים מוסמך של LG יוכל לגשת אליהם במקרה שתצטרך למסור את המכשיר לתיקון.

חשיפה לאנרגיית תדר רדיו

מידע על חשיפה לגלי רדיו ושיעור ספיגה סגולית (SAR).

מכשיר זה תוכנן לעמוד בדרישות הבטיחות הרלוונטיות לחשיפה לגלי רדיו. דרישות אלו מבוססות על קווים מנחים מדעיים, ואלה כוללים שולי בטיחות המיועדים להבטיח את בטיחותם של כל בני האדם, בלא קשר לגילם או למצב בריאותם.

- הנחיות החשיפה לגלי רדיו משתמשות ביחידת מידה הנקראת "שיעור ספיגה סגולית" (SAR). בדיקות SAR מבוצעות באמצעות שיטות מתוקננות, כאשר המכשיר משדר ברמת העוצמה המרבית המאושרת עבורו בכל תחומי התדרים שבשימוש.
- אף כי עשויים להיות הבדלים בין רמות ה-SAR של דגמי מכשירים שונים של LG, כולם מתוכננים לעמוד בהנחיות המתאימות של חשיפה לגלי רדיו.
- מגבלת ה-SAR המומלצת על-ידי הוועדה הבין-לאומית להגנה מפני קרינה בלתי מייננת (ICNIRP) היא ממוצע של 2 ואט/ק"ג על כל 10 גר' של רקמה.
- ערך ה-SAR הגבוה ביותר עבור דגם זה שנמדד לשימוש באוזן הוא 0.393 ואט/ק"ג (10 גר'), וכאשר הוא נישא על הגוף, ערך זה עומד על 1.120 ואט/ק"ג (10 גר').

- מכשיר זה עומד בהנחיות החשיפה ל-RF כשמשמשים בו בתנוחת השימוש הרגילה ליד האוזן או כשהוא ממוקם לפחות 5 מ"מ מהגוף. כאשר נעשה שימוש בנרתיק נשיאה או בתפס או מנשא לחגורה, אסור שתהיה בהם מתכת כלשהי, והמרחק בין המכשיר לגוף צריך להיות לפחות 5 מ"מ. כדי לשדר קובצי נתונים או הודעות, מכשיר זה מחייב חיבור איכותי לרשת. במקרים מסוימים עלול שידור קבצי נתונים או הודעות להיות מושהה עד שחיבור כזה יהיה זמין. הקפד על שמירת הוראות המרחק המינימלי המוזכרות לעיל עד לסיום השידור.

טיפול במוצר ותחזוקה

- השתמש רק באביזרים הכלולים באריזה, שאושרו על ידי LG. LG אינה מספקת אחריות לכל נזק או כשל שיגרמו כתוצאה משימוש באביזרים של חברות צד שלישי.
- חלק מהתוכן והאיוורים עשויים להיראות שונה מהמכשיר שברשותך, והם כפופים לשינוי ללא הודעה מראש.
- אין לפרק יחידה זו. כאשר נדרש תיקון, פנה לטכנאי שירות מוסמך.
- תיקונים במסגרת האחריות, לפי שיקול דעתה של LG, עשויים לכלול חלקים או לוחות חלופיים, חדשים או מחדשים, ובלבד שהם מצוידים בפונקציונליות זהה לזו של החלקים המוחלפים.
- אין לקרב את המכשיר למכשירים חשמליים כגון טלוויזיות, מכשירי רדיו ומחשבים אישיים.
- יש לשמור את היחידה הרחק ממקורות חום כדוגמת רדיאטורים או תנורי בישול.
- אין להפיל את היחידה.
- אין לאפשר זעזוע מכני או חבטה.
- יש לכבות את המכשיר בכל מקום שבו נדרש הדבר על-ידי תקנות מיוחדות. לדוגמה, אין להשתמש במכשיר בבתי חולים, שכן הפעלתו עלולה להשפיע על פעולת מכשור רפואי רגיש.

- אין לאחוז במכשיר בידיים רטובות בזמן טעינתו. אחיזה במצב כזה עלולה לגרום להתחשמלות ולהסב נזק כבד למכשיר.
- אין לטעון את הטלפון ליד חומר דליק, מכיוון שהמכשיר עלול להתחמם ולעלות באש.
- יש להשתמש במטלית יבשה לניקוי חלקו החיצוני של המכשיר (אין להשתמש בחומרים ממסים כגון בנזן, מדלל או אלכוהול).
- אין לטעון את המכשיר כאשר הוא נמצא על-גבי מצעים או ריפוד.
- יש לטעון את המכשיר באזור מאוורר היטב.
- אין לחשוף יחידה זו לכמות מוגזמת של עשן או אבק.
- אין להחזיק את המכשיר בסמוך לכרטיסי אשראי או כרטיסי נסיעה; הנתונים בפס המגנטי עלולים להיפגם.
- אין להקיש על המסך באמצעות חפצים חדים, שכן הדבר עלול לגרום נזק למכשיר.
- אין לחשוף את המכשיר לנוזלים או ללחות.
- יש לנקוט זהירות בשימוש באביזרים, כמו אוזניות. אין לגעת באנטנה שלא לצורך.
- אם זכוכית המכשיר שבורה או סדוקה, אל תיגע בה או תנסה להסיר אותה ואל תשתמש במכשיר. האחריות אינה מכסה נזקים שנגרמו לתצוגת הזכוכית כתוצאה מפגיעה ושימוש לרעה.
- המכשיר שלך הוא מכשיר אלקטרוני המייצר חום במהלך הפעלה רגילה. בהיעדר אוורור הולם, מגע ישיר וממושך מאוד של העור עלול לגרום לאי-נוחות או לכוויות קלות. לפיכך, יש לנקוט זהירות בהחזקת המכשיר במהלך ההפעלה או מיד אחריה.
- אם המכשיר נרטב, נתק אותו מיד והנח לו להתייבש לגמרי. אל תנסה להאיץ את תהליך הייבוש בעזרת מקור חום חיצוני, כמו תנור, מיקרוגל או מייבש שיער.
- הנוזלים שחדרו למכשיר ישנו את צבע תווית המוצר שבתוך המכשיר. כתב האחריות אינו מכסה נזק למכשיר כתוצאה מחשיפה לנוזלים.

הפעלה יעילה של המכשיר

מכשירים אלקטרוניים

- כל המכשירים עלולים לספוג הפרעות שישפיעו לרעה על ביצועיהם.
- אין להשתמש במכשיר בסמוך לציוד רפואי ללא קבלת רשות. בדוק עם הרופא אם תפעול המכשיר עלול להפריע לתפעולו של ההתקן הרפואי.
- יצרנים של קוצבי לב ממליצים להשאיר רווח של 15 ס"מ בין קוצב הלב לבין התקנים אחרים כדי למנוע הפרעה אפשרית לקוצב הלב.
- התקן זה עשוי להפיק אור חזק או מהבהב.
- מכשירים עלולים להפריע לעזרי שמיעה מסוימים.
- הפרעה משנית עלולה להשפיע על מכשירי טלוויזיה, מכשירי רדיו, מחשבים וכולי.
- השתמש במכשיר שלך בטמפרטורות שבין 0°C ו- 40°C , אם ניתן. חשיפת המכשיר לטמפרטורות נמוכות או גבוהות באופן קיצוני עלולה לגרום נזק, תקלות ואפילו פיצוץ.

בטיחות בדרכים

- בדוק את החוקים והתקנות לגבי שימוש במכשירים באזורים שבהם אתה נהג.
- אין להחזיק את המכשיר ביד בזמן נהיגה.
- יש להפנות את מלוא תשומת הלב לנהיגה.
- רד לשול הדרך וחנה לפני ביצוע שיחה או מענה לשיחה, בהתאם לתנאי הדרך.
- אנרגיית תדר רדיו עשויה להשפיע על מערכות אלקטרוניות מסוימות בכלי רכב, כדוגמת מערכות סטריאו וציוד בטיחות.
- אם המכונה מצוידת בכרית אוויר מתנפחת, אין לחסום אותה על-ידי התקנה של ציוד אלחוטי נישא. הדבר עלול לגרום לכשל של הכרית או לפגיעה חמורה עקב ביצועים לא נאותים שלה.
- אם אתה מאזין למוסיקה בעת תנועה, ודא שהעוצמה היא ברמה סבירה, כך שתמשיך להיות מודע לסביבתך. הדבר חשוב במיוחד בקרבת כבישים.

מנעו נזק לשמיעתכם

כדי למנוע נזק אפשרי לשמיעה, אל תאזין בעוצמות קול גבוהות לאורך זמן.



חשיפה לעוצמות קול גבוהות במשך פרקי זמן ארוכים עלולה להזיק לשמיעה. לכן אנו ממליצים שלא תדליק או תכבה את המכשיר סמוך לאוזנך. מומלץ גם להגדיר את עוצמת הקול של המוסיקה והשיחה לרמה סבירה.

- כאשר אתה משתמש באוזניות, הנמך את עוצמת הקול אם אינך מצליח לשמוע את האנשים שבסביבתך מדברים, או אם האדם שלצדך יכול לשמוע את מה שאתה שומע באוזניות.

• עוצמת קול מופרזת מאוזניות פנימיות ואוזניות חיצוניות עלולה לגרום לאובדן שמיעה.



חלקי זכוכית

חלקים מסוימים של המכשיר עשויים מזכוכית. זכוכית זו עלולה להישבר אם המכשיר ייפול על משטח קשה או יקבל מכה חזקה. אם הזכוכית נשברת, אל תנסה לגעת בה או להסיר אותה. יש להפסיק להשתמש במכשיר עד להחלפת הזכוכית על-ידי ספק שירות מורשה.

סביבה שבה מבוצעות עבודות עם חומרי נפץ

אל תשתמש במכשיר באזורים שבהם מתבצעות פעולות פיצוץ. שים לב להגבלות ועמוד בכל התקנות או הכללים.

סביבה שבה קיימת סבירות לפיצוץ

- אין להשתמש במכשיר באזורי תדלוק.
- אין להשתמש בו בסמוך לדלק או לכימיקלים.
- אין להוביל או לאחסן גז דליק, נוזלים דליקים או חומרי נפץ בתא הרכב המכיל את המכשיר או את אביזריו.

כלי טיס

- התקנים אלחוטיים עלולים לגרום להפרעה במטוס.
- יש לכבות את המכשיר לפני העלייה למטוס.
- אין להשתמש בו על הקרקע ללא קבלת רשות מאנשי הצוות.

ילדים

- יש לשמור על המכשיר במקום בטוח, מחוץ להישג ידם של ילדים קטנים. המכשיר כולל חלקים זעירים העלולים להוות סכנת חנק אם ינותקו מהטלפון.

שיחות חירום

- רק רשתות סלולריות מסוימות מאפשרות לבצע שיחות חירום. לפיכך, בשום מקרה אין לסמוך רק על המכשיר לביצוע שיחות חירום. בדוק את הנושא עם חברת הסלולר המקומית.

מידע לגבי הסוללה והטיפול בה

- אין צורך לפרוק את הסוללה במלואה לפני טעינתה מחדש. בניגוד למערכות סוללה אחרות, אין השפעת זיכרון שעלולה להשפיע על ביצועי הסוללה.
- יש להשתמש אך ורק בסוללות ובמטענים של LG. מטעני LG מיועדים למרב את חיי הסוללה.
- אין לפרק או לקצר את הסוללה.
- יש לשמור על ניקיון מגעי המתכת של הסוללה.
- יש להחליף את הסוללה כאשר היא אינה מפיקה עוד רמת ביצועים סבירה. ניתן לטעון מחדש את מארז הסוללה מאות פעמים לפני שיהיה צורך להחליפו.
- כדי למרב את שמישות הסוללה, טענו אותה מחדש אם לא הייתה בשימוש במשך זמן רב.
- אין לחשוף את מטען הסוללה לאור שמש ישיר או להשתמש בו בתנאי לחות גבוהה, כמו חדר אמבטיה.
- אין להשאיר את הסוללה במקומות חמים או קרים, שכן הדבר עלול לפגום בביצועיה.
- סכנת התפוצצות אם הסוללה הוחלפה בסוג סוללה שאינו מתאים. השלך סוללות משומשות בהתאם להוראות.

- אם עליך להחליף סוללה, קח אותה למרכז השירות המורשה הקרוב של LG Electronics או לספק לצורך קבלת סיוע.
- יש לנתק תמיד את המטען מהשקע לאחר שהמכשיר נטען במלואו כדי למנוע בזבז מיותר של חשמל מצד המטען.
- אורך חיי הסוללה בפועל תלוי בתצורת הרשת, בהגדרות המוצר, באופי השימוש, בתנאי הסוללה ובתנאים הסביבתיים.
- הקפד שלא ייווצר מגע בין הסוללה לבין פריטים חדים כגון שיניים או ציפורניים של בעל חיים. מגע כזה עלול לגרום לשריפה.

אבטחת הפרטים האישיים

- הקפד להגן על הפרטים האישיים שלך כדי למנוע דליפת נתונים או שימוש לרעה במידע רגיש.
- הקפד תמיד לגבות נתונים חשובים בזמן השימוש במכשיר. LG אינה נושאת באחריות לאובדן נתונים כלשהו.
- בעת השלכת המכשיר, הקפד לגבות את כל הנתונים ולאפס אותו כדי למנוע שימוש לרעה במידע רגיש.
- קרא בעיון את מסך ההרשאות במהלך הורדת יישומים.
- נקוט משנה זהירות כאשר אתה משתמש ביישומים שיש להם גישה לפונקציות מרובות או לפרטים האישיים שלך.
- בדוק באופן סדיר את החשבונות האישיים שלך. אם תגלה סימן כלשהו לשימוש לרעה בפרטים האישיים שלך, בקש מספק השירות למחוק או לשנות את פרטי החשבון שלך.
- אם המכשיר שלך אבד או נגנב, שנה את הסיסמה של החשבון כדי לאבטח את הפרטים האישיים שלך.
- אין להשתמש ביישומים שמקורם אינו ידוע.

הודעה לגבי החלפת סוללה



- למען בטיחותך, אל תסיר את הסוללה המשולבת במוצר. אם עליך להחליף סוללה, קח אותה לנקודת השירות הקרובה של LG Electronics או למפיץ לצורך קבלת עזרה.
- סוללת ליתיום-יון הינה רכיב מסוכן, העלול לגרום לפציעה.
- החלפת הסוללה על-ידי אדם שאינו מוסמך לכך עלולה לגרום נזק להתקן.



01

**תכונות הניתנות
להתאמה אישית**

הערות בנושא תכונות של עמידות במים


מוצר זה עמיד במים וחסין לאבק, בהתאם לדירוג Ingress Protection IP68.

המוצר שרכשת עבר בדיקות בסביבה מבוקרת שהוכיחו שהוא עמיד לחדירת אבק ומים בנסיבות מסוימות (עומד בדרישות לקבלת סיווג IP68 כפי שהן מפורטות בתקן הבינלאומי IEC 60529 - Degrees of Protection provided by Enclosures [IP Code], התנאים שבהם בוצעה הבדיקה: 15-35°C, 106kPa-86, עומק של כ-1.5 מטר למשך 30 דקות). אין לחשוף את המכשיר לתנאים שונים מתנאי הבדיקה. התוצאות עשויות להשתנות במהלך שימוש בפועל.

אזהרה

בתנאים שונים מתנאי הבדיקה שנערכה על ידי LGE לעמידה בתקן IP68 (המתוארים במדריך ההפעלה הזה), צבעו של המחווון לזיהוי נזק שנגרם ממגע עם נוזלים ישתנה. לתשומת לבך, נזקים שנגרמים מסיבות אלה מבטלים את זכאותך לשירותי תיקון חינם הניתנים במסגרת האחריות.

יש להימנע מחשיפת המוצר לסביבה שבה קיימים אבק או לחות במידה מוגזמת. אין להשתמש במוצר בסביבות הבאות.


אין לטבול את המוצר בנוזלים כימיקליים כלשהם (סבון, וכו') מלבד מים. 

אין לטבול את המוצר במי מלח, לרבות מי ים. 

אין לטבול את המוצר במעיינות מים חמים. 


אין לשחות עם המוצר. 

אין להניח את המוצר ישירות על חול (לדוגמה, בחוף ים) או על בוץ. 

אין להכניס את המוצר למים בעומק של יותר מ-1.5 מטרים לערך. 

אין להשאיר את המוצר טבול במים למשך יותר מ-30 דקות.





- אם המוצר נרטב, הקפד לנגב את המיקרופון, את הרמקול ואת שקע הסטריאו במטלית יבשה לפני השימוש.
- אם המוצר נרטב או שהרטבת את הידיים, הקפד לנגב את הידיים או את המוצר לפני שאתה משתמש בו.
- אין להשתמש במוצר במקומות שבהם עלולים להתיז עליו מים בלחץ גבוה (לדוגמה, בקרבת ברז או ראש מקלחת) ואין לטבול אותו במים לפרקי זמן ארוכים, מכיוון שהוא אינו מיועד לעמידה בלחץ מים גבוה.
- מוצר זה אינו עמיד לזעזועים. אין להפיל את המוצר או לגרום לו זעזועים. הדבר עלול לגרום לנזק או לעיוות היחידה המרכזית, וייתכן שבעקבות זאת תתאפשר חדירה של מים.
- תכונות העמידות של המוצר לחדירת מים או אבק עשויות להיפגע אם המוצר ייפול או יקבל מכה.
- אם המוצר נרטב, יש לייבש אותו ביסודיות באמצעות בד רך ונקי.
- אם תשתמש במוצר כשהוא רטוב, ייתכן שמסך המגע ותכונות אחרות לא יפעלו כהלכה.
- המוצר שרכשת עמיד לחדירת מים רק כשהמגש של כרטיס ה-SIM/כרטיס הזיכרון סגור כהלכה במקומו בתוך המוצר.
- אין לפתוח או לסגור את המגש של כרטיס ה-SIM/כרטיס הזיכרון כשהמוצר רטוב או שקוע במים. חשיפה של מגש פתוח לרטיבות או ללחות עשויה לגרום נזק למוצר.
- מגש כרטיס ה-SIM/זיכרון מוקף בגומי [אריזה] כדי לסייע במניעה של חדירת אבק, מים או לחות למוצר. אין לפגום במסגרת הגומי [אריזה], שכן הדבר עשוי לאפשר חדירה של אבק, מים או לחות למוצר ולגרום לו נזק.

• אם לא תפעל על פי ההוראות המפורטות, ייתכן שהדבר יגרום לכך שהאחריות המוגבלת על המוצר תבוטל. 

תכונות הקלטת וידאו


מצלמה בזווית רחבה

באפשרותך לצלם תמונות או להקליט סרטונים עם טווח רחב יותר משדה הראייה שלך בפועל על-ידי שימוש בזווית הרחבה שבמצלמה הקדמית והאחורית.


הפעל את היישום 'מצלמה', ולאחר מכן הקש על  /  או על  /  כדי להחליף בין הזווית הרגילה והרחבה.

מצלמה קדמית

סמל זווית רחבה



סמל זווית רגילה



מצלמה אחורית

סמל זווית רחבה





סמל זווית רגילה



• לפרטים, ראה [התחלת המצלמה](#).




מצב מרובע


תוכל לצלם מספר רב של תמונות או סרטונים במתכונת של קולאז' על ידי שימוש במצלמה הקדמית ובמצלמה האחורית. ניתן לשמור תמונות וסרטוני וידאו בפריסות שונות.

- 1 הפעל את היישום 'מצלמה', ולאחר מכן הקש על **בסיסי (A) < מרובע (O)**.
- 2 הקש על **מצב** ובחר את מצב המצלמה הרצוי.
- 3 כדי לצלם תמונה, הקש על . כדי להקליט סרטון וידאו, הקש על .

סרטון קצרצר




באפשרותך לצלם תמונה או להקליט סרטון וידאו ולהציג אותו מיד בתצוגה מקדימה.

- 1 כשאתה במצב 'ריבוע', הקש על **מצב** < .
- 2 הקש על  כדי לצלם תמונה. כדי להקליט סרטון וידאו, הקש על .




צילום משבצת







באפשרותך לצלם עד 4 תמונות או סרטונים (באורך מרבי של 3 שניות) המאורגנים בריבוע.

- 1 כשאתה במצב 'ריבוע', הקש על **מצב** < .
- 2 הקש על  /  כדי לצלם תמונות או להקליט סרטוני וידאו בו-זמנית או ברצף, בהתאם לסדר הפריסה שמוצג.

3 הקש על לשמירה.






התאם צילום


- באפשרותך לצלם 2 תמונות או סרטונים בו-זמנית או בנפרד.
- 1 כשאתה במצב 'ריבוע', הקש על **מצב** < .
 - 2 הקש על  /  כדי לצלם תמונה או להקליט סרטון וידאו בו-זמנית או בנפרד.
 - 3 הקש על  /  כדי לצלם תמונות ולהקליט סרטוני וידאו.
 - 4 הקש על  לשמירה (במקרה הצורך).



מדריך צילום


- באפשרותך לצלם תמונות על-ידי מעקב אחר ההעמדה בתצלום אחר.
- 1 כשאתה במצב 'ריבוע', הקש על **מצב** < .
 - 2 בחר מבין ההעמדות שבצד את זו שברצונך לעקוב אחריה.
 - 3 הקש על  כדי לצלם תמונה.

 • השתמש במחווך ההחלקה כדי לשלוט בשקיפות הרקע.




מעקב אחר המיקוד בעת שימוש המצלמה

באפשרותך לעקוב אחר אובייקט ולהתמקד בו בזמן צילום תמונות או הקלטת סרטונים.

1 הפעל את היישום 'מצלמה', ולאחר מכן הקש על  < **Tracking focus**

2 לפני שתקליט וידאו או תצלם תמונה, הקש קלות על המסך כדי לבחור אובייקט שבו ברצונך להתמקד.



3 צלם את התמונה או התחל בהקלטת סרטון הווידאו.

- לפרטים, ראה **התחלת המצלמה**.
- כדי להשתמש בתכונה זו, בחר במצלמה הרגילה (📷) לצילום תמונות או להקלטת סרטונים.
- תכונה זו אינה זמינה כאשר אתה משתמש במצלמה הקדמית או במצלמה בזווית רחבה.
- תכונה זו אינה זמינה במקרים הבאים:
 - הגבלת הגודל של סרטון וידאו: הרזולוציה שלה מוגדרת כ-16:9 UHD.
 - הגבלת FPS: ה-FPS שלה מוגדר כ-FPS 60.

הקלטה יציבה

ניתן להשתמש בתכונת ההקלטה היציבה כדי לצמצם את מידת הטשטוש בעת הקלטת סרטון וידאו.

הפעל את היישום 'מצלמה', ולאחר מכן הקש על **בסיסי (A)**, **מרובע (C)**, או **ידני (D)** < ⚙ < **הקלטה יציבה**.


• לפרטים, ראה **התחלת המצלמה**.

חתימה

אתה יכול ליצור תצלום אישי באמצעות חתימתך.



1 הפעל את היישום 'מצלמה', ולאחר מכן הקש על **בסיסי (A)** < ⚙ < **הוסף חתימה**.

2 הזן את החתימה באופן הרצוי והקש על **הוסף**.



• תכונה זו אינה זמינה כאשר אתה משתמש ב'מצב וידאו ידני'.



הקלטת סרטון וידאו Hi-Fi


הקלטת סרטוני וידאו באיכות גבוהה על-ידי לכידת צליל באיכות גבוהה יותר עם טווח תדרים דינמי רחב יותר באמצעות 2 מיקרופונים רגישים מסוג AOP (Acoustic Overload Point) והקלטת Hi-Fi מדהימה. הפעל את יישום המצלמה, ולאחר מכן הקש על **ידי** <  **Hi-Fi** 

- לפרטים, ראה **התחלת המצלמה**.
- ניתן להפעיל סרטוני Hi-Fi ביישומים שתומכים ב-Hi-Fi בלבד.
- תכונה זו אינה זמינה בעת שימוש במצלמה הקדמית.

תכונות גלריה

לחצן צף

כדי לעבור במהירות אל המסך הראשי בעת הצגת הגלריה' בכיוון לרוחב, גע והחזק את , והזז את האצבע כלפי מעלה אל , אחר-כך שחרר את הלחצן.



- אתה יכול להזיז את מיקום הלחצן הצף על-ידי גרירה אופקית שלו לאורך החלק התחתון של המסך.

סרט צילום

באפשרותך להציג את התמונות וסרטוני הווידאו שצילמת במסך התצוגה המקדימה של המצלמה.

הפעל את היישום 'מצלמה', ולאחר מכן הקש על **בסיסי (A)** < **סרט צילום**.


- כאשר אתה מצלם תמונות או מקליט סרטוני וידאו, באפשרותך להציג בצד המסך את התמונות הממוזערות של התמונות שנשמרו.
- גלול את רשימות התמונות הממוזערות מעלה או מטה כדי לדפדף בתמונות ובסרטוני הווידאו.
- הקש על תמונה ממוזערת כדי להציג את התצלום או את סרטון הווידאו במסך המצלמה.
- הקש על התמונה הממוזערת שוב כדי לחזור אל התצוגה המקדימה של המצלמה.



- תכונה זו אינה נתמכת כשאתה מצלם תמונה או מקליט סרטון וידאו ביחס הגובה-רוחב 18:9.
- התכונה 'סרט צילום' זמינה רק במצב תצוגה אוטומטית.


תוכן קשור

באפשרותך לערוך ולהתאים אישית תוכן קשור ב'גלריה'.



- 1 בזמן הצגת תמונה בתצוגה מקדימה, הקש על .
- 2 כאשר מופיע הסמל הקשור לתאריך שבו צילמת את התמונה, גע במסך.



- באפשרותך להציג את התמונות הקשורות לתאריך שבחרת.



- ניתן לקשור תוכן קשור לעד ארבעה שילובים של 'זיכרונות, תאריך, מקום, מצב מצלמה'.

- הקש על  כדי לשמור את התוכן הקשור כסרטון וידאו.
- הקש על  כדי לגשת אל אפשרויות נוספות.




יצירת GIF

- ניתן ליצור בקלות קובץ GIF באמצעות סרטון וידאו מוקלט.
- 1 בנקודת ההתחלה הרצויה בזמן צפייה בווידיאו, הקש על < : < **צור קובץ GIF.**
 - 2 בחר את האורך של קובץ ה-GIF שברצונך ליצור.
 - קובץ GIF נוצר עבור משך הזמן החל מהשעה הנוכחית.
 - עבור סרטוני וידאו שאורכם קצר מ-5 שניות, תמונות GIF מופקות באופן אוטומטי עבור הזמן הנותר.

• התכונה של יצירת GIF מוצעת עבור הפעילות היצירתית של המשתמש. אם אתה מפר זכויות יוצרים של אדם אחר או עובר על חוקי ההשמצה על-די שימוש בתכונת היצירה של GIF, אתה עשוי להיחשף לתביעה אזרחית ופלילית. הקפד שלא לשכפל או להעביר עבודה של אחרים ללא רשות. חברת LG Electronics לא תוכל לקבל אחריות מכל סוג שהוא עקב פעולה של משתמש.



יצירת טפט קולאז'

- באפשרותך ליצור תמונת קולאז' משלך ולהציג אותה כמסך נעילה. אתה יכול לבחור תמונות קולאז' מרובות בתור טפט שמשתנה בכל פעם שאתה מפעיל או מכבה את המסך.
- 1 הקש על  < **הגדרות** < **תצוגה** < **מסך נעילה** < **טפט** < **טפט קולאז'.**
 - 2 הקש על + ובחר את התמונות שברצונך להציג כקולאז'.

3 ערוך את מצגת השקופיות באופן הרצוי והקש על הגדר טפט.



תכונות הקלטת שמע

סקירה כללית של הקלטת שמע ב-HD

באפשרותך לקבוע את הגדרות השמע באופן ידני, כדי שתוכל להקליט שמע על בסיס ההגדרות הממוטבות עבור המצב שנבחר.

מצבי הקלטה

באפשרותך להקליט קובץ שמע באיכות High Definition על-ידי בחירה והגדרת תצורה של מצב השמע כך שיתאים לסביבת ההקלטה.

הקש על  < **חיוניים** < **הקלטת שמע ב-HD** < .

רגילה




באפשרותך להקליט שמע ללא הגדרות נוספות.

הופעה

באפשרותך להקליט שמע בקונצרט או באירועי מוסיקה אחרים.

מותאם אישית


תוכל לקבוע את תצורת ההגדרות הרצויות כדי להקליט שמע.

•  כאשר תחבר את האפרכסת למכשיר, יופיע הסמל . הקש על  ולאחר מכן בחר את המיקרופון שבו ברצונך להשתמש.

מצב סטודיו

במצב 'סטודיו', אתה יכול להפעיל קובץ שמע או מוסיקה ולהקליט את קולך בו-זמנית, ליצור אקורד על-ידי הקלטת קולך מספר רב של פעמים, ולהקליט את הערותיך מעל קובץ השמע המקורי של המציג או הדובר.


1 הקש על  < **חיוניים** < **הקלטת שמע ב-HD**.

2 בחר בסמל  < **מותאם אישית**.

3 הקש על  ובחר קובץ שמע לשימוש כמוסיקת רקע.

4 הקש על  כדי להקליט קול.

5 הקש על  כדי לשמור את הקובץ המוקלט.

•  ניתן להפעיל מוסיקת רקע באמצעות האוזניות בלבד. הקפד לחבר את האוזניות לפני השימוש בתכונה זו.

תכונות מועילות נוספות לשימוש ביישום 'הקלטת שמע באיכות גבוהה'

GAIN

תוכל לכוונן את רגישות הקול המוקלט באמצעות המיקרופון. ככל שערך החיזוק גבוה יותר, כך הקול מוקלט ברמת רגישות גבוהה יותר.

LCF

תוכל לסנן רעשים חלשים כגון המהום חלש של המזגן. ככל שערך ה-LCF (Low Cut Filter - מסנן בחיתוך נמוך) המוגדר גבוה יותר, כך רעשים בתדר גבוה יסוננו בצורה טובה יותר.

LMT

תכונה זו יכולה למנוע קיטוע של הצליל המוקלט. ככל שערך ה-LMT (Limiter - מגביל) המוגדר גבוה יותר, כך צלילים רבים יותר בתדר נמוך לא ייקטעו.

- כדי לשנות הגדרות נוספות, הקש על **< הגדרות**, ולאחר מכן התאם אישית את סוג הקובץ, עומק הסיביות, קצב הדגימה והגדרות אחרות.
- באפשרותך לנטר את איכות הקול בעזרת האוזנייה המחוברת במהלך הקלטת שמע. במהלך הקלטת שמע במצב 'סטודיו', אין תמיכה בניטור קול. תוכל לשמוע את מוסיקת הרקע בלבד.


זיהוי טביעת אצבע

סקירה כללית של זיהוי טביעת אצבע

כדי להשתמש בפונקציה לזיהוי טביעות אצבע, עליך לרשום תחילה טביעת אצבע במכשיר שלך.

תוכל להשתמש בפונקציה לזיהוי טביעות אצבע במקרים הבאים:

- לביטול נעילת המסך.
- להצגת תוכן נעול גלריה או ב-QuickMemo+.
- כדי לאשר רכישה, היכנס ליישום או זהה את עצמך באמצעות טביעת האצבע שלך.

• תוכל להשתמש בטביעות אצבע לזיהוי משתמשים במכשיר. ייתכן שטביעות אצבעות דומות מאוד של משתמשים שונים יזוהו על-ידי חיישן טביעת האצבע כאותה טביעת אצבע. 

אמצעי זהירות לזיהוי טביעת אצבע

רמת הדיוק של זיהוי באמצעות טביעת אצבע עשויה לרדת בשל כמה סיבות. כדי להבטיח זיהוי ברמת דיוק מרבית, בדוק את הפריטים הבאים לפני השימוש במכשיר.

- מקש ההפעלה/נעילה של המכשיר כולל חיישן טביעת אצבע. ודא שלא נגרם נזק למקש ההפעלה/נעילה על-ידי חפץ מתכתי, כמו מטבע או מפתח.
- רישום או זיהוי של טביעת אצבע עלול שלא לפעול במקרה של מים, אבק או חומרים אחרים על מקש ההפעלה/נעילה או על האצבע. הקפד להניח על החיישן אצבע נקייה ויבשה כדי לאפשר זיהוי טביעת אצבע.
- ייתכן שטביעת האצבע לא תזוהה כראוי אם יש צלקת על כרית האצבע או שהיא לא חלקה כתוצאה מהשריה במים.
- אם האצבע שלך מקופלת או שהנחת רק את קצה האצבע באופן חלקי בלבד, ייתכן שהזיהוי לא יצלח. ודא שהאצבע מכסה את משטח מקש ההפעלה/נעילה במלואו.

- סרוק אצבע אחת בלבד בכל רישום. סריקה של יותר מאצבע אחת עשויה להשפיע על הרישום והזיהוי של טביעת האצבע.
- המכשיר עלול ליצור חשמל סטטי אם האוויר שמסביבו יבש. הימנע מסריקת טביעות אצבע בסביבה יבשה; לחלופין, גע בחפץ מתכתי (כמו מטבע או מפתח) לפני הסריקה, כדי לפרוק חשמל סטטי.

רישום טביעות אצבע


תוכל לרשום ולשמור את טביעת האצבע שלך במכשיר כדי להשתמש בזיהוי באמצעות טביעת אצבע.

1 הקש על < הגדרות < כללי < טביעות אצבע ואבטחה < טביעות אצבע.

- יש להגדיר מסך נעילה כדי שניתן יהיה להשתמש בתכונה זו.
- אם נעילת המסך אינה פעילה, קבע את תצורת מסך הנעילה על-ידי ביצוע ההוראות המוצגות על המסך. ראה **הגדרת נעילת מסך** לפרטים.

2 אתר את מקש ההפעלה/נעילה בגב המכשיר והנח עליו בעדינות אצבע אחת כדי לרשום את טביעת האצבע.

- לחץ בעדינות על מקש ההפעלה/נעילה כדי לאפשר לחיישן לזהות את טביעת האצבע שלך. לחיצה חזקה מדי על מקש ההפעלה/נעילה עלולה להפעיל את פונקציית נעילת המסך או לכבות את המסך.
- ודא שקצה האצבע מכסה את משטח החיישן של מקש ההפעלה/נעילה במלואו.



- 3 פעל בהתאם להוראות המוצגות על המסך.
- חזור על סריקת טביעת האצבע על-ידי הזזת האצבע בקצב איטי ביותר עד שטביעת האצבע תירשם.
- 4 בסיום תהליך הרישום של טביעת האצבע, הקש על **אישור**.
- הקש על **הוסף עוד** כדי לרשום טביעת אצבע נוספת. אם רשמת טביעת אצבע אחת בלבד ומצב האצבע לא תקין, ייתכן שהזיהוי לא יפעל היטב. כדי למנוע מצב כזה, עדיף לרשום מספר טביעות אצבע.

ניהול טביעות אצבע

תוכל לערוך או למחוק טביעות אצבע רשומות.

- 1 הקש על \bigcirc < הגדרות < כללי < **טביעות אצבע ואבטחה** < **טביעות אצבע**.
- 2 בטל את הנעילה בהתאם לשיטת הנעילה שצויינה.
- 3 מרשימת טביעות האצבע, הקש על טביעת האצבע כדי לשנות את שמה. כדי למחוק אותה, הקש על \square .

ביטול נעילת המסך עם טביעת אצבע

תוכל לבטל את נעילת המסך או להציג תוכן נעול בעזרת טביעת אצבע. הפעל את הפונקציה הרצויה:

- 1 הקש על \bigcirc < הגדרות < כללי < **טביעות אצבע ואבטחה** < **טביעות אצבע**.
- 2 בטל את הנעילה בהתאם לשיטת הנעילה שצויינה.
- 3 במסך הגדרות טביעת אצבע, הפעל את הפונקציה הרצויה:
 - **נעילת מסך**: בטל את נעילת המסך עם טביעת אצבע.
 - **נעילת תוכן**: בטל את נעילת התוכן עם טביעת אצבע. לשם כך, ודא שמנעול התוכן מוגדר.

סקירה כללית של תכונת זיהוי הפנים

באפשרותך לבטל את נעילת המסך על ידי שימוש בנתוני הפנים השמורים אצלך.

- תכונה זו עשויה להיות רגישה יותר מבחינת אבטחה מאשר שיטות אחרות לנעילת מסך, כגון Knock Code, תבנית, קוד PIN או סיסמה.
- אם ייעשה ניסיון להשתמש בפנים דומות או בתצלום שלך, ייתכן שהדבר יצליח להביא לביטול נעילת המסך.
- נתוני הפנים המזוהים נשמרים בצורה מאובטחת במכשיר שלך.
- כשאתה בוחר בזיהוי פנים לביטול נעילת המסך, עליך להזין את ה-Knock Code, תבנית, קוד PIN או סיסמה ששימשו לשיוך הפנים מבלי להשתמש ישירות בתכונת זיהוי הפנים לאחר הפעלת המכשיר. לכן, עליך להיזהר שלא לשכוח את הערך שצוין.
- אם המכשיר אינו מצליח לזהות את פניך, או ששכחת את הערך שצוין לצורך השיוך, הבא את המכשיר למרכז שירות הלקוחות הקרוב ביותר של LG והצטייד בתעודת הזהות שלך.

אמצעי זהירות לצורך זיהוי פנים

רמת הדיוק של זיהוי הפנים עשויה לרדת במקרים הבאים. כדי להגדיל את רמת הדיוק, בדוק את ההפרעות האפשריות הבאות לפני השימוש במכשיר.

- אם פניך מכוסים בכובע, משקפיים או מסכה, או שפניך שונות משמעותית בשל איפור כבד או זקן.
- אם קיימים טביעות אצבע או חומרים זרים בחזית עדשת המצלמה, או שהמכשיר שלך אינו מצליח לזהות את פניך בשל תאורה חזקה או חלשה מדי.

שיוך נתוני פנים

לפני שימוש בתכונת זיהוי הפנים, עליך לשייך את נתוני הפנים שלך למכשיר שברשותך.

1 הקש על < הגדרות < תצוגה < מסך נעילה < בחירת נעילת מסך < אפשר תווי פנים.

- כדי להשתמש בתכונה זו, חובה היה להגדיר את נעילת המסך מלכתחילה באמצעות Knock Code, תבנית, קוד PIN או סיסמה.
- כאשר נעילת המסך אינה מוגדרת, שייך את הנתונים בהתאם להוראות המוצגות במסך. לפרטים, ראה **הגדרת נעילת מסך**.

2 הרם את המכשיר ממש מול חזית עיניך.

3 שייך את פניך בהתאם להוראות המוצגות במסך.

• בצע את שיוך הפנים בחדר עם תאורה שאינה חזקה או חלשה מדי.

• מקם את פניך בשלמותן בתוך קווי התיחום של המסך, ולאחר מכן כוונן אותן באטיות על ידי הזזתן מעלה, מטה, שמאלה או ימינה.

4 בסיום תהליך שיוך הפנים, הקש על **אישור**.

ביטול נעילת המסך באמצעות טביעת פניך

באפשרותך לבטל את נעילת המסך באמצעות טביעת הפנים שלך במקום באמצעות Knock Code, תבנית, קוד PIN או סיסמה.

1 גרור את < הגדרות < תצוגה < מסך נעילה < בחירת נעילת מסך.

2 בטל את נעילת המסך בהתאם לשיטת הנעילה שצויינה.

3 גרור את  כדי להפעיל תכונת זיהוי הפנים.

שיפור זיהוי הפנים

באפשרותך להוסיף נתוני פנים במגוון תנאים כדי לשפר את יכולת זיהוי הפנים.

1 הקש על < הגדרות < תצוגה < מסך נעילה < תווי פנים.

2 בטל את נעילת המסך בהתאם לשיטת הנעילה שצוינה.

3 בחר באפשרות **שפר את זיהוי תווי הפנים**.

4 שייך את פניך בהתאם להוראות המוצגות במסך.

5 בסיום תהליך שיוך הפנים, הקש על **אישור**.

מחיקת נתוני פנים

אם זיהוי הפנים אינו פועל כראוי, באפשרותך למחוק את נתוני הפנים המשויכים למכשיר ולשייך אותם מחדש.

1 הקש על < הגדרות < תצוגה < מסך נעילה < תווי פנים.

2 בטל את נעילת המסך בהתאם לשיטת הנעילה שצוינה.

3 בחר באפשרות **מחק תווי פנים** כדי למחוק את נתוני הפנים.

ביטול נעילת המסך באמצעות טביעת פניך כאשר המסך כבוי

כאשר מסך המכשיר כבוי, הרם את המכשיר והתבונן בחזית העדשה. כעת המכשיר מסוגל לזהות את פניך, ונעילת המסך מבטלת.

כדי להשבית תכונה זו, פעל לפי ההנחיות שלהלן.

1 הקש על < הגדרות < תצוגה < מסך נעילה < תווי פנים.

2 בטל את נעילת המסך בהתאם לשיטת הנעילה שצוינה.

3 גרור את **אפשר לתווי הפנים לבטל את הנעילה כאשר המסך מכובה** כדי להשבית את התכונה.

• תכונת זיהוי הפנים זמינה רק כאשר המסך נעול.

ביטול נעילת המסך באמצעות זיהוי פנים ולאחריו החלקה על המסך

כאשר המסך כבוי, באפשרותך לבטל את נעילתו על ידי ביצוע זיהוי פנים ולאחר מכן החלקה על המסך.

1 הקש על  < הגדרות < תצוגה < מסך נעילה < תווי פנים.

2 בטל את נעילת המסך בהתאם לשיטת הנעילה שצוינה.

3 גרור את החלק אצבע לביטול הנעילה לאחר זיהוי תווי פניך  כדי להפעיל את התכונה.


קידום זיהוי הפנים

באפשרותך למנוע את ביטול נעילת המכשיר על ידי תצלומים, תמונות או סרטונים.

1 הקש על  < הגדרות < תצוגה < מסך נעילה < תווי פנים.

2 בטל את נעילת המסך בהתאם לשיטת הנעילה שצוינה.

3 גרור את תווי פנים מתקדם  כדי להפעיל את התכונה.

• רמת המהירות של זיהוי הפנים עשויה לרדת כשאתה משבית תכונה זו. 



התכונה 'ריבוי משימות'


ריבוי-חלונות

ניתן להשתמש בשני יישומים במקביל על-ידי חלוקת המסך לחלונות מרובים.

בזמן השימוש ביישום, הקש הקשה ממושכת על בלחצני התצוגה ולאחר מכן בחר יישום מרשימת היישומים שהיו בשימוש לאחרונה.

- ניתן להשתמש בשני יישומים שמוצקים במסך הראשי בו-זמנית.
- כדי להפסיק להשתמש בתכונת ריבוי-חלונות, הקש הקשה ממושכת על .




- תכונת ריבוי-חלונות אינה נתמכת על-ידי יישומים מסוימים, כולל יישומים שהורדת. 

מסך סקירה כללית

מסך 'סקירה כללית' מספק תצוגה מקדימה של היישומים שהיו בשימוש לאחרונה.

כדי להציג את רשימת היישומים שהיו בשימוש לאחרונה, הקש על במסך הראשי ולאחר מכן הקש על היישום המוצג.


- גע והחזק יישום, וגרור אותו אל הקצה העליון של המסך כדי להפעיל את היישום בעזרת התכונה 'ריבוי-חלונות'. ניתן גם להקיש על  בראש כל אחד מהיישומים.

Always-on display


תוכל להציג את התאריך, השעה, החתימה או מידע אחר על המסך, גם כאשר המסך הראשי כבוי. Always-on display היא תכונה שימושית לבדיקה מהירה של השעה ולהצגת החתימה שלך.



1 הקש על  < הגדרות < תצוגה < Always-on display ולאחר מכן הקש על  כדי להפעיל תכונה זו.



- ייתכן שתכונה זו כבר מופעלת במכשיר כברירת מחדל בעת רכישתו. 
- הגדרת ברירת המחדל עשויה להשתנות בהתאם לאזור ולספק השירות.

2 הקש על **תוכן** ובחר את הפריט שברצונך להציג כשהמסך כבוי.

- אל תשכח לבדוק שהחתימה שלך אינה חורגת משדה הקלט. 
- שימוש ב-Always-on display יאיץ את התרוקנות הסוללה. השבת תכונה זו כדי להאריך את חיי הסוללה.


שיתוף מהיר

תוכל לשתף תמונה או סרטון וידאו עם היישום הרצוי מיד לאחר הצילום.

1 הקש על  < , ולאחר מכן צלם תמונה או הקלט סרטון וידאו.

2 הקש על סמל היישום שמופיע במסך כדי לשתף אותו באמצעות יישום זה.

באפשרותך גם להחליק את הסמל לכיוון ההפוך כדי לראות באילו יישומים אחרים תוכל להשתמש כדי לשתף את התמונות וסרטוני הווידאו שלך.



- היישום שסמל 'שיתוף מהיר' מציג עשוי להשתנות בהתאם לסוג ולתדירות הגישה שלך אל היישומים המותקנים במכשיר.
- תוכל להשתמש בתכונה זו רק כאשר אתה מצלם תמונה או מקליט סרטון וידאו במצבים 'בסיסי' ו'מרובע'. ראה **מצב בסיסי** ו**מצב מרובע** לפרטים.



02

**פונקציות
בסיסיות**

רכיבי מוצרים ואביזרים

הפריטים הבאים נכללים במכשיר שלך.

- מכשיר
- אוזניות סטריאו
- מטען
- מדריך להתחלה מהירה
- כבל USB
- פין שליפה


- הפריטים המתוארים לעיל עשויים להיות אופציונליים.
- הפריטים הכלולים באריזת המכשיר והזמינות של כל אביזר עשויים להשתנות בהתאם לאזור ולספק השירות.
- השתמש תמיד באביזרים מקוריים של LG Electronics. השימוש באביזרים המיוצרים על-ידי יצרנים אחרים עלול להשפיע על ביצועי השיחות של המכשיר או לגרום לתקלות. ייתכן ששירות התיקונים של LG אינו מכסה דבר זה.



- אם אחד מהפריטים הבסיסיים הללו חסרים, פנה למשווק שממנו רכשת את המכשיר.
- כדי לרכוש פריטים בסיסיים נוספים, פנה למרכז שירות לקוחות של LG.
- כדי לרכוש פריטים אופציונליים, פנה למרכז שירות לקוחות של LG לקבלת רשימה של משווקים זמינים.
- פריטים מסוימים בקופסת המוצר כפופים לשינוי ללא הודעה מוקדמת.
- המראה והמפרטים של המכשיר כפופים לשינוי ללא הודעה מוקדמת.
- מפרט המכשיר עשוי להשתנות, בהתאם לאזור ולספק השירות.
- הקפד להשתמש באביזרים מקוריים שסופקו על ידי LG Electronics. השימוש באביזרים של צד שלישי עלול לגרום נזק למכשיר או לגרום לתקלות.
- הסר את הסרט המגן מחיישן טביעת האצבע לפני שימוש בתכונה לזיהוי טביעת אצבע.



סקירה כללית של החלקים



- חיישן קרבה/תאורת סביבה
 - חיישן קרבה: במהלך שיחה, חיישן הקרבה מכבה את המסך ומשבית את פונקציונליות המגע כאשר המכשיר צמוד לגוף. הוא מפעיל בחזרה את המסך והופך את פונקציונליות המגע לזמינה כאשר המכשיר נמצא מחוץ לטווח ספציפי.
 - חיישן תאורת הסביבה: חיישן תאורת הסביבה מנתח את עוצמת תאורת הסביבה כאשר מצב בקרת בהירות אוטומטית מופעל.
- מקשי עוצמת קול
 - כוונן את עוצמת הקול של רינגטונים, שיחות או התראות.
 - בזמן השימוש במצלמה, לחץ בעדינות על מקש עוצמת הקול כדי לצלם תמונה. כדי לצלם תצלומים מתמשכים, לחץ לחיצה ארוכה על מקש עוצמת הקול.
 - לחץ פעמיים על מקש החלשת עוצמת הקול (-) כדי להפעיל את היישום מצלמה כאשר המסך נעול או כבוי. לחץ פעמיים על מקש הגברת עוצמת הקול (+) כדי להפעיל את Capture+.
- מקש הפעלה/נעילה (חיישן טביעת אצבע)
 - לחץ לחיצה קצרה על המקש כאשר ברצונך להפעיל או לכבות את המסך.
 - לחץ לחיצה ארוכה על המקש כאשר ברצונך לבחור אפשרות בקרת צריכת חשמל.
 - הפעל את תכונת הזיהוי באמצעות טביעת אצבע כדי לפשט את התהליך של ביטול נעילת המסך. לפרטים, ראה **סקירה כללית של זיהוי טביעת אצבע**.


- המכשיר כולל סוללה פנימית ניתנת לטעינה. כדי לשמור על בטיחות, אל תוציא את הסוללה המובנית.
- ייתכן שהגישה לפונקציות מסוימות תהיה מוגבלת, בהתאם למפרטי המכשיר.
- החלק האחורי של המכשיר כולל אנטנת NFC מובנית. נקוט משנה זהירות כאשר אתה מטפל במכשיר כדי להימנע מגרימת נזק או מכיסוי אנטנת ה-NFC.



- אל תניח חפצים כבדים על המכשיר ואל תשב עליו. אחרת, עלול להיגרם נזק למסך המגע.
- כיסוי מגן למסך או אביזרים אחרים עלולים להפריע לפעולתו של חיישן הקרבה.
- אם המכשיר רטוב או שאתה משתמש בו במקום לח, ייתכן שמסך המגע או הלחצנים לא יפעלו כראוי.


החזק את המכשיר בצורה נכונה כפי שמוצג להלן. אם תכסה את פתח המיקרופון עם היד, עם האצבע או עם כיסוי מגן בעת שימוש במכשיר, ייתכן שבמהלך שיחה לא תישמע בביור.

דוגמה להחזקה טובה



מיקרופון

דוגמה להחזקה לא טובה



אל תכסה את המיקרופון.

הדלקה או כיבוי

הדלקת המכשיר

כאשר המכשיר כבוי, לחץ לחיצה ארוכה על מקש הפעלה/נעילה.

- כאשר תפעיל את המכשיר בפעם הראשונה, תתבצע קביעת תצורה ראשונית. זמן האתחול הראשון של הטלפון החכם עשוי להיות ארוך מן הרגיל.

כיבוי המכשיר

לחץ לחיצה ארוכה על מקש הפעלה/נעילה ולאחר מכן בחר **כיבוי**.


אפשרויות בקרת צריכת חשמל


לחץ לחיצה ממושכת על מקש הפעלה/נעילה ולאחר מכן בחר אפשרות.

- **כיבוי:** כבה את המכשיר.
- **כיבוי והפעלה מחדש:** הפעל מחדש את המכשיר.
- **הפעל מצב טיסה:** חסום פונקציות הקשורות לטלקומוניקציה, כולל ביצוע שיחות טלפון, העברת הודעות וגלישה באינטרנט. פונקציות אחרות נשארות זמינות.


התקנת כרטיס ה-SIM

הכנס את כרטיס ה-SIM (Subscriber Identity Module) שסופק על-ידי ספק השירות כדי להתחיל להשתמש במכשיר.


- נהג בזהירות עם סיכת השליפה מכיוון שיש לה קצה חד. 

- כדי שתכונות העמידות במים והעמידות באבק יפעלו באופן יעיל, יש להכניס בצורה נכונה את מגש הכרטיס. 

1 הכנס את פין השליפה לתוך החור במגש הכרטיס.




2 משוך החוצה את מגש הכרטיס.




3 הנח את כרטיס ה-SIM על מגש הכרטיס כאשר המגעים המוזהבים פונים כלפי מטה.

שים את כרטיס SIM העיקרי במגש של כרטיס ה-SIM 1 ואת כרטיס SIM המשני במגש של כרטיס ה-SIM 2.

• מגש כרטיס SIM 2 משמש גם כמגש של כרטיס הזיכרון. עם זאת, לא ניתן לשים את כרטיס ה-SIM ואת כרטיס הזיכרון (אופציונלי) בו-זמנית.



4 הכנס את מגש הכרטיס בחזרה לתוך החרוץ.



- מכשיר זה תומך בכרטיסי Nano SIM בלבד.
- לקבלת ביצועים ללא בעיות, מומלץ להשתמש במכשיר עם הסוג הנכון של כרטיס SIM. השתמש תמיד בכרטיס SIM מקורי שסופק על-ידי המפעיל.
- אם תכניס את מגש הכרטיס למכשיר בזמן שמגש הכרטיס רטוב, עלול להיגרם נזק למכשיר. תמיד ודא שמגש הכרטיס יבש.

אמצעי זהירות בעת שימוש בכרטיס ה-SIM


- אל תאבד את כרטיס ה-SIM. LG-אינה נושאת באחריות לנזקים ולבעיות שייגרמו כתוצאה מאובדן או העברה של כרטיס ה-SIM.
- הקפד שלא לגרום נזק לכרטיס ה-SIM כאשר אתה מכניס או מוציא אותו.

הכנסת כרטיס הזיכרון


הכנס את כרטיס הזיכרון למכשיר.


המכשיר יכול לתמוך בכרטיס microSD בנפח של עד 2 TB. בהתאם ליצרן ולסוג של כרטיס הזיכרון, ייתכן שכרטיסי זיכרון מסוימים לא יתאימו למכשיר שלך.

- 1 הכנס את פין השליפה לתוך החור במגש הכרטיס.
- 2 משוך החוצה את מגש הכרטיס.
- 3 הנח את כרטיס הזיכרון על מגש הכרטיס כאשר המגעים המוזהבים פונים כלפי מטה.





4 הכנס את מגש הכרטיס בחזרה לתוך החרץ.


- ייתכן שכרטיסי זיכרון מסוימים לא יהיו תואמים באופן מלא למכשיר. שימוש בכרטיס לא תואם עלול לגרום נזק למכשיר או לכרטיס הזיכרון או לשיבוש הנתונים המאוחסנים בו. 

- כתיבה ומחיקה של נתונים בתכיפות גבוהה עלולות לקצר את חיי השירות של כרטיס הזיכרון. 

הוצאת כרטיס הזיכרון


להוצאת כרטיס הזיכרון באופן בטוח, בטל תחילה את הטעינה שלו.

- 1 הקש על  < הגדרות < כללי < אחסון < .
- 2 הכנס את פין השליפה לתוך החור במגש הכרטיס.
- 3 שלוף את מגש הכרטיס והוצא את כרטיס הזיכרון.

- אין להוציא את כרטיס הזיכרון בזמן שהמכשיר מעביר נתונים או ניגש למידע. אי הקפדה על כך עלולה לגרום לאובדן או לגרום לשיבוש הנתונים או לנזק לכרטיס הזיכרון או למכשיר עצמו. LG אינה אחראית להפסדים שייגרמו עקב שימוש לרעה או שימוש לא נאות בכרטיסי זיכרון, לרבות אובדן נתונים. 

טעינת הסוללה

לפני השימוש במכשיר, טען את הסוללה במלואה.
הטען את המכשיר בעזרת הכבל מסוג USB Type-C.



- אין לטעון בזמן שכבל המכשיר או הטעינה רטוב או לח. הדבר עלול לגרום לשריפה, להתחשמלות, לפגיעה או לנזק למכשיר.
- הקפד להשתמש בכבל ה-USB שסופק עם המכשיר.
- הקפד להשתמש במטען ובכבל טעינה המאושרים לשימוש על-ידי LG. טעינת הסוללה באמצעות מטען של צד שלישי עלולה לגרום להתפוצצות הסוללה או לנזק למכשיר.
- המכשיר כולל סוללה פנימית ניתנת לטעינה. כדי לשמור על בטיחות, אל תוציא את הסוללה המובנית.
- שימוש במכשיר כאשר הוא נטען עלול לגרום להתחשמלות. כדי להשתמש במכשיר, הפסק את טעינתו.





- הוצא את המטען משקע החשמל לאחר שהמכשיר נטען במלואו. הדבר ימנע צריכת חשמל מיותרת.
- המוצר מגיע עם מתאם טעינה התומך בהטענה מהירה.
- תכונת הטעינה המהירה עלולה לא לפעול אם נעשה שימוש במתאם טעינה מהיר שאינו המתאם המקורי שסופק עם המוצר.
- ניתן לטעון את הסוללה בדרך נוספת, על-ידי חיבור כבל USB בין המכשיר לבין מחשב שולחני או מחשב נייד. זה עלול להימשך זמן רב יותר לעומת חיבור המתאם לשקע חשמל בקיר.
- אין לטעון את הסוללה באמצעות רצות USB שאינה תומכת במתח הנקוב. הטעינה עלולה להיכשל או להיפסק באופן לא מכוון.

אמצעי זהירות בעת שימוש במכשיר

- הקפד להשתמש בכבל ה-USB המסופק עם המוצר, אל תחבר את המכשיר לכבלי USB או למטענים של חברות צד שלישי. האחריות המוגבלת של LG אינה מכסה שימוש באביזרים של צד שלישי.
- אם לא תפעל על-פי ההוראות המפורטות במדריך זה או אם תשתמש במכשיר לא כהלכה, הדבר עשוי לגרום לו נזק.

שימוש יעיל בסוללה


- חיי הסוללה עשויים להתקצר אם תשאיר מספר רב של יישומים ופונקציות במצב פעיל לאורך זמן.
- כבה את הפעולות ברקע כדי להאריך את חיי הסוללה.
- כדי למזער את צריכת הסוללה, פעל בהתאם לעצות הבאות:
- כבה את הפונקציות Bluetooth® או Wi-Fi כאשר אינך משתמש בהן.
- הגדר זמן קצוב קצר ככל האפשר לכיבוי המסך.
- מזער את בהירות המסך.
- הגדר נעילת מסך שתופעל כאשר המכשיר לא בשימוש.
- בדוק את פרטי השימוש בסוללה וסגור את היישומים שהורדת שמרוקנים את הסוללה.

מסך המגע

תוכל ללמוד כיצד לשלוט במכשיר שברשותך על-ידי שימוש במחוות מסך המגע.

הקשה

הקש קלות עם קצה האצבע כדי לבחור או להפעיל יישום או אפשרות.




הקשת הקשה ממושכת

הקש הקשה ממושכת למשך כמה שניות כדי להציג תפריט עם אפשרויות זמינות.




הקשה כפולה

הקש פעמיים במהירות כדי להגדיל או להקטין דף אינטרנט או מפה.




גרירה

גע והחזק פריט, כגון יישום או וידג'ט, ולאחר מכן הזז את האצבע למיקום אחר בתנועה מבוקרת. תוכל להשתמש במחוזה זו כדי להזיז פריט.





החלקה

גע במסך באצבעך והזז אותה במהירות מבלי לעצור. באפשרותך להשתמש במחוזה זו כדי לגלול ברשימה, בדף אינטרנט, בתמונות, במסכים ועוד.



צביטה או פריסה

צבוט בשתי אצבעות כדי להקטין את התצוגה של תמונה או מפה.
כדי להגדיל, פרוס את האצבעות כדי להרחיקן זו מזו.



- אין לחשוף את מסך המגע לזעזוע פיזי קיצוני. הדבר עלול לגרום נזק לחיישן המגע.




- תקלה של מסך המגע עלולה להתרחש אם תשתמש במכשיר בקרבת חומרים מגנטיים, מתכתיים או מוליכים.
- אם אתה משתמש במכשיר בתנאי תאורה בוהקת, כגון אור שמש ישיר, ייתכן שהמסך לא יהיה גלוי, בהתאם למיקום שלך. השתמש במכשיר במיקום מוצל או במיקום עם תאורת סביבה שאינה בוהקת מדי אך מוארת במידה שמספיקה לקרוא ספרים.
- אל תפעיל כוח רב מדי בעת לחיצה על המסך.
- הקש בעדינות עם קצה האצבע על האפשרות הרצויה.
- ייתכן שבקרת המגע לא תפעל כראוי אם תקיש על המסך עם הציפורן או כשאתה לובש כפפות.
- ייתכן שבקרת המגע לא תפעל כראוי כאשר המסך לח או רטוב.
- ייתכן שמסך המגע לא יפעל כראוי אם יש על המסך ציפוי מגן או שחיברת אל המכשיר אביזר שנרכש בחנות מקוונת או פיזית שאינה מתמחה.
- הצגת תמונה סטטית לפרקי זמן ארוכים עלולה לגרום לדמויות גרר או לצריבת התמונה במסך. כבה את המסך או הימנע מלהציג את אותה תמונה לזמן ארוך כאשר אינך משתמש במכשיר.



מסך ראשי

סקירה כללית של המסך הראשי

המסך הראשי הוא נקודת המוצא שממנה ניתן לגשת לפונקציות וליישומים השונים במכשיר. הקש על  בכל מסך כדי לעבור היישר אל המסך הראשי.

תוכל לנהל את כל היישומים והווידג'טים במסך הראשי. החלק את המסך לשמאל או לימין כדי להציג במבט מהיר את כל היישומים המותקנים.

פריסת המסך הראשי

ניתן להציג את כל היישומים ולארגן וידג'טים ותיקיות במסך הראשי.



• המסך הראשי עשוי להשתנות, בהתאם לספק השירות או לגרסת התוכנה שברשותך.

- **שורת המצב:** הצג את סמלי המצב, השעה ורמת הטעינה של הסוללה.
- **וידג'ט מזג אוויר:** הצג את נתוני מזג האוויר והשעה עבור אזור מסוים.

- **וידג'ט חיפוש ב-Google:** בצע חיפוש ב-Google על-ידי הזנת מילות מפתח מדוברות או כתובות.
- **תיקייה:** צור תיקיות כדי לקבץ יישומים על פי העדפותיך.
- **סמל דף:** הצג את המספר הכולל של לוחות המסך הראשי. הקש על סמל הדף הרצוי כדי לעבור אל הדף שבחרת. הסמל שמשקף את הלוח הנוכחי יסומן.
- **אזור הגישה המהירה:** קבע יישומים ראשיים בתחתית המסך כך שתוכל לגשת אליהם מכל אחד מהלוחות של המסך הראשי.
- **לחצני תצוגה**

- < : חזור למסך הקודם. סגור את לוח המקשים או את החלונות המוקפצים.

- ○ : הקש כדי לעבור למסך הראשי. כדי להפעיל את החיפוש של Google, הקש הקשה ממושכת.

- □ : הקש כדי להציג רשימה של היישומים שהיו בשימוש לאחרונה או הפעל יישום מתוך הרשימה. כדי למחוק את כל היישומים שהיו בשימוש לאחרונה, הקש על **נקה הכל**. כדי להשתמש בשני יישומים בו-זמנית עם תכונת החלונות המרובים, הקש הקשה ממושכת על הסמל בזמן השימוש ביישום.


- ⇄ : בחר באיזה כרטיס SIM בכוונתך להשתמש. הקש והחזק כדי לקבוע את ההגדרות של כרטיס SIM כפול.

עריכת לחצני התצוגה

תוכל לסדר מחדש את לחצני התצוגה או להוסיף פונקציות בשימוש נפוץ לאזור לחצני התצוגה.

הקש על ○ < **הגדרות** < **תצוגה** < **לחצני תצוגה** < **שילוב לחצנים** והתאם אישית את ההגדרות.


- כמה פונקציות, כולל QSlide, לוח התראה ו-Capture+, מסופקות. ניתן להוסיף חמישה פריטים לכל היותר.



סמלי מצב

כאשר מופעלת התראה על הודעה שלא נקראה, אירוע בלוח השנה או התראה של שעון מעורר, בשורת המצב מוצג סמל ההתראה התואם. בדוק את מצב המכשיר על-ידי צפייה בסמלי ההתראות המוצגים בשורת המצב.


אין אות	
נתונים משודרים כרגע דרך הרשת	
התראה מוגדרת	
מצב רטט מופעל	
Bluetooth מופעל	
מחובר למחשב דרך USB	
רמת הסוללה	
מצב טיסה מופעל	
שיחות שלא נענו	
Wi-Fi מחובר	
מצב השתק מופעל	
GPS מופעל	
נקודה חמה מופעלת	


כרטיס SIM חסר	
NFC פועל	

- ייתכן שכמה מהסמלים הללו ייראו שונים או לא יופיעו כלל, בהתאם למצב המכשיר שלך. התייחס לסמלים בהתאם לסביבה האמתית ולאזור שבהם אתה משתמש במכשיר ובהתאם לספק השירות.
- הסמלים המוצגים עשויים להשתנות, בהתאם לאזור או לספק השירות.

חלונית ההתראות

תוכל לפתוח את לוח ההתראות על-ידי גרירת שורת המצב כלפי מטה במסך הראשי.

- כדי לפתוח את רשימת הסמלים לגישה מהירה, גרור את לוח ההתראות כלפי מטה או הקש על .
- כדי לסדר מחדש, להוסיף או להסיר סמלים, הקש על **ערוך**.
- אם תקיש הקשה ארוכה על הסמל, מסך ההגדרות של הפונקציה המתאימה יופיע.



שינוי כיוון המסך

תוכל להגדיר שכיוון המסך ישתנה באופן אוטומטי, בהתאם לכיוון הפיזי של המכשיר.


בלוח ההתראות, הקש על **סיבוב** ברשימת סמלי הגישה המהירה. לחלופין, הקש על \odot < **הגדרות** < **תצוגה** והפעל את **סיבוב מסך אוטומטי**.




עריכת המסך הראשי

במסך הראשי, הקש הקשה ממושכת על אזור ריק ובחר את הפעולה הרצויה.

- כדי לסדר מחדש את הלוחות של המסך הראשי, הקש הקשה ארוכה על לוח ולאחר מכן גרור אותו למיקום אחר.
 - כדי להוסיף וידג'יט למסך הראשי, הקש הקשה ממושכת על אזור ריק במסך הבית ולאחר מכן בחר **וידג'יטים**.
 - כדי לשנות ערכת נושא, הקש הקשה ממושכת על אזור ריק במסך הבית ולאחר מכן בחר **ערכת נושא**.
- אתה יכול גם להקיש על \odot < **הגדרות** < **תצוגה** < **ערכת נושא**, ולאחר מכן לבחור בערכת נושא להחלה על המכשיר.

- כדי לקבוע את תצורת ההגדרות של המסך הראשי, הקש הקשה ממושכת על אזור ריק במסך הבית ולאחר מכן בחר **הגדרות מסך בית**. לפרטים, ראה **הגדרות מסך בית**.
- כדי להציג או להתקין מחדש את היישומים שהוסרו, גע והחזק אזור ריק במסך הראשי, ולאחר מכן בחר באפשרות **יישום סל המיחזור**. ראה **יישום סל המיחזור** לפרטים.
- כדי לשנות את מסך ברירת המחדל, גע והחזק אזור ריק במסך הראשי, עבור אל המסך הרצוי, הקש על , ולאחר מכן הקש על המסך פעם נוספת.




מסך ברירת המחדל

צפייה בערכת הנושא של הרקע

תוכל להציג את תמונת הרקע בלבד על-ידי הסתרת היישומים והווידג'טים במסך הראשי.

הרחק את שתי האצבעות על המסך הראשי.

- כדי לחזור אל מסך היישומים והווידג'טים המקורי, בצע תנועת צביטה במסך הראשי או הקש על .



הזזת יישומים במסך הראשי

במסך הראשי, הקש הקשה ארוכה על יישום ולאחר מכן גרור אותו למיקום אחר.

- כדי להשאיר יישומים בשימוש נפוץ בתחתית המסך הראשי, לחץ לחיצה ארוכה על יישום וגרור אותו לאזור הגישה המהירה שבתחתית המסך.
- כדי להסיר סמל מאזור הגישה המהירה, גרור אותו אל המסך הראשי.

שימוש בתיקיות מתוך המסך הראשי

יצירת תיקיות

במסך הראשי, הקש הקשה ארוכה על יישום ולאחר מכן גרור אותו מעל יישום אחר.

- פעולה זו תיצור תיקייה חשה והיישום יתווסף אליה.

עריכת תיקיות

במסך הראשי, הקש על תיקייה ובצע אחת מהפעולות הבאות.

- כדי לערוך את שם וצבע התיקייה, הקש על שם התיקייה.
- כדי להוסיף יישומים, הקש הקשה ממושכת על יישום ולאחר מכן גרור אותו מעל התיקייה כדי לשחרר אותו.
- כדי להסיר יישום מהתיקייה, הקש הקשה ארוכה על היישום וגרור אל מחוץ לתיקייה. אם היישום שהסרת הוא היישום היחיד שהיה בתיקייה, התיקייה תוסר באופן אוטומטי.
- באפשרותך גם להוסיף או להסיר יישומים לאחר הקשה על + בתיקייה.

הגדרות מסך בית

תוכל להתאים אישית את הגדרות המסך הראשי.

1 הקש על \odot < הגדרות < תצוגה < מסך ראשי.

2 התאם אישית את ההגדרות הבאות:

- **בחר בית:** בחר מצב של המסך הראשי.
- **טפט:** שנה את טפט הרקע של המסך הראשי.
- **אפקט בהחלפת מסכים:** בחר אפקט שיוחל כאשר לוח המסך הראשי מתחלף.
- **צורות סמלים:** בחר אם ברצונך שלסמלים יהיו פינות מרובעות או מעוגלות.
- **סדר את היישומים לפי:** הגדר כיצד יתבצע מיון של יישומים במסך הראשי.

- **רשת:** שנה את מצב סידור היישומים עבור המסך הראשי.
- **הסתר יישומים:** בחר אילו יישומים ברצונך להסתיר ממסך הבית.
- **לולאה רציפה:** הפעל כדי לאפשר גלילה מתמשכת במסך הראשי (חזרה למסך הראשון לאחר המסך האחרון).
- **Smart Bulletin:** השתמש במסך הראשי כדי להציג מידע מותאם אישית, בהתאם לצרכיך.
- **חפש:** חפש ע"י החלקת אצבע כלפי מטה במסך הבית.

נעילת מסך

סקירה כללית של נעילת המסך

- מסך המכשיר נכבה וננעל כאשר לוחצים על מקש הפעלה/נעילה. בנוסף, המסך נכבה וננעל לאחר שהמכשיר לא היה פעיל במשך פרק זמן שצוין.
- אם תלחץ על מקש הפעלה/נעילה כאשר לא מוגדרת נעילת מסך, המסך הראשי יופיע באופן מיידי.
- כדי להבטיח שהמכשיר יהיה מאובטח ולמנוע גישה לא רצויה למכשיר, הגדר נעילת מסך.

- נעילת מסך מונעת קלט מגע מיותר על מסך המכשיר ומצמצמת את צריכת הסוללה. אנו ממליצים להפעיל את נעילת המסך כאשר אינך משתמש במכשיר.



הגדרת נעילת מסך

לרשותך מספר אפשרויות שונות לנעילת המסך.

1 הקש על  < הגדרות < תצוגה < מסך נעילה < בחירת נעילת מסך ולאחר מכן בחר את השיטה המועדפת עליך.

2 התאם אישית את ההגדרות הבאות:

- **ללא:** ביטול פונקציית נעילת המסך.
- **החלקה:** החלק על המסך כדי לבטל את נעילת המסך.
- **Knock Code:** הקש על השטחים במסך לפי תבנית כדי לבטל את נעילת המסך.
- **תבנית:** צייר תבנית לביטול נעילת המסך.
- **קוד PIN:** הזן סיסמה מספרית לביטול נעילת המסך.
- **סיסמה:** הזן סיסמה אלפאנומרית לביטול נעילת המסך.
- **טביעות אצבע:** בטל את נעילת המסך באמצעות טביעת האצבע.
- **אפשר תווי פנים:** בטל את נעילת המסך על ידי זיהוי פניך.

• אם תנסה לבטל את נעילת המכשיר 5 פעמים באופן שגוי, המסך ייחסם למשך 30 שניות.



הגדרות אתחול מאובטח

כאשר אתה בוחר Knock Code, תבנית, קוד PIN או סיסמה כשיטה לנעילת מסך, אתה יכול להגדיר את המכשיר כך שיינעל בכל הפעלה שלו כדי לאבטח נתונים.

- לא תוכל להשתמש בכל הפונקציות, למעט שיחת החירום, עד אשר תבטל את נעילת המכשיר.
- אם תשכח את הסיסמה לביטול הצפנה, לא תוכל לשחזר נתונים מוצפנים ומידע אישי.

הגדרות נעילת מסך

תוכל להתאים אישית את הגדרות נעילת המסך.

1 הקש על  < הגדרות < תצוגה < מסך נעילה.

2 התאם אישית את ההגדרות הבאות:

- **בחירת נעילת מסך:** בחר שיטה לנעילת מסך.
- **תווי פנים:** בטל את נעילת המסך על ידי זיהוי פניך. לפרטים, ראה **סקירה כללית של תכונת זיהוי הפנים**.
- **Smart Lock:** בחר פריטי 'טריגר', שההתרחשות של אחד מהם תגרום לביטול אוטומטי של נעילת המכשיר.
- **טפט:** שנה את טפט הרקע של מסך הנעילה.
- **שעון:** בחר את מיקום השעון במסך הנעול.
- **קיצורי דרך:** הוסף קיצור דרך יישום וגש ישירות ליישום מתוך מסך הנעילה על-ידי גרירת קיצור הדרך של היישום על המסך.
- **אפקט החלקת מסך:** הגדר אפקטי מעבר של המסך שיוחלו כאשר נעילת המסך תבוטל.
- **אנימצית מזג אוויר:** הצג הנפשות של מזג האוויר עבור המיקום הנוכחי במסך הנעילה.
- **פרטי יצירת קשר עבור טלפון שאבד:** הצג פרטי יצירת קשר למצב חירום במסך הנעילה.
- **זמן לנעילה:** הגדר את משך הזמן ללא פעילות, שלאחריו המכשיר יינעל באופן אוטומטי.
- **נעילה באמצעות לחצן ההפעלה:** נעל באופן מידי את המסך בעת לחיצה על מקש הפעלה/נעילה.

• פריטי ההגדרה הזמינים עשויים להשתנות, בהתאם לשיטת נעילת המסך שנבחרה.



ניתן להקיש הקשה כפולה על המסך כדי להפעיל או לכבות אותו.

- אפשרות זו זמינה אך ורק במסך הראשי שסופק על-ידי LG. היא לא תפעל כראוי במפעיל מותאם אישית או במסך ראשי שהותקן על-ידי המשתמש.
- בעת הקשה על המסך, השתמש בקצה האצבע. אל תשתמש בציפורן.
- כדי להשתמש בתכונה הפעל מסך, ודא שחיישן הקרובה/תאורה לא נחסם על-ידי מדבקה או כל חומר זר אחר.

הפעלת המסך

- הקש פעמיים באמצע המסך
- הקשה על החלק העליון או התחתון של המסך עשויה להקטין את שיעור זיהוי הפעולה.

כיבוי המסך

- הקש פעמיים על שטח ריק במסך הראשי ובמסך הנעילה.
- לחלופין, הקש הקשה כפולה על שטח ריק בשורת המצב.

Knock Code

תוכל לבטל את נעילת המסך על-ידי יצירת Knock Code משלך. כאשר המסך נעול, תוכל לגשת ישירות למסך הראשי על-ידי הקשה על המסך ברצף שצוין.

- תוכל להשתמש ב-Knock Code יחד עם התכונה הפעל מסך.
- הקפד להשתמש בקצה האצבע בעת הקשה על המסך.

יצירת Knock Code

- 1 הקש על \bigcirc < הגדרות < תצוגה < מסך נעילה < בחירת נעילת מסך < Knock Code.
- 2 הקש על הריבועים בתבנית הרצויה לך כדי ליצור Knock Code ולאחר מכן הקש על **הבא**.
- 3 לאימות, הזן שוב את ה-Knock Code ולאחר מכן הקש על **אשר**.

ביטול נעילת המסך עם Knock Code

- בטל את נעילת המסך על ידי הזנת ה-Knock Code שיצרת.
- אתה יכול גם להזין את Knock Code במסך המגע כאשר המסך כבוי.
- ניתן גם להזין Knock Code כאשר מסך הנעילה מופעל.

הצפנת כרטיס זיכרון

ניתן להצפין את הנתונים השמורים בכרטיס הזיכרון כדי להגן עליהם. לא ניתן לגשת לנתונים המוצפנים בכרטיס הזיכרון ממכשיר אחר.

- 1 הקש על \bigcirc < הגדרות < כללי < טביעות אצבע ואבטחה < הצפן אחסון כרטיס SD.
 - 2 קרא את הסקירה הכללית של הצפנת כרטיס הזיכרון המוצגת על המסך ולאחר מכן הקש על **המשך** כדי להמשיך.
 - 3 בחר אפשרות והקש על **הצפנה**.
- **הצפנת קובץ חדש:** הצפן רק את הנתונים שנשמרו בכרטיס הזיכרון לאחר ההצפנה.
 - **הצפנה מלאה:** הצפן את כל הנתונים השמורים כעת בכרטיס הזיכרון.
 - **ללא קבצי מדיה:** הצפן את כל הקבצים, למעט קובצי מדיה כמו מוסיקה, תמונות וסרטוני וידאו.

- כדי להצפין את כרטיס הזיכרון, ודא שסוג נעילת המסך הוא קוד PIN או סיסמה.
- לאחר שיחל תהליך הצפנת כרטיס הזיכרון, פונקציות מסוימות לא יהיו זמינות.
- כיווי המכשיר תוך כדי תהליך ההצפנה יגרום לכישלון התהליך ועלול לגרום נזק לנתונים מסוימים. לכן הקפד לוודא שהסוללה טעונה ברמה מספקת לפני שאתה מתחיל בתהליך ההצפנה.
- הקבצים המוצפנים יהיו נגישים רק מהמכשיר שבו הקבצים הוצפנו.
- לא ניתן להשתמש בכרטיס הזיכרון המוצפן במכשיר אחר של LG. כדי להשתמש בכרטיס הזיכרון המוצפן במכשיר ניד אחר, אתחל את הכרטיס.
- ניתן להפעיל הצפנת כרטיס זיכרון אפילו כאשר אין כרטיס זיכרון בתוך המכשיר. כל כרטיס זיכרון שיותקן לאחר ההצפנה יוצפן באופן אוטומטי.

יצירת צילומי מסך

באפשרותך לצלם תמונה של המסך הנוכחי שמוצג במכשיר.


באמצעות קיצור דרך

לחץ לחיצה ארוכה (לפחות שתי שניות) על מקש ההפעלה/נעילה ועל מקש החלשת עוצמת הקול (-) במקביל.

- תוכל לראות תמונות מסך דרך התיקייה **Screenshots** ב-גלריה.

באמצעות Capture+

במסך שבו ברצונך ליצור צילום מסך, גרור את שורת המצב כלפי מטה ולאחר מכן הקש על .

- כאשר המסך כבוי או נעול, קבל גישה אל **Capture+** בשתי לחיצות על מקש הגברת עוצמת הקול (+). כדי להשתמש בתכונה זו, הקש על  < **הגדרות** < **כללי** והפעל את **מקש קיצור דרך**.
- לפרטים, ראה **כתיבת הערות על צילום מסך**.


הזנת טקסט


שימוש במקלדת החכמה

תוכל להשתמש במקלדת Smart כדי להזין ולערוך טקסט. באמצעות מקלדת Smart, תוכל להציג טקסט תוך כדי הקלדה, בלי שתצטרך לעבור בין המסך למקלדת קונבנציונלית. הדבר יאפשר לך לאתר בקלות שגיאות ולתקן אותן תוך כדי הקלדה.

הזנת הסמן

מקלדת Smart מאפשרת לך להזין את הסמן למיקום המדויק שאתה רוצה. בעת הקלדת טקסט, הקש הקשה ממושכת על מקש הרווח ולאחר מכן גרור שמאלה או ימינה.




• אפשרות זו זמינה רק במקלדות QWERTY. 

הצעת מילים

מקלדת Smart מנתחת באופן אוטומטי את דפוסי השימוש שלך כדי להציע מילים בשימוש נפוץ תוך כדי הקלדה. ככל שתשתמש יותר במכשיר, כך ההצעות יהיו מדויקות יותר.

הזן טקסט ולאחר מכן הקש על מילה מוצעת או גרור בעדינות את הצד השמאלי או הימני של המקלדת כלפי מעלה.


- המילה שנבחרה תוזן באופן אוטומטי. אינך צריך להקליד באופן ידני כל אות של המילה.



שינוי הפריסה של מקלדת QWERTY

תוכל להוסיף, למחוק או לסדר מחדש מקשים בשורה התחתונה של המקלדת.

- 1 הקש על \odot < הגדרות < כללי < שפה ומקלדת < מקלדת LG < גובה ופריסת המקלדת < פריסת המקלדת QWERTY.
לחלופין, הקש על \odot במקלדת והקש על גובה ופריסת המקלדת < פריסת המקלדת QWERTY.
- 2 הקש על מקש בשורה התחתונה ולאחר מכן גרור אותו למיקום אחר.



- אפשרות זו זמינה אך ורק במקלדות QWERTZ, QWERTY ו-AZERTY-1.
- ייתכן ששפות מסוימות אינן תומכות בפונקציה זו.



התאמה אישית של גובה המקלדת

תוכל להתאים אישית את גובה המקלדת כדי להבטיח שתוכל להקליד בנוחות.

- 1 הקש על < הגדרות < כללי < שפה ומקלדת < מקלדת LG < גובה ופריסת המקלדת < גובה המקלדת. לחלופין, הקש על במקלדת והקש על גובה ופריסת המקלדת < גובה המקלדת.
- 2 כוונן את גובה המקלדת.



בחירת מצב מקלדת לרוחב


תוכל לבחור מצב מקלדת לרוחב מבין כמה אפשרויות.

- 1 הקש על < הגדרות < כללי < שפה ומקלדת < מקלדת LG < גובה ופריסת המקלדת < סוג מקלדת לרוחב. לחלופין, הקש על במקלדת והקש על גובה ופריסת המקלדת < סוג מקלדת לרוחב.
- 2 בחר מצב מקלדת.

פיצול המקלדת

תוכל לפצל את המקלדת לשניים ולמקם את שני החלקים בשני צדי המסך כאשר המסך נמצא במצב לרוחב.

הקש על  < הגדרות < כללי < שפה ומקלדת < מקלדת LG < גובה ופריסת המקלדת < פיצול המקלדת.

לחלופין, הקש על  במקלדת והקש על גובה ופריסת המקלדת < פיצול המקלדת.

- סובב את המכשיר למצב 'לרוחב' כדי לפצל את המקלדת לשני הצדדים. כדי למזג או לפצל את המקלדת, בצע באצבעותיך תנועת צביטה או פריסה על המקלדת.



מצב תפעול ביד אחת

תוכל להזיז את המקלדת לצד אחד של המסך כך שתוכל להשתמש במקלדת ביד אחת.

1 הקש על  < הגדרות < כללי < שפה ומקלדת < מקלדת LG < גובה ופריסת המקלדת < תפעול ביד אחת.


לחלופין, הקש על  במקלדת והקש על גובה ופריסת המקלדת < תפעול ביד אחת.

2 לחץ על החץ המוצג לצד המקלדת כדי להזיז את המקלדת בכיוון הרצוי.



הזן טקסט באמצעות הקול

במקלדת, הקש הקשה ארוכה על  ובחר .

- כדי לאפשר זיהוי מיטבי של פקודות קוליות, דבר בצורה ברורה.
- כדי להזין טקסט בדיבור, ודא שהמכשיר מחובר לרשת.
- כדי לבחור את השפה שתוגדר לזיהוי קולי, הקש על  < **שפות** במסך הזיהוי הקולי.
- התמיכה בפונקציה זו או רשימת השפות הנתמכות הם בהתאם לאזור השירות.

הוספת שפות למקלדת

באפשרותך להפוך שפות נוספות לזמינות לקלט המקלדת.

1 הקש על  < **הגדרות** < **כללי** < **שפה ומקלדת** < **מקלדת** < **LG** < **בחר שפות**.

2 בחר את השפות שברצונך להפוך לזמינות.

העתקה והדבקה

באפשרותך להעתיק או לגזור טקסט מתוך יישום ולהדביק אותו באותו יישום. לחלופין, אתה יכול להפעיל יישומים אחרים ולהדביק את הטקסט בתוכם.

1 הקש הקשה ארוכה ליד הטקסט שברצונך להעתיק או לגזור.

2 גרור את  /  כדי לציין את האזור שברצונך להעתיק או לגזור.

3 בחר **גזור** או **העתק**.





• הטקסט שנגזר או הועתק נוסף באופן אוטומטי ללוח.


4 הקש הקשה ארוכה על חלון הזנת הקלט ולאחר מכן בחר **הדבק**.

- אם אין פריט שהועתק או נגזר, האפשרות **הדבק** לא תופיע.

אחסון זמני

כאשר אתה מעתיק או גוזר תמונה או טקסט, הם נשמרים באופן אוטומטי במגש קליפים, וניתן להדביק אותם בכל שטח פנוי בכל עת.

- 1 במקלדת, הקש הקשה ארוכה על  ובחר  לחלופין, הקש הקשה ארוכה על חלון הזנת הקלט ולאחר מכן בחר **אחסון זמני**.
- 2 בחר והדבק פריט מתוך מגש הקליפים.
 - ניתן לשמור 20 פריטים לכל היותר במגש הקליפים.
 - הקש על  כדי לנעול פריטים שמורים על מנת להבטיח שהם לא יימחקו גם לאחר שבוצעה חריגה מהכמות המרבית המותרת. ניתן לנעול עשרה פריטים לכל היותר. כדי למחוק פריטים נעולים, תחילה בטל את נעילתם.
 - הקש על  כדי למחוק את הפריטים השמורים במגש הקליפים.


 • ייתכן שיישומים מסוימים שהורדת לא יתמכו במגש הזמני.

שיתוף תוכן

הפעלת תוכן ממכשיר אחר

תוכל להפעיל תמונות, סרטוני וידאו או שירים שנשמרו במכשיר באמצעות מכשיר טלוויזיה.

- 1 חבר את הטלוויזיה והמכשיר שלך לאותה רשת Wi-Fi.
- 2 בזמן הצגת הפריטים מהיישום **גלריה** או **נגן מוסיקה**, הקש על **< נגן בהתקן אחר**.
- 3 בחר את הטלוויזיה שאתה מעוניין להתחבר אליה.

 • לשימוש עם Chromecast, שירותי Google Play חייבים להיות עדכניים.

הצגת תוכן ממכשירים סמוכים

באפשרותך להציג תוכן ממגוון מכשירים, כגון מחשב, NAS או מכשיר נייד, באמצעות היישומים גלריה או נגן מוסיקה.

חיבור המכשירים

חבר את המכשיר שלך ומכשיר אחר, התומכים שניהם בפונקציית DLNA, לאותה רשת אלחוטית.

• ודא שהאפשרות (DLNA) File sharing מופעלת הן במכשיר והן במכשיר המחובר.

חיפוש מכשירים סמוכים

באפשרותך להציג רשימה של מכשירי DLNA באותה רשת על-ידי בחירה בכרטיסייה **מכשירים סמוכים** בכל יישום. השתמש בתוכן ממכשירים סמוכים כאילו היית משתמש בו במכשיר שלך.

שליחה או קבלה של קבצים

באפשרותך לשתף קבצים בין המכשיר שלך ומכשיר LG אחר, או טאבלט או מחשב.

שליחת קבצים

מתוך היישום **גלריה**, **מנהל הקבצים** או **נגן מוסיקה**, הקש על **:** < **שתף** או על **⌘**, ולאחר מכן בחר מכשיר ברשימת שיתוף הקבצים.

קבלת קבצים

גרור את שורת המצב כלפי מטה והקש על **✓**, לאחר מכן הקש על **שיתוף קבצים**.


אם המכשיר שלך אינו תומך בתכונת שיתוף הקבצים, הקש על **○** < **הגדרות** < **רשתות** < **שתף והתחבר** < **שיתוף קבצים** < **SmartShare Beam**.

• ודא שהמכשיר מחובר לאותה רשת אלחוטית שאליה מחובר מכשיר היעד להעברת הקבצים.

• ודא שהאפשרות שיתוף קבצים מופעלת הן במכשיר שלך והן במכשיר היעד.

שליחת קבצים למחשב


אתה יכול לשלוח במהירות קבצים גדולים למחשב.

- 1 התקן את LG Bridge במחשב.
- 2 הפעל את LG Bridge במחשב, ולאחר מכן היכנס באמצעות חשבון LG שלך.
- 3 הקש על  < הגדרות < רשתות < שתף והתחבר < LG AirDrive, ולאחר מכן היכנס באמצעות חשבון LG שלך.
- 4 בחר מחשב ברשימת השיתוף מתוך היישומים גלריה, מנהל הקבצים ונגן מוסיקה.

- ניתן להוריד את LG Bridge מאתר האינטרנט של LG Electronics (www.lg-mobile.co.il).
- כשאתה מעביר קבצים מהמכשיר למחשב בזמן ש-LG Bridge אינו פועל, הם יאוחסנו למשך 7 ימים באחסון הזמני. קבצים המאוחסנים באופן זמני נשמרים באופן אוטומטי במחשב כשאתה מפעיל את LG Bridge בתוך 7 ימים.

צפייה בתוכן מהענן

תוכל להציג ישירות את התוכן השמור בחשבון הענן שלך, בלי להוריד אותו אל המכשיר.

- 1 ביישום גלריה, נגן מוסיקה או מנהל הקבצים, בחר  < ענן.
- 2 בחר חשבון ענן והיכנס.
- 3 שמור או הפעל תוכן בענן.

נא לא להפריע

תוכל להגביל או להשתיק התראות כדי למנוע הפרעות במשך פרק זמן מסוים.

- 1 הקש על < הגדרות < צליל והתראה < נא לא להפריע ולאחר מכן הקש על כדי להפעיל תכונה זו.
- 2 הקש על **צלילים ורטט** ובחר את המצב הרצוי:
 - **עדיפות בלבד**: קבל התראות קוליות או התראות ברטט עבור היישומים שנבחרו. התראות ימשיכו להישמע גם כאשר הפונקציה עדיפות בלבד מופעלת.
 - **שקט מוחלט**: השבת את הקול והרטט.

03

יישומים
שימושיים

התקנה והסרת התקנה של יישומים

התקנת יישומים

- היכנס לחנות יישומים כדי לחפש ולהוריד יישומים.
- תוכל להשתמש בחנויות כמו SmartWorld, חנות Play או חנות היישומים של ספק השירות שלך.

- ייתכן שחנויות יישומים מסוימות ידרשו ממך ליצור חשבון ולהיכנס לחשבון זה.
- יישומים מסוימים עשויים לגבות תשלום.
- אם אתה משתמש בנתונים לנייד, ייתכן שתחויב בתשלום בגין השימוש בנתונים, בהתאם לתוכנית המחירים שלך.
- התמיכה בפונקציית SmartWorld אינה מובטחת ותלויה באזור או בספק השירות.


הסרת התקנה של יישומים

הסר את ההתקנה של יישומים שאינך משתמש בהם עוד מהמכשיר שלך.

הסרת התקנה עם מחוות ההקשה הממושכת

- במסך הראשי, גע והחזק את היישום כדי להסיר את התקנתו, ולאחר מכן גרור אותו מעל האפשרות **מחק** בקצה העליון של המסך.
- אתה יכול לגעת ביישום ולהחזיק אותו ואז לשחרר, ולאחר מכן להקיש על  כדי להסיר את התקנתו.
- תוכל להתקין מחדש יישומים שהסרת אם חלפו מאז ההסרה פחות מ-24 שעות. ראה **יישום סל המיחזור** לפרטים.

הסרת התקנה באמצעות תפריט ההגדרות



הקש על  < הגדרות < כללי < יישומים, בחר יישום ולאחר מכן הקש על **הסר התקנה**.


הסרת התקנה של יישומים מחנות היישומים

כדי להסיר התקנה של יישום, עבור לחנות היישומים שממנה הורדת אותה, והסר את התקנתו.

יישום סל המיחזור

תוכל לראות את היישומים שהוסרו במסך הבית. באפשרותך גם להתקין מחדש יישומים שהסרת, אם חלפו מאז ההסרה פחות מ-24 שעות.

- 1 הקש על  < **כלי ניהול** > **יישום סל המיחזור**. אתה יכול גם לגעת ולהחזיק אזור ריק במסך הראשי, ולאחר מכן להקיש על **יישום סל המיחזור**.
- 2 הפעל את הפונקציה הרצויה:
 - **שחזר**: התקן מחדש את היישום הרצוי.
 - : הסר מהמכשיר לצמיתות את היישומים שביטלת את התקנתם.





- יישומים שתסיר יימחקו מהמכשיר באופן אוטומטי 24 שעות לאחר הסרתם. אם תרצה להתקין מחדש יישומים שהוסרו, תצטרך להוריד אותם מחדש מחנות היישומים. 
- תכונה זו מופעלת רק במסך הראשי שהוגדר כברירת מחדל. אם תסיר יישומים דרך מסך EasyHome או מפעיל יישומים אחר, הם יוסרו מהמכשיר באופן מידי ולצמיתות.


טלפון

שיחה קולית

בצע שיחת טלפון על-ידי שימוש באחת השיטות הזמינות, כמו הזנה דינית של מספר טלפון וביצוע שיחה מרשימת אנשי הקשר או מרשימת השיחות האחרונות.

ביצוע שיחה מהמקלדת


- 1 הקש על  <  < **חייג**.
- 2 בצע שיחה באמצעות שיטה לבחירתך:
 - הזן מספר טלפון ולאחר מכן הקש על .
 - הקש הקשה ממושכת על מספר חיוג מהיר.
 - חפש איש קשר על-ידי הקשה על האות הראשונה בשמו ברשימת אנשי הקשר, ולאחר מכן הקש על .

- כדי להזין את התו "+" לצורך שיחה בינלאומית, הקש הקשה ממושכת על הספרה 0. 
- ראה **הוספת אנשי קשר** כדי ללמוד כיצד להוסיף מספרי טלפון לרשימת מספרי החיוג המהיר.


ביצוע שיחה מרשימת אנשי הקשר

- 1 הקש על  <  < **אנשי קשר**.
- 2 ברשימת אנשי הקשר, בחר איש קשר והקש על .

מענה לשיחה


- כדי לענות לשיחה, גרור את  במסך השיחה הנכנסת.
- כאשר אזוניות סטריאו מחוברות, תוכל לבצע שיחת באמצעות הלחצן חייג/סיום באזוניות.
- כדי לסיים שיחה בצורה פשוטה על-ידי לחיצה על מקש הפעלה/נעילה, הקש על  < **הגדרות** < **רשתות** < **הגדרות שיחה** < **כללי** < **מענה וסיום שיחות**, ולאחר מכן הפעל את **סיים שיחות באמצעות מקש ההפעלה**.



דחיית שיחה

- כדי לדחות שיחה נכנסת, גרור את  על מסך השיחה הנכנסת.
- כדי לשלוח הודעת דחייה, גרור את אפשרות הודעת הדחייה  על המסך.
- כדי להוסיף או לערוך הודעת דחייה, הקש על  < הגדרות < רשתות < הגדרות שיחה < כללי < חסימת שיחה ודחיית עם הודעה < דחה שיחה ושלח הודעה.
- כאשר נכנסת שיחה, לחץ על לחצן הגברת העוצמה (+), על לחצן הנמכת העוצמה (-) או על לחצן ההפעלה/נעילה כדי להשתיק את הרינגטון או הרטט, או כדי להעביר את השיחה להמתנה.

בדיקת שיחה נכנסת בזמן שימוש ביישום



כאשר נכנסת שיחה בזמן שימוש ביישום, ניתן להציג התראה בחלון מוקפץ בקצה העליון של המסך. אתה יכול לקבל את השיחה, לדחות את השיחה או לשלוח הודעה מתוך המסך הקופץ.



- הקש על  < הגדרות < רשתות < הגדרות שיחה < כללי < עוד ולאחר מכן הקש על חלונית שיחה נכנסת  כדי לבטל את ההפעלה.

צפייה בשיחות שלא נענו


במקרה של שיחה שלא נענתה, הסמל ✕ יופיע בשורת המצב, בחלק העליון של המסך.

כדי להציג את פרטי השיחה שלא נענתה, גרור את שורת המצב כלפי מטה. לחלופין, הקש על  <  < **יומן שיחות**.

הפונקציות הנגישות במהלך שיחה


במהלך שיחה, ניתן לגשת אל מגוון פונקציות על-ידי הקשה על הלחצנים במסך:


- **אנשי קשר**: הצג את רשימת אנשי הקשר במהלך שיחה.
- **ניתוק**: סיים שיחה.
- **מקשים**: הצג או הסר את מקשי החיוג.
- **רמקול**: הפעל את פונקציית הרמקול.
- **השתק**: השתק את הקול כדי שהצד השני לא ישמע את קולך.
- **Bluetooth**: העבר את השיחה למכשיר Bluetooth משויך ומחובר.
- **⋮**: גישה לאפשרויות שיחה נוספות.

• פריטי ההגדרה הזמינים עשויים להשתנות בהתאם לאזור או לספק השירות. 




ביצוע שיחה בת שלושה משתתפים


במהלך שיחה, תוכל להתקשר לאיש קשר נוסף.

- 1 במהלך שיחה, הקש על **⋮** < **הוסף שיחה**.
- 2 הזן מספר טלפון ולאחר מכן הקש על .
- שתי השיחות יוצגו במסך במקביל והשיחה הראשונה תעבור להתנה.
- 3 כדי להתחיל שיחת ועידה, הקש על **מיוזג שיחות**.

• ייתכן שתחויב בתשלום עבור כל שיחה. לקבלת מידע נוסף, פנה לספק השירות שלך. 



צפייה ברשומות שיחה

- כדי להציג רשומות שיחה אחרונות, הקש על  <  < **יומן שיחות**. לאחר מכן, תוכל להשתמש בפונקציות הבאות:
- כדי להציג רשומות שיחה מפורטות, בחר איש קשר. כדי לבצע שיחה לאיש קשר שנבחר, הקש על .
 - כדי למחוק את כל רשומות השיחה, הקש על **מחק**.

• משך השיחה המוצג עשוי להיות שונה ממשך השיחה המשמש לחיוב. לקבלת מידע נוסף, פנה לספק השירות שלך. 

הגדרת אפשרויות שיחה

באפשרותך בחור באפשרויות שיחה שונות.





- 1 הקש על  <  < **חייג** או על **יומן שיחות**.
- 2 הקש על **הגדרות שיחה** ובחר אפשרויות בהתאם להעדפותיך.

הודעות

שליחת הודעה


באפשרותך ליצור ולשלוח הודעות לאנשי הקשר שלך באמצעות היישום 'הודעות'.

• שליחת הודעות לחו"ל עלולה להיות כרוכה בתשלום נוסף. לקבלת מידע נוסף, פנה לספק השירות שלך. 

- 1 הקש על  < .
- 2 הקש על .
- 3 ציין נמען וצור הודעה.
 - כדי לצרף קבצים, הקש על .
 - כדי לגשת לפריטי תפריט אופציונליים, הקש על **⋮**.
- 4 הקש על **שלח** כדי לשלוח את ההודעה.

קריאת הודעה


תוכל להציג את חליפת ההודעות שלך עם כל איש קשר.

1 הקש על  < .

2 בחר איש קשר מרשימת ההודעות.

קביעת ההגדרות להעברת הודעות

באפשרותך לשנות את הגדרות העברת ההודעות בהתאם להעדפותיך.

1 הקש על  < .

2 הקש על  : < **הגדרות** ברשימת ההודעות.

מצלמה

התחלת המצלמה


תוכל לצלם תמונה או סרטון וידאו כדי להנציח את כל הרגעים החשובים שלך.

הקש על  < .

- לפני שאתה מצלם תמונה או מקליט סרטון וידאו, נקה את עדשת המצלמה במטלית רכה.
- היזהר שלא להכתים את עדשת המצלמה באצבעותיך או באמצעות חומר זר אחר.
- אם רמת הסוללה נמוכה מ-5%, טען את הסוללה לפני השימוש במצלמה.
- התמונות הנכללות במדריך למשתמש זה עשויות להיות שונות מאלה שנמצאות במכשיר בפועל.
- ניתן לצפות בתמונות ובסרטוני וידאו ולערוך אותם בגלריה. לפרטים, ראה **סקירה כללית של הגלריה**.

החלפת מצב במצלמה


באפשרותך לבחור מצב מצלמה המתאים לסביבה שלך כדי לצלם תמונות וסרטונים בקלות ובנוחות. במסך המצלמה, הקש על מצב 'בסיסי' ובחר את המצב הרצוי.




מצב בסיסי

תוכל לצלם תמונות או להקליט סרטוני וידאו על-ידי בחירת מגוון מצבי מצלמה ואפשרויות.

- 1 הפעל את היישום 'מצלמה', ולאחר מכן הקש על **בסיסי** (A).
- 2 כדי לצלם תמונה, הקש על . כדי להקליט סרטון וידאו, הקש על .








צילום תמונה


- 1 בחר מצב מצלמה והקש על העצם שבו ברצונך למקד את המצלמה.
- 2 הקש על  כדי לצלם תמונה.
 - תוכל גם ללחוץ על מקש הנמכת עוצמה (-) או הגברת עוצמה (+) כדי לצלם תמונה.

- כאשר המסך כבוי או נעול, הפעל את המצלמה בשתי לחיצות מהירות על מקש החלשת עוצמת הקול (-). הקש על  < הגדרות < כללי < מקש קיצור דרך.

הקלטת סרטון וידאו

- 1 בחר מצב מצלמה והקש על העצם שבו ברצונך למקד את המצלמה.
- 2 הקש על .
 - | כדי לצלם תמונה תוך כדי צילום סרטון וידאו, הקש על .
 - כדי להשהות את הצילום של סרטון וידאו, הקש על . כדי לחדש את צילום הווידאו, הקש על .
- 3 הקש על  כדי לסיים את צילום סרטון הווידאו.

התאמה אישית של אפשרויות המצלמה


- תוכל להתאים אישית מגוון אפשרויות מצלמה כדי להתאימה לצרכיך.
- הקש על  על המסך.

- האפשרויות הזמינות משתנות בהתאם למצלמה הנבחרת (מצלמה קדמית או אחורית) ולמצב המצלמה שנבחר.

גודל תמונה	בחר ערכים ליחס הרחב-גובה ולגודל בעת צילום תמונות.
רזולוציית הווידאו	בחר ערכים לרזולוציה ולגודל בעת הקלטת סרטוני וידאו.
סרט צילום	הצג את התמונות וסרטוני הווידאו האחרונים שלך לאורך צד המסך.
HDR	קבל תמונות בצבעים מלאי חיים ואפקטים של פיצוי אפילו אם הפריטים צולמו מול האור. תכונות אלה מסופקות בעזרת טכנולוגיית טווח דינמי רחב (HDR) שבה מצוידת המצלמה.
טיימר	הגדר את הטיימר לצילום אוטומטי של תמונות לאחר פרק זמן שצוין.
צמצם קולי	צלם תמונות עם פקודות קוליות.
Tracking focus	כאשר יש נגיעה בנושא, המצלמה עוקבת אחרי אובייקט בתנועה ושומרת על ההתמקדות בו. (זמין כאשר המצלמה הרגילה בשימוש.)
הקלטה יציבה	מזער טשטוש תנועה בזמן הקלטת וידאו.
העדשות מכוסות	תכונה זו מיידעת אותך על כך שהעדשה רחבת הזווית האחורית מכוסה.
תייג מיקומים	שמור את התמונה עם נתוני מיקום GPS.
רשת	הצג קווים מנחים כך שתוכל לצלם תמונות או סרטוני וידאו בהתבסס על קווי ייחוס אופקיים ואנכיים.
הוסף חתימה	הצג חתימה אישית בתמונות.
אחסון	בחר אם ברצונך לאחסן את התמונות וסרטוני הווידאו אחסון פנימי או כרטיס זיכרון. (אפשרות זו זמינה כאשר הוכנס כרטיס זיכרון.)
תצוגה פשוטה	הסתר את כל התפריטים ממסך המצלמה.
עזרה	הוסף עזרה לכל תפריט במצלמה.

אפשרויות נוספות במצלמה הקדמית





התאם אישית את ההגדרות של צילום סלפי. • צילום בתנועת יד: צלם באמצעות התכונה 'צילום בתנועת יד'. • צילום אוטומטי: צלם כאשר המצלמה מזהה פנים.	צילום סלפי
בחר אם להשתמש תצוגת מחווה כדי להציג תמונה שצילמת מיד לאחר הצילום.	תצוגת מחווה
שמור תמונות הפוכות לאחר צילום תמונות סלפי.	שמור הפוך

- בעת שימוש במצלמה הקדמית, אתה יכול לכוונן את המסנן, אפקט התאורה וגוון העור. 

מצבי המצלמה השונים

פנורמה




תוכל ליצור תמונה פנורמית על ידי הזזת המצלמה בכיוון אחד כדי לצלם ולחבר יחד צילומים רציפים של נוף רחב.

- 1 כשאתה במצב 'בסיסי', הקש על  **מצב** < 
- 2 הקש על  ולאחר מכן הזז בקצב איטי את המצלמה בכיוון אחד.
 - הזז את המכשיר בכיוון החץ שמופיע בהנחיה.
- 3 הקש על  כדי להפסיק את לכידת התמונה הפנורמית.



360 פנורמה





אתה יכול ליצור תצלום פנורמה 360° על-ידי הזת המצלמה בכיוון אחד.


- 1 כשאתה במצב 'בסיסי', הקש על **מצב** .
- 2 הקש על  ולאחר מכן הזז בקצב איטי את המצלמה בכיוון אחד.
 - הזז את המכשיר בכיוון החץ שמופיע בהנחיה.
- 3 הקש על  כדי להפסיק צילום פנורמה 360.



מזון


באפשרותך לצלם תמונה ולהקליט סרטון וידאו באמצעות מחוון הבקרה בצד הימני של המסך.

- 1 כשאתה במצב 'בסיסי', הקש על **מצב** .
- 2 כדי לצלם תמונה, הקש על . כדי להקליט סרטון וידאו, הקש על .
- גרור את מחוון הצבע במסך כדי לכוונן את איון הלבן, ובחר את הצבע הטוב ביותר.
- אם פס המחוון בלתי נראה, הקש על  כדי לכוונן את איון הלבן.



תמונה מוקפצת

תוכל לצלם תמונה או להקליט סרטון וידאו הן בזווית הרגילה והן בזווית הרחבה במצלמה הכפולה שבגב המכשיר, כדי לצלם סצינות כאילו הוצבו בתוך המסגרת. הסצינות הנראות במסך הקדמי הקטן יצולמו במצלמה הרגילה ואילו הסצינות הנראות במסך הרקע הגדול יצולמו דרך המצלמה בזווית הרחבה. החלף צורה במסך הקדמי או החל אפקטים שונים כדי לצלם תמונה או סרטון וידאו חושניים.

1 כשאתה במצב 'בסיסי', הקש על **מצב** < .

2 הקש על \vee ובחר בפריסה הרצויה.

3 בחר אפקטים:


• **עין הדג:** החל אפקט של עדשה קמורה על האזור שצולם באמצעות המצלמה בזווית רחבה.

• **שחור-לבן:** החל גווני אפור על האזור שצולם באמצעות המצלמה בזווית רחבה.

• **שוליים דהויים:** הכה את קצוות האזור שצולם באמצעות המצלמה בזווית רחבה.


• **טשטוש עדשה:** טשטש את האזור שצולם באמצעות המצלמה בזווית רחבה.

4 הקש על  כדי לצלם תמונה. כדי להקליט סרטון וידאו, הקש על .




סרטון קצרצר

תוכל לצלם קטעי וידאו קצרים ולהרכיב מהם סרט קצר בן 60 שניות.

- 1 כשאתה במצב 'בסיסי', הקש על **מצב** .
- 2 הקש על .



• הקש על הסמל פעם אחת כדי להקליט קליפ וידאו באורך שלוש שניות. הקש הקשה ארוכה על הסמל כדי ליצור קליפ וידאו ארוך יותר (אורך מרבי: דקה אחת).



- 3 הקש על **שמור**.

הילוך איטי




באפשרותך ליצור סרטון וידאו משעשע על ידי שינוי מהירות התנועה של המצלומים. תכונה זו מאפשרת לצלם וידאו במהירות גבוהה יותר ולאחר מכן להקרין אותו במהירות רגילה, כך שהסרטון ייראה בהילוך איטי.


- 1 כשאתה במצב 'בסיסי', הקש על **מצב** .
- 2 הקש על  והקלט סרטון.
- 3 הקש על  כדי לסיים את צילום סרטון הווידאו.




Time lapse



באפשרותך לצלם סדרה של מסגרות במרווחי זמן קבועים כדי לתעד שינויים המתרחשים באיטיות לאורך זמן, כמו למשל תנועת עננים, תנועת גרמי השמיים בלילה, תנועה בכבישים ועוד.


- 1 כשאתה במצב 'בסיסי', הקש על **מצב** .
- 2 הקש על  והקלט סרטון.
- 3 הקש על  כדי לסיים את צילום סרטון הווידאו.

• כאשר מקליטים סרטון וידאו Time lapse לא מוקלט קול. 



צילום רציף

- תוכל לצלם צילומים רציפים של תמונות כדי ליצור תמונות נעות. במסך המצב בסיסי, לחץ לחיצה ארוכה על .
- צילומים רציפים מצולמים במהירות מהירה כאשר  מוחזק לחץ.

• כאשר האחסון מוגדר כ'אחסון פנימי', אתה יכול לצלם עד 100 תמונות. כאשר האחסון מוגדר כ'אחסון חיצוני', אתה יכול לצלם עד 30 תמונות ברצף. 

תצוגה פשוטה

כשאתה במצב 'בסיסי', הקש על  < **תצוגה פשוטה** כדי להסתיר תפריטים במסך המצלמה. הקש על  כדי להציג אותם.

מצב מרובע

תוכל לצלם מספר רב של תמונות או סרטונים במתכונת של קולאז' על ידי שימוש במצלמה הקדמית ובמצלמה האחורית. ניתן לשמור תמונות וסרטוני וידאו בפריסות שונות.

1 הפעל את היישום 'מצלמה', ולאחר מכן הקש על **בסיסי (A)** < **מרובע** (⊞).

2 הקש על **מצב** ובחר את מצב המצלמה הרצוי.

3 כדי לצלם תמונה, הקש על . כדי להקליט סרטון וידאו, הקש על .

התאמה אישית של אפשרויות המצלמה

תוכל להתאים אישית מגוון אפשרויות מצלמה כדי להתאימה לצרכיך.

הקש על  על המסך.

- האפשרויות הזמינות משתנות בהתאם למצלמה הנבחרת (מצלמה קדמית או אחורית) ולמצב המצלמה שנבחר.

גודל תמונה	בחר ערכים ליחס הרחב-גובה ולגודל בעת צילום תמונות.
רזולוציית הווידאו	בחר ערכים לרזולוציה ולגודל בעת הקלטת סרטוני וידאו.
HDR	קבל תמונות בצבעים מלאי חיים ואפקטים של פיצוי אפילו אם הפריטים צולמו מול האור. תכונות אלה מסופקות בעזרת טכנולוגיית טווח דינמי רחב (HDR) שבה מצוידת המצלמה.
טיימר	הגדר את הטיימר לצילום אוטומטי של תמונות לאחר פרק זמן שצוין.
צמצם קולי	צלם תמונות עם פקודות קוליות.
Tracking focus	כאשר יש נגיעה בנושא, המצלמה עוקבת אחרי אובייקט בתנועה ושומרת על ההתמקדות בו. (זמין כאשר המצלמה הרגילה בשימוש.)

מזער טשטוש תנועה בזמן הקלטת וידאו.	הקלטה יציבה
תכונה זו מיידעת אותך על כך שהעדשה רחבת הזווית האחורית מכוסה.	העדשות מכוסות
שמור את התמונה עם נתוני מיקום GPS.	תייג מיקומים
הצג קווים מנחים כך שתוכל לצלם תמונות או סרטוני וידאו בהתבסס על קווי ייחוס אופקיים ואנכיים.	רשת
הצג חתימה אישית בתמונות.	הוסף חתימה
בחר אם ברצונך לאחסן את התמונות וסרטוני הווידאו אחסון פנימי או כרטיס זיכרון. (אפשרות זו זמינה כאשר הוכנס כרטיס זיכרון.)	אחסון
הוסף עזרה לכל תפריט במצלמה.	עזרה

אפשרויות נוספות במצלמה הקדמית

<p>התאם אישית את ההגדרות של צילום סלפי.</p> <ul style="list-style-type: none"> • צילום בתנועת יד: צלם באמצעות התכונה 'צילום בתנועת יד'. • צילום אוטומטי: צלם כאשר המצלמה מזהה פנים. 	צילום סלפי
שמור תמונות הפוכות לאחר צילום תמונות סלפי.	שמור הפוך

• בעת שימוש במצלמה הקדמית, אתה יכול לכוונן את המסנן, אפקט התאורה וגוון העור.



מצב מצלמה ידני

תוכל ליצור תמונות בעלות מגע מקצועי על-ידי שימוש במגוון תכונות מתקדמות. כוונן את איזון הלבן, המיקוד, הבהירות, ה-ISO, מהירות הצמצם ואפשרויות אחרות.

1 הפעל את היישום 'מצלמה', ולאחר מכן הקש על **בסיסי (A)** < **ידני** (📷).

2 התאם אישית את ההגדרות המצלמה הבאות.



- כוונן את רמת החשיפה.
- כוונן את מהירות הצמצם.
- כוונן את מהירות ה-ISO.
- כוונן את איזון הלבן.
- כוונן את המיקוד.
- כוונן את הבהירות.

3 הקש על 📷 כדי לצלם תמונה.

התאמה אישית של אפשרויות המצלמה

תוכל להתאים אישית מגוון אפשרויות מצלמה כדי להתאימה לצרכיך.

הקש על ⚙️ על המסך.

גודל תמונה	בחר ערכים ליחס הרחב-גובה ולגודל בעת צילום תמונות.
טיימר	הגדר את הטיימר לצילום אוטומטי של תמונות לאחר פרק זמן שצוין.
צמצם קולי	צלם תמונות עם פקודות קוליות.
Tracking focus	כאשר יש נגיעה בנושא, המצלמה עוקבת אחרי אובייקט בתנועה ושומרת על ההתמקדות בו. (זמין כאשר המצלמה הרגילה בשימוש.)


שמור את התמונה עם נתוני מיקום GPS.	תייג מיקומים
הצג קווים מנחים כך שתוכל לצלם תמונות בהתבסס על קווי ייחוס אופקיים ואנכיים.	מדריך
התמונה מאוחסנת בתבנית קובץ RAW כדרך שתוכל לשנות אותה. קבצי DNG ו-JPEG נוצרים בזמן צילום תמונה, ואחר-כך הם נשמרים בתור תמונה לא דחוסה ברזולוציה גבוהה.	שמור כRAW
תכונה זו מיידעת אותך על כך שהעדשה רחבת הזווית האחורית מכוסה.	העדשות מכוסות
הפחת את רמת הרעש בערכי ISO גבוהים.	צמצום רעשים
הצג חתימה אישית בתמונות.	הוסף חתימה
בחר אם ברצונך לאחסן את התמונות וסרטוני הווידאו אחסון פנימי או כרטיס זיכרון. (אפשרות זו זמינה כאשר הוכנס כרטיס זיכרון.)	אחסון
הוסף עזרה לכל תפריט במצלמה.	עזרה

מצב וידאו ידני

באפשרותך להקליט סרטון וידאו על-ידי התאמה אישית ידנית של האפשרויות השונות. כוונן את הערכים של איזון הלבן, המיקוד, הבהירות, ה-ISO, מהירות הצמצם ועוד.

1 הפעל את היישום 'מצלמה', ולאחר מכן הקש על **בסיסי (A)** < **ידני** (☐).

2 התאם אישית את הגדרות המצלמה.



3 הקש על 📶 כדי להקליט סרטון וידאו.

התאמה אישית של אפשרויות המצלמה

תוכל להתאים אישית מגוון אפשרויות מצלמה כדי להתאימה לצרכיך.


הקש על ⚙️ על המסך.

בחור ערכים ליחס הרחוב-גובה ולגודל עבור סרטוני וידאו.	רזולוציית הווידאו
בחור את ערך המסגרות לשנייה.	קצב מסגרות
בחור את איכות התמונה עבור סרטוני וידאו.	קצב סיביות
הקלט סרטון וידאו עם קול באיכות Hi-Fi.	Hi-Fi
הגדר את הטיימר לצילום אוטומטי של תמונות לאחר פרק זמן שצוין.	טיימר
מזער טשטוש תנועה בזמן הקלטת וידאו.	הקלטה יציבה
תכונה זו מיידעת אותך על כך שהעדשה רחבת הזווית האחורית מכוסה.	העדשות מכוסות
כאשר יש נגיעה בנושא, המצלמה עוקבת אחרי אובייקט בתנועה ושומרת על ההתמקדות בו. (זמין כאשר המצלמה הרגילה בשימוש.)	Tracking focus
שמור את התמונה עם נתוני מיקום GPS.	תייג מיקומים
הצג קווים מנחים כך שתוכל להקליט סרטוני וידאו בהתבסס על קווי הייחוס האופקיים והאנכיים.	רשת
בחור אם ברצונך לאחסן את התמונות וסרטוני הווידאו אחסון פנימי או כרטיס זיכרון.	אחסון
הוסף עזרה לכל תפריט במצלמה.	עזרה

תכונות שימושיות אחרות ביישום המצלמה

AE/AF lock

כדי לתקן את רמת החשיפה הנוכחית ואת מיקום המיקוד, הקש הקשה ממושכת על המסך במצב 'בסיסי'. כדי לכבות את התכונה, הקש על האזור הריק של המסך.




Focus peaking

במצב מצלמה ידני או במצב הווידאו ידני, הקש על **FOCUS**.





כדי לכבות את התכונה, הקש על **Focus peaking**.



מעבר בין המצלמות

באפשרותך לעבור מהמצלמה הקדמית לאחורית וחזרה בהתאם לסביבה.

במסך המצלמה, הקש על  או גרור את המסך בכיוון כלשהו כדי לעבור בין המצלמה הקדמית למצלמה האחורית.



• השתמש במצלמה הקדמית לצילום תמונות סלפי. לפרטים, ראה **צילום סלפי**.



מעבר למצלמה הכפולה

החלף בין הזווית הרגילה לזווית הרחבה כדי לצלם תמונות או להקליט סרטונים בהתאם להעדפותיך.

- הקש על  /  או על  /  כדי להחליף בין המצלמה הרגילה למצלמה בזווית רחבה.
- דרך נוספת להחליף בין הזווית הרגילה לרחבה היא לצבט בעזרת האצבעות או להרחיב ביניהן.

זום להתקרבות או התרחקות מהאובייקט המצולם

באפשרותך להשתמש בתכונת ההגדלה או ההקטנה במסך המצלמה בעת צילום תמונה או הקלטת סרטון וידאו.

- במסך המצלמה, קרב או הרחק את אצבעותיך כדי להתרחק או להתקרב אל האובייקט המצולם, ולאחר מכן השתמש בפס ההחלקה +/- המוצג.
- במקרה כזה, המכשיר יעבור באופן אוטומטי בין מצלמת הזווית הרחבה לבין המצלמה הכללית שבגב המכשיר כדי לצלם את התמונה או סרטון הווידאו.

• תכונת הזום אינה זמינה בעת שימוש במצלמה הקדמית במצב סלפי.



צילום סלפי



תוכל להשתמש במצלמה הקדמית כדי להציג את פניך על המסך ולצלם סלפי.

צילום בתנועת יד

תוכל לצלם תמונות סלפי באמצעות מחוות.

הצג את כף ירך למצלמה הקדמית ולאחר מכן סגור אותה לאגרוף. תוכל גם לסגור אגרוף ולאחר מכן לפתוח אותו לכיוון המצלמה הקדמית.


- בתוך שלוש שניות תצולם תמונה.



- כדי להשתמש בתכונה זו, עבור למצב המצלמה הקדמית ולאחר מכן הקש על  < **צילום סלפי** < **צילום בתנועת יד**.
- ודא שכף היד והאגרוף שלך נכללים בתוך קו הייחוס כך שהמצלמה תוכל לזהות אותם.
- ייתכן שתכונה זו לא תהיה זמינה בעת שימוש בחלק מתכונות המצלמה.

צילום אינטרוולי

- תוכל לצלם תמונות סלפי במרווחי זמן קבועים. בעת השימוש במצלמה הקדמית, תוכל להציג את כף ירך למצלמה ולאחר מכן לכווץ אגרוף פעמיים במהירות.
- ארבע תמונות מצולמות במרווחים של כשתי שניות לאחר שהיית טיימר של שלוש שניות.




- הקש על  < **צילום סלפי** < **צילום בתנועת יד** כדי להשתמש בתכונה זו.

צילום אוטומטי

אתה יכול להיעזר בתכונת זיהוי הפנים כדי לצלם תמונות סלפי בקלות ובנוחות. ניתן להגדיר את המכשיר כך, שכאשר אתה מביט במסך המצלמה הקדמית מזהה את פרצופך ומצלמת סלפי באופן אוטומטי.


- המסגרת המנחה הלבנה מופיעה כאשר המצלמה הקדמית מזהה את פניך. אם הנושא בתוך המסגרת המנחה מפסיק לנוע, צבע המסגרת המנחה הופך לכחול והמצלמה מצלמת את התמונה.



• הקש על  < **צילום סלפי** < **צילום אוטומטי** כדי להפעיל את התכונה 'צילום אוטומטי'.


תצוגת מחווה

לאחר צילום סלפי באמצעות המצלמה הקדמית, תוכל לראות תצוגה מקדימה של הסלפי מיד אם תקרב את המסך לפנים שלך.



- הקש על  < **תצוגת מחווה** כדי להפעיל את תכונת תצוגת המחווה.
- רק תצוגה מקדימה אחת תהיה זמינה לאחר צילום של תמונה.
- אם תסובב את המכשיר כשהמסך במצב תצוגה מקדימה, המסך יחזור למצב מצלמה.

שמור הפוך

לפני שתצלם תמונה עם המצלמה הקדמית, הקש על  < **שמור הפוך**. התמונה תסתובב בכיוון ההופכי.

- בעת שימוש במצלמה הקדמית, תוכל לשנות את האופן שבו תמונות סלפי מצולמות באפשרויות המצלמה. לפרטים, ראה **התאמה אישית של אפשרויות המצלמה**.

סקירה כללית של הגלריה

תוכל להציג ולנהל תמונות וסרטוני וידאו שנשמרו במכשיר.

1 הקש על  < .


• תמונות וסרטוני וידאו שנשמרו מוצגים לפי תיקיות.

2 הקש על תיקייה ובחר קובץ.

• הצג את הקובץ שנבחר במצב מסך מלא.

• בעת צפייה בתמונה, החלק שמאלה או ימינה כדי להציג את התמונה הקודמת או התמונה הבאה.


• בעת צפייה בסרטון וידאו, החלק שמאלה או ימינה כדי להריץ אחורה או להריץ קדימה את הסרטון.


• ייתכן שחלק מתבניות הקבצים אינן נתמכות, בהתאם לתוכנות המותקנות. 

• ייתכן שקבצים מסוימים לא ייפתחו עקב קידוד.

• קבצים שחורגים ממגבלת הגודל עלולים לגרום לשגיאה.


הצגת תמונות



• כדי להציג את פריטי התפריט, הקש בעדינות על המסך. כדי להסתיר את פריטי התפריט, הקש שוב על המסך. 

לחצן צף

כדי לעבור במהירות אל המסך הראשי בעת הצגת ה'גלריה' בכיוון לרוחב, גע והחזק את **⏪**, והזז את האצבע כלפי מעלה אל **⦿**, אחר-כך שחרר את הלחצן.



- אתה יכול להזיז את מיקום הלחצן הצף על-ידי גרירה אופקית שלו לאורך החלק התחתון של המסך.


כתיבת תזכורת בתמונה

- 1 תוך כדי הצגת תמונה, הקש על **📝**.
- 2 כתוב תזכורת בתמונה והקש על **שמור**.

- ייתכן שחלק מהתמונות אינן תומכות בתכונה 'מזכר תצלום'.


תוכן קשור

באפשרותך לערוך ולהתאים אישית תוכן קשור ב'גלריה'!



- 1 בזמן הצגת תמונה בתצוגה מקדימה, הקש על .
- 2 כאשר מופיע הסמל הקשור לתאריך שבו צילמת את התמונה, גע במסך.





- באפשרותך להציג את התמונות הקשורות לתאריך שבחרת.




- ניתן לקשור תוכן קשור לעד ארבעה שילובים של 'זיכרונות, תאריך, מקום, מצב מצלמה'!

- הקש על  כדי לשמור את התוכן הקשור כסרטון וידאו.
- הקש על  כדי לגשת אל אפשרויות נוספות.

עריכת תמונות

- 1 תוך כדי הצגת תמונה, הקש על .
 - 2 ערוך את התמונה בעזרת מגוון של אפקטים וכלי עריכה.
 - 3 הקש על **שמור** כדי לשמור שינויים.
- התמונה הערוכה תחליף את הקובץ המקורי.
 - כדי לשמור את התמונה שנערכה כקובץ אחר, הקש על  : <
- שמור עותק.**


הפעלת קובץ וידאו



- כדי לכוונן את עוצמת הקול, גרור את הצד הימני של מסך הווידאו למעלה או למטה.
- כדי לכוונן את בהירות המסך, גרור את הצד השמאלי של המסך מעלה או מטה.

עריכת סרטוני וידאו

- 1 תוך כדי הצגת סרטון וידאו, הקש על ✎.
- 2 השתמש במגוון אפקטים וכלי עריכה כדי לערוך את סרטון הווידאו.



3 הקש על שמור כדי לשמור שינויים.

יצירת GIF

ניתן ליצור בקלות קובץ GIF באמצעות סרטון וידאו מוקלט.

1 בנקודת ההתחלה הרצויה בזמן צפייה בווידאו, הקש על < :

צור קובץ GIF.

2 בחר את האורך של קובץ ה-GIF שברצונך ליצור.

- קובץ GIF נוצר עבור משך הזמן החל מהשעה הנוכחית.
- עבור סרטוני וידאו שאורכם קצר מ-5 שניות, תמונות GIF מופקות באופן אוטומטי עבור הזמן הנותר.

• התכונה של יצירת GIF מוצעת עבור הפעילות היצירתית של המשתמש. אם אתה מפר זכויות יוצרים של אדם אחר או עובר על חוקי ההשמצה על-ידי שימוש בתכונת היצירה של GIF, אתה עשוי להיחשף לתביעה אזרחית ופלילית. הקפד שלא לשכפל או להעביר עבודה של אחרים ללא רשות. חברת LG Electronics לא תוכל לקבל אחריות מכל סוג שהוא עקב פעולה של משתמש.



קבצים קשורים

ניתן ליצור קשר בין קבצים לפי תמונות ווידאו שצולמו באותו מיקום או באותו תאריך.

1 בחר את התמונות והווידאו שנשמרו, והקש על

2 בחר תיקייה רצויה, ולאחר מכן הקש על כדי ליצור סרטון וידאו.

מחיקת קבצים

תוכל למחוק קבצים באמצעות אחת משתי האפשרויות הבאות:

• הקש הקשה ממושכת על קובץ ברשימה, ולאחר מכן הקש על

מחק.

• הקש על ברשימת הקבצים ומחק את הקבצים הרצויים.

• קבצים שנמחקו מועברים באוסל **מיחזור** לפח האשפה וניתן לשחזר אותם לגלריה בתוך 7 ימים.

• בגלריה, הקש על < **סל מיחזור**. הקש על כדי למחוק לחלוטין את הקבצים. במקרה זה, לא ניתן לשחזר את הקבצים.

שיתוף קבצים

- תוכל לשתף קבצים באמצעות אחת משתי האפשרויות הבאות:
 - בעת הצגת תמונה, הקש על \otimes כדי לשתף את הקובץ בשיטה הרצויה.
 - תוך כדי הצגת סרטון וידאו, הקש על > **שתף** כדי לשתף את הקובץ בשיטה הרצויה.
 - ברשימת הקבצים, הקש על \otimes כדי לבחור קובץ ולשתף אותו בשיטה הרצויה.

אנשי קשר

סקירה כללית של אנשי קשר

- באפשרותך לשמור ולנהל אנשי קשר.
- הקש על \bigcirc < **חיוניים** < **אנשי קשר**.

הוספת אנשי קשר

הוספת אנשי קשר חדשים

- 1 במסך של רשימת אנשי הקשר, הקש על $+$.
- 2 הזן פרטי יצירת קשר והקש על **שמור**.

ייבוא אנשי קשר

תוכל לייבא אנשי קשר מהתקן אחסון אחר.

- 1 במסך של רשימת אנשי הקשר, הקש על > **ניהול אנשי קשר** < **ייבוא**.
- 2 בחר את מיקומי המקור והיעד של איש הקשר שברצונך לייבא ולאחר מכן הקש על **אישור**.
- 3 בחר את אנשי הקשר והקש על **ייבוא**.

הוספת אנשי קשר לרשימת מספרי החיוג המהיר

- 1 במסך של רשימת אנשי הקשר, הקש על : < **חיוג מהיר**.
- 2 הקש על **הוסף איש קשר** ממספר חיוג מהיר.
- 3 בחר איש קשר.

חיפוש אנשי קשר

- תוכל לחפש אנשי קשר באמצעות אחת משתי האפשרויות הבאות:
- במסך רשימת אנשי הקשר, הזן שם איש קשר בתיבת החיפוש.
 - גלול מעלה או מטה ברשימת אנשי הקשר.
 - באינדקס של מסך רשימת אנשי הקשר, הקש על האות הראשונה של איש קשר.

רשימת אנשי קשר

עריכת אנשי קשר

- 1 במסך רשימת אנשי הקשר, בחר באיש הקשר הרצוי.
- 2 במסך פרטי איש הקשר, הקש על ✎ וערוך את הפרטים.
- 3 הקש על **שמור** כדי לשמור שינויים.

מחיקת אנשי קשר

- תוכל למחוק אנשי קשר באמצעות אחת משתי האפשרויות הבאות:
- במסך רשימת אנשי הקשר, הקש הקשה ממושכת על איש קשר שברצונך למחוק ולאחר מכן הקש על **מחק איש קשר**.
 - הקש על : < **מחק** במסך של רשימת אנשי הקשר.

הוספת מועדפים

- באפשרותך לרשום אנשי קשר בשימוש נפוץ כמועדפים.
- 1 במסך רשימת אנשי הקשר, בחר באיש הקשר הרצוי.
 - 2 במסך פרטי איש הקשר, הקש על ☆.

יצירת קבוצות












- 1 במסך של רשימת אנשי הקשר, הקש על **קבוצות** < : <
קבוצה חדשה.
- 2 הזן שם קבוצה חדשה.
- 3 הקש על **הוסף חברים**, בחר אנשי קשר ולאחר מכן הקש על **הוסף**.
- 4 הקש על **שמור** כדי לשמור את הקבוצה החדשה.

QuickMemo+





סקירה כללית של QuickMemo+

תוכל להוסיף הערות יצירתיות על-ידי שימוש במגוון אפשרויות בתכונות מתקדמות אלה של פנקס רשימות, כגון ניהול תמונות וצילומי מסך, שאינה נתמכת על-ידי פנקס הרשימות הקונבנציונלי.



יצירת הערה

- 1 הקש על  < **חיוניים** < QuickMemo+.
- 2 הקש על  כדי ליצור הערה.
 -  : שמור הערה.
 -  : בטל את הפעולה האחרונה.
 -  : בצע שוב את הפעולה האחרונה שביטלת.
 -  T : הזן הערה על-ידי שימוש בלוח המקשים.
 -  : כתוב הערות באופן ידני.
 -  : מחק הערות שנכתבו בכתב יד.
 -  : הגדל או הקטן תצוגה, סובב או מחק חלקים מהערה בכתב יד.
 -  : קבל גישה לאפשרויות נוספות.
- 3 הקש על  כדי לשמור את ההערה.

כתיבת הערות על תמונה



- 1 הקש על  < **חיוניים** < QuickMemo+.
- 2 הקש על  כדי לצלם תמונה ולאחר מכן הקש על **אישור**.
 - התמונה מצורפת באופן אוטומטי לפנקס הרשימות.
- 3 הקש על **T** או על  כדי לכתוב הערות על התמונה.
 - כתוב הערות על התמונה בכתב יד.
 - הזן טקסט מתחת לתמונה.
- 4 הקש על  כדי לשמור את ההערה.



כתיבת הערות על צילום מסך


- 1 תוך הצגת המסך שברצונך לצלם, גרור את שורת המצב כלפי מטה והקש על .
 - צילום המסך נראה עמו ערכת נושא ברקע של פנקס הרשימות. כלי מזכר מופיעים בחלקו העליון של המסך.
- 2 רשום הערות כרצונך.
 - כתוב הערות על התמונה בכתב יד.
- 3 הקש על  ושמור את ההערות במיקום הרצוי לך.
 - ניתן להציג הערות שמורות ב-QuickMemo+ או ב-**גלריה**.
 - כדי לשמור הערות באותו מיקום כל הזמן, סמן את התיבה **השתמש כברירת מחדל לפעולה זו** ובחר יישום.

ניהול תיקיות

באפשרותך להציג הערות שקובצו לפי סוג.

- 1 הקש על  < **חיוניים** < QuickMemo+.
- 2 בחלק העליון של המסך, הקש על  ובחר פריט תפריט:
 - **כל התזכירים**: הצג את כל ההערות שנשמרו ב-QuickMemo+.
 - **התזכירים שלי**: הצג הערות שנוצרו על-ידי QuickMemo+.
 - **Capture+**: הצג הערות שנוצרו על-ידי Capture+.



- **מזכר תצלום:** הצג הערות שנוצרו על-ידי .
- **סל מיחזור:** הצג הערות שנמחקו.
- **קטגוריה חדשה:** הוסף קטגוריות.
-  : סדר מחדש, הוסף או מחק קטגוריות. כדי לשנות שם של קטגוריה, הקש על הקטגוריה.



-  תיקיות מסוימות לא מופיעות בעת הפעלת QuickMemo+ בפעם הראשונה. תיקיות מושבתות מופעלות ומופיעות כאשר הן מכילות הערה קשורה אחת לפחות.

שעון

התראה



תוכל להגדיר התראה שתופעל במועד שצוין.

- 1 הקש על  < **חיוניים** < **שעון** < **התראה**.
- 2 הקש על  כדי להוסיף התראה חדשה.
- 3 קבע את הגדרות ההתראה והקש על **שמור**.

-  אם תבחר התראה שהוגדרה בעבר, תוכל לערוך אותה.
- כדי למחוק התראה, הקש על  בראש המסך. לחלופין, הקש הקשה ארוכה על ההתראה.

שעון עולמי

תוכל להציג את השעה הנוכחית בערים ברחבי העולם.

- 1 הקש על  < **חיוניים** < **שעון** < **שעון עולמי**.
- 2 הקש על  והוסף עיר.

טיימר

תוכל להגדיר טיימר כדי להפעיל התראה לאחר פרק זמן שצוין.

- 1 הקש על **○** < **חיוניים** < **שעון** < **טיימר**.
- 2 הגדר את הזמן והקש על **התחל**.
 - כדי להשהות את הטיימר, הקש על **השהה**. כדי לחדש את פעולת הטיימר, הקש על **המשך**.
 - כדי לאפס את הגדרות הטיימר, הקש על **⊙**.
- 3 הקש על **הפסק** כדי להפסיק את התראת הטיימר.

שעון עצר

תוכל להשתמש בשעון העצר כדי לתעד את משך הזמן שחלף.



- 1 הקש על **○** < **חיוניים** < **שעון** < **שעון עצר**.
- 2 הקש על **התחל** כדי להפעיל את שעון העצר.
 - כדי לתעד זמן הקפה, הקש על **הקפה**.
- 3 הקש על **השהה** כדי להשהות את שעון העצר.
 - כדי לחדש את פעולת שעון העצר, הקש על **המשך**.
 - כדי לנקות את כל הרשומות ולהפעיל מחדש את שעון העצר, הקש על **איפוס**.

לוח שנה

סקירה כללית של לוח השנה

תוכל להשתמש בלוח השנה כדי לנהל אירועים ומשימות.

הוספת אירועים


- 1 הקש על  < חיוניים < לוח שנה.
 - 2 בחר תאריך ולאחר מכן הקש על .
 - 3 הזן פרטי אירוע והקש על שמור.
- אם תקיש על תאריך בלוח השנה והתאריך מכיל אירועים, יופיע חלון מוקפץ שמציג רשימה של האירועים. הקש על אירוע בחלון המוקפץ כדי להציג את פרטי האירוע.

סנכרון אירועים

הקש על  : < לוחות שנה לסינכרון ובחר את לוח השנה שברצונך לסנכרן.

- בעת שמירת אירועים מהמכשיר שלך אל חשבון Google, מתבצע סינכרון אוטומטי שלהם גם עם לוח השנה של Google. בהמשך תוכל לסנכרן מכשירים אחרים מול לוח השנה של Google כדי שגם באותם מכשירים האירועים יהיו זהים לאלה השמורים במכשיר שלך; לאחר הסינכרון תוכל לנהל את האירועים שלך דרך אותם מכשירים.

Event pocket

תוכל להשתמש ב-Event Pocket כדי ליצור אירועים. הקש על  כדי לפתוח את ה-Event Pocket ולאחר מכן גרור תוכן לתאריך בלוח השנה.

-  : נהל תמונות, טקסט, מזכרים ואירועים שנשמרו באופן זמני. תוכל גם לשתף טקסט, תמונות ומזכרים מיישום אחר ולשמור אותם בכיס. אם תקיש על **כיס** בעת יצירת אירוע, האירוע יישמר באופן זמני בכיס.
-  : הוסף חשבון Facebook כדי להציג מידע על אירועים של Facebook. ייתכן שמכשירים מסוימים אינם תומכים בפונקציה שמציגה מידע על אירועים של Facebook.
-  : הצג מידע תיירותי על האזור הקרוב, כגון מיקום של מסעדות ושירותים נוחים כדי לתכנן אירוע.
-  : נהל משימות שאין להן תאריך יעד, כמו למשל אירועים.

משימות

תוכל לרשום משימות במכשיר שלך כדי לנהל בקלות לוחות זמנים.

- 1 הקש על < חיוניים < משימות.
- 2 הקש על כדי להוסיף משימה.
- 3 הזן פרטי משימה ולאחר מכן הקש על שמור.

נגן מוסיקה

תוכל להשמיע ולנהל שירים או אלבומי מוסיקה.

- 1 הקש על < חיוניים < נגן מוסיקה.
- 2 בחר קטגוריה.
- 3 בחר קובץ מוסיקה.



- ייתכן שחלק מתבניות הקבצים אינן נתמכות, בהתאם לתוכנות המותקנות.
- קבצים שחורגים ממגבלת הגודל עלולים לגרום לשגיאה.
- קובצי מוסיקה עשויים להיות מוגנים על-ידי בעלים בינלאומיים של זכויות יוצרים או חוקי זכויות יוצרים. ייתכן שתצטרך להשיג אישור משפטי לפני העתקת קובץ מוסיקה. כדי להוריד או להעתיק קובץ מוסיקה, תחילה בדוק את חוק זכויות היוצרים עבור המדינה הרלוונטית.
- מודל זה תומך בהפעלת שמע Hi-Fi. קובצי שמע מסוג Hi-Fi מציגים את סמל Hi-Fi.

מחשבון

ניתן להשתמש בשני סוגי מחשבוניים: המחשבון הפשוט והמחשבון המדעי

- 1 הקש על \odot < **חיוניים** < **מחשבון**.
 - 2 השתמש בלוח המקשים כדי לבצע חישוב.
- כדי להשתמש במחשבון מדעי, גרור שמאלה את פס ההחלקה הרוק שנמצא בצד הימני של המסך.
 - כדי להפעיל מחדש חישוב, הקש הקשה ממושכת על לחצן **.DEL**

LG Health

סקירה כללית של LG Health

תוכל לנהל ענייני בריאות ולשמור על הרגלי אימון טובים על ידי ניהול מעקב אחר אימוני הכושר שלך.

צעדים ראשונים עם LG Health

תוכל להגדיר את LG Health בעת הפעלת היישום בפעם הראשונה, או לאחר האיפוס.

- 1 הקש על **חינויים < LG Health**.
- 2 פעל לפי ההוראות שעל המסך כדי להשלים את קביעת התצורה.

שימוש ב-LG Health

תוכל להציג מידע ראשי ב-LG Health ולנהל את כמות האימון הגופני ואת נתוני הבריאות.

- 1 הקש על **חינויים < LG Health**.
- 2 לרשותך האפשרויות הבאות.



- **☰** : הצג את יומן האימונים של היום הרצוי.
- **👤** : התחל לעקוב אחר אימון כושר. המסלול והיקף התרגול הגופני שלך יתועדו עבור כל סוג של אימון.
- **⋮** : הגדר יעדי אימון יומיים, כולל קלוריות וצעדים, או קבע הגדרות שונות ב-LG Health.

- המידע בנושאי בריאות המסופק על-ידי LG Health משמש כמידע כללי לנוחות המשתמש ולא ניתן להשתמש בו למטרות מניעת מחלות, טיפול, אבחון או בעיות רפואיות אחרות.
- היישום LG Health עשוי להשתנות או לא להיות זמין, בהתאם למדינה ולספק השירות. הפונקציות של LG Health הזמינות והיישומים שניתן להוסיף ל-LG Health עשויים להשתנות, בהתאם למדינה. הבדלים אלה נובעים כתוצאה מהבדלים בחוקים ובתקנות.

דוא"ל

סקירה כללית של דוא"ל

תוכל לרשום חשבון דוא"ל במכשיר שלך ולאחר מכן תוכל לבדוק ולשלוח הודעות דוא"ל מהמכשיר.

- אם אתה משתמש בנתונים לנייד, ייתכן שתחויב בתשלום בגין השימוש בנתונים, בהתאם לתוכנית המחירים שלך. לקבלת מידע נוסף, פנה לספק השירות שלך.

רישום חשבונות דוא"ל

כאשר תשתמש ביישום הדוא"ל בפעם הראשונה, תתבקש לרשום את חשבון הדוא"ל שלך.

- 1 הקש על  < חיוניים < דוא"ל.
- 2 בחר ספק שירותי דוא"ל.

3 הזן את כתובות הדוא"ל ואת הסיסמה, ולאחר מכן הקש על **הבא** כדי לרשום את החשבון שלך.

- כדי לרשום באופן ידני חשבון דוא"ל, הקש על **הגדרה ידנית** (במקרה הצורך).

ניהול חשבונות דוא"ל

כדי להציג או לערוך את הגדרות חשבון הדוא"ל שלך, הקש על < : **הגדרות**.

- כדי להוסיף חשבון, הקש על **הוסף חשבון**.
- כדי למחוק חשבון, הקש על < : **הסר חשבון**.



פתיחת חשבון דוא"ל נוסף

אם יש כמה חשבונות דוא"ל רשומים וברצונך להציג חשבון נוסף, הקש על ≡ ובחר חשבון אחר מרשימת החשבונות.

בדיקת דוא"ל

- 1 הקש על ≡ ובחר תיבת דואר.
- 2 בחר דוא"ל מרשימת הדוא"ל.
- הודעת הדוא"ל תופיע.


שליחת דוא"ל

- 1 הקש על +.
- 2 הזן את כתובת הדוא"ל של הנמען.
- 3 הזן נושא והודעה
- כדי לצרף קבצים, הקש על .
- כדי לגשת לפריטי תפריט אופציונליים, הקש על ∴.
- 4 הקש על  כדי לשלוח את הדוא"ל.

רדיו FM

תוכל להאזין לרדיו FM.


הקש על  < **חיוניים** < **רדיו FM**.

- כדי להשתמש ביישום זה, תחילה חבר אונליה למכשיר. 
- האונליה הופלת לאנטנת הרדיו.
- התמיכה באפשרות זו תלויה באזור.

מנהל הקבצים

תוכל להציג ולנהל קבצים שנשמרו במכשיר שלך או בענן.

1 הקש על  < **כלי ניהול** < **מנהל הקבצים**.

2 הקש על  ובחר במיקום האחסון הרצוי.

LG Mobile Switch


העבר בקלות נתונים ממכשיר משומש למכשיר חדש באמצעות LG Mobile Switch.

1 הקש על  < **כלי ניהול** < **LG Mobile Switch**.

אתה יכול גם להקיש על  < **הגדרות** < **כללי** < **גיבוי**

< **איפוס** < **LG Mobile Switch**.

2 פעל בהתאם להוראות המופיעות במסך כדי לבחור שיטת העברה רצויה.


• איפוס המכשיר עלול להביא למחיקת קבצי גיבוי שנשמרו באחסון. הקפד להעתיק ולאחסן את קבצי הגיבוי החשובים במחשב שלך. 

• הנתונים בחשבון Google לא יגובו. כאשר אתה מסנכרן את חשבון Google שלך, יישומי Google, אנשי הקשר של Google, יזמן Google, נתוני יישום התזכורות של Google ויישומים שהורדו מחנות Play יאוחסנו ביישום Drive באופן אוטומטי. 

• טען את הסוללה באופן מלא לפני העברת נתונים כדי למנוע כיבוי שלא בכוונה בזמן התהליך.

LG Friends Manager

באפשרותך להתחבר למכשירי LG Friends ולנהל אותם בקלות.

הקש על  < **כלי ניהול** < **LG Friends Manager**.

הורדות

תוכל להציג, למחוק או לשתף קבצים שהורדת מהאינטרנט או יישומים.

הקש על ○ < כלי ניהול < הורדות.

LG SmartWorld

תוכל להוריד מגוון משחקים, תכני שמע, יישומים וגופנים המסופקים על-ידי LG Electronics. התאם אישית את המכשיר שלך כדי להתאימו להעדפותיך באמצעות ערכות הנושא והגופנים של המסך הראשי.

- אם אתה משתמש בנתונים לנייד, ייתכן שתחויב בתשלום בגין השימוש בנתונים, בהתאם לתוכנית המחירים שלך.
- ייתכן שלא תהיה תמיכה בתכונה זו, התמיכה נקבעת בהתאם לאזור או לספק השירות.

- 1 הקש על ○ < שירותים < SmartWorld.
- 2 הקש על : < חשבון LG, ולאחר מכן היכנס.
- 3 בחר והורד את פריטי התוכן הרצויים.

מוריד את SmartWorld

אם היישום עולם חכם אינו מותקן, בצע את השלבים הבאים כדי להוריד אותו.

- 1 הקש על ○ < הגדרות < כללי < אודות הטלפון < כללי < מרכז עדכונים < עדכוני אפליקציות.
- 2 ברשימה, בחר SmartWorld והקש על הורד.

שירות התראות חירום

תוכל להציג שידורי טקסט בזמן במצבי חירום, כגון סופות טייפון, שיטפונות ורעידות אדמה.

הקש על  < שירותים < שירות התראות חירום.

Instagram

השתמש בשירות רשתות חברתיות כדי ללכוד ולשתף את התמונות וסרטוני הווידאו שלך. תוכל גם להחיל אפקטי מסנן כדי להפוך את התמונות וסרטוני הווידאו שלך ליצירתיים ומעניינים יותר.

הקש על  < מומלץ < Instagram.

פייסבוק

באפשרותך להשתמש בשירות רשתות חברתיות כדי לעדכן, להציג ולשתף פוסטים, תמונות וסרטוני וידאו עם אנשי הקשר המקוונים שלך.

הקש על  < מומלץ < פייסבוק.

Evernote

תוכל לכתוב ולאסוף מידע חשוב ולאחר מכן לשתף זאת עם מכשירים אחרים שתומכים ב-Evernote.

הקש על  < מומלץ < Evernote.

Chrome

היכנס ל-Chrome ויבא כרטיסיות פתוחות, סימניות ונתוני שורת כתובת ממחשב למכשיר שלך.

יישומי Google

כדי להשתמש ביישומי Google, הגדר חשבון Google. חלון הרישום של חשבון Google יופיע באופן אוטומטי כאשר תשתמש ביישום של Google בפעם הראשונה. אם אין לך חשבון Google, צור חשבון במכשיר שלך. לפרטים בנוגע לאופן השימוש ביישום, עיין בעזרה שסופקה ביישום.

• ייתכן שיישומים מסוימים לא יפעלו, בהתאם לאזור ולספק השירות.

Docs

צור מסמכים או ערוך מסמכים שנוצרו באינטרנט או במכשיר אחר. שתף וערוך מסמכים עם אחרים.

Drive

העלה, שמור, פתח, שתף וסדר קבצים במכשיר שלך. ניתן לגשת לקבצים הנגישים מהיישומים מכל מקום, כולל סביבות מקוונות ולא מקוונות.

Duo

ערוך שיחת וידאו עם בני משפחה, חברים וכל אחד אחר שמשתמש ביישום.

Gmail

רשום את חשבון הדוא"ל של Google במכשיר שלך כדי לבדוק אם הגיע דוא"ל או כדי לשלוח דוא"ל.

Google

השתמש ב-Google כדי לחפש דפי אינטרנט, תמונות, חדשות ועוד על-ידי הזנת מילות מפתח או אמירתן בקול רם.

מפות

חפש את המיקום שלך או את המיקום של מקום על המפה. הצג מידע גיאוגרפי.

תמונות

הצג או שתף תמונות או אלבומים השמורים במכשיר שלך.

סרטים Play

השתמש בחשבון Google כדי לשכור או לרכוש סרטים. קנה תוכן והפעל אותו בכל מקום.

מוזיקה Play

קנה קובצי מוזיקה מ-חנות Play. הפעל קובצי מוזיקה שנשמרו במכשיר שלך.

Sheets

צור גיליונות אלקטרוניים או ערוך גיליונות אלקטרוניים שנוצרו באינטרנט או במכשיר אחר. שתף וערוך גיליונות אלקטרוניים עם אחרים.

Slides

צור חומרים למצגת או ערוך חומרים למצגת שנוצרו באינטרנט או במכשיר אחר. שתף וערוך חומרים למצגת עם אחרים.

YouTube



כפש והפעל סרטונים. העלה סרטוני וידאו ל-YouTube כדי לשתף אותם עם אנשים ברחבי העולם.

04

הגדרות

הגדרות

תוכל להתאים אישית את הגדרות המכשיר על פי העדפותיך.
הקש על  < הגדרות.

- הקש על  והזן מילת מפתח בתיבת החיפוש כדי לגשת לפריט הגדרה.
- הקש על  כדי לשנות את מצב התצוגה. מדריך למשתמש זה מניח שאתה משתמש בתצוגת לשוניות.

רשתות

כרטיס SIM כפול

ניתן לקבוע את הגדרות SIM כפול.

1 במסך ההגדרות, הקש על **רשתות** < **כרטיס SIM כפול**.

2 התאם אישית את הפונקציות הבאות:

- **כרטיס 1 SIM**: שנה את השם והסמל של כרטיס 1 SIM.
- **כרטיס 2 SIM**: שנה את השם והסמל של כרטיס 2 SIM.
- **צבע נושא לכרטיס SIM**: שנה את ערכות הנושא לצבעים עבור כרטיסי ה-SIM.
- **מצב חסכון בעלויות**: הפעל או בטל את ההפעלה של מצב חסכון בעלויות. במצב חסכון בעלויות, אם אתה מבצע שיחה אל איש קשר שהוקצה לו SIM ספציפי, SIM זה ישמש עבור השיחה אפילו אם ה-SIM השני פעיל; לדוגמה, הוא עושה שימוש בנתונים ניידים.
- **נתונים ניידים**: בחר בכרטיס SIM שבו ברצונך להשתמש עבור שירות נתונים ניידים. אתה יכול גם לכבות פונקציה זו.
- **נדידת נתונים**: בחר באפשרות זו כדי לאפשר למכשיר להשתמש בנתונים ניידים כאשר אתה בנדידה אל מחוץ לאזור הרשת הביתית שלך.

תוכל להתחבר למכשירים סמוכים או באמצעות רשת Wi-Fi.

התחברות לרשת Wi-Fi

- 1 במסך ההגדרות, הקש על **רשתות** < Wi-Fi.
- 2 הקש על  כדי להפעיל אותו.
 - רשתות ה-Wi-Fi הזמינות יופיעו באופן אוטומטי.
- 3 בחר רשת.
 - ייתכן שתצטרך להזין את סיסמת ה-Wi-Fi של הרשת.
 - המכשיר מדלג על תהליך זה עבור רשתות Wi-Fi שבוצעה אליהם גישה בעבר. אם אינך רוצה להתחבר באופן אוטומטי לרשת Wi-Fi מסוימת, הקש הקשה ארוכה על הרשת ולאחר מכן הקש על **שכח רשת**.

הגדרות רשת Wi-Fi

- במסך ההגדרות, הקש על **רשתות** < Wi-Fi.
- **עבור לנתונים ניידים:** אם תופעל פונקציית הנתונים הניידים אך המכשיר לא יצליח להתחבר לאינטרנט באמצעות Wi-Fi, המכשיר יתחבר לאינטרנט באופן אוטומטי באמצעות פונקציית הנתונים הניידים.
 - : התאם אישית את ההגדרות של רשת Wi-Fi

Wi-Fi Direct


תוכל לחבר את ההתקן שלך להתקנים אחרים שתומכים ב-Wi-Fi Direct כדי לשתף נתונים ישירות איתם. אינך צריך נקודת גישה. תוכל להתחבר עם יותר משני מכשירים באמצעות Wi-Fi Direct.


1 במסך ההגדרות, הקש על **רשתות** < Wi-Fi < : < Wi-Fi **מתקדם** < Wi-Fi Direct.

- מכשירים סמוכים שתומכים ב-Wi-Fi Direct יופיעו באופן אוטומטי.

2 בחר התקן.

- החיבור מתרחש כאשר המכשיר מקבל את בקשת החיבור.

• בעת שימוש ב-Wi-Fi Direct, הסוללה עשויה להתרוקן מהר יותר. 



Bluetooth


תוכל לחבר את המכשיר שלך למכשירים סמוכים שתומכים ב-Bluetooth כדי להחליף איתם נתונים. חבר את המכשיר לאזוניית Bluetooth ולמקלדת. בדרך זו תוכל לשלוט בקלות רבה יותר במכשיר.

שיוך עם מכשיר אחר

1 במסך ההגדרות, הקש על **רשתות < Bluetooth**.


2 הקש על  כדי להפעיל אותו.

- המכשירים הזמינים מופיעים באופן אוטומטי.
- כדי לרענן את רשימת המכשירים, הקש על **חיפוש**.

•  רק מכשירים שמוגדרים כגלויים מוצגים ברשימה.

3 בחר מכשיר מהרשימה.


4 פעל לפי ההוראות שעל המסך כדי לבצע את האימות.

•  המערכת מדלגת על שלב זה עבור מכשירים שבוצעה אליהם גישה בעבר.

שליחת נתונים דרך חיבור Bluetooth


1 בחר קובץ.

• תוכל לשלוח קובצי מולטימדיה או אנשי קשר.

2 הקש על  < **Bluetooth**.

3 בחר מכשיר יעד עבור הקובץ.


• הקובץ יישלח ברגע שמכשיר היעד יקבל אותו.

•  תהליכי שיתוף הקבצים עשויים להשתנות, בהתאם לקובץ.

נתונים ניידים

תוכל להפעיל או לקבל נתונים לנייד. תוכל גם לנהל את השימוש בנתונים לנייד.

הפעלת נתונים לנייד


- 1 במסך ההגדרות, הקש על **רשתות** < **נתונים ניידים**.
- 2 הקש על  כדי להפעיל אותו.

התאמה אישית של הגדרות הנתונים לנייד

- 1 במסך ההגדרות, הקש על **רשתות** < **נתונים ניידים**.
- 2 התאם אישית את ההגדרות הבאות:
 - **נתונים ניידים**: הגדר שימוש ברשתות סלולריות לצורך חיבורי נתונים.
 - **הגבל שימוש בנתונים ניידים**: הגדר מגבלה לשימוש בנתונים לנייד כדי לחסום נתונים לנייד אם הגעת למגבלה.
 - **התאם אישית את ההגדרות הנתונים לנייד**.

הגדרות שיחה

תוכל להתאים אישית את הגדרות השיחה, כגון אפשרויות שיחה קולית ושיחה בינלאומית.


• ייתכן שחלק מהפונקציות אינן נתמכות, בהתאם לאזור ולספק השירות. 

- 1 במסך ההגדרות, הקש על **רשתות** < **הגדרות שיחה**.
- 2 התאם אישית את ההגדרות.

שתף והתחבר

NFC

תוכל להשתמש במכשיר גם ככרטיס נסיעה בתחבורה ציבורית או ככרטיס אשראי. תוכל גם לשתף נתונים עם המכשיר השני.

- 1 במסך ההגדרות, הקש על **רשתות** < **שתף והתחבר** < **NFC**.
- 2 הקש על  כדי להפעיל אותו.
- הצמד את המכשיר שלך למכשיר השני התומך ב-NFC כדי לאפשר שיתוף נתונים.

• המיקום של אנטנת NFC תלוי בסוג המכשיר. ראה **סקירה כללית של החלקים** לפרטים על אזור אנטנת ה-NFC.



Android Beam

תוכל לשתף קבצים על ידי הצמדת גב המכשיר אל מכשיר השני. תוכל גם לשתף קבצים, כולל מוסיקה, סרטונים או אנשי קשר ואף לפתוח דף אינטרנט או להפעיל יישום דרך המכשיר השני.

- 1 במסך ההגדרות, הקש על **רשתות** < **שתף והתחבר** < **Android Beam**.

- 2 הצמד את גב המכשיר אל המכשיר השני.

• המיקום של אנטנת NFC תלוי בסוג המכשיר.



שיתוף קבצים

תוכל לשלוח ולקבל קבצים בין המכשיר שלך למכשירים או טאבלטים אחרים של LG.

• לפרטים, ראה **שליחה או קבלה של קבצים**.

- 1 במסך ההגדרות, הקש על **רשתות < שתף והתחבר > שיתוף קבצים**.
- 2 התאם אישית את ההגדרות הבאות:
 - **G6 plus**: שנה את שם המכשיר.
 - **שמור ב**: הגדר את תיקיית היעד שבה יישמרו קבצים שנשלחו ממכשירים אחרים.
 - **שיתוף קבצים**: אפשר קבלה של קבצים שנשלחו ממכשירים אחרים.
 - **SmartShare Beam**: שתף קבצים עם מכשירים אחרים דרך SmartShare Beam.
 - **עזרה**: באפשרותך להציג עזרה על שיתוף קבצים.

שרת מדיה

תוכל לשתף תוכן מדיה במכשיר שלך עם מכשירים סמוכים שתומכים ב-DLNA.

- 1 במסך ההגדרות, הקש על **רשתות < שתף והתחבר > שרת מדיה**.
- 2 התאם אישית את ההגדרות הבאות:
 - **שיתוף תוכן**: שתף תוכן במכשיר עם מכשירים סמוכים.
 - **G6 plus**: הגדר את שם המכשיר שלך.
 - **תוכן לשיתוף**: בחר את סוג תוכן המדיה כדי לשתף עם מכשירים אחרים.
 - **מכשירים מורשים**: הצג רשימה של מכשירים שמורשים לגשת לתוכן במכשיר.
 - **התקנים לא מורשים**: הצג רשימה של מכשירים שאינם מורשים לגשת לתוכן במכשיר.

שתף מסך


תוכל להקרין את המסך ולהשמיע את הצלילים מהמכשיר באמצעות מכשיר אחר, כמו למשל טלוויזיה, בתנאי שהוא תומך בפונקציה Miracast.

1 במסך ההגדרות, הקש על **רשתות** < **שתף והתחבר** < **שתף מסך**.

2 הקש על  כדי להפעיל אותו.

3 בחר מכשיר מרשימה של מכשירים סמוכים.

- אם המכשיר הרצוי אינו מופיע, הקש על **חיפוש** כדי לרענן את הרשימה.
- לאחר ההתחברות למכשיר, המכשיר מציג את מסך המכשיר שלך.

•  שיתוף המסך יכבה באופן אוטומטי אם אין מכשיר תואם לשיתוף בקרבת מקום.

LG AirDrive

תוכל להשתמש בחשבון LG כדי לנהל קבצים שנשמרו במכשיר ממחשב. אינך צריך חיבור USB.

1 במסך ההגדרות, הקש על **רשתות** < **שתף והתחבר** < **LG AirDrive** <

2 השתמש בחשבון LG יחיד כדי להיכנס ל-LG Bridge במחשב ול-LG AirDrive במכשיר.


• ניתן להוריד את תוכנת LG Bridge מאתר www.lg-mobile.co.il

3 נהל קבצים במכשיר מהמחשב.


הדפסה

תוכל לחבר את המכשיר למדפסת Bluetooth ולהדפיס תמונות או מסמכים השמורים במכשיר.

- 1 במסך ההגדרות, הקש על **רשתות** < **שתף והתחבר** < **הדפסה**.

• אם המדפסת הרצויה אינה מצוינת ברשימה, התקן את מנהל ההתקן של המדפסת מחנות היישומים. 

- 2 הקש על כדי להפעיל אותו.
- 3 בחר מדפסת במסך רשימת המדפסות.
 - כדי להוסיף מדפסת, הקש על : < **הוסף מדפסת**.
 - כדי לחפש שם מדפסת, הקש על : < **חפש**.
 - הקש על : < **הגדרות** במסך רשימת המדפסות.
- 4 בחר קובץ והקש על : < **הדפס**.
 - המסמך מודפס.

• אם אין לך חשבון Google, הקש על **הוסף חשבון** כדי ליצור חשבון. 


שיתוף אינטרנט

שיתוף באמצעות USB

תוכל לחבר את המכשיר למכשיר אחר דרך USB ולשתף נתונים לנייד.

- 1 חבר את המכשיר והמכשירים האחרים באמצעות כבל USB.
- 2 במסך ההגדרות, הקש על **רשתות** < **שיתוף אינטרנט** < **שיתוף באמצעות USB** ולאחר מכן הקש על כדי להפעיל אותו.

- אפשרות זו משתמשת בנתונים לנייד, ועשויה להיות כרוכה בתשלום, בהתאם לתוכנית המחירים שלך. לקבלת מידע נוסף, פנה לספק השירות שלך.
- בעת התחברות למחשב, הורד את מנהל התקן ה-USB מהאתר www.lg-mobile.co.il והתקן אותו במחשב.
- לא ניתן להעביר קבצים בין המכשיר למחשב כאשר חיבור לאינטרנט באמצעות USB מופעל. כבה את החיבור לאינטרנט באמצעות USB כדי לשלוח או לקבל קבצים.
- מערכות הפעלה שתומכות בחיבור לאינטרנט הן Windows XP ואילך, או Linux.




נקודה חמה ניידת ב- Wi-Fi

תוכל להגדיר את המכשיר כנתב אלחוטי כך שהמכשירים האחרים יוכלו להתחבר לאינטרנט באמצעות חיבור הנתונים לנייד של המכשיר.

- 1 במסך ההגדרות, הקש על **רשתות** < **שיתוף אינטרנט** < **נקודה חמה ניידת ב- Wi-Fi** ולאחר מכן הקש על כדי להפעיל אותו.
- 2 הקש על **הגדרת נקודה חמה של Wi-Fi**, ולאחר מכן הזן את שם Wi-Fi (SSID) והסיסמה.
- 3 הפעל את Wi-Fi במכשיר השני ובחר את השם של רשת המכשיר ברשימת ה-Wi-Fi.
- 4 הזן את סיסמת הרשת.


- אפשרות זו משתמשת בנתונים לנייד, ועשויה להיות כרוכה בתשלום, בהתאם לתוכנית המחירים שלך. לקבלת מידע נוסף, פנה לספק השירות שלך.
- לרשותך מידע נוסף באתר אינטרנט זה:
<http://www.android.com/tether#wifi>



שיתוף אינטרנט ב-Bluetooth

ניתן לחבר מכשיר עם חיבור Bluetooth לאינטרנט דרך חיבור הנתונים לנייד במכשיר שלך.

- 1 במסך ההגדרות, הקש על **רשתות** < **שיתוף אינטרנט** < **שיתוף אינטרנט ב-Bluetooth** ולאחר מכן הקש על  כדי להפעיל אותו.
- 2 הפעל את Bluetooth בשני המכשירים ושייך אותם.

-  אפשרות זו משתמשת בנתונים לנייד, ועשויה להיות כרוכה בתשלום, בהתאם לתוכנית המחירים שלך. לקבלת מידע נוסף, פנה לספק השירות שלך.
- לרשותך מידע נוסף באתר אינטרנט זה:
http://www.android.com/tether#Bluetooth_tethering

עזרה

תוכל להציג את העזרה בנושא קשירה ונקודות חמות. במסך ההגדרות, הקש על **רשתות** < **שיתוף אינטרנט** < **עזרה**.

עוד

מצב טיסה

תוכל לכבות את פונקציות השיחה והנתונים לנייד. כאשר מצב זה מופעל, פונקציות שאינן כוללות נתונים, כמו הפעלת משחקים ומוסיקה, הופכות ללא זמינות.

- 1 במסך ההגדרות, הקש על **רשתות** < **עוד** < **מצב טיסה**.
- 2 הקש על **הפעל** במסך האישור.

רשתות ניידות

אתה יכול להתאים אישית את הגדרות הרשת הניידת.

- 1 במסך ההגדרות, הקש על **רשתות** < **עוד** < **רשתות ניידות**.
- 2 התאם אישית את ההגדרות הבאות:
 - **סוג רשת**: בחרו סוג רשת.
 - **שמות נקודות גישה**: הצג או שנה את נקודת הגישה לשימוש בשירותי נתונים לנייד. כדי לשנות את נקודת הגישה, בחר אפשרות מתוך רשימת נקודות הגישה.
 - **מפעילי רשת סלולרית**: חפש מפעילי רשת סלולרית והתחבר באופן אוטומטי לרשת.

VPN

תוכל להתחבר לרשת וירטואלית בטוחה, כמו אינטראנט. תוכל גם לנהל רשתות פרטיות וירטואליות מחוברות.

הוספת VPN

- 1 במסך ההגדרות, הקש על **רשתות** < **עוד** < **VPN**.
- 2 הקש על **הוסף VPN**.

• תכונה זו זמינה רק כאשר נעילת המסך מופעלת. אם נעילת המסך מבוטלת, מופיע מסך התראות. הקש על **שנה** במסך ההתראה כדי להפעיל את נעילת המסך. ראה **הגדרת נעילת מסך** לפרטים.

- 3 הזן פרטי VPN והקש על **שמור**.

קביעת ההגדרות של VPN

- 1 הקש על VPN ברשימה **רשתות VPN**.
- 2 הזן את פרטי חשבון המשתמש של VPN והקש על **התחבר**.
 - כדי לשמור את פרטי החשבון, סמן את התיבה **שמור פרטי חשבון**.

צליל והתראה

תוכל להתאים אישית את הגדרות הקול, הרטט וההתראות. במסך ההגדרות, הקש על **צליל והתראה** והתאם אישית את ההגדרות הבאות:

- **פרופילי צליל:** שנה את מצב הצליל ל**צליל**, **רטט בלבד** או **שקט**.
- **עוצמה:** התאם את עוצמת הצליל של פריטים שונים.
- **צלצול טלפון SIM1 / צלצול טלפון SIM2:** בחר רינגטון לשיחות נכנסות. הוסף או מחק רינגטונים.
- **צלצול מותאם:** צור רינגטון לשיחה נכנסת מאיש קשר מסוים.
- **עוצמת רטט:** כוונן את עוצמת הרטט.
- **צליל עם רטט:** קבע כי המכשיר יפעיל רטט וישמיע רינגטון בו-זמנית.
- **SIM1 סוג רטט / SIM2 סוג רטט:** אתה יכול לבחור את סוג הרטט כשאתה מקבל שיחות.
- **נא לא להפריע:** הגדר את השעה, הטווח וסוג היישום לקבלת הודעות של התראות. קבל הודעות של התראות בימים מסוימים בשבוע בלבד.
- **מסך נעילה:** הצג או הסתר הודעת התראה במסך הנעילה. תוכל גם להסתיר מידע פרטי.
- **יישומים:** בחר את היישומים שיוורשו להציג התראות במסך וקבע סדר עדיפות ביניהם בהקשר עם התראות והודעות.
- **Hi-Fi Quad DAC:** חבר לאוזניה, לרמקול או למכשירי שמע חיצוניים אחרים, והשתמש בכל אחד מהם כ-Hi-Fi Quad DAC.
- **עוד < SIM1 צליל התראה / SIM2 צליל התראה:** בחר רינגטון להתראה. הגדר מוסיקה שנשמרה במכשיר כרינגטון להתראה.
- **עוד < רטט בעת הקשה:** קבע שהמכשיר יפעיל רטט כאשר תקיש על פריטים מסוימים על המסך.
- **עוד < אפקטים קוליים:** בחר אפקט קול שיושמע כאשר תקיש על מקש החיוג או על המקלדת, כאשר תבחר אפשרות או כאשר תנעל או תבטל נעילה של המסך.

תצוגה

תוכל להתאים אישית הגדרות מפורטות לכל סוג מסך. במסך ההגדרות, הקש על **תצוגה** והתאם אישית את ההגדרות הבאות:

- **מסך ראשי:** התאם אישית את הגדרות המסך הראשי. לפרטים, ראה **הגדרות מסך בית**.
- **מסך נעילה:** התאם אישית את הגדרות מסך הנעילה. לפרטים, ראה **הגדרות נעילת מסך**.
- **ערכת נושא:** בחר ערכת נושא של מסך עבור ההתקן שלך.
- **לחצני תצוגה:** סדר מחדש את לחצני המגע של המסך הראשי או שנה את צבעי הרקע שלהם.
- **סוג גופן:** שנה את סוג הגופן.
- **גודל גופן:** שנה את גודל הגופן.
- **טקסט מודגש:** הדגש את הטקסט על במסך.
- **התאמת הצגת יישום לגודל המסך:** כוונן את גודל פריסת היישומים במסך.
- **גודל תצוגה:** הגדר את הפריטים במסך לגדול שתוכל לראות בקלות. ייתכן שחלק מהפריטים ישנו מיקום.
- **תצוגה נוחה:** הגדר את המכשיר להפחתת כמות האור הכחול על המסך כדי לצמצם את מאמץ העיניים.
- **בהירות:** השתמש במחוון כדי לשנות את בהירת המסך של המכשיר. כדי לכוונן באופן אוטומטי את בהירות המסך בהתאם לעוצמת תאורת הסביבה, הקש על **אוטומטי**.
- **אוטומטי:** הגדר את המכשיר כך שבהירות המסך תותאם באופן אוטומטי לעוצמת התאורה בסביבה.
- **Always-on display:** הצג תמיד מידע, כמו התאריך, השעה והתראות, גם כאשר המסך כבוי. לפרטים, ראה **Always-on display**.
- **סיבוב מסך אוטומטי:** סובב באופן אוטומטי את המסך בהתאם לכיוון המכשיר.
- **כיבוי מסך אוטומטי:** כבה באופן אוטומטי את המסך כאשר המכשיר לא היה פעיל במשך פרק זמן שצוין.

- **עוד < KnockOn**: הפעל או כבה את המסך על-ידי הקשה כפולה על המסך.
- **עוד < שומר מסך**: הצג שומר מסך כאשר המכשיר מחובר למחזיק או למטען. בחר את סוג השומר המסך שיוצג.
- **עוד < תצוגה ממוזערת**: באפשרותך להקטין את גודל המסך כדי להשתמש במכשיר בצורה נוחה ביד אחת. גרור את לחצני המגע במסך הבית שמופיעים בתחתית המסך שמאלה או ימינה.

כללי

שפה ומקלדת

תוכל להתאים אישית את הגדרות השפה והמקלדת עבור המכשיר שלך.

- 1 במסך ההגדרות, הקש על **כללי < שפה ומקלדת**.
- 2 התאם אישית את ההגדרות הבאות:
 - **שפה**: בחר שפה והחל אותה על המכשיר.
 - **מקלדת נוכחית**: הצג את המקלדת שנמצאת כעת בשימוש. בחר מקלדת לשימוש בעת הזנת טקסט.
 - **מקלדת LG**: התאם אישית את הגדרות מקלדת LG.
 - **הקלדה קולית של Google**: בחר אפשרויות להכתבת טקסט מאת Google.
 - **פלט המרת טקסט לדיבור**: בחר את ההגדרות לפלט טקסט-לדיבור.
 - **מהירות מצביע**: כוונן את מהירות המצביע של העכבר או של לוח המעקב.
 - **המרת לחצנים**: הגדר ביצוע פעולות ראשיות בתפעול ישיר דרך הלחצן הימני של העכבר.

מיקום

באפשרותך להתאים אישית את האופן שבו יישומים מסוימים יעשו שימוש בפרטי המיקום שלך.

- 1 במסך ההגדרות, הקש על **כללי > מיקום**.
- 2 התאם אישית את ההגדרות הבאות:
 - **מצב:** בחר שיטה לאספקת פרטי המיקום שלך.
 - **המקומות שלי:** הגדר את המכשיר לניתוח מקומות שבהם אתה מבקר לעתים תכופות כך שהוא יוכל לזהות באופן אוטומטי כתובת מגורים.
 - **בקשת מיקום האחרונה:** הצג יישומים שביקשו לאחרונה פרטי מיקום.
 - **קביעת מיקום חסכונית:** הערך את מיקום המכשיר על-ידי שימוש בצריכת חשמל נמוכה.
 - **היסטוריית המיקומים של Google:** קבע הגדרות היסטוריית מיקום של Google.

חשבונות וסנכרון

תוכל להוסיף או לנהל חשבונות, כולל חשבון Google. תוכל גם לסנכרן יישומים או פרטי משתמש מסוימים באופן אוטומטי.

- 1 במסך ההגדרות, הקש על **כללי > חשבונות וסנכרון**.
- 2 התאם אישית את ההגדרות הבאות:
 - **לסנכרן נתונים באופן אוטומטי:** סנכרן את כל החשבונות הרשומים באופן אוטומטי.
 - **חשבונות:** הצג רשימה של החשבונות הרשומים. כדי להציג או לשנות פרטים של חשבון, הקש על החשבון.
 - **הוסף חשבון:** הוסף חשבונות.

ענן

אתה יכול להירשם לחשבון הענן ולהציג תוכן שנשמר בענן מהמכשיר.

- 1 במסך ההגדרות, הקש על **כללי > ענן**.

2 התאם אישית את ההגדרות.

הגדרות

משתמשים

תוכל להוסיף משתמשים שאיתם תשתף את המכשיר שלך.

1 במסך ההגדרות, הקש על **כללי** < **משתמשים**.

2 התאם אישית את ההגדרות.

נגישות

תוכל לנהל יישומי Plug-in של נגישות המותקנים במכשיר שלך.

1 במסך ההגדרות, הקש על **כללי** < **נגישות**.

2 התאם אישית את ההגדרות הבאות:

• **ראייה** < **TalkBack**: הגדר את המכשיר כך שיודיע על סטטוס המסך או על פעולות באמצעות קול.

• **ראייה** < **התראות קוליות על הודעות/שיחות**: הגדר את המכשיר כך שיקריא בקול את פרטי המתקשר או ההודעה.

• **ראייה** < **גודל גופן**: שנה את גודל הגופן.

• **ראייה** < **טקסט מודגש**: הדגש את הטקסט על במסך.

• **ראייה** < **גודל תצוגה**: הגדר את הפריטים במסך לגדול שתוכל לראות בקלות. ייתכן שחלק מהפריטים ישנו מיקום.

• **ראייה** < **שינוי גודל תצוגה במגע**: הגדל או הקטן את התצוגה על-ידי הקשה על המסך שלוש פעמים.

• **ראייה** < **חלון זום**: הגדל או הקטן תצוגה בתוך חלון והפוך את הצבעים.

• **ראייה** < **סמן עכבר גדול**: הגדל את סמן העכבר.

• **ראייה** < **מסך בעל ניגודיות גבוהה**: הפוך את צבע הרקע לשחור כדי להשיג מסד בניגודיות גבוהה.

• **ראייה** < **היפוך צבעי המסך**: הגבר את ניגודיות הצבע בתצוגה לטובת אנשים עם לקות ראייה.

• **ראייה** < **התאמה אישית של צבעי המסך**: כוונן את צבע התצוגה.

• **ראייה** < **גווני אפור**: העבר את המסך למצב גווני אפור.

• **ראייה** < **סיים שיחות באמצעות מקש ההפעלה**: סיים שיחה על-ידי לחיצה על מקש הפעלה/נעילה.

- **שמיעה < כתובית:** הפעל את שירות הכתוביות בעת הקרנת סרטוני וידאו לאנשים כבדי שמיעה.
- **שמיעה < התראות פלש:** הגדר את המכשיר כך שייתן לך התראה בעזרת אור מהבהב עבור שיחות נכנסות, הודעות והתראות.
- **שמיעה < השתק את כל הצלילים:** השתק את כל הצלילים והנמך את עוצמת הקול במקלט.
- **שמיעה < ערוץ שמע:** בחר את סוג השמע.
- **שמיעה < איזון קול:** כוונן את איזון פלט השמע. השתמש במחוון כדי לשנות את האיזון.
- **תנועה ותודעה < Touch assistant:** הפעל את לוח המגע כדי להקל את השימוש בלחצנים ובמחוות.
- **תנועה ותודעה < קלט בנגיעה:** כדי להזין טקסט, הקש הקשה ממושכת על המסך או שנה אותו על-ידי נגיעה במסך.
- **תנועה ותודעה < מקלדת פיזית:** התאם אישית את הגדרות המקלדת.
- **תנועה ותודעה < לחיצת עכבר אוטומטי:** לחץ באופן אוטומטי על סמן העכבר במקרה שאין תנועה.
- **תנועה ותודעה < לחץ לחיצה ממושכת לשיחות:** השב לשיחות או דחה שיחות על-ידי הקשת הקשה ממושכת על לחצן השיחה במקום לגרור אותו.
- **תנועה ותודעה < כיבוי מסך אוטומטי:** כבה באופן אוטומטי את המסך כאשר המכשיר לא היה פעיל במשך פרק זמן שצוין.
- **תנועה ותודעה < אזורי בקרת מגע:** הגבל את אזור המגע כך שניתן יהיה לשלוט חלק מסוים של המסך בלבד באמצעות קלט המגע.
- **קיצור דרך לתכונות הנגישות:** קבל במהירות גישה לפונקציות בשימוש נפוץ על-ידי הקשה על  שלוש פעמים.
- **סיבוב מסך אוטומטי:** שנה באופן אוטומטי את כיוון המסך בהתאם למצב הפיזי של המכשיר.
- **שינוי אופן גישה:** צור צירופי מקשים שיסייעו לך לשלוט במכשיר שלך.

מקש קיצור דרך

תוכל להשתמש במקשי עוצמת הקול כדי להפעיל ישירות יישומים כאשר המסך כבוי או נעול.

1 במסך ההגדרות, הקש על **כללי** < **מקש קיצור דרך**.

2 הקש על  כדי להפעיל אותו.

- לחץ פעמיים על מקש החלשת עוצמת הקול (-) כדי להפעיל את היישום מצלמה כאשר המסך נעול או כבוי. לחץ פעמיים על מקש הגברת עוצמת הקול (+) כדי להפעיל את Capture+.

שירותי Google

תוכל להשתמש בהגדרות Google לניהול יישומי Google שברשותך והגדרות החשבון שלך.

במסך ההגדרות, הקש על **כללי** < **שירותי Google**.

טביעות אצבע ואבטחה

1 במסך ההגדרות, הקש על **כללי** < **טביעות אצבע ואבטחה**.

2 התאם אישית את ההגדרות הבאות:

- **טביעות אצבע**: השתמש בטביעת אצבע כדי לבטל נעילת המסך או התוכן. לפרטים, ראה **סקירה כללית של זיהוי טביעת אצבע**.

- **נעילת תוכן**: הגדר את השיטה לנעילת קבצים בגלריה או ב QuickMemo+.

- **הצפן אחסון כרטיס SD**: הצפן את כרטיס הזיכרון כדי למנוע שימוש במכשיר אחר. לפרטים, ראה **הצפנת כרטיס זיכרון**.

- **אתחול מאובטח**: הגן על המכשיר שלך בעזרת מנעול בעת שהוא מופעל. ראה **הגדרות אתחול מאובטח** לפרטים.

- **הגדר נעילת כרטיס SIM**: נעל או בטל נעילה של כרטיס ה-USIM, או שנה את הסיסמה (PIN).

- **הפוך את הסיסמאות לגלויות**: הצג סיסמה בזמן שאתה מזין אותה.

- **מנהלי התקנים:** אפשר הרשאות להגבלת השליטה או השימוש במכשיר עבור יישומים מסוימים.
- **מקורות לא מוכרים:** אפשר התקנה של יישומים מיישומים שאינם מחנות Play.
- **הגנה על אישורים:** הצג את סוג האחסון שבו אישור האבטחה יישמר.
- **תעודת ניהול:** נהל את אישור האבטחה השמור בהתקן.
- **Trust agents:** הצג והשתמש בסוכנים אמינים המותקנים במחשב.
- **קביעת מסך:** תקן את מסך היישום כדי לאפשר שימוש ביישום הפעיל כעת בלבד.
- **גישה לשימוש:** הצג פרטים על השימוש ביישומים במכשיר.

Smart settings

תוכל לשנות באופן אוטומטי את הגדרות המכשיר בהתאם לדפוסי השימוש ולמיקום.

- כדי להשתמש בפונקציה 'הגדרות חכמות', הקפד להגדיר את כתובת המגורים. לפרטים, ראה **מיקום**.

- 1 במסך ההגדרות, הקש על **כללי** < **Smart settings**.
- 2 הפעל פריטים שברצונך לשנות בהם את ההגדרות באופן אוטומטי

תאריך ושעה

תוכל להתאים אישית את הגדרות התאריך והשעה עבור המכשיר שלך.


- 1 במסך ההגדרות, הקש על **כללי** < **תאריך ושעה**.
- 2 התאם אישית את ההגדרות.

אחסון

תוכל להציג ולנהל את האחסון הפנימי במכשיר או בשטח האחסון של כרטיס הזיכרון.

1 במסך ההגדרות, הקש על **כללי** < **אחסון**.

2 התאם אישית את ההגדרות הבאות:


- **אחסון בהתקן**: הצג את שטח האחסון הכולל ופנה שטח באחסון הפנימי של המכשיר. הצג רשימה של יישומים שנמצאים בשימוש ואת קיבולת האחסון עבור כל יישום.
- **אחסון נייד**: הצג את שטח האחסון הכולל ואת השטח הפנוי בכרטיס הזיכרון. אפשרות זו מופיעה רק כאשר הוכנס כרטיס זיכרון. כדי לבטל טעינה של כרטיס זיכרון, הקש על .

חיסכון בחשמל ובסוללה

תוכל להציג את פרטי הסוללה הנוכחית או להפעיל מצב חיסכון בחשמל.

1 במסך ההגדרות, הקש על **כללי** < **חיסכון בחשמל ובסוללה**.

2 התאם אישית את ההגדרות הבאות:

- **ניצול סוללה**: הצג את \בפרטי השימוש בסוללה. כדי להציג פרטים נוספים, בחר פריט ספציפי.
- **אחוז הסוללה בשורת המצב**: הצג את רמת טעינת הסוללה שנותרה כאחוז בשורת המצב.
- **חיסכון בחשמל**: הקטן את צריכת הסוללה על-ידי ביטול הגדרות מכשיר מסוימות, כמו בהירות התצוגה, המהירות ועוצמת הרטט. בשורת המצב מופיע  כאשר מצב חיסכון בחשמל מופעל.
- **מצב חיסכון בחשמל במשחקים**: כוונן את איכות הווידאו כדי להקטין את צריכת הסוללה בעת הפעלת משחקים.

זיכרון

תוכל להציג את הסכום הממוצע של השימוש בזיכרון לאורך פרק זמן מסוים ואת הזיכרון שהיה בשימוש על-ידי היישום.

- 1 במסך ההגדרות, הקש על **כללי** < **זיכרון**.
- 2 הקש על ▼ כדי להגדיר משבצת זמן לאחזור נתונים.

Smart Doctor

תוכל להשתמש ב-Smart Doctor כדי לאבחן את מצב המכשיר ולמטב אותו.

במסך ההגדרות, הקש על **כללי** < **Smart Doctor**.

יישומים

תוכל להציג רשימה של יישומים מותקנים. בעת הצורך, עצור יישומים פועלים או מחק יישומים.

- 1 במסך ההגדרות, הקש על **כללי** < **יישומים**.
- 2 בחר יישום ובצע פעולות.

הקש ושלם

תוכל לבצע תשלומים עם המכשיר הנייד במקום עם כרטיס אשראי. במסך ההגדרות, הקש על **כללי** < **הקש ושלם**.

גיבוי ואיפוס

תוכל לגבות נתונים השמורים במכשיר שלך במכשיר או בטאבלט אחר של LG. אפס את המכשיר, בעת הצורך.

- 1 במסך ההגדרות, הקש על **כללי** < **גיבוי ואיפוס**.
- 2 התאם אישית את ההגדרות הבאות:

• **LG Mobile Switch**: העבר בקלות נתונים של ההודעות שנשמרו, התמונות, המסכים הראשיים ונתונים אחרים למכשיר חדש. ראה **LG Mobile Switch** לפרטים.

- **גיבוי ושחזור:** גבה את נתוני המכשיר שלך או שחזר נתונים למכשיר מגיבוי.
- **גבה את הנתונים שלי:** גבה את נתונים היישום שלך, את סיסמאות Wi-Fi והגדרות אחרות לשרת Google.
- **חשבון גיבוי:** הצג את חשבון הגיבוי הנוכחי שנמצא בשימוש.
- **שחזור אוטומטי:** שחזר באופן אוטומטי הגדרות גיבוי ונתונים בעת התקנה מחדש של יישום.
- **איפוס הגדרות רשת:** אפס את Wi-Fi, Bluetooth והגדרות רשת אחרות.
- **שחזור נתוני היצרן:** אפס את כל ההגדרות עבור המכשיר ומחק נתונים.

• פעולת איפוס המכשיר מוחקת את כל הנתונים השמורים בו. הזן את שם המכשיר, את חשבון Google ופרטים התחלתיים אחרים פעם נוספת.



אודות הטלפון

תוכל להציג מידע אודות המכשיר, כמו שם, הסטטוס, פרטי התוכנה ומידע משפטי.
במסך ההגדרות, הקש על **כללי** < **אודות הטלפון** והצג מידע.

רגולציה ובטיחות

ניתן להציג סימוני תקינה ומידע הקשור אליהם במכשיר.
במסך ההגדרות, הקש על **כללי** < **רגולציה ובטיחות**.

05

נספח

הגדרות השפה של LG

בחר את השפה שתשמש במכשיר שלך.

- הקש על  < הגדרות < כללי < שפה ומקלדת < שפה < הוספת שפה ובחר שפה.

- הקש הקשה ממושכת על  וגרור אותה לחלק העליון של רשימת השפות כדי להגדיר אותה כשפת ברירת מחדל.

LG Bridge

LG Bridge - סקירה כללית

LG Bridge הוא יישום המסייע לך בניהול נוח של תמונות, מוסיקה, סרטוני וידאו ומסמכים השמורים בטלפון החכם של LG דרך המחשב שלך. באמצעות היישום תוכל לגבות אנשי קשר, תמונות ופריטים נוספים במחשב ואף לעדכן את תוכנת המכשיר.

- לפרטים, עיין בעזרה של LG Bridge. 
- זמינות של תכונות נתמכות אינה אחידה ותלויה במכשיר.
- מנהל התקן USB של LG נחוץ לך כדי לחבר טלפון חכם של LG אל המחשב והוא יותקן יחד עם LG Bridge.

הפונקציות הכלולות ביישום LG Bridge

- נהל דרך המחשב שלך את הקבצים השמורים במכשיר באמצעות חיבור Wi-Fi או חיבור נתונים ניידים.
- גבה נתונים מהמכשיר במחשב שלך או שחזר אותם מהמחשב באמצעות כבל USB.
- עדכן את תוכנת המכשיר דרך המחשב שלך באמצעות כבל USB.

התקנת LG Bridge במחשב

- 1 במחשב שלך, עבור אל www.lg-mobile.co.il.
- 2 בחר את המדינה שלך ולחץ על **Q**.
- 3 בשורת החיפוש, הקלד את שם המכשיר שברשותך.
- 4 לחץ על **תמיכה < Manuals & Downloads**.
- 5 ב'תוכנה וקושחה', לחץ על **PC Sync** והורד את קובץ ההגדרה.
 - לחץ על **פרטים** כדי להציג את דרישות המינימום להתקנת LG Bridge.


עדכון תוכנת הטלפון

עדכון תוכנת הטלפון הנייד של LG מהאינטרנט

למידע נוסף אודות השימוש בפונקציה זו, בקר בכתובת <http://www.lg.com/common/index.jsp> בחר את המדינה והשפה שלך.

תכונה זו מאפשרת לך לעדכן בנוחות את הקושחה של הטלפון לגרסה חדשה יותר מהאינטרנט, ללא צורך לבקר במרכז שירות. תכונה זו תהיה זמינה רק אם LG תייצר גרסת קושחה חדשה שתהיה זמינה למכשיר שלך.

מאחר שעדכון הקושחה של הטלפון הנייד דורש את תשומת לבו המלאה של המשתמש במשך כל תהליך העדכון, הקפד לקרוא את כל ההוראות וההערות שיופיעו בכל שלב לפני שתתקדם הלאה. חשוב לזכור שניתוק כבל ה-USB במהלך השדרוג עלול לגרום נזק חמור לטלפון הנייד.

•  LG שומרת על זכותה, על פי שיקול דעתה הבלעדי, להפוך עדכוני קושחה לזמינים עבור דגמים נבחרים בלבד ואינה ערבה לזמינות הגרסה החדשה של הקושחה לכל דגמי הטלפון.

עדכון תוכנת הטלפון הנייד של LG באופן אלחוטי (OTA)

תכונה זו מאפשרת לך לעדכן בנוחות את תוכנת הטלפון לגרסה חדשה יותר בשיטת OTA, מבלי לחבר כבל USB. תכונה זו תהיה זמינה רק אם LG תייצר גרסת קושחה חדשה שתהיה זמינה למכשיר שלך.

תחילה בדוק את גרסת התוכנה בטלפון הנייד:

הגדרות < כללי < אודות הטלפון < כללי < מרכז עדכונים < עדכון תוכנה < חפש עדכונים כעת.

-  הנתונים האישיים שלך משטח האחסון הפנימי בטלפון—לרבות פרטי חשבון Google וכל חשבון אחר, נתונים והגדרות של המערכת/היישומים שלך, יישומים שהורדו ורישיון ה-DRM שלך—עשויים ללכת לאיבוד בתהליך עדכון התוכנה של הטלפון. לפיכך, LG ממליצה לך לגבות את הנתונים האישיים שלך לפני שתעדכן את תוכנת הטלפון. LG לא תישא באחריות לאובדן נתונים אישיים כלשהם.
- הזמינות של תכונה זו תלויה באזור ובספק השירות.

מדריך למניעת גניבה

הגדר את המכשיר שלך כך שאנשים אחרים לא יוכלו להשתמש בו אם הוא יאופס להגדרות היצרן ללא רשותך. לדוגמה, אם המכשיר אבד, נגנב או נמחק, רק אדם בעל חשבון Google או בעל פרטי נעילת מסך יוכל להשתמש במכשיר.

כל שעליך לעשות כדי לוודא שהמכשיר שלך מוגן הוא:

- להגדיר נעילת מסך: אם המכשיר אבד או נגנב, אך הגדרת נעילת מסך, לא תהיה אפשרות למחוק את המכשיר באמצעות תפריט 'הגדרות', כל עוד נעילת המסך לא תבוטל.
- הוסף את חשבון Google שלך למכשיר: אם המכשיר שלך נמחק אך הגדרת בו את חשבון Google שלך, לא תהיה אפשרות לסיים את תהליך ההגדרה של המכשיר עד שהפרטים של חשבון Google יוזנו שוב.

לאחר שהמכשיר יהיה מוגן, תצטרך לבטל את נעילת המסך או להזין את הסיסמה של חשבון Google אם עליך לבצע איפוס להגדרות היצרן. הדבר יבטיח שאתה או מישהו שאתה סומך עליו תבצעו את האיפוס.

- אל תשכח את חשבון Google והסיסמה שהוספת למכשיר לפני ביצוע האיפוס להגדרות היצרן. אם אינך יכול לספק את פרטי החשבון במשך תהליך ההגדרה, לא תוכל להשתמש כלל במכשיר לאחר ביצוע האיפוס להגדרות היצרן.

פרטי הודעה על תוכנת קוד פתוח

אנא בקרו באתר <http://opensource.lge.com> על מנת להשיג את קוד המקור תחת GPL, LGPL, MPL, קוד פתוח ורשיונות אחרים. בנוסף לקוד המקור, זמינים להורדה תנאי הרשיון, אחריות, כתבי ויתור וזכויות יוצרים. LG Electronics תספק קוד מקור על גבי התקליטור, תמורת תשלום המכסה הוצאות של ביצוע ואחסון. לבקשה ניתן לפנות לכתובת הדואר האלקטרוני: opensource@lge.com. הצעה זו תקפה למשך (3) שנים ממועד הרכישה.

מידע בנושאי תקינה (מספר הזיהוי של התקן, תיוג אלקטרוני וכולי)

לקבלת פרטים בנושאי תקינה, עבור להגדרות < כללי > רגולציה ובטיחות.

סימנים מסחריים

- Copyright© 2017 LG Electronics, Inc. כל הזכויות שמורות. LG והסמל של LG הם סימנים מסחריים רשומים של LG Group ושל החברות הקשורות אליה.
- Duo™, YouTube™, Gmail™, Google Maps™, Google™ וחנות Google Play™ הם סימנים מסחריים של Google, Inc.
- Bluetooth® הוא סימן מסחרי רשום של Bluetooth SIG, Inc. ברחבי העולם.
- Wi-Fi® והלוגו של Wi-Fi הם סימנים מסחריים רשומים של Wi-Fi Alliance.
- כל יתר הסימנים המסחריים וזכויות היוצרים הם רכושם של בעליהם בהתאמה.

הצהרת תאימות

בזאת, **LG Electronics** מצהירה שהמוצר **LG-H870DSU** תואם לדרישות היסודיות ולתנאים הרלוונטיים האחרים של הנחיה **2014/53/EU**.

ניתן למצוא עותק שלהצהרת התאימות בכתובת
<http://www.lg.com/global/declaration>

מידע נוסף

 **DOLBY AUDIO™**

DOLBY AUDIO

מיוצר ברישיון מטעם Dolby Laboratories. Dolby Audio, וסמל ה-D הכפול הם סימנים מסחריים של Dolby Laboratories.

 **DOLBY VISION™**

DOLBY VISION

Dolby Vision, וסמל ה-D הכפול הם סימנים מסחריים של Dolby Laboratories. מיוצר ברישיון מטעם Dolby Laboratories. עבודות סודיות שלא פורסמו. Copyright © 2013-2015 Dolby Laboratories. כל הזכויות שמורות.

Dolby Vision תומך ב-4 מצבים לקבלת החוויה המיטבית.

- **קולנועית:** המצב הקרוב ביותר לקולנוע, טוב ביותר בסביבות חשוכות.
- **מבריק:** מציע את איכות הווידאו הטובה ביותר בסביבות בהירות יותר.
- **רגיל:** מאפשר השגת איזון בין החיסכון בחשמל לבין איכות הווידאו.
- **חי:** מחזק את הבהירות והצבעים לקבלת תמונה עזה יותר.

חלקי זכוכית מחוסמת

חלקי הזכוכית המחוסמת במכשיר זה אינם קבועים ועשויים להתבלות עם הזמן.

- אם הפלת את המכשיר על משטח קשה או אם הוא נתון למכות חזקות, עלול להיגרם נזק לזכוכית המחוסמת. אם זה קורה, הפסק מיד להשתמש במכשיר ופנה למרכז שירות לקוחות של LG.
- ניתן לרכוש בשוק כיסויי מגן כדי להגן על המכשיר מפני נזק. שים לב כי כיסויים אלה אינם כלולים במסגרת שירות האחריות שניתן על-ידי LG Electronics והבטיחות אינה מובטחת.

יחס גובה-רוחב

מכשיר זה עושה שימוש ביחס גובה-רוחב של 18:9.

- ייתכן שחלק מהיישומים שהורדו אינם תומכים ביחס גובה-רוחב של 18:9.

במקרה כזה, בחר ביחס המסך האופטימלי עבור היישום, או התייעץ עם ספק היישום לקבלת מידע נוסף.

שאלות נפוצות

בפרק זה מוצגות מספר בעיות שאתה עלול להיתקל בהן במהלך השימוש בטלפון. בעיות מסוימות יצריכו פנייה לספק השירות, אך את רובן תוכל לפתור בקלות בעצמך.

הודעה	סיבות אפשריות	אפשרויות לתיקון הבעיה
שגיאת כרטיס SIM	אין כרטיס SIM בטלפון או שהוא הוכנס בצורה לא נכונה.	ודאו שכרטיס ה-SIM הוכנס כראוי.
אין חיבור לרשת/ החיבור חלש	האות חלש או שאתה נמצא מחוץ לטווח הרשת של ספק השירות.	התקרב לחלון או צא לאזור פתוח. בדוק את מפת הכיסוי של מפעיל הרשת הסלולרית.
לא ניתן להגדיר יישומים	הם לא נתמכים על-ידי ספק השירות או שנדרש רישום עבורם.	פנה אל ספק השירות.
יישום שהורדתי קורים לשגיאות רבות.	יש בעיות ביישום.	1. הקש על ○ < הגדרות. 2. הקש על כללי < יישומים. 3. הקש על היישום < הסר התקנה .
לא ניתן לבצע שיחות	טעות בחיוג	רשת חדשה לא מאושרת.
	הוכנס כרטיס SIM חדש.	בדוק אם קיימות מגבלות חדשות.
לא ניתן להפעיל את המכשיר	הסוללה לא נטענה.	טען את הסוללה. בדוק את מחוון הטעינה בתצוגה.

הודעה	סיבות אפשריות	אפשרויות לתיקון הבעיה
שגיאת טעינה	הסוללה לא נטענה.	טען את הסוללה.
	הטמפרטורה החיצונית גבוהה או נמוכה מדי.	ודא שהמכשיר נטען בטמפרטורה רגילה.
	בעיית מגעים	בדוק את המטען ואת החיבור שלו למכשיר.
	אין מתח	חברו את המטען לשקע אחר.
	המטען פגום	החלף את המטען.
	מטען לא מתאים	השתמש רק באביזרים מקוריים של LG.
המספר אסור.	פונקציית מספר קבוע מראש פועלת.	בדוק את התפריט 'הגדרות' ונטרל את הפונקציה.
הקבצים אינם נפתחים	אין תמיכה בתבנית הקובץ	בדוק את תבניות הקובץ הנתמכות.
המסך אינו נדלק כאשר מתקבלת שיחה.	בעיה בחיישן הקרבה	אם אתה משתמש בנרתיק או כיסוי להגנה, ודא שהוא אינו מכסה את האזור שסביב חיישן הקרבה. ודא שהאזור שמסביב לחיישן הקרבה נקי.
אין צליל	מצב רטט	בדוק את מצב ההגדרות בתפריט הצליל כדי לוודא שאינך במצב רטט או במצב 'ללא הפרעות'.

אפשרויות לתיקון הבעיה	סיבות אפשריות	הודעה
<p>הפעלה מחדש של המכשיר אם המכשיר קופא או נתקע, ייתכן שיהיה עליך לסגור יישומים או לכבות את המכשיר ולהפעיל אותו שוב.</p>		
<p>ביצוע אתחול הקש הקשה ארוכה על מקש ההפעלה/נעילה ועל מקש הנמכת העוצמה (-) למשך כ- 10 שניות כדי להפעיל מחדש את המכשיר.</p>		
<p>איפוס המכשיר אם השיטות שלעיל לא פותרות את הבעיה, בצע שחזור של נתוני היצרן. במסך ההגדרות, הקש על כללי < גיבוי ואיפוס > שחזור נתוני היצרן.</p> <p>* אפס את כל ההגדרות עבור המכשיר ומחק נתונים. לפני ביצוע של שחזור נתוני היצרן, זכור ליצור עותקי גיבוי של כל הנתונים החשובים שמאוחסנים במכשיר.</p> <p>* אם רשמת חשבון Google למכשיר, עליך להיכנס לאותו חשבון Google לאחר איפוס המכשיר.</p>	<p>בעיה של פעולת תוכנה/ חומרה לא רציפה</p>	<p>ניתוק או קפיאה</p>

About this user guide

Thank you for choosing this LG product. Please carefully read this user guide before using the device for the first time to ensure safe and proper use.

- Always use genuine LG accessories. The supplied items are designed only for this device and may not be compatible with other devices.
- This device is not suitable for people who have a visual impairment due to the touchscreen keyboard.
- Descriptions are based on the device default settings.
- Default apps on the device are subject to updates, and support for these apps may be withdrawn without prior notice. If you have any questions about an app provided with the device, please contact an LG Service Centre. For user-installed apps, please contact the relevant service provider.
- Modifying the device's operating system or installing software from unofficial sources may damage the device and lead to data corruption or data loss. Such actions will violate your LG licence agreement and void your warranty.
- Some content and illustrations may differ from your device, depending on the area, service provider, software version, or OS version, and are subject to change without prior notice.
- Software, audio, wallpaper, images, and other media supplied with your device are licenced for limited use. If you extract and use these materials for commercial or other purposes, you may be infringing copyright laws. As a user, you are fully responsible for the illegal use of media.
- Additional charges may incur for data services, such as messaging, uploading, downloading, auto-syncing and location services. To void additional charges, select a data plan suitable to your needs. Contact your service provider to obtain additional details.

Instructional notices



WARNING: Situations that could cause injury to the user and third parties.



CAUTION: Situations that may cause minor injury or damage to the device.



NOTE: Notices or additional information.

Table of contents

5 Guidelines for safe and efficient use

01

Custom-designed Features

- 13 Notes on Water Resistant Properties
- 15 Video recording features
- 20 Gallery features
- 23 Making collage wallpapers
- 24 Audio recording features
- 27 Fingerprint recognition
- 30 Face recognition
- 34 Multi-tasking feature
- 35 Always-on Display
- 36 quick share

02

Basic Functions

- 38 Product components and accessories
- 39 Parts overview
- 41 Turning the power on or off
- 42 Installing the SIM card

- 44 Inserting the memory card
- 45 Removing the memory card
- 45 Battery
- 47 Touch screen
- 50 Home screen
- 59 Screen lock
- 63 Memory card encryption
- 64 Taking screenshots
- 65 Entering text
- 70 Content sharing
- 73 Do not disturb

03

Useful Apps

- 75 Installing and uninstalling apps
- 76 App trash
- 76 Phone
- 80 Messaging
- 81 Camera
- 101 Gallery
- 106 Contacts
- 108 QuickMemo+
- 110 Clock
- 111 Calendar

113	Tasks
113	Music
114	Calculator
114	LG Health
116	E-mail
117	FM Radio
118	File Manager
118	LG Mobile Switch
118	LG Friends Manager
119	Downloads
119	LG SmartWorld
120	Cell Broadcast
120	Instagram
120	Facebook
120	Evernote
120	Chrome
121	Google apps

04

Settings

124	Settings
124	Networks
137	Sound & notification
138	Display
139	General

05

Appendix

149	LG Language Settings
149	LG Bridge
150	Phone software update
152	Anti-Theft Guide
153	Open Source Software Notice Information
153	Regulatory information (Regulation ID number, E-labeling, etc.)
153	Trademarks
154	DECLARATION OF CONFORMITY
154	More information
156	FAQ

Guidelines for safe and efficient use

Please read these simple guidelines. Not following these guidelines may be dangerous or illegal.

Should a fault occur, a software tool is built into your device that will gather a fault log. This tool gathers only data specific to the fault, such as signal strength, cell ID position in sudden call drop and applications loaded. The log is used only to help determine the cause of the fault. These logs are encrypted and can only be accessed by an authorised LG Repair centre should you need to return your device for repair.

Exposure to radio frequency energy

Radio wave exposure and Specific Absorption Rate (SAR) information.

This device has been designed to comply with applicable safety requirements for exposure to radio waves. These requirements are based on scientific guidelines that include safety margins designed to assure the safety of all persons, regardless of age and health.

- The radio wave exposure guidelines employ a unit of measurement known as the Specific Absorption Rate, or SAR. Tests for SAR are conducted using standardised methods with the device transmitting at its highest certified power level in all used frequency bands.
- While there may be differences between the SAR levels of various LG device models, they are all designed to meet the relevant guidelines for exposure to radio waves.
- The SAR limit recommended by the International Commission on Non-ionizing Radiation Protection (ICNIRP) is 2 W/kg averaged over 10 g of tissue.
- The highest SAR value for this model tested for use at the ear is 0.393 W/kg (10 g) and when worn on the body is 1.120 W/kg (10 g).

- This device meets RF exposure guidelines when used either in the normal use position against the ear or when positioned at least 5 mm away from the body. When a carry case, belt clip or holder is used for body-worn operation, it should not contain metal and should position the product at least 5 mm away from your body. In order to transmit data files or messages, this device requires a quality connection to the network. In some cases, transmission of data files or messages may be delayed until such a connection is available. Ensure the above separation distance instructions are followed until the transmission is completed.

Product care and maintenance

- Use only in-box accessories which are authorised by LG. LG does not guarantee any damage or failure which is caused by third party accessories.
- Some contents and illustrations may differ from your device without prior notice.
- Do not disassemble this unit. Take it to a qualified service technician when repair work is required.
- Repairs under warranty, at LG's discretion, may include replacement parts or boards that are either new or reconditioned, provided that they have functionality equal to that of the parts being replaced.
- Keep away from electrical appliances such as TVs, radios and personal computers.
- The unit should be kept away from heat sources such as radiators or cookers.
- Do not drop.
- Do not subject this unit to mechanical vibration or shock.
- Switch off the device in any area where you are required to by special regulations. For example, do not use your device in hospitals as it may affect sensitive medical equipment.
- Do not handle the device with wet hands while it is being charged. It may cause an electric shock and can seriously damage your device.
- Do not charge a handset near flammable material as the handset can become hot and create a fire hazard.

- Use a dry cloth to clean the exterior of the unit (do not use solvents such as benzene, thinner or alcohol).
- Do not charge the device when it is on soft furnishings.
- The device should be charged in a well ventilated area.
- Do not subject this unit to excessive smoke or dust.
- Do not keep the device next to credit cards or transport tickets; it can affect the information on the magnetic strips.
- Do not tap the screen with a sharp object as it may damage the device.
- Do not expose the device to liquid or moisture.
- Use accessories like earphones cautiously. Do not touch the antenna unnecessarily.
- Do not use, touch or attempt to remove or fix broken, chipped or cracked glass. Damage to the glass display due to abuse or misuse is not covered under the warranty.
- Your device is an electronic device that generates heat during normal operation. Extremely prolonged, direct skin contact in the absence of adequate ventilation may result in discomfort or minor burns. Therefore, use care when handling your device during or immediately after operation.
- If your device gets wet, immediately unplug it to dry off completely. Do not attempt to accelerate the drying process with an external heating source, such as an oven, microwave or hair dryer.
- The liquid in your wet device, changes the colour of the product label inside your device. Damage to your device as a result of exposure to liquid is not covered under your warranty.

Efficient device operation

Electronics devices

All devices may receive interference, which could affect performance.

- Do not use your device near medical equipment without requesting permission. Please consult your doctor to determine if operation of your device may interfere with the operation of your medical device.
- Pacemaker manufacturers recommend that you leave at least 15 cm of space between other devices and a pacemaker to avoid potential interference with the pacemaker.
- This device may produce a bright or flashing light.
- Some hearing aids might be disturbed by devices.
- Minor interference may affect TVs, radios, PCs etc.
- Use your device in temperatures between 0 °C and 40 °C, if possible. Exposing your device to extremely low or high temperatures may result in damage, malfunction, or even explosion.

Road safety

Check the laws and regulations on the use of devices in the area when you drive.

- Do not use a hand-held device while driving.
- Give full attention to driving.
- Pull off the road and park before making or answering a call if driving conditions so require.
- RF energy may affect some electronic systems in your vehicle such as car stereos and safety equipment.
- When your vehicle is equipped with an air bag, do not obstruct with installed or portable wireless equipment. It can cause the air bag to fail or cause serious injury due to improper performance.
- If you are listening to music whilst out and about, please ensure that the volume is at a reasonable level so that you are aware of your surroundings. This is of particular importance when near roads.

Avoid damage to your hearing



To prevent possible hearing damage, do not listen at high volume levels for long periods.

Damage to your hearing can occur if you are exposed to loud sound for long periods of time. We therefore recommend that you do not turn on or off the handset close to your ear. We also recommend that music and call volumes are set to a reasonable level.

- When using headphones, turn the volume down if you cannot hear the people speaking near you, or if the person sitting next to you can hear what you are listening to.



- Excessive sound pressure from earphones and headphones can cause hearing loss.

Glass Parts

Some parts of your device are made of glass. This glass could break if your device is dropped on a hard surface or receives a substantial impact. If the glass breaks, do not touch or attempt to remove it. Stop using your device until the glass is replaced by an authorised service provider.

Blasting area

Do not use the device where blasting is in progress. Observe restrictions and follow any regulations or rules.

Potentially explosive atmospheres

- Do not use your device at a refueling point.
- Do not use near fuel or chemicals.
- Do not transport or store flammable gas, liquid or explosives in the same compartment of your vehicle as your device or accessories.

In aircraft

Wireless devices can cause interference in aircraft.

- Turn your device off before boarding any aircraft.
- Do not use it on the ground without permission from the crew.

Children

Keep the device in a safe place out of the reach of small children. It includes small parts which may cause a choking hazard if detached.

Emergency calls

Emergency calls may not be available on all mobile networks. Therefore you should never depend solely on your device for emergency calls. Check with your local service provider.

Battery information and care

- You do not need to completely discharge the battery before recharging. Unlike other battery systems, there is no memory effect that could compromise the battery's performance.
- Use only LG batteries and chargers. LG chargers are designed to maximise the battery life.
- Do not disassemble or short-circuit the battery.
- Keep the metal contacts of the battery clean.
- Replace the battery when it no longer provides acceptable performance. The battery pack may be recharged hundreds of times before it needs replacing.
- Recharge the battery if it has not been used for a long time to maximise usability.
- Do not expose the battery charger to direct sunlight or use it in high humidity, such as in the bathroom.
- Do not leave the battery in hot or cold places, as this may deteriorate battery performance.
- Risk of explosion if battery is replaced by an incorrect type. Dispose of used batteries according to the instructions.
- If you need to replace the battery, take it to the nearest authorised LG Electronics service point or dealer for assistance.

- Always unplug the charger from the wall socket after the device is fully charged to save unnecessary power consumption of the charger.
- Actual battery life will depend on network configuration, product settings, usage patterns, battery and environmental conditions.
- Make sure that no sharp-edged items such as animal's teeth or claws, come into contact with the battery. This could cause a fire.

Securing personal information

- Make sure to protect your personal information to prevent data leakage or misuse of sensitive information.
- Always back up important data while using the device. LG is not responsible for any data loss.
- Make sure to back up all data and reset the device when disposing of the device to prevent any misuse of sensitive information.
- Read the permission screen carefully while downloading applications.
- Be cautious using the applications that have access to multiple functions or to your personal information.
- Check your personal accounts regularly. If you find any sign of misuse of your personal information, ask your service provider to delete or change your account information.
- If your device is lost or stolen, change the password of your account to secure your personal information.
- Do not use applications from unknown sources.



Notice for Battery replacement

- For your safety, do not remove the battery incorporated in the product. If you need to replace the battery, take it to the nearest authorised LG Electronics service point or dealer for assistance.
- Li-Ion Battery is a hazardous component which can cause injury.
- Battery replacement by non-qualified professional can cause damage to your device.



01

Custom-designed Features

Notes on Water Resistant Properties

This product is water and dust resistant in compliance with the Ingress Protection rating IP68.

Your product has undergone testing in a controlled environment and is proven to be water and dust resistant in certain circumstances (meets the requirements of classification IP68 as described by the international standard IEC 60529 - Degrees of Protection provided by Enclosures [IP Code]; test conditions: 15-35 °C, 86-106kPa, 1.5 meter, for 30 minutes). Do not expose the device in conditions that are different from the test conditions. Results may vary in actual use.



WARNING

In conditions that are different from LGE's test conditions for IP68 (as specified in this manual), the liquid damage indicator located inside the product changes colour. Please note that any damages that occur due to such causes makes you ineligible for any free-of-charge repair services provided under warranty.

Avoid exposing the product to environments with excessive dusts or moisture. Do not use the product in the following environments.



Do not immerse the product in any liquid chemicals (soap, etc.) other than water.



Do not immerse the product in salt water, including seawater.



Do not immerse the product in a hot spring.



Do not swim with this product.



Do not place the product directly on sand (such as at a beach) or mud.



Do not immerse your product in water deeper than approximately 1.5 meter.

Do not immerse your product in water for longer than 30 minutes.

- If your product becomes wet be sure to wipe the microphone, speaker, and stereo jack with a dry cloth before use.
- Should your product or your hands become wet, dry them before handling the product.
- Do not use the product in places where it may be sprayed with high pressure water (e.g. near a faucet or shower head) or submerge it in water for extended periods of time, as the product is not designed to withstand high water pressure.
- This product is not resistant to shock. Do not drop the product or subject it to shock. Doing so might damage or deform the main unit, causing water leakage.
- The product's water and dust resistant features may be damaged by dropping or receiving an impact.
- If the product gets wet, use a clean, soft cloth to dry it thoroughly.
- The touch screen and other features may not work properly if the device is used while wet.
- Your product is water resistant only when the SIM/Memory card tray is properly inserted into the product.
- Do not open or close the SIM/Memory card tray while the product is wet or immersed in water. Exposing the open tray to water or moisture may damage the product.
- The SIM/Memory card tray contains rubber [packing] to help prevent dust, water, or moisture from entering the product. Do not damage the rubber [packing] as this may allow dust, water, or moisture to enter your product and cause damage.






- Failure to follow the provided instructions may invalidate your device's limited warranty.

Video recording features

Wide-angle camera

You can take photos or record videos with a wider range than your actual field of vision by using the wide-angle on the front and rear camera.


Launch the Camera app, then tap  /  or  /  to switch between the standard and wide-angle.

Front camera

Standard angle icon




Wide-angle icon



Rear camera

Standard angle icon



Wide-angle icon



• See *Starting the camera* for details.

SQUARE camera mode


You can take multiple photos or videos in the form of a collage by using the front and rear cameras. Photos and videos can be saved with different layouts.

- 1 Launch the Camera app, then tap **AUTO** (A) > **SQUARE** (O).
- 2 Tap **MODE** and select the desired camera mode.
- 3 To take a photo, tap . To record a video, tap .

Snap shot

You can take a photo or record a video and preview it right away.


- 1 In the SQUARE mode, tap **MODE** > .
- 2 Tap to take photo. To record a video, tap .



Grid shot







You can take up to 4 photos or videos (max of 3 seconds) organised in a square.

- 1 In the SQUARE mode, tap **MODE** > .
- 2 Tap / to take photos or record videos simultaneously or sequentially depending on the displayed layout order.
- 3 Tap to save.



Match shot



You can take 2 photos or videos at the same time or separately.

- 1 In the SQUARE mode, tap **MODE** > .
- 2 Tap  /  to take a photo or record a video at the same time or separately.
- 3 Tap  /  to take photos or record videos.
- 4 Tap  to save (if necessary).




Guide shot

You can take photos by following the pose of another photo.

- 1 In the SQUARE mode, tap **MODE** > .
- 2 Select from the poses on the right to choose the one you want to follow.
- 3 Tap  to take a photo.





- Use the slide bar to control the background transparency.



Tracking focus while using the camera


You can track and maintain focus on an object while taking photos or recording videos.

- 1 Launch the Camera app, then tap  > **Tracking focus**.
- 2 Before recording a video or taking a photo, lightly tap the screen to select an object to focus on.



- 3 Take the photo or start recording your video.



- See *Starting the camera* for details.
- To use this feature, select the standard camera () for taking photos or recording videos.
- This feature is unavailable when you use the front camera or the wide-angle camera.
- This feature is unavailable in the following cases:
 - Video size limitation: Resolution is set as UHD 16:9.
 - FPS limitation: FPS is set as 60 FPS.

Steady recording

You can use the Steady recording feature to minimise motion blur while recording a video.

Launch the Camera app, then tap **AUTO** (A), **SQUARE** (S), or **MANUAL** (M) > ⚙️ > **Steady recording** .




• See *Starting the camera* for details.

Signature

You can create a personalised photo by using your signature.

- 1 Launch the Camera app, then tap **AUTO** (A) > ⚙️ > **Add signature**.
- 2 Enter the signature as desired and tap **ADD**.



• This feature is not available when you use the Manual video mode.

Hi-Fi video recording

Record high quality videos by capturing higher quality sound with a wider dynamic frequency range using 2 sensitive AOP (Acoustic Overload Point) mics and incredible Hi-Fi recording.

Launch the Camera app, then tap **MANUAL** (📷) > ⚙️ > **Hi-Fi** .




- See *Starting the camera* for details.
- Hi-Fi videos can only be played in apps that support Hi-Fi.
- This feature is unavailable when you use the front camera.

Gallery features

Floating button

To quickly move to the Home screen while viewing the Gallery in landscape orientation, touch and hold ◀️, move your finger upward to ⦿, then release it.



- You can move the floating button's position by dragging it horizontally along the bottom part of the screen.

Camera roll

You can view the photos and videos you have taken on the camera preview screen.

Launch the Camera app, then tap **AUTO** (A) > ⚙️ > **Camera roll**.


- When you take photos or record videos, you can view the thumbnails for the saved pictures along the side of the screen.
- Scroll the thumbnail lists up or down to browse the photos and videos.
- Tap a thumbnail to view the photo or video on the camera screen.
- Tap the thumbnail again to return to the camera viewfinder.



- This feature is not supported when you take a photo or record a video in the 18:9 aspect ratio.
- Camera roll feature is only available in Auto view mode.

Related content

You can edit and customise related content in the Gallery.



- 1 While viewing a picture preview, tap .
- 2 When the icon related with the date you took the photo appears, touch the screen.



- You can view the photos related with the date you chose.



- Related content can be related to up to four combinations of 'Memories, Date, Place, Camera mode'

- Tap  to save the related content as a video.
- Tap  to access additional options.



Making a GIF

You can easily make a GIF file using recorded video.

- 1 At the desired starting point while watching the video, tap **:** > **Create GIF**.
- 2 Select the length of the GIF you want to create.
 - GIF is generated for the time selected from the current time.
 - For videos less than 5 seconds, GIF images are automatically generated for the remaining time.



- The GIF making feature is provided for the user's creative activity. If you infringe other's copyright or defamation laws by using the GIF making feature, you may be liable for civil and criminal liability. Be sure to not duplicate or transfer work of others without permission. LG Electronics cannot accept any liability for the user's action.


Making collage wallpapers

You can make your own collage image to display it as a lock screen.

You can select multiple collage images as a wallpaper that changes each time you turn on or off the screen.

- 1 Tap **○** > **Settings** > **Display** > **Lock screen** > **Wallpaper** > **Collage Wallpapers**.
- 2 Tap **+** and select the images you want to display as a collage.

3 Edit the slideshow as desired and tap **SET WALLPAPER**.



Audio recording features

HD Audio Recorder overview

You can configure the audio settings manually so that you can record audio based on the settings optimised for the selected mode.

Recording modes

You can record a high definition audio file by selecting and configuring the audio mode to suit the recording environment.

Tap  > **Essentials** > **HD Audio Recorder** > .

Normal

You can record audio without extra settings.



Concert

You can record audio in a concert or other music events.

Custom






You can configure the desired settings to record audio.



- When you connect the earpiece to the device,  appears. Tap  and then select the microphone to use.

Studio Mode

With Studio mode, you can play an audio file or music and record your voice at the same time, create a chord by recording your voice multiple times, and record your comments over the presenter's or speaker's original audio file.

- 1 Tap  > **Essentials** > **HD Audio Recorder**.
- 2 Select  > **Custom**.
- 3 Tap  and select an audio file to use as background music.
- 4 Tap  to record voice.
- 5 Tap  to save the recorded file.



- Background music can only be played through earphones. Make sure to plug in earphones before using this feature.

Other useful features for use of the HD Audio Recorder app

GAIN

You can adjust the sensitivity of the sound recorded by the microphone. The higher the GAIN value is set, the more sensitively the sound is recorded.

LCF

You can filter any low-pitched noises such as the low hum of the air conditioner.

The higher the LCF (Low Cut Filter) value is set, the better high-frequency noises are filtered.

LMT

It can prevent clipping of the recorded sound. The higher the LMT (Limiter) value is set, the more low frequency sounds that will not get clipped.



- To change additional settings, tap **> Settings**, then customise the file type, bit depth, sampling rate and other settings.
- You can monitor sound quality with the connected earpiece while recording audio. While recording audio in Studio mode, sound monitoring is not supported. You can hear only the background music.

Fingerprint recognition

Fingerprint recognition overview

You must register your fingerprint on your device first before using the fingerprint recognition function.

You can use the fingerprint recognition function in the following cases:

- To unlock the screen.
- To view the locked content in the Gallery or QuickMemo+.
- Confirm a purchase by signing in to an app or identifying yourself with your fingerprint.



- Your fingerprint can be used by the device for user identification. Very similar fingerprints from different users may be recognised by the fingerprint sensor as the same fingerprint.

Precautions for fingerprint recognition

Fingerprint recognition accuracy may decrease due to a number of reasons. To maximise the recognition accuracy, check the following before using the device.

- The device's Power/Lock key has a fingerprint sensor. Ensure that the Power/Lock key is not damaged by a metallic object, such as coin or key.
- When water, dust or other foreign substance is on the Power/Lock key or your finger, the fingerprint registration or recognition may not work. Clean and dry your finger before having the fingerprint recognised.
- A fingerprint may not be recognised properly if the surface of your finger has a scar or is not smooth due to being soaked in water.
- If you bend your finger or use the fingertip only, your fingerprint may not be recognised. Make sure that your finger covers the entire surface of the Power/Lock key.

- Scan only one finger for each registration. Scanning more than one finger may affect fingerprint registration and recognition.
- The device may generate static electricity if the surrounding air is dry. If the surrounding air is dry, avoid scanning fingerprints, or touch a metallic object such as coin or key before scanning fingerprints to remove static electricity.

Registering fingerprints

You can register and save your fingerprint on the device to use fingerprint identification.

1 Tap > **Settings** > **General** > **Fingerprints & security** > **Fingerprints**.




- A lock screen must be set in order to be able to use this feature.
- If the screen lock is not active, configure the lock screen by following the on-screen instructions. See [Setting a screen lock](#) for details.

2 Locate the Power/Lock key on the back of the device and gently put your finger on it to register the fingerprint.





- Gently press the Power/Lock key so that the sensor can recognise your fingerprint. If you press the Power/Lock key with an excessive force, the screen lock function may start or the screen may be turned off.
- Ensure that your fingertip covers the entire surface of the sensor of the Power/Lock key.



- 3 Follow the on-screen instructions.
 - Repeat scanning the fingerprint by moving your finger little by little until the fingerprint registers.
- 4 When the fingerprint registration is done, tap **OK**.
 - Tap **ADD MORE** to register another fingerprint. If you register only one fingerprint and the corresponding finger is not in a good condition, the fingerprint recognition may not work well. As the preventive measure against this kind of situation, register multiple fingerprints.


Managing fingerprints

You can edit or delete registered fingerprints.

- 1 Tap  > **Settings** > **General** > **Fingerprints & security** > **Fingerprints**.
- 2 Unlock according to the specified lock method.
- 3 From the fingerprint list, tap a fingerprint to rename it. To delete it, tap .

Unlocking the screen with a fingerprint

You can unlock the screen or view the locked content by using your fingerprint. Activate the desired function:

- 1 Tap  > **Settings** > **General** > **Fingerprints & security** > **Fingerprints**.
- 2 Unlock according to the specified lock method.
- 3 On the fingerprint settings screen, activate the desired function:
 - **Screen lock:** Unlock the screen with a fingerprint.
 - **Content lock:** Unlock content with a fingerprint. To do this, make sure that the content lock is set.

Face recognition

Face recognition overview

You can release the screen lock by using the saved facial data.



- This feature may be more vulnerable to security than the other screen locks such as Knock Code, Pattern, PIN, and Password.
- When a similar face or your photo image is used, the screen lock can be released.
- The recognised facial data is securely stored in your device.
- When the face recognition is selected for screen lock, you must enter the Knock Code, Pattern, PIN, or Password that has been used for face registration without directly using the face recognition after the power is turned on. Accordingly, be careful not to forget the specified value.
- If the device cannot detect your face, or you forgot the value specified for registration, visit the nearest LG Customer Service Centre with your device and ID card.


Precautions for face recognition

Face recognition accuracy may decrease in the following cases. To increase its accuracy, check the following before using the device.

- Whether your face is covered with a hat, eyeglasses, or mask, or your face is significantly different due to heavy makeup or beard.
- Whether there are fingerprints or foreign substances on the front of the camera lens, or your device cannot detect your face due to a too bright or dark light.

Registering facial data

Before use of the face recognition feature, register your facial data on your device.

- 1 Tap  > **Settings** > **Display** > **Lock screen** > **Select screen lock** > **Allow faceprint.**





- To use this feature, the screen lock must have been set with a Knock Code, Pattern, PIN, or Password.
- When the screen lock is not set, register the data by following the on-screen instructions. See *Setting a screen lock* for details.

- 2 Raise your device in the front of your eyes.
- 3 Register your face by following on-screen instructions.
 - Register your face in a room that is not too bright or dark.
 - Position your entire face inside the guideline on the screen, and then adjust it by slowly moving up, down, left, or right.
- 4 When the face registration is done, tap **OK**.


Unlocking the screen with your face

You can release the screen lock with your face instead of Knock Code, Pattern, PIN, or Password.

- 1 Tap  > **Settings** > **Display** > **Lock screen** > **Select screen lock**.
- 2 Unlock the screen according to the specified method.
- 3 Drag  to activate the face recognition feature.


Improving the face recognition

You can add facial data in various conditions to improve face recognition.

- 1 Tap  > **Settings** > **Display** > **Lock screen** > **Faceprint**.
- 2 Unlock the screen according to the specified method.
- 3 Select **Improve face recognition**.
- 4 Register your face by following on-screen instructions.
- 5 When the face registration is done, tap **OK**.

Deleting facial data



You can delete the registered facial data and register it again if the face recognition does not work properly.

- 1 Tap  > **Settings** > **Display** > **Lock screen** > **Faceprint**.
- 2 Unlock the screen according to the specified method.
- 3 Select **Delete faceprint** to delete the facial data.

Unlocking the screen with your face when the screen is turned off



With the screen turned off, raise your device and look at the front of the screen. The device can detect your face and the screen is unlocked.

To deactivate this feature, follow the instruction below.

- 1 Tap  > **Settings** > **Display** > **Lock screen** > **Faceprint**.
- 2 Unlock the screen according to the specified method.
- 3 Drag **Allow faceprint when screen is off**  to deactivate the feature.
 - Face recognition feature is available only when the screen is locked.



Unlocking the screen with face recognition and then screen swiping

With the screen turned off, you can unlock the screen by performing face recognition and then swiping the screen.

- 1 Tap  > **Settings** > **Display** > **Lock screen** > **Faceprint**.
- 2 Unlock the screen according to the specified method.
- 3 Drag **Swipe to unlock after face recognized**  to activate the feature.

Enhancing the face recognition

You can prevent your device from being unlocked by photos, images, or videos.

- 1 Tap  > **Settings** > **Display** > **Lock screen** > **Faceprint**.
- 2 Unlock the screen according to the specified method.
- 3 Drag **Advanced faceprint**  to activate the feature.





- Face recognition speed may decrease when you activate this feature.



Multi-tasking feature

Multi-Window

You can use two apps at the same time by separating the screen into the multiple windows.

While using an app, touch and hold  from the Home touch buttons, then select an app from the recently used apps list.


- You can use two apps displayed on the main screen at the same time.
- To stop the Multi-Window feature, touch and hold .




- The Multi-Window feature is not supported by some apps, including downloaded apps.

Overview screen

The Overview screen provides a preview of your recently used apps.



To view the list of recently used apps, tap  on the Home, then tap the displayed app.

- Touch and hold an app and drag it to the top of the screen to start the app with the Multi-Window feature. You can also tap  at the top of each app.

Always-on Display

You can display the date, time, signature or other information on the screen even when the main screen is turned off. Always-on Display is a useful feature in order to check the time quickly and display your own signature.



- 1 Tap  > **Settings** > **Display** > **Always-on display** and then tap  to activate it.



- This feature may be turned on when you purchase the device.
- The default setting may vary depending on the area and service provider.


- 2 Tap **Content** and select the item you want to display when the screen is off.




- Make sure to check that your signature does not exceed the input field.
- The battery may drain faster when you use Always-on display. Turn off this feature to use the battery longer.

quick share

You can share a photo or video to the app you want immediately after taking it.

- 1 Tap  then take a photo or record a video.
- 2 Tap the app icon that appears on the screen to share it using that app. You can also swipe the icon towards the opposite direction to see what other apps you can use to share your photos and videos.



- The app displayed by the quick share icon may vary, depending on the type and frequency of access to the apps installed on the device.
- You can use this feature only when you take a photo or record a video in the *AUTO* and *SQUARE* modes. See *AUTO mode* and *SQUARE camera mode* for details.



02

Basic Functions

Product components and accessories

The following items are included with your device.

- Device
- Stereo headset
- USB cable
- Charger
- Quick Start Guide
- Ejection pin





- The items described above may be optional.
- The items supplied with the device and any available accessories may vary depending on the area and service provider.
- Always use genuine LG Electronics accessories. Using accessories made by other manufacturers may affect your device's call performance or cause malfunctions. This may not be covered by LG's repair service.



- If any of these basic items are missing, contact the dealer from which you purchased your device.
- To purchase additional basic items, contact an LG Customer Service Centre.
- To purchase optional items, contact an LG Customer Service Centre for available dealers.
- Some items in the product box are subject to change without notice.
- The appearance and specifications of your device are subject to change without notice.
- Device specifications may vary depending on the area or service provider.
- Be sure to use authentic accessories provided by LG Electronics. Using third-party accessories may damage the device or cause malfunctions.
- Remove the protective film from the Fingerprint sensor before use of the fingerprint recognition feature.

Parts overview




- Proximity/Ambient light sensor
 - Proximity sensor: During a call, the proximity sensor turns off the screen and disables touch functionality when the device is in close proximity to the human body. It turns the screen back on and enables touch functionality when the device is outside a specific range.
 - Ambient light sensor: The ambient light sensor analyses the ambient light intensity when the auto-brightness control mode is turned on.
- Volume keys
 - Adjust the volume for ringtones, calls or notifications.
 - While using the Camera, gently press a Volume key to take a photo. To take continuous photos, press and hold the Volume key.
 - Press the Volume Down (-) key twice to launch the Camera app when the screen is locked or turned off. Press the Volume Up (+) key twice to launch Capture+.
- Power/Lock key (Fingerprint sensor)
 - Briefly press the key when you want to turn the screen on or off.
 - Press and hold the key when you want to select a power control option.
 - Turn on the fingerprint recognition feature to simplify the process of unlocking the screen. See *Fingerprint recognition overview* for details.



- Your device has an internal rechargeable battery. For your safety, do not remove the embedded battery.
- Some functions may be restricted for access, depending on the device specifications.
- On the rear of the device includes a built-in NFC antenna. Be cautious when handling the device to avoid damaging or covering the NFC antenna.
- Do not put heavy objects on the device or sit on it. Failure to do so may damage the touch screen.
- Screen-protective film or accessories may interfere with the proximity sensor.
- If your device is wet or is being used in a humid place, the touch screen or buttons may not function properly.

Hold the device correctly as shown below. If you cover the microphone hole with a hand, finger, or protective case while using the device, you may sound unclear during a call.



Turning the power on or off

Turning the power on

When the power is turned off, press and hold the Power/Lock key.



- When the device is turned on for the first time, initial configuration takes place. The first booting time for the smart phone may be longer than usual.

Turning the power off

Press and hold the Power/Lock key, then select **Power off**.

Power control options

Press and hold the Power/Lock key, then select an option.

- **Power off:** Turn off the device.
- **Power off and restart:** Restart the device.
- **Turn on Airplane mode:** Block telecommunication-related functions, including making phone calls, messaging and browsing the Internet. Other functions remain available.

Installing the SIM card

Insert the SIM (Subscriber Identity Module) card provided by your service provider to start using your device.




- Be careful with the ejection pin since it has a sharp edge.




- In order for the water-resistant and dust-resistant features to work effectively, the card tray must be inserted correctly.

- 1 Insert the ejection pin into the hole on the card tray.




- 2 Pull out the card tray.




- 3 Put the SIM card on the card tray with the gold-coloured contacts facing downwards.
- Put the primary SIM card on the SIM card tray 1 and the secondary SIM card on the SIM card tray 2.



- The SIM card tray 2 also serves as the memory card tray. However, you cannot put both the SIM card and the memory card (optional) at the same time.



- 4 Insert the card tray back into the slot.



- This device supports only Nano SIM cards.
- For problem-free performance, it is recommended to use the device with the correct type of SIM card. Always use a factory-made SIM card supplied by the operator.
- If you insert the card tray into your device while the card tray is wet, your device may be damaged. Always make sure the card tray is dry.

Precautions when using the SIM card


- Do not lose your SIM card. LG is not responsible for damage and other issues caused by loss or transfer of a SIM card.
- Be careful not to damage the SIM card when you insert or remove it.

Inserting the memory card

Insert the memory card into your device.

The device can support up to a 2 TB microSD card. Depending on the memory card manufacturer and type, some memory card may not be compatible with your device.

- 1 Insert the ejection pin into the hole on the card tray.
- 2 Pull out the card tray.
- 3 Put the memory card on the card tray with the gold-coloured contacts facing downwards.



- 4 Insert the card tray back into the slot.



- Some memory cards may not be fully compatible with the device. If you use an incompatible card, it may damage the device or the memory card, or corrupt the data stored in it.



- Frequent writing and erasing of data may shorten the memory card lifespan.

Removing the memory card

Unmount the memory card before removing it for safety.

- 1 Tap **○** > **Settings** > **General** > **Storage** > **△**.
- 2 Insert the ejection pin into the hole on the card tray.
- 3 Pull out the card tray and remove the memory card.




- Do not remove the memory card while the device is transferring or accessing information. This may cause data to be lost or corrupted, or may damage the memory card or the device. LG is not responsible for losses that result from the abuse or improper use of memory cards, including the loss of data.

Battery

Charging the battery

Before using the device, fully charge the battery.

Charge the device with the USB Type-C cable.





- Do not charge while the device or charging cable is wet or contains moisture. This can cause fire, electric shock, injury or damage to device.
- Make sure to use the USB cable provided with your device.
- Make sure to use an LG-approved charger and charging cable. Charging the battery with a third-party charger may cause the battery to explode or may damage the device.
- Your device has an internal rechargeable battery. For your safety, do not remove the embedded battery.
- Using the device when it is charging may cause electric shock. To use the device, stop charging it.



- Remove the charger from the power socket after the device is fully charged. This prevents unnecessary power consumption.
- A charging adapter that supports fast charging is included with the product.
- The fast charging feature may not work if a fast charging adapter other than the genuine adapter provided with the product is used.
- Another way to charge the battery is by connecting a USB cable between the device and a desktop or laptop computer. This may take a longer time than plugging the adapter to a wall outlet.
- Do not charge the battery by using a USB hub that is unable to maintain the rated voltage. Charging may fail or unintentionally stop.

Precautions when using the device

- Make sure to use the USB cable provided; do not use third party USB cables or chargers with your device. The LG limited warranty does not cover the use of third party accessories.
- Failure to follow the instructions in this guide and improper use may damage the device.

Using the battery efficiently

Battery lifespan may decrease if you keep many apps and functions running simultaneously and continuously.

Cancel background operations to increase battery life.

To minimise battery consumption, follow these tips:


- Turn off the Bluetooth® or Wi-Fi network function when not using them.
- Set the screen timeout to as short a time as possible.
- Minimise the screen brightness.
- Set a screen lock when the device is not used.
- Check the battery usage details and close any downloaded apps that are draining the battery.

Touch screen

You can familiarise yourself with how to control your device by using touch screen gestures.


Tapping

Lightly tap with your fingertip to select or run an app or option.




Touching and holding

Touch and hold for several seconds to display a menu with available options.




Double-tapping

Tap twice quickly to zoom in or out on a web page or map.




Dragging

Touch and hold an item, such as an app or widget, then move your finger to another location in a controlled motion. You can use this gesture to move an item.





Swiping

Touch the screen with your finger and move it quickly without pausing. You can use this gesture to scroll through a list, a web page, photos, screens, and more.



Pinching and spreading

Pinch two fingers to zoom out such as on a photo or map. To zoom in, spread your fingers apart.




- Do not expose the touch screen to excessive physical shock. You might damage the touch sensor.



- A touch screen failure may occur if you use the device near a magnetic, metallic or conductive material.
- If you use the device under bright lights, such as direct sunlight, the screen may not be visible, depending on your position. Use the device in a shady location or a location with an ambient light that is not too bright and bright enough to read books.
- Do not press the screen with excessive force.
- Gently tap with your fingertip on the option you want.
- Touch control may not work properly if you tap while wearing a glove or by using the tip of your fingernail.
- Touch control may not work properly if the screen is moist or wet.
- The touch screen may not function properly if a screen-protective film or accessory purchased from a third party store is attached to the device.
- Displaying a static image for extended periods of time may result in afterimages or screen burn-in. Turn off the screen or avoid displaying the same image for a long time when you do not use the device.

Home screen

Home screen overview

The Home screen is the starting point for accessing various functions and apps on your device. Tap  on any screen to directly go to the Home screen.

You can manage all apps and widgets on the Home screen. Swipe the screen left or right to view all installed apps at a glance.

Home screen layout

You can view all apps and organise widgets and folders on the Home screen.



- The Home screen may vary, depending on the service provider or software version.

- **Status bar:** View status icons, the time and the battery level.
- **Weather widget:** View the information of weather and time for a specific area.
- **Google search widget:** Perform a Google search by inputting spoken or written keywords.
- **Folder:** Create folders to group apps by your preferences.
- **Page icon:** Display the total number of Home screen canvases. Tap the desired page icon to go to the page you selected. The icon reflecting the current canvas will be highlighted.


- **Quick access area:** Fix main apps at the bottom of the screen so that they can be accessed from any Home screen canvas.
- **Home touch buttons**
 - ◀: Return to the previous screen. Close the keypad or pop-up windows.
 - ○: Tap to go to the Home screen. To launch Google search, touch and hold.
 - □: Tap to view a list of recently used apps or run an app from the list. To delete all the recently used apps, tap **CLEAR ALL**. To use two apps at the same time with the Multi-Window feature, touch and hold the button while using an app.
 - ↔: Choose which SIM card you are going to use. Tap and hold to configure the Dual SIM card settings.

Editing the Home touch buttons

You can rearrange the Home touch buttons or add frequently used functions to the Home touch buttons area.
















Tap ○ > **Settings** > **Display** > **Home touch buttons** > **Button combination** and customise the settings.

- Several functions, including QSlide, Notification panel and Capture+, are provided. A maximum of five items can be added.



Status icons

When there is a notification for an unread message, calendar event or alarm, the status bar displays the corresponding notification icon. Check your device's status by viewing notification icons displayed on the status bar.

	No signal
	Data is being transmitted over the network
	Alarm is set
	Vibrate mode is on
	Bluetooth is on
	Connected to a computer via USB
	Battery level
	Airplane mode is on
	Missed calls
	Wi-Fi is connected
	Mute mode is on
	GPS is on
	Hotspot is on
	No SIM card
	NFC is on




- Some of these icons may appear differently or may not appear at all, depending on the device's status. Refer to the icons according to the actual environment and area in which you are using the device and your service provider.
- Displayed icons may vary, depending on the area or service provider.

Notifications panel

You can open the notifications panel by dragging the status bar downward on the main screen.


- To open the quick access icons list, drag the notifications panel downwards or tap ∇ .
- To rearrange, add, or remove icons, tap **EDIT**.
- If you touch and hold the icon, the settings screen for the corresponding function appears.



Switching the screen orientation

You can set the screen orientation to automatically switch according to the device's physical orientation.

On the notification panel, tap **Rotation** from the quick access icon list.


You can also tap  > **Settings** > **Display** and activate **Auto-rotate screen**.





Editing the Home screen

On the Home screen, touch and hold on an empty space, then select the desired action from below.

- To rearrange the Home screen canvases, touch and hold on a canvas, then drag it to another location.
- To add a widget to the Home screen, touch and hold on a blank area of the Home screen, then select **Widgets**.
- To change a theme, touch and hold on a blank area of the Home screen, then select **Theme**.

You can also tap  > **Settings** > **Display** > **Theme**, then select a theme to apply to the device.

- To configure the Home screen settings, touch and hold on a blank area of the Home screen, then select **Home screen settings**. See *Home screen settings* for details.
- To view or reinstall the uninstalled apps, touch and hold on a blank area of the Home screen, then select **App trash**. See *App trash* for details.
- To change the default screen, touch and hold on a blank area of the Home screen, move to desired screen, tap , then tap the screen once more.




Viewing the background theme

You can view only the background image by hiding the apps and widgets on the Home screen.

Spread two fingers apart on the Home screen.

- To return to the original screen, which displays apps and widgets, pinch your fingers on the Home screen or tap ◀



Moving apps on the Home screen

On the Home screen, touch and hold an app, then drag it to another location.

- To keep frequently used apps at the bottom of the Home screen, touch and hold an app, then drag it to the quick access area at the bottom.
- To remove an icon from the quick access area, drag the icon to the Home screen.

Using folders from the Home screen

Creating folders

On the Home screen, touch and hold an app, then drag it over another app.

- A new folder is created and the apps are added to the folder.

Editing folders

On the Home screen, tap a folder and do one of the following actions.

- To edit the folder name and colour, tap the folder name.
- To add apps, touch and hold an app, then drag it over the folder and release it.
- To remove an app from the folder, touch and hold the app and drag it to outside the folder. If the removed app is the only one app that existed in the folder, the folder is removed automatically.
- You can also add or remove apps after tapping **+** in the folder.

Home screen settings

You can customise Home screen settings.

- 1 Tap **○ > Settings > Display > Home screen.**
- 2 Customise the following settings:
 - **Select Home:** Select a Home screen mode.
 - **Wallpaper:** Change the Home screen background wallpaper.
 - **Screen swipe effect:** Select an effect to apply when the Home screen canvas switches.
 - **Icon shape:** Choose if you want icons to have square or rounded corners.
 - **Sort apps by:** Set how apps are sorted on the Home screen.

- **Grid:** Change the app arrangement mode for the Home screen.
- **Hide apps:** Select which apps you want to hide from the Home screen.
- **Continuous loop:** Enable to allow continuous Home screen scrolling (loop back to first screen after the last screen).
- **Smart Bulletin:** Use the Home screen to view information customised to your needs.
- **Search:** Search by swiping down on the Home screen.

Screen lock

Screen lock overview

Your device's screen turns off and locks itself if you press the Power/Lock key. This also happens after the device is left idle for a specified period of time.

If you press the Power/Lock key when a screen lock is not set, the Home screen appears immediately.


To ensure security and prevent unwanted access to your device, set a screen lock.



- Screen lock prevents unnecessary touch input on the device screen and reduces battery consumption. We recommend that you activate the screen lock while not using the device.

Setting a screen lock

There are several options available for configuring the screen lock settings.

- 1 Tap  > **Settings** > **Display** > **Lock screen** > **Select screen lock** and then select the method you prefer.
- 2 Customise the following settings:
 - **None**: Deactivate the screen lock function.
 - **Swipe**: Swipe on the screen to unlock the screen.
 - **Knock Code**: Tap the spaces of the screen in a pattern to unlock the screen.
 - **Pattern**: Draw a pattern to unlock the screen.
 - **PIN**: Enter a numeric password to unlock the screen.
 - **Password**: Enter an alphanumeric password to unlock the screen.
 - **Fingerprints**: Unlock the screen by using your fingerprint.
 - **Allow faceprint**: Unlock the screen by recognising your face.



- If you incorrectly attempt to unlock the device 5 times, the screen is blocked for 30 seconds.


Secure start-up settings

When you select Knock Code, Pattern, PIN or Password as a screen lock method, you can configure your device to be locked whenever turning on the device in order to secure your data.

- You cannot use all functions, except for emergency calls until you unlock the device.
- If you forget your decryption password, you cannot restore encrypted data and personal information.

Lock screen settings

You can customise the following lock screen settings.

- 1 Tap  > **Settings** > **Display** > **Lock screen**.
- 2 Customise the following settings:
 - **Select screen lock:** Select a screen lock method.
 - **Faceprint:** Unlock the lock screen by recognising your face. See [Face recognition overview](#) for details.
 - **Smart Lock:** Select trusted items so that if one of them occurs, the device is automatically unlocked.
 - **Wallpaper:** Change the lock screen background wallpaper.
 - **Clock:** Select the position of the clock on the locked screen.
 - **Shortcuts:** Add an app shortcut and directly access the app from the lock screen by dragging the app shortcut on the screen.
 - **Screen swipe effect:** Set screen transition effects to apply when the screen is unlocked.
 - **Weather animation:** Display weather animations for the current location on the lock screen.
 - **Contact info for lost phone:** Display emergency contact information on the lock screen.
 - **Lock timer:** Set the amount of idle time after which the device automatically locks.
 - **Power key instantly locks:** Instantly lock the screen when the Power/Lock key is pressed.



- Available setting items may vary, depending on the selected screen lock method.

KnockON

You can turn the screen on or off by double-tapping the screen.



- This option is available only on the Home screen provided by LG. It may not function properly on a custom launcher or on the Home screen installed by the user.
- When tapping the screen, use your fingertip. Do not use a fingernail.
- To use the KnockON feature, make sure that the proximity/light sensor is not blocked by a sticker or any other foreign substance.

Turning on the screen

Double-tap the middle of the screen.

- Tapping the top or bottom of the screen may decrease the recognition rate.

Turning off the screen

Double-tap on an empty space on the Home screen and Lock screen.

You can also double-tap an empty space on the status bar.


Knock Code

You can unlock the screen by creating your own Knock Code. When the screen is locked, you can directly access the Home screen by tapping the screen in a specified sequence.



- You can use your Knock Code together with the KnockOn feature.
- Make sure to use your fingertip when tapping the screen.

Creating a Knock Code

- 1 Tap  > **Settings** > **Display** > **Lock screen** > **Select screen lock** > **Knock Code**.
- 2 Tap the squares in a pattern of your choice to create a Knock Code and tap **NEXT**.
- 3 Input the created Knock Code again for verification, then tap **CONFIRM**.

Unlocking the screen with a Knock Code


Unlock the screen by inputting the Knock Code you have created.

You can also input your Knock Code on the touch screen when the screen is turned off.

- It is also possible to enter a Knock Code when the lock screen is turned on.

Memory card encryption

You can encrypt and protect data saved on the memory card. The encrypted data in the memory card cannot be accessed from another device.

- 1 Tap  > **Settings** > **General** > **Fingerprints & security** > **Encrypt SD card**.
- 2 Read the on-screen overview of memory card encryption and then tap **CONTINUE** to continue.
- 3 Select an option and tap **ENCRYPT NOW**.
 - **New data encryption**: Encrypt only data that is saved on the memory card after encryption.
 - **Full encryption**: Encrypt all the data currently saved on the memory card.
 - **Exclude media files**: Encrypt all files, except for media files such as music, photos and videos.



- To encrypt the memory card, make sure that a screen lock is set using a PIN or password.
- Once memory card encryption starts, some functions are not available.
- If the device is turned off while encryption is underway, the encryption process will fail, and some data may be damaged. Therefore, be sure to check if the battery level is sufficient before starting encryption.
- Encrypted files are accessible only from the device where the files were encrypted.
- The encrypted memory card cannot be used on another LG device. To use the encrypted memory card on another mobile device, format the card.
- You can activate memory card encryption even when no memory card is installed into the device. Any memory card that is installed after encryption will automatically be encrypted.

Taking screenshots


You can take screenshots of the current screen you are viewing.

Via a shortcut


Press and hold the Power/Lock key and the Volume Down (-) key at the same time for at least two seconds.

- Screenshots can be viewed from the **Screenshots** folder in the **Gallery**.

Via Capture+

On the screen where you want to take a screenshot, drag the status bar downwards, then tap .



- When the screen is turned off or locked, you can access **Capture+** by pressing the Volume Up (+) key twice. To use this feature, tap  **Settings** > **General** and turn on **Shortcut keys**.
- See *Writing notes on a screenshot* for details.

Entering text


Using the Smart keyboard

You can use the Smart keyboard to enter and edit text.

With the Smart keyboard, you can view text as you type without bothering to alternate between the screen and a conventional keyboard. This allows you to easily find and correct errors when typing.

Moving the cursor

With the Smart keyboard, you can move the cursor to the exact position you want. When typing text, touch and hold on the space bar and then drag left or right.




- This option is available only on the QWERTY keyboard.

Suggesting words

Smart keyboard automatically analyses your usage patterns to suggest frequently used words as you type. The longer you use your device, the more precise the suggestions are.

Enter text, then tap a suggested word or gently drag the left or right side of the keyboard upwards.

- The selected word is automatically entered. You do not need to manually type every letter of the word.




Changing the QWERTY keyboard layout

You can add, delete or rearrange keys on the bottom row of the keyboard.

- 1 Tap **Settings** > **General** > **Language & keyboard** > **LG Keyboard** > **Keyboard height and layout** > **QWERTY keyboard layout**.

You can also tap  on the keyboard and tap **Keyboard height and layout** > **QWERTY keyboard layout**.

- 2 Tap a key on the bottom row, then drag it to another position.





- This option is available on the QWERTY, QWERTZ and AZERTY keyboards.
- This function may not be supported for some languages.


Customising the keyboard height

You can customise the keyboard height to maximise hand comfort when typing.

- 1 Tap  > **Settings** > **General** > **Language & keyboard** > **LG Keyboard** > **Keyboard height and layout** > **Keyboard height**.


You can also tap  on the keyboard and tap **Keyboard height and layout** > **Keyboard height**.

- 2 Adjust the keyboard height.



Selecting a landscape keyboard mode

You can select a landscape keyboard mode from several choices.

- 1 Tap  > **Settings** > **General** > **Language & keyboard** > **LG Keyboard** > **Keyboard height and layout** > **Keyboard type in landscape**.

You can also tap  on the keyboard and tap **Keyboard height and layout** > **Keyboard type in landscape**.

- 2 Select a keyboard mode.

Splitting the keyboard


You can split the keyboard in half and place each piece on either side of the screen when the screen is in landscape mode.

Tap  > **Settings** > **General** > **Language & keyboard** > **LG Keyboard** > **Keyboard height and layout** > **Split keyboard**.

You can also tap  on the keyboard and tap **Keyboard height and layout** > **Split keyboard**.





- Rotate the device to landscape mode to split the keyboard to both sides. To merge or split the keyboard, pinch together or spread apart your fingers on the keyboard.




One-handed operation mode

You can move the keyboard to one side of the screen so that you can use the keyboard with one hand.



1 Tap  > **Settings** > **General** > **Language & keyboard** > **LG Keyboard** > **Keyboard height and layout** > **One-handed operation**.

You can also tap  on the keyboard and tap **Keyboard height and layout** > **One-handed operation**.


2 Press the arrow displayed next to the keyboard to move the keyboard in the direction you want.



Entering text by using voice


On the keyboard, touch and hold  and then select .



- To maximise the voice command recognition, speak clearly.
- To enter text with your voice, make sure that your device is connected to a network.
- To select the language for voice recognition, tap  > **Languages** on the voice recognition screen.
- This function may be not supported, or the supported languages may differ depending on the service area.



Adding languages to the keyboard

You can make additional languages available for keyboard input.

- 1 Tap  > **Settings** > **General** > **Language & keyboard** > **LG Keyboard** > **Select languages**.
- 2 Select the languages you want to make available.

Copy and Paste

You can cut or copy text from an app, and then paste the text into the same app. Or, you can run other apps and paste the text into them.





- 1 Touch and hold around the text you want to copy or cut.
- 2 Drag  /  to specify the area to copy or cut.
- 3 Select either **CUT** or **COPY**.
 - Cut or copied text is automatically added to the clipboard.
- 4 Touch and hold the text input window, then select **PASTE**.



- If there is no item that has been copied or cut, the **PASTE** option will not appear.

Clip Tray

If you copy or cut an image or text, it is automatically saved to the clip tray and can be pasted to any space at any time.

- 1 On the keyboard, touch and hold  and select .
You can also touch and hold the text input window, then select **CLIP TRAY**.
- 2 Select and paste an item from the clip tray.
 - A maximum of 20 items can be saved to the clip tray.
 - Tap  to lock saved items in order not to delete them, even when the maximum quantity is exceeded. A maximum of ten items can be locked. To delete locked items, unlock them first.
 - Tap  to delete the items saved to the clip tray.




- The clip tray may not be supported by some downloaded apps.

Content sharing

Playing content from another device

You can play photos, videos or songs saved on your device from a TV.

- 1 Connect the TV and your device to the same Wi-Fi network.
- 2 While viewing the items from the **Gallery** or **Music** app, tap  > **Play on other device**.
- 3 Select the TV you want to connect to.



- For use with Chromecast, Google Play services should be up to date.

Viewing content from nearby devices

You can view content from various devices, such as a computer, NAS or mobile device, by using the Gallery or Music apps.

Connecting the devices

Connect both your device and another device that support DLNA function to the same wireless network.



- Make sure that File sharing (DLNA) is activated on both the device and the connected device.

Searching for nearby devices


You can view a list of DLNA devices on the same network by selecting the **Nearby devices** menu in each app.

Use content from nearby devices as if you were using it on your device.


Sending or receiving files



You can share files between your device and another LG device, or a tablet or computer.

Sending files

From the **Gallery**, **File Manager** or **Music** app, tap **:** > **Share** or  then select a device on the file sharing list.

Receiving files

Drag the status bar downward and tap , then tap **File sharing**.


If your device does not support the file sharing feature, tap  > **Settings** > **Networks** > **Share & connect** > **File sharing** > **SmartShare Beam** .



- Make sure that your device is connected to the same wireless network as the file transfer target device.
- Make sure that File sharing is activated on both the device and the target device.

Sending files to a computer

You can quickly send large files to your computer.


- 1 Install LG Bridge on your computer.
- 2 Start LG Bridge on the computer, then sign in using your LG account.
- 3 Tap  > **Settings** > **Networks** > **Share & connect** > **LG AirDrive**, then sign in using your LG account.
- 4 Select a computer on the sharing list from the **Gallery**, **File Manager** and **Music** apps.



- You can download LG Bridge from the LG Electronics website (www.lg-mobile.co.il).
- When you transfer files from the device to the computer while LG Bridge is not running, they are stored for 7 days in the temporary storage.
Temporarily stored files are automatically saved on the computer when you launch LG Bridge within 7 days.



Viewing content from your cloud

You can directly view the content saved on your cloud account, without downloading it to your device.

- 1 From the **Gallery**, **Music** or **File Manager** app, select  > **Cloud**.
- 2 Select a cloud account and sign in.
- 3 Save or play content in your cloud.

Do not disturb

You can limit or mute notifications to avoid disturbances for a specific period of time.

- 1 Tap  > **Settings** > **Sound & notification** > **Do not disturb** and then tap  to activate it.
- 2 Tap **Sounds and vibrations** and select the mode you want:
 - **Priority only**: Receive sound or vibrate notifications for the selected apps. Even when Priority only is turned on, alarms still sound.
 - **Total silence**: Disable both the sound and vibration.



03

Useful Apps

Installing and uninstalling apps

Installing apps

Access an app store to search and download apps.

- You can use SmartWorld, Play Store or the app store provided by your service provider.




- Some app stores may require you to create an account and sign in.
- Some apps may charge fees.
- If you use mobile data, you may be charged for data usage, depending on your pricing plan.
- SmartWorld may not be supported depending on the area or service provider.

Uninstalling apps

Uninstall apps that you no longer use from your device.

Uninstalling with the touch and hold gesture

On the Home screen, touch and hold the app to uninstall, then drag it over **Delete** at the top of the screen.

You can touch and hold the app and release it, then tap  to uninstall.

- If apps were uninstalled within 24 hours from now, you can reinstall them. See *App trash* for details.

Uninstalling by using the settings menu

Tap  > **Settings** > **General** > **Apps**, select an app, then tap **Uninstall**.

Uninstalling apps from the app store

To uninstall an app, access the app store from which you download the app and uninstall it.



- Some apps cannot be uninstalled by users.


App trash

You can view the uninstalled apps on the Home screen. You can also reinstall apps which were uninstalled within 24 hours from now.

1 Tap  > **Management** > **App trash**.

You can also touch and hold an empty area of the Home screen, then tap **App trash**.

2 Activate the desired function:

- **Restore:** Reinstall the selected app.
- : Remove the uninstalled apps permanently from the device.







- Uninstalled apps are automatically removed from the device 24 hours after they were uninstalled. If you want to reinstall the uninstalled apps, you must download them again from the app store.
- This feature is activated on the default Home screen only. If you uninstall apps while using the EasyHome screen or other launcher, they are immediately and permanently removed from the device.

Phone

Voice call

Make a phone call by using one of the available methods, such as manually entering a phone number and making a call from the contact list or the list of recent calls.




Making a call from the keypad

- 1 Tap  >  > **Dial**.
- 2 Make a call by using a method of your choice:
 - Enter a phone number and tap .
 - Touch and hold a speed dial number.
 - Search for a contact by tapping the initial letter of a contact name in the contact list, and then tap .




- To enter "+" when making an international call, touch and hold number 0.
- See *Adding contacts* for details on how to add phone numbers to the speed dial list.

Making a call from the contact list

- 1 Tap  >  > **Contacts**.
- 2 From the contact list, select a contact and tap .



Answering a call

To answer a call, drag  on the incoming call screen.

- When the stereo headset is connected, you can make calls by using the call/end button on the headset.
- To end a call simply by pressing the Power/Lock key, tap  > **Settings** > **Networks** > **Call** > **Common** > **Answer and end calls**, then turn on **End call with the Power key**.


Rejecting a call



To reject an incoming call, drag  across the incoming call screen.

- To send a rejection message, drag the rejection message option  across the screen.
- To add or edit a rejection message, tap  > **Settings** > **Networks** > **Call** > **Common** > **Call blocking & Decline with message** > **Decline with message**.
- When a call is coming in, press the Volume Up (+), Volume Down (-) or Power/Lock key to mute ringtone or vibration, or to hold the call.




Checking an incoming call while using an app

When a call comes in while using an app, a pop-up notification can be displayed at the top of the screen. You can receive the call, reject the call, or send message from the pop-up screen.




- Tap  > **Settings** > **Networks** > **Call** > **Common** > **More** and then tap **Incoming voice call pop-up**  to deactivate it.

Viewing missed calls

If there is a missed call, the status bar at the top of the screen displays . To view missed call details, drag the status bar downwards. You can also tap  >  > **Call logs**.

Functions accessible during a call

During a call, you can access a variety of functions by tapping the on-screen buttons:



- **Contacts**: View the contact list during a call.
- **End**: End a call.
- **Dialpad**: Display or hide the dial pad.
- **Speaker**: Turn on the speakerphone function.
- **Mute**: Mute your voice so that your voice cannot be heard by the other party.
- **Bluetooth**: Switch the call to a Bluetooth device that is paired and connected.
- : Access additional call options.



- Available settings items may vary depending on the area or service provider.

Making a three-way calling

You can make a call to another contact during a call.



- 1 During a call, tap  > **Add call**.
- 2 Enter a phone number and tap .
 - The two calls are displayed on the screen at the same time, and the first call is put on hold.
- 3 To start a conference call, tap **Merge calls**.



- You may be charged a fee for each call. Consult with your service provider for more information.

Viewing call records

To view recent call records, tap  >  > **Call logs**. Then, you can use the following functions:




- To view detailed call records, select a contact. To make a call to the selected contact, tap .
- To delete call records, tap  > **Delete**.



- The displayed call duration may differ from the call charge. Consult with your service provider for more information.

Configuring call options

You can configure various call options.

- 1 Tap  >  > **Dial** or **Call logs**.
- 2 Tap  > **Call settings** and then configure the options to suit your preferences.






Messaging

Sending a message

You can create and send messages to your contacts using the Messaging app.



- Sending messages abroad may incur additional charges. Consult with your service provider for more information.

- 1 Tap  > .
- 2 Tap .
- 3 Specify a recipient and create a message.
 - To attach files, tap .
 - To access optional menu items, tap .
- 4 Tap **Send** to send the message.

Reading a message

You can view exchanged messages organised by contact.

- 1 Tap  > .
- 2 Select a contact from the message list.

Configuring messaging settings

You can change messaging settings to suit your preferences.

- 1 Tap  > .
- 2 Tap  > **Settings** from the message list.

Camera

Starting the camera

You can take a photo or record a video to cherish all of your memorable moments.

Tap  > .




- Before taking a photo or recording a video, wipe the camera lens with a soft cloth.
- Be careful not to stain the camera lens with your fingers or other foreign substance.
- If the battery level is lower than 5%, charge the battery before using the camera.
- Images included in this user guide may be different from the actual device.
- Photos and videos can be viewed or edited from the Gallery. See [Gallery overview](#) for details.

Changing the camera mode

You can select a camera mode that suits your environment to take a photo or record a video easily and conveniently.


On the camera screen, tap AUTO mode and select the desired mode.




AUTO mode

You can take photos or record videos by selecting a variety of camera modes and options.


- 1 Launch the Camera app, then tap **AUTO** (A).
- 2 To take a photo, tap . To record a video, tap .








Taking a photo

- 1 Select a camera mode and tap the subject to focus the camera on.
- 2 Tap  to take a photo.
 - You can also press the Volume Down (-) or Volume Up (+) key to take a photo.




- When the screen is turned off or locked, start the camera by pressing the Volume Down (-) key twice. Tap  > **Settings** > **General** > **Shortcut keys**.

Recording a video

- 1 Select a camera mode and tap the subject to focus the camera on.
- 2 Tap 
 - To take a photo while recording a video, tap .
 - To pause the video recording, tap . To resume the video recording, tap .
- 3 Tap  to end the video recording.

Customising the camera options

You can customise a variety of camera options to suit your preferences.

Tap  on the screen.



- Available options vary depending on the selected camera (front or rear camera) and the selected camera mode.

Photo size	Select values for aspect ratio and size for taking photos.
Video resolution	Select values for resolution and size for recording videos.
Camera roll	Display your recent photos and videos along the side of the screen.
HDR	Obtain photos in vivid colours and get compensated effects even when they are taken against the light. These functions are provided by the high dynamic range (HDR) technology equipped in the camera.
Timer	Set the timer to automatically take photos after a specified period of time.
Cheese shutter	Take photos with voice commands.
Tracking focus	When the subject is touched, the camera tracks and maintains focus on a moving object. (Available when the standard camera is in use.)
Steady recording	Minimise motion blur while recording a video.
Covered lens	Let you know when the rear wide-angle lens is covered.
Tag locations	Save the image with GPS location data.
Grid	Display guide grids so that you can take photos or record videos based on the horizontal and vertical reference lines.
Add signature	Display a personalised signature on the photos.
Storage	Select if you want to store the pictures and videos in the Internal storage or SD card. (Available when the memory card is inserted.)
Simple view	Hide all menus from the camera screen.
Help	Provide Help for each camera menu.

Additional options on the front camera

Selfie shot	Customise selfie shot settings. <ul style="list-style-type: none">• Gesture shot: Shoot using the Gesture shot feature.• Auto shot: Shoot when the camera detects a face.
Gesture view	Choose whether to use Gesture view to view the taken photo immediately after taking a photo.
Save as flipped	Save as flipped images after taking selfies.






- When using the front camera, you can adjust the filter, lighting effect, and skin tone.

Various camera modes

Panorama

You can create a panoramic photo by moving the camera in one direction to photograph and stitch continuous shots of a wide view.

- 1 In the AUTO mode, tap **MODE** > 
- 2 Tap  and then slowly move the camera in one direction.
 - Move the device by following the direction of the arrow in the guideline.
- 3 Tap  to stop capturing the panoramic.



360 Panorama

You can create a 360° panorama photo by moving the camera in one direction.


- 1 In the AUTO mode, tap **MODE** > 📷.
- 2 Tap 📷 and then slowly move the camera in one direction.
 - Move the device by following the direction of the arrow in the guideline.
- 3 Tap 🛑 to stop capturing the 360° panorama.



Food





You can take a photo and record a video using the control slide bar on the right of the screen.


- 1 In the AUTO mode, tap **MODE** > 🍴.
- 2 To take a photo, tap 📷. To record a video, tap 📹.
 - Drag the colour slide bar on the screen to adjust the white balance and select the best colour.
 - If the slide bar is invisible, tap ⚙️ to adjust the white balance.



Popout



You can take a photo or record a video by using both the standard and wide-angle of the dual camera at the back of the device to record the scenes as if they were put in the frame. The scenes shown in the small, front screen are shot by using the standard camera, and the scenes shown in the large, background screen are shot by using the wide-angle camera. Change the front screen to a different shape or apply various effects to take a sensuous photo or video.


- 1 In the AUTO mode, tap **MODE** > .
- 2 Tap  and select the desired layout.
- 3 Select the desired effect:
 - **Fisheye**: Apply a convex lens effect to the area captured by the wide-angle camera.
 - **B&W**: Apply grayscale to the area captured by the wide-angle camera.
 - **Vignette**: Darken the edges of the area captured by the wide-angle camera.
 - **Lens blur**: Blur the area captured by the wide-angle camera.
- 4 Tap  to take a photo. To record a video, tap .



Snap

You can record short videos clips and assemble them into a 60-second short film.




- 1 In the AUTO mode, tap **MODE** > .
- 2 Tap 
 - Tap the icon once to record a three-second video clip. Touch and hold the icon to create a longer video clip (maximum length: one minute).



- 3 Tap **SAVE**.

Slo-mo




You can create an entertaining video by changing the moving speeds of subjects in your video. This feature allows you to record a video at a faster rate of speed and then play it at the standard speed so that the video appears to be slowed down.

- 1 In the AUTO mode, tap **MODE** > .
- 2 Tap  and record a video.
- 3 Tap  to end the video recording.




Time-lapse

You can take a sequence of frames at set intervals to record changes that take place slowly over time, such as cloud movements, celestial motions, traffic, and more.

- 1 In the AUTO mode, tap **MODE** > .
- 2 Tap  and record a video.
- 3 Tap  to end the video recording.




- While recording a Time-lapse, voices are not recorded.



Burst shot

You can take continuous shots of photos to create moving pictures.



In the AUTO mode, touch and hold .

- Continuous shots are taken at a fast speed while  is held down.



- When the storage is set as Internal storage, you can take up to 100 photos. When the storage is set as External storage, you can take up to 30 photos in a row.

Simple view

In the AUTO mode, tap  > **Simple view** to hide menus on the camera screen. Tap  to display them.

SQUARE camera mode

You can take multiple photos or videos in the form of a collage by using the front and rear cameras. Photos and videos can be saved with different layouts.

- 1 Launch the Camera app, then tap **AUTO** (📷) > **SQUARE** (📷).
- 2 Tap **MODE** and select the desired camera mode.
- 3 To take a photo, tap 📷. To record a video, tap 🎥.

Customising the camera options

You can customise a variety of camera options to suit your preferences.

Tap ⚙️ on the screen.



- Available options vary depending on the selected camera (front or rear camera) and the selected camera mode.

Photo size	Select values for aspect ratio and size for taking photos.
Video resolution	Select values for resolution and size for recording videos.
HDR	Obtain photos in vivid colours and get compensated effects even when they are taken against the light. These functions are provided by the high dynamic range (HDR) technology equipped in the camera.
Timer	Set the timer to automatically take photos after a specified period of time.
Cheese shutter	Take photos with voice commands.
Tracking focus	When the subject is touched, the camera tracks and maintains focus on a moving object. (Available when the standard camera is in use.)

Steady recording	Minimise motion blur while recording a video.
Covered lens	Let you know when the rear wide-angle lens is covered.
Tag locations	Save the image with GPS location data.
Grid	Display guide grids so that you can take photos or record videos based on the horizontal and vertical reference lines.
Add signature	Display a personalized signature on the photos.
Storage	Select if you want to store the pictures and videos in the Internal storage or SD card. (Available when the memory card is inserted.)
Help	Provide Help for each camera menu.

Additional options on the front camera

Selfie shot	<p>Customise selfie shot settings.</p> <ul style="list-style-type: none"> • Gesture shot: Shoot using the Gesture shot feature. • Auto shot: Shoot when the camera detects a face.
Save as flipped	Save as flipped images after taking selfies.



- When using the front camera, you can adjust the filter, lighting effect, and skin tone.

MANUAL camera mode

You can create photos featuring professional touch by using a variety of advanced features. Adjust the white balance, focus, brightness, ISO, shutter speed and other options.

- 1 Launch the Camera app, then tap **AUTO** (A) > **MANUAL** (r).
- 2 Customise the following camera settings.



- Adjust white balance.
- Adjust focus.
- Adjust brightness.
- Adjust exposure level.
- Adjust shutter speed.
- Adjust ISO speed.

- 3 Tap (r) to take the photo.

Customising the camera options

You can customise a variety of camera options to suit your preferences. Tap (⚙️) on the screen.


Photo size	Select values for aspect ratio and size for taking photos.
Timer	Set the timer to automatically take photos after a specified period of time.
Cheese shutter	Take photos with voice commands.
Tracking focus	When the subject is touched, the camera tracks and maintains focus on a moving object. (Available when the standard camera is in use.)

Tag locations	Save the image with GPS location data.
Guide	Display guide grids so that you can take photos based on the horizontal and vertical reference lines.
Save as RAW	The image is stored as a RAW file format so that you can modify it. The DNG and JPEG files are created while taking a photo, then saved as a non compressed high resolution image.
Covered lens	Let you know when the rear wide-angle lens is covered.
Noise reduction	Reduce noise at high ISO settings.
Add signature	Display a personalized signature on the photos.
Storage	Select if you want to store the pictures and videos in the Internal storage or SD card. (Available when the memory card is inserted.)
Help	Provide Help for each camera menu.

MANUAL video mode

You can record a video by manually customising various options. Adjust values for white balance, focus, brightness, ISO, shutter speed and more.


- 1 Launch the Camera app, then tap **AUTO** (A) > **MANUAL** (M).
- 2 Customise the camera settings.



- 3 Tap  to record a video.

Customising the camera options

You can customise a variety of camera options to suit your preferences.

Tap  on the screen.

Video resolution	Select values for aspect ratio and size for videos.
Frame rate	Select the frames per second value.
Bit rate	Select the image quality for videos.
Hi-Fi	Record a video with Hi-Fi quality sound.
Timer	Set the timer to automatically take photos after a specified period of time.
Steady recording	Minimise motion blur while recording a video.
Covered lens	Let you know when the rear wide-angle lens is covered.
Tracking focus	When the subject is touched, the camera tracks and maintains focus on a moving object. (Available when the standard camera is in use.)
Tag locations	Save the image with GPS location data.
Grid	Display guide grids so that you can record videos based on the horizontal and vertical reference lines.
Storage	Select if you want to store the pictures and videos in the Internal storage or SD card.
Help	Provide Help for each camera menu.

Other useful features in the Camera app

AE/AF lock

You can fix the current exposure level and focus position by touching and holding the screen in the AUTO mode. To turn off the feature, tap a blank area on the screen.




Focus peaking

In the MANUAL camera or MANUAL video mode, tap **FOCUS**.





To turn off the feature, tap **Focus peaking**.



Switching between cameras

You can switch between the front and rear cameras to suit your environment.





On the camera screen, tap  or drag the screen in any direction to switch between the front and rear cameras.



- Use the front camera to take selfies. See *Selfie shot* for details.

Switching to dual camera

Switch between the standard and wide-angle to take photos or record videos to suit your preferences.

- Tap  /  or  /  to switch between the standard and wide-angle camera.
- Another way to switch between the standard and wide-angle is to pinch or spread your fingers.

Zoom in or out

You can use zoom in or out on the camera screen while taking a photo or recording a video.

- On the camera screen, pinch or spread two fingers to zoom in or out, then use the displayed +/- slide bar.
- Then the wide-angle camera and general camera on the back of the device are automatically switched to take a photo or record a video.



- The zoom feature is not available when using the front camera in selfie mode.

Selfie shot

You can use the front camera to view your face on the screen and take selfies.


Gesture shot

You can take selfies by using gestures.


Show your palm to the front camera and then clench your fist.

You can also clench your fist and then open it towards the front camera.

- In three seconds, a photo is taken.






- To use this feature, switch to the front camera mode, then tap  > **Selfie shot > Gesture shot**.
- Make sure that your palm and fist are within the reference line so that the camera can detect them.
- This feature may not be available while using some of the camera features.


Interval shot

You can take selfies at an interval.

While using the front camera, you can show your palm to the camera, then clench your fist twice quickly.

- Four photos are taken at about two seconds interval after a timer delay of three seconds.



- Tap  > **Selfie shot > Gesture shot** to use this feature.

Auto shot

You can use the face detection feature to take selfies easily and conveniently. You can set the device so that, when you look at the screen, the front camera detects your face and takes a selfie automatically.


- The white coloured guide frame appears when the front camera detects your face. If the subject within the guide frame stops moving, the guide frame colour turns blue, then the camera takes a photo.




- Tap  > **Selfie shot** > **Auto shot** to enable the Auto shot feature.


Gesture view

After taking a selfie with the front camera, you can preview the selfie immediately by placing the screen close to your face.



- Tap  > **Gesture view** to enable the Gesture view feature.
- Only one preview is available each time a photo is taken.
- If you rotate the device while in preview screen, the screen switches to camera mode.

Save as flipped

Before taking a photo with the front camera, tap  > **Save as flipped**. The image is flipped horizontally.





- When using the front camera, you can change how selfies are taken in the camera options. See *Customising the camera options* for details.

Gallery

Gallery overview


You can view and manage photos and videos saved on your device.

- 1 Tap  > .
 - Saved photos and videos are displayed by folder.
- 2 Tap a folder and select a file.
 - View the selected file in full-screen mode.
 - While viewing a photo, swipe left or right to view the previous or next photo.
 - While viewing a video, swipe left or right to rewind or fast-forward the video.





- Some file formats may not be supported, depending on the installed software.
- Some files may not be opened due to encoding.
- Files that exceed the size limit may cause an error.


Viewing photos



- To display the menu items, gently tap the screen. To hide the menu items, tap the screen again.


Floating button

To quickly move to the Home screen while viewing the Gallery in landscape orientation, touch and hold , move your finger upward to , then release it.



- You can move the floating button's position by dragging it horizontally along the bottom part of the screen.

Writing a memo on the photo


- 1 While viewing a photo, tap .
- 2 Write a memo on the photo and tap **SAVE**.



- Some photos may not support the photo memo feature.

Related content

You can edit and customise related content in the Gallery.



- 1 While viewing a picture preview, tap .
- 2 When the icon related with the date you took the photo appears, touch the screen.





- You can view the photos related with the date you chose.




- Related content can be related to up to four combinations of 'Memories, Date, Place, Camera mode'

- Tap  to save the related content as a video.
- Tap  to access additional options.

Editing photos


- 1 While viewing a photo, tap .
- 2 Use a variety of effects and tools to edit the photo.
- 3 Tap **SAVE** to save changes.
 - The changes are overwritten to the original file.
 - To save the edited photo as another file, tap  > **Save copy**.


Playing a video



- To adjust the sound volume, drag the right side of the video screen up or down.
- To adjust the screen brightness, drag the left side of the screen up or down.

Editing videos


- 1 While viewing a video, tap .
- 2 Use a variety of effects and edit tools to edit the video.



- 3 Tap **SAVE** to save changes.

Making a GIF

You can easily make a GIF file using recorded video.



- 1 At the desired starting point while watching the video, tap  > **Create GIF**.
- 2 Select the length of the GIF you want to create.
 - GIF is generated for the time selected from the current time.
 - For videos less than 5 seconds, GIF images are automatically generated for the remaining time.



- The GIF making feature is provided for the user's creative activity. If you infringe other's copyright or defamation laws by using the GIF making feature, you may be liable for civil and criminal liability. Be sure to not duplicate or transfer work of others without permission. LG Electronics cannot accept any liability for the user's action.




Related files

You can relate files by photos and videos taken with the same location or date.

- 1 Select the saved photos and videos and tap .
- 2 Select a desired folder, then tap  to create a video.




Deleting files

You can delete files by using one of the following options:

- Touch and hold a file from the file list, then tap **Delete**.
- Tap  from the file list and delete the desired files.
- Deleted files are automatically moved to **Trash** and they can be restored to the Gallery within 7 days.
- On the Gallery, tap  > **Trash**. Tap  to completely delete the files. In this case, the files cannot be restored.

Sharing files

You can share files by using one of the following options:

- While viewing a photo, tap  to share the file by using the method you want.
- While viewing a video, tap  > **Share** to share the file by using the method you want.
- Tap  from the file list to select files and share them using the method you want.

Contacts


Contacts overview

You can save and manage contacts.

Tap  > **Essentials** > **Contacts**.


Adding contacts

Adding new contacts


- 1 On the contact list screen, tap .
- 2 Enter contact details and tap **SAVE**.

Importing contacts

You can import contacts from another storage device.

- 1 On the contact list screen, tap  > **Manage contacts** > **Import**.
- 2 Select the source and target locations of the contact you want to import, and then tap **OK**.
- 3 Select the contacts and tap **IMPORT**.

Adding contacts to the speed dial list

- 1 On the contact list screen, tap  > **Speed dial**.
- 2 Tap **Add contact** from a speed dial number.
- 3 Select a contact.


Searching for contacts

You can search for contacts by using one of the following options:

- On the contact list screen, enter a contact name in the search box.
- Scroll the contact list up or down.
- From the index of the contact list screen, tap the initial letter of a contact.


Contacts list

Editing contacts

- 1 On the contact list screen, select a contact.
- 2 On the contact detail screen, tap  and edit details.
- 3 Tap **SAVE** to save changes.


Deleting contacts

You can delete contacts by using one of the following options:


- On the contact list screen, touch and hold a contact you want to delete, then tap **Delete contact**.
- Tap  > **Delete** on the contact list screen.

Adding favourites

You can register frequently used contacts as favourites.

- 1 On the contact list screen, select a contact.
- 2 On the contact detail screen, tap .

Creating groups












- 1 On the contact list screen, tap **Groups** >  > **New group**.
- 2 Enter a new group name.
- 3 Tap **Add members**, select contacts, then tap **ADD**.
- 4 Tap **SAVE** to save the new group.

QuickMemo+





QuickMemo+ overview

You can make creative notes by using a variety of options on this advanced notepad feature, such as image management and screenshots, which are not supported by the conventional notepad.



Creating a note

- 1 Tap  > **Essentials** > **QuickMemo+**.
- 2 Tap  to create a note.
 -  : Save a note.
 -  : Undo the last action.
 -  : Redo the last action you undid.
 -  : Enter a note by using the keypad.
 -  : Write notes by hand.
 -  : Erase handwritten notes.
 -  : Zoom in or out, rotate or erase the parts of a handwritten note.
 -  : Access additional options.
- 3 Tap  to save the note.

Writing notes on a photo



- 1 Tap  > **Essentials** > **QuickMemo+**.
- 2 Tap  to take a photo, then tap **OK**.
 - The photo is automatically attached into the notepad.
- 3 Tap **T** or  to write notes on the photo.
 - Write notes by hand on the photo.
 - Enter text below the photo.
- 4 Tap  to save the note.



Writing notes on a screenshot

- 1 While viewing the screen you want to capture, drag the status bar downwards and then tap .
 - The screenshot appears as the notepad background theme. Memo tools appear at the top of the screen.
- 2 Take notes as desired.
 - Write notes by hand on the photo.
- 3 Tap  and save the notes to the location you want.
 - Saved notes can be viewed in either **QuickMemo+** or **Gallery**.
 - To save notes in the same location all the time, select the **Use as default app** checkbox and select an app.

Managing folders

You can view notes grouped by type.

- 1 Tap  > **Essentials** > **QuickMemo+**.
- 2 At the top of the screen, tap  and select a menu item:
 - **All memos**: View all notes saved in QuickMemo+.
 - **My memos**: View notes created by QuickMemo+.
 - **Capture+**: View notes created by Capture+.

- **Photo memos:** View notes created by .
- **Trash:** View deleted notes.
- **New category:** Add categories.
- : Rearrange, add or delete categories. To change the name of a category, tap the category.





- Some folders do not appear when launching QuickMemo+ for the first time. Disabled folders are enabled and appear when they contain at least one related note.


Clock

Alarm

You can set an alarm to trigger it at a specified time.



- 1 Tap  > **Essentials** > **Clock** > **Alarm**.
- 2 Tap  to add a new alarm.
- 3 Configure the alarm settings and tap **SAVE**.



- If you select a previously set alarm, you can edit the alarm.
- To delete an alarm, tap  at the top of the screen. You can also touch and hold the alarm.



World clock

You can view the current time in cities around the world.

- 1 Tap  > **Essentials** > **Clock** > **World clock**.
- 2 Tap  and add a city.


Timer

You can set the timer to trigger an alarm after a specified period of time.

- 1 Tap  > **Essentials** > **Clock** > **Timer**.
- 2 Set the time and tap **Start**.
 - To suspend the timer, tap **Pause**. To resume the timer, tap **Resume**.
 - To reset the timer settings, tap .
- 3 Tap **Stop** to stop the timer alarm.

Stopwatch

You can use the stopwatch to record a lap time.



- 1 Tap  > **Essentials** > **Clock** > **Stopwatch**.
- 2 Tap **Start** to initiate the stopwatch.
 - To record a lap time, tap **Lap**.
- 3 Tap **Pause** to suspend the stopwatch.
 - To resume the stopwatch, tap **Resume**.
 - To clear all the records and restart the stopwatch, tap **Reset**.

Calendar


Calendar overview

You can use the calendar to manage events and tasks.

Adding events

- 1 Tap  > **Essentials** > **Calendar**.
- 2 Select a date and then tap .
- 3 Enter event details and tap **SAVE**.
 - If you tap a date from the calendar and the date contains events, a pop-up window appears showing a list of the events. Tap an event from the pop-up window to view the event details.

Syncing events


Tap  > **Calendars to sync**, and select a calendar to sync.







- When your events are saved from the device to your Google account, they are automatically synced with the Google calendar, too. Then, you can sync other devices with the Google calendar in order to make those devices have the same events that your device has and to manage your events on those devices.

Event pocket

You can use the event pocket to create events.

Tap  to open the event pocket and then drag content to a date in the calendar.

- : Manage images, text, memos and temporarily saved events. You can also share text, images and memos from another app and save them to the pocket. If you tap **POCKET** when creating an event, the event is temporarily saved to the pocket.
- : Add a Facebook account to view information on Facebook events. Some devices may not support the Facebook event information function.
- : View tourism information about the surrounding area, such as restaurants and convenient facilities, to plan an event.
- : Manage tasks that have no deadline, such as events.

Tasks

You can register tasks to your device to easily manage schedules.

- 1 Tap **○** > **Essentials** > **Tasks**.
- 2 Tap **+** to add a task.
- 3 Enter task details and then tap **SAVE**.

Music

You can play and manage songs or music albums.

- 1 Tap **○** > **Essentials** > **Music**.
- 2 Select a category.
- 3 Select a music file.





- Some file formats may not be supported, depending on the installed software.
- Files that exceed the size limit may cause an error.
- Music files may be protected by international copyright owners or copyright laws. You may have to obtain legal permission before copying a music file. To download or copy a music file, first check the copyright law for the relevant country.
- This model supports Hi-Fi audio playback. Hi-Fi audio files display the Hi-Fi icon.

Calculator

You can use two types of calculators: the simple calculator and the scientific calculator.

- 1 Tap > **Essentials** > **Calculator**.
- 2 Use the keypad to make a calculation.
 - To use scientific calculator, drag the green coloured slide bar located in the right side of the screen to the left.
 - To restart a calculation, touch and hold the **DEL** button.

LG Health

LG Health overview

You can manage your health and maintain good exercise habits by keeping track of the exercises you do.


Getting started with LG Health


You can configure LG Health when launching the app for the first time or after resetting it.




- 1 Tap  > **Essentials** > **LG Health**.
- 2 Follow the on-screen instructions to complete configuration.

Using LG Health

You can view main information on LG Health and manage the amount of physical exercise and health information.

- 1 Tap  > **Essentials** > **LG Health**.
- 2 The following options are available.



-  : View your exercise log on the day you want to check.
-  : Begin tracking an exercise. The route and amount of your physical exercise are recorded for each exercise type.
-  : Set your daily exercise goals including calories and steps, or set various LG Health settings.



- Health-related information provided by LG Health is designed for user convenience and cannot be used for purposes of disease prevention, treatment, diagnosis or other medical issues.
- LG Health may vary or may not be available, depending on the country and service provider. LG Health functions that are available and apps that can be added to LG Health may vary, depending on the country. This is due to differing laws and regulations.

E-mail

E-mail overview

You can register an email account to your device and then you can check and send emails from your device.



- If you use mobile data, you may be charged for data usage depending on your pricing plan. Consult with your service provider for more information.


Registering email accounts

When you use the email app for the first time, register your email account.


- 1 Tap > **Essentials** > **E-mail**.
- 2 Select an email service provider.
- 3 Enter your email address and password and then tap **NEXT** to register your account.
 - To manually register an email account, tap **MANUAL SETUP** (if necessary).

Managing email accounts


To view or edit your email account settings, tap  > **Settings**.

- To add an account, tap **Add account**.
- To delete an account, tap  > **Remove account**.





Opening another email account

If several email accounts are registered and you want to view another account, tap  and select another one from the account list.

Checking email

- 1 Tap  and select a mail box.
- 2 Select an email from the email list.
 - The email message appears.

Sending email

- 1 Tap .
- 2 Enter the recipient's email address.
- 3 Enter a subject and message.
 - To attach files, tap .
 - To access optional menu items, tap .
- 4 Tap  to send the email.

FM Radio

You can listen to FM radio.



Tap  > **Essentials** > **FM Radio**.



- To use this app, first connect earphones to the device. The earphones function as the radio antenna.
- This function may not be supported depending on the area.



File Manager

You can view and manage files saved on your device or cloud.

- 1 Tap  > **Management** > **File Manager**.
- 2 Tap  and select the desired storage location.

LG Mobile Switch

Easily transfer data from a used device to a new device via LG Mobile Switch.

- 1 Tap  > **Management** > **LG Mobile Switch**.
You can also tap  > **Settings** > **General** > **Backup & reset** > **LG Mobile Switch**.
- 2 Follow the on-screen instructions to select a desired method for transfer.




- Resetting your device may delete backup files saved in storage. Make sure to copy and store the important backup files to your PC.



- Data in a Google account will not be backed up. When you synchronise your Google account, Google apps, Google contacts, Google calendar, Google memo app data and apps downloaded from the Play Store are stored on the Drive app automatically.
- Fully charge the battery before transferring data to avoid unintentional powering off during the process.

LG Friends Manager

You can connect to LG Friends devices and manage them with ease.

Tap  > **Management** > **LG Friends Manager**.

Downloads

You can view, delete or share files downloaded via the Internet or apps.



Tap  > **Management** > **Downloads**.

LG SmartWorld

You can download a variety of games, audio content, apps and fonts provided by LG Electronics. Customise your device to suit your preferences by using Home themes and fonts.




- If you use mobile data, you may be charged for data usage depending on your pricing plan.
- This feature may not be supported depending on the area or service provider.

- 1 Tap  > **Services** > **SmartWorld**.
- 2 Tap  > **LG Account**, then sign in.
- 3 Select and download the desired content items.

Downloading SmartWorld app

If the SmartWorld app is not installed, follow these steps to download it.

- 1 Tap  > **Settings** > **General** > **About phone** > **Common** > **Update centre** > **App Updates**.
- 2 From the list, select **SmartWorld** and tap **Download**.

Cell Broadcast

You can view real-time text broadcasts on emergency situations, such as typhoons, floods and earthquakes.

Tap  > **Services** > **Cell Broadcast**.

Instagram

Use a social networking service to capture and share your photos and videos. You can also apply filter effects to make your photos and videos more creative and interesting.

Tap  > **Recommended** > **Instagram**.

Facebook

You can use a social networking service to update, view and share posts, photos and videos with your online contacts.

Tap  > **Recommended** > **Facebook**.

Evernote

You can write and collect important information and then share them with other devices that support **Evernote**.

Tap  > **Recommended** > **Evernote**.

Chrome

Sign in to Chrome and import opened tabs, bookmarks and address bar data from a computer to your device.

Google apps

You can use Google apps by setting a Google account. The Google account registration window appears automatically when you use a Google app for the first time. If you do not have a Google account, create one from your device. For details on how to use an app, see the Help in the app.



- Some apps may not work depending on the area or service provider.

Docs

Create documents or edit documents created online or from another device. Share and edit documents together with others.

Drive

Upload, save, open, share and organise files from your device. Files accessible from apps can be accessed from anywhere, including online and offline environments.

Duo

Make a video call with your family, friends and anyone else who uses the app.

Gmail

Register your Google email account to your device to check or send email.

Google

Use the Google to search for web pages, images, news and more by entering or speaking keywords.

Maps

Find your location or the location of a place on the map. View geographical information.

Photos

View or share photos or albums saved on your device.

Play Movies & TV

Use your Google account to rent or purchase movies. Purchase content and play it anywhere.

Play Music

Purchase music files from the Play Store. Play music files saved on your device.

Sheets

Create spreadsheets or edit spreadsheets created online or from another device. Share and edit spreadsheets together with others.


Slides

Create presentation material or edit presentation material created online or from another device. Share and edit presentation material together with others.

YouTube

Search and play videos. Upload videos on YouTube to share them with people around the world.

Google Assistant

Your device has the Google Assistant built in. Ask it questions. Tell it to do things. It's your own personal Google. Touch and hold the  and then you will see "Hi, how can I help?", after which you can say your voice command.



• The Google Assistant is not available in all languages.



04



Settings

Settings

You can customise the device settings in accordance with your preferences.

Tap  > **Settings**.



- Tap  and enter a keyword in the search box to access a setting item.
- Tap  to change the view mode. This user guide assumes that you are using the **Tab view**.

Networks

Dual SIM card

You can configure Dual SIM settings.

- 1 On the settings screen, tap **Networks** > **Dual SIM card**.
- 2 Customise the following functions:
 - **SIM card 1**: Change the name and icon of the SIM card 1.
 - **SIM card 2**: Change the name and icon of the SIM card 2.
 - **SIM card colour theme**: Change the colour themes for the SIM cards.
 - **Cost save mode**: Activate or deactivate the cost save mode. In the cost save mode, if you make a call to a contact to which a specific SIM is assigned, this SIM is used for the call even if the other SIM is active, for example, it is using mobile data.
 - **Mobile data**: Select a SIM card you want to use for mobile data service. You can also turn off this function.
 - **Data roaming**: Select this option to enable the device to use mobile data when you are roaming outside your home network area.

Wi-Fi


You can connect to nearby devices over a Wi-Fi network.

Connecting to a Wi-Fi network

- 1 On the settings screen, tap **Networks > Wi-Fi**.
- 2 Tap to activate it.
 - Available Wi-Fi networks appear automatically.
- 3 Select a network.
 - You may need to enter the network's Wi-Fi password.
 - The device skips this process for previously accessed Wi-Fi networks. If you do not want to automatically connect to a certain Wi-Fi network, touch and hold the network and then tap **Forget network**.

Wi-Fi network settings

On the settings screen, tap **Networks > Wi-Fi**.

- **Switch to mobile data:** If the mobile data connection function is activated but the device cannot connect to the Internet via Wi-Fi connection, the device automatically connects to the Internet via the mobile data connection.
-  : Customise Wi-Fi network settings.


Wi-Fi Direct

You can connect your device to other devices that support Wi-Fi Direct to share data directly with them. You do not need an access point. You can connect with more than two devices by using Wi-Fi Direct.

- 1 On the settings screen, tap **Networks > Wi-Fi > ⋮ > Advanced Wi-Fi > Wi-Fi Direct**.
 - Nearby devices that support Wi-Fi Direct automatically appear.
- 2 Select a device.
 - Connection occurs when the device accepts the connection request.



- The battery may drain faster when using Wi-Fi Direct.



Bluetooth

You can connect your device to nearby devices that support Bluetooth to exchange data with them. Connect your device to a Bluetooth headset and a keyboard. This makes it easier to control the device.

Pairing with another device

- 1 On the settings screen, tap **Networks > Bluetooth**.
- 2 Tap to activate it.
 - Available devices appear automatically.
 - To refresh the device list, tap **SEARCH**.




• Only devices set as visible are displayed on the list.

- 3 Select a device from the list.
- 4 Follow the on-screen instructions to perform authentication.



• This step is skipped for previously accessed devices.

Sending data via Bluetooth

- 1 Select a file.
 - You can send multimedia files or contacts.
- 2 Tap  **Bluetooth**.
- 3 Select a target device for the file.
 - The file is sent as soon as the target device accepts it.



• File sharing processes may differ, depending on the file.


Mobile data

You can turn on or off mobile data. You can also manage mobile data usage.

Turning on mobile data

- 1 On the settings screen, tap **Networks > Mobile data**.
- 2 Tap to activate it.

Customising mobile data settings

- 1 On the settings screen, tap **Networks > Mobile data**.
- 2 Customise the following settings:
 - **Mobile data:** Set to use data connections on mobile networks.
 - **Limit mobile data usage:** Set a limit for mobile data usage to block mobile data if the limit is reached.
 - : Customise mobile data settings.

Call

You can customise call settings, such as voice call and international call options.



- Some features may not be supported depending on the area or service provider.

- 1 On the settings screen, tap **Networks > Call**.
- 2 Customise the settings.

Share & connect

NFC

You can use the device as a transportation card or credit card. You can also share data with the other device.

- 1 On the setting screen, tap **Networks > Share & connect > NFC**.
- 2 Tap to activate it.
 - Touch your device with other device that supports NFC to allow sharing data.



- NFC antenna may be located differently depending on the device type. See [Parts overview](#) for details about the NFC antenna area.

Android Beam

You can share files by touching the back of the device to other device. You can also share files including music, videos or contacts and open a web page or launch an app from the other device.

- 1 On the settings screen, tap **Networks > Share & connect > Android Beam**.
- 2 Touch the back of the device with another device.



- NFC antenna may be located differently depending on the device type.

File sharing

You can send and receive files between your device and other LG devices or tablets.



• See *Sending or receiving files* for details.

- 1 On the settings screen, tap **Networks > Share & connect > File sharing**.
- 2 Customise the following settings:
 - **G6 plus**: Change the device name.
 - **Save to**: Set the destination folder to save files sent from other devices in.
 - **File sharing**: Permit receipt of files sent from other devices.
 - **SmartShare Beam**: Share files with other devices via SmartShare Beam.
 - **Help**: You can view help on sharing files.

Media server

You can share media content on your device with nearby devices that support DLNA.

- 1 On the settings screen, tap **Networks > Share & connect > Media server**.
- 2 Customise the following settings:
 - **Content sharing**: Share content on your device with nearby devices.
 - **G6 plus**: Set your device's name.
 - **Content to share**: Select the type of media content to share with other devices.
 - **Allowed devices**: View a list of devices permitted to access content on your device.
 - **Not-allowed devices**: View a list of devices not permitted to access content on your device.

Screen sharing

You can play the screen and sound of the device on a different device, such as a TV, that supports the Miracast function.

- 1 On the settings screen, tap **Networks > Share & connect > Screen sharing**.
- 2 Tap to activate it.
- 3 Select a device from the list of nearby devices.
 - If the desired device does not appear, tap **SEARCH** to refresh the list.
 - After connecting to the device, the device displays the screen of your device.



- Screen sharing turns off automatically if there is no sharing-compatible device in the vicinity.

LG AirDrive

You can use your LG account to manage files saved on the device from a computer. You do not need a USB connection.

- 1 On the settings screen, tap **Networks > Share & connect > LG AirDrive**.
- 2 Use a single LG account to sign in to LG Bridge on the computer and **LG AirDrive** on the device.
 - LG Bridge software can be downloaded from www.lg-mobile.co.il.
- 3 Manage files on the device from the computer.

Printing

You can connect your device to a Bluetooth printer and print photos or documents saved on the device.

1 On the settings screen, tap **Networks > Share & connect > Printing**.



- If the desired printer is not in the list, install the printer driver from the app store.

2 Tap to activate it.

3 Select a printer from the printer list screen.

- To add a printer, tap **⋮ > Add printer**.
- To search for a printer name, tap **⋮ > Search**.
- Tap **⋮ > Settings** from the printer list screen.

4 Select a file and tap **⋮ > Print**.

- The document prints.



- If you do not have a Google account, tap **ADD ACCOUNT** to create an account.

Tethering


USB tethering

You can connect the device to another device via USB and share mobile data.

- 1 Connect your device and other devices via USB cable.
- 2 On the settings screen, tap **Networks > Tethering > USB tethering** and then tap to activate it.



- This option uses mobile data and may incur data usage fees, depending on your pricing plan. Consult with your service provider for more information.
- When connecting to a computer, download the USB driver from www.lg-mobile.co.il and install it on the computer.
- You cannot send or receive files between your device and a computer while USB tethering is turned on. Turn off USB tethering to send or receive files.
- Operating systems that support tethering are Window XP or higher, or Linux.




Wi-Fi hotspot

You can set the device as a wireless router so that other devices can connect to the Internet by using your device's mobile data.

- 1 On the settings screen, tap **Networks > Tethering > Wi-Fi hotspot** and then tap to activate it.
- 2 Tap **Set up Wi-Fi hotspot**, and enter the Wi-Fi name (SSID) and password.
- 3 Turn on Wi-Fi on the other device, and select the name of the device network on the Wi-Fi list.
- 4 Enter the network password.



- This option uses mobile data and may incur data usage fees, depending on your pricing plan. Consult with your service provider for more information.
- More information is available at this web site:
<http://www.android.com/tether#wifi>



Bluetooth tethering

A Bluetooth-connected device can connect to the Internet by using your device's mobile data.

- 1 On the settings screen, tap **Networks > Tethering > Bluetooth tethering** and then tap to activate it.
- 2 Turn on Bluetooth on both devices and pair them.



- This option uses mobile data and may incur data usage fees, depending on your pricing plan. Consult with your service provider for more information.
- More information is available at this web site:
http://www.android.com/tether#Bluetooth_tethering

Help

You can view help on using tethering and hotspots.

On the settings screen, tap **Networks > Tethering > Help**.

More

Airplane mode

You can turn off the call and mobile data functions. When this mode is on, functions that do not involve data, such as games and music playback, remain available.

- 1 On the settings screen, tap **Networks > More > Airplane mode**.
- 2 Tap **TURN ON** in the confirmation screen.

Mobile networks

You can customise the mobile networks settings.

- 1 On the settings screen, tap **Networks > More > Mobile networks**.
- 2 Customise the following settings:
 - **Network mode:** Select a network type.
 - **Access Point Names:** View or change the access point for using mobile data services. To change the access point, select a choice from the access point list.
 - **Network operators:** Search for network operators and connect automatically to a network.

VPN

You can connect to a safe virtual network, such as an intranet. You can also manage connected virtual private networks.

Adding VPN

- 1 On the settings screen, tap **Networks > More > VPN**.
- 2 Tap **Add VPN**.



- This feature is available only when the screen lock is activated. If the screen lock is deactivated, a notification screen appears. Tap **CHANGE** from the notification screen to activate the screen lock. See [Setting a screen lock](#) for details.

- 3 Enter VPN details and tap **SAVE**.

Configuring VPN settings

- 1 Tap a VPN from the **VPNS** list.
- 2 Enter the VPN user account details and tap **CONNECT**.
 - To save the account details, select the **Save account information** checkbox.

Sound & notification

You can customise sound, vibrate and notification settings.

On the settings screen, tap **Sound & notification** and customise the following settings:

- **Sound profile:** Change the sound mode to **Sound, Vibrate only**, or **Silent**.
- **Volume:** Adjust the sound volume for various items.
- **SIM1 ringtone/SIM2 ringtone:** Select a ringtone for incoming calls. Add or delete ringtones.
- **Ringtone ID:** Create a ringtone for an incoming call from a particular contact.
- **Vibration strength:** Adjust the vibration intensity.
- **Sound with vibration:** Set the device to vibrate and play a ringtone simultaneously.
- **SIM1 vibration type/SIM2 vibration type:** You can select the type of vibration when receiving calls.
- **Do not disturb:** Set the time, range and app type to receive notification messages. Receive notification messages only on particular days of the week.
- **Lock screen:** Display or hide a notification message on the lock screen. You can also hide private information.
- **Apps:** Select the apps that can show their notification messages on the screen, and set the priorities of those apps in regard to notification messages.
- **Hi-Fi Quad DAC:** Connect to the earpiece, speaker or other external audio devices and use any of them as a Hi-Fi Quad DAC.
- **More > SIM1 notification sound/SIM2 notification sound:** Select a notification ringtone. Set music saved on the device as a notification ringtone.

- **More > Vibrate on tap:** Set the device to vibrate when you tap certain items on the screen.
- **More > Sound effects:** Select a sound effect to play when you tap the dialpad or keyboard, select an option, or lock or unlock the screen.

Display

You can customise detailed settings for each screen type.

On the settings screen, tap **Display** and customise the following settings:

- **Home screen:** Customise settings for the Home screen. See *Home screen settings* for details.
- **Lock screen:** Customise lock screen settings. See *Lock screen settings* for details.
- **Theme:** Select a screen theme for your device.
- **Home touch buttons:** Rearrange Home touch buttons or change their background colours.
- **Font type:** Change the font face.
- **Font size:** Change the font size.
- **Bold text:** Bold the text on the screen.
- **App scaling:** Adjust the screen size of apps.
- **Display size:** Set the items on the screen to a size easy for you to see. Some items may change position.
- **Comfort view:** Set the device to reduce amount of blue light on screen to reduce eye strain.
- **Brightness:** Use the slide bar to change the device's screen brightness. To automatically adjust screen brightness according to ambient light intensity, tap the **Auto** switch.
- **Auto:** Set the device so that the screen brightness is automatically adjusted in accordance with the ambient light intensity.
- **Always-on display:** Always display information, such as the date, time and notifications, even when the screen is turned off. For details, see *Always-on Display*.

- **Auto-rotate screen:** Automatically rotate the screen according to the device's orientation.
- **Screen timeout:** Automatically turn off the screen when the device is left idle for a specified period of time.
- **More > KnockON:** Turn the screen on or off by tapping the screen twice.
- **More > Screen saver:** Display a screen saver when the device is connected to the holder or charger. Select a screen saver type to display.
- **More > Mini view:** You can make the screen size smaller to conveniently use the device with one hand. Drag the Home touch button at the bottom of the screen to the left or right.

General

Language & keyboard

You can customise language and keyboard settings for your device.

- 1 On the settings screen, tap **General > Language & keyboard**.
- 2 Customise the following settings:
 - **Language:** Select a language to apply for the device.
 - **Current keyboard:** View the keyboard currently in use. Select a keyboard to use when entering text.
 - **LG Keyboard:** Customise the LG keyboard settings.
 - **Google voice typing:** Configure the options for text dictation by Google.
 - **Text-to-speech output:** Configure the settings for text-to-speech output.
 - **Pointer speed:** Adjust the pointer speed of a mouse or trackpad.
 - **Reverse buttons:** Reverse the right mouse button to perform primary direct-manipulation actions.

Location

You can customise how your location information is used by particular apps.

- 1 On the settings screen, tap **General > Location**.
- 2 Customise the following settings:
 - **Mode**: Select a method to provide your location information.
 - **My place**: Set the device to analyse frequently visited places so that it can automatically recognise a residential address.
 - **RECENT LOCATION REQUEST**: View apps that recently requested location information.
 - **Low power location estimation**: Estimate the device location by using low power consumption.
 - **Google Location History**: Configure the Google location history settings.

Accounts & sync

You can add or manage accounts, including a Google account. You can also sync particular apps or user information automatically.

- 1 On the settings screen, tap **General > Accounts & sync**.
- 2 Customise the following settings:
 - **Auto-sync data**: Sync all the registered accounts automatically.
 - **ACCOUNTS**: View a list of registered accounts. To view or change details of an account, tap the account.
 - **ADD ACCOUNT**: Add accounts.

Cloud

You can register a cloud account and view content saved on cloud from the device.

- 1 On the settings screen, tap **General > Cloud**.
- 2 Customise the settings.

Users


You can add users to share your device with them.

- 1 On the settings screen, tap **General > Users**.
- 2 Customise the settings.

Accessibility


You can manage accessibility plug-ins installed on your device.

- 1 On the settings screen, tap **General > Accessibility**.
- 2 Customise the following settings:
 - **Vision > TalkBack**: Set the device to notify screen status or actions via voice.
 - **Vision > Message/call voice notifications**: Set the device to read the caller information or message content via voice.
 - **Vision > Font size**: Change the font size.
 - **Vision > Bold text**: Bold the text on the screen.
 - **Vision > Display size**: Set the items on the screen to a size easy for you to see. Some items may change position.
 - **Vision > Touch zoom**: Zoom in or out by tapping the screen three times.
 - **Vision > Window zoom**: Zoom in or out within a window and invert the colour.
 - **Vision > Large mouse pointer**: Magnify the mouse pointer.
 - **Vision > High contrast screen**: Turn the background colour into black for a high contrast screen.
 - **Vision > Screen colour inversion**: Increase the display colour contrast for people with low vision.
 - **Vision > Screen colour adjustment**: Adjust the display colour.
 - **Vision > Grayscale**: Switch the screen to grayscale mode.
 - **Vision > End calls with the Power key**: End a call by pressing the Power/Lock key.

- **Hearing > Captions:** Turn on the subtitle service when playing videos for the hearing impaired.
- **Hearing > Flash alerts:** Set the device to notify you with a blinking light for incoming calls, messages and alarms.
- **Hearing > Mute all sounds:** Mute all sounds and lower volume on the receiver.
- **Hearing > Audio channel:** Select the audio type.
- **Hearing > Sound balance:** Adjust the audio output balance. Use the slide bar to change the balance.
- **Motor & cognition > Touch assistant:** Turn on the touch board to make buttons and gestures easier to use.
- **Motor & cognition > Touch input:** Enter text by touching and holding the screen or modify it by simply touching the screen.
- **Motor & cognition > Physical keyboard:** Customise the keyboard settings.
- **Motor & cognition > Auto mouse click:** Automatically click the mouse pointer in case of no movement.
- **Motor & cognition > Touch and hold for calls:** Answer or decline calls by touching and holding the call button instead of dragging it.
- **Motor & cognition > Screen timeout:** Turn off the screen automatically when the device is left idle for a specified period of time.
- **Motor & cognition > Touch control areas:** Limit the touch area so that only a particular portion of the screen can be controlled by touch input.
- **Accessibility features shortcut:** Quickly access a frequently used function by tapping  three times.
- **Auto-rotate screen:** Automatically change the screen orientation according to the physical position of the device.
- **Switch Access:** Create key combinations to control your device.

Shortcut keys

You can use the volume keys to directly launch apps when the screen is turned off or locked.

- 1 On the settings screen, tap **General > Shortcut keys**.
- 2 Tap  to activate it.
 - Press the Volume Down (-) key twice to launch the Camera app when the screen is locked or turned off. Press the Volume Up (+) key twice to launch Capture+.

Google services

You can use Google settings to manage your Google apps and account settings.

On the settings screen, tap **General > Google services**.

Fingerprints & security

- 1 On the settings screen, tap **General > Fingerprints & security**.
- 2 Customise the following settings:
 - **Fingerprints:** Use your fingerprint to unlock the screen or content. See *Fingerprint recognition overview* for details.
 - **Content lock:** Set the method to lock files in the Gallery or QuickMemo+.
 - **Encrypt SD card:** Encrypt the memory card to prevent use on another device. See *Memory card encryption* for details.
 - **Secure start-up:** Protect your device with a lock when it powers on. See *Secure start-up settings* for details.
 - **Set up SIM card lock:** Lock or unlock the USIM card, or change the password (PIN).
 - **Make passwords visible:** Display a password as you enter it.

- **Phone administrators:** Allow privileges to restrict the control or use of the device to particular apps.
- **Unknown sources:** Allow the installation of apps from non-Play Store apps.
- **Credential protection:** View the type of the storage where the security certificate will be saved.
- **Certificate management:** Manage the security certificate saved on the device.
- **Trust agents:** View and use trust agents installed on the device.
- **Screen pin:** Fix the app screen so that only the currently active app can be used.
- **Usage access:** View details on usage of apps on the device.

Smart settings

You can automatically change your device settings according to the usage pattern and location.



- To use Smart settings, make sure to set the residential address. See [Location](#) for details.

- 1 On the settings screen, tap **General > Smart settings**.
- 2 Activate items you want to automatically change settings for.


Date & time

You can customise date and time settings for your device.

- 1 On the settings screen, tap **General > Date & time**.
- 2 Customise the settings.


Storage

You can view and manage internal storage on the device or storage space of the memory card.

- 1 On the settings screen, tap **General > Storage**.
- 2 Customise the following settings:
 - **DEVICE STORAGE:** View the total storage space and free space in the device's internal storage. View a list of apps in use and the storage capacity for each app.
 - **PORTABLE STORAGE:** View the total storage space and free space in the memory card. This option appears only when a memory card is inserted. To unmount the memory card, tap .

Battery & power saving

You can view the current battery information or turn on power-saving mode.

- 1 On the settings screen, tap **General > Battery & power saving**.
- 2 Customise the following settings:
 - **Battery usage:** View the battery usage details. To view more details, select a specific item.
 - **Battery percentage on status bar:** Display the remaining battery level as a percentage on the status bar.
 - **Battery saver:** Reduce battery consumption by cutting down some device settings, such as the display brightness, speed and vibration intensity. The status bar displays  when power-saving mode is on.
 - **Game battery saver:** Adjust the video quality to reduce battery consumption when playing games.

Memory

You can view the average amount of memory usage over a certain period of time and the memory occupied by an app.

- 1 On the settings screen, tap **General > Memory**.
- 2 Tap ▼ to set a time slot to retrieve data.

Smart Doctor

You can use Smart Doctor to diagnose the device's condition and optimise it.

On the settings screen, tap **General > Smart Doctor**.

Apps

You can view a list of installed apps. Stop apps from running or delete apps, if necessary.

- 1 On the settings screen, tap **General > Apps**.
- 2 Select an app and perform actions.

Tap & pay

You can make payments with your device instead of a credit card.

On the settings screen, tap **General > Tap & pay**.

Backup & reset

You can back up data saved on your device to another device or account. Reset the device, if necessary.

- 1 On the settings screen, tap **General > Backup & reset**.
- 2 Customise the following settings:
 - **LG Mobile Switch**: Easily transfer data the saved messages, images, home screens and other data to a new device. See [LG Mobile Switch](#) for details.

- **Backup & restore:** Back up your device data or restore data to your device from a backup.
- **Back up my data:** Back up your app data, Wi-Fi password and other settings to the Google server.
- **Backup account:** View the current backup account in use.
- **Automatic restore:** Automatically restore backup settings and data when reinstalling an app.
- **Network settings reset:** Reset Wi-Fi, Bluetooth and other network settings.
- **Factory data reset:** Reset all settings for the device and delete data.



- Resetting your device deletes all data on it. Enter your device name, Google account and other initial information again.

About phone

You can view information about your device, such as the name, status, software details and legal information.

On the settings screen, tap **General > About phone** and view information.

Regulatory & Safety

You can view regulatory marks and related information on your device.

On the settings screen, tap **General > Regulatory & Safety**.





05

Appendix

LG Language Settings

Select a language to use on your device.

- Tap  > **Settings** > **General** > **Language & keyboard** > **Language** > **ADD LANGUAGE**, and select a language.
 - Touch and hold  and drag it to the top of the language list to set it as a default language.

LG Bridge

LG Bridge overview

LG Bridge is an app that helps you manage the photos, music, videos and documents saved on your LG smartphone from your computer conveniently. You can back up contacts, photos and more to the computer or update the device software.




- See LG Bridge help for details.
- The supported features may vary depending on the device.
- LG USB driver is a necessary program to connect your LG smartphone with the computer and is installed when you install LG Bridge.

LG Bridge functions

- Manage the files on the device from a computer via Wi-Fi connection or mobile data connection.
- Back up data from the device to a computer or restore data from a computer to the device via USB cable connection.
- Update the device software from a computer via USB cable connection.

Installing LG Bridge on a computer

- 1 Go to www.lg-mobile.co.il from your computer.
- 2 Select your region and click .
- 3 In the search bar, enter the name of your device.
- 4 Click **Support > Manuals & Downloads**.
- 5 In the Software & Firmware, Click **PC Sync** and download the setup file.
 - Click **Details** to view the minimum requirements for installing LG Bridge.

Phone software update

LG Mobile phone software update from the Internet

For more information about using this function, please visit <http://www.lg.com/common/index.jsp>, select your country and language.

This feature allows you to conveniently update the firmware on your phone to a newer version from the Internet without needing to visit a service centre. This feature will only be available if and when LG makes a newer firmware version available for your device.

Because the mobile phone firmware update requires the user's full attention for the duration of the update process, please make sure you check all instructions and notes that appear at each step before proceeding. Please note that removing the USB cable during the upgrade may seriously damage your mobile phone.



- LG reserves the right to make firmware updates available only for selected models at its own discretion and does not guarantee the availability of the newer version of the firmware for all handset models.

LG Mobile Phone software update via Over-the-Air (OTA)

This feature allows you to conveniently update your phone's software to a newer version via OTA, without connecting a USB cable. This feature will only be available if and when LG makes a newer firmware version available for your device.

To perform the phone software update,

Settings > General > About phone > Common > Update centre > Software Update > Check now for update.



- Your personal data from internal phone storage—including information about your Google account and any other accounts, your system/application data and settings, any downloaded applications and your DRM licence—might be lost in the process of updating your phone's software. Therefore, LG recommends that you backup your personal data before updating your phone's software. LG does not take responsibility for any loss of personal data.
- This feature depends on the area or service provider.

Anti-Theft Guide

Set up your device to prevent other people from using it if it's been reset to factory settings without your permission. For example, if your device is lost, stolen, or wiped, only someone with your Google account or screen lock information can use the device.

All you need to make sure your device is protected is:

- Set a screen lock: If your device is lost or stolen but you have a screen lock set, the device can't be erased using the Settings menu unless your screen is unlocked.
- Add your Google account on your device: If your device is wiped but you have your Google account on it, the device can't finish the setup process until your Google account information is entered again.

After your device is protected, you'll need to either unlock your screen or enter your Google account password if you need to do a factory reset. This ensures that you or someone you trust is doing the reset.



- Do not forget your Google account and password you had added to your device prior to performing a factory reset. If you can't provide the account information during the setup process, you won't be able to use the device at all after performing the factory reset.

Open Source Software Notice Information

To obtain the source code under GPL, LGPL, MPL, and other open source licenses, that is contained in this product, please visit <http://opensource.lge.com>.

In addition to the source code, all referred license terms, warranty disclaimers and copyright notices are available for download.

LG Electronics will also provide open source code to you on CD-ROM for a charge covering the cost of performing such distribution (such as the cost of media, shipping, and handling) upon email request to opensource@lge.com. This offer is valid for three (3) years from the date on which you purchased the product.

Regulatory information (Regulation ID number, E-labeling, etc.)

For regulatory details, go to **Settings > General > Regulatory & Safety**.

Trademarks

- Copyright ©2017 LG Electronics, Inc. All rights reserved. LG and the LG logo are registered trademarks of LG Group and its related entities.
- Google™, Google Maps™, Gmail™, YouTube™, Duo™ and Google Play™ store are trademarks of Google, Inc.
- Bluetooth® is a registered trademark of Bluetooth SIG, Inc. worldwide.
- Wi-Fi® and the Wi-Fi logo are registered trademarks of the Wi-Fi Alliance.
- All other trademarks and copyrights are the property of their respective owners.

DECLARATION OF CONFORMITY

Hereby, **LG Electronics** declares that this **LG-H870DSU** product is in compliance with the essential requirements and other relevant provisions of Directive **2014/53/EU**.

A copy of the Declaration of Conformity can be found at <http://www.lg.com/global/declaration>

More information

DOLBY AUDIO



Manufactured under license from Dolby Laboratories. Dolby, Dolby Audio, and the double-D symbol are trademarks of Dolby Laboratories.

DOLBY VISION



Dolby, Dolby Vision, and the double-D symbol are trademarks of Dolby Laboratories. Manufactured under license from Dolby Laboratories. Confidential unpublished works. Copyright © 2013-2015 Dolby Laboratories. All rights reserved.

Dolby Vision supports 4 modes for the best experience.

- **Cinematic:** Stays closest to cinema, best in dark environments.
- **Bright:** Offers the best video quality in brighter environments.
- **Standard:** Balances power saving and video quality.
- **Vivid:** Boosts brightness and colours for a bolder picture.

Tempered glass parts

Tempered glass parts of this device are not permanent and they may wear out over time.

- If you drop your device on a hard surface or subject it to severe impact, the tempered glass may be damaged.

If this happens, stop using your device immediately and contact an LG Customer Service Centre.

- You can purchase protective cases to protect your device from damage on the market.

Note that these protective cases are not covered under the warranty service provided by LG Electronics and safety is not guaranteed.

Aspect ratio


This device uses 18:9 aspect ratio.

- Some downloaded apps may not support 18:9 aspect ratio.

In this case, select the most optimal screen ratio for the app or consult the app provider for more information.

FAQ

This chapter lists some problems you might encounter when using your phone. Some problems require you to call your service provider, but most are easy to fix yourself.

Message	Possible causes	Possible corrective measures
SIM card error	There is no SIM card in the phone or it is inserted incorrectly.	Make sure the SIM card is correctly inserted.
No network connection/ Dropped network	Signal is weak or you are outside the carrier network.	Move toward a window or into an open area. Check the network operator coverage map.
No applications can be set	Not supported by service provider or registration required.	Contact your service provider.
Downloaded application causes a lot of errors.	Application has problems.	1. Tap  > Settings . 2. Tap General > Apps . 3. Tap the app > Uninstall .
Calls not available	Dialling error	New network not authorised.
	New SIM card inserted.	Check for new restrictions.
Device cannot be turned on	Battery is not charged.	Charge battery. Check the charging indicator on the display.

Message	Possible causes	Possible corrective measures
Charging error	Battery is not charged.	Charge battery.
	Outside temperature is too hot or cold.	Make sure device is charging at a normal temperature.
	Contact problem	Check the charger and its connection to the device.
	No voltage	Plug the charger into a different outlet.
	Charger defective	Replace the charger.
	Wrong charger	Use only original LG accessories.
Number not allowed.	The Fixed dialling number function is on.	Check the Settings menu and turn the function off.
Files do not open	Unsupported file format	Check the supported file formats.
The screen does not turn on when I receive a call.	Proximity sensor problem	If you use a protection tape or case, make sure it has not covered the area around the proximity sensor. Make sure that the area around the proximity sensor is clean.
No sound	Vibration mode	Check the settings status in the sound menu to make sure you are not in vibration or no interruptions mode.

Message	Possible causes	Possible corrective measures
Hangs up or freezes	Intermittent software/hardware problem	<p>Restarting the device</p> <p>If your device freezes or hangs, you may need to close apps or turn off the device and turn it on again.</p>
		<p>Performing a boot-up</p> <p>Press and hold the Power/Lock key and the Volume Down (-) key for about 10 seconds to restart your device.</p>
		<p>Resetting the device</p> <p>If the methods above do not solve your problem, perform a factory data reset.</p> <p>On the settings screen, tap General > Backup & reset > Factory data reset.</p> <p>*Reset all settings for the device and delete data. Before performing the factory data reset, remember to make backup copies of all important data stored in the device.</p> <p>*If you registered a Google account to the device, you must sign in to the same Google account after resetting the device.</p>



CE