



تحذير من أجل السلامة

يجب فصل هذا الجهاز عن مخرج التيار الكهربائي الرئيسي أثناء عدم استخدامه. لا تسمح لهذا الجهاز بالتعرض للأمطار أو الرطوبة.

تحذير

من أجل منع وقوع الصدمة الكهربائية، لا تسحب عنه الغطاء. لا يوجد في الداخل أجزاء للاستخدام. التصليح يجب أن يقوم به الشخص المختص.

تحذيرات للوقاية

اقرأ هذه التعليمات قبل تشغيل الجهاز

- تجنب درجات الحرارة أو البرودة العالية والرطوبة والغبار.
- تجنب الاستخدام قريباً من حقل مغناطيسي (سيؤثر سلباً على إنجاز الجهاز).
- حاذر عند مسح الغطاء بمادة متطايرة كالبينزين والكحول إلخ أو قطعة قماش معالجة بمواد كيميائية. ربما يؤدي ذلك إلى إتلاف سطح الغطاء أو تقشير الطلاء.
- استخدم هذا الجهاز فقط بوضع أفقي ولا تضع فوقه أي شيء ثقيل.
- حافظ على وضع الجهاز بعيداً عن أحواض الزهور وأنباب الماء وحوض الغسيل، إذا سقط عليه أي مادة سائلة فقد يحدث تلف كبير للجهاز. في مثل هذه الحالة قم بعرضه على خبير فني متخصص.
- لا تحجز منطقة التهوية، ثقب التهوية تمنع زيادة السخونة. وحتى المواد الخفيفة أو الناعمة كالورق أو القماش قد تسد ثقب التهوية.
- لا يوجد أجزاء للاستخدام من الداخل. من أجل الإصلاح والصيانة اعرضه على الفني المتخصص.

SAFETY PRECAUTION

THIS EQUIPMENT MUST BE DISCONNECTED FROM THE MAINS POWER SUPPLY WHEN IT IS NOT IN USE. DO NOT ALLOW THIS UNIT TO BE EXPOSED TO RAIN OR MOISTURE.

CAUTION

TO PREVENT ELECTRIC SHOCK, DO NOT REMOVE THE COVER. NO USER SERVICEABLE PARTS ARE INSIDE. REFER SERVICING TO QUALIFIED PERSONNEL.

PRECAUTIONS

Please read these precautions before you operate this unit.

- Avoid extreme heat, cold, moisture and dust.
- Avoid using near a magnetic field. (This will adversely affect the units performance.)
- Be careful when the surface of the case is wiped with a volatile agent such as benzene, alcohol, thinner, etc. or a chemically processed cloth, the surface finish may deteriorate or its coating may peel.
- Use the unit only in a horizontal position, and do not place anything heavy on it.
- Keep the unit away from flower vases, tubs, sinks, etc. If any liquids should spill into unit, serious damage could occur. In that case, please consult qualified service personnel.
- Do not obstruct the ventilation holes: they prevent overheating. Even soft materials such as paper and cloth may prevent proper ventilation of the unit.
- **There are no serviceable parts inside. For service, please contact your service centre.**

ENGLISH

Specification

Power requirements

- Refer to the main label.
- Built-in rechargeable battery

Power consumption

- Refer to the main label.
- Dimensions (W x H x D): Approx. 310 mm x 700 mm x 316 mm
- Bus Power Supply (USB): 5 V $\overline{\text{---}}$ 500 mA
- Amplifier (Total RMS Output power): 250 W RMS
- Operating Temperature: 5 °C - 35 °C
- Operating Humidity: 5 % - 80 % RH
- Ingress Protection: IPX4

- Liquid: Protected against splashing water.

Battery Life: Approx. 20 hours

- Operation time may vary depending on the battery or operation status.

- This unit contains magnets which can be harmful to some kind of object (Ex: Magnetic card, Pacemaker etc).
- Internal lithium battery in the unit should not be replaced by user because of danger of explosion if battery is incorrectly replaced, and must be replaced with the same type battery by expert.

- Do not leave the unit on an unstable place such as high shelves. It may fall down because of the vibration of the sound.

CAUTION when using this product in environments of low humidity.

- It may cause static electricity in environments of low humidity.
- It is recommended to use this product after touching any metal object which conducts electricity.

For models using water-resistant products

When charged, the water-resistant function is limited, so use it in a place that is not exposed to water.

IMPORTANT SAFETY NOTICE

The cord grip for the plug fitted to this product is built into the existing power cord as supplied. If, for any reason you need to shorten the cord.

DO NOT RE-USE THE PLUG.

A new plug must be used to ensure your continued safety by securing the plug to the power cord in accordance with Plug & Socket Regulations 1994.

العربية

المواصفة

متطلبات الطاقة

- ارجع إلى الملصق الرئيسي.
- بطارية مدمجة قابلة لإعادة الشحن

استهلاك الطاقة

- ارجع إلى الملصق الرئيسي.
- الأبعاد (العرض x الارتفاع x العمق): تقريباً ٣١٠ مم x ٧٠٠ مم x ٣١٦ مم
- مصدر طاقة الناقل (USB): ٥ فولت $\overline{\text{---}}$ ٥٠٠ مللي أمبير
- مضخم الصوت (إجمالي طاقة خرج RMS): ٢٥٠ واط RMS
- درجة الحرارة المناسبة للتشغيل: ٥ درجات مئوية إلى ٣٥ درجة مئوية
- درجة الرطوبة المناسبة للتشغيل: من ٥ % إلى ٨٠ % رطوبة نسبية
- الحماية من الدخول: IPX4

- السوائل: الحماية ضد الرش بالماء.

عمر البطارية: تقريباً ٢٠ ساعات

- قد يختلف زمن التشغيل حسب البطارية أو حالة التشغيل.

- تحتوي هذه الوحدة على مغناطيس قد يُسبب ضرر لبعض أنواع الأشياء (مثل: البطاقات المغنطة، منظم ضربات القلب، إلخ).

- يمنع استبدال بطارية الليثيوم الداخلية في الوحدة من قبل المستخدم نظراً لإمكانية تعرض البطارية إلى خطر الانفجار إذا تم استبدالها على نحو خاطئ ويجب استبدالها بنفس نوع البطارية من قبل شخص متخصص.

- لا تترك الوحدة في مكان غير مستقر مثل الأرفف العالية. قد تسقط بسبب اهتزاز الصوت.

تنبيه عند استخدام هذا المنتج في البيئات المنخفضة الرطوبة.

- قد يُسبب تولد كهرباء ساكنة في البيئات ذات الرطوبة المنخفضة.
- يوصى باستخدام هذا المنتج بعد لمس أي جسم معدني موصل للكهرباء.

للطرازات التي تستخدم منتجات مقاومة للماء

أثناء الشحن، تكون وظيفة مقاومة الماء محدودة، ومن ثم، استخدمها في مكان لا يتغلغل إليه الماء.

ملاحظة سلامة هامة

كلابة الوصلة للقابس مزودة مع هذا المنتج وتم تثبيتها داخل الوصلة الكهربائية الموجودة التي تم تزويدها ، إذا كان لأي سبب

احتجت لتقصير الوصلة.

لا تستعمل مرة أخرى هذا القابس يجب استعمال قابس جديد للتأكيد على سلامتك بصورة متواصلة وذلك عن طريق إحكام إدخال القابس إلى الوصلة الكهربائية طبقاً للوائح القابس والمقبس للعام 1994.

ENGLISH Installing and Using the Product

Please read this manual carefully before operating your set and retain it for future reference. To view the instructions of advanced features, visit <http://www.lg.com> or scan QR code and then download Owner's Manual. Some of the content in this manual may differ from your product.



- A Handle
- B Controls
- C Flash Lighting
- D Speaker (Tweeter)
- E Dot Animation
- F Speaker (Woofer) / Woofer Lighting
- G Attaching the ferrite core (optional)
 - Wind the power cord cable twice around the ferrite core.

1 Connect the power cord to the product by opening the rear cover and charge it before use

2 Connecting the Speaker to a Smartphone via Bluetooth

- Press the **Power** (A) button to turn on the product.
- Press the **Function** (B) button on the product repeatedly to select the BT function. The BT LED blinks.
- Tap the **Settings** (C) button on your smartphone and select **Bluetooth**. Turn on the **Bluetooth** function. (Off > On)
- From the list of smartphone devices, find and tap on "LG-XL7S(XX)".
- Once the smartphone is connected to the product via **Bluetooth**, the BT LED will turn on. Play a desired track in the music app on your smartphone.

3 Playing Music from the USB

- Open the back cover of the product and plug the USB storage device into the USB terminal.
- Press the **Power** (A) button to turn on the product.
- Press the **Function** (B) button on the product repeatedly to select the USB function. The USB LED will turn on.
- Press the **Play/Pause** (D) button to enjoy the music.

4 Connecting to the LG XBOOM App

- Find the **LG XBOOM app** on the Google Play or App Store and install it on your smartphone.
- Run the **LG XBOOM app** and use its functions. (EQ, Wireless Party Link, Dot Animation, Lighting, Setting etc.)

5 Power Saving

If there is no playback or button input for 15 minutes, the product turns off automatically. On the **LG XBOOM app**, you can enable or disable [Auto Power Management].

- ⚠ This product has wheels and a handle so you can easily move the product. Press the lock button on the handle and then pull the handle up. Release the lock button to lock the handle in place.

- Design and specifications are subject to change without notice.

العربية تركيب المنتج واستخدامه



- A المقبض
- B أجهزة التحكم
- C إضاءة فلاش
- D مكبر الصوت (تويتر)
- E دوت أنيميشن
- F مكبر الصوت (مضخم الصوت) / إضاءة مضخم الصوت
- G تركيب الحلقة الحديدية (اختياري)
 - قم بلف كابل سلك الطاقة مرتين حول الحلقة الحديدية.

1 وصل سلك الطاقة بالمنتج عبر فتح الغطاء الخلفي وشحنه قبل الاستخدام

2 توصيل مكبر الصوت بهاتف ذكي عبر Bluetooth

- انقر على زر الطاقة (A) لتشغيل المنتج.
- اضغط على زر الوظيفة (B) في المنتج بشكل متكرر لتحديد وظيفة البلوتوث. يومض مؤشر LED الخاص بالبلوتوث.
- انقر على زر الإعدادات (C) في هاتفك الذكي وحدد **Bluetooth**. شغل وظيفة **Bluetooth**. (إيقاف تشغيل < تشغيل)
- من قائمة أجهزة الهاتف الذكي، ابحث وانقر على «LG-XL7S(XX)».
- بمجرد توصيل الهاتف الذكي بالمنتج عبر **Bluetooth**، سيتم تشغيل مؤشر LED الخاص بـ BT. قم بتشغيل المسار المطلوب في تطبيق الموسيقى على هاتفك الذكي.

3 تشغيل الموسيقى من USB

- افتح الغطاء الخلفي للمنتج وقم بتوصيل جهاز تخزين USB بطرف USB.
- انقر على زر الطاقة (A) لتشغيل المنتج.
- انقر على زر الوظيفة (B) في المنتج بشكل متكرر لتحديد وظيفة USB. سيومض مؤشر LED الخاص بـ USB.
- انقر على زر التشغيل/الإيقاف المؤقت (D) للاستمتاع بالموسيقى.

4 الاتصال بتطبيق LG XBOOM

- ابحث عن تطبيق **LG XBOOM** على Google Play أو App Store وقم بتثبيته على هاتفك الذكي.
- شغل تطبيق **LG XBOOM** واستخدم وظائفه. (موازن الصوت، ارتباط الطرف اللاسلكي، دوت أنيميشن، الإضاءة، الإعداد، إلخ).

5 حفظ الطاقة

إذا لم يكن هناك تشغيل أو إدخال زر لمدة ١٥ دقيقة، يتم إيقاف تشغيل المنتج تلقائياً. في تطبيق **LG XBOOM**، يمكنك تمكين أو تعطيل [Auto Power Management].

- ⚠ يحتوي هذا المنتج على عجلات ومقبض حتى تتمكن من تحريك المنتج بسهولة. اضغط على زر القفل الموجود على المقبض ثم اسحب المقبض لأعلى. حرر زر القفل لقفل المقبض في مكانه.

- يخضع التصميم والمواصفات للتغيير دون إشعار مسبق.

