LG CordZero™

USER'S MANUAL
A9

Make sure to read the "Safety Cautions" carefully before starting to use this product.
Please keep this User's Manual within easy reach of the user.

MFL69883609

www.lg.com

Copyright © 2018 LG Electronics Inc. All Rights Reserved.

MFL69883609_en_180115.indd 2 2018-01-15 오후 5:13:37

TABLE OF CONTENTS

This User's Manual may contain images or contents that differ slightly to the purchased product.

SAFETY CAUTIONS 04

PACKAGE INFORMATION 10

INSTALLATION 11

Installing the standing charging station 11

Installing the wall-mount station 12

Storage of the combination tool and crevice tool 12

HOW TO USE 13

Note about using the product 13

Using the Product 13

Charging the Product 14

Power / Suction Strength button 14

Using the nozzles 15

MAINTENANCE 16

Cleaning the Dustbin 16

Cleaning the Filters 16

Cleaning the Power Drive Floor/Carpet Nozzle 18

Cleaning the Bedding Power Punch 18

POINTS TO CHECK BEFORE CONTACTING CUSTOMER SERVICE. 19

DISPOSAL INFORMATION 20

Disposal of old products not related with the purchase of a new product 20

PRODUCT SPECIFICATIONS 20

MFL69883609_en_180115.indd 3 2018-01-15 오후 5:13:37

SAFETY PRECAUTIONS

The following cautions are intended to protect you from unexpected risk or property loss by ensuring safe and correct usage of the product.

⚠	**Pictograms are designed to draw attention to matters and uses that may pose a risk to the user. Make sure to carefully read any item marked with this symbol and comply with it to prevent any risk.**
⚠WARNING	**Failure to comply with this warning may result in serious damage, injury or even death to the user.**
⚠CAUTION	**Failure to comply with this warning may result in damage to the product or moderate injury to the user.**

⚠ WARNING

1. This appliance is not intended for use by persons (including children) with reduced physical, sensory or mental capabilities, or lack of experience and knowledge, unless they have been given supervision or instruction concerning use of the appliance by a person responsible for their safety.
2. Children should be supervised to ensure that they do not play with the appliance.
3. If the supply cord is damaged, it must be replaced by an LG Electronics Service Agent in order to avoid a potential hazard.
4. This appliance can be used by children aged 8 years and above and persons with reduced physical, sensory or mental capabilities or lack of experience and knowledge if they have been given supervision or instruction concerning use of the appliance in a safe way and understand the hazards involved. Children shall not play with the appliance.
   Cleaning and user maintenance must not be performed by children without supervision.

MFL69883609_en_180115.indd 4 2018-01-15 오후 5:13:37

Installation and Usage

Do not install the product where it may be exposed to water, rainfall or severe moisture. Do not use the product in any outdoor location, workshop or garage environment.

- Such conditions will leave the product vulnerable to fire when charging the battery.
- Please install the product in a well-ventilated place.

Make sure to avoid places where there is a risk of leakage of flammable gas, industrial oil or metallic dust.

- It may cause product malfunction or damage.

If you intend to use the charging station by "standing" it vertically (standing type), make sure to secure it to the wall with the appropriate type of screws .

- Otherwise, the charging station or product may slant and become damaged or cause property damage or injury.

Please place the charging station on an even surface.

- Otherwise, the product may fall and sustain damage or cause an injury.

If you intend to mount the charging station on a wall (wall-mounted type), make sure to secure it tightly to the wall using the appropriate type of screws.

- Failure to do so may damage the product and/or cause an injury.

Never install the charging station on a wall with any piping (power, water) or power cables behind it.

- There is a risk of injury from electric shock, fire or flooding

Power requirements

This product should only be used with AC 230 V. Make sure to check the power specifications of the place where you intend to use the product.

- The wrong specifications will result in electric shock or damage the product in the event of a short-circuit.

Do not apply excessive force to the power cord to bend it, or place it under a heavy object as this will damage it.

- The power cord may get damaged and cause electric shock or injury.

Please refrain from using multiple power appliances in one power board or power socket and make sure to use a power socket with a capacity of 10A.

- Failure to do so may result in fire due to abnormal overheating of the socket.
- Or it may activate the circuit breaker leading to a loss of power.

Never touch the power cord and plug with a wet hand.

- This may result in injury or electric shock.

Please clear any dust or water from the power cord and plug with a dry cloth.

- Failure to do so may result in electric shock, short circuit or fire.

When unplugging the power cord, never pull the cord itself and always hold the power plug.

- Failure to do so will damage the cord it and may result in electric shock or fire.

Stop using the product and contact the customer service department of LG Electronics if the power cord or power plug is damaged or the holes of the power outlet socket are loose.

- Failure to do so may result in electric shock or fire.

Make sure to unplug the power cord when cleaning or maintaining the charging station.

- Failure to do so may result in injury or electric shock.

Make sure to unplug the power cord when the product is not to be used for an extended period of time.

- Failure to do so may result in electric shock, short circuit or fire.

Make sure to organize the power cord of the charging station while using or cleaning the product.

- Otherwise, the cord may get tangled with the product and result in malfunction, electric shock or injury if its disconnected or broken.

Avoid touching the pins of the power plug with your finger(s) when unplugging the power cord.

- Failure to do so may result in electric shock or fire.

MFL69883609_en_180115.indd 5 2018-01-15 오후 5:13:37

Proper usage

Make sure that no child is allowed to use the product.

- The product is too heavy for a child to handle properly.

Make sure that no hand, foot, hair or clothes gets stuck in the rotating brush or wheel while using or cleaning the product.

- Failure to do so may damage the product or result in injury.

No one other than a qualified technician/service engineer from LG Electronics may disassemble, repair or modify the product.

- Do not attempt to disassemble or repair the product yourself as it may result in electric shock, injury or fire.

Never use the battery and the charging station with other appliances other than this product.

- It may cause a product malfunction or fire.

Do not use the battery of another appliance in the product.

- It may cause malfunctioning or fire.

Do not arbitrarily disassemble, remove or short-circuit the battery.

- It may result in electric shock, injury or fire.

Do not apply heat or shock to the battery.

- It may cause electric shock, injury or fire.

Never insert a sharp metallic object such as a pin, nail or knife in a hole or gap in the product or the charging station.

- Otherwise, you may get injured or suffer electric shock.

Do not vacuum liquids with this product. Make sure that no water, beverage or detergent gets inside the product or the charging station.

- Failure to do so may result in injury or electric shock.

Do not apply or spray a flammable substance (gasoline or thinner) or surface active agent (detergent or bath soap) on the product.

- It may result in malfunction or fire.

In the event of a gas leakage (propane or urban gas), make sure to ventilate the area first without coming into contact with the product or its power plug.

- Otherwise, there may be sparks which may result in an explosion, fire or injury.

Do not use or store a heating device or flammable substance(ether, benzene, alcohol, chemicals, combustible spray, insecticide, air freshener or cosmetics) in close proximity to the product.

- It may result in product malfunction or fire.

Do not attempt to clean up a liquid substance (water, beverage), Odorous substances (candy, chocolate, pet feces, etc.), metallic objects (such as blade, pins), flammable substances, surface active agents, or glass shards with this product.

- It may result in product malfunction or fire.
- In the event that any liquid, metallic object, glass shard or spark gets inside the product, immediately turn off the product and contact the customer service department of LG Electronics.

Do not use the product with the exhaust or inlet port blocked.

- It will cause the product to overheat and result in malfunction or fire.

In the event that smoke is emitted by the product while it is charging, immediately unplug the power cord and contact the customer service department of LG Electronics.

- Failure to do so may cause electric shock or fire.

Do not expose the product, and the battery in particular, to heat, a heating device or direct sunlight.

- It may result in electric shock, explosion or fire.

Do not keep the product or its battery inside a vehicle which is exposed to direct sunlight.

- It may cause fire or explosion.

In the event that some kind of liquid leaks from the battery, make sure that it does not contact the skin or eyes.

- It may burn the skin or severely damage the eyes.
- If liquid from the battery comes into contact with part of the skin, immediately wash it off with plenty of water and seek medical advice.

Do not wash the inlet port with water or detergent.

- As the inlet port contains a motor, it may result in electric shock or fire.

Always use the charging station provided with the product to charge the product and its battery.

- Using any charging device other than the provided station will damage the battery and result in electric shock, explosion or fire.

MFL69883609_en_180115.indd 6 2018-01-15 오후 5:13:37

Never allow any water, beverage or detergent to get inside the battery.

- It may cause electric shock, explosion or fire.

Do not touch the charging terminals on the product or the charging station, or insert an electrified object inside the product or the station.

- Otherwise, you may get injured or suffer electric shock.

Always leave the product on the charging station when it is not in use.

- Otherwise, the product may fall and get damaged or cause injury.

In the event that the earth leakage breaker gets activated while the product is placed on the charging station, immediately remove the product from the station and contact the customer service department of LG Electronics.

- Failure to do so may cause electric shock or fire.

Do not wash the dust bin with water.

- The water will get into the motor and cause electric shock or fire.

Do not attempt to vacuum fine dust such as cement with the product.

- It may cause product malfunction or fire.

Make sure that no child can play with the product, charging station or battery.

- It may damage the product and cause an injury.
- If a child places the product or battery into its mouth, it will cause electric shock or injury, or damage the product or battery.

When using the product, remove the wire or string from the bottom.

- Straps or wires may wrap around the product and cause a product malfunction or a broken cord.

Disposal

Discard the packing materials (plastic vinyl, styrofoam) properly so that no child comes into contact with them.

- Such materials may cause a child to suffocate.

When disposing of the product, make sure to remove the battery from the product's body.

- Failure to do so may result in fire or explosion.

MFL69883609_en_180115.indd 7 2018-01-15 오후 5:13:37

⚠ CAUTION

Proper usage

Do not apply impact to the product or drop it from a height.

- It may damage the product and/or result in injury.

Make sure that the product does not fall.

- It may cause injury or damage the product.

Make sure that the filter is installed in the product prior to each use.

- Failure to install a filter may result in product malfunction.

Make sure to wipe up any liquid such as water or oil or pet excrement from the floor before using the product.

- Such substances will cause the unit to malfunction or cause irreparable damage

Do not clean the product with a volatile or organic solvent (thinner or acetone).

- It may damage the product.
- Always use a soft cloth to clean the product.

Make sure to avoid running into a person or a pet while using the product.

- It may cause injury.

Do not kick the product.

- It may cause the product to malfunction.

Do not put any object other than the product, especially a metallic or magnetic object, on the charging station.

- It may damage the product or cause electric shock.

Do not clean the same spot repeatedly for an extended period of time.

- Vibration from the inlet port may damage the floor or the carpet.

Make sure that your finger does not get stuck when assembling the product or the charging station.

- It may injure your finger.

Do not let a child or a pet hang onto the charging station.

- It may cause injury or damage the product.

Do not put double-sided tape directly onto the wallpaper as it may be torn by external force.

- Anchor the charging station with the wall anchoring screw(s) to prevent tearing of the wallpaper.


Do not apply force or impact to the filter parts or dust bin parts.

- The parts may become deformed, compromise the performance or cause the unit to malfunction.


MFL69883609_en_180115.indd 8 2018-01-15 오후 5:13:37

PACKAGE INFORMATION

Standing type




Wall-mount type




1. Product body
2. Extension pipe
3. Power Drive Carpet Nozzle
4. Charging station
5. Charging station pipe
6. Combination tool and crevice tool holder
7. Charging station support
8. Adaptor
9. Battery

Body parts


- Parts and accessories may vary depending on the model that you have purchased.




Product body



Extension pipe



Power Drive Floor Nozzle




Charging station




Adaptor



Battery



Crevice Tool



Combination Tool



Wall Anchoring Block



Double-sided tape (2)



Screw Anchor (2)



Anchoring screw for wall-mount type (Φ 3.5 mm, length 50 mm)(2)



Anchoring screw for standing type (Φ 3.5 mm, length 90 mm)




Pre-Filter

- Please note that these parts come with their corresponding models only.



Battery




Power Drive Carpet Nozzle



Bedding Power Punch

Charging station pipe




Charging station support

MFL69883609_en_180115.indd 9 2018-01-15 오후 5:13:38

Installing the floor standing charging station

1 Put the bottom of the charging station onto the floor and assemble the pipe first, followed by the upper body mount.




⚠ CAUTION

- Avoid getting your fingers stuck in any gap.


2 Connect the power adapter to the port on the back of the charging station and plug the power cord into the power outlet.

- The cord can be secured tidily by putting it through the power cord anchoring ring located on the back of the charging station pipe.




3 After ensuring there are no pipes or wires insider behind the wall, make a hole at the appropriate height to anchor the charging station and insert the screw anchor.

- Recommended diameter of hole: Φ6.5; Recommended depth: 50~100 mm.



4 Put the anchoring block on the back of the charging station and anchor the charging station with the screw.


- Make sure to fully tighten the screw.




When using double-sided tape (do not use if the wall is wallpapered)

1 Use double-sided tape to attach the wall anchoring block to the charging station in step 4.

- Be sure to remove the center part of the double-sided tape before mounting it.



2 Use the remaining part of the tape to anchor the station to the wall before inserting the screw.



MFL69883609_en_180115.indd 10 2018-01-15 오후 5:13:39

⚠ CAUTION

- Avoid dropping the product and parts when taking them out of the package. It may damage the product and/or cause personal injury.
- Do not use double-sided tape to anchor the charging station on papered walls. Please use the provided screws as otherwise the wall paper will get torn by movement of the charging station during the docking of the unit.
- We recommend anchoring the station with the anchoring screw.

Please note


- The charging station, its pipe and support cannot be disassembled separately once they have been assembled, and the charging station has been attached to the wall.
- The charging station can be removed as needed. After unscrewing it from the wall, pull the station upward whilst the bottom of the station remains upright on the floor.
- Use the anchoring screws only when the wall is made of concrete or is solid enough.

Installing the wall-mount station

1 Connect the power adapter to the port on the back of the charging station and plug the power cord into the power outlet.

2 Make a hole 1 meter from the floor to insert the wall plug or screw anchor.
   - Recommended diameter of hole: Φ6.5; Recommended depth: 60 mm.

3 Anchor the station to the wall with the provided anchoring screws.




Please note

- A service request to change the installation location of the charging station will incur additional costs if required to do so by a qualified installer.


Storage of the combination tool and crevice tool

Keep the combination tool and crevice tool on the charging station for easy access.

1 Attach the combination tool and crevice tool to the dedicated holders.



2 Press and hold the inlet removal button and pull downward to remove the combination tool or crevice tool.



MFL69883609_en_180115.indd 11 2018-01-15 오후 5:13:39


Note about using the product

Points to be aware of when using the product

- Make sure that the dustbin lid is on prior to using the product. Otherwise, the suction strength will deteriorate and cleaning will not be satisfactory.
- Support the bottom of the product when cleaning an elevated surface.
- When leaving the product unattended or unused for an extended period, make sure to place it properly on the charging station or lie it on the floor. Otherwise, the product may fall and get damaged or cause an injury.
- Make sure that the exhaust filter is properly assembled before using the product.
- Environmental conditions such as temperature and humidity may cause static to accumulate on the product. Please contact the customer service department of LG Electronics if the problem persists.
- Any foreign object on the inlet port or extension pipe will prevent the product from functioning properly. Make sure to remove any foreign object such as a sock or stocking before using the product.
- The battery runtime will be shortened after using the product repeatedly for an extended period due to its characteristics.
- When the battery is about to become fully run down during use, the last block on the battery indicator will start to flash and the product will power off after a while. Fully charge the battery in this case.
- Please use the product at normal room temperatures as the battery runtime will deteriorate severely if used at temperatures lower than 5℃ or higher than 38℃ for an extended period of time.
- Refer to Product specifications for battery run time details.
- These times are a guide only and may be less depending on the surface type.


Using the Product

1 Assemble the body, extension pipe, inlet port, and battery in that order.




2 Press the button on the extension pipe to adjust its length.

- The pipe has 4 extendable length positions



3 Attach the accessory tool to the body or the extension pipe.




⚠ CAUTION

- Prolonged use of the product with the accessory tool attached may overburden the motor.
- Using the inlet port to clean a TV, monitor or LCD display may scratch the screen.
- Exercise caution to avoid getting your finger stuck in any gap when assembling the attachments.
- If any foreign object is sucked into the inlet during cleaning, operation of the vacuum cleaner might stop in order to prevent damage to the body or motor. Immediately stop using the vacuum cleaner and remove the object before resuming cleaning.


MFL69883609_en_180115.indd 12 2018-01-15 오후 5:13:40

Charging the Product

1 Put the product on the charging station.
- The battery indicator will start to flash and charging will proceed in 3 steps.



2 The battery indicator starts to flash and charging will start.
- All of the indicators will stay on when the battery is fully charged.




⚠ CAUTION
- Make sure to securely fit the unit on to the charging station. Otherwise, the product may fall and get damaged.


Please note
- The battery will not be charged if the ambient temperature is below 5°C. only charge the battery when ambient temperatures are between 5° and 38° C.
- The battery indicator will flash if the product is fully charged, removed from the station, and charged again soon. The flashing stops soon, and the indicator stays on.

Charging the auxiliary battery

1 Hold the product and pull the battery by pressing both ends of the battery.




2 Insert the battery into the auxiliary charging station.



Please note
- Make sure that the power adapter is connected to both the charging station and the power outlet
- If the main battery is charging on the charging station, the auxiliary battery will only start charging once the main battery is fully charged.
- The auxiliary battery indicator flashes when charging starts.
- The indicator will stay on when the auxiliary battery is fully charged.
- Fully charging a single battery usually takes 4 hours, but it will take twice as long if you charge it along with a discharged auxiliary battery.

Power / Suction Strength button

You can adjust the suction strength with the suction strength button located on the handle.



1 Power On/Off button
- Press the power On/Off button to activate the Normal mode.

2 Mode button
- Press "+" once to activate the Power mode.
- Press and hold "+" for more than 3 seconds to activate the Turbo mode.
- The unit will take a moment to switch to the Turbo mode from the Normal mode when the "+" button is held down.
- Press "-" to switch from Turbo to Power, or from Power to Normal.

MFL69883609_en_180115.indd 13 2018-01-15 오후 5:13:40

Using the nozzles

- Please note that the following applies to the corresponding models:
- The nozzle can be attached to the product body or extension pipe.
- Use a different mode if the inlet gets stuck on the floor, carpet or bed sheets or if you need a more powerful mode.

⚠ CAUTION

- Do not use the product for any purpose other than domestic household.

Power Drive Carpet Nozzle

- It is suitable for cleaning carpets or rugs.
- It can be used to clean hard floors but will generate some noise.

⚠ CAUTION


- Do not use this nozzle on a play mat (PVC) for children.

Power Drive Floor Nozzle (some models only)

- It is suitable for cleaning hard floor surfaces.

Bedding Power Punch (some models only)

- Bedding Power Punch lets you clean bed sheets and covers more effectively. This attachment can be used to remove Pet Hair from various surfaces without hair tangling.
- Make sure to adjust the suction level to an appropriate setting when you vacuum-clean a blanket with a thin outer fabric as the cleaner may attempt to suck the outer fabric.



Crevice Tool


It is suitable for cleaning dust in a corner or a narrow space.

Combination Tool

This accessory is helpful for cleaning corners or small gaps.


Basic

For cleaning flat surfaces such as a sofa or mattress.



Brush type

For cleaning delicate surfaces such as a frame or furniture.



⚠ CAUTION

- Prolonged use of the product with an accessory tool attached may over heat the motor.
- Using this accessory tool on a TV, monitor or LCD display may scratch the screen.
- Avoid getting your finger stuck in any gaps when fitting the accessory tools.
- If any foreign object is sucked into the inlet during cleaning, operation of the unit might stop in order to prevent damage to the body, motor or inlet. Immediately stop using the vacuum cleaner and remove the object before resuming cleaning.

MFL69883609_en_180115.indd 14 2018-01-15 오후 5:13:40


MAINTENANCE

Cleaning the the Dustbin


1 Remove the battery from the unit before cleaning the dustbin.

2 Please empty the dustbin next to a wastebasket or where dust and foreign objects can be emptied easily.


3 Press the dustbin button downward to open it.
- Empty the bin.
- Be careful as dust/foreign matter may spill out when you open the dustbin.




4 Insert the crevice tool into the large dust separation device and turn it counterclockwise to remove it. Use the suction end of the crevice tool to do this with ease.



5 Wash the dust separation device with running water.
- Be sure to dry the device completely before using it.



6 Remove the dust separation device and use the combination tool to clean out the dust inside the dustbin.




⚠ WARNING
- Never wash the product's body with water. Water may reach the motor and cause electric shock or fire.
- Do not apply force or any impact to the dust bin parts or the dust separation device as it may damage them.
- Use the product only after cleaning the dust separation device and reassembling it on the product. Failure to do so will damage the product.


Cleaning the Filters

The Pre-filter and exhaust filter need to be cleaned at least once a month to maintain the cleaning performance of the product.

1 Turn the exhaust filter counterclockwise to remove it and take out the pre-filter.



2 With the unit upside down, use the combination tool to clear dust from the motor part.




MFL69883609_en_180115.indd 15 2018-01-15 오후 5:13:41

3 Clean the exhaust filter by brushing the dust off or by washing it in running water.

- To maintain cleaning performance, remove the dust from the exhaust filter at least once a month.




- Wash the exhaust filter in running water if it emits an odor.
- The exhaust filter may emit an odor if it is not dried completely after it has been cleaned in water. Make sure to dry it completely before refitting it




4 Clean the pre-filter by brushing the dust off or by washing it in running water.

- If the pre-filter is cleaned with water, use an extra pre-filter. Washing the pre-filter with water and not completely drying it may cause it to smell. Make sure to dry it completely.
- The more often the filters are cleaned, the more optimal the suction power will be.
- Filters are consumables. Please purchase more filters from an authorized service center.



5 To refit the filters, attach the Pre-filter first, followed by the exhaust filter, so as to align the white circle, and then turn it clockwise.



⚠ WARNING

- Never wash the product's body with water as it may reach the motor and result in electric shock or fire.
- Make sure that no foreign object reaches the motor as it will damage the product and may result in explosion or fire.
- Do not insert a finger or a sharp object near the motor as it will damage the product and may result in injury or electric shock.

⚠ CAUTION


- Make sure to reattach the exhaust filter and Pre-filter to the product after washing them. Using the product without these filters will allow dust to reach the motor inside the product and cause malfunction.

Please note

- As too much dust will reduce the suction power, we recommend cleaning the filters before and after using the product.

※ Removing foreign objects from inside the product

In order to maintain product performance, be sure to remove any foreign objects and dust from inside the product (body, extension pipe, inlets). The foreign materials inside the product can cause the product to shutdown during operation, generate noise, or cause poor suction.



※ If the inside of the product body, Extension pipe, or Inlet port is clogged with foreign objects, the power automatically turns off to protect the product. Separate the battery from the product and remove the foreign objects.

MFL69883609_en_180115.indd 16 2018-01-15 오후 5:13:42


Cleaning the Power Drive Floor/ Carpet Nozzle

Please clean the floor and carpet nozzles as follows:


1 Remove the nozzle from the product.

2 Turn the nozzle upside down and turn the rotating brush removal screw counterclockwise.


- Use a coin or a flat head screwdriver to turn the screw.




3 Pull the brush in the direction of the arrow to remove it.




4 Attach the crevice tool to the unit and use the vacuum to remove dust/foreign objects from the brush and the bottom of the nozzle.



5 Use a wet towel or tissue to remove any remaining foreign matter and dust from the brush and the bottom of the nozzle.



6 Assemble the brush in reverse order after cleaning.




⚠ CAUTION

- Avoid getting your finger stuck in any gaps when reassembling.
- Do not wash the rotating brush and the nozzle with water.
- Do not use the rotating brush as a mop.
- Do not use the nozzle to absorb any liquid.


Cleaning the Bedding Power Punch

1 Remove the Bedding Power Punch and turn it upside down.

2 Attach the crevice tool to the unit and use the vacuum to remove dust/foreign objects from the bottom of the Bedding Power Punch.



3 Use a wet towel or tissue to move any remaining foreign matter and dust.



⚠ WARNING

- Do not wash the Bedding Power Punch with water.
- Do not suck any liquids including water into the Bedding Power Punch.

MFL69883609_en_180115.indd 17 2018-01-15 오후 5:13:43

POINTS TO CHECK BEFORE CONTACTING CUSTOMER SERVICE.

Please check once again if one of the following symptoms is present while using the product. The product may not be malfunctioning.

Symptom	Cause	Solution
The product does not operate.	**Is the battery fully discharged?**	• Charge the battery.
	Is the product powered off?	• Press the power button to power on the product.
Suction is too weak.	**Is the dustbin full of dust?**	• Empty the dustbin.
	Is the filter clogged?	• Clean the pre-filter. If suction is still weak after cleaning the pre-filter, please contact the customer service department for advise
	Is the inlet clogged?	
	Is there a foreign object on the rotating brush of the inlet port?	• Make sure to remove any foreign objects (thread, hair) from the rotating brush.
The unit does not appear to be charging.	**Is the power adapter connected to the charging station?**	• Make sure that the adapter is properly plugged into the charging station.
	Is the power cord plugged into the outlet?	• Make sure that the power cord is properly plugged into the power outlet.
	Is there any foreign object on the charging terminals?	• Remove any foreign objects from the charging terminals with a dry cloth.
Hot air is expelled from the unit.	**Is it operating properly?**	• The hot air originates from cooling of the motor and is not a sign of malfunction.
A strange odor is coming from the product.	**Did you purchase the cleaner within the last 3 months?**	• The cleaner may emit a smell of rubber for about 3 months after purchase.
	Is it operating properly?	• If the cleaner is working fine, it is not malfunctioning.
	Is the dustbin full of dust?	• Also, dust in the bin may cause some odor. Empty the bin and clean it.
	Are there any foreign objects in the filter?	• The filter may emit an odor if it has not been cleaned for some time. Clean both the pre-filter and the exhaust filter.
	Is the Pre-filter wet?	• Washing the pre-filter with water and not leaving it long enough to dry completely may cause it to smell. Make sure to dry it completely before reassembling it on the cleaner.
	Is the exhaust filter wet?	• Washing the exhaust filter with water and not leaving it long enough to dry completely may cause it to smell. Make sure to dry it completely before reassembling it on the cleaner.
The cleaner makes too much noise.	**Is it operating properly?**	• Different levels of noise is normal during operation due to three power settings. It is not a sign of malfunction.
The unit powers off too soon.	**Is the battery fully charged?**	• The battery must be fully charged before cleaning. If the problem persists even though the battery is fully charged, and the pipes and attachments are clear from obstructions, then please contact LG customer service
	Is there any foreign substance in the body of the product, Extension pipe, or Inlet port?	• Remove the foreign objects from the body of the product, Extension pipe, or Inlet port.
The rotating brush does not rotate.	**Is the brush properly attached?**	• Remove the brush, clean it if necessary and attach it again.
	Are there any foreign objects on the rotating brush?	• Remove any foreign objects from the rotating brush.


MFL69883609_en_180115.indd 18 2018-01-15 오후 5:13:43


DISPOSAL INFORMATION


Disposal of old products not related with the purchase of a new product

You must contact your local city council or the related government authority before disposing of large appliances.

PRODUCT SPECIFICATIONS







Item/Model	A9********
Dimensions	260 mm(W) X 270 mm(L) X 1120 mm(H)
Weight	2.7 kg
Power consumption:	400 W (Maximum power: 450 W)/250 W/ 80 W (Turbo/Power/ Normal)
Suction power	140 W (In Turbo mode) 1)
Battery	DC 25.55 V
Battery runtime2) (When fully charged, and using the Power Drive nozzles3))	Approx. 6 minutes in Turbo
	Approx. 9 minutes in Power
	Approx. 30 minutes in Normal
Battery runtime2) (When fully charged, and without using the Power Drive nozzles3))	Approx. 6 minutes in Turbo
	Approx. 9 minutes in Power
	Approx. 40 minutes in Normal

Item	Charger (Adaptor)
Input	100 - 240 V~ 50/60 Hz, 0.8 A
Output	DC 29.4 V 1.0 A

Item/Model	Battery
Type	Rechargeable Li-ion Battery
Rated	DC 25.55 V, 2000 mAh, 7 cells

1) The result is average of suction power with ASTM-F558 standard tested by individual test lab. Individually measured data would be different with the test result.
2) Test result according to our test standard, it may be different depending on actual use environment and period of use.
3) Floor, carpet, bedding only (suction port may vary by model)

MFL69883609_en_180115.indd 19 2018-01-15 오후 5:13:43

Memo

הערות

מידע על סילוק

סילוק מוצרים ישנים שאינם קשורים לרכישת מוצר חדש


עליך לפנות למועצת העיר המקומית או לרשות הממשלתית הרלוונטית לפני השלכת מכשירים גדולים.


מפרט מוצר


פריט/מודל	A9********
ממדים	1120 mm(H) x 270 mm(L) x 260 mm(W)
משקל	2.7 kg
צריכת חשמל:	400 וט(כח מקסימלי 450 וט)/250 וט /80 וט(טורבו/כח/נורמלי)
עוצמת שאיבה	140וט(במצב טורבו)[1]
סוללה	DC 25.55 V
זמן חיים של סוללות[2] בעת טעינה מלאה, וללא שימוש במברשת הראשית[3]	6דקות בקרוב במצב טורבו
	9דקות בקרוב במצב פעולה
	40דקות בקרוב במצב נורמלי
זמן חיים של הסוללה[2] בעת טעינה מלאה, ושימוש במברשת ראשית[3]	6דקות בקרוב במצב טורבו
	9דקות בקרוב במצב פעולה
	30דקות בקרוב במצב נורמלי

פריט	מטען (מתאם)
קלט	100 - 240 V~ 50/60 Hz, 0.8 A
פלט	DC 29.4 V 1.0 A

פריט/מודל	סוללה
סוג	סוללת ליתיום נטענת
מדורג	DC 25.55 V, 2000 mAh, 7 cells







1) התוצאה הינה ממוצע של עוצמת שאיבה אשר נבדק בתקן ASTM-F558 ע"י מעבדת בדיקה עצמאית. תוצאות אשר יתקבלו מבדיקה עצמאית יכולות להיות שונות מתוצאות בדיקת המעבדה.

2) תוצאות הבדיקה בהתאם לתקן הבדיקה שלנו, התוצאות יכולות להיות שונות בהתאם לשימוש, לסביבה ותקופת השימוש.

3) רצפה, שטיח, מצעים בלבד (יציאת היניקה עשויה להשתנות בהתאם לדגם)

MFL69883609_he_180115.indd 19 2018-01-15 오후 6:04:50

.נקודות שיש לבדוק לפני פניה לשירות הלקוחות

בדוק שוב אם אחד מהתסמינים הבאים קיים בעת השימוש במוצר. ייתכן שהמוצר אינו פגום.


סימפטום	גורם	פתרון
המוצר אינו פועל.	**האם הסוללה טעונה במלואה?**	• הטען את הסוללה.
	האם המוצר כבוי?	• לחץ על כפתור ההפעלה על מנת להטעין את המוצר.
השאיבה חלשה מידי.	**האם מיכל האבק מלא באבק?**	• רוקן את מיכל האבק.
	האם הסנן סתום?	• נקה את קדם המסנן . אם השאיבה עדיין חלשה לאחר ניקוי קדם המסנן , פנה למחלקת שירות הלקוחות לקבלת ייעוץ
	האם מקום הכניסה סתום?	
	האם יש חפץ זר על המברשת המסתובבת של מקום הכניסה?	• הקפד להסיר את כל האובייקטים זרים (חוט, שיער) מהמברשת המסתובבת.
נראה שהיחידה אינה מטעינה.	**האם מתאם החשמל מחובר לתחנת הטעינה?**	• ודא שהמתאם מחובר כהלכה לתחנת הטעינה.
	האם כבל החשמל מחובר לשקע?	• ודא שכבל החשמל מחובר היטב לשקע החשמל.
	האם יש אובייקט זר על מסופי הטעינה?	• הסר חפצים זרים ממסוף הטעינה באמצעות מטלית יבשה.
אויר חם נפלט מהיחידה.	**האם זה פועל כראוי?**	• האוויר החם מקורו בקירור המנוע ואינו מהווה סימן לתקלה.
נודף ריח מוזר מהמוצר.	**האם רכשת את השואב בשלושת החודשים האחרונים?**	• המנקה עשוי לפלוט ריח של גומי במשך כ 3 חודשים לאחר הרכישה.
	האם זה פועל כראוי?	• אם השואב עובד בסדר לא קיימת בו תקלה.
	האם סל האשפה מלא באבק?	• כמו כן, אבק במיכל עלול לגרום לריח כלשהו.יש לרוקן את במיכל ולנקות אותו.
	יש יש חפצים זרים על המסנן?	• המסנן עשוי לפלוט ריח אם הוא לא נוקה במשך זמן מה. נקה הן את מסנן מראש מסנן פליטה.
	האם קדם המסנן רטוב?	• שטיפת הקדם מסנן במים מבלי להניח אותו מספיק זמן לייבוש לחלוטין עלול לגרום לו להדיף הריח. הקפד לייבש אותו לחלוטין לפני הרכבה מחדש על המנקה.
	האם מסנן הפליטה רטוב?	• שטיפת מסנן הפליטה במים מבלי להניח אותו מספיק זמן לייבוש לחלוטין עלול לגרום לו להדיף הריח. הקפד לייבש אותו לחלוטין לפני הרכבה מחדש על המנקה.
המנקה גורם ליותר מידי רעש.	**האם הוא פועל כראוי?**	• קיימות רמות שונות של רעש נורמלי במהלך הפעולה בגלל שיש שלוש הגדרות של צריכת חשמל. זה איננו סימן של תקלה.
זרם החשמל של היחידות מפסיק מוקדם מידי.	**האם הסוללה טעונה במלואה?**	• יש לטעון את הסוללה במלואה לפני הניקוי. אם הבעיה נמשכת למרות שהסוללה טעונה במלואה והצינורות והקבצים נקיים מחסימות, פנה לשירות הלקוחות של LG .
	האם יש חומר זר בגוף של המוצר, צינור ההרחבה או במקום היציאה?	• הסר את האובייקטים הזרים מגוף המוצר, צינור הארכה או יציאת כניסת.
המברשת המסתובבת אינה מסתובבת.	**האם המברשת מחוברת כראוי?**	• הסר את המברשת, נקו אותה במידת הצורך וחבר אותה שוב.
	האם ישנם עצמים זרים על המברשת המסתובבת?	• הסר את כל האובייקטים הזרים מהמברשת המסתובבת.

MFL69883609_he_180115.indd 18 2018-01-15 오후 5:19:31


ניקוי מברשת רצפה\שטיחים

יש לנקות את המברשת באופן הבא:


1. הסר את המברשת מהמוצר.
2. סובב את המברשת כלפי מטה וסובב את בורג הסרת המברשת המסתובבת נגד כיוון השעון.
   - השתמש במטבע או במברג שטוח כדי לסובב את הבורג.




3. משוך את המברשת בכוון החץ לצורך הסרתה.




4. חבר את כלי הפינות ליחידה והשתמש בואקום כדי להסיר אבק / חפצים זרים מהמברשת ומתחת לזרבובית.



5. השתמש במגבת רטובה או בטישו כדי להסיר שאריות של חומר זר ואבק מן המברשת ומהחלק התחתון של המברשת.



6. חבר את המברשת בסדר הפוך לאחר הניקוי




⚠ זהירות


- הזהר לבל תתקענה אצבעותיך בחריצים בעת החיבור.
- אין לשטוף במים את המברשת ואת הזרבובית.
- אין להשתמש במברשת המסתובבת כסמרטוט.
- אין להשתמש בשואב האבק לצורך ספיגת נוזלים.

נקוי מברשת חובטת

1. הסר את המברשת החובטת והפוך אותה .
2. צרף את הכלי הפינות ליחידה ולהשתמש בואקום כדי להסיר אבק / חפצים זרים מהתחתית של המברשת החובטת



3. השתמש במגבת רטובה או בטישו לסילוק שאריות של חומר זר ואבק.



⚠ אזהרה

- אין לשטוף במים את המברשת החובטת.
- אין לשאוב נוזלים כלשהם, כולל מים לתוך המברשת החובטת

MFL69883609_he_180115.indd 17 2018-01-15 오후 5:19:32


3 נקה את מסנן הפליטה ע"י הברשת האבק החוצה או ע"י שטיפתו במים זורמים.

• יש לנקות את האבק ממסנן הפליטה אחת לחודש לפחות על מנת לשמור על יכולת הניקוי של המכשיר.



• אם מסנן הפליטה מדיף ריח יש לשטוף או במים זורמים.

• מסנן פליטה עשוי לפלוט ריח לאחר הניקוי שלו במים במידה שהוא אינו מיובש לחלוטין. הקפד לייבש אותו לחלוטין לפני התאמתו מחדש.




4 יש לנקות את הקדם מסנן על ידי הברשת האבק החוצה או על ידי שטיפתו במים זורמים.


• אם מראש מסנן הוא ניקה עם מים, להשתמש מראש מראש מסנן. אם לאחר שטיפת הקדם מסנן במים לא מייבשים אותו כליל עלול להגרם לו להדיף ריח . יש להקפיד לייבש אותו לחלוטין.

• ככל שמנקים את המסננים לעיתים תכופות יותר כך תתקרב עוצמת השאיבה למידתה האופטימלית.

• מסננים מתכלים עם הזמן. מומלץ לרכוש מסננים נוספים ממרכז שירות מורשה.



5 כדי להתקין מחדש את המסננים, חבר תחילה את המסנן הקדם, ולאחר מכן את מסנן הפליטה, כדי ליישר את המעגל הלבן ולאחר מכן סובב אותו בכיוון השעון.



⚠ אזהרה

• אין לשטוף במים את הגוף המוצר. כניסת מים למנוע עלולה לגרום לשוק חשמלי או לשריפה.

• ודא כי אין חפץ זר שמגיע למנוע מאחר שהוא עלול לגרום נזק למוצר ועלול גרום לפיצוץ או שריפה.

• אין להכניס אצבע או חפץ חד לקרבת המנוע, שכן עלול להגרם נזק למוצר או לגרום לפציעה או להתחשמלות.

⚠ זהירות


• הקפד לחבר מחדש את מסנן הפליטה ואת קדם המסנן אל המוצר לאחר שטיפתם. השימוש במוצר ללא מסננים אלה יאפשר לאבק להגיע למנוע שבתוכו ולגרום לתקלה.

שים לב

• מאחר שאבק רב מדי עלול להקטין את כוח השאיבה, אנו ממליצים לנקות את המסננים לפני ואחרי השימוש במוצר.

※ הרחקת עצמים זרים מפנים המוצר

על מנת לשמור על ביצועי המוצר, הקפד להסיר חפצים זרים ואבק מתוך המוצר (גוף, צינור הרחבה, מפרצון). החומרים הזרים בתוך המוצר עלולים לגרום לכבוי המוצר במהלך הפעולה, לגרום לרעש או להקטין את יכולת השאיבה.



※ אם החלק הפנימי של גוף המוצר, צינור ההארכה או פתח היציאה סתומים בגלל אובייקטים זרים, יכבה החשמל באופן אוטומטי כדי להגן על המוצר. הפרד את הסוללה מהמוצר והסר את האובייקטים הזרים.

MFL69883609_he_180115.indd 16 2018-01-15 오후 5:19:33


נקוי מיכל האבק

1 הסר את הבטריה מהיחידה לפני נקוי מיכל האבק.


2 יש לרוקן את מיכל האבק בצמוד למיכל האשפה או במקום שבו ניתן להסיר בקלות אבק וחפצים זרים.

3 לחץ על כפתור המיכל בכוון מטה על מנת לפתוח אותו.

- רוקן את המיכל.
- הזהר לבל ישפך החוצה עצם זר או אבק בעת פתיחת מיכל האבק.



כפתור מיכל האבק

4 הכנס את כלי הפינות לתוך התקן הגדול להפרדת אבק והפעל אותו נגד כיוון השעון כדי להסיר אותו. השתמש בקצה היניקה של כלי הפינות כדי לעשות זאת ביתר קלות.



5 שטוף את כלי הפרדת האבק במים זורמים.

- דאג ליבש לחלוטין את המכשיר טרם השימוש בו.



6 הסר את התקן הפרדת האבק והשתמש בכלי השילוב כדי לנקות את האבק מתוך מיכל האבק.


כלי משולב


⚠ אזהרה

- אין לשטוף במים את גוף המוצר.המים עלולים להגיע למנוע ולרגם לשוק חשמלי או לשריפה.
- אין להפעיל כח או לחץ על חלקי מיכל האבק או על מכשיר הפרדת האבק למנוע הנזקותם.
- השתמש במוצר רק לאחר ניקוי התקן הפרדת האבק והרכבתו מחדש במוצר. אי ביצוע פעולה זו עלול לגרום נזק למוצר.


נקוי הסננים

יש לנקות את קדם המסנן ומסנן הפליטה לפחות פעם בחודש על מנת לשמור על יכולת הניקוי של המוצר.

1 סובב את מסנן פליטה נגד כיוון השעון כדי להסיר אותו ולהוציא את הקדם-מסנן.



2 כאשר המכשיר הפוך, השתמש בכלי השילוב על מנת לנקות אבק מהחלק של המנוע.



MFL69883609_he_180115.indd 15 2018-01-15 오후 5:19:33

שימוש בזרבובית

- שים לב כי הסעיפים הבאים מתייחסים למודלים המתאימים:
- ניתן לחבר את הזרבובית לגוף המוצר או לצינור הארכה.
- השתמש במצב אחר במידה שהמפרצון נתקע על הרצפה, השטיח או סדינים למיטה או אם נדרש מצב חזק יותר.

⚠ זהירות

- אין להשתמש במוצר שלא לצורך משק בית מקומי.

שואב אבק חשמלי

- מתאים לניקוי שטיחים או משטחים.
- ניתן לשימוש לצורך ניקוי רצפה קשה אם כי עלול להרעיש.

⚠ זהירות


- אין להשתמש בשואב האבק על מזרון משחקים (PVC) לילדים.

מברשת ראשית לרצפה (מספר דגמים בלבד)

- מתאים לניקוי משטחי רצפה קשים.

מברשת חובטת (דגמים מסוימים בלבד)

- מברשת חובטת מאפשרת ניקוי סדינים וכיסויי מיטה ביתר יעילות. נספח זה ניתן לשימוש לצורך הסרת שיער של חיות מחמד ממשטחים שונים ללא הווצרות פקעות שיער.
- הקפד להתאים את רמת השאיבה בצורה מתאימה בעת שאיבת אבק משמיכה עם אריג חיצוני דק כדי למנוע שאיבה של האריג החיצוני.



כלי לפינות


מתאים לנקוי אבק מפינות או מקומות צרים.

כלי משולב

כלי העזר יעיל לנקוי אבק מפינות ואזורים צרים.


בסיסי

לנקוי משטחים שטוחים כמו ספות ומזרונים.



סוג המברשת

לניקוי משטחים עדינים כמו מסגרות ורהיטים.



⚠ זהירות


- שמוש ממושך במוצר עם הכלי הנלווה מחובר עלול לגרום להתחממות יתר של המנוע.
- שימוש בכלי העזר עבור טלויזיה, מוניטור או צג LCD עלול לגרום לשריטת המסך.
- הזהר לבל תתקענה אצבעותיך בחריצים בעת התאמת כלי העזר.
- אם במהלך הניקוי נשאב חפץ זר לתוך הכניסה , הפעולה של שואב האבק עלולה להעצר על מנת למנוע נזק לגוף או המנוע. הפסק מיד את השמוש בשואב האבק וסלק את החפץ הזר בטרם תמשיך בניקוי.

MFL69883609_he_180115.indd 14 2018-01-15 오후 5:19:33

טעינת המוצר


1 הנח את המוצר על תחנת הטעינה.

• מחוון הסוללה יתחיל להבהב והטעינה תמשך בשלושה שלבים.



2 מחוון הסוללה מתחיל להבהב ויתחיל תהליך הטעינה.

• כל המחוונים ישארו דולקים כשהסוללה טעונה במלואה.



זהירות

• הקפד להתאים את היחידה בצורה מאובטחת לתחנת הטעינה ,שאם לא כן, עלול המוצר ליפול ולהנזק.


שים לב

• הסוללה לא תטען אם טמפרטורת הסביבה נמוכה מ - 5 ° C. טען את הסוללה אך ורק כאשר הטמפרטורת הסביבה היא בין 5 ° ו 38 ° C.

• מחוון הסוללה יהבהב אם המוצר נטען במלואו, הוסר מהתחנה ויטען שוב בקרוב. ההבהוב ייפסק לאחר פרק זמן קצר והמחוון יישאר דולק.

טעינת סוללת העזר

1 החזק את המוצר ומשוך את הסוללה על - ידי לחיצה על שני קצוות הסוללה .



2 הכנס את הסוללה לתוך תחנת העזר של הטעינה.



שים לב

• ודא שמתאם המתח מחובר הן לתחנת הטעינה והן לשקע החשמל

• אם הסוללה הראשית נטענת בתחנת הטעינה, סוללת העזר תתחיל לטעון רק לאחר טעינת הסוללה הראשית.


• מחוון סוללת העזר מהבהב כאשר הטעינה מתחילה.

• המהבהב ישאר דלוק כאשר סוללת העזר תוטען במלואה.

• טעינה מלאה של סוללה אחת נמשכת בדרך כלל 4 שעות, אך הפעולה תמשך זמן כפול אם תטעין אותה ביחד עם סוללת עזר מרוקנת.

כפתור הפעלה/עוצמת שאיבה

ניתן לכוונן את עוצמת השאיבה באמצעות לחצן עוצמת השאיבה הממוקם על הידית.



1 כפתור הפעלה/כיבוי

• לחץ על כפתור ההפעלה/כיבוי על מנת להפעיל את המצב הנורמלי.

2 כפתור מצב

• לחץ לחיצה אחת על"+" לשנות מצבי הפעלה.

• לחץ והחזק את "+" במשך יותר מ-3 שניות על מנת להפעיל מצב טורבו.

• ייקח ליחידה רגע קל כדי לעבור ממצב רגיל למצב טורבו כאשר כפתור "+" מוחזק.

• לחץ "-" על מנת לעבור ממצב טורבו למצב רגיל או ההפך.

MFL69883609_he_180115.indd 13 2018-01-15 오후 5:19:34


הערה על השמוש במוצר

נקודות שיש לשים לב אליהן בעת השמוש במוצר

- ודא שמכסה מיכל האבק מותקן לפני השימוש במוצר. שאם לא כן ידרדר כוח היניקה והניקוי לא יתבצע כראוי.
- תמוך בתחתית המוצר בעת ניקוי משטח מוגבה.
- בעת השארת המוצר ללא השגחה או ללא שימוש במשך תקופה ממושכת, הקפד למקם אותו כהלכה בתחנת הטעינה או השכב אותו על הרצפה. שאם לא כן, המוצר עלול ליפול ולהפגם או עלול לגרום לחבלה.
- ודא כי מסנן הפליטה מותקן כראוי לפני השימוש במוצר.
- תנאים סביבתיים כגון טמפרטורה ולחות עלולים לגרום להצטברות של חשמל סטטי במוצר. אנא צור קשר עם מחלקת שירות הלקוחות של LGאלקטרוניקה אם הבעיה נמשכת.
- המצאות חפץ זר על יציאת הכניסה או צינור ההארכה יפריע לתפקוד הראוי של המוצר. הקפד להסיר כל חפץ זר כגון גרב או גרביון לפני השימוש במוצר.
- תקופת החיים של הסוללה יתקצר לאחר שימוש חוזר במוצר במשך תקופה ארוכה בגלל מאפייניה.
- כאשר הסוללה עומדת להתרוקן לחלוטין במהלך השימוש, יתחיל הבלוק האחרון על מחוון הסוללה להבהב והמוצר יכבה לאחר זמן מה. במקרה כזה יש לטעון את הסוללה במלואה .
- יש להשתמש במוצר בטמפרטורת החדר הרגילה. אורך החיים של הסוללה יורד באופן תלול אם השמוש נעשה בטמפרטורות נמוכות מ -5 מעלות צלזיוסּ או גבוהות מ -38 מעלות צלזיוסּ במשך זמן ממושך.
- לקבלת פרטים אודות זמן הפעלת הסוללה עיין במפרט המוצר.
- זמנים אלה הם לצורך הדרכה בלבד ועשויים להיות פחותים בהתאם לסוג השטח.


שמוש במוצר

1 הרכב את הגוף, צינור הרחבה,אזור הכניסה ואת הסוללה בסדר הזה.




2 לחץ על הלחצן שעל צינור ההארכה כדי להתאים את אורכו

- לצינור יש ארבעה מצבי הארכה אפשריים.



3 חבר את הכלי הנלווה לגוף או לצינור ההרחבה.



⚠ זהירות

- שמוש ממושך במוצר עם הכלי הנלווה מחובר עלול לגרום לעומס יתר על המנוע.
- שימוש בכניסה לצורך ניקוי טלוויזיה, צג LCD או התצוגה עלול לגרם לשריטת המסך.
- יש לנקוט משנה זהירות כדי למנוע התקעות האצבעות בחריצים בעת הרכבת הקבצים המצורפים.
- אם במהלך הניקוי נשאב חפץ זר לתוך הכניסה , הפעולה של שואב האבק עלולה להעצר על מנת למנוע נזק לגוף או המנוע. הפסק מיד את השמוש בשואב האבק וסלק את החפץ הזר בטרם תמשיך בניקוי.

MFL69883609_he_180115.indd 12 2018-01-15 오후 5:19:34

⚠ זהירות

- הזהר מהשמטת המוצר והחלקים בעת הוצאתם מהחבילה. הדבר עלול להזיק למוצר ו / או לגרום לפציעה גופנית.
- אין להשתמש בסרט דו צדדי על מנת לעגן את תחנת הטעינה על הקירות המודפסים. אנא השתמש בברגים המסופקים, שאם לא כן עלול הנייר להקרע מתנועת תחנת הטעינה במהלך העגינה של היחידה.
- מומלץ לעגן את התחנה בעזרת בורג עגינה.

שים לב

- לא ניתן לפרק בנפרד את תחנת הטעינה, את הצינור והתמיכה שלה לאחר הרכבתם ולאחר חיבור תחנת הטעינה לקיר.
- ניתן להסיר את תחנת הטעינה לפי הצורך. לאחר פריקתו מן הקיר יש למשוך את התחנה כלפי מעלה בעוד תחתית התחנה נשארת זקופה על הרצפה.
- השתמש בברגי העיגון רק כאשר הקיר עשוי בטון או שהוא מספיק מוצק .


התקנת התחנה המורכבת על קיר

1 חבר את מתאם המתח ליציאה בגב תחנת הטעינה וחבר את כבל החשמל לשקע החשמל.

2 נקב חור במרחק מטר אחד מהרצפה על מנת להכניס את תקע הקיר או את בורג העוגן.

- קוטר החור המומלץ: Φ6.5
  העומק המומלץ: 60 מ"מ.

3 עגן את התחנה לקיר בעזרת ברגי העוגן המסופקים.




שים לב

- בקשה לשירות של שינוי מיקום ההתקנה של תחנת הטעינה ע"י מתקין מוסמך כרוכה בתשלום נוסף .


איחסון הכלי המשולב וכלי הפינות

אנא שמור על כלי הטעינה וכלי הסריקה בתחנת הטעינה לצורך גישה קלה.

1 צרף את הכלי השילוב וכלי הפינות למחזיקים המתאימים.




2 לחץ והחזק את לחצן הסרת הכניסה ומשוך כלפי מטה על מנת להסיר את הכלי המשולב או את כלי הפינות.



MFL69883609_he_180115.indd 11 2018-01-15 오후 5:19:35

התקנת תחנת טעינה העומדת על הריצפה

1 הנח את תחתית תחנת הטעינה על הרצפה והרכב את הצינור תחילה ולאחר מכן את מתלה הגוף העליון.




זהירות

- הזהר לבל יתקעו אצבעותיך בחריצים.


2 חבר את מתאם המתח ליציאה בגב תחנת. הטעינה ואת כבל החשמל לשקע החשמל

- ניתן לאבטח את הכבל על ידי הנחתו באמצעות טבעת עיגון כבל החשמל הממוקמת בחלק האחורי של צינור תחנת הטעינה.




3 לאחר שתוודא שאין צינורות או חוטים פנימיים מאחורי הקיר, בצע חור בגובה המתאים כדי לעגן את תחנת הטעינה והכנס .את עוגן הבורג

- הקוטר המומלץ של החור: Φ6.5; העומק המומלץ:50-100מ"מ.



4 הנח את בלוק העגינה בגב תחנת הטעינה ועגן את תחנת הטעינה באמצעות הבורג.


- הקפד להדק את הבורג במלואו.




בעת שימוש בסרט הדבקה דו צדדי (אין להשתמש אם יש טפטים על הקיר)

1 השתמש בסרט הדבקה דו צדדי כדי לחבר את בלוק העגינה של הקיר לתחנת הטעינה בשלב 4.

- הקפד להסיר את החלק המרכזי של הסרט הדו צדדי לפני ההרכבה .




2 השתמש בשארית הסרט כדי לעגן את התחנה לקיר לפני הכנסת הבורג.




MFL69883609_he_180115.indd 10 2018-01-15 오후 5:19:35

מידע על החבילה

סוג עומד




סוג המורכב על קיר





1 גוף המוצר
2 צינור הארכה
3 שואב אבק חשמלי
4 תחנת הטענה
5 צינור תחנת טעינה
6 נושא אביזרים: כלי משולב וכלי פינות
7 תמיכה בתחנת הטעינה
8 מתאם
9 סוללה


חלקי הגוף

• חלקים ואביזרים עשויים להשתנות בהתאם לדגם שרכשת.


גוף המוצר



צינור הארכה



מברשת ראשית לשטיח


תחנת הטענה


מתאם


סוללה


כלי לפינות


כלי משולב


כלי עיגון לקיר


סרט הדבקה דו צדדי (2)


בורג עוגן (2)



בורג עיגון עבור הסוג המורכב לקיר (Φ 3.5מ"מ, אורך 50 מ"מ)(2)


בורג עיגון עבור הסוג העומד (Φ 3.5מ"מ, אורך 90 מ"מ)



הקדם מסנן


• שים לב כי חלקים אלה מגיעים עם המודלים המתאימים בלבד.


סוללה


מברשת ראשית לשטיח


מברשת חובטת למיטה


צינור תחנת טעינה


תמיכת תחנת טעינה

MFL69883609_he_180115.indd 9 2018-01-15 오후 5:19:36

⚠ זהירות

שמוש נכון

אין להפעיל לחץ על המוצר או להפילו מגובה.
• דבר זה עלול לגרום לנזק למוצר ו/או לחבלה.

יש להבטיח שהמוצר לא יפול.
• זה עלול לפגוע במוצר ולגרום לו נזק.

לפני כל שימוש יש לודא שהמסנן מותקן במוצר.
• שימוש במוצר ללא מסנן עלול לגרום לו נזק.

יש להקפיד לנגב מהריצפה כל נוזל כגון מים או שמן או צואת חיות מחמד לפני השימוש במוצר.
• חומרים אלה עלולים לגרום לתקלה ביחידה או לגרום לנזק בלתי הפיך.

אין לנקות את המוצר עם ממיס נדיף או אורגני (מדלל או אצטון).
• זה עלול לגרום נזק למוצר.
• יש להשתמש בבד עדין לניקוי המוצר.

הקפד להימנע מהתקלות עם אדם או חיית מחמד בעת השימוש במוצר.
• זה עלול לגרום לפגיעה.

אין לבעוט במוצר.
• זה עלול לגרום לתקלה בפעולת המוצר.

• אין להניח על תחנת הטעינה שום חפץ ,מלבד המוצר עצמו (במיוחד חפץ מתכתי או מגנטי).
• דבר זה עלול לגרום נזק למוצר או שוק חשמלי

אין לחזור על נקוי אזור מסויים לאורך זמן ממושך.
• רעידות של אזור הכניסה עלולות לגרום נזק לריצפה או לשטיח.

ודא שאצבעך לא נתקעת בעת הרכבת המוצר או תחנת הטעינה.
• זה עלול לגרום לפציעה באצבע שלך.

יש למנוע מילדים או בעלי חיים גישה לתחנת ההטענה.
• זה עלול לפגוע במוצר ולגרום לו נזק.

אין לשים סרט דו צדדי ישירות על הטפט מאחר שהוא עשוי להיות קרוע כתוצאה מכוח חיצוני.
• הצמד את תחנת הטעינה לקיר בעזרת בורג/ים על מנת למנוע קריעה של הטפט.

אין להפעיל כוח או לחץ על חלקי המסנן או חלקי מיכל האבק.
• החלקים עשויים להתעוות, לפגוע בביצועים או לגרום לתקלה ביחידה.

MFL69883609_he_180115.indd 8 2018-01-15 오후 5:19:36

אין לאפשר למים, משקה או חומר ניקוי להיכנס לסוללה.

• דבר זה עלול לגרום לשוק חשמלי, פיצוץ או התלקחות.

אין לגעת במסופי הטעינה שעל המוצר או בתחנת הטעינה, או להכניס למוצר או לתחנת הטעינה חפץ מחושמל כלשהו.

• פעולות אלה עלולות לגרם לחבלה או לשוק חשמלי.

כאשר המוצר אינו בשימוש יש להניח אותו על תחנת הטעינה.

• שאם לא כן, עלול המוצר ליפול ולהנזק או לגרם לחבלה.

במקרה שההארקה מופעלת בזמן שהמוצר ממוקם בתחנת הטעינה, הורד מיד את המוצר מהתחנה ופנה למחלקת שירות הלקוחות של LG אלקטרוניקה.

• אי ציות לכלל זה עלולה לגרום לשוק חשמלי או לשריפה.

אין לשטוף במים את מיכל האבק.

• הדבר עלול לגרום לחדירת מים למנוע ולגרום לשוק חשמלי או לשריפה.

אין לנסות לשאוב אבק דק כגון מלט בעזרת המוצר.

• דבר זה עלול לגרום לתקלה במוצר או לשריפה.

יש לשמור את המוצר, תחנת הטעינה והסוללה מחוץ להישג ידם של ילדים.

• זאת על מנת למנוע נזק למוצר או חבלה.

• הכנסת המוצר או הסוללה לפה עלולה לגרום חבלה או שוק חשמלי לילד או נזק למוצר ולסוללה.

השלכה

בהשלת חומרי האריזה מהמוצר (פלסטיק ויניל,קלקר) יש להקפיד שהם לא יבואו במגע עם ילדים.

• חומרים אלה עלולים לגרום לחנק.

בעת סילוק המוצר, הקפד להסיר את הסוללה מגוף המוצר.

• אי ציות לכלל זה עלולה לגרום לפיצוץ או התלקחות.

• אין להשתמש במוצר בשטח פתוח או על משטח רטוב.

• יש למנוע מילדים להשתמש במוצר כצעצוע.נדרשת תשומת לב רבה בזמן שהמכשיר נמצא בסביבת ילדים.

• השתמש במכשיר בהתאם להוראות שבמדריך זה בלבד. השתמש רק בקבצים המצורפים המומלצים של היצרן.

• אין להשתמש בכבל או בתקע פגום.

• אין להשתמש בכבל לצורך משיכה או נשיאה ,כידית, לסגירת דלת, או למשוך אותו סביב קצוות או פינות חדות.

• אין להוציא את התקע ע"י משיכת כבל.להוצאת התקע אחוז בתקע ולא בכבל.

• אין לטפל במטען, בתקע המטען ובמסופי המטען בידיים רטובות.

• אין לשים חפצים על הפתחים. אין להשתמש במקרה שאחד הפתחים חסומים; יש למנוע הצטברות אבק, מוך, שיער, וכל דבר שעלול להפחית את זרימת האוויר.

• הרחק מהפתחים ומחלקים נעים שיער, בגדים רופפים, אצבעות או כל חלק גוף אחר .

• הזהר במיוחד בעת ניקוי על מדרגות.

• אין להשתמש לצורך איסוף נוזלים דליקים או נוזלי בערה כמו בנזין, או באזורים בהם עלולה להיות נוכחות של חומרים אלה.

• אין להטעין את היחידה באזור פתוח.

• השתמש במטען שסופק ע"י היצרן בלבד לצורך הטענה חוזרת.

• אין לשרוף את המכשיר גם אם הוא נפגע קשות. הסוללות עלולות להתפוצץ באש.

• אין להרים שום חפץ בוער או מעשן ,כגון סיגריות, גפרורים, או אפר חם.

• אין להשתמש כשהמסנן אינו נמצא במקומו.

MFL69883609_he_180115.indd 7 2018-01-15 오후 5:19:36

שמוש נכון

הרחק את המוצר מהישג ידם של ילדים.

• ילדים אינם מסוגלים לטפל במוצר כראוי מפאת כובד משקלו.

ודא שלא נתקעו במברשת המסתובבת או בגלגל יד, רגל, שיער או בגדים בעת שימוש או ניקוי המוצר.

• דבר זה עלול לגרום נזק למוצר או לחבלה.

אין איש פרט לטכנאי / מהנדס שירות מוסמך של LG אלקטרוניקה רשאי לפרק, לתקן או לשנות את המוצר.

• אין לנסות לפרק או לתקן את המוצר בעצמך על מנת למנוע פגיעה משוק חשמלי, חבלה או התלקחות.

אין להשתמש בתחנת הטעינה ובסוללה עבור מוצרים אחרים פרט למוצר זה.

• שימוש כזה עלול לגרום לתקלה במוצר או לשריפה.

אין להשתמש בסוללה עבור התקן אחר במוצר.

• שימוש כזה עלול לגרום לתקלה בהתקן או לשריפה.

אין לפרק באופן שרירותי את הסוללה, להסיר אותה או לקצר אותה.

• פעולות אלה עלולות לגרום לשוק חשמלי, חבלה או שריפה.

אין להחיל חום או הלם על הסוללה.

• פעולות אלה עלולות לגרום לשוק חשמלי, חבלה או שריפה.

אין להכניס חפץ מתכתי חד כגון סיכה, מסמר או סכין לתוך חלל או פער במוצר או בתחנת הטעינה.

• פעולות אלה עלולים לגרום לשוק חשמלי או חבלה.

אין לשאוב נוזלים עם מוצר זה. יש לוודא שלא יכנסו למוצר או לתחנת הטעינה מים, משקה או חומר ניקוי .

• דבר זה עלול לגרום לחבלה או לשוק חשמלי.

אין לשים או לרסס על המוצר חומר דליק (בנזין או מדלל) או חומר פעיל על פני שטח (חומר ניקוי או סבון).

• דבר זה עלול לגרום לתקלה במוצר או לשריפה.

במקרה של דליפת גז (פרופאן או גז עירוני), הקפד לאוורר תחילה את האזור מבלי לבוא במגע עם המוצר או עם תקע החשמל שלו.

• אי ציות לכלל זה עלול לגרום לניצוצות שעלולים לגרום לפיצוץ, אש או חבלה.

אין להשתמש או לאחסן בקרבת המוצר התקן חימום או חומר דליק (אתר, בנזין, אלכוהול, כימיקלים, תרסיס דליק, חומרי הדברה, מטהר אוויר או קוסמטיקה) .

• דבר זה עלול לגרום לתקלה במוצר או לשריפה.

אין לנסות לנקות חומר נוזלי (מים, משקה), חפצים מתכתיים (כגון להב, סיכות), חומרים דליקים, חומרים פעילים פנימיים או זכוכית עם מוצר זה.

• דבר זה עלול לגרום לתקלה במוצר או לשריפה.

• במקרה שנכנס למוצר נוזל כלשהו, חפץ מתכתי, שבר זכוכית או ניצוץ , כבה מיד את המוצר ופנה למחלקת שירות הלקוחות של LG אלקטרוניקה.

אין להשתמש במוצר במקרה של חסימת מוצא הפליטה או הכניסה.

• דבר זה עלול לגרום להתחממות יתר של המוצר ולקלקולו או להתלקחות.

במקרה שנפלט עשן מהמוצר בזמן הטעינה, נתק מיד את כבל החשמל ופנה למחלקת שירות הלקוחות של LG אלקטרוניקה.

• אי ציות לכלל זה עלול לגרום לשוק חשמלי או לשריפה.

אין לחשוף את המוצר, ואת הסוללה בפרט, לחום, מכשיר חימום או ישירות לאור השמש.

• חשיפה כזאת עלולה לגרום לשוק חשמלי, פיצוץ או דליקה.

אין להחזיק את המוצר או הסוללה בתוך כלי רכב החשוף ישירות לאור השמש.

• דבר זה עלול לגרום לפיצוץ או התלקחות.

במקרה של דליפת נוזלים מהסוללה יש למנוע מגע עם העור או העיניים.

• הדבר עלול לגרום לכוויה בעור או נזק חמור לעיניים.

• במקרה שנוזל מהסוללה בא במגע עם חלק מן העור, יש לשטוף אותו מיד עם הרבה מים ולפנות לייעוץ רפואי.

אין לשטוף את אזור היציאה במים או חומר מלבין.

• מאחר שבאזור הכניסה נמצא מנוע, עלול להגרם התחשמלות או שריפה.

יש להשתמש אך ורק בתחנת הטעינה המצורפת למוצר על מנת לטעון את המוצר והסוללה.

• שימוש בהתקן טעינה כלשהו, למעט התחנה שסופקה,עלול לפגוע בסוללה ולגרום לשוק חשמלי, פיצוץ או שריפה.

• יש לשמור את הסוללות בסביבה יבשה

• זהירות סכנה אין להחליף את הסוללות, יש להשתמש אך ורק בסוללות המסופקות עם המכשיר

• כשהמכשיר אינו בשימוש זמן רב יש להוציא את הסוללה מהמכשיר

• יש להשתמש אך ורק בספק מתח טעינה המקורי מדגם ADC-30FSA-30 29430EPG ולא בשום תחליף אחר

MFL69883609_he_180115.indd 6 2018-01-15 오후 5:19:36

התקנה ושמוש

אין להתקין את המכשיר במקום החשוף למים,לגשם או ללחות.אין להשתמש במכשיר באזור פתוח או בסביבת בית מלאכה או מוסך.

- תנאי סביבה אלו עלולים לגרום להתלקחות המכשיר בעת הטענת הסוללה.
- נא התקן את המכשיר באזור מאוורר היטב.

המנע משימוש במכשיר במקומות שבהם ישנה סכנה של דליפת גז דליק, שמן תעשייתי או אבק מתכתי.

- עלול לגרום לנזק למוצר.

במידה שבכוונתך להשתמש בתחנת הטעינה ע"י העמדתה בצורה אנכית (סוג עמידה), יש לדאוג לאבטח אותו ע"י הצמדתו לקיר בעזרת ברגים מתאימים.

- שאם לא כן, עלולה תחנת הטעינה או המוצר לנטות אלכסונית ולהנזק או לגרום נזק לרכוש או לחבלה.

יש להניח את תחנת הטעינה על משטח אחיד.

- שאם לא כן, עלול המוצר ליפול ולהנזק או לגרום לחבלה.

במידה שבכוונתך לטעון את תחנת הטעינה על קיר (סוג מותקן על הקיר),יש להקפיד להדק אותו בחוזקה אל הקיר באמצעות הברגים המתאימים.

- שאם לא כן עלול המוצר להנזק ו/ או לגרום לחבלה.

אין להתקין את תחנת הטעינה על קיר עם צנרת (חשמל, מים) או בהמצאות כבלי חשמל מאחוריה.

- קיים סיכון של חבלה עקב שוק חשמלי, שריפה או הצפה.

דרישות כח חשמלי

מוצר זה ניתן לשימוש עם AC של 230 ואט בלבד. הקפד לבדוק את מפרט הכוח של המקום שבו בכוונתך להשתמש במוצר.

- מפרטים בלתי מתאימים עלולים לגרום להלם חשמלי או לנזק למוצר במקרה של קצר.

אין להפעיל כוח מופרז על כבל החשמל כדי לכופף אותו, או למקם אותו תחת חפץ כבד על מנת למנוע גרימת נזק לכבל החשמל.

- כבל החשמל עלול להנזק ולגרום לשוק חשמלי או לחבלה.

יש להמנע משימוש במספר מכשירי חשמל בלוח חשמל אחד או בשקע חשמל .כמו כן יש להקפיד ולהשתמש בשקע חשמל בעל קיבולת של 10A.

- אי ציות לכלל זה עלול לגרום לשריפה עקב התחממות יתר חריגה של השקע.
- או לחילופין, להפעיל את המפסק ולגרום בכך לאובדן כוח חשמלי.

אין לגעת בכבל החשמל ובתקע ביד רטובה.

- נגיעה ביד רטובה עלולה לגרום לחבלה או לשוק חשמלי.

יש לנקות אבק או מים מכבל החשמל והתקע באמצעות מטלית יבשה.

- אי ציות לכלל זה עלול לגרום לשוק חשמלי,קצר חשמלי או התלקחות.

בעת ניתוק כבל החשמל,אין למשוך את הכבל עצמו ויש לאחוז בתקע החשמל.

- אי ציות לכלל זה עלול לגרום לנזק לכבל ובכך לגרום לשוק חשמלי או התלקחות

במידה שכבל החשמל או תקע החשמל פגומים או שהחורים בשקע החשמל רופפים יש להפסיק את השימוש במוצר ולפנות למחלקת שירות הלקוחות של LG אלקטרוניקה.

- אי ציות לכלל זה עלול לגרום לשוק חשמלי או התלקחות.

הקפד לנתק את כבל החשמל בעת ניקוי או תחזוקת תחנת הטעינה.

- אי ציות לכלל זה עלול לגרום לחבלה או לשוק חשמלי.

הקפד לנתק את כבל החשמל כאשר המוצר אינו בשימוש במשך פרק זמן ממושך.

- אי ציות לכלל זה עלול לגרום לשוק חשמלי ,קצר חשמלי או התלקחות.

הקפד לאגד את כבל החשמל של תחנת הטעינה בעת שימוש או ניקוי המוצר.

- שאם לא כן עלול כבל החשמל להסתבך עם המוצר ולגרום לתקלה, לשוק חשמלי או לחבלה במידה שהוא מנותק או שבור.

הימנע מנגיעה בפינים של תקע החשמל עם האצבע בעת ניתוק כבל החשמל.

- הדבר עלול לגרום לשוק חשמלי או להתלקחות.

MFL69883609_he_180115.indd 5 2018-01-15 오후 5:19:36

אמצעי בטיחות

מדריך זה מכיל הודעות בטיחות חשובות רבות.

⚠ **זהו סמל התראה בטיחותית. סמל זה מתריע בפני סיכונים פוטנציאליים העלולים לגרום לנזק לרכוש ו / או לנזק גופני חמור ואף למוות.**

⚠ **אזהרה** **מציין מצב מסוכן אשר, אם לא נמנע, עלול לגרום למוות או לפציעה חמורה.**

⚠ **זהירות** **מציין מצב מסוכן אשר, אם לא נמנע, עלול לגרום לפציעה בינונית או קלה.**

⚠ אזהרה

1. מכשיר זה אינו מיועד לשימוש על ידי אנשים (כולל ילדים) עם יכולות פיזיות, חושיות או נפשיות מוגבלות, או חוסר ניסיון וידע .אלא אם כן ניתנה להם הדרכה לגבי השימוש במכשיר או שהשימוש מתבצע תחת השגחת אדם אחראי
2. יש לוודא שילדים לא ישחקו עם המכשיר
3. במידה שכבל החשמל פגום, יש להחליף אותו על ידי סוכן שרות של אל גי אלקטרוניקה על מנת למנוע נזק אפשרי
4. ילדים בני 8 ומעלה ואנשים עם יכולות פיזיות, חושיות או נפשיות מוגבלות או אנשים עם חוסר ניסיון וידע רשאים להשתמש בהתקן תחת השגחה או בתנאי שניתנה להם הדרכה לגבי שימוש בטיחותי במכשיר ולאחר שהבינו היטב את הסכנות הכרוכות בשימוש לא בטיחותי במכשיר. יש לאסור על ילדים לשחק במכשיר.אין לאפשר ניקוי ותחזוקת המכשיר בידי ילדים .ללא השגחה

MFL69883609_he_180115.indd 4 2018-01-15 오후 5:19:36

תוכן עניינים

מדריך משתמש זה עשוי להכיל תמונות או תוכן השונה מעט מהמוצר שנרכש.

אזהרות בטיחות 04

מידע על החבילה 10

התקנה 11

התקנת תחנת הטעינה 11
התקנת תחנה מורכבת על קיר 12
אחסנה של כלי שילוב וכלי הפינות 12

אופן השמוש 13

הערה על השמוש במוצר 13
שמוש במוצר 13
הטענת המוצר 14
לחצן כוח /עוצמת יניקה 14
שימוש במברשות 15

תחזוקה 16

ניקוי מיכל האבק 16
נקוי המסננים 16
ניקוי מברשת הרצפה והשטיח 18
נקוי ניקוי מברשת חובטת למיטה 18

נקודות לבדיקה לפני פנייה לשרות לקוחות 19

מידע על סילוק 20

סילוק של מוצרים ישנים שאינם קשורים עם רכישת מוצר חדש 20

מאפייני המוצר 20

MFL69883609_he_180115.indd 3 2018-01-15 오후 5:19:36

LG CordZero™

מדריך למשתמש
A9

לפני השימוש, קרא בעיון את דפי בטיחות הבטיחות כדי לאפשר הפעלה בטוחה של המוצר. לאחר קריאת מדריך זה, שמור אותו במיקום נגיש.

MFL69883609

www.lg.com

Copyright © 2018 LG Electronics Inc. All Rights Reserved.