



ENGLISH

OWNER'S MANUAL

Safety and Reference

LED TV*

* Disclaimer

LG LED TV applies LCD screen with LED backlights.

Please read this manual carefully before operating your set and retain it for future reference.



* M F L 7 1 8 0 9 9 5 0 *

(2204-REV01)

www.lg.com

Copyright © 2021 LG Electronics Inc. All Rights Reserved.

1 Warning! Safety instructions

2 Preparing

- Lifting and moving the TV
- Mounting on the Table
- Mounting to the Wall
- Antenna/Cable
- Satellite dish

3 Starting TV

- Turning on the TV
- Registering Magic Remote Control

4 Using Remote Control

- Using Magic Remote Control
- Using Remote Control

5 Connections

6 Troubleshooting

7 Specifications

- Open Source Software Notice Information
- Licenses

8 Regulatory

Before reading this manual

- Read this manual thoroughly before operating your TV, and keep it for future reference.
- On the website you can download the manual including installation, using, troubleshooting, specifications, license etc and view its contents on your PC or mobile device.

User Guide

For more information about this TV, read the USER GUIDE embedded in the product.

- To open the USER GUIDE  →  → [Support] → [User Guide]

Separate Purchase

- Separate purchase items can be changed or modified for quality improvement without any notification. Contact your dealer to buy these items. These devices only work with certain models.
- The model name or design may be changed depending on the upgrade of product functions, manufacturer's circumstances or policies.
- Magic Remote Control : **MR21GA**
Check whether your TV model supports Bluetooth in the Wireless Module Specification to verify whether it can be used with the Magic Remote.
- A cable to connect antennas and external devices must be purchased separately.

✓ Note

- Product specifications or contents of this manual may be changed without prior notice due to upgrade of product functions.
- The items supplied with your product may vary depending on the model.
- Image shown may differ from your TV.

1 Warning! Safety instructions



CAUTION : TO REDUCE THE RISK OF ELECTRIC SHOCK, DO NOT REMOVE COVER (OR BACK). NO USER-SERVICEABLE PARTS INSIDE. REFER TO QUALIFIED SERVICE PERSONNEL.

 This symbol is intended to alert the user to the presence of uninsulated "dangerous voltage" within the product's enclosure that may be of sufficient magnitude to constitute a risk of electric shock to persons.

 This symbol is intended to alert the user to the presence of important operating and maintenance (servicing) instructions in the literature accompanying the appliance.

WARNING : TO REDUCE THE RISK OF FIRE AND ELECTRIC SHOCK, DO NOT EXPOSE THIS PRODUCT TO RAIN OR MOISTURE.

- TO PREVENT THE SPREAD OF FIRE, KEEP CANDLES OR OTHER ITEMS WITH OPEN FLAMES AWAY FROM THIS PRODUCT AT ALL TIMES.

- **Do not place the TV and/or remote control in the following environments:**

- Keep the product away from direct sunlight.
- An area with high humidity such as a bathroom.
- Near any heat source such as stoves and other devices that produce heat.
- Near kitchen counters or humidifiers where they can easily be exposed to steam or oil.
- An area exposed to rain or wind.
- Do not expose to dripping or splashing and do not place objects filled with liquids, such as vases, cups, etc. on or over the apparatus (e.g., on shelves above the unit).
- Near flammable objects such as gasoline or candles, or expose the TV to direct air conditioning.
- Do not install in excessively dusty places.

Otherwise, this may result in fire, electric shock, combustion/explosion, malfunction or product deformation.

- **Ventilation**

- Install your TV where there is proper ventilation. Do not install in a confined space such as a bookcase.
- Do not install the product on a carpet or cushion.
- Do not block or cover the product with cloth or other materials while unit is plugged in.
- Take care not to touch the ventilation openings. When watching the TV for a long period, the ventilation openings may become hot.
- Protect the power cord from physical or mechanical abuse, such as being twisted, kinked, pinched, closed in a door, or walked upon. Pay particular attention to plugs, wall outlets, and the point where the cord exits the device.
- Do not move the TV whilst the Power cord is plugged in.
- Do not use a damaged or loosely fitting power cord.
- Be sure to grasp the plug when unplugging the power cord. Do not pull on the power cord to unplug the TV.
- Do not connect too many devices to the same AC power outlet as this could result in fire or electric shock.

- **Disconnecting the Device from the Main Power**
 - The power plug is the disconnecting device. In case of an emergency, the power plug must remain readily accessible.
- Do not let your children climb or cling onto the TV. Otherwise, the TV may fall over, which may cause serious injury.
- **Outdoor Antenna Grounding** (Can differ by country):
 - If an outdoor antenna is installed, follow the precautions below.

An outdoor antenna system should not be located in the vicinity of overhead power lines or other electric light or power circuits, or where it can come in contact with such power lines or circuits as death or serious injury can occur.
- **Grounding** (Except for devices which are not grounded.)
 - TV with a three-prong grounded AC plug must be connected to a three-prong grounded AC outlet. Ensure that you connect the earth ground wire to prevent possible electric shock.
- Never touch this apparatus or antenna during a lightning storm. You may be electrocuted.
- Make sure the power cord is connected securely to the TV and wall socket if not secured damage to the Plug and socket may occur and in extreme cases a fire may break out.
- Do not insert metallic or inflammable objects into the product. If a foreign object is dropped into the product, unplug the power cord and contact the customer service.
- Do not touch the end of the power cord while it is plugged in. You may be electrocuted.

- **If any of the following occur, unplug the product immediately and contact your local customer service.**
 - The product has been damaged.
 - If water or another substance enters the product (like an AC adapter, power cord, or TV).
 - If you smell smoke or other odors coming from the TV.
 - When lightning storms or when unused for long periods of time.
- Even the TV is turned off by remote control or button, AC power source is connected to the unit if not unplugged in.
- Do not use high voltage electrical equipment near the TV (e.g., a bug zapper). This may result in product malfunction.
- Do not attempt to modify this product in any way without written authorization from LG Electronics. Accidental fire or electric shock can occur. Contact your local customer service for service or repair. Unauthorized modification could void the user's authority to operate this product.
- Use only an authorized attachments / accessories approved by LG Electronics. Otherwise, this may result in fire, electric shock, malfunction, or product damage.
- Never disassemble the AC adapter or power cord. This may result in fire or electric shock.
- Handle the adapter carefully to avoid dropping or striking it. An impact could damage the adapter.
- To reduce the risk of fire or electrical shock, do not touch the TV with wet hands. If the power cord prongs are wet or covered with dust, dry the power plug completely or wipe dust off.

- **Batteries**

- Store the accessories (battery, etc.) in a safe location out of the reach of children.
- Do not short circuit, disassemble, or allow the batteries to overheat. Do not dispose of batteries in a fire. Batteries should not be exposed to excessive heat.
- Caution: Risk of fire or explosion if the battery is replaced by an incorrect type.

- **Moving**

- When moving, make sure the product is turned off, unplugged, and all cables have been removed. It may take 2 or more people to carry larger TVs. Do not press or put stress on the front panel of the TV. Otherwise, this may result in product damage, fire hazard or injury.
- Keep the packing anti-moisture material or vinyl packing out of the reach of children.
- Do not allow an impact shock, any objects to fall into the product, and do not drop anything onto the screen.
- Do not press strongly upon the panel with a hand or a sharp object such as a nail, pencil, or pen, or make a scratch on it. It may cause damage to screen.

- **Cleaning**

- When cleaning, unplug the power cord and wipe gently with a soft/dry cloth. Do not spray water or other liquids directly on the TV. Do not clean your TV with chemicals including glass cleaner, any type of air freshener, insecticide, lubricants, wax (car, industrial), abrasive, thinner, benzene, alcohol etc., which can damage the product and/or its panel. Otherwise, this may result in electric shock or product damage.

2 Preparing

Lifting and moving the TV


Please note the following advice to prevent the TV from being scratched or damaged and for safe transportation regardless of its type and size.

- It is recommended to move the TV in the box or packing material that the TV originally came in.
- Before moving or lifting the TV, disconnect the power cord and all cables.


- When holding the TV, the screen should face away from you to avoid damage.



- Hold the top and bottom of the TV frame firmly. Make sure not to hold the transparent part, speaker, or speaker grill area.



- When transporting a large TV, there should be at least 2 people.
- When transporting the TV by hand, hold the TV as shown in the following illustration.




- When transporting the TV, do not expose the TV to jolts or excessive vibration.
- When transporting the TV, keep the TV upright, never turn the TV on its side or tilt towards the left or right.
- Do not apply excessive pressure to cause flexing / bending of frame chassis as it may damage screen.
- When handling the TV, be careful not to damage the protruding buttons.



- Avoid touching the screen at all times, as this may result in damage to the screen.
- When attaching the stand to the TV set, place the screen facing down on a cushioned table or flat surface to protect the screen from scratches.

Mounting on the Table

- 1 Lift and tilt the TV into its upright position on a table.
 - Leave a 10 cm (minimum) space from the wall for proper ventilation.
- 2 Connect the power cord to a wall outlet.




(Depending on model)



- Do not apply foreign substances (oils, lubricants, etc.) to the screw parts when assembling the product.
(Doing so may damage the product.)
- If you install the TV on a stand, you need to take actions to prevent the product from overturning. Otherwise, the product may fall over, which may cause injury.
- Do not use any unapproved items to ensure the safety and product life span.
- Any damage or injuries caused by using unapproved items are not covered by the manufacturer's warranty.
- Make sure that the screws are inserted correctly and fastened securely. (If they are not fastened securely enough, the TV may tilt forward after being installed.) Do not use too much force and over tighten the screws; otherwise screw may be damaged and not tighten correctly.
- If a television is not positioned in a sufficiently stable location, it can be potentially hazardous due to falling. Many injuries, particularly to children, can be avoided by taking simple precautions such as:
 - Using cabinets or stands recommended by the manufacturer of the television.
 - Only using furniture that can safely support the television.
 - Ensuring the television is not overhanging the edge of the supporting furniture.
 - Not placing the television on tall furniture (for example, cupboards or bookcases) without anchoring both the furniture and the television to a suitable support.
 - Not standing the televisions on cloth or other materials placed between the television and supporting furniture.
 - Educating children about the dangers of climbing on furniture to reach the television or its controls.

Securing TV to the Wall


- 1 Insert and tighten the eye-bolts, or TV brackets and bolts on the back of the TV.
 - If there are bolts inserted at the eye-bolts position, remove the bolts first.
- 2 Mount the wall brackets with the bolts to the wall. Match the location of the wall bracket and the eye-bolts on the rear of the TV.
- 3 Connect the eye-bolts and wall brackets tightly with a sturdy rope. Make sure to keep the rope horizontal with the flat surface.
 - Use a platform or cabinet that is strong and large enough to support the TV securely.
 - Brackets, bolts and ropes are not provided. You can obtain additional accessories from your local dealer.



(Depending on model)

Mounting to the Wall


Attach an optional wall mount bracket at the rear of the TV carefully and install the wall mount bracket on a solid wall perpendicular to the floor. When you attach the TV to other building materials, please contact qualified personnel. LG recommends that wall mounting be performed by a qualified professional installer. We recommend the use of LG's wall mount bracket. LG's wall mount bracket is easy to move with cables connected. When you do not use LG's wall mount bracket, please use a wall mount bracket where the device is adequately secured to the wall with enough space to allow connectivity to external devices. It is advised to connect all the cables before installing fixed wall mounts.



(Depending on model)




- Remove the stand before installing the TV on a wall mount by performing the stand attachment in reverse.
- For more information of screws and wall mount bracket, refer to the Separate Purchase.
- If you intend to mount the product to a wall, attach VESA standard mounting interface (optional parts) to the back of the product. When you install the set to use the wall mounting bracket (optional parts), fix it carefully so as not to drop.
- When mounting a TV on the wall, make sure not to install the TV by hanging the power and signal cables on the back of the TV.
- Do not install this product on a wall if it could be exposed to oil or oil mist. This may damage the product and cause it to fall.
- Do not use a sharp object when you detached the cable cover. This could damage the cable or the cabinet. It may also cause personal harm.
(Depending on model)



(Depending on model)

- When installing the wall mounting bracket, it is recommended to cover the stand hole using tape, in order to prevent the influx of dust and insects. (Depending on model)




(Depending on model)


Wall Mounting Bracket

(Depending on model)

Make sure to use screws and wall mount bracket that meet the VESA standard. Standard dimensions for the wall mount kits are described in the following table.



Model	43/50UP77* 43/50UP78* 43/50UP80* 43/50UP81*	55/60/65UP77* 55/65UP78* 55/60/65UP80* 55/65UP81*
Screws distance (A) (mm)	200	300
Standard screw	M6	M6
Number of screws	2	2
Wall mount bracket	WB21LMB	WB21LMB



Model	43/50UP75*	55UP75*	65UP75*	70/75UP77*	70/75UP75*
	43/50UP77*	55UP77*	60/65UP77*	70/75UP78*	82/86UP80*
	43/50UP78*	55UP78*	65UP78*	70/75UP78*	
	43/50UP80*	55UP80*	60/65UP80*	70/75UP80*	
	43/50UP81*	55UP81*	65UP81*		
VESA (A x B) (mm)	200 x 200	300 x 300	300 x 300	400 x 400	600 x 400
Standard screw	M6	M6	M6	M6	M8
Number of screws	4	4	4	4	4
Wall mount bracket	LSW240B MSW240	OLW480B MSW240	OLW480B	LSW440B	LSW640B

Antenna/Cable

Connect the TV to a wall antenna socket with an RF cable (75 Ω).

- Use a signal splitter to use more than 2 TVs.
- If the image quality is poor, install a signal amplifier properly to improve the image quality.
- If the image quality is poor with an antenna connected, try to realign the antenna in the correct direction.
- An antenna cable and converter are not supplied.
- For a location that is not supported with Ultra HD broadcasting, this TV cannot receive Ultra HD broadcasts directly.

Satellite dish

Connect the TV to a satellite dish to a satellite socket with a satellite RF cable (75 Ω). (Depending on model)

3 Starting TV

Turning on the TV

You can simply operate the TV functions, using the button.



Using button



Power On (Press)

Power Off¹⁾ (Press and Hold)

Menu Control (Press²⁾)

Menu Selection (Press and Hold³⁾)

- 1) All running apps will close, and any recording in progress will stop.
- 2) You can access and adjust the menu by pressing the button when TV is on.
- 3) You can use the function when you access menu control.



- If the TV is turned on for the first time after it was shipped from the factory, initialization of the TV may take a few minutes.

Adjusting the menu

When the TV is turned on, press the  button one time. You can adjust the Menu items using the button.



Turns the power off.



Changes the input source.



Adjusts the volume level.



Scrolls through the saved programmes.



- Your TV's OSD (On Screen Display) may differ slightly from that shown in this manual.
- The available menus and options may differ from the input source or product model that you are using.
- New features may be added to this TV in the future.
- The device must be easily accessed to a location outlet near the access. Some devices are not made by turning on / off button, turning off the device and unplugging the power cord.


Inserting the battery

(Depending on model)

- When the message [Magic Remote battery is low. Please change the battery.] is displayed, replace the battery. To replace batteries, open the battery cover, replace batteries (1.5 V AA) matching the $+$ and $-$ ends to the label inside the compartment, and close the battery cover.



- To replace batteries, open the battery cover, replace batteries (1.5 V AAA) matching the $+$ and $-$ ends to the label inside the compartment, and close the battery cover.



- Do not mix new batteries with old batteries. This may cause the batteries to overheat and leak.
- Failure to match the correct polarities of the battery may cause the battery to burst or leak, resulting in fire, personal injury, or ambient pollution.
- This apparatus uses batteries. In your community there might be regulations that require you to dispose of these batteries properly due to environmental considerations. Please contact your local authorities for disposal or recycling information.
- Batteries inside or inside the product shall not be exposed to excessive heat such as sunshine, fire or the like.
- In Analogue TV and some countries, some remote control buttons may not work.

Registering Magic Remote Control

How to register the Magic Remote Control

To use the Magic Remote, first pair it with your TV.

- Put batteries into the Magic Remote and turn the TV on.
 - Point the Magic Remote at your TV and press the \odot **Wheel (OK)** on the remote control.
- * If the TV fails to register the Magic Remote, try again after turning the TV off and back on.

How to deregister the Magic Remote Control

Press the \leftarrow **(Back)** and HH **(Home)** buttons at the same time, for five seconds, to unpair the Magic Remote with your TV.

- * Press and hold the HH **(Home)** and \odot **(Q. Settings)** buttons for more than 5 seconds to disconnect and re-register the Magic Remote at the same time.

- It is recommended that an Access Point (AP) be located more than 0.2 m away from the TV. If the AP is installed closer than 0.2 m, the Magic remote control may not perform as expected due to frequency interference.

4 Using Remote Control

Using Magic Remote Control

(Depending on model)

The descriptions in this manual are based on the buttons on the remote control. Please read this manual carefully and use the TV correctly.

	Power Turns the TV on or off.		Number buttons Enters numbers.
	—(Dash) Inserts a — between numbers such as 2-1 and 2-2.		Accesses the [Quick Help].
	 Accesses the saved programmes list.  Accesses the [Guide].		More actions Displays more remote control functions.
	 Accesses the [Edit Quick Access]. - [Edit Quick Access] is a feature that allows you to enter a specified app or Live TV directly by pressing and holding the number buttons.		AD/SAP* Audio descriptions function will be enabled.
	Volume buttons Adjusts the volume level.		Mute Mutes all sounds.
	Programme buttons Scrolls through the saved programmes.		Voice recognition Network connection is required to use the voice recognition function.
	Home Accesses the Home menu.		Check for recommended content. (Some recommended services may not be available in some countries.)
	Home Launches the last used apps.		Voice recognition Speak while pressing and holding the button to use the voice recognition feature.
	Input Changes the input source.		Up/Down/Left/Right Press the up, down, left or right button to scroll the menu. If you press  buttons while the pointer is in use, the pointer will disappear from the screen and Magic Remote will operate like a general remote control. To display the pointer on the screen again, shake Magic Remote to the left and right.
	Input Accesses the [Home Dashboard].		Q. Settings Accesses the Quick Settings.
	Wheel (OK) Press the centre of  button to select a menu. You can change channels by using  button.		Q. Settings Displays the [All Settings] menu.
	Wheel (OK) Accesses the [Magic Explorer]. You can run the [Magic Explorer] feature when the pointer colour is changed to purple. If watching a programme, press and hold down the pointer onto the video. When using [TV Guide], [Settings], [Sports Alert], or [Art Gallery], press and hold down on the text.		These access special functions in some menus.
	Back Returns to the previous level.		Red button Runs the record function.
	Back Clears on-screen displays and returns to last input viewing.		Streaming Service buttons Connects to the Video Streaming Service.
			Home Dashboard Accesses the [Home Dashboard]. (Depending On Country)
			User Guide Accesses the [User Guide]. (Depending On Country)
			Accesses your favorite programmes list. (Depending On Country)
			Control buttons Controls media contents. (Depending On Country)

(Some buttons and services may not be provided depending on models or regions.)



**** To use the button, press and hold for more than 1 second.**

- In Analogue TV and some countries, some remote control buttons may not work.

Using Remote Control

(Depending on model)

The descriptions in this manual are based on the buttons on the remote control. Please read this manual carefully and use the TV correctly.



Power Turns the TV on or off.

Accesses the saved programmes list.

Shows programme guide.

Teletext buttons These buttons are used for teletext.

Edits QUICK ACCESS. (Depending on model)

- QUICK ACCESS is a feature that allows you to enter a specified app or Live TV directly by pressing and holding the number buttons.

Volume buttons Adjusts the volume level.

Programme buttons Scrolls through the saved programmes


Home Accesses the Home menu

Home Launches the last used apps.

Input Changes the input source

OK Selects menus or options and confirms your input.

OK Accesses the [Magic Explorer]. When using [TV Guide], [Settings], [Sports Alert], or [Art Gallery], press and hold down on the text.



9 **

...

1 AD

1 ...

...

...

...

...

...

...

...

...

...

...

...

...

...

...

...

...

...

...

...

...

...

...

Number buttons Enters numbers

Accesses the [Quick Help].

More actions Displays more remote control functions.

Audio descriptions function will be enabled. (Depending on model)

Recalls your preferred subtitle in digital mode. (Depending on model)

Mute Mutes all sounds.

Mute Accesses the [Accessibility] menu

Navigation buttons (up/down/left/right) Scrolls through menus or options.

Q. Settings Accesses the Quick Settings.

Back Returns to the previous level.

Search Check for recommended content. (Some recommended services may not be available in some countries.)

Search for content such as TV programmes, movies and other videos, or perform a web search by entering text in the search bar.

You can watch TV or LG Channels.

Clears on-screen displays and returns to TV viewing.

Control buttons Control buttons for media contents.

These access special functions in some menus.

Streaming Service buttons Connects to the Video Streaming Service.

Home dashboard Accesses the [Home Dashboard]. (Depending On Country)

User Guide Accesses the [User Guide]. (Depending On Country)

Accesses your favourite programme list. (Depending On Country)

Starts to record and displays record menu. (Only Time Machine^{Ready} supported model)

(Some buttons and services may not be provided depending on models or regions.)

✓ Note

**** To use the button, press and hold for more than 1 second.**

- In Analogue TV and some countries, some remote control buttons may not work.

5 Connections

Connect various external devices to the TV and switch input modes to select an external device. For more information of external device's connection, refer to the manual provided with each device.

HDMI

- When connecting the HDMI cable, the product and external devices should be turned off and unplugged.



- Supported HDMI Audio format (Depending on model):

True HD (48 kHz),
Dolby Digital / Dolby Digital Plus (32 kHz / 44.1 kHz / 48 kHz),
PCM (32 kHz / 44.1 kHz / 48 kHz / 96 kHz / 192 kHz)

Note

If the device connected to Input Port also supports HDMI Deep Colour, your picture may be clearer. However, if the device doesn't support it, it may not work properly. In that case, connect the device to a different HDMI port or change the TV's [HDMI Deep Colour] setting to off.

- → → [General] → [Devices] → [HDMI Settings] → [HDMI Deep Colour] (Only 82/86UP80*)

- On : Support 4K @ 50/60 Hz (4:4:4, 4:2:2, 4:2:0),
<3,4 port Only> 4K @ 100/120 Hz (4:4:4, 4:2:2, 4:2:0)
- Off : Support 4K @ 50/60 Hz (4:2:0)

(Except for 82/86UP80*)

- On : Support 4K @ 50/60 Hz (4:4:4, 4:2:2, 4:2:0)
- Off: Support 4K @ 50/60 Hz (4:2:0)


- Use a certified cable with the HDMI logo attached.

- If you do not use a certified HDMI cable, the screen may not display or a connection error may occur.

- Recommended HDMI Cable Types
 - Ultra High Speed HDMI®/™ cable (3 m or less)



USB

Some USB Hubs may not work. If a USB device connected using a USB Hub is not detected, connect it to the USB port on the TV directly.



Note

- For an optimal connection, HDMI cables and USB devices should have bezels less than 10 mm thick, 18 mm width and 8 mm a wire diameter. Use an extension cable that supports USB 2.0 or higher if the USB cable or USB memory stick does not fit into your TV's USB port. (Depending on model)




* A ≤ 10 mm

* B ≤ 18 mm

* C ≤ 8 mm

CI module

View the encrypted (pay) services in digital TV mode. (Depending on model)



✓ Note

- Check if the CI module is inserted into the **COMMON INTERFACE** in the right direction. If the module is not inserted properly, this can cause damage to the TV and the **COMMON INTERFACE**.
- If the TV does not display any video and audio when CI+ CAM is connected, please contact to the Terrestrial/Cable/Satellite Service Operator.

External Devices

Available external devices are: Blu-ray player, HD receivers, DVD players, VCRs, audio systems, USB storage devices, PC, gaming devices, and other external devices.

✓ Note

- The external device connection may differ from the model.
- Connect external devices to the TV regardless of the order of the TV port.
- If you record a TV program on a Blu-ray/DVD recorder or VCR, make sure to connect the TV signal input cable to the TV through a DVD recorder or VCR. For more information of recording, refer to the manual provided with the connected device.
- Refer to the external equipment's manual for operating instructions.
- If you connect a gaming device to the TV, use the cable supplied with the gaming device.
- In PC mode, there may be noise associated with the resolution, vertical pattern, contrast or brightness. If noise is present, change the PC output to another resolution, change the refresh rate to another rate or adjust the brightness and contrast on the [Picture] menu until the picture is clear.
- In PC mode, some resolution settings may not work properly depending on the graphics card.
- If Ultra HD content is played on your PC, video or audio may become disrupted intermittently depending on your PC's performance. (Depending on model)
- When connecting via a wired LAN, it is recommended to use a CAT 7 cable. (Only when **LAN** port is provided.)

6 Troubleshooting

Cannot control the TV with the remote control.	<ul style="list-style-type: none">Check the remote control sensor on the product and try again.Check if there is any obstacle between the product and the remote control.Check if the batteries are still working and properly installed (⊕ to ⊕, ⊖ to ⊖).
No image display and no sound is produced.	<ul style="list-style-type: none">Check if the product is turned on.Check if the power cord is connected to a wall outlet.Check if there is a problem in the wall outlet by connecting other products.
The TV turns off suddenly.	<ul style="list-style-type: none">Check the power control settings. The power supply may be interrupted.Check if the auto-off function is activated on the settings related time.If there is no signal while the TV is on, the TV will turn off automatically after 15 minutes of inactivity.
When connecting to the PC (HDMI), no signal is detected.	<ul style="list-style-type: none">Turn the TV off/on using the remote control.Reconnect the HDMI cable.Restart the PC with the TV on.
Abnormal Display	<ul style="list-style-type: none">If the product feels cold to the touch, there may be a small "flicker" when it is turned on. This is normal, there is nothing wrong with product.This panel is an advanced product that contains millions of pixels. You may see tiny black dots and/or brightly coloured dots (red, blue or green) at a size of 1 ppm on the panel. This does not indicate a malfunction and does not affect the performance and reliability of the product. This phenomenon also occurs in third-party products and is not subject to exchange or refund.You may find different brightness and colour of the panel depending on your viewing position(left/right/top/down). This phenomenon occurs due to the characteristic of the panel. It is not related with the product performance, and it is not malfunction.Displaying a still image for a prolonged period of time may cause image sticking. Avoid displaying a fixed image on the TV screen for a long period of time.
Generated Sound	<ul style="list-style-type: none">"Cracking" noise: A cracking noise that occurs when watching or turning off the TV is generated by plastic thermal contraction due to temperature and humidity. This noise is common for products where thermal deformation is required.Electrical circuit humming/panel buzzing: A low level noise is generated from a high-speed switching circuit, which supplies a large amount of current to operate a product. It varies depending on the product. This generated sound does not affect the performance and reliability of the product.



- When cleaning the product, be careful not to allow any liquid or foreign objects to enter the gap between the upper, left or right side of the panel and the guide panel.
(Depending on model)



- Make sure to wring any excess water or cleaner from the cloth.
- Do not spray water or cleaner directly onto the TV screen.
- Make sure to spray just enough of water or cleaner onto a dry cloth to wipe the screen.

7 Specifications

(Depending on country)

Broadcasting Specifications		
	Digital TV	Analogue TV
Television system	DVB-T/T2 ¹⁾ DVB-T/T2/C/S/S2 ²⁾	PAL B/B, PAL B/G, PAL D/K, PAL-I SECAM B/G, SECAM D/K NTSC-M
Programme coverage	VHF, UHF C-Band ²⁾ , Ku-Band ²⁾	VHF, UHF, CATV
Maximum number of storable programmes	DVB-T/T2 & Analogue TV : 3,000 DVB-S/S2 : 6,000	
External antenna impedance	75 Ω	
CI Module³⁾ (W x H x D)	100.0 mm x 55.0 mm x 5.0 mm	

1) Only DVB-T2 support models. Despite DVB-T2 model, DVB-T/T2 function does not apply in Philippines.

2) Only DVB-T2/C/S2 support models.

3) Depending on model.

After Sales Service (Egypt Only)

Shelf Life Time : 3 Years

LG is committed to providing all spare parts of this device during the shelf life time.

(Depending on country)
(Only 82/86UP80*)

Wireless module (LGSBWAC95) specifications

Wireless LAN (IEEE 802.11a/b/g/n/ac)

Frequency range	Output Power (Max.)
2,400 to 2,483.5 MHz	19 dBm
5,150 to 5,725 MHz	18 dBm
5,725 to 5,850 MHz	13.5 dBm

Bluetooth

Frequency range	Output Power (Max.)
2,400 to 2,483.5 MHz	9 dBm

As band channels can vary per country, the user cannot change or adjust the operating frequency. This product is configured for the regional frequency table.

For consideration of the user, this device should be installed and operated with a minimum distance of 20 cm between the device and the body.

(Only Oman)

OMAN-TRA

D172249

TRA/TA-R/9674/20

(Only Vietnam)
(Only 82/86UP80*)

Wireless module (LGSBWAC95) specifications

Wireless LAN (IEEE 802.11a/b/g/n/ac)

Frequency range	Output Power (Max.)
2,400 to 2,483.5 MHz	17.5 dBm
5,150 to 5,725 MHz	17.5 dBm
5,725 to 5,850 MHz	13.5 dBm

Bluetooth

Frequency range	Output Power (Max.)
2,400 to 2,483.5 MHz	9 dBm

As band channels can vary per country, the user cannot change or adjust the operating frequency. This product is configured for the regional frequency table.

For consideration of the user, this device should be installed and operated with a minimum distance of 20 cm between the device and the body.

(Depending on country)
(Only 70/75UP75*)

Wireless module (LGSBWAC02) specifications

Wireless LAN (IEEE 802.11a/b/g/n/ac)

Frequency range	Output Power (Max.)
2,400 to 2,483.5 MHz	17 dBm
5,150 to 5,725 MHz	19 dBm
5,725 to 5,850 MHz	10.5 dBm

Bluetooth

Frequency range	Output Power (Max.)
2,400 to 2,483.5 MHz	8.5 dBm

As band channels can vary per country, the user cannot change or adjust the operating frequency. This product is configured for the regional frequency table.

For consideration of the user, this device should be installed and operated with a minimum distance of 20 cm between the device and the body.

(Only Oman)

OMAN-TRA

D172338

TRA/TA-R/8042/19

(Only Vietnam)
(Only 70/75UP75*)

Wireless module (LGSBWAC02) specifications

Wireless LAN (IEEE 802.11a/b/g/n/ac)

Frequency range	Output Power (Max.)
2,400 to 2,483.5 MHz	17 dBm
5,150 to 5,350 MHz	17.5 dBm
5,725 to 5,850 MHz	10.5 dBm

Bluetooth

Frequency range	Output Power (Max.)
2,400 to 2,483.5 MHz	8.5 dBm

As band channels can vary per country, the user cannot change or adjust the operating frequency. This product is configured for the regional frequency table.

For consideration of the user, this device should be installed and operated with a minimum distance of 20 cm between the device and the body.

(Depending on country)
(Except for 82/86UP80*, 70/75UP75*)

Wireless module (LGSBWAC03) specifications

Wireless LAN (IEEE 802.11a/b/g/n/ac)

Frequency range	Output Power (Max.)
2,400 to 2,483.5 MHz	18.5 dBm
5,150 to 5,725 MHz	19.5 dBm
5,725 to 5,850 MHz	11.5 dBm

Bluetooth

Frequency range	Output Power (Max.)
2,400 to 2,483.5 MHz	9 dBm

As band channels can vary per country, the user cannot change or adjust the operating frequency. This product is configured for the regional frequency table.

For consideration of the user, this device should be installed and operated with a minimum distance of 20 cm between the device and the body.

(Only Oman)

OMAN-TRA

D172249

TRA/TA-R/9673/20

(Only Vietnam)
(Except for 82/86UP80*, 70/75UP75*)

Wireless module (LGSBWAC03) specifications

Wireless LAN (IEEE 802.11a/b/g/n/ac)

Frequency range	Output Power (Max.)
2,400 to 2,483.5 MHz	17.5 dBm
5,150 to 5,725 MHz	17.5 dBm
5,725 to 5,850 MHz	11.5 dBm

Bluetooth

Frequency range	Output Power (Max.)
2,400 to 2,483.5 MHz	9 dBm

As band channels can vary per country, the user cannot change or adjust the operating frequency. This product is configured for the regional frequency table.

For consideration of the user, this device should be installed and operated with a minimum distance of 20 cm between the device and the body.

Environment condition	
Operating Temperature	0 °C to 40 °C
Operating Humidity	Less than 80 %
Storage Temperature	-20 °C to 60 °C
Storage Humidity	Less than 85 %

- The energy information provided with the product is indicated in accordance with the regulations of each country. (Depending on Country)
 - The Energy consumption is measured in accordance with IEC 62087.
- Actual Energy consumption may vary depending on factors such as the type of video content being played and TV settings.
- For information of the power supply and power consumption, refer to the label attached to the product. (Depending on Country)
 - * On some models, the label is inside the external device connection terminal cover.

(Only Nigeria)

Connection and use of this communications equipment is permitted by the Nigerian Communications Commission

Open Source Software Notice Information

To obtain the source code under GPL, LGPL, MPL, and other open source licenses, that is contained in this product, please visit <https://opensource.lge.com>.

In addition to the source code, all referred license terms, warranty disclaimers and copyright notices are available for download.

LG Electronics will also provide open source code to you on CD-ROM for a charge covering the cost of performing such distribution (such as the cost of media, shipping, and handling) upon email request to opensource@lge.com.

This offer is valid for a period of three years after our last shipment of this product. This offer is valid to anyone in receipt of this information.

Licenses



QUICKSET™

(Magic Remote supported models only)



Use of any third party applications and/or services enabled on the Smart TVs require third party licences or subscriptions and are subject to the third party applications and/or services Terms of Use.

It is the responsibility of the customers and/or user to ensure that they comply with the Terms of Use and do not use the third party applications and/or services for commercial purposes, unless an appropriate license has been obtained.

Breach of the terms of use or misuse of third party applications and/or services may infringe third party intellectual property rights including copyright law and is not authorized or sanctioned by LG.

8 Regulatory

WARNING! (STABILITY HAZARD)

A television set may fall, causing serious personal injury or death. Many injuries, particularly to children, can be avoided by taking simple precautions such as:

- ALWAYS use cabinets or stands or mounting methods recommended by the manufacturer of the television set.
- ALWAYS use furniture that can safely support the television set.
- ALWAYS ensure the television set is not overhanging the edge of the supporting furniture.
- ALWAYS educate children about the dangers of climbing on furniture to reach the television set or its controls.
- ALWAYS route cords and cables connected to your television so they cannot be tripped over, pulled or grabbed.
- NEVER place a television set in an unstable location.
- NEVER place the television set on tall furniture (for example, cupboards or bookcases) without anchoring both the furniture and the television set to a suitable support.
- NEVER place the television set on cloth or other materials that may be located between the television set and supporting furniture.
- NEVER place items that might tempt children to climb, such as toys and remote controls, on the top of the television or furniture on which the television is placed.

If the existing television set is going to be retained and relocated, the same considerations as above should be applied.

Symbols

~	Refers to alternating current (AC).	⊕	Refers to stand-by.
---	Refers to direct current (DC).		Refers to "ON" (power).
□	Refers to class II equipment.	⚡	Refers to dangerous voltage.

(Only Jordan)

CE



The model and serial number of the product are located on the back and on one side of the product. Record them below in case you ever need service.

Model _____

Serial No. _____



تجد طراز المنتج ورقمه التسلسلي على الجهة الخلفية منه وعلى أحد جوانبه. ذُرّنها أدناه في حال احتجت إلى أي خدمة.

الطراز

الرقم التسلسلي.

(الأردن فقط)

CE

8 معلومات تنظيمية

تحذير (خطر الثبات)

قد يقع جهاز التلفاز مسبباً إصابات خطيرة أو الوفاة. يمكن تجنب حدوث العديد من الإصابات، خصوصاً للأطفال من خلال اتخاذ إجراءات بسيطة مثل:

- استخدم دائمًا هيكل أو حوامل أو طرق تركيب توصي بها الجهة المصنعة للتلفاز.
 - استخدم دائمًا قطعة الأثاث التي يمكنها تحمل وزن التلفاز بشكل آمن.
 - تأكّد دائمًا أن التلفاز في موضع لا يتجاوز فيه طرف قطعة الأثاث الموضوع عليها.
 - قم دائمًا بتوجيه الأطفال بمخاطر تسلق قطعة الأثاث للوصول إلى التلفاز أو عناصر التحكم الخاصة به.
 - قم دائمًا بتوجيه الأسلاك والكابلات المتصلة بالتلفاز الخاص بك بحيث لا يتم التئر فيها أو سحبها أو الإمساك بها.
 - لا تضع التلفاز في موقع غير ثابت أبداً.
 - لا تضع التلفاز على قطعة أثاث طويلة أبداً (على سبيل المثال، خزانات أو خزانات كتب) من دون تثبيت قطعة الأثاث والتلفاز بدعامة مناسبة.
 - لا تضع التلفاز على قماش أو مواد أخرى قد تكون بين التلفاز وقطعة الأثاث الحاملة له.
 - لا تضع العناصر التي قد تغير الأطفال بالتساقط أبداً، مثل الألعاب والريموت، فوق التلفاز أو قطعة الأثاث الموضوع عليها التلفاز.
- إذا كان سيتم الاحتفاظ بمجموعة التلفاز الحالية ونقلها، يجب تطبيق الاعتبارات الواردة أعلاه نفسها.

الرموز

Ⓐ	يشير إلى وضع الاستعداد.	Ⓑ	يشير إلى التيار المتردد (AC).
☰	يشير إلى "تشغيل" (الطاقة).	☰	يشير إلى التيار المستمر (DC).
▢	يشير إلى الفولتية الخطيرة.	▢	يشير إلى أجهزة الفتنة .

معلومات حول إشعار البرامج المفتوحة المصدر

للحصول على التعليمات البرمجية المصدر بموجب GPL و LGPL و MPL و تراخيص مفتوحة المصدر أخرى يتضمنها هذا المنتج، يرجى زيارة الموقع <https://opensource.lge.com>.

بالإضافة إلى التعليمات البرمجية المصدر، تتوفّر كل أحكام الترخيص وإشعارات إخلاء المسؤولية وإشعارات حقوق النشر للتنزيل. ستوفّر LG Electronics أيضاً التعليمات البرمجية المفتوحة المصدر على قرص CD-ROM مقابل رسوم يغطي تكفة القيام بهذا التوزيع (مثل تكلفة وسائل النقل والشحن والتسلیم) بناءً على طلب يُرسل عبر البريد الإلكتروني إلى opensource@lge.com. إن هذا العرض سارٍ لفترة ثلاثة سنوات بعد عملية الشحن الأخيرة لهذا المنتج. يتوفر هذا العرض لأي شخص يلتقي هذه المعلومات.

التراخيص



QUICKSET™

(الطرازات التي تدعم الريموت السحري Magic فقط)



يتطلب استخدام أي تطبيقات و/أو خدمات تابعة لجهات خارجية ممكناً على أجهزة التلفاز الذكية تراخيص أو اشتراكات من جهة خارجية وتتضمّن لشروط استخدام تطبيقات و/أو خدمات الجهة الخارجية.

يتحمل العملاء و/أو المستخدم مسؤولية التأكيد من امتثالهم لشروط الاستخدام وعدم استخدام تطبيقات و/أو خدمات الجهة الخارجية لأغراض تجارية، ما لم يتم الحصول على الترخيص المناسب.

قد يشكل خرق شروط الاستخدام أو إساءة استخدام تطبيقات و/أو خدمات الجهات الخارجية تعدّياً على حقوق الملكية الفكرية للجهة الخارجية بما في ذلك قانون حقوق النشر وهو أمر غير مصرح به أو مجاز من قبل LG.

ظروف بيئة التشغيل	
من 0 إلى 40 درجة مئوية	درجة حرارة التشغيل
أقل من 80 %	نسبة رطوبة التشغيل
من 20 - إلى 60 درجة مئوية	درجة حرارة التخزين
أقل من 85 %	نسبة الرطوبة في مكان التخزين

- تُحدَّد معلومات الطاقة المقَّمة مع المنتج وفقاً للوائح البلد. (وفقاً للبلد)
 - يُقاس استهلاك الطاقة تبعاً للجنة الكهربائية التقنية الدولية (IEC 62087).
 - قد يختلف استهلاك الطاقة الفعلي تبعاً لعوامل مثل نوع محتوى التبديل المعروض وإعدادات التلفاز.
 - لمعلومات عن تزويد الطاقة واستهلاكها، راجع الملصق الموجود على المنتج. (وفقاً للبلد)
- * في بعض الطرز، يوجد الملصق داخل غطاء طرف توصيل الجهاز الخارجي.

(تبغى للبلد)
فقط* (70/75UP75)

مواصفات الوحدة اللاسلكية (LGSBWAC02)	
شبكة LAN اللاسلكية (IEEE 802.11a/b/g/n/ac)	
طاقة الإخراج (الحد الأقصى)	نطاق التردد
17 ديسيل ملي واط	2483.5 ~ 2400 ميجاهرتز
19 ديسيل ملي واط	5725 ~ 5150 ميجاهرتز
10.5 ديسيل ملي واط	5850 ~ 5725 ميجاهرتز

نقطة Bluetooth	
طاقة الإخراج (الحد الأقصى)	نطاق التردد
8.5 ديسيل ملي واط	2483.5 ~ 2400 ميجاهرتز

يمكن لقوافل النطاق أن تتغير حسب الدولة، فلا يمكن للمستخدم تغيير تردد التشغيل أو تعديله. تم تكوين المنتج لجدول التردد الإقليمي. لا عبارات خاصة بالمستخدم، يجب تركيب الجهاز وتشغيله على مسافة 20 سم على الأقل بين الجهاز والجسم.

(تبغى للبلد)
(70/75UP75*, 82/86UP80) (باستثناء*)

مواصفات الوحدة اللاسلكية (LGSBWAC03)	
شبكة LAN اللاسلكية (IEEE 802.11a/b/g/n/ac)	
طاقة الإخراج (الحد الأقصى)	نطاق التردد
18.5 ديسيل ملي واط	2483.5 ~ 2400 ميجاهرتز
19.5 ديسيل ملي واط	5725 ~ 5150 ميجاهرتز
11.5 ديسيل ملي واط	5850 ~ 5725 ميجاهرتز

نقطة Bluetooth	
طاقة الإخراج (الحد الأقصى)	نطاق التردد
9 ديسيل ملي واط	2483.5 ~ 2400 ميجاهرتز

يمكن لقوافل النطاق أن تتغير حسب الدولة، فلا يمكن للمستخدم تغيير تردد التشغيل أو تعديله. تم تكوين المنتج لجدول التردد الإقليمي. لا عبارات خاصة بالمستخدم، يجب تركيب الجهاز وتشغيله على مسافة 20 سم على الأقل بين الجهاز والجسم.

المواصفات 7

(تَبَعًا لِلْبَادِ)

مواصفات البث	نظام التلفاز
النافار التناهري	نافار رقبي
PAL B/B, PAL B/G, PAL D/K, PAL-I SECAM B/G, SECAM D/K NTSC-M	^١ DVB-T/T2 ^٢ DVB-T/T2/C/S/S2
VHF, UHF, CATV	VHF, UHF ^٣ C-Band, ^٤ Ku-Band
3000 و النافار التناهري : 6000 : DVB-S/S2	أقصى عدد من البرامج القابلة للتخزين
75 أوم	مقاومة الهوائي الخارجي
55.0 x 100.0 مم x 5.0 مم	جج وحدة ^٥ Cl (العمق) العرض x الارتفاع x العمق)

- 1) الطرازات التي تدعم DVB-T2 فقط. رغم أن ميزة DVB-T2 لا تتطابق في الغلبين.
 - 2) الطرازات التي تدعم DVB-T2/C/S2 فقط.
 - 3) سبب الطراز.

خدمة ما بعد البيع (مصر فقط)
العمر الافتراضي: ٣ سنوات

لتلزم شركة LG بتعويض جميع قطع الغيار الخاصة بهذه الأجهزة خلال فترة العمر الافتراضي.

(تَعَا لِلْبَلَد)

(فقط 80* / 86UP/82)

مواصفات الوحدة اللاسلكية (LGSBWAC95)	
نطاق التردد	شبكة LAN اللاسلكية (IEEE 802.11a/b/g/n/ac)
نطاق التردد	طاقة الإخراج (الحد الأقصى)
2483.5 ~ 2400	19 ديسيريل ملي واط
5725 ~ 5150	18 ديسيريل ملي واط
5850 ~ 5725	13.5 ديسيريل ملي واط
Bluetooth تقنية	
نطاق التردد	طاقة الإخراج (الحد الأقصى)
2483.5 ~ 2400	9 ديسيريل ملي واط

6 استكشاف الأخطاء وإصلاحها

<ul style="list-style-type: none"> • افحص مستشعر الريموت على المنتج وحاول مجدداً. • تتحقق من عدم وجود أي عائق بين المنتج والريموت. • تتحقق مما إذا كانت البطاريات لا تزال تعمل وما إذا كانت متيبة على نحو صحيح (+ إلى +، - إلى -). 	<p>يتعذر التحكم في التلفاز باستخدام الريموت.</p>
<ul style="list-style-type: none"> • تتحقق مما إذا كان المنتج ي يعمل. • تتحقق مما إذا كان سلك الطاقة متصلًا بمقبس الحائط. • تتحقق مما إذا كان هناك مشكلة في مقبس الحائط من خلال توصيل منتجات أخرى. 	<p>لا يُعرض أي صورة ولا يصدر أي صوت.</p>
<ul style="list-style-type: none"> • تتحقق من إعدادات التحكم في الطاقة. قد يُقطع الإمداد بالطاقة. • تتحقق من عدم تشطيط خاصية الغلق التلقائي في الإعدادات المتعلقة بالوقت. • في حالة عدم وجود إشارة أثناء تشغيل الجهاز، سيتوقف تشغيل الجهاز تلقائياً بعد مرور 15 دقيقة دون وجود إشارة. 	<p>يتوقف تشغيل التلفاز فجأة.</p>
<ul style="list-style-type: none"> • شُغل التلفاز أو أوقف تشغيله باستخدام الريموت. • أعد توصيل كابل HDMI. • أعد تشغيل الكمبيوتر الشخصي مع تشغيل التلفاز. 	<p>عند الاتصال بالكمبيوتر الشخصي (HDMI)، لا يُكتشف عن أي إشارة.</p>
<ul style="list-style-type: none"> • إذا كان ملمس المنتج بارداً، فقد تنشأ "مضمة" صغيرة عند تشغيله. يُعد ذلك طبيعياً، لا يوجد خطأ في المنتج. • تُعد هذه اللوحة متقدماً متقدماً يحتوي على الملايين من وحدات البكسل. قد ترى نقاطاً سوداء صغيرة و/أو نقاطاً ملونة باللون زاهية (أحمر أو أزرق أو أخضر) على حجم جزء واحد في الملايين على الشاشة. لا يشير ذلك إلى خلل ولا يؤثر في أداء المنتج ودقته. تحدث هذه الظاهرة أيضاً مع منتجات الغير ولا تخضع للاستبدال أو استعادة الأموال. • قد يختلف لون اللوحة وبريقها حسب الموضع الذي تنظر منه (يسار/يمين/أعلى/أسفل). • تحدث هذه الظاهرة تبعاً لخصائص اللوحة. • لا تتعلق بأداء المنتج، ولا تُعد خللاً. • قد يؤدي عرض صورة ثانية لفترة طويلة إلى التصاق الصورة. تجنب عرض صورة ثانية على شاشة التلفاز لمدة طويلة. 	<p>عرض غير طبيعي</p>
<ul style="list-style-type: none"> • صوت "تكبير": يعود سبب الصوت الصادر عند مشاهدة التلفاز أو إيقاف تشغيله إلى التقاضي الحراري للبلاستيك بفعل الحرارة والرطوبة. هذا الصوت شائع في المنتجات التي يكون فيها تغيير الشكل بفعل الحرارة ضروري. • طنين الدائرة الكهربائية/طنين الشاشة: يصدر صوت خافت من دائرة التبديل ذات السرعة العالية، والتي تتمد المنتج بقوة تيار عالية لتشعيشه. ويختلف ذلك بحسب المنتج. هذا الصوت المولد لا يؤثر في أداء المنتج ودقته. 	<p>الأصوات الصادرة</p>



- عند تنظيف المنتج، احرص على لا تسمح بدخول أي سائل أو أجسام غريبة إلى الفتحة الموجودة بين الجزء العلوي أو الأيمن أو الأيسر من الشاشة ولوحة التوجيه.



(حسب الطراز)

- تأكد من إزالة أي ماء أو منظف زائد من قطعة القماش.
- لا ترش الماء أو المنظف مباشرةً على شاشة التلفاز.
- احرص على رش قدر كافٍ فحسب من الماء أو المنظف على قطعة القماش الجافة لمسح الشاشة.



- تحقق من إدخال وحدة CI في COMMON INTERFACE بالاتجاه الصحيح. فقد يؤدي عدم إدخال الوحدة بالشكل الصحيح إلى إلحاق ضرر بالتلفاز وبـCOMMON INTERFACE.
- إذا لم يقم التلفاز بعرض أي ملف فيديو أو صوت عندما يكون CI+ CAM متصل، يرجى الاتصال بمشغل خدمة نظام البيث الأرضي/الكبل/القرن الصناعي.

الأجهزة الخارجية المتاحة هي: مشغلات Blu-ray، وأجهزة الاستقبال عالية الدقة، ومشغلات أقراص الفيديو الرقمية (DVD)، وأجهزة VCR، والأنظمة المسوية، وأجهزة تخزين USB، وأجهزة الكمبيوتر الشخصي، وأجهزة الألعاب، وأجهزة حاربة أخرى.

- قد يختلف توصيل الجهاز الخارجي عن هذا الطراز.
- وصل الأجهزة الخارجية بالتلفاز بغض النظر عن ترتيب المنافذ في التلفاز.
- إذا سجلت برنامج التلفاز على مسجل/Blu-ray/أقراص الفيديو الرقمية (DVD) أو جهاز VCR، فتأكد من توصيل كابل إدخال الإشارة في التلفاز بالتلفاز عبر مسجل/أقراص الفيديو الرقمية (DVD) أو جهاز VCR. للحصول على مزيد من المعلومات عن التسجيل، راجع الدليل المرفق مع الجهاز المتصل.
- راجع الدليل المرفق مع الجهاز الخارجي للاطلاع على تعليمات التشغيل.
- إذا وصلت جهاز الألعاب بالتلفاز، فاستخدم الكابل المرفق مع جهاز الألعاب.
- في وضعية الكمبيوتر، قد يحدث تشويش ذو صلة بالدقة أو النمط الرأسي أو التباين أو السطوع. إذا حدث تشويش، فغير إخراج الكمبيوتر إلى دقة أخرى أو غير معدل التجديد إلى معدل آخر أو اضبط السطوع والتباين على قائمة [صورة] إلى أن تصبح الصورة واضحة.
- في وضع الكمبيوتر، قد لا تعمل بعض إعدادات الدقة بشكل صحيح استناداً إلى بطاقة الرسومات.
- في حالة تشغيل محتوى HD على جهاز الكمبيوتر الخاص بك، فقد يصبح الفيديو أو الصوت مشوشاً على فترات متقطعة حسب أداء جهاز الكمبيوتر لديك. (حسب الطراز)
- عند الاتصال عبر شبكة LAN سلكية، يوصى باستخدام كبل 7 CAT. (عند تزويد الجهاز بمنفذ LAN فقط).

الأجهزة الخارجية

ملاحظة

5 التوصيات

وصل الأجهزة الخارجية المتنوعة بالتلفاز وبتل أوضاع الإدخال لتحديد جهاز خارجي. للحصول على مزيد من المعلومات عن الاتصال بالجهاز الخارجي، راجع الدليل المرفق مع كل جهاز.

HDMI



- عند توصيل كبل HDMI، يجب إيقاف تشغيل المنتج والأجهزة الخارجية وفصلهم عن مصدر الطاقة.
- تنسيق الملفات الصوتية المدعوم في HDMI (حسب الطراز):
• 48 كيلوهرتز، True HD
• Dolby Digital Plus / Dolby Digital 32 كيلو هرتز / 44.1 كيلو هرتز / 48 كيلو هرتز،
• 32 PCM كيلو هرتز / 44.1 كيلو هرتز / 48 كيلو هرتز / 96 كيلو هرتز / 192 كيلو هرتز

ملاحظة

إذا كان الجهاز المتصل بمنفذ الإدخال يدعم HDMI Deep Colour أيضاً، فقد تصبح الصورة لديك أوضاع ولكن إذا لم يدعمه الجهاز فقد لا يعمل جيداً. في تلك الحالة، قم بتوصيل الجهاز بمنفذ HDMI مختلف أو قم بتغيير إعداد [HDMI Deep Colour] الخاص بالتلفاز إلى إيقاف.

- [HDMI Deep Colour] ← [HDMI] ← [إعدادات الأجهزة] ← [عام] ← [⋮] ← [الجهاز] ← [إعدادات HDMI] فقط (82/86UP80*)

- تشغيل: يدعم @ 4K 60/50 هرتز (4:4:4، 0:2:4، 2:2:4، 2:2:2)

< المنفذ 3 و 4 فقط > @ 4K 120/100 هرتز (4:4:4، 0:2:4، 2:2:4، 2:2:2)

- إيقاف: يدعم @ 4K 60/50 هرتز (0:2:4) (82/86UP80*)
(باستناء*)

- تشغيل: يدعم @ 4K 60/50 هرتز (4:4:4، 0:2:4، 2:2:4)

- إيقاف: يدعم @ 4K 60/50 هرتز (0:2:4)


• استخدم كابلًا معتمدًا مع وجود شعار HDMI عليه.

• إذا لم تستخدم كابل HDMI معتمدًا، فقد لا تُعرض الشاشة أي بيانات أو قد يحدث خطأ في الاتصال.

• أنواع كابلات HDMI الموصى بها

- كبل HDMI®™ فائق السرعة (3 م أو أقل)

USB




- للحصول على أفضل اتصال، يجب ألا تتجاوز أطوال كابلات HDMI وأجهزة USB 10 مم سمكًا و18 مم عرضًا وقطر السلك 8 مم. استخدم كبل إطالة يدعم USB 2.0 أو أعلى إذا كان كبل USB أو بطاقة ذاكرة USB لا تلائم منفذ USB في التلفاز. (حسب الطراز)

ملاحظة

• $10 \geq A$ *

• $18 \geq B$ *

• $8 \geq C$ *



استخدام الريموت

(حسب الظرف)

تُستند الأوصاف المذكورة في هذا الدليل إلى الأدلة الموجودة في الريموت. يرجى قراءة هذا الدليل بعناية واستخدام التلفاز استخداماً صحيحاً.

أَوْ أَلَّا قَامَ لَادْخَالِ الْأَقَامَةِ

الوصول إلى [المساعدة السريعة].

إجراءات إضافية لعرض المزيد من وظائف الريموت.

سيتم تمكين وظيفة الأوصاف الصوتية. (حسب
الطاراز)
الاستدعاء ترجمتك المفضلة في الوضع الرقمي.
(حسب، الطراز)

لكلم الصوت لكم جميع الأصوات.

علم المعرفة يو-ري إلى الوصول [إلى قائمته]
[إمكانية الوصول].

الإعدادات السريعة للوصول إلى الإعدادات السريعة.

البحث تحقق من المحتوى الموصى به. (قد لا يتتوفر بعض الخدمات الموصى بها في بعض البلدان).

للبحث عن المحتوى مثل برامج التلفاز
والأفلام والفيديوهات الأخرى أو إجراء بحث
عبر الإنترنت من خلال إدخال نص في شريط
البحث

يمكّنك مشاهدة التلفزيون أو
المسرح شاشات العرض الظاهر على الشاشة
والعودة إلى عرض التلفاز.
أزرار التحكم أزرار التحكم لمحتويات الوسائط.

تمكّن هذه الأذرار من الوصول إلى الوظائف
الخاصة في بعض القوائم.

أزرار خدمة البث للاتصال بخدمة بث الفيديوهات.

لوحة معلومات المنزل الوصول إلى [لوحة معلومات المنزل]. (وفقاً للبلد)

دليل المستخدم للوصول إلى قائمة البرامج المفضلة لديك. (وفقاً للبلد) [\[دليل المستخدم\]](#)

الآن، ان الذي يدعى Time Machine Ready،
ابدأ التسجيل وعرض قائمة التسجيلات.

الضرر الذي يدعم فقط المناطق.


قد لا تتوفر بعض الأزرار والخدمات بحسب التراخيص أو المناطق.

ملاحظة ✓

** لاستخدام الزر ، اضغط مطولاً لأكثر من 1 ثانية

5

فـ أحـدـةـ الـتـافـةـ التـاظـرـ،ـ وـعـضـنـ الـلـادـانـ،ـ قـدـ لـاتـعـهـ،ـ لـأـنـ دـارـ الـدـارـ،ـ



التشغيل لتشغيل التلفاز أو ايقاف تشغيله.

للوصول إلى قائمة البرامج
المحفوظة.
عرض دليل البرنامج.

أزرار عرض المعلومات تُستخدم
هذا الأزرار لعرض المعلومات.
لتعديل الوصول السريع. (حسب
الطراز) TOPT TEXT

الرسور الرابع هو
ميزة تسمح لك بالدخول
إلى تطبيق معين أو بث
تلفزيوني مباشر، مباشرة
عن طريق الضغط مطولاً
على أزرار الأرقام.

ازرار مستوى الصوت لضبط
مستوى الصوت.

ارزار البرامج للمربيين عبر البرامج
المحفوظة.
الصفحة الرئيسية للوصول إلى
قائمة الصفحة الرئيسية.

الصفحة الرئيسية عرض التطبيقات
المستخدم حديثاً.
الإدخال لتغيير مصدر الإدخال.

موافق لتحديد القوائم أو الخيارات
وتأكيد إدخالك.

موافق للوصول إلى قائمته
[المستكشف السحري]. عند استخدام
[دليل التفاز]، [الإعدادات]، [منبه
الرياضة]، أو [معرض فني]، اضغط
مع الاستمرار على النص.

استخدام الريموت 4

استخدام الريموت السحري Magic

(حسب الطراز)

تستند الأوسماف المذكورة في هذا الدليل إلى الأزرار الموجودة في الريموت. يُرجى قراءة هذا الدليل بعناية واستخدام التلفاز استخداماً صحيحاً.

أزرار الأرقام لإدخال الأرقام.

الوصول إلى [المساعدة السريعة].

إجراءات إضافية لعرض المزيد من وظائف الريموت.

** سيم تمكين وظيفة الأوسماف الصوتية.

كتم الصوت لكتم جميع الأصوات.

كتم الصوت يؤدي إلى الوصول إلى قائمة [إمكانية الوصول].

التعرف على الصوت يلزم الاتصال بالشبكة لاستخدام وظيفة التعرف على الصوت.

تحقق من المحتوى الموصى به. (قد لا تتوفر بعض الخدمات الموصى بها في بعض البلدان).

التعرف على الصوت تحدث أثناء الضغط على زر [التعريف على الصوت] لاستخدام ميزة التعرف على الصوت.

أعلى/[أسفل]/[يسار]/[يمين] اضغط على زر أعلى أو أسفل أو يسار أو يمين لتمرير القائمة. إذا قمت بالضغط على أزرار (⑥) وكان المؤشر في حالة الاستخدام، فسوف يختفي المؤشر من الشاشة وسيعمل الريموت السحري Magic كريموت عادي. لعرض المؤشر على الشاشة مرة أخرى، قم بتحريك الريموت السحري Magic إلى اليسار واليمين.

الإعدادات السريعة للوصول إلى الإعدادات السريعة.

الإعدادات السريعة تعرض قائمة [جميع الإعدادات].

تمكّن هذه الأزرار من الوصول إلى الوظائف الخاصة في بعض القوائم.

الزر الأحمر لتشغيل وظيفة التسجيل.

أزرار خدمة البث لاتصال بخدمة بث الفيديوهات.

لوحة معلومات المنزل الوصول إلى [لوحة معلومات المنزل]. (وفقاً للبلد)

دليل المستخدم للوصول إلى [دليل المستخدم]. (وفقاً للبلد)

الوصول إلى قائمة البرامج المفضلة لديك.

أزرار التحكم في محظيات الوسانط. (وفقاً للبلد)

أزرار التحكم في محظيات الوسانط.



التشغيل لتشغيل التلفاز أو إيقاف تشغيله.

— (شريطة) لإدخال — بين الأرقام مثل 2-1 و 2-2.

الوصول إلى قائمة البرامج المحفوظة.

للوصول إلى قائمة [الدليل].

GUIDE
** QUICK
ACCESS

للوصول إلى [تعديل الوصول السريع].

- [تعديل الوصول السريع] هو ميزة تسمح لك بالدخول إلى تطبيق معين أو بث تلفزيوني مباشر، مباشرةً عن طريق الضغط مطلقاً على أزرار الأرقام.

أزرار مستوى الصوت لضبط مستوى الصوت.

أزرار البرنامج للتتمرير عبر البرامج المحفوظة.

الصفحة الرئيسية للوصول إلى قائمة الصفحة الرئيسية.

الصفحة الرئيسية عرض التطبيقات المستخدمة حديثاً.

الإدخال للتغيير مصدر الإدخال.

الإدخال الوصول إلى [لوحة معلومات المنزل].

العجلة (موفق) اضغط على منتصف زر (⑩) لتحديد قائمة. يمكنك تغيير البرامج بواسطة استخدام زر (⑪).

العجلة (موفق) للوصول إلى قائمة [المستكشف السحري]. يمكنك تشغيل ميزة [المستكشف السحري] عند تغير لون المؤشر إلى اللون الأرجواني.

إذا كنت تشاهد برنامجاً، فاضغط مع الاستمرار على المؤشر فوق الفيديو.

عند استخدام [دليل التلفاز]، [الإعدادات]، [منبه الرياضة]، أو [عرض فني]، اضغط مع الاستمرار على التنص.

الرجوع للعودة إلى المستوى السابق.


الرجوع لمسح شاشات العرض الظاهرة على الشاشة والعودة إلى الإدخال السابق.

(قد لا تتوفر بعض الأزرار والخدمات بحسب الطرازات أو المناطق).

ملاحظة ✓

** لاستخدام الزر، اضغط مطلقاً لأكثر من 1 ثانية.
• في أجهزة التلفاز التناطري وبعض البلدان، قد لا تعمل أزرار الريموت.

(حسب الطراز)



- عند ظهور رسالة [إبطارية]، قم بتنبيل البطارية. لاستبدال البطاريات، افتح غطاء البطارية، واستبدل البطاريات 1.5 فولت من نوع AA (التي تتطابق فيها الأقطاب + و - مع التسمية الموجودة داخل حجرة البطاريات وأغلق غطاء البطارية.

- لاستبدال البطاريات، افتح غطاء البطارية، واستبدل البطاريات 1.5 فولت من نوع AAA (التي تتطابق فيها الأقطاب + و - مع التسمية الموجودة داخل حجرة البطاريات وأغلق غطاء البطارية.

- لا تخلط بين البطاريات الجديدة والبطاريات القديمة. لأن هذا قد يؤدي إلى ارتفاع حرارة البطاريات وحدوث تسرب بها.
- قد يتسبب عدم التتطابق مع أقطاب البطارية الصحيحة بحدوث انفجار أو تسرب، مما يؤدي إلى تشوب حريق أو حدوث إصابة جسدية أو تلوث البيئة المحيطة.
- يستخدم هذا الجهاز بطاريات. ومن الممكن أن تكون هناك قوانين تنظيمية في مجتمعك تلزمك بالتخالص من هذه البطاريات بشكل صحيح بسبب الاعتبارات البيئية. يرجى الاتصال بالسلطات المحلية للحصول على معلومات حول طريقة التخلص منها أو كيفية إعادة تدويرها.
- يجب ألا تتعرض البطاريات الداخلية أو الموجودة داخل المنتج إلى حرارة زائدة مثل أشعة الشمس أو النيران أو ما شابه ذلك. في أجهزة التلفاز التناهري وبعض البلدان، قد لا تعمل أزرار الريموت.

تسجيل الريموت السحري Magic

كيفية تسجيل الريموت السحري Magic

لاستخدام الريموت السحري، يجب إقرانه مع التلفاز أولًا.

1 ضع البطاريات في الريموت السحري للتحكم عن بعد Magic وقم بتشغيل التلفاز.

2 وجه الريموت السحري Magic إلى تلفازك واضغط على (العجلة (موفق) الموجود على الريموت.

* إذا فشل التلفاز في تسجيل الريموت السحري، فأعاد المحاولة بعد إيقاف تشغيل التلفاز وإعادة تشغيله.

كيفية إلغاء تسجيل الريموت السحري Magic

اضغط على أزرار (الرجوع) (الصفحة الرئيسية) في نفس الوقت، لمدة 5 ثوان، لإلغاء إقران الريموت السحري Magic مع التلفاز.


* اضغط مع الاستمرار على أزرار (الصفحة الرئيسية) (الإعدادات السريعة) لأكثر من 5 ثوان لفصل الريموت السحري Magic وإعادة تسجيله في الوقت نفسه.

* يوصى بوضع نقطة وصول (AP) على بعد أكثر من 0.2 متر عن التلفاز. إذا تم تثبيت نقطة الوصول على بعد أقرب من 0.2 متر، فقد لا يعمل الريموت السحري Magic على النحو المتوقع نظرًا لتدخل الترددات.

3 بدء تشغيل التلفاز

تشغيل التلفاز

يمكنك تشغيل وظائف التلفاز ببساطة، باستخدام الزر.



استخدام الزر

- التشغيل (ضغط)
إيقاف التشغيل⁽¹⁾ (ضغط مع الاستمرار)
التحكم في القائمة (ضغط)⁽²⁾
الاختيار من القائمة (ضغط مع الاستمرار)⁽³⁾
- 1) سوف تُغلق جميع التطبيقات قيد التشغيل وسوف يتوقف أي تسجيل جار.
2) يمكنك الوصول إلى القائمة وضبطها عن طريق الضغط على الزر عندما يكون التلفاز قيد التشغيل.
3) يمكنك استخدام الوظيفة عندما تصل إلى عنصر التحكم في القائمة.



- إذا كانت هذه هي المرة الأولى لتشغيل التلفاز بعد شحنه من المصنع، فقد تستغرق تهيئته عدة دقائق. ✓ ملاحظة

ضبط القائمة

عند تشغيل التلفاز، اضغط على زر **⑤** مرة واحدة. يمكنك ضبط العناصر في القائمة باستخدام الزر.

لتغيير مصدر الإدخال.


لإيقاف التشغيل.

للتمرير عبر البرامج المحفوظة.

لضبط مستوى الصوت.

- قد تختلف خيارات العرض على الشاشة الخاصة بكل جهاز تلفاز بشكل بسيط مما هو مبين في هذا الدليل. ✓ ملاحظة

- قد تختلف القوائم والخيارات المتوفرة عن مصدر الإدخال أو طراز المنتج الذي تستخدمنه.
- يمكن إضافة ميزات جديدة إلى هذا التلفاز في المستقبل.
- يجب توصيل الجهاز بمأخذ تيار سهل الوصول. لم يتم صنع بعض الأجهزة بزر التشغيل / إيقاف التشغيل، إيقاف التشغيل و فصل سلك الطاقة.



الطراز	(مم) (B x A) VESA	البراغي القياسي	عدد البراغي	حامل التثبيت على الحاطن
70/75UP75*	60/65UP77*	65UP75*	55UP75*	43/50UP75*
82/86UP80*	70/75UP78*	65UP78*	55UP78*	43/50UP77*
	70/75UP80*	60/65UP80*	55UP80*	43/50UP78*
		65UP81*	55UP81*	43/50UP80*
400 × 600	400 × 400	300 × 300	300 × 300	200 × 200
M8	M6	M6	M6	M6
4	4	4	4	4
LSW640B	LSW440B	OLW480B	OLW480B MSW240	LSW240B MSW240

الهوائي/الكابل

وصل التلفاز بمقبس هوائي على الحاطن باستخدام كابل تردد راديو (بمقاومة قدرها 75 أوم).

- استخدم مجزئ الإشارة لاستخدام أكثر من جهاز تلفاز.
- إذا كانت جودة الصورة رديئة، فثبت مكبر الإشارة بشكل صحيح لتحسين جودة الصورة.
- إذا كانت جودة الصورة رديئة مع وجود هوائي متصل، فحاول إعادة توجيه الهوائي في الاتجاه الصحيح.
- لا يتوفّر كابل هوائي ومحول.
- بالنسبة إلى الموقع غير المدعوم من بث HD Ultra، فلا يمكن لهذا التلفاز استقبال بث Ultra HD مباشرةً.


طبق القمر الصناعي

وصل التلفاز بطبق القمر الصناعي ومقبس القمر الصناعي باستخدام كابل تردد راديو (بمقاومة قدرها 75 أوم). (حسب الطراز)

قوس التثبيت على الحائط


(حسب الطراز)

تأكد من استخدام براغي وحامل تثبيت على الحائط التي تتوافق مع معايير VESA. يوفر الجدول التالي وصفاً للأبعاد القياسية لمجموعة قوس التثبيت على الحائط.



55/60/65UP77*	43/50UP77*	الطراز
55/65UP78*	43/50UP78*	
55/60/65UP80*	43/50UP80*	
55/65UP81*	43/50UP81*	
300	200	المسافة بين المسامير (A) (مم)
M6	M6	البراغي القياسي
2	2	عدد البراغي
WB21LMB	WB21LMB	حامل التثبيت على الحائط


- أزل الحامل قبل تركيب التلفاز على أداة التثبيت على الحاطن من خلال جعل أداة التعليق بالحامل في الاتجاه المعاكس.
- للحصول على مزيد من المعلومات عن البراغي وقوس التثبيت على الحاطن، راجع الشراء المنفصل.
- إذا كنت تتوى تثبيت المنتج على حاطن، فثبت واجهة التثبيت المطابقة لمعيار VESA (أجزاء اختيارية) على الجهة الخلفية للمنتج.
- عند تركيب جهاز التلفاز لاستخدام حامل التثبيت على الحاطن (أجزاء اختيارية)، بُنِيَتْ جيًّا حتى لا يسقط.
- عند تثبيت التلفاز على الحاطن، تأكد من عدم تركيب التلفاز بطريقة تكون فيها كابلات التشغيل والإشارة معلقة على الجهة الخلفية من التلفاز.
- لا تثبت هذا المنتج على حاطن في حال وجود احتمال تعرضه للزيت أو رذاذ الزيت. فقد يلحق هذا ضررًا بالمنتج ويسبب سقوطه.
- لا تستخدم أداة حادة عندما تفصل غطاء الكابل. فقد يسبب ذلك ضررًا بالكابل أو بالهيكل. كما قد يسبب ضررًا شخصيًّا. (حسب الطراز)



(حسب الطراز)

- عند تركيب حامل التثبيت على الحاطن، يوصى بفتحية فتحة الحامل باستخدام شريط لاصق، لمنع دخول الغبار والحشرات.

(حسب الطراز)




(حسب الطراز)

1 أدخل المسامير ذات العروة أو قوسى التلفاز والمسامير في جهة التلفاز الخلفية وقم بربطها بإحكام.

• أزل المسامير التي تم إدخالها في موضع المسامير ذات العروة أولًا في حالة توفرها.

2 ثبّت على الحائط قوسى التثبيت على الحائط باستخدام المسامير. طبّق موضع قوس التثبيت على الحائط مع المسامير ذات العروة في جهة التلفاز الخلفية.


3 قم بتوصيل المسامير ذات العروة وقوسي التثبيت على الحائط بإحكام بواسطة حبل قوي. تأكّد من المحافظة على الحبل في وضع أفقى مع السطح المستوي.



- استخدم دعامة أو خزانة قوية وكبيرة بشكل كافٍ لتحمل جهاز التلفاز بشكل آمن.
- الحوامل والمسامير والحالب غير مرفقة. يمكنك الحصول على الملحقات الإضافية من الوكيل المحلي.

التثبيت على الحائط


ثبّت حامل التثبيت الاختياري على الحائط الموجود في الجزء الخلفي من التلفاز بعناية وثبّت حامل التثبيت على حائط صلب في اتجاه عمودي على الأرضية. عندما ثبّت التلفاز على مواد البناء الأخرى، يُرجى الاتصال بفني مؤهل. تُوصي LG بأن يقوم فني تركيب محترف مؤهل بالثبيت على الحائط. تُوصي باستخدام حامل التثبيت على الحائط من LG. يسهل نقل حامل التثبيت على الحائط من LG مع الكابلات المتصلة. وفي حالة عدم استخدام حامل التثبيت على الحائط من LG، يُرجى استخدام حامل التثبيت على الحائط في المكان الذي يكون فيه الجهاز آمناً تماماً على الحائط مع وجود مساحة كافية تتيح الاتصال بالأجهزة الخارجية. يُنصح بتوصيل جميع الكابلات قبل تركيب أدوات التثبيت المُحكمة على الحائط.



(حسب الطراز)

التثبيت على الطاولة

- 1 ارفع التلفاز وأملأه إلى الوضع المستقيم على الطاولة.
- أبق مسافة 10 سم (على الأقل) من الحاطن للتهوية المناسبة.
- 2 قم بتوصيل سلك الطاقة بمصدر الطاقة في الحاطن.



(حسب الطراز)

-
- لا تضع مواد غريبة (زيوت وشحوم وما إلى ذلك) على البراغي عند تركيب المنتج.
!(فقد يلحق ذلك الضرر بالمنتج.)
 - في حالة تركيب التلفاز على حامل، ستحتاج إلى القيام ببعض الإجراءات لتقديري سقوط المنتج، وإلا فقد يسقط المنتج مما قد يتسبب في حدوث إصابة.
 - لا تستخدم أي مواد غير معتمدة لضمان السلامة وطول العمر الافتراضي للمنتج.
 - لا يغطي الضمان أي أضرار أو إصابات تنتج عن استخدام مواد غير معتمدة.
 - احرص على إدخال البراغي بشكل صحيح واربطها بـ بالحکام. (في حال عدم ربطها بـ بالحکام بشكل كافٍ، قد يمبل التلفاز نحو الأمام بعد تثبيته). لا تستخدم القوة المفرطة لربط البراغي وإلا فقد يؤدي ذلك إلى الحاق ضرر بالبراغي وارتكانه.
 - إذا لم يتم وضع التلفاز في موضع ثابت بشكل كافٍ، فيمكن لهذا أن يشكل خطراً حيث يصبح التلفاز معرضاً للسقوط. يمكن تجنب حدوث العديد من الإصابات، خصوصاً للأطفال من خلال اتخاذ إجراءات بسيطة مثل:
 - استخدام خزان أو حاملات توصي بها الجهة المصنعة للتلفاز.
 - استخدام قطع الأثاث التي تدعم التلفاز بشكل آمن فقط.
 - الحرص على وضع التلفاز بموضع لا يتجاوز طرف قطعة الأثاث الداعمة.
 - عدم وضع التلفاز على قلم أثاث طويلة (على سبيل المثال، خزانة أو خزانة كتب) من دون تثبيت الأثاث والتلفاز على دعامة مناسبة.
 - عدم وضع التلفاز على قطعة قماش أو مواد أخرى تم وضعها بين التلفاز وقطعة الأثاث الداعمة.
 - توخي الأطفال حول مخاطر قطع الأثاث للوصول إلى التلفاز وأدوات التحكم الخاصة به.

التحضير 2


حمل التلفاز ونقله

يرجى قراءة الإرشادات التالية لمنع خدش التلفاز أو إلحاق الضرر به ولضمان النقل الآمن بغض النظر عن نوعه وحجمه.


- يُوصى بنقل التلفاز في الصندوق أو مغلفاً بمواد التعبئة التي أرفق بها.
- افصل سلك الطاقة وجميع الكابلات قبل نقل التلفاز أو حمله.



- عند الإمساك بالتلفاز، يجب أن يكون اتجاه الشاشة بعيداً عنك وذلك لتجنب إلحاق الضرر بها.



- أمسك الجزء العلوي والسفلي من إطار التلفاز بإحكام، تأكّد من عدم الإمساك بالجزء الشفاف أو بمكبر الصوت أو بمنطقة شبكة مكبر الصوت.



- يتطلّب نقل جهاز تلفاز كبير 2 أشخاص على الأقل.
- عند نقل التلفاز باليدي، يجب الإمساك به كما هو موضح في الصورة التالية.

- عند نقل التلفاز باليدي، لا تعرّضه للارتجاج أو الاهتزاز الشديد.
- عند نقل التلفاز، اجعله دوماً مستقيماً، وتجنب قلبه على جانبه أو إمانته بيميناً أو بيساراً.
- لا تستخدّم القوة الزائدة لدرجة التسبّب في إمالة/ثني هيكل الإطار، إذ قد يؤدّي هذا إلى إلحاق الضرر بالشاشة.
- عند حمل التلفاز، احرص على عدم إلحاق ضرر بالأزرار البارزة.

-
- تجنب لمس سطح الشاشة في كل وقت، إذ قد يؤدّي ذلك إلى إلحاق الضرر بها.
 - عند توصيل الحامل بالتلفاز، وجّه الشاشة إلى الأسفل وضعها على طاولة مغطاة بقماش ناعم أو سطح مستوٍ لحمايتها من الخدوش.



• البطاريات

- خزن الملحاقات (البطاريات وغيرها) في مكان آمن بعيداً عن متناول الأطفال.
- لا تقم بقصير الدائرة أو فك البطاريات أو تركها لتسخن أكثر مما ينبغي. لا تتخلص من البطاريات في النار. فلا ينبغي أن تتعرض البطاريات للحرارة الزائدة.
- تنبية: في حال تم استبدال البطارية بنوع غير صحيح، فسيؤدي ذلك إلى خطير نشوب حريق أو حدوث انفجار.

• النقل

- أثناء النقل، تأكيد من إيقاف تشغيل المنتج وفصله عن الطاقة وأنه تم إزالة كل الكابلات. قد يتطلب حمل أجهزة التلفاز الكبيرة 2 أشخاص أو أكثر.
- لا تضع على الشاشة الأمامية من جهاز التلفاز.
- وإلا، فقد يحدث تلف المنتج أو تتعرض لخطر الحريق أو الإصابة.

- أبق مواد التغليف المضادة للرطوبة أو المصنوعة من الفينيل بعيدة عن متناول الأطفال.
- لا تسمح بتعرض الجهاز للسمدات أو بسقوط أي أشياء داخله، ولا تسقط أي شيء على الشاشة.
- لا تضغط بشدة على الشاشة أو تدخشها بيدك أو بواسطة شيء حاد مثل مسمار أو قلم رصاص أو قلم حبر. قد يتسبب هذا في تلف الشاشة.

• التنظيف

- عند التنظيف، افضل سلك الطاقة وامسح برفق بقطعة قماش ناعمة/جافة. لا ترش الماء أو المسوائل الأخرى على التلفاز مباشرة. لا تستخدم مطلياً مواد تنظيف الزجاج ومعطرات الجو ومبادات الحشرات والشحوم والشمع (الشمع المخصص للسيارات، الشمع الصناعي) والمواد الكاشطة والتنز والبنزين والكحول، الخ. التي قد تلحق ضرراً بالمنتجات وشاشتها. وإنما، فقد يتسبب ذلك في حدوث صدمة كهربائية أو تلف المنتج.

- إذا حدث أي مما يلي، فافصل المنتج عن الفور واتصل بمركز خدمة العملاء المحلي.
 - في حال تلف المنتج.
 - في حال تسرب المياه أو مادة أخرى إلى المنتج (مثل محول التيار المتردد أو سلك الطاقة أو التلفاز).
 - إذا شممت رائحة دخان أو رائحة أخرى من التلفاز.
 - عندما تهب عواصف رعدية أو عند عدم استخدامه لفترة زمنية طويلة.
- حتى عند إيقاف تشغيل التلفاز عن طريق الريموت أو الزر، يتم توصيل مصدر طاقة التيار المتردد بالوحدة إذا لم يتم فصلها عن القابس.
- لا تستخدم منتجات كهربائية ذات فولتية عالية بالقرب من التلفاز (على سبيل المثال صاعق الحشرات). فقد يلحق ذلك ضررًا بالمنتج.
- لا تحاول تعديل هذا المنتج بأي طريقة من دون الحصول على تصريح مكتوب من **LG Electronics**. فقد يتشرب حريق أو تحدث صدمة كهربائية. اتصل بخدمة العملاء المحلية للحصول على الخدمة أو الإصلاح. قد يؤدي التعديل غير المصرح به إلى إلغاء صلاحية المستخدم لتشغيل هذا المنتج.
- لا تستخدم سوى المرفقات/الملحقات المعتمدة من شركة **LG Electronics**. وإلا، فقد يتسبب ذلك في نشوب حريق أو حدوث صدمة كهربائية أو قصور وظيفي أو تشوّه المنتج.
- لا تفكك أبدًا محول التيار المتردد أو سلك الطاقة. فقد يتسبب ذلك في نشوب حريق أو حدوث صدمة كهربائية.
- توخِّ الحرص عند استخدام المحول لتجنب سقوطه أو وقوفه على الأرض. فقد يلحق ذلك ضررًا بالمحول.
- للحد من مخاطر نشوب حريق أو حدوث صدمة كهربائية، لا تلمس التلفاز عندما تكون يدك مبللة. إذا كانت أطراف سلك الطاقة رطبة أو يغطّيها الغبار، فاحرص على تجفيف قابس الطاقة تماماً أو امسح الغبار عنه.
- فصل الجهاز عن مصدر الطاقة الرئيسي
 - إن قابس الطاقة هو الجهاز المستخدم لفصل الجهاز عن الطاقة. في الحالات الطارئة، يجب أن يبقى قابس الطاقة موضوعاً في مكان يسهل الوصول إليه.
 - لا تدع الأطفال يتسلقون التلفاز أو يتعلقون به. وإلا فقد يسقط التلفاز مما يتسبب في حدوث إصابة خطيرة.
- **تاريض الهوائي الخارجي** (يمكن أن يختلف حسب البلد):
 - في حال تركيب هوائي خارجي، اتبع الاحتياطات الواردة أدناه.
- ينبع عدم وضع نظام الهوائي الخارجي بالقرب من خطوط الكهرباء المعلوية أو الإضاءة الكهربائية أو دوائر الطاقة الأخرى أو في الأماكن التي يمكنها أن يلامس خطوط أو دوائر الطاقة هذه، حيث يمكن أن يتسبب هذا في حدوث وفاة أو إصابة خطيرة.
- **التاريض** (باستثناء الأجهزة التي لا يتم تاريضها).
 - يجب توصيل مهازن التلفاز المزود بقابس تيار متردد ثلاثي الأطراف بمقياس تيار متردد ذو طرف الأرضي ثلاثي الأطراف. تأكّد من توصيل سلك التاريض الأرضي لمنع احتفال حدوث صدمة كهربائية.
 - لا تلمس أبداً هذا الجهاز أو الهوائي أثناء العاصفة الرعدية. فقد يتعرض للصعق الكهربائي.
 - تأكّد من توصيل سلك الطاقة بالتلفاز ومقياس الحاطن بأمان، فقد يحدث تلفٌ في القابس أو المقياس وقد يتسبّب حريق في أصعب الحالات إذا لم يتم توصيله بأمان.
 - لا تدخل أحساماً معdenة أو قابلة للاشتعال في المنتج. إذا سقط جسم عريض في المنتج، فافصل سلك الطاقة واتصل بخدمة العملاء.
 - لا تلمس طرف سلك الطاقة أثناء توصيله بالكهرباء. فقد تتعرض للصعق الكهربائي.

1 تحذير! تعليمات الأمان



تنبيه: لتقليل خطر الصدمة الكهربائية، لا تقم ب拔掉 the food (أو الجزء الخالي). ولا توجد قطع قابلة للصيانة من قبل المستخدم في المنتج. أوكل هذا الأمر إلى فريق الخدمة المؤهل.

يُقصد بهذا الرمز تنبيه المستخدم إلى وجود "فولتية خطيرة" غير معزولة داخل المنتج قد تحتوي على مقدار كافٍ لإلحاق خطر الصدمات الكهربائية بالأشخاص.

يُقصد بهذا الرمز تنبيه المستخدم إلى وجود تعليمات مهمة متعلقة بكيفية تشغيل المنتج وصيانته (خدمة) داخل الدليل المرفق مع الـ.

تحذير: للحد من مخاطر نشوب حريق وحدوث صدمات كهربائية، لا تعرّض المنتج للمطر أو الرطوبة.

• التهوية

- قم بتنبيه جهاز التلفاز لديك في مكان جيد التهوية.
- لا تقم بتنبيه في مساحة ضيقة مثل خزانة الكتب.
- لا تقم بتنبيه المنتج على سجاد أو وسادة.
- لا تقم بحجب المنتج أو تغطيته بقطعة قماش أو مواد أخرى أثناء توصيل الوحدة بالكهرباء.
- احرص على عدم لمس فتحات التهوية. أثناء مشاهدة التلفاز لفترة طويلة، قد تصبح فتحات التهوية ساخنة.
- احرص على حماية سلك الطاقة من سوء الاستخدام المادي والبيكانيكي، مثل تعرضه للنتر أو الانواء أو الضغط عليه أو إغلاق الباب عليه أو المشي فوقه، انتبه جيداً إلى المقابس والماخذ في الحاطط ومخرج السلك من الجهاز.
- لا تحرّك جهاز التلفاز أثناء توصيل سلك الطاقة.
- لا تستخدم سلك الطاقة التالفة أو غير محكم التركيب.
- تأكّد من الإمساك بالفلاس عند فصل سلك الطاقة. لا تسحب سلك الطاقة لفصل التلفاز.
- لا توصل أجهزة كثيرة جدًا بمخرج التيار المتردد نفسه، لأنّ هذا قد يؤدي إلى نشوب حريق أو حدوث صدمة كهربائية.

• لمنع انتشار الحريق، ابق الشموع أو العناصر المشتعلة الأخرى دائمًا بعيدة عن المنتج.

• لا تضع التلفاز وأو الرسيموم في الظروف التالية:

- أبق المنتج بعيداً عن أشعة الشمس المباشرة.

- منطقة ذات رطوبة عالية كالحمام مثلاً.

- بالقرب من مصدر حرارة كالموقد أو الأجهزة الأخرى التي تُصدر حرارة.

- بالقرب من طاولات المطبخ أو أجهزة ضبط الرطوبة حيث يمكن أن يتعرض سبورة للبخار أو الزيت.

- منطقة معرضة للمطر أو الرياح.

- لا تعرّض الجهاز ل قطرات المياه ولا تضع أغراضًا تحتوي على موائل، مثل المزهريات أو الأكواب وما إلى ذلك عليه (مثلاً على الرفوف الموجودة فوق الوحدة).

- بالقرب من المواد القابلة للاشتعال مثل البنزين أو الشموع أو تعرّض التلفاز لتكيف هواء مباشر.

- لا ترتكب الجهاز في أماكن تتعرّض للغبار كثيراً.

وإلا، فقد يتسبّب ذلك في نشوب حريق أو حدوث صدمة كهربائية أو احتراق/انفجار أو قصور وظيفي أو نشوة المنتج.

١ تحذير! تعليمات الأمان

٢ التحضير

- حمل التلفاز ونظقه
- التثبيت على الطاولة
- التثبيت على الحائط
- الهوائي/الكابل
- طبق القمر الصناعي

٣ بدء تشغيل التلفاز

- تشغيل التلفاز
- تسجيل الريموت السحري Magic

٤ استخدام الريموت

- استخدام الريموت السحري Magic
- استخدام الريموت

قبل قراءة هذا الدليل

- يرجى قراءة هذا الدليل بعناية قبل تشغيل التلفاز والاحتفاظ به للرجوع اليه في المستقبل.
- على الموقع الإلكتروني، يمكنك تنزيل الدليل بما في ذلك التثبيت والاستخدام واستكشاف الأخطاء وإصلاحها والمواصفات والترخيص وما إلى ذلك، وعرض محتوياته على جهاز الكمبيوتر أو الجوال.

دليل المستخدم

- لمزيد من المعلومات حول هذا التلفاز، اقرأ دليل المستخدم المرفق في المنتج.
- لفتح دليل المستخدم  ← [الدعم] ← [دليل المستخدم]

الشراء المنفصل

- يمكن تغيير عناصر الشراء المنفصل أو تعديلاها لتحسين الجودة من دون أي إخطار. اتصل بالبائع لشراء هذه العناصر. لا تعمل هذه الأجهزة إلا مع طرازات معينة.
- قد يتغير اسم الطراز أو تصميمه حسب ترقية وظائف المنتج أو ظروف جهة التصنيع أو سياساتها.
- الريموت السحري Magic : **MR21GA** تحقق مما إذا كان طراز التلفاز يدعم تقنية Bluetooth في الوحدة اللاسلكية للتحقق من إمكانية استخدامه مع الريموت السحري Magic.
- يجب شراء كبل توصيل الهوائيات والأجهزة الخارجية بشكل منفصل.

٧ ملاحظة

- قد تتغير مواصفات المنتج أو المحتويات في هذا الدليل من دون إخطار مسبق نتيجة ترقية وظائف المنتج.
- قد تختلف العناصر المرفقة مع المنتج حسب الطراز.
- قد تختلف الصورة المعروضة عن صورة التلفاز لديك.



العنوان

دليل المستخدم

*LED تلفاز

* إخلاء المسؤولية

يرجى قراءة هذا الدليل بعناية قبل تشغيل الجهاز والاحتفاظ به للرجوع إليه في المستقبل. يأتي التلفاز الذي يعمل بتقنية LED من LG مزوداً بشاشة LCD مع تقنية الإضاءة الخلفية LED.