

عربي
ENGLISH



ENGLISH
عربي

دليل مستخدم

User Guide

LG-P350

LG-P350



CE 0168 !

www.lg.com

P/N : MFL67159986 (1.0)



CE 0168 !

www.lg.com

P/N : MFL67159986 (1.0)



دليل مستخدم LG-P350



- قد لا تنطبق بعض محتويات هذا الدليل على هاتفك وهذا يتوقف على برنامج الهاتف أو موفر الخدمة لديك.
- هذا الجهاز غير مخصص للمكفوفين نظرا للوحة المفاتيح التي تعمل باللمس.

Copyright ©2011 LG

Electronics, Inc جميع الحقوق محفوظة. LG وشعار LG هما علامتان تجاريتان مسجلتان لمجموعة LG Group والكيانات التابعة، كل العلامات التجارية الأخرى تعود إلى مالكيها.

• Gmail و Google search و
• Android و Talk و YouTube
• Market هي علامات تجارية لـ
• Google, Inc

تهانينا لشرائك هاتف LG-P350 المتقدم
والصغير من LG، والمصمّم للعمل مع
التكنولوجيا الرقمية الأحدث لاتصالات
الهواتف المحمولة.

ملاحظة هامة

يرجى التحقق لمعرفة ما إذا كان قد تم وصف أي مشكلة من المشاكل التي تواجهها مع هاتفك في هذا القسم قبل نقل الهاتف إلى الصيانة أو قبل الاتصال بممثل الصيانة.

1. ذاكرة الهاتف

عندما تكون المساحة المتاحة على ذاكرة الهاتف أقل من 10%، فلن يستطيع الهاتف استقبال رسالة جديدة، لذا تحتاج إلى التحقق من ذاكرة الهاتف وحذف بعض البيانات مثل التطبيقات أو الرسائل لإتاحة المزيد من المساحة في الذاكرة. لإدارة التطبيق

1 على الشاشة الرئيسية. المس علامة التبويب التطبيقات وحدد الإعدادات > التطبيقات > إدارة التطبيقات.

2 عندما تظهر جميع التطبيقات، قم بالتمرير وحدد التطبيق الذي تريد إلغاء تثبيته.

3 اضغط على إلغاء التثبيت والمس موافق لإلغاء تثبيت التطبيق المطلوب.

2. إطالة فترة عمل البطارية

يمكنك تمديد فترة عمل البطارية عن طريق إيقاف الميزات التي لا تحتاج إلى تشغيلها بصورة مستمرة في الخلفية، يمكنك أيضاً مراقبة كيفية استهلاك التطبيقات وموارد النظام لطاقة البطارية.

لتمديد فترة عمل البطارية

- قم بإيقاف تشغيل الاتصالات اللاسلكية التي لا تستخدمها. أوقف تشغيل Wi-Fi أو بلوتوث في حال عدم استخدامها.
- قلل سطوع الشاشة واضبط مهلة أقصر لإيقاف الشاشة.
- أوقف تشغيل المزامنة التلقائية لـ Gmail والتقويم والاسماء والتطبيقات الأخرى.
- قد تؤدي بعض التطبيقات التي قمت بتنزيلها إلى تقليل فترة عمل البطارية.
- للتحقق من مستوى شحن البطارية
- 1 على الشاشة الرئيسية. المس علامة التبويب التطبيقات وحدد الإعدادات > حول الهاتف > الحالة.
- 2 يتم عرض حالة البطارية (الشحن، التفريغ) والمستوى (مثل النسبة

ملاحظة هامة


المئوية لاكتتمال الشحن) في أعلى الشاشة.
لمراقبة ما يستخدم البطارية والتحكم فيه

1 على الشاشة الرئيسية، المس علامة التبويب التطبيقات وحدد الإعدادات > حول الهاتف > استخدام البطارية.

2 يعرض الجزء العلوي من الشاشة وقت استخدام البطارية. سواء الفترة التي مرت منذ آخر توصيل لها بمصدر طاقة أو إذا تم توصيلها بمصدر طاقة، الفترة التي مرت على استخدام طاقة البطارية، يعرض الجزء الرئيسي بالشاشة التطبيقات أو الخدمات التي تستخدم طاقة البطارية بدءاً مما يستهلك أكبر قدر من الطاقة وصولاً إلى ما يستهلك أقل قدر من الطاقة.

3. تثبيت برنامج مفتوح المصدر

إذا قمت بتثبيت برنامج مفتوح المصدر على هاتفك، ولم تستخدم البرنامج الذي توفره الجهة المصنعة، فقد لا يعمل الهاتف بشكل صحيح.

 **تحذير:** في حال قمت بتثبيت برنامج يختلف عن الذي توفره الجهة المصنعة ثم قمت باستخدامه، فتبطل كفاءة الهاتف.

 **تحذير:** لحماية الهاتف والبيانات الشخصية، قم بتنزيل التطبيقات من مصادر موثوقة فقط، مثل Android Market™. في حالة عدم تثبيت بعض التطبيقات بالهاتف بشكل صحيح، قد لا يعمل الهاتف بشكل طبيعي أو قد يحدث خطأ جسيم، ستكون بحاجة إلى إلغاء تثبيت هذه التطبيقات وكل بياناتها وإعداداتها من الهاتف.

4. استخدام نقش إلغاء القفل

قم بضبط نقش إلغاء القفل لتأمين الهاتف، يؤدي إلى فتح شاشات ترشدك أثناء رسم نقش إلغاء قفل الشاشة.

على الشاشة الرئيسية، المس علامة التبويب التطبيقات وحدد الإعدادات < الحماية < إعداد قفل الشاشة < النقش.

اتبع الشاشات لترشدك أثناء رسم

5. استخدام الوضع الآمن وإعادة التعيين الثابتة

استخدام الوضع الآمن

* لاستعادة الهاتف من أي عطل
قم بإيقاف تشغيل الهاتف. ثم
إعادة التمهيد. أثناء رجوع الهاتف
لحالة التشغيل. اضغط باستمرار
على مفتاح الإرسال أثناء عرض
شعار Android. سيقوم الهاتف
بالتمهيد بكامل الخطوات إلى
الشاشة الرئيسية ويعرض "الوضع
الآمن" في الزاوية اليسرى السفلى.

* استخدام إعادة التعيين الثابتة (تعيينات
الشركة المصنّعة)

إذا لم يعد الهاتف لحالته الأصلية استخدم
إعادة التعيين الثابتة لإرجاعه

1 أخرج البطارية وأعدّها إلى مكانها.

2 اضغط باستمرار لأكثر من 10

ثوان: مفتاح الطاقة/القفل +
مفتاح الإرسال + مفتاح خفض
مستوى الصوت.

3 عند تشغيل الطاقة. حرّر هذه
المفاتيح.

نقش إلغاء قفل الشاشة. حدد التالي
للمتابعة إلى الشاشة التالية.

⚠ تحذير: ينبغي أخذ الاحتياطات
اللازمة عند استخدام نقش القفل. من
الهام تذكر نقش إلغاء القفل الذي قمت
بتعيينه. لديك 5 فرص لإدخال نقش
إلغاء القفل أو رمز PIN أو كلمة المرور. إذا
استخدمت كل الفرص الـ 5، فيمكنك
إعادة المحاولة بعد 30 ثانية.

عند تعذّر استعادة نقش إلغاء القفل أو
رمز PIN أو كلمة المرور:

اضغط على زر نسيان النقش. في حال إنشاء
حساب Google على الهاتف. ثم يُطلب منك
تسجيل الدخول باستخدام حساب Google
لإلغاء قفل الهاتف في حال عدم إنشاء حساب
Google على الهاتف أو نسيانه. عليك تنفيذ
إعادة تعيين ثابتة.

تنبيه: في حالة تنفيذ إعادة تعيين
ثابتة. سيتم حذف كل تطبيقات
وبيانات المستخدم. يرجى تذكر إجراء
نسخ احتياطي لأي بيانات هامة قبل
تنفيذ إعادة تعيين ثابتة.



تحذير

في حالة تنفيذ إعادة تعيين ثابتة، سيتم حذف كل تطبيقات المستخدم وبياناته. يُرجى تذكر إجراء نسخ احتياطي لأي معلومات هامة قبل تنفيذ إعادة تعيين ثابتة.

6. التوصيل بشبكات Wi-Fi

بفضل استخدام تقنية Wi-Fi في هاتفك، يمكنك الوصول إلى نقطة وصول لاسلكية أو "نقطة فعالة". تكون بعض نقاط الوصول مفتوحة ويمكنك ببساطة الاتصال بها. في حين تكون بعض النقاط الأخرى مخفية أو تطبق ميزات أمان أخرى. لذا يلزمك تكوين الهاتف حتى يمكنه الاتصال بها. أوقف تشغيل ميزة Wi-Fi عند عدم استخدامها وذلك لإطالة فترة عمل البطارية.

لتشغيل ميزة Wi-Fi والاتصال بشبكة Wi-Fi

- 1 على الشاشة الرئيسية، المس علامة التبويب التطبيقات وحدد الإعدادات > الإتصالات اللاسلكية و الشبكات > ضوابط Wi-Fi.
- 2 المس Wi-Fi لتشغيله وبدء البحث عن شبكات Wi-Fi المتوفرة.
- يتم عرض قائمة بشبكات Wi-Fi المتاحة، كما تتم العلامة إلى الشبكات المؤمنة برمز القفل.
- 3 المس إحدى الشبكات للاتصال بها.
- إذا كانت الشبكة مفتوحة، ستتم مطالبتك بتأكيد رغبتك في الاتصال بهذه الشبكة عن طريق لمس اتصال.
- إذا كانت الشبكة مؤمنة، فستتم مطالبتك بإدخال كلمة مرور أو بيانات اعتماد أخرى. (راجع مسؤول الشبكة للحصول على التفاصيل).
- 4 يعرض شريط الحالة رموز تشير إلى حالة Wi-Fi.

7. استخدام بطاقة micro SD

يمكن حفظ الصور بالإضافة إلى ملفات الموسيقى والفيديو على ذاكرة خارجية فقط.

قبل استخدام الكاميرا المدمجة، ستحتاج إلى إدخال بطاقة ذاكرة micro SD إلى هاتفك أولاً.

بدون إدخال بطاقة ذاكرة، لن تتمكن من حفظ الصور ومقاطع الفيديو التي قمت بتسجيلها.

⚠ تحذير:

لا تقم بإدراج بطاقة الذاكرة أو إخراجها عندما يكون الهاتف في وضع التشغيل، وإلا فقد يلحق الضرر بطاقة الذاكرة والهاتف. وقد تلتف البيانات المخزنة في بطاقة الذاكرة. لفصل بطاقة الذاكرة بأمان، يرجى تحديد الشاشة الرئيسية > التطبيقات > الإعدادات > تخزين الهاتف و بطاقة SD < فصل بطاقة SD.

8. فتح التطبيقات وتغييرها

يُعد القيام بمهام متعددة أمراً سهلاً مع Android لأن التطبيقات المفتوحة تظل قيد التشغيل حتى في حالة فتح تطبيق آخر، لا توجد حاجة للخروج من التطبيق قبل فتح آخر. يمكنك استخدام العديد من التطبيقات المفتوحة والتنقل بينها، حيث يقوم برنامج Android بإدارة كل تطبيق وإيقافه وتشغيله عند الحاجة وذلك للتأكد من أن التطبيقات الخاملة لا تستهلك موارد بشكل غير ضروري.

لإيقاف استخدام التطبيق الذي تستخدمه

1 على الشاشة الرئيسية، المس علامة التبويب التطبيقات وحدد الإعدادات > التطبيقات > إدارة التطبيقات > قيد التشغيل.

2 قم بالتمرير إلى التطبيق المطلوب والمس إيقاف إجباري لإيقاف استخدامه.

- نقل ملفات الوسائط المتعددة (الصور، ملفات الفيديو، الموسيقى) بسهولة من خلال عملية سحب وإفلات بسيطة بين الكمبيوتر الشخصي والهاتف.
- نقل الرسائل من الهاتف إلى الكمبيوتر الشخصي.
- استخدام هاتفك كمودم.
- تحديث البرنامج من دون خسارة بياناتك.

تثبيت برنامج **LG PC Suite** من بطاقة الذاكرة **micro SD**

- 1 قم بإدراج بطاقة ذاكرة **micro SD** في الهاتف. (قد تكون مدرجة مسبقاً في الهاتف.)
- 2 قبل توصيل كبل البيانات **USB**. تأكد من أن وضع ذاكرة التخزين فقط ممكن على الهاتف. (في قائمة التطبيقات، اختر الإعدادات < تخزين الهاتف و بطاقة **SD** ثم حدد خانة الاختيار ذاكرة تخزين فقط.)
- 3 قم بتوصيل هاتفك بالكمبيوتر الشخصي بواسطة كبل بيانات **USB**.
- 4 اسحب رمز **USB** في شريط

تلميح: الرجوع إلى التطبيقات المستخدمة مؤخراً - اضغط باستمرار على مفتاح الشاشة الرئيسية، فتعرض شاشة قائمة التطبيقات التي استخدمتها مؤخراً

9. نسخ **LG PC Suite** من بطاقة **SD**

إن **LG PC Suite IV** عبارة عن برنامج يساعدك على توصيل الهاتف المحمول بالكمبيوتر الشخصي باستخدام كبل اتصال بيانات **USB**. بحيث يمكنك استخدام وظائف الهاتف المحمول على الكمبيوتر الشخصي.

الوظائف الرئيسية لبرنامج **LG PC Suite IV**

- إنشاء بيانات الهاتف وتعديلها وحذفها بسهولة.
- مزامنة البيانات بين الكمبيوتر الشخصي والهاتف (الاسماء، التقويم، رسالة (SMS)، العلامة المرجعية، سجل المكالمات).

10. توصيل الهاتف بالكمبيوتر عبر USB

ملاحظة: يتوجب عليك تثبيت برنامج LG PC suite على الكمبيوتر. لمزامنة البيانات على الهاتف مع الكمبيوتر الشخصي باستخدام كبل USB. يمكنك تنزيل هذا البرنامج من موقع ويب لـ LG (www.lg.com). انتقل إلى الموقع <http://www.lg.com> وحدد منطقتك، والبلد واللغة. قم بزيارة موقع ويب LG للحصول على مزيد من المعلومات. نظراً إلى أن PC suite مضمّن في بطاقة SD في صندوق الوارد. يمكنك نقله ببساطة إلى الكمبيوتر الشخصي. لا يعتمد LG-P350:

- اتصال الكمبيوتر عبر بلوتوث
- مزامنة LG Air Sync (مزامنة عبر ويب، R-Click)
- (On Screen Phone) OSP
- المهام في التقويم
- المذكرة
- تطبيق Java

يتوفر دليل المستخدم الخاص بـ PC suite IV في قائمة التعليمات بعد تثبيت برنامج PC Suite IV.

الحالة.

• اختر تم توصيل USB وتشغيل وحدة تخزين USB.

• يمكنك عرض محتوى ذاكرة التخزين على الكمبيوتر الشخصي ونقل الملفات.

5 • انسخ حافظة "LGPCSuiteIV" من وسيلة ذاكرة التخزين إلى جهاز الكمبيوتر الشخصي.

• قم بتشغيل ملف "LGInstaller.exe" على الكمبيوتر الشخصي واتبع الإرشادات.

* عند اكتمال تثبيت LG PC Suite IV، قم بتعطيل وضع ذاكرة تخزين فقط لتشغيل LG PC Suite IV.

ملاحظة: يرجى عدم فصل ملف برنامج آخر مثبت على بطاقة الذاكرة أو حذفه. إذ قد يؤدي ذلك إلى إلحاق الضرر بالتطبيقات المثبتة مسبقاً على الهاتف.

ملاحظة هامة

1 استخدم كبل USB الذي يأتي مع

الهاتف لتوصيل الهاتف بمنفذ USB الموجود على الكمبيوتر. وسوف تتلقى إعلماً بتوصيل USB.

2 افتح نافذة الإشعار والمس جهاز USB الذي تم توصيله.

3 المس "تشغيل وحدة تخزين USB" لتأكيد رغبتك في نقل الملفات بين بطاقة micro SD في الهاتف والكمبيوتر.

عند توصيل الهاتف كوحدة تخزين USB، سوف تتلقى إعلماً بذلك. لقد تم تثبيت بطاقة micro SD الخاصة بالهاتف كأحد محركات الأقراص بالكمبيوتر. يمكنك الآن نسخ الملفات من بطاقة micro SD وإليها.

11. إلغاء قفل الشاشة عند استخدام اتصال البيانات

سوف تصبح الشاشة مظلمة إذا لم يتم لمسها لفترة من الوقت عند استخدام اتصال البيانات. لتشغيل شاشة LCD، ما عليك إلا لمسها.

ملاحظة: عند إلغاء تثبيت PC Suite IV، لا تتم إزالة برامج تشغيل USB وبلوتوث تلقائياً، وبالتالي، يجب إلغاء

تثبيتها يدوياً.

تلميح! لاستخدام بطاقة micro SD في الهاتف مرة أخرى، ستحتاج لفتح نافذة الإشعار ولس "إيقاف تشغيل تخزين USB".

في هذه الأثناء، لا يمكنك الوصول إلى بطاقة micro SD من هاتفك، ولذا لا يمكنك استخدام التطبيقات التي تعتمد على بطاقة micro SD كالكاميرا والمعرض والموسيقى. لفصل الهاتف عن الكمبيوتر، اتبع بعناية الإرشادات التي تظهر على الكمبيوتر لفصل أجهزة USB بشكل صحيح لتفادي فقدان المعلومات الموجودة على البطاقة.

1 افصل جهاز USB عن الكمبيوتر.

2 افتح نافذة الإشعار والمس إيقاف تشغيل وحدة تخزين USB.

3 المس إيقاف تشغيل في مربع الحوار الذي يفتح.

12. حمل الهاتف بشكل مستقيم

يرجى حمل الهاتف المحمول بشكل مستقيم كالهاتف العادي.

أثناء إجراء/تلقي مكالمات أو إرسال/تلقي بيانات، حاول تجنب الإمساك بالجزء السفلي من الهاتف حيث

يكون الهوائي موجوداً. قد يؤثر ذلك على جودة المكالمة.

13. عند تجمّد الشاشة

في حال لم يتجاوب الهاتف مع إدخال المستخدم أو تجمّدت الشاشة؛ أخرج البطارية. وقم بإدراجها مجدداً ثم قم بتشغيل الهاتف. في حال استمرت المشكلة، يرجى الاتصال بمركز الخدمة.

14. لا تقم بتوصيل الهاتف عند

تشغيل/إيقاف تشغيل الكمبيوتر الشخصي

تأكد من قطع اتصال الهاتف والكمبيوتر الشخصي باستخدام كبل البيانات إذ قد تحدث أخطاء على الكمبيوتر الشخصي.

قبل استخدام الهاتف المحمول، يرجى قراءة التعليمات أولاً!

- في حال وجود ملف فيديو مع ملف ملف فرعي (ملف من نوع sim. أو Srt. يحمل اسم ملف الفيديو نفسه). ضع الملفين في الحافظة نفسها لعرض الملف الفرعي تلقائياً عند تشغيل ملف الفيديو.
- عند تنزيل ملفات فيديو أو موسيقى، يجب أن تكون حقوق النشر محفوظة. يرجى الانتباه إلى أن الملف التالف أو الملف المزوّد بملحق خطأ قد يلحق الضرر بالهاتف.

كيفية تشغيل ملفات الموسيقى / الفيديو في الهاتف

تشغيل ملفات الموسيقى

- من الشاشة الرئيسية، المس علامة التبويب التطبيقات < الموسيقى. حدد الملف الذي تريد تشغيله من علامات التبويب الفنان والألبومات والأغاني وقوائم التشغيل.

تشغيل ملفات الفيديو

- على الشاشة الرئيسية، المس علامة التبويب التطبيقات < مشغل الفيديو وحدد موقع الملف الذي تريده في القائمة ثم حدده للتشغيل.

كيفية حفظ ملفات الموسيقى / الفيديو في الهاتف

- قم بتوصيل الهاتف بالكمبيوتر الشخصي باستخدام كبل USB. المس شريط الحالة على الشاشة الرئيسية واسحبه لأسفل. حدد تم توصيل USB < تشغيل وحدة تخزين USB < فتح حافظة لعرض الملفات. إذا لم تقم بتنصيب LG Android Platform Driver على الكمبيوتر الشخصي، فيجب أن تقوم بتعيينه يدوياً. على الشاشة الرئيسية، المس علامة التبويب التطبيقات وحدد الإعدادات < تخزين الهاتف و بطاقة SD < تنشيط وسيلة ذاكرة التخزين فقط.

- احفظ ملفات الموسيقى أو الفيديو من الكمبيوتر الشخصي إلى وحدة التخزين القابلة للإزالة في الهاتف.
- يمكنك نسخ ملفات من الكمبيوتر الشخصي إلى وحدة التخزين القابلة للإزالة في الهاتف أو نقلها باستخدام قارئ البطاقات.

كيفية نقل جهات الاتصال من الهاتف القديم إلى الهاتف الحالي

قم بتصدير جهات الاتصال كملف CSV من الهاتف القديم إلى الكمبيوتر الشخصي باستخدام برنامج مزامنة الكمبيوتر الشخصي.

1 قم بتنزيل LG PC Suite IV على الموقع www.lg.com وقم بتثبيته في الكمبيوتر الشخصي. قم بتشغيل البرنامج وتوصيل الهاتف بالكمبيوتر الشخصي باستخدام كبل USB.

2 حدد الرمز جهات الاتصال. انتقل إلى القائمة < الملف > استيراد وحدد ملف CSV المحفوظ في الكمبيوتر الشخصي.

3 في حال اختلفت الحقول في ملف CSV المستورد عن الحقول في LG PC Suite IV، فيجب أن تقوم بتخطيط الحقول. بعد تخطيط الحقول، انقر فوق موافق. سيتم لاحقاً إضافة جهات الاتصال إلى الكمبيوتر الشخصي.

4 في حال كشف برنامج LG PC Suite IV اتصال الهاتف (باستخدام كبل LG-P350)، انقر فوق "مزامنة" أو "مزامنة جهات الاتصال" لمزامنة جهات الاتصال المحفوظة في الكمبيوتر الشخصي إلى الهاتف وحفظها.

كيفية إرسال البيانات من الهاتف عبر بلوتوث

إرسال البيانات عبر بلوتوث؛ يمكنك إرسال البيانات عبر بلوتوث من خلال تشغيل التطبيق المناسب خارج قائمة بلوتوث، بخلاف الهواتف المحمولة العادية.

* إرسال صور: قم بتشغيل تطبيق المعرض وحدد الصورة < القائمة. انقر فوق مشاركة وحدد بلوتوث < تحقق من كون بلوتوث قيد التشغيل وحدد بحث عن الأجهزة < واختر الجهاز الذي تريد إرسال البيانات إليه من القائمة.

قبل استخدام الهاتف المحمول، يرجى قراءة التعليمات أولاً!

* الاتصال بـ FTP (يعتمد هذا الهاتف خادم FTP فقط): حدد "الإعدادات" < "الاتصالات اللاسلكية و الشبكات" < "إعدادات بلوتوث". ثم حدد خانة الاختيار "قابل للكشف" و ابحث عن أجهزة أخرى. اعثر على الخدمة التي تريد واتصل بخادم FTP.

تلميح: الإصدار هو بلوتوث 2.1 EDR وتمت المصادقة عليه من قبل بلوتوث SIG. وهو متوافق مع الأجهزة الأخرى المصادق عليها من قبل بلوتوث SIG. - إذا أردت البحث عن هذا الهاتف من أجهزة أخرى، انتقل إلى "الإعدادات" < "الاتصالات اللاسلكية و الشبكات" < "إعدادات بلوتوث". ثم حدد خانة الاختيار "قابل للكشف". يتم مسح خانة الاختيار بعد 120 ثانية.

- الأنماط المعتمدة هي HFP و HSP و OPP و خادم PBAP و خادم FTP و A2DP و AVRCP و DUN.

* تصدبر جهات اتصال: قم بتشغيل تطبيق جهات الاتصال. المس العنوان الذي تريد التصدير إليه. اضغط على القائمة وحدد مشاركة < بلوتوث < تحقق من كون بلوتوث قيد التشغيل وحدد التحقق من الأجهزة < واختر الجهاز الذي تريد إرسال البيانات إليه من القائمة.* إرسال العديد من جهات الاتصال المحددة: قم بتشغيل تطبيق "جهات الاتصال". لتحديد أكثر من جهة اتصال واحدة اضغط على القائمة والمس تحديد متعدد. حدد جهات الاتصال التي تريد إرسالها أو اضغط على مفتاح القائمة والمس تحديد الكل. حدد المشاركة < بلوتوث < تحقق من كون بلوتوث قيد التشغيل وحدد التحقق من الأجهزة < واختر الجهاز الذي تريد إرسال البيانات إليه من القائمة.

التعرّف على الهاتف الخاص بك

لتشغيل الهاتف، اضغط باستمرار على مفتاح الطاقة لمدة 3 ثوانٍ.
لايقاف تشغيل الهاتف، اضغط على مفتاح الطاقة لمدة 3 ثوانٍ والممس إيقاف التشغيل.

تلميح: عندما تكون الشاشة مقفلة

1. قم بتمرير إصبعك من اليسار إلى اليمين لإلغاء قفل الشاشة.
2. لايقاف تشغيل الهاتف، اضغط على مفتاح الطاقة لمدة 3 ثوانٍ والممس إيقاف التشغيل.



⚠ تحذير: قد يؤدي وضع شيء ثقيل الوزن على الهاتف أو الجلوس عليه إلى إلحاق الضرر بوظائف شاشة LCD وشاشة اللمس.

تلميح! عند الضغط على أي تطبيق اضغط على مفتاح القائمة للتحقق من الخيارات المتوفرة.

تلميح! لا يدعم LG-P350 مكالمات الفيديو.

تلميح! في حال حدوث أخطاء في LG-P350 عند استخدامه، وفي حال تعذّر تشغيله، قم بإزالة البطارية وتثبيتها مجدداً وتشغيل الهاتف بعد 5 ثوانٍ.

موصل سماعة استيريو




مفاتيح مستوى الصوت

- على الشاشة الرئيسية:
للتحكم بمستوى صوت
الرنين.

- أثناء مكالمة: للتحكم
بمستوى صوت سماعة
الأذن.

- عند تشغيل مساز:
للتحكم بمستوى
الصوت باستمرار.

الشاحن. موصل كبل USB
الصغير



الميكروفون



عدسة الكاميرا

الغطاء الخلفي

فتحة بطاقة SIM

البطارية


فتحة بطاقة الذاكرة
micro SD



تركيب بطاقة SIM والبطارية

قبل البدء باستكشاف الهاتف الجديد، يجب أن تقوم بإعداده. لإدراج بطاقة SIM والبطارية:


1 لإزالة الغطاء الخلفي، امسك الهاتف بيدك بقوة. وباليد الأخرى، اضغط بقوة بإبهامك على الغطاء الخلفي. وارفع غطاء البطارية بالسبابة.



2 أدخل بطاقة SIM داخل فتحة بطاقة SIM. تأكد من كون ناحية الملامسات الذهبية الموجودة على البطاقة موجهة نحو الأسفل.



شحن الهاتف

حرّك إلى الخلف غطاء موصل الشاحن الموجود على جانب هاتف LG-P350. أدخل الشاحن، وقم بتوصيله بمأخذ كهربائي. يجب شحن LG-P350 إلى أن ترى .



ملاحظة: يجب شحن البطارية بالكامل أولاً لتحسين فترة عمل البطارية.

ملاحظة: الهاتف LG-P350 مزود بهوائي داخلي. احرص على عدم خدش أو تلف هذا الجانب الخلفي إذ قد يؤدي ذلك إلى تقليل كفاءة الجهاز.

3 أدخل البطارية في مكانها من خلال محاذاة الملامسات الذهبية الموجودة على الهاتف والبطارية.



4 اعد تركيب الغطاء الخلفي للهاتف.




تثبيت بطاقة الذاكرة

لتخزين ملفات وسائط متعددة مثل الصور الملتقطة من خلال كاميرا مدمجة، يجب أن تقوم بإدخال بطاقة ذاكرة في الهاتف.

ملاحظة: يدعم الهاتف LG-P350 بطاقة ذاكرة تصل سعتها 32 جيجابايت، لإدخال بطاقة ذاكرة:

1 قم بإيقاف تشغيل الهاتف قبل إدخال بطاقة الذاكرة أو إزالتها. انزع الغطاء الخلفي.



2 أدخل بطاقة الذاكرة في الفتحة. تأكد من كون ناحية الملامسات الذهبية موجهة نحو الأسفل.



- 1 على الشاشة الرئيسية، المس علامة التبويب التطبيقات لفتح قائمة التطبيقات.
 - 2 قم بالتمرير والمس الإعدادات.
 - 3 قم بالتمرير والمس تخزين الهاتف و بطاقة SD.
 - 4 فصل بطاقة SD.
 - 5 المس تهيئة بطاقة SD، ثم قم بتأكيد خيارك.
 - 6 إذا قمت بضبط نقش القفل، فأدخل نقش القفل وحدد مسح كل شيء، سيتم تهيئة البطاقة وتصبح جاهزة للاستخدام.
- ملاحظة: إذا توفر محتوى على بطاقة الذاكرة، قد تكون بنية الحافظة مختلفة بعد التهيئة نظراً لحذف كل الملفات.



⚠️ تحذير!

لا تقم بإدراج بطاقة الذاكرة أو إخراجها عندما يكون الهاتف في وضع التشغيل. وإلا، فقد يلحق الضرر بطاقة الذاكرة والهاتف، وقد تتلف البيانات المخزنة في بطاقة الذاكرة.

تهيئة بطاقة الذاكرة

قد تكون بطاقة الذاكرة مهينة أصلاً، إذا لم يتم تهيئة بطاقة الذاكرة، فعليك تهيئتها قبل أن تبدأ باستخدامها.

ملاحظة: يتم حذف كل الملفات الموجودة على البطاقة عندما تقوم بتهيئة البطاقة.

الشاشة الرئيسية الخاصة بك

إقفال الهاتف

تلميح! ضبط نقش إلغاء القفل: يمكنك رسم نقش إلغاء القفل الخاص بك من خلال توصيل أربع نقاط أو أكثر. تقفل شاشة الهاتف عند تعيين نقش. ارسـم النـقش الـذي قـمت بـتـعـيـنـه عـلى الشـاشـة لإلـغـاء قـفل الـهـاتف.

تلميح! يجب إنشاء حساب Gmail الخاص بك أولاً عند تعيين نقش إلغاء قفل.

تنبيه: سيتم إقفال الهاتف لمدة 30 ثانية بعد 5 محاولات غير صحيحة من رسم نقش إلغاء القفل.

اضغط على مفتاح الطاقة/القفل لإقفال الهاتف LG-P350. عند عدم استخدامه، يساعد ذلك على منع الضغط على أي من المفاتيح بطريق الخطأ وعلى توفير طاقة البطارية. إذا لم تستخدم الهاتف لفترة معينة، يتم استبدال الشاشة الرئيسية أو الشاشة الأخرى التي تقوم بعرضها بشاشة القفل لتوفير طاقة البطارية. ملاحظة: إذا كان ثمة برامج قيد التشغيل أثناء تعيين النـقش، فـقـد تـبقـى قـيد التـشـغـيل فـي وـضـع القـفـل. يُنصـح بـإنـهـاء كـل الـبـرـامـج قـبـل دـخـول وـضـع القـفـل لـتـجـنـب أي رـسـوم غـير ضـرـورـية. (مـثـلاً، المـكـالمـة الـهـاتفـية. والوصول إلى ويب واتصالات البيانات).

شاشة إلغاء القفل

الأخيرة التي كنت تستخدمها.

الصفحة الرئيسية


اضغط بإصبعك إلى اليسار أو اليمين لعرضها.

ويمكنك تخصيص كل لوحة مع عناصر واجهة الاستخدام والاختصارات. وتكون اختصارات للتطبيقات، والحافظات والخلفيات المفضلة لديك.

ملاحظة: قد تخلق بعض صور الشاشات وهذا يتوقف على موفر خدمة الهاتف.

تلميح! لإضافة رمز تطبيق إلى الشاشة الرئيسية، المس باستمرار التطبيق الذي تريد إضافته إلى الشاشة الرئيسية.

تلميح!


• المس هذا الرمز واضغط عليه. سيتغير رمز التطبيقات إلى رمز المهملات .

• اسحب رمز تطبيق وأفلته في رمز المهملات .


تلميح! لا يمكنك حذف التطبيقات المحملة مسبقاً. (يمكن حذف رموزها فقط من الشاشة.)

عندما لا يكون الهاتف LG-P350 قيد الاستخدام، يعود إلى شاشة

القفل. قم بتمرير إصبعك من اليسار إلى اليمين لإلغاء قفل الشاشة.



وضع الصامت

المس  ليصبح  في نافذة الإشعار أو في حال عدم استخدام نقش إلغاء القفل، ما عليك إلا سحب  إلى اليسار.




لتنشيط الهاتف، اضغط على إرسال أو مفتاح الطاقة/القفل. تظهر شاشة القفل. المس رمز القفل وقم بتمرير إصبعك إلى الجانب الأيمن لإلغاء قفل الشاشة الرئيسية. تفتح الشاشة

العودة إلى تطبيقات مستخدمة مؤخراً

المس مفتاح الشاشة الرئيسية واضغط عليه. ستظهر الشاشة إطاراً منبثقاً مع رموز تطبيقات استخدمتها مؤخراً.

نافذة الإشعار

يتم تشغيل نافذة الإشعار في أعلى الشاشة.





المس نافذة الإشعار ومررها نحو الأسفل بإصبعك. أو المس مفتاح القائمة على الشاشة الرئيسية. وحدد الإشعارات. يمكنك هنا التحقق من حالة Wi-Fi وبلوتوث وإشعارات أخرى وإدارتها.


لوحة المفاتيح على الشاشة


يمكنك أيضاً إدخال نص باستخدام لوحة المفاتيح على الشاشة. تعرض لوحة المفاتيح على الشاشة تلقائياً عندما تحتاج إلى إدخال نص. لعرض لوحة المفاتيح يدوياً، ما عليك إلا لمس حقل النص حيث تريد إدخال النص.


لوحة مفاتيح الهاتف (لوحة المفاتيح الكاملة)


 مفتاح Shift - المس مرة واحدة لكتابة الحرف التالي بخط كبير. اضغط مرتين للكتابة بأحرف كبيرة (عند الكتابة باللغة الانجليزية).

 مفتاح XT9 - تشغيل وضع XT9 أو إيقاف تشغيله.

 مفتاح الإعدادات - اضغط لعرض قائمة الإعدادات. اختر من ضمن الخيارات إعدادات المحرر وتخطيط لوحة المفاتيح ولغة الكتابة وقاموس المستخدم و أسلوب إدخال آخر.

 مفتاح الأرقام والرموز - المس لتغيير الإدخال إلى الأرقام والرموز.

 مفتاح الإدخال - اضغط لإنشاء سطر جديد في حقل الرسالة.


 مفتاح اللغة - اضغط لتغيير

Google وأحداث التقويم
ومعلومات أخرى من هذه التطبيقات
والخدمات على ويب مع الهاتف.

المكالمات

الرد على مكالمة ورفضها

عندما تكون الشاشة مقفلة/ عند
إلغاء قفل الشاشة


عند رنين الهاتف. اسحب رمز الرد  إلى اليمين.

اسحب رمز الرفض  إلى اليسار
لرفض مكالمة واردة. اسحب شريط
رسالة الاعتذار من الأسفل إذا أردت
إرسال رسالة.


أو عند رنين الهاتف اضغط على
مفتاح الرد (الإرسال). اضغط مفتاح
الرفض (مفتاح الطاقة/القفل)
لرفض المكالمة الواردة.

المس شريط رسالة الاعتذار من
الأسفل.

لغة لوحة المفاتيح على الشاشة.

مفتاح الحذف 

التنقل إلى الأمام أو إلى
الخلف بين الأحرف.

تلميح! للتبديل بين لوحة المفاتيح
الكاملة ولوحة مفاتيح الهاتف.
المس  من لوحة الهاتف و اختر
تخطيط لوحة المفاتيح.

إعداد حساب Google

عند فتح تطبيق Google للمرة
الأولى على الهاتف. سيطلب منك
تسجيل الدخول بحساب Google
الموجود والخاص بك. سيطلب منك
إنشاء حساب Google إذا لم يكن
لديك حساباً.

هام

- تعمل بعض التطبيقات مع حساب
Google الأول الذي قمت بإضافته
فقط. إذا كنت تخطط لاستخدام
أكثر من حساب Google واحد مع
الهاتف. فتأكد من تسجيل الدخول
إلى الحساب الذي تريد استخدامه
مع هذه التطبيقات أولاً. عند
تسجيل الدخول. تتم مزامنة جهات
الاتصال ورسائل البريد الإلكتروني

الرسائل

يجمع الهاتف LG-P350 ميزات إرسال رسائل نصية ورسائل الوسائط المتعددة قائمة واحدة بديهية وسهلة الاستخدام.



تحذير: قد يختلف الحد المكوّن من 160 حرفاً من بلدٍ إلى آخر وفقاً لكيفية ترميز SMS واللغة.



تحذير: إذا تمت إضافة صورة، أو ملف فيديو أو ملف صوتي إلى رسالة SMS، فسيتم تحويلها تلقائياً إلى رسالة MMS، وسيفرض رسم عليك وفقاً لذلك.

الشبكات الاجتماعية

بواسطة هاتفك، يمكنك الاستفادة من الشبكات الاجتماعية وإدارة مدوّنتك الصغيرة في مجتمعات على الإنترنت. يمكنك تحديث حالتك الحالية وتحميل صور وعرض تحديثات حالات أصدقائك مباشرة بوقت فعلي. يمكنك إضافة حسابات Facebook و Twitter إلى هاتفك، إذا لم يكن لديك حساب، فيمكنك زيارة مواقعها الخاصة لإعداده.

ملاحظة: قد تفرض تكاليف إضافية عند الاتصال بخدمات على الإنترنت واستخدامها. اتصل بموفر الشبكة للتحقق من رسوم البيانات.

فتح البريد الإلكتروني وشاشة الحسابات


يمكنك استخدام تطبيق البريد الإلكتروني لقراءة البريد الإلكتروني من خدمات أخرى غير خدمة Gmail. يعتمد تطبيق البريد الإلكتروني أنواع الحسابات التالية: POP3 و IMAP و Exchange.

الكاميرا

التعرّف على محدّد المنظر

السطوع - يعمل هذا الخيار على تحديد مقدار ضوء الشمس الداخل للصورة والتحكم فيه. قم بتمرير مؤشر السطوع على طول الشريط باتجاه علامة "-" للحصول على صورة أقل سطوعاً أو باتجاه علامة "+" للحصول على صورة أكثر سطوعاً.

التكبير/التصغير - تكبير أو تصغير. كطريقة بديلة يمكنك استخدام مفاتيح مستوى الصوت الجانبية.



وضع الفيديو - قم بتمرير هذا الرمز لأسفل للتبديل إلى وضع الفيديو.

التقاط صورة

المعرض - يمكنك هذا الخيار من الوصول إلى الصور المحفوظة من داخل وضع الكاميرا. ما عليك سوى اللمس. وسيظهر المعرض على الشاشة.

الإعدادات - المس هذا الرمز لفتح قائمة الإعدادات. انظر إلى استخدام الإعدادات المتقدمة.

تأثير الألوان - اختر درجة اللون للصورة الجديدة.

ملاحظة: يجب أن تقوم بإدخال بطاقة ذاكرة أولاً لالتقاط صورة. من دون إدخال بطاقة ذاكرة. لن تتمكن من التقاط صورة أو حفظ الصورة التي التقطتها.

بمجرد التقاط الصورة

تظهر الصورة الملتقطة على الشاشة.

مشاركة المس لمسشاركة صورتك ك بلوتوث أو البريد الإلكتروني أو Facebook أو Gmail أو الرسائل أو Picasa أو Twitter.

ملاحظة: قد تتم إضافة رسوم إضافية عند تنزيل رسائل الوسائط المتعددة (MMS) أثناء التجوال.

ملاحظة: قد يختلف خيار المشاركة بحسب المنطقة والهاتف والناقل والمخطط وإصدار برنامج هاتف Android.


ضبط ك المس لاستخدام الصورة ك رمز اسم أو خلفية الشاشة.

إعادة التسمية المس لتعديل اسم الصورة المحددة.

تطبيقات Google Google Maps

موقعي  - أُنشر إلى موقعك الحالي على الخريطة.

الانضمام إلى Latitude  - شارك موقعك مع Google والأصدقاء الذين تختارهم.

المزيد  - امسح الخريطة أو اعثر على عناصر موضوع عليها علامة نجمة والكثير غير ذلك.

⚠️ إشعار:

بعض التطبيقات في جهازك LG-P350 تتطلب الاتصال عبر GPS (النظام العالمي لتحديد المواقع) لكن خدمة تحديد الموقع غير معتمدة وبعض المزايا يمكن ان تكون غير متاحة حسب منطقتك أو مزود الخدمة الخاص بك.

Market™

يتيح لك Android Market™ تنزيل تطبيقات وألعاب مفيدة.



تحقق من موقعك الحالي وحركة المرور واحصل على التوجيهات للوصول إلى وجهتك، يجب أن يتم توصيل LG-P500 بـ Wi-Fi أو 3G/GPRS.

ملاحظة مهمة: قد لا تعمل هذه التطبيقات عندما لا يدعمها موفر الخدمة

ملاحظة: لا تغطي Google Maps™ كل المدن والبلدان.

اضغط على مفتاح القائمة لاستخدام الخيارات:

البحث  - أدخل المكان الذي تريد البحث عنه.

الاتجاهات  - يتيح لك هذا الخيار العثور على طريق، المكان الذي أدخلته. المس  لإدخال البيانات .

اختر من بين الخيارات جهات الاتصال أو الإشارة على الخريطة أو موقعي الحالي.

الطبقات  - يمكنك تبديل العرض من حركة المرور إلى القمر الاصطناعي أو الأرض. اضغط على Latitude فترى موقع جهات الاتصال من حساب Google.

Gmail™

يتم تكوين Gmail™ عندما تقوم بإعداد هاتفك، تتم مزامنة Gmail™ تلقائياً على الهاتف مع حساب Gmail™ على ويب، ويتوقف ذلك على إعدادات المزامنة.


الويب


المتصفح

ملاحظة: يتم فرض رسوم إضافية عند الاتصال بهذه الخدمات وتنزيل المحتوى. اتصل بموفر الشبكة للتحقق من رسوم البيانات.


استخدام الخيارات


اضغط على مفتاح القائمة لعرض الخيارات.


إطار جديد - فتح إطار جديد. 

العلامة المرجعية - إضافة/ 

إظهار علامة مرجعية، إظهار الموقع الذي تتم زيارته بكثرة والمحفوظات.

الإطارات - تظهر كل الإطارات المفتوحة. 

تحديث - المس لتحديث صفحة ويب. 

إعادة التوجيه - ينقلك هذا الخيار إلى الصفحة التي اتصلت بها بعد الصفحة الحالية، يختلف ذلك عن مفتاح الرجوع الذي ينتقل إلى الصفحة السابقة. 

Talk

Talk هو برنامج مراسلات فورية على Google. يسمح لك بالاتصال بأشخاص آخرين يستخدمون أيضاً Talk.



ThinkFree Office

يتيح لك ThinkFree Office قراءة المستندات، ويوفر وظائف تعديل محدودة لـ Microsoft Word و Excel و PowerPoint. ولكن، لا يمكنك تعديل ملف PDF.

1 المس باستمرار ملفاً، فتتوفر خيارات الفتح، والتحميل، وإعادة التسمية، والنقل، والنسخ، والحذف والإرسال والخصائص. يتوقف ذلك على نوع الملف.

Wi-Fi

لتشغيل Wi-Fi

من الشاشة الرئيسية، افتح نافذة الإشعار والمس  لتشغيل Wi-Fi. من القائمة، اختر الإعدادات < الاتصالات اللاسلكية و الشبكات < Wi-Fi .

لاتصال بشبكة Wi-Fi

اختر شبكة Wi-Fi التي تريد الاتصال بها، إذا رأيت ، فحتاج إلى إدخال كلمة المرور للاتصال.

تلميح!

إذا كنت خارج منطقة تغطية Wi-Fi واخترت اتصال الجيل الثالث (3G)، فقد تفرض رسوم إضافية.

اتصال USB

يمكنك مشاركة اتصال إنترنت في الهاتف مع الكمبيوتر. يمكنك توصيل الهاتف بالكمبيوتر باستخدام كبل USB.

الإعدادات < الاتصالات اللاسلكية والشبكات < الاتصال والنقطة الفعالة والمحمولة < اتصال USB.

انقر فوق تعليمات للحصول على مزيد من المعلومات حول اتصال USB.

تلميح!

لاستخدام اتصال USB، تحتاج إلى تثبيت PC Suite في الكمبيوتر الشخصي أولاً.

اتصال Wi-Fi

استخدم LG-P350 كنقطة Wi-Fi فعالة ومحمولة.

الإعدادات < الاتصالات اللاسلكية والشبكات < الاتصال والنقطة الفعالة والمحمولة < نقطة Wi-Fi الفعالة والمحمولة.

تلميح!

إذا انتقل الهاتف إلى وضع السكون حتى إذا كان متصلاً بشبكة Wi-Fi، فيتم إيقاف اتصال Wi-Fi تلقائياً.

وفي هذه الحالة، إذا كان لهاتفك وصول إلى بيانات الجيل الثالث (3G)، قد يتصل الهاتف بشبكة الجيل الثالث (3G) تلقائياً وبالتالي سيتم فرض رسوم إضافية.

ملاحظة: يعتمد LG-P350 حماية WEP و WPA/WPA2 PSK و 802.1x EAP. إذا قام موفر خدمة Wi-Fi أو مسؤول الشبكة بتعيين

إشعار

للحصول على التعليمات البرمجية للمصدر ضمن GPL و LGPL و MPL وتراخيص مصدر أخرى مفتوحة، يرجى زيارة الموقع <http://opensource.lge.com/> كل شروط الترخيص والتنازلات والإشعارات ذات الصلة متوفرة للتنزيل مع التعليمات البرمجية للمصدر.

التشفير لحماية الشبكة، فعليك ملء المفتاح في الإطار المنبثق، إذا لم يتم تعيين التشفير فلن يظهر الإطار المنبثق هذا. يمكنك الحصول على المفتاح من موفر خدمة Wi-Fi لديك أو من مسؤول الشبكة.

تحديث برنامج الهاتف

تحديث برنامج الهاتف المحمول LG من إنترنت

لمزيد من المعلومات حول استخدام هذه الوظيفة، تفضل بزيارة <http://update.lgmobile.com> أو [http://www.lg.com/](http://www.lg.com/common/index.jsp) وحدد الدولة واللغة.

تسمح لك هذه الميزة بتحديث أحدث إصدار لبرامج الهاتف الثابت بسهولة من إنترنت من دون الحاجة إلى زيارة مركز خدمة.

بما أن تحديث برنامج الهاتف المحمول الثابت يتطلب انتباه المستخدم الكامل لمدة عملية التحديث، يرجى التحقق من كل التعليمات والملاحظات التي تظهر في كل خطوة قبل المتابعة. يرجى الانتباه إلى أن إزالة كبل بيانات USB أو البطارية أثناء الترقية قد يتسبب بإلحاق ضرر بالغ بهاتفك المحمول.

الملحقات

يمكن استخدام هذه الملحقات مع الهاتف LG-P350.
(قد تكون العناصر المذكورة أدناه اختيارية.)



كبل البيانات
لتوصيل الجهاز
LG-P350
والكمبيوتر.



الشاحن



دليل المستخدم
اعرف المزيد حول
LG-P350.



البطارية



سماعة
استيريو

ملاحظة:

- استخدم دائماً ملحقات LG الأصلية.
- يؤدي عدم القيام بذلك إلى إبطال الكفالة.
- وقد تختلف الملحقات من منطقة إلى أخرى.

LG-P350 User Guide



- Some of the contents of this manual may not apply to your phone depending on your phone's software or your service provider.
- This handset is not recommended for the visually impaired because of its touch-screen keypad.
- Copyright ©2011 LG Electronics, Inc. All rights reserved. LG and the LG logo are registered trademarks of LG Group and its related entities. All other trademarks are the property of their respective owners.
- Google search, Gmail, YouTube, Talk and Android Market are trademarks of Google, Inc.



Congratulations on your purchase of the advanced and compact LG-P350 phone by LG, designed to operate with the latest digital mobile communication technology.

Important notice

Please check to see if any problems you have encountered with your phone are described in this section, before taking the phone in for service or calling a service representative.

1. Phone memory

When available space on your phone memory is less than 10%, your phone cannot receive a new message. You need to check your phone memory and delete some data such as applications or messages to make more memory available.

To manage the application

- 1 On the home screen, touch **Applications** tab and select **Settings > Applications > Manage applications**.
- 2 When all applications appear, scroll and select the application you want to uninstall.
- 3 Tap **Uninstall** and touch OK to uninstall the application you desired.

2. Optimising Battery Life

You can extend your battery's life by turning off features that you don't need to run constantly in the background. You can also monitor how applications and system resources consume battery power.

To extend the life of your battery

- Turn off radio communications that you aren't using. If you aren't using Wi-Fi or Bluetooth turn them off.
- Turn down screen brightness and set a shorter screen timeout.
- Turn off automatic syncing for Gmail, Calendar, Contacts, and other applications.
- Some applications you've downloaded may cause your battery's life to be reduced.

Important notice

To check the battery charge level


- 1 On the home screen, touch **Applications** tab and select **Settings> About phone > Status**.
- 2 The battery status (charging, discharging) and level (as a percentage of fully charged) are displayed at the top of the screen.


To monitor and control what uses the battery

- 1 On the home screen, touch **Applications** tab and select **Settings> About phone> Battery use**.
- 2 The top of the screen displays battery usage time. Either how long since last connected to a power source or, if connected to a power source, how long you were last running on battery power. The body of the screen lists applications or services using battery power from greatest amount to least.

3. Installing an Open Source OS

If you install an open source OS on your phone, and do not use the OS provided by the manufacturer, this may cause your phone to malfunction.

 **WARNING:** If you install and use an OS other than the one provided by the manufacturer, your phone is no longer covered by the warranty.


 **WARNING:** To protect your phone and personal data, download applications only from trusted sources, such as Android Market™. If some applications are not properly installed on your phone, your phone may not work correctly or a serious error could occur. You will need to uninstall those applications and all of its data and settings from the phone.

4. Using Unlock pattern

Set unlock pattern to secure your phone. Opens a set of screens that guide you through drawing a screen unlock pattern.

On the home screen, touch Applications tab and select **Settings > security > Set up screen lock > Pattern**.

Follow the screens to be guided through drawing a screen unlock pattern. Select Next to continue to next screen.

 **WARNING:** Precautions to take when using the Pattern Lock. It is very important that you remember the unlock pattern you set. You have 5 opportunities to enter your unlock Pattern, PIN or Password. If you have used all 5 opportunities, you may attempt again after 30 seconds.

When you can't recall your unlock Pattern, PIN, or Password:

If you've created a Google account on the phone, tap the Forgot pattern button. Then, you are required to sign in with your Google account to unlock your phone. If you haven't created a Google account on the phone or you forgot it, you need to perform a hard reset.

Caution: If you perform a hard reset, all user applications and user data will be deleted. Please remember to backup any important data before performing a hard reset.

Important notice

5. Using Safe Mode and Hard Reset

Using Safe mode

* To recover the phone from any malfunction

Turn off your phone and reboot. While your phone is powering back on, press and hold the Send key while the Android Logo is displayed. Your phone will boot all the way to the main screen and display "safe mode" in the lower left-hand corner.

* Using Hard Reset (Factory Reset)

If it does not restore to its original state, use **Hard Reset** to initialise your phone.

- 1 Remove and reinsert the battery.
- 2 Press and hold for over 10 seconds: **Power/Lock** key + **Send** key + **Down Volume** key.

- 3 When the power turns on, release these keys.

WARNING

If you perform a Hard Reset, all user applications and user data will be deleted. Please remember to back up any important data before performing a **Hard Reset**.

6. Connecting to Wi-Fi networks

To use Wi-Fi on your phone, you access a wireless access point, or "hotspot." Some access points are open and you can simply connect to them. Others are hidden or implement other security features, so you must configure your phone so it can connect to them.

Turn off Wi-Fi when you're not using it, to extend the life of your battery.

To turn Wi-Fi on and connect to a Wi-Fi network

- 1 On the home screen, touch **Applications** tab and select **Settings > Wireless & networks > Wi-Fi settings**.
- 2 Touch **Wi-Fi** to turn it on and begin scan for available Wi-Fi networks.
 - List of available Wi-Fi networks is displayed. Secured networks are indicated by a lock icon.
- 3 Touch a network to connect to it.
 - If the network is open, you are prompted to confirm that you want to connect to that network by touching **Connect**.
 - If the network is secured, you're prompted to enter a password or other credentials. (Ask your network administrator for details.)
- 4 The Status bar displays icons that indicate Wi-Fi status.

7. Using a micro SD card

Pictures, along with Music and Video files, can only be saved to external memory.

Before using the built-in camera, you need to insert a micro SD memory card to your phone first. Without inserting a memory card, you will not be able to save pictures and video you have taken.

WARNING:

Do not insert or remove the memory card when the phone is on. Otherwise, it may damage the memory card as well as your phone, and the data stored on the memory card may be corrupted. To remove the memory card safely, please select **Home Screen > Applications > Settings > SD card & phone storage > Unmount SD card**.

Important notice

8. Opening and Switching Applications

Multi-tasking is easy with Android because open applications keep running even when you open another application. There's no need to quit an application before opening another. Use and switch among several open applications. Android manages each application, stopping and starting them as needed, to ensure that idle applications don't consume resources unnecessarily.

To stop the application you use

- 1 On the home screen, touch **Applications** tab and select **Settings > Applications > Manage applications > Running**.
- 2 Scroll to the desired application and touch **Force stop** to stop using it.

TIP Getting back to recent Apps

- Press and hold Home key, then a screen will display a list of the applications you used recently

9. Copy LG PC Suite from SD Card

The LG PC Suite IV is a program that helps you connect your mobile phone to a PC using a USB data communication cable, so that you can use the functions of the mobile phone on your PC.

Major Functions of the LG PC Suite IV

- Create, edit and delete phone data conveniently.
- Synchronise data between a PC and a phone (Contacts, Calendar, Message(SMS), Bookmark, Call log).

- Transfer multimedia files (photos, videos, music) conveniently with a simple drag & drop between a PC and a phone.
- Transfer the messages from a phone to a PC.
- Use your phone as a Modem.
- S/W update without losing your data.

Installing LG PC Suite from your micro SD memory card

- 1 Insert your micro SD memory card on your phone. (It may already be inserted on your phone.)
- 2 Before connecting the USB data cable, make sure that the **Mass storage only** mode is enabled on your phone. (On the applications menu, choose **Settings > SD card & phone storage**, then select **Mass storage only** check box.)

- 3 Connect your phone through USB data cable to your PC.
- 4
 - In the status bar, drag the USB icon.
 - Choose USB Connected and Turn On USB storage.
 - You can view the mass storage content on your PC and transfer the files.
- 5
 - Copy the '**LGPCSuiteIV**' folder on your mass storage to your PC.
 - Run 'LGInstaller.exe' file on your PC and follow the instructions.

* When LG PC Suite IV installation is completed, disable **Mass storage only** mode to run LG PC Suite IV.

NOTE: Please do not remove or delete other program files installed on your memory card. This may cause damage to your preinstalled applications on the phone.

Important notice

10. Connecting your phone to a computer via USB

NOTE: To synchronise your phone via USB cable with your PC, you need to install the LG PC Suite program on your PC. You can download this program from the LG website (www.lg.com). Go to <http://www.lg.com> and select your region, country & language. Visit LG website for more information. As PC Suite is embedded at inboxed SD card, you can simply copy it to your PC.

LG-P350 does not support:

- PC Connection via Bluetooth
- LG Air Sync (Web Sync, R-Click)
- OSP (On Screen Phone)
- To-do in Calendar
- Memo
- Java Application

User's guide for PC Suite IV is in Help menu after the installation PC Suite IV.

- 1 Use the USB cable with your phone to connect the phone to a USB port on your computer. You receive a notification that the USB is connected.
- 2 Open the Notification drawer and touch USB connected.
- 3 Touch **"Turn On USB storage"** to confirm that you want to transfer files between your phone's micro SD card and the computer.

When the phone is connected as USB storage, you will receive a notification. Your phone's micro SD card is mounted as a drive on your computer. You can now copy files to and from the micro SD card.

11. Unlock screen when using data connection

Your display will go dark if untouched for a period of time when using data connection. To turn on your LCD screen, just

touch it.

Note: When uninstalling PC Suite IV, USB and Bluetooth Drivers are not automatically removed. Therefore, they must be uninstalled manually.

Tip! To use a micro SD card on your phone again, you need to open the Notification drawer and touch "**Turn off USB storage**". During this time, you can't access the micro SD card from your phone, so you can't use applications that rely on the micro SD card, such as Camera, Gallery and Music.

To disconnect your phone from the computer, carefully follow your computer's instructions to disconnect USB devices correctly, to avoid losing information on the card.

- 1 Safely disconnect the USB device on your computer.
- 2 Open the Notification drawer and touch **Turn off USB storage**.

- 3 Touch **Turn off USB storage** in the dialog that opens.

12. Hold phone up right

Please hold the mobile phone up right as a regular phone.

While making/receiving calls or sending/receiving data, try to avoid holding the lower part of the phone where the antenna is located. It may affect call quality.

13. When Screen freezes

If the phone does not respond to user input or the screen freezes:

Remove the battery, insert it again and turn the phone on. If it still does not work, please contact the service centre.

14. Do not connect your phone when turning your PC on/off

Make sure to disconnect your phone and PC via data cable as your PC might have errors.

Before using the mobile phone, please read first!

How to save music/video files to the phone

Connect your phone to the PC using the USB cable.

Touch and drag down the status bar on the home screen. Select **USB connected > Turn on USB storage > Open folder to view files.**

If you didn't install LG Android Platform Driver on your PC, you need to set it manually. On the home screen, touch **Applications** tab and select **Settings > SD card & phone storage > activate Mass storage only.**

Save music or video files from the PC to the phone's removable storage.

- You may copy or move files from the PC to the phone's removable storage using a card reader.

- If there is a video file with a subtitle file (.smi or .srt file with the same name as the video file), place them in the same folder to display the subtitle automatically when playing the video file.
- When downloading music or video files, copyright must be secured. Please note that a corrupted file or file with a wrong extension may cause damage to the phone.

How to play music/video files to the phone

Playing music files

From home screen touch **Application** tab > **Music**. Locate the file you want to play from Artist, Albums, Songs, Playlists tabs.

Playing video files

From home screen touch **Application** tab > **Video player**, locate the file you want in the list and select it to play.

How to move the contacts from the old phone to the current phone

Export your contacts as a CSV file from your old phone to the PC using a PC sync program.

- 1 Download LG PC Suite IV at www.lg.com and install it in the PC. Run the program and connect your phone to the PC using the USB cable.
- 2 Select the **Contacts** icon. Go to **Menu > File > Import** and select the CSV file saved in the PC.
- 3 If the fields in the imported CSV file are different from the ones in LG PC Suite IV, you need to map the fields. After mapping the fields, click OK. Then, the contacts are added to the PC.
- 4 If the connection of LG-P350 phone (using the USB cable) is detected by LG PC Suite IV, click "Sync" or "Sync Contacts" to synchronise the contacts saved in the PC to your phone and save them.

How to send data from your phone via Bluetooth

Sending data via Bluetooth:

You can send data via Bluetooth by running a corresponding application, not from Bluetooth menu, unlike regular mobile phones.

- * **Sending pictures:** Run the Gallery application and select **Picture > Menu**. Click **Share** and select **Bluetooth > Check If Bluetooth is turned on** and select **Scan for devices > Choose the device you want to send data from the list**.

Before using the mobile phone, please read first!

* **Exporting contacts:** Run the Contacts application. Touch the address you want to export to. Press **Menu** and Select **Share > Bluetooth > Check** if Bluetooth is turned on and select **Scan for devices >** Choose the device you want to send data from the list.

* **Sending multi-selected contacts:** Run the "Contacts" application. To Select more than one contact press **Menu** key and touch **Multiselect**. Select the contacts you want to send or press **Menu** key and touch **Select all**. Select **Share > Bluetooth > Check** if Bluetooth is turned on and select **Scan for devices >** Choose the device you want to send data from the list.

* **Connecting to FTP (Only the FTP server is supported on this handset):** Select **"Settings" > "Wireless & networks" > "Bluetooth settings"**. Then, select the **"Discoverable"** checkbox and search for other devices. Find the service you want and connect to the FTP server.

TIP: The version is Bluetooth 2.1 EDR and certified by Bluetooth SIG. It is compatible with other Bluetooth SIG certified devices.

- If you want to search for this phone from other devices, go to **"Settings" > "Wireless & networks" > "Bluetooth settings"**.

Then, select the **"Discoverable"** checkbox.

The checkbox is cleared after 120 seconds.

- Supported profiles are HFP, HSP, OPP, PBAP (server), FTP (server), A2DP, AVRCP, and DUN.

Getting to know your phone

To turn the phone on, press and hold the Power key for 3 seconds.

To turn the phone off, press the Power key for 3 seconds and touch Power Off.

TIP! When screen is locked

1. Drag your finger from left to right to unlock the screen.
2. To turn the phone off, press the Power key for 3 seconds and touch Power Off.

Earpiece


Home key 

- Returns to the home screen from any screen.

Menu key 

- Check what options are available.

Send key 



Back key 


- Returns to the previous screen.

Search key 

- Search the web and contents in your phone.

Power/Lock key 

- Powers your phone on/off by pressing and holding the key.
- Turns the screen off and locks the phone.

 **WARNING:** Placing a heavy object on the phone or sitting on it can damage its LCD and touch-screen functionalities.

Tip! Press Menu key whenever you tap an application to check what options are available.

Tip! LG-P350 does not support video call.

Tip! If LG-P350 has errors when you use it or you cannot turn it on, remove battery, install it again and turn it on after 5 seconds.

Getting to know your phone

Stereo earphone connector



Charger, micro USB cable connector



Volume keys

- On the home screen: controls ringer volume.
- During a call: controls your earpiece volume.
- When playing a track: controls volume continuously.



Microphone



Camera lens

Back cover

SIM card slot

Battery


micro SD memory card slot



Installing the SIM card and battery

Before you can start exploring your new phone, you'll need to set it up. To insert the SIM card and battery:

- 1 To remove the back cover, hold the phone firmly in your hand. With your other hand, firmly press your thumb on the back cover. Lift off the battery cover with your forefinger.



- 2 Slide the SIM card into the SIM card holder. Make sure the gold contact area on the card is facing downwards.



Getting to know your phone


- 3 Insert the battery into place by aligning the gold contacts on the phone and the battery.



- 4 Replace the back cover of the phone.



Charging your phone

Slide back the cover of the charger connector on the side of your LG-P350. Insert the charger, and plug it into an electrical outlet. Your LG-P350 must be charged until you can see .



NOTE: The battery must be initially fully charged to improve battery lifetime.

NOTE: The LG-P350 has an internal antenna. Be careful not to scratch or damage this rear area, as this will cause loss of performance.



Installing the memory card

To store multimedia files such as captured images by using a built-in camera, you must insert a memory card to your phone.

NOTE: The LG-P350 supports up to a 32GB memory card.

To insert a memory card:

- 1 Turn the phone off before inserting or removing the memory card. Remove the back cover.
- 2 Insert the memory card into the slot. Make sure the gold contact area is facing downwards.



Getting to know your phone



WARNING!

Do not insert or remove the memory card when the phone is on. Otherwise, it may damage the memory card as well as your phone, and the data stored on the memory card may be corrupted.

Formatting the memory card

Your memory card may already be formatted. If it isn't, you must format it before you can use it.

NOTE: All files on the card are deleted when you format the card.

- 1 On the home screen, touch the **Applications** tab to open the applications menu.
- 2 Scroll and touch **Settings**.
- 3 Scroll and touch **SD card & phone storage**.
- 4 Unmount SD card.
- 5 Touch **Format SD card**, then confirm your choice.
- 6 If you set the pattern lock, input the pattern lock and select **Erase everything**. The card will then be formatted and ready to use.

NOTE: If there is content on your memory card, the folder structure may be different after formatting since all the files will have been deleted.

Tip!

If your memory card is already Unmounted, you can use the following step to format it. Touch **Applications > Settings > SD card & phone storage > Format SD card**.

Your Home screen

Lock your phone

When you are not using LG-P350, press the Power/Lock key to lock your phone. This helps prevent accidental presses and saves battery power.

Also, if you do not use the phone for a while, the home screen or other screen you are viewing is replaced with the lock screen to conserve the battery.

Note: If there are any programs running when you set the pattern, they may be still running in lock mode. It is recommended to exit all programs before entering the lock mode to avoid unnecessary charges. (e.g. phone call, web access and data communications).

Tip! Setting unlock pattern:

You can draw your own unlock pattern by connecting four or more dots.


If you set a pattern, the phone's screen is locked. To unlock the phone, draw the pattern you set on the screen.

Tip! When you set an unlock pattern, you need to create your Gmail account first.




Caution: The phone will be locked for 30 seconds after 5 incorrect attempts at drawing the unlock pattern.

Unlock screen

Whenever your LG-P350 is not in use, it will return to the lock screen. Drag your finger from left to right to unlock the screen.



Silent Mode

From Notification drawer, touch  to be  or if you don't use an unlock pattern, simply drag  to the left.



To wake up your phone, press **Send** or **Power/Lock** key. The lock screen will appear. Touch the lock icon and drag your finger to the right to unlock your home screen. The last screen

you were working on opens.



Home

Simply swipe your finger to the left or right to view them. You can also customise each panel with widgets, shortcuts, which are shortcuts to your favourite applications, folders and wallpapers.

NOTE: Some screen images may be different depending on your phone provider.

Tip! To add an application icon to the home screen, touch and hold the application you want to add to the home screen.

Tip!

- Touch and hold that icon. The **Applications** icon will be change as the **Trash** icon .
- Drag and drop an application icon to the **Trash** icon .


Tip! You cannot delete the preloaded applications. (Only their icons can be deleted from the screen.)

Getting back to a recently used applications

Touch and hold the Home key. The screen will show you a pop up with icons of applications that you've used recently.

Notification drawer

The notification drawer runs across the top of your screen.




Touch and slide the notification drawer down with your finger. Or, on the home screen, touch **Menu** key and select **Notifications**. Here, you can


check and manage Wi-Fi, Bluetooth status as well as other notifications.


Onscreen Keyboard

You can also enter text using the onscreen keyboard. The onscreen keyboard automatically displays on the screen when you need to enter text. To manually display the keyboard, simply touch a text field where you want to enter text.

Phone Keypad (Qwerty Keypad)


 **Shift Key** - Touch once to capitalise the next letter you type. Double tap for all caps.


 **XT9 Key** - Turn XT9 Mode on or off.

 **Setting key**- Tap to view the settings menu. Choose from Editor settings, Keyboard layout, Writing language, User dictionary and Other input method.



 **Number and Symbols Key -**


Touch to change input to number and symbol entry.

 **Enter Key -** Tap to create a new line in the message field.

 **Language Key -** Tap to change the On-screen Keyboard language.

 **Delete Key**

  Go forward or backward between letters.

Tip! To switch between Qwerty Keypad and Phone Keypad, touch  from Phone Keypad and choose Keyboard Layout.

Google Account Set-up

The first time you open the Google application on your phone, you will be required to sign in with your existing Google account. If you do not have a Google account, you're prompted to create one.

IMPORTANT

- Some applications work only with the first Google Account you add. If you plan to use more than one Google Account with your phone, be sure to sign into the one you want to use with such applications first. When you sign in, your contacts, Gmail messages, Calendar events, and other information from these applications and services on the web are synchronised with your phone.

Calls

Answering and rejecting a call

When screen is locked/ When screen is unlocked


When your phone rings, drag the **Answer** icon  to the right.


Drag **Decline** icon  to the left to reject an incoming call. Drag Excuse msg bar from the bottom

if you want to send one. Or else When your phone rings press the Answer button(Send key). Press Decline button(Power/Lock key) to reject the incoming call.Touch the Excuse msg bar from the bottom.

Messaging

Your LG-P350 combines SMS and MMS into one intuitive, easy-to-use menu.

 **WARNING:** The 160-character limit may vary from country to country depending on how the SMS is coded and in what language.

 **WARNING:** If an image, video, or audio file is added to an SMS message, it will be automatically converted into an MMS message, and you will be charged accordingly.

Opening Email and the Accounts Screen

You can use the **Email** application to read email from services other than Gmail. The Email application supports the following account types: POP3, IMAP and Exchange.

Social Networking

With your phone, you can take advantage of social networking and manage your micro-blog in on-line communities. You can update your current status, upload photos, and view your friends' status updates in real-time.

You can add your Facebook and Twitter accounts to your phone. If you don't have an account, you can visit their sites to set it up.

NOTE: Additional costs may be incurred when connecting and using online services. Check your data charges with your network provider.

Camera

Getting to know the viewfinder

Brightness – This defines and controls the amount of sunlight entering the image. Slide the brightness indicator along the bar, towards “-” for a lower brightness image, or towards “+” for a higher brightness image.

Zoom – Zoom in or zoom out. Alternatively, you can use the side volume keys.



Video mode – Slide down this icon to switch to video mode.

Taking a photo

Gallery – This enables you to access your saved photos from within the camera mode. Simply touch, and your gallery will appear on the screen.

Settings – Touch this icon to open the settings menu. See **Using the advanced settings**.

Colour effect – Choose a colour tone for your new photo.

NOTE: You need to insert a memory card first to take a picture. Without inserting a memory card, you will not be able to take a picture or save the picture you have taken.

Once you've taken the photo

Your captured photo will appear on the screen.

Share Touch to share your photo as **Bluetooth, Email, Facebook, Gmail, Messaging, Picasa** or **Twitter**.

NOTE: Additional charges may apply when MMS messages are downloaded while roaming.

NOTE: Share option may vary by area, phone, carrier, plan and version of Android Phone Software.

Set as Touch to use the image as **Contact icon** or **Wallpaper**.

Rename Touch to edit the name of the selected picture.


Google applications



Maps


Check your current location and traffic and receive directions to your destination. The LG-P350 must be connected to Wi-Fi or 3G/GPRS.

NOTE: Maps does not cover all cities and countries.


Press Menu key to use options:

Search  – Enter the place you are looking for.

Directions  – This will let you find out the route of the place you entered. Touch  to input the data. Choose from Contacts or Point on Map or My current location.

Layers  – You can switch view from Traffic to Satellite or Terrain. Tap Latitude, then you will see the location of your contacts from Google Account.

My Location  – Point your current location on the map.

Join Latitude  – Share your location with friends you choose and Google.

More  – Clear map or find Starred items and more.

WARNING:

Some of the applications in your LG-P350 requires GPS connectivity but GPS functions cannot be supported and some features may be unavailable depending on your region or service provider.

Market™

Android Market™ lets you download useful applications and games.

Gmail™

Gmail™ is configured when you first set up your phone. Depending on your synchronisation settings, Gmail™ on your phone is automatically synchronised with your Gmail™ account on the web.

Talk

Talk is Google's instant messaging program. It lets you communicate with other people who also use Talk.

ThinkFree Office

ThinkFree Office allows you to read documents, and provides limited editing functions for Microsoft Word, Excel and PowerPoint. However, you cannot edit a PDF file.

- 1 Touch and hold a file, then Open, Upload, Rename, Move, Copy, Delete, Send and Properties options are available. This is depending on the file type.

The Web

Browser

NOTE: Additional charges apply when connecting to these services and downloading content. Check data charges with your network provider.

Using options


Press the **Menu** key to view options.

 **New window** – Open a new window.

 **Bookmark** – Add/Show Bookmark, show Most Visited Site and History.


 **Windows** – Show all your open windows.


 **Refresh** – Touch to refresh the web page.

 **Forward** – Goes to the page you connected to after the current page. This is different from the Back key, which goes to the previous page.


Wi-Fi

Turn on Wi-Fi

From Home Screen , open Notification drawer and touch  on.

From Menu, choose Settings > Wireless & Networks > Wi-Fi .

To connect to Wi-Fi

Choose the Wi-Fi network you want to connect with. If you see , you need to enter a password to connect.

TIP!

If you are out of the Wi-Fi area and choose 3G connection, additional charges may be applied.

USB tethering

You can share your phone's internet connection with your computer.

You can tether your phone to your computer with a USB cable.

Settings > Wireless & Networks > Tethering & portable hotspot > USB tethering.

For more information regarding USB tethering, click Help.

TIP!

To use USB Tethering, you need to install PC Suite onto your PC first.

Wi-Fi Tethering

Use your LG-P350 as a portable Wi-Fi hotspot.

Settings > Wireless & Networks > Tethering & portable hotspot > Portable Wi-Fi hotspot.

TIP!

If your phone turns into sleep mode even when it is connected to Wi-Fi, the Wi-Fi connection will be disabled automatically. In this case, if your phone has access to 3G data, it may be connected to the 3G network automatically, and additional charges may be applied.

NOTE: The LG-P350 supports WEP, WPA/WPA2-PSK and 802.1x EAP security. If your Wi-Fi service provider or network administrator sets encryption for network security, fill in the key in the pop-up window. If encryption is not set, this pop-up window will not be shown. You can obtain the key from your Wi-Fi service provider or network administrator.

Phone Software update

LG Mobile Phone Software update from internet

For more information on using this function, please visit <http://update.lgmobile.com> or <http://www.lg.com/common/index.jsp> → select country and language.

This feature allows you to conveniently update the firmware of your phone to the latest version from the internet without the need to visit a service centre.

As the mobile phone firmware update requires the user's full attention for the duration of the updating process, please make sure to check all instructions and notes that appear at each step before proceeding. Please note that removing the USB data cable or battery during the upgrade may seriously damage your mobile phone.

Notice

To obtain the corresponding source code under GPL, LGPL, MPL and other open source licences, please visit <http://opensource.lge.com/>. All referred licence terms, disclaimers and notices are available for download with the source code.

Accessories

These Accessories are available for use with the LG-P350.
(Items described below may be optional.)

Charger



Data cable

Connect your LG-P350 and PC.



Battery



User Guide

Learn more about your LG-P350.



Stereo headset



NOTE:

- Always use genuine LG accessories.
- Failure to do this may void your warranty.
- Accessories may vary in different regions.