
DVD RECORDER

OWNER'S MANUAL

MODEL : DR6621



Before connecting, operating or adjusting this product, please read this instruction booklet carefully and completely.

Safety Precautions

CAUTION

RISK OF ELECTRIC SHOCK
DO NOT OPEN

CAUTION: TO REDUCE THE RISK
OF ELECTRIC SHOCK
DO NOT REMOVE COVER (OR BACK)
NO USER-SERVICEABLE PARTS INSIDE
REFER SERVICING TO QUALIFIED SERVICE
PERSONNEL.

This lightning flash with arrowhead symbol within an equilateral triangle is intended to alert the user to the presence of uninsulated dangerous voltage within the product's enclosure that may be of sufficient magnitude to constitute a risk of electric shock to persons.

The exclamation point within an equilateral triangle is intended to alert the user to the presence of important operating and maintenance (servicing) instructions in the literature accompanying the product.

WARNING: TO REDUCE THE RISK OF FIRE OR ELECTRIC SHOCK, DO NOT EXPOSE THIS PRODUCT TO RAIN OR MOISTURE.

WARNING: Do not install this equipment in a confined space such as a book case or similar unit.

CLASS 1 LASER PRODUCT
KLASSE 1 LASER PRODUKT
LUOKAN 1 LASER LAITE
KLASS 1 LASER APPARAT
CLASSE 1 PRODUIT LASER

CAUTION:

This DVD Recorder employs a Laser System.

To ensure proper use of this product, please read this owner's manual carefully and retain for future reference should the unit require maintenance, contact an authorized service location (see service procedure).

Use of controls, adjustments, or the performance of procedures other than those specified herein may result in hazardous radiation exposure.

To prevent direct exposure to laser beam, do not try to open the enclosure. Visible laser radiation when open. DO NOT STARE INTO BEAM.

CAUTION: The apparatus should not be exposed to water (dripping or splashing) and no objects filled with liquids, such as vases, should be placed on the apparatus.

CE This product is manufactured to comply with the radio interference requirements of EEC DIRECTIVE 89/336/EEC, 93/68/EEC and 73/23/EEC.

SERIAL NUMBER: The serial number is found on the back of this unit. This number is unique to this unit and not available to others. You should record requested information here and retain this guide as a permanent record of your purchase.

Model No. _____

Serial No. _____

Table of Contents

INTRODUCTION

Safety Precautions 2
Table of Contents 3-4
DVD Recorder Overview 5-10
Recordable Discs 5
Playable Discs 5
Disc-related terms 6
• Types of video CDs 6
About Symbols 6
• About the ⦸ symbol display 6
• About the disc symbols for instructions 6
About recordable discs 7
• What are 'recording modes'? 7
• Is editing a DVD like editing a video tape? . 7
• About word 'Original' and 'Playlist' 7
About DVD recording 8-9
• Disc types and recording formats, modes, and settings 8
• Recording TV audio channels 8
• Notes for recording 8
• Restrictions on video recording 9
• What is 'CPRM'? 9
• Copyright 9
Remote Control Operating Range 9
Remote Control Battery Installation 9
Resetting the DVD Recorder 9
Precautions 10
• Handling the unit 10
• Cleaning the unit 10
Notes on Discs 10
• Handling discs 10
• Storing discs 10
• Cleaning discs 10
Front Panel 11
Function Display Window 12
Remote Control Overview 13
Rear Panel Connections 14

DVR HOOKUP

Connections 15-19
Connecting to the Aerial 15
Connections to Your TV 16
Connecting to a cable box or satellite receiver 17
Connecting an external decoder box 17
Connecting to an Amplifier 18
Accessory Audio/Video (A/V) Connections to DVD Recorder 19
Connecting a Digital Camcorder 19

DVR SETUP

Pre-operation Setup 20-31
Initial Settings 20
General Operation 20
General 20-25
• Auto Programming 20
• Program Edit 21-22
• Auto Clock Set 23
• Manual Clock Set 23
• TV Aspect Ratio 24
• Display Mode 24
• AV1 Decoder 24
• Progressive Scan 24
• PBC (On/Off) 25
• Factory Set 25
Language 25
• Display Language 25
• Disc Language 25
Audio 26
• Dolby Digital 26
• DTS 26
• MPEG 26
• Sampling Frequency 26
• DRC (Dynamic Range Control) 26
• Vocal 26
Lock (Parental Control) 27-28
• Set Password 27
• Rating 27
• Country Code 28
Recording 28-29
• Record Mode Set 28
• Record Aspect 28
• DV Record Audio 28
• Auto Chapter 29
Disc 29-30
• Disc Format 29
• Disc Protect 29
• Finalize 30
• Disc Label 30
Overview for the On-Screen Display 31
• Displaying Information While Watching TV . . 31
• Disc Information On-screen Display 31

Table of Contents

PLAYBACK

DVD and Video CD Operation 32-35
DVD or Video CD Playback 32
General Features 32
- TITLE Selection 32
- CHAPTER/TRACK Selection 32
- Search 32
- Still Picture and Frame-by-Frame Playback . 32
- Slow Motion 33
- Random 33
- Repeat 33
- Repeat A-B 33
- Time Search 33
- Zoom 34
- Marker Search 34
- Reviewing the Contents of DVD Video Discs: Menus 34
- Title Menu 34
- Disc Menu 34
- Camera Angle 34
- Changing the Audio Soundtrack 34
- Audio Channel Selection 35
- 3D Surround 35
- Subtitles 35
- Instant Skip 35
- Last Condition Memory 35
- PIP (Picture-in-Picture) 35

Audio CD and MP3/WMA Operation 36-38
Playing an Audio CD or MP3/WMA file 36
Notes on MP3/WMA Recordings 36
- Pause 37
- Track Selection 37
- Repeat Track/All/Off 37
- Random 37
- 3D Surround 37
- Search 37
- Repeat A-B 37

Programmed Playback 38
JPEG File Operation 39
Viewing JPEG Disc 39
- Slide Show 39
- Still Picture 39
- Moving to another File 39
- To rotate picture 39

RECORDING

Basic Recording 40
Basic Recording from TV channels 40
Instant Timer Recording 40
Timer Recording 41-42
Reviewing Timer Recording Details 42
Canceling a Timer Recording 42
Stopping a Timer Recording in Progress 42
Timer Recording Troubleshooting 42
Recording from External Input source 43-44
Recording from External Components 43
Recording from a Digital Camcorder 43
What is DV? 44
- DV-Related Messages 44
- Troubleshooting 44

EDITING

Title List and Chapter List Menu 45-49
Using the Title List-Original menu VR 45
Using the Chapter List-Original menu VR . . . 45
Using the Title List-Playlist menu VR 46
Using the Chapter List-Playlist menu VR . . . 46
Using the Title List menu Video 47
- Deleting a Title 47

Using the Title List menu +RW 48
Using the Chapter List menu +RW 48
Using the Title List menu +R 49
Using the Chapter List menu +R 49
Title and Chapter Editing 50-55
Titles, Chapters and Parts 50
Adding Chapter Markers 50
Changing Title Thumbnails 50
Making a New Playlist 51
Adding Additional Title/Chapters to the Playlist 51
Deleting a Title/Chapter 52
Deleting a Part 52
Naming a Title 53
Combining Two Chapters Into One 53
Moving a Playlist Chapter 54
Protect a Title 54
Hide a Chapter 55
Divide One Title Into Two 55
Additional Information 56
Overwrite Recording 56
Viewing Title List menu displayed on other DVD Recorders or Players 56
Playing Your Recordings on Other DVD Players (Finalizing a Disc) 56

REFERENCE

Language Code and Country Code List 57
Controlling Your TV with the Supplied Remote . 58
Troubleshooting 59-60
Specifications 61

About the symbols for instructions

⚠ Indicates hazards likely to cause harm to the unit itself or other material damage.

Note Indicates special operating features of this unit.

Tip Indicates tips and hints for making the task easier.

DVD Recorder Overview

Recordable Discs

DVD-RW (Digital Video Disc - ReWritable): These Discs can be recorded on repeatedly. Recordings can be erased, then you can record again on the same Disc.

DVD-R (Digital Video Disc - Recordable): These Discs can be recorded only once. After you finalize a DVD-R, you cannot record on it or edit it.

DVD+RW (Digital Video Disc + ReWritable): These Discs can be recorded on repeatedly. Recordings can be erased, then you can record again on the same Disc.

DVD+R (Digital Video Disc + Recordable): These Discs can be recorded only once. After you finalize a DVD+R, you cannot record on it or edit it any more.

Notes :

– This Recorder cannot record CD-R or CD-RW discs.
– DVD-R/RW, DVD+R/RW and CD-R/RW discs recorded using a personal computer or a DVD or CD Recorder may not play if the disc is damaged or dirty, or if there is dirt or condensation on the Recorder's lens.
– If you record a disc using a personal computer, even if it is recorded in a compatible format, there are cases in which it may not play because of the settings of the application software used to create the disc. (Check with the software publisher for more detailed information.)
– The Recommendable DVD discs :

DVD-R	DVD+R	DVD-RW	DVD+RW
SONY	SONY	SONY	SONY
TDK	TDK	TDK	TDK
Imation	Imation	Imation	Imation
Verbatim	MAXELL	Verbatim	Verbatim
RiDATA	RiDATA	Memorex	RiDATA
Panasonic	Fujifilm	Fujifilm	Fujifilm
LG	Ricoh	LG	Ricoh
Mitsubishi	HP	Mitsubishi	HP
That's	That's	Samsung	Ritek
Pioneer	Philips	Pioneer	Radus

Playable Discs

DVD VIDEO	DVD (8 cm / 12 cm disc)
COMPACT disc DIGITAL VIDEO	Video CD (VCD) (8 cm / 12 cm disc)
COMPACT disc DIGITAL AUDIO	Audio CD (8 cm / 12 cm disc)

In addition, this unit can play DVD-R/DVD-RW discs; DVD+R/DVD+RW discs; CD-R/CD-RW/DVD-R/DVD-RW/DVD+R/DVD+RW discs that contain audio titles, MP3 files, WMA Files, or JPEG files; SVCD; and kodak picture CDs.

Notes :

– Depending on the conditions of the recording equipment or the CD-R/RW (or DVD±R/±RW) disc itself, some CD-R/RW (or DVD±R/±RW) discs cannot be played on the unit.
– Do not attach any seal or label to either side (the labeled side or the recorded side) of a disc.
– Do not use irregularly shaped CDs (e.g., heart-shaped or octagonal). Doing so may result in malfunctions.
– Depending on the recording software & the finalization, some recorded discs (CD-R/RW or DVD±R/RW) may not be playable.

Regional code of the DVD Recorder and DVDs



This DVD Recorder is designed and manufactured for playback of Region 2 encoded DVD software. The region code on the labels of some DVD discs indicates which type of DVD Recorder can play those discs. This unit can play only DVD discs labeled 2 or ALL. If you try to play any other discs, the message "Incorrect region code. Can't play back" will appear on the TV screen. Some DVD discs may not have a region code label even though their playback is prohibited by area limits.

Notes on DVDs and Video CDs

Some playback operations of DVDs and Video CDs may be intentionally fixed by software manufacturers. As this unit plays DVDs and Video CDs according to disc content designed by the software manufacturer, some playback features of the unit may not be available or other functions may be added.
Refer also to the instructions supplied with the DVDs and Video CDs. Some DVDs made for business purposes may not be played on the unit.

Disc-related terms

Title (DVD only)
The main film content, accompanying feature content, or music album.
Each title is assigned a title reference number enabling you to locate it easily.

Chapter (DVD only)
Sections of a picture or a musical piece that are smaller than titles. A title is composed of one or several chapters. Each chapter is assigned a chapter number to enable you to locate the chapter you want. Depending on the disc, chapters may not be labeled.

Track (Video CD and Audio CD only)
Sections of a picture or a musical piece on a Video CD or an Audio CD. Each track is assigned a track number, enabling you to locate the track you want.

Scene
On a Video CD with PBC (Playback control) functions, moving pictures and still pictures are divided into sections called "Scenes". Each scene available is displayed on the Scene menu and assigned a scene number, enabling you to locate the scene you want.
A scene may be composed of one or several tracks.

Types of Video CDs

There are two types of Video CDs:

Video CDs equipped with PBC (Version 2.0)
PBC (Playback control) functions allow you to interact with the system via menus, search functions, or other typical computer-like operations. Moreover, high resolution still pictures can be played if they are included on the disc.

Video CDs not equipped with PBC (Version 1.1)
Operated in the same way as audio CDs, these discs allow playback of video pictures as well as sound, but they are not equipped with PBC.

About Symbols

About the ⃠ symbol display

" ⃠ " may appear on the TV screen during operation. This icon means the function explained in this owner's manual is not available on that specific disc, or at that time.

About the disc symbols for instructions

A section whose title has one of the following symbols are applicable only to those discs represented by the symbol.

Many functions provided on this Recorder are dependent on the recording mode. One or more of the symbols (VR, Video, DVD+R, DVD+RW) appear by each function (explained in this manual) so that you can see at a glance whether it's applicable to the disc loaded.

- Video — DVD-R/RW with Video recording mode
- VR — DVD-RW with VR recording mode
- +R — DVD+R disc
- +RW — DVD+RW disc
- DVD — DVD-Video disc
- VCD — Video CDs
- CD — Audio CDs
- MP3 — MP3 CDs
- WMA — WMA CDs
- JPEG — JPEG CDs

The finalized DVD disc is a DVD-Video disc.

About recordable discs

How are recordable discs different?
The essential difference among DVD-R, DVD-RW, DVD+R and DVD+RW is that DVD-R and DVD+R are record-once medium, while DVD-RW and DVD+RW are re-recordable/erasable medium. You can re-record/erase a DVD-RW and DVD+RW disc approximately 1,000 times.

Can I play my recordable discs in a regular DVD player?
Generally, DVD-R, DVD+R and DVD-RW discs recorded in Video mode are playable in a regular DVD player, but they must be 'finalized' first. This process fixes the contents of the disc to make them readable to other DVD players as DVD-Video discs.
DVD-RW discs recorded in VR (Video Recording) mode are playable in some players.
Unfinalized DVD+RW discs are playable in a regular DVD player.

RW COMPATIBLE — This indicates a product feature that is capable of playing DVD-RW discs recorded with Video Recording format.

What are 'recording modes'?

There are various recording modes available using this Recorder. When recording to a DVD-R, DVD+R or DVD+RW disc, recordings are always in Video mode. DVD-RW discs can be formatted for VR mode recording or Video mode recording.

VR mode recording VR
- 4 different picture quality/recording time settings available (HQ, SQ, LQ, EQ)
- Not playable on regular DVD players
- Recordings can be extensively edited

Video mode recording Video
- 4 different picture quality/recording time settings available (HQ, SQ, LQ, EQ)
- Playable on regular DVD players (after finalization)
- Limited editing features

DVD+RW mode recording +RW
- 4 different picture quality/recording time settings available (HQ, SQ, LQ, EQ)
- Playable on regular DVD players
- The edited contents is playable on regular DVD players only after finalizing
- Recordings can be edited the title/chapter

DVD+R mode recording +R
- 4 different picture quality/recording time settings available (HQ, SQ, LQ, EQ)
- Playable on regular DVD players (after finalization)
- Any edited contents are not be compatible on regular DVD players. (Hide, chapter combine, added chapter mark, etc.)
- Limited title/chapter editing features.

Note :
DVD-Video Format (Video mode) is a new format for recording on DVD-R/RW and DVD+R/RW discs that was approved by the DVD Forum in 2000. You may therefore experience problems playing recordable DVD discs in some players. Symptoms include video artifacts, audio and/or video dropouts and playback suddenly stopping.
Our company cannot take responsibility for problems playing discs recorded on this Recorder in other players.

Is editing a DVD like editing a video tape?

No. When you edit a video tape you need one video deck to play the original tape and another to record the edits. With DVD, you edit by making a 'Playlist' of what to play and when to play it. On playback, the Recorder plays the disc according to the Playlist.

About word 'Original' and 'Playlist'

Throughout this manual, you will often see the words Original and Playlist to refer to the actual content and the edited version.
- **Original:** content refers to what's actually recorded on the disc.
- **Playlist:** content refers to the edited version of the disc — how the Original content is to be played.

Disc type	Disc format	Recording mode	Functions
DVD-Video	Video format	n/a	Playback only
DVD-RW	Video Recording format (default)	VR mode	Playback, Recording, Original/Playlist Editing
	Video format	Video mode	Playback, limited Recording, limited Editing
DVD-R	Video format	Video mode	Playback, limited Recording, limited Editing
DVD+RW	+RW Video format	DVD+RW	Playback, limited Recording, Title/Chapter Editing
DVD+R	+R Video format	DVD+R	Playback, limited Recording, limited Title/Chapter Editing

About DVD recording

Notes :

- This recorder cannot make recordings on CD-R or CD-RW discs.
- Our company takes no responsibility for recording failure due to power outages, defective discs, or damage to the Recorder.
- Fingerprints and small scratches on a disc can affect playback and/or recording performance. Please take proper care of your discs.

Disc types and recording formats, modes, and settings

This recorder can play five different kinds of DVD discs: pre-recorded DVD-Video discs, DVD-RW, DVD-R, DVD+RW and DVD+R discs. The disc format for DVD-R discs is always "Video format"—the same as pre-recorded DVD-Video discs. This means that once finalized, you can play a DVD-R in a regular DVD player.
By default, the DVD-RW disc format is Video Recording (VR) format, though you can change this to Video format, if required. (Reinitializing the disc will erase the contents of the disc.)
The recording mode is closely related to the disc format. If the disc format is Video Recording format, then the recording mode is VR mode; if the disc format is Video mode, then the recording mode is Video mode (except for DVD-Video, which is not recordable, and so does not have a recording mode).
Within the recording modes (which are fixed for them whole disc) are the record settings. These can be changed as required for each recording and determine the picture quality and how much space the recording will take up on the disc.

Recording TV audio channels

This recorder can record either NICAM or regular audio. If the NICAM setting (page 22) is set to Auto, then if the broadcast is NICAM, you can record the NICAM audio. If the broadcast is non-NICAM, the regular audio is always recorded.

Notes for recording

- The recording times shown are not exact because the recorder uses variable bit-rate video compression. This means that the exact recording time will depend on the material being recorded.
- When recording a TV broadcast, if the reception is poor or the picture contains interference, the recording times may be shorter.
- If you record still pictures or audio only, the recording time may be longer.
- The displayed times for recording and time remaining may not always add up to exactly the length of the disc.
- The recording time available may decrease if you heavily edit a disc.
- If using a DVD-RW disc, make sure you change the recording format (Video mode or VR mode) before you record anything on the disc. See page 29 (Disc Format) for how to do this.
- When using a DVD-R disc, you can keep recording until the disc is full, or until you finalize the disc. Before you start a recording session, check the amount of recording time left on the disc.
- When using a DVD-RW disc in Video mode, recording time available will only increase if you erase the last title recorded on the disc.
- The Erase Title option in the Title List-Original menu only hides the title, it does not actually erase the title from the disc and increase the recording time available (except for the last recorded title on a DVD-RW disc in Video mode).
- Overwrite recording is available using DVD+RW discs.

Restrictions on video recording

- You cannot record copy-protected video using this recorder. Copy-protected video includes DVD-Video discs and some satellite broadcasts. If copy-protected material is encountered during a recording, recording will pause or stop automatically and an error message will be displayed on-screen.
- Video that is 'copy-once only' can only be recorded using a DVD-RW disc in VR mode with CPRM (see below).
- NTSC format signals from the analog or the DV inputs is not recorded correctly with this recorder.
- Video signals in SECAM format (from the built-in TV tuner or from the analog inputs) are recorded in PAL format.

What is 'CPRM'?

CPRM is a copy protection system (with scramble system) only allowing the recording of 'copy once' broadcast programs. CPRM stands for Content Protection for Recordable Media.
This Recorder is CPRM compatible, which means that you can record copy-once broadcast programs, but you cannot then make a copy of those recordings. CPRM recordings can only be made on DVD-RW discs formatted in VR mode, and CPRM recordings can only be played on players that are specifically compatible with CPRM.


Copyright

- Recording equipment should be used only for lawful copying and you are advised to check carefully what is lawful copying in the area in which you are making a copy. Copying of copyright material such as films or music is unlawful unless permitted by a legal exception or consented to by the rights owner.
- This product incorporates copyright protection technology that is protected by method claims of certain U.S. patents and other intellectual property rights owned by Macrovision Corporation and other rights owners. Use of this copyright protection technology must be authorized by Macrovision Corporation, and is intended for home and other limited viewing uses only, unless otherwise authorized by Macrovision corporation. Reverse engineering or disassembly is prohibited.
- CONSUMERS SHOULD NOTE THAT NOT ALL HIGH DEFINITION TELEVISION SETS ARE FULLY COMPATIBLE WITH THIS PRODUCT AND MAY CAUSE ARTIFACTS TO BE DISPLAYED IN THE PICTURE. IN CASE OF 625 PROGRESSIVE SCAN PICTURE PROBLEMS, IT IS RECOMMENDED THAT THE USER SWITCH THE CONNECTION TO THE 'STANDARD DEFINITION' OUTPUT. IF THERE ARE QUESTIONS REGARDING OUR TV SET COMPATIBILITY WITH THIS MODEL 625p DVD RECORDER, PLEASE CONTACT OUR CUSTOMER SERVICE CENTER.

Remote Control Operation Range

Point the Remote Control at the remote sensor and press the buttons.

Remote Control Battery Installation



Remove the battery cover on the rear of the Remote Control, and insert two R03 (size AAA) batteries with ⊕ and ⊖ matched correctly.

⚠Caution
Do not mix old and new batteries. Never mix different types of batteries (standard, alkaline, etc.).

Resetting the DVD Recorder

If you observe any of the following symptoms...

- The unit is plugged in, but the power will not turn on or off.
- The front panel display is not working.
- The DVD Recorder is not operating normally.

...you can reset the DVD Recorder as follows:

- Press and hold the POWER button for at least five seconds. This will force the unit to power off. Press the POWER button again to turn the unit back on.
- Unplug the power cord, wait at least five seconds, and then plug it in again.

Precautions

Handling the unit

When shipping the unit
The original shipping carton and packing materials come in handy. For maximum protection, re-pack the unit as it was originally packaged at the factory.

When setting up the unit
The picture and sound of a nearby TV, VCR, or radio may be distorted during playback. In this case, position the unit away from the TV, VCR, or radio, or turn off the unit after removing the disc.

To keep the surface clean
Do not use volatile liquids, such as insecticide spray, near the unit. Do not leave rubber or plastic products in contact with the unit for a long period of time. They will leave marks on the surface.

Cleaning the unit

To clean the cabinet
Use a soft, dry cloth. If the surfaces are extremely dirty, use a soft cloth lightly moistened with a mild detergent solution. Do not use strong solvents such as alcohol, benzine, or thinner, as these might damage the surface of the unit.

To obtain a clear picture
The DVD Recorder is a high-tech, precision device. If the optical pick-up lens and disc drive parts are dirty or worn, the picture quality will be poor.
Regular inspection and maintenance are recommended after every 1,000 hours of use. (This depends on the operating environment.)
For details, please contact your nearest dealer.

Notes on Discs

Handling discs

Do not touch the playback side of the disc. Hold the disc by the edges so that fingerprints will not get on the surface. Do not stick paper or tape on the disc.




Storing discs

After playing, store the disc in its case.
Do not expose the disc to direct sunlight or sources of heat, or leave it in a parked car exposed to direct sunlight, as there may be a considerable temperature increase inside the car.

Cleaning discs

Fingerprints and dust on the disc can cause poor picture quality and sound distortion. Before playing, clean the disc with a clean cloth. Wipe the disc from the center outward.



Do not use strong solvents such as alcohol, benzine, thinner, commercially available cleaners, or anti-static spray intended for older vinyl records.

Front Panel

INPUT4 (VIDEO IN/AUDIO IN (Left/Right))
Connect the audio/video output of an external source (Audio system, TV/ Monitor, VCR, Camcorder, etc.).

STOP (■)
Stops playback or recording.

POWER button and indicator
Switches the DVD Recorder ON or OFF. Lights up red when the recorder is in standby mode.

PAUSE (❚❚)
Pause playback or recording temporarily, press again to exit pause mode.


REC (●)
Starts recording. Press repeatedly to set the recording time.

PLAY (►)
To play back a disc.

PROG. (+/-)
Scans up or down through memorized channels.

OPEN/CLOSE (⏏)
Opens or closes the disc tray.

Disc Tray
Insert a disc here.



Display window
Shows the current status of the DVD Recorder.

Remote Sensor
Point the DVD Recorder remote control here.


▶▶/▶▶❙
Go to NEXT chapter/track.
Press and hold for two seconds for a fast forward search during playback.

❙◀◀/◀◀
Go to beginning of current chapter/ track or to previous chapter/track.
Press and hold for two seconds for a fast reverse search during playback.

DV INPUT
Connect the DV output of a digital camcorder.

INPUT 4 (S-VIDEO IN)
Connect the S-Video output of an external source (TV/ Monitor, VCR, Camcorder, etc.).

Function Display Window



Remote Control Overview

POWER
Switches the recorder ON or OFF.

TV/DVD
To view channels selected by the recorder tuner or by the TV tuner.

PIP
Selects PIP function on or off.

0-9 numerical buttons
Selects numbered options in a menu.

AV
Changes the input to use for recording (Tuner, AV1-4, or DV IN).

AUDIO
Selects an audio language (DVD) or an audio channel (CD).

SUBTITLE
Selects a subtitle language.

ANGLE
Selects a DVD camera angle, if available.

REC (●)
Starts recording. Press repeatedly to set the recording time.

REC MODE
Selects the recording mode: HQ, SQ, LQ, or EQ.

TIMER REC
Displays Timer Record menu.

CLEAR
Removes a track number on the Program List or a mark on the Marker Search menu.

ZOOM
Enlarges DVD video image.

INSTANT SKIP
Skips 15 seconds forward on the disc (about the length of a typical TV commercial).

TITLE
Displays the disc's Title menu, if available.


THUMBNAIL
Selects a thumbnail picture for the current title and chapter for use in the Original and Playlist menu.

CHP ADD
Inserts a chapter marker when playing/recording.

MARKER
Marks any point during playback.

SEARCH
Displays Marker Search menu.

PROGRAM
Add the track to the Program List.



OPEN/CLOSE (⏏)
Opens and closes the disc tray.

TV Control Buttons
POWER: Turns the TV on or off.
AV: Selects the TV's source.
PR +/–: Selects TV's channel.
VOL +/–: Adjusts TV's volume.
MUTE: Temporarily turns TV sound OFF, press again to restore.

SKIP (⏮ / ⏭)
Go to next chapter or track. Returns to beginning of current chapter or track or go to previous chapter or track.

SCAN (◀◀ / ▶▶)
Search backward or forward.

PAUSE/STEP (❚❚)
Pause playback or recording temporarily, press again to exit pause mode.

► (PLAY)
Starts playback.

STOP (■)
Stops playback or recording.

MENU/LIST
Accesses menu on a DVD disc, Title List or Playlist menu.

SETUP
Accesses or removes the Setup menu.

ENTER
- Acknowledges menu selection.
- Displays information while viewing a TV program.

◄ / ► / ▲ / ▼ (left/right/up/down)
Selects an option in the menu.

PR ▲ / ▼ (up/down)
Scans up or down through memorized channels.

DISPLAY
Accesses On-Screen Display.

RETURN (↩)
- Removes the menu.
- Displays the menu of a video CD with PBC.

3D SURR.
Selects 3D SURROUND during playback.

RANDOM
Plays tracks in random order.

REPEAT
Repeat chapter, track, title, all.

A-B
Repeat sequence.

Rear Panel Connections

AERIAL
Connect the aerial to this terminal.


EURO AV 2 DECODER
Connect the audio/video output of an external source (Pay-TV decoder, Set Top Box, VCR, etc.).

COAXIAL (Digital audio out jack)
Connect to digital (coaxial) audio equipment.

COMPONENT VIDEO OUT/PROGRESSIVE SCAN (Y Pb Pr)
Connect to a TV with Y Pb Pr inputs.

VIDEO OUT/AUDIO OUT (Left/Right)
Connect to a TV with video and audio inputs.

VIDEO IN 3 / AUDIO IN 3 (Left/Right)
Connect the audio/video output of an external source (Audio system, TV/Monitor, VCR, Camcorder).



Cooling fan

AC Power Cord
Plug into the power source.

OPTICAL (Digital audio out jack)
Connect to digital (optical) audio equipment.

S-VIDEO OUT
Connect to a S-Video Input on TV.

VIDEO OUTPUT Switch
Select either COMPONENT VIDEO OUT or RGB signal of EURO AV1 AUDIO/VIDEO terminal depending on how you connect the DVD Recorder to the TV.

EURO AV 1 AUDIO/VIDEO
Connect to a TV with SCART jack.

RF. OUT
Passes the signal from the AERIAL to your TV/monitor


⚠Caution
Do not touch the inner pins of the jacks on the rear panel. Electrostatic discharge may cause permanent damage to the unit.

Connecting to the Aerial

Remove the aerial cable plug from your TV set and insert it into the aerial socket at the back of the recorder. Plug one end of the aerial cable into the TV socket on the DVD recorder and the other end into the aerial input socket on your TV set.

RF coaxial connection

Connect the RF. OUT jack on the DVD Recorder to the aerial input jack on the TV using the 75-ohm Coaxial Cable supplied **(R)**. The RF. OUT jack passes the signal through from the AERIAL jack.




Tips

- Depending on your TV and other equipment you wish to connect, there are various ways you could connect the recorder. Use only one of the connections described below.
- Please refer to the manuals of your TV, VCR, Stereo System or other devices as necessary to make the best connections.

⚠ **Caution**

– Make sure the DVD Recorder is connected directly to the TV. Tune the TV to the correct video input channel.
– Do not connect the DVD Recorder's AUDIO OUT jack to the phono in jack (record deck) of your audio system.
– Do not connect your DVD Recorder via your VCR. The DVD image could be distorted by the copy protection system.

Rear of TV



Rear of DVD Recorder

Connections to Your TV

- Make one of the following connections, depending on the capabilities of your existing equipment.
- When using the COMPONENT VIDEO OUT jacks, set the VIDEO OUTPUT switch to COMPONENT. When using the SCART jack, set the VIDEO OUTPUT switch to RGB.

SCART connection

Connect the EURO AV1 AUDIO/VIDEO scart jack on the DVD Recorder to the corresponding in jacks on the TV using the scart cable **(T)**.

Video connection

Connect the VIDEO OUT jack on the DVD Recorder to the video in jack on the TV using the video cable **(V)**.

S-Video connection

Connect the S-VIDEO OUT jack on the DVD Recorder to the S-Video in jack on the TV using the S-Video cable **(S)**.

Component Video connection

Connect the COMPONENT VIDEO OUT jacks on the DVD Recorder to the corresponding input jacks on the TV using an Y Pb Pr cable **(C)**.

Progressive Scan (ColorStream®Pro) connection

If your television is a high-definition or "digital ready" television, you may take advantage of the recorder's progressive scan output for the highest video resolution possible. If your TV does not accept the Progressive Scan format, the picture will appear scrambled if you try Progressive Scan on the recorder.

Connect the COMPONENT VIDEO OUT / PROGRESSIVE SCAN jacks on the recorder to the corresponding in jacks on the TV using the Y Pb Pr cable **(C)**.

Notes :

- Set the Progressive to "On" on the setup menu for progressive signal, see page 24.
- Set the progressive to "Off" by removing any disc from the unit and close the disc tray. See that "NO DISC" is displayed on the display window. Then press STOP and hold it for five seconds before releasing it.
- Progressive scan does not work with the analog video connections (yellow VIDEO OUT jack) or S-VIDEO connection.

Audio (Left/Right) Connection

Connect the left and right AUDIO OUT jacks of the DVD Recorder to the audio left and right IN jacks on the TV using the audio cables **(A)**. Do not connect the DVD Recorder's AUDIO OUT jack to the phono in jack (record deck) of your audio system.

Connecting to a cable box or satellite receiver

If you have a cable or satellite receiver with a built-in decoder, connect it to this recorder and your TV as shown on this page. If you are using a separate decoder box for your cable/satellite TV, set up following the instructions on the right.
Using the setup on this page you can:

- Record any channel by selecting it on the cable box/satellite tuner.

1 Connect RF cables as shown.
This enables you to watch and record TV channels.


2 Use the SCART cable to connect the EURO AV1 AUDIO/VIDEO connector to a SCART AV connector on your TV.
This enables you to watch discs.

3 Use a SCART cable to connect the EURO AV2 DECODER connector to a SCART AV connector on your satellite/cable box.
This enables you to record scrambled TV channels.

Tip

This recorder has a 'loop through' function. This feature allows you to record a TV program from the built-in TV tuner in this recorder, while watching a satellite or cable channel. Press TV/DVD to select the TV mode during recording. The TV indicator appears

⚠ **Caution:**
Do not connect this recorder 'through' your VCR, satellite receiver or cable box. Always connect each component directly to your TV or AV receiver.



Connecting an external decoder box

If you have an external, dedicated decoder box for your satellite or cable TV system, use the setup described on this page.

1 Connect the cable from the aerial/cable TV outlet to the aerial input on your cable/satellite tuner.


2 Use a SCART cable to connect your decoder to your cable/satellite tuner.
See the manual for your decoder box for more detailed instructions.

3 Use a SCART cable to connect the EURO AV2 DECODER connector to a SCART AV connector on your satellite/cable box.

4 Use the SCART cable to connect the EURO AV1 AUDIO/VIDEO connector to a SCART AV connector on your TV.

⚠ **Caution:**

- Do not connect your decoder box directly to this recorder.
- Information from the decoder (for example, relating to pay TV services), is only viewable when this recorder is off (in standby).
- For timer recording to work properly on this recorder, the satellite/cable box must also be switched on during recording.



Connecting to an Amplifier

Connecting to an amplifier equipped with two channel analog stereo or Dolby Pro Logic II/ Pro Logic

Connect the Left and Right AUDIO OUT jacks on the DVD Recorder to the audio left and right in jacks on your amplifier, receiver, or stereo system, using the audio cables **(A)**.

Connecting to an amplifier equipped with two channel digital stereo (PCM) or to an Audio/ Video receiver equipped with a multi-channel decoder (Dolby Digital™, MPEG 2, or DTS)

1 Connect one of the DVD Recorder's DIGITAL AUDIO OUT jacks (OPTICAL **O** or COAXIAL **X**) to the corresponding in jack on your amplifier. Use an optional digital (optical **O** or coaxial **X**) audio cable.

2 You will need to activate the recorder's digital output. (See "Audio" on page 25).

Digital Multi-channel sound

A digital multi-channel connection provides the best sound quality. For this you need a multi-channel Audio/Video receiver that supports one or more of the audio formats supported by your DVD Recorder (MPEG 2, Dolby Digital and DTS). Check the receiver manual and the logos on the front of the receiver.


⚠ Caution:

Due to the DTS Licensing agreement, the digital output will be in DTS digital out when DTS audio stream is selected.

Notes :

– If the audio format of the digital output does not match the capabilities of your receiver, the receiver will produce a strong, distorted sound or no sound at all.
– Six Channel Digital Surround Sound via digital connection can only be obtained if your receiver is equipped with a Digital Multi-channel decoder.
– To see the audio format of the current DVD in the on-screen display, press AUDIO.
– This recorder does not perform internal (2 channel) decoding of a DTS sound track. To enjoy DTS multi channel surround, you must connect this recorder to a DTS compatible receiver via one of this recorder's digital audio outputs.

Rear of DVD Recorder



Amplifier (Receiver)


Accessory Audio/Video (A/V) Connections to DVD Recorder

Connect the input jacks (AV3, AV4) on the DVD Recorder to the audio/video out jacks on your accessory component, using audio/video cables.

Note :

If you use the S-VIDEO IN jack on the front panel, the VIDEO IN jack on the front panel is not available.

Jack panel of Accessory Component (VCR, Camcorder, etc.)



Connecting a Digital Camcorder


Using the front panel DV IN jack, it is possible to connect a DV digital camcorder or DVD-R/RW recorder and digitally transfer DV tapes or DVD-R/RW discs to DVD-R/RW.

Use a DV cable (not supplied) to connect the DV in/out jack of your DV camcorder/video deck to the front panel DV IN jack of this recorder.

Note :

This jack is for connection to DV digital camcorder only. It is not compatible with digital satellite tuners or D-VHS video decks.

DV Digital Camcorder



Initial Settings

In this menu system, there are several ways to customize the settings provided. Most menus consist of three levels to set up the options, but some require greater depth for the variety of settings. If you press SETUP, only the first and second level of the menu system will appear on the TV screen. The third level can be displayed by pressing ►. For navigating the menu levels, you will see "►" on the right side of the menu label to help you go to the next level.

To bring up and exit the Menu:
Press SETUP to bring up the menu. A second press of SETUP will take you back to initial screen.

To go to the next level:
Press ► on the remote control.

To go back to the previous level:
Press ◄ on the remote control.

General Operation

1. **Press SETUP.**
   The Setup menu appears.
2. **Use ▲ / ▼ to select the desired option.**
3. **While the desired item is selected, press ► to move to the second level.**
4. **Use ▲ / ▼ to select the second desired option.**
5. **Press ► to move to the third level.**
6. **Use ▲ / ▼ to select the desired setting then press ENTER to confirm your selection.**
   Some items require additional steps.
7. **Press SETUP to exit the Setup menu.**


General

Auto Programming

This DVD Recorder is equipped with a frequency synthesized tuner capable of receiving up to 88 TV channels.

Preparation:

- Connect the DVD Recorder to the desired type of aerial, as shown in Connecting to the Aerial on page 15.




1. **Press SETUP.**
   The Setup menu appears.
2. **Use ▲ / ▼ to select the General option.**
3. **While the General option is selected, press ► to move to the second level.**
4. **Use ▲ / ▼ to select the Auto Programming option.**
5. **Press ► to move to the third level.**
   Country option is highlighted.
6. **Use ▲ / ▼ to select a country then press ►.**
   "Start" icon is highlighted.
7. **Press ENTER to begin the channel search.**
   The tuner will automatically cycle through all available channels in the area and place them in the tuner's memory.

Note :
After you have connected your DVD recorder for the very first time. If you press SETUP for initial setting, you can only set the "Auto Programming" option. Then you can set the other options.

Program Edit

You can edit a channel manually (add, delete, name, move, etc.).




1 **Press SETUP.**
The Setup menu appears.

2 **Use ▲ / ▼ to select the General option.**

3 **While the General option is selected, press ► to move to the second level.**


4 **Use ▲ / ▼ to select the Program Edit option then press ► to move to the third level.**
"Edit" icon is highlighted.

5 **Press ENTER.**
Program List menu appears.



6 **Use ▲ / ▼ to select a PR number then press ENTER.**
Program List options appears on the left side of the menu display.

7 **Use ▲ / ▼ to select an option then press ENTER to confirm.**



Program Edit: Edits the selected program.

Station Rename: Edits the station name.

Move: Moves the program's location on the program list.

Delete: Deletes the program from program list.

Decoder On/Off: Set the decoder for the program to On or Off.


Nicam Auto/Off: Set the NICAM function to for the program Auto or Off.

8 **Press RETURN (↶) repeatedly to exit Program List menu.**

Program Edit

You can perform a search to select and store TV channels manually.

1. Use ▲ / ▼ to select a program on the Program List menu then press ENTER.
   Program List options appears on the left side of the Program List menu.
2. Use ▲ / ▼ to select 'Program Edit' option from the options then press ENTER.
   Program Edit menu appears.



3. See the descriptions on below to use Program Edit menu.

   ◄ / ► (left/right): Moves the cursor to the previous or next column.

   ▲ / ▼ (up/down): Changes the setting at the current cursor position.

   PR: Indicates program number (display only)

   Seek: Searches a station automatically. Use ◄ / ► to select Seek option then press ▲ / ▼. Searching stops when the DVD recorder tunes in a station.

   Ch.: Changes the channel number to edit. Use ◄ / ► to select Ch. option then press ▲ / ▼.

   MFT: Changes the frequency for fine tuning. Use ◄ / ► to select MFT option then press ▲ / ▼.

   PAL/SECAM: Changes TV signal system (PAL or SECAM). Use ◄ / ► to select PAL/SECAM option then press ▲ / ▼.


4. Choose OK then press ENTER to confirm the setting and returns to the Program List menu.

Program Edit (Continued)

Station Rename

You can name stations independently. Names can be up to 5 characters long.

1. Use ▲ / ▼ to select a program on the Program List menu then press ENTER.
   Program List options appears on the left side of the Program List menu.
2. Use ▲ / ▼ to select 'Station Rename' option from Program List options then press ENTER.
   Keyboard menu appears.



3. Enter a name for the station. Use ▲ ▼ ◄ ► to select a character then press ENTER to confirm your selection.
   - **Alphabet Capital:** Switches the keyboard upper case characters.
   - **Alphabet Small:** Switches the keyboard to lower case characters.
   - **Symbol:** Switches the keyboard to symbol characters.
   - **OK:** Select to finish.
   - **Cancel:** Select to exit the menu.
   - **Space:** Inserts a space at the cursor position.
   - **Delete:** Deletes the previous character at the cursor position.
   - **◄ / ►:** Moves cursor to left or right.

   Tip

   Remote control buttons for entering a name
   Numbers (0~9): Enters the character of corresponding location on the selected column.

4. Choose 'OK' icon then press ENTER to fix the name and returns to the Program List menu.

Sorting TV channels manually

You can sort the program's position on the Program List menu.

1. Use ▲ / ▼ to select a program on the Program List menu then press ENTER.
   Program List options appears on the left side of the Program List menu.
2. Use ▲ / ▼ to select 'Move' option from Program List options then press ENTER.
3. Use ▲ / ▼ to select a desired position then press ENTER to store.

Deleting a program

You can delete a program on the Program List menu.

1. Use ▲ / ▼ to select a program on the Program List menu then press ENTER.
   Program List options appears on the left side of the Program List menu.
2. Use ▲ / ▼ to select 'Delete' option from Program List options then press ENTER. The Program is deleted.

Setting the Decoder On/Off

1. Use ▲ / ▼ to select the program you wish to link with the decoder function on the Program List menu then press ENTER.
   Program List options appears on the left side of the Program List menu.
2. Use ▲ / ▼ to select 'Decoder On/Off' option from Program List options then press ENTER. If you select On, 'Decoder' appears on the menu screen.


Setting the NICAM Auto/Off

This DVD recorder can receive Hi-Fi sound transmissions in NICAM Stereo. However, if sound distortion occurs, due to poor reception, you can switch Off

1. Use ▲ / ▼ to select a program on the Program List menu then press ENTER.
   Program List options appears on the left side of the Program List menu.
2. Use ▲ / ▼ to select 'Nicam Auto/Off' option from Program List options then press ENTER. If you select Auto, 'NICAM' appears on the menu screen.

Auto Clock Set

When Channel auto search is completed the actual Time and Date are also set automatically. If the time in the DVD recorder display is not correct, the clock must be set manually.



1 **Press SETUP.**
The Setup menu appears.

2 **Use ▲ / ▼ to select the General menu.**

3 **While the General option is selected, press ► to move to the second level.**

4 **Use ▲ / ▼ to select the Clock Set option.**

5 **Press ► to move to the third level.**

6 **Use ▲ / ▼ to select the Auto option then press ENTER.**

7 **Press SETUP to exit the Setup menu.**


Note :

There are cases where the TV station does not send, or sends wrong date and/or time information and the DVD Recorder sets the incorrect time.
If this happens, we recommend that you set the clock manually.

Manual Clock Set

1 **Follow steps 1-5 as shown left. (Auto Clock Set).**

2 **Use ▲ / ▼ to select the Manual option then press ENTER.**




3 **Enter the necessary information for date and time.**
◄ / ► (left/right): Moves the cursor to the previous or next column.
▲ / ▼ (up/down): Changes the setting at the current cursor position.

4 **Press ENTER to confirm your setting, then press SETUP to exit the Setup menu.**

Pre-operation Setup (Continued)

TV Aspect Ratio


You can choose:
- 4:3: Select when a standard 4:3 TV is connected.
- 16:9: Select when a 16:9 wide TV is connected.



Display Mode


Display Mode setting works only when the TV Aspect Ratio is set to "4:3".

You can choose:
- Letter Box: Displays a wide picture with bands on the upper and lower portions of the screen.
- Pan Scan: Automatically displays the wide picture on the entire screen and cuts off the portions that do not fit.



AV1 Decoder


We have already described, how to connect a decoder for pay-TV station on page 17. For viewing or recording of an encoded program from EURO AV1 AUDIO/VIDEO connector, you do not have to control anything. You just select AV1 source by pressing AV button and wait shortly until the decoding will start.
Choose 'On' if your recorder is connected with a decoder, otherwise leave it set to 'OFF '.



Progressive Scan

Progressive Scan Video provides the highest quality pictures with less flickering.

- If you are using the COMPONENT VIDEO OUT / PROGRESSIVE SCAN jacks, but are connecting the DVD Recorder to a standard (analog) television, set Progressive Scan to OFF.
- If you are using the COMPONENT VIDEO OUT jacks for connection to a TV or monitor that is compatible with a progressive scan signal, set Progressive Scan to ON.



⚠Caution


Once the setting for progressive scan output is entered, an image will only be visible on a progressive scan compatible TV or monitor. If you set Progressive Scan to ON in error, you must reset the unit.

1) Remove any disc from the unit and close the disc tray. See that "NO DISC" is displayed on the display window.
2) Press STOP and hold it for five seconds before releasing it. The video output will be restored to the standard setting and a picture will once again be visible on a conventional analog TV or monitor.

PBC

The PBC setting can be changed. Set Playback Control (PBC) to ON or OFF.

- ON: Video CDs with PBC are played according to the PBC.
- OFF: Video CDs with PBC are played the same way as Audio CDs.




Factory Set

If you need to, you can reset the Recorder to all its factory settings. Select "Set" icon then press ENTER.

Note :


Some options can not be reset. (Rating, Password, and Country Code)



Language

Display Language

Select a language for the Setup menu and on-screen display.



Disc Language

Select a language for the disc's Menu, Audio, and Subtitle.

- Original: The original language set for the disc is selected.
- Other: To select another language, select Other option then press ENTER. Use the numbered and ENTER buttons to key-in the corresponding 4-digit number according to the language code list on page 57. If you a mistake before pressing ENTER, press ◄ repeatedly to delete one by one and correct it.



Audio

Each DVD disc has a variety of audio output options. Set the Recorder's Audio Output according to the type of audio system you use.

Dolby Digital

PCM: Select when connected to a 2-channel digital stereo amplifier. The DVD Recorder's digital audio outputs sound in the PCM 2ch format when you play a DVD video disc recorded on the Dolby Digital recording system.
Bitstream: Select "Bitstream" if you connected the DVD Recorder's DIGITAL OUT jack to a Dolby Digital decoder (or an Amplifier or other equipment with a Dolby Digital decoder).



DTS

OFF: If you select "OFF", the DTS signal is not output through the DIGITAL OUT jack.
Bitstream: Select "Bitstream" if you connected the DVD Recorder's DIGITAL OUT jack to a DTS decoder (or an Amplifier or other equipment with a DTS decoder).




MPEG

PCM: Select when connected to a 2-channel digital stereo amplifier. The DVD Recorder's digital audio outputs sound in the PCM 2ch format if you play a DVD video disc recorded on the MPEG2 recording system.
Bitstream: Select "Bitstream" if you connected the DVD Recorder's DIGITAL OUT jack to an MPEG decoder (or an Amplifier or other equipment with a MPEG decoder).




Sampling Frequency

If your Receiver or Amplifier is NOT capable of handling 96 kHz signals, select 48 kHz. If this choice is made, this unit will automatically convert any 96 kHz signals to 48 kHz so your system can decode them.
If your Receiver or Amplifier is capable of handling 96 kHz signals, select 96 kHz. If this choice is made, this unit will pass each type of signal through without any further processing.




DRC (Dynamic Range Control)

With the DVD format, you can hear a program's soundtrack in the most accurate and realistic presentation possible, thanks to digital audio technology. However, you may wish to compress the dynamic range of the audio output (the difference between the loudest sounds and the quietest ones). Then, you may listen to a movie at a lower volume without losing clarity of sound. Set DRC to ON for this effect.



Vocal

Set Vocal to ON only when a multi-channel karaoke DVD is playing. The karaoke channels on the disc will mix into normal stereo sound.



Lock (Parental Control)

Set Password

Changing the 4-digit code



1 **Press SETUP.**
The Setup menu appears.

2 **Use ▲ / ▼ to select the Lock option.**

3 **While the Lock option is selected, press ► to move to the second level.**

4 **Use ▲ / ▼ to select the Set Password option.**

5 **Press ► to move to the third level.**

6 **If you have not entered a password yet;**
Enter a 4-digit password using the numbered buttons to create a personal 4-digit security password, then press ENTER. Enter the 4-digit password again and press ENTER to verify when "OK" is highlighted.
If you have already entered a password;
Enter a 4-digit password using the numbered buttons to confirm the personal 4-digit security password, then press ENTER when "OK" is highlighted.

Tip
If you make a mistake before pressing ENTER, press ◄ repeatedly to delete password numbers one by one then correct it.

7 **While "Change" is selected, press ENTER.**
If you select "Delete" then press ENTER. The password is deleted.

8 **Enter a 4-digit password using the numbered buttons to create a personal 4-digit security password then press ENTER when "OK" is highlighted.**

9 **Enter the 4-digit password again and press ENTER to verify when "OK" is highlighted.**

Tip
If you a mistake before pressing ENTER, press ◄ repeatedly to delete password numbers one by one then correct it.


If you forget your 4-digit code

If you forget your password, to clear the current password, follow the procedure below.

1. Press SETUP to display the Setup menu.
2. Use the Number buttons to enter the 6-digit number "210499".
3. Select "Yes" then press ENTER. The 4-digit password is cleared. Enter a new code as shown left.

Rating

Movies on DVDs may contain scenes not suitable for children. Therefore, discs may contain Parental Control information that applies to the complete disc or to certain scenes on the disc. These scenes are rated from Level 1 to 8, and alternatively, more suitable scenes are available for selection on some discs. Ratings are country-dependent. The Parental Control feature allows you to prevent discs from being played by your children or to have certain discs played with alternate scenes.



1 **Follow steps 1-3 as shown above to the left (Set Password).**

2 **Use ▲ / ▼ to select the Rating option.**

3 **Press ► to move to the third level.**

4 **Follow step 6 as shown above to the left (Set Password).**

5 **Select a rating from 1 to 8 using the ▲ / ▼ buttons. One (1) has the least playback restrictions. Eight (8) has the most playback restrictions.**
No limit: *If you select No limit, Parental Control is not active. The disc will play in full.*
Level 1 to 8: *Some discs contain scenes not suitable for children. If you set a rating for the Recorder, all disc scenes with the same rating or lower will be played. Higher rated scenes will not be played unless an alternate scene is available on the disc. The alternate scene must have the same rating or a lower one. If no suitable alternate scene is found, playback will stop. You must enter the 4-digit password or change the rating level in order to play the disc.*

6 **Press ENTER to confirm your rating selection, then press SETUP to exit the menu.**

Country Code

Enter the code of a country/area whose standards were used to rate the DVD video disc, referring to the list (See "Country Codes", page 57.).



1 **Press SETUP.**
The Setup menu appears.

2 **Use ▲ / ▼ to select the Lock option.**

3 **While the Lock option is selected, press ► to move to the second level.**

4 **Use ▲ / ▼ to select the Country Code option.**

5 **Press ► to move to the third level.**

6 **If you have not entered a password yet;**
Enter a 4-digit password using the numbered buttons to create a personal 4-digit security password, then press ENTER. Enter the 4-digit password again and press ENTER to verify when "OK" is highlighted.
If you have already entered a password;
Enter a 4-digit password using the numbered buttons to confirm the personal 4-digit security password, then press ENTER when "OK" is highlighted.

Tip

If you a mistake before pressing ENTER, press ◄ repeatedly to delete password numbers one by one then correct it.

7 **Select the first character using the ▲ / ▼ buttons.**

8 **Shift the cursor using ► buttons and select the second character using ▲ / ▼ buttons.**

9 **Press ENTER to confirm your country code selection, then press SETUP to exit the menu.**

Recording

Record Mode Set

You can set the picture quality for recording; HQ (High Quality), SQ (Standard Quality), LQ (Low Quality), EQ (Extend Quality).



Record Aspect Ratio

When recording in VR mode formatted DVD-RW disc, you can set the recording aspect ratio to suit the material you're recording (16:9 widescreen, or 4:3 standard).




DV Record Audio

You need to set this if you have a camcorder using 32kHz/12-bit sound connected to the front panel DV IN port.
Some digital camcorders have two stereo tracks for audio. One is recorded at the time of shooting; the other is for over-dubbing after shooting.
On the Audio 1 setting, the sound that was recorded while shooting is used.
On the Audio 2 setting, the over-dubbed sound is used.



Auto Chapter

When recording, chapter markers are put in at the specified interval. You can set this interval to 5 minutes, 10 minutes, or 15 minutes. If you select None, it switches automatic chapter marking off, no separations.



Disc

Disc Format

If you load a completely blank disc, the "Disc Format" menu will appear. Select "Yes" then press ENTER. The Recorder will initialize the disc.

DVD-R: The Recorder initializes the disc for Video mode. The recording mode will always be Video mode.

DVD-RW: The Recorder initializes the disc for VR mode.

DVD+R / DVD+RW: The Recorder initializes the disc. Also, you can format the disc from the Setup menu as below.



1 **Press SETUP.**
The Setup menu appears.

2 **Use ▲ / ▼ to select the Disc option.**


3 **While the Disc option is selected, press ► to move to the second level.**

4 **Use ▲ / ▼ to select the Disc Format option.**


5 **Press ► to move to the third level.**
"Start" icon is highlighted.

6 **Press ENTER.**
Disc Format menu appears.

7 **For DVD-RWs, use ◄ / ► to select a Disc Format Mode (Vr Mode or Video Mode) then press ENTER.**
For DVD+RWs, go to step 8.



8 **Use ◄ / ► to select "Yes" then press ENTER.**
It takes a few moments to format the disc.




⚠**Caution**

If you want to change the disc format, everything recorded on the disc will be erased.

Disc Protect

When recording in DVD+RW / +R disc or VR mode formatted DVD-RW disc, set to ON to prevent accidental recording, editing or deleting of the disc loaded. If you need to unlock the disc to make edits, select OFF.



Finalize

Finalizing 'fixes' the recordings in place so that the disc can be played on a regular DVD player or computer equipped with a suitable DVD-ROM drive.
Finalizing a Video mode disc creates a menu for navigating the disc. This is accessed by pressing MENU/LIST or TITLE.

⚠ **Caution**

After you've finalized a disc recording on a DVD-R, DVD-RW, or a DVD+R disc, you can't edit or record anything else on that disc except on a DVD+RW disc.




1 **Follow steps 1-3 as shown on page 29 (Disc Format).**

2 **Use ▲ / ▼ to select the Finalize option.**

3 **Press ► to move to the third level.**
Finalize is highlighted.

4 **Press ENTER.**
Finalize menu appears.



5 **Select "Yes" then press ENTER.**
The recorder starts finalizing the disc.

Note :

How long finalization takes depends on the type of disc, how much is recorded on the disc, and the number of titles on the disc. A heavily recorded disc can take up to 8 minutes or more to finalize.


Tip

If you load a DVD-RW that has already been finalized, you can 'unfinalize' it by choosing Unfinalize from the Finalize menu. After doing this, you can edit and re-record onto the disc.

Disc Label

Use this to enter a name for the disc. This name appears when you load the disc and when you display disc information on-screen.

- The disc name can be up to 21 characters long.
- For discs formatted on a different DVD Recorder, you will see only a limited number of characters.




1 **Follow steps 1-3 as shown Disc Format on page 29.**

2 **Use ▲ / ▼ to select the Disc Label option.**

3 **Press ► to move to the third level.**
"Edit" icon is highlighted.

4 **Press ENTER.**
Keyboard menu appears.



5 **Enter a name for the disc. Use ▲ ▼ ◄ ► to select a character then press ENTER to confirm your selection.**

- **Alphabet Capital:** Switches the keyboard to upper case characters.
- **Alphabet Small:** Switches the keyboard to lower case characters.
- **Symbols:** Switches the keyboard to symbol characters.
- **OK:** Select to finish.
- **Cancel:** Select to exit the menu.
- **Space:** Inserts a space at the cursor position.
- **Delete:** Deletes the previous character at the cursor position.
- **◄ / ►:** Moves cursor to left or right.

6 **Choose OK then press ENTER to save the name and return to the Setup menu.**

7 **Press SETUP to exit the menu.**


Overview for the On-Screen Display

This manual gives basic instructions for operating the DVD Recorder. Some DVDs require specific operation or allow only limited operation during playback. When this occurs, the symbol ⃠ appears on the TV screen, indicating that the operation is not permitted by the DVD Recorder or is not available on the disc.

Displaying Information While Watching TV

While viewing the TV channels, press ENTER to display the information displayed on-screen.

Indicates channel number, station name, and audio signal (STEREO, MONO) received by the tuner.



Indicates current date and time.

Disc Information On-screen Display

You can display various information about the disc loaded on-screen.

1 **Press DISPLAY repeatedly to display/change the information displayed on-screen.**

2 **To remove the On-Screen Display, press DISPLAY repeatedly until it disappears.**
See the descriptions on the following pages for detailed explanations of displays as a disc is playing.

Recorder Status Icon Displays

▮▮ Resume play from this point

⃠ Action prohibited or not available

Notes :

- Some discs may not provide all of the features on the On-Screen Display, examples shown the below.
- If no button is pressed for 5 seconds, the On-Screen Display will disappear.

DVD VR Video +RW +R

Menu Options		Function (Use ▲ / ▼ to select desired option)	Selection Method
Title Number		**Shows the current title number and total number of titles, and** skips to the desired title number.	◄ / ►, or Numbers, ENTER
Chapter Number		**Shows the current chapter number and total number of chapters, and** skips to the desired chapter number.	◄ / ►, or Numbers, ENTER
Time Search		**Shows the elapsed playing time, and** searches the point by the elapsed time directly.	◄ / ►, Numbers, ENTER
Audio Language (DVD only) and Digital Audio Output Mode		**Shows the current audio soundtrack language, encoding method, and channel number, and** changes the setting.	◄ / ►
Subtitle Language		**Shows the current subtitles language, and** changes the setting.	◄ / ►
Angle		**Shows the current angle number, total number of angles, and** changes the angle number.	◄ / ►
Sound		**Shows the current sound mode, and** changes the setting.	◄ / ►

VCD

Menu Options		Function (Use ▲ / ▼ to select desired option)	Selection Method
Track Number		**Shows the current track number and total number of tracks or PBC On mode, and** skip to the desired track number.	◄ / ►, or Numbers, ENTER
Time		**Shows the elapsed playing time (Display only).**	–
Audio Channel		**Shows the audio channel, and** changes the audio channel.	◄ / ►
Sound		**Shows the current sound mode, and** changes the setting.	◄ / ►

DVD or Video CD Playback

Playback Setup

- Turn the TV on and select the video input source connected to the DVD Recorder.
- Audio System: Turn the Audio System on and select the input source connected to the DVD Recorder.

1 **Press OPEN/CLOSE (⏏) to open the disc tray.**

2 **Load your chosen disc in the tray, with the playback side down.**

3 **Press OPEN/CLOSE (⏏) to close the tray.**
READING appears on the display window, and playback starts automatically. If playback does not start, press ► (PLAY).
In some cases, the disc menu might appear instead.

Tip

If a menu is displayed

A menu may be displayed first after loading a DVD or Video CD that contains a menu.

DVD

Use the ◄ ► ▲ ▼ buttons to select the title/chapter you want to view, then press ENTER to start playback. Press TITLE or MENU/LIST to return to the menu display.

VCD

- Use the number buttons to select the track you want to view.
  Press RETURN (↶) to return to the menu display.
- Menu setting and the exact operating procedures for using the menu may differ depending on the disc. Follow the instructions on each menu screen.
  You may also set PBC to OFF in the Setup menu.
  See page 25.

Notes :

– If Parental Control is set and the disc is not within the Rating settings (not authorized), the 4-digit code must be entered and/or the disc must be authorized (see "Rating", on page 27).
– DVDs may have a Region Code.
Your recorder will not play discs that have a region code different from your recorder. The region code for this Recorder is 2 (two).

General Features

Note :

Unless stated otherwise, all operations described use the Remote Control. Some features may also be available on the Setup menu.

TITLE Selection



DVD Video VR +RW +R

If a disc has more than one title, you can move to another title as follows:

- Press DISPLAY then use ▲ / ▼ to select the title icon. Then, press the appropriate numbered button (0-9) or ◄ / ► to select a title number.

CHAPTER/TRACK Selection



DVD Video VR +RW +R VCD

If a title on a disc has more than one chapter/track, you can move to another chapter/track as follows:

- Press SKIP (I◄◄ or ►►I) briefly during playback to select the next chapter/track or to return to the beginning of the current chapter/track.
- Press SKIP (I◄◄) twice briefly to step back to the previous chapter/track.
- To go directly to any chapter/track during playback, press DISPLAY. Then, use ▲ / ▼ to select chapter icon (or for a Video CD, select track icon). Then, enter the chapter/track number using the numbered buttons (0-9) or press ◄ / ►.

Search

DVD Video VR +RW +R VCD

1. Press SCAN (◄◄ or ►►) during playback.
   The Recorder will enter SEARCH mode.
2. Press SCAN (◄◄ or ►►) to select the required speed: ◄◄X2, ◄◄X4, ◄◄X16, ◄◄X100 (backward) or ►►X2, ►►X4, ►►X16, ►►X100 (forward).
   With a Video CD, the Search speed changes: ◄◄X2, ◄◄X4, ◄◄X8 (backward) or ►►X2, ►►X4, ►►X8 (forward).
3. To exit SEARCH mode, press ► (PLAY).

Still Picture and Frame-by-Frame Playback

DVD Video VR +RW +R VCD

1. Press PAUSE/STEP (❚❚) on the remote control during playback. Advance the picture frame-by-frame by pressing PAUSE/STEP (❚❚) repeatedly.
2. To exit PAUSE mode, press ► (PLAY).

General Features (Continued)

Slow Motion

DVD Video VR +RW +R VCD

1. Press PAUSE/STEP (❚❚) during playback.
   The Recorder will enter PAUSE mode.
2. Press SCAN (◀◀ or ▶▶) during PAUSE mode.
   The DVD Recorder will enter SLOW mode.
3. Use the SCAN (◀◀ or ▶▶) to select the required speed: ◀❚ 1/16, ◀❚ 1/8, ◀❚ 1/4, or ◀❚ 1/2 (backward), or ❚▶ 1/16, ❚▶ 1/8, ❚▶ 1/4, or ❚▶ 1/2 (forward).
   With a Video CD, the Slow speed changes: ❚▶ 1/8, ❚▶ 1/4 or ❚▶ 1/2 (forward).
4. To exit Slow Motion mode, press ► (PLAY).

Note :

Slow motion playback in reverse is not possible with Video CDs.

Random

Karaoke DVD VCD

1. Press RANDOM during playback.
   The unit automatically begins Random Playback and "RANDOM" appears on the TV screen.
2. To return to normal playback, press RANDOM until "NORMAL" appears on the TV screen.

Tip

By pressing SKIP ▶▶❙ during Random playback, the unit selects another title (track) and resumes Random playback.

Note :

- This function only works with DVD Karaoke discs or Video CDs without PBC.
- On a Video CD with PBC, you must set PBC to OFF in the Setup menu to use the Random function. See page 25.

Repeat

Chapter

DVD Video VR +RW +R VCD

DVD Discs - Repeat Chapter/Title/Off

Press REPEAT to select a desired repeat mode.

- Chapter: repeats the current chapter.
- Title: repeats the current title .
- Off: does not play repeatedly.

Video CDs - Repeat Track/All/Off

Press REPEAT to select a desired repeat mode.

- Track: repeats the current track.
- All: repeats the all tracks on the disc.
- Off: does not play repeatedly.

Note :

On a Video CD with PBC, you must set PBC to OFF in the Setup menu to use the Repeat function. See page 25.

Repeat A-B

A-B

DVD Video VR +RW +R VCD

To repeat a sequence in a title:

1. Press A-B at your chosen starting point.
   Repeat icon and 'A-' appears on the TV screen.
2. Press A-B again at your chosen ending point.
   Repeat icon and 'A-B' appears on the TV screen, and the repeat sequence begins.
3. To cancel the sequence, press A-B repeatedly to select Off.

Time Search

00:10:30

DVD Video VR +RW +R

The Time Search function allows you to start playback at any chosen time on the disc.

1. Press DISPLAY twice during playback. The On-Screen Display appears on the TV screen.
   The Time Search box shows the elapsed playing time of the current disc.
2. Within 10 seconds, use ▲ / ▼ to select the Time Search icon in the On-Screen Display.
   The "0:00:00" display appears in the Time Search box.
3. Within 10 seconds, use the number buttons to enter the required start time. Enter hours, minutes, and seconds from left to right in the box.
   You can not enter an invalid time.
   If you enter the wrong numbers, press CLEAR. Then enter the correct numbers.
4. Within 3 seconds, press ENTER to confirm the start time.
   Playback starts from the selected time on the disc.

General Features (Continued)

Zoom

DVD Video VR +RW +R VCD

The Zoom function allows you to enlarge the video image and to move through the enlarged image.

1. Press ZOOM during playback or still playback to activate the Zoom function.
   Each press of the ZOOM button changes the TV display in the sequence shown below.
   x2 size → x4 size → normal size
2. Use the ◄ ► ▲ ▼ buttons to move through the zoomed picture.
3. To resume normal playback, press CLEAR or press ZOOM repeatedly until the normal picture appears.

Note :

The Zoom function may not work for some DVDs.

Marker Search



DVD Video VR +RW +R VCD

You can start playback from a memorized point. Up to nine points can be memorized.
To enter a mark, follow these steps.

1. During disc playback, press MARKER when playback reaches the spot that you want to memorize.
   The Marker icon will appear on the TV screen briefly.
2. Repeat step 1 to enter up to nine Marker points on a disc.

To Recall or Clear a Marked Scene

1. During disc playback, press SEARCH.
   The Marker Search menu will appear on the TV screen.
2. Within 10 seconds, use ◄ / ► to select the marker number that you want to recall or clear.
3. Press ENTER and playback starts from the marked scene. Or, Press CLEAR and the marker number is erased from the list.
4. You can play any marker by inputting its number on the marker search menu.

Reviewing the Contents of DVD Video Discs: Menus

DVDs may contain menus that allow you to access special features. To open the disc menu, press MENU/LIST. Then, press the appropriate number button to select an option. Or, use the ◄ ► ▲ ▼ buttons to highlight your selection, then press ENTER.

Title Menu DVD

1. Press TITLE.
   If the current title has a menu, the menu will appear on the TV screen. Otherwise, the disc menu may appear.
2. The menu may contain camera angles, spoken language and subtitle options, and chapters for the title.

Disc Menu DVD

1. Press MENU/LIST.
   The disc menu is displayed.
2. To remove the disc menu, press MENU/LIST again.

Camera Angle DVD



If the disc contains sequences recorded from different camera angles, the angle icon appears briefly on the TV screen. You can then change the camera angle if you wish.

- Press ANGLE then ◄ / ► repeatedly during playback to select the desired angle.
  The number of the current angle appears on the TV screen.

Changing the Audio Soundtrack



DVD Video VR +RW +R

Press AUDIO then press ◄ / ► repeatedly during playback to hear a different audio language (DVD only) or audio soundtrack if available.

Note :

Some discs feature both Dolby Digital and DTS soundtracks. There is no analog audio output when DTS is selected. To listen to the DTS soundtrack, connect this Recorder to a DTS decoder via one of the digital outputs. See page 18 for connection details.

Audio Channel Selection



VCD

Press AUDIO then press ◄ / ► repeatedly during playback to hear a different audio channel (Stereo, Left or Right).

3D Surround



DVD Video VR +RW +R VCD

This unit can produce a 3D Surround effect, which simulates multi-channel audio playback from two conventional stereo speakers, instead of the five or more speakers normally required to listen to multi-channel audio from a Home Theater System.

1. Press 3D SURR. then press ◄ / ► repeatedly during playback to select "3D SUR".
2. To turn off the 3D Surround effect, select "NORM".

Subtitles



DVD Video VR +RW +R

Press SUBTITLE then press ◄ / ► repeatedly during playback to see the different subtitle languages.

Instant Skip

DVD Video VR +RW +R

Each press INSTANT SKIP skips forward 15 seconds.

Note :

If ⃠ appears, the feature is not available on the disc.

Last Condition Memory

DVD Video VR +RW +R

This Recorder memorizes the user settings for the last disc that you have viewed. Settings remain in memory even if you remove the disc from the Recorder or switch off the Recorder. If you load a disc that had its settings memorized, the latest stop position is automatically recalled.


Notes :

– Settings are stored in memory for use any time.
– This Recorder does not memorize settings for a disc if you switch off the Recorder before commencing to play the disc.

PIP (Picture-in-Picture)

DVD Video VR +RW +R VCD

This function enables you to view the stored stations in the sub picture during playback.



Turning PIP On and Off

Press PIP to switch on the sub picture, press PIP again to switch it off.

Input source selection for sub picture

Press AV to select the input source for the sub picture. Each time AV is pressed, each input source available for the sub picture is displayed as shown below.

Tuner → AV1 → AV2 → AV3 → AV4 → DV

Program selection for sub picture

Use PR (▲ / ▼) to change the program if sub picture's input source is Tuner. The selected program number is displayed on the TV screen. You can display the selected program by pressing STOP (■).

Sub picture position change

Press ◄ / ► repeatedly until desired position is achieved. The sub picture moves clockwise or counterclockwise.

Playing an Audio CD or MP3/WMA file CD MP3 WMA

The DVD Recorder can play MP3/WMA formatted recordings on CD-ROM, CD-R, or CD-RW, DVD-R, DVD-RW, DVD+R, DVD+RW discs.


Audio CD

Once you insert an audio CD a menu appears on TV screen. Press ▲ / ▼ to select a track then press ► (PLAY) or ENTER and playback starts.



MP3 / WMA

1. Press ▲ / ▼ to select a folder, and press ENTER to see the folder contents.
2. Press ▲ / ▼ to select a track then press ► (PLAY) or ENTER. Playback starts.



Tips

- If you are in a file list and want to return to the Folder list, use the ▲/▼ to highlight 🖿 and press ENTER to return to the previous menu screen.
- Press and hold ▲ / ▼ to go to the next / previous page.
- On CDs (or DVDs) with mixed content (MP3/WMA files and JPEG files), you can select between the MP3/WMA menu and JPEG menu. Press TITLE and MP3/WMA or JPEG word on top on the menu is highlighted. Use ◄/► to select MP3/WMA or JPEG then press ENTER.
- You can view TV channel or video input source by pressing RETURN (↶). If you want to return to the AUDIO CD or MP3/WMA menu, press MENU/LIST.

Notes on MP3/WMA Recordings

MP3 / WMA disc compatibility with this player is limited as follows:

- Sampling frequency: within 32 - 48 kHz (MP3), within 32 - 48kHz (WMA)
- Bit rate: within 32 - 320kbps (MP3), 32 - 192kbps (WMA)
- The recorder cannot read an MP3/WMA file that has a file extension other than ".mp3" / ".wma".
- CD-R physical format should be ISO 9660
- If you record MP3 / WMA files using software that cannot create a file system (eg. Direct-CD) it is impossible to playback MP3 / WMA files. We recommend that you use Easy-CD Creator, which creates an ISO 9660 file system.
- File names should have a maximum of 8 letters and must incorporate an .mp3 or .wma extension.
- They should not contain special letters such as / ? * : " < > I etc.
- The total number of files on the disc should be less than 999.

This DVD recorder requires discs and recordings to meet certain technical standards in order to achieve optimal playback quality. Pre-recorded DVDs are automatically set to these standards. There are many different types of recordable disc formats (including CD-R containing MP3 or WMA files) and these require compatible playback.

Customers should note that permission is required in order to download MP3 / WMA files and music from the Internet. Our company has no right to grant such permission. Permission should always be sought from the copyright owner.

Pause CD MP3 WMA

1. Press PAUSE/STEP (❚❚) during playback.
2. To return to playback, press ► (PLAY) or press PAUSE/STEP (❚❚) again.

Track Selection CD MP3 WMA

- Press SKIP ⏮ or ⏭ briefly during playback to go to the next track or to return to the beginning of the current track.
- Press SKIP ⏮ twice briefly to step back to the previous track.
- On an Audio CD, to go directly to any track, enter the track number using the numbered buttons (0-9) during playback on the Track List.

Repeat Track/All/Off

CD MP3 WMA

Press REPEAT to select a desired repeat mode.

- TRACK: repeats the current track.
- ALL : repeats the all tracks on the disc.
- OFF (No display): does not play repeatedly.

Random CD MP3 WMA

1. Press RANDOM during playback or in Stop mode. The unit automatically begins Random Playback and "Random" appears on the menu display.
2. To return to normal playback, press RANDOM repeatedly until "Random" disappears from the menu display.

Tip

By pressing SKIP ⏭ during Random playback, the unit selects another track and resumes Random playback.

3D Surround CD MP3 WMA

This unit can produce 3D Surround effects, that simulate multi-channel audio playback from two conventional stereo speakers, instead of the five or more speakers normally required to listen to multi-channel audio from a Home Theater System.

1. Press 3D SURR. during playback to select "3D SUR".
2. To turn the 3D Surround effect off, press 3D SURR. until "3D SUR" disappears from the menu display.

Search CD

1. Press SCAN (◄◄ or ►►) during playback.
   The Recorder will enter SEARCH mode.
2. Press SCAN (◄◄ or ►►) to select the required speed: ◄◄X2, ◄◄X4, ◄◄X8 (backward) or ►►X2, ►►X4, ►►X8 (forward).
   Search speed and direction are indicated on the menu display.
3. To exit SEARCH mode, press ► (PLAY).

Repeat A-B CD MP3 WMA

To repeat a sequence in a track:

1. Press A-B at your chosen starting point.
   Repeat icon and 'A' appears on the menu screen.
2. Press A-B again at your chosen ending point.
   The Repeat icon and 'A - B' appears on the menu screen, and the repeat sequence begins.
3. To exit the sequence and return to normal play, press A-B again.
   The Repeat icon disappears from the menu screen.

Programmed Playback

The program function enables you to store your favorite tracks from any disc in the player memory. A program can contain 99 tracks (Audio CD) or 256 tracks (MP3/WMA).

1. Insert a disc.

   Audio CD and MP3/WMA Discs:
   Audio CD or MP3/WMA menu appears.

2. Select a track on the List.


3. Press PROGRAM. Or, select " " icon then press ENTER to place the selected track on the Program list. Repeat to place additional tracks on the list.

   You can add all tracks in the disc. Select " " icon then press ENTER.

4. Select the track you want to start playing on the Program list. Press and hold ▲ / ▼ to move to the next / previous page.



Audio CD Menu



MP3/WMA Menu

5. Press ► (PLAY) or ENTER to start. Playback begins in the order in which you programmed the tracks. Playback stops after all of the tracks on the Program list have played once.

Repeat Programmed Tracks

You can play a track/all on a disc.

1. Press REPEAT when playing a disc. The repeat icon appears.
2. Press REPEAT to select a desired repeat mode.
   - TRACK: repeats the current track
   - ALL: repeats all the tracks on programmed list.
   - Off(No display): does not play repeatedly.

Note :

If you press SKIP (►►I) once during Repeat Track playback, the repeat playback cancels.

Erasing a Track from Program List

1. Use ▲ ▼ ◄ ► to select the track that you wish to erase from the Program list.
2. Press CLEAR. Or, select " " icon then press ENTER to erase the selected track on the Program list. Repeat to erase additional tracks on the list.

Erasing the Complete Program List

Select " ", then press ENTER. The complete Program for the disc is erased.

Note:


The programs are also cleared when the disc is removed.

JPEG File Operation

Viewing a JPEG Disc

Using this DVD Recorder you can view Kodak PICTURE CDs and CD-R/RW, DVD+R/RW or DVD-R/RW with JPEG files.

1. Insert a disc and close the tray. The JPEG menu appears on the TV screen.



2. Press ▲ / ▼ to select a folder, then press ENTER. A list of files in the folder appears. If you are in a file list and want to return to the previous Folder list, use the ▲ / ▼ buttons on the remote to highlight .. then press ENTER.

3. If you want to view a particular file, press ▲ / ▼ to highlight a file then press ENTER or ► (PLAY). Slide Show starts from the selected file if Speed option is not II (Off).
   While viewing a file, you can press STOP to move to the previous menu (JPEG menu).

Tip:

- There are four Slide Speed options ( ) : >>> (Fast), >> (Normal), > (Slow) and II (Off).
  Use ▲ ▼ ◄ ► to highlight the Speed options ( ). Then, use ◄ / ► to select the option you want to use then press ENTER.
- If you are in a file list and want to return to the Folder list, use the ▲/▼ to highlight .. and press ENTER to return to the previous menu screen.
- Press and hold ▲ / ▼ to go to the next / previous page.
- On CDs (or DVDs) with mixed content (MP3/WMA files and JPEG files), you can select between the MP3/WMA menu and JPEG menu. Press TITLE and MP3/WMA or JPEG word on top on the menu is highlighted. Use ◄/► to select MP3/WMA or JPEG then press ENTER.
- You can view TV channel or video input source by pressing RETURN (↶). If you want to return to the JPEG menu, press MENU/LIST.

Slide Show JPEG

Use ▲ ▼ ◄ ► to highlight the (Slide Show) on the JPEG menu then press ENTER.

Still Picture JPEG

1. Press PAUSE/STEP during slide show.
   The recorder will now go into PAUSE mode.
2. To return to the slide show, press ► (PLAY) or press PAUSE/STEP again.

Moving to another File JPEG

Press SKIP (I◄◄ or ►►I) or cursor (◄ or ►) once while viewing a picture to advance to the next or previous file.

To rotate picture JPEG

Press ▲ / ▼ during showing a picture to rotate the picture clockwise or counter clockwise.

JPEG disc compatibility with this recorder is limited as follows:

- Depending upon the size and number of JPEG files, it could take a long time for the DVD Recorder to read the disc's contents. If you don't see an on-screen display after several minutes, some of the files may be too large — reduce the resolution of the JPEG files to less than 5M pixels as 2760 x 2048 pixels and burn another disc.
- The total number of files and folders on the disc should be less than 999.
- Some discs may be incompatible due to a different recording format or the condition of disc.
- Ensure that all the selected files have the ".jpg" extensions when copying into the CD layout.
- If the files have ".jpe" or ".jpeg" extensions, please rename them as ".jpg" file.
- File names without ".jpg" extension will not be able to be read by this DVD Recorder. Even though the files are shown as JPEG image files in Windows Explorer.

Basic Recording from TV channels

Follow the instructions below to record a TV program. Recording starts immediately and continues until the disc is full or you stop the recording.

1 **Switch on the recorder and load a recordable disc.**
Also make sure that the TV's input source is set to this recorder. If you load a completely blank disc, the recorder takes a short while to initialize the disc.

2 **Set a recording mode as necessary by pressing REC MODE repeatedly. (HQ, SQ, LQ, EQ)**
HQ; High Quality, SQ; Standard Quality,
LQ: Low Quality, EQ: Extended Quality

3 **Use PR (▲ / ▼) buttons to select the TV channel to record.**

Changing TV Audio Channel
You can select the audio channel (language) to listen by pressing AUDIO during viewing TV program. The current audio channel is displayed on-screen.
Stereo or mono broadcast: Stereo → Left → Right
Bilingual broadcast: Main+Sub → Main → Sub

- If the sound is of poor quality when set to Stereo, you can often improve it by changing to Mono (Left or Right).
- This recorder can record either NICAM or regular audio. If the NICAM setting (page 22) is set to Auto, then if the broadcast is NICAM, the audio automatically changes to NICAM and you can record the NICAM audio. If the broadcast is non-NICAM, the regular audio is always recorded.
  If NICAM sound distortion occurs, due to poor reception, you can switch off NICAM setting of the program.

4 **Press REC (●) once.**
Recording will start. (The REC indicator lights in the display window.)
- Recording continues until you press STOP (■) or the disc is full.
- To record for a fixed length of time, see Instant Timer Recording on right.

5 **Press STOP (■) to stop recording.**

To Pause the Recording

1. Press PAUSE/STEP (❚❚) to pause the disc during recording.
2. When you want to continue recording, press PAUSE/STEP (❚❚).

To record one TV program while watching another


1 Press TV/DVD to select the TV mode during recording. The TV indicator appears in the display window.
2 Using the TV, select the channel to be viewed.

Instant Timer Recording

Instant Timer Recording allows you to make a recording easily of a preset length without using the program timer.

1 **Follow steps 1-4 as shown left (Basic Recording from a TV channels).**

2 **Press REC (●) repeatedly to select the recording time length.**
Recording starts after the first press. Each additional press increases the recording time by 10 minutes within the available free space (maximum 120 minutes).
The recording time is displayed on the TV screen.
At the end of the recording, the DVD Recorder will stop recording and shut off.



Instant Timer Recording Menu

Checking the Recording Time

Press REC (●) once to check the recording time. The remaining time will be displayed on the TV screen for a moment.

To Extend the Recording Time


The recording time can be extended anytime by pressing REC (●).
Each additional press increases the recording time by 10 minutes within the available free space (maximum 120 minutes).

⚠Caution
If the Recorder is unplugged (or there is a power failure) while the Recorder is recording, the recording will be lost.

Timer Recording

This DVD Recorder can be programmed to record up to 7 programs over a period of 1 month. For unattended recording, the timer needs to be set with the channels to be recorded, the starting time and length.

1 Press TIMER REC.
The Timer Record menu will appear.



- **PR** – Choose a memorized program number, or one of the external inputs from which to record.
- **Date** – Choose a date up to 1 month in advance.
- **Start Time** – Set the recording starting time.
- **End Time** – Set the recording ending time.
- **Mode** – Choose a record mode (HQ, SQ, LQ, EQ, or AT).
  AT (Auto) mode determines how much disc time is available and switches record mode, if necessary, to complete recording the program.

Note :

- When you set the VPS/PDC option to On, AT mode is not available.

- **Repeat** – Choose a desired repeat (Once, Daily (Monday - Friday), or Weekly).
- **VPS/PDC** – The VPS/PDC system automatically adjusts the recording time so that even if a program is not running to schedule, you won't miss it. For VPS/PDC to work properly, you must input the correct announced time and date of the program you want to record.
  Note that VPS/PDC may not work with every station.

Notes :

- Stations that use VPS/PDC typically include VPS/PDC information in the teletext TV guide pages. Please refer to these pages when setting a timer recording.
- This recorder takes approximately 20 seconds to switch on and start recording. This means that when using VPS/PDC, there may be instances where the beginning of the program is not recorded.

2 Enter the necessary information for your timer recording(s).

- ◄ / ► (left/right) – moves the cursor left/right
- ▲ / ▼ (up/down) – changes the setting at the current cursor position
- Press RETURN (↶) to exit the Timer Record menu.
- Press ENTER after filling in all the program information.
- Press TIMER REC to display Timer Record List.

3 Press ENTER, the program will be memorized by the DVD Recorder.
To check the programming, the Timer Record List will appear.
Check field's "Rec. OK" on the Timer Record List indicates that the timer recording is programmed correctly and a recordable disc is inserted.

4 Press RETURN (↶) to exit the Program List.

5 Make sure that you load a recordable disc and press POWER to switch your unit to Standby.

Notes :

- The timer indicator lights in the display window if the Recorder is in standby with the timer active.
- You must press POWER to stop the timer recording.
- There is a short delay when a timer recording finishes to confirm the recorded program. If two timer recordings are set to record sequentially (one right after the other), the very beginning of the later program may not be recorded.

Timer Recording (Continued)

Reviewing Timer Recording Details

Programming can be checked whenever the DVD Recorder is turned on. Press TIMER REC twice.

- Use ▲ / ▼ to select a timer recording.
- Press **ENTER** to edit the selected program. Timer Record menu appears.
- Press **CLEAR** to remove the selected program from the Timer Record List.



Canceling a Timer Recording

You can clear a timer setting anytime before the recording actually starts.

- Use ▲ / ▼ to select a program you want to remove on the Timer Recorder List. If you want to remove the program, press CLEAR.
  The confirm message will appear. use ◄/► to select "Yes" then press ENTER.

Stopping a Timer Recording in Progress

After a timer recording has started, you can still cancel the program.

- Press POWER.

Timer Recording Troubleshooting

Even though the timer is set, the Recorder will not record when:

- There is no disc loaded.
- A non-recordable disc is loaded.
- Disc Protect is set to ON in the Setup menu (see page 29).
- Power is turned on.
- There are already 99 titles (DVD-RW, DVD-R, DVD+R), 49 titles (DVD+RW) recorded on the disc.

You cannot enter program for a timer recording if:

- A recording is already underway.
- The time you're trying to set has already passed.
- There are already 7 timer programs set.

If two or more timer programs overlap:

- The earlier program takes priority.
- After the earlier program finishes, the later program starts.
- If two programs are set to start at exactly the same time, the program entered first takes priority.

If the disc is damaged, the recording may not be completed successfully. In this case even though the Check field shows "Rec. OK", it may not be.

Recording from an External Input Source

Recording from External Components

You can record from an external A/V device, such as a camcorder or VCR, connected to any of the Recorder's external inputs.

1 **Make sure that the component you want to record from is connected properly to the DVD Recorder. See page 19.**

2 **Press AV repeatedly to select the external input to record from.**

- Tuner: Built-in tuner
- AV1: EURO AV1 AUDIO VIDEO mounted on back panel
- AV2: EURO AV2 DECODER mounted on back panel
- AV3: AUDIO IN 3 / VIDEO IN 3 mounted on back panel
- AV4: INPUT 4 (VIDEO, AUDIO (L/R), S-VIDEO IN) mounted on front panel
- DV: DV IN mounted on front panel

3 **Load a recordable disc.**

4 **Select the recording mode as necessary by pressing REC MODE repeatedly. (HQ, SQ, LQ, EQ)**

HQ; High Quality, SQ; Standard Quality, LQ: Low Quality, EQ: Extended Quality

5 **Press REC (●) once.**

Recording will start. (The REC indicator lights in the display window.)

- Recording continues until you press STOP (■) or the disc is full.
- To record for a fixed length of time, see Instant Timer Recording on page 40.

6 **Press STOP (■) to stop recording.**

Note :

If your source is copy-protected using CopyGuard, you will not be able to record it using this Recorder. See Copyright on page 9 for more details.

Recording from a Digital Camcorder

You can record from a digital camcorder connected to the DV IN port on the front panel of this Recorder. Using the Recorder's remote, you can control both the Camcorder and this Recorder.
Before recording, make sure that the audio input for the DV IN port is set up (see page 28).

Tips

- The source signal must be DVC-SD format.
- Some camcorders cannot be controlled using this Recorder's remote.
- If you connect a second DVD Recorder using a DV cable, you cannot control the second DVD from this one.
- You can't control this unit remotely from a component connected to the DV IN port.
- You can't record date and time information from a DV cassette.

1 **Make sure your Digital Camcorder is connected to the front panel DV IN port. See page 19.**

2 **Check that the DV audio input is as you require.**

You can choose between Audio 1 (original audio) and Audio 2 (over-dubbed audio).

- DV Input is set from the DV Rec Audio in sub-menu of the Setup menu. See DV Rec Audio on page 28 for more information.

3 **Press AV repeatedly to select the DV input.**

DV appears in the display window and on the TV screen.

4 **Find the place on the Camcorder tape that you want to the recording to start from.**

For best results, pause playback at the point from which you want to record.

- Depending on your Camcorder, you can use this Recorder's remote to control the Camcorder using the STOP, PLAY and PAUSE functions.

5 **Press REC (●) once to start recording.**

- Recording is automatically stopped if the Recorder detects no signal.
- You can pause or stop the recording by pressing PAUSE/STEP (❚❚) or STOP (■). You cannot control the Camcorder from this Remote Control during recording.
- In Video mode, the final frame of the recording may remain displayed on screen for a while after recording stops.
- For timer recording to work properly on this Recorder, the Digital Camcorder must also be switched on and be operating.

What is DV?

Using DV, also known as i.LINK, you can connect a DV-equipped Camcorder to this Recorder using a single DV cable for input and output of audio, video, data and control signals.
The i.LINK interface is also known as IEEE 1394-1995.
"i.LINK" and the "i.LINK" logo are trademarks.

- This Recorder is only compatible with DV-format (DVC-SD) camcorders. **Digital Satellite Tuners, PCs, and D-VHS Video Recorders are not compatible.**
- You cannot connect more than one DV camcorder at a time to this Recorder.
- You cannot control this Recorder from external equipment connected via the DV IN port (including two DVD Recorders).
- It may not be possible to always control the connected Camcorder via the DV IN port.
- Digital Camcorders can usually record audio as stereo 16-bit/48kHz, or twin stereo tracks of 12-bit/32kHz. This Recorder can only record one stereo audio track. Set DV Rec Audio to Audio 1 or Audio 2 as required (see page 28).
- Audio input to the DV IN port should be 32 or 48kHz (not 44.1kHz).
- Picture disturbance on the recording may occur if the source component pauses playback or plays an unrecorded section of tape, or if the power fails in the source component, or the DV cable becomes disconnected.
- Although DV Rec Audio is set to Audio 2 and Audio 2 signal is not present, DV Rec Audio will be reset to Audio 1 automatically.

DV-Related Messages

You may see the following messages appear on your TV screen when using the DV IN port.

Not connected to Camcorder
The Camcorder is not connected properly, or the Camcorder is switched off.

Too many devices connected
The DV IN port on this Recorder supports connection to just one Camcorder.

Check the tape
There is no cassette loaded into the connected equipment.

Uncontrollable device
This Recorder cannot control the Camcorder.

Updating Information
Camcorder is updating information for DV.

Camera mode
Camcorder is set to camera mode.

Troubleshooting

If you can't get a picture and/or audio through the DV IN port, check the bullet points:

- Make sure the DV cable is properly connected.
- Try switching off the connected equipment then switching back on.
- Try switching the audio input.

Note :
Depending on the connected Camcorder, you may not be able to control it using the Remote Control supplied with this Recorder.


Title List and Chapter List Menu

Using the Title List-Original menu VR

The Title List-Original is where you build and edit your Playlist, and where you can delete titles and make other changes to the Original content of the disc. You can also play individual titles directly from the Title List-Original menu.
The Recorder must be in Stop mode in order to edit using the Title List-Original.

1 Press MENU/LIST to display the Title List-Original menu.

- Use the ▲ / ▼ buttons to display the previous/ next page if there are more than 6 titles.
- To exit the Title List-Original menu, press RETURN (↩).



2 To view Title List-Original options, select the title you want then press ENTER.
Title List-Original options appears on the left side of the menu.

3 Use ▲ / ▼ to select an option then press ENTER to confirm.



Play: Starts playback for the selected title.

Chapter: Moves to Chapter List-Original menu of the title. (refer to right on this page)

Delete: Deletes the title. (page 52)

Edit: Selects Edit options.
- **Title Name:** Edits the title name. (page 53)
- **Delete Parts:** Deletes a part of the Title. (page 52)

Playlist: Adds the title to the Playlist. (page 51)

4 Press RETURN (↩) repeatedly to exit the Title List-Original menu.

Tip


Press DISPLAY to show more detailed title information for selected title.

Using the Chapter List-Original menu VR

1 Press MENU/LIST to display Title List-Original menu.

2 Use ▲ ▼ ◄ ► to choose the title you want to view the Chapter List-Original menu then press ENTER.
Title List-Original options appears on the left side of the menu.

3 Use ▲ / ▼ to select 'Chapter' from Title List-Original options then press ENTER.
Chapter List-Original menu appears on the TV screen.



4 To view Chapter List-Original options, select the chapter you want then press ENTER.
Chapter List-Original options appears on the left side of the menu.

5 Use ▲ / ▼ to select an option then press ENTER to confirm.



Play: Starts playback of the selected chapter.

Title: Moves to Title List-Original menu of the chapter. (refer to left on this page)

Delete: Deletes the chapter. (page 52)

Edit: Selects Edit options.
- **Combine:** Combines two chapters into one. (page 53)

Playlist: Adds the chapter to the Playlist. (page 51)


6 Press RETURN (↩) repeatedly to exit Chapter List-Original menu.

Title List and Chapter List Menu (Continued)

Using the Title List-Playlist Menu VR

1 Press MENU/LIST repeatedly to display the Title List-Playlist menu.

- Use the ▲ / ▼ buttons to display the previous/ next page if there are more than 6 titles.
- To exit the Title List-Playlist, press RETURN (↩).



2 To view Title List-Playlist options, select the title you want then press ENTER.
Title List-Playlist options appears on the left side of the menu.

3 Use ▲ / ▼ to select an option then press ENTER to confirm.



Play: Starts playback the selected title.

Chapter: Moves to Chapter List-Playlist menu of the title. (refer to right on this page)

Delete: Deletes the title from the Title List-Playlist menu. (page 52)



Edit: Selects Edit options.

- **Title Name:** Edits the title name. (page 53)
- **Delete Part:** Deletes a part of the Title. (page 52)

4 Press RETURN (↩) repeatedly to exit Title List-Playlist menu.

Tip


Press DISPLAY to display more detailed title information for selected title.

Using the Chapter List-Playlist Menu VR

1 Press MENU/LIST repeatedly to display the Title List-Playlist menu.


2 Use ▲ ▼ ◄ ► to choose the title you want to view Chapter List-Playlist menu then press ENTER.
Title List-Playlist options appears on the left side of the menu.

3 Use ▲ / ▼ to select 'Chapter' from Title List-Playlist options then press ENTER.
Chapter List-Playlist menu appears on the TV screen.



4 To view Chapter List-Playlist options, select the chapter you want then press ENTER.
Chapter List-Playlist options appears on the left side of the menu.

5 Use ▲ / ▼ to select an option then press ENTER to confirm.



Play: Starts playback of the selected chapter.

Title: Moves to Title List-Playlist menu of the chapter. (refer to left on this page)

Delete: Deletes the chapter from the Chapter List-Playlist menu. (page 52)



Edit: Selects Edit options.


- **Combine:** Combines two chapters into one. (page 53)
- **Move:** Moves a chapter of Chapter List-Playlist menu to a position on the menu. (page 54)

6 Press RETURN (↩) repeatedly to exit Chapter List-Playlist menu.

Using the Title List menu Video

From the Title List display you can play, name, and delete titles.
After a Video mode disc is finalized, the Title List screen changes its appearance and all you can do is select titles to play.

1 Press MENU/LIST to display the Title List.



2 Use ▲ / ▼ to choose a title then press ENTER.
Title List options appears on the left side of the Title List display.

3 Use ▲ / ▼ to select an option then press ENTER to confirm.



Play: Starts playback of the selected title.

Delete: Deletes the title from the Title List.

Edit: Selects Edit options.
- **Title Name:** Edits the title name. (page 53)

4 Press RETURN (↶) repeatedly to exit Title List.

Tip
Press DISPLAY to display more detailed title information for selected title.

Deleting a Title Video

Before a disc is finalized, you can delete titles recorded on the disc.

⚠**Caution**
- If you delete a title from a DVD-R disc, the title will disappear from the Title List, but the available recording time will not increase.
- When deleting a title from a DVD-RW disc, the remaining time available for recording will only increase if it is the last title on the disc.

1 Press MENU/LIST to display Title List

2 Use ▲ ▼ ◄ ► to choose a title you want to delete then press ENTER.
Title List options appears on the left side of the Title List menu.

3 Use ▲ / ▼ to select 'Delete' then press ENTER to confirm.
The confirm message for deleting will appear.



4 Use ◄ / ► to select 'Yes' then press ENTER.
The selected chapter or title is deleted.
After pressing ENTER, the new, updated menu is displayed.

5 Repeat steps 2-3 to delete additional titles from the Title List.

6 Press RETURN (↶) repeatedly to remove the Title List display.


Title List and Chapter List Menu (Continued)

Using the Title List menu +RW

The Title List is where you can see the all recorded titles, and where you can delete titles and make other changes to the Original content of the disc. You can also play titles directly from the Title List menu.
The Recorder must be in Stop mode in order to edit using the Title List menu.

1 **Press MENU/LIST to display the Title List menu.**

- Use the ▲ / ▼ buttons to display the previous/ next page if there are more than 6 titles.
- To exit the Title List menu, press RETURN (↩).



2 **To view Title List options, select the title you want then press ENTER.**
Title List options appears on the left side of the menu.

3 **Use ▲ / ▼ to select an option then press ENTER to confirm.**



Play: Starts playback of the selected title except the hidden chapters.

Full Play: Starts playback of the selected title including the hidden chapters.

Chapter: Moves to Chapter List menu of the title. (refer to right on this page)

Delete: Deletes the title. (page 52)

Protect: Protects against accidental recording, editing, or deleting of the title. (page 54)

Edit: Selects Edit options.
- **Title Name:** Edits the title name. (page 53)
- **Divide:** Divides one title into two titles. (page 55)

4 **Press RETURN (↩) repeatedly to exit Title List menu.**

Tip

Press DISPLAY to display more detailed title information for selected title.

⚠Caution


If you press REC (●) after the Title List menu appears, the selected title is erased then overwrite recording starts. (See page 56 for more details.)

Using the Chapter List menu +RW

1 **Press MENU/LIST to display Title List menu.**

2 **Use ▲▼◄► to choose the title you want to view Chapter List menu then press ENTER.**
Title List options appears on the left side of the menu.

3 **Use ▲ / ▼ to select 'Chapter' from Title List options then press ENTER.**
Chapter List menu appears on the TV screen.



4 **To view Chapter List options, select the chapter you want then press ENTER.**
Chapter List options appears on the left side of the menu.

5 **Use ▲ / ▼ to select an option then press ENTER to confirm.**



Play: Starts playback of the selected chapter.

Title: Moves to Title List menu of the chapter. (refer to left on this page)

Edit: Selects Edit options.
- **Combine:** Combines two chapters into one. (page 53)
- **Hide (Show):** Hides (or Shows) the selected chapter. (page 55)

6 **Press RETURN (↩) repeatedly to exit Chapter List menu.**


Title List and Chapter List Menu (Continued)

Using the Title List menu +R

The Title List is where you can see the all recorded titles, and where you can delete titles and make other changes to the Original content of the disc. You can also play titles directly from the Title List menu.
The Recorder must be in Stop mode in order to edit using the Title List menu.


1 Press MENU/LIST to display the Title List menu.

- Use the ▲ / ▼ buttons to display the previous/ next page if there are more than 6 titles.
- To exit the Title List menu, press RETURN (↩).



2 To view Title List options, select the title you want then press ENTER.
Title List options appears on the left side of the Title List menu.

3 Use ▲ / ▼ to select an option then press ENTER to confirm.



Play: Starts playback of the selected title except the hidden chapters.

Full Play: Starts playback of the selected title including the hidden chapters.

Chapter: Moves to Chapter List menu of the title. (refer to right on this page)

Delete: Deletes the title. (page 52)

Protect: Protects against accidental recording, editing, or deleting of the title. (page 54)

Edit: Selects Edit options.
- **Title Name:** Edits the title name. (page 53)
- **Divide:** Not available (DVD+RW disc only)

4 Press RETURN (↩) repeatedly to exit Title List menu.

Tip

Press DISPLAY to display more detailed title information for selected title.

Using the Chapter List menu +R

1 Press MENU/LIST to display Title List menu.

2 Use ▲ ▼ ◄ ► to choose the title you want to view the Chapter List menu then press ENTER.
Title List options appear on the left side of the menu.

3 Use ▲ / ▼ to select 'Chapter' from the Title List options then press ENTER.
Chapter List menu appears on the TV screen.



4 To view Chapter List options, select the chapter you want then press ENTER.
Chapter List options appear on the left side of the menu.

5 Use ▲ / ▼ to select an option then press ENTER to confirm.



Play: Starts playback of the selected chapter.

Title: Moves to the Title List menu of the chapter. (refer to left on this page)

Edit: Selects Edit options.
- **Combine:** Combines two chapters into one. (page 53)
- **Hide (Show):** Hides (or Shows) the selected chapter. (page 55)

6 Press RETURN (↩) repeatedly to exit Chapter List menu.

Title and Chapter Editing

Edits you make to the Original content change the actual content of the disc. For example, if you delete a title or chapter from the Original content (Title or Chapter), that title or chapter is deleted from the disc, freeing up extra recording time.
When you edit the Playlist, on the other hand, you are not changing the content of the disc. For example, when you delete a title from the Playlist, you are just telling the Recorder not to play that title; nothing is actually deleted from the disc.

Titles, Chapters, and Parts VR

Titles in the disc's original content contain one or more chapters. When you insert a title into the Playlist, all the chapters within that title also appear. In other words, chapters in the Playlist behave exactly as chapters on a DVD-Video disc do. Parts are sections of Original or Playlist titles. From the Original and Playlist menu, you can add or delete parts. Adding a chapter or title to the Playlist creates a new title made up of a section (ie., chapter) of an Original title. Deleting a part removes part of a title from the Original or Playlist menu.

⚠Caution

- When editing using the Delete, Add, or Move functions, the start and end frames may not be exactly as set in the starting and ending points display.
- During Playlist playback, you may notice a momentary pause between edits. This is not a malfunction.

Adding Chapter Markers

VR +RW +R Chapter

You can put a chapter marker anywhere in a Playlist or Original title during playback.
Once the chapter is marked, you can use the Chapter Search feature, as well as delete, combine and move chapters in the Chapter List-Original or Chapter List-Playlist menu.

Note :

Chapter markers are inserted at regular intervals automatically. You can change this interval from the Initial Setup menu (see Auto Chapter on page 29).

1 **Play the title (Original or Playlist).**

2 **At the point you want to start a new chapter, press CHP ADD.**
A chapter marker icon appears on the TV screen.
- You can also put chapter markers in while recording.

Changing Title Thumbnails

VR +RW +R Thumbnail

Each title displayed in the Title List menu is represented by a thumbnail picture taken from the start of that title or chapter.
If you prefer, select a different still picture from within a title.

1 **Play the title (Original or Playlist).**

2 **Press THUMBNAIL to make the currently displayed picture the one that appears in the Original or Playlist menu.**
The still picture that you choose appears in both the Original or Playlist menu.

Tip

You can also change the thumbnail picture of the title on the Chapter List-Original or Chapter List-Playlist menu. Select a chapter on the Chapter List-Original or Chapter List-Playlist menu, then press THUMBNAIL. The thumbnail picture of the title that includes the chapter is changed.

Making a New Playlist VR


Use this function to add an Original title or chapter to the Playlist. When you do this, the whole title is put into the Playlist (you can delete bits you don't need later — see Deleting a Title/Chapter on page 52).

The title appears in the Playlist complete with the chapter markers that appeared on the Original. However, if you add more chapter markers to the Original later, these are not automatically copied over into the Playlist title.


You can add up to 999 chapters to one disc . If you only want to add a chapter of a title, use the Adding a title/chapter to the Playlist on this page.

1 **Press MENU/LIST repeatedly to display Title List-Original menu.**
If you want to display the Chapter List-Original menu, refer to "Using the Chapter List-Original menu" on page 45.

2 **Choose a title or chapter on the Original menu to put into the Playlist, then press ENTER.**
Original (Title or Chapter) options appear on the left side of the Original menu.



Title List-Original



Chapter List-Original

3 **Use ▲ / ▼ to select 'Playlist' from Original options then press ENTER.**




4 **Select 'New Playlist' then press ENTER.**
The new title appears in the updated Playlist. All chapters of the title are added to the Playlist.

Adding Additional Title/Chapters to the Playlist VR


You can add an Original title or chapter to a Playlist title even if it is already registered.

1 **Press MENU/LIST repeatedly to display Title List-Original menu.**
If you want to show the Chapter List-Original menu, refer to "Using the Chapter List-Original" on page 45.

2 **Choose an Original title or chapter to put into the Playlist, then press ENTER.**
Original menu options appear on the left side of the screen.



Title List-Original



Chapter List-Original

3 **Use ▲ / ▼ to select 'Playlist' from Original menu options then press ENTER.**



4 **Choose a Title List-Playlist that is already registered to insert a title or chapter, then press ENTER.**
The title or chapter appears in the updated Playlist menu.

5 **Repeat steps 1-4 to add additional title or chapter on the Playlist.**

6 **Press RETURN (↩) to exit, or MENU/LIST to go back to the Title List-Original menu.**

Deleting a Title/Chapter

VR +RW +R

If you erase a title or chapter from the Playlist menu on DVD-RW discs formatted in VR mode, you only remove it from the Playlist; the title/chapter remains in the Original menu.

If you choose to delete a title or chapter from Title List or Chapter List menu, the title or chapter is actually deleted from the disc and the remaining time available for recording increases. Titles/chapters deleted from the Original are also removed from the Playlist.


Note :

It may not be possible to delete chapters that are less than 5 seconds long.

1 **On the Title List or Chapter List menu, use ▲▼◄► to choose a chapter or title you want to delete then press ENTER.**
Options appears on the left side of the screen.

2 **Select 'Delete' from the options on the menu.**

e.g., If you select "Delete" on the Title List-Original menu.



3 **Press ENTER to confirm.**
The confirm message for deleting will appear.

4 **Use ◄ / ► to select 'Yes' then press ENTER.**
The selected chapter or title is deleted.
After pressing ENTER, the new, updated menu is displayed.

5 **Repeat steps 1 - 4 to continue to delete from the menu.**

6 **Press RETURN (↶) repeatedly to exit the menu.**

Notes :

- When DVD+RW recording, the deleted title's name is changed to 'Deleted Title'.
- If more than two titles are repeatedly deleted, the titles are combined into one.
- When you are deleting a title or chapter, only the last one on DVD+R/RW increases remaining recording time.

Deleting a Part VR

You can delete a part which you do not want in the title.

1 **Press MENU/LIST repeatedly to display Title List-Original or Title List-Playlist menu.**

2 **Use ▲▼◄► to choose a title you want to delete then press ENTER.**
The options appears on the left side of the menu.

3 **Select 'Delete Part' from the options on the menu.**
e.g., If you select "Delete Part" on the Title List-Original menu.



4 **Press ENTER.**
Title Edit (Delete Part) menu appears on the TV screen.
'Start Point' icon is highlighted.



5 **Starts playback and use pause step, search and slow-motion to find the starting point.**

6 **Press ENTER at the starting point of the section you want to delete.**
'End Point' icon is highlighted.
The part is indicated on the Progress Bar.

7 **Use pause step, search and slow-motion to find the ending point.**

8 **Press ENTER at the ending point of the section you want to delete.**
You can cancel the selected point, use ▲ / ▼ to select 'Cancel' icon then press ENTER.

9 **After you finish editing, select the 'Done' icon then press ENTER.**
The confirm message for deleting will appear.

10 **Use ◄ / ► to select 'Yes' then press ENTER.**
The selected part is deleted from the title and Title List-Original or Title List-Playlist menu appears.

Naming a Title VR Video +RW +R

You can name titles independently.


1 **On the Title List menu, use ▲▼◄► to choose the title you want to name then press ENTER.**
Options appears on the left side of the menu.

2 **Use ▲/▼ to select the 'Title Name' option then press ENTER.**
Keyboard menu appears.

e.g., If you select "Title Name" on the Title List-Original menu.



3 **Enter a name for the title. Use ▲▼◄► to select a character then press ENTER to confirm your selection. Refer to step 5 as shown on page 30 (Disc Label).**



4 **Choose OK then press ENTER to save the name and return to the previous menu display.**

5 **Press RETURN (↶) repeatedly to exit the menu.**

Notes :

- Names can be up to 21 characters long.
- For discs formatted on a different DVD Recorder, you will see only a limited character set.
- When recording on DVD-R, DVD+R or DVD+RW discs, the entered name is displayed on the DVD player only after finalization.

Combining Two Chapters Into One

VR +RW +R

Use this function to combine two adjacent Playlist or Original chapters into one.


Note :

This function is not available if there is only one chapter within the title.

1 **On the Chapter List menu, select the second chapter of the two chapters you want to combine then press ENTER.**
Chapter List options appear on the left side of the menu.

2 **Use ▲ / ▼ to select 'Combine'.**
The combine indicator appears between the two chapters you want to combine.

e.g., If you select "Combine" on the Chapter List-Playlist menu.




3 **Press ENTER to confirm.**
After pressing ENTER, the updated menu is displayed.

Moving a Playlist Chapter VR

Use this function to re-arrange the playing order of the Playlist chapters on the Title List-Playlist menu.

1 **Press MENU/LIST repeatedly to display Title List-Playlist menu.**
To display the Chapter List-Playlist menu, refer to "Using the Chapter List-Playlist" on page 45.


Note :
This function is not available if there is only one chapter.



2 **Select a chapter from the Chapter List-Playlist menu.**

3 **Press ENTER.**
Chapter List-Playlist options appear on the left side of the menu.

4 **Use ▲ / ▼ to select 'Move' from Playlist options then press ENTER.**



5 **Use ▲ ▼ ◄ ► to choose the place you want to move the chapter to then press ENTER.**
After pressing ENTER, updated menu is displayed.


Protect a Title +RW +R

Use this function to protect against accidental recording, editing or deleting of the title.

1 **Press MENU/LIST to display the Title List menu.**

2 **Use ▲ ▼ ◄ ► to choose a title you want to protect then press ENTER.**
Options appear on the left side of the screen.

3 **Select 'Protect' from the options.**



4 **Press ENTER to confirm.**
The lock mark will appears on the title's thumbnail.

Tip
If you select a title that has already been protected on the Title List menu, you can 'unprotect' it by choosing "Protect" from the Title List menu options. After doing that, you can edit and delete the title.

Hide a Chapter +RW +R

Use this function to hide a chapter on Chapter List menu.

1 **On the Chapter List menu, use ▲▼◄► to choose a chapter you want to hide then press ENTER.**
Options appear on the left side of the screen.

2 **Select "Hide' from the options.**

e.g., If you select "Hide" on the Chapter List menu.



3 **Press ENTER to confirm.**
The chapter's thumbnail will dim.

Tip


If you select a chapter that is already dim on the Chapter List menu, you can 'show' it by choosing "Show" from the Chapter List menu options. After doing that, you are able to see the title.

Dividing One Title Into Two +RW


Use this command to split a title up into two new titles.

1 **On the Title List menu, select a title you want to divide then press ENTER.**
The menu options appears on the left side of the screen.

2 **Select 'Divide' from the Title List menu options.**



3 **Press ENTER after the 'Divide' option is highlighted.**
Title Edit (Divide) menu appears and goes into STOP mode.



4 **Use pause step, search and slow-motion to find the point you want to divide the title.**

5 **When the 'Divide' option is highlighted, press ENTER at that point.**

You can remove the dividing point and exit the Title Edit (Divide) menu, use ▲ / ▼ to select 'Cancel' option then press ENTER. The division point is removed.


6 **Choose 'Done' option then press ENTER to fix the dividing point.**
The title is divided into two new titles. It take up to 4 minutes to divide.

Overwriting Recording +RW

To overwrite a new video recording on a previously recorded title, follow these steps. This feature is not available for DVD+Rs, that always record at the end of the Disc.

1 **Select input source you want to record (TV channel, AV1-4, DV).**

2 **Press MENU/LIST to display the Title List menu.**



3 **Use ▲ ▼ ◄ ► to choose a title you want to overwrite.**

4 **Press REC (●) to start overwrite recording.**
Overwrite recording starts from the start point of the title.

5 **Press STOP (■) to stop the overwrite recording.**
The new title is created and updated menu is displayed.

Notes :

- This function is not available for a protected title.
- **If the overwrite is longer than the recording length of the current title, the next title is overwritten. But if next title is protected, the overwriting stops at the starting point of the title.**
- If the selected title's recording length is less than 10 seconds, the next title is overwritten. But if the next title is protected, overwriting stops.

Viewing Title List menu displayed on other DVD Recorders or Players

+RW +R


You can view the Title List menu displayed on the other DVD player that is capable of playing DVD+RW or DVD+R discs.

1 **Insert DVD+R or DVD+RW disc recorded already.**

2 **Press TITLE in Play mode.**
Title List menu will appear as shown below.

Tip

You can remove the Title List menu by pressing STOP (■).



3 **To play back a title, select the title you want then press ENTER or ► (PLAY).**

Playing Your Recordings on Other DVD Players (Finalizing a Disc)

Most regular DVD players can play finalized discs recorded in Video mode, finalized DVD+R or DVD+RWs. A small number of players can also play DVD-RW discs recorded in VR mode, finalized or not. Check the manual that came with the other player to check what formats of discs it will play.

Finalizing 'saves' the recordings and editings in place so that the disc can be played on a regular DVD player or computer equipped with a suitable DVD-ROM drive. Finalizing a Video mode disc creates a menu screen for navigating the disc. The menu can be accessed by pressing MENU/LIST or TITLE.
To finalize a disc, refer to "Finalize" on page 30.

Notes :

- Unfinalized DVD+RW is playable on regular DVD players.
- The edited contents of a DVD+RW disc is compatible on regular DVD players only after finalization.
- Any edited contents of the DVD+R disc are not compatible on regular DVD players. (Hide, chapter combine, added chapter mark, etc.)

Language Code and Country Code List

Language Codes

Use this list to input your desired language for the following initial settings:
Disc Audio, Disc Subtitle, Disc Menu.

Language	Code	Language	Code	Language	Code	Language	Code
Abkhazian	6566	Fiji	7074	Lingala	7678	Singhalese	8373
Afar	6565	Finnish	7073	Lithuanian	7684	Slovak	8375
Afrikaans	6570	French	7082	Macedonian	7775	Slovenian	8376
Albanian	8381	Frisian	7089	Malagasy	7771	Somali	8379
Ameharic	6577	Galician	7176	Malay	7783	Spanish	6983
Arabic	6582	Georgian	7565	Malayalam	7776	Sudanese	8385
Armenian	7289	German	6869	Maltese	7784	Swahili	8387
Assamese	6583	Greek	6976	Maori	7773	Swedish	8386
Aymara	6588	Greenlandic	7576	Marathi	7782	Tagalog	8476
Azerbaijani	6590	Guarani	7178	Moldavian	7779	Tajik	8471
Bashkir	6665	Gujarati	7185	Mongolian	7778	Tamil	8465
Basque	6985	Hausa	7265	Nauru	7865	Tatar	8484
Bengali; Bangla	6678	Hebrew	7387	Nepali	7869	Telugu	8469
Bhutani	6890	Hindi	7273	Norwegian	7879	Thai	8472
Bihari	6672	Hungarian	7285	Oriya	7982	Tibetan	6679
Breton	6682	Icelandic	7383	Panjabi	8065	Tigrinya	8473
Bulgarian	6671	Indonesian	7378	Pashto, Pushto	8083	Tonga	8479
Burmese	7789	Interlingua	7365	Persian	7065	Turkish	8482
Byelorussian	6669	Irish	7165	Polish	8076	Turkmen	8475
Cambodian	7577	Italian	7384	Portuguese	8084	Twi	8487
Catalan	6765	Japanese	7465	Quechua	8185	Ukrainian	8575
Chinese	9072	Javanese	7487	Rhaeto-Romance	8277	Urdu	8582
Corsican	6779	Kannada	7578	Rumanian	8279	Uzbek	8590
Croatian	7282	Kashmiri	7583	Russian	8285	Vietnamese	8673
Czech	6783	Kazakh	7575	Samoan	8377	Volapük	8679
Danish	6865	Kirghiz	7589	Sanskrit	8365	Welsh	6789
Dutch	7876	Korean	7579	Scots Gaelic	7168	Wolof	8779
English	6978	Kurdish	7585	Serbian	8382	Xhosa	8872
Esperanto	6979	Laothian	7679	Serbo-Croatian	8372	Yiddish	7473
Estonian	6984	Latin	7665	Shona	8378	Yoruba	8979
Faroese	7079	Latvian, Lettish	7686	Sindhi	8368	Zulu	9085

Country Codes


Choose a country code from this list.

Country	Code	Country	Code	Country	Code	Country	Code
Afghanistan	AF	Ethiopia	ET	Malaysia	MY	Saudi Arabia	SA
Argentina	AR	Fiji	FJ	Maldives	MV	Senegal	SN
Australia	AU	Finland	FI	Mexico	MX	Singapore	SG
Austria	AT	France	FR	Monaco	MC	Slovak Republic	SK
Belgium	BE	Germany	DE	Mongolia	MN	Slovenia	SI
Bhutan	BT	Great Britain	GB	Morocco	MA	South Africa	ZA
Bolivia	BO	Greece	GR	Nepal	NP	South Korea	KR
Brazil	BR	Greenland	GL	Netherlands	NL	Spain	ES
Cambodia	KH	Islands	HM	Netherlands Antilles	AN	Sri Lanka	LK
Canada	CA	Hong Kong	HK	New Zealand	NZ	Sweden	SE
Chile	CL	Hungary	HU	Nigeria	NG	Switzerland	CH
China	CN	India	IN	Norway	NO	Taiwan	TW
Colombia	CO	Indonesia	ID	Oman	OM	Thailand	TH
Congo	CG	Israel	IL	Pakistan	PK	Turkey	TR
Costa Rica	CR	Italy	IT	Panama	PA	Uganda	UG
Croatia	HR	Jamaica	JM	Paraguay	PY	Ukraine	UA
Czech Republic	CZ	Japan	JP	Philippines	PH	United States	US
Denmark	DK	Kenya	KE	Poland	PL	Uruguay	UY
Ecuador	EC	Kuwait	KW	Portugal	PT	Uzbekistan	UZ
Egypt	EG	Libya	LY	Romania	RO	Vietnam	VN
El Salvador	SV	Luxembourg	LU	Russian Federation	RU	Zimbabwe	ZW

Controlling Your TV with the Supplied Remote

You can control the sound level, input source, and power switch of your LG TV with the supplied remote.

You can control your TV using the buttons below.



TV Control Buttons

By pressing	You can
POWER	Turn the TV on or off.
AV	Switch the TV's input source between the TV and other input sources.
PR +/–	Scan up or down through memorized channels.
VOL +/–	Adjust the sound level of the TV.
MUTE	Temporarily turn TV sound OFF, press again to restore.

Controlling other TVs with the remote

You can control the sound level, input source, and power switch of non-LG TVs as well. If your TV is listed in the table below, set the appropriate manufacturer code.

1. **While holding down TV POWER button, press the number buttons to select the manufacturer code for your TV (see the table below).**
2. **Release TV POWER button.**

Code numbers of controllable TVs

If more than one code number is listed, try entering them one at a time until you find the one that works with your TV.

Manufacturer	Code Number
LG / GoldStar	1 (Default), 2
Zenith	1, 3, 4
Samsung	6, 7
Sony	8, 9
Hitachi	4

Notes :

- Depending on your TV, some or all buttons may not function on the TV, even after entering the correct manufacturer code.
- If you enter a new code number, the code number previously entered will be erased.
- After you replace the batteries in the remote, the code number you have set may be reset to the default setting. Re-enter the appropriate code number again.

Troubleshooting

Check the following guide for the possible cause of a problem before contacting service.

Symptom	Cause	Solution
No power.	• The power cord is disconnected.	• Plug the power cord into the wall outlet securely.
No picture.	• TV/DVD mode for the recorder is set to TV.	• Press TV/DVD on the remote control repeatedly to choose DVD mode. TV indicator disappears in the display window.
	• The TV is not set to receive DVD Recorder signal output.	• Select the appropriate video input mode on the TV so the picture from the DVD Recorder appears on the TV screen.
	• The video cable is not connected securely.	• Connect the video cable securely.
	• The connected TV power is turned off.	• Turn on the TV.
No sound.	• The equipment connected with the audio cable(s) is not set to receive DVD Recorder signal output.	• Select the correct input mode on the Audio Receiver so you can listen to the sound from the DVD Recorder.
	• The audio cables are not connected securely.	• Connect the audio cable securely.
	• The power of the equipment connected with the audio cable is turned off.	• Turn on the equipment connected with the audio cable.
	• The audio connecting cord is damaged.	• Replace it with new one.
The playback picture is poor.	• The disc is dirty.	• Clean the disc.
The DVD Recorder does not start playback.	• No disc is inserted.	• Insert a disc. (Check that the disc indicator in the display window is lit.)
	• An unplayable disc is inserted.	• Insert a playable disc. (Check the disc type, color system, and regional code.)
	• The disc is placed upside down.	• Place the disc with the playback side down.
	• The disc is not placed within the guide.	• Place the disc on the disc tray correctly inside the guide.
	• The disc is dirty.	• Clean the disc.
	• The Rating level is set.	• Cancel the Rating function or change the rating level.
The picture from the external input is distorted	• The video signal from the external component is copy-protected.	• You cannot connect via this Recorder. Connect the component directly to your TV.
Some channels are skipped over when using ▲ / ▼.	• Those channels are not stored in the Recorder.	• Restore channels. See “Program Edit” on pages 21-22.
The picture or sound of broadcasting channel is weak or missing.	• Aerial or cables are loose.	• Tighten connections or replace cable.
Camcorder image is not shown.	• Camcorder is off.	• Turn camcorder on and operate properly.
Camcorder image via A/V input or DV IN to DVD Recorder is not shown on TV screen.	• DVD Recorder INPUT SELECT is incorrect.	• Use AV to select input channel (AV1, AV2, DV, etc.)

Troubleshooting (Continued)

Symptom	Cause	Solution
Can't play a disc recorded using this Recorder on another player.	• The disc was recorded in Video mode.	• Finalize the disc. (page 30)
	• Some players will not play even a finalized disc recorded in Video mode.	• No solution.
	• The disc was recorded in VR mode,	• The other player must be RW compatible in order to play it.
	• Discs recorded with copy-once material cannot be played on other players.	• No solution.
Cannot record or did not record successfully.	• The remaining blank space on the disc is insufficient.	• Use another disc.
	• The source you are trying to record is copy protected.	• You cannot record the source.
	• When setting the recording channel, the channel is tuned on the TV's own tuner.	• Select the channel on the Recorder's built-in TV tuner.
	• When recording to a Video mode disc, programs that are copy-once protected cannot be recorded.	• Use a VR mode formatted disc for copy-once material.
Timer recording is not possible.	• Clock in DVD Recorder is not set to correct time.	• Set clock to correct time. See "Auto Clock Set" or "Manual Clock Set" on page 23.
	• Timer has been programmed incorrectly.	• Reprogram Timer. See "Timer Recording" on page 41.
	• Timer record indicator light does not appear after programming timer.	• Reprogram Timer.
Stereo Audio Record and/or Playback is not present.	• TV is not Stereo-compatible.	• No solution.
	• Broadcast program is not in stereo format.	• No solution.
	• DVD Recorder A/V Out jacks are not connected to TV A/V In jacks.	• Make A/V connections. Stereo is available only via A/V output from DVD Recorder.
	• DVD Recorder Audio/Video Out is not selected for viewing at the TV.	• Select AUX or A/V source as TV input.
	• DVD Recorder's TV audio channel is set to mono.	• Set TV audio channel mode to Stereo. See "Changing TV audio channel" on page 40.
The Remote Control does not work properly.	• The Remote Control is not pointed at the remote sensor on the DVD Recorder.	• Point the Remote Control at the remote sensor on the DVD Recorder.
	• The Remote Control is too far from the DVD Recorder.	• Operate the Remote Control within 7 m.
	• There is an obstacle in the path of the Remote Control and the DVD Recorder.	• Remove the obstacle.
	• The batteries in the Remote Control are exhausted.	• Replace the batteries with new ones.

Moisture Condensation

Moisture condensation can occur:	In locations where moisture condensation may occur:
• If the DVD Recorder is moved from a cold place to a warm place.	• Keep the DVD Recorder plugged into an AC power outlet with POWER On. This will help prevent condensation.
• Under extremely humid conditions.	• If condensation has occurred, wait a few hours for the DVD Recorder to dry before using it.

Specifications

General

Power requirements	AC 110-240V, 50/60 Hz
Power consumption	30W
Dimensions (approx.)	430 x 69 x 280 mm (w x h x d)
Mass (approx.)	3.8Kg
Operating temperature	5˚C to 35˚C
Operating humidity	5 % to 90 %
Television system	PAL B/G, SECAM L colour system
Recording format	PAL

Recording

Recording format	DVD Video Recording, DVD-VIDEO
Recordable discs	DVD-ReWritable, DVD-Recordable, DVD+ReWritable, DVD+Recordable
Recordable time	Approx. 1 hour (HQ mode), 2 hours (SQ mode), 4 hours (LQ mode), 6 hours (EQ mode)
Video recording format	
Sampling frequency	27MHz
Compression format	MPEG 2
Audio recording format	
Sampling frequency	48kHz
Compression format	Dolby Digital

Playback

Frequency response	DVD (PCM 48 kHz): 8 Hz to 22 kHz, CD: 8 Hz to 20 kHz DVD (PCM 96 kHz): 8 Hz to 44 kHz
Signal-to-noise ratio	More than 100 dB (AUDIO OUT connector)
Harmonic distortion	Less than 0.008% THD (AUDIO OUT connector)
Dynamic range	More than 95 dB (AUDIO OUT connector)

Inputs

ANTENNA IN	Antenna input, 75 ohms
VIDEO IN	1.0 Vp-p 75 ohms, sync negative, RCA jack x 2 / SCART x 2
AUDIO IN	0 dBm more than 47 kohms, RCA jack (L, R) x 2 / SCART x 2
DV IN	4 pin (i.LINK/IEEE 1394 standard)

Outputs

VIDEO OUT	1 Vp-p 75 Ω, sync negative, RCA jack x 1 / SCART
S-VIDEO OUT	(Y) 1.0 V (p-p), 75 Ω, negative sync, Mini DIN 4-pin x 1 (C) 0.3 V (p-p) 75 Ω
COMPONENT VIDEO OUT	(Y) 1.0 V (p-p), 75 Ω, negative sync, RCA jack x 1 (Pb)/(Pr) 0.7 V (p-p), 75 Ω, RCA jack x 2
Audio output (digital audio)	0.5 V (p-p), 75 Ω, RCA jack x 1
Audio output (optical audio)	3 V (p-p), 75 Ω, Optical connector x 1
Audio output (analog audio)	2.0 Vrms (1 KHz, 0 dB), 600 Ω, RCA jack (L, R) x 1 / SCART

Accessories:

Scart cable 1
Audio cable (L, R) 1
Remote control 1
Video cable 1
RF Coaxial Cable 1
Batteries 2

- Design and specifications are subject to change without notice.
- Manufactured under license from Dolby Laboratories. “Dolby”, “Pro Logic” and the double-D symbol are trademarks of Dolby Laboratories.
- DTS and DTS Digital Out are registered trademarks of Digital Theater Systems, Inc.



P/NO : 3834RD0040G