LG

e-mail http://www.lge.com

Cassette Type Air Conditioner

OWNER'S MANUAL

- Please read carefully and thoroughly this manual before operating this unit.
- Contact the authorized SVC man for repair or maintenance of this unit.
- Contact the installer for installation of this unit.
- The appliance is not intended for use by young children or infirm persons without supervision.
- Young children should be supervised to ensure that they do not play with the appliance.

Prior to installation, [illegible] air-conditioning unit must be subm[illegible] for approval by the utility service wh[illegible] rovides electricity (EN 61000-3 No[illegible]

Safety Precautions
Warning 2
Caution 3

Operating Instructions
Indoor Unit, Outdoor Unit.....4
Name and Function of Remote Controller 5
Wireless Remote Controller (optional).....6
Set the Current Time and a day of the Week.....7
Weekly Program Setting 8
Holiday Setting 9
Timer Setting 9
Self-diagnosis Function 9
Operation Mode 10
Operation Procedure 10

Care and Maintenance
Indoor unit.....23
Outdoor unit.....23
Not used for long time.....24

Troubleshooting Tips
Before You Call For Service 25

Safety precautions

To prevent injury to the user or other people and property damage, the following instructions must be followed.

■ Incorrect operation due to ignoring of instruction will cause harm or damage. The seriousness is classified by the following indications.

⚠ WARNING

This symbol indicates the possibility of death or serious injury.

⚠ CAUTION

This symbol indicates the possibility of injury or damage to properties only.

⚠ WARNING

■ **Do not install, remove and reinstall the unit by yourself.**
- Improper installation will cause water leakage, electrical shock, or fire. Please consult authorized dealer or specialist for the installation work. Please note fault caused by improper installation is not covered by warranty.
- Unit must be installed in an easily accessible area. Any additional cost required to hire a special equipment to service the unit will be the responsibility of the customer.

⚠ WARNING

Do not damage or [illegible]
- It will cause electrical shock or fire.
- If the supply cord is damaged, it must be replaced by the manufacturer or its service agent or a similarly qualified person in order to avoid a hazard.

Do not operate switch [illegible] with wet
- It may cause electrical shock.

Plug in the power cord [illegible]
- Otherwise, it will cause electrical shock or fire due to heat generation.

Do not operate or stop the [illegible]
- It will cause electrical shock or fire due to heat generation.

Do not insert your finger or [illegible] the fan guard
- Since the fan rotates at high speed, this may cause an injury or damage the unit.

Do not expose the skin to [illegible]
- This could damage your health.

When an abnormality (smell of burning, etc) [illegible]
- If the unit continues to be operated in an abnormal condition, it may cause a fire, trouble, etc. In this case, consult your dealer.

Repair or relocation should not be done by [illegible]
- If this is done in correctly, it may cause a fire, electric shock, injury by dropping of the unit, water leakage, etc. Consult your dealer.

CAUTION

- Contact the authorized Service technician for repair or maintenance of this unit.
- Contact the installer for installation of this unit.
- The air conditioner is not intended for use by young children or infirm persons without supervision.
- Young children should be supervised to ensure that they do not play with the air conditioner.

⚠ CAUTION



- Water may enter the unit and degrade the insulation. It may cause an electric shock.



- An oxygen shortage may occur.



- Since the fan rotates at high speed during operation, it may cause an injury.



- This could injure the pet or plant.



- It may cause a fire or deformation of the cabinet.



- The unit may drop or fall down and cause an injury.



- It may cause imperfect combustion.



- It may cause an injury.



- It may cause an injury through dropping or falling down.



- In the cooling mode, if it is operated in a room with high humidity (80%r.h. or more) for a long time, water condensed in the air conditioner may drop and may wet and spoil furniture, etc.



- It may case an injury, etc. by falling down.



- Do not use this air conditioner to preserve precision devices, food, animal, plants and art objects.
  It may cause deterioration of quality, etc.



- If will cause electrical shock or fire.



- It may cause an injury.




- It will cause an injury by the rotating blower.

Operating Instructions

Indoor Unit, Outdoor Unit

Indoor Unit




Signal Receptor

Receives the signals from the remote control.
(Signal receiving sound: two short beeps or one long beep.)

Operation Indication Lamps

⏻	On/Off	: Lights up during the system operation.
	Filter Sign	: Lights up after 2400 hours from the time of first operating unit. (Refer to page 23.)
	Timer	: Lights up during Timer operation.
	Defrost Mode	: Lights up during Defrost Mode or Hot Start operation. (Heat pump model only)
	Outdoor Unit Operation	: Lights up during outdoor unit operation. (Cooling model only)
	Forced Operation	: Operation procedures when the remote control can't be used.


Outdoor Unit



Heat pump model: Cassette Type Air Conditioner for cooling and heating
Cooling model: Cassette Type Air Conditioner for cooling

Name and Function of Remote Controller

Remote Controller



Heat Pump Model

Cooling Model

Operation display
Displays the operation conditions.

On/Off Button
Operation starts when this button is pressed, and stops when the button is pressed again.

Set Temperature Button
Used to set the temperature when the desired temperature is obtained.

FAN Operation Button
Used to circulate room air without cooling or heating.

Fan Speed & Jet Cool Button
Used to set the desired fan speed and select Jet cool mode.

Operation Mode Selection Button
Used to select the operation mode.
- Cooling Operation Mode
- Soft Dry Operation Mode
- Heating Operation Mode(except cooling model)
- Auto Operation Mode

Auto Swing Button
Used to swing up and down.

Room Temperature Checking Button
Used to check the room temperature.

Plasma Air Clean Button (optional)

Timer Cancel Button
Used to cancel the timer.

Timer Set Button
Used to set the timer when the desired time is obtained.

Week Button
Used to set a day of the week.

Program Button
Used to set the weekly timer.

Holiday Button
Used to set a holiday of the week.

Time Set Button
Used to set the time of the day and change the time in the weekly timer Function.

Set and Clear Button
Used to set and clear the weekly timer.


Swirl Button
Used to select swirl mode.

Reset Button
Used to set the current time and clear the setting time.

※ Display temperature can be different from actual room temperature if the remote controller is installed at the place where sun-rays are falling directly or the place nearby heat source.

Wireless Remote Controller (optional)

This air-conditioner is equipped with wired remote controller basically. But if you want to be available with wireless remote controller, you pay for it.



- **OPERATION DISPLAY**
  Displays the operation conditions.
- **ON/OFF BUTTON**
  Operation starts when this button is pressed and stops when the button is pressed again.
- **JET COOL BUTTON**
  Used to select jet cool mode.
- **ON/OFF TIMER BUTTONS**
  Used to set the time of starting and stopping operation.
- **TIME SETTING BUTTONS**
  Used to adjust the time.
- **TIMER SET/CANCEL BUTTONS**
  Used to set the timer when the desired time is obtained and to cancel the Timer operation.
- **AUTO SWING BUTTON**
  Used to swing up and down.
- **SLEEP MODE BUTTON**
  Used to set Sleep Mode operation.
- **AIR CIRCULATION BUTTON**
  Used to circulate the room air without cooling or heating (turns indoor fan on/off).
- **ROOM TEMPERATURE CHECKING BUTTON**
  Used to check the room temperature.
- **RESET BUTTON**
  Used prior to resetting time or after replacing batteries.
- **INDOOR FAN SPEED SELECTOR**
  Used to select fan speed in four steps-low, medium, high, or auto.
- **ROOM TEMPERATURE SETTING BUTTONS**
  Used to select the room temperature.
- **OPERATION MODE SELECTION BUTTON**
  Used to select the operation mode.
- **PLASMA AIR CLEAN BUTTON(OPTIONAL)**

※ The wireless remote controller do not operate the swirl mode.

CAUTION

of handling the wireless remote controller


- Aim at the signal receptor on the air conditioner so as to operate.
- The remote control signal can be received at a distance of up to about 7m.
- Be sure that there are no obstructions between the remote controller and the signal receptor.
- Do not drop or throw the remote controller.
- Do not place the remote controller in a location exposed to direct sunlight, or near the heating unit, or any other heat source.
- Block a strong light over the signal receptor with a curtain or etc. so as to prevent the abnormal operation. (ex:electronic quick start, ELBA, inverter type fluorescent lamp)

Set the Current Time and a day of the Week

1 Press the ' Hour ' button.


Each time the button is pressed, the number is changed from **00** to **23**.
You can set the number of the current hour.






2 Press the ' Min ' button.

Each time the button is pressed, the number is increased from **00** to **59**.
You can set the number of the current minute.






3 Press ' Week ' button.

Each time the button is pressed, a day of the week is shifted from sunday to saturday.
You can set the day of the week.






4 Press the ' ● RESET ' button.

If you want to reset the current time and a day of the week, click the Reset button.






Weekly Program Setting


1 Press the Program button.
The remote controller is displayed like below. Then ' Program set ', ' Sun ' and '01' is blinked.

Program




2 Press the ' Week ' button.
Select the Monday.


Week



3 Change the timer setting until the desired time is set.
After you select a time, push the SET/CLR button once or one more time.




For Example if the air-conditioner is turned on from 6 to 8 and from 13 to 22 and turned off at other time monday, display is as follows. (black bar indicates turn-on, white bar indicates turn-off.)
If you follow the above procedure, you can set timer for turning or and off in all of the week.




4 If you don't set the weekly program again after setting the weekly program, it is same the previous setting. If you want to keep the weekly program for only a week follow the next procedure.

1 Press the "CANCEL" button and "SET/CLR" button simultaneously. Then the display will be toggled like befor.

Ⓐ (default)



Ⓑ




2 Detach your finger from buttons at the moment that it is displayed the Ⓑ figure.
Then the weekly program is kept for only one week.

Holiday Setting


If Tuesday is a holiday in this week, you may set a holiday.


1 Press the Program button.






2 Press the Week button.
Select the Tuesday.





3 Press the Holiday button.






Then the remote controller will be displayed ' Tue '.
The outside rectangular means holiday.
※ You cannot set the weekly program for a holiday.


Timer Setting (Delay start/Pre-set stop)

This function is used to turn on or turn off after several hours.

1 Press the Timer button
to turn Timer on or off.




2 Change the timer setting until the desired time is set.




3 If you want to cancel the timer setting, press the Cancel button.



• When the air conditioner is turned off, the air conditioner is turned on after 8 hours.




• When the air conditioner is turned on, the air conditioner is turned off after 5 hours.




Self-diagnosis Function

*'**CH**' will flash in the remote controller display when a problem occurs.*
Then please contact your dealer.

Operation Mode



(Heat Pump Model)



(Cooling Model)


Operation Procedure

1st On/Off Button

2nd Operation Mode Selection Button


3rd Room Temperature Setting Button

4th Indoor Fan Speed Selection Button



Cooling Operation Mode

1 Press the On/Off Button.




2 Select Cooling Operation.

Press the Operation Mode Selection Button.
Each time the button is pressed, the operation mode is shifted in the arrow direction.




Operation Display



Cooling Operation Soft Dry Operation Heating Operation Auto Operation




Operation Display




Soft Dry Operation Auto Operation

3 Set the temperature lower than the room temperature.



- The temperature can be set within a range of 18℃ ~ 30℃ by 1℃ .




To increase the Temperature.

To decrease the Temperature.

4 Set the fan speed.



Operation Display



- Select the fan speed in five steps-high, auto, power jet, low, medium.
- The display shows high fan speed.
- Each time the button is pressed, the fan speed mode is shifted.

※ During Cooling operation, pressing the fan speed button can be changed Jet Cool operation mode.(Refer to p19.)

2 Soft Dry Operation Mode

This mode dehumidifies without overcooling.

1 Press the On/Off Button.




2 Select Soft Dry Operation.

Press the operation Mode Selection Button.
Each time the button is pressed, the operation mode is shifted in the arrow direction.




Operation Display



Cooling Operation | **Soft Dry Operation** | Heating Operation | Auto Operation



Operation Display




Cooling Operation | Auto Operation

3 During Dry Operation.

- The indoor fan speed is automatically set to the low, so the shift of the indoor fan speed is impossible because of already being set to the best speed for Dry Operation by Micom Control.


3 Heating Operation Mode (Heat pump model only)

1 Press the On/Off Button.




2 Select Heating Operation.


Press the Operation Mode Selection Button.
Each time the button is pressed, the operation mode is shifted in the arrow direction.




3 Set the temperature higher than the room temperature.



- The temperature can be set within a range of 16℃~30℃ by 1℃.




4 Set the fan speed.




- Select the fan speed in four steps-high, Auto, low, medium.
- The display shows high fan speed
- Each time the button is pressed, the fan speed mode is shifted.

5 This air-conditioner is set to the hot start control in order not to discharge the cold air during the heating operation. This time, the remote controller indicates 'Preheat'.



6 If the outdoor temperature is too low during the heating operation, this air-conditioner is set to the defrosting operation and the remote controller indicates 'Defrost'.



4 Auto Operation Mode (Cooling model)


1 Press the On/Off Button.




2 To select **Auto Operation**, press the Operation Mode Selection button.
Each time the button is pressed, the operation mode is shifted in the direction of the arrow.




Operation Display



3 The temperature and fan speed are automatically set by the electronic controls based on the actual room temperature. If you want to change the set temperature, close the door on the remote control and press the Room Temperature Setting buttons. The cooler or warmer you feel, the more times (up to two times) you should press the button. The set temperature will then be changed.
The temperature can be set within a range of -2~2 by 1 level.



(This indication will be shifted to the initial Auto Mode Display state after 5 seconds.)




During Auto Operation:

- ❑ You cannot switch the indoor fan speed. It has already been set by the Fuzzy rule.
- ❑ If the system is not operating as desired, manually switch to another mode. The system will not automatically switch from the cooling mode to the heating mode, or from heating to cooling, it must be done by manually resetting.
- ❑ During Auto Operation, pressing the auto swing button makes the horizontal louvers swing up and down automatically. If you want to stop auto-swing, press the auto swing button again.

5 Auto Operation Mode (Heat pump model)


1 Press the On/Off Button.



2 To select **Auto Operation**, press the Operation Mode Selection button.
Each time the button is pressed, the operation mode is shifted in the direction of the arrow.




Operation Display




Cooling Operation | Soft Dry Operation | Heating Operation

3 The setting temperature can be changed, when the set temperature button is pressed.



- The temperature can be set within a range of 18℃~30℃ with increment/decrement of 1℃.



To increase the Temperature.

To decrease the Temperature.

During Auto Operation:

- ❑ You can switch the indoor fan speed.
- ❑ The system will automatically switch from the cooling mode to the heating mode, or from heating to cooling, when you select Auto Operation mode.

6 FAN Operation Mode


• Used to circulate room air without cooling or heating.

1 Press the On/Off Button.




2 Press FAN Operation Button.





3 Each time Fan Speed button is pressed, the fan speed mode is shifted in the arrow direction.



• Fan speed is Auto.


• Fan speed is high.


• Fan speed is medium.

• Fan speed is low.

7 Comfort Operation with Swirl

- It is the function for comfort cooling/heating operation.
- The diagonal two louvers are opened the more larger than the other louvers. After one minute, it is opposite.





1 Press the On/Off Button.
The unit will respond with a beep.




2 Press the Swirl Button to operate comfort cooling or heating.
Then it will be changed the open angle of two horizontal louvers.



3 To cancel the Swirl Mode, press the Swirl Button again.





8 Vane Control

You can change the open angle to the install situation.

1 Press the On/Off Button.




2 Press the right arrow and auto swing button simultaneously for three seconds.
Then the display will be toggled like before.
Detach your finger from buttons at the moment that it is displayed "**P0**" in the operation display.






3 Press the Auto Swing button again.
Then it will be changed the open angle of two horizontal louvers.
(from **P0** to **P5**)





4 Press the right arrow button and Auto Swing button to finish the setting.




5 Press the left arrow button and Auto Swing button for three seconds in order to set the other two louvers. Next procedure is the same before.



6 Although the air conditioner is turned ON/OFF, the previous setting position is not changed If you want to set the default position, you have to set the "**P0**". Because the default is the "**P0**".

9 Jet Cool Operation Mode



1 Press the On/Off button.


The unit will respond with a beep.

Select Cooling Operation.




2 Press the Fan speed button.





- Each time Fan Speed button is pressed, the fan speed mode is shifted in the arrow direction.

3 To cancel the jet cool mode, press the fan speed button again, the set temperature button, operation button, or fan operation button.




NOTE:

❑ *During the Jet Cool function at any moment, the A/C starts to blow the cool air at extremely high speed setting the room temp. automatically to 18 °C. It is especially used to cool the room temp. in the shortest time in a hot summer.*
In heating mode however, the Jet Cool function is not available.

❑ *In order to return to the normal cooling mode from the Jet Cool mode, you just press either the operation mode selection button, fan speed button or temperature setting button or fan operation button.*

10 Auto Swing Mode



1 Press the On/Off button. (Confirm the unit on operation.)



2 Press the Auto Swing button then the horizontal louvers swing up and down automatically.



3 Press again the Auto Swing button to cancel the Auto Swing mode.



11 Child Lock Function

This is the function that any children cannot used to the air-conditioner.


Operation procedure

1 ***To set the Child-Lock Function***


Press the Timer button and Minute Set button for three seconds. Then the operation mode shift to child lock mode and it is displayed ' **CL** ' in the operation display. When you press any button in this time, the remote controller is not converted to any selected mode and the ' **CL** ' is displayed in the remote controller for about three seconds. But the Room Temperature function is operated in spite of child lock mode.

2 ***To cancel the Child-Lock Function***

Press the Timer button and Minute Set button for three seconds. Then the child-lock mode is cancelled and the preselected mode is displayed in the remote controller.



12 PLASMA Purification Operation (Optional)




1 Press the On/Off button. The unit will respond with a beep.




2 Open the door on the remote control.
Press the PLASMA air purifying operation ON/OFF button.

Operation will start when the button is pressed and stop when the button is pressed again.



3 Set the fan speed again with door of the remote control closed. You can select the fan speed in four steps-low, medium, high or Auto.
Each time the button is pressed, the fan speed mode is shifted.

✳ Air purifying operation (PLASMA) with cooling, heating or any other operations.




Tips for Filter sign LED

1. Filter sign lamp (LED) is ON.
2. If LED indicating filter sign lamp is ON, clean the filter.
3. After cleaning the filter, press the Timer button and ◀ button of wired remote controller at the same time for 3 sec.
   Then filter sign LED is OFF.

13 Forced Operation

Operation procedures when the remote control can't be used.
Press the tact switch (Forced operation) for 2 seconds.
If you want to stop operation, press again the tact switch.
In case the power comes on again after power failure on the Forced Operation mode, the operating conditions are automatically set as follows:
During Forced Operation, the initial mode continues.



Forced operation
(Tact switch)


	Cooling Model	Heat pump Model	
		Room Temp. ≥ set Temp.-2°C	Room Temp. < set Temp.-2°C
Operating mode	Cooling	Cooling	Heating
Indoor FAN Speed	High	set available	set available
Setting Temperature	22℃	set available	set available

14 Auto Restart Function

In case the power comes on again after a power failure, Auto Restarting Operation is the function to operate procedures automatically to the previous operating conditions.

Helpful information

Fan speed and cooling capacity.
The cooling capacity indicated in the specification is the value when the fan speed is set to high, and the capacity will be lower at low or medium fan speed.
High fan speed is recommended when you wish to cool the room quickly.



Care and maintenance of the air conditioner


Indoor Unit

Grille, Case and Remote Control

❒ Turn the system off before cleanining, To clean, wipe with a soft, dry cloth. Do not use bleach or abrasives.


NOTE:

Supply power must be disconnected before cleaning the indoor unit.



Air Filters

The air filters behind the front grille should be checked and cleaned once every 2 weeks or more often if neccessary.



■ Never use any of the followings:

- Water hotter than 40℃. Could cause deformation and/or discoloration.
- Volatile substances. Could damage the surfaces of the air conditioner.



1 Remove the Air filters.

■ Take hold of the tab and pull slightly forward to remove the filter.

⚠ CAUTION

When the air filter is to be removed, do not touch the metal parts of the indoor unit.

It may cause an injury.

2 Clean dirt from the air filter using a vacuum cleaner or washing with water.

■ If dirt is conspicuous, wash with a neutral detergent in lukewarm water.

■ If hot water (50℃ or more) is used, it may be deformed.

3 After washing with water, dry well in the shade.

■ Do not expose the air filter to direct sunlight or heat from a fire when drying it.


4 Install the air filter.

Outdoor Unit

The heat exchanger coils and panel vents of the outdoor unit should be checked regularly. If clogged with dirt or soot, the heat exchanger and panel vents may be professionally steam cleaned.

NOTE:

Dirty or clogged coils will reduce the operating efficiency of the system and cause higher operating costs.



When the air conditioner is not GOING to be used for a long time.

When the air conditioner is not going to be used for a long time.

1 Operate the air conditioner at the following settings for 2 to 3 hours.
- Type of operation: Fan operation mode.(Refer to page 16.)
- This will dry out the internal mechanisms.

2 Turn off the breaker.

⚠ CAUTION

Turn off the breaker when the air conditioner is not going to be used for a long time.

Dirt may collect and may cause a fire.

Helpful information

The air filters and your electiric bill.
If the air filters become clogged with dust, the cooling capacity will drop, and 6% of the electricity used to operate the air conditioner will be wasted.

When the air conditioner is not going to be used for a long time.

1 Clean the air filter and install it in the indoor unit.
(Refer to page 23 for cleaning it.)

2 Check that the air inlet and outlet of the indoor/outdoor unit are not blocked.

3 Check that the ground wire is connected correctly. It may be connect to the indoor unit side.

Do not overcool the room.

This is not good for the health and wastes electricity.

Keep blinds or curtains

Do not let direct sunshine enter the room when the air conditioner is in operation.

Keep room temperature

Adjust the vertical and horizontal airflow direction to ensure a uniform temperature in the room.

Make sure that the doors

Avoid opening doors and windows as much as possible to keep the cool air in the room.

Clean the air filter regularly.

Blockages in the air filter reduce the airflow and lower cooling and dehumidifying effects. Clean at least once every two weeks.

When the air conditioner is used again.

Since windows are kept closed, it is a good idea to open them and ventilate the room now and then.

Before you call for service...

Troubleshooting Tips! Save time and money!

Check the following points before requesting repairs or service.... If the malfunction persist, please contact your dealer.

			
• Have you made a mistake in timer operation? • Has the fuse blown or has the circuit breaker been tripped?	• Check that this is not a damp smell exuded by the walls, carpet, furniture or cloth items in the room.	• Condensation occurs when the airflow from the air conditioner cools the warm room air.	• This is the protector of the mechanism. • Wait about three minutes and operation will begin.
			
• Is the air filter dirty? See air filter cleaning instructions. • The room may have been very hot when the room air conditioner was first turned on. Allow time for it to cool down. • Has the temperature been set incorrectly? • Are the indoor unit's air inlet or outlet vents obstructed?	• For a noise that sounds like water flowing. -This is the sound of freon flowing inside the air conditioner unit. • For a noise that sounds like the compressed air releasing into atmosphere. -This is the sound of the dehumidifying water being processed inside the air conditioning unit.	• This sound is generated by the expansion/constriction of the front panel, etc. due to changes of temperature.  • Cleaning the filter, press the Timer button and ◀ button of wired remote controller at the same time for 3 sec.	• Are the batteries depleted? • Are the batteries inserted in the opposite (+) and (-) directions?

Memo

LG Electronics Inc.

P/No.: 3828A20070W

Printed in Korea