



BAHASA INDONESIA
English

PETUNJUK PENGGUNAAN
GS205

CE0168

P/NO : MMBB0375305 (1.0)

www.lg.com

Product Authentication program

Dear Customers,

To protect all LG customers from counterfeit and grey market products and make sure that you receive official warranty service, LG is now running a product authentication program.

To make sure your handset is a genuine product of LG, ONLY one SMS containing the IMEI No. of your purchased handset will be automatically sent to LG on the date of purchase.

Once your phone is authenticated, you will receive the message 'Your handset is a genuine LG product.'

The customer shall bear the cost of one SMS for the product authentication program.

In return, you will receive one additional month of warranty for free.

One additional month of warranty covers only mobile phone, not batteries and accessories.

The IMEI No. sent to LG guarantees your handset to be free from manufacturing defects during the warranty period from the date of purchase without proof of purchase or warranty card.

Program Pendaftaran Produk

Kepada Pelanggan,

Untuk melindungi seluruh pelanggan LG dari penipuan dan barang tidak resmi dan memastikan bahwa anda menerima layanan garansi yang asli, LG menjalankan sebuah program pendaftaran produk.

Untuk memastikan bahwa handphone anda adalah produk asli dari LG, hanya dengan cara mengirimkan satu SMS pada saat anda membeli yang berisi no IMEI dari handphone yang anda beli yang secara otomatis akan terkirim ke LG.

Jika handphone anda telah terdaftar, anda akan menerima pesan "Handphone anda adalah produk asli dari LG"

Pelanggan harus menanggung biaya dari satu kali SMS tersebut untuk program pendaftaran produk.

Sebagai balasannya, anda akan menerima tambahan satu bulan garansi secara cuma-cuma.

Tambahan satu bulan garansi hanya berlaku untuk mobile phone, bukan baterai dan aksesoris.

No IMEI handphone yang telah terkirim ke LG akan mendapatkan garansi secara gratis dari kerusakan pabrik selama masa garansi, dimulai dari tanggal pembelian tanpa menggunakan bukti pembelian atau kartu garansi.

Bluetooth QD ID B015953

GS205

PETUNJUK PENGGUNAAN

Buku petunjuk ini mungkin berbeda dari ponselnya, tergantung pada versi perangkat lunak ponsel dan penyedia layanan yang dipakai.



Contents

Memasang kartu SIM dan baterai handset	3	Susunan menu	9
Memasang Kartu SIM	3	Referensi fitur cepat	10
Ilustrasi	3	Browser	10
Komponen Ponsel	4	Riwayat panggilan	11
Menghidupkan dan Mematikan Ponsel Anda	5	Piranti	11
Membuat panggilan	5	Multimedia	12
Membuat panggilan internasional	5	Pesan	14
Menjawab panggilan	5	Pengaturan berkas	16
Memilih fungsi dan pilihan	6	Profil	16
Mengisikan teks	7	Kontak	17
Mode T9	7	Pengaturan	18
Mode ABC	7	Pedoman untuk pemakaian yang aman dan efisien	21
Mode 123 (Mode Angka)	7	Aksesoris	25
Mode Simbol	7	Data Teknis	26
AntiTheftMobileTracker(ATMT)	8		

Memasang Kartu SIM

Bila Anda berlangganan ke jaringan seluler, Anda akan diberikan kartu SIM plugin yang telah diisi dengan perincian berlangganan, seperti halnya PIN, layanan opsional yang tersedia dan banyak lagi.

- Penting!**
- › Kartu SIM plugin dan kontakannya mudah rusak oleh goresan atau tekukan, karena itu berhati-hatilah saat memegang, menyisipkan atau melepas kartu. Jauhkan semua kartu SIM dari jangkauan anak kecil.
 - › USIM tak didukung di ponsel ini.

Ilustrasi

Selalu matikan handset dan putuskan charger sebelum mengeluarkan baterai.

- 1** Tekan tombol pelepas dan lepaskan penutup belakang.
- 2** Angkat baterainya.
- 3** Sisipkan kartu SIM.
- 4** Sisipkan baterainya.
- 5** Pasang penutup belakangnya.
- 6** Isilah baterainya.

Catatan: Isi penuh baterainya sebelum memakainya untuk pertama kali.





Komponen Ponsel





Menghidupkan dan Mematikan Ponsel Anda

1. Tekan dan tahan tombol Akhiri hingga hidup.
2. Tekan dan tahan tombol Akhiri hingga mati.



Membuat panggilan

1. Isikan nomor telepon termasuk kode area.
2. Tekan tombol  untuk memanggil nomor tersebut.
3. Untuk mengakhiri panggilan, tekan tombol  atau tombol lunak kanan.



Membuat panggilan internasional

1. Tekan dan tahan tombol  untuk awalan internasional. Karakter '+' secara otomatis memilih kode akses internasional.
2. Isikan kode negara, kode area, dan nomor telepon.
3. Tekan tombol  [Kirim] untuk memanggil nomor tersebut.

Menjawab panggilan

1. Ketika Anda menerima panggilan, ponsel berdering dan ikon telepon berkedip akan muncul pada layar.
2. Jika Sembarang tombol telah diatur sebagai mode jawab, menekan sembarang tombol akan menjawab panggilan kecuali tombol .
3. Untuk mengakhiri panggilan, tekan tombol .

Memilih fungsi dan pilihan

Ponsel Anda menyediakan serangkaian fungsi yang memungkinkan Anda untuk melakukan personalisasi ponsel. Fungsi-fungsi ini disusun dalam menu dan sub-menu, yang diakses via dua tombol lunak yang telah ditandai  dan . Masing-masing menu dan sub-menu memungkinkan Anda untuk melihat dan mengubah pengaturan fungsi tertentu.



Peran tombol lunak bervariasi tergantung pada konteksnya; label di baris bawah layar tepat di atas masing-masing tombol menunjukkan peran yang aktif.



Tekan tombol lunak kiri untuk mengakses Menu yang tersedia.

Tekan tombol lunak kanan untuk mengakses Kontak yang tersedia.

Mengisikan teks

Anda dapat memasukkan karakter alfanumerik dengan memakai keypad ponsel. Ubah mode input teks dengan menekan tombol . Tombol  juga dipakai untuk mengubah profil ke mode sunyi dalam layar siaga.

Mode T9

Mode input teks prediktif T9 memungkinkan Anda untuk mengisikan kata secara mudah dengan penekanan tombol minimal. Saat Anda menekan masing-masing tombol, ponsel mulai menampilkan karakter yang diperkirakan akan Anda ketikkan berdasarkan kamus bawaan.

Mode ABC

Mode ini memungkinkan Anda untuk mengisikan huruf dengan menekan tombol berlabel huruf yang diperlukan sekali, dua kali, tiga atau empat kali sampai huruf tersebut ditampilkan.

Mode 123 (Mode Angka)

Ketikkan angka menggunakan satu tekanan tombol per angka.

Mode Simbol

Mode simbol memungkinkan Anda memasukkan beragam simbol atau karakter khusus. Untuk mengisikan simbol, pilih **Pilihan → Sisipkan Simbol**. Pakailah tombol navigasi untuk memilih simbol yang diinginkan dan tekan tombol OK.

Anti Theft Mobile Tracker (ATMT)

Anti Theft Mobile Tracker (ATMT) memungkinkan Anda melacak ponsel Anda yang hilang. Bila ada orang yang memakai ponsel Anda tanpa izin, layanan pelacakan akan diaktifkan.

Anda akan diingatkan melalui pesan teks yang dikirimkan ke nomor telepon default yang telah Anda atur, tanpa sepengetahuan pihak lain yang tidak sah tersebut. Anda senantiasa dapat mengaktifkan ATMT dan mengkonfigurasi pengaturan pribadi.

Untuk mengaktifkan Anti Theft Mobile Tracker

1. Dari menu utama, pilih **Pengaturan** > **Pengamanan** > **Anti Theft Mobile Tracker** dan tekan **OK**.
2. Pilih **Atur ATMT** dan tekan **OK**.
3. Pilih **Hidup** atau **Mati** dan tekan **OK**.
4. Masukkan kode ATMT untuk mengaktifkan atau menonaktifkan fungsi ini.
5. Edit Nama, nomor telepon Utama dan Sekunder dan Simpan pengaturan.

Catatan

- › Kode ATMT default adalah "0000". Anda harus mengisikan kode sebelum mengkonfigurasi pengaturan ATMT.

Susunan menu

1 Browser

- 1 Rumah
- 2 Yahoo!
- 3 Buku petunjuk
- 4 Masukkan alamat
- 5 Halaman terkini
- 6 Layanan kotak masuk
- 7 Pengaturan

2 Riwayat panggilan

- 1 Semua panggilan
- 2 Pgl n tak terjawab
- 3 Panggilan keluar
- 4 Panggilan masuk
- 5 Durasi panggilan
- 6 Biaya panggilan
- 7 Penghitung GPRS

3 Piranti

- 1 Jam alarm
- 2 Kalender
- 3 Kalkulator
- 4 Memo
- 5 Daftar kerja
- 6 Satuan konversi
- 7 Jam dunia

4 Multimedia

- 1 Pemutar MP3
- 2 Kamera
- 3 Perekam video
- 4 Radio FM
- 5 Jadwalkan rekaman FM
- 6 Perekam suara
- 7 Pembuat melodi
- 8 Pembuat nada dering

5 Pesan

- 1 Pesan baru
- 2 Kotak masuk
- 3 Konsep
- 4 Kotak keluar
- 5 Terkirim
- 6 Dengarkan pesan suara
- 7 Pesan info
- 8 Templet
- 9 Pengaturan

6 Pengaturan berkas

- 1 Gambar
- 2 Suara
- 3 Video
- 4 Lainnya
- 5 Permainan & Aplks

7 Profil

- 1 Normal
- 2 Sunyi
- 3 Luar ruang
- 4 Mode penerbangan

8 Kontak

- 1 Cari
- 2 Kontak baru
- 3 Panggil cepat
- 4 Kelompok pemanggil
- 5 Salin semua
- 6 Hapus semua
- 7 Pengaturan
- 8 Nomor Ekstra

9 Pengaturan

- 1 Tanggal & Waktu
- 2 Bahasa
- 3 Menampilkan karakter
- 4 Pintasan
- 5 Panggilan palsu
- 6 Panggilan
- 7 Pengamanan
- 8 Konektivitas
- 9 Hemat daya
- 0 Atur ulang
- * Status memori

Referensi fitur cepat

Bagian ini menyediakan penjelasan singkat tentang fitur-fitur pada ponsel Anda.

Browser Menu 1

Rumah	Menghubungkan ke halaman rumah. Halaman rumah akan berupa situs yang telah ditentukan dalam profil yang diaktifkan. Ia akan ditentukan oleh penyedia layanan jika Anda belum menentukannya dalam profil yang diaktifkan.
Yahoo!	Anda dapat mengakses Yahoo! Messenger, akun email dari berbagai penyedia utama, melakukan pencarian cepat, atau melihat berita terbaru di Web. Untuk informasi lebih lanjut, Anda dapat mengunjungi Yahoo!® Mobile.
Buku petunjuk	Menu ini memungkinkan Anda untuk menyimpan URL halaman Web favorit untuk memudahkan akses di lain waktu.
Masukkan alamat	Anda dapat menghubungkan langsung ke situs yang Anda inginkan. Setelah mengisikan URL tertentu, tekan pilihan kemudian tombol OK untuk membuat koneksi untuk menghubungkan ke situs tersebut.
Halaman terkini	Menu ini menayangkan daftar semua halaman yang baru saja dikunjungi.
Layanan kotak masuk	menyimpan semua Pesan Dorong yang dikirim dari jaringan seperti halnya operator/CP/SP dsb.
Pengaturan	Anda dapat mengatur profil, cache, dan pengamanan yang terkait dengan layanan Internet.

Riwayat panggilan Menu 2

- Semua panggilan** Anda dapat melihat daftar semua panggilan yang keluar atau yang masuk.
- Pgln tak terjawab** Anda dapat melihat berbagai panggilan yang tak dijawab.
- Panggilan keluar** Anda dapat melihat berbagai panggilan keluar (yang dipanggil atau yang dicoba).
- Panggilan masuk** Anda dapat melihat berbagai panggilan yang masuk.
- Durasi panggilan** Memungkinkan Anda melihat durasi panggilan keluar dan masuk. Anda juga dapat mereset timer panggilan.
- Biaya panggilan** Melihat biaya yang telah dikenakan pada nomor yang dihubungi dan durasi panggilan atas semua panggilan masuk dan panggilan keluar. Anda juga dapat melakukan Pengaturan biaya.
- Penghitung GPRS** Anda dapat mengecek jumlah total data yang ditransfer lewat jaringan melalui pilihan informasi GPRS. Selain itu, Anda juga dapat melihat berapa lama Anda sudah online.

Piranti Menu 3

- Jam alarm** Anda dapat mengatur jam alarm agar berbunyi pada waktu yang ditentukan.
- Kalender** Bila Anda masuk ke menu ini, sebuah kalender akan muncul. Terdapat kursor kotak pada tanggal saat ini.

Piranti Menu 3 (Sambungan)

Kalkulator	Kalkulator menyediakan fungsi perhitungan dasar: penambahan, pengurangan, perkalian dan pembagian.
Memo	Anda dapat menambahkan memo baru, melihat dan mengelola memo tersimpan.
Daftar kerja	Anda dapat melihat, mengedit dan menambah Daftar kerja yang akan dilakukan.
Satuan konversi	Ini akan mengubah ukuran ke dalam satuan yang Anda inginkan. Ada 2 jenis yang dapat dikonversi ke satuan: Panjang dan Berat
Jam dunia	Fungsi Jam Dunia menyediakan informasi waktu pada kota-kota besar seluruh dunia. Selain itu, Anda dapat mengatur sembarang kota sebagai Kota Asal Anda dan Membuat Selisih Waktu HIDUP/MATI.

Multimedia Menu 4

Pemutar MP3	Dengan memakai pemutar MP3 di ponsel, Anda dengan mudah dapat menikmati beragam musik.
Kamera	Anda dapat memotret dengan kamera bawaan dan menyesuaikan pengaturannya menurut kebutuhan.
Perekam video	Anda dapat merekam klip video melalui kamera bawaan.

Radio FM	Dengan antena FM tertanam, Anda dapat menerima radio FM tanpa earphone eksternal. Anda dapat mendengarkan stasiun radio favorit kapan saja. Catatan: Di area dengan sinyal radio FM yang lemah, sensitivitas dapat ditingkatkan dengan mode antena dan nirkabel. Karena itu sebaiknya pasanglah mikrofon telinga untuk mendapatkan kualitas FM yang lebih baik dan sempurna.
Jadwalkan rekaman FM	Fungsi ini memungkinkan Anda lebih dulu menjadwalkan rekaman radio FM.
Perekam suara	Anda dapat merekam memo suara.
Pembuat melodi	Fungsi ini memungkinkan Anda mengubah nada dering atau melodi.
Pembuat nada dering	Fungsi ini memungkinkan Anda membuat nada dering pribadi dengan memakai piranti ini.

Pesan baru

Menu ini berisi berbagai fungsi yang berhubungan dengan SMS (Short Message Service) dan MMS (Multimedia Message Service).

Catatan: Anda dapat mengirim SMS ke beberapa pengguna sekaligus. Tekan saja Pilihan dan pilih Kirim ke Beberapa. Ini akan membuka daftar kontak di mana pengguna dapat menandai/tidak menandai kontak bagi pengiriman pesan SMS.

Catatan: Untuk mengirim SMS ke grup kontak tertentu, tekan saja Pilihan dan pilih Kirim ke Grup setelah membuat SMS.

Pesan Menu 5 (Sambungan)



Kotak masuk	Anda akan diperingatkan bila telah menerima pesan. Pesan akan disimpan dalam Kotak masuk. Anda dapat menyimpan SMS hingga 150 berturut-turut (dengan menjumlahkan semua pesan di setiap folder; kotak masuk, draf, terkirim dan kotak keluar).
Konsep	Dengan memakai menu 'Simpan ke konsep', Anda dapat menyimpan pesan untuk sementara dalam Konsep.
Kotak keluar	Ini adalah folder penyimpanan sementara untuk pesan yang tidak terkirim atau pesan yang telah Anda kirim namun gagal disampaikan.
Terkirim	Setelah mengirim pesan, pesan teks atau pesan multimedia akan disimpan dalam folder Terkirim.
Dengarkan pesan suara	Menu ini memberi Anda cara cepat untuk mengakses kotak pesan suara Anda (jika disediakan oleh jaringan Anda).
Pesan info	Pesan Layanan info adalah pesan teks yang dikirim oleh jaringan ke GSM.
Templet	Ada beberapa pesan siap-pakai dalam daftar tersebut. Anda dapat melihat dan mengedit pesan templet atau membuat pesan baru.
Pengaturan	Menu ini memungkinkan Anda mengatur fitur dari penyedia layanan jaringan Anda.

Pengaturan berkas Menu 6

Gambar	Menayangkan daftar file gambar seperti halnya JPG, GIF, BMP, dll.
Suara	Memainkan daftar file MP3, AMR, MID, WAV, dan AAC dalam memori Multimedia.
Video	Menampilkan daftar file video.
Lainnya	File selain gambar, dan suara, akan disimpan dalam folder ini.
Permainan & Aplks	Anda dapat mengakses berbagai pilihan permainan dan aplikasi pada ponsel Anda.

Profil Menu 7

Pada Profil, Anda dapat menyesuaikan dan mengatur sendiri nada ponsel untuk acara, lingkungan dan grup penelepon yang berbeda. Ada empat profil preset: Normal, Sunyi, Luar Ruang, dan Mode penerbangan.

Cari	Pilih Cari dan isikan nama yang ingin Anda cari dari daftar kontak.
Kontak baru	Anda dapat mendaftarkan alamat kontak baru. Anda dapat mengisikan nama, nomor telepon berbeda, alamat email, Grup dan gambar dari kontak baru.
Panggil cepat	Anda dapat memberikan tombol  sampai  ke entri Daftar nama. Anda dapat langsung memanggil dengan menekan tombol ini saat di layar siaga.
Kelompok pemanggil	Anda dapat menampilkan daftar anggota setiap Kelompok pemanggil. Ada 7 Kelompok pemanggil yang dapat Anda buat daftarnya.
Salin semua	Anda dapat menyalin berbagai entri dari Memori kartu SIM ke Memori ponsel dan sebaliknya.
Hapus semua	Anda dapat menghapus semua entri dari SIM atau Ponsel. Fungsi ini memerlukan kode pengaman.
Pengaturan Nomor Ekstra	Anda dapat mengatur pilihan tampilan kontak. <ul style="list-style-type: none">› Nomor panggil layanan: Pakailah fungsi ini untuk mengakses daftar layanan khusus yang disediakan oleh operator jaringan Anda (jika didukung oleh kartu SIM).› Nomor sendiri: Anda dapat menyimpan dan mengecek nomor sendiri dalam kartu SIM.› Kartu namaku: Pilihan ini memungkinkan Anda membuat kartu nama sendiri yang menampilkan nama, nomor dan email.

Pengaturan Menu 9

Tanggal & Waktu	Anda dapat mengatur berbagai fungsi yang berhubungan dengan tanggal dan waktu.
Bahasa	Anda dapat mengubah bahasa untuk teks tampilan dalam ponsel Anda. Perubahan ini juga akan mempengaruhi mode Input Bahasa.
Menampilkan karakter	Anda dapat mengubah pengaturan untuk Menampilkan karakter ponsel.
Pintasan	Anda dapat mengatur fungsi 4 tombol navigasi untuk dipakai sebagai pintasan dalam mode siaga.
Panggilan palsu	Anda dapat mengatur panggilan masuk palsu yang akan masuk setelah waktu tertentu dengan nama dan nomor yang Anda atur.
Panggil	Anda dapat mengatur menu yang relevan dengan sebuah panggilan dengan menekan tombol lunak kiri [OK] dalam menu Pengaturan.
Pengamanan	<p>Menu ini memungkinkan Anda mengatur keamanan ponsel.</p> <ul style="list-style-type: none">› Permintaan kode PIN: Anda dapat mengatur ponsel untuk menanyakan kode PIN dari kartu SIM Anda saat ponsel dihidupkan.› Auto kunci tombol: Anda dapat membuat keypad dikunci secara otomatis setelah beberapa saat.

- › **Kunci ponsel:** Anda dapat memakai kode pengaman untuk menghindari penyalahgunaan ponsel.
- › **Anti Theft Mobile Tracker:** Fitur ATMT pada ponsel ini memberi Anda kemampuan sistem pelacak dalam ponsel seandainya ponsel Anda hilang atau salah menaruhnya.

Pengaturan Menu 9 (Sambungan)

Kunci aplikasi

Untuk mencegah pemakaian tidak sah atas berbagai aplikasi di ponsel, Anda dapat mengaktifkan penguncian aplikasi yang mengharuskan pengguna mengisikan kata sandi bila mengakses aplikasi. Kata sandi sama dengan kode pengaman (kata sandi default adalah 0000).

- › **Folder rahasia:** Untuk menjaga data pribadi Anda tetap terlindungi, Anda dapat menyimpan file dalam Folder rahasia. Bila fitur folder rahasia diaktifkan, pengguna nanti harus mengisikan kata sandi bila mengakses folder yang dipilih. Kata sandi default adalah 0000.
- › **Ubah kode:** PIN adalah singkatan dari Personal Identification Number (Nomor Identifikasi Pribadi) untuk mencegah pemakaian oleh orang yang tidak berhak. Anda dapat mengubah kode akses: Kode pengaman, Kode PIN, Kode PIN2, dan Kode ATMT.

Pengaturan Menu 9 (Sambungan)

Konektivitas	<p>Anda dapat menghubungkan ponsel dengan perangkat lain.</p> <ul style="list-style-type: none">› Bluetooth: Ini memungkinkan koneksi nirkabel antar perangkat elektronik.› Jaringan: Anda juga dapat memilih jaringan secara manual dan mengaturnya.
Hemat daya	<p>Pilih di antara yang berikut, Mati/Hanya malam/Selalu Hidup, untuk mengubah pengaturan hemat daya yang telah diatur oleh pabrik.</p>
Atur ulang	<p>Anda dapat menginisialisasi semua default pabrik. Anda memerlukan Kode pengaman untuk mengaktifkan fungsi ini.</p>
Status memori	<p>Anda dapat mengecek ruang kosong dan pemakaian memori pada ponsel, kartu SIM dan memori eksternal (jika telah dimasukkan).</p>

Pedoman untuk pemakaian yang aman dan efisien

Harap baca pedoman singkat ini. Tidak mengikuti pedoman ini dapat membahayakan atau melanggar hukum. Informasi lebih terperinci telah diberikan dalam manual ini.

Peringatan

- › Demi keselamatan Anda, HANYA pakailah baterai dan pengisi daya yang ASLI.
- › Matikan ponsel di area yang diwajibkan oleh peraturan khusus, misalnya di asal sakit, karena ini dapat mempengaruhi peralatan medis.
- › Baterai harus dibuang sesuai dengan peraturan yang berlaku.

Pemeliharaan dan perawatan produk

PERINGATAN! Hanya pakai baterai, pengisi daya dan aksesoris yang disetujui untuk dipakai bersama ponsel model ini. Pemakaian jenis apa pun lainnya dapat membatalkan persetujuan atau garansi yang berlaku untuk ponsel ini, dan dapat membahayakan.

- › Jangan membongkar unit ini. Bawalah ke teknisi servis yang memenuhi syarat bila perbaikan diperlukan.
- › Perbaikan selama garansi, berdasar keputusan LG, mungkin meliputi komponen atau papan pengganti yang baru atau rekondisi, asalkan mempunyai fungsionalitas yang sama dengan komponen yang digantikan.
- › Unit harus dijauhkan dari sumber panas seperti halnya radiator atau kompor.
- › Pakailah kain kering untuk membersihkan bagian luar unit. (Jangan pakai cairan pelarut.)
- › Jangan menyimpan ponsel di dekat kartu kredit atau tiket transportasi, karena dapat merusak informasi pada strip magnetik.

Perangkat elektronik

Semua ponsel dapat menerima interferensi, yang dapat mempengaruhi kinerjanya.

- › Jangan memakai ponsel Anda dekat peralatan medis tanpa meminta izin. Hindari meletakkan ponsel di atas alat pacu jantung, mis. di saku baju Anda.

Keselamatan di jalan raya

Perhatikan hukum dan peraturan tentang pemakaian ponsel di daerah tempat Anda mengemudi.

- › Jangan memakai ponsel saat mengemudi.
- › Pakailah kit bebas-genggam, jika tersedia.
- › Pinggirkan dan parkir di tepi jalan sebelum membuat atau menjawab panggilan jika kondisi mengemudi mengharuskan.

Area peledakan

Jangan gunakan di tempat peledakan sedang berlangsung. Perhatikan tanda larangan dan ikuti semua regulasi atau peraturan.

Udara yang berpotensi ledakan

Jangan gunakan telepon di SPBU. Jangan memakai ponsel di dekat bahan bakar atau bahan kimia.

Di pesawat terbang

Perangkat nirkabel dapat menyebabkan interferensi di dalam pesawat terbang.

- › Matikan ponsel Anda sebelum naik ke pesawat terbang.

Anak-anak

Simpan ponsel di tempat yang aman jauh dari jangkauan anak-anak. Ponsel berisi komponen kecil yang jika terlepas dapat menyebabkan bahaya tercekik.

Panggilan darurat

Mungkin tidak semua jaringan seluler mendukung panggilan darurat. Oleh karenanya, Anda tidak boleh hanya mengandalkan ponsel untuk panggilan darurat. Tanyakan pada penyedia layanan di tempat Anda.

Informasi dan pemeliharaan baterai

- › Anda tidak perlu mengosongkan baterai Anda sebelum mengisi ulang. Tidak seperti sistem baterai lain, tidak ada efek memori yang dapat mempengaruhi kinerja baterai.
- › Pakailah hanya baterai dan pengisi daya LG. Pengisi daya LG dirancang untuk memaksimalkan masa pakai baterai.
- › Jangan membongkar atau menyebabkan arus-pendek pada paket baterai.
- › Ganti baterai bila kinerjanya sudah tidak dapat diterima lagi. Paket baterai dapat diisi ulang ratusan kali sampai perlu diganti.
- › Jangan sampai pengisi daya baterai terkena sinar matahari langsung atau dipakai di tempat dengan kelembapan tinggi, seperti halnya dalam kamar mandi.
- › Resiko ledakan jika baterai diganti dengan jenis yang salah.
- › Buanglah baterai bekas sesuai dengan petunjuk pabriknya.

Paparan terhadap energi frekuensi radio

Informasi paparan gelombang radio dan Tingkat Penyerapan Spesifik (SAR)

Model ponsel GS205 ini dirancang untuk memenuhi persyaratan keselamatan yang berlaku untuk paparan gelombang radio. Persyaratan ini didasarkan pada pedoman ilmiah dengan mempertimbangkan margin keselamatan yang dirancang untuk memastikan keselamatan semua orang, tidak tergantung usia dan kondisi kesehatannya.

- › Pedoman paparan gelombang radio memakai satuan pengukuran yang dikenal sebagai Tingkat Penyerapan Spesifik, atau SAR. Pengujian SAR dilakukan memakai metode yang telah distandardisasi dengan ponsel memancarkan pada level daya tertinggi yang diizinkan di semua band frekuensi yang dipakainya.
- › Meskipun mungkin terdapat perbedaan level SAR dari beragam model ponsel LG, kesemuanya dirancang untuk memenuhi pedoman yang terkait dengan paparan pada gelombang radio.
- › Batas SAR yang dianjurkan oleh International Commission on Non-ionizing Radiation Protection (ICNIRP), adalah rata-rata 2 W/kg pada sepuluh (10) gram jaringan tubuh.
- › Nilai SAR tertinggi untuk model ponsel ini yang diuji oleh DASY4 untuk pemakaian di telinga adalah 0.582 W/kg (10 g) dan bila dipakai di tubuh 0.539 W/kg (10 g).
- › Informasi data SAR untuk penduduk negara/kawasan yang menerapkan ambang batas SAR yang dianjurkan oleh Institute of Electrical and Electronics Engineers (IEEE) adalah sebesar rata-rata 1,6 W/kg pada satu (1) gram jaringan tubuh (misalnya AS, Kanada, Australia dan Taiwan).

Tersedia beragam aksesoris untuk ponsel Anda. Anda dapat memilih opsi ini sesuai dengan kebutuhan komunikasi pribadi Anda.

Baterai Standar




Headset



Adaptor Perjalanan

Hubungkan ini dengan kabel USB yang disertakan. Ini memungkinkan Anda untuk mengisi baterai.



Kabel USB dan CD

Anda dapat menghubungkan ponsel ke PC untuk bertukar data.



Catatan

- › Selalu pakailah aksesoris LG asli. Jika tidak dilakukan hal ini dapat membatalkan garansi Anda.
- › Aksesoris mungkin berbeda di setiap wilayah; harap hubungi perusahaan layanan regional kami atau agen LG untuk informasi lebih lanjut.

Umum

Nama produk : GS205

Sistem : E-GSM 900 / DCS 1800

Suhu Sekitar

› Maks. : +55 °C (pemakaian)
+45 °C (pengisian)

› Min : -10 °C

Declaration of Conformity  LG Electronics

Supplier Details

Name

LG Electronics Inc

Address

LG Electronics Inc, LG Tels Tower 20,
Yeouido-dong, Yeongdeungpo-gu, Seoul, Korea 150-721

Product Details

Product Name

E-GSM 900 / DCS 1800 Dual-band Terminal Equipment

Model Name

GS205

Trade Name

LG

CE 0168

Applicable Standards Details

RElevant Directive 1999/5/EC

EN 301 490-01 V1.8.1, EN 301 490-07 V1.8.1, EN 301 490-17 V2.1.1

EN 301 811 V8.0.2

EN 60950:2001, EN62208-1:2008

EN 60950-1:2001

EN600828 V1.7.1

Supplementary Information

The conformity to above standards is verified by the following Notified Body (NB/T)

NB/T, Porsyth House-Churchfield Road - Walton-on-Thames Surrey - KT12 2TD, United Kingdom

Notified Body Identification Number : 0108

Declaration

I hereby declare under our sole responsibility that the product mentioned above to which this declaration relates complies with the above mentioned standards and Directives

Name

Issued Date

Seung Hyun, Ji / Director 1. Apr. 2010

LG Electronics Logistics and Services S.V.
Valsebosweg 18, 1527 AE Almere, The Netherlands

Signature of representative

PT. LG ELECTRONICS INDONESIA
Kawasan Industri MM2100Blok G
Cikarang Barat, Bekasi, Jawa Barat 17520
INDONESIA

GS205 USER GUIDE

This manual may differ from the phone depending on the phone software version and service provider used.



Contents

Installing the SIM card and the handset battery	3	Menu tree	9
Installing the SIM Card	3	Quick feature reference	10
Illustrations	3	Browser	10
Phone Components	4	Call history	10
Turning Your Phone On and Off	5	Tools	11
Making a call	5	Multimedia	12
Making an international call	5	Messaging	13
Answering a call	5	My stuff	14
Selecting functions and options	6	Profiles	15
Entering Text	7	Contacts	15
T9 Mode	7	Settings	16
ABC Mode	7	Guidelines for safe and efficient use	18
123 Mode (Numbers Mode)	7	Accessories	22
Symbol Mode	7	Technical Data	23
Anti Theft Mobile Tracker (ATMT)	8		

Installing the SIM card and the handset battery

Installing the SIM Card

When you subscribe to a cellular network, you are provided with a plug-in SIM card loaded with your subscription details, such as your PIN, any optional services available and many others.

- Important!** > The plug-in SIM card and its contacts can be easily damaged by scratches or bending, so be careful when handling, inserting or removing the card. Keep all SIM cards out of the reach of small children.
> USIM is not supported in this phone.

Illustrations

Always switch the device off and disconnect the charger before removing the battery.

- 1** Remove the back cover.
- 2** Lift battery away.
- 3** Insert the SIM card.
- 4** Insert the battery pack.
- 5** Attach the back cover.
- 6** Charge the battery.

Note: Fully charge the battery before using it for the first time.

1



2



3



4



5



6





Phone Components





Turning Your Phone On and Off

1. Press and hold the End key until the power comes on.
2. Press and hold the End key until the power goes off.




Making a call

1. Enter a phone number including the area code.
2. Press the  key to call the number.
3. To end the call, press the  key or the right soft key.



Making an international call

1. Press and hold the  key for the international prefix. The '+' character automatically selects the international access code.
2. Enter the country code, area code, and the phone number.
3. Press  [Send] key to call the number.

Answering a call

1. press the  [send] key to answer the call when the phone rings.
2. If the Any key has been set as the answer mode, any key press will answer a call except for the  key.
3. To end the call, press the  key.

Selecting functions and options

Your phone offers a set of functions that allow you to customize the phone. These functions are arranged in menus and sub-menus, accessed via the two soft keys marked  and . Each menu and sub-menu lets you view and alter the settings of a particular function.



The roles of the soft keys vary according to the current context; the label on the bottom line of the screen just above each key indicates its current role.



Press the left soft key to access the available Menu.

Press the right soft key to access the available Contacts.

Entering Text

You can enter alphanumeric characters by using the phone's keypad. Change the text input mode by pressing the  key. Also  key is used to change the profile to silent mode in idle screen.

T9 Mode

The T9 predictive text input mode lets you enter words easily with a minimum number of key presses. As you press each key, the phone begins to display the characters that it thinks you are typing based on the built-in dictionary.

ABC Mode

This mode allows you to enter letters by pressing the key labeled with the required letter once, twice, three or four times until the letter is displayed.

123 Mode (Numbers Mode)

Type numbers using one keystroke per number.

Symbol Mode

The symbol mode enables you to enter various symbols or special characters. To enter a symbol, select **Options** → **Insert Symbol**. Use the navigation keys to select the desired symbol and press the OK key.

Anti Theft Mobile Tracker (ATMT)

Anti-theft mobile tracker (ATMT) allows you to track your lost phone. When someone uses your phone without your permission, the tracking service will be activated.

You are reminded by a text message sent to the default phone number you have set, without the unauthorized user's knowledge. You can always activate the ATMT and configure your personal settings.

To activate Anti-theft mobile tracker

1. From the main menu, select **Settings > Security > Anti theft mobile tracker** and press **OK**.
2. Select **Set ATMT** and press **OK**.
3. Switch **On** or **Off** and press **OK**.
4. Input the ATMT code to enable or disable this function.
5. Edit Name, Primary and Secondary numbers and Save the settings.

Note

- › The default ATMT code is "0000". You have to enter the code before configuring the ATMT settings.

Menu tree

1 Browser

- 1 Home
- 2 Yahoo!
- 3 Bookmarks
- 4 Enter address
- 5 Recent pages
- 6 Service Inbox
- 7 Settings

2 Call history

- 1 All calls
- 2 Missed calls
- 3 Dialed calls
- 4 Received calls
- 5 Call duration
- 6 Call costs
- 7 Data information

3 Tools

- 1 Alarm clock
- 2 Calendar
- 3 Calculator
- 4 Memo
- 5 To do
- 6 Unit converter
- 7 World clock
- 8 SIM Services

4 Multimedia

- 1 MP3 player
- 2 Camera
- 3 Video camera
- 4 FM radio
- 5 Schedule FM record
- 6 Voice recorder
- 7 Melody composer
- 8 Ringtone creator

5 Messaging

- 1 New message
- 2 Inbox
- 3 Drafts
- 4 Outbox
- 5 Sent
- 6 Listen to voicemail
- 7 Info message
- 8 Templates
- 9 Settings

6 My stuff

- 1 Images
- 2 Sounds
- 3 Videos
- 4 Others
- 5 External memory
- 6 Games & Apps

7 Profiles

- 1 Normal
- 2 Silent
- 3 Outdoor
- 4 Flight mode

8 Contacts

- 1 Search
- 2 New contact
- 3 Speed dials
- 4 Groups
- 5 Copy all
- 6 Delete all
- 7 Settings
- 8 Information

9 Settings

- 1 Date & Time
- 2 Languages
- 3 Display
- 4 Shortcut
- 5 Call
- 6 Security
- 7 Connectivity
- 8 Power save
- 9 Reset
- 0 Memory status

Quick feature reference

This section provides brief explanations of features on your phone.

Browser Menu 1

Home	Connects to a homepage. The homepage will be the site which is defined in the activated profile. It will be defined by the service provider if you have not defined it in the activated profile.
Yahoo!	You can access to your Yahoo! Messenger, email accounts from any major providers, do a quick search, or view latest news on the Web. For more information, you can visit Yahoo!® Mobile for more information.
Bookmarks	This menu allows you to store the URL of favorite web pages for easy access at a later time.
Enter address	You can connect directly to the site you want. After entering a specific URL, press options then OK key to make the connection Done to connect to the site.
Recent pages	This menu shows all lists of recently browsed pages.
Service Inbox	Service Inbox stored all the Push Message sent from network like operator/CP/SP etc.
Settings	You can set the profile, cache and security related to internet service.

Call history Menu 2

All calls	You can view all lists of outgoing or incoming calls.
Missed calls	You can view the unanswered calls.

Call history Menu 2 (Continued)

Dialled calls	You can view the outgoing calls (called or attempted).
Received calls	You can view the Received calls.
Call duration	Allows you to view the duration of your incoming and outgoing calls. You can also reset the call timers.
Call cost	View the charges applied to your dialled numbers and the call duration of all your received and dialled calls. Also you can do Cost Settings.
Data information	You can check the amount of data transferred over the network through the GPRS information option. In addition, you can also view how much time you are online.

Tools Menu 3

Alarm clock	You can set the alarm clock to go on at a specified time.
Calendar	When you enter this menu, a calendar appears. A square cursor is located on the current date.
Calculator	The calculator provides the basic arithmetic functions: addition, subtraction, multiplication and division.
Memo	You can add new memo, view and manage saved memos.
To Do	You can view, edit and add tasks to do.
Unit converter	This converts any measurement into a unit you want. There are 2 types that can be converted into units: Length, Weight

Tools Menu 3 (Continued)

World clock The World Clock function provides time information on major cities worldwide. Also you can set any city as your Home city and Make Daylight savings ON/OFF.

Multimedia Menu 4

MP3 player Using the MP3 player in your phone, you can easily enjoy various music.

Camera You can take photos with the built in camera and adjust its settings to suit your needs.

Video camera You can record a video clip through the built-in camera.

FM radio With embedded FM antenna, you can receive FM radio without an external earphone. You can listen to your favourite radio station anytime.

Note: In weak FM radio signal area the sensitivity can degrade with wireless and antenna mode. So it is advisable to insert the ear-mic for better and enhanced FM quality.

Schedule FM record This function allows you to pre-schedule FM radio recordings.

Voice recorder You can record voice memo.

Melody composer This function allows you to compose a ring tone or melody.

Ringtone creator This function allows you to create your own personal ringtones by using this tool.

Messaging Menu 5

- New message** This menu includes functions related to SMS (Short Message Service) and MMS (Multimedia Message Service).
Note: You can send SMS to many users at a time. Simply press Option and select Send to Many. This will open contact list where in user can mark/unmark contacts for sending SMS message.
Note: To send the SMS to a particular group of contacts, simply press Options and select Send to Group after composing the SMS.
- Inbox** You will be alerted when you have received messages. They will be stored in Inbox. You can save SMS up to 150 respectively (summing up all the messages in each folder; inbox, drafts, sent and outbox).
- Drafts** Using 'Save to drafts' menu, you can save the message temporarily in Drafts.
- Outbox** This is a temporary storage folder for the unsent messages or messages that you have sent but fail to deliver.
- Sent** After sending out the message, the text message or multimedia message is saved in the Sent folder.
- Listen to voicemail** This menu provides you with a quick way of accessing your voice mailbox (if provided by your network).
- Info message** Info service messages are text messages delivered by the network to GSM.

Messaging Menu 5 (Continued)

- Templates** There are pre-defined messages in the list. You can view and edit the template messages or create new messages.
- Settings** This menu allows you to set features of your network service provider.



My stuff Menu 6

- Images** Shows the list of image files such as JPG, GIF, BMP, etc.
- Sounds** Plays the list of MP3, AMR, MID, WAV, AAC files in Multimedia memory.
- Videos** Displays the list of video files.
- Others** Other files except images, sounds are stored in this folder.
- External memory** When you insert the memory card, you can view Image, Sounds, Videos and Others menu in memory card.
- Games & Apps** You can access a great selection of games and applications on your phone.

Profiles Menu 7

In Profiles, you can adjust and customize the phone tones for different events, environments, or caller groups. There are four preset profiles: Normal, Silent, Outdoor and Flight mode.

Contacts Menu 8

- Search** Select Search and enter the name that you want to search from the contact list.
- New contact** You can register a new contact address. You can enter the name, different phone numbers, email addresses, Groups and images of a new contact.
- Speed dials** You can assign any of the keys from  to  with a Name list entry. You can call directly by pressing this key when you are in idle screen.
- Groups** You can list up to the members per each group. There are 7 groups you can make lists to.
- Copy all** You can copy entries from SIM card memory to Phone memory and vice versa.
- Delete all** You can delete all the entries from SIM or Phone. This function requires the security code.
- Settings** You can set the contact display option.
- Information**
- › **Service dial number:** Use this function to access a particular list of services provided by your network operator (if supported by the SIM card).
 - › **Own number:** You can save and check your own number in SIM card.
 - › **My business card:** This option allows you to create your own business card featuring Name, any numbers and email.

Settings Menu 9

- Date & Time** You can set functions relating to the date and time.
- Languages** You can change the language for the display texts in your phone. This change will also affect the Language Input mode.
- Display** You can change settings for the phone display.
- Shortcut** You can set the functions of 4 navigation keys to use as shortcuts in idle mode.
- Call** You can set the menu relevant to a call by pressing the left soft key [OK] in the Setting menu.
- Security** This menu allows you to set the phone's safety.
- › **PIN code request:** You can set the phone to ask for the PIN code of your SIM card when the phone is switched on.
 - › **Auto key lock:** You can make the key pad locked automatically after some time.
 - › **Phone lock:** You can use a security code to avoid unauthorized use of the phone.
 - › **Anti Theft Mobile Tracker:** The ATMT feature of this phone provides you with the ability to have a tracking system in place for your mobile in case you lose or misplace it.
 - › **Application lock:** To prevent unauthorized use of phone applications, you can enable application lock which requires user to enter a password when accessing applications. Password is the same as the security code (Default password is 0000).

- › **Secret folder:** You can set the password to avoid unauthorized use of My stuff and External Memory folders. You will need a security code to access the data. To activate the secret folder, go to secret folder in Security Under Settings. Set Secret folder to ON. When secret folder feature is activated, user will be required to enter a password when accessing the selected folder. Default password is 0000.
- › **Change codes:** PIN is an abbreviation of Personal Identification Number to prevent use by unauthorized persons. You can change the access codes: Security code, PIN code, PIN2 code, ATMT code.

Connectivity

You can connect between a phone and other devices.

- › **Bluetooth:** This enables wireless connections between electronic devices.
- › **Network:** You can also select a network manually and set a network.

Power save

Choose among the followings, Off/Night only/ Always On, to change the factory set power saving settings.

Reset

You can initialize all factory defaults. You need Security code to activate this function.

Memory status

You can check free space and memory usage of phone, SIM card and external memory (if inserted).

Guidelines for safe and efficient use

Please read these simple guidelines. Not following these guidelines may be dangerous or illegal. Further detailed information is given in this manual.

Warning

- › For your safety, use **ONLY** specified ORIGINAL batteries and chargers.
- › Switch off the phone in any area where required by special regulations, e.g. in a hospital where it may affect medical equipment.
- › Batteries should be disposed off in accordance with relevant legislation.

Product care and maintenance

WARNING! Only use batteries, chargers and accessories approved for use with this particular phone model. The use of any other types may invalidate any approval or warranty applying to the phone, and may be dangerous.

- › Do not disassemble this unit. Take it to a qualified service technician when repair work is required.
- › Repairs under warranty, at LG's option, may include replacement parts or boards that are either new or reconditioned, provided that they have functionality equal to that of the parts being replaced.
- › The unit should be kept away from heat sources such as radiators or cookers.
- › Use a dry cloth to clean the exterior of the unit. (Do not use any solvents.)
- › Do not keep the phone next to credit cards or transport tickets; it can affect the information on the magnetic strips.

Electronic devices

All mobile phones may get interference, which could affect performance.

- › Do not use your mobile phone near medical equipment without requesting permission. Avoid placing the phone over a pacemaker, i.e. in your breast pocket.

Road safety

Check the laws and regulations on the use of mobile phones in the areas when you drive.

- › Do not use a hand-held phone while driving.
- › Use a hands-free kit, if available.
- › Pull off the road and park before making or answering a call if driving conditions so require.

Blasting area

Do not use the phone where blasting is in progress. Observe restrictions, and follow any regulations or rules.

Potentially explosive atmospheres

Do not use the phone at a refueling point. Do not use near fuel or chemicals.

In aircraft

Wireless devices can cause interference in aircraft.

- › Turn off your mobile phone before boarding any aircraft.

Children

Keep the phone in a safe place out of children's reach. It includes small parts which if detached may cause a choking hazard.

Emergency calls

Emergency calls may not be available under all cellular networks. Therefore, you should never depend solely on the phone for emergency calls. Check with your local service provider.

Battery information and care

- › You do not need to completely discharge the battery before recharging. Unlike other battery systems, there is no memory effect that could compromise the battery's performance.
- › Use only LG batteries and chargers. LG chargers are designed to maximize the battery life.
- › Do not disassemble or short-circuit the battery pack.
- › Replace the battery when it no longer provides acceptable performance. The battery pack may be recharged hundreds of times before it needs to be replaced.
- › Do not expose the battery charger to direct sunlight or use it in high humidity, such as the bathroom.
- › Risk of explosion if battery is replaced by an incorrect type.
- › Dispose off used batteries according to the manufacturer's instructions.

Exposure to radio frequency energy

Radio wave exposure and Specific Absorption Rate (SAR) information

This mobile phone model GS205 has been designed to comply with applicable safety requirement for exposure to radio waves. This requirement is based on scientific guidelines that include safety margins designed to ensure safety of all persons, regardless of age and health.

- › The radio wave exposure guidelines employ a unit of measurement known as the Specific Absorption Rate, or SAR. Tests for SAR are conducted using standardised methods with the phone transmitting at its highest certified power level in all used frequency bands.
- › While there may be differences between the SAR levels of various LG phone models, they are all designed to meet the relevant guidelines for exposure to radio waves.
- › The SAR limit recommended by the International Commission on Non-Ionizing Radiation Protection (ICNIRP) is 2W/kg averaged over ten (10) gram of tissue.
- › The highest SAR value for this model phone tested by DASY4 for use at the ear is 0.582 W/kg (10g) and when worn on the body is 0.539 W/kg (10g).
- › SAR data information for residents in countries/regions that have adopted the SAR limit recommended by the Institute of Electrical and Electronics Engineers (IEEE) is 1.6 W/kg averaged over one (1) gram of tissue (for example USA, Canada, Australia and Taiwan).

There are various accessories for your mobile phone. You can select these options according to your personal communication requirements..

Standard Battery




Headset



Travel Adapter

Connect this and the included USB cable. This allows you to charge the battery.



USB cable and CD

You can connect your phone to PC to exchange the data between them.



Note

- › Always use genuine LG accessories. Failure to do this may invalidate your warranty.
- › Accessories may be different in different regions; please check with our regional service company or agent for further enquires.

General



Product name : GS205

System : E-GSM 900 / DCS 1800

Ambient Temperatures

> Max. : +55°C (discharging)
+45°C (charging)

> Min : -10°C

Declaration of Conformity		 LG Electronics
Supplier Details		
Name LG Electronics Inc		
Address LG Electronics Inc, LG Twin Towers 20, Yeouido-dong, Yeongdeungpo-gu, Seoul, Korea 100-721		
Product Details		
Product Name E-GSM 900 / DCS 1800 Dual-band Terminal Equipment		
Model Name GS205		
Trade Name LG		
CE0168		
Applicable Standards Details		
R&TTE Directive 1999/5/EC EN 301 489-01 V1.3.1, EN 301 489-07 V1.3.1, EN 301 489-17 V2.1.1 EN 301 011 V9.3.2 EN 60369:2001, EN62206-1:2006 EN 60909-1:2001 EN500328 V1.7.1		
Supplementary Information		
The conformity to above standards is verified by the following Notified Body(BAF)		
BAF7, Forsyth House-Churchfield Road - Walton-on-Thames Surrey - KT12 2TD , United Kingdom Notified Body Identification Number: 0168		
Declaration		
I hereby declare under our sole responsibility that the product mentioned above to which this declaration relates complies with the above mentioned standards and Directives		Name Insook Hwang, Jr / Director 1. Apr. 2010
LG Electronics Logistics and Services B.V., Velduwschen 16, 1527 AE Almere, The Netherlands		 Signature of representative

PT. LG ELECTRONICS INDONESIA
Kawasan Industri MM2100Blok G
Cikarang Barat, Bekasi, Jawa Barat 17520
INDONESIA

