



GU230

برخی از محتویات این دفترچه راهنما ممکن است بسته به نرم افزار گوشی یا ارائه دهنده خدمات، با گوشی شما متفاوت باشند.

CE 0168

www.lg.com

P/N : MMBB0356518 (1.1)

GU230

Some of the contents in this manual may differ from your phone depending on the software of the phone or your service provider.

CE 0168

www.lg.com

P/N : MMBB0356518 (1.1)



Bluetooth QD ID B015954

راهنمای کاربر - فارسی - GU230

این دفترچه راهنما به شما کمک می کند تلفن همراه خود را بهتر بشناسید. در این منو توضیحات مفید راجع به ویژگی های تلفن در اختیار شما قرار می گیرد.



آشنایی با تلفن همراه



نصب کارت حافظه

درپوش کارت حافظه را باز کرده و یک کارت micro SD وارد کنید در حالی که سطح طلایی رنگ آن رو به پایین باشد. درپوش کارت حافظه را ببندید تا با صدای کلیک بسته شود. برای خارج کردن کارت حافظه همانطور که در شکل نشان داده شده است، کارت را به آرامی فشار دهید.



توجه: کارت حافظه یک وسیله جانبی اختیاری است.

فرمت کردن کارت حافظه

گزینه **منو** را فشار داده و **تنظیمات** را انتخاب کنید.

مدیر حافظه و سپس **حافظه خارجی** را انتخاب کرده و **فرمت کردن** را فشار دهید و کد امنیتی را وارد نمایید.

هشدار: هنگامی که کارت



حافظه را فرمت می کنید، کلیه

اطلاعات موجود روی آن پاک خواهد

شد. اگر نمی خواهید اطلاعات موجود

روی کارت حافظه را از دست بدهید،

ابتدا از آن یک پشتیبان تهیه کنید.

نصب سیم کارت و شارژ کردن باتری

نصب سیم کارت

وقتی در یک شبکه سلولی مشترک می شوید، یک سیم کارت همراه با جزئیات اشتراک از جمله پین، هرگونه خدمات اختیاری موجود و بسیاری موارد دیگر در اختیار شما قرار می گیرد.

مهم!


سیم کارت وارد شده و سطوح تماس آن با هرگونه خراش یا خم شدن به آسانی آسیب می بیند، بنابراین هنگام نگه داشتن کارت در دست، وارد کردن یا خارج کردن آن از تلفن همراه دقت کنید. سیم کارت ها را

دور از دسترس کودکان قرار دهید.

تصاویر

- 1 درب محفظه باتری را بردارید
- 2 باتری را خارج کنید
- 3 سیم را وارد کنید
- 4 باتری را وارد کنید
- 5 درب محفظه باتری را ببندید
- 6 باتری را شارژ کنید





هشدار: وقتی گوشی روشن است، باتری را خارج نکنید، این کار باعث آسیب به تلفن می شود. 

تماس ها


برقراری تماس

1 شماره تلفن را با استفاده از صفحه کلید وارد کنید. برای حذف یک رقم CLR را فشار دهید.


2 برای شروع تماس  را فشار دهید.

3 برای پایان دادن به تماس،  را فشار دهید.

پاسخ دادن به تماس یا رد آن

وقتی تلفن زنگ می زند،  را فشار داده و به تماس پاسخ دهید.

شما می توانید میزان صدا را با فشار دادن کلیدهای جانبی کنترل کنید.

برای رد کردن تماس ورودی،  را فشار دهید یا رد کردن را انتخاب کنید.

نکته! می توانید تنظیمات گوشی خود

را به نحوی تغییر دهید که به تماس های خود به روش های مختلف پاسخ دهید. منو را فشار داده، تنظیمات و سپس تماس را انتخاب کنید. حالت پاسخ گویی را انتخاب کرده و از بین گزینه های کلید ارسال را فشار دهید، باز کردن صفحه کشویی و یک کلید را فشار دهید انتخاب کنید.

نکته! برای وارد کردن + جهت

برقراری تماس بین المللی، 0 را فشار داده و نگه دارید.

برقراری تماس با استفاده از

فهرست مخاطبین

1 از صفحه آماده به کار، نام ها را انتخاب کنید.

2 با استفاده از صفحه کلید، اولین حرف مخاطبی که می خواهید با او تماس بگیرید را وارد کنید. برای مثال، برای نوشتن کلمه **Office**، دکمه مربوطه را 6 بار فشار دهید تا نویسه مورد نظر "O" انتخاب شود.

3 برای شروع تماس، تماس را انتخاب کرده یا  را فشار دهید.

شماره گیری سریع

می توانید یک شماره را به مخاطبی که زیاد با وی تماس می گیرید اختصاص دهید.

مشاهده تاریخچه تماس

تتها در صورتی می توانید گزارش تماس های بی پاسخ، دریافتی و گرفته شده را مشاهده کنید که شبکه از قابلیت شناسایی خط تماس (CLI) در حوزه خدماتی پشتیبانی کند.

تغییر تنظیمات تماس

می توانید منوی مربوط به یک تماس را تنظیم کنید. منو را فشار داده، تنظیمات و سپس تماس را انتخاب کنید.

• انتقال تماس - انتخاب کنید که تماس ها انتقال یابند یا خیر.

• محدودیت تماس - زمان مورد نظر را برای محدودیت تماس ها انتخاب کنید.

• شماره گیری ثابت - فهرست شماره هایی که از تلفن شما شماره گیری می شوند را انتخاب کنید. برای این کار به کد بین 2 از اپراتور نیاز دارید. از گوشی شما فقط می توان با شماره های مندرج در فهرست شماره گیری ثابت تماس گرفت.

• انتظار تماس - زمانی که پشت

خطی دارید به شما اطلاع داده شود. (به ارائه دهنده شبکه شما بستگی دارد).

• رد تماس - فهرست تماس های رد شده را تنظیم کنید.

• ارسال شماره من - انتخاب کنید که آیا هنگام تماس با دیگران شماره شما نمایش داده شود یا خیر. (به ارائه دهنده شبکه شما بستگی دارد).

• شماره گیر مجدد خودکار - روشن یا خاموش را انتخاب کنید.

• حالت پاسخ گویی - انتخاب کنید با هر کلید یا فقط کلید ارسال به تلفن پاسخ داده شود.

• تایمر تماس رایگان - انتخاب کنید تایمر نشان داده شود یا خیر.

• یادآور دقیقه - روشن را انتخاب کنید و در حین تماس بعد از هر دقیقه یک بوق یادآور دقیقه بشنوید.

• حالت پاسخ گویی بلوتوث - هندزفری یا گوشی را تنظیم کنید.

• ذخیره شماره جدید - بله یا خیر را انتخاب کنید.

• تنظیمات بستن درب کشویی - گزینه های پایان تماس یا ادامه تماس را انتخاب کنید.

مخاطبین

جستجوی مخاطب

1 از صفحه آماده به کار، نام ها را انتخاب کنید.

2 با استفاده از صفحه کلید، اولین حرف مخاطبی که می خواهید با او تماس بگیرید را وارد کنید.

3 برای حرکت در بین مخاطبین، از پیکان های بالا و پایین استفاده کنید.

افزودن مخاطب جدید

1 منو را فشار داده، مخاطبین و سپس نام ها را انتخاب کنید. سپس گزینه ها-افزودن مخاطب جدید را فشار دهید.

2 اطلاعات لازم را در قسمت های مربوطه وارد کرده و گزینه ها-انجام شد را انتخاب کنید.

افزودن مخاطب به گروه

می توانید مخاطبین خود را گروه بندی کنید، به عنوان مثال همکاران و اعضای خانواده تان را در گروه های جداگانه ای قرار دهید. گروه های متعددی وجود دارد از جمله خانواده، دوستان، همکاران، همکلاسی ها و اشخاص مهم که از قبل روی گوشی ایجاد شده است.

پیام رسانی

گوشی GU230 حاوی عملکردهایی برای ارسال پیام های متنی و پیام های چندرسانه ای و ایمیل، و همچنین پیام های خدماتی شبکه می باشد.

رسال پیام

- 1 **منو** را فشار داده، **پیام رسانی** و سپس **ایجاد پیام** را انتخاب کنید.
- 2 ویرایشگر پیام جدید باز می شود. ویرایشگر پیام، **پیام متنی** و **پیام های چندرسانه ای** را با هم ترکیب کرده و به صورت یک پیام جدید در می آورد که تغییر وضعیت در بین آن ها بسیار آسان است. تنظیمات پیش فرض ویرایشگر پیام، حالت پیام متنی است.
- 3 پیام خود را وارد کنید.
- 4 **گزینه ها-وارد کردن** را برای افزودن یک تصویر، کلیپ تصویری، کلیپ صوتی، برنامه زمانی، کارت ویزیت، یادداشت، قسمت متن، کارها یا یک الگوی متنی انتخاب کنید.
- 5 **گزینه ها - کلید ارسال** را فشار دهید.

تنظیم ایمیل

- شما می توانید هنگام سفر، از قابلیت های ارسال ایمیل در **GU230** استفاده کنید. تنظیم اشتراک ایمیل **POP3** یا **IMAP4** بسیار آسان و سریع است.
- 1 **منو** را فشار داده، **پیام رسانی** و **تنظیمات پیام** را انتخاب کنید.
 - 2 **ایمیل** و سپس **اشتراک های ایمیل** را انتخاب کنید.
 - 3 **افزودن** را فشار داده و سپس **اشتراک ایمیل** را تنظیم کنید.

وارد کردن متن

می توانید با استفاده از صفحه کلید گوشی، نویسه های حرفی عددی وارد کنید. روش های ورودی متن در گوشی عبارتند از: حالت پیشگوی T9، حالت دستی ورودی الفبا و حالت 123.

توجه: در برخی قسمت ها فقط یک حالت ورودی متن مجاز است (مثلاً شماره تلفن در دفترچه آدرس).

حالت پیشگوی T9

حالت پیشگوی T9 از یک فرهنگ لغت داخلی برای تشخیص لغاتی که می نویسید و بسته به توالی کلیدهایی که در صفحه فشار می دهید استفاده می کند. کافی است کلیدهای عددی مربوط به حرفی که می خواهید وارد کنید را فشار دهید، و فرهنگ لغت به محض اینکه تمام حروف درج شدند، کلمه را شناسایی می کند.

ارسال ایمیل با استفاده از اشتراک

جدید

جهت ارسال/دریافت ایمیل، باید یک اشتراک ایمیل تنظیم کنید.

1 منو را فشار داده، پیام رسانی و سپس ایجاد پیام را انتخاب کنید.

2 ایمیل را انتخاب کنید، یک ایمیل جدید باز می شود.

3 یک موضوع وارد کنید.

4 پیام خود را وارد کنید.

5 گزینه ها را فشار دهید، وارد کردن

را برای افزودن یک تصویر،

کلیپ تصویری، کلیپ صوتی،

کارت ویزیت، برنامه زمانی یا یک

یادداشت انتخاب کنید.

6 ارسال به را فشار داده و یک آدرس

گیرنده وارد کنید یا باز کردن

فهرست مخاطبین، گزینه ها و سپس

وارد کردن مخاطب را انتخاب نمایید

7 برای ارسال ایمیل، ارسال را فشار

دهید.

حالت دستی ورود الفبا

این حالت به شما امکان می دهد حروف را با فشار دادن کلید مربوط به هر حرف وارد کنید. کلید مربوطه را یک بار، دو بار، سه یا چهار بار فشار می دهید تا زمانی که حرف مورد نظر ظاهر شود.

حالت 123

اعداد را با یک بار فشار دادن کلید مربوطه وارد کنید. شما همچنین می توانید در حین ماندن در حالت حرفی، اعداد را نیز با فشار دادن و نگه داشتن دکمه های مورد نظر وارد کنید.

پوشه های پیام

منو را فشار دهید، پیام رسانی را انتخاب کنید. ساختار پوشه ای مورد استفاده در گوشی GU230 نسبتاً واضح و قابل فهم است. ایجاد پیام - به شما امکان می دهد پیام های جدید ایجاد کنید.

صندوق دریافت - همه پیام هایی که دریافت می کنید در صندوق دریافت شما قرار می گیرد.

صندوق پستی من - شامل همه پیام های ایمیل شما است.

پیش نویس ها - اگر وقت کافی برای تکمیل یک پیام نداشته باشید، آنچه نوشته اید را می توانید در این پوشه ذخیره کنید.

صندوق ارسال - این یک پوشه ذخیره سازی موقت است که در آن پیام های در حال ارسال یا پیام هایی که ارسال آن ها ناموفق بوده است ذخیره می شوند.

موارد ارسال شده - کلیه پیام هایی که ارسال می کنید در پوشه پیام های ارسالی قرار می گیرد.

موارد ذخیره شده- می توانید به پیام های ذخیره شده، الگوهای متنی و الگوهای چندرسانه ای دسترسی داشته باشید

نمادهای احساسی - فهرستی از نمادهای احساسی که از قبل برای پاسخ سریع نوشته شده است.

رسانه

موسیقی

GU230 مجهز به یک پخش کننده موسیقی داخلی است که می توانید همه موسیقی های دلخواه خود را در تلفن پخش کنید.

پخش آهنگ

- 1 منو را فشار داده و رسانه و سپس موسیقی را انتخاب کنید.
- 2 همه آهنگ ها را انتخاب کرده و سپس ترانه مورد نظر برای پخش را انتخاب کنید.
- 3 برای مکث ترانه، || را انتخاب کنید.
- 4 برای رفتن به ترانه بعدی، ►► را انتخاب کنید.

5 برای رفتن به ترانه قبلی، ◀◀ را انتخاب کنید.

6 برگشت را برای توقف موسیقی و برگشت به منوی پخش کننده موسیقی انتخاب کنید.

ایجاد فهرست پخش

می توانید با انتخاب آهنگ هایی از پوشه همه آهنگ ها فهرست های پخش مخصوص به خود ایجاد کنید.

1 منو را فشار داده و رسانه را انتخاب کنید.

2 موسیقی و سپس لیست پخش را انتخاب کنید.


3 ابتدا گزینه ها را فشار داده و لیست پخش جدید را انتخاب کنید، نام لیست پخش را وارد کرده و ذخیره را فشار دهید.

4 پوشه همه آهنگ ها نمایش داده خواهد شد. همه ترانه هایی که می خواهید در لیست پخش قرار بگیرند را با رفتن به آن ها و انتخاب برگزینید.

5 برای ذخیره لیست پخش، انجام شد را انتخاب کنید.


دوربین

گرفتن عکس فوری

- 1 منو را انتخاب کرده و سپس رسانه را انتخاب کنید. برای باز کردن نمایاب، دوربین را انتخاب کنید.
- 2 در حالی که گوشی را نگه داشته اید، لنز دوربین را به سمت سوژه مورد نظر بگیرید.
- 3 تلفن را طوری نگه دارید که سوژه مورد نظر عکس را در کادر داشته باشید.
- 4 برای گرفتن عکس، کلید  وسط را فشار دهید.

دوربین فیلمبرداری

فیلمبرداری فوری

- 1 در صفحه آماده به کار، منو و سپس رسانه را انتخاب کنید.
- 2 فیلم را انتخاب کنید.
- 3 لنز دوربین را به سمت سوژه مورد نظر بگیرید.
- 4 برای شروع ضبط،  را فشار دهید.
- 5

REC در گوشه پایین نمایاب ظاهر می شود و یک تایمر که مدت زمان فیلم را نشان می دهد.

- 6 برای متوقف کردن فیلم، توقف را انتخاب کنید.

رادیو FM

استفاده از رادیو FM

گوشی LG GU230 شما دارای یک رادیو FM است که می توانید از طریق آن به برنامه های رادیویی دلخواه خود گوش کنید.

گوش دادن به رادیو

- 1 منو را فشار داده و رسانه و سپس رادیو FM را انتخاب نمایید.
- 2 شماره کانال ایستگاه رادیویی مورد نظر خود را برای گوش دادن انتخاب کنید.

ضبط از رادیو

ضبط صوت

از ضبط صوت برای ضبط یادداشت های صوتی یا صداهای دیگر استفاده کنید.

گالری

می توانید هر نوع فایل رسانه ای را در حافظه گوشی ذخیره کنید تا به تصاویر، صداها، فیلم ها و بازی های خود دسترسی آسان و سریع داشته باشید. همچنین می توانید فایل های خود را روی یک کارت حافظه ذخیره کنید. مزیت استفاده از کارت حافظه این است که می توانید فضای حافظه خود گوشی را خالی نگه دارید. همه فایل های چندرسانه ای در گالری ذخیره می شوند. برای باز کردن لیست پوشه ها، منو و سپس گالری را انتخاب کنید.

1 در حالی که به رادیو گوش

می دهید، کلید وسط را فشار دهید.

2 زمان ضبط در تلفن شما نمایش داده

می شود. برای توقف ضبط،

وقتی ضبط انجام شد، محتوای ضبط

شده به صورت فایل mp3 در

گالری ذخیره می شود.

3 وقتی ضبط انجام شد، گزینه را

انتخاب کرده و سپس از بین گزینه

های پخش، حذف، ویرایش صدا،

استفاده به عنوان، تغییر نام فایل،

اطلاعات یا ارسال از طریق انتخاب

کنید.

توجه: اگر در ناحیه ای با گیرندگی

رادیویی ضعیف باشید، ممکن است

در گوش دادن به رادیو با مشکل

مواجه شوید.

بنابراین توصیه می کنیم، برای

گیرندگی رادیوی مناسب، میکروفن را

در محل اتصال هندزفری وارد کنید و

به رادیو گوش دهید.

تصاویر من

تصاویر حاوی پوشه ای از تصاویر پیش فرض تلفن، تصاویری که خود در تلفن بارگیری کرده و با دوربین تلفن گرفته اید می باشد.

صداها من

پوشه صداها حاوی صداهای پیش فرض، صداهای ضبط شده شما، موارد ضبط شده از رادیو و فایل های صوتی بارگیری شده می باشد. در اینجا می توانید صداها را مدیریت و ارسال کنید، یا آنها را به عنوان آهنگ زنگ تنظیم نمایید.

فیلم های من

پوشه فیلم ها حاوی فیلم های بارگیری شده و نیز فیلم هایی است که با دوربین گوشی گرفته اید.

موارد دیگر

از منوی موارد دیگر می توانید فایل هایی را که در پوشه تصاویر، صداها یا فیلم ها ذخیره نشده اند را مشاهده کنید.

بازی ها و برنامه های من

گوشی GU230 شما از قبل با بازی هایی ارائه شده است تا با استفاده از آن ها اوقات فراغت خود را پر کنید. چنانچه بازی یا برنامه اضافی بارگیری کنید، آنها در این پوشه ذخیره خواهند شد.

کارت حافظه من

اگر کارت حافظه را وارد کرده باشید، کارت حافظه به صورت یک پوشه در گالری نشان داده می شود.

سازمان دهنده

استفاده از تقویم

با ورود به این منو، یک تقویم ظاهر می شود. یک مکان نمای مربع شکل در تاریخ فعلی قرار می گیرد. می توانید با استفاده از کلیدهای پیمایش، مکان نما را به تاریخ دیگری انتقال دهید.

افزودن یک مورد به لیست کارها
کارهایی را برای انجام، مشاهده، و پیرایش و اضافه کنید.

تنظیم زنگ هشدار

می توانید تا 5 ساعت زنگ دار تنظیم کنید که رأس ساعتی خاص به صدا درآیند.

استفاده از ماشین حساب

ماشین حساب چهار عملکرد اصلی ریاضی

شامل: جمع،

تفریق، ضرب، تقسیم و برنامه های کاربردی علمی را انجام می دهد.

استفاده از زمان سنج

این گزینه به شما امکان می دهد از عملکرد زمان سنج استفاده کنید.

تبدیل واحد

این گزینه، هر نوع اندازه گیری را به واحدی که می خواهید تبدیل می کند.

افزودن یک شهر به ساعت جهانی

می توانید شهر مورد نظر خود را به لیست ساعت جهانی اضافه کنید.

همچنین می توانید زمان فعلی گرینویچ (GMT) و شهرهای مهم جهان را بررسی کنید.

برو به

به شما کمک می کند به منوی مورد

جستجوی خود بروید. می توانید این

مورد را به عنوان "برو به" تنظیم کنید.

انتقال اعتبار

برنامه انتقال اعتبار فقط در کشورهای

خاصی فعال است. این برنامه روشی

ساده و امن را برای انتقال اعتبار

تماس به یک مخاطب (مخاطب جدید

یا مخاطب از دفترچه تلفن) ارائه

می دهد.

در این برنامه گزینه های زیر وجود دارد.

• مخاطبین

این گزینه به کاربر امکان می دهد مخاطب را از دفترچه تلفن گوشی انتخاب کرده و اعتبار تماس را به وی انتقال دهد.

• کد امنیتی روشن/خاموش

کاربر می تواند با این گزینه، استفاده از برنامه انتقال اعتبار را محافظت کند. اگر کد امنیتی فعال باشد (روشن)، برای امنیت بیشتر، قبل از انتقال اعتبار تماس، کد امنیتی درخواست می شود.

وب

دسترسی به شبکه

مرورگر WAP را باز کرده و در تنظیمات وب، به صفحه اصلی مشخصه فعال شده دسترسی پیدا کنید. همچنین می توانید به صورت دستی، یک آدرس URL وارد کرده و صفحه WAP مربوطه را باز کنید.

1 منو را فشار داده و وب را انتخاب کنید.

2 برای دسترسی مستقیم به صفحه اصلی مرورگر، اصلی را انتخاب کنید. یا می توانید، برو به آدرس را انتخاب کرده و URL مورد نظر را تایپ کنید.

قابلیت اتصال

تغییر تنظیمات اتصال

حالت اتصال USB.

1 ذخیره انبوه: این گزینه را انتخاب کرده و گوشی را به رایانه وصل کنید و فایل های مورد نظر را با استفاده از قابلیت کشیدن و رها کردن در پوشه دستگاه جداشدنی GU230 بریزید.

2 PC Suite: این گزینه را

انتخاب کرده و گوشی را در حالت PC Sync به رایانه وصل کنید.

3 همیشه سؤال شود: با انتخاب این گزینه، می توانید هر بار که گوشی به رایانه وصل می شود، حالت را انتخاب کنید.

توجه: برای استفاده از عملکرد ذخیره انبوه USB، باید یک کارت حافظه خارجی در تلفن وارد کنید.

تغییر تنظیمات بلوتوث

1 منو را فشار داده و تنظیمات -

اتصال را انتخاب کنید. گزینه بلوتوث را انتخاب کنید.

2 گزینه تنظیمات بلوتوث را انتخاب کنید.

تغییرات را بر روی گزینه های زیر انجام دهید:

• قابل رؤیت بودن من - انتخاب کنید

که آیا دستگاه شما برای دیگران نمایش داده شود یا مخفی گردد.

• نام تلفن من - نامی را برای گوشی LG GU230 وارد کنید.

• خدمات پشتیبانی شده - موارد تحت پشتیبانی را نشان می دهد.

• آدرس من - آدرس بلوتوث خود را نمایش دهید.

ارتباط با دستگاه بلوتوث دیگر

با مرتبط کردن GU230 و دستگاه دیگر، هر بار که از طریق بلوتوث به گوشی دیگر وصل می شوید، تلفن شما یک رمز ورود به طور پیش فرض ایجاد می کند.

1 بررسی کنید که بلوتوث گوشی

روشن بوده و قابل رویت باشد. می توانید تنظیمات مربوط به قابل رویت

بودن خود را در منوی تنظیمات

بلوتوث با انتخاب قابل رویت بودن

من و سپس قابل رویت تغییر دهید.

2 گزینه دستگاه فعال را از منوی

بلوتوث انتخاب کنید.

3 گوشی GU230 دستگاه ها را

جستجو می کند. وقتی جستجو کامل

شد، افزودن و نوسازی در صفحه

ظاهر می شود.

4 دستگاه مورد نظر را برای ارتباط

انتخاب کنید، افزودن را فشار داده

و کد ورود را وارد کنید سپس کلید

تأیید را انتخاب نمایید. دستگاه مورد

نظر را برای ارتباط انتخاب کنید،

و با هر بار اتصال، گوشی به طور

پیش فرض یک رمز ورود ایجاد

می کند.

5 تلفن شما به دستگاه دیگر متصل

می شود که برای آن باید کد ورود

را وارد نمایید.

دستگاه مورد نظر را برای ارتباط

انتخاب کنید، و با هر بار اتصال،

گوشی به طور پیش فرض یک رمز

ورود ایجاد می کند.

6 اکنون اتصال بلوتوث حفاظت شده با

کد ورود آماده است.

تنظیمات

تغییر تاریخ و زمان

عملکردهای مربوط به تاریخ و زمان را تنظیم کنید.

تغییر مشخصه ها

شما می توانید تنظیمات هر مشخصه را به دلخواه تغییر دهید.

1 مشخصه مورد نظر را انتخاب کرده و از منوی گزینه ها، ویرایش را انتخاب کنید.

2 برای مشخصه های بیصدا و فقط لرزشی، می توانید این گزینه را فعال کنید.

استفاده از حالت پرواز

از این عملکرد برای رفتن به حالت پرواز انتخاب - **بله** استفاده کنید. با فعال شدن حالت پرواز، دیگر نمی توانید تماس برقرار کنید، به اینترنت متصل شوید یا پیام ارسال کنید.

نصب LG PC Suite در رایانه

1 به سایت www.lg.com رفته و ابتدا Middle East (خاورمیانه) و سپس کشور خود را انتخاب نمایید.

2 منوی Products (محصولات) را انتخاب کرده و سپس Manual & Software (راهنما و نرم افزار) را انتخاب کنید، روی Go to

Manual & S/W download section (برو به بخش بارگیری راهنما و نرم افزار) کلیک کنید.

Yes (بله) را کلیک کرده و LG PC Suite installer (نصب کننده LG PC Suite) ظاهر می شود. (, Windows XP, Windows Media Player

و بیشتر).

3 زبانی که مایل هستید نصب کننده با آن اجرا گردد را انتخاب و روی OK (تأیید) کلیک کنید.

4 مراحل نصب را برای تکمیل LG PC Suite Installer wizard (برنامه جادویی نصب کننده LG PC Suite) دنبال کنید.

5 وقتی نصب کامل شد، نماد LG PC Suite در دسک تاپ ظاهر می شود.

تغییر تنظیمات صفحه نمایش

تنظیمات نمایشگر تلفن را تغییر دهید.

حاوی اطلاعات راجع به IMEI گوشی به سرقت رفته، محل و شماره فردی که در حال حاضر از گوشی استفاده می کند خواهد بود (این اطلاعات از طریق پیام پخش سلولی مشخص می شوند).

تغییر تنظیمات امنیتی

تنظیمات امنیتی خود را تغییر دهید تا بتوانید از گوشی GU230 و اطلاعات مهم آن محافظت کنید.

بازنشانی تلفن

برای بازنشانی همه تنظیمات به تنظیمات کارخانه، بازبازی تنظیمات کارخانه را انتخاب کنید. برای فعال کردن این ویژگی، کد امنیتی لازم است.

مشاهده وضعیت حافظه

می توانید از مدیر حافظه برای تعیین نحوه استفاده از هر یک از حافظه ها و نیز آگاهی از فضای خالی موجود آن ها استفاده کنید: معمول، رزرو شده، سیم کارت و حافظه خارجی، همچنین می توانید با وارد کردن کارت حافظه، محل ذخیره اولیه را نیز تنظیم کنید.

- درخواست کد پین - انتخاب کنید که هر بار که گوشی روشن می شود، کد پین درخواست شود.
- قفل گوشی - یک کد امنیتی را برای قفل کردن تلفن انتخاب کنید: هنگام روشن شدن، هنگام تعویض سیم یا فوراً.
- تغییر کدها - کد امنیتی، کد پین، کد پین 2 و کد ATMT را تغییر دهید.
- سیستم ردیابی ضدسرقت موبایل - هنگامی که گوشی به سرقت می رود، پیامی را برای شماره هایی که توسط صاحب واقعی گوشی از قبل تنظیم شده است ارسال می کند. برای فعال کردن ویژگی ATMT، باید ATMT را روی روشن تنظیم کرده و تنظیمات ATMT را با نام، شماره اولیه و ثانویه پیگیری نمایید. کد ATMT به طور پیش فرض "0000" است. ATMT SMS

دستورالعمل های استفاده ایمن و موثر

- اگرچه ممکن است تفاوت هایی بین سطوح SAR در مدل های مختلف گوشی های LG وجود داشته باشد، اما همه مدل ها به گونه ای طراحی شده اند که دستورالعمل های مربوط به قرار گرفتن در معرض امواج رادیویی در آنها رعایت شده باشد.
- میزان SAR توصیه شده توسط کمیسیون بین المللی محافظت در برابر تشعشعات غیر یونیزه (ICNIRP)، برابر 2 وات بر کیلوگرم به طور متوسط در 10 گرم بافت بدن است.
- بالاترین مقدار SAR اندازه گیری شده توسط DASY4 برای این دستگاه هنگام استفاده کنار گوش 0.716 وات بر کیلوگرم (10 گرم) است و برای استفاده روی بدن 1.06 وات بر کیلوگرم (10 گرم) می باشد.
- اطلاعات داده ای SAR برای ساکنین کشورها/نواحی که میزان SAR توصیه شده توسط مؤسسه مهندسی برق و الکترونیک (IEEE) را پذیرفته اند، 1.6 وات بر کیلوگرم در 1 گرم بافت بدن است.
- **قرار گرفتن در معرض انرژی فرکانس رادیویی**
اطلاعات قرار گرفتن در معرض امواج رادیویی و ضریب جذب ویژه (SAR)
این گوشی تلفن همراه مدل GU230 به گونه ای طراحی شده است که تابع مقررات و شرایط لازم مربوط به قرار گرفتن در معرض امواج رادیویی باشد.
این شرایط لازم مبتنی بر دستورالعمل های علمی است از جمله استفاده از لبه های ایمنی که به گونه ای طراحی شده اند که ایمنی کلیه افراد، صرفنظر از سن و وضع سلامتی آنها، را تضمین می کنند.
- دستورالعمل های مربوط به قرار گرفتن در معرض امواج رادیویی از یک واحد اندازه گیری مخصوص تحت عنوان "ضریب جذب ویژه" یا SAR، استفاده می کنند. تست های SAR با استفاده از روش های استاندارد، و در حالی که گوشی در بالاترین میزان نیروی تابید شده در کلیه باندهای فرکانس قرار داشته، انجام گرفته است.

دستورالعمل های استفاده ایمن و موثر (ادامه)

مراقبت و نگهداری از دستگاه

بزشکی حساس تأثیر بگذارد.

• هنگامی که باتری شارژ می شود، گوشی را در دست نگه ندارید. این کار می تواند باعث برق گرفتگی شده و شدیداً به تلفن آسیب برساند.

• از شارژ کردن گوشی در کنار مواد قابل اشتعال پرهیز کنید، چون ممکن است گوشی داغ شده و باعث آتش سوزی شود.

• از پارچه خشک برای تمیز کردن سطوح خارجی دستگاه استفاده کنید (از محلولهای پاک کننده مانند بنزین، تینر یا الکل استفاده نکنید).

• گوشی را هنگام شارژ روی اثاثیه نرم قرار ندهید.


• گوشی باید هنگام شارژ از تهویه کافی برخوردار باشد.

• از قرار دادن گوشی در معرض دود یا گرد و غبار غلیظ خودداری کنید.

• گوشی را در مجاورت کارت های اعتباری یا بلیط های حمل و نقل قرار ندهید. این کار ممکن است

روی اطلاعات موجود در نوارهای مغناطیسی تأثیر بگذارد.

• با وسایل نوک تیز روی صفحه تلفن ضربه نزنید، این کار به تلفن آسیب می رساند.

 **هشدار:** فقط از باتری ها، شارژرها و تجهیزات جانبی که برای استفاده با این مدل خاص توصیه شده اند استفاده کنید. استفاده از سایر انواع تجهیزات، به غیر از انواع توصیه شده، ممکن است باعث باطل شدن ضمانت نامه شده و خطر آفرین باشد.

• از باز کردن این دستگاه اکیداً خودداری کنید. چنانچه گوشی نیاز به تعمیر داشته باشد، فقط به تکنسین های مجاز مراجعه کنید.

• گوشی را دور از وسایل برقی مانند تلویزیون، رادیو، و رایانه قرار دهید.

• دستگاه باید دور از منابع حرارتی مانند بخاری، اجاق و امثال آن نگه داری شود.

• مراقب باشید گوشی نیافتد.

• گوشی را در معرض لرزش یا تکان های شدید قرار ندهید.

• در مکان هایی که قوانین ویژه ای ایجاب می کند که تلفن همراه خود را خاموش نگه دارید، حتماً گوشی را خاموش کنید. مثلاً، از کاربرد تلفن همراه در بیمارستان خودداری کنید، وگرنه ممکن است روی تجهیزات

- از قرار دادن گوشی در معرض مایعات یا رطوبت خودداری کنید.
- از لوازم جانبی مانند هدفون با احتیاط استفاده کنید. بی دلیل به آنتن تلفن دست نزنید.
- همه حواس خود را به رانندگی بدهید.
- در صورت امکان، از یک کیت هندزفری استفاده کنید.
- چنانچه شرایط رانندگی ایجاب کند، قبل از تماس گرفتن یا پاسخ دادن به یک تماس در محل امنی پارک کنید.
- انرژی فرکانس رادیویی ممکن است بر برخی از سیستم های الکترونیک وسیله نقلیه شما مانند استریوهای خودرو و تجهیزات ایمنی آن تأثیر بگذارد.

استفاده بهینه از گوشی

ابزارهای الکترونیک

- بدون اجازه از مسئولین مربوطه، از تلفن همراه در مجاورت تجهیزات پزشکی استفاده نکنید. از قرار دادن تلفن همراه خود روی مرکز تحریکی قلب، یعنی در جیب جلوی پیراهن، خودداری کنید.
- برخی از وسایل کمک شنوایی ممکن است در اثر مجاورت با تلفن های همراه دچار اختلال گردند.
- تداخل جزئی ممکن است روی تلویزیون، رادیو، رایانه ها و غیره تأثیر بگذارد.
- اگر هنگام حرکت به موسیقی گوش می دهید، دقت کنید که صدا زیاد بلند نباشد تا بتوانید متوجه محیط اطراف خود نیز باشید. این نکته در کنار جاده ها و خیابان ها بسیار ضروری است.
- در صورتی که خودرو شما مجهز به کیسه هوا است، با تجهیزات نصب شده یا بی سیم قابل حمل، مانعی بر سر راه آن قرار ندهید. زیرا ممکن است به دلیل عمل نکردن و یا عملکرد نادرست، آسیب های جدی ایجاد کند.

ایمنی جاده

- هنگام رانندگی قوانین و مقررات مربوط به استفاده از تلفن همراه در نواحی مختلف را رعایت کنید.
- از به کار بردن گوشی های دستی در حین رانندگی خودداری کنید.

دستورالعمل های استفاده ایمن و موثر (ادامه)

- صدرا را آن قدر زیاد نکنید که به شنوایی شما آسیب وارد کند.
- از حمل یا انبار کردن گازها یا مایعات قابل اشتعال یا مواد منفجره در قسمتی از وسیله نقلیه که گوشی تلفن همراه یا لوازم جانبی آن قرار دارد خودداری کنید.

در هواپیما

دستگاه های بی سیم می توانند اختلالاتی را در سیستم های هواپیما ایجاد کنند.

- قبل از سوار شدن به هواپیما، تلفن همراه خود را خاموش کنید.
- هنگامی که در هواپیما هستید بدون کسب اجازه از کادر پرواز، از تلفن استفاده نکنید.

کودکان

تلفن را در مکانی امن دور از دسترس کودکان خردسال قرار بدهید.

در تلفن قطعات کوچکی وجود دارد که در صورت جدا شدن ممکن است توسط کودکان بلعیده شده و باعث خفگی شود.

تماس های اضطراری

ممکن است امکان برقراری تماس های اضطراری در همه شبکه های تلفن همراه موجود نباشد. بنابراین، هرگز نباید در خصوص تماس های اضطراری فقط به تلفن همراه خود اتکا کنید. برای

اگر برای مدتی طولانی در معرض صدای بلند قرار بگیرید، ممکن است شنوایی شما آسیب ببیند. بنابراین توصیه می کنیم از روشن یا خاموش کردن گوشی در کنار گوش خود اجتناب کنید. همچنین توصیه می کنیم میزان صدای موسیقی و نیز تماس ها به در یک سطح مناسب و منطقی تنظیم شود.

ناحیه انفجار

از کاربرد تلفن همراه در محل هایی که عملیات انفجار در حال انجام است خودداری کنید. محدودیت ها را رعایت کرده و از کلیه قوانین و مقررات پیروی کنید.

محیط هایی که احتمال انفجار در آنها وجود دارد

- از به کار بردن تلفن همراه در محل های سوخت گیری خودداری کنید.
- از دستگاه در مجاورت مواد سوختی یا شیمیایی استفاده نکنید.

اطلاعات بیشتر با شبکه مخابراتی خود تماس بگیرید.

اطلاعات باتری و مراقبت از آن

- لازم نیست شارژ باتری کاملاً خالی شود تا آن را مجدداً شارژ کنید.
- برخلاف سایر سیستم های باتری، هیچ تأثیر حافظه ای وجود ندارد که بتواند به عملکرد باتری صدمه وارد کند.
- فقط از باتری ها و شارژرهای LG استفاده کنید. شارژرهای LG به گونه ای طراحی شده اند که عمر باتری را به حداکثر برسانند.
- از باز کردن یا ایجاد مدار اتصال کوتاه در باتری خودداری کنید.
- سطوح اتصال فلزی باتری را تمیز نگه دارید.
- زمانی که دیگر باتری عملکرد مطلوبی ندارد، آن را تعویض کنید.
- باتری را می توان صدها بار شارژ کرد تا زمانی که نیاز به تعویض داشته باشد.
- اگر باتری برای مدت زیادی مورد استفاده قرار نگرفته باشد، آن را مجدداً شارژ کنید تا عمر مفید آن افزایش یابد.
- از قرار دادن باتری در معرض نور مستقیم خورشید و یا استفاده از آن در محیط های بسیار مرطوب مانند حمام و امثال آن خودداری کنید.
- باتری را در مکان های بسیار گرم یا سرد رها نکنید، این کار ممکن است بر عملکرد باتری تأثیر نامطلوب داشته باشد.
- تعویض باتری گوشی با باتری نامناسب می تواند خطر انفجار گوشی را در پی داشته باشد.
- باتری های مستعمل را طبق دستورالعمل های ارائه شده توسط کارخانه سازنده دور بیندازید. لطفاً در صورت امکان آنها را بازیافت نمایید. آنها را همراه با زباله های خانگی دور بیندازید.
- اگر لازم است باتری را تعویض کنید، برای کمک آن را به نزدیکترین مرکز فروش یا مرکز خدمات مجاز LG Electronics ببرید.
- همیشه بعد از شارژ شدن کامل تلفن، به منظور صرفه جویی در مصرف نیروی شارژر، آن را از پریز بکشید.
- طول عمر واقعی باتری به پیکربندی شبکه، تنظیمات محصول، الگوهای استفاده، باتری و شرایط محیطی دارد.

لوازم جانبی

لوازم جانبی مختلفی برای گوشی تلفن همراه شما موجود است. این لوازم در زیر شرح داده شده اند.

باتری



- کابل داده ها
- راهنمای کاربر

شارژر



- هدست استریو



توجه

- همیشه فقط از لوازم جانبی اصل LG استفاده کنید. عدم رعایت این اصل مهم ممکن است ضمانت نامه را از درجه اعتبار ساقط کند.
- لوازم جانبی ممکن است در نواحی مختلف متفاوت باشد. برای کسب اطلاعات بیشتر، لطفاً به شرکت یا نمایندگی خدمات ما در محل خود مراجعه کنید.

اطلاعات فنی

عمومی

نام محصول: GU230

سیستم: GSM 850 / E-GSM 900

DCS 1800 / PCS 1900

دماهای محیط

حداکثر: +55 درجه سانتی گراد (دشارژ)

+45 درجه سانتی گراد (شارژ)

حداقل: -10 درجه سانتی گراد

Declaration of Conformity



Suppliers Details

Name

LG Electronics Inc

Address

LG Electronics Inc. LG Twin Towers 20,
Yeouido-dong, Yeongdeungpo-gu, Seoul, Korea 150-721

Product Details

Product Name

GSM 850 / E-GSM 900 / DCS 1800 / PCS 1900 Quad band Terminal Equipment

Model Name

GU230

Trade Name

LG

CE 0168

Applicable Standards Details

R&TTE Directive 1999/5/EC

EN 301 489-01 V1.6.1, EN 301 489-07 V1.3.1, EN 301 489-17 V1.2.1
EN 301 511 V9.0.2
EN 50360:2001, EN62209-1:2006
EN 60950-1:2001
EN300328 V1.7.1

Supplementary Information

The conformity to above standards is verified by the following Notified Body(BABT)

BABT, Forsyth House-Churchfield Road - Walton-on-ThamesSurrey - KT12 2TD , United Kingdom
Notified Body Identification Number : 0168

Declaration

I hereby declare under our sole responsibility that the product mentioned above to which this declaration relates complies with the above mentioned standards and Directives

European Standard Center
LG Electronics Logistics and Services B.V.
Veluwezoom 15, 1327 AE Almere, The Netherlands
Tel : +31 - 36- 547 - 8940, Fax : +31 - 36 - 547 - 8794
e-mail : jacob @ lge.com

Name

Issued Date

Seung Hyoum, Ji / Director 01. Oct. 2009



Signature of representative

GU230 User Guide — English

This guide will help you understand your new mobile phone. It will provide you with useful explanations of features on your phone.



Getting to Know Your Phone



Installing a Memory Card

Lift the memory card cover and insert a microSD card with the gold contact area facing downward. Close the memory card cover so that it clicks shut.

To remove the memory card, gently push it as shown in the diagram.



Note: A memory card is an optional accessory.

Formatting the Memory Card

Press **Menu** and select **Settings**.

Choose **Memory manager**, select **External memory**, press **Format**, and then insert the security code.

⚠ WARNING: When you format your memory card, all the content will be wiped. If you do not want to lose the data on your memory card, back it up first.

Installing the SIM Card and Charging the Battery

Installing the SIM Card

When you subscribe to a cellular network, you are provided with a plug-in SIM card loaded with your subscription details, such as your PIN, any optional services available and many others.

Important!

› The plug-in SIM card can be easily damaged by scratches

or bending, so be careful when handling, inserting or removing the card. Keep all SIM cards out of the reach of small children.

Illustrations



- 1 Open the battery cover
- 2 Remove the battery
- 3 Insert your SIM
- 4 Insert your battery
- 5 Close the battery cover
- 6 Charge your battery



WARNING: Do not remove the battery when the phone is switched on, as this may damage the phone.


Calls

Making a Call


- 1 Key in the number using the keypad. To delete a digit, press **CLR**.
- 2 Press  to initiate the call.
- 3 To end the call, press .

TIP! To enter + when making an international call, press and hold **0**.


Making a Call from Your Contacts

- 1 Select **Names** from the **Standby** screen.
- 2 Using the keypad, enter the first letter of the contact you want to call. For example, for **Office**, press "6" three times to select the first character, "O"
- 3 Select **Call** or press  to initiate the call.

Answering and Rejecting a Call

When your phone rings, press  to answer the call.

You can control the volume by pressing the Up and Down Navigation keys.

Press  or select **Reject** to reject the incoming call.

TIP! You can change the settings on your phone to answer your calls in different ways. Press **Menu**, select **Settings** and choose **Call**. Select **Answer mode** and choose from **Press send key**, **Slide up** and **Press any key**.

Speed Dialing

You can assign a speed dial number to a contact you call frequently.

Viewing your Call History

You can only check the log of missed, received and dialed calls if the network supports Calling Line Identification (CLI) within the service area.

Changing the call settings

You can set call-specific functions. Press **Menu**, select **Settings** and choose **Call**.

- **Call divert** - Choose whether to divert your calls.
- **Call barring** - Select when you would like calls to be barred.
- **Fixed dial numbers** - Choose a list of numbers that can be called from your phone. You will need your PIN2 code from your operator. Only numbers included in the fixed dial list can be called from your phone.
- **Call waiting** - Be alerted when you have a call waiting. This depends on your network provider.
- **Call reject** - Set the rejected call list.
- **Send my number** - Choose whether your number will be displayed when you call someone. This depends on your network provider.
- **Auto redial** - Choose **On** or **Off**.
- **Answer mode** - Choose whether to answer the phone using Any key, Send key only or Slide up.
- **Free call timer** - Choose whether or not to display the call time.
- **Minute minder** - Select **On** to hear a tone every minute during a call.
- **BT answer mode** - Set to Hands-free or Handset.

- **Save new number** - Choose **Yes** or **No**.
- **Slide close setting** - Choose **End call** or **Continue call**.

Contacts

Searching for a Contact

- 1 Select **Names** from the **standby screen**.
- 2 Using the keypad, enter the first letter of the contact you want to call.
- 3 To scroll through the contacts, use the up and down arrows.

Adding a New Contact

- 1 Press **Menu**, then select **Contacts** and choose **Names**. Then press **Options** - Add new contact.
- 2 Enter all the information you have in the fields provided and select **Options-Done**.

Adding a Contact to a Group

You can save your contacts in groups; for example, to keep your work colleagues and family separate. There are a number of groups including **Family, Friends, Colleagues, School** and **VIP** already set up on the phone.

Messaging

Your GU230 includes text messaging, multimedia messaging and E-mail functions, and can also receive network service messages.

Sending a Message

- 1 Press **Menu**, select **Messaging** and choose **Create message**.
- 2 A new message editor will open. The message editor combines **Text message** and **Multimedia messages** into one intuitive and easy-to-switch-between editor. The default setting for the message editor is text messages.
- 3 Enter your message.
- 4 Choose **Options - Insert** to add an **Image**, **Video clip**, **Sound clip**, **Schedule**, **Business card**, **Note**, **Text field**, **To-do** or **Text template**.
- 5 Press **Options - Send**.

Setting up Your E-mail

You can stay in touch on the move using email on your GU230. It's quick and simple to set up a POP3 or IMAP4 email account.

- 1 Press **Menu**, select **Messaging**, and choose **Message Settings**.
- 2 Select **E-mail** then **E-mail accounts**.
- 3 Press **Add** then set the **E-mail account**.

Sending an E-mail Using your New Account

To send/receive an email, you should set up an email account.

- 1 Select **Menu**, select **Messaging** and choose **Create message**.
- 2 Choose **E-mail** and a new email will open.
- 3 Enter a subject.
- 4 Enter your message.
- 5 Press Options and select Insert to add an **Image**, **Video Clip**, **Sound Clip**, **Business card**, **Schedule** or **Note**.
- 6 Press **Send** to and enter the recipient's address, or press **Options** and select **Insert - Contact Details to open your contacts list**.
- 7 Press **Send** and your email will be sent.

Entering Text

You can enter alphanumeric characters using the phone's keypad. The following text input methods are available on the phone: T9 predictive mode, ABC manual mode and 123 mode.

Note: Some fields may allow only one text input mode (e.g. telephone numbers in the address book fields).

T9 Predictive Mode

T9 predictive mode uses a built-in dictionary to recognize the words you are writing based on the key sequences you press. Simply press the number key associated with the letter you want to enter, and the dictionary will recognize the word once all the letters are entered.

ABC Manual Mode

This mode allows you to enter letters by pressing the key labeled with the required letter once, twice, three or four times until the letter is displayed.

123 Mode

Type numbers using one keystroke per number. You can also add numbers while remaining in letter modes by pressing and holding the desired key.

Message Folders

Press **Menu** and select **Messaging**. The folder structure used on your GU230 is fairly self-explanatory.

Create message - Allows you to create new messages.

Inbox - All the messages you receive are placed in your Inbox.

My mailbox - Contains all your email messages.

Drafts - If you don't have time to finish writing a message, you can save what you have done so far here.

Outbox - This is a temporary storage folder while messages are being sent. It also stores any messages that have failed to send.

Sent items - All the messages you send are placed in your Sent folder.

Saved Items - You can access your saved messages, text templates and multimedia templates here.




Emoticons - A list of useful pre-written emoticons that can be used for a quick reply.

Media

Music


Your GU230 has a built-in **Music** player so you can play all your favorite music.

Playing a Song

- 1 Press **Menu** and select **Media**, then choose **Music**.
- 2 Choose **All tracks** then select the song you want to play.
- 3 Select  to pause the song.
- 4 Select  to skip to the next song.
- 5 Select  to skip to the previous song.
- 6 Select **Back** to stop the music and return to the music player menu.


Creating a Playlist

You can create your own playlists by choosing a selection of songs from the **All songs** folder.

- 1 Press **Menu** and select **Media**.
- 2 Choose **Music**, then select **Playlists**.
- 3 Press **Options** and select **Add new playlist**, then enter the playlist name and press **Save**.
- 4 The **All tracks** folder will be displayed. Select all of the songs that you would like to include in your playlist by scrolling to them and selecting .
- 5 Select **Done** to store the playlist.


Camera

Taking a Quick Photo

- 1 Select **Menu** and select **Media**. Select **Camera** to open the viewfinder.
- 2 Holding the phone, point the lens toward the subject of the photo.
- 3 Position the phone so you can see the subject of your photo.
- 4 Press the **Center**  key to take a photo.

Video Camera

Shooting a Quick Video

- 1 In the standby screen, select **Menu** and select **Media**.
- 2 Choose **Video**.
- 3 Point the camera lens toward the subject of the video.
- 4 Press  to start recording.

- 5 "Rec" will appear in the bottom-left corner of the viewfinder and a timer will show the length of your video.
- 6 Select **Stop** to stop recording.

FM Radio


Using the FM Radio

Your LG GU230 has an **FM radio** feature so you can tune into your favorite stations and listen on the move.

Listening to the Radio

- 1 Press **Menu** and select **Media**, then choose **FM radio**.
- 2 Select the channel number of the station you would like to listen to.

Recording the Radio

- 1 Press the **center key** while listening to the **radio**.
- 2 The recording time is displayed on your phone. If you want to stop the recording, press the . When a recording has been made, the recorded contents will be saved in the **Gallery** as an mp3 file.
- 3 When the recording is done, select **Option** and then choose from **Play**, **Delete**, **Sound edit**, **File**, **Use as** or **Send via**.

Note: If you are in an area with bad radio reception, you may have difficulty listening to the **radio**.

It is recommended that you insert headphones into the hands-free connector when listening to the **radio** to ensure good radio reception.

Voice Recorder

Use your **Voice recorder** to record voice memos or other sounds.

Gallery

You can store any kind of **Media file** on your phone's memory to give you easy access to all of your images, sounds, videos, games etc. You can also save your files to a memory card. The advantage of using a memory card is that you can free up space on your phone's memory. All your multimedia files will be saved in the **Gallery**. Press **Menu** then select **Gallery** to open a list of folders.

My Memory Card

If you have inserted a memory card, it will be displayed as a folder in the **Gallery**.

My Images

The **Images folder** contains a folder of default images on your phone, images downloaded by you, and images taken on your phone's camera.

My Sounds

The **Sounds folder** contains default sounds, your voice recordings, radio recordings and sound files downloaded by you. From here you can manage and send sounds, or set them as ringtones.

My Videos

The **Videos folder** shows the list of downloaded videos and videos you have recorded on your phone.

Others

In the **Others folder**, you can view files that are not saved in the **Images**, **Sounds** or **Videos folders**.

My Games & Apps

Your GU230 comes with preloaded games to keep you amused in your spare time. If you choose to download any additional games or applications they will be saved in this folder.

Organiser

Setting your Alarm

You can set up to five alarms to go off at a specified time

Using the Calendar

When you enter this menu, a calendar appears. A square cursor is located on the current date.

You can move the cursor to another date using the navigation keys.

Adding an Item to Your To-Do List

You can view, edit and add tasks to do..

Using the Calculator

The calculator provides the basic arithmetic functions—addition, subtraction, multiplication and division—as well as scientific functions.

Using the Stopwatch

This option allows you to use stopwatch functions.

Converting Units

This can convert many measurements into the unit you want.

Adding a City to Your World Time

You can add a required city to the list of world clocks. You can also check the current Greenwich Mean Time (GMT) and the time in major cities around the world.

Go To

This helps you go to the menu you are searching for. You can set an item as Go to.

Credit Transfer

The credit transfer application is activated for certain countries. This application offers a simple and secure way to transfer call credit to a new contact or a contact from your phonebook.

Some of the options for this application are described below.

- **Contacts**

This option allows the user to select the contact from the handset phonebook to whom the call credit will be transferred.

- **Security code on/off**

User can protect the use of the credit transfer application with this option. If the security code is activated (ON), then the security code will be requested before call credit transfers to ensure security.

Web

Accessing the Web

You can launch the WAP browser and access the homepage of the activated profile on web settings. You can also manually enter a URL address and access the associated WAP page.

- 1 Press **Menu** and select **Web**.
- 2 To access the web homepage directly, select **Home**. Alternately, select **Go to address** and type in your desired URL.

Connectivity

Changing your Connectivity Settings

USB connection mode

- 1 Mass storage: Select Mass storage and connect the handset to your computer. You can then drag and drop files to the GU230 removable device folder.

- 2 PC Suite: Select PC Suite and connect the handset to your computer in PCSync mode.
- 3 Always ask: Selecting this option will allow you to choose which method to use every time you connect your handset to your computer.

Note: To use the USB mass storage function, you will need to insert an external memory card in your phone.

Changing Your Bluetooth Settings

- 1 Press **Menu** and select **Settings - Connectivity**. Choose **Bluetooth**.
- 2 Choose **Settings** for the following options:
 - **My phone's visibility**
- Choose whether to show or hide your device to others.

- **My phone's name** - Enter a name for your LG GU230.
- **Supported services** - Shows what services are supported.
- **My address** - View your Bluetooth address.

Pairing with Another Bluetooth Device

By pairing your GU230 and another device, your handset will create a password by default every time you connect to another handset via Bluetooth.

- 1 Check your Bluetooth is **On** and **Visible**. You can change your visibility in the **Settings** menu by selecting **My phone's visibility** and then **Visible**.
- 2 Select **Active devices** from the **Bluetooth** menu.
- 3 Your GU230 will search for devices. When the search is complete, **Add** and **Refresh** will appear on the screen.

4 Choose the device you want to pair with, select Add, enter the passcode and then press the **Center key**. When you have chosen a device you want to pair with, the handset will then create a password by default every time you connect.

5 Your phone will then connect to the other device. The same passcode will need to be entered on this device.

When you have chosen a device you want to pair with, the handset will then create a password by default every time you connect.

6 Your passcode-protected Bluetooth connection is now ready.

Installing LG PC Suite on Your Computer

- 1 Go to www.lg.com, select from "Europe," "Middle East," "Africa," "Americas," "CIS," and "Asia & Pacific," and then select your country.
- 2 From the Products menu, select Manual & Software and click Download Section. Click Yes, and the LG PC Suite installer will then appear. (Windows XP, Windows Media Player and more are supported).
- 3 Select the language you would like the installer to run in and click OK.
- 4 Follow the instructions shown onscreen to complete the LG PC Suite Installer wizard.
- 5 Once the installation is complete, the LG PC Suite icon will appear on your desktop.

Settings

Changing Your Profiles

You can personalize each profile setting.

- 1 Choose the **Profiles** you want and select **Edit** from **Options**.
- 2 If you activate Silent mode, the phone will vibrate only.

Using Flight Mode

When **Flight mode** is activated, you will not be able to make calls, connect to the Internet or send messages.

Changing Your Date & Time

You can set functions relating to the date and time.

Changing Your Display Settings

You can change the settings for the phone display.

Changing Your Security Settings

Change your security settings to keep your GU230 and the important information it holds protected.

- **PIN code request** - Choose a PIN code to be requested when you turn your phone on.
- **Handset lock** - Choose a security code to lock your phone: When **power on**, When **SIM changed** or **Immediately**.

- **Anti-theft mobile tracker**
- When the handset is stolen, handset sends the SMS to the numbers configured by real owner. To activate the ATMT feature, you will need to set ATMT on, and configure the ATMT settings with name, primary number and secondary number. Default ATMT code is "0000." ATMT SMS will contain information about the stolen phone IMEI, current location (captured as per Cell Broadcast message) & number of the person who is using that handset.
- **Change codes** - Change your PIN code, PIN2 code, Security code or Anti-theft code.

Resetting Your Phone

Use **Restore factory settings** to reset all the settings to their factory definitions. You need the security code to activate this function.

Viewing Memory Status

You can use the **Memory manager** to determine how each memory is used and see how much space is available in the **Handset common memory, Handset reserved memory, SIM memory** or **Primary storage setting**. You can also set the **External memory** when the memory card is inserted.

Guidelines for Safe and Efficient Use

Exposure to Radio Frequency Energy

Radio Wave Exposure and Specific Absorption Rate (SAR) Information

This GU230 mobile phone model has been designed to comply with the applicable safety requirements for exposure to radio waves.


These requirements are based on scientific guidelines that include safety margins designed to ensure the safety of all users, regardless of age and health.

- The radio wave exposure guidelines employ a unit of measurement known as the Specific Absorption Rate, or SAR. SAR tests are conducted using standardized methods with the phone transmitting at its highest certified power level in all used frequency bands.
- While there may be differences between the SAR levels for various LG phone models, they are all designed to meet the relevant guidelines for exposure to radio waves.
- The SAR limit recommended by the International Commission on Non-Ionizing Radiation Protection (ICNIRP) is 2 W/kg averaged over 10 g of tissue.

Guidelines for Safe and Efficient Use (Continued)

- The highest SAR value for this phone model tested by DASYS4 for use close to the ear is 0.716 W/kg (10 g), and when worn on the body is 1.06 W/kg (10 g).
- SAR data information for residents in countries/regions that have adopted the SAR limit recommended by the Institute of Electrical and Electronics Engineers (IEEE), which is 1.6 W/kg averaged over 1 g of tissue.

Product Care and Maintenance

 **WARNING:** Only use batteries, chargers and accessories approved for use with this particular phone model. The use of any other types may invalidate any approval or warranty applying to the phone, and may be dangerous.

- Do not disassemble this unit. Take it to a qualified service technician when repair work is required.
- Keep away from electrical appliances such as TVs, radios and personal computers.
- The unit should be kept away from heat sources such as radiators or cookers.

- Do not drop.
- Do not subject this unit to mechanical vibration or shock.
- Switch off the phone in any area where you are required by special regulations. For example, do not use your phone in hospitals as it may affect sensitive medical equipment.
- Do not handle the phone with wet hands while it is being charged. It may cause an electric shock and can seriously damage your phone.
- Do not charge a handset near flammable material as the handset can become hot and create a fire hazard.
- Use a dry cloth to clean the exterior of the unit (do not use solvents such as benzene, thinner or alcohol).
- Do not charge the phone when it is on soft furnishings.
- The phone should be charged in a well-ventilated area.
- Do not subject this unit to excessive smoke or dust.
- Do not keep the phone next to credit cards or transport tickets; it can affect the information on the magnetic strips.
- Do not tap the screen with a sharp object as it may damage the phone.
- Do not expose the phone to liquid or moisture.
- Use accessories like earphones cautiously. Do not touch the antenna unnecessarily.

Guidelines for Safe and Efficient Use (Continued)

Efficient Phone Operation

Electronic Devices

- Do not use your mobile phone near medical equipment without requesting permission. Avoid placing the phone over pacemakers, i.e. in your breast pocket.
- Some hearing aids might experience disturbance due to mobile phones.
- Minor interference may affect TVs, radios, PCs etc.

Road Safety

Check the laws and regulations on the use of mobile phones in the areas where you drive.

- Do not use a hand-held phone while driving.
- Give your full attention to driving.

- Use a hands-free kit, if available.
- Pull off the road and park before making or answering a call if driving conditions so require.
- RF energy may affect some electronic systems in your vehicle, such as car stereos and safety equipment.
- If your vehicle is equipped with an airbag, do not obstruct it with installed or portable wireless equipment. This may cause the airbag to fail or cause serious injury due to improper performance.
- If you are listening to music while out and about, please ensure that the volume is at a reasonable level so that you are aware of your surroundings. This is particularly imperative when near roads.

Avoid Damage to Your Hearing

Damage to your hearing can occur if you are exposed to loud sounds for long periods of time. We therefore recommend that you do not turn the handset on or off when it is close to your ear. We also recommend that music and call volumes are set to a reasonable level.

Blasting Area

Do not use the phone where blasting is in progress. Observe restrictions, and follow the rules and regulations.

Potentially Explosive Atmospheres

- Do not use the phone at a refueling point.
- Do not use near fuel or chemicals.
- Do not transport or store flammable gas, liquid, or explosives in the same compartment of your vehicle as your mobile phone and accessories.

In Aircraft

Wireless devices can cause interference to aircraft.

- Turn your mobile phone off before boarding any aircraft.
- Do not use it on the aircraft without permission from the crew.

Guidelines for Safe and Efficient Use (Continued)

Children

Keep the phone in a safe place out of the reach of small children.

It includes small parts which may cause a choking hazard if detached.

Emergency Calls

Emergency calls may not be available under all mobile networks. You should therefore never depend solely on the phone for emergency calls. Check with your local service provider.

Battery Information and Care

- You do not need to completely discharge the battery before recharging. Unlike other battery systems, there is no memory effect that could compromise the battery's performance.
- Use only LG batteries and chargers. LG chargers are designed to maximize the battery life.
- Do not disassemble or short-circuit the battery pack.
- Keep the metal contacts of the battery pack clean.
- Replace the battery when it no longer provides acceptable performance. The battery pack maybe recharged hundreds of times until it needs replacing.

- Recharge the battery if it has not been used for a long time to maximize usability.
- Do not expose the battery charger to direct sunlight or use it in places with high humidity, such as in the bathroom.
- Do not leave the battery in hot or cold places, as this may deteriorate the battery performance.
- There is a risk of explosion if the battery is replaced by an incorrect type.
- Dispose of used batteries according to the manufacturer's instructions. Please recycle when possible. Do not dispose of batteries in the household waste.
- If you need to replace the battery, take it to the nearest authorized LG Electronics service point or dealer for assistance.
- Always unplug the charger from the wall socket after the phone is fully charged to save unnecessary power consumption of the charger.
- Actual battery life will depend on network configuration, product settings, usage patterns, battery and environmental conditions.

Accessories

Various accessories are available for your mobile phone. These are detailed below.

Charger



- Stereo headset



Battery



- Data cable
- User Guide

NOTE

- Always use genuine LG accessories. Failure to do so may invalidate your warranty.
- Accessories may be different in different regions. Please check with our regional service company or agent for further enquires.

Technical Data

General

Product Name: GU230

System: GSM 850 / E-GSM 900 /
DCS 1800 / PCS 1900

Ambient Temperatures

Max.: +55°C (discharging)
+45°C (charging)

Min.: -10°C

Declaration of Conformity



Suppliers Details

Name

LG Electronics Inc

Address

LG Electronics Inc. LG Twin Towers 20,
Yeouido-dong, Yeongdeungpo-gu, Seoul, Korea 150-721

Product Details

Product Name

GSM 850 / E-GSM 900 / DCS 1800 / PCS 1900 Quad band Terminal Equipment

Model Name

GU230

Trade Name

LG

CE 0168

Applicable Standards Details

R&TTE Directive 1999/5/EC

EN 301 489-01 V1.6.1, EN 301 489-07 V1.3.1, EN 301 489-17 V1.2.1
EN 301 511 V9.0.2
EN 50360:2001, EN62209-1:2006
EN 60950-1:2001
EN300328 V1.7.1

Supplementary Information

The conformity to above standards is verified by the following Notified Body(BABT)

BABT, Forsyth House-Churchfield Road - Walton-on-ThamesSurrey - KT12 2TD , United Kingdom
Notified Body Identification Number : 0168

Declaration

I hereby declare under our sole responsibility that the product mentioned above to which this declaration relates complies with the above mentioned standards and Directives

European Standard Center
LG Electronics Logistics and Services B.V.
Veluwezoom 15, 1327 AE Almere, The Netherlands
Tel : +31 - 36 - 547 - 8940, Fax : +31 - 36 - 547 - 8794
e-mail : jacob @ lge.com

Name

Issued Date

Seung Hyoun, Ji / Director

01. Oct. 2009


Signature of representative



