

Για περισσότερες πληροφορίες
τηλεφωνήστε στο: 800 11 200 300



CE0168



ΕΛΛΗΝΙΚΑ
ENGLISH

Οδηγός χρήσης GM360

LG Electronics

Οδηγός χρήσης GM360

P/NO : MMBB0383412(1.0) **W**

www.lg.com

Bluetooth QD ID B016467



Συγχαρητήρια για την αγορά του προηγμένου τηλεφώνου GM360 μικρών διαστάσεων της LG, το οποίο έχει σχεδιαστεί για να λειτουργεί με την πιο πρόσφατη τεχνολογία ψηφιακής κινητής επικοινωνίας.



Απόρριψη της παλιάς σας συσκευής

- 1 Όταν ένα προϊόν διαθέτει το σύμβολο ενός διαγραμμένου κάλαθου απορριμμάτων, τότε το προϊόν καλύπτεται από την Ευρωπαϊκή Οδηγία 2002/96/ΕΟΚ.
- 2 Η απόρριψη όλων των ηλεκτρικών και ηλεκτρονικών προϊόντων πρέπει να γίνεται χωριστά από τα γενικά οικιακά απορρίμματα μέσω καθορισμένων εγκαταστάσεων συλλογής απορριμμάτων, οι οποίες έχουν δημιουργηθεί είτε από την κυβέρνηση ή από τις τοπικές αρχές.
- 3 Η σωστή απόρριψη της παλιάς σας συσκευής θα βοηθήσει στην αποτροπή πιθανών αρνητικών συνεπειών για το περιβάλλον και την υγεία του ανθρώπου.
- 4 Για πιο λεπτομερείς πληροφορίες σχετικά με την απόρριψη της παλιάς σας συσκευής, επικοινωνήστε με το αρμόδιο τοπικό γραφείο, υπηρεσία διάθεσης οικιακών απορριμμάτων ή το μαγαζί από το οποίο αγοράσατε το προϊόν.

Κάποια από τα περιεχόμενα του εγχειριδίου ενδέχεται να διαφέρουν σε σχέση με το τηλέφωνό σας, ανάλογα με την έκδοση του λογισμικού του τηλεφώνου ή τον παροχέα υπηρεσιών.

GM360 Οδηγός χρήσης

Περιεχόμενα

Οδηγίες για ασφαλή και αποτελεσματική χρήση.....	3	Ανταλλαγή μηνυμάτων.....	22
Εξοικείωση με τις λειτουργίες του τηλεφώνου	9	Φωτογραφική μηχανή	28
Εγκατάσταση της κάρτας SIM/USIM και της μπαταρίας	10	Βιντεοκάμερα.....	29
Κάρτα μνήμης.....	11	Φωτογραφίες και βίντεο	30
Φορτίστε το τηλέφωνό σας	11	Πολυμέσα	32
Χρήση της οθόνης αφής....	12	Ατζέντα.....	36
Η αρχική οθόνη.....	14	Συγχρονισμός PC.....	39
Κλήσεις.....	18	Internet	42
		Ρυθμίσεις	44
		Τεχνικά δεδομένα.....	49

Οδηγίες για ασφαλή και αποτελεσματική χρήση

Διαβάστε αυτές τις απλές οδηγίες. Η μη τήρηση των οδηγιών αυτών μπορεί να αποβεί επικίνδυνη ή παράνομη.

Έκθεση σε ενέργεια ραδιοσυχνότητας

Πληροφορίες σχετικά με την έκθεση σε ραδιοκύματα και το συντελεστή ειδικής απορρόφησης (ΣΕΑ). Το μοντέλο κινητού τηλεφώνου GM360 έχει σχεδιαστεί έτσι, ώστε να συμμορφώνεται με τις ισχύουσες απαιτήσεις ασφαλείας για την έκθεση σε ραδιοκύματα. Οι απαιτήσεις αυτές βασίζονται σε επιστημονικές οδηγίες που περιλαμβάνουν περιθώρια ασφαλείας για την προστασία όλων των ατόμων, ανεξάρτητα από την ηλικία ή την κατάσταση της υγείας τους.

• Στις οδηγίες σχετικά με την έκθεση σε ραδιοκύματα χρησιμοποιείται μια μονάδα μέτρησης, η οποία είναι γνωστή ως συντελεστής ειδικής απορρόφησης ή ΣΕΑ. Οι έλεγχοι για το ΣΕΑ διεξάγονται χρησιμοποιώντας τυπικές μεθόδους με το τηλέφωνο να εκπέμπει στο μέγιστο πιστοποιημένο επίπεδο ισχύος σε όλες τις ζώνες συχνοτήτων που χρησιμοποιεί.

- Αν και μπορεί να υπάρχουν διαφορές μεταξύ των επιπέδων του ΣΕΑ για διάφορα μοντέλα τηλεφώνων της LG, όλα έχουν σχεδιαστεί ώστε να ανταποκρίνονται στις σχετικές οδηγίες για την έκθεση σε ραδιοκύματα.
- Το όριο του ΣΕΑ που συνιστάται από τη Διεθνή Επιτροπή Προστασίας από τη Μη Ιονίζουσα Ακτινοβολία (ICNIRP) είναι 2 W/kg, με βάση τον υπολογισμό της μέσης τιμής για 10 g σωματικού ιστού.
- Η υψηλότερη τιμή ΣΕΑ για αυτό το μοντέλο τηλεφώνου, όπως έχει ελεγχθεί με το σύστημα DASY4, είναι 1,33 W/kg (10 g) για χρήση στο αυτί και 1,31 W/kg (10 g) για χρήση στο σώμα.
- Δεδομένα του ΣΕΑ για τους κατοίκους χωρών/περιοχών που έχουν υιοθετήσει το όριο του ΣΕΑ, το οποίο συνιστάται από το Ινστιτούτο Ηλεκτρολόγων και Ηλεκτρονικών Μηχανικών (IEEE), το οποίο είναι 1,6 W/kg κατά μέσο όρο για 1 g σωματικού ιστού.

Οδηγίες για ασφαλή και αποτελεσματική χρήση

Φροντίδα και συντήρηση του προϊόντος

ΠΡΟΕΙΔΟΠΟΙΗΣΗ

Χρησιμοποιείτε μόνο τις μπαταρίες, τους φορτιστές και τα αξεσουάρ που έχουν εγκριθεί για χρήση με το συγκεκριμένο μοντέλο τηλεφώνου. Η χρήση διαφορετικών τύπων ενδέχεται να καταστήσει άκυρη κάθε έγκριση ή εγγύηση που ισχύει για το τηλέφωνο και μπορεί να αποβεί επικίνδυνη.

- Μην αποσυναρμολογείτε τη συσκευή. Όταν απαιτούνται εργασίες επισκευής, παραδώστε την σε εξειδικευμένο τεχνικό. Σύμφωνα με την LG, οι επισκευές που καλύπτονται από την εγγύηση περιλαμβάνουν την τοποθέτηση ανταλλακτικών μερών ή πινάκων (είτε καινούργιων είτε επισκευασμένων), με την προϋπόθεση ότι η λειτουργικότητά τους είναι όμοια με τη λειτουργικότητα των μερών που αντικαταστάθηκαν.
- Κρατάτε τη συσκευή μακριά από ηλεκτρικές συσκευές όπως τηλεοράσεις, ραδιόφωνα και υπολογιστές.
- Η συσκευή πρέπει να φυλάσσεται μακριά από πηγές θερμότητας, όπως καλοριφέρ ή ηλεκτρικές κουζίνες.
- Προσέξτε να μην πέσει.
- Η συσκευή δεν πρέπει να υπόκειται σε μηχανικές δονήσεις ή κραδασμούς.
- Απενεργοποιείτε το τηλέφωνο στις περιοχές όπου αυτό απαιτείται από ειδικούς κανονισμούς. Για παράδειγμα, μην χρησιμοποιείτε το τηλέφωνο σε νοσοκομεία, καθώς η χρήση του μπορεί να επηρεάσει ευαίσθητο ιατρικό εξοπλισμό.
- Μην πιάνετε το τηλέφωνο με βρεγμένα χέρια όταν φορτίζεται. Μπορεί να υποστείτε ηλεκτροπληξία και να προκληθεί σοβαρή βλάβη στο τηλέφωνο.
- Μην φορτίζετε το τηλέφωνο κοντά σε εύφλεκτα υλικά, καθώς ενδέχεται να θερμανθεί και να δημιουργηθεί κίνδυνος πυρκαγιάς.
- Χρησιμοποιήστε ένα στεγνό πανί για τον καθαρισμό του εξωτερικού της συσκευής (μην χρησιμοποιείτε διαλύτες, όπως βενζίνη, διαλυτικό ή οινόπνευμα).
- Μην φορτίζετε το τηλέφωνο όταν βρίσκεται πάνω σε μαλακά υφάσματα.

- Το τηλέφωνο πρέπει να φορτίζεται σε καλά αεριζόμενο χώρο.
- Η συσκευή δεν πρέπει να υφίσταται υπερβολικό καπνό ή σκόνη.
- Μην τοποθετείτε το τηλέφωνο δίπλα σε πιστωτικές κάρτες ή εισιτήρια μέσω μεταφοράς. Μπορεί να επηρεάσει τις πληροφορίες που περιέχονται στις μαγνητικές ταινίες.
- Μην χτυπάτε την οθόνη με αιχμηρά αντικείμενα, καθώς ενδέχεται να προκαλέσετε βλάβη στο τηλέφωνο.
- Μην εκθέτετε το τηλέφωνο σε υγρά ή υγρασία.
- Χρησιμοποιείτε με προσοχή τα αξεσουάρ, όπως είναι τα ακουστικά. Μην ακουμπάτε την κεραία άνευ λόγου.

Αποτελεσματική λειτουργία τηλεφώνου

Ηλεκτρονικές συσκευές

- Όλα τα κινητά τηλέφωνα μπορεί να δέχονται παρεμβολές που ενδεχομένως να επηρεάζουν την απόδοσή τους.
- Μην χρησιμοποιείτε το κινητό τηλέφωνο κοντά σε ιατρικό εξοπλισμό χωρίς να έχετε λάβει σχετική άδεια. Αποφεύγετε να τοποθετείτε το τηλέφωνο κοντά σε

βηματοδότη, όπως για παράδειγμα σε τσέπη στο στήθος σας.

- Ορισμένα ακουστικά βοήθημα ενδέχεται να υφίστανται παρεμβολές από κινητά τηλέφωνα.
- Μικρές παρεμβολές ενδέχεται να επηρεάσουν συσκευές, όπως τηλεράσεις, ραδιόφωνα, υπολογιστές κ.λπ.

Οδική ασφάλεια

Ελέγξτε τους νόμους και τους κανονισμούς για τη χρήση των κινητών τηλεφώνων στις περιοχές όπου οδηγείτε.

- Μην χρησιμοποιείτε ποτέ τηλέφωνο χειρός όταν οδηγείτε.
- Εστιάστε όλη σας την προσοχή στην οδήγηση.
- Χρησιμοποιείτε handsfree, εφόσον υπάρχει.
- Σταματήστε στην άκρη του δρόμου και σταθεμεύστε πριν πραγματοποιήσετε ή απαντήσετε σε μια κλήση, εάν το απαιτούν οι συνθήκες οδήγησης.
- Η ενέργεια ραδιοσυχνότητων ενδέχεται να επηρεάσει ορισμένα ηλεκτρονικά συστήματα στο όχημά σας, όπως το ραδιόφωνο του αυτοκινήτου και τον εξοπλισμό ασφαλείας.

Οδηγίες για ασφαλή και αποτελεσματική χρήση

- Εάν το όχημά σας είναι εξοπλισμένο με έναν ή περισσότερους αερόσακους, μην εγκαθιστάτε ή τοποθετείτε ασύρματο εξοπλισμό σε σημεία όπου θα εμποδίζεται η λειτουργία του αερόσακου. Ενδέχεται να προκληθεί δυσλειτουργία του αερόσακου ή σοβαρός τραυματισμός λόγω ακατάλληλης απόδοσης.
- Όταν ακούτε μουσική ενώ βρίσκεστε έξω, βεβαιωθείτε ότι έχετε ρυθμίσει την ένταση σε ένα λογικό επίπεδο, για να έχετε επίγνωση του τι συμβαίνει γύρω σας. Αυτό επιβάλλεται ιδιαίτερα όταν βρίσκεστε κοντά σε δρόμο.

Αποφύγετε την πρόκληση βλάβης στην ακοή σας

Ενδέχεται να προκληθεί βλάβη στην ακοή εάν εκτίθεστε σε δυνατό ήχο για μεγάλα χρονικά διαστήματα. Επομένως, σας συνιστούμε να μην ενεργοποιείτε ή απενεργοποιείτε το τηλέφωνο κοντά στα αυτιά σας. Επίσης, σας συνιστούμε να ρυθμίζετε την ένταση της μουσικής και του ήχου κλήσης σε ένα λογικό επίπεδο.

Γυάλινα εξαρτήματα

Ορισμένα εξαρτήματα της κινητής συσκευής είναι κατασκευασμένα από γυαλί. Το γυαλί αυτό ενδέχεται να σπάσει σε περίπτωση πτώσης της κινητής συσκευής σε σκληρή επιφάνεια ή έντονου χτυπήματος. Εάν σπάσει γυάλινο εξάρτημα, μην το αγγίξετε και μην επιχειρήσετε να το αφαιρέσετε. Διακόψτε τη χρήση της κινητής συσκευής έως ότου αντικατασταθεί το γυαλί από εξουσιοδοτημένο παροχέα υπηρεσιών.

Περιοχές όπου εκτελούνται ανατινάξεις

Μην χρησιμοποιείτε το τηλέφωνο σε περιοχές όπου γίνονται ανατινάξεις. Ακολουθείτε τους περιορισμούς και τυχόν κανονισμούς ή κανόνες.

Περιβάλλοντα όπου υπάρχει κίνδυνος εκρήξεων

- Μην χρησιμοποιείτε το τηλέφωνο σε σημεία ανεφοδιασμού καυσίμων.
- Μην χρησιμοποιείτε το τηλέφωνο κοντά σε καύσιμα ή χημικά.
- Μην μεταφέρετε ή αποθηκεύετε εύφλεκτα αέρια, υγρά ή εκρηκτικά στον ίδιο χώρο του αυτοκινήτου

όπου βρίσκεται το κινητό τηλέφωνο και τα αξεσουάρ του.

Σε αεροσκάφος

Οι ασύρματες συσκευές μπορούν να προκαλέσουν παρεμβολές στα συστήματα αεροσκαφών.

- Πριν την επιβίβασή σας σε αεροσκάφος, απενεργοποιείτε το κινητό σας τηλέφωνο.
- Μην το χρησιμοποιείτε όσο το αεροσκάφος βρίσκεται στο έδαφος χωρίς άδεια από το πλήρωμα.

Παιδιά

Διατηρήστε το τηλέφωνο σε ασφαλές σημείο μακριά από μικρά παιδιά. Περιλαμβάνει εξαρτήματα μικρού μεγέθους που ενδέχεται να αποτελέσουν κίνδυνο για πνιγμό εάν αποσπαστούν από το τηλέφωνο.

Επείγουσες κλήσεις

Η πραγματοποίηση επείγουσών κλήσεων μπορεί να μην είναι διαθέσιμη σε όλα τα δίκτυα κινητής τηλεφωνίας. Για το λόγο αυτό, δεν πρέπει να βασίζεστε αποκλειστικά σε αυτό το τηλέφωνο για επείγουσες κλήσεις. Επικοινωνήστε με τον τοπικό παροχέα υπηρεσιών για να ενημερωθείτε σχετικά με αυτό το θέμα.

Πληροφορίες και φροντίδα μπαταριών

- Δεν είναι απαραίτητο να αποφορτιστεί πλήρως η μπαταρία για να την επαναφορτίσετε. Σε αντίθεση με άλλα συστήματα μπαταριών, δεν εμφανίζεται το φαινόμενο μνήμης που μπορεί να επηρεάσει την απόδοση της μπαταρίας.
- Χρησιμοποιείτε μόνο μπαταρίες και φορτιστές LG. Οι φορτιστές LG έχουν σχεδιαστεί για να μεγιστοποιούν τη διάρκεια ζωής της μπαταρίας.
- Μην αποσυναρμολογείτε ή βραχυκυκλώνετε την μπαταρία.
- Διατηρείτε τις μεταλλικές επαφές της μπαταρίας καθαρές.
- Αντικαθιστάτε την μπαταρία όταν μειωθεί σημαντικά η απόδοσή της. Η μπαταρία μπορεί να επαναφορτιστεί εκατοντάδες φορές μέχρι να χρειαστεί αντικατάσταση.
- Φορτίστε την μπαταρία εάν δεν έχει χρησιμοποιηθεί για πολύ καιρό για να μεγιστοποιήσετε τη διάρκεια χρήσης της.
- Μην εκθέτετε το φορτιστή της μπαταρίας σε άμεσο ηλιακό φως και μην τον χρησιμοποιείτε σε χώρους με πολλή υγρασία, όπως το μπάνιο.

Οδηγίες για ασφαλή και αποτελεσματική χρήση

- Μην αφήνετε την μπαταρία σε θερμούς ή κρύους χώρους, καθώς μπορεί να μειωθεί η απόδοσή της.
- Εάν αντικαταστήσετε την μπαταρία με λάθος τύπο μπαταρίας, υπάρχει κίνδυνος έκρηξης.
- Απορρίψτε τις χρησιμοποιημένες μπαταρίες σύμφωνα με τις οδηγίες του κατασκευαστή. Ανακυκλώστε, εάν είναι εφικτό. Μην τις απορρίπτετε ως οικιακά απορρίμματα.
- Σε περίπτωση που χρειαστεί να αντικαταστήσετε την μπαταρία, επισκεφτείτε στο πλησιέστερο εξουσιοδοτημένο σημείο εξυπηρέτησης ή τον πλησιέστερο μεταπωλητή της LG Electronics για βοήθεια.
- Για να μην αποφύγετε την άσκοπη κατανάλωση ενέργειας από το φορτιστή, αποσυνδέετε πάντοτε το φορτιστή από την πρίζα μετά την πλήρη φόρτιση του τηλεφώνου.
- Η πραγματική διάρκεια ζωής της μπαταρίας εξαρτάται από τη διαμόρφωση του δικτύου, τις ρυθμίσεις των προϊόντων, τις συνήθειες χρήσης, την μπαταρία και τις περιβαλλοντικές συνθήκες.

Εξοικείωση με τις λειτουργίες του τηλεφώνου



⚠ ΠΡΟΕΙΔΟΠΟΙΗΣΗ: Εάν τοποθετήσετε ένα βαρύ αντικείμενο στο τηλέφωνο ή καθίσετε πάνω του ενώ το έχετε στην τσέπη σας, μπορεί να προκαλέσετε βλάβη στην οθόνη LCD του τηλεφώνου και στη λειτουργία της οθόνης αφής.

Εγκατάσταση της κάρτας SIM/USIM και της μπαταρίας

1 Αφαίρεση του καλύμματος της μπαταρίας

Σύρετε το κάλυμμα της μπαταρίας προς το κάτω μέρος του τηλεφώνου και απομακρύνετε το.




ΠΡΟΕΙΔΟΠΟΙΗΣΗ: Μην χρησιμοποιείτε τα νύχια σας για να αφαιρέσετε την μπαταρία.

ΠΡΟΕΙΔΟΠΟΙΗΣΗ: Μην αφαιρείτε την μπαταρία όταν είναι ενεργοποιημένο το τηλέφωνο, καθώς ενδέχεται να προκληθεί βλάβη στο τηλέφωνο.

2 Τοποθέτηση της κάρτας SIM/USIM

Σύρετε την κάρτα SIM/USIM μέσα στην υποδοχή της, αφού βεβαιωθείτε ότι η περιοχή της κάρτας με τις χρυσές επαφές είναι στραμμένη προς τα κάτω. Πριν τοποθετήσετε την κάρτα SIM/USIM, βεβαιωθείτε ότι έχετε αφαιρέσει την μπαταρία από το τηλέφωνο. Για να αφαιρέσετε την κάρτα SIM/USIM, τραβήξτε τη προσεκτικά προς τα έξω.



3 Τοποθετήστε τη μπαταρία

Εισαγάγετε το αριστερό μέρος της μπαταρίας πρώτα στο πάνω άκρο της θέσης μπαταρίας. Βεβαιωθείτε ότι οι επαφές της μπαταρίας ευθυγραμμίζονται με τους ακροδέκτες του τηλεφώνου. Πιέστε προς τα κάτω το δεξί μέρος της μπαταρίας, ώσπου να εφαρμόσει στη θέση του.



Κάρτα μνήμης

Τοποθέτηση κάρτας μνήμης

Μπορείτε να επεκτείνετε το διαθέσιμο χώρο μνήμης του τηλεφώνου σας χρησιμοποιώντας μια κάρτα μνήμης MicroSD.

ΣΗΜΕΙΩΣΗ: Η κάρτα μνήμης είναι προαιρετικό αξεσουάρ.

- 1 Ανοίξτε το κάλυμμα της κάρτας μνήμης. Σύρετε την κάρτα μνήμης στην υποδοχή έως ότου ασφαλίσει στη θέση της.



- 2 Βεβαιωθείτε ότι η χρυσή επαφή είναι στραμμένη προς τα κάτω.

Φορτίστε το τηλέφωνό σας

Αφαιρέστε το κάλυμμα της υποδοχής φορτιστή στο πλάι του GM360.

Συνδέστε το φορτιστή ταξιδιού και το συνοδευτικό καλώδιο USB. Συνδέστε το καλώδιο USB στο τηλέφωνο και, στη συνέχεια, συνδέστε σε πρίζα. Το GM360 πρέπει να φορτιστεί ώσπου να εμφανιστεί στην οθόνη το μήνυμα “Φόρτιση πλήρης”.

ΣΗΜΕΙΩΣΗ: Η μπαταρία πρέπει να φορτιστεί πλήρως στην αρχή, προκειμένου να βελτιωθεί η διάρκεια ζωής της. Παραβλέψτε το πρώτο μήνυμα “Φόρτιση πλήρης” και αφήστε το τηλέφωνο να φορτίζεται κατά τη διάρκεια της νύχτας.



Χρήση της οθόνης αφής

Συμβουλές για την οθόνη αφής

- Για να επιλέξετε ένα στοιχείο, πατήστε στο κέντρο του εικονιδίου.
- Μην ασκείτε μεγάλη πίεση. Η οθόνη αφής είναι τόσο ευαίσθητη, που ενεργοποιείται ακόμα και με ένα ελαφρύ, σταθερό πάτημα.
- Χρησιμοποιήστε την άκρη του δάχτυλού σας για να πατήσετε την επιλογή που θέλετε. Προσέξτε να μην πατήσετε άλλα πλήκτρα.
- Όταν το GM360 δεν χρησιμοποιείται, η οθόνη του κλειδώνεται ξανά.

Έλεγχος της οθόνης αφής

Τα στοιχεία ελέγχου στην οθόνη αφής του GM360 αλλάζουν με δυναμικό τρόπο, ανάλογα με την εργασία που εκτελείτε.

Άνοιγμα εφαρμογών

Για να ανοίξετε οποιαδήποτε εφαρμογή, απλώς πατήστε το αντίστοιχο εικονίδιο.




Κύλιση

Σύρετε από την μία πλευρά στην άλλη για να πραγματοποιήσετε κύλιση. Σε ορισμένες οθόνες, όπως η λίστα του ιστορικού κλήσεων, μπορείτε επίσης να πραγματοποιήσετε κύλιση προς τα πάνω ή κάτω.



Κίνηση κλειδώματος οθόνης
 Κίνηση κλειδώματος οθόνης - Καθορίστε μια κίνηση για τις 9 συντομεύσεις εφαρμογών. Η Κίνηση κλειδώματος οθόνης δίνει στους χρήστες τη δυνατότητα να ξεκλειδώνουν το τηλέφωνο και να εκτελούν τις εφαρμογές απευθείας, σχεδιάζοντας μια κίνηση στην οθόνη. Για να ρυθμίσετε αυτή τη δυνατότητα,

- 1 Επιλέξτε  - Οθόνες - Κίνηση κλειδώματος οθόνης
- 2 Σύρετε την κίνηση που θέλετε από το κάτω μέρος της οθόνης και μεταφέρετέ τη στις εφαρμογές στις οποίες θέλετε να την αντιστοιχίσετε.


ΣΥΜΒΟΥΛΗ! Σχεδιάστε το σύμβολο ? για να μεταβείτε στο μενού "Κίνηση κλειδώματος οθόνης", στην οθόνη κλειδώματος.



Η αρχική οθόνη

Σε κάθε τύπο αρχικής οθόνης μπορείτε να μεταφέρετε και να κάνετε απευθείας κλικ στην επιλογή που θέλετε.


Ενεργό



Αρχική οθόνη χρήσιμων εφαρμογών - Όταν πατάτε  κάτω δεξιά στην οθόνη, εμφανίζεται ο πίνακας χρήσιμων εφαρμογών για κινητά. Όταν καταχωρείτε τη χρήσιμη εφαρμογή με μεταφορά, η χρήσιμη εφαρμογή δημιουργείται στη θέση όπου έγινε η απόθεση.

Ενεργό



Αρχική οθόνη ταχείας κλήσης - Όταν πατάτε , εμφανίζεται η λίστα ταχείας κλήσης. Μπορείτε να πραγματοποιήσετε κλήση, να στείλετε μήνυμα ή να επεξεργαστείτε την επαφή απευθείας από αυτήν την αρχική οθόνη.

Ενεργό



Αρχική οθόνη Livesquare - Στην οθόνη Livesquare μπορείτε εύκολα να πραγματοποιήσετε κλήση και να στείλετε μήνυμα στον αριθμό που αντιστοιχεί σε ένα avatar. Για να χρησιμοποιήσετε τη λειτουργία κλήσης, μηνυμάτων ή επαφών, επιλέξτε avatar και πατήστε το εικονίδιο **Γρήγ. πλήκτρο** που θέλετε να χρησιμοποιήσετε.

ΣΥΜΒΟΥΛΗ! Το περιβάλλον εργασίας χρήστη βασίζεται σε τρεις τύπους Αρχικής οθόνης. Για να πραγματοποιήσετε εναλλαγή μεταξύ των αρχικών οθονών, απλώς σύρετε γρήγορα πάνω στην οθόνη από τα αριστερά προς τα δεξιά ή από τα δεξιά προς τα αριστερά.

Η αρχική οθόνη

Πλήκτρα άμεσης πρόσβασης

Τα πλήκτρα γρήγορης πρόσβασης στην αρχική οθόνη παρέχουν εύκολη πρόσβαση με ένα πάτημα στις λειτουργίες που χρησιμοποιείτε περισσότερο.



Πατήστε το για να εμφανίσετε το πληκτρολόγιο αφής και να πραγματοποιήσετε μια κλήση.



Πατήστε για να ανοίξετε τις **Επαφές**. Για να αναζητήσετε τον αριθμό που θέλετε να καλέσετε, πληκτρολογήστε το όνομα της επαφής στο πάνω μέρος της οθόνης με το πληκτρολόγιο αφής. Μπορείτε, επίσης, να δημιουργήσετε νέες επαφές και να επεξεργαστείτε τις ήδη υπάρχουσες.



Πατήστε το για να αποκτήσετε πρόσβαση στο μενού **Μηνύματα**. Από εδώ μπορείτε να δημιουργήσετε ένα νέο SMS ή MMS ή να δείτε το φάκελο με τα μηνυμάτά σας.




Πατήστε το για να ανοίξετε το πλήρες **Μενού ανώτερου επιπέδου**, το οποίο χωρίζεται σε τέσσερις κατηγορίες.


Η αρχική οθόνη

Αλλαγή κατάστασης από τη γραμμή κατάστασης

Πατήστε το κέντρο της γραμμής κατάστασης, για να ανοίξει το στοιχείο Κατάσταση. Εμφανίζει την τρέχουσα ώρα, το δίκτυο, το αναγνωριστικό SVC, καθώς και πληροφορίες για την κατάσταση της μπαταρίας, της μνήμης του τηλεφώνου, της εξωτερικής μνήμης, του προφίλ και των λειτουργιών MP3 και Bluetooth. Εδώ μπορείτε να ορίσετε τον τύπο του προφίλ, να πραγματοποιήσετε αναπαραγωγή/παύση MP3 και να ενεργοποιήσετε/απενεργοποιήσετε το Bluetooth.

Χρήση της λειτουργίας πολλαπλών εργασιών










Πατήστε το πλήκτρο πολλαπλών εργασιών  της συσκευής για να ανοίξετε το μενού "Πολλαπλές εργασίες". Από εδώ μπορείτε να δείτε όλες τις εφαρμογές που εκτελούνται και να αποκτήσετε πρόσβαση σε αυτές με ένα πάτημα.

Όταν δεν εκτελείται καμία εφαρμογή στο παρασκήνιο (π.χ. ένα παιχνίδι ή το ραδιόφωνο), στη γραμμή εργασιών θα εμφανιστεί το εικονίδιο .

Γραμμή κατάσταση

Η γραμμή κατάστασης χρησιμοποιεί διάφορα εικονίδια ως ενδείξεις στοιχείων, όπως η ισχύς του σήματος, τα νέα μηνύματα και η διάρκεια ζωής της μπαταρίας, ενώ σας ενημερώνει εάν είναι ενεργοποιημένη η λειτουργία Bluetooth ή GPRS.




Στη συνέχεια, ακολουθεί ένας πίνακας, ο οποίος εξηγεί το νόημα των εικονιδίων που πιθανότατα θα δείτε στη γραμμή κατάστασης.

Εικονίδιο	Περιγραφή
	Πολλαπλές εργασίες
	Ισχύς σήματος δικτύου (ο αριθμός των γραμμών διαφέρει)
	Δεν υπάρχει σήμα δικτύου
	Υπόλοιπο διάρκειας ζωής μπαταρίας
	Κενή μπαταρία
	Νέο SMS
	Νέο φωνητικό μήνυμα
	Ο φάκελος "Εισερχόμενα" είναι πλήρης
	Αποτυχία αποστολής μηνύματος


Εικονίδιο	Περιγραφή
	Η αποστολή μηνύματος πολυμέσων απέτυχε
	Ξυπνητήρι ενεργό
	Εξατομικευμένο προφίλ σε χρήση (Ο αριθμός του εικονιδίου ποικίλλει)
	Κανονικό προφίλ σε χρήση
	Προφίλ εξωτερικών χώρων σε χρήση
	Αθόρυβο προφίλ σε χρήση
	Ακουστικά σε χρήση
	Εκτροπή κλήσεων
	EDGE σε χρήση
	Περιορισμός
	Λειτουργία πτήσης ενεργή
	Bluetooth ενεργό
	Αναπαραγωγή BGM
	Παύση BGM
	Η κάρτα μνήμης έχει ενεργοποιηθεί για χρήση


Κλήσεις

Πραγματοποίηση κλήσης

- 1 Για να ανοίξετε το πληκτρολόγιο του κινητού, πατήστε .
 - 2 Πληκτρολογήστε τον αριθμό χρησιμοποιώντας το πληκτρολόγιο.
 - 3 Για να ξεκινήσει η κλήση, πατήστε .
 - 4 Για να τερματίσετε την κλήση, πατήστε το έξυπνο πλήκτρο.
- ΣΥΜΒΟΥΛΗ!** Για να εισαγάγετε το σύμβολο + προκειμένου να πραγματοποιήσετε διεθνή κλήση, πατήστε παρατεταμένα το .
- ΣΥΜΒΟΥΛΗ!** Πατήστε το πλήκτρο λειτουργίας για να κλειδώσετε την οθόνη αφής και να αποτραπεί η κατά λάθος πραγματοποίηση κλήσεων.



Πραγματοποίηση κλήσης από τις επαφές

- 1 Στην αρχική οθόνη, πατήστε  για να ανοίξετε τις **Επαφές**.
- 2 Πατήστε το πλαίσιο του πεδίου "Όνομα" στο πάνω μέρος της οθόνης και χρησιμοποιήστε το πληκτρολόγιο του κινητού για να εισαγάγετε τα πρώτα γράμματα της επαφής που θέλετε να καλέσετε.

- 3 Στη φιλτραρισμένη λίστα πατήστε το εικονίδιο "Κλήση", που βρίσκεται δίπλα στην επαφή που θέλετε να καλέσετε. Αν υπάρχουν πάνω από ένας αριθμοί για αυτήν την επαφή, για την κλήση θα χρησιμοποιηθεί ο προεπιλεγμένος αριθμός.
- 4 Εναλλακτικά, πατήστε το όνομα της επαφής και επιλέξτε τον αριθμό που θα χρησιμοποιηθεί, εάν υπάρχουν περισσότεροι από ένας αριθμοί για τη συγκεκριμένη επαφή. Μπορείτε ακόμη να πατήσετε  για να ξεκινήσει η κλήση στον προεπιλεγμένο αριθμό.

Απάντηση και απόρριψη κλήσης

Όταν χτυπάει το τηλέφωνο, πατήστε το Έξυπνο πλήκτρο για να απαντήσετε στην κλήση.


Για σίγαση του ήχου, σύρετε το κάλυμμα προς τα πάνω. Έτσι ξεκλειδώνετε το τηλέφωνο, αν είναι κλειδωμένο. Στη συνέχεια, πατήστε . Η λειτουργία αυτή χρησιμεύει αν έχετε ξεχάσει να αλλάξετε το προφίλ σας σε Σίγαση για μια συνάντηση. Για να απορρίψετε μια εισερχόμενη κλήση, πατήστε .




Ταχεία κλήση

Μπορείτε να αντιστοιχίσετε μια επαφή που καλείτε συχνά με έναν αριθμό ταχείας κλήσης.

- 1 Επιλέξτε **Επαφές** στην καρτέλα **ΕΠΙΚΟΙΝΩΝΙΑ** και επιλέξτε **Ταχείες κλήσεις**.
- 2 Το φωνητικό ταχυδρομείο έχει ήδη αντιστοιχιστεί στον αριθμό ταχείας κλήσης 1. Τη ρύθμιση αυτή δεν μπορείτε να την αλλάξετε. Πατήστε οποιονδήποτε άλλο αριθμό για να τον αντιστοιχίσετε σε μια επαφή ταχείας κλήσης.
- 3 Ανοίγουν οι Επαφές. Πατήστε μία φορά τον αριθμό τηλεφώνου, για να επιλέξετε την επαφή που θέλετε να αντιστοιχίσετε σε αυτόν τον αριθμό. Για να βρείτε μια επαφή, πατήστε το πλαίσιο του πεδίου Όνομα και πληκτρολογήστε το πρώτο γράμμα του ονόματος της επαφής που θέλετε.

Πραγματοποίηση δεύτερης κλήσης

- 1 Κατά τη διάρκεια της αρχικής κλήσης, πατήστε το  και πληκτρολογήστε τον αριθμό που θέλετε να καλέσετε.

- 2 Για να πραγματοποιήσετε την κλήση, πατήστε .
- 3 Στην οθόνη κλήσεων θα εμφανιστούν και οι δύο κλήσεις. Η αρχική σας κλήση θα είναι κλειδωμένη και ο συνομιλητής σας θα είναι σε αναμονή.
- 4 Για να πραγματοποιήσετε εναλλαγή μεταξύ των κλήσεων, πατήστε  ή πατήστε τον αριθμό της κλήσης που είναι σε αναμονή.
- 5 Για να τερματίσετε τη μία ή και τις δύο κλήσεις, πατήστε το  και επιλέξτε **Τέλος** και, στη συνέχεια, **Όλα, Αναμονή ή Ενεργό**.

ΣΥΜΒΟΥΛΗ! Επιλέξτε οποιαδήποτε καταχώρηση του αρχείου καταγραφής για να δείτε την ημερομηνία, την ώρα και τη διάρκεια της κλήσης.

ΣΗΜΕΙΩΣΗ: Θα χρεωθείτε για κάθε κλήση που πραγματοποιείτε.

Προβολή αρχείου καταγραφής κλήσεων

Πατήστε **Κλήσεις** στην καρτέλα **ΕΠΙΚΟΙΝΩΝΙΑ**.

Κλήσεις

ΣΥΜΒΟΥΛΗ! Επιλέξτε οποιαδήποτε καταχώρηση του αρχείου καταγραφής για να δείτε την ημερομηνία, την ώρα και τη διάρκεια της κλήσης.

Χρήση της εκτροπής κλήσεων

- 1 Πατήστε **Ρυθμίσεις κλήσεων** στην καρτέλα ΡΥΘΜΙΣΕΙΣ.
- 2 Πατήστε **Εκτροπή κλήσεων**.
- 3 Επιλέξτε εάν θα γίνεται εκτροπή όλων των φωνητικών κλήσεων, όταν είναι κατειλημμένη η γραμμή, όταν δεν υπάρχει απάντηση ή όταν δεν είστε διαθέσιμος.
- 4 Εισαγάγετε τον αριθμό στον οποίο θέλετε να γίνεται εκτροπή.
- 5 Για ενεργοποίηση, πατήστε **Αίτηση**.

ΣΗΜΕΙΩΣΗ: Η εκτροπή κλήσεων επιφέρει χρεώσεις. Για λεπτομέρειες, επικοινωνήστε με τον παροχέα δικτύου.

ΣΥΜΒΟΥΛΗ! Για να απενεργοποιήσετε όλες τις εκτροπές κλήσεων, επιλέξτε **Απενεργοποίηση όλων** από το μενού **Εκτροπή κλήσεων**.

Χρήση της φραγής κλήσεων

- 1 Πατήστε **Ρυθμίσεις κλήσεων** στην καρτέλα ΡΥΘΜΙΣΕΙΣ.
- 2 Πατήστε **Φραγή κλήσεων**.
- 3 Ενεργοποιήστε μία ή και τις έξι επιλογές:
Όλες οι εξερχόμενες
Διεθνείς εξερχόμενες
Εξερχόμενες διεθνείς κλήσεις εκτός από τη χώρα μου
Όλες οι εισερχόμενες
Εισερχόμενες στο εξωτερικό
Απενεργοποίηση όλων
- 4 Πληκτρολογήστε τον κωδικό φραγής κλήσεων. Για τη συγκεκριμένη υπηρεσία, συμβουλευτείτε τον παροχέα δικτύου.

ΣΥΜΒΟΥΛΗ!

Επιλέξτε **Κλ. καθορισμένων αριθμών** από το μενού **Ρυθμίσεις κλήσεων** για να ενεργοποιήσετε και να δημιουργήσετε μια λίστα με αριθμούς που μπορείτε να καλείτε από το τηλέφωνό σας. Θα χρειαστείτε τον κωδικό PIN2 από την εταιρεία κινητής τηλεφωνίας με την οποία συνεργάζεστε. Από το τηλέφωνό σας θα μπορείτε να καλείτε μόνο τους αριθμούς που περιλαμβάνονται στη λίστα καθορισμένων αριθμών.

Αλλαγή των ρυθμίσεων για κοινές κλήσεις

- 1 Πατήστε **Ρυθμίσεις κλήσεων** στην καρτέλα ΡΥΘΜΙΣΕΙΣ.
- 2 Πραγματοποιήστε κύλιση και πατήστε **Κοινές ρυθμίσεις**. Από εδώ μπορείτε να προσαρμόσετε τις ρυθμίσεις για τις παρακάτω επιλογές:

Απόρριψη κλήσης - Σύρετε το διακόπτη στην ένδειξη **Ενεργοπ.**, για να επισημάνετε την επιλογή "Απόρριψη λίστας". Μπορείτε να πατήσετε το πλαίσιο κειμένου για να επιλέξετε από όλες τις κλήσεις, συγκεκριμένες επαφές ή ομάδες, κλήσεις από μη καταχωρημένους αριθμούς (οι αριθμοί που δεν βρίσκονται στις επαφές σας) ή κλήσεις χωρίς αναγνώριση καλούντα. Πατήστε **Αποθήκευση** για να αλλάξετε τη ρύθμιση.

Αποστολή αριθμού μου - Επιλέξτε εάν θα εμφανίζεται ο αριθμός σας όταν καλείτε κάποιον.

Αυτόματη επανάκληση - Σύρετε το διακόπτη αριστερά για **Ενεργοπ.** ή δεξιά για **Απενεργοπ.**

Απάντηση με - Επιλέξτε αν θα απαντάτε στο τηλέφωνο με το πλήκτρο αποστολής ή με οποιοδήποτε πλήκτρο.

Υπενθύμιση λεπτού - Σύρετε το διακόπτη αριστερά, στην ένδειξη **Ενεργοπ.**, έτσι ώστε να ακούγεται ένας ήχος ανά λεπτό κατά τη διάρκεια της κλήσης.

Λειτουργία απάντησης BT - Επιλέξτε **Handsfree** για να μπορείτε να απαντάτε στις κλήσεις με ακουστικά Bluetooth ή επιλέξτε **Τηλέφωνο** για να απαντάτε στις κλήσεις πατώντας ένα πλήκτρο του τηλεφώνου.


Αποθήκευση νέου αριθμού - Για να αποθηκεύσετε νέο αριθμό, επιλέξτε **Ναι**.


Ανταλλαγή μηνυμάτων

Ανταλλαγή μηνυμάτων

Το GM360 συνδυάζει SMS και MMS σε ένα έξυπνο και εύχρηστο μενού.

Αποστολή μηνύματος


- 1 Πατήστε **Μηνύματα** στην καρτέλα ΕΠΙΚΟΙΝΩΝΙΑ. Στη συνέχεια, πατήστε **Νέο μήνυμα** για να ξεκινήσετε τη δημιουργία νέου μηνύματος.
- 2 Πατήστε **Εισαγ.** για να προσθέσετε εικόνα, βίντεο, ήχο, πρότυπο ή κάτι άλλο.
- 3 Πατήστε **Παραλήπτης** στο κάτω μέρος της οθόνης, για να εισαγάγετε τους παραλήπτες. Στη συνέχεια, εισαγάγετε τον αριθμό ή πατήστε  για να επιλέξετε επαφή. Μπορείτε ακόμη και να προσθέσετε πολλές επαφές.
- 4 Όταν είστε έτοιμοι, πατήστε **Αποστολή**.


 **ΠΡΟΕΙΔΟΠΟΙΗΣΗ:** Αν στο SMS προστεθεί εικόνα, βίντεο ή ήχος, το μήνυμα μετατρέπεται αυτόματα σε MMS και θα έχετε την αντίστοιχη χρέωση.

Εισαγωγή κειμένου


Υπάρχουν πέντε τρόποι εισαγωγής κειμένου:

Πληκτρολόγιο κινητού, πληκτρολόγιο υπολογιστή, οθόνη γραφής με το χέρι, πλαίσιο γραφής με το χέρι, διπλό πλαίσιο γραφής.

Για να επιλέξετε τη μέθοδο εισαγωγής, πατήστε  και επιλέξτε **Μέθοδος εισαγωγής**.

Για να ενεργοποιήσετε τη λειτουργία T9, πατήστε . Αυτό το εικονίδιο εμφανίζεται μόνο όταν επιλέγετε το **Πληκτρολόγιο κινητού** ως μέθοδο εισαγωγής δεδομένων.

Πατήστε  για να αλλάξετε τη γλώσσα εγγραφής.

Πατήστε  για να πραγματοποιήσετε εναλλαγή μεταξύ αριθμών, συμβόλων και κειμένου. Χρησιμοποιήστε το πλήκτρο **Shift** για αλλαγή μεταξύ πεζών και κεφαλαίων.

Λειτουργία T9

Η λειτουργία T9 χρησιμοποιεί ένα ενσωματωμένο λεξικό για να αναγνωρίζει τις λέξεις που γράφετε, σύμφωνα με την ακολουθία των πλήκτρων που πατάτε. Προβλέπει τη λέξη που θέλετε να εισαγάγετε και προτείνει εναλλακτικές λύσεις.


Αναγνώριση γραφής

Στη λειτουργία γραφής, εσείς απλώς γράφετε στην οθόνη και το GM360 μετατρέπει το χειρόγραφο σε μήνυμα. Επιλέξτε **Οθόνη γραφής με το χέρι** ή **Πλαίσιο γραφής με το χέρι**, ανάλογα με την προβολή που προτιμάτε.

Ρύθμιση e-mail

Πατήστε **Email** στην καρτέλα ΕΠΙΚΟΙΝΩΝΙΑ.

Αν δεν έχει δημιουργηθεί λογαριασμός email, εκκινήστε τον οδηγό ρύθμισης email και ολοκληρώστε τη διαδικασία.

Για να ελέγξετε και να επεξεργαστείτε τις ρυθμίσεις, επιλέξτε . Μπορείτε επίσης να ελέγξετε τις επιπλέον ρυθμίσεις που συμπληρώθηκαν αυτόματα κατά τη δημιουργία του λογαριασμού.

Ανάκτηση των email


Μπορείτε να ελέγχετε το λογαριασμό σας για νέα email, είτε αυτόματα είτε μη αυτόματα. Για μη αυτόματο έλεγχο:

- 1 Πατήστε **Email** στην καρτέλα ΕΠΙΚΟΙΝΩΝΙΑ.
- 2 Πατήστε το λογαριασμό που θέλετε να χρησιμοποιήσετε.
- 3 Επιλέξτε Εισερχόμενα.
- 4 Για λήψη e-mail, από το μενού Επιλογές επιλέξτε Ανάκτηση ή Συγχρονισμός.

Αποστολή email μέσω του νέου σας λογαριασμού

- 1 Πατήστε **Νέο Email**, για να ανοίξετε νέο email.
- 2 Ολοκληρώστε το μήνυμα.
- 3 Πατήστε **Αποστολή**, και το email θα σταλεί.

Αλλαγή των ρυθμίσεων e-mail

- 1 Πατήστε **Email** στην καρτέλα ΕΠΙΚΟΙΝΩΝΙΑ.
- 2 Πατήστε  και επιλέξτε **Ρυθμίσεις E-mail**. Στη συνέχεια, μπορείτε να προσαρμόσετε τις παρακάτω ρυθμίσεις:
Λογαριασμοί email
Προτιμώμενο e-mail

Ανταλλαγή μηνυμάτων

Άδεια για απάντηση Email

- Επιλέξτε αν θα επιτρέπεται η αποστολή μηνυμάτων επιβεβαίωσης ανάγνωσης.

Αίτηση για απάντηση Email

- Επιλέξτε αν θα ζητάτε μηνύματα επιβεβαίωσης ανάγνωσης.

Διάστημα ανάκτησης - Επιλέξτε πόσο συχνά το GM360 θα πραγματοποιεί ελέγχους για νέα μηνύματα email.

Αριθμός e-mail προς ανάκτηση - Επιλέξτε τον αριθμό των email που θα ανακτώνται κάθε φορά.

Συμπερίληψη μηνύματος σε προώθηση & απάντηση - Επιλέξτε να περιλαμβάνεται το αρχικό μήνυμα στην απάντησή σας.

Συμπερίληψη συνημμένου - Επιλέξτε να συμπεριλαμβάνεται το αρχικό συνημμένο σε κάθε απάντηση.

Αυτ. ανάκτ. σε περιαγωγή

- Επιλέξτε αν θα γίνεται αυτόματη ανάκτηση των μηνυμάτων σας όταν βρίσκεστε στο εξωτερικό (περιαγωγή).

Ειδοποίηση νέου e-mail - Επιλέξτε αν θα ειδοποιείστε για νέα email.

Υπογραφή - Ενεργοποιήστε αυτή τη λειτουργία (**Ενεργοπ.**) και δημιουργήστε υπογραφή email.

Προτεραιότητα - Επιλέξτε το επίπεδο προτεραιότητας των μηνυμάτων e-mail.

Μέγεθος αποστολής e-mail

- Ορίστε μέγιστο μέγεθος για την αποστολή email.

Μετρητής e-mail - Εισαγάγετε την ημερομηνία που θέλετε. Μπορείτε να ελέγξετε τα email που στείλατε κατά τη διάρκεια αυτής της περιόδου.

Φάκελοι μηνυμάτων

Υπάρχουν πέντε φάκελοι στο μενού "Μηνύματα".

Εισερχόμενα - Όλα τα μηνύματα που λαμβάνετε τοποθετούνται στα εισερχόμενα.

Πρόχειρα - Εάν δεν ολοκληρώσετε τη δημιουργία ενός μηνύματος, μπορείτε να το αποθηκεύσετε ως πρόχειρο σε αυτόν το φάκελο.

Εξερχόμενα - Αυτός ο φάκελος χρησιμοποιείται για την προσωρινή αποθήκευση των μηνυμάτων κατά την αποστολή τους.

Απεσταλμένα - Όλα τα μηνύματα που έχετε στείλει τοποθετούνται σε αυτόν το φάκελο.

Φάκελοι - Δημιουργήστε φακέλους για να αποθηκεύετε τα μηνυμάτά σας.

Αλλαγή ρυθμίσεων για τα μηνύματα πολυμέσων

Πατήστε **Μηνύματα** στην καρτέλα ΕΠΙΚΟΙΝΩΝΙΑ. Πραγματοποιήστε κύλιση και επιλέξτε **Ρυθμίσεις** και **Μήνυμα πολυμέσων**. Μπορείτε να κάνετε τις εξής αλλαγές:

Τύπος ανάκτησης - Επιλέξτε μεταξύ των στοιχείων **Τοπικό δίκτυο** ή **Δίκτυο περιαγωγής**. Εάν, στη συνέχεια, επιλέξετε **Χειροκίνητα**, θα λαμβάνετε μόνο ειδοποιήσεις για MMS και έπειτα θα αποφασίζετε εάν θέλετε να τα λάβετε ή όχι.

Αναφορά παράδοσης - Επιλέξτε αν θα δέχεστε ή/και θα ζητάτε αναφορές παράδοσης.

Αναφορά ανάγνωσης - Επιλέξτε αν θα δέχεστε ή/και θα ζητάτε αναφορές ανάγνωσης.

Προτεραιότητα - Επιλέξτε το επίπεδο προτεραιότητας των μηνυμάτων MMS.

Περίοδος ισχύος - Επιλέξτε το χρονικό διάστημα για το οποίο θα

αποθηκεύονται τα μηνυμάτά σας στο κέντρο μηνυμάτων.

Διάρκεια slide - Επιλέξτε την προεπιλεγμένη διάρκεια εμφάνισης των slide στην οθόνη.

Δημιουργία - Επιλέξτε αν τα μηνύματα πολυμέσων θα δημιουργούνται ελεύθερα ή με περιορισμούς.

Χρόνος παράδοσης - Επιλέξτε το χρονικό διάστημα που θα μεσολαβήσει μέχρι την παράδοση του μηνύματος.

Κέντρο MMS - Επιλέξτε ή προσθέστε κέντρο MMS.

Υπηρεσίες κοινωνικής δικτύωσης (SNS)

Το GM360 διαθέτει υπηρεσίες κοινωνικής δικτύωσης, με τις οποίες μπορείτε να απολαμβάνετε και να διαχειρίζεστε το κοινωνικό σας δίκτυο. Μπορείτε να ενημερώσετε την κατάσταση της θέσης σας στις υπηρεσίες κοινωνικής δικτύωσης, καθώς και να δείτε τις σχετικές ενημερώσεις των φίλων σας.

Πατήστε το μενού **Social network** και επιλέξτε μεταξύ των παρακάτω τοποθεσιών: Facebook, Twitter και Myspace.

Ανταλλαγή μηνυμάτων

ΣΥΜΒΟΥΛΗ! Το Facebook είναι μια ενσωματωμένη, προφορτωμένη εφαρμογή του τηλεφώνου, με ευκολία πρόσβασης. Το Twitter είναι μια εφαρμογή που βασίζεται σε τεχνολογία Java. Άλλες εφαρμογές μπορούν να χρησιμοποιήσουν το πρωτόκολλο WAP (Πρωτόκολλο ασύρματων εφαρμογών).

ΣΗΜΕΙΩΣΗ: Η δυνατότητα SNS είναι μια εφαρμογή που καταναλώνει μεγάλο όγκο δεδομένων. Όταν συνδέεστε σε διαδικτυακές υπηρεσίες και τις χρησιμοποιείτε, ενδέχεται να υπάρξουν πρόσθετες χρεώσεις. Για πληροφορίες σχετικά με τις χρεώσεις δεδομένων, συμβουλευτείτε τον παροχέα υπηρεσιών.

Facebook

Αρχική σελίδα: Όταν συνδεθείτε, βλέπετε την ενημερωμένη κατάσταση των φίλων σας. Εισαγάγετε το σχολίο σας σχετικά με τη νέα κατάσταση ή ελέγξτε άλλες καταστάσεις. Πατήστε “Επιλογές”, για να επιλέξετε “Ανανέωση”, “Φίλτρο News Feed” (Ενημερ. κατάσταση, Φωτογραφία), “Διαγραφή” ή “Αποσύνδεση”. Επίσης, για να γράψετε σχόλια, επιλέξτε το εικονίδιο +.

Προφίλ: Μπορείτε να επιλέξετε Τοίχος > “Ενημερώσεις κατάστασης” και να γράψετε την τρέχουσα κατάσταση. Δείτε λεπτομέρειες και ανεβάστε τη φωτογραφία σας. Απλώς πατήστε Φωτογραφίες > Ανέβασμα φωτογραφιών. Επιλέξτε “Μετάβαση στις εικόνες” ή “Τραβήξτε μια φωτογραφία” και, στη συνέχεια, εισαγάγετε μια λεζάντα με εικόνες.

Φίλοι: Μπορείτε να βρείτε πολλούς φίλους στις υπηρεσίες κοινωνικής δικτύωσης και να δείτε την κατάστασή τους. Για να αναζητήσετε φίλους στο Facebook, επιλέξτε “Αναζήτηση”.

Μηνύματα: Εμφανίζονται όλα τα προσωπικά σας μηνύματα κοινωνικής δικτύωσης. Μπορείτε να δείτε το φάκελο εισερχομένων/εξερχομένων και να γράψετε μήνυμα κοινωνικής δικτύωσης.

ΣΥΜΒΟΥΛΗ! Χρήση της χρήσιμης εφαρμογής τροφοδοσίας του Facebook: Μπορείτε να προσθέσετε τη χρήσιμη εφαρμογή τροφοδοσίας του Facebook στην αρχική οθόνη. Σύρετε τη χρήσιμη εφαρμογή τροφοδοσίας του Facebook από την περιοχή χρήσιμων εφαρμογών και πατήστε **OK**. Αν η χρήσιμη εφαρμογή τροφοδοσίας του Facebook έχει καταχωρηθεί στην αρχική οθόνη, θα εμφανίζονται οι 3 πιο πρόσφατες τροφοδοσίες από την τοποθεσία κοινωνικής δικτύωσης. Επίσης, αν πατήσετε τη χρήσιμη εφαρμογή τροφοδοσίας, αποκτάτε απευθείας πρόσβαση στην εφαρμογή του Facebook.




Στις ρυθμίσεις του SNS, υπάρχουν οι επιλογές Ενεργοποίηση/ Απενεργοποίηση SNS, Σύνδεση σε λογαριασμό SNS και Διαγραφή (αποσύνδεση). Η λειτουργία SNS μπορεί να ενεργοποιείται και να απενεργοποιείται αυτόματα, αν καθορίσετε ένα συγκεκριμένο χρονικό διάστημα στο μενού Αυτόματη σύνδεση.

Βιβλίο συνδέσμων


Αν η λειτουργία SNS είναι ενεργοποιημένη, ο πελάτης SNS μπορεί να ενημερώνει τα προσωπικά στοιχεία του προφίλ, όπως όνομα, αριθμός τηλεφώνου, διεύθυνση e-mail και φωτογραφία, από τη λειτουργία των Επαφών "Αποθήκευση σε επαφή". Αν η λειτουργία SNS είναι απενεργοποιημένη, οι πληροφορίες από το SNS δεν εμφανίζονται στη λίστα επαφών.

Φωτογραφική μηχανή

Γρήγορη λήψη φωτογραφίας


- 1 Πατήστε το πλήκτρο  στη δεξιά πλευρά του τηλεφώνου.
- 2 Όταν η κάμερα εστιαστεί στο θέμα σας, πατήστε  στη δεξιά πλευρά του κέντρου της οθόνης, για να τραβήξετε φωτογραφία. Μπορείτε επίσης να πατήσετε σταθερά το πλήκτρο  στο πλάι του τηλεφώνου.


ΣΥΜΒΟΥΛΗ! Για να μεταβείτε στη λειτουργία κάμερας ή βίντεο, σύρετε προς τα πάνω ή προς τα κάτω το εικονίδιο κάμερας ή βίντεο, που βρίσκεται κάτω δεξιά στο σκόπευτρο.





Μετά τη λήψη φωτογραφίας


Στην οθόνη θα εμφανιστεί η φωτογραφία που έχετε τραβήξει. Το όνομα της εικόνας θα εμφανίζεται στο κάτω μέρος της οθόνης.


 Πατήστε για αποστολή της φωτογραφίας ως μηνύματος, email ή μέσω Bluetooth.


 Πατήστε για να ορίσετε εικόνα στην Αρχική οθόνη.

 Πατήστε για να επεξεργαστείτε τη φωτογραφία.


 Πατήστε το για να επεξεργαστείτε το όνομα της επιλεγμένης φωτογραφίας.

 Πατήστε το για να διαγράψετε τη φωτογραφία που μόλις τραβήξατε και πατήστε **Ναι** για επιβεβαίωση. Εμφανίζεται το μήνυμα "Διαγράφηκε".

 Πατήστε το για μετακίνηση στη συλλογή.



Βιντεοκάμερα



Γρήγορη λήψη βίντεο

- 1 Πατήστε για μερικά δευτερόλεπτα το πλήκτρο κάμερας στη δεξιά πλευρά του τηλεφώνου.

ΣΥΜΒΟΥΛΗ! Για να μεταβείτε στη λειτουργία κάμερας ή βίντεο, σύρετε προς τα πάνω ή προς τα κάτω το εικονίδιο κάμερας ή βίντεο, που βρίσκεται στο κέντρο και δεξιά στο σκόπευτρο.

- 2 Κρατήστε το τηλέφωνο οριζόντια και στρέψτε το φακό προς το αντικείμενο του βίντεο.

- 3 Πατήστε το πλήκτρο κάμερας του τηλεφώνου μία φορά, για να ξεκινήσει η εγγραφή. Αλλιώς, πατήστε την κόκκινη κουκκίδα.
- 4 Η ένδειξη **Rec** εμφανίζεται στο κάτω μέρος του σκοπεύτρου, με ένα χρονόμετρο που δείχνει τη διάρκεια του βίντεο.
- 5 Για παύση του βίντεο, πατήστε και επιλέξτε για να συνεχίσετε.
- 6 Για να διακόψετε την εγγραφή, πατήστε στην οθόνη ή πατήστε για δεύτερη φορά.

Μετά τη λήψη βίντεο

- ▶ Πατήστε το για αναπαραγωγή του βίντεο.
- ✉ Πατήστε το για να στείλετε το βίντεο με **Μήνυμα ή Email** ή μέσω **Bluetooth**.
- 📷 Πατήστε το για να επεξεργαστείτε το όνομα της επιλεγμένης φωτογραφίας.
- 📷 Πατήστε το για να επεξεργαστείτε το βίντεο.
- 🗑️ Πατήστε το για να διαγράψετε το βίντεο που μόλις τραβήξατε, και πατήστε **Ναι** για επιβεβαίωση. Το σκόπευτρο θα εμφανιστεί ξανά. Πατήστε για να τραβήξετε άλλο βίντεο απευθείας.

Βιντεοκάμερα

📷 Πατήστε το για να εμφανιστεί μια συλλογή των αποθηκευμένων βίντεο και φωτογραφιών.



Φωτογραφίες και βίντεο

Προβολή φωτογραφιών και βίντεο

- 1 Πατήστε **Συλλογή** στην καρτέλα **ΨΥΧΑΓΩΓΙΑ**. Αλλιώς, πατήστε 📷 στην οθόνη προεπισκόπησης της κάμερας. Μπορείτε να ελέγξετε τις φωτογραφίες και τα βίντεό σας.
- 2 Στην οθόνη θα εμφανιστεί η συλλογή σας.
- 3 Πατήστε το βίντεο ή τη φωτογραφία, για να ανοίξει κανονικά.
- 4 Για αναπαραγωγή του βίντεο, πατήστε ▶. Για παύση της αναπαραγωγής, πατήστε το ⏏.

ΣΥΜΒΟΥΛΗ! Μετακινήστε το δείκτη προς τα αριστερά ή προς τα δεξιά, για να δείτε άλλες φωτογραφίες ή βίντεο.

⚠️ ΠΡΟΕΙΔΟΠΟΙΗΣΗ:
Ορισμένες λειτουργίες μπορεί να μην αποδίδουν σωστά, εάν το αρχείο πολυμέσων δεν έχει εγγραφεί στο τηλέφωνο.


Προβολή φωτογραφιών ως παρουσίασης


Η λειτουργία παρουσίασης εμφανίζει μία-μία όλες τις φωτογραφίες που υπάρχουν στη συλλογή, με τη μορφή παρουσίασης. Τα βίντεο δεν μπορούν να προβληθούν σε παρουσίαση.


1 Πατήστε  στη **Συλλογή**, και έπειτα πραγματοποιήστε κύλιση και επιλέξτε **Παρουσίαση**.


2 Ξεκινάει η παρουσίαση.


Υπάρχουν διάφορες επιλογές κατά τη διάρκεια των παρουσιάσεων:

Πατήστε  για να επιστρέψετε.

 Πατήστε το για να διακόψετε προσωρινά την παρουσίαση σε μια συγκεκριμένη φωτογραφία.

 Πατήστε το ξανά για να συνεχίσετε την αναπαραγωγή.

 Πατήστε το για να γίνει τυχαία προβολή.

 Πατήστε το για να αυξήσετε ή να μειώσετε την ταχύτητα της παρουσίασης.


Ορισμός φωτογραφίας ως φόντου

1 Πατήστε **Συλλογή** στην καρτέλα **ΨΥΧΑΓΩΓΙΑ**.

2 Πατήστε τη φωτογραφία που θέλετε να ορίσετε ως φόντο.

3 Πατήστε στην οθόνη για να ανοίξετε το μενού.

4 Πατήστε .

5 Μπορείτε να αλλάξετε το μέγεθος της φωτογραφίας με .

6 Όταν είστε ικανοποιημένοι με τη φωτογραφία, πατήστε **OK**.


7 Επιλέξτε μεταξύ των στοιχείων που θέλετε να αλλάξετε: **Όλα**, **Χρήσιμη εφαρμογή**, **Ταχεία κλήση**.

Πολυμέσα

Στη μνήμη του τηλεφώνου σας μπορείτε να αποθηκεύσετε όποια αρχεία πολυμέσων θέλετε, έτσι ώστε να έχετε εύκολη πρόσβαση σε όλες τις φωτογραφίες, τους ήχους, τα βίντεο και τα παιχνίδια σας. Επίσης, μπορείτε να αποθηκεύσετε τα αρχεία σας σε μια κάρτα μνήμης. Όταν χρησιμοποιείτε κάρτα μνήμης, μπορείτε να απελευθερώσετε χώρο στη μνήμη του τηλεφώνου. Μπορείτε να βρείτε αυτά τα αρχεία στο μενού **Αρχεία** στην καρτέλα ΨΥΧΑΓΩΓΙΑ.

Χρήση εικόνας

Μπορείτε να επιλέξετε εικόνες για να τις χρησιμοποιήσετε ως φόντο ή για την κλειδωμένη οθόνη, ή ακόμα και ως μέσο αναγνώρισης καλούντα.

- 1 Πατήστε **Αρχεία** στην καρτέλα ΨΥΧΑΓΩΓΙΑ και επιλέξτε **Εικόνες**. Επιλέξτε την εικόνα που θέλετε. Στη συνέχεια, πατήστε .
- 2 Πατήστε **Χρήση ως** και επιλέξτε μεταξύ των παρακάτω:
Εικόνα αρχικής οθόν. - Ορίστε φόντο για την αρχική οθόνη.
Εικόνα κλειδ. οθόνης - Ορίστε φόντο για την κλειδωμένη οθόνη.
Εικόνα επαφών - Αντιστοιχίστε μια εικόνα σε ένα συγκεκριμένο


άτομο στη λίστα επαφών, ώστε να εμφανίζεται η εικόνα όταν σας καλεί.

Εικόνα έναρξης - Ορίστε μια εικόνα που θα εμφανίζεται όταν ενεργοποιείτε το τηλέφωνο.


Εικόνα τερματισμού - Ορίστε μια εικόνα που θα εμφανίζεται όταν απενεργοποιείτε το τηλέφωνο.

Μεταφορά ή αντιγραφή εικόνας

Μπορείτε να μεταφέρετε ή να αντιγράψετε μια εικόνα μεταξύ της μνήμης του τηλεφώνου και της κάρτας μνήμης. Αυτή η διαδικασία γίνεται είτε για να απελευθερώσετε χώρο σε μία από τις μνήμες είτε για να προστατεύσετε τις εικόνες σας από το ενδεχόμενο απώλειας.

- 1 Πατήστε **Αρχεία** στην καρτέλα ΨΥΧΑΓΩΓΙΑ, επιλέξτε **Εικόνες** και πατήστε .
- 2 Επιλέξτε **Μετακίνηση** ή **Αντιγραφή**.
- 3 Μπορείτε να επιλέξετε/ αποεπιλέξετε τις εικόνες με διαδοχικά πατήματα. Επιλέξτε την εικόνα που θέλετε να μετακινήσετε ή να αντιγράψετε, και πατήστε **Αντιγραφή/Μετακίνηση**.

Χρήση ήχου

- 1 Πατήστε **Αρχεία** στην καρτέλα ΨΥΧΑΓΩΓΙΑ και επιλέξτε **Ήχοι**.
- 2 Όταν επιλέξετε έναν ήχο που θέλετε, εμφανίζεται ένα μήνυμα επιβεβαίωσης.
- 3 Πατήστε **Ναι**. Θα ξεκινήσει η αναπαραγωγή.
- 4 Πατήστε  και επιλέξτε **Χρήση ως**.
- 5 Επιλέξτε **Ήχος κλήσης, Ήχος μηνύματος, Εκκίνηση ή Τερματισμός**.

Μουσική

Το LG GM360 διαθέτει ενσωματωμένο πρόγραμμα αναπαραγωγής μουσικής, ώστε να μπορείτε να ακούτε όλα τα αγαπημένα σας κομμάτια. Για να μεταβείτε στο πρόγραμμα αναπαραγωγής μουσικής, πατήστε **Μουσική** στην καρτέλα ΨΥΧΑΓΩΓΙΑ. Από εδώ μπορείτε να αποκτήσετε πρόσβαση σε πολλούς φακέλους:

Πρόσφατη αναπαραγωγή - Αναπαράγονται τα τραγούδια που ακούσατε πρόσφατα.

ΣΗΜΕΙΩΣΗ: Τα πνευματικά δικαιώματα των αρχείων μουσικής προστατεύονται από διεθνείς συνθήκες και από την εγχώρια νομοθεσία για τα πνευματικά δικαιώματα. Ενδέχεται να χρειάζεται να λάβετε σχετική άδεια για να πραγματοποιήσετε αναπαραγωγή ή αντιγραφή μουσικής. Σε ορισμένες χώρες οι διατάξεις του νόμου απαγορεύουν την αντιγραφή από ιδιώτες υλικού που προστατεύεται από τους νόμους περί πνευματικών δικαιωμάτων. Πριν από τη λήψη ή την αντιγραφή του αρχείου, ελέγξτε τις νομικές διατάξεις που ισχύουν στη χώρα σας σχετικά με τη χρήση παρόμοιου υλικού.

Όλα τα κομμάτια - Περιέχει όλα τα τραγούδια που έχετε στο τηλέφωνο, εκτός από την προεπιλεγμένη προφορτωμένη μουσική.

Καλλιτέχνες - Περιηγηθείτε στη μουσική σας συλλογή κατά καλλιτέχνη.

Άλμπουμ - Περιηγηθείτε στη μουσική σας συλλογή κατά άλμπουμ.

Είδη - Περιηγηθείτε στη μουσική σας συλλογή κατά είδος.

Λίστες αναπαραγωγής
- Περιλαμβάνει όλες τις λίστες

Πολυμέσα

αναπαραγωγής που έχετε δημιουργήσει.

Τυχαία αναπαραγωγή - Ακούστε τα κομμάτια σας σε τυχαία σειρά.

Μεταφορά μουσικής στο τηλέφωνο

Ο πιο εύκολος τρόπος για να μεταφέρετε μουσική στο τηλέφωνό σας είναι μέσω Bluetooth ή μέσω του καλωδίου συγχρονισμού.

Μπορείτε επίσης να χρησιμοποιήσετε το λογισμικό LG PC Suite. Για να πραγματοποιήσετε μεταφορά μέσω Bluetooth:

- 1 Βεβαιωθείτε ότι και οι δύο συσκευές διαθέτουν ενεργοποιημένη λειτουργία Bluetooth και είναι ορατές μεταξύ τους.
- 2 Επιλέξτε το αρχείο μουσικής στην άλλη συσκευή και επιλέξτε αποστολή μέσω Bluetooth.
- 3 Όταν το αρχείο είναι έτοιμο για αποστολή, πρέπει να πατήσετε **Ναι** για να το λάβετε στο τηλέφωνό σας.
- 4 Το αρχείο θα πρέπει να εμφανιστεί στο φάκελο **Μουσική > Όλα τα κομμάτια**.

Δημιουργία λίστας αναπαραγωγής

Για να δημιουργήσετε τις δικές σας λίστες αναπαραγωγής, επιλέξτε διάφορα τραγούδια από το φάκελο **Λίστες αναπαραγωγής**.

- 1 Πατήστε **Μουσική** στην καρτέλα ΨΥΧΑΓΩΓΙΑ.
- 2 Πατήστε **Λίστες αναπαραγωγής**, επιλέξτε **Προσθήκη νέας λίστας αναπαραγωγής**, εισαγάγετε το όνομα της λίστας αναπαραγωγής και πατήστε **Αποθήκευση**.
- 3 Ο φάκελος **Όλα τα κομμάτια** θα εμφανίσει όλα τα τραγούδια που υπάρχουν στο τηλέφωνό σας. Επιλέξτε όλα τα τραγούδια που θέλετε να συμπεριλάβετε στη λίστα αναπαραγωγής. Δίπλα στο όνομα κάθε τραγουδιού θα εμφανιστεί ένα σύμβολο επιλογής.
- 4 Πατήστε **Τέλος**.

Ραδιόφωνο FM


Το LG GM360 διαθέτει λειτουργία ραδιοφώνου FM, ώστε να μπορείτε να συντονίζεστε στους αγαπημένους σας σταθμούς και να τους ακούτε όταν μετακινείστε.

Για την ακρόαση ραδιοφώνου, πρέπει να συνδέσετε τα ακουστικά σας.

Αναζήτηση σταθμών


Για να συντονίσετε το τηλέφωνό σας σε ραδιοφωνικούς σταθμούς, πραγματοποιήστε αυτόματη ή μη αυτόματη αναζήτηση. Οι σταθμοί θα αποθηκευτούν σε συγκεκριμένους αριθμούς καναλιών, έτσι ώστε να μην χρειάζεται να επαναλάβετε το συντονισμό. Πρέπει να συνδέσετε πρώτα το σετ ακουστικών στο τηλέφωνο, καθώς λειτουργεί ως κεραία.

Για αυτόματο συντονισμό:

- 1 Πραγματοποιήστε κύλιση και πατήστε **Ραδιόφωνο FM** στην καρτέλα ΨΥΧΑΓΩΓΙΑ. Στη συνέχεια, πατήστε .
- 2 Πατήστε **Αυτόματη αναζήτηση**. Εμφανίζεται ένα μήνυμα επιβεβαίωσης. Επιλέξτε **Ναι**. Στη συνέχεια, οι σταθμοί βρίσκονται αυτόματα και αντιστοιχίζονται σε ένα κανάλι του τηλεφώνου.


ΣΗΜΕΙΩΣΗ: Μπορείτε επίσης να πραγματοποιήσετε μη αυτόματο συντονισμό με ένα σταθμό, επιλέγοντας ◀ και ▶ στο κέντρο της οθόνης. Εάν πατήσετε παρατεταμένα τα πλήκτρα ◀ και ▶, θα γίνει αυτόματη εύρεση των σταθμών.

Επαναφορά καναλιών

- 1 Πραγματοποιήστε κύλιση και πατήστε **Ραδιόφωνο FM** στην καρτέλα ΨΥΧΑΓΩΓΙΑ. Στη συνέχεια, πατήστε .
- 2 Για επαναφορά του καναλιού, επιλέξτε Επαναφορά καναλιού. Για επαναφορά όλων των καναλιών, επιλέξτε Επαναφορά όλων των καναλιών. Όλα τα κανάλια θα επανέλθουν στην αρχική συχνότητα των 87,5 Mhz.

Ατζέντα

Προσθήκη συμβάντος στο ημερολόγιο

- 1 Πατήστε **Ατζέντα** στην καρτέλα ΕΦΑΡΜΟΓΕΣ και επιλέξτε **Ημερολόγιο**.
- 2 Επιλέξτε την ημερομηνία στην οποία θέλετε να προσθέσετε ένα συμβάν.
- 3 Πατήστε  και επιλέξτε **Προσθήκη συμβάντος**.
- 4 Πατήστε **Κατηγορία** και επιλέξτε **Συνάντηση, Επέτειος ή Γενέθλια**.
- 5 Εισαγάγετε **Θέμα**.
- 6 Ελέγξτε και εισαγάγετε την ημερομηνία και την ώρα που θέλετε να ξεκινάει το συμβάν.
- 7 Ρυθμίστε τις επιλογές **Αφύπνιση** και **Επανάληψη**.
- 8 Επιλέξτε **Αποθ.** και το συμβάν θα αποθηκευτεί στο ημερολόγιο. Ένας τετράγωνος δείκτης θα σημειώσει την ημέρα στην οποία έχουν αποθηκευτεί συμβάντα ενώ κατά το χρόνο έναρξης θα ακουστεί ένα κουδούνισμα, ώστε να μπορείτε να είστε οργανωμένοι.

Προσθήκη σημείωσης

- 1 Πατήστε **Σημειώσεις** στην καρτέλα ΕΦΑΡΜΟΓΕΣ.

- 2 Πατήστε **Προσθήκη σημείωσης**.
- 3 Πληκτρολογήστε τη σημείωση και, στη συνέχεια, πατήστε “Αποθήκευση”.
- 4 Η σημείωση θα εμφανιστεί στην οθόνη, στην εφαρμογή **Σημειώσεις**.

Ρύθμιση αφύπνισης

- 1 Πατήστε **Αφύπνιση** στην καρτέλα ΕΦΑΡΜΟΓΕΣ. Το στοιχείο **Widget alarm** εμφανίζεται από προεπιλογή στη λίστα και δεν μπορείτε να το διαγράψετε.
- 2 Πατήστε **Προσθήκη αφύπνισης**.
- 3 Ρυθμίστε την ώρα που θέλετε να ηχήσει η αφύπνιση στο πλαίσιο του πεδίου **Ώρα**.
- 4 Επιλέξτε τρόπο επανάληψης της αφύπνισης στο πλαίσιο **Επανάληψη**:
- 5 Πατήστε **Τύπος αφύπνισης**, για να επιλέξετε τον τύπο αφύπνισης που θέλετε.
- 6 Επιλέξτε **Κουδούνι αφύπνισης** και, στη συνέχεια, επιλέξτε ήχο από το φάκελο.
- 7 Προσθέστε μια σημείωση για το ξυπνητήρι στο πλαίσιο **Σημειώσεις**.
- 8 Τέλος, μπορείτε να ορίσετε το διάστημα αναβολής αφύπνισης σε

5, 10, 20 ή 30 λεπτά, 1 ώρα ή να την απενεργοποιήσετε.

9 Αφού ρυθμίσετε την αφύπνιση, πατήστε **Αποθ.**

ΣΗΜΕΙΩΣΗ: Μπορείτε να ρυθμίσετε έως και 5 αφυπνίσεις, συμπεριλαμβανομένου του **Widget Alarm**.

ΣΥΜΒΟΥΛΗ! Για να ορίσετε την αφύπνιση, επιλέξτε **Ενεργοποίηση/Απενεργοποίηση**.

Αποτύπωση οθόνης



Το πλήκτρο της φωτογραφικής μηχανής βρίσκεται στη δεξιά πλευρά του τηλεφώνου. Αν το πατήσετε δύο φορές, η οθόνη αποτυπώνεται. Η εικόνα αποθηκεύεται στη Συλλογή, καθώς και στις Εικόνες στο φάκελο Αρχεία.

Η λειτουργία αυτή αποτυπώνει τις εξής οθόνες:

WAP, SNS, σύνταξη και προβολή e-mail, σύνταξη μηνύματος και εισερχόμενα μηνύματα κ.λπ.

Πλήκτρο φωτογραφικής μηχανής





Αν το πατήσετε δύο φορές, η οθόνη αποτυπώνεται.

Εγγραφή φωνής

Χρησιμοποιήστε τη λειτουργία φωνητικής εγγραφής για να εγγράψετε φωνητικές σημειώσεις ή άλλα αρχεία ήχου.

Πατήστε **Φωνητική εγγραφή** στην καρτέλα ΕΦΑΡΜΟΓΕΣ. Στη συνέχεια, επιλέξτε πρώτα  και έπειτα **Ρυθμίσεις**, για να αλλάξετε ρυθμίσεις.

Εγγραφή ήχου ή φωνής


- 1 Για να ξεκινήσετε την εγγραφή, πατήστε .
- 2 Για να διακόψετε προσωρινά την εγγραφή, πατήστε .
- 3 Για να τερματίσετε την εγγραφή,

Ατζέντα

πατήστε 

- 4 Πατήστε  για να ακούσετε την εγγραφή.

Χρήση του υπολογιστή

- 1 Πατήστε **Εργαλεία** στην καρτέλα ΕΦΑΡΜΟΓΕΣ.
- 2 Επιλέξτε **Υπολογιστής**.
- 3 Πατήστε τα αριθμητικά πλήκτρα στο πληκτρολόγιο του κινητού, για να εισάγετε αριθμούς.
- 4 Για απλούς υπολογισμούς, επιλέξτε την πράξη που θέλετε (+, -, *, /) και έπειτα πατήστε =.
- 5 Για πιο περίπλοκους υπολογισμούς, πατήστε  και επιλέξτε **sin, cos, tan, log, ln, exp, sqrt, deg** ή **rad** κ.λπ.



Μετατροπή μονάδων

- 1 Πατήστε **Εργαλεία** στην καρτέλα ΕΦΑΡΜΟΓΕΣ.
- 2 Επιλέξτε **Μετατροπéας μονάδων**.
- 3 Επιλέξτε το είδος της μετατροπής που θέλετε να κάνετε: **Νόμισμα, Επιφάνεια, Μήκος, Βάρος, Θερμοκρασία, Όγκος ή Ταχύτητα**.

Προσθήκη πόλης στο παγκόσμιο ρολόι

- 1 Πατήστε **Εργαλεία** στην καρτέλα

ΕΦΑΡΜΟΓΕΣ.

- 2 Επιλέξτε **Παγκόσμιο ρολόι**.
- 3 Πατήστε πρώτα  και έπειτα **Νέα πόλη**.
- 4 Πραγματοποιήστε κύλιση στη σφαίρα, πατήστε την περιοχή που θέλετε και επιλέξτε την πόλη στο χάρτη.
- 5 Εναλλακτικά, πατήστε  και πληκτρολογήστε το όνομα της πόλης που θέλετε στο πλαίσιο του πεδίου αναζήτησης.


Χρήση του χρονομέτρου

- 1 Πατήστε **Εργαλεία** στην καρτέλα ΕΦΑΡΜΟΓΕΣ.
- 2 Επιλέξτε **Χρονόμετρο**.
- 3 Πατήστε **Έναρξη** στο κάτω μέρος της οθόνης, για να ξεκινήσει το χρονόμετρο.
- 4 Εάν θέλετε να καταγράψετε έναν ενδιάμεσο χρόνο, πατήστε **Lap**.
- 5 Για να σταματήσετε το χρονόμετρο, πατήστε **Διακοπή**.
- 6 Επιλέξτε **Συνέχεια** για να επανεκκινήσετε το χρονόμετρο από το χρονικό σημείο που είχε σταματήσει ή επιλέξτε **Επαναφορά** για να ξεκινήσει η χρονομέτρηση από την αρχή.


Συγχρονισμός PC

Μπορείτε να συγχρονίσετε τον υπολογιστή με το τηλέφωνό σας, για να βεβαιωθείτε ότι ταιριάζουν όλες οι σημαντικές λεπτομέρειες και ημερομηνίες. Μπορείτε ακόμη να δημιουργήσετε εφεδρικά αντίγραφα των αρχείων σας, για να έχετε το κεφάλι σας ήσυχο.

Εγκατάσταση του LG PC Suite στον υπολογιστή σας

- 1 Στην Αρχική οθόνη πατήστε  και επιλέξτε **Συνδεσιμότητα** στην καρτέλα ΡΥΘΜΙΣΕΙΣ.
- 2 Επιλέξτε **Σύνδεση USB** και πατήστε **PC Suite**.
- 3 Συνδέστε το τηλέφωνο και τον υπολογιστή μέσω καλωδίου USB και περιμένετε λίγο. Εμφανίζεται μήνυμα του οδηγού εγκατάστασης.
- 4 Ακολουθήστε τις οδηγίες στην οθόνη για να ολοκληρώσετε τα βήματα του Οδηγού του LG PC Suite Installer.
- 5 Όταν ολοκληρωθεί η εγκατάσταση, στην επιφάνεια εργασίας θα εμφανιστεί το εικονίδιο του LG PC Suite.

Σύνδεση τηλεφώνου και υπολογιστή

- 1 Στην Αρχική οθόνη πατήστε  και επιλέξτε **Συνδεσιμότητα** στην καρτέλα ΡΥΘΜΙΣΕΙΣ.
- 2 Επιλέξτε **Σύνδεση USB**.
- 3 Πατήστε **PC Suite**.
- 4 Συνδέστε το τηλέφωνο και τον υπολογιστή μέσω καλωδίου USB και περιμένετε λίγο. Το PC Suite εκτελείται αυτόματα.

Δημιουργία εφεδρικών αντιγράφων και επαναφορά πληροφοριών του τηλεφώνου

- 1 Συνδέστε το τηλέφωνο στο PC όπως περιγράφεται παραπάνω.
- 2 Στην περιοχή "Εργαλεία", κάντε κλικ στα στοιχεία **Εφεδρικό αντίγραφο** και **Επαναφορά**.
- 3 Σημειώστε το περιεχόμενο για το οποίο θέλετε να δημιουργηθεί αντίγραφο ασφαλείας ή να γίνει επαναφορά. Επιλέξτε την τοποθεσία όπου θέλετε να αποθηκευτούν τα αντίγραφα ασφαλείας ή από την οποία θα γίνει η επαναφορά. Κάντε κλικ στο εικονίδιο **Έναρξη**.

Συγχρονισμός PC

- 4 Θα δημιουργηθεί αντίγραφο ασφαλείας των πληροφοριών σας ή θα γίνει επαναφορά τους.

Προβολή αρχείων του τηλεφώνου στον υπολογιστή

- 1 Συνδέστε το τηλέφωνό σας στον υπολογιστή όπως περιγράφεται παραπάνω.
- 2 Κάντε κλικ στο εικονίδιο **Φωτογραφίες**.
- 3 Τα αρχεία εικόνας του τηλεφώνου φορτώνονται στον υπολογιστή. Εμφανίζονται όταν κάνετε κλικ στη μνήμη του τηλεφώνου.
- 4 Κάντε κλικ στο εικονίδιο **Βίντεο**.
- 5 Τα αρχεία βίντεο του τηλεφώνου φορτώνονται στον υπολογιστή. Εμφανίζονται όταν κάνετε κλικ στη μνήμη του τηλεφώνου.

ΣΥΜΒΟΥΛΗ! Η προβολή περιεχομένων του τηλεφώνου στον υπολογιστή σας βοηθά να ταξινομήσετε αρχεία, να οργανώσετε έγγραφα και να διαγράψετε περιεχόμενα που δεν χρειάζεστε πλέον.

Συγχρονισμός των επαφών

- 1 Συνδέστε το τηλέφωνο στον υπολογιστή σας.
- 2 Κάντε κλικ στο εικονίδιο **Επαφές**.
- 3 Ο υπολογιστής εισάγει και εμφανίζει όλες τις επαφές που έχουν αποθηκευτεί στο τηλέφωνο. (Κάντε κλικ στην επιλογή "Συγχρονισμός επαφών". Στη συνέχεια, φορτώνονται οι επαφές από το τηλέφωνο)
- 4 Κάντε κλικ στο μενού **Αρχείο** και επιλέξτε **Εξαγωγή**. Στη συνέχεια, μπορείτε να επιλέξετε τον προορισμό και τη θέση αποθήκευσης των επαφών.


Συγχρονισμός μηνυμάτων

- 1 Συνδέστε το τηλέφωνο στον υπολογιστή.
- 2 Κάντε κλικ στο εικονίδιο **Μηνύματα**.
- 3 Όλα τα μηνύματα του τηλεφώνου θα εμφανιστούν σε φακέλους στην οθόνη.
- 4 Κάντε κλικ στον τίτλο των στηλών, για να αναταξινομήσετε μηνύματα που έχουν ταξινομηθεί με βάση τον **Αποστολέα**, τα **Περιεχόμενα** και την **Ημερομηνία παραλαβής**.

Χρήση του τηλεφώνου ως συσκευής συγχρονισμού μουσικής

Το τηλέφωνό σας μπορεί να χρησιμοποιηθεί ως συσκευή συγχρονισμού μουσικής μόνο για αρχεία συγχρονισμού μουσικής.

Ο συγχρονισμός μουσικής μπορεί να γίνει με το Windows Media Player 10/11 και υποστηρίζει τόσο τη μνήμη του τηλεφώνου, όσο και εξωτερική κάρτα μνήμης.

- 1 Αποσυνδέστε το τηλέφωνό σας από το PC.
- 2 Στην Αρχική οθόνη επιλέξτε  και **Συνδεσιμότητα** στην καρτέλα ΡΥΘΜΙΣΕΙΣ.
- 3 Επιλέξτε **Σύνδεση USB**.
- 4 Πατήστε **Συγχρονισμός μουσικής**.
- 5 Συνδέστε το τηλέφωνο στον υπολογιστή σας. Στο τηλέφωνο εμφανίζεται η ένδειξη: **Συνδέθηκε**.

Internet

Πρόσβαση στο Internet

- 1 Πατήστε **Browser** στην καρτέλα ΕΦΑΡΜΟΓΕΣ.
- 2 Για να μεταβείτε απευθείας στην αρχική σελίδα της εφαρμογής “Browser”, επιλέξτε **Αρχική σελίδα**.
Εναλλακτικά, επιλέξτε **Εισαγωγή διεύθυνσης**, πληκτρολογήστε τη διεύθυνση URL και έπειτα επιλέξτε **Σύνδεση**.


ΣΗΜΕΙΩΣΗ: Όταν συνδέεστε σε αυτή την υπηρεσία και πραγματοποιείτε λήψη περιεχομένου, επιβαρύνεστε με πρόσθετες χρεώσεις. Για πληροφορίες σχετικά με τις χρεώσεις δεδομένων, συμβουλευτείτε τον παροχέα υπηρεσιών.

Προσθήκη και πρόσβαση στους σελιδοδείκτες

Για εύκολη και γρήγορη πρόσβαση στις αγαπημένες σας σελίδες, μπορείτε να προσθέσετε σελιδοδείκτες και να αποθηκεύσετε σελίδες web.

- 1 Πατήστε **Browser** στην καρτέλα ΕΦΑΡΜΟΓΕΣ.
- 2 Επιλέξτε **Σελιδοδείκτες**. Στην οθόνη θα εμφανιστεί μια λίστα με τους σελιδοδείκτες σας.
- 3 Για να προσθέσετε νέο σελιδοδείκτη, επιλέξτε **Προσθήκη σελιδοδείκτη**. Εισαγάγετε ένα όνομα για το σελιδοδείκτη και, στη συνέχεια, τη διεύθυνση URL στο πλαίσιο του αντίστοιχου πεδίου.
- 4 Πατήστε **Αποθήκευση**. Ο σελιδοδείκτης θα εμφανιστεί στη λίστα με τους σελιδοδείκτες.
- 5 Για να μεταβείτε στο σελιδοδείκτη, απλώς πατήστε το εικονίδιο “Σύνδεση” δίπλα στο σελιδοδείκτη ή πατήστε τον τίτλο του σελιδοδείκτη και επιλέξτε **Σύνδεση**. Θα συνδεθείτε με το σελιδοδείκτη.

Αποθήκευση σελίδας

- 1 Αποκτήστε πρόσβαση στη σελίδα που θέλετε, όπως περιγράφεται πιο πάνω.
- 2 Πατήστε το  και επιλέξτε **Αποθήκευση αυτής της σελίδας**.
- 3 Εισαγάγετε ένα όνομα για τη σελίδα, έτσι ώστε να μπορείτε να την αναγνωρίζετε εύκολα.
- 4 Πατήστε **Αποθήκευση**.

Πρόσβαση σε αποθηκευμένη σελίδα

Πατήστε **Browser** στην καρτέλα ΕΦΑΡΜΟΓΕΣ. Στη συνέχεια, επιλέξτε **Αποθηκευμένες σελίδες**. Εδώ μπορείτε να δείτε τις αποθηκευμένες σελίδες.

Προβολή ιστορικού προγράμματος περιήγησης

Πατήστε **Browser** στην καρτέλα ΕΦΑΡΜΟΓΕΣ. Στη συνέχεια, επιλέξτε **Ιστορικό**.

Ρυθμίσεις

Εξατομίκευση των προφίλ

Στη συνέχεια, μπορείτε να αλλάξετε όλες τις επιλογές ήχων και ειδοποίησης που υπάρχουν στη λίστα, όπως είναι οι ρυθμίσεις **Ήχος κλήσης**, **Ένταση**, **Ήχος μηνύματος** και άλλες.

Αλλαγή ρυθμίσεων οθόνης

Πατήστε **Οθόνης** στην καρτέλα ΡΥΘΜΙΣΕΙΣ.

Ρυθμίσεις οθόνης

Φόντο - Επιλέξτε θέμα για την αρχική οθόνη ή για την κλειδωμένη οθόνη.

Πρότυπο αρχικής οθόνης χρήσιμων εφαρμογών - Επιλέξτε πρότυπο για την αρχική οθόνη.

Livesquare - Πατήστε **Οδηγός χρήσης Livesquare** για να δείτε τις λειτουργίες του.

Θέμα τηλεφώνου - Επιλέξτε μαύρο ή άσπρο.

Αρχικό μενού - Επιλέξτε το στυλ του αρχικού μενού: **Ζικ-Ζακ**, **Κύλιση** ή **Ανά οθόνη**.

Κλειδώμα οθόνης - Επιλέξτε τρόπο ξεκλειδώματος.

Κίνηση κλειδώματος οθόνης - Επιλέξτε τύπο κίνησης σε μια οθόνη κλειδώματος.

Κλήση - Ρυθμίστε το χρώμα των αριθμών.

Γραμματοσειρά - Ρυθμίστε το μέγεθος της γραμματοσειράς. Υπάρχουν τέσσερις επιλογές: **Μικρό**, **Μεσαίο**, **Μεγάλο** και **Πολύ μεγάλο**.

ΣΗΜΕΙΩΣΗ: Όσο περισσότερο παραμένει ενεργός ο φωτισμός, τόσο μεγαλύτερη ισχύς μπαταρίας χρησιμοποιείται. Ως αποτέλεσμα, ίσως χρειάζεται να φορτίσετε πιο συχνά το τηλέφωνό σας.

Φωτεινότητα - Ρυθμίστε τη φωτεινότητα της οθόνης.

Μήνυμα οθόνης - Επιλέξτε **Ενεργοπ.** ή **Απενεργοπ.** και συμπληρώστε το μήνυμα οθόνης στο πεδίο κειμένου.

Όνομα δικτύου - Επιλέξτε **Ενεργοπ.** ή **Απενεργοπ.**

Εκκίνηση/Τερματισμός - Επιλέξτε θέμα για την οθόνη εκκίνησης/τερματισμού.

Αλλαγή ρυθμίσεων τηλεφώνου

Ρυθμίσεις τηλεφώνου

Ημερομηνία & ώρα - Προσαρμόστε τις ρυθμίσεις

ημερομηνίας και ώρας ή επιλέξτε αυτόματη ενημέρωση της ώρας ή χρήση της θερινής ώρας.

Εξοικονόμηση ενέργειας

- Επιλέξτε να ενεργοποιήσετε ή να απενεργοποιήσετε τις εργοστασιακές ρυθμίσεις εξοικονόμησης ενέργειας ή επιλέξτε "Μόνο νύχτα".

Γλώσσες - Αλλάξτε τη γλώσσα της οθόνης του GM360.

Αυτ. κλειδ. πλήκτρ. - Ρυθμίστε το πληκτρολόγιο της αρχικής οθόνης, ώστε να κλειδώνεται αυτόματα.

Ασφάλεια - Προσαρμόστε τις ρυθμίσεις ασφάλειας, συμπεριλαμβανομένων των κωδικών PIN και του κλειδώματος της συσκευής.

Πληροφορίες μνήμης - Για περισσότερες πληροφορίες, ανατρέξτε στην ενότητα **Χρήση της διαχείρισης μνήμης**.

Επαναφορά ρυθμίσεων - Επαναφέρει όλες τις ρυθμίσεις στις εργοστασιακές προεπιλογές τους.

Πληροφορίες - Για να δείτε τις τεχνικές πληροφορίες του GM360, επιλέξτε **Βοήθεια**. Επίσης, μπορείτε να αναβαθμίσετε το λογισμικό

μέσω της επιλογής **Πληροφορίες τηλεφώνου**.

Χρήση της διαχείρισης μνήμης

Το GM360 διαθέτει τρεις μνήμες: τη μνήμη τηλεφώνου, την κάρτα SIM/USIM και μια εξωτερική κάρτα μνήμης.

Μπορείτε να χρησιμοποιήσετε τη Διαχείριση μνήμης για να δείτε πώς χρησιμοποιείται η κάθε μνήμη και πόσος διαθέσιμος χώρος υπάρχει.

Πατήστε **Τηλεφώνου** στην καρτέλα ΡΥΘΜΙΣΕΙΣ και, στη συνέχεια, πατήστε **Πληροφορίες μνήμης**.

Κοινή μνήμη τηλεφώνου - Δείτε τη διαθέσιμη μνήμη του GM360 για τις εξής κατηγορίες: Εικόνες, Ήχοι, Βίντεο, MMS, Email, Εφαρμογές Java και άλλες.

Δεσμευμένη μνήμη τηλεφώνου

- Δείτε τη διαθέσιμη μνήμη του τηλεφώνου για τις εξής κατηγορίες: SMS, Επαφές, Ημερολόγιο, Λίστα εργασιών, Σημειώσεις, Αφύπνιση, Κλήσεις, Σελιδοδείκτες και Διάφορα στοιχεία.

Μνήμη SIM/USIM - Δείτε τη διαθέσιμη μνήμη στην κάρτα SIM/USIM.

Εξωτερική μνήμη - Δείτε τη διαθέσιμη μνήμη στην εξωτερική κάρτα μνήμης

Ρυθμίσεις

(ενδέχεται να πρέπει να αγοράσετε την κάρτα μνήμης ξεχωριστά).

Ρύθμιση κύριας αποθήκευσης

- Επιλέξτε την τοποθεσία όπου θέλετε να αποθηκεύονται τα στοιχεία.

Επιλέξτε μεταξύ μνήμης τηλεφώνου και εξωτερικής μνήμης.

Αλλαγή ρυθμίσεων συνδεσιμότητας

Ρυθμίσεις δικτύου

Επιλογή δικτύου - Αν επιλέξετε “Αυτόματα”, το GM360 αναζητά αυτόματα δίκτυο και δηλώνει το τηλέφωνο στο δίκτυο. Αυτή η επιλογή συνιστάται για καλύτερη εξυπηρέτηση και ποιότητα.

Αν επιλέξετε Χειροκίνητα, εμφανίζονται όλα τα διαθέσιμα δίκτυα και μπορείτε να επιλέξετε ένα από αυτά για εγγραφή.

Λίστες προτιμήσης - Μπορείτε να προσθέσετε ένα δίκτυο με το οποίο προτιμάτε να συνδεθείτε. Αν το δίκτυο πραγματοποιεί αυτόματη αναζήτηση, απλώς επιλέξετε ένα δίκτυο από τη λίστα δικτύων. Αν όχι, προσθέστε νέο δίκτυο χειροκίνητα.

Προφίλ Internet - Αυτό το μενού εμφανίζει τα προφίλ Internet.

Δεν μπορείτε να διαγράψετε ή να επεξεργαστείτε προεπιλεγμένες διαμορφώσεις που εξαρτώνται από τη μεταβλητή χώρας.


Σημεία πρόσβασης - Ο παροχέας δικτύου έχει ήδη αποθηκεύσει τις πληροφορίες αυτές. Μπορείτε να προσθέσετε νέα σημεία πρόσβασης χρησιμοποιώντας αυτό το μενού.

Πακέτο σύνδεσης δεδομένων

- Επιλέξτε το όταν η συσκευή πρέπει να συνδεθεί στο δίκτυο για δεδομένα πακέτου.

Σύνδεση USB - Επιλέξτε υπηρεσία δεδομένων από τις διαθέσιμες επιλογές και χρησιμοποιήστε το λογισμικό LG PC Suite για να συγχρονίσετε το GM360 και να αντιγράψετε αρχεία από το τηλέφωνο. Για περισσότερες πληροφορίες σχετικά με το συγχρονισμό, ανατρέξτε στην ενότητα **Συγχρονισμός PC**. Εάν χρησιμοποιείτε συγχρονισμό μουσικής με το Windows Media Player, επιλέξτε **Συγχρονισμός μουσικής** σε αυτό το μενού. Ο **συγχρονισμός μουσικής** είναι διαθέσιμος μόνο για περιεχόμενο μουσικής.

Αλλαγή ρυθμίσεων Bluetooth:

Πατήστε **Bluetooth** στην καρτέλα ΡΥΘΜΙΣΕΙΣ. Στη συνέχεια, επιλέξτε  και πατήστε **Ρυθμίσεις**.

Κάντε τις αλλαγές σας στις παρακάτω ρυθμίσεις:

Ορατότητα συσκευής - Επιλέξτε μεταξύ των ρυθμίσεων **Ορατή**, **Κρυφή** ή **Ορατή για 1 λεπτό**.

Όνομα συσκευής - Εισαγάγετε όνομα για το GM360.

Υποστ. υπηρεσίες - Επιλέξτε τον τρόπο χρήσης του Bluetooth σε συνδυασμό με διάφορες υπηρεσίες.

Λειτουργία απομακρυσμένης SIM/USIM - Ενεργοποιήστε ή απενεργοποιήστε τη λειτουργία.

Η διεύθυνσή μου - Δείτε τη διεύθυνση του Bluetooth.

Σύζευξη με άλλη συσκευή Bluetooth

Αν πραγματοποιήσετε σύζευξη του GM360 με άλλη συσκευή, μπορείτε να δημιουργήσετε σύνδεση που προστατεύεται από κωδικό πρόσβασης.

1 Βεβαιωθείτε ότι οι ρυθμίσεις για τη λειτουργία Bluetooth είναι

Ενεργοπ. και **Ορατή**. Μπορείτε να αλλάξετε τη ρύθμιση ορατότητας από το μενού **Ρυθμίσεις**.

2 Πατήστε **Αναζήτηση**.

3 Το GM360 αναζητά συσκευές. Όταν ολοκληρωθεί η αναζήτηση, στην οθόνη θα εμφανιστεί η επιλογή **Ανανέωση**.

4 Επιλέξτε τη συσκευή με την οποία θέλετε να γίνει σύζευξη, εισαγάγετε τον κωδικό πρόσβασης και πατήστε **OK**.

5 Στη συνέχεια, το τηλέφωνο συνδέεται με την άλλη συσκευή, στην οποία πρέπει να εισαγάγετε τον ίδιο κωδικό πρόσβασης.

6 Η σύνδεση Bluetooth με προστασία κωδικού πρόσβασης είναι πλέον έτοιμη.

Χρήση ακουστικών Bluetooth

1 Ελέγξτε ότι οι ρυθμίσεις για τη λειτουργία Bluetooth είναι **Ενεργοποίηση** και **Ορατό**.

2 Ακολουθήστε τις οδηγίες που συνόδευαν το τηλέφωνο, για να το θέσετε σε λειτουργία σύζευξης και να πραγματοποιήσετε σύζευξη των συσκευών.

Ρυθμίσεις

- 3 Πατήστε **Ερώτηση πριν από σύνδεση** ή **Πάντα σύνδεση** και πατήστε **Ναι** για άμεση σύνδεση. Το GM360 μεταβαίνει αυτόματα στο προφίλ “Ακουστικά”.

Αναβάθμιση λογισμικού

Πρόγραμμα αναβάθμισης λογισμικού κινητού τηλεφώνου LG

Για περισσότερες πληροφορίες σχετικά με την εγκατάσταση και τη χρήση του προγράμματος, επισκεφτείτε την τοποθεσία <http://update.lgmobile.com>. Αυτή η λειτουργία σας δίνει τη δυνατότητα να αναβαθμίσετε το λογισμικό στην πιο πρόσφατη έκδοση γρήγορα και άνετα μέσω Internet, χωρίς να απαιτείται επίσκεψη στο κέντρο εξυπηρέτησης. Καθώς το πρόγραμμα αναβάθμισης λογισμικού του κινητού τηλεφώνου απαιτεί την απόλυτη προσοχή του χρήστη σε όλη τη διάρκεια της διαδικασίας αναβάθμισης, πρέπει να ελέγξετε όλες τις οδηγίες και τις σημειώσεις που εμφανίζονται σε κάθε βήμα, πριν προχωρήσετε. Πρέπει να έχετε υπόψη σας ότι η αφαίρεση του καλωδίου επικοινωνίας δεδομένων USB ή των μπαταριών κατά τη διάρκεια της αναβάθμισης μπορεί να

προκαλέσει σοβαρή βλάβη στο κινητό σας τηλέφωνο. Ο κατασκευαστής δεν αναλαμβάνει καμία ευθύνη για απώλεια δεδομένων κατά τη διάρκεια της διαδικασίας αναβάθμισης, οπότε συνιστάται να διατηρείτε οποιαδήποτε σημαντική πληροφορία εκ των προτέρων, για λόγους ασφαλείας.

Τεχνικά δεδομένα

Γενικό



Όνομα προϊόντος: GM360

Σύστημα: GSM 850 / E-GSM 900 / DCS 1800 / PCS 1900

Θερμοκρασίες περιβάλλοντος

Μεγ.: +55°C (αποφόρτιση),
+45°C (φόρτιση)

Ελάχ.: -10°C

Δήλωση Συμμόρφωσης			
Στοιχεία Προμηθευτή			
Όνομα			
LG Electronics Inc			
Διεύθυνση			
LG Twin Tower 20, Yeouido-dong, Yeongdeungpo-gu Seoul, Korea 150-721			
Πληροφορίες Προϊόντος			
Όνομα Προϊόντος			
GSM 850 / E-GSM 900 / DCS 1800 / PCS 1900 Quad Band Terminal Equipment			
Μοντέλο			
GM360			
Εμπορική Επωνυμία			
LG			
CE 0168			
Τεχνικές Απαιτήσεις			
R&TE Directive 1999/5/EC20			
EN 301 489-01 v1.8.1 / EN 301 489-07 v1.3.1 / EN 301 489-17 v1.3.2			
EN 300 328 V1.7.1			
EN 60950-1 - 2001			
EN 50368:2001/EN62209-1:2006			
EN 301 511 V9.0.2			
Προσθήκες Πληροφοριών			
Η συμμόρφωση με τα παραπάνω πρότυπα πιστοποιείται από τον εκδόλοχο κοινοποιημένο φορέα (BABT)			
BABT, Forsyth House, Churchfield Road, Walton-on-Thames, Surrey, KT12 2TD, United Kingdom			
Notified Body Identification Number - 0168			
Δήλωση			
Εγώ, ο υπεργραμμένος, δηλώνω υπεύθυνα ότι το προϊόν που αναφέρεται παραπάνω στο κείμενο αυτής της δήλωσης συμμορφώνεται προς τα προαναφερθέντα πρότυπα και Οδηγίες		Όνομα	Ημερομηνία Έκδοσης
LG Electronics Logistics and Services B.V., Veluwezoom 15, 1327 AE Almere, The Netherlands		Seung Hyun, J. Διευθυντής	30. MAR. 2010
			
		Υπογραφή του εκπαιστού	



Some of the contents in this manual may differ from your phone depending on the software of the phone or your service provider.



GM360 User Guide

Congratulations on your purchase of the advanced and compact GM360 phone by LG, designed to operate with the latest digital mobile communication technology.



Disposal of your old appliance

- 1** When this crossed-out wheeled bin symbol is attached to a product it means the product is covered by the European Directive 2002/96/EC.
- 2** All electrical and electronic products should be disposed of separately from the municipal waste stream via designated collection facilities appointed by the government or the local authorities.
- 3** The correct disposal of your old appliance will help prevent potential negative consequences for the environment and human health.
- 4** For more detailed information about disposal of your old appliance, please contact your city office, waste disposal service or the shop where you purchased the product.

Contents


Getting to know your phone	6	Changing the common call setting	21
Open view	7	Contacts	22
Installing the SIM and battery	8	Searching for a contact	22
Charging your phone	9	Adding a new contact	22
Memory card	10	Creating a group	22
Using your touch screen	11	Changing your contact settings	23
Touch screen tips	11	Viewing information	23
Control the touch screen	11	Messaging	24
Your home screen	13	Messaging	24
The quick keys	14	Sending a message	24
The status bar	15	Entering text	24
Changing your Status from the status bar	16	T9 mode	24
Using the Multi-tasking function	16	Handwriting recognition	24
Calls	17	Setting up your email	25
Making a call	17	Retrieving your emails	25
Making a call from your contacts	17	Sending an email using your new account	25
Answering and rejecting a call	17	Changing your email settings	25
In-call options	18	Message folders	26
Speed dialling	19	Changing your text message settings	26
Making a second call	19	Changing your multimedia message settings	27
Viewing your call logs	19	Changing your other settings	27
Using call divert	20		
Using call barring	20		

Contents

Social network services (SNS).....	28	Using an image.....	39
Facebook.....	28	Printing an image	39
Linkbook.....	29	Moving or copying a file.....	40
Camera.....	30	Sounds.....	40
Getting to know the viewfinder.....	30	Using a sound	40
Taking a quick photo.....	31	Videos	40
After taking a photo.....	31	Watching a video	40
Using the advanced settings.....	32	Sending a video clip	41
Video camera.....	33	Games & Apps	41
Getting to know the viewfinder.....	33	Playing a game	41
Making a quick video	34	Documents	41
After making a video.....	34	Transferring a file to your phone.....	41
Using the advanced settings.....	35	Others	41
Your photos and videos.....	36	Music	42
Viewing your photos and videos ...	36	Transferring music onto your phone	42
Capturing an image from a video..	36	42
Viewing your photos as a slide show	36	Playing a song.....	42
.....	36	Creating a playlist	43
Setting a photo as wallpaper.....	37	FM Radio	43
Editing your photos	37	Searching for stations	43
Adding an effect to a photo.....	38	Resetting channels.....	43
Multimedia.....	39	Organiser	44
Pictures.....	39	Adding an event to your calendar.	44
Sending a photo.....	39	Adding an item to your task list	44
		Using date finder	44
		Adding a memo.....	45

Setting your alarm.....	45	Using RSS reader	50
Adding a memo with the drawing Panel	45	Saving a page.....	51
Screen Capture	46	Accessing a saved page	51
Voice recorder	46	Viewing your browser history	51
Recording a sound or voice	46	Changing the web browser settings	51
Using your calculator.....	46	Using your phone as a modem.....	51
Converting a unit	47	Access to Google.....	52
Adding a city to your World clock..	47	Settings	53
Using the stopwatch	47	Personalising your profiles.....	53
PC Sync.....	48	Changing your screen settings.....	53
Installing LG PC Suite on your computer	48	Changing your phone settings.....	54
Connecting your phone and PC.....	48	Using memory manager.....	54
Backing up and restoring the information on your phone	48	Changing your connectivity settings	55
Viewing phone files on your PC.....	48	Sending and receiving your files using Bluetooth.....	55
Synchronising your contacts.....	49	Changing your Bluetooth settings:56	
Synchronising your messages.....	49	Pairing with another Bluetooth device.....	56
Using your phone as a Music Sync device	49	Using a Bluetooth headset.....	57
The web	50	Software Upgrade	57
Accessing the web	50	Accessories	58
Adding and accessing your bookmarks	50	Technical data.....	59
		Guidelines for safe and efficient use.	61

Getting to know your phone



Call key

- Dials a phone number and answers incoming calls.

Multitasking key



Handsfree or Stereo earphone connector

Power/Lock key

- Short press to turn on/off the screen.
- Long press for power on/off.

⚠ WARNING: Placing a heavy object on the phone or sitting on it while it is in your pocket can damage the phone's LCD and touch screen functionality.

Open view



Installing the SIM and battery


1 Remove the battery cover


Slide the battery cover towards the bottom of the phone and away from it.




2 Install the SIM card

Slide the SIM card into the SIM card holder making sure that the gold contact area on the card is facing downwards. Please make sure the battery is removed from the phone before installing the SIM card. To remove the SIM card, pull it gently outwards.



 **WARNING:** Do not use your fingernail to remove the battery.

 **WARNING:** Do not remove the battery when the phone is switched on, as this may damage the phone.

3 Install the battery

Insert the left side of the battery into the top edge of the battery compartment first. Ensure that the battery contacts align with the phone's terminals. Press the right side of the battery until down it clicks into place.



Charging your phone

Remove the charger socket cover on the side of your GM360. Connect the Travel Adapter (Charger) and the included USB cable. Connect the USB cable into the phone and plug it into a power socket. Your GM360 must be charged until the "Battery full" message appears on the screen.

NOTE: The battery must be fully charged initially to improve battery lifetime. Disregard the first "Battery full" message and keep the phone on charge overnight.



Memory card

Installing a memory card

You can expand the memory space on your phone by using a MicroSD memory card.

NOTE: A memory card is an optional accessory.


- 1 Open the microSD card slot cover on the left-hand edge of the phone.



- 2 Slide the microSD card into the slot until it clicks into place. Make sure the gold contact area is facing downwards.

Formatting the memory card

Your memory card may already be formatted. If it isn't, you will need to format it before you can start to use it.

- 1 From the Home screen select , then **Phone settings** in **SETTINGS** tab.
- 2 Touch **Memory info** then choose **External memory**.
- 3 Touch **Format** and then confirm your choice.
- 4 Enter the password, if one is set. Your card will then be formatted and ready to use.

NOTE: If there is existing content on your memory card, the folder structure may be different after formatting since all files will have been deleted.

Using your touch screen

Touch screen tips


- To select an item, touch the centre of the icon.
- Do not press too hard. The touchscreen is sensitive enough to pick up a light, firm touch.
- Use the tip of your finger to touch the option you require. Be careful not to touch any other keys.
- Whenever your GM360 is not in use, it will return to the lock screen.

Control the touch screen

The controls on the GM360 touch screen change dynamically depending on the task you are carrying out.

Opening Applications

To open any application, simply touch its icon.



Scrolling

Drag from side to side to scroll. On some screens, such as the call history list, you can also scroll up or down.



Using your touch screen

Lock screen gesture

Lock screen gesture - set a gesture to the 9 extended shortcut applications. Gesture in Lock screen allows users to unlock the phone and execute the applications directly as they draw a gesture on the screen.

To set up this feature,

- 1 Select  - Screen settings - Lock screen gesture


- 2 Drag & drop the preferred gesture from the bottom of the screen to the applications you want to assign them to.

TIP! Draw ? shape to go to Lock screen gesture menu in the lock screen.




Your home screen

You can drag and click what you need right away in all home screen types.



Widget home screen - When you touch  on the bottom right of the screen, the mobile widget panel appears. When you register widget by dragging it, the widget is created in the spot where it was dropped.



Speed dial home screen - When you touch , the speed dial list appears. You can call, send a message or edit the contact directly in this home screen.



Livesquare home screen - On the Livesquare screen, You can easily make a call and send a message to the number allocated to an avatar. To use the call, messaging or contacts function, select an avatar and choose the **Quick key** icon you want to use.

TIP! The User Interface is based on three types of Homescreen. To swap between the home screens just wipe quickly over the display from left to right, or from right to left.

Your home screen

The quick keys

The quick keys on your home screen provide easy, one-touch access to the functions you use the most.



Touch to bring up the touch dialling pad to make a call.



Touch to open your **Contacts**. To search for the number you want to call, enter the name of the contact at the top of the screen using the touchpad. You can also create new contacts and edit existing ones.



Touch to access the **Messaging** menu. From here you can create a new SMS or MMS, or view your message folder.



























Touch to open the full **Top menu** which is divided into four categories.

The status bar


The status bar uses various icons to indicate things like signal strength, new messages and battery life, as well as telling you whether your Bluetooth or GPRS is active.


Below is a table which explains the meaning of the icons you're most likely to see in the status bar.

Icon	Description
	Multitasking
	Network signal strength (number of bars will vary)
	No network signal
	Remaining battery life
	Battery empty
	New text message
	New voice message
	Message inbox is full
	Message sending failed
	Multimedia message sending failed
	An alarm is set

Icon	Description
	Customised Profile in use (The number in the icon will vary)
	Normal profile in use
	Outdoor profile in use
	Silent profile in use
	Headset in use
	Calls are diverted
	EDGE in use
	Roaming
	Flight mode is on
	Bluetooth is active
	BGM play
	BGM pause
	Memory card is enabled for use

Your home screen


Icon	Description
	<p>For incoming Push email Check Push email: Touch Games & Applications in the Entertainment and then touch Applications.</p> <p>*Attention: Depending on the region or SIM operator, user may not be able to use push e-mail and access WAP (or MMS) simultaneously.</p>

When you have an application running in the background (e.g. a game or the FM radio),  will appear in the status bar.

Changing your Status from the status bar



Touch the centre of the status bar to open the Status Summary. It shows the current Time, Network, SVC ID, Battery, Handset memory, External Memory, Profile, MP3s and Bluetooth status. Here you can set the Profile type, play/pause MP3s and activate/deactivate Bluetooth.


Using the Multi-tasking function

Press the multi-tasking hard key  to open the Multitasking menu. From here you can view all the applications that are running and access them with one touch.

Calls



Making a call

- 1 Touch  to open the keypad.
- 2 Key in the number using the keypad.
- 3 Touch  to initiate the call.
- 4 To end the call, press the Smart key.

TIP! To enter + for making an international call, press and hold .



TIP! Press the power key to lock the touchscreen to prevent calls being made by mistake.

Making a call from your contacts

- 1 From the home screen touch  to open the **Contacts**.
- 2 Tap the Name field box on the top of the screen and enter the first few letters of the contact you would like to call using the keypad.
- 3 From the filtered list, touch the Call icon next to the contact you want to call. The call will use the default number if there is more than one for that contact.
- 4 Or, you can touch the contact name and select the number to use if there is more than one for that contact to use. You can also touch  to initiate the call to the default number.


Answering and rejecting a call

When your phone rings, touch the Smart key to answer the call.

To mute the ringing, slide up the cover. This will unlock the phone if it is locked, then tap . This is useful if you forgot to change your profile to Silent for a meeting. Touch  to reject an incoming call.

Calls

In-call options







TIP! To scroll through a list of options or your list of contacts, touch the last item visible and slide your finger up the screen. The list will move up so more items become visible.

Speed dialling

You can assign a frequently-called contact to a speed dial number.

- 1 Select **Contacts** in the **COMMUNICATION** tab and select **Speed dials**.
- 2 Your voicemail is already set to speed dial 1. You cannot change this. Touch any other number to assign it a speed dial contact.
- 3 Your Contacts will open. Select the contact you want to assign to that number by touching their phone number once. To find a contact, tap the Name field box and enter the first letter of the name of the contact required.

Making a second call

- 1 During your initial call, touch  and type the number you want to call.
- 2 Touch  to connect the call.
- 3 Both calls will be displayed on the call screen. Your initial call will be locked and the caller put on hold.
- 4 To change between the calls, touch  or press the number of the held call.
- 5 To end one or both calls press  and select **End** followed by **All**, **Held** or **Active**.

TIP! Touch any single call log entry to view the date, time and duration of the call.

NOTE: You will be charged for each call you make.

Viewing your call logs

Touch **Recent history** in the **COMMUNICATION** tab.

TIP! Touch any single call log entry to view the date, time and duration of the call.

Calls

Using call divert

- 1 Touch **Call settings** in the **SETTINGS** tab.
- 2 Touch **Call divert**.
- 3 Choose whether to divert all voice calls, when the line is busy, when there is no answer or when you cannot be contacted.
- 4 Enter the number you want to divert to.
- 5 Touch **Request** to activate.

NOTE: Charges are incurred for diverting calls. Please contact your network provider for details.

TIP! To turn off all call diverts, select **Deactivate all** from the **Call divert** menu.

Using call barring

- 1 Touch **Call settings** in the **SETTINGS** tab.
- 2 Touch **Call barring**.
- 3 Choose any or all of the six options:
 - All outgoing**
 - Outgoing international**
 - Outgoing international calls except home country**
 - All incoming**
 - Incoming when abroad**
 - Deactivate all**
- 4 Enter the call barring password. Please check with your network operator about this service.

TIP! Select **Fixed dial numbers** from the **Call settings** options to turn on and compile a list of numbers which can be called from your phone. You'll need your PIN2 code from your operator. Only numbers included in the fixed dial list can be called from your phone.

Changing the common call setting

- 1 Touch **Call settings** in the **SETTINGS** tab.
- 2 Scroll and touch **Common settings**.

From here you can adjust the settings for:

Call reject - Slide the switch to **ON** to highlight the Reject list. You can touch the text box to choose from all calls, specific contacts or groups, or those from unregistered numbers (those not in your contacts) or with no caller ID. Touch **Save** to change the setting.

Send my number - Choose whether your number will be displayed when you call someone.

Auto redial - Slide the switch left for **ON** or right for **OFF**.

Answer mode - Choose whether to answer the phone using the send key or any key.

Minute minder - Slide the switch left to **ON** to hear a tone every minute during a call.

BT answer mode - Select **Hands-free** to be able to answer a call using a Bluetooth headset, or select **Handset** to press a key on the handset to answer a call.

Save new number - Select **Yes** to save a new number.

Contacts

Searching for a contact

There are two ways to search for a contact:


- 1 Touch **Contacts** in the **COMMUNICATION** tab.
- 2 Touch **Search**.
- 3 You see a list of contacts. Typing in the first letter of a contact's name in the **Name** field will jump the menu to that alphabetical area of the list.

TIP! The alphabetical keypad is displayed once you tap the **Name** field.


Adding a new contact

- 1 Touch **Contacts** in the **COMMUNICATION** tab and touch **Add contact**.
- 2 Choose whether to save the contact to your **Handset** or **SIM**.
- 3 Enter your first and last name.
- 4 You can enter up to five different numbers per contact. Each entry has a preset type **Mobile**, **Home**, **Office**, **Pager** and **Fax**.
- 5 Add an email addresses. You can enter up to two different email addresses per contact.

- 6 Assign the contact to one or more groups. You can assign up to three groups per contact. Choose between **No group**, **Family**, **Friends**, **Colleagues**, **School** or **VIP**.
- 7 You can also add a **Ringtone**, **Birthday**, **Anniversary**, **Homepage**, **Home address**, **Company name**, **Job title**, **Company address**, **Memo** and **Livecon**.
- 8 Touch **Save** to save the contact.

TIP! Birthday widget can be accessed by selecting the icon . It displays upcoming birthdays chronologically for the month by taking birthdays that are saved in **Contacts**. This widget also facilitates communication to a contact that has birthday by allowing features such as **Call**, **Messaging** and **Email**.

Creating a group

- 1 Touch **Contacts** in the **COMMUNICATION** tab. And touch **Groups**.
- 2 Touch **Add group** or touch  and select **Add group**.
- 3 Enter a name for your new group. You can also assign a ringtone to the group.

4 Touch Save.

NOTE: If you delete a group, the contacts which were assigned to that group will not be lost. They will remain in your **Contacts**.

Changing your contact settings

You can adapt your contact settings so that your **Contacts** suits your own preferences.

- 1 Touch **Contacts** in the **COMMUNICATION** tab and touch **Settings**.
- 2 From here, you can adjust the following settings:
 - Contact list settings** - Adjust the **Contacts location**, **Name display** and **Quick command key** settings.
 - Copy** - Copy your contacts from your handset to your SIM or from your SIM to your handset. You can choose one at a time, or all at once.
 - Move** - This works in the same way as Copy, but the contact will only be saved to the location you've moved it to.

Send all contacts via Bluetooth -

Send all of your contacts to another device using Bluetooth. You will be prompted to turn on Bluetooth if you select this option.

Backup contacts - See **Backing up and restoring the information on your phone**.

Restore contacts - See **Backing up and restoring the information on your phone**.

Clear contacts - Delete all your contacts. Choose between **Handset** and **SIM** and touch **Yes** if you are sure you want to wipe your contacts.

Viewing information

- 1 Touch **Contacts** in the **COMMUNICATION** tab and touch **Information**.
- 2 From here you can view your **Service dial numbers**, your **Own number**, your **Memory info**. (showing your memory usage) and **My profile**.

TIP! To add your own business card, select **My profile** and enter your details as you would for any contact. Touch **Save** to finish.


Messaging

Messaging

Your GM360 combines SMS and MMS into one intuitive and easy-to-use menu.


Sending a message


- 1 Touch **Messaging** in the **COMMUNICATION** tab. And touch **New message** to begin composing a new message.
- 2 Touch **Insert** to add an image, video, sound, template and so on.
- 3 Touch **Recipient** at the bottom of the screen to enter the recipients. Then enter the number or touch  to select a contact. You can even add multiple contacts.
- 4 Touch **Send** when ready.


 **WARNING:** If an image, video or sound is added to an SMS it will be automatically converted to an MMS and you will be charged accordingly.


Entering text

There are five ways to enter text: **Keypad**, **Keyboard**, **Handwriting-Screen**, **Handwriting-Box**, **Handwriting-Double Box**.

You can choose your input method by tapping  and **Input method**.

Touch  to turn on T9 mode. This icon is only shown when you choose **Keypad** as the input method.

Touch  to choose the writing language.

Touch  to change between numbers, symbols and text input. Use **Shift** key to change between capital or lowercase input.

T9 mode

The T9 mode uses a built-in dictionary to recognise the words you're writing based on the sequence of keys you've touched. It predicts the word you are inputting and suggests alternatives.


Handwriting recognition

In Handwriting mode you simply write on the screen and your GM360 will convert your handwriting into your message. Select **Handwriting-Screen** or **Handwriting-Box** according to your preferred view.

Setting up your email

Touch **E-mail** in the COMMUNICATION tab.

If the email account is not set up, start the email set up wizard and finish it.

You can check and edit settings by selecting . You can also check the additional settings that were filled in automatically when you created the account.

Retrieving your emails

You can automatically or manually check your account for new emails. To check manually:

- 1 Touch **E-mail** in the COMMUNICATION tab.
- 2 Touch the account you want to use.
- 3 Select **Inbox**
- 4 To receive an E-mail, choose either **Retrieve** or **Synchronisation** in **Option** menu.

Sending an email using your new account

- 1 Touch **New e-mail** and a new email will open.
- 2 Complete the message.
- 3 Touch **Send** and your email will be sent.

Changing your email settings

- 1 Touch **E-mail** in the COMMUNICATION tab.
- 2 Touch  and select **E-mail settings** and then you can adapt the following settings:
E-mail accounts
Preferred e-mail

Allow reply e-mail - Choose to allow the sending of read confirmation messages.

Request reply e-mail - Choose whether to request read confirmation messages.

Retrieve interval - Choose how often your GM360 checks for new email messages.

Retrieve amount - Choose the number of emails to be retrieved at any one time.

Include message in Fwd. & Reply - Choose to include the original message in your reply.

Include attachment - Choose to include the original attachment in any reply.

Auto retrieval in roaming - Choose whether to retrieve your messages automatically when abroad (roaming).

Messaging

New e-mail notification - Choose whether to be alerted to new emails.

Signature - Switch this feature **ON** and create an email signature.

Priority - Choose the priority level of your email messages.

Mail sending size - Set the maximum size of sending mail.

E-mail counter - Input the date you want. You can check emails you sent during that period.

Message folders

There are five folders in Messaging menu.

Inbox - All the messages you receive are placed into your inbox.

Drafts - If you do not finish writing a message, you can save what you have done in this folder.

Outbox - This is a temporary storage folder while messages are being sent.

Sent items - All the messages you have sent are placed in this folder.

My folders - Create folders to store your messages.

Changing your text message settings

Touch **Messaging** in the **COMMUNICATION** tab and touch **Settings**. Select **Text message**. You can make changes to:

Text message centre - Enter the details of your message centre.

Delivery report - Slide the switch left to receive confirmation that your messages have been delivered.

Validity period - Choose how long your messages are stored at the message centre.

Message types - Convert your text into **Text, Voice, Fax, X.400** or **E-mail**.

Character encoding - Choose how your characters are encoded. This impacts the size of your messages and therefore data charges.

Send long text as - Choose to send long messages as **Multiple SMS** or as an **MMS**.

Changing your multimedia message settings

Touch **Messaging** in the **COMMUNICATION** tab. Scroll and choose **Settings** and **Multimedia message**. You can make changes to:

Retrieval mode - Choose between **Home network** or **Roaming network**. If you then choose **Manual** you will receive only notifications of MMS and you can then decide whether to download them in full.

Delivery report - Choose to request and/or allow delivery reports.

Read reply - Choose to request and/or allow read replies.

Priority - Choose the priority level of your multimedia message.

Validity period - Choose how long your messages are stored at the message centre.

Slide duration - Choose how long your slides appear on the screen by default.


Creation mode - Choose to create multimedia messages freely or restrictively.

Delivery time - Choose how long to wait before a message is delivered.

Multi msg centre - Choose or add a multimedia message centre.

Changing your other settings

Touch **Messaging** in the **COMMUNICATION** tab. And touch **Settings**.

Voicemail - Touch  to add a new Voicemail service. Contact your network operator for more information about the service they provide.

Service message - Choose to receive or block service messages. You can also set your message security by creating trusted and untrusted lists of senders in **Service security** option.

Message counter - Choose to set period for counting messages.

Info. service - Choose whether to turn Cell broadcast on/off and select your channels and languages.

Messaging

Social network services (SNS)

Your GM360 has SNS that lets you enjoy and manage your social network. You can update your own SN place status and view your friends' SN updates.

Touch **Social network** menu and select the site as below: Facebook, Twitter and Myspace.

TIP! Facebook is a native application preloaded onto your phone, and easy to access. Twitter is a java application based on Java technology. Other applications access to the WAP(Wireless Application Protocol) services.

NOTE: SNS feature is a data intensive application. An additional costs may be incurred when connecting and using online services. Check your data charges with your network provider.

Facebook

Home: Log in and you will see your friend's updated status. Input your comment about new status or check others. Touch Options to choose Refresh, News Feed filter(Status updates, Photo), Delete or Settings.

You can also write comments by selecting + icon.

Profile: You can select the Wall > Status updates and write the current status. See your info detail and upload the photo by touching Album > Upload Photo. Choose from Go to images or Take a picture, and then input some caption with images.

Friends: You can find many friends in SNS and view their status. Search your friends in facebook by selecting Search tap.

Message: It will show all your SN messages. You can see the Inbox/Sent folder, and write a SN message.

TIP! Using Facebook Feed Widget
You can add the facebook feed widget to your home screen. Drag the facebook feed widget from widget tray and touch **OK**.
If the facebook widget registered on home screen, it will show latest 3 feeds from your SN site.
You can also access the facebook application directly by touching up the feed widget.


There are SNS on/off, SNS account login & Delete(logout) in SNS setting. And SNS can be on/off automatically by setting a certain period of time in Auto connection menu.

Linkbook

If the SNS Mode is set to On, you can save the personal information of your Facebook contacts, such as name, phone number, email address, and photo, into Contacts. Use the Save to Contact button on Facebook to save their personal information. You can check the stored information in the Contact view. If the SNS Mode is set to off, SNS information is not displayed in Contacts list.




Camera

Getting to know the viewfinder



TIP! You can bring up the options by tapping the screen. They automatically turn off after a few seconds.

Taking a quick photo

- 1 Press the  key on the right side of the phone.
- 2 When the camera has focused on your subject, touch the  on the right-center of the screen to take a photo. You can also press the  key on the side of the phone firmly.

TIP! To switch to the camera mode or video mode, slide up/down the camera or video icon on the centre-right of the viewfinder.

After taking a photo


Your captured photo will appear on the screen. The name of the image runs along the bottom of the screen.

-  Touch to send the photo as a message, email or via Bluetooth.
-  Touch to set a Home screen image.
-  Touch to edit the photo.
-  Touch to edit the name of the selected picture.
-  Touch to delete the photo you have just taken and confirm by touching **Yes**. The “Deleted” message appears.
-  Touch to move to your gallery.



Camera

Using the advanced settings

From the viewfinder, touch  to open all the advanced settings options.

Shot mode - This enables you to select the two shooting modes.

Colour Effect - Choose a colour tone to apply to the photo you're taking. There are four colour tone options: **Off**, **Black & White**, **Negative** or **Sepia**.

White balance - Choose from **Auto**, **Incandescent**, **Sunny**, **Fluorescent** or **Cloudy**.

Night mode - Useful to use in dark places.

Self-timer - The self-timer allows you to set a delay before the camera takes the picture, after the capture button is pressed. Choose from **3 seconds**, **5 seconds** or **10 seconds**. Great for the group photo you want to be part of.

Quality - Choose between **Super fine**, **Fine** and **Normal**. The finer the quality the sharper a photo will be, but the file size will increase. This means you'll be able to store fewer photos in your memory.

Focus - Sets the focus of camera.

View mode - Choose between Full screen or Full image. In Full screen, the image may be cropped to fit the screen.

Select storage - Choose whether to save your photos to the Handset memory or to the External memory.

Show captured image - Choose to view the picture with options after taking a photo.

Hide icons - Choose the camera settings icons to be hidden manually or automatically.


Shutter sound - Select one of the three shutter sounds.

Grid screen - Choose from **Off**, **Simple cross** or **Trisection**.

Reset settings - Reset all the camera settings.

Video camera

Getting to know the viewfinder









TIP! You can close all shortcut options for a clearer viewfinder screen. Simply touch the centre of the viewfinder once. To recall the options, touch the screen again.

Video camera

Making a quick video



- 1 Press the camera key on the right side of the phone for a few seconds.



TIP! To switch to the camera mode or video mode, slide up/down the camera or video icon on the right centre of the viewfinder.


- 2 Holding the phone horizontally, point the lens towards the subject of the video.
- 3 Press the camera key  on the phone once to start recording. Or touch the red dot .
- 4 **Rec** will appear at the bottom of the viewfinder with a timer at the bottom showing the length of the video.
- 5 To pause the video, touch  and resume by selecting .
- 6 Touch  on screen or press the  a second time to stop recording.


After making a video


A still image representing your captured video will appear on the screen. The name of the video runs along the bottom of the screen together with seven icons down the left and right sides .

-  Touch to play the video.
-  Touch to send the video as a **Message or Email** or by **Bluetooth**.

-  Touch to edit the video.
-  Touch to edit the name of the selected picture.

 Touch to delete the video you have just made and confirm by touching **Yes**. The viewfinder will reappear.

Touch  to shoot another video straight away.

 Touch to view a gallery of saved videos and images.



Using the advanced settings

From the viewfinder, touch **Settings** to open all the advanced settings options.

Colour Effect - Choose a colour tone to use on your new video. **Off, Black & White, Negative, Sepia.**

White balance - The white balance ensures that any white in your videos is realistic. In order for your camera to correctly adjust the white balance, you may need to determine the light conditions. Choose from **Auto, Incandescent, Sunny, Fluorescent** or **Cloudy**.

Quality - Choose between **Super fine, Fine** and **Normal**. The finer the quality, the sharper a video will be, but the file size will increase. As a result, you will be able to store fewer videos in the phone's memory.

Duration - Set a time limit for your video. Choose whether or not to send the video as an MMS.

TIP! If you choose MMS duration, choosing a lower image quality will enable you to shoot a longer video.

Select storage - Choose whether to save your videos to the Handset memory or to the External memory.

Voice - Choose whether or not to record a video with sound.

Hide icons - Choose the camera settings icons to be hidden manually or automatically.

Reset settings - Reset all the video camera settings.




Your photos and videos


Viewing your photos and videos


- 1 Touch **Gallery** in the ENTERTAINMENT tab. Or Touch  on your camera preview screen. You can check your pictures and videos.
- 2 Your gallery will appear on the screen.
- 3 Touch the video or photo to open it fully.
- 4 To play the video touch . To pause playback touch .

TIP! Flick left or right to view other photos or videos.

Capturing an image from a video







- 1 Select the video you would like to capture an image from.
- 2 Touch  to pause the video on the frame you'd like to convert to an image and touch the upper left side of the screen to open the  menu.
- 3 From the options menu select .
- 4 The image will appear on the screen, with its image name.

- 5 Touch  to return to the video.
- 6 The image will be saved in your **My stuff** folder and appear in the gallery.



 **WARNING:** Some functions will not work properly if the multimedia file has not been recorded on the phone.

Viewing your photos as a slide show


Slideshow mode will show all the photos in your gallery one at a time as a slideshow. Videos can not be viewed as a slideshow.

- 1 Touch  in the **Gallery**, then scroll and select **Slide show**.
- 2 The slideshow will begin. There are options within slideshows: Touch  to go back.
 Touch to pause the slideshow on a particular photo.
 Touch again to resume playback.
 Touch to show random.
 Touch to increase or decrease the speed of the slideshow.

Setting a photo as wallpaper


- 1 Touch **Gallery** in the ENTERTAINMENT tab.
- 2 Touch the photo you would like to set as wallpaper.
- 3 Touch the screen to open the menu.
- 4 Touch .
- 5 You can change the size of the picture with .
- 6 When you are happy with the picture touch **Set**.
- 7 Choose from the options what you want to change: **All**, **Widget**, **Speed dial**.


Editing your photos


- 1 Open the photo you'd like to edit and touch  to bring up the options.
- 2 Touch the icons to alter your photo:

 Move your finger across the screen to select the area.


 Draw something on your photo freehand. Select the line thickness from the four options, then the colour you want to use.


 Add writing to the picture.


 Decorate your photo with stamps. Choose from the different stamps and colours and touch your photo where you want to place them.


 Erase whatever you draw. You can also select the eraser size.

 Touch to return to the gallery.

 Save the changes you have made to the photos. Select to save the changes over the **Original file**, or as a **New file**. If you select **New file**, enter a file name.

 Undo the last effect or edit you made to the photo.

 Touch to open the Filter options.

 You can adjust the selected photo.



Your photos and videos

Adding an effect to a photo

- 1 From the editing screen, touch



- 2 Choose to apply any of the options to the photo:

Face beautify - Automatically detect a face in the image and brighten it up.


Tunnel effect - Lomo camera effect.

Colour negative - Colour negative effect.

Black and white - Black and white colour effect.

Sepia - Give a Sepia effect.

Blur - Give a blurred effect.

Sharpen - Move the marker along the bar to sharpen the focus of the photo. Select **OK** icon to apply the changes or choose  to cancel.

Mosaic blur - Touch to apply a blurred mosaic effect to the photo.

Oil painting - Give an Oil painting effect.

Sketch - Apply an effect that makes the picture look like a sketch.

Emboss - Give an Emboss effect.

Vivid - Give an effect of clearness and brilliance.

Moonlight - Change the light to look like moonlight.

Antique - Give an old-looking effect.

Glow - Give a light beam effect.

Cartoon - Give a cartoon effect.

Water color - Give a watercolour effect.

- 3 To undo an effect simply touch

Undo  .

Multimedia

You can store any multimedia files on your phone's memory so that you have easy access to all your pictures, sounds, videos and games. You can also save your files to a memory card. Using a memory card allows you to free space in your phone's memory. You can find these files in the menu **My stuff** in the ENTERTAINMENT tab.

Pictures

Images contains a list of pictures including default images pre-loaded onto your phone, images downloaded by you and images taken on your phone's camera.


Sending a photo

- 1 Touch **My stuff** in the ENTERTAINMENT tab and select **Images**. Select the picture you want.
- 2 Touch **Send** and choose from **Multimedia message**, **Email** and **Bluetooth**.

Using an image

You can choose images to use as wallpapers and the lock screen or even to identify a caller.

- 1 Touch **My stuff** in the ENTERTAINMENT tab and select

Images. Select the picture you want. And touch .

- 2 Touch **Use as** and choose from:

Homescreen image - Set a wallpaper for the home screen.

Lock screen image - Set a wallpaper for the lock screen.

Contacts image - Allocate an image to a particular person in your contacts list so that their picture shows when they call you.

Start up image - Set an image to appear when you switch the phone on.

Shut down image - Set an image to appear when you switch the phone off.

Printing an image


- 1 Touch **My stuff** in the ENTERTAINMENT tab and select **Images**. Select the picture you want. And touch .
- 2 Touch **Print** then choose between **Bluetooth** and **PictBridge**.

TIP! You can print via bluetooth or by connecting to a PictBridge compatible printer.

Multimedia

Moving or copying a file

You can move or copy a file between the phone memory and the memory card. You might want to do this to either free some space in one of the memory banks or to safeguard your images from being lost.

- 1 Touch **My stuff** in the ENTERTAINMENT tab, select **Images** and touch .
- 2 Select **Move** or **Copy**.
- 3 You can mark/unmark the images by tapping it sequentially. Mark the image that you want to move or copy and touch **Copy/Move**.

Sounds

The **Sounds** contains a list of sounds including the downloaded sounds, default sounds and voice recordings. From here you can manage or send sounds or set them as a ringtone.

Using a sound

- 1 Touch **My stuff** in the ENTERTAINMENT tab and select **Sounds**.
- 2 Select a sound you want and a confirmation message appears.
- 3 Touch **Yes**. It will begin to play.
- 4 Touch  and select **Use as**.
- 5 Choose from **Ringtone**, **Message tone**, **Start-up** and **Shut down**.

Videos

The **Videos** shows a list of downloaded videos and videos you have recorded on your phone.

Watching a video

- 1 Touch **My stuff** in the ENTERTAINMENT tab and select **Videos**.
- 2 Select a video to play.

Sending a video clip

- 1 Select a video.
- 2 Touch  then **Send** and choose from **Message, Email, Bluetooth**.

Games & Apps

You can install new games and applications on your phone to keep you amused when you have spare time.

You can also access this using the menu **Games & Apps** in the ENTERTAINMENT tab.

Playing a game

- 1 Touch **Games & Apps** in the ENTERTAINMENT tab.
- 2 Select **Games**, then choose a game to launch.

Documents

From the **Documents** menu in **My stuff**, you can view all your document files. From here, you can view your Excel, PowerPoint, Word, Text and pdf files.

Transferring a file to your phone

Bluetooth is probably the easiest way of transferring a file from your computer to your phone. You can also use the Mass storage or LG PC Suite via your sync cable.

To transfer using Bluetooth:

- 1 Make sure your phone and computer have Bluetooth switched on and are visible to one another.
- 2 Use your computer to send the file via Bluetooth.
- 3 When the file is sent you will have to accept it on your phone by touching **Yes**.
- 4 The file should appear in **My folder** as a default, the second tab in **My stuff**. You may overlook the file if the folder is full.

Others

The **Others** contains a list of the files which are not pictures, sounds, videos, documents, games or applications.

Multimedia

Music

Your LG GM360 has a built-in music player so you can play all your favourite tracks. To access the music player, touch **Music** in the ENTERTAINMENT tab. From here, you can access a number of folders:

Recently played - Plays the songs you have played recently.

NOTE: The copyright of music files can be protected by international treaties and national copyright laws. It may be necessary to obtain permission or a license to reproduce or copy music. In some countries national law prohibits private copying of copyrighted material. Before downloading or copying the file, please check the national legislation of the applicable country concerning the use of such material.

All tracks - Contains all the songs you have on your phone except the pre-loaded default music.

Artists - Browse through your music collection by artist.

Albums - Browse through your music collection by album.

Genres - Browse through your music collection by genre.

Playlists - Contains all the playlists you have created.

Shuffle tracks - Play your tracks in a random order.

Transferring music onto your phone



The easiest way to transfer music onto your phone is via Bluetooth or your sync cable.

You can also use LG PC Suite. To transfer using Bluetooth:

- 1 Make sure both devices have Bluetooth switched on and can see each other.
- 2 Select the music file on the other device and choose to send it via Bluetooth.
- 3 When the file is ready to be sent you should accept it on your phone by touching **Yes**.
- 4 The file should appear in **Music > All tracks**.

Playing a song

- 1 Touch **Music** in the ENTERTAINMENT tab.
- 2 Select one of the folders and the song you want to play.
- 3 Touch **||** to pause the song.
- 4 Touch **▶▶** to skip to the next song.

- 5 Touch  to go back to the previous song.
- 6 Touch  to return to the **Music** menu. You may touch more than once to return to the menu.

Creating a playlist

You can create your own playlists by choosing a selection of songs from the **Playlists** folder.

- 1 Touch **Music** in the ENTERTAINMENT tab.
- 2 Touch **Playlists**, then **Add new playlist**, enter the playlist name and touch **Save**.
- 3 The **All tracks** folder will show all the songs in your phone. Touch all of the songs that you would like to include in your playlist; a tick will show next to the track names.
- 4 Touch **Done**.

FM Radio


Your LG GM360 has an FM radio feature so you can tune into your favourite stations to listen on the move.





You must attach your headphones to listen to the radio.

Searching for stations


You can tune your phone to radio stations by searching for them either manually or automatically. They will then be saved to specific channel numbers, so you don't have to keep re-tuning. You must first attach the headset to the phone as this acts as the aerial.

To auto tune:

- 1 Scroll and touch **FM radio** in the ENTERTAINMENT tab, then .
- 2 Touch **Auto scan**. A confirmation message appears. Select **Yes**, then the stations will be automatically found and allocated to a channel in your phone.


NOTE: You can also manually tune into a station by using  and  displayed in the centre of the screen. If you press and hold  and , the stations will be automatically found.

Resetting channels

- 1 Scroll and touch **FM radio** in the ENTERTAINMENT tab, then .
- 2 Choose **Reset channel** to reset the choose **Reset all channels** to reset all of the channels. Each channel will return to the starting 87.5MHz frequency.

Organiser

Adding an event to your calendar

- 1 Touch **Organiser** in the UTILITIES tab and select **Calendar**.
- 2 Select the date you would like to add an event to.
- 3 Touch  then **Add event**.
- 4 Touch **Category** then choose from **Appointment**, **Anniversary** or **Birthday**.
- 5 Enter **Subject**.
- 6 Check and enter the date and the time you would like your event to begin. For **Appointment** and **Anniversary** enter the time and date your event finishes in the lower two time and date boxes. Enter the location if it is an **Appointment**.
- 7 Set **Alarm** and **Repeat**.
- 8 Select **Save** and your event will be saved in the calendar. A square cursor will mark the day that any events have been saved to and a bell will ring at the start time of your event, so that you can stay organised.

Adding an item to your task list

- 1 Touch **Organiser** in the UTILITIES tab.
- 2 Select **Tasks** and touch **Add Task**.
- 3 Set the date for the task, add notes and select a priority level: **High**, **Medium** or **Low**.
- 4 Save your task by selecting **Save**.

Using date finder

Date finder is a handy tool to help you calculate what the date will be after a certain amount of days has passed. For example, 60 days from 10.10.07 will be 09.12.2007.


- 1 Touch **Organiser** in the UTILITIES tab.
- 2 Select **Date finder**.
- 3 Set the required date in the **From** tab.
- 4 Set the number of days in the **After** tab.
- 5 The **Target date** will be shown below.

Adding a memo

- 1 Touch **Memo** in the UTILITIES tab.
- 2 Touch **Add memo**.
- 3 Type your memo, then touch **Save**.
- 4 Your memo will then appear on the screen in the **Memo** application.

Setting your alarm


- 1 Touch **Alarm** in the UTILITIES tab. **Widget alarm** should appear in the list as default and you can not delete it.
- 2 Touch **Add alarm**.
- 3 Set the time you would like the alarm to sound in the **Time** field box.
- 4 Choose how you would like your alarm to repeat in the **Repeat** box: **Not repeated**, **Daily**, **Mon ~ Fri**, **Mon ~ Sat**, **Sat ~ Sun**, **Except holiday** or **Choose weekday**. The icons then indicate the weekday you select.

- 5 Select **Alarm type** to select the type of alarm you want.
- 6 Choose **Alarm bell** and select a sound from the folder. To listen to sounds, touch the sound, followed by .
- 7 Add a memo for the alarm in the **Memo** box.
- 8 Finally, you can set the snooze interval to 5, 10, 20, or 30 minutes, 1 hour or off.
- 9 Once you have set your alarm, touch **Save**.

NOTE: You can set up to 5 alarms including **Widget alarm**.

TIP! Slide the switch **ON/OFF** to the alarm to set it.

Adding a memo with the drawing Panel

- 1 Scroll and touch **Drawing Panel** in the UTILITIES tab .
- 2 Touch **Add drawing**.
- 3 Draw your memo on the touch screen LCD followed by .
- 4 Touch **Yes**, then your memo will appear on the screen in the **Drawing Panel** application.

Organiser

Screen Capture



The camera key is located on the right side of the phone. By pressing the Camera key twice, the screen can be captured. Captured image will be saved in Gallery as well as in Image in My Stuff.

This feature captures following screens:
WAP, SNS, Email composer & view screen, Message composer & Received messages etc.


Camera key



By pressing the Camera key twice, the screen can be captured.

Voice recorder

Use your voice recorder to record voice memos or other audio files.





Touch **Voice recorder** in the UTILITIES tab and select , then **Settings** to change Settings:

Duration - Set the recording duration. Choose from **No limit**, **MMS msg. size** or **1 min.**

Quality - Select the sound quality. Choose from **Super fine**, **Fine** or **Normal**.


Memory in use - Select where to save the audio files. Choose between External memory and Handset memory.

Recording a sound or voice

- 1 Touch  to begin recording.
- 2 Touch  to pause recording.
- 3 Touch  to end recording.
- 4 Touch  to listen to your recording.

Using your calculator

- 1 Touch **Tools** in the UTILITIES tab.
- 2 Select **Calculator**.
- 3 Touch the numeric keys using the keypad to input numbers.


- 4 For simple calculations, touch the function you require (+, -, ×, ÷), followed by =.
- 5 For more complex calculations, touch  and choose from **sin**, **cos**, **tan**, **log**, **ln**, **exp**, **sqrt**, **deg** or **rad** etc.

Converting a unit

- 1 Touch **Tools** in the UTILITIES tab.
- 2 Select **Unit converter**.
- 3 Choose whether you would like to convert **Currency**, **Surface**, **Length**, **Weight**, **Temperature**, **Volume** or **Velocity**.
- 4 You can then select the unit, and enter the value you would like to convert from, followed by the unit you would like to convert to.
- 5 The corresponding value will appear on the screen.

Adding a city to your World clock

- 1 Touch **Tools** in the UTILITIES tab.
- 2 Select **World clock**.
- 3 Touch the , followed by **New city**.

- 4 Scroll the globe, touch the area you want and choose the city on the map.
- 5 Or touch the  and type the name of the city you require in the search field box.


Using the stopwatch

- 1 Touch **Tools** in the UTILITIES tab.
- 2 Select **Stopwatch**.
- 3 Touch **Start** on the bottom of the screen to begin the timer.
- 4 Touch **Lap** if you want to record a lap time.
- 5 Touch **Stop** to end the timer.
- 6 Touch **Resume** to restart the stopwatch at the time you stopped it at, or touch **Reset** to begin the time again.


PC Sync

You can synchronise your PC with your phone to make sure all your important details and dates match. You can also backup your files to put your mind at ease.

Installing LG PC Suite on your computer

- 1 From the Home screen press  and select **Connectivity** on the SETTINGS tab.
- 2 Select **USB connection mode** and touch **PC Suite**.
- 3 Connect the handset and PC via USB cable and wait for a while. Installation guide message will be displayed.
- 4 Follow the instructions on the screen to complete the LG PC Suite Installer wizard.
- 5 Once installation is complete, the LG PC Suite icon will appear on your desktop.

Connecting your phone and PC

- 1 From the Home screen press  and select **Connectivity** on the SETTINGS tab.
- 2 Select **USB connection mode**.
- 3 Touch **PC Suite**.

- 4 Connect the handset and PC via USB cable and wait for a while. PC Suite runs automatically.

Backing up and restoring the information on your phone

- 1 Connect your phone to your PC as outlined above.
- 2 Click on the **Backup & Restore** at the Tools.
- 3 Mark the content you would like to backup or restore. Select the location you would like to backup information to, or restore information from. Click **Start** icon.
- 4 Your information will be backed up or restored.

Viewing phone files on your PC

- 1 Connect your phone to your PC as outlined previously.
- 2 Click on the **Photos** icon.
- 3 Phone image files will be loaded on the PC. When you click on the Phone Memory, they will be displayed.
- 4 Click on the **Videos** icon.
- 5 Phone video files will be loaded on the PC. When you click on

the Phone Memory, they will be displayed.

TIP! Viewing the contents of your phone on your PC helps you to arrange files, organise documents and remove content that you no longer need.

Synchronising your contacts


- 1 Connect the phone to your PC.
- 2 Click on the **Contacts** icon.
- 3 Your PC will now import and display all contacts saved to your handset. (Click on Sync Contacts, then it will load contacts of phone)
- 4 Click on File and select **Export**. You can now select the target and where you want to save your contacts to.

Synchronising your messages

- 1 Connect the phone to your PC.
- 2 Click on the **Messages** icon.
- 3 All your phone messages will be displayed in folders on the screen.
- 4 Click the title of the columns to rearrange messages sorted by **Sender, Contents** and **Received date**.

Using your phone as a Music Sync device

Your Phone can be used as a Music Sync device for Sync Music Files only. Music Sync can be carried out using Windows Media Player 10/11 and supports both Handset Memory and an External Memory Card.

- 1 Disconnect your phone from your PC.
- 2 From the Home screen select , then select **Connectivity** on the SETTINGS tab.
- 3 Select **USB connection mode**.
- 4 Touch **Music sync**.
- 5 Connect the phone to your PC. Your phone will read: **Connected**.

The web

Accessing the web

- 1 Touch the **Browser** in UTILITIES tab.
- 2 To go straight to the browser home page, select **Home**. Alternately, select **Enter address** and type in the URL, followed by **Connect**.

NOTE: An additional cost is incurred when connecting to this service and downloading content. Check your data charges with your network provider.

Adding and accessing your bookmarks

For easy and fast access to your favourite websites, you can add bookmarks and save web pages.


- 1 Touch **Browser** in the UTILITIES tab.
- 2 Select **Bookmarks**. A list of your Bookmarks will appear on the screen.
- 3 To add a new bookmark, touch **Add bookmark**. Enter a name for your bookmark followed by the URL in the corresponding field box.
- 4 Touch **Save**. Your Bookmark will now appear in the list of bookmarks.

- 5 To access the bookmark simply touch the Connect icon next to the bookmark or touch the bookmark title and then touch **Connect**. You will be connected to your bookmark.

Using RSS reader

RSS (Really Simple Syndication) is a family of web feed formats used to publish frequently updated content such as blog entries, news headlines or podcasts. An RSS document, which is called a feed, web feed, or channel, contains either a summary of content from an associated web site or the full text. RSS makes it possible for people to keep up with their favourite web sites automatically. It is much easier than checking them manually. The user subscribes to a feed by entering the feed's link into the reader or by clicking an RSS icon in a browser that initiates the subscription process. The reader checks the user's subscribed feeds regularly for new content, downloading any updates that it finds.

Saving a page

- 1 Access your required webpage as described above.
- 2 Touch  and select **Save this page**.
- 3 Enter a name for the webpage so you can easily recognise it.
- 4 Touch **Save**.

Accessing a saved page

Touch **Browser** in the UTILITIES tab. And select **Saved pages**. You can view the saved pages here.

Viewing your browser history

Touch **Browser** in the UTILITIES tab. And select **History**.

Changing the web browser settings

Touch **Browser** in the UTILITIES tab. And select **Settings**. You can choose to edit **Profiles**, **Appearance settings**, **Cache**, **Cookies** or **Security** settings.

Using your phone as a modem

Your GM360 can double as a modem for your PC, giving you email and internet access even when you can't connect using wires. You can use either the USB cable or Bluetooth.

Using the USB cable:

- 1 Ensure you have the LG PC Suite installed on your PC.
- 2 Connect your GM360 and your PC using the USB cable as outlined previously and launch the LG PC Suite software.
- 3 Click **InternetKit** on your PC. Then click **Add** button and select **Modem**.
- 4 Write the Profile that can connect to the Internet and save the values.
- 5 The profile that you create will appear on your PC screen. Select it and click **Connect**. Your PC will connect through your GM360.

NOTE: For more information about synchronising using the LG PC Suite.

The web

Using Bluetooth:

- 1 Ensure Bluetooth is switched **On** and **Visible** for both your PC and GM360.
- 2 Pair your PC and GM360 so that a passcode is required for connection.
- 3 Use the **Connection wizard** on your LG PC Suite to create an active Bluetooth connection.
- 4 Click **Internet Kit** on your PC. Then click **New** button.
- 5 Choose **LG Mobile USB Modem** and select **OK**. It will now appear on screen.
- 6 Write the Profile that can connect to the Internet and save the values.
- 7 The profile that you create will appear on your PC screen. Select it and click **Connect**.
Your PC will connect through your GM360.

Access to Google

You can use Google service using this menu.

Google service offers user a chance to use **Search**.

Settings

Personalising your profiles

You can quickly change your profile on the Home screen.

You can personalise each profile setting using the settings menu.

- 1 Touch **Profiles** in the SETTINGS tab.
- 2 Choose the profile you want to edit.
- 3 You can then change all the sounds and alert options available in the list, including your **Ringtone** and **Volume**, **Message tone** settings and more.

Changing your screen settings

Touch **Screen settings** in SETTINGS tab.

Screen settings

Wallpaper - Choose the theme for your home screen or lock screen.

Widget home template - Choose a home template.

Livesquare - Touch **Livesquare guide** to check its functions.

Handset theme - Choose black or white (Cartoon styled UI).

Top menu - Choose the style of the top menu, **Zigzag**, **Scrolling** or **Screen by screen**.

Lock screen - Choose the way of unlock.

Lock screen gesture - Choose the gesture type in a lock screen.

Dialling - Adjust the number colour.

Font - Adjust the font size. There are four options: **Small**, **Medium**, **Large** and **Very large**.

NOTE: The longer the backlight is on, the more battery power is used. This may result in your needing to charge your phone more often.

Brightness - Adjust the screen brightness.

Greeting message - Choose **ON** or **OFF** and fill in the greeting message in the text field.

Network name - Choose **On** or **Off**.

Start-up/Shut down - Choose the theme for your start-up/shut down screen.

Settings

Changing your phone settings

Enjoy the freedom of adapting how your GM360 works for your own style.

Touch **Phone settings** in the **SETTINGS** tab, then choose from the list below.

Phone settings

Date & Time - Adjust your date and time settings or choose whether to update the time automatically or to use the daylight saving option.

Power save - Choose to switch the factory set power saving settings on/off or Night only.

Languages - Change the language of your GM360's display.

Auto keylock - Lock the keypad automatically in the Home screen.

Security - Adjust your security settings, including PIN codes and handset lock.

Memory info - See **Using memory manager** for more information.

Reset settings - Restores all settings to their factory defaults.

Information - Select **Help** to view the technical information for your GM360. And you can upgrade software with **Handset information**.

Using memory manager

Your GM360 has three memories available: the phone, the SIM Card and an external memory card.

You can use memory manager to see how each memory is been used and see how much space is available.

Touch **Phone settings** in the **SETTINGS** tab, then **Memory info**.

Handset common memory - View the memory available on your GM360 for Pictures, Sounds, Videos, MMS, Email, Java applications and others.

Handset reserved memory - View the memory available on your handset for SMS, Contacts, Calendar, Task list, Memo, Alarm, Call history, Bookmarks and Miscellaneous items.

SIM memory - View the memory available on your SIM Card.

External memory - View the memory available on your external memory card (you may need to purchase the memory card separately).

Primary storage setting - Choose the location you prefer items to be saved to between Handset and External memory.

Changing your connectivity settings

Your connectivity settings have already been set up by your network operator, so you can enjoy your new phone immediately. To change any settings, use this menu: Touch **Connectivity** in the **SETTINGS** tab.

Network settings

Select network - If you select Automatic, the GM360 automatically searches for the network and registers the handset to the network. This is recommended for best service and quality. If you select Manual, all the currently available networks are shown and you can select one of them for registration.

Preferred lists - You can add a preferred network to connect to. If the network is searching automatically, simply choose one from the network list and if not, add a new network manually.

Internet profiles - This menu shows the Internet profiles. You cannot delete or edit default configurations depending on your country variant.

Access points - Your network operator has already saved this information. You can add new access points using this menu.

Packet data conn. - Choose when your device should be connected to network for packet data.

USB connection mode - Choose a Data service from the options and synchronise your GM360 using the LG PC Suite software to copy files from your phone. See **PC Sync** for more information on synchronisation. If you use Music sync with Windows Media Player, select **Music sync** in this menu. **Music sync** is only available for music content.

Sending and receiving your files using Bluetooth

To send a file:

- 1 Open the file you want to send, typically this will be a photo, video or music file.
- 2 Choose **Send**.
Choose **Bluetooth**.

Settings


- 3 If you have already paired the **Bluetooth** device, your GM360 will not automatically search for other **Bluetooth** devices. If not, your GM360 will search for other **Bluetooth** enabled devices within range.
- 4 Choose the device you want to send the file to.
- 5 Your file will be sent.

TIP! Check the progress bar to make sure your file is sent.

To receive a file:

- 1 To receive files, your Bluetooth must be both **ON** and **Visible**. See **Changing your Bluetooth settings** below for more information.
- 2 A message will prompt you to accept the file from the sender. Touch **Yes** to receive the file.
- 3 You will see where the file has been saved. For image files, you can choose to **View** the file or **Use as wallpaper**. Files will usually be saved to the appropriate folder in **My stuff**.

Changing your Bluetooth settings:

Touch **Bluetooth** in the **SETTINGS** tab. And select  and choose **Settings**.

Make your changes to:

My device visibility - Choose to be **Visible**, **Hidden** or **Visible for 1 min**.

My device name - Enter a name for your GM360.

Supported services - Select how to use Bluetooth in association with different services.

Remote SIM Mode - Turn on or off.

My address - Show your Bluetooth address.

Pairing with another Bluetooth device

By pairing your GM360 and another device, you can set up a passcode protected connection.

- 1 Check that your Bluetooth is **ON** and **Visible**. You can change your visibility in the **Settings** menu.
- 2 Touch **Search**.
- 3 Your GM360 will search for devices. When the search is completed, **Refresh** will appear on screen.

- 4 Choose the device you want to pair with and enter the passcode, then touch **OK**.
- 5 Your phone will then connect to the other device, on which you will need to enter the same passcode.
- 6 Your passcode protected Bluetooth connection is now ready.

Using a Bluetooth headset

- 1 Check your Bluetooth is **On** and **Visible**.
- 2 Follow the instructions that came with your headset to put it in pairing mode and pair your devices.
- 3 Touch **Ask before connect** or **Always connect** and touch **Yes** to Connect now. Your GM360 will automatically switch to Headset profile.

Software Upgrade

LG Mobile Phone Software Upgrade Program

For more information on installing and using this program, please visit <http://update.lgmobile.com>. This feature allows you to upgrade your software to the latest version quickly and conveniently on the

Internet without needing to visit our service centre. As the mobile phone software upgrade program requires the user's full attention for the duration of the upgrade process, please be sure to check any instructions and notes that appear at each step before proceeding. Please note that removing the USB data communication cable or batteries during the upgrade may seriously damage your mobile phone. As the manufacturer takes no responsibility for loss of data during the upgrade process, you are advised to note down any important information in advance for safekeeping.

Accessories

These accessories are supplied with the GM360.

Charger



Data cable



Battery



Stereo headset



NOTE:

- Always use genuine LG accessories.
- Failure to do this may invalidate your warranty.
- Accessories may be different in different regions; please check with our regional service company or agent for further inquiries.

Technical data

General

Product name : GM360

System : GSM 850 / E-GSM 900 / DCS 1800 / PCS 1900

Ambient Temperatures

Max : +55°C (discharging),
+45°C (charging)

Min : -10°C

Declaration of Conformity



Suppliers Details

Name

LG Electronics Inc

Address

LG Twin Tower 20, Yeouido-dong, Yeongdeungpo-gu Seoul, Korea 150-721

Product Details

Product Name

GSM 850 / E-GSM 900 / DCS 1800 / PCS 1900 Quad Band Terminal Equipment

Model Name

GM360

Trade Name

LG

CE 0168

Applicable Standards Details

R&TTE Directive 1999/5/EC

EN 301 489-01 v1.8.1 / EN 301 489-07 v1.3.1 / EN 301 489-17 v1.3.2

EN 300 328 V 1.7.1

EN 60950-1 : 2001

EN 50360:2001/EN62209-1:2006

EN 301 511 V9.0.2

Supplementary Information

The conformity to above standards is verified by the following Notified Body(BABT)

BABT, Forsyth House, Churchfield Road, Walton-on-Thames, Surrey, KT12 2TD, United Kingdom
Notified Body Identification Number : 0168

Declaration

I hereby declare under our sole responsibility that the product mentioned above to which this declaration relates complies with the above mentioned standards and Directives


Name

Issued Date

Seung Hyoun, Ji / Director

30. MAR. 2010

LG Electronics Logistics and Services B.V.
Veluwezoom 15, 1327 AE Almere, The Netherlands


Signature of representative

Guidelines for safe and efficient use

Please read these simple guidelines. Not following these guidelines may be dangerous or illegal.

Exposure to radio frequency energy

Radio wave exposure and Specific Absorption Rate (SAR) information. This mobile phone model GM360 has been designed to comply with applicable safety requirements for exposure to radio waves. These requirements are based on scientific guidelines that include safety margins designed to assure the safety of all persons, regardless of age and health.

- The radio wave exposure guidelines employ a unit of measurement known as the Specific Absorption Rate, or SAR. Tests for SAR are conducted using standardised methods with the phone transmitting at its highest certified power level in all used frequency bands.
- While there may be differences between the SAR levels of various LG phone models, they are all designed to meet the relevant guidelines for exposure to radio waves.
- The SAR limit recommended by the International Commission on

Non-Ionizing Radiation Protection (ICNIRP) is 2W/kg averaged over 10g of tissue.

- The highest SAR value for this model phone tested by DASy4 for use at the ear is 1.33 W/kg (10 g) and when worn on the body is 1.31 W/kg(10 g).
- SAR data information for residents in countries/regions that have adopted the SAR limit recommended by the Institute of Electrical and Electronics Engineers (IEEE), which is 1.6 W/kg averaged over 1g of tissue.

Product care and maintenance

WARNING

Only use batteries, chargers and accessories approved for use with this particular phone model. The use of any other types may invalidate any approval or warranty applying to the phone, and may be dangerous.

- Do not disassemble this unit. Take it to a qualified service technician when repair work is required.
- Keep away from electrical appliances such as TVs, radios, and personal computers.

Guidelines for safe and efficient use

- The unit should be kept away from heat sources such as radiators or cookers.
- Do not drop.
- Do not subject this unit to mechanical vibration or shock.
- Switch off the phone in any area where you are required by special regulations. For example, do not use your phone in hospitals as it may affect sensitive medical equipment.
- Do not handle the phone with wet hands while it is being charged. It may cause an electric shock and can seriously damage your phone.
- Do not charge a handset near flammable material as the handset can become hot and create a fire hazard.
- Use a dry cloth to clean the exterior of the unit (do not use solvents such as benzene, thinner or alcohol).
- Do not charge the phone when it is on soft furnishings.
- The phone should be charged in a well ventilated area.
- Do not subject this unit to excessive smoke or dust.
- Do not keep the phone next to credit cards or transport tickets; it can affect the information on the magnetic strips.
- Do not tap the screen with a sharp object as it may damage the phone.
- Do not expose the phone to liquid or moisture.
- Use the accessories like earphones cautiously. Do not touch the antenna unnecessarily.

Efficient phone operation

Electronics devices

- All mobile phones may get interference, which could affect performance.
- Do not use your mobile phone near medical equipment without requesting permission. Avoid placing the phone over pacemakers, for example, in your breast pocket.
 - Some hearing aids might be disturbed by mobile phones.
 - Minor interference may affect TVs, radios, PCs, etc.

Road safety

- Check the laws and regulations on the use of mobile phones in the area when you drive.
- Do not use a hand-held phone while driving.
 - Give full attention to driving.

- Use a hands-free kit, if available.
- Pull off the road and park before making or answering a call if driving conditions so require.
- RF energy may affect some electronic systems in your vehicle such as car stereos and safety equipment.
- When your vehicle is equipped with an air bag, do not obstruct with installed or portable wireless equipment. It can cause the air bag to fail or cause serious injury due to improper performance.
- If you are listening to music whilst out and about, please ensure that the volume is at a reasonable level so that you are aware of your surroundings. This is particularly imperative when near roads.

Avoid damage to your hearing

Damage to your hearing can occur if you are exposed to loud sound for long periods of time. We therefore recommend that you do not turn on or off the handset close to your ear. We also recommend that music and call volumes are set to a reasonable level.

Glass Parts

Some parts of your mobile device are made of glass. This glass could break if your mobile device is dropped on a hard surface or receives a substantial impact. If the glass breaks, do not touch or attempt to remove. Stop using your mobile device until the glass is replaced by an authorised service provider.

Blasting area

Do not use the phone where blasting is in progress. Observe restrictions, and follow any regulations or rules.

Potentially explosive atmospheres

- Do not use the phone at a refueling point.
- Do not use near fuel or chemicals.
- Do not transport or store flammable gas, liquid, or explosives in the same compartment of your vehicle as your mobile phone and accessories.

In aircraft

Wireless devices can cause interference in aircraft.

- Turn your mobile phone off before boarding any aircraft.

Guidelines for safe and efficient use

- Do not use it on the ground without permission from the crew.

Children

Keep the phone in a safe place out of the reach of small children. It includes small parts which may cause a choking hazard if detached.

Emergency calls

Emergency calls may not be available under all mobile networks. Therefore, you should never depend solely on the phone for emergency calls. Check with your local service provider.

Battery information and care

- You do not need to completely discharge the battery before recharging. Unlike other battery systems, there is no memory effect that could compromise the battery's performance.
- Use only LG batteries and chargers. LG chargers are designed to maximise the battery life.
- Do not disassemble or short-circuit the battery pack.
- Keep the metal contacts of the battery pack clean.
- Replace the battery when it no longer provides acceptable

performance. The battery pack maybe recharged hundreds of times until it needs replacing.

- Recharge the battery if it has not been used for a long time to maximise usability.
- Do not expose the battery charger to direct sunlight or use it in high humidity, such as in the bathroom.
- Do not leave the battery in hot or cold places, this may deteriorate the battery performance.
- There is risk of explosion if the battery is replaced by an incorrect type.
- Dispose of used batteries according to the manufacturer's instructions. Please recycle when possible. Do not dispose as household waste.
- If you need to replace the battery, take it to the nearest authorised LG Electronics service point or dealer for assistance.
- Always unplug the charger from the wall socket after the phone is fully charged to save unnecessary power consumption of the charger.
- Actual battery life will depend on network configuration, product settings, usage patterns, battery and environmental conditions.

ΟΡΟΙ ΕΓΓΥΗΣΗΣ

1. ΤΙ ΚΑΛΥΠΤΕΙ ΑΥΤΗ Η ΕΓΓΥΗΣΗ

Η LG σας εγγυάται ότι το συσκευασμένο τηλέφωνο όπως και τα περιεχόμενα εξαρτήματα δεν θα έχουν πρόβλημα όσον αφορά τα υλικά και την τεχνική αρτιότητα τους, σύμφωνα με τους ακόλουθους όρους και προϋποθέσεις:

- (1) Η εγγύηση του προϊόντος ισχύει για 24 μήνες, αρχής γενομένης από την ημερομηνία προμήθειας του προϊόντος.
- (2) Η εγγύηση των 24 μηνών ισχύει από την ημερομηνία της πρώτης πώλησης και δεν ανανεώνεται με την μεταπώληση του προϊόντος.
- (3) Η εγγύηση αυτή είναι έγκυρη μόνο για τον αρχικό αγοραστή του προϊόντος κατά τη διάρκεια της περιόδου εγγύησης, αλλά είναι περιορισμένη για συγκεκριμένη χώρα εάν έχει οριστεί.
- (4) Το εξωτερικό περίβλημα και τα διακοσμητικά εξαρτήματα θα πρέπει να μην παρουσιάζουν πρόβλημα κατά την ώρα αποστολής και, για το λόγο αυτό, δεν θα καλύπτονται από τους όρους αυτής της εγγύησης.
- (5) Κατόπιν αιτήσεως της LG, ο καταναλωτής πρέπει να έχει τη δυνατότητα να παρέχει πληροφορίες που να αποδεικνύουν την ημερομηνία προμήθειας της συσκευής.
- (6) Η LG θα επιβαρύνεται με το κόστος αποστολής του προϊόντος από και προς το εκάστοτε εξουσιοδοτημένο κέντρο τεχνικής εξυπηρέτησης πελατών LG υπό την προϋπόθεση ότι η εγγύηση βρίσκεται σε ισχύ και ο πελάτης, χρησιμοποιεί την ταχύ μεταφορική εταιρία που έχει οριστεί από την LG.

2. ΤΙ ΔΕΝ ΚΑΛΥΠΤΕΙ ΑΥΤΗ Η ΕΓΓΥΗΣΗ

- (1) Προβλήματα ή βλάβες που προέρχονται από τη χρήση του προϊόντος με διαφορετικό τρόπο από τον κανονικό και συνήθη.
- (2) Προβλήματα ή βλάβες από αντικανονική χρήση, αντικανονικές συνθήκες, ακατάλληλη αποθήκευση, έκθεση σε υγρό περιβάλλον ή υγρασία, αυθαίρετες μετατροπές, αντικανονικές συνδέσεις, επισκευές χωρίς εξουσιοδότηση, κακή χρήση, αμέλεια, κακομεταχείριση, ατύχημα, μετατροπή, αντικανονική εγκατάσταση, ή άλλες ενέργειες που δεν ευθύνεται η LG, συμπεριλαμβανομένων βλαβών που προέρχονται από την μεταφορά, διείσδυση τροφών ή υγρών.
- (3) Θραύση ή βλάβη στις κεραίες εκτός και αν προκλήθηκαν άμεσα από πρόβλημα υλικού ή κακοτεχνίας.
- (4) Όταν το Τμήμα Τεχνικής Εξυπηρέτησης Πελατών της LG δεν ενημερώθηκε από τον καταναλωτή για το θεωρούμενο πρόβλημα ή δυσλειτουργία του προϊόντος κατά τη χρονική διάρκεια της εγγύησης.

- (5) Προϊόντα από τα οποία έχει αφαιρεθεί ο σειριακός αριθμός ή έχει καταστεί άκυρος.
- (6) Αυτή η εγγύηση αντικαθιστά όλες τις άλλες εγγυήσεις, άμεσες ή έμμεσες που προκύπτουν είτε ουσιαστικά είτε από ερμηνεία των νόμων, προβλεπόμενες από το νόμο ή με διαφορετικό τρόπο, συμπεριλαμβανομένων, αλλά μη περιορισμένων από οποιαδήποτε έμμεση εγγύηση εμπροσεισιμότητας ή καταλληλότητας για μία συγκεκριμένη χρήση.
- (7) Βλάβη που προέρχεται από τη χρήση μη εγκεκριμένων προαιρετικών εξαρτημάτων από την LG.
- (8) Όλες τις πλαστικές επιφάνειες και όλα τα άλλα εξωτερικά εκτεθειμένα εξαρτήματα που έχουν χαραχθεί ή χαλάσει εξ αιτίας της συνήθους χρήσης από τον πελάτη.
- (9) Προϊόντα που έχουν λειτουργήσει εκτός των ορίων των μέγιστων προδιαγραφών.
- (10) Προϊόντα που χρησιμοποιούνται ή αποκτώνται με πρόγραμμα νοίκιασης.
- (11) Αναλώσιμα υλικά.

3. ΟΡΟΙ:

Καμία άλλη διατυπωμένη εγγύηση δεν είναι εφαρμόσιμη σ' αυτό το προϊόν.
Η ΔΙΑΡΚΕΙΑ ΟΠΟΙΑΣΔΗΠΟΤΕ ΕΜΜΕΣΗΣ ΕΓΓΥΗΣΗΣ, ΣΥΜΠΕΡΙΛΑΜΒΑΝΟΜΕΝΗΣ ΤΗΣ ΕΜΜΕΣΗΣ ΕΓΓΥΗΣΗΣ ΕΜΠΟΡΕΥΣΙΜΟΤΗΤΑΣ, ΠΕΡΙΟΡΙΖΕΤΑΙ ΣΤΗ ΔΙΑΡΚΕΙΑ ΤΗΣ ΔΙΑΤΥΠΩΜΕΝΗΣ ΕΓΓΥΗΣΗΣ Σ' ΑΥΤΟ ΤΟ ΕΓΓΡΑΦΟ. Η LG ELECTRONICS ΔΕΝ ΘΑ ΕΥΘΥΝΕΤΑΙ ΓΙΑ ΤΗΝ ΑΔΥΝΑΜΙΑ ΧΡΗΣΗΣ ΤΟΥ ΠΡΟΪΟΝΤΟΣ, ΑΝΑΣΤΑΤΩΣΗ, ΑΠΩΛΕΙΑ Ή ΑΛΛΕΣ ΒΛΑΒΕΣ, ΑΜΕΣΕΣ Ή ΣΥΝΕΠΑΚΟΛΟΥΘΕΣ, ΠΟΥ ΕΓΓΕΙΡΟΝΤΑΙ ΑΠΟ ΤΗ ΧΡΗΣΗ Η ΤΗΝ ΑΔΥΝΑΜΙΑ ΧΡΗΣΗΣ ΑΥΤΟΥ ΤΟΥ ΠΡΟΪΟΝΤΟΣ Ή ΓΙΑ ΟΠΟΙΑΔΗΠΟΤΕ ΑΘΕΤΗΣΗ ΔΙΑΤΥΠΩΜΕΝΗΣ Ή ΕΜΜΕΣΗΣ ΕΓΓΥΗΣΗΣ, ΣΥΜΠΕΡΙΛΑΜΒΑΝΟΜΕΝΗΣ ΤΗΣ ΕΜΜΕΣΗΣ ΕΓΓΥΗΣΗΣ ΕΜΠΟΡΕΥΣΙΜΟΤΗΤΑΣ ΠΟΥ ΕΦΑΡΜΟΖΕΤΑΙ Σ' ΑΥΤΟ ΤΟ ΠΡΟΪΟΝ.

Μερικές χώρες δεν επιτρέπουν τον ορισμό ορίων των δευτερευόντων ή συνεπακόλουθων βλαβών ή περιορισμών στο χρόνο διάρκειας της έμμεσης εγγύησης, έτσι αυτοί οι περιορισμοί ή οι εξαιρέσεις μπορεί να μην ισχύουν για εσάς. Η εγγύηση αυτή σας δίνει συγκεκριμένα νομικά δικαιώματα και μπορεί να έχετε επίσης άλλα δικαιώματα που ποικίλουν από χώρα σε χώρα.

**Για περισσότερες πληροφορίες
τηλεφωνήστε στο: 800 11 200 300**



LG Electronics Inc.

