

عربي
ENGLISH



ENGLISH
عربي

دليل مستخدم

GX500

USER GUIDE

GX500



CE 0168 !

www.lg.com

P/NO : MMBB0371112 (1.0) W



CE 0168 !

www.lg.com

P/NO : MMBB0371112 (1.0) W

Bluetooth QD ID B016312



Some of the contents in this manual may differ from your phone depending on the software of the phone or your service provider.



GX500 User Guide

Congratulations on your purchase of the advanced and compact GX500 phone by LG, designed to operate with the latest digital mobile communication technology.

Contents

Guidelines for safe and efficient use	6
Getting to know your phone	10
Open view	12
Installing the SIM and battery	13
Memory card	15
Menu map	16
Your standby screen	17
Touch screen tips	17
The quick keys	18
Changing your Status from the status bar	20
Using the Multitasking function ..	20
Calls	21
Making a call.....	21
Making a call from your contacts.....	21
Answering and rejecting a call ..	21
Speed dialling	21
Making a second call	22
Viewing your call logs.....	22
Using call divert.....	23
Using call barring.....	23
Changing the common call setting	24
Contacts	25
Searching for a contact	25
Adding a new contact	25
Creating a group.....	26
Changing your contact settings ..	26
Viewing information	27
Messaging	28
Messaging	28
Sending a message	28
Entering text.....	29
T9 predictive	29
Abc manual.....	29
Keyboard.....	30
Handwriting recognition.....	30
Setting up your email	30
Retrieving your email	31
Changing your email settings.....	31
Message folders	32
Changing your text message settings.....	32
Changing your multimedia message settings	33
Changing your other settings ..	34
Camera	35
Taking a quick photo	35
After you've taken your photo ..	35
Using the advanced settings.....	35
Viewing your saved photos	36

Contents

Video camera.....	37	Playing a game.....	44
Shooting a quick video.....	37	Documents.....	44
After you've shot your video.....	37	Transferring a file to your phone.....	45
Adjusting the Exposure.....	38	Viewing a file.....	45
Using the advanced settings.....	38	Others.....	45
Watching your saved videos.....	39	Music.....	46
Your photos and videos.....	40	Transferring music onto your phone.....	46
Viewing your photos and videos.....	40	Playing a song.....	47
Using zoom when viewing a photo.....	40	Creating a playlist.....	47
Adjusting the volume when viewing a video.....	40	Using the radio.....	47
Setting a photo as wallpaper.....	40	Searching for stations.....	48
Editing your photos.....	41	Resetting channels.....	48
Multimedia.....	42	Utilities.....	49
Pictures.....	42	Recording a sound or voice.....	49
Sending a photo.....	42	Using your calculator.....	49
Printing an image.....	42	Converting a unit.....	49
Moving or copying an image.....	43	Adding a city to your world time.....	49
Sounds.....	43	Using the stopwatch.....	50
Videos.....	43	Adding an item to your calendar.....	50
Watching a video.....	43	Adding an item to your task list.....	51
Sending a video clip.....	43	Date finder.....	51
Games and Applications.....	44	Settings.....	51
Installing a game/application via local install.....	44		

PC Suite	52	Settings	61
Installing the LG PC Suite on your computer	52	Using Dual SIM-card menu.....	61
Connecting your phone and PC	52	Personalising your profiles.....	61
Backing up and restoring your phone's information	53	Changing your screen settings...61	
Viewing phone files on your PC..	53	Changing your phone settings ...62	
Synchronising your contacts.....	54	Changing your connectivity settings.....	63
Synchronising the messages	54	Network settings	63
Music Sync	54	Connectivity Settings.....	64
Transferring music using Windows Media Player	55	Java settings.....	64
DivX Converter.....	55	Using memory manager	64
The web.....	57	Sending and receiving your files using Bluetooth.....	65
Browser	57	Pairing with another Bluetooth device.....	66
Opera Mini	57	Using a Bluetooth headset.....	66
Accessing the web.....	57	Wi-Fi.....	67
Adding and accessing your bookmarks	58	Software Upgrade.....	67
Using RSS reader.....	58	Accessories	68
Saving a page	59	Network service.....	69
Accessing a saved page.....	59	Technical data.....	69
Viewing your browser history	59	Trouble Shooting.....	71
Changing the web browser settings.....	59		
Using your phone as a modem ..	60		

Guidelines for safe and efficient use


Please read these simple guidelines. Not following these guidelines may be dangerous or illegal.

Exposure to radio frequency energy

Radio wave exposure and Specific Absorption Rate (SAR) information. This mobile phone model GX500 has been designed to comply with applicable safety requirements for exposure to radio waves. These requirements are based on scientific guidelines that include safety margins designed to assure the safety of all persons, regardless of age and health.

- The radio wave exposure guidelines employ a unit of measurement known as the Specific Absorption Rate, or SAR. Tests for SAR are conducted using standardised methods with the phone transmitting at its highest certified power level in all used frequency bands.
- While there may be differences between the SAR levels of various LG phone models, they are all designed to meet the relevant guidelines for exposure to radio waves.
- The SAR limit recommended by the International Commission on Non-Ionizing Radiation Protection (ICNIRP) is 2W/kg averaged over 10g of tissue.
- The highest SAR value for this model phone tested by DASY4 for use at the ear is 1.45 W/kg (10g) and when worn on the body is 0.841 W/Kg (10g).
- SAR data information for residents in countries/regions that have adopted the SAR limit recommended by the Institute of Electrical and Electronics Engineers (IEEE), which is 1.6 W/kg averaged over 1g of tissue.

Product care and maintenance

 **WARNING:** Only use batteries, chargers and accessories approved for use with this particular phone model. The use of any other types may invalidate any approval or warranty applying to the phone, and may be dangerous.

- Do not disassemble this unit. Take it to a qualified service technician when repair work is required. Repairs under warranty, at LG's option, may include replacement parts or boards that are either new or reconditioned, provided that they have functionality equal to that of the parts being replaced.
- Keep away from electrical appliances such as TVs, radios, and personal computers.
- The unit should be kept away from heat sources such as radiators or cookers.
- Do not drop.
- Do not subject this unit to mechanical vibration or shock.
- Switch off the phone in any area where you are required by special regulations. For example, do not use your phone in hospitals as it may affect sensitive medical equipment.
- Do not handle the phone with wet hands while it is being charged. It may cause an electric shock and can seriously damage your phone.
- Do not charge a handset near flammable material as the handset can become hot and create a fire hazard.
- Use a dry cloth to clean the exterior of the unit (do not use solvents such as benzene, thinner or alcohol).
- Do not charge the phone when it is on soft furnishings.
- The phone should be charged in a well ventilated area.
- Do not subject this unit to excessive smoke or dust.
- Do not keep the phone next to credit cards or transport tickets; it can affect the information on the magnetic strips.
- Do not tap the screen with a sharp object as it may damage the phone.
- Do not expose the phone to liquid or moisture.
- Use the accessories like earphones cautiously. Do not touch the antenna unnecessarily.

Efficient phone operation

Electronics devices

All mobile phones may get interference, which could affect performance.

- Do not use your mobile phone near medical equipment without requesting permission. Avoid placing the phone over pacemakers, for example, in your breast pocket.

Guidelines for safe and efficient use

- Some hearing aids might be disturbed by mobile phones.
- Minor interference may affect TVs, radios, PCs, etc.

Road safety

Check the laws and regulations on the use of mobile phones in the area when you drive.

- Do not use a hand-held phone while driving.
- Give full attention to driving.
- Use a hands-free kit, if available.
- Pull off the road and park before making or answering a call if driving conditions so require.
- RF energy may affect some electronic systems in your vehicle such as car stereos and safety equipment.
- When your vehicle is equipped with an air bag, do not obstruct with installed or portable wireless equipment. It can cause the air bag to fail or cause serious injury due to improper performance.
- If you are listening to music whilst out and about, please ensure that the volume is at a reasonable level so that you are aware of your surroundings. This is particularly imperative when near roads.

Avoid damage to your hearing

Damage to your hearing can occur if you are exposed to loud sound for long periods of time. We therefore recommend that you do not turn on or off the handset close to your ear. We also recommend that music and call volumes are set to a reasonable level.

Blasting area

Do not use the phone where blasting is in progress. Observe restrictions, and follow any regulations or rules.

Potentially explosive atmospheres

- Do not use the phone at a refueling point.
- Do not use near fuel or chemicals.
- Do not transport or store flammable gas, liquid, or explosives in the same compartment of your vehicle as your mobile phone and accessories.

In aircraft

Wireless devices can cause interference in aircraft.

- Turn your mobile phone off before boarding any aircraft.
- Do not use it on the aircraft without permission from the crew.

Children

Keep the phone in a safe place out of the reach of small children. It includes small parts which may cause a choking hazard if detached.

Emergency calls

Emergency calls may not be available under all mobile networks. Therefore, you should never depend solely on the phone for emergency calls. Check with your local service provider.

Battery information and care

- You do not need to completely discharge the battery before recharging. Unlike other battery systems, there is no memory effect that could compromise the battery's performance.
- Use only LG batteries and chargers. LG chargers are designed to maximize the battery life.
- Do not disassemble or short-circuit the battery pack.
- Keep the metal contacts of the battery pack clean.
- Replace the battery when it no longer provides acceptable performance. The battery pack may be recharged hundreds of times until it needs replacing.
- Recharge the battery if it has not been used for a long time to maximize usability.
- Do not expose the battery charger to direct sunlight or use it in high humidity, such as in the bathroom.
- Do not leave the battery in hot or cold places, this may deteriorate the battery performance.
- There is risk of explosion if the battery is replaced by an incorrect type.
- Dispose of used batteries according to the manufacturer's instructions. Please recycle when possible. Do not dispose as household waste.
- If you need to replace the battery, take it to the nearest authorized LG Electronics service point or dealer for assistance.
- Always unplug the charger from the wall socket after the phone is fully charged to save unnecessary power consumption of the charger.
- Actual battery life will depend on network configuration, product settings, usage patterns, battery and environmental conditions.

Getting to know your phone

End/Power key

Ends or rejects a call.
Turns the phone on/off.
Press once to return to the standby screen.



Multitasking key

Call key


Dials a phone number and answers incoming calls.



⚠ WARNING: Placing a heavy object on the phone or sitting on it while it is in your pocket can damage the phone's LCD and touch screen functionality.



Open view



Installing the SIM and battery

1 Remove the battery cover

Slide the battery cover towards the bottom of the phone and away from it.



2 Remove the battery

Using the cut-out at the top and lift it from the battery compartment.



⚠ WARNING: Do not use your fingernail when removing the battery.


⚠ WARNING: Do not remove the battery when the phone is switched on, as this may damage the phone.

3 Install the SIM card

Slide the SIM card into the SIM card holder making sure that the gold contact area on the card is facing downwards. To remove the SIM card, pull it gently in the opposite direction.



⚠ WARNING



Make sure that your SIM card has a neat and clean cut before you insert it into the holder.

Installing the SIM and battery

4 Install the battery

Insert the bottom of the battery first into the bottom edge of the battery compartment. Ensure that the battery contacts align with the terminals on the phone. Press down the top of the battery until it clicks into place.



6 Charging your phone

Lift and twist the charger socket cover on the side of your GX500. Insert the charger and plug it into a mains electricity socket. Your GX500 needs to be charged until "Battery full" appears on screen.



5 Replace the battery cover

Slide the battery cover towards the top of the phone until it clicks into place.


Memory card

Installing a memory card

You can expand the memory space on your phone by using a MicroSD memory card.


NOTE: A memory card is an optional accessory.

- 1 Open the memory card slot cover on the right hand edge of the phone.
- 2 Slide the memory card into the slot until it clicks into place.
- 3 Replace the cover.



Formatting the memory card

Your memory card may already be formatted. If your card isn't formatted, you will need to format it before you can begin using it.

- 1 From the standby screen select , then scroll through SETTINGS Tab and choose **Phone settings**.
- 2 Touch **Memory info** then choose **External memory**.
- 3 Touch **Format** and then confirm your choice.
- 4 Enter the password, if one is set, and your card will then be formatted and ready to use.

NOTE: If your memory card has an existing content. It will automatically be filled in the correct folder; for example, videos will be stored in the My Videos folder.

Menu map

Touch  in the standby screen to open the **Top menu**. From here you can access further menus: **COMMUNICATION**, **ENTERTAINMENT**, **UTILITIES** and **SETTINGS**.



COMMUNICATION

- Contacts
- Recent history
- Messaging
- E-mail
- Dialling
- Social networking
- Speed dials
- New message



ENTERTAINMENT

- Camera
- Gallery
- Music
- My stuff
- Games & Apps
- Pocket Apps
- FM radio
- Video camera



UTILITIES

- Browser
- Google
- Alarms
- Organiser
- Memo
- Voice recorder
- Tools
- Drawing Panel



SETTINGS

- Dual SIM settings
- Profiles
- Screen settings
- Phone settings
- Call settings
- Bluetooth
- Connectivity
- Wi-Fi

Your standby screen



From your standby screen you can access all the menu options, make a quick call and view the status of your phone as well as many other things.

Touch screen tips

The home screen is also a great place to get accustomed to the touch screen.

To select an item, touch the icon accurately. Your GX500 will vibrate slightly when it recognises you've touched an option.

To scroll through lists, touch the last item visible and slide your finger up the screen. The list will move up so more items are visible.


- There's no need to press too hard, the touchscreen is sensitive enough to pick up on a light, yet firm, touch.
 - Use the tip of your finger to touch the option you want. Be careful not to touch any other options around it.
 - When the screen back light is off, press the Unlock/Lock key on the right hand side to bring back the home screen.
 - Don't use any case or cover on the phone. The touchscreen won't work with any material covering it.
 - There are two types of idle screen. Flick left or right to change your idle screen types on the standby screen.
- 1 **Widget idle** - When you touch , the mobile widget panel appears.
 - 2 **Speed dial idle** - When you touch , the speed dial list appears. You can drag and click what you need right away in both idle types.

Your standby screen

The quick keys

The quick keys provide easy, one-touch access to your most used functions.



Touch to bring up the touch dialing pad to make a call. Input the number as you would using a normal key pad and touch **Call** or press the  hard key.



Touch to open your address book. To search for the number you want to call, enter the name of the contact at the top of the screen using the touchpad. You can also create new contacts and edit existing ones.



Touch to access the Messaging options menu. From here you can create a new SMS or MMS, or view your message folder.




























Touch to open the full Top menu which is divided into four vertical sub-menus. Touch each sub-menu's tab to view further options.

The status bar

The status bar uses various icons to indicate things like signal strength, new messages and battery life, as well as telling you whether your Bluetooth or GPRS is active.

Below is a table which explains the meaning of the icons you're most likely to see in the status bar.

Icon	Description
	Multitasking
	Network signal strength (number of bars will vary)
	No network signal
	Remaining battery life
	Battery empty
	New text message
	New voice message
	Message inbox is full
	Message sending failed
	Multimedia message sending failed

Icon	Description
	An alarm is set
	Customised Profile in use
	Normal profile in use
	Outdoor profile in use
	Silent profile in use
	Headset profile in use
	Calls are diverted
	EDGE in use
	Roaming
	Flight mode is on
	Bluetooth is active
	BGM play
	BGM pause
	Memory card is enabled for use
	Wi-Fi


Your standby screen


Changing your Status from the status bar

Touch the status bar to open the Status Summary. It shows the current Time, Network, Battery, Handset memory, External Memory, Profile, MP3, SIM property set (SIM1 / SIM2), Wi-Fi and Bluetooth status. Here you can set Profile type, play/pause MP3 and activate/deactivate Bluetooth.

TIP! You can see the network signals highlighted by selected colour when you switch them. It makes you easily identify the strength of your signal of the selected SIM-Card.




Using the Multitasking function


Press the multitasking hard key  to open the Multitasking menu. From here you can view all the applications you have running and access them with one touch.

When you have an application running in the background (e.g. a game or the FM radio),  will appear in the status bar.



Calls

Making a call



- 1 Touch  to open the keypad.
- 2 Key in the number using the keypad. To delete a digit touch the clear key.
- 3 Press the  hard key or touch **Call** to initiate the call.
- 4 To end the call press the  hard key.


TIP! To enter + for making an international call, press and hold .

Making a call from your contacts

- 1 From the standby screen touch  to open the address book.
- 2 Enter the first few letters of the contact you would like to call at the top of the screen using the touchpad.
- 3 From the filtered list, touch the contact you'd like to call and select the number to use if you have more than one saved.
- 4 Touch .

Answering and rejecting a call



When your phone rings press the  hard key or touch  to answer the call.

Tap  to mute the ringing. This is great if you've forgotten to change your profile to Silent for a meeting.

Press the  hard key or touch  to reject an incoming call.

Speed dialling





You can assign a frequently-called contact to a speed dial number.

- 1 From the home screen touch  to open Contacts.
- 2 Touch  and choose **Speed dials**.
- 3 Your Voicemail is already set to speed dial 1. You cannot change this. Touch any other number to assign it with a speed dial contact.

Calls

- 4 Your address book will open. Select the contact you'd like to assign to that number by touching their phone number once. To find a contact tap the Name field box and enter the first letter of the name of the contact required.


Making a second call

- 1 During your initial call, touch  and type the number you want to call.
- 2 Dial the number or search your contacts.
- 3 Press  to connect the call.
- 4 Both calls will be displayed on the call screen. Your initial call will be locked and the caller put on hold.
- 5 To change between the calls, touch  and choose **Swap call** or press the number of the held call.
- 6 To end one or both calls press  and select **End** followed by **All**, **Held** or **Active**.

TIP! You can combine your calls by selecting **Join calls**. Check that your network provider supports conference calling.

NOTE: You will be charged for each call you make.

Viewing your call logs


Touch  and select **Communication** and tap **Recent history**. Choose to view:

All calls - View a complete list of all dialled, received and missed calls.


Dialled calls - View a list of all the numbers you have called.

Received calls - View a list of all the numbers that have called you.

Missed calls - View a list of all the calls you have missed.

TIP! From any call log touch  and **Delete all** to delete all the recorded items.


Using call divert

- 1 Touch  and select **Settings** and choose **Call settings**.
- 2 Touch **Call divert**.
- 3 Choose whether to divert all calls, when the line is busy, when there is no answer or when you are not reachable.
- 4 Input the number you'd like to divert to.
- 5 Touch **Request** to activate.

NOTE: Charges are incurred for diverting calls. Please contact your network provider for details.

TIP! To turn off all call diverts, choose **Deactivate all** from the **Call divert** menu.

Using call barring


- 1 Touch  and select **Settings** and choose **Call settings**.
- 2 Touch **Call barring**.

- 3 Choose any or all of the six options:
 - All outgoing**
 - Outgoing international**
 - Outgoing international calls except home country**
 - All incoming**
 - Incoming when abroad**
 - Deactivate all**
- 4 Enter the call barring password. Please check with your network operator for this service.

TIP! Select **Fixed dial numbers** from the **Call settings** option to turn on and compile numbers which can be called from your phone. You'll need your PIN2 code from your operator. Only numbers included in the fixed dial list can be called from your phone.

Calls

Changing the common call setting

1 Touch  and select **Settings** and choose **Call settings**.

2 Touch **Common setting**.

From here you can amend the settings for:

Call reject - Slide the switch to **On** to highlight the Reject list. You can touch the text box to choose from all calls, specific contacts or groups, or those from unregistered numbers (those not in your contacts) or with no caller ID. Touch **Save** to change the setting.

Send my number - Choose whether your number will be displayed when you call someone.

Auto redial - Slide the switch left for **On** or right for **Off**.

Answer mode - Choose whether to answer the phone using the send key or any key.

Minute minder - Slide the switch left to **On** to hear a tone every minute during a call.

BT answer mode - Select **Hands-free** to be able to answer a call using a Bluetooth headset, or select **Handset** to press a key on the handset to answer a call.




Save new number - Select **Yes** to save a new number.

Contacts



Searching for a contact

There are two ways to search for a contact:

From the standby screen


- 1 From the standby screen touch  to open the address book. Select the contact from the list that you want to make a call.
- 2 Touch  or press the  hard key to initiate the call.

From the main menu

- 1 Touch , select .
- 2 Touch **Contacts**, then **Search**.
- 3 You see a list of contacts. Typing in the first letter of a contact's name in the Name field will jump the menu to that alphabetical area of the list.

TIP! The alphabetical keypad is displayed once you tap the Name field.

Adding a new contact

- 1 From the standby screen touch  and touch **Add contact**.
- 2 Choose whether to save the contact to your Handset or SIM (SIM 1/SIM 2).
- 3 Enter the first and last name of your new contact. You do not have to enter both, but you must enter one or the other.
- 4 You can enter up to five different numbers per contact. Each entry has a preset type **Mobile**, **Home**, **Office**, **Pager**, and **Fax**. When you have finished, touch **Close**.
- 5 Add an email address.
- 6 Assign the contact to one or more groups. Choose from **No group**, **Family**, **Friends**, **Colleagues**, **School** or **VIP**.

Contacts

7 You can also add a **Ringtone**, **Birthday**, **Anniversary**, **Homepage**, **Home address**, **Company name**, **Job title**, **Company address** and a **Memo**.

8 Touch **Save** to save the contact.

Creating a group

1 Touch .

2 Touch **Contacts** then **Groups**.

3 Touch .

4 Select **Add group**.

5 Enter a name for your new group. You can also assign a ringtone to the group.

6 Touch **Save**.

NOTE: If you delete a group, the contacts which were assigned to that group will not be lost. They will remain in your address book.

Changing your contact settings

You can adapt your contact settings so that your address book suits your own preferences.

TIP! To scroll through a list of options, touch the last item visible and slide your finger up the screen. The list will move up so more items are visible.

1 From the standby screen touch .

2 Touch **Contacts**, then **Settings**.

3 From here you can adjust the following settings:

Contact list settings - Choose to adjust the **Name display** and **Quick command key** settings.

Copy - Copy your contacts between your SIM cards(SIM1 or SIM2) and your handset. Choose to do this one at a time, or all at once. If you select one at a time, you'll need to select each contact to copy one by one.

Move - This works in the same way as Copy, but the contact will only be saved to the location you've moved it to. So if you move a contact from the SIM to the handset it will be deleted from the SIM memory.


Send all contacts via Bluetooth - Send all of your contacts to another device using Bluetooth. You will be prompted to turn on Bluetooth if you select this option.

Backup contacts - Performs and backup your contacts on to the external memory. This option requires external memory.

Restore contacts - Restores your contacts from the external memory. This option requires external memory.

Clear contacts - Delete all your contacts. Choose between Handset and SIM and touch Yes if you are sure you want to wipe your contacts.

Viewing information

- 1 From the standby screen touch .
- 2 Touch **Contacts**, then **Information**.
- 3 From here you can view your **Service dial numbers**, your **Own number**, your **Memory info**. (how much memory space you've got left) and **My business card**.




TIP! If you've yet to add a business card for yourself, select **My business card** and enter all your details as you would for any contact. Touch **Save** to finish.

Messaging

Messaging

Your GX500 combines SMS, MMS and email into one intuitive and easy to use menu.

There are two ways to enter the messaging centre:


- 1 Touch  from the standby screen.
- 2 Touch  from the standby screen, then select Communication tab and choose .


Sending a message

- 1 Touch **New message**, then select Message to open a blank message field box.
- 2 From here you can send an SMS or MMS. To send an email, touch  from the standby screen. Then select Communication tab and **E-mail**.
- 3 Touch **Insert**, to add an image, video, sound or template.

- 4 Touch **To** at the top of the screen to enter the recipient's number, or touch the search icon to open your address book. You can add multiple contacts. Touch **Send** when ready.

NOTE: You can send SMS to many users at a time. Click on contact search icon and Select multiple from Options where in user can mark/unmark contacts for sending message. To send the SMS to a particular group of contacts click on contacts search icon and select search by Group after composing the SMS.

 **WARNING:** You will be charged per 1 page text message for each person that you send the message to.

 **WARNING:** If an image, video or sound is added to SMS it will be automatically converted to MMS and you will be charged accordingly.


Entering text


There are five ways to enter text:


Keypad, Keyboard, Handwriting-Screen, Handwriting-Box, Handwriting-Double Box.


You can choose your input method by tapping  and **Input method**.

Tap the screen once, the keyboard appears.

 Touch to turn on T9 predictive text.

 You can choose writing languages.

 Tap to change numbers, symbols and text keypad.

Use  to scroll through the different keyboard types in each text entry mode (for example, capitals or lowercase).

T9 predictive

T9 mode uses a built-in dictionary to recognise words you're writing based on the key sequences you touch. Simply touch the number key associated with the letter you want to enter, and the dictionary will predict the word you want to use.

For example, press 8, 3, 5, 3, 7, 4, 6, 6, 3 to write 'telephone'.

Abc manual

In Abc mode you must touch the key repeatedly to enter a letter. For example, to write 'hello', touch 4 twice, 3 twice, 5 three times, 5 three times again, then 6 three times.

Messaging

Keyboard

In Keyboard mode the screen flips to landscape and a full keyboard appears on screen.

Simply touch each letter to write your message and press:

 to switch to upper case.

Handwriting recognition



In Handwriting mode you simply write on the screen and your GX500 will convert your handwriting into your message. Select **Handwriting-Screen**, **Handwriting-Box** or **Handwriting-Double Box** depending on your preferred view.

TIP! You may find it easier to use the stylus in this mode, please remember to press lightly to protect your screen from damage.

Handwriting recognition translates stylus gestures into letters, numbers or other characters, and displays these characters as text. Handwriting recognition is only active where text can be entered.

Setting up your email

You can stay in touch on the move using email on your GX500. It's quick and simple to set up a POP3 or IMAP4 email account.

- 1 Touch  then select Communication tab.
- 2 Select  then scroll menu to **Settings**.
- 3 Touch **Email** then **Email accounts**.
- 4 Touch **Add account**.
- 5 Setup Wizard will help you set up your email settings.
- 6 You can check and edit settings by selecting the account in the list. You can also check the additional settings that were filled in automatically when you created the account.
- 7 You can change your default email account by touching **Activate**.

Retrieving your email



You can automatically or manually check your account for new emails.

To check manually:

- 1 Touch  then select .
- 2 Touch **Mailbox**.
- 3 Touch the account you want to use then .
- 4 Choose Folder synchronisation and your GX500 will connect to your email account and retrieve your new messages.

Changing your email settings

You can change your email settings according to your own preferences.

- 1 Touch  then select .
- 2 Touch **Settings** and **Email** and then you can adapt the following settings:
Allow reply Email - Choose to allow the sending of 'read, confirmation' messages.

Request reply Email - Choose whether to request read confirmation messages.

Retrieve interval - Choose how often your GX500 checks for new email messages.

Retrieve amount - Choose the number of emails to be retrieved at any one time.

Include message in Fwd & Reply - Choose to include the original message in your reply.

Include attachment - Choose to include the original attachment in any reply.

Auto Retrieval in Roaming - Choose whether to retrieve your messages automatically or not.

New email notification - Choose whether to be alerted to new emails.

Signature - Create an email signature and switch this feature on.

Priority - Choose the priority level of your email messages.

Messaging

Message folders

You'll recognise the folder structure used on your GX500, which is fairly self-explanatory.

New message - Open a new blank message.

Inbox - All the messages you receive are placed into your inbox. From here you can view, delete and do more. (See

Managing your messages below for details.)

Drafts - If you don't have time to finish writing a message, you can save what you've done so far here.

Outbox - This is a temporary storage folder while messages are being sent.

Sent items - Messages you send are placed in this folder.

My Folders - Create folders to store your messages.

Templates - Use a list of commonly used text and multimedia message templates.


Emoticons - Add and insert emoticons for your messages.

Settings - Change the settings for your text and multimedia messages.

Changing your text message settings

Your GX500 message settings are pre-defined so that you can send messages immediately. These settings can be changed according to your preferences.

TIP! To scroll through a list of options, touch the last item visible and slide your finger up the screen. The list will move up so more items are visible.

Touch  then choose **Settings**. Select **Text message**. You can make changes to:

Text message centre - Enter the details of your message centre.

Delivery report - Slide the switch left to receive confirmation that your messages have been delivered.

Validity period - Choose how long your messages are stored at the message centre.

Message types - Convert your message into **Text, Voice, Fax, X.400** or **Email**.

Character encoding - Choose how your characters are encoded. This impacts the size of your messages and therefore data charges.

Send long text as - Choose to send long messages as Multiple SMS or as MMS.

Changing your multimedia message settings

Your GX500 message settings are pre-defined so that you can send messages immediately. These settings can be changed according to your preferences.

Touch , select  then . Choose **Settings** and **Multimedia message**. You can make changes to:

Retrieval mode - Choose **Home** or **Roaming network**. If you then choose Manual you will receive only notifications of MMS and you can then decide whether to download them in full.

Delivery report - Choose to allow and/or request delivery reports.

Read reply - Choose to allow and/or request reply reports.

Messaging

Priority - Choose the priority level of your MMS.

Validity period - Choose how long your messages are stored at the message centre.



Slide duration - Choose how long your slides appear on screen by default.

Creation mode - Choose mode to create multimedia messages restrictive, warning, free.

Delivery time - Choose how long before messages are delivered.

Multi msg centre - Enter the details of your message centre.

Changing your other settings

Touch , choose **Settings** on the  then:


Voicemail - Touch  to add a new Voicemail service. Contact your network operator for more information on the service they provide.

Service message - Choose to receive or block service messages. You can also set your message security by creating trusted and untrusted lists of senders in **Service security** option.

Info. service - Choose your reception status, language and other settings.


Camera

Taking a quick photo








- 1 Long press the camera hot key on the right side of the phone.
- 2 The view finder will appear on screen.
- 3 Holding the phone horizontally, point the lens towards the subject of the photo.
- 4 Position the phone so you can see the subject of your photo in the preview screen.
- 5 Press the  on the side of the phone firmly to take the photo.

After you've taken your photo


Your captured photo will appear on screen.

-  Touch to send the photo as a **Message**, **Email** or **Bluetooth**. See Sending a message and Sending and receiving your files using Bluetooth.

NOTE: Additional cost may occur when MMS are downloaded when roaming.

-  Touch to edit the name of the selected picture.
-  Touch to use the image as wallpaper.
-  Touch to edit the image using various tools.
-  Touch to return to the previous menu.
-  Touch to delete the image.
-  Touch to take another photo immediately.
-  Touch to view a gallery of your saved photos.

Using the advanced settings

From the view finder touch  to open all the advanced settings options.

Colour effect - Choose a colour tone to apply to the photo you're taking. There are four colour tone options: **Off**, **Black & White**, **Negative** or **Sepia**.

White balance - Choose from **Auto**, **Incandescent**, **Sunny**, **Fluorescent** or **Cloudy**.

Camera

Night mode - Useful in dark places.

Self-timer - The self-timer allows you to set a delay before the camera takes the picture, after the capture button is pressed. Choose from **3 seconds**, **5 seconds** or **10 seconds**. Great for that group photo you want to be a part of.

Quality - Choose between **Super fine**, **Fine** and **Normal**. The finer the quality the sharper a photo will be, but the file size will increase. This means you'll be able to store fewer photos in your memory.

View Mode - To be inserted after **Quality**.

Select storage - To be inserted before **Show captured image**.

Show captured image - Choose to view the picture with options after taking a photo.

Hide icons - Choose the camera settings icons to be hidden manually or automatically.


Shutter sound - Select one of the three shutter sounds.

Grid screen - Choose from **Off**, **Simple cross** or **Trisection**.

Noise reduction - To be inserted between **Grid screen** and **Reset settings**.








Reset settings - Reset all the camera settings.

Viewing your saved photos

1 You can access your saved photo's from within the camera mode. Simply touch  and your gallery will appear on screen.

Video camera








Shooting a quick video

- 1 Press and hold the camera key  on the right side of the phone.
- 2 Alternatively, drag down  in the viewfinder in camera mode to switch to video mode.
- 3 The video camera's viewfinder will appear on screen.
- 4 Holding the phone horizontally, point the lens towards the subject of the video.
- 5 Press the camera key  once to start recording.
- 6 **Rec** will appear at the bottom of viewfinder and a timer at the bottom showing the length of your video.
- 7 To pause the video touch  and resume by selecting .
- 8 Touch  on the screen or press the camera key  a second time to stop recording.

TIP! To switch to the camera mode or video mode, slide up/down the camera or video icon on the right centre of the viewfinder.

After you've shot your video

A still image representing your captured video will appear on screen. The name of the video is displayed at the bottom of the screen together with eight icons down the right side.

-  Touch to play the video.
-  Touch to send the video as a **Message or Email** or by **Bluetooth**.
-  Touch to edit the video.
-  Touch to edit the name of the selected video.
-  Touch to return to the previous menu.
-  Touch to delete the video you have just made, and confirm by touching **Yes**. The viewfinder will reappear.
-  Touch to shoot another video immediately. Your current video will be saved.
-  Touch to view the saved videos and pictures gallery.

Video camera

Adjusting the Exposure

Exposure defines the difference between light and dark (contrast) in an video.

- 1 Touch .
- 2 Slide the exposure indicator along the bar, left for a lower exposure, hazier video, or right for a higher contrast, sharper video.

Using the advanced settings

From the view finder touch  to open all the advanced settings options.

Colour Effect - Choose a colour tone to use on your new video.
Off, Black & White, Negative, Sepia.

White balance - The white balance ensures that any white in your videos is realistic. In order for your camera to correctly adjust the white balance you may need to determine the light conditions. Choose from **Auto, Incandescent, Sunny, Fluorescent** or **Cloudy**.

Night Mode - You can take better My images at night by selecting On.

Self Timer - The self-timer allows you to set a delay before the camera takes the picture, after the capture button is pressed. Choose from Off, 3 seconds, 5 seconds or 10 seconds.

Quality - Choose between **Super fine, Fine** and **Normal**. The finer the quality, the sharper a video will be, but the file size will increase. As a result, you will be able to store fewer videos in the phone's memory.

View mode - Applies artistic effects to the pictures.

Select storage - Choose whether to save your videos to the **Handset memory** or to the **External memory**.

Show Captured Image - Choose to view the picture with options after taking a photo.

Hide Icons - Choose the camera settings icons to be hidden manually or automatically.



Shutter Sound - Select one of three different shutter sounds.

Grid Screen - Choose from Off, Simple cross or Trisection.

Noise Reduction - This function could reduce noise and refine a picture after taken.


Reset settings - Reset all the video camera settings.

Watching your saved videos


- 1 In the view finder touch .
- 2 Your gallery will appear on screen.
- 3 Touch the video you want to view once to bring it to the front of the gallery.
- 4 Touch  on the video.

Your photos and videos

Viewing your photos and videos

- 1 Touch  on the camera preview screen.
- 2 Your gallery will appear on the screen.
- 3 Touch the video or photo to open it fully.

TIP! Flick left or right to view other photos or videos.

TIP! To delete a photo or video, open it and select . Touch **Yes** to confirm.


Using zoom when viewing a photo

When viewing photos, you can zoom in and out.

Adjusting the volume when viewing a video

To adjust the volume of a video while it is playing, touch the volume bar on the screen Top after pressing the loudspeaker symbol. Alternatively, use the volume keys on the side of the phone.

Setting a photo as wallpaper


- 1 Touch the photo you want to set as wallpaper to open it.
- 2 Touch the screen to open the options menu.
- 3 Touch .
- 4 You can zoom in and out and move the cropped section of the picture using a thumbnail at the bottom of the screen.
- 5 When you are happy with the picture touch **Set**.
- 6 Choose from the options what you want to change:
All, Widget, Speed dial.


Editing your photos


You can do lots of great things to your photos to change them, add to them or liven them up.


1 Open the photo you want to edit and touch  to show the options.


2 Touch the icons to alter your photo:


 Crop your photo. Choose a square or circular crop area and move your finger across the screen to select the area.


 Draw something on your photo, freehand. Select the line thickness from the four options, then the colour you want to use.


 Adding writing on a picture. See **Adding text to a photo**.

 Decorate your photo with stamps. Choose from the different stamps and touch your photo where you want to place them.


 Erase the editing you have done to the picture. You can choose the size of eraser you use.


 Touch to return to the gallery.

 Save the changes you have made to the photos. Select to save the changes over the **Original file**, or as a **New file**. If you select **New file**, enter a file name.



 Undo the last effect or edit you made to the photo.

 Touch to open further effect options including **Rotate**. There are also more advanced editing options. See **Adding a colour accent** and **Swapping the colours in a photo**.

 Touch to open the Filter options.

 This helps to adjust a picture taken using automatic colour, brightness etc.

Multimedia


You can store any multimedia files into your phone's memory so that you have easy access to all of your pictures, sounds, videos and games. You can also save your files to a memory card. The advantage of using a memory card is that you can free up space on your phone's memory. To access the Multimedia menu, touch . Touch  to open a list of folders storing all of your multimedia files.

Pictures




My images contains a list of pictures including default images pre-loaded onto your phone, images downloaded by you and images taken on your phone's camera.

Touch  to change the view from thumbnail view to list view.

Sending a photo

- 1 Touch .
- 2 Touch  then choose **My images**.
- 3 Touch **Send** and choose from **Message**, **Email** or **Bluetooth**.
- 4 If you choose **Message** or **Email**, your photo will be attached to a message and you can write and send the message as normal. If you choose **Bluetooth**, Bluetooth will be turned on automatically and your phone will search for a device to send the picture.

Printing an image

- 1 Touch .
- 2 Touch  then **My images**.
- 3 Select an image and touch .
- 4 Touch **Print** then choose **Bluetooth**.

Moving or copying an image

You can move or copy an image between the phone memory and the memory card. You might want to do this to either free up some space in one of the memory banks or to safeguard your images from being lost.

- 1 Touch .
- 2 Touch  then **My images**.
- 3 Touch  and select **Move** or **Copy**.
- 4 You can mark/unmark the images by tapping it sequentially. Mark the image that you want to move or copy and touch **Copy/Move**.

Sounds

The **My sounds** folder contains the Downloaded sounds, **Default sounds** and **Voice recordings**. From here you can manage, send or set sounds as ringtones.

Videos

The **My videos** folder shows a list of downloaded videos and videos you have recorded on your phone.

Watching a video

- 1 Touch .
- 2 Touch  then **My videos**.
- 3 Select a video to play.

Sending a video clip



- 1 Select a video and touch .
- 2 Touch **Send** and choose from **Message**, **Email** or **Bluetooth**.
- 3 If you choose **Message** or **Email**, your video clip will be attached to the message and you can write and send the message as normal. If you choose **Bluetooth**, Bluetooth turns on automatically and your phone will search for a device to send the video.

Multimedia

Games and Applications



You can install new games and applications to your phone to keep you amused when you have time to spare.

Installing a game/application via local install

- 1 Touch .
- 2 Touch  and **Others** or My memory card if external memory is inserted.
- 3 Select the file (*.jad or *.jar) to install. An application will be installed.

NOTE: The jad should contain its own jar.

Playing a game

- 1 Touch .
- 2 Touch  then **Games**.
- 3 Select a game to launch. GX500 comes with some preloaded application.

Documents

From the **Documents** menu, you can view all of your document files. From here you can view Excel, Powerpoint, Word, Text and PDF files.



Transferring a file to your phone

Bluetooth is probably the easiest way to transfer a file from your computer to your phone. You can also use LG PC Suite via your sync cable.

To transfer using Bluetooth:

- 1 Make sure your phone and computer have Bluetooth switched on and are visible to one another.
- 2 Use your computer to send the file via Bluetooth.
- 3 When the file is sent you will have to accept it on your phone by touching **Yes**.
- 4 The file should appear in your **Documents** or **Others** folder.




Viewing a file

- 1 Touch .
- 2 Touch  then **Documents**.
- 3 Select a document and touch to View.

Others

The **Others** folder is used to store files which are not pictures, sounds, videos, games or applications. It is used in the same way as the **Documents** folder. You may find that when you transfer files from your computer to your phone that they appear in the **Others** folder rather than the **Documents** folder. If this happens you can move them.

To move a file from **Others** to **Documents**:

- 1 Touch .
- 2 Touch  then **Others**.
- 3 Touch  and select **Move** then choose a file.
- 4 Touch **Move**, choose the destination folder from the list by touching the arrow icon. The screen will display **Moved** when the transfer is complete.

Multimedia

Music

Your LG GX500 has a built-in music player so you can play all your favourite tracks. To access the music player, touch . Scroll through Entertainment to . From here you can access a number of folders:

Recently played - View all of the songs you have played recently.

All tracks - Contains all of the songs you have on your phone.

Artists - Browse through your music collection by artist.

Albums - Browse through your music collection by album.

Genres - Browse through your music collection by genre.

Playlists - Contains all playlists you have created.

Shuffle tracks - Play your tracks in a random order.

Transferring music onto your phone

The easiest way to transfer music onto your phone is via Bluetooth or your sync cable.

You can also use LG PC Suite. To transfer using Bluetooth:


- 1 Make sure both devices have Bluetooth switched on and are visible to one another.
- 2 Select the music file on the other device and choose to send it via Bluetooth.
- 3 When the file is ready to be sent you should accept it on your phone by touching **Yes**.
- 4 The file should appear in **Music > All tracks**.

Playing a song

- 1 Touch .
- 2 Scroll through Entertainment to , then touch **All tracks**.
- 3 Select the song you want to play.
- 4 Touch  to pause the song.
- 5 Touch  to skip to the next song.
- 6 Touch  to skip to the previous song.
- 7 Touch  to return to the **Music** menu.

Creating a playlist

You can create your own playlists by choosing a selection of songs from the **All tracks** folder.

- 1 Touch .
- 2 Scroll through Entertainment to , then touch **Playlists**.
- 3 Touch **Add new playlist**, enter the playlist name and touch **Save**.

- 4 The **All tracks** folder will show all the songs in your phone. Touch all of the songs that you would like to include in your playlist; a tick box will show next to the track names.
- 5 Touch **Done**.

Using the radio

Your LG GX500 has an FM radio feature so you can tune into your favourite stations to listen to while on the move.

NOTE: You will need to insert your headphones in order to listen to the radio. Insert them into the headphone socket (this is the same socket that you plug your charger into).

Multimedia

Searching for stations

You can tune radio stations into your phone by searching for them either manually or automatically. They will then be saved to specific channel numbers so you don't have to keep re-tuning. You can save up to 48 channels in your phone. You must first attach the headset to the phone as this acts as the antenna.

To auto tune:




- 1 Touch .
- 2 Scroll through Entertainment to **FM radio** then .
- 3 Touch **Auto scan**. Then the stations will be automatically found and allocated to a channel in your phone.

Resetting channels



- 1 Touch .
- 2 Scroll through Entertainment to **FM radio** then .
- 3 Choose **Reset** to reset the current channel or choose **Reset all** to reset all of the channels. Each channel will return to the starting 87.5 MHz frequency.

Utilities


Recording a sound or voice

- 1 Touch  then scroll through **Utilities**.
- 2 Touch **Voice recorder**.
- 3 Touch  to begin recording.
- 4 Touch  to end recording.
- 5 Touch  to listen to your recording.

Using your calculator

- 1 Touch , then scroll through utilities and touch **Tools**.
- 2 Touch **Calculator**.
- 3 Touch the numeric keys to input numbers.
- 4 For simple calculations, touch the function you require (+, -, ×, ÷), followed by =.
- 5 For more complex calculations, touch  and choose from **sin, cos, tan, log, ln, exp, sqrt, deg** or **rad** etc.

Converting a unit


- 1 Touch , then scroll through utilities and touch **Tools**.
- 2 Touch **Unit converter**.
- 3 Choose whether you would like to convert **Currency, Area, Length, Weight, Temperature, Volume** or **Velocity**.
- 4 You can then select the unit, and enter the value you would like to convert from, followed by the unit you would like to convert to.

Adding a city to your world time

- 1 Touch , then scroll through utilities and touch **Tools**.
- 2 Touch **World clock**.
- 3 Touch the , followed by **New city**. Start typing the name of the city you require and it will show at the top of the screen.

Utilities

Using the stopwatch


- 1 Touch , then scroll through utilities and touch **Tools**.
- 2 Touch **Stopwatch**.
- 3 Touch **Start** to begin the timer.
- 4 Touch **Lap** if you want to record a lap time.
- 5 Touch **Stop** to end the timer.
- 6 Touch **Resume** to restart the stopwatch at the time you stopped it at, or touch **Reset** to begin the time again.

Adding an item to your calendar

- 1 Touch , from the home screen and then touch **Organiser**.
- 2 Touch **Calendar** then touch **Add event**.
- 3 Touch **Category** then choose from **Appointment**, **Anniversary** or **Birthday**. Check the date and enter the time you would like your event to begin.

- 4 For appointments and anniversaries enter the time and date your event finishes in the lower two time and date boxes.
- 5 If you would like to add a subject or a note to your event, touch **Note** and type in your note, followed by **Save**.
- 6 Set **Alarm** and **Repeat**.
- 7 Select **Save** and your event will be saved in the calendar. A square cursor will mark the day that any events have been saved to and a bell will ring at the start time of your event, so that you can stay organised.

Adding an item to your task list

- 1 Touch , from the home screen and then touch **Organiser**.
- 2 Touch **Tasks** then touch **Add task**.
- 3 Set the date for the to do item, add notes and select a priority level: **High**, **Medium** or **Low**.

Date finder

Date finder is a handy tool to help you calculate what the date will be once a certain number of days have passed.

Settings

Calendar settings - You can set the configurations to view the calendar.

Send all organiser data via Bluetooth - You can send all the data in your calendar and/or Tasks from your phone to other phones by using Bluetooth.

Memory info. - You can view the information of available memory regarding Calendar, Tasks, Memo and Secret memo.


Clear all - You can delete all data regarding Calendar, Tasks, Memo and Secret memo.

PC Suite

You can synchronise your PC with your phone. This will ensure all your important details and dates match, and also act as a back up to help put your mind at ease.

TIP! You will need to install the application PC Suite provided on the CD-ROM or available for download from www.lg.com PRODUCTS > Manual & Software > Go to Manual & S/W Download Section.


Installing the LG PC Suite on your computer

- 1 From the Home screen press  and select **Connectivity** on the SETTINGS tab.
- 2 Select **USB connection mode** and click **PC Suite**.
- 3 Connect handset and PC via USB cable and wait for a while.
- 4 Installation guide message will be displayed on the computer screen.

Caution! If installation guide message is not displayed in your PC, please check your CD-ROM setting on Windows.

- 5 Insert the supplied CD-ROM or the click the Download button to directly download the LG PC Suite program from the internet.
- 6 Click on the LG PC Suite Installer which will appear on your screen.

Connecting your phone and PC

- 1 From the home screen press  and select **Connectivity** on the SETTINGS tab.
- 2 Select **USB connection mode**.
- 3 Touch **PC Suite**.
- 4 Connect the handset and PC via USB cable and wait for a while. PC Suite runs automatically.

Backing up and restoring your phone's information

- 1 Connect your phone to your PC as outlined above.
- 2 Click on the **Backup** icon, and select **Backup** or **Restore**.
- 3 Choose whether to back up **Contacts/Calender/ToDo/Memo/photo/video**. Select the location you want to back up the information to, or restore it from. Click **OK** button then Back up or Restore Button respectively then press Finish button.
- 4 Your information will be backed up.

Viewing phone files on your PC

- 1 Connect your phone to your PC as outlined above.
- 2 Click on the Manage Photos, Videos or Music icon.
- 3 Images, audio files and videos you have saved on your phone will be displayed on the screen in the LG Phone folder.

TIP! Viewing the contents of your phone on your PC helps you to manage files you no longer need.

PC Suite

Synchronising your contacts

- 1 Connect the phone to your PC.
- 2 Click on the **Contacts** icon.
- 3 Click **Sync Contacts** button.
Welcome to LG Air Sync Service will be displayed > Press Start Button > Select Contacts Sub options (Include outlook contacts or call logs are transferred from the phone during sync > Press Next > Do you want to proceed pop up > next > Select Contacts > Press Sync Now).

Synchronising the messages


- 1 Connect the phone to your PC.
- 2 Click on the Messages icon.
- 3 All your phone messages will be displayed in folders on the screen.

- 4 Use the toolbar at the top of the screen to edit and rearrange messages.


Music Sync


This menu lets you add music to your GX500. Before you start transferring music from your PC to your phone, make sure your computer has the following set-up and accessory is at hand:

- Microsoft Windows XP or Vista
- Windows Media Player 10 or above
- USB data cable
- microSD card (If you wish to use external memory as the music storage.)

 **WARNING:** Do not disconnect your phone during the transfer.

Transferring music using Windows Media Player

- 1 From the home screen select , then scroll through **Connectivity** in the **Settings** tab.
- 2 Select **USB connection mode** and choose **Music sync**.
- 3 Connect your handset and PC using a compatible USB cable.
- 4 When you try to connect the handset to your PC, your handset will read: "Music Sync" followed by Connected.
- 5 The PC will prompt you to launch your preferred music management software.
- 6 Select Window Media Player.
- 7 Go to the Sync Tab, then drag and drop the music you wish to transfer to your handset into the **Sync List** panel.
- 8 Click on the **Start Sync** button. This starts the transfer process.

 **WARNING:** Do not disconnect your phone during the transfer.

DivX Converter

Install the DivX converter, which is supplied on the same CD-ROM as the PC Suite software. DivX will convert media files on your PC to a format that lets you upload them and view them on your phone.

Once installed, select **DivX** from the Program Files on your PC, then **DivX converter** followed by Converter.

Use the arrows in the application to change the conversion format to Mobile. If you right click on the application box and select **Preferences**, you can change the location where the converted files are saved.

Drag and drop the files into the application for initial analysis. Then select **Convert** for the process to begin. When the process is complete a Conversion complete pop up will be displayed.

NOTE: GX500 doesn't support Divx file format.

PC Suite

ABOUT DIVX VIDEO: DivX® is a digital video format created by DivX, Inc. This is an official DivX Certified device that plays DivX video. Visit www.divx.com for more information and software tools to convert your files into DivX video.

ABOUT DIVX VIDEO-ON-DEMAND: This DivX Certified® device must be registered in order to play DivX Video-on-Demand (VOD) content. To generate the registration code, locate the DivX VOD section in the device setup menu. Go to vod.divx.com with this code to complete the registration process and learn more about DivX VOD.

Pat. 7,295,673

The web

Browser



Browser gives you a fast, full colour world of games, music, news, sport, entertainment and loads more, straight to your mobile phone. Wherever you are and whatever you're into.

Opera Mini

GX500 supports Opera Mini 5 browser which is a Java application that can be accessed from the Browser menu or from the Games&Apps menu in your phone. Some of the salient features of this browser are Multiple Windows, Security, Touch zooming, Book Marks, History, Saved Pages, Speed Dial.

NOTE: To browse using Opera Mini 5, Data Connection is required.

Accessing the web


- 1 From the standby screen select , then scroll through UTILITIES Tab and choose .
- 2 To access the browser homepage directly, select **Home**. Alternately select **Enter address** and type in your desired URL, followed by **Connect**.

NOTE: An additional cost is incurred when connecting to this service and downloading content. Check your data charges with your network provider.

The web

Adding and accessing your bookmarks

For easy and fast access to your favourite websites, you can add bookmarks and save web pages.


- 1 From the standby screen select , then scroll through UTILITIES Tab and choose .
- 2 Select **Bookmarks**. A list of your Bookmarks will appear on the screen.
- 3 To add a new bookmark, select  and touch **Add bookmark**. Enter a Title for your bookmark followed by the URL.
- 4 Touch **Save**. Your Bookmark will now appear in the list of bookmarks.
- 5 To access the bookmark simply touch the bookmark and then touch Connect. You will be connected to your bookmark.

Using RSS reader

RSS (Really Simple Syndication) is a family of web feed formats used to publish frequently updated content such as blog entries, news headlines or podcasts. An RSS document, which is called a feed, web feed, or channel, contains either a summary of content from an associated web site or the full text.



RSS makes it possible for people to keep up with their favourite web sites in an automated manner that is easier than checking them manually. The user subscribes to a feed by entering the feed's link into the reader or by clicking an RSS icon in a browser that initiates the subscription process. The reader checks the user's subscribed feeds regularly for new content, downloading any updates that it finds.

Saving a page



- 1 Access your required webpage as described above.
- 2 Touch  and select **Save this page**.
- 3 Enter a name for the webpage so you can easily recognise it.
- 4 Touch **Save**.

TIP! This menu will also allow you to edit titles of saved pages, protect or unprotect the screen memo, and delete saved pages.



Accessing a saved page

- 1 From the standby screen select , then scroll through UTILITIES Tab and choose .
- 2 Select **Saved pages**.
- 3 Select the required page and it will open.

Viewing your browser history

- 1 From the standby screen select , then scroll through UTILITIES Tab and choose .
- 2 Select **History**. A list of web page titles you have accessed recently will be displayed. To access one of these pages, simply select the required page.

Changing the web browser settings

- 1 From the standby screen select , then scroll through UTILITIES Tab and choose . Select **Settings**.
- 2 You can choose to edit **Profiles, Appearance settings, Cache, Cookies, Security**.

The web

Using your phone as a modem

Your GX500 can be used as a modem for your PC, giving you email and internet access even when you can't connect using wires. You can use either the USB cable or Bluetooth.

Using the USB cable:

- 1 Ensure you have the LG PC Suite installed on your PC.
- 2 Connect your GX500 and your PC using the USB cable and launch the LG PC Suite software.
- 3 Click **Internet Kit** on your PC. Then click **New button** and select **Modem**.
- 4 Choose **LG Mobile USB Modem** and select **OK**. It will now appear on screen.
- 5 Write the Profile that can connect to the Internet and save the values.
- 6 The profile that you create will appear on your PC screen. Select it and click **Connect**. Your PC will connect through your GX500.

Using Bluetooth:



By pairing your GX500 and another device, you can set up a passcode protected connection.

- 1 Check that your Bluetooth is **ON** and **Visible**. You can change your visibility in the Settings menu.
- 2 Touch Search.
- 3 Your GX500 will search for devices. When the search is completed, Refresh will appear on screen.
- 4 Choose the device you want to pair with and select **OK**.
- 5 Your phone will then connect to the other device, on which a new default passcode will be create to this connection.
- 6 Your passcode protected Bluetooth connection is now ready.

Settings

Within this folder you can adapt your settings to make your GX500 personal to you.


Using Dual SIM-card menu

To select or change the SIM-card, press  and then scroll through SETTINGS Tab, then select .



Personalising your profiles

You can quickly change your profile on the standby screen. Simply touch the status summary bar on the top and touch the profile tab.

Using the settings menu you can personalise each profile setting.

- 1 Press  and then scroll through SETTINGS Tab.
- 2 Touch **Profiles** and then choose the profile you want to edit.
- 3 You can then change all of the sounds and alert options available in the list.

Changing your screen settings

- 1 Press  and then scroll through SETTINGS Tab.
- 2 Touch  and then choose from:

Wallpaper - Choose the theme for your standby screen.

Top Menu - Choose the style of the top menu.

Lock screen - Choose the style of the lock screen.

Dialling - Adjust the number size and colour.

Font - Adjust the font size.

Brightness - Adjust the screen brightness.

NOTE: The longer the backlight is on for, the more battery power is used and you may need to charge your phone more often.

Greeting message - Choose on or off and fill in the greeting message.

Start-up/Shut down - Choose the image for your start-up/shut down screen.



Settings

- 3 Touch **Save** to save your settings.

Changing your phone settings

Enjoy the freedom of adapting how your GX500 works to your own style.

TIP! To scroll through a list of options, touch the last item visible and slide your finger up/right the screen. The list will move up/right so more items are visible.

- 1 Press  and then scroll through SETTINGS Tab.
- 2 Touch  then choose from the list below.
 - Date & time** - Adjust your date and time settings or choose to auto update the time when you travel or for daylight saving.
 - Power save** - Choose to switch the factory set power saving settings **Off, Night only, Always on.**
 - Touch Settings** - Change the touchpad value settings.

Languages - Change the language of your GX500's display.

Motion silent - Make the GX500 go into the mute or snooze settings by flipping it over when it is ringing.

Auto key lock - Lock the keypad automatically in standby screen.

Security - Adjust your security settings, including PIN code request, handset lock, change codes and Anti theft Mobile tracker.

Memory info - You can use memory manager to determine how each memory is used.

Reset settings - Reset all the settings to their factory definitions.



Information - View the technical information for your GX500.

TIP! Anti-theft Mobile tracker (ATMT)

- Touch **Security** and **ATMT**. When the handset is stolen, handset sends the SMS to the numbers configured by real owner. User has to configure the ATMT settings with Owner Name, Alternate no (1), Alternate no (2) etc. Default ATMT code is "000000"
- ATMT SMS will contain information about the stolen phone IMEI, current location & number of the person who is using that handset.

Changing your connectivity settings

Your connectivity settings have already been set up by your network operator, so you can enjoy your new phone immediately. If you want to change any settings, use this menu.

Press  and then scroll through SETTINGS Tab. Select .

Network settings

Select Network - If you set to **Automatic**, GX500 automatically searches for the network and registers the handset to the network. This is recommended for best service and quality. If you set to **Manual** all the currently available networks are shown and you can select one of them for registration. If the registration of the network has failed, the network lists are displayed again and you can select any other one for registration.

NOTE: When your handset loses the network in manual mode, the popup message to select the available network will be shown on the Idle screen.

Preferred lists - If the network is searching automatically, you can add a preferred network to be connected to.

Settings

Connectivity Settings

Internet profile - This menu shows the Internet profiles. You can create new profiles, delete or edit them however, you cannot delete or edit default configurations depending on country variant.

Access points - Your network operator has already saved this information. You can add new access points using this menu.

Packet data conn. - Choose when your device should be connected to network for packet data.

USB connection mode - Choose Data service and synchronise your GX500 using the LG PC Suite software to copy files from your phone. If you use **Music sync** with Windows Media Player, select **Music sync** in this menu.


Music sync is only available for music content.

Java settings - Allows you to set profiles for connections made by Java programs and to view certificates.

Using memory manager

Your GX500 has three memories available: the phone, the SIM Card and an external memory card (you may need to purchase the memory card separately).

You can use memory manager to determine how each memory is used and see how much space is available.

Touch  and choose **Phone settings** in the SETTINGS Tab then **Memory info**.

Handset common memory - View the memory available on your GX500 for Pictures, Sounds, Video, Flash, MMS, Email, Java applications and others.

Handset reserved memory - View the memory available on your handset for Text msg, Contacts, Calendar, Tasks, Memo, Alarm, Call history, Bookmarks and Miscellaneous items.

SIM(SIM1/SIM2) memory - View the memory available on your SIM Card.

External memory - View the memory available on your external memory card (you may need to purchase the memory card separately).

Primary storage setting -

Choose the location you prefer items to be saved to between Handset and External memory.

Sending and receiving your files using Bluetooth

Bluetooth is a great way to send and receive files as no wires are needed and connection is quick and easy. You can also connect to a Bluetooth headset to make and receive calls.

To send a file:

- 1 Open the file you want to send, typically this will be a photo, video or music file.
- 2 Choose **Send**.
Choose **Bluetooth**.

- 3 If you have already paired the Bluetooth device, your GX500 will not automatically search for other Bluetooth devices. If not, your GX500 will search for other Bluetooth enabled devices within range.

- 4 Choose the device you want to send the file to.

- 5 Your file will be sent.

TIP! Keep an eye on the progress bar to make sure your file is sent.

To receive a file:

- 1 To receive files your Bluetooth must be both **On** and **Visible**. See Changing your Bluetooth settings on the right for more information.
- 2 A message will prompt you to accept the file from the sender. Touch **Yes** to receive the file.
- 3 You will see where the file has been saved and you can choose to **View** the file or **Use as wallpaper**. Files will usually be saved to the appropriate folder in your Media Album.

Settings

Changing your bluetooth settings:

1 Touch  and choose **Bluetooth** in the SETTINGS Tab.

2 Touch  and choose **Settings**.

Make your changes to:

My device visibility - Choose to be **Visible** or **Hidden** or **Visible for 1 min**.

My device name - Enter a name for your GX500.

Supported services - Choose how to use Bluetooth in association with different services.

My address - Show your Bluetooth address.

Pairing with another Bluetooth device

By pairing your GX500 and another device, you can set up a passcode protected connection. This means your pairing is more secure.

- 1 Check your Bluetooth is **On** and **Visible**. You can change your visibility in the **Settings** menu.
- 2 Touch **Search**.
- 3 Your GX500 will search for devices. When the search is completed **Refresh** will appear on screen.
- 4 Choose the device you want to pair with and enter the passcode, then touch **OK**.
- 5 Your phone will then connect to the other device, on which you should enter the same passcode.
- 6 Your passcode protected Bluetooth connection is now ready.

Using a Bluetooth headset

- 1 Check your Bluetooth is **On** and **Visible**.
- 2 Follow the instructions that came with your headset to place your headset in pairing mode and pair your devices.

- 3** Touch **Ask before connect** or **Always connect** and touch **Yes** to Connect now. Your GX500 will automatically switch to Headset profile.

Wi-Fi

Wireless Manager allows you to manage Internet connections via Wi-Fi (Wireless LAN) on your device.

It allows the phone to connect to local wireless networks or access the Internet wirelessly. Wi-Fi is faster and has a greater range than Bluetooth wireless technology and can be used for fast emailing and Internet browsing.

NOTE: The GX500 supports WEP and WPA-PSK/2 encryption, but not EAP or WPS encryption. If your Wi-Fi service provider or network administrator sets encryption for network security, fill in the key in the pop-up window. If encryption is not set, this pop-up window will not be shown. You can obtain the key from your Wi-Fi service provider or network administrator.

Software Upgrade

LG Mobile Phone Software Upgrade Program

For more information on installing and using this program, please visit <http://update.lgmobile.com>

This feature allows you to upgrade your software to the latest version quickly and conveniently on the Internet without needing to visit our service centre. The mobile phone software upgrade program requires the user's full attention for the duration of the upgrade process, so please be sure to check any instructions and notes that appear at each step before proceeding. Please note that removing the USB data communication cable or batteries during the upgrade may seriously damage your mobile phone. The manufacturer takes no responsibility for loss of data during the upgrade process, so you are advised to note down any important information in advance for safekeeping.

Accessories

These accessories are supplied with GX500.

Charger



Data cable
and CD



Battery



User Guide




Stereo
headset



NOTE:

- Always use genuine LG accessories.
- Failure to do this may invalidate your warranty.
- Accessories may be different in different regions; please check with our regional service company or agent for further inquiries.

 **WARNING:** When the protection film is attached on the touch window, touch sensitivity might decreased.

Network service

The wireless phone described in this guide is approved for use on the GSM 850, E-GSM 900, DCS 1800 and PCS 1900 network.

A number of features included in this guide are called Network Services. These are special services that you arrange through your wireless service provider. Before you can take advantage of any of these Network Services, you must subscribe to them through your service provider and obtain instructions for their use from your service provider.

Technical data

General

Product name: GX500

System: GSM 850 / E-GSM 900
/ DCS 1800 / PCS 1900

Ambient Temperatures

Max: +55°C (discharging),
+45°C (charging)

Min: -10°C

Declaration of Conformity



Suppliers Details

Name

LG Electronics Inc

Address

LG Electronics Inc. LG Twin Towers 20,
Yeouido-dong, Yeongdeungpo-gu, Seoul, Korea 150-721

Product Details

Product Name

GSM 850 / E-GSM 900 / DCS 1800 / PCS 1900 Quad band Terminal Equipment

Model Name

GX500

Trade Name

LG

CE 0168 !

Applicable Standards Details

R&TTE Directive 1999/5/EC

EN 301 489-01 V1.6.1, EN 301 489-07 V1.3.1, EN 301 489-17 V1.3.2
EN 301 511 V9.0.2
EN 50360:2001 EN62209-1:2006
EN 60950-1:2001
EN300328 V1.7.1

Supplementary Information

The conformity to above standards is verified by the following Notified Body(BABT)

BABT, Forsyth House-Churchfield Road - Walton-on-Thames Surrey - KT12 2TD , United Kingdom

Notified Body Identification Number : 0168

Declaration

I hereby declare under our sole responsibility that the product mentioned above to which this declaration relates complies with the above mentioned standards and Directives

LG Electronics Logistics and Services B.V.
Veluwezoom 15, 1327 AE Almere, The Netherlands

Name

Issued Date

Seung Hyoun, Ji / Director

12. Feb. 2010

Signature of representative

Trouble Shooting

This chapter lists some problems that you might encounter while using your phone. Some problems require that you call your service provider, but most of problems you encounter are easy to correct yourself.

Message	Possible causes	Possible Corrective measures
SIM error	There is no SIM card in the phone or you may have inserted it incorrectly.	Make sure that the SIM card is correctly inserted.
No connection to the network	Signal weak Outside GSM network	Move higher to a window or open space. Check service provider coverage map.
Codes do not match	When you want to change a security code you have to confirm the new code by entering it again. The two codes that you have entered do not match.	Contact your Service Provider.
Function cannot be set	Not supported by Service Provider or registration required	Contact your Service Provider.
Calls not available	Dialling error New SIM card inserted Charge limit reached	New network not authorised. Check for new restrictions. Contact Service Provider or reset limit with PIN 2.

Trouble Shooting

Message	Possible causes	Possible Corrective measures
Phone cannot be switched on	On/Off key pressed too briefly	Press On/Off key for at least two seconds.
	Battery empty	Charge battery. Check charging indicator in the display.
	Battery contacts dirty	Clean contacts.
Charging error	Battery totally empty	Charge battery.
	Temperature out of range	Make sure the ambient temperature is right, wait for a while, and then charge again.
	Contact problem	Check power supply and connection to the phone. Check the battery contacts, clean them if necessary.
	No mains voltage	Plug in to a different socket or check voltage.
	Charger defective	If the charger does not warm up, replace it.
	Wrong charger	Only use original LG accessories.
	Battery defective	Replace battery.
Phone loses network	Signal too weak	Reconnection to another service provider is automatic.
Number not permitted	The Fixed dial number function is on.	Check settings.

استكشاف الأخطاء وإصلاحها

الرسالة	الأسباب المحتملة	التدابير التصحيحية الممكنة
يتعذر تشغيل الهاتف	اضغط مفتاح التشغيل/إيقاف التشغيل لبرهة قصيرة جداً البطارية فارغة	اضغط مفتاح التشغيل/إيقاف التشغيل لثانيتين على الأقل. اشحن البطارية، تفضل مؤشر الشحن في شاشة العرض. نظف الملامسات.
	البطارية فارغة بالكامل درجة الحرارة خارج النطاق	اشحن البطارية. تأكد من أن درجة الحرارة المحيطة جيدة وانتظر قليلاً ثم حاول الشحن مرة أخرى.
	مشكلة في الاتصال	دقق في وحدة التزويد بالطاقة والاتصال بالهاتف، دقق في ملامسات البطارية، وقم بتنظيفها إذا اقتضى الأمر.
خطأ في الشحن	لا جهد رئيسي	قم بالتوصيل بمقبس آخر أو دقق في الفولتية.
	الشاحن به خلل	إذا لم يسخن الشاحن، فقم باستبداله.
	الشاحن غير مناسب	استخدم ملحقات LG الأصلية فقط.
	خلل في البطارية	استبدل البطارية.
الهاتف ينقطع عن الشبكة	الإشارة ضعيفة جداً	إعادة الاتصال بموفر خدمة آخر تتم تلقائياً.
الرقم غير مسموح به	وظيفة رقم الاتصال المحدد قيد التشغيل.	تحقق من الإعدادات.

استكشاف الأخطاء وإصلاحها

يسرد هذا الفصل بعض المشاكل التي قد تصادفها أثناء استخدام الهاتف. بعض المشاكل تتطلب منك الاتصال بموفر الخدمة، ولكن معظم المشاكل التي تواجهها تكون سهلةً لذلك يمكنك تصحيحها بنفسك.

الرسالة	الأسباب المحتملة	التدابير التصحيحية الممكنة
خطأ SIM	لا يوجد بطاقة SIM في الهاتف أو ربما قمت بإدراجها بشكل غير صحيح.	تأكد من إدخال بطاقة SIM بطريقة صحيحة.
لا يوجد اتصال بالشبكة	الإشارة ضعيفة خارج شبكة GSM	انتقل نحو الأعلى إلى نافذة أو مكان مفتوح. تحقق من خريطة التغطية التي يزودك بها موفر الخدمة.
الرموز غير متطابقة	عندما ترغب في تغيير رمز الحماية، عليك تأكيد الرمز الجديد وذلك بإدخاله مرة أخرى. عدم تطابق الرمزین اللذين أدخلتهما.	اتصل بموفر الخدمة.
يتعذر إعداد الوظيفة	غير معتمد من قبل موفر الخدمة أو التسجيل مطلوب.	اتصل بموفر الخدمة.
المكالمات غير متوفرة	خطأ في الطلب تم بلوغ الحد الخاص برسوم المكالمات بطاقة SIM جديدة.	شبكة جديدة غير مصرح لها. تحقق من القيود الجديدة. اتصل بموفر الخدمة أو أعد تعيين الحد بواسطة PIN 2.

Declaration of Conformity



Suppliers Details

Name

LG Electronics Inc

Address

LG Electronics Inc, LG Twin Towers 20,
Yeouido-dong, Yeongdeungpo-gu, Seoul, Korea 150-721

Product Details

Product Name

GSM 850 / E-GSM 900 / DCS 1800 / PCS 1900 Quad band Terminal Equipment

Model Name

GX500

Trade Name

LG

CE 0168



Applicable Standards Details

R&TTE Directive 1999/5/EC

EN 301 489-01 V1.6.1, EN 301 489-07 V1.3.1, EN 301 489-17 V1.3.2
EN 301 511 V9.0.2
EN 50360:2001 EN62209-1:2006
EN 60950-1:2001
EN300328 V1.7.1

Supplementary Information

The conformity to above standards is verified by the following Notified Body(BABT)

BABT, Forsyth House-Churchfield Road - Walton-on-Thames Surrey - KT12 2TD , United Kingdom

Notified Body Identification Number : 0168

Declaration

I hereby declare under our sole responsibility that the product mentioned above to which this declaration relates complies with the above mentioned standards and Directives

Name

Issued Date

Seung Hyoun, Ji / Director

12. Feb. 2010

LG Electronics Logistics and Services B.V.
Veluwezoom 15, 1327 AE Almere, The Netherlands

Signature of representative

خدمة الشبكة

تمت الموافقة على استخدام الهاتف اللاسلكي الذي جاء وصفه في هذا الدليل. على شبكات GSM 850، و GSM 900 و E-GSM 1800 و DCS 1900.

وهناك عدد من الميزات المضمّنة في هذا الدليل وتسمى خدمات الشبكة. هذه الخدمات عبارة عن خدمات خاصة يمكنك الحصول عليها عبر موفر خدمة اللاسلكية، قبل أن تتمكن من الاستفادة من أي خدمة من خدمات الشبكة. عليك الاشتراك فيها عبر موفر الخدمة والحصول على الإرشادات المتعلقة باستخدامها والتي يزودك بها موفر الخدمة.

بيانات تقنية

عام

اسم المنتج: GX500

النظام: GSM 850 / E-GSM 900 / DCS 1800 / PCS 1900

درجات الحرارة المحيطة

القصى: +55 درجة مئوية (تفريغ).
+45 درجة مئوية (شحن)

الحد الأدنى: -10 درجات مئوية

الملحقات

يتم تزويدك بهذه الملحقات مع الهاتف GX500.



كبل البيانات
والقرص
المضغوط
للبيانات



الشاحن



دليل المستخدم



البطارية



سماعة رأس
استيريو

ملاحظة:

- استخدم ملحقات LG الأصلية دائماً.
- يؤدي عدم القيام بذلك إلى إبطال الضمان.
- قد تختلف الملحقات من منطقة لأخرى؛ يرجى مراجعة شركة أو وكيل الخدمة الإقليمي لمزيد من الاستفسارات.

⚠ تحذير: عندما يكون فيلم الحماية موصولاً بإطار اللمس، قد تنخفض حساسية اللمس.

تحديث البرنامج

برنامج تحديث برنامج الهاتف المحمول من LG

لمزيد من المعلومات حول تثبيت هذا البرنامج واستخدامه، يرجى زيارة موقع <http://www.lgmobile.com>

تتيح لك هذه الميزة تحديث برنامجك إلى الإصدار الأخير بسرعة وبشكل مريح على إنترنت من دون الحاجة إلى زيارة مركز الخدمة الخاص بنا. بما أن برنامج ترقية برنامج الهاتف المحمول يتطلب انتباه المستخدم الكامل لمدة عملية الترقية، يرجى التحقق من التعليمات والملاحظات التي تظهر في كل خطوة قبل المتابعة. تجدر الملاحظة إلى أن إزالة كبل اتصال بيانات USB أو البطاريات أثناء التحديث قد يتسبب بإلحاق ضرر بالغ بهاتفك المحمول، وبما أن جهة التصنيع لا تتحمل أي مسؤولية تجاه خسارة بيانات أثناء عملية الترقية. ننصحك بتدوين أي معلومات مهمة لتوخي الأمان.

Wi-Fi

يتيح لك مدير التشغيل اللاسلكي إدارة اتصالات إنترنت عبر Wi-Fi (شبكة LAN اللاسلكية) على جهازك.

يتيح للهاتف الاتصال بالشبكات اللاسلكية المحلية، أو الوصول إلى إنترنت لاسلكياً. Wi-Fi أسرع وذات نطاق أوسع من تقنية بلوتوث اللاسلكية، وبالتالي يمكن استخدامه لإرسال رسائل بريد إلكتروني سريعاً ولاستعراض إنترنت.

ملاحظة: GX500 يدعم WEP، تشفير WPA-PSK/2، وليس EAP، أو تشفير WPS. إذا قام موفر خدمة Wi-Fi أو مسؤول الشبكة بتعيين التشفير لحماية الشبكة، فعليك ملئ المفتاح في الإطار المنبثق. إذا لم يتم تعيين التشفير، فلن يظهر الإطار المنبثق هذا، يمكنك الحصول على المفتاح من موفر خدمة Wi-Fi لديك أو من مسؤول الشبكة.

الإعدادات

تغيير إعدادات بلوتوث:

- 1 المس  ثم قم بالتمرير عبر علامة التبويب الإعدادات.
- 2 اختر  ثم المس  واختر الإعدادات.

أدخل تغييراتك على:

إمكانية رؤية جهازي - اختر أن يكون الجهاز مرئياً أو مخفياً أو مرئياً لـ **1 دقيقة**.

اسم الجهاز - أدخل اسماً لـ GX500.

الخدمات المعتمدة - اختر الطريقة التي تريدها لاستخدام بلوتوث مع مختلف الخدمات،
عنواني - عرض عنوان بلوتوث.

الاقتران بجهاز بلوتوث آخر

عند إجراء اقتران لهاتف GX500 بجهاز آخر، يمكنك إعداد اتصال محمي برمز مرور. وهذا يعني أن الاقتران أصبح آمناً أكثر.

- 1 تحقق من كون بلوتوث في وضع **التشغيل و مرئياً**. يمكنك تغيير الرؤية في القائمة الإعدادات.
- 2 المس بحث.

3 يبحث الهاتف GX500 عن الأجهزة. عند اكتمال عملية البحث، يظهر تحديث على الشاشة.

- 4 اختر الجهاز الذي تريد الاقتران به وأدخل رمز المرور. ثم المس **موافق**.
- 5 يتصل هاتفك حينئذٍ بالجهاز الآخر. حيث عليك إدخال رمز المرور نفسه.
- 6 لقد أصبح اتصال بلوتوث المحمي برمز مرور آمناً الآن.

استخدام سماعة رأس بلوتوث

- 1 تحقق من كون بلوتوث في وضع **التشغيل و مرئياً**.
- 2 اتبع الإرشادات التي تصحب سماعة الرأس لوضعها في وضع الاقتران وإجراء اقتران للأجهزة.
- 3 المس **السؤال قبل الاتصال أو الاتصال دوماً** والمس **نعم** للاتصال الآن. يقوم الهاتف GX500 بالتبديل تلقائياً إلى وضع سماعة الرأس.

ذاكرة (SIM1/SIM2) - عرض
الذاكرة المتوفرة في بطاقة SIM.
الذاكرة الخارجية - عرض
الذاكرة الخارجية المتوفرة في بطاقة الذاكرة الخارجية (قد تحتاج إلى شراء بطاقة الذاكرة بشكل منفصل).
إعدادات الحفظ الأساسي - اختر
الموقع الذي تفضل حفظ العناصر فيه.

إرسال الملفات واستلامها باستخدام بلوتوث

يعتبر بلوتوث طريقة جيدة لإرسال الملفات وتلقيها إذ لا حاجة إلى أسلاك ويكون الاتصال سريعاً وسهلاً. كما يمكنك الاتصال بسماعات رأس بلوتوث لإجراء مكالمات وتلقيها.

إرسال ملف:

- 1** افتح الملف الذي تريد إرساله، وهو عادة عبارة عن صورة أو فيديو أو ملف موسيقي.
- 2** اختر إرسال. اختر بلوتوث.

- 3** إذا قمت مسبقاً بإقران جهاز بلوتوث، فلن يقوم GX500 بالبحث تلقائياً عن أجهزة بلوتوث أخرى. في حال تعذر ذلك، سيبحث GX500 عن أجهزة بلوتوث أخرى تم تمكينها ضمن النطاق.
- 4** اختر الجهاز الذي تريد إرسال الملف إليه والمس تحديد.
- 5** سيتم إرسال ملفك.

تلميح! راقب شريط التقدم لكي تتأكد من إرسال الملف.

لاستلام ملف:

- 1** لتلقي ملفات، يجب أن يكون بلوتوث في وضع التشغيل و مرئياً. راجع تغيير إعدادات بلوتوث إلى اليمين للحصول على مزيد من المعلومات.
- 2** تظهر رسالة تطالبك بقبول الملف من المرسل. المس نعم لاستلام الملف.
- 3** ستشاهد الموقع الذي تم حفظ الملف فيه ويمكنك أن تختار عرض الملف أو استخدام كخلفية للشاشة. يتم عادة حفظ الملفات في الحافظة المناسبة في ألبوم الوسائط.

الإعدادات

إعدادات الاتصال

وضع إنترنت - تظهر هذه القائمة أنماط إنترنت. يمكنك إنشاء أوضاع جديدة أو تعديلها باستخدام قائمة الخيار. إلا أنّ حذف أو تعديل التكوينات الافتراضية يتوقّف على متغيّرات الدولة.

نقاط الوصول - قام مشغّل الشبكة بحفظ هذه المعلومات مسبقاً. يمكنك إضافة نقاط وصول جديدة باستخدام هذه القائمة.

اتصال بيانات الرزمة - اختر الوقت الذي تريد أن يتصل فيه هاتفك بشبكة حزم البيانات.

وضع اتصال USB - اختر خدمة البيانات وقم بمزامنة هاتف GX500 باستخدام البرنامج LG PC Suite لنسخ الملفات من الهاتف. إذا استخدمت مزامنة الموسيقى مع Windows Media Player، حدد مزامنة الموسيقى في هذه القائمة. مزامنة الموسيقى متوفرة لمحتويات الموسيقى.



إعدادات جافا

تتيح لك تعيين الأوضاع للاتصالات التي تقوم بها برامج جافا ولعرض شهادتك.

استخدام إدارة الذاكرة

تتوفر في GX500 ثلاثة أنواع من الذاكرة: الهاتف. وبطاقة SIM وبطاقة ذاكرة خارجية (قد تحتاج إلى شراء بطاقة الذاكرة بشكل منفصل).

يمكنك استخدام إدارة الذاكرة لتحديد طريقة استخدام كل نوع من أنواع الذاكرة والمساحة المتوفرة فيها.

المس  ثم قم بالتمرير عبر علامة التبويب الإعدادات. حدد  ثم معلومات الذاكرة.

الذاكرة العامة للهاتف - عرض الذاكرة المتوفرة في GX500 للصور والأصوات، والفيديو، وال فلاش، وMMS، والبريد الإلكتروني، وتطبيقات جافا وغير ذلك.

ذاكرة الهاتف المحجوزة - عرض الذاكرة المتوفرة في الهاتف للرسائل النصية والأسماء والتقويم والمهام والمذكّرة والمنبه ومحفوظات المكالمات والإشارات المرجعية وعناصر متفرقة.

إعدادات الشبكة

تحديد الشبكة - إذا قمت بالتعيين إلى تلقائي، فسيبحث GX500 تلقائياً عن الشبكة ويسجل الجهاز على الشبكة. ننصح بهذا الأمر للحصول على خدمة وجودة أفضل. إذا قمت بالتعيين إلى يدوي يظهر كل الشبكات المتوفرة حالياً ويمكنك تحديد إحدى هذه الشبكات لتسجيلها. إذا فشلت تسجيل الشبكة، فسيتم سرد قوائم الشبكة مجدداً ويمكنك تحديد أي قائمة تريد للتسجيل.

ملاحظة: عندما يفقد هاتفك الاتصال بالشبكة في الوضع اليدوي، ستظهر الرسالة المنيقطة في شاشة الخمول لتحديد الشبكة المتاحة.

القوائم المفضلة - إذا كانت الشبكة تجري بحثاً تلقائياً، فيمكنك أن تضيف الشبكة المفضلة التي تريد الاتصال بها.

تلميح! جهاز التتبع الخاص بمكافحة سرقة المحمول (ATMT)

- المس الحماية و ATMT. عند سرقة الهاتف، يرسل الهاتف رسالة نصية SMS الأرقام التي قام المالك الحقيقي بتكوينها. يتوجب على المستخدم تكوين إعدادات ATMT مع اسم المالك، والبدل رقم (1). والبدل رقم (2) إلخ. رمز ATMT الافتراضي هو "000000"

- ستحتوي رسالة ATMT على معلومات حول الهاتف المسروق IMEI وموقعه الحالي ورقم هاتف الشخص الذي يستخدم الهاتف.

تغيير إعدادات إمكانية الاتصال

تم مسبقاً إعداد إعدادات إمكانية الاتصال بواسطة مشغل الشبكة. بحيث يمكنك أن تتمتع باستخدام هاتفك الجديد منذ البداية، إذا أردت تغيير أي ضابط من الإعدادات استخدم هذه القائمة.

اضغط على  ثم قم بالتمرير عبر علامة التبويب الإعدادات. تحديد



الإعدادات

إعدادات اللمس - قم بتغيير إعدادات قيمة لوحة اللمس.
اللغات - قم بتغيير لغة عرض GX500.

صامت عند الوضع بالمقلوب - في حالة المكالمات الواردة أو إيقاف تشغيل المنبه، يستطيع المستخدم قلب الهاتف للانتقال إلى وضع كتم الصوت أو التاجيل.
قفل المفاتيح التلقائي - قم بإقفال لوحة المفاتيح تلقائياً في شاشة وضع الانتظار.

الحماية - اضبط إعدادات الحماية. وهذا يشمل طلب رمز PIN، وقفل الهاتف، وتغيير الرموز، وجهاز التنبع الخاص بمكافحة سرقة المحمول (ATMT).

معلومات الذاكرة. - ويمكنك استخدام إدارة الذاكرة لتحديد طريقة استخدام كل نوع من أنواع الذاكرة.

إعادة تعيين الضبط - إعادة تعيين كل الإعدادات وفق تعريفات الشركة المصنعة.

المعلومات - عرض معلومات GX500 التقنية.

بدء التشغيل/إيقاف التشغيل - اختر صورة شاشة بدء التشغيل/إيقاف التشغيل.

3 المس حفظ لحفظ الإعدادات.

تغيير إعدادات الهاتف

تمتّع بحرية تكيف كيفية عمل GX500 مع أسلوبك الخاص.

تلميح! للتمرير عبر قائمة الخيارات، المس العنصر المرئي الأخير و قم بتمرير إصبعك إلى أعلى/يمين الشاشة. ستتحرك القائمة نحو الأعلى/اليمن بحيث يصبح عدد أكبر من العناصر مرئياً.

1 اضغط على  ثم قم بالتمرير عبر علامة التبويب الإعدادات.

2 المس  ثم اختر من ضمن القائمة أدناه.

التاريخ والوقت - اضبط التاريخ والوقت أو اختر تحديث الوقت بشكل تلقائي عند السفر أو للتوقيات الصيفية.

توفير الطاقة - اختر تبديل إعدادات توفير الطاقة التي تم تعيينها في الشركة المصنعة إيقاف التشغيل. والليل فقط وتشغيل دائم.

الإعدادات

باستطاعتك تكبيف الإعدادات ضمن هذه الحافظة لإضفاء طابع شخصي على الهاتف GX500.

إستخدام بطاقات SIM ثنائية- قائمة البطاقة

لتحديد أو تغيير بطاقة SIM، اضغط  ثم قم بالتمرير عبر علامة التبويب إعدادات، ثم حدد .

تخصيص الأوضاع

يمكنك أن تقوم بسرعة بتغيير الوضع على شاشة وضع الانتظار، ما عليك سوى لمس شريط ملخص الحالة في الأعلى ولمس علامة تبويب الوضع. يمكنك تخصيص كل إعدادات الوضع باستخدام قائمة الإعدادات.

1 اضغط على  ثم قم بالتمرير عبر علامة التبويب الإعدادات.

2 المس الأوضاع ثم اختر الوضع الذي ترغب في تعديله.

3 يمكنك حينئذٍ تغيير كل خيارات الأصوات والتنبيهات المتوفرة في القائمة.

تغيير إعدادات الشاشة

1 اضغط على  ثم قم بالتمرير عبر علامة التبويب الإعدادات.

2 المس  ثم اختر من:

خلفية الشاشة - اختر سمة لشاشة وضع الانتظار.

القائمة الرئيسية - اختر وضع القائمة الرئيسية.

إقفال الشاشة - اختر وضع شاشة القفل.

الاتصال - اضبط حجم الرقم ولونه.

السطوع - اضبط سطوع الشاشة.

ملاحظة: بقدر ما تطول الفترة التي تكون خلالها الإضاءة الخلفية قيد التشغيل، بقدر ما يتم استخدام طاقة البطارية وقد تحتاج إلى شحن هاتفك بشكل متكرر أكثر.

رسالة ترحيب - اختر تشغيل أو إيقاف تشغيل وقم بملئ رسالة الترحيب.

ويب

استخدام الهاتف كمودم

يمكن استخدام الهاتف GX500 كمودم للكمبيوتر. ما يوفر لك الوصول إلى البريد الإلكتروني وإنترنت حتى عندما لا يكون باستطاعتك الاتصال باستخدام الأسلاك. ويمكنك استخدام إما كبل USB أو بلوتوث.

استخدام كبل USB:

1 تأكد من تثبيت LG PC Suite على الكمبيوتر.

2 قم بتوصيل الجهاز GX500 والكمبيوتر باستخدام كبل USB وابدأ بتشغيل البرنامج LG PC Suite.

3 انقر فوق مجموعة إنترنت على الكمبيوتر. ثم انقر فوق زر جديد وحدد مودم.

4 اختر مودم USB لمحمول LG وحدد موافق. يظهر الآن على الشاشة.

5 اكتب الوضع الذي يجعلك تتصل بإنترنت واحفظ القيم.

6 سيظهر الوضع الذي أنشأته على شاشة الكمبيوتر. حدده وانقر فوق اتصال. سيتصل الكمبيوتر من خلال GX500.

استخدام بلوتوث:

عند إجراء اقتران لهاتف GX500 بجهاز آخر. يمكنك إعداد اتصال محمي برمز مرور.

1 تحقق من كون بلوتوث في وضع التشغيل و مرئيًا. يمكنك تغيير الرؤية في قائمة الإعدادات.

2 المس بحث.


3 يبحث GX500 عن الأجهزة. عند اكتمال عملية البحث. يظهر تحديث على الشاشة.

4 اختر الجهاز الذي تريد إجراء الاقتران به. وحدد موافق.

5 سيتصل هاتفك حينئذٍ بالجهاز الآخر. الذي سيتم إنشاء رمز مرور عليه لهذا الاتصال.



6 لقد أصبح اتصال بلوتوث المحمي برمز مرور آمنًا الآن.

حفظ صفحة

- 1 انتقل إلى صفحة ويب المطلوبة كما تم وصفه أعلاه.
- 2 المس  وحدد حفظ هذه الصفحة.
- 3 أدخل اسماً لصفحة ويب بحيث يمكنك التعرّف عليها بسهولة.
- 4 المس حفظ.

تلميح! ستسمح لك أيضاً هذه القائمة بتعديل عناوين الصفحات المحفوظة. وحماية شاشة المذكرة أو إلغاء حمايتها. وحذف الصفحات المحفوظة.



الوصول إلى صفحة محفوظة

- 1 على شاشة وضع الانتظار حدد  ثم قم بالتمرير عبر علامة التبويب الأدوات المساعدة ثم اختر .
- 2 حدد الصفحات المحفوظة.
- 3 حدد الصفحة المطلوبة افتتح.

عرض محفوظات المتصفح

- 1 على شاشة وضع الانتظار حدد  ثم قم بالتمرير عبر علامة التبويب الأدوات المساعدة ثم اختر .
- 2 حدد المحفوظات. تظهر قائمة بعناوين صفحات ويب التي وصلت إليها مؤخراً. للوصول إلى إحدى هذه الصفحات. ما عليك إلا تحديد الصفحة المطلوبة.

تغيير إعدادات متصفح ويب

- 1 في شاشة وضع الانتظار حدد  . ثم قم بالتمرير عبر علامة التبويب الأدوات المساعدة واختر  . حدد الإعدادات.
- 2 يمكنك أن تختار تعديل الأوضاع أو إعدادات المظهر أو ذاكرة التخزين المؤقت أو ملفات تعريف الارتباط أو الحماية.

ويب



استخدام قارئ RSS

إنّ RSS أو توزيع المحتوى والتطبيقات عبارة عن مجموعة من أشكال تغذية ويب يتم استخدامها لنشر محتوى يتكرر تحديثه مثل إعلانات المدونات أو عناوين الأخبار أو البث الصوتي على ويب podcasts. ويحتوي مستند RSS والذي يسمى تغذية أو تغذية ويب أو قناة على ملخص محتوى من موقع ويب مرتبط أو على النص الكامل.

وبفضل تغذية RSS سيتمكن الأشخاص من الاحتفاظ بمواقعهم المفضلة على ويب بطريقة مؤتمتة تعتبر أسهل من التدقيق في تلك المواقع يدوياً. وباستطاعة المستخدم أن يشترك في قناة عبر إدخال ارتباط القناة في القارئ أو بالنقر فوق رمز RSS في متصفح يبدأ عملية الاشتراك. ويتحقق القارئ من القنوات التي اشترك فيها المستخدم بشكل دوري بحثاً عن محتوى جديد. ويقوم بتنزيل أي تحديثات يعثر عليها.

إضافة الإشارات المرجعية والوصول إليها

لكي تتمكن من الوصول إلى مواقعك المفضلة على ويب بشكل سريع وسهل، يمكنك إضافة إشارات مرجعية وحفظ صفحات ويب.

- 1 على شاشة وضع الانتظار حدد ثم قم بالتمرير عبر علامة التبويب الأدوات المساعدة ثم اختر .
- 2 حدد الإشارات المرجعية. تظهر قائمة بالإشارات المرجعية على الشاشة.
- 3 لإضافة إشارة مرجعية جديدة، حدد  والمس إضافة إشارة مرجعية. أدخل عنواناً للإشارة المرجعية. يتبعه URL.
- 4 المس حفظ. تظهر إشارتك المرجعية الآن في قائمة الإشارات المرجعية.
- 5 للوصول إلى الإشارة المرجعية ما عليك إلا لمس الإشارة المرجعية ولمس توصيل. سيتم توصيلك بالإشارة المرجعية.

ويب

المتصفح


المتصفح يصلك بعالم سريع وكامل من الألعاب. والموسيقى. والأخبار. والرياضة. والترفيه وغيرها. مباشرةً من هاتفك المحمول. حيثما كنت ومهما كنت تفعل.

Opera Mini

يعتمد GX500 متصفح Opera Mini 5 وهو إحدى تطبيقات جافا التي يمكن الوصول إليها من قائمة المتصفح أو من قائمة الألعاب والتطبيقات في الهاتف. ومن بين أبرز ميزات هذا المتصفح نذكر: عدة إطارات. والحماية. والتكبير/التصغير بواسطة اللمس. والإشارات المرجعية. والمحفوظات. والصفحات المحفوظة والاتصال السريع.

ملاحظة: يتطلب الاستعراض باستخدام Opera Mini 5 اتصال البيانات.

الوصول إلى ويب

- 1 على شاشة وضع الانتظار حدد  ثم قم بالتمرير عبر علامة التبويب الأدوات المساعدة ثم اختر .
- 2 للوصول إلى صفحة المتصفح الرئيسية مباشرة. حدد الصفحة الرئيسية. كطريقة بديلة. حدد إدخال العنوان وكتب عنوان URL المطلوب. يتبعه اتصال.

ملاحظة: يتم فرض رسم إضافي عند الاتصال بهذه الخدمة وتنزيل المحتوى. للحصول على تفاصيل تتعلق بالرسوم المفروض على البيانات. اتصل بموفر الشبكة.

PC Suite

حول فيديو DivX: ®DivX عبارة عن
تهيئة فيديو رقمية أنشأتها شركة
DivX, Inc. هذا جهاز رسمي من
DivX مسموح به وهو يشغل فيديو
DivX. يرجى زيارة الموقع [www.
divx.com](http://www.divx.com) للحصول على مزيد
من المعلومات وعلى أدوات البرامج
لتحويل ملفاتك إلى ملفات فيديو
بتنسيق DivX.

حول DivX فيديو عند الطلب: يجب
تسجيل جهاز DivX® المسموح به
هذا مع DivX ليتمكن من تشغيل
محتويات DivX فيديو عند الطلب
(VOD). لإنشاء رمز التسجيل، حدّد
موقع قسم DivX VOD في قائمة
إعداد الجهاز. انتقل إلى موقع [vod.
divx.com](http://vod.
divx.com) بواسطة هذا الرمز
لإكمال عملية التسجيل ومعرفة
المزيد حول DivX VOD.

Pat. 7,295,673

DivX Converter


قم بتثبيت DivX converter الذي يتم تزويدك به على القرص المضغوط نفسه حيث برنامج PC Suite. سيقوم DivX بتحويل ملفات الوسائط الموجودة على جهاز الكمبيوتر إلى تنسيق يسمح لك بتحميلها وعرضها على هاتفك. عند تثبيت DivX، حدده من Program Files على الكمبيوتر. ثم **DivX converter** يتبعه Converter.

استخدم الأسهم في التطبيق لتغيير تنسيق التحويل إلى Mobile. إذا نقرت فوق التطبيق بزر الماوس الأيمن وحددت تفضيلات. فيمكنك تغيير الموقع الذي تم حفظ الملفات المحولة فيه.

قم بسحب الملفات وإفلاتها في التطبيق لإجراء تحليل أولي. ثم حدد تحويل كي تبدأ العملية. عندما تنتهي العملية يظهر إطار منبثق لإعلامك باكتمال عملية التحويل. ملاحظة: لا يعتمد الهاتف GX500 تنسيق ملفات DivX.

نقل الموسيقى باستخدام Windows Media Player

- 1 على الشاشة الرئيسية حدد  ثم قم بالتمرير عبر إمكانية الاتصال في علامة التبويب الإعدادات.
- 2 حدد وضع اتصال USB واختر مزامنة الموسيقى.
- 3 قم بتوصيل الهاتف والكمبيوتر باستخدام كبل USB متوافق.
- 4 عندما تحاول توصيل الهاتف بالكمبيوتر سيقراً الهاتف: "تزامن الموسيقى" يتبعه تم التوصيل.
- 5 سيطالبك الكمبيوتر بتشغيل برنامج إدارة الموسيقى المفضلة لديك.
- 6 حدد Window Media Player.
- 7 انتقل إلى علامة التبويب مزامنة. ثم قم بسحب وإفلات الموسيقى التي ترغب في إرسالها إلى الهاتف إلى لوحة الرسم مزامنة القائمة.
- 8 انقر فوق الزر بدء المزامنة. سيؤدي ذلك إلى بدء عملية النقل.

 تحذيرة: لا تقم بفصل الهاتف أثناء النقل.


PC Suite

4 تظهر كل رسائل الهاتف في الحافظات على الشاشة.

تزامن الموسيقى

تتيح لك هذه القائمة إضافة الموسيقى إلى الهاتف GX500. قبل أن تبدأ بنقل الموسيقى من الكمبيوتر إلى الهاتف. تأكد من توفر الإعداد التالي والملحق:

- Microsoft Windows XP أو Vista
- Windows Media Player 10 أو إصدار لاحق
- كبل بيانات USB
- بطاقة microSD (إذا رغبت في استخدام الذاكرة الخارجية كجهاز تخزين للموسيقى).

 تحذير: لا تقم بفصل الهاتف أثناء النقل.

مزامنة الأسماء

- 1 قم بتوصيل الهاتف بالكمبيوتر.
- 2 انقر فوق رمز الأسماء.
- 3 انقر فوق الزر مزامنة الأسماء. فتظهر الرسالة مرحباً بك في خدمة مزامنة LG Air Sync < اضغط على زر بدء التشغيل < حدد خيارات الأسماء الفرعية (بما في ذلك جهات اتصال outlook أو يتم نقل سجلات المكالمات من الهاتف أثناء المزامنة < اضغط على التالي < اختصار هل تريد المتابعة < التالي < حدد الأسماء < اضغط على المزامنة الآن).

مزامنة الرسائل

- 1 قم بتوصيل الهاتف بالكمبيوتر.
- 2 انقر فوق رمز الرسائل.
- 3 تظهر كل رسائل الهاتف في الحافظات على الشاشة.

- إجراء نسخ احتياطي لمعلومات الهاتف واستعادتها**
- 1 أصبح الآن هاتفك والكمبيوتر متصلين ببعضهما.
 - 2 انقر فوق رمز نسخ احتياطي وحدد نسخ احتياطي أو استعادة.
 - 3 اختر النسخ الاحتياطي لـ الأسماء\التقويم\المهمة\المذكرة\الصورة\الفيديو. حدد الموقع الذي تريد إجراء نسخ احتياطي للمعلومات فيه. أو استعادة المعلومات منه. انقر فوق الزر موافق ثم الزر نسخ احتياطي أو استعادة تباعاً ثم اضغط على الزر إنهاء.
 - 4 سيتم إجراء نسخ احتياطي للمعلومات.
- عرض ملفات الهاتف على الكمبيوتر**
- 1 أصبح الآن هاتفك والكمبيوتر متصلين ببعضهما.
 - 2 انقر فوق رمز إدارة الصور. ملفات الفيديو أو موسيقى.
 - 3 تظهر على الشاشة في حافظة هاتف LG كل الصور وملفات الصوت. والفيديو التي حفظتها في الهاتف.
- تلميح!** يساعدك عرض محتويات الهاتف على الكمبيوتر على إدارة الملفات التي لم تعد بحاجة إليها.

PC Suite

تنبيه! في حال عدم ظهور رسالة دليل التثبيت على جهاز الكمبيوتر، يرجى التحقق من إعداد القرص المضغوط على Windows.

- 5 قم بإدراج القرص المضغوط المرفق مع الهاتف أو انقر فوق زر التنزيل لتنزيل برنامج LG PC Suite مباشرة من إنترنت.
- 6 انقر فوق مثبت LG PC Suite الذي يظهر على الشاشة.

توصيل الهاتف والكمبيوتر

- 1 حدد وضع PC Suite في قائمة إمكانية الاتصال ثم قم بتوصيل كبل USB بالهاتف والكمبيوتر.
- 2 سيتم تنشيط LG PC Suite تلقائياً على الكمبيوتر.
- 3 أصبح الآن هاتفك والكمبيوتر متصلين ببعضهما.

يمكنك مزامنة الكمبيوتر مع الهاتف. هذا الأمر يضمن تطابق التفاصيل والتواريخ المهمة، ويستخدم كمنسخ احتياطي للاطمئنان.

تلميح! ستحتاج إلى تثبيت التطبيق PC Suite المتوفر على القرص المضغوط أو الذي يمكن تنزيله من الموقع www.lg.com المنتجات < الدليل والبرامج < الانتقال إلى قسم تنزيل الدليل والبرامج.

تثبيت برنامج LG PC Suite على الكمبيوتر

- 1 على الشاشة الرئيسية، المس  ثم قم بالتمرير عبر الإعدادات ثم المس إمكانية الاتصال.
- 2 حدد اتصال USB وانقر فوق PC Suite.
- 3 قم بتوصيل الهاتف والكمبيوتر عبر كبل USB وانتظر بضع دقائق.
- 4 ستعرض رسالة دليل التثبيت على شاشة الكمبيوتر.

الباحث عن التاريخ

الباحث عن التاريخ هو أداة سهلة تساعدك على احتساب تاريخ الأيام القليلة المقبلة.

الإعدادات

إعدادات التقويم - يمكنك تعيين التكوينات لعرض التقويم.

إرسال كل بيانات منظم المواعيد عبر بلوتوث - يمكنك إرسال كل البيانات الموجودة في التقويم و/أو المهام من الهاتف إلى هاتف آخرى باستخدام بلوتوث.

معلومات الذاكرة. - يمكنك عرض معلومات الذاكرة المتوفرة في ما يتعلق بالتقويم، والمهام، والمذكرة والمذكرة السرية.


مسح الكل - يمكنك حذف كل البيانات المتعلقة بالتقويم، والمهام، والمذكرة والمذكرة السرية.


الأدوات المساعدة

- 4 بالنسبة إلى المواعيد ومناسبات الذكرى السنوية أدخل تاريخ ووقت انتهاء الحدث في المربعين السفليين للتاريخ والوقت.
 - 5 إذا كنت ترغب في إضافة موضوع أو ملاحظة إلى الحدث. المس ملاحظة واكتب ملاحظتك بتبعها حفظ.
 - 6 عين منبه و تكرر.
 - 7 حدد حفظ فيتم حفظ الحدث في التقويم. يقوم رأس مؤشر مربع الشكل بتحديد اليوم الذي تم حفظ أية أحداث فيه وسيمر جرس في وقت البدء المعين للحدث. بحيث يمكنك أن تحافظ على تنظيم أوقاتك.
- إضافة عنصر إلى قائمة المهام**
- 1 المس **+** على الشاشة الرئيسية ثم المس منظم المواعيد.
 - 2 المس المهام ثم المس إضافة مهمة.
 - 3 عيّن تاريخ عنصر المهمة. وأضف الملاحظات وحدد مستوى للأولوية: عالية أو متوسطة أو منخفضة.
- استخدام ساعة الإيقاف**
- 1 المس **+**. ثم قم بالتمرير عبر الأدوات المساعدة والمس أدوات.
 - 2 المس ساعة الإيقاف.
 - 3 المس بدء لبدء تشغيل المؤقت.
 - 4 المس دورة إذا أردت تسجيل وقت الدورة.
 - 5 المس إيقاف لإيقاف تشغيل المؤقت.
 - 6 المس استئناف لإعادة تشغيل ساعة الإيقاف في الوقت الذي توقفت فيه أو المس إعادة تعيين لإعادة بدء التوقيت من جديد.
- إضافة عنصر إلى التقويم**
- 1 المس **+** على الشاشة الرئيسية ثم المس منظم المواعيد.
 - 2 المس التقويم ثم المس إضافة حدث.
 - 3 المس فئة ثم اختر من ضمن موعد أو ذكرى أو عيد ميلاد. تحقق من التاريخ وأدخل الوقت الذي تريد أن يبدأ عنده الحدث.


الأدوات المساعدة

تسجيل ملف صوتي أو صوت

1 المس . ثم قم بالتمرير عبر الأدوات المساعدة.


2 المس  مسجل الصوت.

3 المس  لبدء التسجيل.

4 المس  لإنهاء التسجيل.

5 المس  للاستماع إلى التسجيل.

استخدام الحاسبة

1 المس . ثم قم بالتمرير عبر الأدوات المساعدة والمس أدوات.


2 المس الحاسبة.

3 المس المفاتيح الرقمية لإدخال الأرقام.

4 بالنسبة إلى الحسابات البسيطة. حدد الوظيفة التي تحتاج إليها (+، -، ×، و ÷). يليها =.

5 بالنسبة إلى العمليات الحسابية الأكثر تعقيداً. المس  واختر من ضمن **sin** أو **cos** أو **tan** أو **log** أو **ln** أو **exp** أو **sqrt** أو **deg** أو **rad** إلخ.

تحويل وحدة


1 المس . ثم قم بالتمرير عبر الأدوات المساعدة والمس أدوات.

2 المس محول الوحدات.

3 اختر ما إذا كنت ترغب في تحويل العملة أو المساحة أو الطول أو الوزن أو درجة الحرارة أو الحجم أو السرعة.

4 يمكنك الآن تحديد الوحدة وإدخال القيمة التي تريد التحويل منها. تتبعها الوحدة التي تريد التحويل إليها.

إضافة مدينة إلى ساعتك العالمية

1 المس . ثم قم بالتمرير عبر الأدوات المساعدة والمس أدوات.

2 المس الساعة العالمية.

3 المس . يتبعه مدينة جديدة. ابدأ بكتابة اسم المدينة التي تريدها وسيظهر الاسم في أعلى الشاشة.


الوسائط المتعددة

البحث عن محطات

يمكنك إعداد محطات الراديو في هاتفك وذلك بالبحث عنها إما يدوياً أو تلقائياً. وسيتتم حينئذٍ حفظها في أرقام قنوات معينة بحيث لن تعود بحاجة إلى إعادة ضبطها. ويمكنك حفظ ما يصل إلى 48 قناة في هاتفك. ينبغي بك أولاً أن توصل سماعة الرأس بالهاتف إذ إنها تعمل كهوائي.

للضبط تلقائياً:


1 المس .

2 قم بالتمرير عبر راديو FM ثم .

3 المس بحث تلقائياً. فيتم تلقائياً العثور على المحطات وتخصيصها إلى قناة في هاتفك.





إعادة تعيين القنوات

1 المس .

2 قم بالتمرير عبر راديو FM ثم .

3 اختر إعادة تعيين لإعادة تعيين القناة الحالية أو اختر إعادة تعيين الكل لإعادة تعيين كل القنوات. تعود كل قناة إلى معدل التردد 87.5 ميجاهرتز وهو تردد البداية.

تشغيل أغنية

- 1 المس .
- 2 قم بالتمرير عبر الترفيه لـ . ثم المس كل المسارات.
- 3 حدد الأغنية التي تريد تشغيلها.
- 4 المس  لإيقاف الأغنية مؤقتاً.
- 5 المس  للانتقال إلى الأغنية التالية.
- 6 المس  للانتقال إلى الأغنية السابقة.
- 7 المس  للعودة إلى قائمة الموسيقى.

إنشاء قائمة تشغيل

يمكنك إنشاء قوائم التشغيل الخاصة بك وذلك بإنشاء مجموعة مختارة من الأغاني من حافظة كل المسارات.

- 1 المس .
- 2 قم بالتمرير عبر الترفيه لـ . ثم المس قوائم التشغيل.
- 3 المس إضافة قائمة تشغيل جديدة. وأدخل اسم قائمة التشغيل والمس حفظ.

4 تعرض حافظة كل المسارات كل

الأغاني الموجودة على هاتفك. المس كل الأغاني التي تريد تضمينها في قائمة التشغيل. فتظهر علامة إلى جانب اسم كل أغنية.

5 المس تم.

استخدام الراديو

تتوفر في طراز الهاتف LG GX500 ميزة راديو FM بحيث يمكنك إعداد محطاتك المفضلة للاستماع إليها أثناء التنقل.


ملاحظة: ستحتاج إلى إدخال سماعات الرأس لكي تتمكن من الاستماع إلى الراديو. أدخل سماعات الرأس في المأخذ المخصص لها (هذا المأخذ هو نفسه المأخذ الذي تقوم بتوصيل الشاحن فيه).

الوسائط المتعددة

الموسيقى

يكون مشغّل الموسيقى مضمّنًا في الهاتف LG GX500 بحيث يمكنك تشغيل كل مسارات الموسيقى

المفضلة لديك، للوصول إلى مشغّل الموسيقى، المس .

قم بالتمرير عبر الترفيه لـ . من هنا يمكنك الوصول إلى عدد من الحافظات:

تم تشغيلها مؤخرًا - قم بعرض كل الأغاني التي قمت بتشغيلها مؤخرًا.

كل المسارات - يحتوي على كل الأغاني الموجودة في هاتفك.

الفنانون - الاستعراض عبر مجموعتك الموسيقية حسب الفنان.

الألبومات - الاستعراض عبر مجموعتك الموسيقية حسب الألبوم.

الأنواع - الاستعراض عبر مجموعتك الموسيقية حسب النوع.

قوائم التشغيل - تحتوي على كل قوائم التشغيل التي أنشأتها.

مزج المسارات - شغّل المسارات بترتيب عشوائي.

نقل الموسيقى إلى الهاتف

الطريقة الأسهل لنقل الموسيقى إلى الهاتف تتم عبر بلوتوث أو كبل المزامنة.

يمكن أيضًا استخدام LG PC Suite. للنقل باستخدام بلوتوث:

1 تأكد من تشغيل بلوتوث على الجهازين ومن كونهما مرئيين بالنسبة إلى بعضهما البعض.

2 حدد ملف الموسيقى على الجهاز الآخر واختر إرساله عبر بلوتوث.

3 عندما يصبح الملف جاهزًا للإرسال، يجب أن تقبله على هاتفك بلمس نعم.

4 يجب أن يظهر الملف في الموسيقى < كل المسارات.

نقل ملف إلى هاتفك

تُعتبر تقنية بلوتوث الطريقة الأكثر سهولة على الأرجح لنقل ملف من الكمبيوتر إلى هاتفك. كما يمكنك استخدام LG PC Suite عبر كبل المزامنة.

لنقل باستخدام بلوتوث:

- 1 تأكد من تشغيل بلوتوث على الهاتف والكمبيوتر ومن كونهما مرئيين لبعضهما بالنسبة إلى بعض.
- 2 استخدم الكمبيوتر لإرسال الملف عبر بلوتوث.
- 3 عندما يُرسل الملف إليك سيترتب عليك قبوله على الهاتف وذلك بلمس نعم.
- 4 يجب أن يظهر الملف في حافظة المستندات أو حافظات أخرى.

عرض ملف

- 1 المس .
- 2 المس  ثم المستندات.
- 3 حدد مستنداً والمس للعرض.

أخرى

تُستخدم الحافظة أخرى لتخزين ملفات ليست عبارة عن صور، أو أصوات، أو ملفات فيديو، أو ألعاب أو تطبيقات، وهي تُستخدم بالطريقة نفسها التي يتم بها استخدام حافظة المستندات. وقد تجد أن الملفات تظهر في الحافظة أخرى عوضاً عن ظهورها في حافظة المستندات عندما تنقلها من الكمبيوتر إلى هاتفك. إذا حدث مثل هذا الأمر فيمكنك نقلها. لنقل ملف من حافظة أخرى إلى حافظة المستندات:

- 1 المس .
- 2 المس  ثم أخرى.
- 3 حدد ملفاً والمس .
- 4 المس نقل. اختر الحافظة المطلوبة من القائمة بواسطة لمس رمز السهم. ستعرض الشاشة تم النقل عندما تكتمل عملية النقل.



الوسائط المتعددة

الألعاب والتطبيقات

يمكنك تثبيت ألعاب وتطبيقات جديدة إلى هاتفك لمساعدتك على التسلية عندما يكون لديك بعض الوقت للقيام بذلك.

تثبيت لعبة/تطبيق بواسطة

التثبيت المحلي

- 1 المس .
- 2 المس  و أخرى أو بطاقة الذاكرة إذا كانت الذاكرة الخارجية مدرجة.
- 3 حدد الملف (.jar* أو .jad*) الذي تود تثبيته. سيتم تثبيت تطبيق.

ملاحظة: ينبغي أن يحتوي ملف jad على ملف jar الخاص به.

تشغيل لعبة

- 1 المس .
 - 2 المس  ثم ألعاب.
 - 3 حدد لعبة لتشغيلها.
- يحتوي GX500 على بعض التطبيقات المحملة مسبقاً.

المستندات


من قائمة مستندات، يمكنك عرض كل ملفات المستندات. من هنا يمكنك عرض ملفات Excel، و PowerPoint، و Word، و Text و PDF.

نقل صورة أو نسخها

يمكنك نقل صورة أو نسخها بين ذاكرة الهاتف وبطاقة الذاكرة. ويمكنك القيام بذلك إما لتحرير بعض المساحة في إحدى وحدات الذاكرة أو لمنع فقدان الصور.

1 المس 

2 المس  ثم صوري.

3 المس  وحدد نقل أو نسخ.

4 فسيتم إرفاق صورتك بالرسالة

ويمكنك كتابة الرسالة وإرسالها

بشكل عادي. حدّد الصورة التي

تريد أن تنقلها أو تنسخها والمس

نسخ/نقل.

أصوات

تحتوي حافظة أصواتي على الأصوات

التي تم تنزيلها. وعلى الأصوات

الافتراضية والتسجيلات الصوتية.

ومن هنا يمكنك إدارة الأصوات. أو


إرسالها أو ضبطها كنغمات رنين.

ملفات الفيديو

تعرض حافظة ملفات الفيديو خاصتي قائمة بملفات الفيديو التي تم تنزيلها إلى هاتفك وملفات الفيديو التي قمت بتسجيلها على هاتفك.


مشاهدة فيديو

1 المس 

2 المس  ثم مقاطع الفيديو.

3 حدد فيديو ليتم تشغيله.

إرسال فيديو كليب

1 حدد فيديو والمس 

2 المس إرسال واختر من ضمن رسالة أو بريد إلكتروني أو بلوتوث.

3 إذا اخترت الرسالة أو البريد

الإلكتروني. فسيتم إرفاق ملف

الفيديو بالرسالة ويمكنك كتابة



رسالتك وإرسالها بشكل عادي. إذا

اخترت بلوتوث. فسيتم تشغيل

بلوتوث تلقائياً وسيبحث هاتفك عن جهاز ليرسل الفيديو إليه.

الوسائط المتعددة



إرسال صورة

- 1 المس . ثم اختر صوري.
- 2 المس  ثم اختر صوري.
- 3 المس إرسال واختر من ضمن رسالة. بريد إلكتروني أو بلوتوث.
- 4 إذا اخترت رسالة أو بريد إلكتروني. فسيتم إرفاق صورتك بالرسالة ويمكنك كتابة الرسالة وإرسالها بشكل عادي. إذا اخترت بلوتوث. فسيتم تشغيل بلوتوث تلقائياً وسيبحث هاتفك عن جهاز ليرسل الصورة إليه.

طباعة صورة

- 1 المس .
- 2 المس  ثم صوري.
- 3 حدد صورة والمس .
- 4 المس طباعة ثم اختر بلوتوث.

تلميح! يمكنك الطباعة عبر بلوتوث أو عبر الاتصال بطابعة PictBridge متوافقة.


يمكنك تخزين أي ملفات وسائط متعددة في ذاكرة الهاتف بحيث يتوفر لديك الوصول السهل إلى كل الصور والأصوات وملفات الفيديو والألعاب. كما يمكنك حفظ ملفاتك في بطاقة الذاكرة. الفائدة من استخدام بطاقة الذاكرة هي أنها تسمح لك بتحرير مساحة على ذاكرة الهاتف. للوصول إلى قائمة الوسائط المتعددة. المس . المس  لفتح قائمة الحافظات التي تحفظ كل ملفات الوسائط المتعددة.

الصور

تحتوي صوري على قائمة بالصور تتضمن الصور الافتراضية التي تم تحميلها مسبقاً إلى هاتفك. وصوراً قمت أنت بتنزيلها وصوراً تم التقاطها بكاميرا الهاتف. المس لتغيير العرض من عرض الصور المصغرة إلى عرض قائمة.

تعديل الصور


يمكنك تطبيق الكثير من الأشياء الرائعة على صورك لتغييرها، أو الإضافة إليها، أو إضفاء بعض الحيوية إليها.

1 افتح الصورة التي تريد تعديلها والمس  لإظهار الخيارات.


2 المس الرموز لتغيير الصورة:


 اقتصاص الصورة. اختر


منطقة اقتصاص مربعة أو دائرية وحرك إصبعك عبر الشاشة لتحديد المنطقة.


 أرسم شيئاً على الشكل الحر لصورتك. حدّد سماكة الخط من ضمن الخيارات الأربعة واللون الذي تود استخدامه.


 إضافة نص إلى صورة. راجع إضافة نص إلى صورة.


 قم بتزيين صورتك بواسطة الطوابع. اختر من ضمن الطوابع المتوفرة والمس الصورة حيث ترغب في وضع هذه الطوابع.


 احذف التعديل الذي أضفته إلى الصورة. يمكنك اختيار حجم الممحاة التي تستخدمها.


 المس للعودة إلى الاستوديو.

 ا حفظ التغييرات التي أدخلتها على الصور. حدد لحفظ التغييرات كتحديث للملف الأصلي أو ملف جديد. إذا حددت ملف جديد فأدخل اسم ملف.

 تراجع عن آخر تأثير أو تعديل أضفته إلى الصورة.

 المس لفتح المزيد من خيارات التأثير بما فيها التمدوير. هناك أيضاً المزيد من خيارات التعديل المتقدمة. راجع إضافة تدرج لون و مبادلة الألوان في صورة.

 المس لتطبيق خيارات التأثير على صورة.

 هذا يساعدك على إعداد صورة تم التقاطها باستخدام لون تلقائي. وسطوع تلقائي. إلخ.

الصور ومقاطع الفيديو


إعداد مستوى الصوت عند عرض فيديو

لضبط مستوى صوت الفيديو أثناء تشغيله، المس بشرط مستوى الصوت الموجود في أعلى الشاشة بعد الضغط على رمز مكبر الصوت. كطريقة بديلة، استخدم مفاتيح مستوى الصوت على جانب الهاتف.


تعيين صورة خلفية الشاشة

- 1 المس الصورة التي ترغب في تعيينها كخلفية الشاشة لفتحها.
- 2 المس الشاشة لفتح قائمة الخيارات.
- 3 المس خيار استخدام خلفية للشاشة.
- 4 يمكنك تكبير وتصغير الصورة ونقل المقطع المقتص مسخدمًا صورة مصغرة أسفل الشاشة.
- 5 عند إنتهائك من إعداد الصورة كما تحب، المس ضبط.
- 6 إختار ما تريد تغييره ما بين الكل، عنصر واجهة الإستخدام أو إتصال سريع.

عرض الصور وملفات الفيديو

- 1 المس  على شاشة المعاينة الخاصة بالكاميرا.
- 2 يظهر الاستوديو على الشاشة.
- 3 المس الفيديو أو الصورة لفتحهما كلياً.

تلميح! انقر إلى اليمين أو إلى اليسار لعرض صور أخرى أو ملفات فيديو أخرى.

تلميح! لحذف فيديو أو صورة، افتحه وحدد . المس نعم للتأكيد.

استخدام التكبير/التصغير عند عرض صورة



عند مشاهدة صور، يمكنك التكبير والتصغير.

شاشة الشبكة - اختر من ضمن إيقاف تشغيل، أو تقاطع بسيط. أو ثلاثية الأجزاء.

تخفيض الضجيج - تساعد هذه الوظيفة على تخفيض الضجيج وتنقية صورة بعد التقاطها.

إعادة تعيين الإعدادات - قم بإعادة تعيين إعدادات كاميرا الفيديو كافة.

مشاهدة ملفات الفيديو المحفوظة

- 1 في الباحث عن العرض المس .
- 2 يظهر الاستوديو على الشاشة.
- 3 المس الفيديو الذي تريد عرضه مرة واحدة لإحضاره إلى مقدمة الاستوديو.
- 4 المس  على الفيديو.

كاميرا الفيديو

إعداد التعرض

يعرّف التباين الفرق بين الألوان الفاتحة والداكنة (التباين) في فيديو ما.

1 المس []

2 ادفع مؤشر التباين عبر الشريط. نحو اليسار للحصول على تباين منخفض، وفيديو ضبابي. أو نحو اليمين للحصول على تباين أعلى وصورة أوضح.

استخدام الإعدادات المتقدمة

في محدد المنظر المس [] لفتح كل خيارات الإعدادات المتقدمة.

تأثير الألوان - اختر درجة اللون التي تريد تطبيقها على الفيديو الذي تلتقطه. يمكنك الاختيار بين: إيقاف، أو أسود وأبيض، أو سالب أو بني داكن.

توازن اللون الأبيض - يضمن توازن الأبيض ظهور أي لون أبيض في الفيديو كواقعي. لكي تتمكن الكاميرا من إعداد توازن اللون الأبيض بشكل صحيح، قد تحتاج إلى تحديد شروط الإضاءة. اختر ما بين: تلقائي، متوهج، منظم، فلورسنت و غائم.

الوضع الليلى - يمكنك التقاط صوري بشكل أفضل عبر تحديد تشغيل.

المؤقت الذاتي - يسمح لك المؤقت

الذاتي بتعيين فترة تأخير قبل أن

تلتقط الكاميرا الصورة. بعد ضغط

زر الالتقاط، اختر من ضمن إيقاف

التشغيل. 3 ثوانٍ، 5 ثوانٍ أو 10 ثوانٍ.

الجودة - اختر من ضمن دقيق جداً

ودقيق وعادي.

بقدر ما تكون الجودة دقيقةً بقدر ما

يكون الفيديو واضح المعالم ولكن

حجم الملف سيكون أكبر. أي أنك

ستتمكن من تخزين عدد أقل من

الفيديو في ذاكرة الهاتف.

وضع العرض - يطبق تأثيرات فنية

على الصور.

تحديد موقع التخزين - اختر ما

إذا كنت تريد حفظ ملفات الفيديو

في ذاكرة الهاتف أو في الذاكرة

الخارجية.

إظهار الصورة الملتقطة - اختر

عرض الصورة مع الخيارات بعد التقاط

صورة.

إخفاء الرموز - إخفاء الرموز على





جانب محدد المنظر.

صوت الغالق - حدد خياراً من ضمن

خيارات صوت الغالق الثلاث.









كاميرا الفيديو

التقاط فيديو سريع

- 1 اضغط باستمرار على مفتاح الكاميرا الموجود في الجانب الأيمن من الهاتف.
- 2 كطريقة بديلة، قم بالسحب لأسفل  في محدد المنظر في وضع الفيديو.
- 3 سيظهر محدد المنظر في كاميرا الفيديو على الشاشة.
- 4 مع حمل الهاتف أفقياً، صوّب العدسة باتجاه موضوع الفيديو.
- 5 اضغط على زر الالتقاط مرةً واحدةً لبدء التسجيل.
- 6 يظهر تسجيل في الأسفل فوق مؤقت طول الفيديو ويظهر مؤقت في الأسفل طول الفيديو.
- 7 لإيقاف الفيديو مؤقتاً المس  وللاستئناف حدد .
- 8 المس  على الشاشة أو اضغط زر الالتقاط مرةً ثانيةً لإيقاف التسجيل.

تلميح! للانتقال بين وضعي الكاميرا / الفيديو.حرك أعلى / أسفل أيقونة الكاميرا أو الفيديو الموجودة على مركز عدسة الكاميرا.

بعد الانتهاء من التقاط الفيديو

- ستظهر على الشاشة صورةً ثابتةً تمثل الفيديو الملتقط. ويمتد اسم الصورة عبر أسفل الشاشة مع ثمانية رموز في الجانب الأيمن السفلي.
-  المس لتشغيل الفيديو.
 -  المس لإرسال الفيديو ك رسالة أو بريد إلكتروني أو بواسطة بلوتوث.
 -  المس لتعديل الفيديو.
 -  المس لتعديل إسم الفيديو المحدد.
 -  المس للعودة إلى القائمة السابقة.
 -  المس لحذف الفيديو الذي قمت بالتقاطه لتوّك. وأكد بلمس نعم.
 - يظهر محدد المنظر من جديد.
 -  المس لإنشاء فيديو آخر على الفور. وسيتم حفظ الفيديو الحالي.
 -  المس لعرض معرض الصور وملفات الفيديو المحفوظة.

الكاميرا

إظهار الصورة الملتقطة - اختر اذا كنت تريد عرض الصورة بعد التقاطها.

إخفاء الرموز - اختر رموز إعدادات الكاميرا لإخفائها يدوياً أو تلقائياً.


صوت الغالق - حدّد خياراً من ضمن خيارات صوت الغالق الثلاثة.

شاشة الشبكة - اختر من ضمن إيقاف تشغيل، أو تقاطع بسيط، أو ثلاثية الأجزاء.

تخفيض الضجيج - تساعد هذه الوظيفة على تخفيض الضجيج وتنقية صورة بعد التقاطها.

إعادة تعيين الإعدادات - إعادة تعيين كل إعدادات الكاميرا.

عرض الصور المحفوظة

1 يمكنك الوصول إلى الصور المحفوظة من ضمن وضع الكاميرا، ما عليك سوى لمس  وسيظهر الاستوديو على الشاشة.

الوضع الليلي - يمكنك التقاط صوري بشكل أفضل عبر تحديد تشغيل.

المؤقت الذاتي - يسمح لك المؤقت الذاتي بتعيين فترة تأخير بعد ضغط زر الالتقاط قبل أن تلتقط الكاميرا الصورة. اختر من ضمن إيقاف. **3 ثوان**. **5 ثوان** أو **10 ثوان**. يُعتبر هذا الأمر جيداً لصور المجموعة التي تريد أن تكون جزءاً منها.


الجودة - اختر من ضمن دقيق جداً ودقيق و عادي. بقدر ما تكون الجودة دقيقة بقدر ما تكون الصورة واضحة المعالم ولكن حجم الملف سيكون أكبر. أي أنك ستتمكن من تخزين عدد أقل من الصور في الذاكرة.


وضع العرض - يطبق تأثيرات فنية على الصور. يمكنك إختيار وضع العرض الذي تريده ما بين عادي و ملئ الشاشة.


تحديد موقع التخزين - اختر ما إذا كنت تريد حفظ ملفات الفيديو في ذاكرة الهاتف أو في الذاكرة الخارجية.


الكاميرا

ملاحظة: قد يتم فرض رسم إضافي لدى تنزيل برسائل وسائط متعددة MMS عند التجوال.


 المس للعودة إلى القائمة السابقة.

 المس لحذف الصورة.

 المس لالتقاط صورة أخرى على الفور.

 المس لعرض معرض من الصور المحفوظة.

استخدام الإعدادات المتقدمة

في محدد المنظر المس  لفتح كل خيارات الإعدادات المتقدمة.

تأثير الألوان - اختر اللون الذي تريد تطبيقه على الصورة التي

تلتقطها. هناك أربع درجات ألوان يمكن الاختيار منها إيقاف. أو أسود وأبيض. أو سالب أو بني داكن.

توازن اللون الأبيض - يضمن توازن الأبيض ظهور أي لون أبيض في الفيديو كواقعي. لكي تتمكن الكاميرا من إعداد توازن اللون الأبيض بشكل صحيح. قد تحتاج إلى تحديد شروط الإضاءة. يمكنك الاختيار من: تلقائي. متوهج. مشمس. فلورسنت و غائم.

التقاط صورة سريعة

1 اضغط مطوياً على مفتاح الكاميرا في الجانب الأيمن من الهاتف.

2 سيظهر محدد المنظر على الشاشة.


3 مع الإمساك بالهاتف أفقياً. صوّب العدسة باتجاه موضوع الصورة.

4 ضع الهاتف بحيث يمكنك مشاهدة موضوع الصورة في معاينة الشاشة.

5 اضغط  على جانب الهاتف بقوة لالتقاط الصورة.

بعد التقاط الصورة

تظهر الصورة الملتقطة على الشاشة.

 المس لإرسال الصورة ك رسالة بريد إلكتروني أو بلوتوث. راجع إرسال رسالة. وإرسال واستلام ملفاتك باستخدام بلوتوث.

الرسائل

الألوية - اختر مستوى أولوية برسائل وسائط متعددة MMS.

مدة الصلاحية - اختر فترة تخزين رسائلك في مركز الرسائل.

مدة الشريحة - اختيار مدة ظهور الشرائح على الشاشة.

وضع الإنشاء - اختر وضعاً لإنشاء رسائل وسائط متعددة مقيدة ومحذرة وحررة.

وقت الاستلام - اختيار المدة قبل استلام الرسائل.

مركز الرسائل المتعددة - إدخال تفاصيل مركز الرسائل.

تغيير الإعدادات الأخرى

الرسائل. واختار إعدادات في ثم:




البريد الصوتي - الرسائل. لإضافة خدمة بريد صوتي جديدة، اتصل بمشغل الشبكة للحصول على مزيد من المعلومات حول الخدمة التي يقدمها.

خدمة الرسائل - اختر استلام أو حظر رسائل الخدمة. كما يمكنك تعيين حماية الرسالة وذلك بإنشاء قوائم بالمرسلين الموثوق بهم وغير الموثوق بهم.

خدمة المعلومات - اختر حالة الاستلام، واللغة، والأسماء أخرى.

تغيير إعدادات رسائل الوسائط المتعددة

تكون إعدادات الرسائل في الهاتف GX500 معرّفة مسبقاً بحيث يمكنك إرسال الرسائل على الفور. يمكن تغيير هذه الإعدادات بحسب تفضيلاتك.

المس . وحدد  ثم .

اختر إعدادات ورسالة وسائط

متعددة. يمكنك إدخال تغييرات على:

وضع الاسترداد - اختر شبكة محلية أو شبكة جوال. إذا اخترت يدوي


فستتلقى إعلام برسائل وسائط

متعددة MMS فقط ويمكنك حينئذٍ

أن تقرر ما إذا كنت ترغب في تنزيلها بشكل كامل.

تقرير الاستلام - اختر السماح بتقرير الاستلام و/أو طلبه.

تقرير القراءة - اختر السماح و/أو طلب تقرير رد.

المس  ثم اختر الإعدادات ثم

حدد الرسائل النصية:

مركز الرسائل النصية - أدخل تفاصيل مركز الرسائل.

تقارير استلام - مرر المفتاح إلى اليسار لاستلام تأكيد بأنه تم تسليم رسائلك.

مدة الصلاحية - اختر فترة تخزين رسائلك في مركز الرسائل.

أنواع الرسائل - تحويل الرسالة إلى نص أو صوت أو فاكس أو X.400 أو بريد إلكتروني.

ترميز الحروف - اختر طريقة ترميز الحروف. ويؤثر هذا الأمر على حجم رسائلك وبالتالي على رسوم البيانات.

إرسال النص الطويل ك - اختيار

إرسال النص الطويل كرسائل نصية متعددة SMS أو كرسالة وسائط متعددة MMS.

الرسائل

حافظات الرسائل

ستتعرف على بنية الحافظة المستخدمة في الهاتف GX500.

والتي تفسر نفسها بنفسها.

رسالة جديدة - فتح رسالة جديدة فارغة.

صندوق الوارد - يتم وضع كل الرسائل التي تردك في صندوق الوارد. من هنا يمكنك عرض وحذف وأكثر من ذلك. انظر إدارة الرسائل أدناه للحصول على التفاصيل.

مسودات - إذا لم يكن لديك الوقت الكافي للانتهاء من كتابة رسالة. فيمكنك حفظ ما كتبته حتى الآن هنا.

صندوق الصادر - عبارة عن حافظة تخزين مؤقت للرسائل فيما يكون إرسالها جارياً.

العناصر المرسلة - توضع كل الرسائل التي ترسلها في هذا المجلد. حافظاتي - إنشاء حافظات لتخزين رسائلك.

النماذج - استخدام قائمة بنماذج الرسائل النصية ورسائل الوسائط المتعددة الشائعة الاستخدام.

رموز تعبيرية - إضافة وإدراج رموز تعبيرية لرسائلك.

الإعدادات - تغيير الإعدادات الخاصة بالنص ورسائل الوسائط المتعددة.

تغيير إعدادات الرسائل النصية

تكون إعدادات الرسائل في الهاتف GX500 معرّفة مسبقاً بحيث يمكنك إرسال الرسائل على الفور. يمكن تغيير هذه الإعدادات بحسب تفضيلاتك.


تلميح! للتمرير عبر قائمة الخيارات. المس العنصر المرئي الأخير وقم بتمرير إصبعك إلى أعلى الشاشة. ستتحرك القائمة نحو الأعلى بحيث يصبح عدد أكبر من العناصر مرئياً.

استرداد بريدك الإلكتروني

يمكنك أن تتحقق من وجود رسائل بريد إلكتروني جديدة في حسابك تلقائياً أو يدوياً. للتحقق يدوياً:

1 المس  ثم حدد .

2 المس صندوق البريد.

3 المس الحساب الذي تريد استخدامه ثم .

4 اختر استرداد فيتصل هاتفك GX500 بحساب بريدك الإلكتروني ويسترد رسائلك الجديدة.

تغيير إعدادات البريد الإلكتروني

يمكنك تغيير إعدادات البريد الإلكتروني وفق تفضيلاتك الخاصة.

1 المس  ثم حدد .

2 المس إعدادات و بريد إلكتروني ثم يمكنك تكييف الإعدادات التالية:

السماح بالرد على البريد

الإلكتروني - اختر السماح بإرسال رسائل "تأكيد القراءة".

طلب الرد على البريد الإلكتروني - اختر ما إذا كان يجب طلب رسائل تأكيد القراءة.

الفاصل الزمني للاسترداد - اختر مدى تكرار قيام GX500 بالتحقق من وجود رسائل بريد إلكتروني جديدة.

عدد الرسائل لاستردادها - اختر عدد رسائل البريد الإلكتروني التي تود استردادها في آن واحد.

تضمين الرسالة في إعادة التوجيه والرد - اختر تضمين الرسالة الأصلية في ردك.

تضمين الرسالة في إعادة التوجيه والرد - اختر تضمين الرسالة الأصلية في ردك.

استرداد تلقائي أثناء التجوال - اختر ما إذا كنت ترغب في استرداد رسائلك تلقائياً.


إعلام ببيد إلكتروني جديد - اختر ما إذا كان يجب تنبيهك عند وصول رسائل بريد إلكتروني جديدة.

التوقيع - قم بإنشاء توقيعاً على البريد الإلكتروني وتشغيل هذه الميزة.

الأولوية - اختر مستوى الأولوية لرسائل البريد الإلكتروني.

الرسائل

لوحة المفاتيح

في وضع لوحة المفاتيح تنقلب الشاشة إلى الوضع الأفقي وتظهر لوحة مفاتيح كاملة على الشاشة. ما عليك إلا لمس كل حرف لكتابة رسالتك واضغط:  للتبديل إلى الأحرف الكبيرة.

التعرّف على الكتابة اليدوية


في وضع الكتابة اليدوية ما عليك إلا أن تكتب على الشاشة وسيقوم GX500 بتحويل كتابتك اليدوية إلى رسالتك. حدد شاشة الكتابة اليدوية. صندوق الكتابة اليدوية أو صندوق الكتابة اليدوية المزدوج وفق طريقة العرض المفضلة لديك.


تلميح! قد تجد أنه من الأسهل استخدام إبرة الفونوغراف في هذا الوضع. يرجى أن تتذكر أنه عليك الضغط بشكل خفيف وذلك لحماية الشاشة من أي ضرر قد يلحق بها.

يترجم التعرّف على الكتابة اليدوية حركات إبرة الفونوغراف إلى أحرف. أو أرقام أو أحرف أخرى. ثم يعرض هذه الأحرف على شكل نص. يكون التعرّف على الكتابة اليدوية نشطاً فقط حيث يمكن إدخال نص.

إعداد البريد الإلكتروني

يمكنك أن تبقى على تواصل أثناء التنقل من خلال استخدام البريد الإلكتروني على الهاتف GX500. فعملية إعداد حساب بريد إلكتروني POP3 أو IMAP4 تعتبر عملية بسيطة وسهلة.

1 المس  ثم حدد علامة التبويب الاتصال.

2 حدد  ثم مرر القائمة إلى الإعدادات.

3 المس بريد إلكتروني ثم حسابات البريد الإلكتروني.

4 المس إضافة حساب.

5 سيساعدك معالج الإعداد على إعداد إعدادات بريدك الإلكتروني.


6 يمكنك التحقق من الإعدادات وتعديلها بواسطة تحديد حساب في القائمة. كما يمكنك التحقق من الإعدادات الإضافية التي تمت تعيّناتها تلقائياً عندما أنشأت الحساب.

7 يمكنك أن تغيّر حساب البريد الإلكتروني الافتراضي بواسطة لمس تنشيط.


إدخال النص

هناك خمس طرق لإدخال نص:


لوحة المفاتيح الأفقية و لوحة المفاتيح الرأسية و شاشة الكتابة اليدوية و صندوق الكتابة اليدوية و صندوق الكتابة المزدوج.


يمكنك اختيار أسلوب الإدخال بلمس  وأسلوب الإدخال.


اضغط على الشاشة مرة واحدة فتظهر لوحة المفاتيح.

 T9 المس لبدء تشغيل نص T9

النبؤي.

 بإمكانك اختيار لغات الكتابة.

 123 اضغط لتغيير الأرقام والرموز و لوحة مفاتيح النص.

استخدم  للتمرير عبر مختلف أنواع لوحات المفاتيح في كل وضع من أوضاع إدخال النص (مثلاً. الأحرف الكبيرة أو الأحرف الصغيرة).

T9 التنبؤي

يستخدم وضع T9 قاموساً مضمناً للتعرف على الكلمات التي تكتبها استناداً إلى تسلسل المفاتيح التي تلمسها. ما عليك إلا لمس مفتاح الرقم المقترن بالحرف الذي تريد إدخاله. وسيتوقع القاموس الكلمة التي تود استخدامها.

اضغط مثلاً 8, 3, 5, 3, 7, 4, 6, 3 لكتابة 'telephone'.

دليل abc

في وضع abc عليك لمس المفتاح بشكل متكرر لإدخال حرف. فلكتابه كلمة 'hello' مثلاً، المس 4 مرتين. و 3 مرتين. و 5 ثلاث مرات. و 5 ثلاث مرات مجدداً، ثم 6 ثلاث مرات.

الرسائل

الرسائل

يجمع الهاتف GX500 ميزات إرسال رسائل نصية SMS ورسائل وسائط متعددة MMS وبريد إلكتروني في قائمة واحدة بديهية وسهلة الاستخدام.

هناك طريقتان لدخول مركز الرسائل:

1 **المس**  في شاشة وضع الانتظار.

2 **المس**  في شاشة وضع الانتظار. ثم حدد اتصال واختر رسالة جديدة .

إرسال رسالة

1 **المس رسالة جديدة.** ثم حدد الرسالة لفتح رسالة فارغة.


2 **من هنا يمكنك إرسال رسائل نصية SMS ورسائل وسائط متعددة MMS.** لإرسال رسالة بريد إلكتروني. **المس**  في شاشة وضع الانتظار. ثم حدد علامة التبويب اتصال و **البريد الإلكتروني.**


3 **المس إدراج.** لإضافة صورة أو فيديو أو صوت أو نموذج.

4 **المس إلى** في أعلى الشاشة لإدخال

رقم المستلم. أو المس رمز البحث لفتح الأسماء. يمكنك إضافة أسماء عديدة. **المس إرسال** عندما تصبح جاهزًا.

ملاحظة: يمكنك إرسال رسالة نصية SMS للعديد من المستخدمين في كل مرة. انقر فوق رمز البحث عن أسماء وحدد متعدد من الخيارات حيث يمكن أن يحدد المستخدم/ يلغي تحديد أسماء لإرسال رسالة. لإرسال رسالة نصية SMS لمجموعة معيّنة من الأسماء انقر فوق رمز البحث عن الأسماء وحدد البحث حسب المجموعة بعد إعداد رسالة نصية SMS.

 **تحذير:** سيتم فرض رسم عليك لكل رسالة نصية تتألف من صفحة واحدة لكل شخص تُرسل الرسالة إليه.

 **تحذير:** إذا تمت إضافة صورة أو فيديو أو صوت إلى إعداد رسالة نصية SMS فسيتم تحويلها تلقائيًا إلى رسالة وسائط متعددة MMS وسيُفرض رسم عليك وفقاً لذلك.

إستعادة الأسماء - إستعادة
الأسماء الخاصة بك من الذاكرة
الخارجية. هذا الخيار يتطلب ذاكرة
خارجية.

مسح الأسماء - مسح جميع
الأسماء الخاصة بك. إختار بين
الهاتف و SIM والمس "نعم"
إذا كنت متأكد أنك تريد مسح
الأسماء الخاصة بك.

عرض المعلومات

1 من شاشة وضع الانتظار المس
.

2 المس الأسماء. ثم المعلومات.

3 من هنا يمكنك عرض أرقام
الاتصال بالخدمة. الرقم الخاص. و
معلومات الذاكرة. (كمية مساحة
الذاكرة المتوفرة) و بطاقة العمل
الخاصة بي.

تلميح! إذا كنت بحاجة إلى إضافة
بطاقة عمل لنفسك. فحدد بطاقة
العمل الخاصة بي وأدخل كل
التفاصيل المتعلقة بك كما لو كان
الأمر يتعلق بأي جهة اتصال أخرى.
المس حفظ للانتهاء.

نسخ - قم بنسخ الأسماء بين
بطاقات SIM (SIM1 أو SIM2)
والهاتف. اختر القيام بنسخ كل
جهة اتصال على حدة. أو نسخ
كل الجهات دفعةً واحدة. إذا
اخترت نسخ كل جهة على حدة.
فستحتاج إلى تحديد كل جهة
لنسخ الأسماء الواحدة بعد الأخرى.
نقل - يعمل هذا الأمر بالطريقة
نفسها التي يعمل بها النسخ.
غير أن الأسماء ستُحفظ فقط في
الموقع الذي تم نقلها إليه. لذا. إذا
نقلت جهة اتصال من بطاقة SIM
إلى الهاتف فسيتم حذفها من
ذاكرة بطاقة SIM.

إرسال كل الأسماء عبر بلوتوث -
قم بإرسال كل الأسماء إلى جهاز
آخر بواسطة بلوتوث. ستتم
مطالبتك ببدء تشغيل بلوتوث إذا
قمت بتحديد هذا الخيار.


نسخ احتياطي للأسماء - قم
بنسخ الأسماء الخاصة بك إلى
ذاكرة خارجية. هذا الخيار يتطلب
ذاكرة خارجية.

الأسماء

تغيير إعدادات الأسماء

يمكنك تكييف إعدادات الأسماء بحيث يتناسب الأسماء لديك مع تفضيلاتك.



تلميح! للتمرير عبر قائمة الخيارات. المس العنصر المرئي الأخير وقم بتمرير إصبعك إلى أعلى الشاشة. ستتحرك القائمة نحو الأعلى بحيث يصبح عدد أكبر من العناصر مرئياً.

- 1 من شاشة وضع الانتظار المس 
- 2 المس الأسماء. ثم الإعدادات.
- 3 من هنا يمكنك تنظيم الإعدادات التالية:
إعدادات قائمة الأسماء - اختر لضبط عرض اسم وإعدادات الأمر السريع.

7 كما يمكنك أيضاً إضافة نغمة رنين. وعيد ميلاد. وذكرى. وصفحة رئيسية. وعنوان منزل. واسم شركة. ومهنة. وعنوان شركة و مذكرة.

8 المس حفظ لحفظ جهة الاتصال.

إنشاء مجموعة


- 1 المس .
 - 2 المس الأسماء ثم مجموعات.
 - 3 المس .
 - 4 حدد إضافة مجموعة.
 - 5 أدخل اسماً للمجموعة الجديدة. يمكنك أيضاً أن تحدّد نغمة رنين خاصة بالمجموعة.
 - 6 المس حفظ.
- ملاحظة: إذا قمت بحذف مجموعة. فلن تفقد الأسماء التي تم تعيينها إلى تلك المجموعة. بل ستبقى موجودة في دفتر عناوينك.



الأسماء

البحث عن جهة اتصال

هناك طريقتان للبحث عن جهة اتصال:

في شاشة وضع الانتظار

- 1 في شاشة وضع الانتظار المس  لفتح الأسماء. حدد من القائمة جهة الاتصال التي تريد الاتصال بها.

- 2 المس  أو اضغط على  مفتاح التشغيل لبدء المكالمة.

في القائمة الرئيسية


- 1 المس  حدد .

- 2 المس الأسماء ثم بحث.

- 3 ستشاهد قائمة بالأسماء. وعندما تكتب الحرف الأول من اسم جهة الاتصال. تنتقل اللانحة إلى منطقة الجهات التي تبدأ بهذا الحرف في القائمة.

تلميح! يتم عرض لوحة المفاتيح الأبجدية طالما تقوم بالضغط على حقل البحث عن اسم.

إضافة جهة اتصال جديدة

- 1 في شاشة وضع الانتظار المس  والمس إضافة جهة اتصال.

- 2 اختر ما إذا كنت تريد حفظ جهة الاتصال في الهاتف أو SIM. (SIM 1/SIM 2).

- 3 أدخل الاسمين الأول والأخير لجهة الاتصال الجديدة. من غير الضروري إدخال الاسمين. ولكن يجب عليك إدخال أحدهما.

- 4 يمكنك أن تدخل حتى خمسة أرقام مختلفة لجهة اتصال واحدة. يتميز كل إدخال بنوع معين مسبقاً خاص بـ المحمول والمنزل والمكتب وجهاز الاستدعاء والفاكس وعام. عندما تنتهي. المس إغلاق.

- 5 أضف عنوان بريد إلكتروني.

- 6 قم بتعيين جهة الاتصال إلى مجموعة أو أكثر. اختر من ضمن بلا مجموعة، أو العائلة، أو الأصدقاء، أو الزملاء، أو المدرسة أو الأشخاص المهمون جداً.

المكالمات

معاودة الاتصال التلقائي - مرر
المفتاح إلى اليسار لبدء
التشغيل أو إلى اليمين ل إيقاف
التشغيل.

وضع الرد - اختر ما إذا كنت تريد
الرد على الهاتف باستخدام مفتاح
الإرسال أو أي مفتاح.

منبه الدقائق - مرر المفتاح إلى
اليسار لبدء تشغيل سماع نغمة
كل دقيقة خلال فترة المكالمة.

وضع الرد بلوتوث - حدد لا يدوي
لتنمكّن من الرد على مكالمة
باستخدام سماعة رأس بلوتوث. أو
حدد هاتف للضغط على مفتاح
موجود على الهاتف للرد على
مكالمة.

حفظ رقم جديد - حدد نعم
لحفظ رقم جديد.

تغيير إعدادات المكالمات العام

1 المس **☰** حدد إعدادات ثم اختر
إعدادات المكالمات.

2 المس إعداد عام. من هنا يمكنك
تعديل إعدادات الخيارات التالية:

رفض المكالمة - مرر المفتاح
إلى بدء التشغيل لتحديد قائمة
الرفض. يمكنك لمس مربع النص
للاختيار من كل المكالمات. أو من
جهات اتصال معيّنة أو مجموعات.
أو من أرقام غير مسجلة (تلك
الأرقام غير الموجودة في الأسماء
أو بلا هوية متصل). المس حفظ
لتغيير الضبط.

إرسال رقمي - اختر ما إذا كنت
ترغب في أن يظهر رقمك عند
اتصالك بأحدهم.

3 اختر أحد الخيارات الستة أو كلها:

كل الصادرة

المكالمات الدولية الصادرة

المكالمات الدولية الصادرة

باستثناء المحلية

كل الواردة

الواردة عند السفر

إلغاء تنشيط الكل

4 أدخل كلمة مرور حظر المكالمات.

تحقق من توفر الخدمة مع مشغل

الشبكة.

تلميح! اختر أرقام اتصال محددة من إعدادات المكالمات لتنشغيل وتجميع قائمة بالأرقام التي يمكن الاتصال بها من هاتفك. ستحتاج إلى الحصول على رمز PIN2 من المشغل. وحدها الأرقام المضمنة في قائمة الاتصال المحدد هي الأرقام التي يمكن طلبها من هاتفك.

استخدام تحويل المكالمات

1 المس **☎** حدد إعدادات ثم اختر إعدادات المكالمات.

2 المس تحويل المكالمات.

3 اختر ما إذا كنت تريد أن يتم تحويل كل المكالمات. عندما يكون الخط مشغولاً، أو عند عدم الرد، أو عندما لا يكون الوصول إليك ممكناً.

4 أدخل الرقم الذي ترغب في أن يتم التحويل إليه.

5 المس طلب للتنشيط.

ملاحظة: يتم فرض رسوم على تحويل المكالمات. يرجى الاتصال بموفر الشبكة للحصول على تفاصيل.

تلميح! إيقاف تشغيل كل عمليات تحويل المكالمات. اختر إلغاء تنشيط الكل من قائمة تحويل المكالمات.

استخدام حظر المكالمات

1 المس **☎** حدد إعدادات ثم اختر إعدادات المكالمات.


2 المس حظر المكالمات.

المكالمات

تلميح! يمكنك دمج مكالماتك عبر تحديد قبول ثم انضمام. تحقق من اعتماد مشغل الشبكة للمكالمات الجماعية.

ملاحظة: سيُفرض عليك رسم مقابل كل مكالمة تجريها.

عرض سجلات المكالمات


المس  وحدد اتصال واضغط على سجلات المكالمات. اختر عرض ما يلي:

كل المكالمات - عرض قائمة كاملة تتضمن كل المكالمات الصادرة والمكالمات المستلمة والمكالمات التي لم يرد عليها.

المكالمات الصادرة - عرض قائمة بكل الأرقام التي طلبتها.


المكالمات المستلمة - عرض قائمة بكل الأرقام التي اتصلت بك.

مكالمات لم يرد عليها - عرض قائمة بكل المكالمات التي لم ترد عليها.

تلميح! من أي سجل مكالمات المس  وحذف الكل لحذف كل العناصر المسجلة.

4 يفتح الأسماء. حدد جهة الاتصال التي تريد تعيينها إلى ذلك الرقم وذلك بلمس رقم هاتفها مرة واحدة. للبحث عن جهة اتصال. اضغط خانة حقل البحث وأدخل الحرف الأول من اسم جهة الاتصال المطلوبة.


إجراء مكالمة ثانية


1 خلال المكالمة الأولية. المس  وقم بكتابة الرقم الذي تود الاتصال به.

2 اطلب الرقم أو ابحث عن الأسماء.

3 اضغط على  لتوصيل المكالمة.




4 يتم عرض المكالمتين معاً على شاشة المكالمة. ويتم إفعال المكالمة الأولية وبوضع المتصل في حالة الانتظار.


5 للتبديل بين المكالمات. المس  ثم اختر تبادل المكالمات أو اضغط على رقم المكالمة قيد الانتظار.

6 لإنهاء إحدى المكالمتين أو كلاهما. اضغط  ثم حدد إنهاء يتبعها الكل. أو قيد الانتظار أو نشط.



المكالمات

إجراء مكالمة






- 1 المس  لفتح لوحة المفاتيح.
- 2 أدخل الرقم باستخدام لوحة المفاتيح. لحذف رقم، المس مفتاح المسح.
- 3 اضغط على  مفتاح المشغل أو المس مكالمة لبدء المكالمة.
- 4 لإنهاء المكالمة اضغط على  مفتاح التشغيل.

تلميح! لإدخال + لإجراء مكالمة دولية، اضغط باستمرار .



إجراء مكالمة من الأسماء

- 1 في شاشة وضع الانتظار المس  لفتح الأسماء.
- 2 أدخل الأحرف القليلة الأولى من جهة الاتصال التي ترغب في الاتصال بها في الجزء العلوي من الشاشة باستخدام لوحة اللمس.
- 3 في القائمة التي تمت تصفيتها، المس جهة الاتصال التي ترغب في الاتصال بها وحدد الرقم الذي تريد استخدامه إذا توفر لديك أكثر من رقم واحد محفوظ.
- 4 المس .

الرد على مكالمة ورفضها

- عندما يرن هاتفك اضغط مفتاح المشغل  أو المس  للرد على المكالمة.
- اضغط  لكتم الرنين. يُعتبر هذا الأمر جيداً إذا كنت قد نسيت تغيير وضع الهاتف إلى صامت أثناء حضور اجتماع ما.
- اضغط مفتاح المشغل  أو المس  لرفض مكالمة واردة.

الاتصال السريع



- يمكنك تعيين جهة اتصال تطلبها بشكل متكرر إلى رقم اتصال سريع.
- 1 في الشاشة الرئيسية المس  لفتح الأسماء.
 - 2 المس  واختر الاتصالات السريعة.
 - 3 يتم مسبقاً تعيين بريدك الصوتي إلى رقم الاتصال السريع 1. ولا يمكنك تغييره، المس أي رقم آخر لتعيينه كجهة اتصال سريع.

شاشة وضع الانتظار

تغيير الحالة من شريط الحالة

المس شريط الحالة لفتح ملخص الحالة. يعرض الوقت الحالي والشبكة والبطارية وذاكرة الهاتف والذاكرة الخارجية والوضع المستخدم للهاتف وخصائص SIM المستخدمة (SIM1/SIM2) وحالة كل من بلوتوث و Wi-Fi. يمكنك هنا تعيين نوع ملف التعريف. وتشغيل/ إيقاف MP3 مؤقتًا. وتنشيط/إلغاء تنشيط تشغيل بلوتوث.

استخدام وظيفة تعدد المهام

اضغط على مفتاح المشغل الخاص بتعدد المهام  لفتح قائمة تعدد المهام. يمكنك من هنا عرض كل التطبيقات الجارية تشغيلها والوصول إليها بواسطة لمسة واحدة. عند وجود تطبيق يجري تشغيله في الخلفية (لعبة أو راديو FM مثلاً). يظهر  في شريط الحالة.

الوصف	الرمز
الوضع المخصص قيد الاستخدام	
الوضع عادي قيد الاستخدام	
الوضع خارجي قيد الاستخدام	
الوضع صامت قيد الاستخدام	
الوضع سماعة الرأس قيد الاستخدام	
المكالمات محوِّلة	
EDGE قيد الاستخدام	
التجوال	
وضع الرحلات الجوية قيد التشغيل	
بلوتوث نشط	
تشغيل الموسيقى الخلفية BGM	
إيقاف مؤقت للموسيقى الخلفية BGM	
تم تمكين بطاقة الذاكرة لاستخدامها	
Wi-Fi	

شريط الحالة

يستخدم شريط الحالة رموزاً مختلفة للإشارة إلى أمور مثل قوة الإشارة والرسائل الجديدة وفترة عمل البطارية. وكذلك لإعلامك ما إذا كان بلوتوث أو GPRS نشطاً. يفسر الجدول التالي معنى الرموز التي قد تشاهدها على شريط الحالة.

الوصف	الرمز
تعدد المهام	
قوة إشارة الشبكة (يختلف عدد الأشرطة)	
إشارة الشبكة غير متوفرة	
فترة العمل المتبقية للبطارية	
البطارية فارغة	
رسالة نصية جديدة	
رسالة صوتية جديدة	
صندوق الوارد للرسائل ممتلئ	
فشل إرسال الرسالة	
فشل إرسال رسالة الوسائط المتعددة	
تم تعيين منبه	

شاشة وضع الانتظار

المفاتيح السريعة

توفر المفاتيح السريعة وصولاً سهلاً بمجرد لمسة واحدة إلى أكثر الوظائف استخداماً.

المس لفتح الأسماء. للبحث عن الرقم الذي تريد الاتصال به، أدخل اسم جهة الاتصال في أعلى الشاشة مستخدماً لوحة اللمس. يمكنك إنشاء جهات اتصال جديدة وتعديل الأسماء الموجودة.



المس لإحضار لوحة الطلب بواسطة اللمس لإجراء مكالمة، أدخل الرقم كما لو كنت تستخدم لوحة مفاتيح عادية ثم المس **مكالمة** أو اضغط على **مفتاح المشغل**.




المس لفتح القائمة العلوية الكاملة التي تنقسم إلى أربع قوائم فرعية عمودية. المس التويب لكل قائمة فرعية لمشاهدة المزيد من الخيارات.




المس للوصول إلى قائمة خيارات الرسائل. من هنا يمكنك إنشاء رسائل نصية SMS ورسائل وسائط متعددة MMS جديدة، أو عرض حافظة الرسائل.



شاشة وضع الانتظار

- استخدم رأس إصبعك للمس الخيار المطلوب. احتس من عدم لمس أي مفاتيح أخرى حوله.
 - عندما يكون ضوء الشاشة الخلفي متوقفاً عن التشغيل. اضغط مفتاح إقفال/إلغاء القفل في الجانب الأيمن من الهاتف لاستعادة الشاشة الرئيسية.
 - لا تضع غطاءً أو غلافاً خارجياً على الهاتف. لن تعمل شاشة للمس عند تغطيتها بأي مادة.
 - هناك نوعان من شاشة الانتظار انقر إلى اليسار أو إلى اليمين لتغيير نوع شاشة الخمول الموجودة على شاشة وضع الانتظار.
- 1 عنصر واجهة الاستخدام شامل - عندما تلمس  تظهر لوحة عنصر واجهة الاستخدام النقال.
 - 2 اتصال سريع شامل - عندما تلمس  تظهر قائمة الاتصال السريع. يمكنك أن تقوم بسحب وإفلات ما تحتاج إليه فوراً في كلا نوعي الخمول.
- في شاشة وضع الانتظار يمكنك الوصول إلى كل خيارات القوائم. وإجراء مكالمة سريعة وعرض حالة الهاتف. بالإضافة إلى عدة أمور أخرى.
- ### تلميح شاشة للمس
- تعتبر الشاشة الرئيسية أيضاً مكاناً جيداً لتعتاد على شاشة للمس. لتحديد عنصر. المس الرمز بدقة. سيهتز الهاتف GX500 بعض الشيء عندما يتعرف على لمسك لخيار ما. للتمرير عبر القوائم المس العنصر الأخير المرئي وقم بإزلاق إصبعك إلى أعلى الشاشة. ستتحرك القائمة نحو الأعلى بحيث يصبح عدد أكبر من العناصر مرئياً.
- لا حاجة إلى الضغط بقوة. فشاشة للمس حساسة بشكل كافٍ يتيح لها التعرف على لمسة خفيفة ولكن ثابتة.

خريطة القوائم

المس  على شاشة وضع الانتظار لفتح قائمة علوية. من هنا يمكنك الوصول إلى المزيد من القوائم: الاتصال، والترفيه، والأدوات المساعدة والإعدادات.

الترفيه



الكاميرا
الاستوديو
الموسيقى
أشياء
الألعاب والتطبيقات
تطبيقات الهواتف
Pocket Apps
راديو FM
كاميرا فيديو

اتصال



الأسماء
سجلات المكالمات
الرسائل
البريد الإلكتروني
اتصال
الشبكات الاجتماعية
الاتصالات السريعة
رسالة جديدة

الإعدادات



ضوابط بطاقة SIM
المزوجة
الأوضاع
إعدادات الشاشة
إعدادات الهاتف
إعدادات المكالمات
بلوتوث
التوصيل
Wi-Fi

الأدوات المساعدة



المتصفح
Google
تنبيهات
منظم المواعيد
مذكرة
مسجل الصوت
الأدوات
لوحة الرسم


بطاقة الذاكرة

تركيب بطاقة ذاكرة

يمكنك توسيع مساحة الذاكرة المتوفرة على هاتفك باستخدام بطاقة ذاكرة MicroSD.


ملاحظة: بطاقة الذاكرة هي عبارة عن ملحق اختياري.

- 1 افتح غطاء فتحة بطاقة الذاكرة الموجود على حافة الهاتف اليمنى.
- 2 حرّك بطاقة الذاكرة إلى داخل الفتحة. حتى تستقر في مكانها.
- 3 قم باستبدال الغطاء.



تنسيق بطاقة الذاكرة

قد تكون بطاقة الذاكرة مهياً أصلاً. إذا لم تكن بطاقة الذاكرة مهياً، فعليكتهيئتها قبل أن تبدأ باستخدامها.

- 1 في شاشة وضع الانتظار حدد  في شاشة وضع الانتظار حدد ثم قم بالتمرير عبر علامة التبويب الإعدادات واختر إعدادات الهاتف.
 - 2 المس معلومات الذاكرة ثم اختر ذاكرة خارجية.
 - 3 المس تهيئة ثم أكد خيارك.
 - 4 أدخل كلمة المرور. إذا كان قد تم تعيينها، فتم تهيئة بطاقتك وتصبح جاهزة للاستخدام.
- ملاحظة:** إذا تضمّنت بطاقة الذاكرة محتوى موجوداً، فسيتم تصنيفه بشكل تلقائي في الحافظة الصحيحة، فسيتم مثلًا تخزين ملفات الفيديو في حافظة مقاطع الفيديو.

تثبيت بطاقة SIM و البطارية

6 شحن الهاتف

ارفع غطاء مقبس الشاحن الموجود على جانب GX500. أدخل الشاحن وقم بتوصيله بمقبس كهربائي رئيسي. يجب أن يتم شحن الهاتف GX500 حتى تظهر رسالة على الشاشة تفيد بأن "البطارية ممتلئة".



4 تثبيت البطارية

أدخل أسفل البطارية أولاً في حافة حجرة البطارية السفلى. تأكد من محاذاة موصلات البطارية مع الأطراف الموجودة على الهاتف. اضغط جهة البطارية العليا إلى الأسفل حتى تستقر في مكانها.



5 تثبيت غطاء البطارية

حرك غطاء البطارية نحو الجزء العلوي من الهاتف حتى يستقر في مكانه.


تثبيت بطاقة SIM و البطارية

3 تركيب بطاقة SIM

قم بتمرير بطاقة SIM إلى داخل حاملها وتأكد من كون ناحية الموصلات الذهبية الموجودة على البطاقة موجهة نحو الأسفل. لإخراج بطاقة SIM، اسحبها بلطف في الاتجاه المعاكس.



تحذير ⚠



تأكد من أنه تم اقتصاص بطاقة SIM بالطريقة الصحيحة قبل إدخالها في الحامل.

1 نزع غطاء البطارية

حرك غطاء البطارية نحو أسفل الهاتف وبعيداً عنه.



2 إخراج البطارية


بواسطة الفتحة الموجودة في الأعلى، وارفع البطارية من حجرتها.



⚠ تحذير: لا تستخدم أظافرك عند إخراج البطارية.

⚠ تحذير: لا تخرج البطارية عندما يكون الهاتف قيد التشغيل. إذ قد يؤدي ذلك إلى إلحاق الضرر بالهاتف.

نظرة على الهاتف وهو مفتوح





التعرّف على الهاتف الخاص بك



مفتاح الاتصال
يقوم بطلب رقم هاتف والإجابة على المكالمات الواردة.

مفتاح تعدد المهام

مفتاح التشغيل/إيقاف التشغيل
يقوم بإنهاء مكالمة أو رفضها.
تشغيل/إيقاف تشغيل الهاتف.
اضغط مرة واحدة للعودة إلى شاشة وضع الانتظار.

⚠ تحذيرة: قد يؤدي وضع شيء ثقيل الوزن على الهاتف أو الجلوس عليه عند وجوده في جيبك إلى إلحاق ضرر بوظيفة شاشة LCD وشاشة اللمس.

الأطفال

ضع الهاتف في مكان آمن بعيداً عن متناول الأطفال. فهو يحتوي على أجزاء صغيرة قد تنفصل عنه وتتسبب بالاختناق.

مكالمات الطوارئ

قد لا تكون مكالمات الطوارئ متوفرةً ضمن شبكات الهاتف المحمول كافة. وبالتالي عليك ألا تعتمد فقط على هاتفك المحمول لمكالمات الطوارئ. راجع موافق الخدمة المحلي لديك لمزيد من المعلومات.

معلومات حول البطارية والعناية بها

- أعد شحن البطارية إذا كنت قد توقفت عن استخدامها لفترة وقت طويلة وذلك لزيادة صلاحية استعمالها إلى الحد الأقصى.
 - لا تعرّض شاحن البطارية لنور الشمس المباشر أو لا تستخدمه في أماكن عالية الرطوبة، مثل الحمام.
 - لا تترك البطارية في الأماكن الساخنة أو الباردة. فقد يؤدي ذلك إلى التراجع في أداء البطارية.
 - هناك خطر انفجار، إذا تم استبدال البطارية ببطارية أخرى من نوع غير صحيح.
 - تخلص من البطاريات المستعملة طبقاً لتعليمات الشركة المصنّعة. يرجى إعادة التصنيع عندما يكون ذلك ممكناً. لا تتخلص منها كمهملات منزلية.
 - إذا كنت بحاجة إلى استبدال البطارية، فقم بأخذها إلى أقرب فرع للصيانة أو وكيل معتمد من LG Electronics للمساعدة.
 - قم دائماً بفصل الشاحن عن المقبس بعد شحن الهاتف بالكامل لتفادي استهلاك الشاحن طاقة غير ضرورية.
 - إن عمر البطارية الفعلي يتوقف على تكوين الشبكة والأسماء المنتج والنقوش المستخدمة والبطارية والأوضاع البيئية.
- لست بحاجة إلى إفراغ البطارية بشكل كامل قبل إعادة شحنها. وبخلاف أنظمة البطاريات الأخرى، ليس هناك من تأثير للذاكرة يمكنه تخفيض أداء البطارية.
 - استخدم بطاريات وشواحن LG فقط. فشواحن LG مصمّمة لإطالة فترة عمل البطارية.
 - لا تعمل على تفكيك البطارية أو تعريضها لحدوث تماس.
 - حافظ على نظافة الموصلات المعدنية الموجودة على البطارية.
 - استبدل البطارية عندما يصبح أداؤها غير مقبول. قد يعاد شحن البطارية مئات المرات قبل أن تصبح بحاجة إلى الاستبدال.

إرشادات لاستخدام آمن و فعال

• قد يؤثر الحد الأدنى من التشويش على أجهزة التلفزيون والراديو والكمبيوتر الشخصي.

السلامة على الطرقات

تحقق من القوانين والأنظمة المتعلقة باستخدام الهواتف المحمولة في المناطق أثناء القيادة.

• لا تستخدم هاتفاً محمولاً باليد أثناء القيادة.

• عليك دوماً تركيز كامل الانتباه على القيادة.

• استخدم مجموعة أدوات لا يدوية، إذا كانت متوفرة.

• توقّف عند جانب الطريق قبل إجراء مكالمة أو الإجابة على المكالمة إذا كانت ظروف القيادة تستدعي ذلك.

• قد تؤثر طاقة RF على بعض الأنظمة الإلكترونية في المركبة مثل الاستيريو ومعدات السلامة في السيارة.

• عندما تكون المركبة مزودة بكيس هوائي، عليك عدم إعاقة عمله بواسطة تجهيزات لاسلكية مثبتة أو محمولة. فقد يبطل ذلك عمل الكيس الهوائي أو قد يتسبب ذلك بإصابات خطيرة بسبب أداء غير صحيح.

• إذا كنت تستمع إلى الموسيقى أثناء تنقلك، فتأكد من كون مستوى الصوت معقولاً بحيث تكون مدركاً لما يحيط بك، هذا الأمر يعتبر ملزماً خاصة بالقرب من الطرقات.

تجنّب إلحاق الضرر بسمّك
قد يؤدي تعرّضك إلى أصوات عالية لفترات وقت طويلة إلى إلحاق الضرر بسمّك، ونوصي بالتالي بالأتي تقوم بتشغيل الهاتف أو إيقافه عندما يكون قريباً من أذنيك. كما نوصي بضبط مستوى صوت معقول للموسيقى والمكالمات.

مناطق التفجير

لا تستخدم الهاتف في الأماكن حيث تكون عمليات التفجير جارية، التزم بالقيود، واتبع الأنظمة أو القوانين.

مناطق تتسم أجواؤها بالقابلية

للانفجار

• لا تستخدم الهاتف في نقطة إعادة التزويد بالوقود.
• لا تستخدم الهاتف بالقرب من الوقود أو المواد الكيميائية.
• لا تقم بنقل أو تخزين غاز أو سائل قابل للاشتعال أو متفجرات في حجرة السيارة نفسها التي تحتوي على الهاتف المحمول وملحقاته.

في الطائرة

باستطاعة الأجهزة اللاسلكية أن تتسبب بحدوث تشويش في الطائرة.
• أوقف تشغيل الهاتف المحمول قبل الصعود على متن أي طائرة.
• لا تستعمله على الأرض من دون الحصول على إذن من قِبل طاقم الطائرة.

- لا تعمل بتفكيك الوحدة. اعمل على نقل الوحدة إلى تقني صيانة مؤهل عندما تكون بحاجة إلى تنفيذ عمل ما عليها لإصلاحها. قد تتضمن الإصلاحات المشمولة بالضمان. وفقاً لـ LG. لوحات أو قطع الغيار سواء أكانت جديدة أو مجددة على أن تتميز بوظائف موازية لوظائف الأجزاء التي تم استبدالها.
 - ضع هذه الوحدة في مكان بعيد عن الأجهزة الإلكترونية مثل أجهزة التلفزيون، والرايو، وأجهزة الكمبيوتر الشخصي.
 - يجب إبقاء الوحدة بعيدة عن مصادر السخونة مثل الأجهزة المشعة للحرارة أو الأفران المنزلية.
 - تجنب إسقاط الوحدة.
 - لا تعرّض هذه الوحدة للاهتزاز الميكانيكي أو الصدمات.
 - أوقف تشغيل الهاتف في أي منطقة حيث القوانين الخاصة بتطالبيك بذلك. على سبيل المثال، لا تستخدم الهاتف في المستشفيات إذ قد يؤثر على المعدات الطبية الحساسة.
 - لا تمسك الهاتف بيدين رطبتين فيما يكون شحنه جار. فقد يتسبب هذا الأمر بحدوث صدمة كهربائية أو إلحاق ضرر بالغ بالهاتف.
 - يجب عدم شحن الهاتف بالقرب من مواد قابلة للاشتعال إذ قد يصبح الهاتف ساخناً وقد يؤدي ذلك إلى اندلاع حريق.
 - استخدم قطعة قماش جافة لتنظيف الوحدة من الخارج (لا تستخدم مواد مذيبة كالبنزين أو التينر أو الكحول).
 - لا تشحن الهاتف عندما يكون موضوعاً على أثاث ناعم.
 - يجب أن يتم شحن الهاتف في منطقة ذات تهوية جيدة.
 - لا تعرّض هذه الوحدة للدخان أو الغبار الزائد.
 - لا تضع الهاتف بالقرب من بطاقات الائتمان أو تذاكر النقل؛ فقد يؤثر ذلك على المعلومات الموجودة على الأشرطة المعدنية.
 - لا تضغط على الشاشة بواسطة شيء حاد إذ قد يؤدي ذلك إلى إلحاق الضرر بالهاتف.
 - لا تعرّض الهاتف للسوائل أو الرطوبة.
 - استخدم الملحقات كسماعات الأذن مثلاً بحذر. لا تلمس الهوائي دون وجود سبب يدعوك إلى ذلك.
- تشغيل فعّال للهاتف
الأجهزة الإلكترونية**
- قد تعرّض كل الهواتف المحمولة للتنشويش، ما قد يؤثر على أدائها.
 - لا تستخدم الهاتف المحمول بالقرب من الأجهزة الطبية دون طلب الإذن للقيام بذلك. تجنّب وضع الهاتف على أجهزة إعداد النضض، مثلاً في الجيب على مستوى الصدر.
 - قد تسبب بعض الهواتف المحمولة الإزعاج للأدوات المساعدة للسمع.

إرشادات لاستخدام آمن و فعال

- حد SAR الذي توصي به اللجنة الدولية للحماية من الإشعاع غير المؤين (ICNIRP) هو 2 واط/ كيلوجرام وهو حد مقسّم على نحو متناسب إلى 10 جرامات من النسيج.
- تبلغ أعلى قيمة SAR لطراز الهاتف هذا الذي تم اختباره بواسطة DASY4 للاستخدام على الأذن 1.45 واط/كجم (10 جرام). وعند الحمل على الجسد تبلغ 0.841 واط/كجم (10 جرام).
- معلومات بيانات SAR للمقيمين في بلدان/مناطق تتبنى حد SAR الموصى به من قبل معهد المهندسين الكهربائيين والإلكترونيين (IEEE) هو 1.6 واط/ كيلوجرام كمتوسط لكل جرام واحد (1) من النسيج.

العناية بالمنتج وصيانتة

⚠ تحذير: استخدم فقط البطاريات والشواحن والملحقات الموافق على استخدامها مع طراز الهاتف المعيّن هذا. إن استخدام أي أنواع أخرى قد يؤدي إلى إبطال أي ضمان أو موافقة تنطبق على الهاتف المحمول. وقد يكون خطيراً.

يرجى قراءة هذه الإرشادات البسيطة. عدم التقيد بهذه الإرشادات قد يكون أمراً خطراً أو غير قانوني.

التعرّض لطاقة التردد اللاسلكي

معلومات حول التعرّض للموجات اللاسلكية ومعدل الامتصاص المحدد (SAR).

لقد تم تصميم طراز الهاتف المحمول GX500 هذا بحيث يفي بمتطلبات السلامة السارية المتعلقة بالتعرّض للموجات اللاسلكية. وتستند هذه المتطلبات إلى إرشادات علمية تتضمّن هوامش سلامة مصمّمة لضمان السلامة لكل الأشخاص. دون أخذ العمر والصحة بعين الاعتبار.

• تستخدم إرشادات التباين للموجات اللاسلكية وحدة قياس معروفة بمعدل الامتصاص المحدد. أو SAR. وتجري اختبارات SAR باستخدام أساليب قياسية فيما ينفذ الهاتف عملية الإرسال بأعلى مستوى طاقة مسموح به في كل نطاقات التردد التي تم اختبارها.

• وعلى الرغم من وجود اختلافات بين مستويات SAR لمختلف طرازات هاتف LG. فهي كلها مصممة بحيث تفي بالإرشادات المتعلقة بالتعرّض للموجات اللاسلكية.

63.....	إعدادات الشبكة	عرض ملفات الهاتف على الكمبيوتر	53.....
64.....	إعدادات الاتصال	مزامنة الأسماء	54.....
64.....	إعدادات جافا	مزامنة الرسائل	54.....
64.....	استخدام إدارة الذاكرة	تزامن الموسيقى	54.....
	إرسال الملفات واستلامها باستخدام بلوتوث	نقل الموسيقى باستخدام Windows Media Player	55.....
65.....	بلوتوث	DivX Converter	55.....
66.....	الاقتران بجهاز بلوتوث آخر		
66.....	استخدام سماعة رأس بلوتوث		
67.....	Wi-Fi		
67.....	تحديث البرنامج	ويب	57.....
68.....	الملحقات	المتصفح	57.....
		Opera Mini	57.....
69.....	خدمة الشبكة	الوصول إلى ويب	57.....
		إضافة الإشارات المرجعية والوصول إليها	58.....
69.....	بيانات تقنية	استخدام قارئ RSS	58.....
		حفظ صفحة	59.....
71.....	استكشاف الأخطاء وإصلاحها	الوصول إلى صفحة محفوظة	59.....
		عرض محفوظات المتصفح	59.....
		تغيير إعدادات متصفح ويب	59.....
		استخدام الهاتف كمودم	60.....
		الإعدادات	61.....
		استخدام بطاقات SIM ثنائية-قائمة البطاقة	61.....
		تخصيص الأوضاع	61.....
		تغيير إعدادات الشاشة	61.....
		تغيير إعدادات الهاتف	62.....
		تغيير إعدادات إمكانية الاتصال	63.....

المحتويات

- المستندات 44
نقل ملف إلى هاتفك 45
عرض ملف 45
أخرى 45
الموسيقى 46
نقل الموسيقى إلى الهاتف 46
تشغيل أغنية 47
إنشاء قائمة تشغيل 47
استخدام الراديو 47
البحث عن محطات 48
إعادة تعيين القنوات 48
- الأدوات المساعدة 49**
تسجيل ملف صوتي أو صوت 49
استخدام الحاسبة 49
تحويل وحدة 49
إضافة مدينة إلى ساعتك العالمية 49
استخدام ساعة الإيقاف 50
إضافة عنصر إلى التقويم 50
إضافة عنصر إلى قائمة المهام 50
الباحث عن التاريخ 51
الإعدادات 51
- 52..... PC Suite**
تنصيب برنامج LG PC Suite على الكمبيوتر 52
توصيل الهاتف والكمبيوتر 52
إجراء نسخ احتياطي لمعلومات الهاتف واستعادتها 53
- كاميرا الفيديو 37**
التقاط فيديو سريع 37
بعد الانتهاء من التقاط الفيديو 37
إعداد التعرض 38
استخدام الإعدادات المتقدمة 38
مشاهدة ملفات الفيديو المحفوظة 39
- الصور و مقاطع الفيديو 40**
عرض الصور وملفات الفيديو 40
استخدام التكبير/التصغير عند عرض صورة 40
إعداد مستوى الصوت عند عرض فيديو 40
تعيين صورة كخلفية الشاشة 40
تعديل الصور 41
- الوسائط المتعددة 42**
الصور 42
إرسال صورة 42
طباعة صورة 42
نقل صورة أو نسخها 43
أصوات 43
ملفات الفيديو 43
مشاهدة فيديو 43
إرسال فيديو كليب 43
الألعاب والتطبيقات 44
تنصيب لعبة/تطبيق بواسطة التنصيب المحلي 44
تشغيل لعبة 44

المحتويات

- 6.....إرشادات لاستخدام أمن و فعال
- 10.....التعرف على الهاتف الخاص بك
- 12.....نظرة على الهاتف وهو مفتوح
- 13.....تثبيت بطاقة SIM و البطارية
- 15.....بطاقة الذاكرة
- 16.....خريطة القوائم
- 17.....شاشة وضع الانتظار
- 17.....تلميحات شاشة للمس
- 18.....المفاتيح السريعة
- 20.....تغيير الحالة من شريط الحالة
- 20.....استخدام وظيفة تعدد المهام
- 21.....المكالمات
- 21.....إجراء مكالمة
- 21.....إجراء مكالمة من الأسماء
- 21.....الرد على مكالمة ورفضها
- 21.....الاتصال السريع
- 22.....إجراء مكالمة ثانية
- 22.....عرض سجلات المكالمات
- 23.....استخدام تحويل المكالمات
- 23.....استخدام حظر المكالمات
- 24.....تغيير إعداد المكالمات العام
- 25.....الأسماء
- 25.....البحث عن جهة اتصال
- 25.....إضافة جهة اتصال جديدة
- 26.....إنشاء مجموعة
- 26.....تغيير إعدادات الأسماء
- 27.....عرض المعلومات
- 28.....الرسائل
- 28.....الرسائل
- 28.....إرسال رسالة
- 29.....إدخال النص
- 29.....T9 التنبؤي
- 29.....دليل Abc
- 30.....لوحة المفاتيح
- 30.....التعرف على الكتابة اليدوية
- 30.....إعداد البريد الإلكتروني
- 31.....استرداد بريدك الإلكتروني
- 31.....تغيير إعدادات البريد الإلكتروني
- 32.....حافظات الرسائل
- 32.....تغيير إعدادات الرسائل النصية
- 32.....تغيير إعدادات رسائل الوسائط المتعددة
- 33.....المتعددة
- 34.....تغيير الإعدادات الأخرى
- 35.....الكاميرا
- 35.....التقاط صورة سريعة
- 35.....بعد التقاط الصورة
- 35.....استخدام الإعدادات المتقدمة
- 36.....عرض الصور المحفوظة

تهانينا لشرائك الهاتف المتقدم والصغير الحجم
GX500 من LG. والمصمّم للعمل مع تقنية
الاتصال الرقمي الأحدث للهواتف المحمولة.



قد تختلف بعض المحتويات الموجودة
في هذا الدليل عن هاتفك وذلك استناداً
إلى برنامج الهاتف أو موفر الخدمة.

دليل مستخدم GX500