



OWNER'S MANUAL

FRIDGE & FREEZER



Before beginning installation, read these instructions carefully. This will simplify installation and ensure that the product is installed correctly and safely. Leave these instructions near the product after installation for future reference.

EN ENGLISH

AR العربية



MFL71401509
Rev.02_052020

www.lg.com

Copyright © 2019-2020 LG Electronics Inc. All Rights Reserved.

TABLE OF CONTENTS

This manual may contain images or content that may be different from the model you purchased.

This manual is subject to revision by the manufacturer.

SAFETY INSTRUCTIONS

READ ALL INSTRUCTIONS BEFORE USE	4
WARNING	4
CAUTION	9

INSTALLATION

Before Installation	11
Removing the Fridge and Freezer Door	12
Connecting the Water Line	14
Levelling and Door Alignment	15
Turning on the Power	16
Moving the Appliance for Relocation	16

OPERATION

Before Use	17
Product Features	19
Control Panel	22
Ice and Water Dispenser	23
Automatic Icemaker	25
InstaView	27
Door in Door	28
Drawer	28
Shelf	29
Door Basket	30

SMART FUNCTIONS

LG ThinQ Application	31
Smart Diagnosis	32

MAINTENANCE

Cleaning	34
Water Filter	35

TROUBLESHOOTING

Before Calling for Service.....37

EN 4 SAFETY INSTRUCTIONS

SAFETY INSTRUCTIONS

READ ALL INSTRUCTIONS BEFORE USE

The following safety guidelines are intended to prevent unforeseen risks or damage from unsafe or incorrect operation of the appliance. The guidelines are separated into '**WARNING**' and '**CAUTION**' as described below.

Safety Messages



This symbol is displayed to indicate matters and operations that can cause risk. Read the part with this symbol carefully and follow the instructions in order to avoid risk.



WARNING

This indicates that the failure to follow the instructions can cause serious injury or death.



CAUTION

This indicates that the failure to follow the instructions can cause the minor injury or damage to the product.

WARNING

⚠ WARNING

To reduce the risk of explosion, fire, death, electric shock, injury or scalding to persons when using this product, follow basic precautions, including the following:

Technical Safety

- This appliance is not intended for use by persons (including children) with reduced physical, sensory or mental capabilities, or lack of experience and knowledge, unless they have been given supervision or instruction concerning use of the appliance by a person

responsible for their safety. Children should be supervised to ensure that they do not play with the appliance.

- This appliance is intended to be used in household and similar applications such as:
 - staff kitchen areas in shops, offices and other working environments;
 - farm houses and by clients in hotels, motels and other residential type environments;
 - bed and breakfast type environments;
 - catering and similar non-retail applications.



This symbol alerts you to flammable materials that can ignite and cause a fire if you do not take care.

- This appliance contains a small amount of isobutane refrigerant (R600a), but it is also combustible. When transporting and installing the appliance, care should be taken to ensure that no parts of the refrigerating circuit are damaged.
- The refrigerant and insulation blowing gas used in the appliance require special disposal procedures. Consult with service agent or a similarly qualified person before disposing of them.
- Do not damage the refrigerant circuit.
- If the power cord is damaged or the hole of the outlet socket is loose, do not use the power cord and contact an authorized service centre.
- Do not locate multiple portable outlet sockets or portable power supplies at the rear of the appliance.
- Securely plug the power plug in the outlet socket after completely removing any moisture and dust.
- Never unplug the appliance by pulling on the power cable. Always grip the power plug firmly and pull straight out from the outlet socket.
- Keep ventilation openings, in the appliance enclosure or in the built-in structure, clear of obstruction.

EN 6 SAFETY INSTRUCTIONS

- Do not store explosive substances such as aerosol cans with a flammable propellant in this appliance.
- Do not tilt the appliance to pull or push it when transporting.
- When positioning the appliance, ensure the supply cord is not trapped or damaged.
- Do not use mechanical devices or other means to accelerate the defrosting process.
- Do not use a hair drier to dry the inside of the appliance or place a candle inside to remove the odours.
- Do not use electrical appliances inside the refrigerator.
- Make sure not to get a body part such as a hand or foot stuck while moving the appliance.
- Disconnect the power cord before cleaning the appliance or replacing the inside lamp (where fitted).
- Do not spray water or inflammable substances (toothpaste, alcohol, thinner, benzene, flammable liquid, abrasive, etc.) over the interior or exterior of the appliance to clean it.
- Do not clean the appliance with brushes, cloths or sponges with rough surfaces or which are made of metallic material.
- Only qualified service personnel from LG Electronics service centre should disassemble, repair, or modify the appliance. Contact an LG Electronics customer information centre if you move and install the appliance in a different location.

Risk of Fire and Flammable Materials

- If a leak is detected, avoid any naked flames or potential sources of ignition and air the room in which the appliance is standing for several minutes. In order to avoid the creation of a flammable gas air mixture if a leak in the refrigerating circuit occurs, the size of the room in which the appliance is used should correspond to the amount of refrigerant used. The room must be 1 m² in size for every 8 g of R600a refrigerant inside the appliance.
- Refrigerant leaking out of the pipes could ignite or cause an explosion.

- The amount of refrigerant in your particular appliance is shown on the identification plate inside the appliance.

Installation

- This appliance should only be transported by two or more people holding the appliance securely.
- Install the appliance on a firm and level floor.
- Do not install the appliance in a damp and dusty place. Do not install or store the appliance in any outdoor area, or any area that is subject to weathering conditions such as direct sunlight, wind, rain, or temperatures below freezing.
- Do not place the appliance in direct sunlight or expose it to the heat from heating appliances such as stoves or heaters.
- Be careful not to expose the rear of the appliance when installing.
- Install the appliance in a place where it is easy to unplug the power plug of the appliance.
- Be careful not to let the appliance door fall during assembly or disassembly.
- Be careful not to pinch, crush, or damage the power cable during assembly or disassembly of the appliance door.
- Be careful not to point the power plug up or let the appliance lean against the power plug.
- Do not connect a plug adapter or other accessories to the power plug.
- Do not modify or extend the power cable.
- Ensure that the outlet socket is properly grounded, and that the earth pin on the power cord is not damaged or removed from the power plug. For more details on grounding, inquire at an LG Electronics customer information centre.
- This appliance is equipped with a power cord having an equipment-grounding conductor and a grounding power plug. The power plug must be plugged into an appropriate outlet socket that is installed and grounded in accordance with all local codes and ordinances.

EN 8 SAFETY INSTRUCTIONS

- Never start up an appliance showing any signs of damage. If in doubt, consult your dealer.
- Dispose of all packaging materials (such as plastic bags and styrofoam) away from children. The packaging materials can cause suffocation.
- Do not plug the appliance into a multi socket adapter which does not have a power cable (mounted).
- The appliance should be connected to a dedicated power line which is separately fused.
- Do not use a multi socket outlet which is not properly grounded (portable). In case of using a properly-grounded multi socket outlet (portable), use the multi socket outlet with the current capacity of the power cord rating or higher and use the multi socket outlet only for the appliance.

Operation

- Do not use the appliance for any purpose (storage of medical or experimental materials or shipping) other than any domestic household food storage use.
- If water penetrates electrical parts of the appliance, disconnect power plug and contact an LG Electronics customer information centre.
- Unplug the power plug during a severe thunderstorm or lightening or when not in use for a long period of time.
- Do not touch the power plug or the appliance controls with wet hands.
- Do not bend the power cable excessively or place a heavy object on it.
- Immediately unplug the power plug and contact an LG Electronics customer information centre if you detect a strange sound, odour, or smoke coming from the appliance.
- Do not place hands or metallic objects inside the area emitting the cold air, cover or heat releasing grille on the back.
- Do not apply excessive force or impact to the back cover of the appliance.

- Be careful of nearby children when you open or close the appliance door. The door may bump the child and cause injury.
- Avoid the danger of children getting trapped inside the appliance. A child trapped inside the appliance can cause suffocation.
- Do not put animals, such as pets into the appliance.
- Do not place heavy or fragile objects, containers filled with liquid, combustible substances, flammable objects (such as candles, lamps, etc.), or heating devices (such as stoves, heaters, etc.) on the appliance.
- Do not place any electronic appliance (such as heater and mobile phone) inside the appliance.
- If there is a gas leakage (isobutane, propane, natural gas, etc.), do not touch the appliance or power plug and ventilate the area immediately. This appliance uses a refrigerant gas (isobutane, R600a). Although it uses a small amount of the gas, it is still combustible gas. Gas leakage during appliance transport, installation or operation can cause fire, explosion or injury if sparks are caused.
- Do not use or store flammable or combustible substances (ether, benzene, alcohol, chemical, LPG, combustible spray, insecticide, air freshener, cosmetics, etc.) near the appliance.

Disposal

- When discarding the appliance, remove the door gasket while leaving the shelves and baskets in place and keep children away from the appliance.

CAUTION

CAUTION

To reduce the risk of minor injury to persons, malfunction, or damage to the product or property when using this product, follow basic precautions, including the following:

EN 10 SAFETY INSTRUCTIONS

Operation

- Do not touch frozen food or the metal parts in the freezer compartment with wet or damp hands. It may cause frostbite.
- Do not place glass containers, bottles or cans (especially those containing carbonated drinks) in the freezer compartment, shelves or ice bin that will be exposed to temperatures below freezing.
- The tempered glass on the front side of the appliance door or the shelves can be damaged by an impact. If it is broken, do not touch it with hands.
- Do not hang from the appliance doors, storage room, shelf or climb up into it.
- Do not store an excessive amount of water bottles or containers for side dishes on the door baskets.
- Do not open or close the appliance door with excessive force.
- If the hinge of the appliance door is damaged or operates improperly, stop using the appliance and contact an authorized service centre.
- Prevent animals from nibbling on the power cable or water hose.
- Never eat frozen foods immediately after they have been taken out in the freezer compartment.
- Do not use a thin crystal cup or chinaware when dispensing.
- Make sure not to get a hand or foot stuck upon opening or closing the appliance door or door in door.

Maintenance


- Do not clean glass shelves or covers with warm water when they are cold. They may shatter if exposed to sudden temperature changes.
- Do not insert the shelves upside down. The shelves may fall.
- To remove frost from the appliance, contact an LG Electronics customer information centre.
- Dispose of the ice inside the ice bin in the freezer compartment during an extended power outage.

INSTALLATION

Before Installation

Dimensions and Clearances

Too small of a distance from adjacent items may result in the degradation of freezing capability and increased electricity costs. Allow over 50 mm of clearance between the back of the appliance and the wall when installing the appliance.



-	Type A (mm)	Type B (mm)
A	912	912
B	1790	1790
C	927	738
D	797	615
E	877	690
F	922	733
G	1384	1180
H	1713	1750

NOTE

- You can determine what type of appliance it is by looking at the label inside the appliance.

Ambient Temperature

- The appliance is designed to operate within a limited range of ambient temperatures, depending on the climate zone.
- The internal temperatures could be affected by the location of the appliance, the ambient temperature, the frequency of door opening and so on.
- The climate class can be found on the rating label.

Climate Class	Ambient Temperature Range °C
SN (Extended Temperate)	+10 - +32
N (Temperate)	+16 - +32
ST (Subtropical)	+16 - +38 / +18 - +38**
T (Tropical)	+10 - +43* / +16 - +43 / +18 - +43**

* Australia, India, Kenya


** Argentina

NOTE

- The appliances rated from SN to T are intended to be used at an ambient temperature between 10 °C and 43 °C.

Accessories

*1 This feature is only available on some models.




① Spanner A*¹

EN 12 INSTALLATION

- ② Spanner B*1
- ③ Water Filter
- ④ Water Tube*1
- ⑤ Tube Connector and Clip*1
- ⑥ Tube Connector and Valve*1

the bottom of the front side of the cover, with a flat-head screwdriver.



Removing the Fridge and Freezer Door


If your entrance door is too narrow for the appliance to pass through, remove the appliance doors and pass the appliance laterally.

⚠ WARNING

- Disconnect the power cord, house fuse or circuit breaker before installing, removing the doors, or cleaning the appliance. Failure to follow these instructions may result in death, fire or electric shock.


Removing the Freezer Door

- 1 The water supply line is connected to the top right part in the back of the appliance. Hold the water supply connection and gently push the collet ① to detach the water supply line. Unscrew the cover ②.




- 2 Remove the screw from the hinge cover at the top of the appliance. Lift the hook, located at

- 3 Pull out the tube ③. Unscrew the ground wire ④. Disconnect all wire harnesses ⑤.




- 4 Rotate the hinge lever ⑥ counterclockwise. Lift the top hinge ⑦ free of the hinge lever latch ⑧.




⚠ CAUTION

- When lifting the hinge free of the latch, be careful that the door does not fall forward. It is recommended that two or more people carry out the door removal and refitting.

- 5** Lift the freezer door until it is free of the bottom hinge assembly.



- 3** Lift the fridge door until it is free of the bottom hinge assembly.




⚠ CAUTION


- Place the door on a non-scratching surface with the inner side facing up.

Removing the Fridge Door

- 1** Disconnect all wire harnesses ①.



- 2** Rotate the hinge lever ② clockwise. Lift the top hinge ③ free of the hinge lever latch ④.



⚠ CAUTION

- When lifting the hinge free of the hinge lever latch, be careful that the door does not fall forward. It is recommended that two or more people carry out the door removal and refitting.

⚠ CAUTION

- Place the door on a non-scratching surface with the inner side facing up.

Refitting the Fridge and Freezer Door


Refit the doors in the reverse sequence of their removal once the appliance has been passed through all access doors.

⚠ CAUTION

- Install the fridge door first.

NOTE


- Disassembling/Assembling the water lines




① Collet ② Tube ③ Insert line ④ Clip

- Gently insert the tube until only one of the tube's lines is visible. Pull on the tube to make sure that it is tightly fastened.

Correct



EN 14 INSTALLATION**NOTE**

- If the water tube end is damaged, it should be trimmed to ensure it does not leak when refitted.



⑤ Not straight ⑥ Damaged ⑦ Stretched

- Connecting the water line must only be installed by a qualified plumber and in accordance with local legislation and regulations governing water quality.

NOTE

- This water line installation is not covered by the appliance warranty.

Connecting the Water Line

This section is applied only to models with plumbed water or ice dispenser.

Water Supply Requirements

A cold water supply with water pressure between 138 kPa and 827 kPa (1.4-8.4 kgf/cm²) is required to operate the water dispenser. If the refrigerator is installed in an area with low water pressure (below 138 kPa), you can install a booster pump to compensate for the low pressure.


If a reverse osmosis water filtration system is connected to your cold water supply, the water pressure to the reverse osmosis system needs to be a minimum of 138 kPa to 827 kPa (1.4-8.4 kgf/cm²)

⚠ WARNING

- Unplug the appliance before carrying out any work on connecting the water line. Failure to do so may cause electric shock.
- Only connect the water line to a cold water supply. Failure to do so may cause the water filter to malfunction. Water hammer (water banging in the pipes) in house plumbing can cause damage to appliance parts and can lead to water leakage or flooding.
- Connect to potable water supply only.

Connecting Water to the Appliance

- Unscrew the metal threaded collar nut at the back of the appliance and place it over one end of the water tube.
- Firmly push the water tube onto the water inlet valve and tighten up the collar nut.

**Checking the Water Connection**

- Turn on the water supply and switch on the appliance. Carefully check all fittings for possible leaks due to poorly fitted hoses.
- Press and hold the **Water Filter** button for three seconds. The new water filter has been activated.
- Place a cup under the water dispenser to verify that water is flowing through the appliance.
- Check the connecting tube and joints for leaks once again.


Levelling and Door Alignment

Before Beginning


When the appliance doors appear to be uneven, follow the instructions below to align the doors.

NOTE

- The spanner may differ depending on the model. You will be provided with either spanner type A or B.
 - Spanner Type A




- Spanner Type B



Levelling the Appliance


The appliance has two front levelling legs. Adjust the legs to alter the tilt from front to back or side to side. If the appliance seems unsteady, or the doors do not close easily, adjust the appliance's tilt using the instructions below.

Use the spanner ① to adjust the height by turning the levelling leg to the left to raise it or to the right to lower it.




Door Alignment for Freezer and Fridge Door

If the door of the appliance is not level, adjust the difference in the height of appliance door.




- Open the door and use the spanner ① to loosen the keeper nut by turning it to the left.



EN 16 INSTALLATION

- 2** Use the spanner **②** to adjust the height by turning the adjustment hinge pin to the left or to the right.




the appliance has cooled completely, your food may spoil.

⚠ CAUTION

- Do not adjust the height of the appliance door more than 3 mm.

- 3** Use the spanner **①** to fasten the keeper nut by turning it to the right.


NOTE

- Leveling the doors may not be possible when the floor is not leveled, or is of weak or poor construction.
- The refrigerator is heavy and should be installed on a rigid and solid surface.
- Some timber flooring may cause levelling difficulties if it flexes excessively.

Moving the Appliance for Relocation

Preparing for Relocation

- Remove all food from inside the appliance.
- Pull the power plug out, insert and fix it into the power plug hook at the rear or on top of the appliance.
- Tape parts such as shelves and the door handle to prevent from falling off while moving the appliance.
- Move the appliance with more than two people carefully. When transporting the appliance over a long distance, keep the appliance upright.
- After installing the appliance, connect the power plug into a mains outlet socket and switch it on.

Turning on the Power

Connecting the Appliance

After installing the appliance, connect the power plug into the outlet socket.

NOTE

- After connecting the power supply cord (or plug) to the outlet, wait 3 or 4 hours before you put food into the appliance. If you add food before

OPERATION

Before Use

Notes for Operation

- Users should keep in mind that frost can form if the door is not closed completely or if the humidity is high during the summer.
- Ensure there is sufficient space between food stored on the shelf or door basket to allow the door to close completely.
- Opening the door for long periods can cause a significant increase of the temperature in the compartments of the appliance.
- If the refrigerating appliance is left empty for long periods, switch off, defrost, clean, dry, and leave the door open to prevent mould developing within the appliance.

the repair technician from the our information centre may have difficulty finding the problem.

Suggestion for Energy Saving

- Ensure there is sufficient space between stored foods. This allows cold air to be circulated evenly and lowers electricity bills.
- Store hot food only after it has cooled in order to prevent dew or frost.
- When storing food in the freezer compartment, set the freezer temperature lower than the temperature indicated on the food.
- Do not set the temperature of the appliance lower than needed.
- Do not put food near the temperature sensor of the fridge compartment. Keep a distance of at least 3 cm from the sensor.
- Note that a temperature rise after defrosting has a permissible range in the appliance specifications. If you wish to minimise the impact on the food storage due to a temperature rise, seal or wrap the stored food in several layers.
- The automatic defrosting system in the appliance ensures that the compartment remains free of ice buildup under normal operating conditions.

Door Open Alarm

The alarm sounds 3 times in 30 second intervals if the door is left open or not completely closed for 1 minute.

NOTE

- Contact the LG Electronics customer information centre if the alarm sound continues after 30 seconds even after closing all doors.

Failure Detection

The appliance can automatically detect problems during the operation.

NOTE

- If a problem is detected, the appliance may not operate and an error code is displayed even when any button is pressed.
- If an error code is indicated on the display, do not turn off the power. Immediately contact the LG Electronics customer information centre and report the error code. If you turn off the power,

Storing Foods Effectively

- Store frozen food or refrigerated food inside sealed containers.
- Check the expiration date and label (storage instructions) before storing food in the appliance.
- Do not store food for a long period of time (more than 4 weeks) if it spoils easily at a low temperature.
- Place the refrigerated food or frozen food in each fridge or freezer compartment immediately after purchasing.

EN 18 OPERATION

- Store raw meat and fish in suitable containers in the refrigerator, so that it is not in contact with or drip onto other food.
- Refrigerated foods and other food items can be stored on top of the vegetable drawer.
- Avoid refreezing any food which has been completely thawed. Freezing any food which has been completely thawed again will lower its taste and nutrition.
- Do not overfill the appliance. Cold air can not circulate properly if the appliance is overfilled.
- Cool hot food before storing. If too much hot food is placed inside, the internal temperature of the appliance can increase and negatively affect other foods stored in the appliance.
- If you set an excessively low temperature for food, it may become frozen. Do not set a temperature lower than the required temperature for the food to be stored correctly.
- If there are chill compartments in the appliance, do not store vegetables and fruits with higher moisture content in the chill compartments as they may freeze due to the lower temperature.
- In the event of a blackout, call the electricity company and ask how long it is going to last.
 - You should avoid door openings while the power is off.
 - When the power supply gets back to normal, check the condition of the food.

Max Freezing Capacity

- **Express Freeze** function will allow the freezer to reach its maximum freezing capacity. This generally takes up to 24 hours and automatically switches off.
- **Express Freeze** must be switched on for 2 hours before fresh products are placed in the freezer compartment.
- To get better air circulation, insert all inner parts like baskets, drawers, and shelves.

Freezing the Maximum Amount of Food

If large quantities of food are to be stored, all the freezer drawers should be taken out of the appliance and the food should be stacked directly on the freezer shelves in the freezer compartment.

CAUTION

- To remove the drawers, first remove the food from drawers and then pull out the drawers carefully. Not doing so could cause injury or damage to the drawers.

NOTE

- The shape of each drawer may be different, insert in the right position.

Two Star Compartment


- Two star (**) basket or drawer can be used to store ice and food from -12 °C to -18 °C for short periods.
- Two star frozen food compartments are suitable for storing pre-frozen food, storing or making icecream and making ice cubes.
- Two star compartments are not suitable for the freezing of fresh food.

Product Features

The appearance or components of the appliance may differ from model to model.

Exterior

*1 This feature is only available on some models.



① Control Panel

Sets the refrigerator temperature and freezer temperature, the water filter condition and the dispenser mode.

② Door in Door^{*1}

This is a convenient storage area for frequently-used items that require easy access.

③ Door in Door Lever^{*1}



Opens Door-in-Door.

④ InstaView Door in Door^{*1}

The InstaView Door-in-Door compartment allows for easy access to commonly used food items.

EN 20 OPERATION**Interior (Two Star **)

*1 This feature is only available on some models.

**① LED Lamp**

The LED lamps inside the appliance light up when you open the door.

② Automatic Icemaker^{*1}

This is where ice is automatically produced and stored.

③ Freezer Shelf

This is where frozen foods such as meat, fish, and ice cream can be stored.

④ Freezer Drawer

This is for long-term storage of frozen items.

⑤ Freezer Door Basket

This is where small packaged frozen food or frequently used foods can be stored.

⑥ Door in Door Compartment^{*1}

This is where foods which are taken out frequently such as beverages and snacks are stored.

⑦ Bottle Rack^{*1}

This is where drinks tall bottles or containers are stored.

⚠ CAUTION

- Do not store short bottles or containers. The items may fall and cause an injury or appliance damage.

⑧ Fridge Shelf

This is where refrigerated foods and other items are stored. Store the foods with higher moisture content at the front of the shelf.

The shelf height can be adjusted by inserting the shelf in another groove of different height.

The actual number of shelves will differ from model to model.

⑨ Air Filter^{*1}

This reduces odours inside the fridge compartment.

⑩ Snack Drawer^{*1}

This is where small packages of refrigerated foods are stored.

⑪ Temperature Sensor^{*1}

This sensor senses the temperature of the fridge compartment.

- Maintain the distance between the sensor and food to accurately sense the temperature.

⑫ Water Tank^{*1}

This is where water to supply the dispenser or the automatic icemaker is stored. It requires manual filling.

⑬ Fresh Vegetable Drawer^{*1}

This is where fruits and vegetables are stored to help maintain freshness by adjusting the humidity controller.

⑭ Egg Box^{*1}

This is where eggs are stored.

- Do not use it as the ice bin or place it on the shelf on top of the fridge or the vegetable drawer.

⑮ Vegetable Drawer

This is where fruits and vegetables are stored to remain fresh for as long as possible.

⑯ Fridge Door Basket

This is where small packages of refrigerated foods, drinks and sauce containers are stored.


EN 22 OPERATION

Control Panel

The actual control panel may differ from model to model.

Control Panel and Functions

*1 This feature is only available on some models.



① Hygiene Fresh*¹

This function reduces odours inside the fridge.

② Express Freeze

This function can quickly freeze a large amount of ice or frozen foods.

- This function is enabled and disabled in turn each time you press the button.
- This function automatically terminates after a specific period has passed.

③ Freezer

Press this button repeatedly to select a desired temperature between -24 °C and -14 °C.

- The initial freezer temperature is -19 °C.

④ Fridge

Press this button repeatedly to select a desired temperature between 1 °C and 7 °C.

- The initial fridge temperature is 4 °C.

NOTE

- The actual inner temperature varies depending on the food status, as the indicated setting temperature is a target temperature, not actual temperature within the appliance.

⑤ Non Plumbing*¹

The **Non Plumbing** icon is illuminated when the water dispenser tank is installed correctly.

⑥ Lock

This locks the buttons on the control panel.

- To lock the control panel buttons, press and hold the **Lock** button for 3 seconds until the  icon appears and the function is activated.
- To disable the function, press and hold the **Lock** button for 3 seconds until the  icon appears and the function is deactivated.

⑦ Wi-Fi

This button allows the appliance to connect to a home Wi-Fi network. Refer to Smart Functions for information on the initial setup of the **LG ThinQ** application.

⑧ Water & Ice Type

Select a desired dispenser mode from the buttons on the control panel. Press the dispenser switch with a glass or other container to dispense cubed ice, water or crushed ice.

⑨ Water Filter^{*1}

Replace the water filter when the  indicator lights up.

NOTE

- The control panel automatically turns off for energy saving.
- If there is any finger or skin contacts to the control panel while cleaning it, the button function may operate.

Ice and Water Dispenser

Before Using the Ice and Water Dispenser

CAUTION

- Keep children away from the dispenser to prevent children playing with or damaging the controls.
- Throw away the first few batches of ice (about 20 cubes and 7 cups of water). This is also necessary if the appliance has not been used for a long time.
- Clean the water dispensing system if they have not been used for 48 hours. Flush the water system connected to a water supply if water has not been drawn for 5 days.
- To clean the water dispensing system, flush the water through the dispenser about 5 minutes and throw away the first few batches of ice.
- It is normal for milky / cloudy water to be dispensed after replacing the water filter. This

air in the water will eventually clear and is safe to drink during this transition.

NOTE


- If you open the freezer door while water is being dispensed, the water dispensing will stop.
- If you open the fridge door while water, cubed ice or crushed ice is being dispensed, dispensing will be paused. When you close the door, the selected item will continue to be dispensed.
- If the cup rim is small, water may splash out of the glass or miss it completely.
- Use a cup with a rim of over 68 mm in diameter when dispensing water, cubed ice or crushed ice.
- When the ice maker produces smaller ice cubes, or the cubes become lumped together, the amount of water supplied to the ice maker may be low due to insufficient water in the water tank. If ice is not used frequently or the freezer set temperature is too warm, it may also lump together.

EN 24 OPERATION

Using the Ice and Water Dispenser

Press the dispenser selection button repeatedly until the light above the icon that you want illuminates.

Press the dispenser paddle ① with a glass or other container to dispense cubed ice, water or crushed ice.



Cleaning the Dispenser Tray


Wipe the entire area with a damp cloth. The dispenser tray may become wet easily due to spilled ice or water.



Cleaning the Dispenser

Cleaning the Ice and Water Outlet

Wipe the water outlet ① or ice outlet ② frequently with a clean cloth as it may get dirty easily.




NOTE

- Lint from a cloth may adhere to the outlets.


Filling the Water Tank with Water

This feature is only available on some models. The water tank holds the water to be dispensed or used by the automatic icemaker to make ice.


- 1 Remove the water dispenser tank by pulling it out while holding the handle.




- 2 Open the cover or cap of the water dispenser tank.




- 3** Fill with bottle filtered or clean filtered water up to the reference line indicated inside the water dispenser tank. (Total capacity: 4 ℓ)



- 4** After filling with water, close the cover or cap of the water dispenser tank.



- 5** Refit the water dispenser tank on the fridge shelf.



⚠ WARNING

- Fill with potable water only into icemaker or dispenser water tank.
- Do not fill the water tank with drinks other than water or fill with hot water.

⚠ CAUTION

- Do not apply excessive force or impact when removing or assembling the water dispenser tank. Doing so can cause appliance damage or injury.
- Children should not be allowed near the dispenser tank.

NOTE

- Before using the water dispenser tank after installing the appliance, it should be washed before filling it with water.
- Check if the water dispenser tank has been placed on the appliance correctly. If it is not assembled correctly, water may leak from the tank into the appliance.
- If there is an insufficient amount of water in the water dispenser tank, ice cube size and quantity may be affected and may result in no ice being made.
- If there is no water in the water dispenser tank, the cold water and ice dispensing function of the dispenser cannot be used. Check if there is water in the water dispenser tank and then fill it with water if there is not.
- Wait at least 15 seconds before removing the water tank after having dispensed water or ice from the dispenser.
- Sound from the water tank will be normal when supplying water to the dispenser and the Automatic Ice Maker. It is not a sign of malfunction.

Automatic Icemaker

This feature is only available on some models.
This feature may vary depending on model purchased.

Before Using the In-Door Icemaker


- The icemaker produces ice normally when approximately 48 hours have passed after the appliance is initially installed.
- If the ice bin is completely filled with ice, ice production will stop.
- Sound of ice dropping into the ice bin is normal.
- If ice cubes are stored in the ice bin for a long period of time, they may clump together and may not be separated easily. In such a case, empty the ice bin and allow fresh ice to be made.

EN 26 OPERATION**! CAUTION**

- It is normal for milky or cloudy water to be dispensed after replacing the water filter. This air in the water will clear eventually and is safe to drink.
- The first ice and water dispensed may include particles or odour from the water supply line or the water tank.
- If discolored ice is dispensed, check the water tank and the water supply for a possible source. If the problem continues, contact the LG Electronics customer information centre. Do not use the ice or water until the problem is corrected.
- Do not touch the ice outlet or the automatic icemaker with your hand or a tool.
- Dispense ice into a glass before filling it with water or other beverages. Splashing will occur if ice is dispensed into a glass that already contains liquid.
- Never use a glass that is exceptionally narrow or deep. Ice may jam in the ice passage, affecting the performance of the appliance.
- Keep the glass at a proper distance from the ice outlet. A glass held too close to the outlet may prevent ice from dispensing.
- Dispose of the ice inside the ice bin if you go on vacation or if an extended power outage occurs. Water from melting ice may drop from the dispenser onto the floor.

Freezer Icemaker

The automatic icemaker can automatically make 40-84 cubes at a time, within a 24-hour period if conditions are favorable. This amount may vary according to the environment (ambient temperature around the appliance, frequency of the door being opened, amount of food stored in the appliance, etc.).


**① Power Switch****! CAUTION**

- Do not insert your hands into the mechanical part of the automatic icemaker such as the ice bin or the ice dispenser.
- Do not remove the cover of the automatic icemaker. Touching any mechanical part of the automatic icemaker. It may result in injury.


Removing/Refitting the Ice Storage Bin

The ice dispensing chute may become blocked with frost if only crushed ice is used. Remove the frost that accumulates by removing the ice bin and clearing the passage with a rubber spatula. Dispensing cubed ice periodically can also help prevent frost buildup.


- 1 Hold and remove the cover of the automatic icemaker by lifting it upward.



- 2 To turn off the automatic icemaker, set the switch to OFF (O).



- 3** Hold the ice bin with both hands and pull it out while lifting it upward.



- 4** Mount them in the reverse order of the removal process.

CAUTION

- Do not touch the automatic icemaker's mechanical parts with your hand or a tool. Otherwise, appliance damage or injury may occur.
- Do not disassemble, repair or alter the automatic icemaker. These tasks should only be done by a service technician.
- Caution should be taken, as the automatic icemaker operates continuously after the freezer door is opened when the automatic icemaker switch is set to the on position.
- Keep children away from the dispenser.
- When refitting the ice bin, ensure that it is placed correctly. If it is tilted or unlevel, it may not continue to make ice due to sensor disruption.

Turning the Automatic Icemaker On or Off

To turn the automatic icemaker On/Off, press the power switch on the icemaker to the ON (|) or OFF (O) position.

Normal Sounds You May Hear

The icemaker water valve will buzz as the icemaker fills with water. If the power switch is in the ON (|) position, it will buzz even if it has not yet been hooked up to water. To stop the buzzing, move the power switch to OFF (O).

NOTE

- Do not keep the power turned on to the icemaker if the water line is not connected. Doing so can damage the icemaker.

Preparing for Vacation

If the ambient temperature will drop below freezing, have a qualified technician drain the water supply system to prevent serious property damage due to flooding caused by ruptured water lines or connections. Set the icemaker power switch to OFF (O) and shut off the water supply to the appliance.

NOTE


- The ice bin should be emptied any time the icemaker on/off switch is turned to the OFF (O) position.

InstaView

This feature is only available on some models.

Using the InstaView Door in Door

The InstaView function on the Door in Door lets you see if you're running low on frequently used items like beverages and snacks, without opening the refrigerator door.



EN 28 OPERATION

- 1** Knock twice on the glass to turn the LED light inside the Door in Door on or off.
- 2** The LED light turns off automatically after ten seconds.

NOTE

- The InstaView Door in Door function is disabled for 2 seconds after closing the left or right freezer door, and momentarily disabled whilst the ice dispenser is in use.
- Knock near the center of the glass. Knocking near the edges of the glass may not activate the InstaView Door in Door function.
- Knock hard enough so that the knocking sound is audible.
- The InstaView Door in Door function may activate if a loud noise occurs near the refrigerator.
- Clean the glass door with a dry cloth. To remove stubborn stains, slightly moisten a clean cloth with lukewarm water or a glass cleaner. Do not spray glass cleaner directly at the glass door.


Door in Door

This feature is only available on some models.

Using the Door in Door

Pull the lever at the bottom of the door upwards until the door in door opens.

There is plenty of storage space inside the door in door and its surrounding baskets, allowing you to store food in an organized manner.


**CAUTION**

- Do not open the door of the appliance with the door in door open, or do not open the door in door while the door of the appliance is open. The door in door may be struck by the edge of the appliance and damaged.

Removing/Refitting the Door in Door Case**CAUTION**

- Remove contents from the Door in Door compartment before removal.

- 1** Open the doors completely and remove the contents of the Door in Door case. Lift up and pull out the Door in Door case.



- 2** Mount them in the reverse order of the removal process.

Drawer**CAUTION**

- Always empty the drawers before removing them, and use both hands when removing and refitting them.


- Make sure that the fridge doors are fully open before removing and refitting the drawers.

Using the Vegetable Drawer

*1 This feature is only available on some models.


The humidity in the vegetable crisper drawer can be controlled by sliding the lever in either direction.

- If moved to the left side, the air guide will be open and allow air to circulate through the drawer for reduced humidity.
- If moved to the right side, the air guide will be closed and will maintain any humidity that is currently in the crisper drawer.




Removing/Refitting the Drawers

- 1 Remove the contents of the drawer. Hold the handle of the vegetable drawers and gently pull them out.



- 2 Lift the vegetable drawer up and remove it by pulling it out.



- 3 Mount them in the reverse order of the removal process.

CAUTION

- Always empty the drawers before removing them, and use both hands when removing and refitting them.
- Make sure that the fridge doors are fully open before removing and assembling the drawers.


Shelf


CAUTION

- Glass shelves are heavy. Use special care when removing them.
- Do not clean glass shelves with warm water while they are cold. Shelves may break if exposed to sudden temperature changes or impact.


Removing/Refitting the Shelf

- 1 Tilt up the front of the shelf and then lift the shelf straight up.



EN 30 OPERATION**2** Pull the shelf out.**3** Mount them in the reverse order of the removal process.**3** Mount them in the reverse order of the removal process.**⚠ CAUTION**

- Glass shelves are heavy. Use special care when removing them.
- Do not clean glass shelves with warm water while they are cold. Shelves may break if exposed to sudden temperature changes or impact.
- Make sure that shelves are level from one side to the other. Failure to do so may result in the shelf falling or food spilling.

Door Basket**Removing/Refitting the Door Basket****1** Hold both edges of the basket and remove it by lifting it upward.**2** Refit the door baskets in the reverse order of the removal process.

SMART FUNCTIONS

LG ThinQ Application

This feature is only available on models with Wi-Fi.

The **LG ThinQ** application allows you to communicate with the appliance using a smartphone.

LG ThinQ Application Features

Communicate with the appliance from a smartphone using the convenient smart features.

Smart Diagnosis

- If you experience a problem while using the appliance, this smart diagnosis feature will help you diagnose the problem.

Settings

- Allows you to set various options on the appliance and in the application.

NOTE


- If you change your wireless router, internet service provider, or password, delete the registered appliance from the **LG ThinQ** application and register it again.
- The application is subject to change for appliance improvement purposes without notice to users.
- Functions may vary by model.

Before Using LG ThinQ Application


- Check the distance between the appliance and the wireless router (Wi-Fi network).

- If the distance between the appliance and the wireless router is too far, the signal strength becomes weak. It may take a long time to register or installation may fail.

- Turn off the **Mobile data** or **Cellular Data** on your smartphone.



- Connect your smartphone to the wireless router.



NOTE

- To verify the Wi-Fi connection, check that icon on the control panel is lit.
- The appliance supports 2.4 GHz Wi-Fi networks only. To check your network frequency, contact your Internet service provider or refer to your wireless router manual.
- LG ThinQ** is not responsible for any network connection problems or any faults, malfunctions, or errors caused by network connection.
- If the appliance is having trouble connecting to the Wi-Fi network, it may be too far from the router. Purchase a Wi-Fi repeater (range extender) to improve the Wi-Fi signal strength.
- The Wi-Fi connection may not connect or may be interrupted because of the home network environment.
- The network connection may not work properly depending on the Internet service provider.
- The surrounding wireless environment can make the wireless network service run slowly.
- The appliance cannot be registered due to problems with the wireless signal transmission. Unplug the appliance and wait about a minute before trying again.

EN 32 SMART FUNCTIONS

NOTE

- If the firewall on your wireless router is enabled, disable the firewall or add an exception to it.
- The wireless network name (SSID) should be a combination of English letters and numbers. (Do not use special characters.)
- Smartphone user interface (UI) may vary depending on the mobile operating system (OS) and the manufacturer.
- If the security protocol of the router is set to **WEP**, you may fail to set up the network. Please change it to other security protocols (**WPA2** is recommended) and register the product again.

Installing the LG ThinQ Application

Search for the **LG ThinQ** application from the Google Play Store or Apple App Store on a smartphone. Follow instructions to download and install the application.

Connecting to Wi-Fi

The **Wi-Fi** button, when used with the **LG ThinQ** application, allows the appliance to connect to a home Wi-Fi network. The  icon shows the status of the appliance's network connection. The icon illuminates when the appliance is connected to the Wi-Fi network.

Initial Appliance Registration

Run the **LG ThinQ** application and follow the instructions in the application to register the appliance.

Re-registering the Appliance or Registering Another User

Press and hold the **Wi-Fi** button for 3 seconds to temporarily turn it off. Run the **LG ThinQ** application and follow the instructions in the application to register the appliance.

NOTE

- To disable the Wi-Fi function, press and hold the **Wi-Fi** button for 3 seconds. The  icon will be turned off.

Open Source Software Notice Information

To obtain the source code under GPL, LGPL, MPL, and other open source licenses, that is contained in this product, please visit <http://opensource.lge.com>.

In addition to the source code, all referred license terms, warranty disclaimers and copyright notices are available for download.

LG Electronics will also provide open source code to you on CD-ROM for a charge covering the cost of performing such distribution (such as the cost of media, shipping, and handling) upon email request to opensource@lge.com. This offer is valid for a period of three years after our last shipment of this product. This offer is valid to anyone in receipt of this information.

Smart Diagnosis

This feature is only available on models with the  or  logo.

Use this feature to help you diagnose and solve problems with your appliance.

NOTE

- For reasons not attributable to LGE's negligence, the service may not operate due to external factors such as, but not limited to, Wi-Fi unavailability, Wi-Fi disconnection, local app store policy, or app unavailability.
- The feature may be subject to change without prior notice and may have a different form depending on where you are located.

Using LG ThinQ to Diagnose Issues

If you experience a problem with your Wi-Fi equipped appliance, it can transmit troubleshooting data to a smartphone using the **LG ThinQ** application.

- Launch the **LG ThinQ** application and select the **Smart Diagnosis** feature in the menu. Follow the instructions provided in the **LG ThinQ** application.


NOTE

- For best results, do not move the phone while the tones are being transmitted.

Using Audible Diagnosis to Diagnose Issues

Follow the instructions below to use the audible diagnosis method.

- Launch the **LG ThinQ** application and select the **Smart Diagnosis** feature in the menu. Follow the instructions for audible diagnosis provided in the **LG ThinQ** application.

- 1 Press the **Lock** button to activate the lock function.
 - If the display has been locked for over 5 minutes, you must deactivate the lock and then reactivate it.
- 2 Open the fridge door and then hold the phone on the upper right speaker hole.
- 3 Press and hold the **Freezer** button for three seconds or longer while holding your phone to the speaker until the data transfer is complete.
 - The diagnosis sound is generated after around 3 seconds.
- 4 After the data transfer is complete, the diagnosis will be displayed in the application.

EN 34 MAINTENANCE

MAINTENANCE

Cleaning

General Cleaning Tips

- When cleaning the inside or outside of the appliance, do not wipe it with a rough brush, toothpaste, or flammable materials. Do not use cleaning agents containing flammable substances. This may cause discolouration or damage to the appliance.
 - Flammable substances: alcohol (ethanol, methanol, isopropyl alcohol, isobutyl alcohol, etc.), thinner, bleach, benzene, flammable liquid, abrasive, etc.
- After cleaning, check if the power cable is damaged.

Cleaning the Exterior

- When cleaning the outside air vents of the appliance by means of vacuuming, then the power cord should be unplugged from the outlet to avoid any static discharge that can damage the electronics or cause an electric shock. Regular cleaning of the rear and side ventilation covers is recommended to maintain reliable and economical operation of the unit.
- Keep the air vents on the exterior of the appliance clean. Blocked air vents can cause fire or appliance damage.
- For the appliance exterior, use a clean sponge or soft cloth and a mild detergent in warm water. Do not use abrasive or harsh cleaners. Dry thoroughly with a soft cloth. Do not use contaminated cloths when cleaning the stainless steel doors. Always use a dedicated cloth and wipe in the same direction as the grain. This helps reduce surface staining and tarnishing.

Cleaning the Interior

- When removing a shelf or drawer from inside the appliance, remove all stored foods from the shelf or drawer to prevent injury or damage to


the appliance. Otherwise, injury may occur due to the weight of stored foods.

- Detach the shelves and drawers and clean them with water, and then dry them sufficiently, before replacing them.
- Regularly wipe the door gaskets with a wet soft towel.
- Door basket spills and stains should be cleaned as they can compromise storage ability of the basket and could even be damaged.
- Never clean the shelves or containers in the dishwasher. The parts may become deformed due to the heat.

Cleaning the Condenser Cover

Use a vacuum cleaner with a brush to clean the condenser cover and vents. Do not remove the panel covering the condenser coil area.

We recommend that this be done every 12 months to maintain operating efficiency.



Water Filter

Before Replacing the Water Filter

⚠ WARNING

- Do not allow children to have access to small parts during the installation of this product.
- Do not use with water that is microbiologically unsafe or of unknown quality without adequate disinfection before or after the system. Systems certified for cyst reduction may be used on disinfected water that may contain filterable cysts.

⚠ CAUTION

- Do not install if water pressure exceeds 827 kPa. If your water pressure exceeds 827 kPa, you must install a pressure limiting valve. Contact a plumbing professional if you are uncertain how to check your water pressure.
- Do not install where water hammer conditions may occur. If water hammer conditions exist, you must install a water hammer arrester. Contact a plumbing professional if you are uncertain how to check for this condition.
- Do not install on hot water supply lines. The maximum operating water temperature of this filter system is 37.8 °C.
- Protect filter from freezing. Drain filter when temperatures drop below 4.4 °C.
- The disposable filter cartridge MUST be replaced every 6 months, at the rated capacity or if a noticeable reduction in flow rate occurs.
- Where a backflow prevention device is installed on a water system, a device for controlling pressure due to thermal expansion must be installed.
- Ensure all tubing and fittings are secure and free of leaks.

NOTE

- While the testing was performed under standard laboratory conditions, actual performance may vary.

- It is essential that the manufacturer's recommended installation, maintenance and filter replacement requirements be carried out for the product to perform as advertised.

Application Guidelines/Water Supply Parameters

Service Flow	1.9 lpm
Water Supply	Community or Private Well - Potable Water
Water Pressure	138 - 827 kPa
Water Temperature	0.6 - 37.8°C
Capacity	1892 litres

Replacing the Water Filter (Plumbed Model)


*1 This feature is only available on some models.

The filter must be changed every 6 months or when the indicator lights turns on or the water dispenser output decreases.

- To purchase a replacement water filter:
 - Use replacement cartridge: ADQ736939**
 - Visit your local dealer or distributor or contact the LG Electronics Customer Information Centre. For further assistance, visit our website at lg.com


Thread Nut Type*1

- 1 Loose the screw cap.




EN 36 MAINTENANCE


- 2** Pull the pipe out from the water filter cap until the colored line ① is visible.




- 2** Pull the pipe out from the water filter.




- 3** Push the pipe into the water filter cap, making sure the end is fully sealed.




- 3** Push the pipe into the water filter, making sure the end is fully sealed.



- 4** Tighten the screw cap until the colored line in the water filter is no longer visible.



- 4** Insert the screw cap until the colored line in the water filter is no longer visible.




- 5** Press and hold the **Water Filter** button for three seconds. That resets the **Replacement Filter** icon. The new water filter has been activated.

- 6** Dispense water for approximately 5 minutes to remove trapped air and contaminants from the system.

Push fit connector type^{*1}

- 1** Remove the screw cap.



- 5** Press and hold the **Water Filter** button for three seconds. That resets the **Replacement Filter** icon. The new water filter has been activated.

- 6** Dispense water for approximately 5 minutes to remove trapped air and contaminants from the system.

CAUTION

- Failure to replace filters when required or using non LG authorised water filters can cause the filter cartridge to leak and result in property damage.

TROUBLESHOOTING

Before Calling for Service

Cooling

Symptoms	Possible Cause & Solution
There is no refrigeration or freezing.	Is there a power interruption? <ul style="list-style-type: none">Check the power of other appliances. Check the power of other appliances. <ul style="list-style-type: none">Plug the power plug in the outlet properly.
There is poor refrigeration or freezing.	Is the fridge or freezer temperature set to its warmest setting? <ul style="list-style-type: none">Set the fridge or freezer temperature to a colder setting. Is the appliance in direct sunlight, or is it near a heat generating object such as cooking oven or heater? <ul style="list-style-type: none">Check the installation area and reinstall it away from heat generating objects. Did you store hot food without cooling it first? <ul style="list-style-type: none">Cool the hot food first before putting it in the fridge or freezer compartment. Did you put in too much food? <ul style="list-style-type: none">Maintain an appropriate space between food. Are the appliance doors completely closed? <ul style="list-style-type: none">Completely close the door and make sure that stored food is not obstructing in the door. Is there enough space around the appliance? <ul style="list-style-type: none">Adjust the installation position to make enough space around the appliance.
The appliance contains a bad smell.	Is the fridge or freezer temperature set to 'Warm'? <ul style="list-style-type: none">Set the fridge or freezer temperature to a colder setting. Did you put in food with a strong smell? <ul style="list-style-type: none">Store foods with strong smells in sealed containers. Vegetables or fruit may have spoiled in the drawer. <ul style="list-style-type: none">Throw away rotten vegetables and clean the vegetable drawer. Do not store vegetables too long in the vegetable drawer.

EN 38 TROUBLESHOOTING

Ice & Water

Symptoms	Possible Cause & Solution
The automatic icemaker does not produce ice or produces a small amount of ice.	<p>Did you install the appliance recently?</p> <ul style="list-style-type: none"> The ice maker produces ice normally when approximately 48 hours have passed after the appliance is installed. If the fridge compartment temperature is too cold, the water filter can freeze and block the water flow to the ice maker.
	<p>Did you connect the water supply pipe to the appliance and open the supply valve?</p> <ul style="list-style-type: none"> Connect the water supply pipe to the appliance and open the supply valve completely.
	<p>Is the water supply hose bent?</p> <ul style="list-style-type: none"> If the water supply hose is bent, the water flow could be compromised.
	<p>Have you dispensed a large amount of ice recently?</p> <ul style="list-style-type: none"> It takes approximately 24 hours to produce more ice in the automatic icemaker. Please wait.
	<p>Did you set the ice maker switch or the automatic icemaker button on the control panel to ON?</p> <ul style="list-style-type: none"> Press I on the automatic icemaker switch or set ON for the automatic icemaker button on the control panel. (For more details on how to use, visit LG Electronics website or use your smart device.)
	<p>Is the temperature of the freezer compartment set too high?</p> <ul style="list-style-type: none"> If the set temperature is too warm, ice will be produced slowly or not at all. Set the Freezer temperature to -18 °C for normal operation of the automatic icemaker.
	<p>Have you been opening the appliance door frequently?</p> <ul style="list-style-type: none"> If you open the appliance door frequently, cold air will escape, lowering the speed of ice production. Do not open and close the appliance door frequently.
	<p>Is the appliance door completely closed?</p> <ul style="list-style-type: none"> If the appliance door is not completely closed, the temperature of the freezer compartment will increase, slowing down the ice production speed. Close the appliance door completely.
Ice is not dispensed.	<p>Unable to hear the sound of ice coming out?</p> <ul style="list-style-type: none"> In the control panel, select the modes for cubed ice and crushed ice alternately to dispense the ice.
	<p>Is the ice path blocked? (You can check the ice passage by separating the ice bin.)</p> <ul style="list-style-type: none"> Ice may not be dispensed properly if the ice passage is blocked. Check the ice and clean the ice path regularly.

Symptoms	Possible Cause & Solution
Water does not come out.	<p>The supply valve may be turned off. (For Plumbed models Only)</p> <ul style="list-style-type: none">• Open the water supply valve.• Check if the fridge compartment temperature is too cold, as the water filter can freeze and block the water flow to the dispenser. <p>The water dispenser tank may be empty. (Non plumbed models only)</p> <ul style="list-style-type: none">• Fill the water dispenser tank. <p>Is the water supply valve closed? (For Plumbed models Only)</p> <ul style="list-style-type: none">• Open the water supply valve. <p>Are you using unfiltered water?</p> <ul style="list-style-type: none">• Unfiltered water can contain a large amount of various heavy metals or foreign substances, so the filter may be clogged in the early stage regardless of the life of the filter.
Water tastes strange.	<p>Is the taste of water different when comparing it with the taste of water from the previous water purifier?</p> <ul style="list-style-type: none">• Has the purified water or cold water not been used for an extended period of time? <p>Has it been a long time since you installed and replaced the filter?</p> <ul style="list-style-type: none">• If an expired filter is used, the purification performance may decline. It is recommended to replace the filter according to the filter replacement period. <p>Have you flushed out the filter properly in the initial stage after installing it?</p> <ul style="list-style-type: none">• When you install or replace the filter for the first time, you need to remove air and activated carbon residue from inside the filter. Use the appliance after dispensing and discharging approximately 5 litres of purified water from the dispenser by pressing the water dispensing lever. (Activated carbon is harmless to humans.) <p>Has the purified water or cold water not been used for an extended period of time?</p> <ul style="list-style-type: none">• The taste of old water may change due to bacterial growth. Use the product after dispensing and discharging approximately 5 litres (approximately three minutes) from the water dispenser.

EN 40 TROUBLESHOOTING

Condensation & Frost

Symptoms	Possible Cause & Solution
There is condensation inside the appliance or on the bottom of the vegetable drawer cover.	<p>Did you store hot food without cooling it first?</p> <ul style="list-style-type: none"> Cool the hot food first before putting it inside the fridge or freezer. <p>Did you leave the appliance door open?</p> <ul style="list-style-type: none"> Although the condensation will disappear soon after you close the appliance door, you can wipe it with a dry cloth. <p>Do you open and close the appliance door too frequently?</p> <ul style="list-style-type: none"> Condensation can form due to the temperature difference from the outside. Wipe out the dampness with a dry cloth. <p>Did you put warm or moist food inside without sealing it in a container?</p> <ul style="list-style-type: none"> Store food in a covered or sealed container.
Frost has formed in the freezer compartment.	<p>Doors may not be closed properly.</p> <ul style="list-style-type: none"> Check if the food item inside the appliance is blocking the door and make sure that the door is tightly closed. <p>Did you store hot food without cooling it first?</p> <ul style="list-style-type: none"> Cool the hot food first before putting it in the fridge or freezer compartment. <p>Is the air entry or exit of the freezer compartment blocked?</p> <ul style="list-style-type: none"> Make sure that air entry or exit is not blocked so that the air can circulate inside. <p>Is the freezer compartment overfilled?</p> <ul style="list-style-type: none"> Maintain an appropriate space between items.
Frost or condensation has formed inside or outside the appliance.	<p>Did you open and close the appliance door frequently or is the appliance door improperly closed?</p> <ul style="list-style-type: none"> Frosts or condensation can form if the outside air penetrates inside the appliance. <p>Is the installation environment humid?</p> <ul style="list-style-type: none"> Condensation can appear on the exterior of the appliance if the installation area is too humid or on a humid day such as a rainy day. Wipe off any moisture with a dry cloth.
The side or front of the appliance is warm.	<p>There are anti condensation pipes fitted to these areas of the appliance to reduce condensation forming from around the door area.</p> <ul style="list-style-type: none"> The heat releasing pipe to prevent condensation is installed on the front and side of the appliance. You may feel it particularly hot right after the appliance is installed or during the summer. You can be assured that this is not a problem and is quite normal.

Symptoms	Possible Cause & Solution
There is water inside or outside of the appliance.	<p>Is there water leakage around the appliance?</p> <ul style="list-style-type: none"> Check if the water has leaked from a sink or another place. <p>Is there water on the bottom of the appliance?</p> <ul style="list-style-type: none"> Check if the water is from the thawed frozen food or a broken or dropped container.

Parts & Features

Symptoms	Possible Cause & Solution
The appliance door is not closed tightly.	<p>Is the appliance leaning forward?</p> <ul style="list-style-type: none"> Adjust the front feet to raise the front side slightly. <p>Were the shelves properly assembled?</p> <ul style="list-style-type: none"> Refit the shelves if needed. <p>Did you close the door with excessive force?</p> <ul style="list-style-type: none"> If you apply too much force or speed when closing the door, it may remain briefly open before closing. Make sure that you do not slam the door closed. Close the door gently.
It is difficult to open the appliance door.	<p>Did you open the door right after you closed it?</p> <ul style="list-style-type: none"> If you try to open the appliance door within one minute after you closed it, you may have difficulties because of the pressure inside the appliance. Try to open the appliance door again in a few minutes so that the internal pressure stabilizes.
Door mullion does not fold in and out properly.	<p>Are front levelling legs extended, the appliance level, and doors aligned?</p> <ul style="list-style-type: none"> Once the door baskets are filled, the doors may become misaligned, preventing the door mullion or the Auto Open Door function from working properly. Extend both front levelling legs fully so they are in firm contact with the floor. Follow the instruction in the Door Alignment section to raise the left fridge door until the door mullion is once again working properly. Adjust the right fridge door so it aligns with the left fridge door.
The inside lamp in the appliance does not turn on.	<p>Lamp failure</p> <ul style="list-style-type: none"> Close the door and re-open. If the lamp does not turn on, please contact the LG Electronics customer information centre. Do not attempt removal of the lamp.

EN 42 TROUBLESHOOTING

Noises

Symptoms	Possible Cause & Solution
The appliance is noisy and generates abnormal sounds.	<p>Is the appliance installed on a weak floor or improperly levelled?</p> <ul style="list-style-type: none"> Install the appliance on a solid and flat area. <p>Does the rear of the appliance touch the wall?</p> <ul style="list-style-type: none"> Adjust the installation position to allow enough clearance around the appliance. <p>Are objects scattered behind the appliance?</p> <ul style="list-style-type: none"> Remove the scattered objects from behind the appliance. <p>Is there an object on top of the appliance?</p> <ul style="list-style-type: none"> Remove the object on top of the appliance.
Clicking noises	<p>The defrost control will click when the automatic defrost cycle begins and ends. The thermostat control (or appliance control on some models) will also click when cycling on and off.</p> <ul style="list-style-type: none"> Normal Operation
Rattling noises	<p>Rattling noises may come from the flow of appliance, the water line on the back of the unit (for plumbed models only), or items stored on top of or around the appliance.</p> <ul style="list-style-type: none"> Normal Operation <p>Appliance is not resting evenly on the floor.</p> <ul style="list-style-type: none"> Floor is weak or uneven or levelling legs need to be adjusted. See the Door Alignment section. <p>Appliance with linear compressor was moved while operating.</p> <ul style="list-style-type: none"> Normal operation. If the compressor does not stop rattling after three minutes, turn the power to the appliance off and then on again.
Whooshing noises	<p>Evaporator fan motor is circulating air through the fridge and freezer compartments.</p> <ul style="list-style-type: none"> Normal Operation <p>Air is being forced over the condenser by the condenser fan.</p> <ul style="list-style-type: none"> Normal Operation
Gurgling noises	<p>Appliance flowing through the cooling system.</p> <ul style="list-style-type: none"> Normal Operation
Popping noises	<p>Contraction and expansion of the inside walls due to changes in temperature.</p> <ul style="list-style-type: none"> Normal Operation

Symptoms	Possible Cause & Solution
Vibrating	<p>If the side or back of the appliance is touching a cabinet or wall, some of the normal vibrations may make an audible sound.</p> <ul style="list-style-type: none">To eliminate the noise, make sure that the sides and back do not make any contact with any wall or cabinet.

Wi-Fi

Symptoms	Possible Cause & Solution
Your home appliance and smartphone are not connected to the Wi-Fi network.	<p>The password for the Wi-Fi that you are trying to connect to is incorrect.</p> <ul style="list-style-type: none">Find the Wi-Fi network connected to your smartphone and remove it, then register your appliance on LG ThinQ. <p>Mobile data for your smartphone is turned on.</p> <ul style="list-style-type: none">Turn off the Mobile data of your smartphone and register the appliance using the Wi-Fi network. <p>The wireless network name (SSID) is set incorrectly.</p> <ul style="list-style-type: none">The wireless network name (SSID) should be a combination of English letters and numbers. (Do not use special characters.) <p>The router frequency is not 2.4 GHz.</p> <ul style="list-style-type: none">Only a 2.4 GHz router frequency is supported. Set the wireless router to 2.4 GHz and connect the appliance to the wireless router. To check the router frequency, check with your Internet service provider or the router manufacturer. <p>The distance between the appliance and the router is too far.</p> <ul style="list-style-type: none">If the distance between the appliance and the router is too far, the signal may be weak and the connection may not be configured correctly. Move the location of the router so that it is closer to the appliance.

Memo

Memo

الأعراض	السبب المحتمل والحل
أصوات غرفة	تدفق الجهاز خلال نظام التبريد. • تشغيل عادي
أصوات فرقعة	انكماش الجدران الداخلية وتوسعتها بسبب التغيرات في درجة الحرارة. • تشغيل عادي
الاهتزاز	في حال كان الجزء الجانبي أو الخلفي من الجهاز يلامس خزانة أو حائط، قد تُصدر بعض الاهتزازات العادبة صوتاً مسموعاً.

(واي فاي) Wi-Fi

الأعراض	السبب المحتمل والحل
جهازك المنزلي أو هاتفي الذكي غير متصلين بشبكة Wi-Fi.	كلمة المرور للاتصال بشبكة Wi-Fi التي تحاول الاتصال بها غير صحيحة. • اعثر على شبكة Wi-Fi المتصلة بهاتفك الذكي ثم قم بإنزالها، ثم سجل جهازك على LG ThinQ.
بيانات الهاتف المحمول في هاتفك الذكي مقطعة.	توقف بيانات الهاتف المحمول على هاتفك الذكي وسجل الجهاز باستخدام شبكة Wi-Fi.
لم يتم إعداد اسم الشبكة اللاسلكية (SSID) بشكل صحيح.	يجب أن يكون اسم الشبكة اللاسلكية (SSID) مكوناً من أحرف وأرقام باللغة الإنجليزية. (لا تستخدم رموزاً خاصة)
تردد جهاز التوجيه ليس 2.4 غيغا هرتز.	يتم دعم جهاز التوجيه بتردد 2.4 غيغا هرتز فقط. اضبط جهاز التوجيه اللاسلكي على 2.4 غيغا هرتز ثم وصل الجهاز بجهاز التوجيه اللاسلكي. للتحقق من تردد جهاز التوجيه، راجع مزودو خدمة الإنترنت الخاص بك أو مصنع جهاز التوجيه.
المسافة بين الجهاز وجهاز التوجيه أبعد من اللازم.	إذا كانت المسافة بين الجهاز وجهاز التوجيه أبعد من اللازم، قد تكون الإشارة ضعيفة وقد يتعرض تكوينه بشكل صحيح. انقل جهاز التوجيه من مكانه حتى يصبح أقرب إلى الجهاز.

الأعراض	السبب المحتمل والحل
عدم الباب لا ينطوى للداخل والخارج بشكلٍ صحيح.	<p>هل الأرجل الأمامية ممتدّة، والثلاثة مستوية، والأبواب متحانة؟</p> <ul style="list-style-type: none"> بمجرد ملء سلاسل الباب، قد تصبح الأبواب متحانة بطريقة غير صحيحة، مما يمنع وظيفة عدم الباب أو وظيفة فتح الباب تلقائياً من العمل بشكل صحيح. قم بدمج ضبط المستوى الأماميين بالكامل بحيث تكونان في اتصال ثابت بالأرض. اتبع التعليمات الموجودة في قسم محاذاة الباب لرفع باب الثلاثة الأيسر حتى يصبح عدم الباب يعمل بشكل صحيح مرة أخرى. قم بضبط باب الثلاثة الأيمن ليتم محاذاته مع باب الثلاثة الأيسر.
المصابح الداخلية في الجهاز لا يضيء.	<p>قطع في المصابح</p> <ul style="list-style-type: none"> أغلق الباب وأعد فتحه. إذا لم يتم تشغيل المصابح، فرجّي الاتصال بمركز معلومات العملاء في شركة LG Electronics. لا تحاول فك المصابح.

الصحيح

الأعراض	السبب المحتمل والحل
الجهاز صاخب ويصدر أصواتاً غير طبيعية.	<p>هل تم تثبيت الجهاز على أرضية ضعيفة أو غير مستوية بشكل صحيح؟</p> <ul style="list-style-type: none"> قم بتركيب الجهاز على أرضية صلبة ومستوية.
أصوات الطقطقة	<p>هل تلامس الجهة الخلفية من الجهاز الحائط؟</p> <ul style="list-style-type: none"> اضبط ووضع التثبيت للسامح بمساحة محيطة كافية حول الجهاز.
أصوات قفعقة	<p>هل الأشياء المبعثرة خلف الجهاز؟</p> <ul style="list-style-type: none"> أزل الأشياء المبعثرة من خلف الجهاز.
أصوات ازير	<p>هل يوجد كائن على الجزء العلوي من الجهاز؟</p> <ul style="list-style-type: none"> أزل الكائن الموجود على الجزء العلوي من الجهاز. <p>سيصدر التحكم في إزالة الصفع طقطقة عند بدء دورة إزالة الصفع التلقائي وانتهاء الدورة. سيصدر التحكم في الترمومسات (أو التحكم في الجهاز في بعض الطرز) أيضاً طقطقة عند تشغيل الدورة وإيقافها.</p> <ul style="list-style-type: none"> تشغيل عادي <p>قد تصدر أصوات القفعقة من تدفق الجهاز، أو خط المياه في الجزء الخلفي من الوحدة (للطرز الرئيسية فقط)، أو العناصر المخزنة في الجزء العلوي أو حول الجهاز.</p> <ul style="list-style-type: none"> تشغيل عادي <p>الجهاز غير مستقر بشكل متساوٍ على الأرضية.</p> <ul style="list-style-type: none"> الارضية ضعيفة أو غير مستوية أو أرجل التسوية تحتاج إلى تعديل. انظر قسم محاذاة الباب. <p>الجهاز المزود بضاغط طولي قد يتحرك أثناء التشغيل.</p> <ul style="list-style-type: none"> عملية التشغيل الطبيعية. في حال كان الضاغط لا يتوقف عن القفعة بعد ثلاث ثوان، قم بإيقاف تشغيل الطاقة للجهاز ثم قم تشغيلها مرة أخرى. <p>ينشر محرك مروحة المبرد الهواء داخل وحدات المجمد والثلاثة.</p> <ul style="list-style-type: none"> تشغيل عادي <p>يتم دفع الهواء عبر المكثف بواسطة مروحة المكثف.</p> <ul style="list-style-type: none"> تشغيل عادي

الأعراض	السبب المحتمل والحل
نكون الصقيع بالجمد.	<p>قد لا تكون الأبواب مغلقة بشكل صحيح.</p> <ul style="list-style-type: none"> افحص ما إذا كان عنصر الطعام الموجود داخل الجهاز يعيق الباب وتتأكد من أن الباب مغلق بإحكام.
الصقيع أو التكتيف تكون داخل الجهاز أو خارجه.	<p>هل قمت بتخزين الطعام الساخن دون تبريد أولاً؟</p> <ul style="list-style-type: none"> برد الطعام الساخن أولاً قبل وضعه داخل الثلاجة أو المجمد. <p>هل مدخل أو مخرج الهواء الخاص بالجمد مسدود؟</p> <ul style="list-style-type: none"> تأكد من عدم انسداد مدخل أو مخرج الهواء حتى يمكن تدوير الهواء بالداخل. <p>هل تم الإفراط في ملء المجمد؟</p> <ul style="list-style-type: none"> حافظ على وجود مسافة مناسبة بين المواد. <p>هل تفتح باب الجهاز وتغلقه كثيراً أو هل باب الجهاز مغلق بشكل غير صحيح؟</p> <ul style="list-style-type: none"> يمكن أن يتشكل الصقيع أو التكتيف في حال كان الهواء الخارجي يخترق داخل الجهاز. <p>هل بيئة التثبيت رطبة؟</p> <ul style="list-style-type: none"> يمكن أن يظهر التكتيف على سطح الجهاز في حال كانت منطقة التثبيت رطبة جدًا أو في يوم رطب مثل يوم مطر. امسح أيام رطوبة باستخدام قطعة قماش جافة.
الجزء الجانبي أو الأمامي من الجهاز دافئ.	<p>توجد أنابيب التخلص من التكتيف مثبتة بهذه المناطق من الجهاز لتقليل التكتيف المتكون حول منطقة الباب.</p> <ul style="list-style-type: none"> يتم تثبيت أنبوب تحرير الحرارة على الجانب الأمامي والجانبي من الجهاز لمنع التكتيف. قد تشعر بأنه ساخن باللمس مباشرةً بعد تثبيت الجهاز أو أثناء الصيف. يمكنك أن تتأكد من أن هذه ليست مشكلة وأن هذا الأمر طبيعي جدًا. <p>هل يوجد تسرب مياه حول الجهاز؟</p> <ul style="list-style-type: none"> تحقق مما إذا تسربت المياه من أحد الأحواض أو من مكان آخر. <p>هل توجد مياه على الجزء السفلي من الجهاز؟</p> <ul style="list-style-type: none"> تحقق مما إذا كانت المياه ناتجة عن الطعام المجمد الذائب أو من حاوية مكسورة أو ساقطة.
نوجد مياه داخل الجهاز وخارج.	

الأجزاء والخواص

الأعراض	السبب المحتمل والحل
باب الجهاز غير مغلق بإحكام.	<p>هل الجهاز مائل للأمام؟</p> <ul style="list-style-type: none"> اضبط القدم الأمامية لرفع الجانب الأمامي قليلاً.
من الصعب فتح باب الجهاز.	<p>هل تم تركيب الأرفف بشكل سليم؟</p> <ul style="list-style-type: none"> أعد تركيب الأرفف إذا لزم الأمر. <p>هل أغلقت الباب بقوة مفرطة؟</p> <ul style="list-style-type: none"> في حال كنت تستخدم قوة أو سرعة أكثر من اللازم عند غلق الباب، قد يظل مفتوحاً لفترة وجيزة قبل الإغلاق. تتأكد من أنك لا تغلق الباب بعنف.أغلق الباب برفق. <p>هل فتحت الباب بعد إغلاقه مباشرةً؟</p> <ul style="list-style-type: none"> في حال كنت تحاول فتح باب الجهاز في غضون دقيقة بعد إغلاقه، قد تواجه صعوبات بسبب الضغط الموجود داخل الجهاز. حاول أن تفتح باب الجهاز مرة أخرى في غضون دقائق قليلة حتى يستقر الضغط الداخلي.

الأعراض	السبب المحتمل والحل
المياه لا تخرج.	<p>قد يتم إيقاف تشغيل صمام المزود. (للطرز الرأسية فقط)</p> <ul style="list-style-type: none"> اقتح صمام مزود المياه. تحقق من درجة حرارة وحدة الثلاجة فإذا كانت شديدة البرودة، سيؤدي ذلك إلى تجمد مرشح (فلتر) المياه ومنع تدفق المياه في موزع المياه.
يبدو مذاق المياه غريباً.	<p>قد يكون خزان موزع المياه فارغاً. (للطرز غير الرأسية فقط)</p> <ul style="list-style-type: none"> املاً خزان موزع المياه.
يبدو مذاق المياه غريباً.	<p>هل صمام مزود المياه مغلق؟ (للطرز الرأسية فقط)</p> <ul style="list-style-type: none"> اقفتح صمام مزود المياه.
يبدو مذاق المياه غريباً.	<p>هل تستخدم مياه غير مرشحة؟</p> <ul style="list-style-type: none"> يمكن أن تحتوي المياه غير المرشحة على كمية كبيرة من المعادن الثقيلة أو المواد الغريبة، إذا فإن المرشح قد يكون مسدواً في المرحلة الأولى بغض النظر عن عمر المرشح.
يبدو مذاق المياه غريباً.	<p>هل مذاق المياه مختلفاً عند مقارنته بمذاق مياه من جهاز تنقية؟</p> <ul style="list-style-type: none"> هل المياه النقية أو المياه الباردة لم تستخدم لفترة طويلة من الزمن؟
يبدو مذاق المياه غريباً.	<p>هل مضى وقت طويل منذ أن قمت بثبيت المرشح واستبداله؟</p> <ul style="list-style-type: none"> في حال استخدام مرشح منتهي الصلاحية، قد ينخفض أداء التنقية. يوصى باستبدال المرشح وفقاً لفترة استبدال المرشح.
يبدو مذاق المياه غريباً.	<p>هل قمت بتنظيف المرشح بماء متافق بشكل سليم في المرحلة الأولى بعد ثبيته؟</p> <ul style="list-style-type: none"> عند ثبيت أو استبدال المرشح للمرة الأولى، أنت بحاجة لإزالة الهواء وبقايا الكربون النشط من داخل المرشح. استخدم الجهاز بعد توزيع وتفرير حوالي 5 لترات من المياه النقية من الموزع عن طريق الضغط على رافعة توزيع المياه. (الكربون المشطط غير ضار للبشر)
يبدو مذاق المياه غريباً.	<p>هل المياه النقية أو المياه الباردة لم تستخدم لفترة طويلة من الزمن؟</p> <ul style="list-style-type: none"> قد يتغير مذاق المياه القديمة بسبب النمو البكتيري. استخدم المنتج بعد توزيع وتفرير حوالي 5 لترات (حوالي ثلاثة دقائق) من موزع المياه.

التكتيف والمصقىع

الأعراض	السبب المحتمل والحل
يوجد تكتيف داخل الجهاز أو على أسفل غطاء درج الخضراء.	<p>هل قمت بتخزين الطعام الساخن دون تبريد أولًا؟</p> <ul style="list-style-type: none"> قم بتبريد الطعام الساخن أولًا قبل وضعه داخل الثلاجة أو المجمد.
يوجد تكتيف داخل الجهاز أو على أسفل غطاء درج الخضراء.	<p>هل ترك باب الجهاز مفتوحاً؟</p> <ul style="list-style-type: none"> على الرغم من أن التكتيف سيختفي مباشرةً بعد غلق باب الجهاز، يمكنك مسحه باستخدام قطعة قماش جافة.
يوجد تكتيف داخل الجهاز أو على أسفل غطاء درج الخضراء.	<p>هل تفتح باب الجهاز وتغلقه كثيراً؟</p> <ul style="list-style-type: none"> يمكن أن يتكون التكتيف بسبب الحرارة المختلفة عن الخارج. امسح الرطوبة باستخدام قطعة قماش جافة.
يوجد تكتيف داخل الجهاز أو على أسفل غطاء درج الخضراء.	<p>هل تضع طعاماً رطباً أو دافئاً بالداخل بدون عزله في حاوية؟</p> <ul style="list-style-type: none"> خزن الطعام في وعاء مغطى أو محكم الغلق.

الثلج والماء

الأعراض	السبب المحتمل والحل
<p>لا ينتع صانع الثلج التلقائي ثلجاً أو ينتع كمية صغيرة من الثلج.</p>	<ul style="list-style-type: none"> هل قمت بتنبيت الجهاز مؤخراً؟ ينتج صانع الثلج ثلجاً بشكل طبيعي عند انتهاء 48 ساعة تقريباً بعد تنبيت الجهاز. قد يتجمد المرشح ويمنع تدفق الماء في صانع الثلج إذا كانت درجة حرارة وحدة الثلاجة شديدة البرودة.
<p>لا ينتع صانع الثلج التلقائي ثلجاً أو ينتع كمية صغيرة من الثلج.</p>	<ul style="list-style-type: none"> هل قمت بتوصيل أنبوب مزود المياه بالجهاز وفتح صمام المزود؟ قم بتوصيل أنبوب مزود المياه بالجهاز وفتح صمام المزود بالكامل.
<p>لا ينتع صانع الثلج التلقائي ثلجاً أو ينتع كمية صغيرة من الثلج.</p>	<ul style="list-style-type: none"> هل خرطوم مزود المياه منحنٍ؟ في حال كان خرطوم مزود المياه منحنياً، يمكن تقليل تدفق المياه.
<p>لا ينتع صانع الثلج التلقائي ثلجاً أو ينتع كمية كبيرة من الثلج.</p>	<ul style="list-style-type: none"> هل قمت بتوزيع كمية كبيرة من الثلج مؤخراً؟ يطلب الأمر 24 ساعة تقريباً لإنتاج المزيد من الثلوج في صانع الثلج التلقائي. يرجى الانتظار.
<p>لا ينتع صانع الثلج التلقائي ثلجاً أو ينتع كمية كبيرة من الثلوج.</p>	<ul style="list-style-type: none"> هل قمت بضبط مفتاح صانع الثلج أو زر تشغيل صانع الثلج التلقائي على لوحة التحكم على وضع التشغيل؟ اضغط على إ على مفتاح صانع الثلج التلقائي أو اضبط زر صانع الثلج التلقائي على وضع التشغيل ON على لوحة التحكم. (الحصول على المزيد من التفاصيل حول كيفية الاستخدام، قم بزيارة موقع شركة LG Electronics أو استخدم الجهاز الذكي الخاص بك).
<p>لا ينتع صانع الثلج التلقائي ثلجاً أو ينتع كمية كبيرة من الثلوج.</p>	<ul style="list-style-type: none"> هل درجة حرارة وحدة المُجمد تم ضبطها لتكون مرتفعة للغاية؟ في حال كانت درجة الحرارة المحددة دافئة جدًا، سيتم إنتاج الثلوج ببطء أو لن يتم إنتاجه على الإطلاق. اضبط درجة حرارة المُجمد على 18 درجة مئوية للحصول على عملية تشغيل طبيعية لصانع الثلج التلقائي.
<p>لا ينتع صانع الثلج التلقائي ثلجاً أو ينتع كمية كبيرة من الثلوج.</p>	<ul style="list-style-type: none"> هل تقوم بفتح باب الجهاز كثيراً؟ في حال كنت تفتح باب الجهاز كثيراً، سيتسرب الهواء البارد، وستقل سرعة إنتاج الثلوج. لا تفتح باب الجهاز وتغلقه كثيراً.
<p>لا ينتع صانع الثلج التلقائي ثلجاً أو ينتع كمية كبيرة من الثلوج.</p>	<ul style="list-style-type: none"> هل باب الجهاز مغلق بالكامل؟ في حال كان باب الجهاز مفلاً تماماً، فإن درجة حرارة وحدة المُجمد سترتفع، وستقل سرعة إنتاج الثلوج.أغلق باب الجهاز تماماً.
<p>لا ينتع صانع الثلج التلقائي ثلجاً أو ينتع كمية كبيرة من الثلوج.</p>	<ul style="list-style-type: none"> يتعذر عليك سماع صوت خروج الثلوج؟ في لوحة التحكم، حدد وضعى الثلوج المكعب والثلوج المجروش بشكل تبادلى لتوزيع الثلوج.
<p>لا ينتع صانع الثلج التلقائي ثلجاً أو ينتع كمية كبيرة من الثلوج.</p>	<ul style="list-style-type: none"> هل مسار الثلوج مسدود؟ (يمكنك فحص ممر الثلوج عن طريق فصل صندوق الثلوج). قد لا يتم توزيع الثلوج بشكل صحيح إذا كان ممر الثلوج مسدوداً. افحص الثلوج وقم بتنظيف مسار الثلوج بشكل منتظم.



استكشاف الأعطال وإصلاحها

قبل الاتصال للحصول على الخدمة

التبريد

الأعراض	السبب المحتمل والحل
لا يوجد تبريد أو تجميد.	<ul style="list-style-type: none"> هل هناك انقطاع في التيار الكهربائي؟ افحص طاقة الأجهزة الأخرى. <p>افحص طاقة الأجهزة الأخرى.</p> <ul style="list-style-type: none"> قم بتوصيل قابس الطاقة في مأخذ التيار الكهربائي بشكل سليم.
يوجد تبريد أو تجميد رديء.	<ul style="list-style-type: none"> هل تم ضبط درجة حرارة المجمد إلى الإعداد الأكثر دفناً الخاص بها؟ قم بتعيين درجة حرارة الثلاجة أو المجمد على إعداد أكثر برودة. <p>هل الجهاز معرض لضوء شمس مباشر، أو هل هو قريب من كائن مولد للحرارة مثل فرن طهي أو سخان؟</p> <ul style="list-style-type: none"> تحقق من منطقة التركيب وأعد تركيب المنتج بعيداً عن الأشياء التي تصدر الحرارة. <p>هل قمت بتخزين الطعام الساخن دون تبریده أولاً؟</p> <ul style="list-style-type: none"> برد الطعام الساخن أولاً قبل وضعه داخل الثلاجة أو المجمد. <p>هل تضع الكثير جداً من الأطعمة؟</p> <ul style="list-style-type: none"> حافظ على وجود مسافة مناسبة بين الأطعمة. <p>هل أبواب الجهاز مقفلة بالكامل؟</p> <ul style="list-style-type: none"> قم بإغلاق الباب بشكل كامل وتأكد من أن الطعام المخزن لا يعيق الباب. <p>هل توجد مساحة كافية حول الجهاز؟</p> <ul style="list-style-type: none"> اضبط ووضع التثبيت لتوفير مساحة كافية حول الجهاز.
يحتوي الجهاز على رائحة سيئة.	<ul style="list-style-type: none"> هل تم ضبط درجة حرارة المجمد على وضع "دافئ"؟ قم بتعيين درجة حرارة الثلاجة أو المجمد على إعداد أكثر برودة. <p>هل وضعت طعاماً ذات رائحة قوية؟</p> <ul style="list-style-type: none"> قم بتخزين الأطعمة التي تحتوي على روانق قوية في حاويات مغلقة. <p>قد تفسد الخضروات أو الفاكهة في الدرج.</p> <ul style="list-style-type: none"> تخالص من الخضروات المتعرجة ونظف درج الخضروات. لا تقم بتخزين الخضروات لفترة طويلة جداً في درج الخضروات.

4 قم بتركيب الرأس الحازوني بالحكام حتى يصبح الخط الملون في مرشح المياه غير مرئي.



5 اضغط مع الاستمرار على زر **Water Filter** لمدة ثلاثة ثوانٍ، حيث يعيد ذلك ضبط الرمز **Replacement Filter**. تم تفعيل مرشح المياه الجديد.

6 لإزالة الهواء المحبوس والملوثات من النظام، قم بتوزيع المياه لمدة 5 دقائق تقريباً.

١! تنبيه


- الفشل في استبدال المرشح عند اللزوم أو استخدام مرشحات مياه غير معتمدة من LG يمكن أن يتسبب في حدوث تسرب في وحدة المرشح وإتلاف الممتلكات.

5 اضغط مع الاستمرار على زر **Water Filter** لمدة ثلاثة ثوانٍ، حيث يعيد ذلك ضبط الرمز **Replacement Filter**. تم تفعيل مرشح المياه الجديد.


6 لإزالة الهواء المحبوس والملوثات من النظام، قم بتوزيع المياه لمدة 5 دقائق تقريباً.

نوع موصلات مناسبة لدفع^{*}


1 أزل الرأس الحازوني للبراغي.



2 اسحب الأنابيب خارج مرشح المياه.



3 ادفع الأنابيب في مرشح المياه، وتأكد من أنه بالداخل حتى طرفه.



دليل التشغيل/معلومات الإمداد بالمياه	
ضغط الماء	827 كيلو بسكال - 138
درجة حرارة الماء	37.8 - 0.6 درجة مئوية
السعة	1892 لتر

استبدال مرشح المياه (طراز رأسي)

* لا تتوفر هذه الخاصية إلا في بعض الطرز.

يجب استبدال المرشح كل 6 أشهر أو عندما يضي المؤشر أو يقل قدرة إخراج موزع المياه.


• لشراء فلتر مياه البديل:

- استخدم الوحدة البديلة: **ADQ736939


- قم بزيارة التاجر أو الموزع المحلي أو الاتصال بمركز معلومات العملاء في شركة LG Electronics. وللحصول على المزيد من المساعدة قم بزيارة موقعنا lg.com

النوع صالح سنة سنتين *1


1 فك الرأس الحارزوني.



2 اسحب الأنابيب خارج رأس مرشح المياه حتى يصبح الخط الملون مرئياً.



3 ادفع الأنابيب في رأس مرشح المياه، وتأكد من أنه بالداخل حتى طرفه.



Water Filter (مرشح المياه)

قبل عملية استبدال فلتر المياه

تحذير !

- لا تسمح للأطفال بالعبث بأجزاء المنتج الصغيرة أثناء تركيبه.
- لا تستخدم الجهاز مع المياه غير الآمنة ميكروبيولوجياً أو مع كمية المياه غير المعروفة دون تطهير كافٍ قبل استخدام النظام أو بعده. يمكن استخدام أنظمة معتمدة لتخفيف نسبة المغليات في المياه غير المطهرة والتي قد تحتوي على طفيليات قبلة للتصفيه.

تنبيه !

- يُحظر تركيب المنتج إذا تجاوز ضغط المياه 827 كيلو بسكال. في حالة تجاوز ضغط المياه 827 كيلو بسكال فيجب تركيب صمام التحكم في الضغط. اتصل بفني السباكة إذا كنت غير متأكد من كيفية التحقق من ضغط المياه.
- يُحظر تركيب المنتج إذا وقعت حالات ضغط المياه (المطرقة المائية). عند وقوع حالات ضغط المياه (المطرقة المائية)، فيجب تركيب نظام حجز ضغط المياه. اتصل بفني السباكة إذا كنت غير متأكد من كيفية التتحقق من هذه الحاله.
- يُحظر تركيب المنتج فوق خطوط إمداد الماء الساخن. يبلغ الحد الأقصى لدرجة حرارة الماء لنظام التصفية هذا 37.8 درجة مئوية.
- حافظ على الفلتر من التجمد. قم بتصريف المياه من الفلتر إذا انخفضت درجة الحرارة إلى أقل من 4.4 درجة مئوية.
- يجب استبدال وحدة الفلتر غير القابلة لإعادة الاستخدام كل ستة أشهر بناء على السعة المقررة لها أو عند حدوث انخفاض ملحوظ في معدل التدفق.
- عند تركيب جهاز حماية من التدفق على نظام المياه، فيجب تركيب جهاز للتحكم في الضغط الناتج عن التجمد الحراري.
- تأكد أن جميع الأنابيب والتجهيزات مثبتة بحكام وخلالية من أي تسربات.

ملاحظة

- بالرغم من إجراء الاختبار في ظروف مخبرية قياسية، فقد يختلف الأداء الفعلي.
- من ضروري اتباع توصيات الشركة المصنعة أثناء تركيب وصيانة واستبدال الفلتر الخاص بالمنتج كما هو معلن عنه.


دليل التشغيل/معلومات الإمداد بالمياه	
تدفق الخدمة	1.9 لتر في الدقيقة
الإمداد بالمياه الشرب	بنر خاص أو بنر خاص بالمدينة - مياه الشرب

الصيانة

التنظيف

تنظيف غطاء المكثف

استخدم المكنسة الكهربائية مع الفرشاة لتنظيف غطاء المكثف وفتحات التهوية.
تجنب إزالة اللوحة التي تغطي منطقة لافت المكثف.
نوصي القيام بهذا الإجراء كل 12 شهراً للمحافظة على كفاءة التشغيل.



نصائح عامة حول التنظيف

- عند تنظيف الجهاز من الداخل أو الخارج، تجنب مسحه بفرشاة خشنة، أو مجرون أستان، أو مواد قابلة للاشتعال. تجنب استخدام مواد التنظيف التي تحتوي على مكونات قابلة للاشتعال. قد يتسبب ذلك في تغيير الألوان أو إتلاف الجهاز.
- المواد القابلة للاشتعال: الكحول (إيثانول، الميثanol، الكحول الأيزوبروبيلي، الكحول الأيزوبوريتيل، الخ)، المواد المخففة (التر)، المبيض، البنزين، السائل القابل للاشتعال، المواد الكاشطة، الخ.
- بعد التنظيف، تأكد إذا كان كابل الطاقة تلفاً.

تنظيف الهيكل الخارجي

- في حال تنظيف فتحات التهوية الخارجية من الجهاز عن طريق المكنسة الكهربائية، دعمني يجب أن يكون كبل الطاقة غير موصل من المأخذ لتجنب أي تفريغ شحنات قد ينافس الأجهزة الإلكترونية أو قد يسبب صدمة كهربائية. يوصى بالإجراء تنظيف منتظم لأعطيه فتحات التهوية الخارجية والجانبية للمحافظة على تشغيل موثق به واقتصادي للجهاز.
- يجب المحافظة على نظافة فتحات التهوية الخارجية الموجودة على سطح الجهاز. حيث ينجم عن انسداد فتحات التهوية تشكيل حريق أو تلف الجهاز.
- استخدم في تنظيف سطح الجهاز سفحة نظيفة أو قطعة قماش ناعمة ومنتفقة خففًا في مياه دافئة. ولا تستخدم منتفقات جافة أو خشنة. كما يجب إلا تستخدم قطع القماش الملؤنة عند تنظيف الأدوات المصنوعة من الصلب المقاوم للصدأ. احرص دائمًا على استخدام قطعة قماش مخصصة ومسحة في نفس اتجاه السطح. حيث يساهم ذلك في تقليل حدوث البقع على السطح أو فقدان لمعانه.

تنظيف داخلي

- عند إزالة رف أو درج من داخل الجهاز، قم بإزالة جميع الأطعمة المخزنة من الرف أو الدرج لمنع التعرض لإصابة أو تلف بالجهاز. بخلاف ذلك، قد تحدث الإصابة بسبب وزن الأطعمة المخزنة.
- افصل الرفوف والأدراج وقم بتنظيفها باستخدام المياه، ثم قم بتجفيفها بما فيه الكافية، قبل إعادتها إلى مكانها.
- يشكل منتفظ قم بمسح حشية الباب باستخدام منشفة ناعمة مبللة.
- يجب أن يتم تنظيف الكهربات المنسكبة من سلة الباب والبعض لأنها يمكن أن تنقل قدرة التفريز الخاصة بالسلة ويمكنها حتى أن تتلف.
- لا تتم مطلقاً إلى تنظيف الأرفف أو الأوعية في غسالة الأطباق. قد تصبح القطع مشوهة بسبب الحرارة.

استخدام تطبيق LG ThinQ بغرض تشخيص المشكلات

إذا واجهت مشكلة أثناء استخدام الجهاز المزود بشبكة Wi-Fi، فحينها يمكن نقل بيانات استكشاف الأخطاء وإصالتها إلى هاتف ذكي باستخدام تطبيق **LG ThinQ**.

- قم بتشغيل تطبيق **LG ThinQ** واختر ميزة **Smart Diagnosis**.
من القائمة، اتبع التعليمات الواردة في تطبيق **LG ThinQ**.

استخدام "التشخيص المسموع" بغرض تشخيص المشكلات


اتبع التعليمات أدناه للاستعانة بطريقة التشخيص المسموع.

- قم بتشغيل تطبيق **LG ThinQ** واختر ميزة **Smart Diagnosis**.
من القائمة، اتبع تعليمات استخدام التشخيص المسموع الواردة في تطبيق **LG ThinQ**.

1 اضغط على زر **Lock** لتنشيط وظيفة القفل.

- إذًا تم قفل شاشة العرض لمدة تزيد عن 5 دقائق ، يجب أن تقوم بالغاء التفعيل ثم إعادة تفعيله.

2 افتح باب الثلاجة ثم أمسك الهاتف على فتحة السماعة اليمنى العلوية.



3 اضغط مع الاستمرار على الزر **Freezer** لمدة ثلاثة ثوانٍ أو أكثر بينما تمسك هاتفك نهاية الساعة حتى يتم نقل البيانات.

- * يُصْنَع صوت التشخيص بعد 3 ثوانٍ تقريبًا.

4 بعد إتمام نقل البيانات، سيظهر التشخيص على شاشة التطبيق.

ملاحظة

- للحصول على أفضل نتائج،تجنب تحريك الهاتف بينما يتم إصدار الأصوات.

الاتصال بشبكة Wi-Fi

يتوج استخدام زر **Wi-Fi** مع تطبيق **LG ThinQ** لإمكانية توصيل الجهاز بشبكة Wi-Fi منزلية. توضح أيقونة حالة اتصال شبكة الجهاز. حيث تضيء الأيقونة عندما يكون الجهاز متصل بشبكة Wi-Fi.

- التسجيل الأولى للجهاز
شُغل تطبيق **LG ThinQ** واتبع التعليمات في التطبيق لتسجيل الجهاز.
إعادة تسجيل الجهاز أو تسجيل مستخدم آخر.
اضغط مع الاستمرار على زر **Wi-Fi** لمدة 3 ثوانٍ لإيقافه مؤقتاً. شُغل تطبيق **LG ThinQ** واتبع التعليمات في التطبيق لتسجيل الجهاز.

ملاحظة

- لتعطيل وظيفة **Wi-Fi**، اضغط مع الاستمرار على زر **Wi-Fi** لمدة 3 ثوانٍ. سوف يتم إيقاف تشغيل أيقونة .

معلومات حول إشعار البرامج المفتوحة المصدر

للحصول على التعليمات البرمجية المصدر بموجب **GPL** و **LGPL** و **MPL** وترخيص مفتوحة المصدر أخرى يتضمنها هذا المنتج، يرجى زيارة الموقع <http://opensource.lge.com>. بالإضافة إلى التعليمات البرمجية المصدر، توفر كل أحكام الترخيص وإشعارات إخلاء المسؤولية وأشعارات حقوق النشر للتوزيل. ستتوفر **LG Electronics** أيضًا التعليمات البرمجية المفتوحة المصدر على قرص CD-ROM مقابل رسوم يغطي تكلفة القيام بهذا التوزيع (مثل تكلفة وسائل القفل والشحن والتسلیم) بناءً على طلب يرسل عبر البريد الإلكتروني إلى opensource@lge.com. إن هذا العرض سار لفترة ثلاثة سنوات بعد عملية التسحن الأخيرة لهذا المنتج. يتوفر هذا العرض لأي شخص يتلقى هذه المعلومات.

التشخيص الذكي


تتوفر هذه الميزة فقط في الطرز الذي تحمل العلامة أو . يمكن الاستعانة بهذه الميزة لتشخيص المشكلات التي تواجهك أثناء استخدام الجهاز وحلها.

ملاحظة

- قد لا تعمل هذه الخدمة وذلك يعود لعوامل خارجية على سبيل المثال لا الحصر، عدم توفر شبكة Wi-Fi أو انقطاع الاتصال بشبكة Wi-Fi أو السياسة المحلية لمتجر التطبيقات أو عدم توفر التطبيق وهذه أسباب لا تتم عن تقصير من **LGE**.
- قد تتعرض هذه الميزة لتغيرات دون سابق إنذار وقد يختلف شكلها وفقًا للمنطقة التي تسكن فيها.

الوظائف الذكية

3 وصل هاتفك الذكي بجهاز التوجيه اللاسلكي.



ملاحظة

- للتحقق من اتصال Wi-Fi، افحص رمز على لوحة التحكم ما إذا كان مضبوطاً.
- يدعم الجهاز شبكات Wi-Fi بتردد 2.4 GHz فقط. لمعرفة تردد الشبكة الخاصة بك، اتصل بمزود خدمة الإنترنت أو راجع دليل جهاز التوجيه اللاسلكي.
- تطبيق **LG ThinQ** ليس مسؤولاً عن أي مشاكل الاتصال بالشبكة أو أي أخطاء، أو خلل، أو أخطاء تنتجه عن طريق الاتصال بالشبكة.
- إذا كان لدى الجهاز مشكلة اتصال بشبكة Wi-Fi، قد تكون بعيدة كل البعد عن جهاز التوجيه. اشتري جهاز تقوية Wi-Fi (موسع المدى) لتحسين قوة إشارة Wi-Fi.
- قد لا يتم الاتصال بشبكة Wi-Fi أو قد يتم قطع الاتصال حسب جودة بيئه الشبكة المحلية.
- قد لا يعمل الاتصال بالشبكة بشكل صحيح وفقاً لمزود خدمة الإنترنت.
- يمكن أن تجعل البيئة اللاسلكية المحيطة خدمة الشبكة اللاسلكية تعمل ببطء.
- تعذر تسجيل الجهاز بسبب مشكلات في إرسال الإشارة لاسلكياً. أفصل قابس الجهاز عن الطاقة وانتظر لمدة دقيقة قبل أن تحاول مجدداً.
- إذا كان جدار الحماية الموجود على جهاز التوجيه الخاص بك ممكناً، قم بتعطيله أو اضف إليه استثناء.
- يجب أن يكون اسم الشبكة اللاسلكية (SSID) مكوناً من أحرف وأرقام باللغة الإنجليزية. (لا تستخدم رموزاً خاصة)
- قد تختلف واجهة استخدام الهاتف الذكي حسب نظام تشغيل الهاتف وحسب الشركة المصنعة.
- إذا كان بروتوكول الأمان الخاص الخاص بجهاز التوجيه مضبوطاً على **WEP**، فقم بتغييره إلى بروتوكول أمان آخر (يُنصح باختيار **WPA2**) ثم أعد تسجيل المتنج.

تطبيق LG ThinQ

توفر هذه الميزة فقط في الطرز المزودة بشبكة Wi-Fi. يسمح تطبيق **LG ThinQ** لك للتواصل مع الجهاز باستخدام هاتف ذكي.

ميزايا تطبيق LG ThinQ

تواصل مع هاتف من هاتفي الذكي باستخدام الميزات الذكية المريحة.

Smart Diagnosis

- تساعدك ميزة التشخيص الذكي على تشخيص أي مشكلة تواجهك أثناء استخدام الجهاز.
- الإعدادات
- يسمح لك بتعيين خيارات متعددة على الجهاز وفي التطبيق.


ملاحظة

- إذا غيرت جهاز التوجيه اللاسلكي الخاص بك، أو مزود خدمة الإنترنت، أو كلمة المرور، فقم بمسح الجهاز المسجل من تطبيق **LG ThinQ** وسجله من جديد.
- يخضع التطبيق للتغيير لأغراض تحسين الجهاز بدون إشعار المستخدمين.
- قد تتغير الميزات حسب الطراز.

قبل استخدام تطبيق LG ThinQ


- تأكد من المسافة بين الجهاز وجهاز التوجيه اللاسلكي (شبكة Wi-Fi).
- إذا كانت المسافة بين الجهاز وجهاز التوجيه اللاسلكي بعيدة أكثر من اللازم، ستصبح قوة الإشارة ضعيفة. قد يستغرق التسجيل وقتاً طويلاً أو قد يفشل التثبيت.

- قم بإغلاق بيانات الهاتف المحمول أو البيانات الخلوية على هاتفك الذكي.




ثبت تطبيق LG ThinQ

ابحث عن تطبيق **LG ThinQ** على Apple App Store & Google Play Store من على هاتف ذكي. اتبع التعليمات لتثبيت التطبيق وثبتنه.

2 اسحب الرف للخارج.**3** قم بتركيبها بترتيب عكس ترتيب عملية الإخراج.**! تنبية**


- جبى بالذكر أن الرفوف الزجاجية ثقيلة الوزن. توخي الحذر بشكل خاص عند إخراجها.
- لا تنظف الرفوف الزجاجية بالمياه الدافئة عندما تكون باردة. قد تتكسر الرفوف في حال تعرضت لتغير مفاجئ في درجات الحرارة.
- تأكّد أن الأرفف مستوية على الجانبين. قد يؤدي عدم القيام بهذا إلى سقوط الرف أو انسكاب الطعام.

سلة الباب**إزالّة/إعادة تركيب سلة الباب****1** أمسك كلاً من طرفي السلة وقم بإنزالها لأعلى.**2** قم بإعادة تركيب سلات باب الثلاجة بعكس ترتيب عملية الإخراج.**3** قم بتركيبها بترتيب عكس ترتيب عملية الإخراج.


الدرج

فك/إعادة تركيب الأدراج

- 1** أفرغ محتويات الدرج. وأمسك بمقبض درج الخضروات وأسحبه نحو الخارج برفق.



- 2** ارفع درج الخضروات لأعلى وقم بازالته عن طريق سحبه للخارج.



- 3** قم بتركيبها بترتيب عكس ترتيب عملية الإخراج.

!**تنبيه**

- احرص دائمًا على تفريغ الأدراج قبل تحريكها واستخدم كلتا اليدين أثناء تحريكها وإعادة تركيبها.
- تأكد أن بابي الثلاجة مفتوحان بالكامل قبل إزالة الأدراج وإعادة تجميعها.

الرف

!**تنبيه**

- جدير بالذكر أن الرفوف الزجاجية ثقيلة الوزن. توخي الحذر بشكل خاص عند إخراجها.
- لا تتنطف الرفوف الزجاجية بالمياه الدافئة عندما تكون باردة. قد تتكسر الرفوف في حال تعرضت لتغير مفاجئ في درجات الحرارة.

إزالة/إعادة الرف

- 1** قم بمالء مقدمة الرف وارفعه بستقامة لأعلى.

!**تنبيه**

- احرص دائمًا على تفريغ الأدراج قبل تحريكها واستخدم كلتا اليدين أثناء تحريكها وإعادة تركيبها.
- تأكد أن بابي الثلاجة مفتوحان بالكامل قبل إزالة الأدراج وإعادة تركيبها.

باستخدام درج الخضروات


1* لا تتوفر هذه الخاصية إلا في بعض الطرز.

يمكن التحكم في الرطوبة في درج الخضروات الطازجة عن طريق تحريك الرافعة في أي من الاتجاهين.

- إذا تم تحريكها للجانب الأيسر، سيتم فتح أداة ضبط الهواء مما يسمح للهواء بالانتشار خلال الدرج لتنليل الرطوبة.
- وإذا تم تحريكها للجانب الأيمن، سيتم غلق أداة ضبط الهواء مما سيحافظ على أي رطوبة تكون موجودة في الدرج.


 النوع A*	 النوع B*
--------------	--------------

توجد مساحة تخزين كبيرة داخل الباب الداخلي والسلال المحيطة، مما يسمح لك بتخزين الطعام بطريقة منتظمة.



استخدام خاصية الباب الداخلي InstaView

تسمح لك وظيفة العرض السريع في الباب الداخلي رؤية ما إذا كان يوجد لديك كبيات قليلة من العناصر التي يمكن استخدامها مثل المشروبات والوجبات الخفيفة، بدون فتح باب الثلاجة.



١ تنبية


- لا تقم بفتح باب الجهاز عندما يكون الباب المزدوج مفتوحاً، أو لا تقم بفتح الباب المزدوج عندما يكون باب الجهاز مفتوحاً. قد يصطدم الباب المزدوج بحافة الجهاز ويتأذف.

فك/ إعادة تركيب حافظة الباب الداخلي

٢ تنبية

- أفرغ المحتويات من وحدة الباب الداخلي قبل الفك.

- ١ افتح الباب بالكامل وقم بإزالة محتويات حافظة الباب الداخلي. وارفع واسحب حافظة الباب الداخلي.



- ٢ قم بتركيبها بترتيب عكس ترتيب عملية الإخراج.

١ قم بالنقر مررتين على الزجاج لتشغيل المصباح LED أو إيقاف تشغيله داخل الباب الداخلي.

٢ يتم إيقاف تشغيل مصباح LED بشكل تلقائي بعد عشرة ثوان.

ملاحظة

- يتم تعطيل وظيفة العرض السريع للباب الداخلي لمدة ثانيةين بعد غلق باب المجمد الأيمن أو الأيسر، كما تُعطى للحظات عندما يكون موزع الثلاج قيد الاستخدام.
- انقر بالقرب من منتصف الزجاج. فالنقر بالقرب من حافة الزجاج قد لا يُفعّل وظيفة العرض السريع للباب الداخلي.
- انقر بقعة كافية يمكن بها صوت النقر مسموع.
- ربما تعمل وظيفة العرض السريع للباب الداخلي عند صدور صوت عالي بالقرب من الثلاجة.
- قم بتنظيف الباب الزجاجي بقطعة قماش جافة. لإزالة البقع الشديدة، قم بترطيب قطعة قماش نظيفة بمياه فاترة أو منظف زجاج. لا تقم برش منظف زجاج على الباب الزجاجي مباشرةً.

InstaView

لا تتوفر هذه الخاصية إلا في بعض الطرز.

استخدام الباب الداخلي


اجذب الرافعة الموجودة على الحافة السفلية من الباب الداخلي نحو الأعلى إلى أن تنتفخ.

- عند إعادة تركيب صندوق الثلج، تأكيد من وضعه بشكل صحيح. إذا كان مائلًا أو غير مستوٍ، قد لا يسمى في عمل الثلج بسبب اضطراب المستشعر.


إزالة/إعادة تركيب صندوق تخزين الثلج

قد يتم سد علبة توزيع الثلج بالصفيح إذا تم استخدام الثلج المجروش فقط. قم بإزالة الصفيح الذي يتكون بزاولة صندوق الثلج وتنظيف الممر باستخدام معلقة من المطاط. يمكن أن يساعد أيضًا توزيع الثلج المكعب بشكل دوري في منع تكون الصفيح.


- قم بالإمساك بقطعة صانع الثلج وازنه عن طريق رفعه للأعلى.



- لإيقاف تشغيل صانع الثلج التلقائي، اضغط المفتاح على (OFF) (O).



- قم بالإمساك بصندوق الثلج بكلتا يديك وقم بسحبه للخارج مع رفعه للأعلى.



- قم بتركيبها بترتيب عكس ترتيب عملية الإخراج.

تنبيه !

- لا تلمس الأجزاء الباردة المحاطة إلى أقل من درجة التجمد، فالماء في مؤهل تصريف نظام إمداد المياه لمنع حدوث ضرر جسيم في الأنابيب بالجهاز بسبب فضان المياه الناجمة عن تمزق خطوط المياه أو الوصلات. اضغط مفتاح الطاقة الخاص بوحدة صنع الثلج على الوضع OFF (O) وأغلق مصدر المياه عن الجهاز.
- لا تترك درجة الحرارة المحيطة إلى أقل من درجة التجمد، فالماء في مؤهل تصريف نظام إمداد المياه لمنع حدوث ضرر جسيم في الأنابيب بالجهاز بسبب فضان المياه الناجمة عن تمزق خطوط المياه أو الوصلات. اضغط مفتاح الطاقة الخاص بوحدة صنع الثلج على الوضع OFF (O) وأغلق مصدر المياه عن الجهاز.
- لا تلمس الأجزاء الباردة المحاطة إلى درجة حرارة صانع الثلج التلقائي بيديك أو أيه آداة. وإن، قد ينفج الجهاز أو تحدث إصابة.
- لا تقم بفك صانع الثلج التلقائي أو إصلاحه أو تبديله. هذه المهام يجب تنفيذها فقط عن طريق فني الخدمات.
- يجب الانتباه، حيث إن صانع الثلج التلقائي يكون قيد التشغيل باستمرار بعد فتح باب وحدة الفريزر عندما يكون مفتاح صانع الثلج التلقائي مضبوط على وضع التشغيل.
- ابعد الأطفال عن الموزع.

الباب الداخلي

لا تتوفر هذه الخاصية إلا في بعض الطرز.

تشغيل وحدة صنع الثلج التلقانية وإيقاف تشغيلها

- لتشغيل وحدة صانع الثلج التلقائي أو إيقاف تشغيله، قم بالضغط على مفتاح الطاقة على وحدة صانع الثلج على وضع ON (|) أو (O).

الأصوات الطبيعية التي قد تسمعها

سوف يصدر صمام ماء وحدة صنع الثلج صوت طنين أثناء ملء صانع الثلج بالماء. إذا كان مفتاح الطاقة في وضع التشغيل (|), فسيصدر صوت طنين، حتى لو لم يتم توصيله بعد بالماء. لإيقاف التشغيل، قم بتحريك مفتاح الطاقة إلى وضع إيقاف التشغيل (O).

ملاحظة

- لا تترك الطاقة موصولة إلى وحدة صنع الثلج إذا كان خط المياه غير متصل. وإن، قد يلحق ذلك ضررًا بوحدة صنع الثلج.

التحضير لقضاء عطلة

إذا انخفضت درجة الحرارة المحيطة إلى أقل من درجة التجمد، فالماء في مؤهل تصريف نظام إمداد المياه لمنع حدوث ضرر جسيم في الأنابيب بالجهاز بسبب فضان المياه الناجمة عن تمزق خطوط المياه أو الوصلات. اضغط مفتاح الطاقة الخاص بوحدة صنع الثلج على الوضع OFF (O) وأغلق مصدر المياه عن الجهاز.

ملاحظة


- يجب تفريغ صندوق الثلج كلما تم إدارة مفتاح تشغيل/إيقاف تشغيل وحدة صنع الثلج إلى وضع OFF (O).

**!
تنبيه**

- من الطبيعي تصريف الماء الملين أو المتعكر بعد استبدال مرشح (فانتر) المياه. في نهاية الأمر سيكون هذا الهواء الجاري في الماء أمّا وبلون شفاف تماماً ويصلح الماء للشرب.
- قد يشمل الثلج والمياه الموزعة الأولى على جزيئات أو رواج من خط التزويد بالمياه أو خزان المياه.
- إذا تم توزيع ثلج مغزير لونه، تحقق من خزان المياه ومزود المياه للمصدر المحتمل. إذا استمرت المشكلة، اتصل بمركز معلومات عملاء شركة LG Electronics. لا تستخدم الثلج أو المياه حتى تتم معالجة المشكلة.
- لا تلمس مخرج الثلج أو وحدة صنع الثلج التقليدية بيديك ولا بأي أداة.
- قم بتوزيع الثلج في كلن قبل منه بالماء أو أي مشروبات أخرى. سوف يحدث رذاذاً إذا تم توزيع الثلج في كلن يحتوي بالفعل على سائل.
- لا تستخدم مطلاً كائناً ضيقاً أو عريضاً بشكل كبير. ربما يتكتس الثلج في مر الثلج مما يؤثر على أداء الجهاز.
- حافظ على الكأس على مسافة مناسبة من مخرج الثلج. حيث إن الكأس القريبة جداً من المخرج قد تمنع توزيع الثلج.
- تخلص من الثلج داخل صندوق الثلج إذا ذهبت في إجازة أو إذا حدث انقطاع في التيار الكهربائي. قد يسقط الماء الذائب من الثلج من الموزع على الأرض.

صانع ثلج المجمد

يمكن صانع الثلج التقليدي إنتاج 84-40 مكعب بشكل تقليدي في المرة الواحدة، خلال فترة 24 ساعة إذا كانت الظروف ملائمة. قد يختلف هذا المقدار طبقاً للبيئة (درجة الحرارة المحيطة بالجهاز، عدد مرات فتح الباب، مقدار الطعام المخزن في الجهاز، إلخ).



١ مفاتح الطاقة

**!
تنبيه**

- لا تدخل بيديك إلى الجزء الميكانيكي من صانع الثلج التقليدي مثل صندوق الثلج أو موزع الثلج.
- لا تقم بإزالة غطاء صانع الثلج التقليدي، فإن لمس أي جزء ميكانيكي من صانع الثلج قد يحدث لك إصابة.

**!
تحذير**

- أملأ صانع الثلج أو خزان موزع المياه فقط بمياه صالحة للشرب.
- لا تملأ خزان المياه بالمشروبات بخلاف المياه أو تملأ بالماء الساخن.
- لا تستخدم قوة أو صدمة قوية عند إزالته أو تجميع خزان موزع المياه. القيام بذلك يمكن أن يسبب ثائف أو إصابة.
- يجب عدم السماح للأطفال أن يكونوا على مقربة من خزان التوزيع.

ملاحظة

- قبل استخدام خزان موزع المياه قبل تثبيت الجهاز، يجب غسله قبل أن يتم وضع المياه بداخله.
- تتحقق ما إذا كان خزان موزع المياه قد تم وضعه في الجهاز بشكل صحيح.
- إذا لم يتم تجميعه بشكل صحيح، قد يتسرّب المياه من الخزان داخل الجهاز.
- إذا لم يوجد مقدار كافٍ من المياه في خزان موزع المياه، قد تنتشر كمية وحجم مكعب الثلج وقد ينتج عن ذلك عدم تكون ثلج.
- إذا لم توجد مياه في خزان موزع المياه، لا يمكن استخدام وظيفة توزيع المياه الباردة والثلج للموزع. تتحقق من وجود مياه في خزان موزع المياه ثم قم بملء الخزان باستخدام المياه إذا لم توجد مياه.
- انتظر على الأقل 15 ثانية قبل إزالة خزان المياه بعد الحصول على مياه أو ثلج موزع من الموزع.
- سوف يكون الصوت الناتج من خزان المياه طبيعيًا عن تزويد الموزع وصانع الثلج التقليدي بالمياه. ليس علامة على وجود خلل.


صانع الثلج التقليدي

لا تتوفر هذه الخاصية إلا في بعض الطرز.
تختلف هذه الخاصية وفقاً لنوع الطراز الذي تم شراؤه.


قبل استخدام صانع الثلج الموجود بباب.

- يقوم صانع الثلج بصناعة الثلج بشكل طبيعي بعد مرور 48 ساعة تقريباً بعد التركيب الأولي للجهاز.
- إذا كان صندوق الثلج ملؤماً بشكل كامل بالثلج، سوف يتوقف إنتاج الثلج.
- صوت سقوط الثلج في صندوق الثلج الطبيعي.
- إذا تم تخزين مكعبات الثلج لفترة طويلة من الوقت في صندوق الثلج، ربما تتكتل مع بعضها وقد لا يمكن فصلها بسهولة. في مثل هذه الحالة، قم بتفريغ صندوق الثلج حتى تتيح تكون ثلج جيد.


1 اضغط على زر الموزع **①** باستخدام كوب أو حاوية أخرى للحصول مكعب ثلج أو ماء أو ثلج مجروش.



اضغط على زر الموزع **①** باستخدام كوب أو حاوية أخرى للحصول مكعب ثلج أو ماء أو ثلج مجروش.




2 قم بفتح غطاء أو رأس خزان موزع المياه.




تنظيف الموزع

تنظيف مخرج الثلج والمياه


قم بمسح مخرج المياه **①** أو مخرج الثلج **②** بقطعة قماش نظيفة بشكل متكرر لأنها قد تتلاخس بسهولة.




3 قم بالملء باستخدام زجاجة مياه مرشحة أو مياه مرشحة نظيفة إلى الخط المعياري الموضح داخل خزان موزع المياه. (السعة الإجمالية: 4 لتر)



4 بعد الملء باستخدام المياه، قم بغلق غطاء أو رأس خزان موزع المياه.



5 قم بإعادة تركيب خزان موزع المياه في رف الثلاجة.



• في حالة استخدام قطعة قماش من النسيج الكتاني فقد تلتصق بالمخارج.

تنظيف درج الموزع

قم بمسح المساحة كلها بقطعة قماش مبللة. قد يصبح الموزع مبللاً بسهولة بسبب الثلج أو الماء المنكبين.



ملء خزان المياه بالماء

لا تتوفر هذه الخاصية إلا في بعض الأطراز.

يحتفظ خزان المياه بالمياه الذي يتم توزيعها أو استخدامها عن طريق صانع الثلج التلقائي لعمل ثلج.

- لف أزرار لوحة التحكم، اضغط مع الاستمرار على الزر **Lock** لمدة ثلث ثوانٍ حتى يظهر الرمز  ويتم تفعيل الوظيفة.
- لتعطيل الوظيفة، اضغط مع الاستمرار على الزر **Lock** لمدة ثلث ثوانٍ حتى يظهر الرمز  ويتم إلغاء تفعيل الوظيفة.

Wi-Fi 7

يسمح هذا الزر بتوسيع الجهاز بشبكة Wi-Fi منزلية. راجع الوظائف الذكية للحصول على معلومات حول الإعدادات الأولية لتطبيق **LG ThinQ**.

8 نوع الماء والثلج

حدد وضع الموزع الذي ترغب فيه من أزرار لوحة التحكم. اضغط على مقناح الموزع بمساعدة كوب أو وعاء آخر للحصول مكعب ثلج أو ماء أو ثلوج مجروش.

1*Water Filter 9

استبدل فلتر المياه عندما يضيء المؤشر .

ملاحظة

- يتم إيقاف تشغيل لوحة التحكم تلقائياً لتوفير الطاقة.
- إذا كان هناك أي اتصال بالأصبع أو الجسم مع لوحة التحكم أثناء تنظيفها، فقد تعمل وظيفة الزر.

- إذا قمت بفتح باب وحدة الثلاجة أثناء توزيع المياه، أو الثلوج المكعب، أو الثلوج المجروش، فسوف يتوقف التوزيع بشكل مؤقت. عند غلق الباب، سوف يستمر توزيع الغسق المحدد.
- إذا كانت حافة الكوب صغيرة، قد تتساقط المياه خارج الكأس أو الخروج منها بشكل كامل.
- استخدم كوبًا بحافة قطرها يصل لأكثر من 68 مم عند توزيع مياه أو ثلوج مكعب أو ثلوج مجروش.
- عندما ينفتح صانع الثلوج مكعبات ثلوج صغيرة، أو تصبح مكعبات الثلوج متكللة مع بعضها، ربما يكون مقدار المياه الممدود لصانع الثلوج منخفضًا نظرًا لعدم كفاية المياه في خزان المياه. وإذا لم يستخدم الثلوج بشكل مستمر أو كانت درجة الحرارة المحددة للجمد دافئة جدًا، قد ينكح الثلوج مع بعضه أيضًا.

(موزع المياه والثلج) Dispenser Ice and Water**قبل استخدام موزع المياه والثلج) Water Dispenser****تنبيه !**

- حافظ على الأطفال بعيدًا عن الموزع لمنع الأطفال من اللعب في أو تحطيم وسائل التحكم.
- تخلص من المقابض القليلة الأولى من الثلوج (حوالي 20 مكعب و 7 أكواب من المياه). يكون هذا ضروري أيضًا إذا لم يتم استخدام الجهاز لفترة طويلة.
- قم بتنظيف نظام توزيع المياه إذا لم يستخدم لمدة 48 ساعة. قم بتنظيف نظام المياه الموصى بمزود مياه إذا لم يستخدم المياه لمدة 5 أيام.
- فيما يخص تنظيف نظام توزيع المياه، قم بتنظيف الموزع بالماء لمدة 5 دقائق تقريبًا وألق الدفعات القليلة الأولى من الثلوج.
- من الطبيعي أن تصريف الماء المتعكر / الملبن بعد استبدال مرشح (فلتر) المياه. وفي نهاية الأمر سيكون هذا الهواء الجاري في الماء أمثلًا ويلون شفاف تماماً ويصلح الماء للشرب أثناء هذا الانتقال.

استخدام موزع الثلوج والمياه

اضغط على زر تحديد الموزع بشكل متكرر حتى يضيء الرمز الموجود أعلى الاختيار الذي ترغب به.

ملاحظة


- إذا قمت بفتح باب المُحمد بينما يتم توزيع المياه، فسوف يتوقف التزويد بالمياه.

لوحة التحكم

قد تختلف لوحة التحكم الفعلية من طراز لآخر.

لوحة التحكم والوظائف

* لا تتوفر هذه الخاصية إلا في بعض الطرز.



١* Hygiene Fresh ①

تقلل هذه الوظيفة من الروائح الكريهة داخل الثلاجة.

Express Freeze ②

يمكن لهذه الوظيفة تجميد كمية كبيرة من الأطعمة المجمدة أو المثلجة بسرعة.

- يتم تعيين هذه الوظيفة وتطبيقاتها في كل مرة تضغط فيها على الزر.
- تتوقف هذه الوظيفة بشكل ثقاني بعد مرور فترة معينة.

Freezer ③

اضغط على هذا الزر بشكل متكرر لتحديد درجة الحرارة المرغوب ضبطها من -24 درجة مئوية حتى -14 درجة مئوية.

- درجة الحرارة الأولية للمجمد هي 19 درجة مئوية.

Fridge ④

اضغط على هذا الزر بشكل متكرر لتحديد درجة الحرارة المرغوب ضبطها على 1 درجة مئوية و 7 درجة مئوية.

- درجة الحرارة الأولية للثلاجة هي 4 درجة مئوية.

ملاحظة

- تختلف درجة الحرارة الفعلية الداخلية وفقاً لحالة الطعام، حيث إن إعداد درجة الحرارة المشار إليها هي درجة الحرارة المستهدفة، وليس درجة الحرارة الفعلية داخل الجهاز.

١* Non Plumbing ⑤

يضيء رمز Non Plumbing (عدم الصرف) عندما يتم تركيب خزان موزع المياه بشكل صحيح.

Lock ⑥

يعمل على قفل الأزرار الموجودة على لوحة التحكم.

٥ سلة باب وحدة الفريزر

حيث يمكن تخزين مجموعات صغيرة من الطعام المجمد المغلف أو الأطعمة التي يتكرر استخدامها.

٦ حجيرة الباب الداخلي^{1*}

حيث يحفظ الطعام الذي يتم إخراجه بشكل متكرر مثل المشروبات والوجبات الخفيفة.

٧ رف الزجاجات^{1*}

يتم تخزين زجاجات المشروبات الطويلة أو الحاويات فيها.

٨ تنبية!

- لا تقم بتخزين أية زجاجات أو حاويات قصيرة. فقد تسقط العناصر مما يسبب أي إصابة أو تلف في الجهاز.

٩ رف الثلاجة

هذا هو مكان تخزين الأطعمة المبردة والمواد الأخرى. خزن الأطعمة ذات الرطوبة العالية في الجزء الأمامي من الرف.

يمكن تعديل ارتفاع الرف عن طريق إدخال الرف في مجرى آخر بارتفاع مختلف. سوف يختلف العدد الفعلي للأرفف من طراز لآخر.

١٠ فلتر الهواء^{1*}

تقلل هذه الوظيفة من الروائح الكريهة داخل حجرة الثلاجة.

١١ درج الوجبات الخفيفة^{1*}

حيث يمكن تخزين مجموعات صغيرة من الأطعمة المبردة.

١٢ مُستشعر الحرارة^{1*}

هذا المُستشعر يمكنه استشعار درجة حرارة وحدة الثلاجة.

- الحفاظ على المسافة بين المستشعر والطعام ليستشعر درجة الحرارة بدقة.

١٣ خزان المياه^{1*}

حيث تُخزن المياه المزودة للموزع أو صانع الثلج التلقائي. إنه يتطلب ملأً يومياً.

١٤ درج الخضروات الطازجة^{1*}

حيث يحفظ الفاكهة والخضروات للمساعدة في الحفاظ على نضارتها بضبط جهاز التحكم بالرطوبة.

١٥ صندوق البيض^{1*}

حيث يحفظ البيض.

- لا تستخدم هذا المكان كصندوق ثلج أو تضعه على الرف أعلى الثلاجة أو في درج الخضروات.

١٦ درج الخضروات



حيث يحفظ الفاكهة والخضروات لتبقى طازجة لأطول وقت ممكن.

١٧ سلة باب وحدة الثلاجة

عبارة عن مكان تخزين الحزم الصغيرة من الأطعمة والمشروبات وأوعية الصلصة المبردة.

الجزء الداخلي (نجمتان

1* لا تتوفر هذه الخاصية إلا في بعض الطرز.



١ مصباح LED

تُضيء مصابيح LED داخل الجهاز عندما تفتح الباب.

٢ صانع الثلج التلقائي*

حيث يتم إنتاج الثلج تلقائياً وتخزينه.

٣ رف المجمد

عبارة عن مكان تخزين الأطعمة المجمدة كاللحوم والأسماك والأيس كريم.

٤ درج المجمد


عبارة عن المكان المخصص لتخزين المواد المجمدة على المدى الطويل.

خواص المنتج

قد يختلف الشكل الخارجي للجهاز أو مكوناته من طراز لأخر.

الجهة الخارجية

١* لا تتوفر هذه الخاصية إلا في بعض الطرز.



١ لوحة التحكم

اضبط درجات الحرارة في الثلاجة والمجمد، وحالة مرشح المياه ووضع الموزع.

٢ الباب الداخلي^{١*}

هذه مساحة تخزين مناسبة للأغراض التي يكثر استخدامها وتحتاج إلى الوصول إليها بسهولة.

٣ رافعة الباب الداخلي

تفتح الباب الداخلي

٤ الباب الداخلي^{١*} InstaView^{١*}

يتيح باب العرض السريع في وحدة الباب بالوصول السريع إلى عناصر الطعام المستخدمة عادةً.

أقصى سعة تجميد

- تتيح وظيفة Express Freeze المُجمد للقيام بأقصى كفاءة تجميد له. بشكل عام، تستغرق هذه الوظيفة مدة تصل إلى 24 ساعة وسيتم إيقاف تشغيلها بشكل تلقائي.
- يجب تشغيل وظيفة Express Freeze لمدة ساعتين قبل وضع الأطعمة الطازجة في وحدة المجمد.
- للحصول على توزيع هواء أفضل، قم بإدخال جميع الأجزاء الداخلية مثل السلال، والأدراج، والرفوف.

تجميد الحد الأقصى لكمية الطعام

في حالة وجود كميات كبيرة من الأطعمة ببراد تخزينها، يجب إخراج كل أدراج المجمد خارج الجهاز ويجب رص الأطعمة مباشرةً على الأدراج في وحدة المجمد.

!**تنبيه**

- لفك الأدراج، قم ب拔掉 الطعام الموجود في الأدراج أولًا ثم اسحب الأدراج بعالية. إذا لم تتبعد هذه الإجراءات يمكن أن يتسبب ذلك في إصابة أو ثلف الأدراج.

ملاحظة

- قد يكون شكل كل درج مختلفاً، لذا أدخلها في مواضعها الصحيحة.

حعرو ذات نجمتين

- يمكن استخدام الدرج أو سلة التخزين (**) ذات النجمتين لتخزين الثلاج والطعام من -12 درجة مئوية إلى -18 درجة مئوية لفترات قصيرة.
- تُعد حجيرات الأطعمة المتاحة ذات النجمتين مناسبة لتخزين الأطعمة المتاحة مسبقاً، أو لتخزين المنتجات أو صناعتها، أو لصناعة مكعبات الثلاج.
- تُعد الحجيرات ذات النجمتين غير مناسبة لتجميد الأطعمة الطازجة.

التشغيل

قبل الاستخدام

ملاحظات التشغيل

- عند تخزين الطعام في وحدة المجمد، قم بضبط درجة حرارة المجمد على درجة حرارة أقل من الموصحة على الطعام.
- لا تقم بتغيير درجة حرارة الثلاج على درجة أقل من اللازم.
- لا تضع الطعام بالقرب من مستشعر درجة الحرارة في وحدة الثلاجة. حافظ على مسافة 3 سم على الأقل من المستشعر.
- لاحظ ارتفاع درجة الحرارة بعد إزالة الثلاج له نطق مسموح به في مواصفات الجهاز. إذا كنت ترغب في تقليل التأثير على تخزين الطعام بسبب ارتفاع درجة الحرارة، قم بإغلاق أو حفظ الطعام المخزن في عدة طبقات.
- يضمن نظام إزالة الثلاج تلقائياً في الجهاز خلو حبيرة المجمد من تراكم الثلاج في ظروف التشغيل العادية.

- يجب أن يضع المستخدمون في اعتبارهم أن الصبع قد يكون إذا لم يُعلق الباب بالكامل، أو في حال كانت الرطوبة مرتفعة خلال الصيف.
- تأكد من وجود مسافة كافية بين الطعام المخزن على الرف أو سلة الباب ليسباس باغلاق الباب بالكامل.
- قد يتسبب فتح الباب لفترات طويلة في زيادة درجة الحرارة بصورة ملحوظة داخل حبرات الجهاز.
- إذا تركت جهاز التبريد فالرثما لفترات طويلة، فأغلقه، وقم بزيادة الثلاج المترافق في، ونظفه، وجففه، ودع الباب مفتوحاً لمنع تكون العفن داخل الجهاز.

تخزين الأطعمة بكفاءة

- خزن الطعام المجمد أو الأطعمة المبردة داخل أوعية محكمة الغلق.
- تحقق من تاريخ انتهاء الصلاحية والملصق (تعليمات التخزين) قبل تخزين الطعام في الجهاز.
- لا تخزن الطعام لفترة طويلة من الوقت (أكثر من 4 أسابيع) إذا كان يفسد بسهولة عند درجة حرارة منخفضة.
- ضع الأطعمة المبردة أو الطعام المجمد داخل أي من الثلاجة أو المجمد فور شرائه.
- قم ب تخزين اللحوم والأسماك الطازجة في حاويات مناسبة داخل البراد، حتى لا تلامس الأطعمة الأخرى أو تقطّر عليها.
- يمكن تخزين الأطعمة المبردة وغيرها من الأطعمة أعلى درج الخضراء.
- تجنب إعادة تجميد أي طعام كان قد تم ذوبان تجميده بشكل كامل. تجميد أي طعام كان قد تم ذوبان تجميده بشكل كامل سوف يقلل من مذاقه وتغذيته.
- لا تفوت في ملء الجهاز. لا يمكن للهواء البارد أن يمر بشكل صحيح إذا كان الجهاز مملوءاً أكثر من الحد الأقصى.
- برد الطعام الساخن قبل التخزين. في حال وضع طعام ساخن جداً في الداخل، يمكن أن تزداد درجة الحرارة الداخلية للجهاز مما يؤثر بالسلب على الأطعمة الأخرى المخزنة في الجهاز.
- إذا قمت بضبط درجة حرارة منخفضة بشكل كبير للطعام، ربما يتجمد. لا تقم بضبط درجة حرارة أقل من درجة الحرارة المطلوبة للطعام لئن تخزينه بشكل صحيح.
- في حال وجود حبرات تبريد في الجهاز، لا تخزن الخضراء والفواكه التي تحتوي على محتوى ذي رطوبة عالية في حبيرة التبريد لأنها قد تتجمد بسبب انخفاض درجة الحرارة.
- في حالة حدوث انقطاع التيار الكهربائي، اتصل بشركات الكهرباء وأسال عن مدة الانقطاع.
- يجب أن تتجنب فتح الأبواب أثناء فصل الطاقة عن الجهاز.
- عندما يعود مصدر الطاقة إلى وضعه الطبيعي، تحقق من حالة الطعام.

إنذار فتح الباب

يصدر الإنذار صوتاً ثالثاً مرات بفواصل زمنية مدنية ثلاثة ثانية في حالة ترك الباب مفتوحاً أو لم يتم إغلاقه بالكام في خلال دقيقة واحدة.

ملاحظة

- اتصل بمركز معلومات العملاء لشركة LG Electronics إذا استمر صوت المنبه بفواصل زمنية أكثر من ثلاثة ثانية حتى بعد قفل كل الأبواب.

كشف الأخطاء

يمكن للجهاز الكشف عن المشاكل بشكل تلقائي أثناء التشغيل.

ملاحظة

- إذا اكتفى عن مشكلة، لا يعمل الجهاز ويتم عرض رمز خطأ حتى عند الضغط على أي زر.
- إذا ظهر خطأ على الشاشة، لا تقم بيقاف تشغيل الطاقة. واتصل فوراً بمركز معلومات عملاء شركة LG Electronics وأنزل الخطأ. إذا قمت بيقاف تشغيل الطاقة، فقد يواجهك التوصل من مركز المعلومات صعوبة في اكتشاف المشكلة.

اقتراح توفير الطاقة

- تأكد من وجود مسافة كافية بين الأطعمة المخزنة. يسمح هذا للهواء البارد بالانتشار بالتساوي ويختفي من فواتير الكهرباء.
- خزن الأطعمة الساخنة فقط بعد أن تبرد لمنع التكتف أو التجمد.

3 قم بثبيت الأجزاء مثل الأرفف ومقصي الباب بشرط لمنع السقوط أثناء تحريك الجهاز.

4 قم بتحريك الجهاز بواسطة أكثر من شخصين بعناية، عند نقل الجهاز لمسافة طويلة، أبق الجهاز في وضع رأسي.

5 بعد تركيب الجهاز، قم بتوصيل قابس الطاقة في المأخذ الرئيسي لمقياس الخرج، وقم بتشغيله.

نَّبِيَّ!

- لا تضيّط ارتفاع باب الجهاز لأعلى من 3 مم.


3 استخدم مقاوح الصاملولة **①** لتنبيت صاملولة التثبيت من خلال تدويرها يميناً.

**ملاحظة**

- قد لا يمكن ضبط ارتفاع باب الثلاجة في حالة كانت الأرضية غير مستوية أو كان البناء ضعيف أو غير قوي.
- نظراً لقل حجم الثلاجة، فقم بتركيبها على أرضية صلبة ومستوية.
- قد تتسبب الأرضيات الخشبية في صعوبة تسوية الجهاز إذا كانت شديدة الانثناء.

أو عند وجود صعوبة في غلق الأبواب، قم بضبط ميل الجهاز باستخدام التعليمات الواردة أدناه.

استخدم مقنح الرابط **①** لضبط الارتفاع من خلال إدارة رجل الإستواء لليسار لرفها أو لليمين لخفتها.

**تشغيل الطاقة****توصيل الجهاز**


بعد تركيب الجهاز، قم بتوصيل قابس الطاقة في مقبس خرج.

ملاحظة


- بعد توصيل سلك التيار الكهربائي (أو القابس) بمقبس، انتظر لمدة ثلاثة أو أربع ساعات قبل وضع الطعام في الجهاز. إذا قمت بإضافة الطعام قبل تبريد الجهاز بالكامل، فقد يفسد الطعام.

محاذاة باب المجمد والثلاجة


في حال لم يكن باب الجهاز مستوي، اضبط فرق الارتفاع الخاص بباب الجهاز.



1 افتح الباب واستخدم مقنح الصاملولة **①** لتنبيت من ارخاء صاملولة التثبيت من خلال تدويرها يساراً.



2 استخدم مقنح الصاملولة **②** لتنبيت من تعديل ارتفاع الجهاز عن طريق تدوير سن مفصلة الضبط يساراً أو يميناً.

**تحريك الجهاز لنقله إلى مكان آخر****التجهيز لنقل الجهاز**

1 قم بإخراج الطعام من داخل الجهاز.

2 قم بسحب قابس الكهرباء وإدخاله وتنبيته في وصلة قابس الطاقة في الجزء الخلفي أو أعلى الجهاز.

التحقق من التوصيل بالمياه

1 قم بتشغيل مزود المياه وقم بفتح الجهاز. تحقق بعذر من جميع التجهيزات لكتف أي تسربات محتملة كنتيجة لخراطيم المياه التي تم تركيبها بشكلٍ سيء.

2 اضغط مع الاستمرار على الزر Water Filter لمدة ثلث ثوان. تم تفعيل مرشح المياه الجديد.

3 ضع كوبًا تحت موزع المياه للتحقق من تدفق المياه من خلال الجهاز.

4 تحقق من أنبوب التوصيل والمفصلات من أجل التسربات مرة أخرى.

ضبط استواء الجهاز ومحاذاة الباب


قبل البدء

إذا كانت المسافة بين الأنابيب غير متساوية، فاتبع التعليمات الواردة أدناه لمحاذاة الأنابيب.


ملاحظة

يمكن أن يختلف مفتاح الرابط حسب الطراز الخاص بك. سوف يتم تزويديك بمفتاح ربط إما من نوع A أو B.

- مفتاح البراغي النوع A



- مفتاح البراغي النوع B



متطلبات التزود بالمياه

يتطلب مزود المياه الباردة ضغط مياه يتراوح بين 138 كيلو باسكال و 827 كيلو جرام قلبي/سم² (8.4-1.4 كيلو جرام قلبي/سم²) لتشغيل موزع المياه. في حال تم تركيب التلاجة في مكان ذو ضغط مياه منخفض (أقل من 138 كيلو باسكال)، يمكنك تركيب مضخة تعزيز لتعويض الضغط المنخفض. في حال توصيل نظام ترشيح المياه بالتناضج العكسي بمزود المياه الباردة الخاص بك، يجب أن يكون ضغط المياه بالنسبة لنظام التناضج العكسي كحد أدنى من 138 كيلو باسكال إلى 827 كيلو باسكال (8.4-1.4 كيلو جرام قلبي/سم²)

تحذير!

- افصل الجهاز قبل القيام بأي عمل يتعلق بتوصيل خط المياه. فشل القيام بذلك قد يتسبب في صدمة كهربائية.
- وصل خط المياه فقط بمزود مياه باردة. فشل القيام بذلك قد يتسبب في تعطل ترشيح المياه (تدفق المياه في الأنابيب) في السباكة المنزلية يمكن أن يتسبب ثلث لأجزاء الجهاز ويمكن أن يؤدي إلى تسرب أو فيض المياه.
- التوصيل بمزود مياه الشرب فقط.
- توصيل خط المياه يجب تركيبه فقط بواسطة سباك مؤهل ووفقاً للقوانين واللوائح المحلية التي تنظم جودة المياه.


ملاحظة

- تركيب خط المياه هذا لا يندرج تحت ضمان الجهاز.

توصيل المياه بالجهاز

1 فك صامولة التبريد المعدنية المستنة في الجزء الخلفي من الجهاز ووضعها على أحد طرفي أنبوب المياه.

2 ادفع أنبوب المياه بقورة داخل صمام السحب وأحكِم ربط صامولة الطوق.



ضبط مستوى الجهاز

بحتري الجهاز على قدمين ألمامين مستويين. اضبط هذه الأقدام لتغيير الميل من الأمام إلى الخلف مثلاً أو من جانب إلى آخر. في حالة عدم استواء الجهاز،

إعادة تركيب باب الثلاجة والمجمد


قم بتركيب الأبواب عكس ترتيب إجراءات الفك بمجرد مرور الجهاز من خلال كل أبواب المدخل.

تنبيه

- قم بتركيب باب الثلاجة أولاً.


ملاحظة

- فك / تجميع خطوط الإمداد بالمياه



① الطوق ② الأنبوب ③ خط الإدخال ④ المثبت

قم بدخول الأنبوب برفق حتى يظهر لك خط واحداً من خطوط الأنبوب.
ثم شد هذا الأنبوب حتى تتأكد من إحكام ربطه.



في حال تلف طرف الأنبوب، يجب فحصه مع التنظيف التأكد من عدم تسربه عند إعادة تركيبه.




غير مستقيم ⑤ تالف ⑥ ممدد ⑦

توصيل خط المياه


هذا القسم غير متوفّر إلا مع الطرز المزوّدة بموّزع المياه أو الثلاج.

إزالة باب الثلاجة

1 قم بفصل جميع التوصيلات السلكية.




قم بتنويم ذراع المفصلة ② في اتجاه عقارب الساعة. ثم ارفع المفصلة العلوية ③ لتحريرها من مزلاج ذراع المفصلة ④.



تنبيه

- عند رفع المفصلة وتحريرها من ذراع التثبيت المفصلي، تأكّد من عدم سقوط الباب إلى الأمام. من الموصي به أن يقوم شخصين أو أكثر بإزالة الباب وإعادة تركيبه.

3 ارفع باب الثلاجة حتى ينفصل عن المجموعة المفصليّة السفلية.




تنبيه


- قم بوضع الباب على سطح لا يسبّب الخدوش مع جعل الجانب الداخلي متوجهاً لأعلى.

AR 11 الترکیب

- 3** اسحب الأليوب **③**. قم بفك السلك الأرضي **④**. قم بفصل جميع التوصيلات السلكية **⑤**.




- 4** قم بتدوير الرافعة المفصالية **⑥** بعكس اتجاه عقارب الساعة. ارفع المفصلة العلوية **⑦** لتفصلها عن ذراع التثبيت المفصلي **⑧**.

**٤ تنبیه**

- عند رفع المفصلة وتحريرها من المزلاج، تأكد من عدم سقوط الباب إلى الأمام. من الموصى به أن يقوم شخصان أو أكثر بzarala الباب وإعادة تركييّه.

- 5** ارفع باب المجمد حتى ينفصل عن المجموعة المفصالية السفلية.

**٥ تنبیه**

- قم بوضع الباب على سطح لا يسبب الخدوش مع جعل الجانب الداخلي متوجهاً لأعلى.

إزالة باب الثلاجة والمجمد


في حال كان باب المدخل لديك ضيقاً لمورور الجهاز من خالله، قم بإزالة أبواب الجهاز ومرر الجهاز أفقياً.

١ تحذير


- افصل سلك الطاقة، أو المنصهر المنزلي، أو قاطع الدائرة قبل تركيب الأبواب أو إزالتها أو تنظيف الجهاز. قد يتسبب فشل اتباع هذه التعليمات في الوفاة أو حدوث حريق أو صدمة كهربائية.

إزالة باب المجمد

- 1** يتم توصيل خط الإمداد بالمياه بالجزء العلوي الأيمن في الجزء الخلفي من الجهاز. قم بيلقاف توصيل الإمداد بالمياه وادفع برفق الطوق **①** لفصل خط الإمداد بالمياه. ثم فك براغي الغطاء **②**.



- 2** قم بازالة البراغي من الغطاء المفصالي في الجزء العلوي من الثلاجة. ارفع الخطاف، الموجود أسفل الجانب الأمامي للغطاء، باستخدام مفك برااغي مسطح الرأس.



التركيب

- يمكنك العثور على فئة المناخ في ملصق التصنيف.

نطاق درجة الحرارة المحيطة "درجة منوية"	فئة المناخ
32+ - 10+	(درجة الحرارة المعتدلة) SN
32+ - 16+	(درجة الحرارة) N
**38+ - 18+ / 38+ - 16+	(شبه استوائي) ST
18+ / 43+ - 16+ / *43+ - 10+ **43+ -	(استوائي) T


* أستراليا، الهند، كينيا

** الأرجنتين

قبل إجراء التركيب

الأبعاد والخلوصات

قد تؤدي المسافة الصغيرة جداً بين الجهاز والعناصر المجاورة له إلى تدني قدرته على التجميد وزيادة تكاليف الكهرباء. يُراعي أن تكون المسافة بين ظهر الجهاز وأي حائط أكثر من 50 ملم عند تركيب الجهاز.




ملاحظة

- الأجهزة التي تتدرج ضمن فئة "درجة الحرارة المعتدلة" (SN) إلى درجة الحرارة "الاستوائية" (T) مصممة للاستخدام في درجة حرارة محيطة تتراوح بين 10 و 43 درجة منوية.

الملحقات

- 1* لا تتوفر هذه الخاصية إلا في بعض الطرز.



1 مقناح البراغي ^{1*}

2 مقناح البراغي ^{1*}

3 مرشح المياه (Water Filter)

4 أنبوب المياه

5 موصل الأنابيب ومشبك ^{1*}

6 موصل الأنابيب وصمام ^{1*}

النوع ب (ملم)	النوع أ (ملم)	-
912	912	A
1790	1790	B
738	927	C
615	797	D
690	877	E
733	922	F
1180	1384	G
1750	1713	H

ملاحظة

- يمكنك تحديد نوع الجهاز عند مراجعة البطاقة الموجودة داخله.

درجة الحرارة المحيطة

- تم تصميم الجهاز للعمل ضمن نطاق محدود من درجات الحرارة المحيطة، وذلك حسب المنطقة المناخية.

- قد تتأثر درجات الحرارة الداخلية بسبب موقع الجهاز، ودرجة الحرارة المحيطة، وتيرة فتح الباب، وما إلى ذلك.

- تخلص من الثلج داخل صندوق الثلج في وحدة الفريزر أثناء انقطاع ممتد للتيار الكهربائي.

التخلص

- عند التخلص من الجهاز، قم بإزالة حشية الباب بينما تترك الرفوف والسلال في مكانها وقم بإبعاد الأطفال عن الجهاز.

تنبيه

! تنبيه

للحد من مخاطر حدوث إصابات طفيفة للأشخاص، أو حدوث عطل، أو تلف للمنتج أو الممتلكات عند استخدام المنتج، يجب اتباع احتياطات السلامة الأساسية، بما فيها ما يلي:

التشغيل

- لا تلمس الطعام المجمد أو الأجزاء المعدنية في حجرة الفريزر بأيدي مبللة أو رطبة. قد يتقرح الجلد من شدة البرد.
- تجنب وضع الحلويات أو القناني أو العلب الزجاجية (خاصة تلك التي تحتوي على مشروبات غازية) داخل المجمد أو على الرفوف أو في صندوق الثلج الذي سيتعرض لدرجات حرارة دون التجمد.
- قد يتعرض الزجاج المقسى على الجانب الأمامي من باب الجهاز أو الأرفف إلى الضرر بسبب الاصطدام. في حال كسره، تجنب لمسه باليدين.
- تجنب التعلق بأبواب الجهاز أو حجرة التخزين أو الرف، أو الصعود عليه.
- لا تخزن كمية مفرطة من زجاجات المياه أو حلويات الأطباق الجانبية على شبكات الباب.
- لا تفتح باب الجهاز أو تغلقه بقوة مفرطة.
- إذا كانت مفصلة باب المنتج تالفة أو تعمل بشكل غير سليم، فتوقف عن استخدامه واتصل بمركز خدمة .LG Electronics
- امنح الحيوانات من قضم قبل الطاقة أو خرطوم المياه.
- لا تأكل مطلقاً الأطعمة المجمدة فور إخراجها من حجرة الفريزر.
- لا تقم باستخدام كوب كريستالي رفيع أو أوانى صينية عند التوزيع.
- احرص ألا تعلق يداك أو قدمك عند فتح باب الجهاز أو الباب المزدوج أو إغلاقه.

الصيانة

- لا تنظف الأغطية أو الأرفف الزجاجية بالمياه الدافئة عندما تكون باردة. قد تنكسر في حال تعرضها للتغير مفاجئ بدرجات الحرارة.
- تجنب وضع الأرفف في الاتجاه العكسي. فقد تسقط من مكانها.
- لإزالة الصقير من الجهاز، تواصل مع مركز معلومات العملاء في شركة .LG Electronics

- يجب توصيل الجهاز بخط كهرباء يكون مخصصاً له ومزوداً بمصهر منفصل.
- تجنب استخدام مأخذ متعدد المقابس وغير مؤرض بشكل مناسب (محمول). في حال استخدام مأخذ مؤرض بشكل مناسب متعدد المقابس (محمول)، استخدم المأخذ متعدد المقابس الذي يتحمل سعة تيار تساوي أو تزيد على السعة المقدرة للجهاز، واستخدمه فقط للجهاز وحده.

التشغيل

- لا تستخدم الجهاز لأي غرض (تخزين مواد طبية أو تجريبية أو للشحن) بخلاف الاستخدام لتخزين أي طعام منزلي مألف.
- في حال اختراف المياه لأجزاء إلكترونية من الجهاز، افصل مقبس الطاقة وتواصل مع مركز معلومات العملاء في شركة LG Electronics.
- لا توصل مقبس الطاقة أثناء عاصفة رعدية أو برق شديد أو في حالة عدم استخدامه لفترة طويلة من الوقت.
- تجنب لمس قابس الطاقة أو عناصر التحكم في الجهاز بيدين مبتلتين.
- احرص على عدم ثني كابل الطاقة بشكل مفرط أو وضع شيء ثقيل عليه.
- فصل فوراً مقبس الطاقة وتواصل مع مركز معلومات العملاء في شركة LG Electronics في حال اكتشافك لصوت أو رائحة أو دخان غريب صادر من الجهاز.
- لا تضع بيديك أو أشياء معدنية داخل المنطقة التي ينبع منها الهواء البارد، أو غطاء أو جهاز يصدر حرارة في الخلف.
- لا تستخدم قوة مفرطة أو تصطدم بالغطاء الخلفي للجهاز.
- احذر من تواجد الأطفال بالجوار عندما تفتح باب الجهاز أو تغلقه. قد يصطدم الطفل بالباب وينتسب له بإصابة.
- تجنب خطر احتجاز الأطفال داخل الجهاز. يمكن أن يصاب الطفل المحتجز داخل الجهاز باختناق.
- لا تضع الحيوانات الحية مثل الحيوانات الأليفة داخل الجهاز.
- لا تضع أشياء ثقيلة أو هشة أو حاويات مملوقة بسائل أو مواد قابلة للاحتراق، أو أشياء قابلة للاشتعال (مثل الشموع والمصابيح وما إلى ذلك) أو أجهزة تدفئة (مثل الأفران والساخنات وما إلى ذلك) على الجهاز.
- لا تضع آية أجهزة إلكترونية (مثل مدفأة أو هاتف محمول) داخل الجهاز.
- إذا كان هناك تسرب غاز (أيزوبوتاني، أو بروبان، أو غاز طبيعي، أو ما إلى ذلك)، فلا تلمس الجهاز أو قابس الطاقة وقم بتهوية المكان على الفور. يستخدم هذا الجهاز غاز تبريد (أيزوبوتان، R600a). على الرغم من أنه يستخدم كمية صغيرة من الغاز، إلا أنه لا يزال غازاً قابلاً للاشتعال. يمكن أن يتسبب تسرب الغاز أثناء نقل أو تركيب أو تشغيل الجهاز في نشوب حريق أو انفجار أو إصابة في حالة حدوث الشرر.
- لا تستخدم مواد قابلة للاحتراق أو قابلة للاشتعال (مواد مثل إيثر، وبنزين، وكحول، ومواد كيميائية، وغاز نفطي مسال، ورذاذ قابل للاحتراق، ومبيد حشرات، ومعطر هواء، ومستحضرات تجميل، وما إلى ذلك) أو تخزنها بالقرب من الجهاز.

مخاطر الحرائق والمواد القابلة للاشتعال

- في حال اكتشاف تسريب، تجنب أية ألسنة لهب مكثوفة أو مصادر محتملة للاشتعال وقم بتهوية الغرفة التي يتواجد بها الجهاز لعدة دقائق. لكي تتجنب تكون خليط هواء غازي قابل للاشتعال في حال حدث تسريب في دائرة التبريد، يجب أن يتماشى حجم الغرفة المستخدم فيها الجهاز مع كمية غاز التبريد المستخدم. يجب أن تكون مساحة الغرفة 1 متر مربع لكل 8 جرام من غاز التبريد R600a داخل الجهاز.
- قد يشتعل غاز التبريد المتسرب من الأنابيب أو يتسبب في انفجار.
- يتم توضيح مقدار غاز التبريد داخل الجهاز الخاص على لوحة التعريف الموجودة داخل الجهاز.

التركيب

- عند نقل هذا الجهاز ، ينبغي توفر شخصين أو أكثر للإمساك به بإحكام.
- قم بتركيب الجهاز على أرضية صلبة ومستوية.
- تجنب تركيب الجهاز في أماكن الرطوبة والغبار. تجنب تركيب أو تخزين الجهاز في الهواء الطلق أو في مساحة معرضة للتغيرات الجوية كضوء الشمس المباشر أو الرياح أو المطر أو درجات الحرارة دون درجة التجمد.
- لا تضع الجهاز تحت ضوء الشمس المباشر أو تعريضه للحرارة من قبل أجهزة حرارية مثل الموقد أو المدافئ.
- احرص على عدم كشف الجزء الخلفي من الجهاز عند التركيب.
- قم بتركيب الجهاز في مكان حيث يسهل فصل قابس الطاقة عن الجهاز.
- احرص على عدم السماح لباب الجهاز بالسقوط أثناء التجميع أو التفكيك.
- احرص على عدم قطع، أو سحق، أو تدمير كبل الطاقة أثناء تجميع باب الجهاز أو تفكيكه.
- احرص على عدم توجيه مقبس الطاقة لأعلى أو السماح للجهاز أن يميل في عكس اتجاه مقبس الطاقة.
- لا تقم بتوصيل مهابي القابس أو أية ملحقات أخرى بقابس الطاقة.
- لا تقم بتعديل سلك الطاقة أو تمديده.
- تأكد أن مقبس الخرج مؤرض بشكل صحيح، وبذلك لا يتلف سن التأريض على سلك الطاقة أو تتم إزالته من مقبس الطاقة. لمزيد من التفاصيل عن التأريض، يمكنك الاستفسار عن ذلك من مركز معلومات العملاء في شركة LG Electronics.
- يأتي هذا الجهاز مزوداً بسلك طاقة يحتوي على موصل تأريض للجهاز وقابس طاقة بوصلة تأريض. يجب توصيل قابس الطاقة بمقبس خرج مناسب مثبت ومورض وفقاً لجميع القوانين واللوائح المحلية.
- لا تعمد مطلقاً إلى بدء تشغيل أي جهاز تبعه عليه أي علامات تلف. إذا ساورتك الشكوك، فاتصل بالوكيل.
- تخلص من جميع مواد التعبئة (مثل أكياس البلاستيك ومادة الستايروفوم) بعيداً عن متناول الأطفال، إذ يمكن لمواد التغليف أن تسبب الاختناق.
- لا توصل الجهاز بمحوّل متعدد المقابس لا يوجد كابل طاقة (موصل به).

- خدمات المطاعم والتطبيقات المماثلة لمتاجر الجملة.

يُذكر هذا الرمز بأن المواد القابلة للاشتعال يمكن أن تشتعل أو أن ينشب عنها حريق في حالة عدم توخي الحذر.



- يحتوي هذا الجهاز على كمية صغيرة من وسيط تبريد الأيزوبوتان (R600a)، ولكنه قابل للاشتعال أيضًا. عند نقل وتركيب الجهاز، يجب توخي الحذر لضمان عدم تعرض أجزاء من دائرة التبريد للتلف.
- يتطلب غاز التبريد وغاز المادة العازلة القابل للاشتعال المستخدم بالجهاز إجراءات خاصة للتخلص منهما. استشر وكيل الخدمة أو شخصاً مؤهلاً بشكل مماثل قبل التخلص منها.
- لا تتفوّق دائرة غاز التبريد.
- في حالة تلف سلك الطاقة أو ارتخاء فتحة المقبس، لا تستخدم سلك الطاقة واتصل بمركز خدمة معتمد.
- لا تضع المأخذ المحمولة متعددة المخارج/المقبسات أو أسلاك التيار الكهربائي المحمولة خلف الجهاز.
- أدخل قابس الطاقة بإحكام في مقبس الخرج بعد إزالته أي رطوبة أو غبار بشكل كامل.
- احرص دائمًا على عدم فصل الطاقة عن الجهاز من خلال شد كابل الطاقة. وإخراج قابس الطاقة من مقبس الخرج احرص دائمًا على الإمساك به بإحكام قبل أن تقوم بجذبه في وضعية مستقيمة.
- حافظ على خلو فتحات التهوية الموجودة على الغلاف الخارجي أو بالهيكل المدمج للجهاز، من العوائق.
- لا تقم بتخزين المواد المتقدمة مثل علب الأيروسول ذات الدافع القابل للاشتعال داخل هذا الجهاز.
- لا تقم بإتماله الجهاز لدفعه أو جذبه عند نقله.
- تأكد عند وضع الجهاز من أن سلك التيار الكهربائي غير عالق أو تالف.
- لا تستخدم الأجهزة الميكانيكية أو غيرها من الوسائل لتسرريع عملية إذابة الثلاج.
- لا تستخدم مجفف الشعر لتجفيف الجهاز من الداخل أو تضع شمعة بالداخل لإزالة الروائح.
- لا تستخدم أجهزة كهربائية داخل الثلاجة.
- احرص ألا يعلق جزء من الجسم مثل اليد أو القدم أثناء تحريك الجهاز.
- افصل سلك الطاقة قبل تنظيف الجهاز أو تبديل المصباح الداخلي (حيث يتوجب تركيبه).
- لا تقم برش المياه أو المواد القابلة للاشتعال (معجون الأسنان، والكحول، ومحفف الدهان، والبنزين، والسوائل القابلة للاشتعال، ومواد التنظيف وما إلى ذلك) على الجزء الداخلي أو الخارجي من الجهاز لتنظيفه.
- لا تنظف الجهاز بفرش، أو قطع ملابس، أو الإسفنجات ذات الأسطح الخشنة أو تلك المصنوعة من مادة معدنية.
- يجب أن يقوم فقط موظف خدمة مؤهل من مركز خدمة شركة LG Electronics بفكك الجهاز أو إصلاحه أو تعديله. تواصل مع مركز معلومات العملاء في شركة LG Electronics في حال كنت تنقل الجهاز وتقوم بتركيبه في موقع مختلف.

إرشادات السلامة

اقرأ كل التعليمات قبل الاستخدام

يتمثل الغرض من إرشادات السلامة التالية في الحيلولة دون وقوع المخاطر غير المتوقعة أو الأضرار الناجمة عن التشغيل غير الآمن أو غير الصحيح للمنتج.

يتم تقسيم الإرشادات إلى "تحذير" و "تنبيه" على النحو الموضح أدناه.

رسائل السلامة

يتم عرض هذا الرمز للإشارة إلى الأمور وعمليات التشغيل التي يمكن أن تسبب مخاطر، فاحرص على قراءة الجزء الذي يحمل هذا الرمز بعناية واتبع الإرشادات لتجنب المخاطر.



تحذير

يشير هذا إلى أن عدم اتباع الإرشادات قد يسبب وقوع إصابة خطيرة أو الوفاة.



تنبيه

يشير هذا إلى أن عدم اتباع الإرشادات قد يتسبب في وقوع إصابة طفيفة أو تلف المنتج.



تحذير

تحذير

لتقليل مخاطر وقوع انفجار، أو نشوب حريق، أو حدوث وفاة، أو التعرض لصدمة كهربائية، أو حدوث إصابة، أو حرق للأشخاص عند استخدام المنتج، يجب اتباع احتياطات السلامة الأساسية، بما فيها ما يلي:

السلامة الفنية

- هذا الجهاز غير مخصص لاستخدام الأفراد (بما في ذلك الأطفال) الذين يعانون من نقص في قدراتهم البدنية أو الحسية أو العقلية، أو ليس لديهم خبرة ومعرفة، ما لم يتم الإشراف عليهم أو تقدم لهم الإرشادات المتعلقة باستخدام الجهاز من قبل شخص مسؤول عن سلامتهم، كذلك يجب الإشراف على الأطفال للتأكد من عدم عبئهم بالجهاز.

- هذا الجهاز مخصص للاستخدام المنزلي والاستعمالات المماثلة مثل:

- مناطق المطابخ في المتاجر والمكاتب وبيئات العمل الأخرى؛
- البيوت الزراعية واستخدام نزلاء الفنادق والرُّوْل وأماكن إقامة التُّرَّلَاءِ الأخرى؛
- بيئات تقديم وجبات الإفطار والوجبات المقدمة في السرير؛

استكشاف الأعطال وإصلاحها

قبل الاتصال للحصول على الخدمة.....34.....

جدول المحتويات

قد يحتوي هذا الدليل على صور أو محتوى يختلف عن الطراز
الذى قمت بشرائه.
يخصم هذا الدليل للمراجعة من الشركة المصنعة.

إرشادات السلامة

4.....	اقرأ كل التعليمات قبل الاستخدام
4.....	تحذير
8.....	تنبيه

التركيب

10.....	قبل إجراء التركيب
11.....	إزالة باب الثلاجة والمجمد
12.....	توصيل خط المياه
13.....	ضبط استواء الجهاز ومحاذاة الباب
14.....	تشغيل الطاقة
14.....	تحريك الجهاز لنفقه إلى مكان آخر

التشغيل

16.....	قبل الاستخدام
18.....	خواص المنتج
21.....	لوحة التحكم
22.....	(موزع المياه والثلج) Ice and Water Dispenser
24.....	صانع الثلوج التلقائي
25.....	باب الداخلي
26.....	InstaView
27.....	الدرج
27.....	الرف
28.....	سلة الباب

الوظائف الذكية

29.....	تطبيق LG ThinQ
30.....	التشخيص الذكي

الصيانة

31.....	التنظيف
32.....	(مرشح المياه) Water Filter



دليل المالك الثلاجة والمُجمد

قبل البدء في تركيب الجهاز، اقرأ هذه التعليمات بعناية. حيث سيسهل ذلك عملية التركيب ويضمن تركيب الجهاز بشكل صحيح وآمن. واحتفظ بهذه التعليمات بالقرب من المنتج بعد التركيب للرجوع إليها في المستقبل.



ENGLISH EN العربية AR

www.lg.com

حقوق النشر 2019-2020 إل جي للاكترونيات. كل الحقوق محفوظة



MFL71401509
Rev.02_052020