



Scan the QR code to see the manual.



OWNER'S MANUAL

AIR CONDITIONER



Read this owner's manual thoroughly before operating the appliance and keep it handy for reference at all times.

TYPE: WALL MOUNTED

EN ENGLISH

KK ҚАЗАҚША



5401750967 Rev.:

www.lg.com

Copyright © 2024 LG Electronics. All Rights Reserved

TABLE OF CONTENTS

This manual may contain images or content different from the model you purchased.

This manual is subject to revision by the manufacturer.

SAFETY INSTRUCTIONS	3
IMPORTANT SAFETY INSTRUCTIONS	4
OPERATION	12
Notes for Operation	12
Parts and Functions.....	12
Wireless Remote Control.....	13
Restarting the Air Conditioner Automatically	18
Using the Mode Function.....	18
Using the Jet Mode Function.....	20
Using the Fan Speed Function	21
Using the Air Flow Direction Function.....	21
Setting the On/Off Timer.....	22
Using the Sleep Function (Optional).....	23
Using the Simple Timer Function (Optional).....	23
Using the Energy Display Function (Optional).....	24
Using the Light Off Function (Optional)	24
Using the Comfort Air Function (Optional).....	24
Using the Energy Control Function (Optional).....	25
Using UVnano Function (Optional).....	25
Using Special Functions	26
SMART FUNCTIONS	28
LG ThinQ Application.....	28
Smart Diagnosis	30
MAINTENANCE.....	31
Clean the Air Filter	33
Clean the Allergy Filter (Optional).....	34
TROUBLESHOOTING	35

The following safety guidelines are intended to prevent unforeseen risks or damage from unsafe or incorrect operation of the appliance. The guidelines are separated into 'WARNING' and 'CAUTION' as described below.

 This symbol is displayed to indicate matters and operations that can cause risk. Read the part with this symbol carefully and follow the instructions in order to avoid risk.

WARNING

This indicates that the failure to follow the instructions can cause serious injury or death.

CAUTION

This indicates that the failure to follow the instructions can cause the minor injury or damage to the product.

The following symbols are displayed on indoor and outdoor units.

 This symbol indicates that this appliance uses a flammable refrigerant. If the refrigerant is leaked and exposure to an external ignition source, there is a risk of fire.

 This symbol indicates that the Operation Manual should be read carefully.

 This symbol indicates that a service personnel should be handling this equipment with reference to the Installation Manual.

 This symbol indicates that information is available such as the Operating Manual or Installation Manual.

IMPORTANT SAFETY INSTRUCTIONS

WARNING

To reduce the risk of explosion, fire, death, electric shock, injury or scalding to persons when using this product, follow basic precautions, including the following:

Children in the Household

This appliance is not intended for use by persons (including children) with reduced physical, sensory or mental capabilities, or lack of experience and knowledge, unless they have been given supervision or instruction concerning use of the appliance by a person responsible for their safety. Children should be supervised to ensure that they do not play with the appliance.

Installation

- Do not install the air conditioner on an unstable surface or in a place where there is danger of it falling.
- Contact an authorized service center when installing or relocating the air conditioner.
- Install the panel and the cover of the control box safely.
- Do not install the air conditioner in a place where flammable liquids or gases such as gasoline, propane, paint thinner, etc., are stored.
- Make sure that the pipe and the power cable connecting the indoor and outdoor units are not pulled too tight when installing the air conditioner.
- Use standard circuit breaker and fuse that conform to the rating of the air conditioner.
- Do not input air or gas into the system except with the specific refrigerant.
- Use non-flammable gas (nitrogen) to check for leak and to purge air; using compressed air or flammable gas may cause fire or explosion.

- The indoor/outdoor wiring connections must be secured tightly, and the cable should be routed properly so that there is no force pulling the cable from the connection terminals. Improper or loose connections can cause heat generation or fire.
- Install dedicated electric outlet and circuit breaker before using the air conditioner.
- Do not connect the ground wire to a gas pipe, a lightning rod, or a telephone ground wire.
- Keep any required ventilation openings clear of obstruction.
- Means for disconnection must be incorporated in the fixed wiring in accordance with the wiring rules.
- Do not install the unit in potentially explosive atmospheres.

Operation

- Be sure to use only those parts listed in the service parts list. Never attempt to modify the equipment.
- Make sure that children do not climb on or hit the outdoor unit.
- Dispose of the batteries in a place where there is no danger of fire.
- Use only the refrigerant specified on the air conditioner label.
- Cut off the power supply if there is any noise, smell, or smoke coming from the air conditioner.
- Do not leave flammable substances such as gasoline, benzene, or thinner near the air conditioner.
- Contact an authorized service center when the air conditioner is submerged by flood waters.
- Do not use the air conditioner for an extended period of time in a small place without proper ventilation.
- In the event of a gas leak (such as Freon, propane gas, LP gas, etc.) ventilate sufficiently before using the air conditioner again.

- Be sure to ventilate sufficiently when the air conditioner and a heating appliance such as a heater are used simultaneously.
- Do not block the inlet or outlet of air flow.
- Do not insert hands or other objects through the air inlet or outlet while the air conditioner is operating.
- Make sure that the power cable is neither dirty, loose, nor broken.
- Never touch, operate, or repair the air conditioner with wet hands.
- Do not place any objects on the power cable.
- Do not place a heater or other heating appliances near the power cable.
- Do not modify or extend the power cable. Scratches or peeling insulation on the power cables may result in fire or electric shock, and should be replaced.
- Cut off the power supply immediately in the event of a blackout or a thunderstorm.
- Take care to ensure that power cable could not be pulled out or damaged during operation.
- Do not touch refrigerant pipe, water pipe and any internal parts while the unit is operating or immediately after operation.

Maintenance

- Do not clean the appliance by spraying water directly onto the product.
- Before cleaning or performing maintenance, disconnect the power supply and wait until the fan stops.

Technical Safety

- Installation or repairs made by unauthorized persons can pose hazards to you and others.

- Any person who is involved with working on or breaking into a refrigerant circuit should hold a current valid certificate from an industry-accredited assessment authority, which authorizes their competence to handle refrigerants safely in accordance with an industry recognized assessment specification.
- Servicing shall only be performed as recommended by the equipment manufacturer. Maintenance and repair requiring the assistance of other skilled personnel shall be carried out under the supervision of the person competent in the use of flammable refrigerants.
- The information contained in the manual is intended for use by a qualified service technician who is familiar with the safety procedures and equipped with the proper tools and test instruments.
- Failure to read and follow all instructions in this manual can result in equipment malfunction, property damage, personal injury and/or death.
- The appliance shall be installed in accordance with national wiring regulations.
- When the power cord is to be replaced, the replacement work shall be performed by authorized personnel using only genuine replacement parts.
- This appliance must be properly grounded to minimize risk of electric shock.
- Do not cut or remove the grounding prong from the power plug.
- Attaching the earth wire to the power outlet cover screw does not ground the appliance unless the cover screw is metal, uninsulated, and the power outlet is grounded through house wiring.
- If you have any doubt whether the air conditioner is properly grounded, have the power outlet and circuit checked by a qualified electrician.

- The refrigerant and insulation blowing gas used in the appliance require special disposal procedures. Consult a service agent or a similarly qualified person before disposing of them.
- If the supply cord is damaged, it must be replaced by the manufacturer, its service agent or similarly qualified person in order to avoid a hazard.
- The appliance shall be stored in a well-ventilated area where the room size corresponds to the room area as specified for operation.
- The appliance shall be stored in a room without continuously operating open flames (for example an operating gas appliance) and ignition sources (for example an operating electric heater).
- The appliance shall be stored so as to prevent mechanical damage from occurring.
- Unintended use of the appliance or damage to the housing may result in the escape of dangerous UV-C radiation. UV-C radiation may, even in little doses, cause harm to the eyes and skin.
- This appliance contains a UV-C lamp.
- When the appliances are damaged or need to be replaced, disconnect the power supply and contact the service center.
- Do not operate UV-C lamp outside of the appliance.
- Do not clean and touch air deflector during operation.
- Before opening doors and access panels bearing the ultraviolet radiation hazard symbol for the conducting user maintenance, it is recommended to disconnect the power.
- Read the maintenance instructions before opening the appliance.
- Appliances that are obviously damaged must not be operated.
- The appliance must be disconnected from the supply before replacing the UV-C lamp.

CAUTION

To reduce the risk of minor injury to persons, malfunction, or damage to the product or property when using this product, follow basic precautions, including the following:

Installation

- Do not install the air conditioner in an area where it is directly exposed to sea wind (salt spray).
- Install the drain hose properly for the smooth drainage of water condensation.
- Exercise caution when unpacking or installing the air conditioner.
- Do not touch the leaking refrigerant during installation or repair.
- Transport the air conditioner with two or more people or use a forklift.
- Install the outdoor unit such that it is protected from direct sunlight. Do not place the indoor unit in a place where it is directly exposed to sunlight via the windows.
- Safely dispose of packing materials such as screws, nails, plastic bag or batteries using proper packaging after installation or repair.
- Install the air conditioner in a place where the noise from the outdoor unit or the exhaust fumes will not inconvenience the neighbors. Failure to do so may result in conflict with the neighbors.

Operation

- Remove the batteries if the remote control is not to be used for an extended period of time.

- Make sure that the filter is installed before operating the air conditioner.
- Be sure to check if there is a refrigerant leak after installing or repairing the air conditioner.
- Do not place any object on the air conditioner.
- Never mix different types of batteries, or old and new batteries for the remote control.
- Do not let the air conditioner run for a long time when humidity is very high or when a door or a window has been left open.
- Stop using the remote control if there is a fluid leak in the battery. If your clothes or skin are exposed to the leaking battery fluid, wash off with clean water.
- Do not expose people, animals, or plants to the cold or hot wind from the air conditioner for extended periods of time.
- If the leaking battery fluid has been swallowed, rinse the inside of the mouth thoroughly and consult a doctor.
- Do not drink the water drained from the air conditioner.
- Do not use the product for special purposes, such as preserving foods, works of art, and etc. It is an air conditioner for consumer purposes, not a precision refrigeration system. There is risk of damage or loss of property.
- Do not recharge or disassemble the batteries.

Maintenance

- Never touch the metal parts of the air conditioner when removing the air filter.
- Use a sturdy stool or ladder when cleaning, maintaining, or repairing the air conditioner at a height.
- Never use strong cleaning agents or solvents when cleaning the air conditioner or spray water. Use a smooth cloth.
- To clean the interior, contact an authorized service center or dealer. Using harsh detergents may cause corrosion or damage to the unit.

Disposal of Waste Batteries/Accumulators



- This symbol may be combined with chemical symbols for mercury (Hg), cadmium (Cd) or lead (Pb) if the battery contains more than 0.0005 % of mercury, 0.002 % of cadmium or 0.004 % of lead.
- All batteries/accumulators should be disposed separately from the municipal waste stream via designated collection facilities appointed by the government or the local authorities.
- The correct disposal of your old batteries/accumulators will help to prevent potential negative consequences for the environment, animal and human health.
- For more detailed information about disposal of your old batteries/accumulators, please contact your city office, waste disposal service or the shop where you purchased the product.


Notes for Operation

Suggestion for Energy Saving

- Do not over-cool the space. This may be harmful for your health and may consume more electricity.
- Block sunlight with blinds or curtains while you are operating the air conditioner.
- Keep doors or windows closed tightly while you are operating the air conditioner.
- Adjust the direction of the air flow vertically or horizontally to circulate indoor air.
- Speed up the fan to cool or warm indoor air quickly, within a short period of time.
- Open windows regularly for ventilation. The indoor air quality may deteriorate if the air conditioner is used for long durations.
- Clean the air filter once every 2 weeks. Dust and impurities collected in the air filter may block the air flow or reduce the unit performance.


Parts and Functions

Indoor Unit



- 1** Air Filter
- 2** Air Intake
- 3** Front Cover
- 4** Air Outlet
- 5** Air Deflector (Horizontal Vane)
- 6** Air Deflector (Vertical Louver)
- 7** On/Off Button

Outdoor Unit



- 1** Air Intake Vents
- 2** Air Outlet Vents

NOTE


- The number and location of operation lamps may vary according to the model of the air conditioner.
- The feature may be changed according to the type of model.

Wireless Remote Control


Inserting Batteries

If the display screen of the remote control begins to fade, replace the batteries. Insert AAA (1.5 V) batteries before using the remote control.

- 1 Remove the battery cover.




- 2 Insert the new batteries and make sure that the + and - terminals of the batteries are installed correctly.



Installing the Remote Control Holder (Optional)


To protect the remote control, install the holder where there is no direct sunlight.

- 1 Choose a safe and easily accessible location.
- 2 Fix the holder by fastening 2 screws firmly with a screwdriver.



Operating Method

Point the remote control towards the signal receiver at the right side of the air conditioner to operate it.



NOTE

- The remote control may operate other electronic devices if it is directed towards them. Make sure to point the remote control towards the air conditioner signal receiver.
- For proper operation, use a soft cloth to clean the signal transmitter and receiver.
- In case of a function not provided in the product, no buzzer sound occurs from the product when a button for such function on the remote control is pressed except for Air Flow Direction (⏮️), Energy Display (⏭️), Air Purification function (⏮️).

Setting the Current Time

- 1 Insert batteries.
 - The icon below blinks at the bottom of the display screen.



- 2 Press  or  button to select the minutes.

- 3 Press **Set/Cancel** button to finish.

NOTE

- The On/Off Timer is available after setting the current time.

Using the °C/°F Conversion Function (Optional)

This function changes unit between °C and °F

- Press and hold  button about 5 seconds.


Operating the Air Conditioner without the Remote Control

You can use the **ON/OFF** button of the indoor unit to operate the air conditioner when the remote control is unavailable.


- 1 Open the front cover (Type2) or horizontal vane (Type1).

- 2 Press the **ON/OFF** button.

Type1



Type2




NOTE

- The stepping motor may be broken, if the horizontal vane opens rapidly.
- The fan speed is set to high.
- The feature may be changed according to the type of model.
- The temperature cannot be altered when using this emergency **ON/OFF** button.
- For cooling & heating models, the temperature is set from 22 °C to 24 °C

Using Wireless Remote Control


You can operate the air conditioner more conveniently with the remote control.

1 Button	2 Display Screen	Description	Available Function	
			Single Split	Multi
	-	To turn on/off the air conditioner.	○	○
 Temp. 	88 °C	To adjust the desired room temperature in cooling, heating or auto changeover mode.	○	○
Mode		To select the cooling mode.	○	○
		To select the heating mode.	○	○
		To select the dehumidification mode.	○	○
		To select the fan mode.	○	○
		To select the auto changeover/auto operation mode.	○	○
Jet Mode	Po	To change room temperature quickly.	○	○
Fan Speed		To adjust the fan speed.	○	○
 		To adjust the air flow direction vertically or horizontally.	○	○




NOTE

- * buttons may be changed according to the type of model.
- When connected to the Multi Outdoor unit, the Energy Display, Energy Control, Silent and Smart Diagnosis function may not be supported.



1 Button	2 Display Screen	Description	Available Function	
			Single Split	Multi
	S ON OFF	To turn on/off air conditioner automatically at desired time.	O	O
Set/Cancel	-	To set/cancel the special functions and timer.	O	O
	-	To cancel the timer settings.	O	O
	-	To adjust time.	O	O
*Light Off	-	To set the brightness of the display on the indoor unit.	O	O
Room Temp.		To display the room temperature.	O	O
°C↔°F (5 s)	°C °F	To change unit between °C and °F	O	O
*Comfort Air		To adjust the air flow to deflect wind.	O	O
kW(3 s)	-	To set whether or not to display information regarding energy.	O	X
*Energy Ctrl.	88 %	To bring the effect of the power saving.	O	X
Diagnosis (5 s)	-	To conveniently check maintenance information of a product.	O	X
UVnano (3 s)	-	To keep the fan clean.	O (Optional)	O (Optional)



1 Button	2 Display Screen	Description	Available Function	
			Single Split	Multi
		The Ion generator uses millions of ions to help improve indoor air quality.	O (Optional)	O (Optional)
		To reduce noise from outdoor units.	O	X
		To remove moisture generated inside the indoor unit.	O	O
Reset	-	To initialize the remote control settings.	O	O

NOTE

- Some functions may not be supported, depending on the model.
- * buttons may be changed according to the type of model.
- Press the **Set/Cancel** button to operate the selected **Func.**


Restarting the Air Conditioner Automatically

When the air conditioner is turned on again after a power failure, this function restores the previous settings.


Disabling Auto Restart

- 1 Open the front cover (Type2) or horizontal vane (Type1).
- 2 Press the **ON/OFF** button and hold it for 6 seconds, then the unit will beep twice and the lamp will blink twice 4 times.
 - To re-enable the function, press the **ON/OFF** button and hold it for 6 seconds. The unit will beep twice and the lamp will blink 4 times.

Type1



Type2




NOTE

- The feature may be changed according to the type of model.
- If you press and hold the **ON/OFF** button for 3 – 5 seconds, instead of 6 seconds, the unit will switch to the test operation. In the test operation, the unit blows out strong cooling air for 18 minutes and then returns to factory default settings.

Using the Mode Function

This function allows you to select the desired function.



Cooling Mode

- 1 Turn the appliance on.
- 2 Press **Mode** button repeatedly to select the Cooling Mode.
 - ❄️ is displayed on the display screen.
- 3 Press **▲** or **▼** button to set the desired temperature.

Auto Operation (Artificial Intelligence)

Multi Model

In this operation mode, the system is automatically operated by the electronic controls.

- 1 Turn the appliance on.
- 2 Press **Mode** button repeatedly to select the Auto Operation.
 -  is displayed on the display screen.
- 3 Press  or  button to set the desired temperature.
- 4 Press **Fan Speed** button to adjust the fan speed.

Auto Changeover Mode

Single Split Model

This mode changes the mode automatically to maintain the set temperature at $\pm 2^{\circ}\text{C}$

- 1 Turn the appliance on.
- 2 Press **Mode** button repeatedly to select the Auto Changeover Mode.
 -  is displayed on the display screen.
- 3 Press  or  button to set the desired temperature.
- 4 Press **Fan Speed** button to adjust the fan speed.

Dehumidification Mode

This mode removes excess moisture from a highly humid environment or during the rainy season, in order to prevent mildew from setting in. This mode adjusts the room temperature and the fan speed automatically to maintain the optimal level of humidity.

- 1 Turn the appliance on.
- 2 Press **Mode** button repeatedly to select the Dehumidification Mode.
 -  is displayed on the display screen.

NOTE

- In this mode you cannot adjust the room temperature, it is adjusted automatically.
- The room temperature is not displayed on the display screen.
- In the dehumidification mode, compressor and indoor fan may not operate when the room temperature is below 24°C

Heating Mode

- 1 Turn the appliance on.
- 2 Press **Mode** button repeatedly to select the Heating Mode.
 -  is displayed on the display screen.
- 3 Press  or  button to set the desired temperature.

NOTE

-  will be displayed on the indoor unit when defrosting is operating.
- Furthermore, this indication will be displayed on the indoor unit:
 - When preheating is operating.
 - When the room temperature has been reached to the set temperature.

Fan Mode

This mode only circulates the indoor air without changing the room temperature.

- 1 Turn the appliance on.
- 2 Press **Mode** button repeatedly to select the Fan Mode.
 -  is displayed on the display screen.
- 3 Press **Fan Speed** button to adjust the fan speed.

NOTE

-  or  will be displayed on the indoor unit when fan mode is operating.

Using the Jet Mode Function

Changing Room Temperature Quickly

This function allows you to cool indoor air quickly during the summer or warm it quickly during winter.

- The Jet Mode function is available with Cooling, Heating and Dehumidification Mode.

- 1 Turn the appliance on.
- 2 Press **Mode** button repeatedly to select the desired mode.
- 3 Press **Jet Mode** button.
 -  is displayed on the display screen.

NOTE

- Jet Heating Mode is not available on some models.
- In Jet Cooling Mode, strong air blows out for 30 minutes.
 - After 30 minutes later, setting temperature is maintaining 18 °C
If you want to change the temperature, Press  or  button to set the desired temperature.
- In Jet Heating Mode, strong air blows out for 30 minutes.
 - After 30 minutes later, setting temperature is maintaining 30 °C
If you want to change the temperature, Press  or  button to set the desired temperature.
- This function may operate differently from the remote control display.

Using the Fan Speed Function

Adjusting the Fan Speed

- Press **Fan Speed** button repeatedly to adjust the fan speed.

Display Screen	Speed
	High
	Medium - High
	Medium
	Medium - Low
	Low
-	Natural Wind

NOTE

- The fan speed of Natural Wind adjusts automatically.



- The fan speed icons are displayed on some indoor units.



- Indoor unit display is displayed only 5 seconds and return to the setting temperature on some models.

Using the Air Flow Direction Function

This function adjusts the direction of the air flow vertically (horizontally).

- Press   button repeatedly and select the desired direction.
 - Select  to adjust the direction of the air flow automatically.

NOTE

- Adjusting the air flow direction horizontally may not be supported, depending on the model.
- Adjusting the air deflector arbitrarily may cause product failure.
- If you restart the air conditioner, it starts to operate with the previously set direction of air flow, so the air deflector may not match the icon displayed on the remote control. When this occurs, press  or  button to adjust the direction of the air flow again.
- This function may operate differently from the remote control display.

Setting the On/Off Timer

This function sets the air conditioner to turn on/off automatically at desired time.
On/Off Timer can be set together.

Setting the On Timer

- 1 Press  button repeatedly.
 - The icon below blinks at the bottom of the display screen.



- 2 Press  or  button to select the minutes.

- 3 Press **Set/Cancel** button to finish.
 - After setting the timer, current time and  icon are displayed on the display screen indicating that the desired time is set.

Canceling the On Timer

- 1 Press  button repeatedly.
 - The icon below blinks at the bottom of the display screen.



- 2 Press **Set/Cancel** button to cancel the setting.

Setting the Off Timer

- 1 Press  button repeatedly.
 - The icon below blinks at the bottom of the display screen.



- 2 Press  or  button to select the minutes.

- 3 Press **Set/Cancel** button to finish.
 - After setting the timer, current time and  icon are displayed on the display screen indicating that the desired time is set.

NOTE

- This function is disabled when you set Simple Timer.

Canceling the Off Timer

- 1 Press  button repeatedly.
 - The icon below blinks at the bottom of the display screen.



- 2 Press **Set/Cancel** button to cancel the setting.

Canceling the Timer Setting

- Press  button to cancel all timer settings.

Using the Sleep Function (Optional)

This function turns off the air conditioner automatically when you go to sleep.

- 1 Turn the appliance on.
- 2 Press  button repeatedly.
 - The icon below blinks at the bottom of the display screen.



- 3 Press  or  button to select the hour (up to 7 hours).
- 4 Press **Set/Cancel** button to finish.
 -  is displayed on the display screen.


NOTE

-  is displayed on some indoor units.
- Indoor unit display is displayed from 1H to 7H which is displayed only 5 seconds and then return to the setting temperature.
- In the Cooling and Dehumidification Mode, the temperature increases by 1 °C after 30 minutes and additional 1 °C after another 30 minutes for a more comfortable sleep.
- The temperature increases up to 2 °C from the preset temperature.
- Although the remark for fan speed on the display screen may be changed, the fan speed is adjusted automatically.

Using the Simple Timer Function (Optional)

This function turns off the air conditioner automatically when you go to sleep.

- 1 Turn the appliance on.
- 2 Press  button repeatedly.
 - The icon below blinks at the bottom of the display screen.



- 3 Press  or  button to select the hour (up to 7 hours).
- 4 Press **Set/Cancel** button to finish.
 -  is displayed on the display screen.

NOTE

- This function is disabled when you set Off Timer.

Using the Energy Display Function (Optional)

This function displays the amount of electricity generated on the indoor display as the product operates.

Display the Current Energy Usage

- 1 Turn the appliance on.
- 2 Press  button and hold it about 3 seconds.
 - The instantaneous power consumption () is displayed for a while on some indoor units.

NOTE

- The unit of the displayed value is kW.
- It is not displayed on the wireless remote control.
- If it is more than 99 kW, which is the range of expression, maintain it as 99 kW.
- Display wattage under 10 kW with 0.1 kW unit, and display one over 10 kW with 1 kW unit.
- The actual power may differ from the power displayed.
- When connected to the Multi Outdoor unit, this function may not be supported.

Using the Light Off Function (Optional)

Display Screen Brightness

You can set the brightness of the indoor unit display screen.

- Press **Light Off** button.

NOTE

- Turn on/off the Display screen.
- If the brightness of an indoor appliance's display is set to OFF, pressing a button on the remote control automatically turns the display on for a while.
- This function may operate differently, depending on the model.

Using the Comfort Air Function (Optional)

Comfort Vane Operation

This function conveniently sets the vane to a preset position to deflect the supply air away from blowing directly onto the occupants in the room.

- 1 Turn the appliance on.
- 2 Press **Comfort Air** button repeatedly and select the desired direction.
 -  or  is displayed on the display screen.

NOTE

-  or  is displayed on some indoor units.
- This function is disabled when you press **Mode** or **Jet Mode** button.
- This function is disabled and auto swing of vertical direction is set up when you press  button.
- When this function is off, the horizontal vane operates automatically depending on the set mode.

Using the Energy Control Function (Optional)

- 1 Turn the appliance on.
- 2 Press **Energy Ctrl.** button.
 - Press **Energy Ctrl.** button repeatedly to select each step.

NOTE

- 1 step : The power Input is decreased by 20 % compared to rated power input.
– 80 % is displayed on the display screen.
- 2 step : The power Input is decreased by 40 % compared to rated power input.
– 60 % is displayed on the display screen.
- 3 step (Optional) : The power Input is decreased by 60 % compared to rated power input.
– 40 % is displayed on the display screen.
- L (1 step), LL (2 step) is displayed on some indoor units.
- This function is available with Cooling Mode.
- Capacity may decrease when Energy Control mode is selected.
- Desired temperature is displayed about 5 seconds if you press **Fan Speed**,  or  button.
- Room temperature is displayed about 5 seconds if you press **Room Temp.** button.
- When connected to the Multi Outdoor unit, this function may not be supported.

Using UVnano Function (Optional)

UVnano is a compound word of UV (ultraviolet rays) and nanometer (length unit).

This function reduces various bacteria inside the air conditioner.

Model name: LTPL-G35UV275GS-JA
LTPL-G35U275GS-TWA
CUD7GF1A

Press **Jet Mode** button and hold it about 3 seconds.

NOTE

- **UV** is displayed on some indoor units, depending on the model.
- The UV LED operates at regular intervals to keep the fan clean.
- The UVnano function stops when the air conditioner is turned off.
- When Auto Clean Function starts, UVnano Function works together to keep the fan clean.
- This function is disabled with Heating Mode.

Using Special Functions

- 1 Turn the appliance on.
- 2 Press **Func.** button repeatedly to select the desired function.
- 3 Press **Set/Cancel** button to finish.



Display Screen	Description
	The Ion generator uses millions of ions to help improve indoor air quality.
	To reduce noise from outdoor units.
	To remove moisture generated inside the indoor unit.

NOTE

- Some functions may not be supported, depending on the model.
- Some functions may operate differently from the remote control display.

Canceling Special Functions

- 1 Press **Func.** button repeatedly to select the desired function.
- 2 Press **Set/Cancel** button to cancel the function.

Using the Air Purification Function

These functions supply clean and fresh air by ion particles and the filter.

Function	Display	Description
Ionizer		Ion particles from Ionizer reduce the surface bacteria and other harmful substances.
Plasma		It removes microscopic contaminants from the intake air completely to supply clean and fresh air.

NOTE

- You can use this function without turning the air conditioner on.
- Both the plasma lamp and the cooling lamp light up while Smoke Away/Plasma is in operation on some models.
- Do not touch ionizer during operation.
- This function may operate differently from the remote control display.

Using the Silent Function

This function prevents potential claims by neighbors, reducing noise from outdoor units.

-  is displayed on the display screen.

NOTE

- This function is disabled when you press **Mode** or **Energy Ctrl.** or **Jet Mode** button.
- This function is available with Cooling, Heating, Auto Changeover, Auto Operation Mode.
- When connected to the Multi Outdoor unit, this function may not be supported.

Using the Auto Clean Function

In the Cooling and Dehumidification Mode, moisture is generated inside the indoor unit. This function removes such moisture.

-  is displayed on the display screen.

NOTE

- Some functions cannot be used while the Auto Clean function is in operation.
- When UVnano Function is set, Auto Clean Function works together.
- If you turn off the unit, the fan continues to run for 30 minutes and cleans the inside of the indoor unit.
-  is displayed on some indoor units, depending on the model.

LG ThinQ Application

This feature is only available on models with the  or **ThinQ** logo.

The **LG ThinQ** application allows you to communicate with the appliance using a smartphone.

LG ThinQ Application Features

Communicate with the appliance from a smartphone using the convenient smart features.

Smart Diagnosis

If you experience a problem while using the appliance, this smart diagnosis feature will help you diagnose the problem.

Settings

Allows you to set various options on the appliance and in the application.


NOTE

- If you change your wireless router, internet service provider, or password, delete the registered appliance from the **LG ThinQ** application and register it again.
- The application is subject to change for appliance improvement purposes without notice to users.
- Functions may vary by model.


Before Using LG ThinQ Application

- 1 Check the distance between the appliance and the wireless router (Wi-Fi network).
 - If the distance between the appliance and the wireless router is too far, the signal strength becomes weak. It may take a long time to register or installation may fail.

- 2 Turn off the **Mobile data** or **Cellular Data** on your smartphone.



- 3 Connect your smartphone to the wireless router.



NOTE

- To verify the Wi-Fi connection, check that  icon on the control panel is lit.
- The appliance supports 2.4 GHz Wi-Fi networks only. To check your network frequency, contact your Internet service provider or refer to your wireless router manual.
- **LG ThinQ** is not responsible for any network connection problems or any faults, malfunctions, or errors caused by network connection.
- If the appliance is having trouble connecting to the Wi-Fi network, it may be too far from the router. Purchase a Wi-Fi repeater (range extender) to improve the Wi-Fi signal strength.
- The Wi-Fi connection may not connect or may be interrupted because of the home network environment.
- The network connection may not work properly depending on the Internet service provider.
- The surrounding wireless environment can make the wireless network service run slowly.

- The appliance cannot be registered due to problems with the wireless signal transmission. Unplug the appliance and wait about a minute before trying again.
- If the firewall on your wireless router is enabled, disable the firewall or add an exception to it.
- The wireless network name (SSID) should be a combination of English letters and numbers. (Do not use special characters.)
- Smartphone user interface (UI) may vary depending on the mobile operating system (OS) and the manufacturer.
- If the security protocol of the router is set to **WEP**, you may fail to set up the network. Please change it to other security protocols (**WPA2** is recommended) and register the product again.

Installing the LG ThinQ Application

Search for the **LG ThinQ** application from the Google Play Store or Apple App Store on a smartphone. Follow instructions to download and install the application.

Wireless LAN Module Specifications

Model	LCW-007
Frequency Range	2412 MHz - 2472 MHz
Output Power(Max)	IEEE 802.11b:17.59 dBm IEEE 802.11g:17.39 dBm IEEE 802.11n(HT20):16.64 dBm IEEE 802.11n(HT40):17.05 dBm

Wireless function S/W version: V 1.0

This device should be installed and operated with a minimum distance of 20 cm between the device and the body.

Declaration of Conformity

The LG Electronics declares that the type of radio equipment AIR CONDITIONER corresponds to the Technical regulations of radio equipment; The full text of the Declaration of Conformity is available on the website at the following address:

<https://www.lg.com/global/support/cedoc/cedoc>

Open Source Software Notice Information

To obtain the source code that is contained in this product, under GPL, LGPL, MPL, and other open source licenses that have the obligation to disclose source code, and to access all referred license terms, copyright notices and other relevant documents, please visit <https://opensource.lge.com>.

LG Electronics will also provide open source code to you on CD-ROM for a charge covering the cost of performing such distribution (such as the cost of media, shipping, and handling) upon email request to opensource@lge.com.

This offer is valid to anyone in receipt of this information for a period of three years after our last shipment of this product.

Smart Diagnosis

This feature is only available on models with the  or  logo.

Use this feature to help you diagnose and solve problems with your appliance.

NOTE

- For reasons not attributable to LGE's negligence, the service may not operate due to external factors such as, but not limited to, Wi-Fi unavailability, Wi-Fi disconnection, local app store policy, or app unavailability.
- The feature may be subject to change without prior notice and may have a different form depending on where you are located.

Using LG ThinQ to Diagnose Issues

If you experience a problem with your Wi-Fi equipped appliance, it can transmit troubleshooting data to a smartphone using the **LG ThinQ** application.

- Launch the **LG ThinQ** application and select the **Smart Diagnosis** feature in the menu. Follow the instructions provided in the **LG ThinQ** application.

Using Audible Diagnosis to Diagnose Issues

Follow the instructions below to use the audible diagnosis method.

- Launch the **LG ThinQ** application and select the **Smart Diagnosis** feature in the menu. Follow the instructions for audible diagnosis provided in the **LG ThinQ** application.

- 1 Plug the power plug in the outlet properly.
- 2 Place the mouthpiece of your smartphone close to the  or  logo.
- 3 Press and hold the **Diagnosis(5 s)** button for 5 seconds or longer while holding the smartphone mouthpiece to the logo until the data transfer is complete.
 - Keep the smartphone in place until the data transfer has finished. Time remaining for data transfer is displayed.
- 4 After the data transfer is complete, the diagnosis will be displayed in the application.

NOTE


- For best results, do not move the phone while the tones are being transmitted.
- Be sure to keep ambient noise to a minimum or the phone may not correctly receive the buzzer beeps from the indoor unit.

⚠ WARNING

- Before cleaning or performing maintenance, disconnect the power supply and wait until the fan stops.

If the air conditioner will not be used for an extended period of time, dry the air conditioner to maintain it in best condition. Clean the product regularly to maintain optimal performance and to prevent possible breakdown.

- Dry the air conditioner in Fan mode for 3 to 4 hours and disconnect the power. There may be internal damage if moisture is left in its components.
- Before using the air conditioner again, dry the inner components of the air conditioner in Fan mode for 3 to 4 hours. This will help to remove the odor generated from moisture.



- The feature may be changed according to the type of model.

Type	Description	Interval
Air Filter	Clean with a vacuum or hand wash.	2 weeks
Allergy Filter	Clean with a vacuum or brush.	Every 6 months
Ionizer (Optional)	Use dry cotton bud to remove any dust.	Every 6 months
Indoor Unit	Clean the indoor unit surface by using a soft, dry cloth.	Regularly
	Have a professional clean the condensate drain pan.	Once a year
	Have a professional clean the condensate drain pipe.	Every 4 months
	Replace the remote control batteries.	Once a year
Outdoor Unit	Have a professional clean the heat exchanger coils and the panel vents. (Consult with technician.)	Once a year
	Have a professional clean the fan.	Once a year
	Have a professional clean the condensate drain pan.	Once a year
	Have a professional verify that all the fan assembly is firmly tightened.	Once a year
	Clean the electric components with air.	Once a year

NOTE

- Never use water that is higher than 40 °C when you clean the filters. It may cause deformation or discoloration.
- Never use volatile substances when you clean the filters. They may damage the surface of the product.
- Do not wash the allergy filter with water, because the filter can be damaged (Optional).

Clean the Air Filter

Clean the air filters once every 2 weeks, or more, if necessary.


NOTE

- The air filter can be broken when it is bent.
- When the air filter is not assembled correctly, dust and other substances can enter into the indoor unit.


Type1

If you look at the indoor unit from above it, can assemble the top filter easily.


- 1 Turn off the power to the unit.
- 2 Hold the knobs of the air filter, lift it up slightly.




- 3 Remove it from the indoor unit.



- 4 Clean the filter with a vacuum cleaner or with lukewarm water with neutral detergent.
- 5 Dry the filter in the shade.
- 6 Insert the hooks of the air filter into the front cover.




- 7 Push down hooks to assemble the air filter.




- 8 Check the side of the front cover for correct assembly of the air filter.

Type2

- 1 Turn off the power to the unit.
- 2 Open the front cover.
 - Lift up both sides of the cover slightly.
- 3 Hold the knobs of the air filters, pull them down slightly and remove them from the indoor unit.



- 4 Clean the filters with a vacuum cleaner or with lukewarm water with neutral detergent.
- 5 Dry the filters in the shade.
- 6 Insert the hooks of the air filters into the front cover.




- 7 Check the side of the front cover for correct assembly of the air filters.


Clean the Allergy Filter (Optional)

- 1 Turn off the power to the unit.
- 2 Remove the air filter from the indoor unit.
- 3 Remove the allergy filter from the indoor unit.

Type1




Type2




- 4 Clean the filter with a vacuum cleaner.

- 5 Insert the allergy filter.

Type1



Type2



- 6 Assemble the air filter.
- 7 Check the side of the front cover for correct assembly of the air filter.

NOTE

- The feature and location of allergy filter may vary according to the type of model.

Self-diagnosis Function

This product has a built-in self-diagnosis function. If an error occurs, the lamp of the indoor unit will blink in 2 second intervals. If this occurs, contact your local dealer or service center.

Before Calling for Service

Please check the following before you contact the service center. If the problem persists, contact your local service center.

Symptoms	Possible Causes & Solution
The air conditioner does not work normally.	Burning smell and strange sounds are coming from the unit. • Turn off the air conditioner, switch OFF, or disconnect the power supply, and contact the service center.
	Water leaks from the indoor unit even when the humidity level is low. • Turn off the air conditioner, switch OFF, or disconnect the power supply, and contact the service center.
	The power cable is damaged or it is generating excessive heat. • Turn off the air conditioner, switch OFF, or disconnect the power supply, and contact the service center.
	A switch, a circuit breaker (safety, ground), or a fuse is not operated properly. • Turn off the air conditioner, switch OFF, or disconnect the power supply, and contact the service center.
	The unit generates an error code from its self-diagnosis. • Turn off the air conditioner, switch OFF, or disconnect the power supply, and contact the service center.
The air conditioner does not work.	The air conditioner is unplugged. • Check whether the power cord is plugged into the outlet or the power isolators are switched on.
	A fuse exploded, or the power supply is blocked. • Replace the fuse or check if the circuit breaker has tripped.
	A power failure has occurred. • Turn off the air conditioner when a power failure occurs. • When the power is restored, wait 3 minutes, and then turn on the air conditioner.
	The voltage is too high or too low. • Check if the circuit breaker has tripped.
	The air conditioner was turned off automatically at a preset time. • Turn the air conditioner on.
	The battery setting in the remote controller is incorrect. • Make sure that the batteries are inserted correctly in your remote controller. • If the batteries are placed correctly, but the air conditioner still does not operate, replace the batteries and try again.

Symptoms	Possible Causes & Solution
The air conditioner does not emit cool air.	Air is not circulating properly. • Make sure that there are no curtains, blinds, or pieces of furniture blocking the front of the air conditioner.
	The air filter is dirty. • Clean the air filter once every 2 weeks. • See “Clean the Air Filter” for more information.
	The room temperature is too high. • In summer, cooling the indoor air fully may take some time. In this case, select the Jet Mode to cool the indoor air quickly.
	Cold air is escaping from the room. • Make sure that no cold air is escaping through the ventilation points in the room.
	The desired temperature is higher than the current temperature. • Set the desired temperature to a level lower than the current temperature.
	There is a heating source nearby. • Avoid using heat generators like electric ovens or gas burners while the air conditioner is in operation.
	Fan Mode is selected. • During Fan Mode, air blows from the air conditioner without cooling or heating the indoor air. • Switch the operation mode to cooling operation.
	Outside temperature is too high. • The cooling effect may not be sufficient.
The fan speed cannot be adjusted.	The Jet Mode, or Auto Operation Mode is selected. • In some operation modes, you cannot adjust the fan speed. Select an operation mode in which you can adjust the fan speed.
The temperature cannot be adjusted.	The Fan Mode or Jet Mode is selected. • In some operation modes, you cannot adjust the temperature. Select an operation mode in which you can adjust the temperature.
The air conditioner stops during operation.	The air conditioner is suddenly turned off. • The Timer Function may have timed out, which turns the unit off. Check the timer settings.
	A power failure has occurred during operation. • Wait for the power to come back. If you have the Auto Restart function enabled, your unit will resume its last operation several minutes after power is restored.

Symptoms	Possible Causes & Solution
The indoor unit is still operating even when the unit has been turned off.	The Auto Clean function is being operated. Allow the Auto Clean function to continue since it removes any remaining moisture inside the indoor unit. If you do not want this feature, you can turn the unit off.
The air outlet on the indoor unit is discharging mist.	The cooled air from the air conditioner makes mist. When the room temperature decreases, this phenomenon will disappear.
Water leaks from the outdoor unit.	In the heating operations, condensed water drops from the heat exchanger. This symptom requires installing a drain hose under the base pan. Contact the installer.
There is noise or vibration.	A clicking sound can be heard when the unit starts or stops due to movement of the reversing valve. Creaking sound: The plastic parts of the indoor unit creak when they shrink or expand due to sudden temperature changes. Flowing or Blowing sound: This is the flow of refrigerant through the air conditioner. These are normal symptoms. The noise will stop.
The indoor unit gives off an odor.	Odors (such as cigarette smoke) may be absorbed into the indoor unit and discharged with airflow. If the smell does not disappear, you need to wash the filter. If this does not work, contact the service center to clean your heat exchanger.
The air conditioner does not emit warm air.	When Heating Mode starts, the vane is almost closed, and no air comes out, even though the outdoor unit is operating. This symptom is normal. Please wait until the unit has generated enough warm air to blow through the indoor unit.
	The outdoor unit is in Defrosting Mode. In Heating Mode, ice/frost is built up on the coils when the outside temperature falls. This function removes a layer of frost on the coil, and it should finish in approximately 15 minutes.
	Outside temperature is too low. The heating effect may not be sufficient.

Symptoms	Possible Causes & Solution
Your home appliance and smartphone is not connected to the Wi-Fi network.	The password for the Wi-Fi that you are trying to connect to is incorrect. Find the Wi-Fi network connected to your smartphone and remove it, then register your appliance on LG ThinQ.
	Mobile data for your smartphone is turned on. Turn off the Mobile data of your smartphone and register the appliance using the Wi-Fi network.
	The wireless network name (SSID) is set incorrectly. The wireless network name (SSID) should be a combination of English letters and numbers. (Do not use special characters.)
	The router frequency is not 2.4 GHz. Only a 2.4 GHz router frequency is supported. Set the wireless router to 2.4 GHz and connect the appliance to the wireless router. To check the router frequency, check with your Internet service provider or the router manufacturer.
	The distance between the appliance and the router is too far. If the distance between the appliance and the router is too far, the signal may be weak and the connection may not be configured correctly. Move the location of the router so that it is closer to the appliance.

NOTE

- Some functions may not be supported, depending on the model.



Нұсқаулықты көру үшін QR
кодын сканерлеңіз.



ПАЙДАЛАНУШЫ НҰСҚАУЛЫҒЫ

АУА КОНДИЦИОНЕРІ



Құрылғыны пайдаланбас бұрын пайдаланушы нұсқаулығын мұқият оқып шығыңыз және анықтама үшін оны әрқашан ыңғайлы жерде сақтаңыз.

ТҮРІ: ҚАБЫРҒАҒА ОРНАТЫЛАТЫН

Жабдық Техникалық Ережелер талаптарына сай келеді, электр немесе электронды жабдыққа белгілі бір қауіпті заттардың қолданылуы шектелген.



www.lg.com

Copyright © 2024 LG Electronics. All Rights Reserved

МАЗМҰНЫ

Бұл нұсқаулықта сатып алған үлгіден өзгеше кескіндер немесе мазмұн болуы мүмкін.

Бұл нұсқаулықты өндіруші түзете алады.

ҚАУІПСІЗДІК НҰСҚАУЛАРЫ.....3

Маңызды қауіпсіздік нұсқаулары..... 4

ПАЙДАЛАНУ.....12

Пайдалануға қатысты ескертпелер	12
Бөлшектер мен функциялар	12
Сымсыз қашықтан басқару құралы	13
Ауа кондиционерін автоматты түрде қайта іске қосу	18
Режим функциясын пайдалану	18
«Jet Mode» функциясын пайдалану.....	20
Желдеткіш жылдамдығы функциясын пайдалану	21
Ауа ағынының бағыты функциясын пайдалану	21
Қосу/Өшіру таймерін орнату.....	22
Ұйқы функциясын пайдалану (Қосымша).....	23
Кәдімгі таймер функциясын пайдалану (Қосымша)	23
Қуатты көрсету функциясын пайдалану (Қосымша).....	24
Жарықты өшіру функциясын пайдалану (Қосымша).....	24
Қолайлы ауа функциясын пайдалану (Қосымша).....	24
Қуатты бақылау функциясын пайдалану (Қосымша)	25
UVnano функциясын пайдалану (Қосымша)	25
Арнайы функцияларды пайдалану	26

СМАРТ ФУНКЦИЯЛАРЫ28

LG ThinQ қолданбасы	28
Smart Diagnosis.....	30

ҚЫЗМЕТ КӨРСЕТУ.....31

Ауа сүзгісін тазарту	33
Аллергиялық сүзгіні тазалаңыз (Қосымша).....	34

АҚАУЛАРДЫ ЖОЮ.....35

Қауіпсіздік нұсқаулары өнімге қауіп тудыра отырып, пайдалану және дұрыс пайдаланбау салдарынан болатын қауіптер мен зақымдардың алдын алуға арналған.

Нұсқаулар төменде сипатталғандай «АБАЙЛАҢЫЗ» және «ЕСКЕРТУ» болып бөлінеді.



Бұл таңба қауіп тудыратын жағдайлар мен жұмысты анықтау үшін көрсетіледі. Осындай таңбасы бар бөлімді мұқият оқып шығыңыз және қауіптің алдын алу үшін нұсқауларды орындаңыз.



АБАЙЛАҢЫЗ

Бұл нұсқаулар орындалмаған жағдайда ауыр жарақатқа немесе өлімге әкелуі мүмкін екенін білдіреді.



ЕСКЕРТУ

Бұл нұсқаулар орындалмаған жағдайда өнімнің аз деңгейде зақымдалуы мен бұзылуын білдіреді.

Ішкі және сыртқы құрылғыларда келесі белгілер көрсетіледі.



Бұл белгі жабдықта жанғыш суық агенті пайдаланылатынын білдіреді. Суық агент ағып, оған сырттан ұшқын тиген жағдайда өрт пайда болу қаупі туындайды.



Бұл белгі пайдалану нұсқаулығын мұқият оқып шығу керектігін білдіреді.



Бұл белгі қызмет көрсететін адамдардың осы жабдықты пайдалану нұсқаулығында берілген нұсқауларға сәйкес жөндеуі қажет екенін көрсетеді.



Бұл белгі пайдалану нұсқаулығы немесе орнату нұсқаулығы сияқты ақпараттың бар екенін көрсетеді.

Маңызды қауіпсіздік нұсқаулары

АБАЙЛАҢЫЗ

Құрылғыны пайдаланған кезде жарылу, өрт, өлім, тоқ соғу, зақымдау немесе адамды күйдіру қауіпінің алдын алу үшін мыналарды қоса негізгі қауіпсіздік шараларын қолданыңыз:

Үйдегі балалар

Бұл құрылғы физикалық мүмкіндігі мен ақыл-есі шектеулі немесе құрылғыға қатысты тәжірибесі мен білімі аз адамдарды (балаларды қоса) олардың қауіпсіздігіне жауапты адам қадағаламаған кезде немесе құрылғыны пайдалануға қатысты нұсқаулар берілмеген кезде пайдалануға арналмаған. Балалардың құрылғымен ойнамауы қадағалануы қажет.

Орнату

- Ауа кондиционерін тұрақсыз бетке немесе құлап кету қаупі бар жерге орнатпаңыз.
- Ауа кондиционерін орнатқан немесе орнын ауыстырған кезде өкілетті қызмет көрсету орталығына хабарласыңыз.
- Басқару құралының панелі мен қақпағын қауіпсіз орынға орнатыңыз.
- Ауа кондиционерін тұтанғыш сұйықтар немесе бензин, пропан, бояу еріткіш сияқты заттар сақталған жерге орнатпаңыз.
- Ауа кондиционерін орнату кезінде ішкі және сыртқы құрылғыларды жалғайтын түтік пен қуат кабелінің қатты тартылып қалмауын тексеріңіз.
- Ауа кондиционерінің жұмыс режиміне сәйкес келетін стандартты ажыратқыш пен сақтандырғышты пайдаланыңыз.
- Жүйеге арнайы мұздатқыш агенттен басқа ауа немесе газ жібермеңіз.
- Агенттің ағуын және ауаның шығуын тексеру үшін тұтанбайтын газды (нитроген) пайдаланыңыз; қысылған ауаны пайдалану немесе тұтанғыш газ өрт немесе жарылыс тудыруы мүмкін.

- Ішкі/сыртқы сым қосылымдары қатты қысылуы керек және кабель қосатын терминалдардан тартылып тұрмайтындай етіп жүргізілуі керек. Дұрыс жалғанбау немесе байланыстың жоғалуы қызып кетуге немесе өртке әкелуі мүмкін.
- Ауа кондиционерін пайдаланбас бұрын соған арналған штепселді розетка мен ажыратқышты орнатыңыз.
- Жерге жалғайтын сымды газ құбырына, найзағай тартқышына немесе телефонның жерге жалғанатын сымына жалғамаңыз.
- Ауа айналымына қажетті кез келген саңылаудың бітеліп қалмауын қадағалау керек.
- Сым жалғау ережелеріне сәйкес, бекітілген сымдарға ажырату құралдары кірістірілуі қажет.
- Блокты ықтимал жарылғыш атмосфераларда орнатуға болмайды.

Пайдалану

- Қызмет көрсету бөлшектері тізімінде берілген бөлшектерді ғана пайдаланыңыз. Құрылғыны өзгертуге ешқашан әрекет етпеңіз.
- Балалардың сыртқы құрылғыға шықпауын немесе оны ұрмауын қадағалаңыз.
- Батареяларды өрт болмайтын жерге тастаңыз.
- Ауа кондиционерінің жапсырмасында көрсетілген мұздатқыш агентті ғана пайдаланыңыз.
- Егер ауа кондиционерінен шу, иіс немесе түтін шықса, электр қуатын ажыратыңыз.
- Бензин немесе бояу еріткіш сияқты тұтанғыш заттарды ауа кондиционерінің қасында қалдырмаңыз.
- Ауа кондиционері суға түскен жағдайда өкілетті қызмет көрсету орталығына хабарласыңыз.
- Ауа кондиционерін дұрыс желдетілмейтін жерде ұзақ уақыт пайдаланбаңыз.
- Егер газ жіберілсе (фреон, пропан, сығылған газ, тағы басқа), ауа кондиционерін қайта пайдаланбас бұрын орынды желдетіп алыңыз.

- Ауа кондиционері мен қыздырғыш сияқты қыздыратын құрылғылар бір уақытта пайдаланылған кезде жеткілікті түрде желдетіңіз.
- Ауа ағыны жүретін ішкі не сыртқы саңылауды жаппаңыз.
- Ауа кондиционері жұмыс істеп тұрғанда қолыңызды немесе басқа заттарды ауа жүретін ішкі немесе сыртқы саңылауларға салмаңыз.
- Қуат кабелінің лас және бос еместігін немесе үзілмегенін тексеріңіз.
- Ауа кондиционерін ешқашан ылғал қолыңызбен ұстамаңыз, іске қоспаңыз немесе жөндемеңіз.
- Қуат кабелінің үстіне ешнәрсе қоймаңыз.
- Қыздырғыш немесе басқа қыздыратын құрылғыларды қуат кабелінің қасына қоймаңыз.
- Қуат кабелін өзгертпеңіз немесе ұзартпаңыз. Қуат кабеліндегі сызаттар мен изоляциясының түсуі өрт немесе ток соғу қаупін тудыруы мүмкін және ол ауыстырылуы керек.
- Электр қуаты өшірілген немесе найзағай болған кезде электр қуатын бірден өшіріңіз.
- Қуат кабелінің жұмыс барысында ажыратылмайтындығына немесе зақымдалмайтындығына көз жеткізіңіз.
- Жабдық жұмыс істеп тұрған кезде немесе жұмысынан кейін дереу суық агент құбырына, су құбырына немесе басқа да ішкі бөліктеріне тимеңіз.

Қызмет көрсету

- Өнімге тікелей су шашып құрылғыны тазаламаңыз.
- Құрылғыны тазаламас немесе қызмет көрсетпес бұрын қуат көзін ажыратып, желдеткіш тоқтағанша күтіңіз.

Техникалық қауіпсіздік

- Рұқсаты жоқ адамдардың орнатуы мен жөндеу жұмыстары сізге немесе басқаларға зақым келтіруі мүмкін.

- Хладагент тізбегімен жұмыс істейтін немесе оны ашу жұмысына қатысатын кез келген адамның өндірістік салада жұмыс істеуге рұқсаты бар орган тарапынан берілген жарамды сертификаты болуы керек, ол сертификат адамның өнеркәсіп сипаттамаларына сәйкес келетін хладагенттермен қауіпсіз түрде жұмыс істей алатындығын растайды.
- Қызмет көрсету жұмыстары міндетті түрде жабдықты өндірген мекеме тарапынан ұсынылған талаптарға сай орындалуы керек. Басқа тәжірибелі қызметкерлердің көмегін талап ететін техникалық қызмет көрсету мен жөндеу жұмыстары тез тұтанғыш хладагенттерді қолдануға құзыреті бар адамның бақылауында орындалуы керек.
- Нұсқаулықтағы ақпарат қауіпсіздік процедураларымен таныс және дұрыс тексеру құралдарымен жабдықталған техникалық қызмет көрсету маманы пайдалануға арналған.
- Нұсқаулықтағы барлық нұсқауларды оқымау немесе орындамау құрылғының дұрыс жұмыс істемеуіне, зақымдауға және/немесе өлімге әкелуі мүмкін.
- Құрылғы жергілікті жалғау ережелеріне сәйкес орнатылуы керек.
- Қуат сымы ауыстырылатын кезде ол жұмысты тек рұқсаты бар маман істеуі керек және түпнұсқа бөлшектермен ауыстырылуы керек.
- Құрылғы электр тогының соғу қаупін азайту үшін жерге дұрыс жалғануы керек.
- Ашадағы жерге жалғанатын істікті кесіп алып тастамаңыз.
- Адаптерді қабырғалық розетка қақпағының бұрандасына жалғау құрылғыны қақпақтың бұрандасы темір болмай, оқшауланбаған және қабырғалық розетка іштегі сым арқылы жалғанған жағдайда жерге жалғанбайды.
- Егер ауа кондиционерінің жерге дұрыс жалғануына күмәндансаңыз, қабырғалық розетка мен ажыратқышты электр маманына тексертіңіз.

- Құрылғыда пайдаланылатын мұздатқыш агент пен оқшаулағыш газ арнайы тастау процедураларын қажет етеді. Оларды тастамас бұрын қызмет көрсету агентіне немесе ұқсас маманға хабарласыңыз.
- Егер қуат сымы зақымдалса, қауіптің алдын алу үшін оны өндіруші немесе оның қызмет көрсету агенттері немесе ұқсас мамандар ауыстыруы керек.
- Құрылғы ауа айналымы жақсы аймақта сақталуы керек, ондағы бөлменің өлшемі жұмыс істеуге қажетті бөлме өлшеміне сәйкес келуі керек.
- Құрылғы үздіксіз жанып тұратын от (мысалы, жұмыс істейтін газ құрылғысы) және тұтану көздері (мысалы, жұмыс істейтін электрлік жылытқыш) бар бөлмеде сақталмауы керек.
- Құрылғы механикалық зақымға ұшырамайтын жерде сақталуы керек.
- Құрылғыны мақсатсыз пайдалану немесе корпусының бұзылуы қауіпті UV-C сәулесінің шығуына әкелуі мүмкін. UV-C сәулеленуі, тіпті аз мөлшерде болса да, көзге және теріге зиян тигізуі мүмкін.
- Бұл құрылғының құрамында UV-C шамы бар.
- Құрылғылар зақымданған немесе оларды ауыстыру қажет болған кезде, қуат көзін ажыратып, қызмет көрсету орталығына хабарласыңыз.
- UV-C шамын құрылғыдан тыс жерде қолданбаңыз.
- Жұмыс барысында ауа дефлекторын тазаламаңыз және оған тимеңіз.
- Пайдаланушы техникалық қызмет көрсету процесін жүргізу үшін ультракүлгін сәулелену қаупін білдіретін белгісі бар есіктер мен алынбалы тақталарды ашудан бұрын, қуат көзінен ажырату ұсынылған.
- Аспапты ашудан бұрын, техникалық қызмет көрсету нұсқауларын оқып шығыңыз.
- Зақымдалған аспаптарды пайдалануға болмайды.
- UV-C шамын ауыстырудан бұрын, аспапты қуат көзінен ажырату керек.

ЕСКЕРТУ

Өнімді пайдаланған кезде адамдарға келетін қауіпті азайту, өнімнің дұрыс жұмыс істемеуін болдырмау үшін келесі нұсқаулармен бірге негізгі нұсқауларды орындаңыз:

Орнату

- Ауа кондиционерін тікелей теңіз желі (тұзды бүркінді) болатын жерге орнатпаңыз.
- Су конденсациясы тегіс кебу үшін саңылауды дұрыс жасаңыз.
- Ауа кондиционерін орамнан шығарған және орнатқан кезде абайлаңыз.
- Орнату немесе жөндеу кезінде аққан мұздатқыш агентті ұстамаңыз.
- Ауа кондиционерін екі немесе одан көп адаммен тасымалдаңыз.
- Сыртқы құрылғыны тікелей күн сәулесінен қорғалатындай етіп орнатыңыз. Ішкі құрылғыны күн сәулесі тікелей терезе арқылы түсетін жерге қоймаңыз.
- Орнатудан немесе жөндеуден кейін дұрыс орамды пайдаланып бұрандалар, пластик пакет немесе батареялар сияқты нәрселерді қауіпсіз түрде тастаңыз.
- Ауа кондиционерін сыртқы құрылғыдан шығатын шу немесе пайдаланылған газ көршілерге қолайсыздық тудырмайтын жерге орнатыңыз. Егер олай істемесеңіз, көршілермен келіспеушілік болуы мүмкін.

Пайдалану

- Басқару құралы ұзақ уақыт бойы пайдаланылмаса, оның батареяларын алып тастаңыз.

- Ауа кондиционерін іске қоспастан бұрын сүзгінің орнатылғанын тексеріңіз.
- Ауа кондиционерін орнатқаннан немесе жөндегеннен кейін мұздатқыш агенттің ақпауын тексеріңіз.
- Ауа кондиционеріне ешнәрсе қоймаңыз.
- Қашықтан басқару құралында әр түрлі батареяларды немесе жаңа не ескі батареяларды араластырмаңыз.
- Ылғалдық деңгейі жоғары болған кезде, есік немесе терезе ашық қалған кезде ауа кондиционерін ұзақ уақыт қоспаңыз.
- Батареядан сұйықтық ақса, қашықтан басқару құралын пайдалануды тоқтатыңыз. Киіміңізге немесе терісіңізге батареядан аққан сұйықтық тисе, оларды таза сумен жуыңыз.
- Адамдарды, жануарларды немесе өсімдіктерді ұзақ уақыт бойы суық немесе ыстық лепте ұстамаңыз.
- Егер батареядан аққан сұйықтықты жұтып қойсаңыз, аузыңызды мұқият шайып дәрігерге қаралыңыз.
- Ауа кондиционерінен аққан суды ішпеңіз.
- Өнімді тағам сақтау, өнер туындылары сияқты жеке мақсаттарға пайдаланбаңыз. Бұл нақты мұздату жүйесі емес тұтыну мақсаттарына арналған ауа кондиционері. Өнімнің зақымдалу немесе жойылу қаупі бар.
- Батареяларды қайта зарядтамаңыз немесе бөлшектемеңіз.

Қызмет көрсету

- Ауа сүзгісін алған кезде ауа кондиционерінің темір бөлшектерін ешқашан ұстамаңыз.
- Биіктегі ауа кондиционерін тазалаған, қызмет көрсеткен немесе жөндеген кезде қозғалмайтын орындықты немесе сатыны пайдаланыңыз.
- Ауа кондиционерін тазалаған кезде күшті тазалау құралдары мен ерітінділерін пайдаланбаңыз және су шашпаңыз. Жұмсақ мата пайдаланыңыз.
- Ішін тазалау үшін өкілетті қызмет көрсету орталығына немесе дилерге хабарласыңыз. Күшті тазарту құралдарын пайдалану тот басуға немесе құрылғыны зақымдауы мүмкін.

Қалдық батареяларды/аккумуляторларды қоқысқа тастау



- Батареяның құрамында кем дегенде 0,0005 % сынап, 0,002 % кадмий немесе 0,004 % қорғасын болса, бұл таңба сынап (Hg), кадмий (Cd) немесе қорғасынның (Pb) химиялық таңбасымен бірге көрсетілуі мүмкін.
- Батареялардың/аккумуляторлардың барлығы қалалық қоқыстардан бөлек, мемлекет немесе жергілікті билік органдары тарапынан белгіленген арнайы жинау пункттерінде тасталуы тиіс.
- Ескі батареяларды/аккумуляторларды дұрыс жерге тастау қоршаған ортаға, жануарларға және адамдарға тиетін ықтимал зияннан қорғайды.
- Ескі батареяларды/аккумуляторларды қоқысқа тастау туралы қосымша ақпарат алу үшін қаладағы кеңсеге, қалдықты көдеге жарату қызметіне немесе өнімді сатып алған дүкенге хабарласыңыз.


Пайдалануға қатысты ескертпелер

Қуат үнемдеуге қатысты ұсыныс

- Бөлмені өте қатты салқындатпаңыз. Бұл денсаулығыңызға зиян болуы және электр қуатын көп тұтынуы мүмкін.
- Ауа кондиционерін пайдаланған кезде күн сәулесін пердемен жауып қойыңыз.
- Есіктер мен терезелерді жабулы күйде ұстаңыз.
- Іштегі ауа айналу үшін ауа ағынын көлденеңінен немесе тігінен реттеңіз.
- Іштегі ауаны аз уақыт ішінде жылдам салқындату немесе жылыту үшін желдеткішті жылдамдатыңыз.
- Ауа кондиционері ұзақ пайдаланылса, бөлмедегі ауа нашарлауы мүмкін, сондықтан терезелерді ашып бөлмені желдетіп тұрыңыз.
- Ауа сүзгісін 2 аптада бір рет тазалаңыз. Ауа сүзгісіне жиналған шаң мен қоқыстар ауа өтетін саңылауды бітеуі немесе құрылғының өнімділігін төмендетуі мүмкін.


Бөлшектер мен функциялар

Ішкі құрылғы



- 1** Ауа сүзгісі
- 2** Ауа кіретін саңылау
- 3** Алдыңғы қақпақ
- 4** Ауа шығатын саңылау
- 5** Ауа дефлекторы (Көлденең қалқанша)
- 6** Ауа дефлекторы (Тік қалқанша)
- 7** Қосу/Өшіру түймесі

Сыртқы құрылғы



- 1** Ауа кіретін желдеткіш
- 2** Ауа шығатын желдеткіш

ЕСКЕРТПЕ


- Жұмыс істеудің индикатор шамдарының саны мен орналасуы ауа кондиционерінің моделіне байланысты әр түрлі болуы мүмкін.
- Мүмкіндік модельдің түріне байланысты әр түрлі болуы мүмкін.

Сымсыз қашықтан басқару құралы


Батареялар салу

Егер басқару құралының дисплейі өше бастаса, батареяларды ауыстырыңыз. Басқару құралын пайдаланбас бұрын AAA (1,5 В) батареяларын салыңыз.

- 1 Батарея қақпағын алыңыз.




- 2 Жаңа батареялар салып, олардың + және - клеммаларының дұрыс салынғанын тексеріңіз.



Қашықтан басқару құралын ұстағышын орнату (Қосымша)


Қашықтан басқару құралын қорғау үшін ұстағышты күн сәулесі тікелей түспейтін жерге орнатыңыз.

- 1 Қауіпсіз және ыңғайлы орынды таңдаңыз.
- 2 Ұстағышты 2 бұранда арқылы бұрағышпен бекітіңіз.



Жұмыс істеу әдісі

Ауа кондиционерін іске қосу үшін оның оң жағындағы сигнал қабылдағышына қашықтан басқару құралын бағыттаңыз.



ЕСКЕРТПЕ

- Қашықтан басқару құралы басқа электрондық құрылғыларға бағытталса да оларды басқаруы мүмкін. Қашықтан басқару құралын ауа кондиционерінің сигнал қабылдағышына бағыттағаныңызды тексеріңіз.
- Дұрыс жұмыс істеуі және сигнал таратқышы мен қабылдағышын тазарту үшін жұмсақ мата пайдаланыңыз.
- Егер өнімде ондай функция берілмесе, қашықтан басқару құралында Ауа ағынының бағыты (Swing), Қуат дисплейі (kW(3s)), Ауа тазалау функциясынан (4) басқа осындай функцияға арналған түймені басқанда өнімнен зуммер дыбысы шықпайды.

Ағымдағы уақытты орнату

- 1 Батареялар салу.
 - Төмендегі белгішелер дисплейдің төменгі жағында жыпылықтайды.



- 2 Минутты таңдау үшін ☐ немесе ☐ түймесін басыңыз.

- 3 Аяқтау үшін **Set/Cancel** түймесін басыңыз.

ЕСКЕРТПЕ

- Қосу/Өшіру таймері ағымдағы уақытты орнатқаннан кейін қолжетімді болады.

°C/°F түрлендіру функциясы (Қосымша)

Бұл функция °C және °F мәндерін ауыстырады.

-  түймесін шамамен 5 секунд ұстап тұрыңыз.


Ауа кондиционерін қашықтан басқару құралынсыз іске қосу

Қашықтан басқару құралы жоқ болған кезде ауа кондиционерін қосу үшін іштегі құрылғыдағы **ON/OFF** түймесін пайдалануыңызға болады.


- 1 Алдыңғы қақпақты (2-түрі) немесе көлденең қалақты (1-түрі) ашыңыз.

- 2 **ON/OFF** түймесін басыңыз.

1-түрі



2-түрі




ЕСКЕРТПЕ

- Егер көлденең дефлектор жылдам ашылса, қадамдық мотор бұзылуы мүмкін.
- Желдеткіштің жылдамдығы жоғары.
- Мүмкіндік модельдің түріне байланысты әр түрлі болуы мүмкін.
- Осы төтенше жағдай **ON/OFF** түймесін пайдаланған кезде температура өзгертілмейді.
- Салқындатқыш және жылытқыш модельдері үшін температура 22 °C - 24 °C мәніне дейін қойылады.


Сымсыз қашықтан басқару құралын пайдалану

Ауа кондиционерін қашықтан басқару құралымен оңай басқарасыз.


	1 Түйме	2 Дисплей	Сипаттама	Қолжетімді функция	
				Бір тармақты	Көп тармақты
1		-	Ауа кондиционерін өшіру/қосу.	☐	☐
	 Temp. 	88 °C	Салқындату, жылыту кезінде бөлменің қалаған температурасын реттеу немесе режимді автоматты түрде ауыстыру.	☐	☐
	Mode		Салқындату режимін таңдау.	☐	☐
			Жылыту режимін таңдау.	☐	☐
			Ылғалсыздандыру режимін таңдау.	☐	☐
			Желдеткіш режимін таңдау.	☐	☐
			«Авто ауыстыру»/«Автоматты түрде жұмыс істеу» режимін таңдау.	☐	☐
	Jet Mode		Бөлменің температурасын жылдам өзгерту.	☐	☐
	Fan Speed		Желдеткіш жылдамдығын реттеу.	☐	☐
	 Swing  Swing		Ауа бағытын тігінен немесе көлденеңінен реттеу.	☐	☐

ЕСКЕРТПЕ

- * түймелер модельдің түріне қарай өзгертілуі мүмкін.
- Көп тармақты сыртқы блокқа қосылған кезде, Қуатты көрсету, Қуатты басқару, Дыбыссыз және Смарт диагностика функцияларына қолдау көрсетілмеуі мүмкін.



1 Түйме	2 Дисплей	Сипаттама	Қолжетімді функция	
			Бір тармақты	Көп тармақты
	S ON OFF	Ауа кондиционерінің қалаған уақытта өшірілуі/қосылуы.	○	○
Set/Cancel	-	Арнайы функция мен таймерді орнату/бас тарту.	○	○
	-	Таймер параметрлерін орнату.	○	○
	-	Уақытты реттеу.	○	○
*Light Off	-	Ішкі құрылғыдағы дисплейдің ашықтығын орнату.	○	○
Room Temp.		Бөлменің температурасын көрсету.	○	○
°C↔°F (5 s)	°C °F	°C және °F мәндерін ауыстыру.	○	○
*Comfort Air		Желдің бағытын өзгерту үшін ауа ағынын реттеу.	○	○
kW(3 s)	-	Электр қуатына қатысты ақпараттың көрсетілуін не көрсетілмеуін орнату.	○	×
*Energy Ctrl.	88 %	Электр қуатын үнемдеудің әсерін қосу.	○	×
Diagnosis (5 s)	-	Өнімге техникалық қызмет көрсету туралы ақпаратты тексеру.	○	×
UVnano (3 s)	-	Желдеткішті таза сақтау үшін.	○ (Қосымша)	○ (Қосымша)



1 Түйме	2 Дисплей	Сипаттама	Қолжетімді функция	
			Бір тармақты	Көп тармақты
Func.		Ион генераторы іштегі ауа сапасын жақсарту үшін миллиондаған иондарды пайдаланады.	○ (Қосымша)	○ (Қосымша)
		Сыртқы құрылғыдан шығатын шуды азайту.	○	Х
		Ішкі құрылғының ішінде пайда болған ылғалды жою.	○	○
Reset	-	Қашықтан басқару параметрлерін бастапқы қалпына келтіру.	○	○

ЕСКЕРТПЕ

- Кейбір функцияларға модельге байланысты қолдау жоқ болуы мүмкін.
- * түймелер модельдің түріне қарай өзгертілуі мүмкін.
- Таңдалған **Func.** басқару үшін **Set/Cancel** түймесін басыңыз.


Ауа кондиционерін автоматты түрде қайта іске қосу

Электр қуаты өшірілгеннен кейін ауа кондиционері қосылған кезде бұл функция алдыңғы параметрлерді қайта қалпына келтіреді.


Автоматты түрде қайта іске қосуды ажырату

- 1 Алдыңғы қапқақты (2-түрі) немесе көлденең қалақты (1-түрі) ашыңыз.
- 2 **ON/OFF** түймесін 6 секунд басып тұрыңыз, содан кейін құрылғы екі рет дыбыс шығарады және шам қатарынан 4 рет жыпылықтайды.
 - Функцияны қайта қосу үшін **ON/OFF** түймесін 6 секундтай басып тұрыңыз. Құрылғы екі рет дыбыс шығарады және шам 4 жыпылықтайды.

1-түрі



2-түрі




ЕСКЕРТПЕ

- Мүмкіндік модельдің түріне байланысты әр түрлі болуы мүмкін.
- Егер **ON/OFF** түймесін 6 секунд басудың орнына 3 – 5 секундтай басып тұрсаңыз, құрылғы жұмыс істеуді тексеруге ауысады. Жұмыс істеуді тексеру кезінде құрылғы 18 минуттай өте салқын ауа шығарып кейін әдепкі зауыттық параметрге оралады.

Режим функциясын пайдалану

Бұл функция қалаған функцияны таңдауға мүмкіндік береді.



«Салқындату» режимі

- 1 Құрылғыны қосыңыз.
- 2 «Салқындату» режимін таңдау үшін **Mode** түймесін қайталап басыңыз.
 - Дисплейде белгішесі көрсетіледі.
- 3 Қалаған температураны орнату үшін немесе түймесін басыңыз.

Автоматты түрде жұмыс істеу (Жасанды интеллект)

Көп тармақты үлгі

Осы жұмыс режимінде жүйе электрондық басқару элементтерімен автоматты түрде басқарылады.

- 1 Құрылғыны қосыңыз.
- 2 «Автоматты түрде жұмыс істеу» режимін таңдау үшін **Mode** түймесін қайталап басыңыз.
 - Дисплейде  белгішесі көрсетіледі.
- 3 Қалаған температураны орнату үшін  немесе  түймесін басыңыз.
- 4 Желдеткіштің жылдамдығын реттеу үшін **Fan Speed** түймесін басыңыз.

«Авто ауыстыру» режимі

Бір тармақты үлгі

Бұл автоматты түрде ± 2 °C мәніне қойылған температураны сақтау үшін режимді ауыстырады.

- 1 Құрылғыны қосыңыз.
- 2 «Авто ауыстыру» режимін таңдау үшін **Mode** түймесін қайталап басыңыз.
 - Дисплейде  белгішесі көрсетіледі.
- 3 Қалаған температураны орнату үшін  немесе  түймесін басыңыз.
- 4 Желдеткіштің жылдамдығын реттеу үшін **Fan Speed** түймесін басыңыз.

«Ылғалсыздандыру» режимі

Бұл режим шірудің алдын алу үшін ылғалдығы жоғары деңгейдегі ортадан немесе жаңбырлы күні артық ылғалды шығарады. Режим ылғалдың тиімді деңгейін сақтау үшін бөлменің температурасын және желдеткіштің жылдамдығын реттейді.

- 1 Құрылғыны қосыңыз.
- 2 «Ылғалсыздандыру» режимін таңдау үшін **Mode** түймесін қайталап басыңыз.
 - Дисплейде  белгішесі көрсетіледі.

ЕСКЕРТПЕ

- Бұл режимде бөлменің температурасын реттей алмайсыз, ол автоматты түрде реттеледі.
- Бөлменің температурасы дисплейде көрсетілмейді.
- Құрғату режимінде бөлме температурасы 24 ° градустан төмен болған кезде компрессор мен жабық желдеткіш жұмыс істемеуі мүмкін.

«Жылыту» режимі

- 1 Құрылғыны қосыңыз.
- 2 «Жылыту» режимін таңдау үшін **Mode** түймесін қайталап басыңыз.
 - Дисплейде  белгішесі көрсетіледі.
- 3 Қалаған температураны орнату үшін  немесе  түймесін басыңыз.

ЕСКЕРТПЕ

- Еріту функциясы жұмыс істеген кезде іштегі құрылғыда  көрсетіледі.
- Сонымен қатар, бұл көрсеткіш іштегі құрылғыда көрсетіледі:
 - Алдын ала қыздыру жұмыс істеген кезде.
 - Бөлме температурасы орнатылған температураға жеткен кезде.

«Желдеткіш» режимі

Бұл режим бөлменің температурасын өзгертпестен ішкі ауаны айналдырады.

- 1 Құрылғыны қосыңыз.
- 2 «Желдеткіш» режимін таңдау үшін **Mode** түймесін қайталап басыңыз.
 - Дисплейде  белгішесі көрсетіледі.
- 3 Желдеткіштің жылдамдығын реттеу үшін **Fan Speed** түймесін басыңыз.

ЕСКЕРТПЕ

- Желдеткіш режимі жұмыс істеп тұрғанда, ішкі блокта  немесе  көрсетіледі.

«Jet Mode» функциясын пайдалану

Бөлменің температурасын жылдам өзгерту

Бұл функция бөлменің ішін жазда жылдам салқындатуға немесе қыста жылдам жылытуға мүмкіндік береді.

- «Jet Mode» функциясын салқындату, жылыту және ылғалсыздандыру режимдерімен бірге қолдануға болады.

- 1 Құрылғыны қосыңыз.
- 2 Қалаған режимді таңдау үшін **Mode** түймесін қайталап басыңыз.
- 3 **Jet Mode** түймесін басыңыз.
 - Дисплейде  белгішесі көрсетіледі.

ЕСКЕРТПЕ

- «Жылдам жылыту» режимі кейбір модельдерде жоқ.
- «Jet Cooling» күшті ауа 30 минут бойы үреді.
- 30 минуттан кейін белдесу температурасы 18 °C шамасында болады.
Егер температураны өзгерткіңіз келсе, қажетті температураны орнату үшін  немесе  түймесін басыңыз.
- «Jet Heating» күшті ауа 30 минут бойы үреді.
- 30 минуттан кейін белдесу температурасы 30 °C шамасында болады.
Егер температураны өзгерткіңіз келсе, қажетті температураны орнату үшін  немесе  түймесін басыңыз.
- Бұл функция қашықтан басқару дисплейінен басқаша жұмыс істейді.

Желдеткіш жылдамдығы функциясын пайдалану

Желдеткіш жылдамдығын реттеу

- Желдеткіш жылдамдығын реттеу үшін **Fan Speed** түймесін қайталап басыңыз.

Дисплей	Жылдамдығын
	Жоғары
	Орташа – Жоғары
	Орташа
	Орташа – Төмен
	Төмен
-	Табиғи жел

ЕСКЕРТПЕ

- Вентилятордың табиғи жел жылдамдығы автоматты түрде реттеледі.



- Желдеткіш жылдамдығы белгішелері кейбір ішкі құрылғыларда көрсетіледі.

F1 → F2 → F3 → F4 → F5

- Ішкі құрылғының дисплейі тек 5 секунд көрсетіліп, кейбір модельдерде температура орнатуға қайта оралады.

Ауа ағынының бағыты функциясын пайдалану

Бұл функция ауа ағынының бағытын тігінен (көлденеңінен) реттейді.

- түймесін қайталап басып қалаған бағытты таңдаңыз.

– Ауа ағынын автоматты түрде реттеу үшін түймесін таңдаңыз.

ЕСКЕРТПЕ

- Модельге байланысты ауа ағынының бағытын көлденеңге өзгертуге қолдау жоқ.
- Ауа дефлекторын өз бетінше реттеу өнімнің істен шығуына әкелуі мүмкін.
- Ауа кондиционерін өшіріп қайта қоссаңыз, ол алдында орнатылған ауа үрлеу бағытымен жұмыс істейді, сондықтан ауа дефлекторы қашықтан басқару құралында көрсетілген белгішемен сәйкес келмеуі мүмкін. Олай болған жағдайда ауа ағынының бағытын қайта реттеу үшін немесе түймесін басыңыз.
- Бұл функция қашықтан басқару дисплейінен басқаша жұмыс істейді.

Қосу/Өшіру таймерін орнату

Бұл функция ауа кондиционерін автоматты түрде қалаған уақытта қосылуға/өшіруге қояды. Қосу/өшіру таймерін бірге орнатуға болады.

Қосу таймерін реттеу

- 1  түймесін қайталап басыңыз.
 - Төмендегі белгішелер дисплейдің төменгі жағында жыпылықтайды.



- 2 Минутты таңдау үшін  немесе  түймесін басыңыз.

- 3 Аяқтау үшін **Set/Cancel** түймесін басыңыз.
 - Таймерді орнатқаннан кейін ағымдағы уақыт пен **ON** белгішесі қалаған уақыттың орнатылғанын шығара отырып дисплейден көрсетіледі.

Қосу таймерінен бас тарту

- 1  түймесін қайталап басыңыз.
 - Төмендегі белгішелер дисплейдің төменгі жағында жыпылықтайды.



- 2 Орнатудан бас тарту үшін **Set/Cancel** түймесін басыңыз.

Өшіру таймерін орнату

- 1  түймесін қайталап басыңыз.
 - Төмендегі белгішелер дисплейдің төменгі жағында жыпылықтайды.



- 2 Минутты таңдау үшін  немесе  түймесін басыңыз.

- 3 Аяқтау үшін **Set/Cancel** түймесін басыңыз.
 - Таймерді орнатқаннан кейін ағымдағы уақыт пен **OFF** белгішесі қалаған уақыттың орнатылғанын шығара отырып дисплейден көрсетіледі.

ЕСКЕРТПЕ

- Бұл функция Кәдімгі таймерді орнатқан кезде ажыратылады.

Өшіру таймерінен бас тарту

- 1  түймесін қайталап басыңыз.
 - Төмендегі белгішелер дисплейдің төменгі жағында жыпылықтайды.



- 2 Орнатудан бас тарту үшін **Set/Cancel** түймесін басыңыз.

Таймер параметрінен бас тарту

- Барлық таймер параметрінен бас тарту үшін  түймесін басыңыз.

Ұйқы функциясын пайдалану (Қосымша)

Бұл функция ауа кондиционерін сіз ұйқыға кеткен кезде автоматты түрде өшіреді.

1 Құрылғыны қосыңыз.

2  түймесін қайталап басыңыз.

- Төмендегі белгішелер дисплейдің төменгі жағында жыпылықтайды.



3 Сағатты (7 сағатқа дейін) таңдау үшін  немесе  түймесін басыңыз.

4 Аяқтау үшін **Set/Cancel** түймесін басыңыз.

- Дисплейде  белгішесі көрсетіледі.

ЕСКЕРТПЕ

- Кейбір ішкі құрылғыларда  белгішесі көрсетіледі.
- Ішкі құрылғының дисплейі 1С-7С аралығында және тек 5 секунд көрсетіледі де температура орнатуға қайта оралады.
- Салқындату және ылғалдандыру режимінде температура 30 минуттан кейін 1 °C болып артады және жайлы ұйқы үшін кейінірек тағы 30 минуттан кейін 1 °C болып артады.
- Температура орнатылған температурадан 2 °C артады.
- Дисплейдегі желдеткіш жылдамдығының белгісі өзгертілуі мүмкін болса да желдеткіш жылдамдығы автоматты түрде реттеледі.

Кәдімгі таймер функциясын пайдалану (Қосымша)

Бұл функция ауа кондиционерін сіз ұйқыға кеткен кезде автоматты түрде өшіреді.

1 Құрылғыны қосыңыз.

2  түймесін қайталап басыңыз.

- Төмендегі белгішелер дисплейдің төменгі жағында жыпылықтайды.



3 Сағатты (7 сағатқа дейін) таңдау үшін  немесе  түймесін басыңыз.

4 Аяқтау үшін **Set/Cancel** түймесін басыңыз.

- Дисплейде  белгішесі көрсетіледі.

ЕСКЕРТПЕ

- Бұл функция Өшіру таймерін орнатқан кезде ажыратылады.

Қуатты көрсету функциясын пайдалану (Қосымша)

Бұл функция өнімнің жұмысына сәйкес ішкі құрылғының дисплейінде шығатын электр қуатының өлшемін көрсетеді.

Ағымдағы электр қуатын пайдалануды көрсету

1 Құрылғыны қосыңыз.

2  түймесін 3 секундтай басып тұрыңыз.

- Ағымдағы қуат тұтыну  кейбір ішкі құрылғыларда кішкене уақыт көрсетіледі.

ЕСКЕРТПЕ

- Көрсетілген мәннің бірлігі - кВт.
- Бұл сымсыз қашықтан басқару құралында көрсетілмейді.
- Егер ол 99 кВт болатын ауқымнан артық болса, оны 99 кВт көрсеткішінде ұстаңыз.
- 10 кВт-тан төмен ватты 0,1 кВт бірлікпен, ал 10 кВт-тан артық болса 1 кВт бірлігімен көрсету.
- Нақты қуат көрсетілген қуаттан басқа болуы мүмкін.
- Көп тармақты сыртқы блокқа қосылған кезде, функцияға қолдау көрсетілмеуі мүмкін.

Жарықты өшіру функциясын пайдалану (Қосымша)

Экранның ашықтығы

Ішкі құрылғы дисплейінің ашықтығын орнатуыңызға болады.

- **Light Off** түймесін басыңыз.

ЕСКЕРТПЕ

- Дисплей экранын қосыңыз/өшіріңіз.
- Ішкі блок дисплейінің жарықтығы **ӨШІРУЛІ** күйіне орнатылған болса, қашықтан басқару пультіндегі түймені басу дисплейді біраз уақытқа автоматты түрде қосады.
- Бұл функция үлгісіне байланысты басқаша жұмыс істеуі мүмкін.

Қолайлы ауа функциясын пайдалану (Қосымша)

Қолайлы дефлектордың жұмысы

Бұл функция бөлмедегі адамдарға желдің тікелей соғу бағытын өзгерту үшін дефлекторды алдын ала белгіленген күйге орнатады.

1 Құрылғыны қосыңыз.

2 **Comfort Air** түймесін қайталап басыңыз және қалаған бағытты таңдаңыз.

- Дисплейде  немесе  белгішесі көрсетіледі.

ЕСКЕРТПЕ

- Кейбір ішкі құрылғыларда  немесе  белгішесі көрсетіледі.
- Бұл функция **Mode** немесе **Jet Mode** түймесін басқан кезде ажыратылады.
- Функция ажыратылады және  түймесін басқан кезде тік бағытта автоматты түрде жылжу орнатылады.
- Бұл функция өшірілген кезде, көлденең дефлектор орнатылған режимге байланысты автоматты түрде жұмыс істейді.

Қуатты бақылау функциясын пайдалану (Қосымша)

- 1 Құрылғыны қосыңыз.
- 2 **Energy Ctrl.** түймесін басыңыз.
 - Әр қадамды таңдау үшін **Energy Ctrl.** түймесін басыңыз.

ЕСКЕРТПЕ

- 1-қадам: Қуат кірісі номиналды қуат кірісімен салыстырғанда 20 %-ға азаяды.
– Дисплейде  20 % белгішесі көрсетіледі.
- 2-қадам: Қуат кірісі номиналды қуат кірісімен салыстырғанда 40 %-ға азаяды.
– Дисплейде  40 % белгішесі көрсетіледі.
- 3-қадам (Қосымша): Қуат кірісі номиналды қуат кірісімен салыстырғанда 60 %-ға азаяды.
– Дисплейде  60 % белгішесі көрсетіледі.
- Кейбір ішкі құрылғыларда  (1-қадам),  (2-қадам) белгішесі көрсетіледі.
- Бұл функцияны «Салқындату» режимімен қолдануға болады.
- «Қуатты басқару» режимі таңдалған кезде сыйымдылық кішіреуі мүмкін.
- Егер **Fan Speed**,  немесе  түймесін бассаңыз, қалаған температура шамамен 5 секундтай көрсетіледі.
- **Room Temp.** түймесін бассаңыз, бөлменің температурасы шамамен 5 секундтай көрсетіледі.
- Көп тармақты сыртқы блокқа қосылған кезде, функцияға қолдау көрсетілмеуі мүмкін.

UVnano функциясын пайдалану (Қосымша)

UVnano — UV (ультрафиолет сәулелері) және нанометр (ұзындықты өлшеу бірлігі) сөздерінің тіркесімі.

Бұл функция ауа кондиционерінің ішіндегі түрлі бактериялардың санын азайтады.

Үлгі нөмірі: LTPL-G35UV275GS-JA

LTPL-G35U275GS-TWA

CUD7GF1A


Jet Mode түймесін 3 секундтай басып тұрыңыз.

ЕСКЕРТПЕ

- Үлгіге байланысты **UV** сөзі кейбір ішкі құрылғыларды көрсетіледі.
- Желдеткішті таза сақтау үшін, УК жарық диод шамы қалыпты уақыт аралықтарында жұмыс істейді.
- UVnano функциясы кондиционер өшірілген кезде тоқтайды.
- Автоматты тазалау функциясы іске қосылғанда, UVnano функциясы желдеткішті таза сақтау үшін бірге жұмыс істейді.
- Бұл функцияны «Жылыту» режимі арқылы өшіруге болады.

Арнайы функцияларды пайдалану

- 1 Құрылғыны қосыңыз.
- 2 Қалаған функцияны таңдау үшін **Func.** түймесін қайталап басыңыз.
- 3 Аяқтау үшін **Set/Cancel** түймесін басыңыз.



Дисплей	Сипаттама
	Ион генераторы іштегі ауа сапасын жақсарту үшін миллиондаған иондарды пайдаланады.
	Сыртқы құрылғыдан шығатын шуды азайту.
	Ішкі құрылғының ішінде пайда болған ылғалды жою.

ЕСКЕРТПЕ

- Кейбір функцияларға модельге байланысты қолдау жоқ болуы мүмкін.
- Кейбір функциялар қашықтан басқару дисплейінен басқаша жұмыс істейді.

Арнайы функциялардан бас тарту

- 1 Қалаған функцияны таңдау үшін **Func.** түймесін қайталап басыңыз.
- 2 Функциядан бас тарту үшін **Set/Cancel** түймесін басыңыз.

Ауаны тазарту функциясын пайдалану

Бұл функциялар таза, ион бөлшектері бар ауа береді және оны сүзеді.

Функция	Дисплей	Сипаттама
Ионизатор		Ионизатордан шығатын ион бөлшектері беттегі бактерияны және басқа да зиянды заттарды азайтады.
Плазма		Ол таза ауа беру үшін микроспиялық ластағыш бөлшектерді толықтай жояды.

ЕСКЕРТПЕ

- Бұл функцияны ауа кондиционерін қоспастан пайдалануыңызға болады.
- Кейбір модельдерде «Түтін кетіру»/«Плазма» режимі жұмыс істеп тұрған кезде электродсыз шам мен салқындату шамы жанады.
- Ионизаторды жұмыс істеп тұрған кезінде ұстамаңыз.
- Бұл функция қашықтан басқару дисплейінен басқаша жұмыс істейді.

«Дыбыссыз» функциясын пайдалану

Бұл функция сыртқы құрылғылардан шығатын шуды азайтып, көршілердің шағымдануының алдын алады.

- Дисплейде  белгішесі көрсетіледі.

ЕСКЕРТПЕ

- Бұл функция **Mode**, **Energy Ctrl.** немесе **Jet Mode** түймесін басқан кезде ажыратылады.
- Функцияны «Салқындату», «Жылыту», «Авто ауыстыру» және «Автоматты түрде жұмыс істеу» режимдерінде пайдалануыңызға болады.
- Көп тармақты сыртқы блокқа қосылған кезде, функцияға қолдау көрсетілмеуі мүмкін.

«Авто тазарту» функциясын пайдалану

«Салқындату» және «Ылғалсыздандыру» режимінде ылғал ішкі құрылғының ішінде пайда болады. Бұл функция осындай ылғалды кетіреді.

- Дисплейде  белгішесі көрсетіледі.

ЕСКЕРТПЕ

- Авто тазарту функциясы жұмыс істеп тұрған кезде кейбір функциялар қолданылмайды.
- UVnano функциясы орнатылғанда, автоматты тазалау функциясы бірге жұмыс істейді.
- Егер электр қуатын өшірсеңіз, желдеткіш 30 минут жұмыс істейді және ішкі құрылғының ішін тазалайды.
-  таңбасы моделіне байланысты кейбір ішкі блоктарда көрсетіледі.

LG ThinQ қолданбасы

Бұл мүмкіндік тек  немесе **ThinQ** логотипі бар үлгілерде қолжетімді.

LG ThinQ қолданбасы смартфон арқылы жуу машинасы байланысуға мүмкіндік береді.

LG ThinQ қолданбасының функциялары

Ыңғайлы смарт функцияларды пайдаланып, смартфон арқылы құрылғыңызды басқарыңыз.

Smart Diagnosis

Құрылғыны пайдалану кезінде мәселе болса, бұл Smart Diagnosis мүмкіндігі сізге мәселені диагностикалауға көмектеседі.

Параметрлер

Құрылғы мен қолданбада әртүрлі опцияларды орнатуға мүмкіндік береді.


ЕСКЕРТПЕ

- Егер сымсыз роутеріңізді, интернет провайдеріңізді немесе құпиясөзді ауыстыратын болсаңыз, **LG ThinQ** қолданбасынан тіркелген құрылғыны жойып, оны жаңадан тіркеңіз.
- Құрылғыны жетілдіру мақсатында қолданба пайдаланушыларға ескертілместен өзгертілуі мүмкін.
- Ерекшеліктері үлгісіне қарай әр түрлі болуы мүмкін.


LG ThinQ қолданбасын пайдалану алдында

- 1 Құрылғы мен сымсыз бағдарлауыш арасындағы қашықтықты (Wi-Fi желісін) тексеріңіз.
 - Жабдық пен сымсыз роутер арасы тым алыс болса, сигнал беру деңгейі әлсірейді. Тіркеуге көп уақыт кетуі мүмкін немесе жабдық орнатылмауы мүмкін.

- 2 Смартфоныңыздағы **Мобильді деректер** немесе **Ұялы деректер** функциясын өшіріңіз.



- 3 Смартфоныңызды сымсыз роутерге қосыңыз.



ЕСКЕРТПЕ

- Wi-Fi байланысын тексеру үшін, басқару панеліндегі  белгішесінің жанып тұрғанына көз жеткізіңіз.
- Құрылғы 2,4 Гц Wi-Fi желілерімен ғана жұмыс істейді. Желінің жиілігін анықтау үшін интернет қызметінің провайдеріне хабарласыңыз немесе сымсыз бағдарлауыштың нұсқаулығын қараңыз.
- **LG ThinQ** қолданбасы желілік байланысқа немесе желілік байланысқа қатысты қандай да бір ақаулыққа, олқылықтарға немесе қателіктерге жауапты емес.
- Егер құрылғыны Wi-Fi желілеріне қосуда қандай да бір қиындықтар туындаса, ол көп жағдайда роутерге байланысты емес. Wi-Fi сигналының қуатын жақсарту үшін, Wi-Fi репитерін (диапазон кеңейткіші) сатып алыңыз.
- Үйдегі желі ортасына байланысты Wi-Fi байланысы қосылмауы мүмкін немесе ажырап кетуі мүмкін.
- Желілік байланыс интернет қызметінің провайдеріне байланысты да дұрыс жұмыс істемеуі мүмкін.
- Айналадағы сымсыз орта сымсыз желі қызметін баяулатуы мүмкін.

- Сымсыз сигналды тарату жүйесіндегі ақаулыққа байланысты, жабдықты тіркеу мүмкін емес. Жабдықты электр жүйесінен ажыратып, әрекетті қайталамас бұрын бір минуттай күтіңіз.
- Сымсыз роутердегі брандмауэр қосулы болса, оны өшіріңіз немесе оны ерекше жағдай ретінде қосыңыз.
- Сымсыз желінің атауы (SSID) ағылшын әріптері мен сандардан тұруы қажет. (Ерекше таңбаларды қолданбаңыз)
- Смартфонның пайдаланушы интерфейсі (UI) телефонның операциялық жүйесіне (OS) және өндірушіге байланысты әртүрлі болуы мүмкін.
- Егер роутердің қауіпсіздік протоколы **WEP** күйіне орнатылған болса, желіні орната алмауыңыз мүмкін. Оны басқа қауіпсіздік протоколдарына өзгертіңіз (**WPA2** ұсынылады) және өнімді қайтадан тіркеңіз.

LG ThinQ қолданбасын орнату

Google Play & Apple App дүкенінен немесе смартфоннан **LG ThinQ** қолданбасын іздеңіз. Жүктеу үшін нұсқауларды орындап, қолданбаны орнатыңыз.

Сымсыз LAN модулінің сипаттамалары

Моделі	LCW-0037
Жиілік диапазоны	2412 MHz - 2472 MHz
Шығыс қуаты (макс.)	IEEE 802.11b:17.59 dBm IEEE 802.11g:17.39 dBm IEEE 802.11n(HT20):16.64 dBm IEEE 802.11n(HT40):17.05 dBm

Сымсыз функцияның Б/ж нұсқасы: V 1,0

Бастапқы коды ашық бағдарламалық жасақтама туралы ескертуі ақпарат

GPL, LGPL, MPL бойынша бастапқы кодты және осы өнімде бар бастапқы кодты ашу міндеттемелері бар басқа ашық код лицензияларын алу, сондай-ақ барлық қажетті лицензиялардың шарттарын, авторлық құқық ескертпелері мен басқа сәйкес құжаттарды алу үшін <https://opensource.lge.com> сайтына өтіңіз.

LG Electronics компаниясы сізге CD-ROM дискісінде ашық бастапқы кодты ақылы түрде береді. Қызмет ақысына opensource@lge.com мекенжайына электрондық хатпен сұрау жіберілгеннен кейін мұндай үлестіруді орындау құны (мысалы, тасығыш, жеткізу және өңдеу құны) жатады.

Бұл ұсыныс осы өнім соңғы жөнелтілгеннен бастап үш жыл бойы осы ақпаратты алатын барлық адамға беріледі.

Smart Diagnosis

Бұл мүмкіндік тек  немесе  логотипі бар үлгілерде қолжетімді.

Бұл мүмкіндікті құрылғыдағы мәселелерді диагностикалау және шешуде көмектесуі үшін пайдаланыңыз.

ЕСКЕРТПЕ

- LG салақтығына жатпайтын себептер үшін қызмет келесідей сыртқы факторларға (бірақ олармен шектелмейді) байланысты жұмыс істемеуі мүмкін: Wi-Fi қолжетімсіздігі, Wi-Fi желісінен ажыратылу, жергілікті қолданбалар дүкенінің саясаты немесе қолданбаның қолжетімсіздігі.
- Бұл мүмкіндік алдын ала ескертусіз өзгертілуі мүмкін және қайда орналасқаныңызға байланысты басқа түрде болуы мүмкін.

LG ThinQ қолданбасын мәселелерді диагностикалау үшін пайдалану

Wi-Fi жабдықталған құрылғыңызда мәселе орын алса, ол **LG ThinQ** қолданбасын пайдаланып ақаулықтарды жою туралы деректерді смартфонға тасымалдай алады.

- **LG ThinQ** қолданбасын іске қосып, мәзірде **Smart Diagnosis** мүмкіндігін таңдаңыз. **LG ThinQ** қолданбасында қамтамасыз етілетін нұсқауларды орындаңыз.

Мәселелерді диагностикалау үшін естілетін диагностикалауды пайдалану

Дыбыстық диагностикалау әдісін пайдалану үшін төмендегі нұсқауларды орындаңыз.

- **LG ThinQ** қолданбасын іске қосып, мәзірде **Smart Diagnosis** мүмкіндігін таңдаңыз. **LG ThinQ** қолданбасында қамтамасыз етілетін естілетін диагностика үшін нұсқауларды орындаңыз.

- 1 Қуат ашасын розеткаға дұрыс тығыңыз.
- 2 Смартфонның микрофонын  немесе  логотипіне жақын қойыңыз.
- 3 Смартфонның микрофонын логотипке деректердің тасымалдануы аяқталғанда ұстап тұрып, **Diagnosis(5 s)** түймесін 5 немесе одан көп секунд басып тұрыңыз.
 - Деректердің тасымалдануы аяқталмайынша смартфонды ұстап тұрыңыз. Деректерді тасымалдауға арналған қалған уақыт көрсетіледі.
- 4 Деректерді тасымалдау аяқталғаннан кейін диагноз қолданбада көрсетіледі.

ЕСКЕРТПЕ


- Ең жақсы нәтижеге қол жеткізу үшін дыбыстарды жіберу кезінде телефонды жылжитпаңыз.
- Қоршаған ортадағы шуды азайтыңыз немесе телефон ішкі құрылғыдан келетін дыбыс сигналын дұрыс қабылдамауы мүмкін.

⚠ АБАЙЛАҢЫЗ

- Құрылғыны тазаламас немесе қызмет көрсетпес бұрын қуат көзін ажыратып, желдеткіш тоқтағанша күтіңіз.

Егер ауа кондиционері ұзақ уақыт пайдаланылмаса, оған жақсы жағдайда қызмет көрсету үшін оны кептіріңіз. Оңтайлы жұмыс істеуін қамтамасыз ету және бұзылуың алдын алу үшін өнімді тазартып тұрыңыз.

- Ауа кондиционерін «Желдеткіш» режимінде 3-4 сағаттай кептіріңіз және электр қуатын ажыратыңыз. Егер оның бөлшектерінде ылғал қалып қойса, іші зақымдалуы мүмкін.
- Ауа кондиционерін қайта пайдаланбас бұрын оның ішкі бөлшектерін «Желдеткіш» режимінде 3-4 сағаттай кептіріңіз. Ол ылғалдан пайда болған жағымсыз иісті кетіреді.



- Мүмкіндік модельдің түріне байланысты әр түрлі болуы мүмкін.

Түрі	Сипаттама	Аралығы
Ауа сүзгісі	Шаңсорғышпен тазарту немесе қолмен жуу.	2 апта
Аллергиялық сүзгі	Шаңсорғышпен немесе щеткамен тазарту.	Әр 6 ай сайын
Ионизатор (Қосымша)	Шаңды кетіру үшін мақта талшықтарын пайдалану.	Әр 6 ай сайын
Ішкі құрылғы	Ішкі құрылғының бетін жұмсақ, құрғақ матамен тазарту.	Үнемі
	Конденсациялық дренаж түпті маманға тазартқызу.	Жылына бір рет
	Конденсациялық дренаж түтігін маманға тазарту.	Әр 4 ай сайын
	Қашықтан басқару құралының батареяларын ауыстыру.	Жылына бір рет
Сыртқы құрылғы	Жылу айырбастағыштың иректүтігі мен панель желдеткіштерін маманға тазартқызыңыз. (Техник маманға хабарласыңыз.)	Жылына бір рет
	Желдеткішті маманға тазартқызу.	Жылына бір рет
	Конденсациялық дренаж түпті маманға тазартқызу.	Жылына бір рет
	Желдеткіштің барлық бөлшектерінің дұрыс бекітілгенін маманға тексертіңіз.	Жылына бір рет
	Электр бөлшектерін ауамен тазартыңыз.	Жылына бір рет

ЕСКЕРТПЕ

- Сүзгілерді тазартқанда температурасы 40 °C артық суды пайдаланбаңыз. Ол пішінін немесе түсін өзгертуі мүмкін.
- Сүзгілерді тазартқан кезде бүркілетін құралдарды пайдаланбаңыз. Олар өнімнің бетін зақымдауы мүмкін.
- Аллергиялық сүзгіні сумен жумаңыз, себебі сүзгі зақымдалуы мүмкін (Қосымша).

Ауа сүзгісін тазарту

Ауа сүзгілерін 2 апта сайын бір рет қажет болса бірнеше рет тазартып тұрыңыз.


ЕСКЕРТПЕ

- Ауа сүзгісі иілген кезде сынуы мүмкін.
- Ауа сүзгісі дұрыс салынбаса, ішкі құрылғының ішіне шаң немесе басқа нәрселер кіруі мүмкін.


1-түрі

Егер ішкі құрылғыға оның жоғарғы жағынан қарасаңыз, үстіңгі сүзгіні оңай орната аласыз.


- 1 Электр қуатын өшіріп сымды ажыратыңыз.
- 2 Ауа сүзгісінің тұтқасынан ұстап оны ақырын көтеріңіз.




- 3 Оны ішкі құрылғыдан алып тастаңыз.



- 4 Сүзгінішаңсорғышпен немесе құрамында бейтарап тазалағыш сұйықтығы бар жылы сумен тазартыңыз.
- 5 Сүзгіні көлеңкеде кептіріңіз.
- 6 Ауа сүзгісінің ілмегін алдыңғы қақпаққа салыңыз.




- 7 Ауа сүзгісін бекіту үшін ілмекті төмен итеріңіз.




- 8 Алдыңғы қақпақтың ауа сүзгісіне дұрыс килгенін тексеріңіз.

2-түрі

- 1 Электр қуатын өшіріп сымды ажыратыңыз.
- 2 Алдыңғы қақпақты ашыңыз.
 - Қақпақтың екі жағын кішкене ашыңыз.
- 3 Ауа сүзгілерінің тұтқаларынан ұстап ақырын төмен тартып, оларды ішкі құрылғыдан шығарыңыз.



- 4 Сүзгінішаңсорғышпен немесе құрамында бейтарап тазалағыш сұйықтығы бар жылы сумен тазартыңыз.
- 5 Сүзгілерді көлеңкеде кептіріңіз.
- 6 Ауа сүзгілерінің ілмектерін алдыңғы қақпаққа салыңыз.



- 7 Алдыңғы қақпақтың ауа сүзгілеріне дұрыс килгенін тексеріңіз.


Аллергиялық сүзгіні тазалаңыз (Қосымша)

1 Электр қуатын өшіріп сымды ажыратыңыз.


2 Ауа сүзгілерін ішкі құрылғыдан алып тастаңыз.

3 Аллергиялық сүзгіні ішкі блоктан алып тастаңыз.

1-түрі




2-түрі




4 Сүзгілерді шаңсорғышпен тазартыңыз.

5 Аллергиялық сүзгіні салыңыз.

1-түрі



2-түрі



6 Ауа сүзгілерін киізіңіз.

7 Алдыңғы қақпақтың ауа сүзгісіне дұрыс киілгенін тексеріңіз.

ЕСКЕРТПЕ

- Аллергиялық сүзгінің мүмкіндігі мен орналасуы модельдің түріне байланысты әр түрлі болуы мүмкін.

Өзін-өзі тексеру функциясы

Бұл өнімде өзін-өзі тексеру функциясы бар. Қате болған жағдайда ішкі құрылғының шамы 2 секунд аралықпен жыпылықтайды. Егер осылай болса, жергілікті дилерге немесе қызмет көрсету орталығына хабарласыңыз.

Қызмет көрсетуге шақырмастан бұрын

Қызмет көрсету орталығына хабарлас бұрын келесілерді тексеріңіз. Егер ақау кетпесе, жергілікті дилерге хабарласыңыз.

Белгілер	Ықтимал себептері мен шешімі
Ауа кондиционері қалыпты жұмыс істемейді.	Құрылғыдан өрттің иісі мен әдеттен тыс дыбыстар шығуы мүмкін. Ауа кондиционерін өшіріңіз, электр сымын суырыңыз немесе электр қуатын ажыратыңыз және қызмет көрсету орталығына хабарласыңыз.
	Ылғалдықтың деңгейі төмен болса да ішкі құрылғыдан су ағады. Ауа кондиционерін өшіріңіз, электр сымын суырыңыз немесе электр қуатын ажыратыңыз және қызмет көрсету орталығына хабарласыңыз.
	Қуат кабелі зақымдалған немесе артық жылу шығаруда. Ауа кондиционерін өшіріңіз, электр сымын суырыңыз немесе электр қуатын ажыратыңыз және қызмет көрсету орталығына хабарласыңыз.
	Қосқыш, ажыратқыш (жерге жалғанатын) немесе сақтандырғыш дұрыс жұмыс істемейді. Ауа кондиционерін өшіріңіз, электр сымын суырыңыз немесе электр қуатын ажыратыңыз және қызмет көрсету орталығына хабарласыңыз.
	Құрылғы өзін-өзі тексеруден кате кодын шығарады. Ауа кондиционерін өшіріңіз, электр сымын суырыңыз немесе электр қуатын ажыратыңыз және қызмет көрсету орталығына хабарласыңыз.
Ауа кондиционері жұмыс істемейді.	Ауа кондиционері ажыратылған. Қуат сымының розеткаға жалғанғанын немесе қуат ажыратқышының қосулы екенін тексеріңіз.
	Сақтандырғыш күйген немесе қуат беру блокталған. Егер ажыратқыш өшірілсе, сақтандырғышты ауыстырыңыз немесе тексеріңіз.
	Электр қуатында іркіліс болды. - Электр қуатында кідіріс болған кезде ауа кондиционерін өшіріңіз. - Электр қуаты қалпына келтірілген кезде 3 минут күтіп, ауа кондиционерін қосыңыз.
	Кернеу тым жоғары немесе тым төмен. Ажыратқыштың өшірілгенін тексеріңіз.
	Ауа кондиционері белгіленген уақытта өшті. Ауа кондиционерін қосыңыз.
	Қашықтан басқару құралындағы батареяның орналасуы дұрыс емес. - Қашықтан басқару құралына батареяның дұрыс салынғанын тексеріңіз. - Егер батареялар дұрыс салынса, бірақ ауа кондиционері әлі жұмыс істемей тұрса, батареяларды ауыстырып қайта қосып көріңіз.

Белгілер	Ықтимал себептері мен шешімі
Ауа кондиционері салқын ауа шығармайды.	Ауа дұрыс айналып тұрған жоқ. • Ауа кондиционерін перделер немесе басқа нәрселер жауып тұрмағанына көз жеткізіңіз.
	Ауа кондиционері лас. • Ауа сүзгісін 2 аптада бір рет тазалаңыз. • Толық ақпаратты алу үшін «Ауа сүзгісін тазарту» бөлімін қараңыз.
	Бөлменің температурасы тым жоғары. • Жазда ішкі температураны толық салқындату уақыт алуы мүмкін. Мұндай жағдайда бөлменің ішін жылдам салқындату үшін «Jet Mode» режимін таңдаңыз.
	Бөлмеден салқын ауа кетіп қалады. • Салқын ауаның бөлмедегі желдету саңылауларынан шықпайтынын тексеріңіз.
	Қалаған температура ағымдағы температурадан жоғарырақ. • Қалаған температураны ағымдағы температурадан төменге қойыңыз.
	Жақын жерде жылу көзі бар. • Ауа кондиционері жұмыс істеп тұрғанда электр пеш немесе газ қыздырғыш сияқты жылу бөлетін құрылғыларды пайдаланбаңыз.
	«Желдеткіш» режимі таңдалған. • «Желдеткіш» режимі кезінде ауа кондиционерінен ішкі ауаны салқындатпайтын немесе жылытпайтын ауа шығады. • Жұмыс істеу режимін салқындатуға ауыстырыңыз.
	Сыртқы температура тым жоғары. • Салқындату әсері жеткілікті болмауы мүмкін.
Желдеткіш жылдамдығы реттелмейді.	«Jet Mode» немесе «Автоматты түрде іске қосу» режимі таңдалған. • Кейбір жұмыс істеу режимдерінде желдеткіштің жылдамдығын реттей алмайсыз. Желдеткіш жылдамдығын реттеуге болатын жұмыс істеу режимін таңдаңыз.
Температура реттелмейді.	«Желдеткіш» режимі немесе «Jet Mode» режимі таңдалған. • Кейбір жұмыс істеу режимдерінде температураның реттей алмайсыз. Температураны реттеуге болатын жұмыс режимін таңдаңыз.
Ауа кондиционері жұмыс істеу кезінде тоқтайды.	Ауа кондиционері кенеттен өшеді. • Құрылғыны өшіретін «Таймер» функциясы реттелмеген. Таймер параметрін тексеріңіз.
	Жұмыс кезінде электр қуатында іркіліс болды. • Электр қуатының тұрақталуын күтіңіз. Егер «Автоматты түрде қайта қосу» функциясы қосылған болса, электр қуаты берілген кезде құрылғы соңғы жұмысын бірнеше минут жалғастырады.

Белгілер	Ықтимал себептері мен шешімі
Ішкі құрылғы электр қуаты өшірілсе де жұмыс істеп тұр.	«Авто тазарту» функциясы жұмыс істеп тұр. • «Авто тазарту» функциясына ішкі құрылғының ішіндегі қалған ылғалды кетіргенше жұмысын жалғастыруға мүмкіндік беріңіз. Егер бұл мүмкіндікті қаламасаңыз, құрылғыны өшіруіңізге болады.
Ішкі құрылғыдағы ауа шығатын саңылаудан бу шығады.	Ауа кондиционерінен шығатын салқындаған ауадан бу түзіледі. • Бөлменің температурасы төмендегенде бұл құбылыс кетеді.
Сыртқы құрылғыдан су ағады.	Қыздыру кезінде жылу айырбастағыштан буланған су тамшылайды. • Ол үшін негізгі түпкі ыдыстан ағатын тесік жасау керек. Орнатушыға хабарласыңыз.
Шу немесе діріл бар.	Реверсивті клапанның қозғалуына байланысты құрылғы іске қосылған немесе тоқтаған кезде тықылдаған дыбыс шығады. Сықырлаған дыбыс: Ішкі құрылғының пластмасса бөлшектері кенет температураның өзгеруіне байланысты тартылғанда немесе созылғанда кезде сықырлайды. Ағудың немесе үрлеудің дыбысы: Бұл ауа кондиционері арқылы мұздатқыш агенттің өтуі. • Бұл қалыпты көрсеткіштер. Шу тоқтайды.
Ішкі құрылғы жағымсыз иіс шығарады.	Жағымсыз иістер (темекінің иісі сияқты) ішкі құрылғы арқылы сорылып ауа ағынымен шығарылуы мүмкін. • Егер иіс кетпесе, сүзгіні жууыңыз керек. Егер ол жұмыс істемесе, жылу айырбастағышты тазарту үшін қызмет көрсету орталығына хабарласыңыз.
Ауа кондиционері жылы ауа шығармайды.	«Жылыту» режимі қосылған кезде дефлектор жабылудың қасында тұрады және сыртқы құрылғы жұмыс істеп тұрса да ешқандай ауа сыртқа шықпайды. • Бұл қалыпты көрсеткіш. Құрылғы ішкі құрылғы арқылы жеткілікті жылы ауа шығарғанша күтіңіз.
	Сыртқы құрылғы «Еріту» режимінде. • «Жылыту» режимінде сыртқы температура төмендегенде иректүтіктерде мұз/қырау түзіледі. Бұл функция иректүтіктердегі қырауды кетіреді және шамамен 15 минут ішінде аяқталады.
	Сыртқы температура тым төмен. • Жылыту әсері жеткілікті болмауы мүмкін.

Белгілер	Ықтимал себептері мен шешімі
Тұрмыстық жабдығыңыз бен смартфонңыз Wi-Fi желісіне қосылмаған.	Wi-Fi желісіне қосылу үшін пайдаланып жатқан құпиясөзіңіз дұрыс емес. • Смартфоныңызға қосылған Wi-Fi желісін тауып, жойыңыз да, жабдығыңызды LG ThinQ қолданбасына қайта тіркеңіз.
	Смартфоныңыздың мобильді деректері қосұлы. • Смартфонның Мобильді интернет функциясын өшіріңіз де, жабдықты Wi-Fi желісі арқылы қайта тіркеңіз.
	Сымсыз желі атауы (SSID) қате орнатылды. • Сымсыз желінің атауы (SSID) ағылшын әріптері мен сандардан тұруы қажет. (Ерекше таңбаларды қолданбаңыз)
	Роутердің жиілігі 2,4 ГГц емес. • Жиілігі 2,4 ГГц болатын роутерге ғана қолдау көрсетіледі. Сымсыз роутер жиілігін 2,4 ГГц мәніне орнатып, жабдықты сымсыз роутерге қосыңыз. Роутер жиілігін тексеру үшін, интернет провайдеріне немесе роутер өндірушісіне хабарласыңыз.
	Жабдық пен роутердің арасы тым алыс. • Жабдық пен роутердің арасы тым алыс болса, сигнал әлсіз болып, байланыс дұрыс конфигурацияланбауы мүмкін. Роутерді жабдыққа жақын орналатырыңыз.

ЕСКЕРТПЕ

- Кейбір функцияларға модельге байланысты қолдау жоқ болуы мүмкін.

Memo

Memo

Memo



- Arcelik-LG Klima Sanayi ve Ticaret A.S. Organize Sanayi Ihsan Dede Cad. No.139, 41400 Gebze/Kocaeli, Turkey
- ҚР импорттаушы: “Эл Джи Электроникс Алматы Казахстан” АҚ
ҚР, Алматы қ., Көкорай к-сі, 2А/9
- Arcelik-LG Ауа баптау және АС Саудасы.
Ұйымдастырылған Өнеркәсіп Ихсан Деде Кад, нөмірі 139, 41400 Гебзе/Кочаели, Түркия
- Арчелік-ЛГ Кліма Санай Ве Тікарет А.С. Промислова зона Ихсан Деде Кад. №139, 41400 Гебзе/Коджаелі Туреччина
- Arcelik-LG Havo konditsioner sanoat va tijorat aksionerlik shirkati.
Tashkiliy Sektor Ihsan Dede ko'chasi. No.139, 41400 Gebze/Kocaeli, Turkiya

