
SPECIFICATIONS



Power source	On specification label	
Model	WP-1360R	
Water level	H : 60 Litres	
Water pressure	Less than 100kPa (1kgf/cm)^2	
Dimension	805 x 478 x 975 mm.(W x D x H)	
Weight	26 kg	
Capacity	Wash : 10,1 kg	Spin : 6,5 kg
Power input	Wash : 360 W	Spin : 200 W

LG
Life's Good

OWNER' S MANUAL

WASHING MACHINE

Please read this manual carefully before operating your washing machine and retain it for future reference.

MODEL : WP-1360R

www.lg.com

CAUTION

WARNING

Installation Area
- Avoid area exposed to snow, rain, or where humidity is high. It may cause electric shock.

Heat
- Avoid electric heater, candle light, cigarette light, bug smoker, etc. near the machine. It may ignite or deform plastic part.

Switch Area
- Avoid watering on the switch area. It may cause electric shock or fire.

Hot water
- Avoid using hot water It may deform plastic parts or cause malfunction.

Volatile Material
- Do not use volatile material such as Benzene, Gasoline, bug killer.
- Do not leave strong alkaline substance such as bleach inside the tub. Damage on plastic surface and rubber parts may occur.

In Operation
- Do not insert the hand inside the spin dryer basket while the machine is in operation (Do not let children climb on the machine or climb into the tub. Injury may occur.)
- Do not drain the water out of the wash tub while the spin dryer basket is in operation.Otherwise the spin motor could be damaged.

Installation
- Install the washing machine on a horizontal support. Otherwise,it may cause vibration and noise.
- Be sure to disconnect the power cord from the electric outlet before starting care and maintenance.

Power Cord
- If the power supply cord is damaged, it must only be replaced by the manufacture or its service agent or a similarly qualified person in order to avoid a hazard.
- Do not treat the power supply cord with your wet hand.


- Be sure to earth the washer to prevent electric shock. To reduce the risk of electric shock, do not install the washer in humid spaces.

Electric Outlet
- Avoid connecting several electric devices to single outlet. It may cause fire.

- This appliance is not intended for use by persons (including children) with reduced physical, sensory or mental capabilities, or lack of experience and knowledge, unless they have been given supervision or instruction concerning use of the appliance by person responsible for their safety, Children should be supervised to ensure that they do not play with the appliance

• If this product is used for commercial purpose, it is not warranted.
(Example : Public places such as public bathroom, lodging house, training center, dormitory)
If the product is installed outside the normal service area, any cost of transportation involved in the repair of the product, or the replacement of a defective part, shall be borne by the owner.

FEATURES



1. **Water Supply Inlet**
   Connect here with the inlet hose from the water faucet to feed water to the tub.
2. **Water Supply Selector**
   Select "WASH" to supply water for washing and rinsing and "SPIN" for spin shower rinse.
3. **Wash Timer**
   Select the desired time for washing or rinsing. The maximum is 15 min.
4. **Wash Program**
   Set the program to "Gentle","Normal", "Strong" according to kinds and quantity of the laundry.
5. **Drain Selector**
   Select "Wash • Rinse" for washing and rinsing and "Drain" to drain the water out of the tub.
6. **Spin Timer**
   Select the desired time for spinning. The maximum limit is 5 min. Don't rotate the the knob more than prescribe limit.
   **After continue using spinning program 3 times continue , Please stop spinning more than 1 hour otherwise the spin motor could be damage of fire or stop operation.
   ***To obtain an efficient perfomance according to energy label according to energy label, Wash program 30 mins (60 °C), Rinse 2 times, Spin 1 times should be applied.
   (Only for Saudi Arabia Country)

INSTALLATION

Installation area

- Set on flat and firm floor.
- Incorrect installation may course severe noise and break down.




- Maintain more than 10 cm. between the side of drain hose and the wall.
- A carpet must not obstruct the ventilation openings.



Connecting the earth wire


- Install the earth wire to prevent short-circuit due to leaking current and electric shock.
- It is attached at the back of the washer. Connect it to the metal water pipe. If the water pipe is made of plastic, it does not have the earth effect.
- Do not connect the earth wire to the gas pipe, lightning arrester. telephone connecter, etc.



Warning-the appliance with two-pronged plug must be grounded


Connecting the power plug

- Insert the power plug into the outlet.
- Before connecting the power plug, check if the voltage setting of the washer matches the outlet voltage.
- If AC outlet with ground terminal is used, grounding is not needed. If not, never forget earthing (earthing method above).
- The appliance must be positioned so that the plug is accessible




Other earthing method


- After connecting the earth wire to the earth copper plate, bury it at least 75cm deep under the wet ground.



- Connect to the earthing-only outlet.




- When installing it in an area where earthing is not possible, purchase a short-circuit breaker connect it to the outlet.



Connecting the drain hose

- Push the clamp toward the body of the washing machine as shown in the figure.
- Be sure to reroute the hose so that it is not kinked; kinks or sharp bending in the hose will prevent proper drainage.
- Make sure water is draineded smoothly by placing a base under the machine or by applying other appropriate mean.




INSTALLATION & HOW TO WASH

Before washing

1. Check the washing instruction labels on the clothing to be washed.
2. Remove all objects from the pockets of the clothing.Objects left in the pockets may damage clothing or break the washing machine (could cause the drain hose to clog).
3. After separating oiled or dyed clothing, wash.
4. For your convenience hang up the wash cover on the right or left side of the washing machine tub when not in use.
5. Check and clean detergent box before washing.

Remove this before washing



How to wash

1 Set the drain selector

Set as "Wash•Rinse" position.



Drain Selector

2 Set the water selector to "WASH"



Water Selector


3 Put the appropriate amount of detergent and the laundry into the wash tub. And add water to the desired water level which you want. (Refer to Table 2)



4 Open water supply and fill water till water level mark "H". That is because clothes can absorb adequate amount of water and water will not short.



5 Select the wash program to "Gentle", "Normal" or "Strong" according to the kinds and quantity of the laundry. (Refer to Table 2)



Wash Program

6 Set the desired wash time.



Wash Timer

7 When washing is finished, locate the drain selector to "Drain" position and drain the water out.



Drain Selector

8 Spinning in the spin dryer basket.
Move the laundry into spin dryer basket.
Put the laundry down lightly.
Place the safety cover horizontally on the laundry.
Set the desired spin time with the spin timer.




HOW TO RINSE & HOW TO SPIN

Interim spin rinse

- Interim spin rinse prior to regular rinsing helps removing sudsy water from the laundry and improve rinsing efficiency. Also is helpful to water saving.

1 After washing.
- Move the laundry into the spin dryer basket.
- Place the safety cover horizontally on the laundry.




2 Set the water selector to "SPIN".



Water Selector

3 Set the desired spin flow appropriately.




Spin Timer

4 After interim spin rinse, move the laundry into the wash tub for rinsing.



Note for spinning



1. Put the laundry evenly into the spin dryer basket.
2. Put the laundry down lightly.
3. Place the safety cover horizontally over the laundry, washing machine will be damage if the safety cover is not placed.
4. Close the spin dryer cover.
5. Do not drain the water out of the wash tub while the spin dryer basket is in operation.

- If the spin dryer basket is off-balance and vibrates excessively, stop the spinning, rearrange the clothes evenly, and then resume spinning.
- **If the spinning fail to stop when the spin dryer cover is opened, the brake is out of order. Immediately stop using the machine and request repair service.**


CARE & MAINTENANCE

1



- Pull out lint filter in the shown direction.

2



- Turn the net over and rinse in water.

3



- Fit the filter to its original position. Press the filter until you hear a click sound.

REFERENCE

TABLE 1. WEIGHT GUIDE FOR CLOTHES

Type of clothing	Type of fabric	Weight per piece
Under shirt	Cotton	150g(53.0oz)
Handkerchief	Cotton	50g(1.8oz)
Bath towel	Cotton	300g(10.6oz)
Shirt	Mixed fabric	200g(7.1oz)
Socks (1 pair)	Mixed fabric	50g(1.8oz)
Pajama (shirt and pants)	Cotton	500g(17.6oz)
Winter undershirt	Woolen	600g(21.2oz)
Workclothes	Mixed fabric	800g(28.2oz)
Blouse	Mixed fabric	200g(7.1oz)

TABLE 2. GUIDE FOR WASHING (with SOAK)

Type of Fabric	Wash Selector	Wash Time	Water Level	Amount of Water (Ltr)	Amount of Detergent (gms)
Synthetics, Silk	SOAK-GENTLE	15+15 min.	L	49	50~55
			M	55	56~64
			H	60	65~68
Cotton, Linen	SOAK-NORMAL	20+15 min.	L	49	50~55
			M	55	56~64
			H	60	65~68
Very soiled cotton and linen	SOAK-STRONG	25+15 min.	L	49	50~55
			M	55	56~64
			H	60	65~68

Notes :

- Amount of laundry is a weight of dry laundry.
- Detergent is a general synthetic detergent.

⚠ **CAUTION :** Fill in wash to height 20mm above the level you desire. When washing starts water level will automatically come to level you desire.

TROUBLESHOOTING GUIDE

Before Requesting Service

Problem	Checking point
Motor does not operate,	• Is the power cord firmly plugged in? • Is the timer turned to a suitable point except "Off" ?
Spin dryer basket does not operate.	• Is there any clothing dropped between the basket and tub? • Is the spin dryer cover closed? • Is the laundry gathered to one side of the spin dryer basket?
Water does not enter washer	• Is the water faucet hooked up? • Is the water faucet frozen?
No draining	• Is there lint stuck in the plunger valve? • Is the end of the drain hose guide located at an exceed height? • Is the drain hose laid down? • Is the drain hose twisted?