Model	VC68**H**		
Language	English+Arabic		
Page	39	Color(cover/body)	1/1
Material	Weight 100g	Size(W*H)	150×220(mm)
Date	2011.04.06	Designer	Song Wenshuai
Part No.	MFL57903867	Description	Owners Manual

Chage Record

No.	Change content	ECO No.	Date	Designer	Confirm
1					
2					
3					
4					
5					
6					
7					
8					
9					

LG
Life's Good

OWNER'S MANUAL

New Type Cyclone Vacuum Cleaner

This information contains important instructions for the safe use and maintenance of the vacuum cleaner.
Especially, please read all of the information on page 4,5 for your safety.
Please keep this manual in an easily accessible place and refer to it anytime.

VC68**H**

P/No.:MFL57903867

www.lg.com

C K

Table of contents

Important safety instructions .....4~5

How to use 6

Assembling vacuum cleaner.....6

Operating vacuum cleaner.....8

Using carpet and floor nozzle 9

User's guide for turbine nozzle 10

Using accessory nozzles 11

Emptying dust tank 12

Cleaning dust tank.....13

User's guide for sani punch 14

Cleaning air filter and motor safety filter 15

Cleaning exhaust filter 16

What to do if your vacuum cleaner does not work 17

What to do when suction performance decreases 17

IMPORTANT SAFETY INSTRUCTIONS

Read and follow all instructions before using your vacuum cleaner to prevent the risk of fire,electric shock, personal injury,or damage when using the vacuum cleaner.This guide do not cover all possible conditions that may occur.Always contact your service agent or manufacturer about problems that you do not understand. This appliance complies with the following EC Directives :-73/23/EEC,93/68/EEC-Low Voltage Directive–89/336EEC –EMC Directive.

This is the safety alert symbol.
This symbol alerts you to potential hazards that can kill or hurt you and others.
All safety messages will follow the safety alert symbol and either the word “WARNING” or “CAUTION.”
These words mean:

WARNING This symbol will alert you to hazards or unsafe practices which could cause serious bodily harm or death.

CAUTION This symbol will alert you to hazards or unsafe practices which could cause bodily injury or property damage.

WARNING

- **Disconnect electrical supply before servicing or cleaning the unit or when cleaner is not in use.**
  Failure to do so could result in electrical shock or personal injury.
- **Do not use vacuum cleaner to pick up anything that is burning or smoking such as cigarettes, or hot ashes.**
  Doing so could result in death, fire or electrical shock.
- **Do not vacuum flammable or explosive substances such as gasoline, benzene, thinners, propane (liquids or gases).**
  The fumes from these substances can create a fire hazard or explosion. Doing so could result in death or personal injury.
- **Do not handle plug or vacuum cleaner with wet hands.**
  Doing so could result in death or electrical shock.
- **Do not unplug by pulling on cord.**
  Doing so could result in product damage or electrical shock. To unplug, grasp the plug, not the cord.
- **Keep hair, loose clothing, fingers, and all parts of the body away from openings and moving parts.**
  Failure to do so could result in electrical shock or personal injury.
- **Do not pull or carry by cord, use cord as a handle, close a door on cord, or pull cord around sharp edges or corners. Do not run vacuum cleaner over cord. Keep cord away from heated surfaces.**
  Failure to do so could result in electrical shock or personal injury or fire or product damage.
- **Do not allow to be used as toy. Close attention is necessary when used by or near children.**
  Personal injury or product damage could result.
- **Do not use the vacuum cleaner if the power cord or plug is damaged or faulty.**
  Personal injury or product damage could result. In these cases, contact LG Electronics Service Agent to avoid hazard.
- **Do not use vacuum cleaner if it has been under water.**
  Personal injury or product damage could result. In these cases, contact LG Electronics Service Agent to avoid hazard.
- **Do not continue to vacuum if any parts appear missing or damaged.**
  Personal injury or product damage could result. In these cases, contact LG Electronics Service Agent to avoid hazard.
- **Do not use an extension cord with this vacuum cleaner**
  Fire hazard or product damage could result.
- **Using proper voltage.**
  Using improper voltage may result in damage to the motor and possible injury to the user. Proper voltage is listed on the bottom of vacuum cleaner.
- **Turn off all controls before unplugging.**
  Failure to do so could result in electrical shock or personal injury.
- **Do not change the plug in any way.**
  Failure to do so could result in electrical shock or personal injury or product damage. Doing so result in death. If plug does not fit, contact a qualified electrician to install the proper outlet.
- **Repairs to electrical appliances may only be performed by qualified service engineers.**
  Improper repairs may lead to serious hazards for the user.
- **Do not plug in if control knob is not in OFF position.**
  Personal injury or product damage could result.
  (Depending on model)
- **Keep children away and beware of obstructions when rewinding the cord to prevent personal injury**
  The cord moves rapidly when rewinding.(Depending on model)
- **The hose contains electrical wires. Do not use it if it is damaged, cut or punctured.**
  Failure to do so could result in death,or electrical shock.
  (Depending on model)

IMPORTANT SAFETY INSTRUCTIONS

⚠ CAUTION

- **Do not put any objects into openings.**
  Failure to do so could result in product damage.
- **Do not use with any opening blocked: keep free of dust, lint, hair, and anything that may reduce air flow.**
  Failure to do so could result in product damage.
- **Do not use vacuum cleaner without dust tank and/or filters in place.**
  Failure to do so could result in product damage.
- **Do not use vacuum cleaner to pick up sharp hard objects, small toys, pins, paper clips, etc.**
  They may damage the cleaner or dust bin.
- **Store the vacuum cleaner indoors.**
  Put the vacuum cleaner away after use to prevent tripping over it.
- **The vacuum cleaner is not intended to use by young children or infirm people without supervision.**
  Failure to do so could result in personal injury or product damage.
- **Only use parts produced or recommended by LG Electronics Service Agents.**
  Failure to do so could result in product damage.
- **Use only as described in this manual. Use only with LG recommended or approved attachments and accessories.**
  Failure to do so could result in personal injury or product damage.
- **To avoid personal injury and to prevent the machine from falling when cleaning stairs, always place it at the bottom of stairs.**
  Failure to do so could result in personal injury or product damage.
- **Use accessory nozzles in sofa mode.**
  Failure to do so could result in product damage.
- **Make sure the filters (exhaust filter and motor safety filter) are completely dry before replacing in the machine.**
  Failure to do so could result in product damage.
- **Do not dry the filter in an oven or microwave.**
  Failure to do so could result in fire hazard.
- **Do not dry the filter in a clothes dryer.**
  Failure to do so could result in fire hazard.
- **Do not dry near an open flame.**
  Failure to do so could result in fire hazard.
- **Always clean the dust bin after vacuuming carpet cleaners or fresheners, powders and fine dust.**
  These products clog the filters,reduce airflow and can cause damage to the cleaner. Failure to clean the dust bin could cause permanent damage to the cleaner.
  (Depending on model)
- **Don ’t grasp the tank handle when you are moving the vacuum cleaner.**
  The vacuum cleaner`s body may fall when separating tank and body. Personal injury or product damage could result. **You should grasp the carrier handle** when you are moving the vacuum cleaner.(Depending on model)

Thermal protector :
This vacuum cleaner has a special thermostat that protects the vacuum cleaner in case of motor overheating. If the vacuum cleaner suddenly shuts off, turn off the switch and unplug the vacuum cleaner. Check the vacuum cleaner for possible source of overheating such as a full dust tank, a blocked hose or clogged filter. If these conditions are found, fix them and wait at least 30 minutes before attempting to use the vacuum cleaner. After the 30 minute period, plug the vacuum cleaner back in and turn on the switch. If the vacuum cleaner still does not run, contact a qualified LG authorised Service Agent.

C K

How to use Assembling vacuum cleaner

❶ Carpet and floor nozzle

Push the nozzle into the telescopic pipe.

❷ Telescopic pipe

- Push telescopic pipe firmly into hose handle.
- Grasp the spring latch to expand.
- Pull out the pipe to desired length.

❸ Connecting the hose to the vacuum cleaner

Push the fitting pipe on the flexible hose into the attachment point on the vacuum cleaner. To remove the flexible hose from the vacuum cleaner, press the button situated on the fitting pipe, then pull the fitting pipe out of the vacuum cleaner.

How to use Operating vacuum cleaner

❶ How to operate

- Pull out the power cord to the desired length and plug into the socket.
- Place the control knob of the hose handle to the required position.
- To turn off, slide control knob to OFF position.
- Press the cord reel button to rewind the power cord after use.

❷ Park mode

- To store during vacuuming, for example to move a small piece of furniture or a rug, use park mode to support the flexible hose and nozzle.
  - Slide the hook on the nozzle into the slot on the side of vacuum cleaner.

❸ Storage

- When you have switched off and unplugged the vacuum cleaner, press the cord reel button to automatically rewind the cord.
- You can store your vacuum cleaner in a vertical position by sliding the hook on the nozzle into the slot on the underside of the vacuum cleaner.

How to use Using carpet and floor nozzle

C K

❶ Carpet and floor nozzle (depend on model)

- **The 2 position nozzle**
  This is equipped with a pedal which allows you to alter its position according to the type of floor to be cleaned.
  Hard floor position (tiles, parquet floors...).
  Press on the pedal to lower the brush.
  Carpet or rug position.
  Press on the pedal to lift the brush up.

❷ Suction hole for device protection (depend on model)

You can perform cleaning at any place like corner or crevice since revolution of the suction hole is free.

How to use

USER'S GUIDE FOR TURBINE NOZZLE

❺ Turbine Nozzle (depending on model)

- **Cleaning turbine brush nozzle.**
- Press the button on the rear side of the nozzle to separate the air cover.
- Use the dusting brush & crevice tool to vacuum clean the brush and fan.

How to use Using accessory nozzles

C K

❹ Upholstery nozzle

Upholstery nozzle is for vacuuming upholstery, mattresses etc.

❺ Dusting brush

Dusting brush is for vacuuming picture frames, furniture frames, books and other irregular surfaces.

❻ Crevice tool

Crevice tool is for vacuuming in those normally hard-to-reach places such as reaching cobwebs or between the cushions of a sofa.

NOTICE

Use accessory in the sofa mode

How to use Emptying dust tank

Cleaning the dust " tank".

- Open the tank cap.
- Wash both parts with soft material. Gently rinse both parts under a cold running tap.

⚠ WARNING!

Gently rinse both parts separately under a cold running tap until the water runs clear.
Do not use detergent or a washing machine or dish washer.

Caution: Do not push the cover open button when you carry the vacuum cleaner.
If the cover opens, it is easy to detach the dust tank from the vacuum cleaner.

How to use Cleaning dust tank

- Open cover with pushing button and pull out dust tank.
- Raise dust tank cap.
- Dry fully in shade so that moisture is entirely removed.

NOTICE

If suction power decreases after cleaning dust tank, clean air filter and motor safety filter. ➔ Next page

How to use

USER'S GUIDE FOR SANI PUNCH

Use it as shown in the diagram

Assembling

Effective cleaning

- *bed, bedding, heavy blanket*

- *Light blanket & sheet*

To increase cleaning efficiency for light blankets, lay on top of a bulky blanket and then clean.

SANI PUNCH(depending on model)

• Cleaning Sani Punch

▶ The vibrator may break down due to the cleansing of the inhaler with water.

1 If the dust settles in the box while cleaning,press the button 2or3 times.(It will remove most of the dust.)

2 After the cleaning,if there are lots of dusts in the box, separate the box from the inhaler by turning it anticlockwise.

3 Empty the box.

4 Aim at the Spiral, Fix the box into the inhaler by turning it clockwise

5 Separate the bottom plate by pressing the buttons in the back.

6 Clean the dirty body of the inhaler carefully with a cloth.

7 Wash the separated bottom plate and dry it in the shade.

8 Arrange the vibrator in order.

9 Insert the joining spiral into the groove.

10 Attach the bottom plate properly by pressing down.

How to use Cleaning air filter and motor safety filter

If suction power is decreased after cleaning dust tank, clean air filter and motor safety filter. Air filter and motor safety filter are located at the center of vacuum cleaner in the above figure.

- Open the air filter cover by pulling the air filter cover lever and take out air filter.
- Separate the parts
- Wash air filter and motor safety filter with water.
- Do not wash filters with hot water.
- Dry fully in shade so that moisture is entirely removed.
- Air filter and motor safety filter should be cleaned in the above case.

NOTICE

If filters are damaged, do not use them.
In this cases, contact LG Electronics Service Agent.

How to use Cleaning exhaust filter

- The exhaust filter is a reusable HEPA filter.
- To change the exhaust filter, remove the filter cover on the body by release hook.
- Pull out the exhaust filter.
- Dust off filter. (Do not wash filter with water.)
- The exhaust filter should be cleaned at least once a year.

What to do if your vacuum cleaner does not work

Check that the vacuum cleaner is plugged in correctly and that the electrical socket is working.

What to do when suction performance decreases

- Turn off the vacuum cleaner and unplug it.
- Check the telescopic pipe, flexible hose and cleaning tool for blockages or obstructions.
- Check that the dust tank is not full. Empty if necessary.
- Check that the exhaust filter is not clogged. Clean the exhaust filter if necessary.
- Check that the air filter is not clogged. Clean the air filter if necessary.

Note

LG
Life's Good

LG
Life's Good

الملاحظة

ماذا تعمل اذا لم تشتغل المكنسة الكهربائية.؟

اختبار المقبس الكهربائي وادخال القابس بشكل صحيح .

ماذا تعمل اذا تم تخفيض قوة الشفط؟

- وقف استعمال المكنسة الكهربائية واخراج القابس .
- اختبار الخرطوم المرن والأنابيب المتراكبة وأدوات التنظيف بشكل دقيق .
- اختبار كيس الغبار (مليئ) . ويجب تغييره ان انقتضى الأمر .
- اختبار فلتر العادم . ويجب تنظيفه ان انقتضى الأمر .
- اختبار فلتر الهواء . ويجب تنظيفه ان انقتضى الأمر .

كيفية الاستعمال تنظيف فلتر العادم

- فلتر العادم هو نوع من فلتر HEPA الذي يمكن اعادة استعماله .
- تبديل فلتر العادم، فتح غطاء الفلتر في الجسم بالخطاف .
- اخراج فلتر العادم .
- ازالة الغبار من الفلتر (ممنوع تنظيف الفلتر بالماء) .
- يجب تنظيف فلتر العادم مرة واحدة كل سنة على الأقل .

كيفية الاستعمال تنظيف فلتر الهواء وفلتر سلامة المحركات

اذا تم تخفيض قوة الشفط بعد تنظيف علبة الغبار، فيجب تنظيف فلتر الهواء وفلتر سلامة المحركات . يتم وضع فلتر الهواء وفلتر سلامة المحركات في مركز المكنسة الكهربائية في الشكل أعلاه .

- فتح غطاء فلتر الهواء بسحب ذراع غطاء فلتر الهواء واخراج فلتر الهواء .
- فك الأجزاء .
- غسيل فلتر الهواء وفلتر سلامة المحركات بالماء .
- ممنوع غسيل الفلترات بالماء الساخنة .
- التجفيف بشكل كامل في ظل الشمس من أجل ازالة كل الرطوبة .
- يجب تنظيف فلتر الهواء وفلتر سلامة المحركات حسب الخطوات أعلاه .

الملاحظة:

ممنوع استعمال الفلترات اذا تم تخريبها .
يجب الاتصال بوكيل LG للخدمة والصيانة اذا حدث ذلك .

كيفية الاستعمال

دليل لاستعمال ساني لكمة

الاستعمال كما يظهر في الشكل

التركيب

التنظيف الفعال

• البطانية والورقة الخفيفة • السرير، الفراش، البطانية الثقيلة

من أجل زيادة كفاءة التنظيف للبطانية الخفيفة، وضعها فوق البطانية الضخمة، ثم التنظيف.

❸ ساني لكمة (حسب الموديل)

• تنظيف ساني لكمة

◄ قد يتم تخريب الهزاز بسبب تنظيف جهاز الاستنشاق بالماء

4 يهدف الى اللولب، تركيب العلبة الى جهاز الاستنشاق بتحويله بحركة عقرب الساعة.

3 تفريغ العلبة.

2 بعد التنظيف، اذا كان كثير من الغبار في العلبة، اخراج العلبة من جهاز الاستنشاق بتحويله بمعاكس حركة عقرب الساعة.

1 اذا تم وضع الغبار الى العلبة عند التنظيف، ضغط الزر 2 أو 3 مرات. (سيتم ازالة معظم الغبار.)

7 تنظيف أسفل اللوحة المفصول وتخفيفه في الظل.

6 تنظيف الجسم القذير لجهاز الاستنشاق بعناية مع القماش.

5 اخراج أسفل اللوحة بضغط الزر في الخلف.

10 تركيب أسفل اللوحة بشكل صحيح بضغط التحت.

9 ادخال اللولب الموصول الى الى الأخدود.

8 تجهيز الهزاز بشكل صحيح

كيفية الاستعمال تنظيف علبة الغبار

- فتح الغطاء بضغط الزر وسحب علبة الغبار.
- رفع غطاء علبة الغبار
- التجفيف بشكل كامل في ظل الشمس من أجل ازالة كل الرطوبة .

الملاحظة:
اذا تم تخفيض قوة الشفط بعد تنظيف علبة الغبار، فيجب تنظيف فلتر الهواء وفلتر سلامة المحركات .← الصفحة القادمة.

كيفية الاستعمال تفريغ علبة الغبار

تنظيف زعلبةس الغبار .

• فتح غطاء العلبة .

• تنظيف كل الأجزاء بمادة المرنة .

تنظيف كل الأجزاء تحت الحانفية بالماء .

التحذير!

تنظيف كل الأجزاء تحت الحانفية بالماء الباردة بشكل منفصل حتى خروج ماء نظيفة . ممنوع استعمال السائل الكيماياوي أو غسالة الملابس أو الصحون.

الملاحظة : ممنوع ضغط الزر المفتوح الأمامي عند قبض المقبض لنقل المكنسة الكهربائية، والاّ فيسبب سقوط صندوق الغبار وتخريب المنتوجات .

كيفية الاستعمال استعمال الفوهات المساعدة

❹ فوهة مواد التنجيد

يمكن استعمال فوهة مواد التنجيد لتنظيف الأركان والشقوق .

❺ فرشاة الغبار

استعمال فرشاة الغبار لشفط هياكل الصور والأثاث والكتب والسطوح الغير منتظمة الأخرى .

❻ أدوات تنظيف الأركان

استعمال أدوات تنظيف الأركان لتنظيف أماكن صعبة الوصول، مثل أركان الأسقف وأسفل الأثاث .

الملاحظة

استعمال المتممات المناسبة في موديل الصوفا.

كيفية الاستعمال

دليل الاستعمال للفوهة الطربينية

❺ الفوهة الطربينية (حسب الطراز)

- **تنظيف فوهة الفرشاة الطربينية .**
- ضغط الزر وراء الفوهة لفك غطاء الهواء .
- استعمال فرشاة الغبار وأدوات تنظيف الأركان لتنظيف وشفط الفرشاة والمروح .

كيفية الاستعمال استعمال فوهة السجاد والأرض

❶ فوهة السجاد والأرض (حسب الطراز)

• **الفوهة ذات الوضع الثنائي**
تزويد دواسة لتعديل الوضع حسب أنواع الأرض للتنظيف.
والتي تسمح لك بتغيير وضعها وفقا لنوع الأرضية التي يتم تنظيفها.**وضع الأرضية الصلبة** (أرضيات الباركية والسيراميك...):
اضغط على الدواسة لإنزال الفرشاة لأسفل **وضع السجاد أو البساط.**
اضغط على الدواسة لرفع الفرشاة لأعلى.

❷ فتحة الشفط لحماية الجهاز (حسب الطراز)

يمكنكم تنفيذ عمل الشفط في أي مكان مثل الركن أو الشقوق بفضل تحسين فتحة الشفط.

كيفية الاستعمال تشغيل المكنسة الكهربائية

❶ كيفية التشغيل

- عند اطفاء المكنسة الكهربائية واخراج القابس، ضغط زر بكرة السلك لارجاع السلك الكهربائي .
- يمكنكم تخزين المكنسة الكهربائية بشكل عمودي بنقل خطاف الفوهة الى الفتحة تحت المكنسة الكهربائية .

❷ وضع الوقوف

- الوقوف لنقل الأثاث الصغيرة أو البساط أثناء عمل الشفط، استعمال وضع الوقوف لدعم الخركوم المرن والفوهة .

– نقل خطاف الفوهة الى الفتحة في جانب المكنسة الكهربائية .

❸ وضع التخزين

- سحب السلك الكهربائي حتى الطول المطلوب وادخاله الى المقبس .
- وضع مقبض التحكم لمقبض الخرطوم في المكان المطلوب .
- نقل مقبض التحكم الى مكان "الاطفاء" .
- ضغط زر بكرة السلك لارجاع السلك الكهربائي بعد الاستعمال.

❸ توصيل الخرطوم الى المكنسة الكهربائية

- دفع أنبوب التركيب للخرطوم المرن الى نطقة الالحاق في المكنسة الكهربائية .
- ضغط الزر الموجود في أنبوب التركيب، ثم سحبه الى خارج المكنسة الكهربائية من أجل اخراج الخرطوم المرن من المكنسة الكهربائية .

كيفية الاستعمال تركيب المكنسة الكهربائية

❶ فوهة السجاد والأرض

دفع الفوهة الى الأنبوب المتراكب.

❷ الأنبوب المتراكب

- دفع الأنبوب المتراكب الى مقبض الخرطوم بشكل ثابت .
- قبض ماسورة الربط للتمديد .
- سحب الأنبوب الى الطول المطلوب .

تعليمات هامة للسلامة

⚠ تنبيه

- **لا تضع أي أغراض في الفتحات**

حيث يمكن أن يؤدي عدم القيام بذلك إلى تلف المنتج .

- **لا تستخدم المكنسة في حالة انسداد الفتحات: احفظ الفتحات بعيدا عن الأتربة أو النسالة أو الشعر أو أي شيء قد يقلل تيار الهواء .**

حيث يمكن أن يتسبب ذلك في تلف المنتج .

- **لا تستخدم المكنسة بدون صندوق الأتربة و/أو المرشحات مثبتة في أماكنها.**

حيث يمكن أن يؤدي عدم القيام بذلك إلى تلف المنتج .

- **لا تستخدم المكنسة في تنظيف الأشياء الحادة والصلبة مثل الدبابيس، أو الحجارة، أو الألعاب الصغيرة، إلخ .**

فقد تتلف هذه الأشياء المكنسة أو صندوق الأتربة .

- **تخزين المكنسة الكهربية داخل المنزل .**

أحفظ المكنسة بعيدا بعد الاستخدام لمنع لتجنب التعثر فيها .

- **المكنسة غير معدة للاستخدام من قبل الأطفال أو الافراد ذوي الاحتياجات الخاصة بدون رقابة .**

حيث يمكن أن يؤدي عدم القيام بذلك إلى الإصابة الجسدية أو تلف المنتج .

- **استخدم قطع الغيار المنتجة أو الموصى بها من قبل وكلاء خدمة شركة .نذضفقمهذزعظغم**

حيث يمكن أن يؤدي عدم القيام بذلك إلى تلف المنتج .

- **استخدم المكنسة الكهربية كما هو موصوف في هذا الدليل فقط استخدمها فقط مع الملحقات أو المرفقات الموصى بها أو المعتمدة من .غم**

حيث يمكن أن يؤدي عدم القيام بذلك إلى الإصابة الجسدية أو تلف المنتج .

- **لتجنب الإصابة الجسدية أو لمنع الجهاز من الصندوق عند تنظيف السلالم، ضع المكنسة دائما أسفل السلالم .**

حيث يمكن أن يؤدي عدم القيام بذلك إلى الإصابة الجسدية أو تلف المنتج .

- **استخدم الفوهات المرفقة في وضع الأريكة**

حيث يمكن أن يتسبب ذلك في تلف المنتج .

- **لا تجفف المرشح في فرن أو ميكروويف .**

حيث يمكن أن يؤدي عدم القيام بذلك إلى خطر الحريق .

- **لا تجفف المرشح في مجفف الملابس .**

حيث يمكن أن يؤدي عدم القيام بذلك إلى خطر الحريق .

- **لا تجفف المكنسة بالقرب من مصدر لهب مفتوح .**

حيث يمكن أن يؤدي عدم القيام بذلك إلى خطر الحريق .

- **قم بتنظيف المكنسة دائما بعد تنظيف السجاد والمنظفات والمنعشات والمساحيق والأتربة الدقيقة .**

فهذه الأشياء تسد المرشحات وتقلل تيار الهواء ويمكنها أن تتلف المكنسة قد يؤدي عدم تنظيف صندوق الأتربة إلى تلف دائم للمكنسة. (حسب الطراز)

- **لا تمسك الصندوق من المقبض أثناء تحريك المكنسة .**

فقد يسقط جسم المكنسة عند فصل الصندوق عن المقبض حيث يمكن أن يؤدي ذلك إصابة جسدية أو إلى تلف المنتج **يجب أن تمسك من مقبض الحمل عند تحريك**

(حسب الطراز)

- **إذا أضاء مصباح المؤشر بعد إفراغ صندوق الأتربة باللون (الأحمر)، فقم بتنظيف صندوق الأتربة .**

حيث يمكن أن يؤدي عدم القيام بذلك إلى تلف المنتج

(حسب الطراز)

الواقي الحراري:

يوجد بهذه المكنسة ترموستات يحميها في حالة ارتفاع درجة حرارة المحرك. في حالة توقف المكنسة الكهربية فجأةً، فأغلق المفتاح وافصلها عن التيار الكهربي. افحص المكنسة الكهربية للتأكد من عدم وجود مصدر لارتفاع الحرارة مثل امتلاء غرفة الأتربة أو انسداد خرطوم أو انسداد مرشح. في حالة وجود أي من هذه الحالات، قم بإصلاحها أو انتظر لمدة ٣٠ دقيقة على الأقل قبل محاولة استخدام المكنسة الكهربية. وبعد مرور ٣٠ دقيقة، قم بتوصيل المكنسة الكهربية بالتيار الكهربي وأدر المفتاح .

تعليمات هامة للسلامة

الرجاء قراءة جميع التعليمات قبل استخدام المكنسة الكهربية لمنع خطر حدوث حريق، أو صدمة كهربية، أو إصابة للأشخاص، أو تلف عند استخدم المكنسة الكهربية، لا يشمل هذا الدليل كل الظروف المحتملة التي قد تحدث . اتصل دائما بفني الخدمة أو المصنع في حالة وجود أية مشكلات لا تفهمها يتوافق هذا الجهاز مع قوانين الاتحاد الأوروبي: – EEC/23/73 ، وقانون الفولت المنخفض 89/336/CEE - وقانون EMC.

هذا هو رمز تنبيه للسلامة .
ينبهك هذا الرمز ضد المخاطر المحتملة التي يمكن أن تقتلك أو تؤذيك أنت أو الآخرين .
تنبيه للسالمة وتعني كلمة زتحذيرس أو" WARNING " حق تلي كل رسائل السلامة كل رمز " CAUTION" سزتنبيهس تعني هذه الكلمات ما يلي:

تحذير ينبهك هذا الرمز إلى المخاطر أو الممارسات غير الآمنة والتي قد تؤدي إلى إصابة جسدية خطيرة أو الوفاة.

تنبيه ينبهك هذا الرمز إلى المخاطر أو الممارسات غير الآمنة والتي قد تؤدي إلى إصابة جسدية أو تلف الممتلكات.

تحذير

- **افصل مصدر التيار الكهربي قبل صيانة الوحدة أو تنظيفها أو عند عدم استخدام المكنسة .**
  قد يؤدي عدم القيام بذلك إلى الصدمة الكهربية أو الإصابة الجسدية .
- **لا تستخدم المكنسة في تنظيف أشياء حارقة أو مصدر للأدخنة، مثل السجائر أو الرماد الساخن .**
  حيث يمكن أن يؤدي ذلك إلى الوفاة أو الحريق أو الصدمة الكهربية .
- **لا تقم بتنظيف المواد القابلة للاشتعال أو الانفجار مثل الجازولين أو البنزين أو مخفف الطلاء أو البروبان (سوائل أو غازات) .**
  حيث يمكن للدخان الذي ينبعث من هذه السوائل أن يتسبب في خطر الحريق أو الانفجار حيث يمكن أن يؤدي ذلك إلى الوفاة أو الإصابة الجسدية
- **لا تمسك القابس أو المكنسة بأيدي مبللة .**
  حيث يمكن أن يؤدي ذلك إلى تلف المنتج أو الصدمة
- **لا تفصل التيار الكهربي بجذب السلك .**
  حيث يمكن أن يؤدي ذلك إلى تلف المنتج أو الصدمة الكهربية لفصل التيار عن المكنسة، امسك بالقابس، وليس السلك .
- **احتفظ بالشعر، والملابس الفضفاضة، والأصابع، وكل أجزاء الجسم بعيداً عن الفتحات والأجزاء المتحركة الأخرى .**
  قد يؤدي عدم القيام بذلك إلى الصدمة الكهربية أو الإصابة الجسدية .
- **لا تسحب المكنسة من سلك التيار أو تحملها منه، ولا تستخدم سلك التيار كمقبض، ولا تغلق الباب على سلك التيار، أو تلف سلك التيار حول أطراف حادة لا تسحب المكنسة الكهربية على سلك التيار احتفظ بسلك التيار بعيداً عن الأسطح الساخنة.**
  قد يؤدي عدم القيام بذلك إلى الصدمة الكهربية أو الإصابة الجسدية أو الحريق أو تلف المنتج .
- **لا تستخدم المكنسة الكهربية كلعبة . يجب الانتباه الشديد عند استخدام المكنسة أو عندما تكون قريبه من الأطفال حيث يمكن** أن يتسبب ذلك في الإصابة الجسدية أو تلف المنتج .
- **لا تستخدم الجهاز إذا كان سلك التيار الكهربي تالفًا أو معيبا**
  حيث يمكن أن يتسبب ذلك في الإصابة الجسدية أو تلف المنتج .في هذه الحالة اتصل بوكيل خدمة شركة نذضفقهذزعظغم لتجنب المخاطر.
- **لا تستخدم المكنسة الكهربية إذا كانت مغمورة بالمياه .**
  حيث يمكن أن يتسبب ذلك في الإصابة الجسدية أو تلف المنتج في هذه الحالة اتصل بوكيل خدمة شركة Electronics LG لتجنب المخاطر.
- **لا تستمر في التنظيف بالمكنسة الكهربية إذا بدا لك أن أية أجزاء مفقودة أو تالفة .**
  حيث يمكن أن يتسبب ذلك في الإصابة الجسدية أو تلف المنتج في هذه الحالة اتصل بوكيل خدمة شركة LG Electronics لتجنب المخاطر .
- **لا تستخدم سلك التمديد مع هذه المكنسة الكهربية**
  حيث يمكن أن يتسبب ذلك في خطر الحريق أو تلف المنتج .
- **أستخدام الفولتية الصحيحة**
  قد يؤدي استخدام فولتية غير صحيحة إلى تلف المحرك أو إصابة المستخدم الفولتية السليمة مطبوعة أسفل المكنسة الكهربية .
- **أوقف تشغيل كل مفاتيح التحكم في المكنسة قبل فصلها عن التيار**
  قد يؤدي عدم القيام بذلك إلى الصدمة الكهربية أو الإصابة الجسدية .
- **لا تستبدل القابس بأي شكل من الأشكال**
  قد يؤدي عدم القيام بذلك إلى الصدمة الكهربية أو الإصابة الجسدية أو تلف المنتج قد يؤدي القيام بذلك إلى الوفاة إذا لم يكن القابس مناسبا، فاتصل بكهربائي مختص لتركيب المنفذ الصحيح .
- **يجب فقط القيام بإصلاح الأجهزة الكهربية من قبل مهندسي صيانة متخصصين .**
  قد تؤدي الإصلاحات غير السليمة إلى مخاطر جسيمة للمستخدم.
- **لا تقم بتوصيل التيار الكهربي إذا لم يكن المقبض على الوضع OFF (إيقاف التشغيل) .**
  حيث يمكن أن يتسبب ذلك في الإصابة الجسدية أو تلف المنتج (حسب الطراز)
- **ابق الأطفال بعيدا ولاحظ العوائق عند لف السلك لمنع الإصابة الجسدية .**
  يتحرك السلك بسرعة أثناء اللف . (حسب الطراز)
- **يحتوي الخرطوم على أسلاك كهربية لا تستخدمه إذا كان تالفا أو مقطوعا أو مثقوبا**
  حيث يمكن أن يؤدي عدم القيام بذلك إلى الوفاة أو الصدمة الكهربية (حسب الطراز)

محتويات الجدول

تعليمات السلامة الهامة ..... 4~5

كيفية الاستعمال 6

تركيب المكنسة الكهربائية 6

تشغيل المكنسة الكهربائية 8

استعمال فوهة السجاد والأرض 9

دليل الاستعمال للفوهة الطربينية 10

استعمال الفوهات المساعدة 11

تفريغ علبة الغبار 12

تنظيف علبة الغبار 13

دليل لاستعمال سائي لكمة 14

تنظيف فلتر الهواء وفلتر سلامة المحركات 15

تنظيف فلتر العادم 16

ماذا تعمل اذا لم تشتغل المكنسة الكهربائية؟ 17

ماذا تعمل اذا تم تخفيض قوة الشفط؟ 17

LG
Life's Good

دليل الاستعمال

نوع جديد للمكنسة الكهربائية الاعصارية

هذه المعلومات تحتوى تعليمات هامة لسلامة استعمال وصيانة المكنسة الكهربائية .
وخاصة يرجى قراءة جميع المعلومات في الصفحة 4 و 5 من أجل سلامتكم .
ويرجى احتفاظ هذا الدليل في مكان سهل الوصول ومراجعته في أي وقت .

VC68**H**

www.lg.com

P/No.:MFL57903867