LG

عربي

ENGLISH

PRINTED WITH SOY INK

CE 0168

www.lgmobile.com

P/N : MMBB0338602 (1.1) G

GD900 دليل مستخدم

GD900 دليل مستخدم

LG ELECTRONICS INC.

ENGLISH

عربي

LG

PRINTED WITH SOY INK

CE 0168

www.lgmobile.com

GD900 User Guide

P/N : MMBB0338602 (1.1) G

Bluetooth QD ID B015268

LG

قد تختلف بعض المحتويات الموجودة في هذا الدليل عن هاتفك وذلك استناداً إلى برنامج الهاتف أو موفر الخدمة.

دليل مستخدم GD900

تهانينا لشرائك هاتف GD900 المتقدم والصغير الحجم من LG، والمصمّم للعمل مع التكنولوجيا الرقمية الأحدث لاتصالات الهواتف المحمولة.

المحتويات

الإعداد

التعرّف على الهاتف الخاص بك 8
نظرة على الهاتف وهو مفتوح 10
تثبيت بطاقة SIM و البطارية 11
شحن الهاتف 13
بطاقة الذاكرة 14
خريطة القوائم 16

الشاشة الرئيسية الخاصة بك

تلميحات شاشة اللمس 17
تخصيص الشاشة الرئيسية 18
تواصل مع الهاتف GD900 الخاص بك 19
مفاتيح سريعة 20
شاشة اللمس 21
عرض شريط الحالة 26
استخدام وظيفة تعدد المهام 28

الأساسيات

المكالمات 29
إجراء مكالمة أو مكالمة فيديو 29
الاتصال من قائمة الأسماء 29
الرد على مكالمة ورفضها 29
خيارات أثناء المكالمة 30
ضبط مستوى صوت المكالمة 31
الاتصال السريع 31
إجراء مكالمة ثانية 31
إيقاف تشغيل DTMF 32
عرض سجلات المكالمات 32
استخدام تحويل المكالمات 33
استخدام حظر المكالمات 33
تغيير ضبط المكالمات العام 34
تغيير إعدادات مكالمة الفيديو 34
الأسماء 35
البحث عن جهة اتصال 35
إضافة جهة اتصال جديدة 35
إنشاء مجموعة 36
تغيير إعدادات الأسماء 36
عرض المعلومات 37
الرسائل 38
الرسائل 38
إرسال رسالة 38
إدخال النص 39
T9 تنبؤي 39
دليل Abc 39
إعداد البريد الإلكتروني 39
إرسال بريد إلكتروني باستخدام حسابك الجديد 40
تغيير إعدادات البريد الإلكتروني 40
حافظات الرسائل 41
استخدام النماذج 42
استخدام الرموز التعبيرية 42
تغيير إعدادات الرسائل النصية 42
تغيير إعدادات رسائل الوسائط المتعددة 43
تغيير ضبط الأخرى 44

الكاميرا

الكاميرا 45
التعرّف على محدد المنظر 45
التقاط صورة سريعة 46
بمجرد التقاط الصورة 47
استخدام الفلاش 48
ضبط التباين 48
ضبط حجم الصورة 48
التقاط لقطة متواصلة 49
استخدام الإعدادات المتقدمة 49
تغيير حجم الصورة 51
اختيار تأثير اللون 52
استخدام الكاميرا الداخلية 52
عرض الصور المحفوظة 53
كاميرا فيديو 54
التعرّف على محدد المنظر 54
التقاط فيديو سريع 55
بعد التقاط فيديو 55
ضبط التباين 56
استخدام الإعدادات المتقدمة 56
تغيير حجم صورة الفيديو 58
اختيار درجة اللون 59
استخدام كاميرا الفيديو الداخلية 59
مشاهدة مقاطع الفيديو المحفوظة 60
مشاهدة مقاطع الفيديو على التلفزيون 60
الصور و مقاطع الفيديو 61
عرض الصور ومقاطع الفيديو 61
استخدام التكبير/التصغير عند مشاهدة فيديو أو صورة 61
ضبط مستوى الصوت عند عرض فيديو 61
تعيين صورة كخلفية الشاشة 61
تعديل الصور 62
إضافة نص إلى صورة 63
إضافة تأثير إلى صورة 64
اقتصاص صورة 64
إضافة تدرج لون إلى صورة 64
مبادلة الألوان في صورة 65
تعديل مقاطع الفيديو 65
تشذيب طول الفيديو 65
دمج مقطعَي فيديو معاً 66
دمج صورة بفيديو 66
إضافة نص إلى فيديو 67
تراكب صورة 68
إضافة مسار صوتي إلى الفيديو 68
إضافة مؤثرات صوتية حية إلى الفيديو 69
تغيير سرعة الفيديو 69
إضافة تأثير التعتيم 69
الوسائط المتعددة 70
صور 70

المحتويات

قوائم خيارات صوري.....70
إرسال صورة.....70
استخدام صورة.....71
طباعة صورة.....71
نقل صورة أو نسخها.....72
إنشاء عرض شرائح.....72
التحقق من حالة الذاكرة.....72
أصوات.....73
استخدام صوت.....73
مقاطع فيديو.....73
إرسال ملف فيديو.....74
ألعاب وتطبيقات.....74
تشغيل لعبة.....74
استخدام قائمة الخيارات.....74
جار تثبيت لعبة Java وتطبيقها.....74
استخدام قائمة M-Toy.....75
محتويات الفلاش.....75
عرض ملف SWF/ SVG.....75
مستندات.....75
عرض ملف.....75
نقل ملف إلى هاتفك.....75
أخرى.....76
إنشاء فيلم.....76
الموسيقى.....77
نقل الموسيقى إلى الهاتف.....77
تشغيل أغنية.....78
إنشاء قائمة تشغيل.....78
حذف قائمة تشغيل.....79
استخدام الراديو.....79
البحث عن محطات.....79
إعادة تعيين القنوات.....80
الاستماع إلى الراديو.....80

كن منظمًا

المنسّق.....81
إضافة حدث إلى التقويم.....81
تغيير عرض التقويم الافتراضي.....81
إضافة عنصر إلى قائمة المهام.....82
استخدام الباحث عن التاريخ.....82
تعيين المنبّه.....83
إضافة مذكرة.....83
مسجّل الصوت.....84
تسجيل ملف صوتي أو صوت.....84
إرسال التسجيل الصوتي.....84
استخدام الحاسبة.....85
تحويل وحدة.....85
استخدام ساعة إيقاف.....85
إضافة مدينة إلى ساعتك العالمية.....86
PC Suite.....87
تثبيت برنامج LG PC Suite على الكمبيوتر 87
توصيل الهاتف والكمبيوتر.....88
إجراء نسخ احتياطي لمعلومات الهاتف
واستعادتها.....88

عرض ملفات الهاتف على الكمبيوتر.....88
مزامنة الأسماء.....89
مزامنة الرسائل.....89
تزامن الموسيقى.....89
نقل الموسيقى باستخدام Windows Media Player.....90
استخدام iSync.....91
DivX Converter.....91

ويب

المتصفح.....93
الوصول إلى ويب.....93
إضافة إشارات مرجعية والوصول إليها.....93
استخدام قارئ RSS.....94
الوصول إلى صفحة محفوظة.....94
عرض محفوظات المتصفح.....94
تغيير إعدادات متصفح ويب.....95
استخدام الهاتف كمودم.....95
وصول إلى خرائط Google.....96

الإعدادات

تغيير إعدادات الشاشة.....97
تخصيص الأوضاع.....97
تغيير إعدادات الهاتف.....98
تغيير إعدادات اللمس.....99
تغيير إعدادات التوصيل.....99
استخدام معلومات الذاكرة.....100
استخدام وضع الرحلات الجوية.....101
إرسال الملفات واستلامها باستخدام بلوتوث.....101
تغيير إعدادات بلوتوث.....102
الاقتران بجهاز بلوتوث آخر.....103
استخدام سماعة رأس بلوتوث.....103
WiFi.....104
تحديث البرنامج.....106

الملحقات.....107

خدمة الشبكة.....108

بيانات تقنية.....108

التوجيهات

توجيهات لاستخدام آمن و فعال.....110
استكشاف الأخطاء وإصلاحها.....116

التعرّف على الهاتف الخاص بك

مفتاح الطاقة

تشغيل/إيقاف الهاتف.

سماعة الأذن

جهاز استشعار الأشياء القريبة

كاميرا داخلية

مفتاح الإنهاء

- رفض مكالمة.
- اضغط مرة واحدة للعودة إلى الشاشة الرئيسية.

مفتاح تعدد المهام

مفتاح الارسال

طلب رقم هاتف والإجابة على مكالمات واردة.

زر تحرير البطارية

⚠ **تحذير:** قد يؤدي وضع شيء ثقيل الوزن على الهاتف أو الجلوس عليه إلى إلحاق ضرر بوظيفة شاشة LCD وشاشة اللمس. لا تغطي فيلم الحماية جهاز استشعار الأشياء القريبة الخاص بشاشة LCD. فقد يتسبب الأمر بعدم عمل جهاز الاستشعار بشكل صحيح.

شاحن، كبل البيانات (كبل USB)

تلميح: قبل توصيل كبل USB، انتظر حتى يتم تشغيل الهاتف وتسجيله في الشبكة.

مفاتيح مستوى الصوت

- **عندما تكون الشاشة في وضع الإنتظار:** مستوى صوت نغمة المفاتيح.
- **أثناء مكالمة:** مستوى صوت سماعة الأذن.
- **عند تشغيل مسار:** تحكم بمستوى الصوت باستمرار.

مفتاح الكاميرا

- انتقل مباشرةً إلى قائمة الكاميرا عبر الضغط باستمرار على المفتاح.

نظرة على الهاتف وهو مفتوح

تثبيت بطاقة SIM و البطارية

1 نزع غطاء البطارية

استخدم الصورة المصغّرة لفتح زر تحرير البطارية في أسفل الهاتف وأنزع الغطاء عنها.

2 إزالة البطارية

امسك بالحافة العليا للبطارية وارفعها لإخراجها من حجرتها.

⚠ **تحذير:** لا تقم بإزالة البطارية عندما يكون الهاتف قيد التشغيل، إذ قد يؤدي ذلك إلى إلحاق الضرر بالهاتف.

3 تثبيت بطاقة SIM

أدخِل بطاقة SIM داخل حامل بطاقة SIM. تأكد من كون ناحية الملامسات الذهبية الموجودة على البطاقة موجهة نحو الأسفل. لإزالة بطاقة SIM، لإزالة بطاقة SIM، ادفعها بلطف حتى تسمع طقطقة.. وأخرجها برفق.

تثبيت بطاقة SIM و البطارية

4 تثبيت البطارية

قم أولاً بإدراج الجهة العليا للبطارية في الحافة العليا لحجرة البطارية. تأكد من محاذاة ملامسات البطارية مع أطراف توصيل الهاتف. اضغط جهة البطارية السفلى إلى الأسفل حتى تستقر في مكانها.

شحن الهاتف

حرّك إلى الخلف غطاء موصل الشاحن الموجود على جانب الهاتف GD900. قم بإدراج الشاحن وبتوصيله بمقبس كهربائي رئيسي. يجب شحن الهاتف GD900 حتى تظهر الرسالة "البطارية ممتلئة" على الشاشة.

ملاحظة: يجب أن تكون البطارية مشحونةً بالكامل في البداية لتحسين فترة عمل البطارية. تجاهل الرسالة "البطارية ممتلئة" الأولى، وتابع شحن الهاتف طوال الليل (أو لمدة تصل حتى 14 ساعة).

بطاقة الذاكرة

تثبيت بطاقة الذاكرة

يمكنك توسيع مساحة الذاكرة المتوفرة على هاتفك باستخدام بطاقة ذاكرة.

ملاحظة: بطاقة الذاكرة هي عبارة عن ملحق اختياري.

أدخِل بطاقة الذاكرة داخل الفتحة الموجودة في الأعلى، حتى تستقر في مكانها. تأكد من كون ناحية الملامسات الذهبية موجهة نحو الأسفل.

⚠ **تحذير:** أدخل بطاقة الذاكرة داخل الفتحة، وإلا يمكن إلحاق الضرر بالبطاقة.

تهيئة بطاقة الذاكرة

قد تكون بطاقة الذاكرة مهيأةً أصلاً. إذا لم تكن مهيأةً، ستحتاج إلى تهيئتها قبل البدء باستخدامها.

ملاحظة: يتم حذف كل الملفات أثناء التهيئة.

1 في الشاشة الرئيسية حدد واختر **إعدادات الهاتف** في علامة تبويب الاعدادات.

2 قم بالتمرير والمس **معلومات الذاكرة** ثم قم بالتمرير وحدد **ذاكرة خارجية**.

3 المس **تهيئة** ثم أكد خيارك.

4 أدخل كلمة المرور، إذا كان قد تم تعيين واحدة. ستتم تهيئة البطاقة وتصبح جاهزةً للاستخدام.

ملاحظة: إذا تضمنت بطاقة الذاكرة محتوى موجود، فقد تختلف بنية الحافظة بعد التهيئة بما أنّه تمّ حذف كل الملفات.

نقل الأسماء

لنقل الأسماء من بطاقة SIM إلى هاتفك:

1 في علامة التبويب اتصال، قم بالتمرير إلى **الاسماء** وحدد ثم **تغيير الموقع**.

2 المس **نسخ إلى الهاتف**.

3 اختر **تحديد الكل** أو حدد الأسماء الواحد تلو الآخر والمس **نسخ إلى الهاتف**.

خريطة القوائم

المس على الشاشة الرئيسية لفتح **القائمة العلوية**. من هنا يمكنك الوصول إلى المزيد من القوائم من خلال التمرير عبر الرموز: اتصال، ووسائط متعددة، وأدوات مساعدة واعدادات

اتصال

- الأسماء
- السجلات
- المتصفح
- الرسائل
- بريد إلكتروني
- اتصال
- مكالمة فيديو
- Google

الوسائط المتعددة

- الموسيقى
- الكاميرا
- كاميرا فيديو
- الاستوديو
- أشيائي
- ألعاب وتطبيقات
- راديو FM
- صانع أفلام

أدوات مساعدة

- تنبيهات
- المنسّق
- مذكرة
- ساعة إيقاف
- مسجّل الصوت
- الحاسبة
- الساعة العالمية
- الأدوات

الاعدادات

- الأوضاع
- اعدادات الشاشة
- إعدادات الهاتف
- بلوتوث
- WiFi
- إعدادات المكالمة
- التوصيل
- إعدادات الرسائل

الشاشة الرئيسية الخاصة بك

من هذه الشاشة يمكنك الوصول إلى خيارات القوائم، وإجراء مكالمة، وعرض حالة الهاتف، بالإضافة إلى عدة أمور أخرى.

تلميحات شاشة اللمس

تعتبر الشاشة الرئيسية أيضاً مكاناً جيداً لتعتاد على استخدام شاشة اللمس.

لتحديد عنصر، المس وسط الرمز.

- لا تضغط بقوة، فشاشة اللمس حساسة بشكل كافٍ يتيح لها التعرّف على لمسة خفيفة ولكن ثابتة.
- استخدم رأس إصبعك للمس الخيار المطلوب. احترس من عدم لمس أي مفاتيح أخرى.
- عندما يكون ضوء الشاشة متوقفاً عن التشغيل، قم إمّا بالضغط على مفتاح الطاقة أو بالضغط باستمرار على مفتاح الإقفال/الفتح على شاشة اللمس للعودة إلى الشاشة الرئيسية.
- عندما لا يكون الهاتف GD900 قيد الاستخدام، يعود إلى الشاشة المقفلة.

الشاشة الرئيسية الخاصة بك

تخصيص الشاشة الرئيسية

1 اختصارات الشاشة الرئيسية

2 عنصر واجهة استخدام الشاشة الرئيسية (نشط)

3 الشاشة الرئيسية للاسماء

4 الشاشة الرئيسية للوسائط المتعددة

- **تخصيص الشاشة الرئيسية** - لكل نوع من أنواع الشاشة الرئيسية، يمكنك إضافة كائنات أو إزالتها من خلال الضغط باستمرار على الشاشة، أو من خلال الضغط باستمرار على الكائنات إذا تمت إضافة هذه الأخيرة مسبقاً.

تواصل مع الهاتف GD900 الخاص بك

تستند واجهة المستخدم إلى أربعة أنواع من الشاشات الرئيسية. للتبديل بين الشاشات الرئيسية، ما عليك إلا تمرير إصبعك بسرعة فوق عرض من اليسار إلى اليمين أو من اليمين إلى اليسار.

ملاحظة: تنقّل بواسطة النقر من دون مقاطعة منطقة العرض.

الشاشة الرئيسية الخاصة بك

مفاتيح سريعة

توفر المفاتيح السريعة الموجودة على الشاشة الرئيسية وصولاً سهلاً بمجرد لمسة واحدة إلى أكثر الوظائف استخداماً.

المس لإحضار لوحة الطلب بواسطة اللمس، التي تمكّنك من إجراء مكالمة. أدخِل الرقم باستخدام لوحة المفاتيح العادية والمس **مكالمة صوتية** أو اضغط على .

لاجراء مكالمة فيديو لهذا الرقم,المس خيار مكالمة فيديو بعد ادخال الرقم.

المس لفتح الأسماء. للبحث عن الرقم الذي تريد الاتصال به: أدخِل اسم جهة الاتصال مستخدماً لوحة اللمس. كما يمكنك إنشاء الأسماء جديدة وتعديل الاسماء الموجودة.

المس للوصول إلى قائمة **الرسائل**. من هنا يمكنك إنشاء رسائل نصية جديدة.

المس لفتح القائمة العلوية الكاملة التي تنقسم إلى أربع فئات.

شاشة اللمس

تتغير عناصر التحكم الموجودة على شاشة لمس الهاتف GD900 بشكل مستمر بحسب المهمة التي تجريها.

فتح التطبيقات

لفتح أي تطبيق، ما عليك إلا لمس الرمز الخاص به.

التمرير

قم بالسحب من جهة إلى جهة للتمرير. كما يمكنك التمرير إلى أعلى أو أسفل على بعض الشاشات، مثل صفحات ويب.

الشاشة الرئيسية الخاصة بك

التكبير أو التصغير

عند عرض صور، أو صفحات ويب، أو رسائل بريد إلكتروني، أو خرائط، يمكنك التكبير والتصغير. وذلك عبر جمع إصبعيك معاً أو إبعادهما عن بعضهما.

لوحة لمس شفّافة

استفد إلى الحد الأقصى من لوحة اللمس الشفّافة.

1 اختصار لوحة اللمس : بإمكانك تعيين رمز للقوائم الأكثر استخداماً.
قم بتعيين رمز لكل اختصار، لكي تتمكن من الوصول فوراً إلى الوظائف المفضلة بنقرة إصبع بسيطة.

مثلاً، إذا قمت برسم على شاشة اللمس الشفافة، ستنتقل فوراً إلى البريد الإلكتروني.

2 الضغط السهل : يمكنك النقر فوق شاشة اللمس الشفافة من دون اخفاء الشاشة الرئيسية أثناء استخدام مستعرض الويب.

[تصفح باستخدام مؤشر الفأره]

3 كرة اللمس : قم بضبط مستوى الصوت أو السطوع عبر رسم ↶ و ↷ على لوحة اللمس الشفّافة في الموسيقى وتشغيل Divx والكاميرا وكاميرا الفيديو. كما يمكنك تكبير الصورة وتصغيرها عبر رسم ↶ أو ↷ على لوحة اللمس الشفّافة في وضع الكاميرا، ووضع كاميرا الفيديو.

[تكبير/تصغير]

4 الكتابة اليدوية : استخدم إصبعك لكتابة معلومات حول شاشة اللمس الشفافة، من دون إخفاء الشاشة الرئيسية.

لاستخدام نظام الكتابه اليدوية،ببساطه اكتب على شاشة جهازك وسوف تتحول كتابتك اليدوية الى رسالة.اذا اخترت نظام الاحرف الكبيره (ABC), سيتم ادخال الاحرف على اساس انها كبيرة حتى لو كتبت بنظام الاحرف الصغيرة والعكس صحيح. المس ▲ والمس . يمكنك أن تكتب على الشاشة بإصبعك.

الحرف	سلسلة الحركات
A	
B	
C	
D	
E	
F	
G	
H	
I	
J	
K	
L	
M	
N	
O	
P	
Q	
R	
S	

الحرف	سلسلة الحركات
T	
U	
V	
W	
X	
Y	
Z	
ß	

الاحرف الرمزيه

الرمز	سلسلة الحركات
مسافة	
زر اعادة الكتابة	
ادخال	

علامات الترقيم

علامة الترقيم	سلسلة الحركات
•	•
@	@

ملاحظة: ابدأ كل حركة بنقطة

الارقام

الارقام	سلسلة الحركات
0	
1	
2	
3	
4	
5	
6	
7	
8	
9	

5 لوحة اللمس العادية : من الممكن استخدام لوحة اللمس الشفافة لإدخال الأرقام والنصوص بطريقة سهلة.

6 المفضلة : اعرض جهات الاتصال والأغاني والصور المفضلة لديك على الشاشة بواسطة لمس ★ .

ملاحظة لوحة اللمس الشفّافة مصنوعة من الزجاج المقاوم.

عرض شريط الحالة

يستخدم شريط الحالة رموزاً مختلفةً لعرض بعض الظروف شأن قوة الإشارة، والرسائل الجديدة، وفترة عمل البطارية بالإضافة إلى إعلامك ما إذا كان كل من بلوتوث أو اتصالات البيانات نشطاً.

يفسر الجدول التالي معنى الرموز التي من المحتمل أن تشاهدها على شريط الحالة.

الرمز	الوصف
	لا توجد خدمة
	2G
	3G
	EDGE
	HSDPA
	WiFi قيد التشغيل
	سماعة رأس استيريو أحادية لجهاز بلوتوث
	سماعة رأس استيريو بلوتوث

الرمز	الوصف
	سماعة رأس أحادية بلوتوث
	تشغيل بلوتوث
	النقل باستخدام بلوتوث
	إمكانية رؤية بلوتوث
	جار التنزيل
	اكتمال التنزيل.
	تم إلغاء التنزيل.
	خيار أثناء المكالمة
	إنترنت
	جار البحث
	تحويل المكالمات
	رفض المكالمة
	الحماية
	سماعة الرأس
	منطقة محلية
	التجوال
	المنبه
	جدول (التقويم)
	متعدد المهام

الرمز	الوصف
	إيقاف الموسيقى مؤقتاً
	تشغيل الموسيقى
	تشغيل راديو FM
	تم إرسال بريد إلكتروني
	تم استلام بريد إلكتروني
	رسالة وسائط متعددة
	إرسال وسائط متعددة
	تم استلام وسائط متعددة
	إرسال رسالة نصية
	بريد صوتي جديد
	رسالة جديدة
	فشل إرسال الرسالة
	بريد إلكتروني جديد
	رسالة Push
	وضع الرحلات الجوية
	في الخارج
	صامت
	نغمات الرنين المخصصة 10-1
	الذاكرة الخارجية

الشاشة الرئيسية الخاصة بك

الرمز	الوصف
	حالة البطارية
	إخراج البروجيكتور/التلفزيون

استخدام وظيفة تعدد المهام

المس مفتاح المشغّل الخاص بتعدد المهام لفتح **قائمة** تعدد المهام. يمكنك من هنا عرض بعض التطبيقات جار تشغيلها والوصول إليها بواسطة لمسة واحدة.

المكالمات

تلميح! اضغط على مفتاح التشغيل لإقفال شاشة اللمس وذلك لمنع إجراء مكالمات عن طريق الخطأ.

إجراء مكالمة أو مكالمة فيديو

1 المس لفتح لوحة المفاتيح.

2 اكتب الرقم على لوحة المفاتيح. لحذف رقم، اضغط على مفتاح المسح.

3 المس مفتاح لإجراء المكالمة.

4 لإنهاء المكالمة، المس المفتاح .

تلميح! لإدخال + لإجراء مكالمات دولية، المس * مرتين، أو اضغط باستمرار 0+.

تلميح! يمكنك **حفظ رقم**، **أو إرسال رسالة**، **أو البحث في جهات الاتصال** بالضغط على .

الاتصال من قائمة الأسماء

1 في الشاشة الرئيسية المس لفتح **الاسماء**.

2 قم بالتمرير عبر قائمة الأسماء أو أدخِل أوّل حرف (أحرف) من اسم جهة الاتصال التي تريد الاتصال بها وذلك بلمس .

3 من القائمة، المس جهة الاتصال التي تريد الاتصال بها وحدد الرقم الذي تريد استخدامه إذا توفر أكثر من رقم لجهة الاتصال هذه.

4 المس **مكالمة صوتية** أو **مكالمة فيديو**.

الرد على مكالمة ورفضها

عندما يرنّ هاتفك، اضغط على مفتاح المشغّل للإجابة.

المس مرتين مفتاح المشغّل لرفض مكالمة واردة.

خيارات أثناء المكالمة

خيارات - اختر من قائمة خيارات أخرى تتوفر أثناء المكالمة، بما في ذلك إنشاء مذكرة جديدة والذهاب إلى الرسائل، بحيث يمكنك التدقيق في رسائلك وإضافة الأسماء أثناء إجراء المكالمة. كما يمكنك إنهاء المكالمة من هنا وذلك بلمس إنهاء المكالمة.

انتظار - المس لوضع المكالمة قيد الانتظار.

كتم - المس لإيقاف تشغيل الميكروفون بحيث لن يكون باستطاعة الشخص الذي تتكلم معه سماعك.

مكبر الصوت - المس لبدء تشغيل مكبر صوت الهاتف.

الاسماء - بحث في الاسماء أثناء إجراء مكالمة.

مذكرة - إضافة مذكرة أثناء إجراء مكالمة.

لوحة طلب - المس لفتح لوحة مفاتيح رقمية لكتابة أرقام، مثلاً، عند طلب مراكز الاتصال أو خدمات هاتف مؤتمتة أخرى.

ضبط مستوى صوت المكالمة

لضبط مستوى الصوت أثناء مكالمة، استخدم الزرّين إلى الأعلى وإلى الأسفل الموجودين على يمين الهاتف.

الاتصال السريع

يمكنك تعيين جهة اتصال تطلبها بشكل متكرر إلى رقم اتصال سريع.

1 في الشاشة الرئيسية المس لفتح **الاسماء**.

2 المس وحدد **الاتصال السريع**.

3 تم تعيين البريد الصوتي مسبقاً إلى رقم الاتصال السريع 1. ولا يمكنك تغييره. المس أي رقم آخر لتعيينه كجهة اتصال سريع.

4 تفتح قائمة الأسماء. حدد جهة الاتصال التي تريد تعيينها إلى ذلك الرقم وذلك بلمس رقم هاتفها مرة واحدة.

لطلب رقم اتصال سريع، المس على الشاشة الرئيسية ثم اضغط باستمرار على الرقم المعيّن حتى تظهر جهة الاتصال على الشاشة. تبدأ المكالمة تلقائياً، من دون الحاجة إلى لمس **مكالمة صوتية**.

إجراء مكالمة ثانية

1 أثناء المكالمة الأولية، المس لوحة طلب وحدد الرقم الذي تود الاتصال به.

2 اتصل بالرقم أو ابحث في الأسماء.

3 المس لتوصيل المكالمة.

4 يتم عرض المكالمتين معاً على شاشة المكالمة. يتم إقفال المكالمة الأولية ووضعها في حالة الانتظار.

5 لإنهاء إحدى المكالمتين أو كلتاهما اضغط على إنهاء .

ملاحظة: سيُفرض عليك رسم مقابل كل مكالمة تجريها.

إيقاف تشغيل DTMF

يسمح لك DTMF باستخدام الأوامر الرقمية للتنقل ضمن المكالمات المؤتمتة. يكون DTMF قيد التشغيل كإعداد افتراضي.

لإيقاف تشغيل DTMF أثناء مكالمة (لتسجيل ملاحظة حول رقم) المس ☰ ثم حدد **تعطيل DTMF**.

عرض سجلات المكالمات

على الشاشة الرئيسية، المس ⠿، ثم المس **السجلات** في علامة التبويب اتصال.

اختر من ضمن الخيارات التالية:

كل السجلات - عرض قائمة كاملة تتضمّن كل المكالمات الصادرة، والمكالمات المستلمة والمكالمات التي لم يرد عليها، والمكالمات الصوتية فقط، ومكالمات الفيديو والرسائل.

مكالمة لم يرد عليها - عرض قائمة بكل المكالمات التي لم ترد عليها.

مكالمات فقط - عرض قائمة بكل المكالمات التي أجريتها وتلك التي لم ترد عليها.

رسائل فقط - عرض قائمة بكل الأرقام التي استلمت أو أرسلت نصوصاً ورسائل وسائط متعددة.

المرئية فقط- عرض قائمة بكل مكالمات الفيديو.

تلميح! في أي سجل مكالمات المس ☰ و **حذف الكل** لحذف كل العناصر المسجلة.

تلميح! المس أي إدخال لسجل مكالمة واحدة لعرض تاريخ المكالمة، ووقتها، ومدتها.

استخدام تحويل المكالمات

1 المس واختر **إعدادات المكالمة** في علامة تبويب الاعدادات.

2 المس **تحويل المكالمات** وحدد **المكالمات الصوتية** و/أو **مكالمات فيديو**.

3 اختر ما إذا كنت تريد أن يتم تحويل كل المكالمات، عندما يكون الخط مشغولاً، أو عند عدم الرد، أو عندما لا يكون الوصول إليك ممكناً.

4 المس **تنشيط** للتنشيط.

5 أدخل الرقم الذي تريد أن يتم التحويل إليه.

ملاحظة: يؤدي تحويل المكالمات إلى فرض رسوم. يرجى الاتصال بمشغل الشبكة للحصول على تفاصيل.

تلميح! لإيقاف تشغيل كل عمليات تحويل المكالمات، اختر **إلغاء تنشيط الكل** من قائمة **تحويل المكالمات**.

استخدام حظر المكالمات

1 المس واختر **إعدادات المكالمة** في علامة تبويب الاعدادات.

2 المس **حظر المكالمات** وحدد **المكالمات الصوتية** و/أو **مكالمات فيديو**.

3 اختر أحد الخيارات الخمسة أو كلها:

كل المكالمات الصادرة

المكالمات الصادرة الدولية

المكالمات الصادرة الدولية باستثناء الوطن

كل المكالمات الواردة

المكالمات الواردة عند التواجد بالخارج

4 أدخل كلمة مرور حظر المكالمات. يرجى التحقق من توفر هذه الخدمة مع مشغل الشبكة.

تلميح! حدد **رقم اتصال محدد** لتشغيل وتجميع قائمة بالأرقام التي يمكن الاتصال بها من هاتفك. ستحتاج إلى الحصول على رمز PIN2 من مشغل الشبكة. وحدها الأرقام المضمّنة في قائمة الاتصال المحدد هي الأرقام التي يمكن طلبها من هاتفك.

تغيير ضبط المكالمات العام

1 المس واختر **إعدادات المكالمة** في علامة التبويب إعدادات.

2 المس **إعدادات عامة**. يسمح لك ذلك بتغيير ضبط التالية:

رفض المكالمة - مرر المفتاح إلى اليسار لـ **بدء التشغيل**. يمكنك لمس **قائمة الرفض** لاختيار كل المكالمات، أو الأسماء معيّنة أو مجموعات أو المكالمات من أرقام غير مسجلة (أي الأرقام غير الموجودة في الأسماء لديك).

إرسال رقمي - اختر ما إذا أردت أن يظهر رقمك عند إجراء مكالمة صادرة.

اعادة الاتصال اليا - مرر المفتاح إلى اليسار لـ **بدء التشغيل** أو إلى اليمين لـ **إيقاف التشغيل**.

مذكر الدقائق - مرر المفتاح إلى اليسار لـ **بدء التشغيل** لسماع نغمة كل دقيقة خلال فترة المكالمة.

وضع رد بلوتوث - حدد **لايدوي** لتتمكن من الرد على مكالمة باستخدام سماعة رأس بلوتوث، أو حدد **هاتف** للضغط على مفتاح الهاتف للرد على مكالمة.

حفظ الرقم الجديد - حدد **بدء التشغيل** أو **إيقاف التشغيل** لحفظ رقم جديد.

اعدادات اغلاق الشريحة - اختر ما بي انهاء المكالمة و استمرار المكالمة عندما تغلق الشريحة.

تغيير إعدادات مكالمة الفيديو

1 على الشاشة الرئيسية، المس وقم بالتمرير إلى **إعدادات المكالمة** في علامة تبويب الاعدادات.

2 المس **ضوابط مكالمات الفيديو** وحدد ضوابط مكالمات الفيديو. اختر ما إذا كنت تريد استخدام صورة ثابتة، ثم حدد صورةً و/أو قم بتشغيل المرآة لمشاهدة نفسك على الشاشة لدى إجراء مكالمة فيديو.

الأسماء

البحث عن جهة اتصال

هناك طريقتان للبحث عن جهة اتصال:

من الشاشة الرئيسية

1 على الشاشة الرئيسية، المس لفتح **الاسماء**. المس وأدخِل اسم جهة الاتصال مستخدماً لوحة المفاتيح.

2 المس **مكالمة فيديو** أو **مكالمة صوتية** أو مفتاح لإجراء المكالمة.

تلميح! يمكنك البحث حسب المجموعة وذلك بلمس علامة التبويب الأسماء في أعلى الشاشة وتحديد **مجموعات**. ويؤدي هذا الأمر إلى إحضار قائمة بكل المجموعات لديك.

من القائمة الرئيسية

1 المس ، ثم المس **الأسماء** في علامة التبويب اتصال.

2 المس و **بحث**.

إضافة جهة اتصال جديدة

1 على الشاشة الرئيسية، المس وحدد ثم المس زر **اسم جديد**.

2 اختر ما إذا كنت تريد حفظ جهة الاتصال في **الهاتف** أو في **USIM**.

3 إذا أردت إضافة صورة إلى جهة الاتصال الجديدة، المس **إضافة صورة**.

4 أدخل الاسمين الأول والأخير لجهة الاتصال الجديدة. ليس من الضروري إدخال الاسمين، ولكن يجب إدخال أحدهما على الأقل.

5 أدخِل ما يصل إلى خمسة أرقام مختلفة وقم بتعيين نوع لكل منها من ضمن الأنواع التالية **موبايل**،**المنزل**، **والمكتب**، **جهاز المناداة**، **وفاكس**، **والمرئية** وعام.

6 أضِف عنوان بريد إلكتروني.

7 قم بتعيين جهة الاتصال إلى مجموعة أو أكثر، واختر من ضمن بدون مجموعة، العائلة، الاصدقاء، المدرسة، VIP

8 كما يمكنك أيضاً إضافة **نغمة رنين**، **وصفحة رئيسية**، **وعنوان منزل**، **واسم شركة**، **ومهنة**، **وعنوان شركة**، **وعيد ميلاد**، **وذكرى ومذكرة**.

9 المس لحفظ جهة الاتصال.

تلميح! يمكنك إنشاء مجموعات مخصصة الأسماء لديك. راجع **إنشاء مجموعة**.

إنشاء مجموعة

1 على الشاشة الرئيسية، المس ثم المس **الاسماء** في علامة التبويب اتصال.

2 المس الأسماء في أعلى الشاشة ثم المس **مجموعات** وحدد مجموعة جديدة.

3 أدخِل اسماً للمجموعة الجديدة.

4 المس لحفظ المجموعة.

ملاحظة: إذا قمت بحذف مجموعة، فلن تفقد الأسماء التي تم تعيينها إلى تلك المجموعة. بل ستبقى موجودةً في جهات الاتصال لديك.

تلميح! يمكنك تعديل مجموعة موجودة وذلك بلمس المجموعة المحددة مرة واحدة. اختر من ضمن عرض الأعضاء، أو تعديل مجموعة، أو إرسال رسالة، أو إرسال بطاقة عمل أو حذف مجموعة.

تغيير ضوابط الأسماء

يمكنك تكييف ضوابط الأسماء بحيث تتناسب مع تفضيلاتك الخاصة.

1 المس **الاسماء** في علامة التبويب اتصال، حدد ثم قم بالتمرير إلى **إعدادات الاسم**.

2 من هنا يمكنك تنظيم ضبط التالية:

اسم العرض - اختر ما إذا أردت عرض اسم جهة الاتصال الأول أو الأخير أولاً.

نسخ الكل - انسخ الأسماء من بطاقة SIM إلى الهاتف، أو من الهاتف إلى بطاقة SIM. يمكنك القيام بذلك لكل جهة اتصال على حدة، أو لكل الجهات دفعةً واحدة.

نقل الكل - يعمل هذا الأمر بالطريقة نفسها التي يعمل فيها النسخ، غير أنه يتم تخزين جهة الاتصال في الموقع الجديد فقط. لذا، حالما يتم نقل جهة اتصال من بطاقة SIM إلى الهاتف، فسيتم حذفها من ذاكرة بطاقة SIM.

مسح الاسماء - قم بحذف كل الأسماء المتوفرة لديك. المس **نعم** إذا كنت تريد بالتأكيد حذف كل الأسماء لديك.

معلومات الذاكرة - عرض معلومات حول سعة الذاكرة.

عرض المعلومات

1 المس **جهات الاتصال** في علامة التبويب اتصال، حدد ☰ والمس **المعلومات**.

2 من هنا يمكنك عرض **أرقام الاتصال بالخدمة**، و**أرقام خاصة**، و**معلومات الذاكرة** (مساحة الذاكرة المتبقية) و**بطاقة العمل الخاصة بي**.

تلميح! لإضافة بطاقة العمل الخاصة بك، حدد **بطاقة العمل الخاصة بي** وأدخِل التفاصيل كما تقوم عادةً بالنسبة لأي جهة اتصال. المس الرمز **حفظ** للانتهاء.

الرسائل

الرسائل

يجمع الهاتف GD900 ميزات إرسال رسائل نصية، وMMS في قائمة واحدة بديهية وسهلة الاستخدام.

هناك طريقتان لدخول مركز الرسائل:

1 على الشاشة الرئيسية، المس أو ، ثم قم بالتمرير إلى **الرسائل** في علامة التبويب اتصال.

إرسال رسالة

1 المس ثم **كتابة رسالة** لفتح رسالة فارغة.

2 المس **إلى** لإدخال رقم المستلم، أو فتح جهات الاتصال لديك أو المفضلات. يمكنك إضافة عدة الأسماء. حالما تنتهي، المس صندوق الرسائل أدناه لبدء إنشاء رسالة نصية.

3 بعد إدخال النص، يمكنك إرسال رسالة نصية بلمس زر الإرسال في أعلى الرسالة.

تلميح! تلميح! سوف يتم الخصم من رصيدك لكل شخص ترسل له رسالة.

4 المس **إدراج** لإضافة نموذج نص، أو نماذج وسائط متعددة، أو رمز تعبيري، أو اسم ورقم، أو شريحة جديدة، أو موضوع أو توقيع.

تحذير قد يختلف حد عدد الأحرف عن 160 من بلد إلى آخر وذلك استناداً إلى كيفية ترميز رسائل نصية.

تحذير: إذا تمت إضافة صورة، أو فيديو أو ملف صوت إلى رسالة نصية، فسيتم تحويلها تلقائياً إلى رسالة وسائط متعددة وسيُفرض رسم عليك وفقاً لذلك.

إدخال النص

لوحة المفاتيح.

T9 المس لبدء تشغيل نص T9 التنبؤي.

المس لتغيير لغة الكتابة.

ABC @#* اضغط للتبديل بين لوحات مفاتيح الأرقام، والرموز والنص.

استخدام للتمرير عبر مختلف لوحات المفاتيح في كل وضع من أوضاع إدخال النص (مثلاً، الأحرف الكبيرة أو الأحرف الصغيرة).

لإدخال مسافة المس .

T9 تنبؤي

في وضع T9، سترى T9 .

يستخدم وضع T9 قاموساً مضمناً للتعرف إلى الكلمات التي تكتبها استناداً إلى تسلسل المفاتيح التي تلمسها. ما عليك إلا لمس مفتاح الرقم المقترن بالحرف الذي تريد إدخاله، وسيتوقع القاموس الكلمة التي تود استخدامها.

اضغط مثلاً على 8، 3، 5، 3، 7، 4، 6، 6 و 3 لكتابة 'telephone'.

دليل Abc

في وضع Abc عليك لمس المفتاح بشكل متكرر لإدخال حرف. فلكتابة كلمة 'hello' مثلاً، المس 4 مرتين، و3 مرتين، و5 ثلاث مرات، و5 ثلاث مرات مجدداً، ثم 6 ثلاث مرات.

إعداد بريد إلكتروني

يمكنك البقاء على تواصل أثناء التنقل وذلك باستخدام الهاتف GD900 لإرسال رسائل بريد إلكتروني. فعملية إعداد حساب بريد إلكتروني POP3 أو IMAP4 تُعتبر عمليةً بسيطةً وسهلةً.

1 المس على الشاشة الرئيسية، وقم بالتمرير إلى **بريد إلكتروني** في علامة التبويب اتصال.

2 المس **كتابة بريد إلكتروني**. في حال عدم إعداد حساب بريد إلكتروني، فابدأ معالج إعداد البريد الإلكتروني.

تلميح! في حال تعيين حساب بريد إلكتروني مسبقاً، لا يتم تنشيط المعالج تلقائياً.

إرسال بريد إلكتروني باستخدام حسابك الجديد

1 المس على الشاشة الرئيسية، وقم بالتمرير إلى **بريد إلكتروني** في علامة التبويب اتصال لفتح رسالة فارغة جديدة.

2 أدخِل عنوان المستلم ودوّن رسالتك. ويمكنك أيضاً إرفاق صور، وملفات فيديو، وملفات صوت وأنواع أخرى من الملفات.

3 المس **إرسال بريد إلكتروني** لإرسال بريدك الإلكتروني.

تلميح! أثناء اتصال WiFi نشط، يتم إرسال رسائل البريد الإلكتروني وتلقيها عبر WiFi.

تغيير إعدادات البريد الإلكتروني

يمكنك تغيير إعدادات البريد لإلكتروني وفق تفضيلاتك الخاصة.

1 المس على الشاشة الرئيسية، ثم قم بالتمرير إلى **إعدادات الرسائل** في علامة التبويب إعدادات.

2 حدد **بريد إلكتروني**.

3 يمكنك تعديل ضبط التالية:

حسابات البريد الإلكتروني - قم بإدارة حسابات بريدك الإلكتروني.

السماح ببريد إلكتروني للرد - اختر ما إذا كنت تريد السماح بإرسال رسائل تأكيد القراءة.

طلب رد بريد إلكتروني - اختر ما إذا كنت تريد طلب رسائل تأكيد القراءة.

الفاصل الزمني للاسترداد - حدد مدى تكرار قيام GD900 بالتحقق من وجود رسائل بريد إلكتروني جديدة.

تضمين رسالة في الارسال والرد - حدد تضمين الرسالة الأصلية في أي رد.

تضمين المرفق - حدد تضمين المرفق الأصلي في أي رد.

استرداد تلقائي أثناء التجوال - اختر ما إذا كنت تريد استرداد الرسائل تلقائياً أثناء التواجد في الخارج (التجوال).

اعلام جديد بالبريد الإلكتروني معلومات - اختر ما إذا كنت تريد أن يتم تنبيهك عند استلام بريد إلكتروني جديد بواسطة رسالة منبثقة.

التوقيع - قم بإنشاء توقيع على البريد الإلكتروني وشغّل هذه الميزة.

حافظات الرسائل

ستتعرف على بنية المجلدات المستخدمة في الهاتف GD900.

صندوق الوارد - يتم تخزين كل الرسائل المستلمة في صندوق الوارد. من هنا يمكنك عرضها وحذفها، من بين وظائف أخرى.

صندوق الصادر - عبارة عن مجلد تخزين مؤقت للرسائل فيما يكون إرسالها جارٍ.

المرسَلة - يتم تخزين الرسائل التي أرسلتها في هذه الحافظة.

المسودات - إذا لم تنتهي من كتابة رسالة، فيمكنك حفظ ما كتبته في هذه الحافظة.

الرسائل

صندوق مترابط - يمكن عرض الرسائل القصيرة (SMS) التي يتم تبادلها مع جهة أخرى بترتيب زمني بحيث تحصل على نظرة عامة عن الحديث.

حافظاتي - إنشاء حافظات لتخزين رسائلك.

استخدام النماذج

قم بإنشاء نماذج لرسائل نصية ووسائط متعددة التي ترسلها بشكل متكرر. هناك بعض النماذج الموجودة مسبقاً على الهاتف، والتي يمكنك تعديلها.

1 عند كتابة رسالة جديدة، يمكنك إدخال **نماذج** من **إدراج** في قائمة الخيارات.

2 اختر **نماذج نصية** أو **نماذج وسائط متعددة**. يمكنك إضافة، أو تعديل، أو حذف أو حذف كل النماذج. لتعديل رسالة، ما عليك سوى تحديدها، وتعديلها ومن ثم لمس **حفظ نموذج**.

استخدام الرموز التعبيرية

يمكنك إضفاء الحيوية على رسائلك من خلال استخدام الرموز التعبيرية. تجد على هاتفك بعض الرموز التعبيرية الشائعة الاستخدام.

1 عند كتابة رسالة جديدة، يمكنك إدخال **رموز تعبيرية** من **إدراج** في قائمة الخيارات.

2 يمكنك إضافة رمز تعبيري جديد بلمس **رمز تعبيري جديد**.

تغيير إعدادات الرسائل النصية

تكون إعدادات الرسائل في الهاتف GD900 محددة مسبقاً بحيث يمكنك إرسال رسائل على الفور. يمكن تغيير هذه ضبط بحسب تفضيلاتك.

قم بالتمرير إلى **إعدادات الرسائل** في علامة التبويب إعدادات ثم المس **الرسائل النصية**. يمكنك إدخال تغييرات على:

مركز الرسائل النصية - أدخِل تفاصيل مركز الرسائل.

تقرير التسليم- مرر المفتاح إلى اليسار لاستلام تأكيد بتسليم رسائلك.

مدة الصلاحية - اختر فترة تخزين رسائلك في مركز الرسائل.

أنواع الرسائل - قم بتحويل النص إلى **صوت**، أو **فاكس**، أو **X.400** أو **بريد إلكتروني**.

ترميز الحروف ـ اختر طريقة ترميز الحروف. ويؤثر هذا الأمر على حجم رسائلك وبالتالي على رسوم البيانات.

إرسال النص الطويل كـ - اختر إرسال الرسائل الطويلة كرسائل نصية متعددة أو كرسائل وسائط متعددة.

تغيير إعدادات رسائل الوسائط المتعددة

تكون إعدادات الرسائل في الهاتف GD900 محددة مسبقاً بحيث يمكنك إرسال رسائل على الفور. يمكن تغيير هذه ضبط بحسب تفضيلاتك.

في **الضبط**، حدد **ضوابط الرسائل** و**رسالة وسائط متعددة**. يمكنك إدخال تغييرات على:

وضع الاسترداد - حدد **شبكة محلية** أو **شبكة التجوال**. إذا حددت يدوي، فستتلقى إعلاماً برسائل وسائط متعددة فقط. ويمكنك حينئذٍ أن تقرر ما إذا كنت تريد تنزيلها بشكل كامل أم لا.

ملاحظة: قد يتم فرض رسم إضافي لدى تنزيل رسائل وسائط متعددة عند التجوال.

تقرير التسليم - اختر السماح بتقرير الاستلام و/أو طلبه.

تقرير قراءة - اختر السماح بإشعار بقراءة الرسالة و/أو إرساله.

أولوية - اختر مستوى الأولوية لرسائل وسائط متعددة.

فترة الصلاحية - اختر فترة تخزين رسالتك في مركز الرسائل.

مدة الشريحة - اختر مدة ظهور الشرائح على الشاشة.

وضع الإنشاء - مقيّد/ تحذير/ متوفر

وقت التسليم - اختيار المدة قبل تسليم كل رسالة.

مركز رسائل وسائط متعددة - أدخِل تفاصيل مركز الرسائل.

تغيير ضبط الأخرى

قم بالتمرير إلى **إعدادات الرسائل** في علامة التبويب إعدادات ثم:

البريد الصوتي - المس **نمط جديد** أو لإضافة خدمة بريد صوتي جديدة. اتصل بمشغّل الشبكة للحصول على مزيد من المعلومات حول الخدمة التي يقدمها.

رسالة الخدمة - اختر استلام أو حظر رسائل الخدمة. كما يمكنك أيضاً تعيين مستويات حماية الرسالة وذلك بإنشاء قوائم مرسِلين موثوق بهم وغير موثوق بهم.

خدمة المعلومات ـ اختر حالة الاستلام، واللغة إعدادات أخرى.

الكاميرا

التعرّف على محدد المنظر

افتح الغطاء لاستخدام الكاميرا الخارجية.

رجوع - المس هنا للعودة إلى خريطة القوائم.

وضع الكاميرا - يظهر ما إذا كانت الكاميرا في وضع الفيديو أو في وضع الصورة. كما يمكن استخدامه لالتقاط الصور.

الاستوديو - المس هذا الرمز لعرض الاستوديو.

التباين - راجع ضبط التباين في الصفحة 48.

ماكرو - قم بتشغيله لالتقاط لقطات قريبة.

حالة الفلاش- يمكنك اختيار حالة الفلاش اما اتوماتيك او دائما تشغيل او دائما ايقاف.

ضبط - المس هذا الرمز لفتح قائمة ضبط. راجع استخدام الإعدادات المتقدمة في الصفحة 49 للحصول على التفاصيل.

تلميح! يمكنك إغلاق كل خيارات القائمة المختصرة للحصول على شاشة أوضح لمحدد المنظر. ما عليك إلا لمس وسط محدد المنظر مرة واحدة. لاستدعاء الخيارات. المس الشاشة مرة أخرى.

الكاميرا

التقاط صورة سريعة

1 اضغط باستمرار على مفتاح الكاميرا الموجود في الجانب الأيمن من الهاتف.

2 مع حمل الهاتف أفقياً، صوّب العدسة باتجاه موضوع الصورة.

3 اضغط برفق على زر الالتقاط فيظهر صندوق البؤرة في وسط شاشة محدد المنظر.

4 ضع الهاتف بحيث يمكنك مشاهدة موضوع الصورة في صندوق البؤرة.

5 عندما يتحوّل لون صندوق البؤرة إلى أخضر، فهذا يعني أن الكاميرا تركّز على موضوع الصورة.

6 اضغط باستمرار على زر الالتقاط.

تلميح! تتبّع الوجه

يكشف عن الوجوه البشرية ويركز عليها تلقائياً لمساعدتك على التقاط صور أكثر وضوح.

بمجرد التقاط الصورة

تظهر الصورة الملتقطة على الشاشة. يظهر اسم الصورة مع أربعة رموز في الجانب الأيمن.

إرسال المس لإرسال الصورة كـ **رسالة**، أو **بريد إلكتروني**، أو **بلوتوث**.

راجع الصفحة 38 لإرسال رسالة، والصفحة 101 لإرسال الملفات واستلامها باستخدام بلوتوث.

ملاحظة: قد يتم فرض رسم إضافي لدى تنزيل رسائل وسائط متعددة عند التجوال.

استخدام المس لاستخدام الصورة كخلفية.

إعادة تسمية المس لتعديل اسم الصورة المحددة.

تحرير المس لتعديل الصورة مستخدماً أدوات مختلفة.

المس للعودة إلى القائمة السابقة.

المس لحذف الصورة.

المس لالتقاط صورة أخرى على الفور. وسيتم حفظ صورتك الحالية.

المس لعرض معرض من الصور المحفوظة.

الكاميرا

استخدام الفلاش

الضبط الافتراضي للفلاش هو تلقائي، ولكن هناك خيارات أخرى.

1 حدد في الزاوية اليسرى لمحدد المنظر للدخول إلى قائمة الفلاش الفرعية.

2 هناك ثلاثة خيارات للفلاش:

تلقائي - ستقوم الكاميرا بتقييم الإضاءة المتوفرة لالتقاط صورة جيدة وستستخدم الفلاش كما تقتضي الحاجة.

متوقف عن التشغيل دائماً - لن يضيء فلاش الكاميرا أبداً. ويُعتبر هذا الأمر مفيداً إذا ما رغبت في توفير طاقة البطارية.

تشغيل دائما - يضيء فلاش الكاميرا دائماً.

3 حين تقوم بلمس خيار تريده، تنغلق قائمة الفلاش تلقائياً بحيث تسمح لك بالتقاط الصورة فوراً.

4 يتغير رمز حالة الفلاش الموجود على محدد المنظر وفقاً للوضع الجديد الذي عيّنته للفلاش.

ضبط التباين

يعرّف التباين الفرق بين المناطق المضيئة والمناطق الداكنة في صورة ما. فتظهر الصورة ذات التباين المنخفض ضبابيةً، بينما تظهر الصورة ذات التباين العالي أكثر دقةً ووضوحاً.

1 المس 0.0 .

2 ادفع مؤشر التباين عبر الشريط نحو للحصول على تباين منخفض وصورة ضبابية، أو نحو للحصول على تباين أعلى وصورة أوضح.

أو حرّك عجلة اللمس على شاشة اللمس الشفافة في اتجاه عقارب الساعة لزيادة السطوع أو باتجاه معاكس لحركة عقارب الساعة لتخفيفه. عليك تنشيط مؤشر مستوى الصوت أولاً عبر لمس 0.0 .

ضبط حجم الصورة

كما يمكنك تكبير الصورة وتصغيرها. حرّك اصبعك على لوح اللمس الشفاف بشكل دائري باتجاه عقارب الساعة لتكبير الصورة، وحرّكه بعكس اتجاه عقارب الساعة لتصغير الصورة.

التقاط لقطة متواصلة

1 من محدد المنظر, المس الاعدادت لفتح اعدادات متقدمة واختر نظام التقاط الصور ثم حدد الالتقاط المستمر.

2 حدد مكان موضوع الصورة في محدد المنظر واضغط على زر الالتقاط كما تفعل لالتقاط صورة عادية.

3 تأخذ الكاميرا لقطات بطريقة متتابعة وسريعة.

استخدام الإعدادات المتقدمة

في محدد المنظر, المس لفتح كل خيارات الإعدادات المتقدمة.

يمكنك تغيير ضبط الكاميرا عبر تمرير العجلة. بعد تحديد الخيار, المس زر **موافق**.

تبديل إلى - للصور الشخصية الذاتية, بدّل إلى كاميرا LG GD900 الداخلية. كما يمكنك أيضاً التبديل بين وضع الكاميرا ووضع كاميرا فيديو.

الكاميرا

حجم الصورة - غيّر حجم الصورة لتوفير مسافة في الذاكرة أو لالتقاط صورة ذات حجم مناسب لجهة اتصال. راجع **تغيير حجم الصورة** في الصفحة 51.

تأثير الألوان - اختر درجة اللون التي تريد استخدامها في الصورة الجديدة. راجع **اختيار تأثير اللون** في الصفحة 52.

موازنة الأبيض - اختر من ضمن **تلقائي** و**متوهج** و**مشمس** و**فلورسنت** و**غائم**.

المؤقت - يسمح لك المؤقت الذاتي بتعيين فترة تأخير بعد الضغط على الغالق. حدد **إيقاف التشغيل**، أو **3 ثوانٍ**، أو **5 ثوانٍ** أو **10 ثوانٍ**. هذا خيار مثالي إن أردت تضمين نفسك في الصورة.

وضع اللقطة - اختر وضع اللقطات العادية أو وضع اللقطات المتواصلة.

ISO - يحدد تصنيف ISO حساسية جهاز استشعار الضوء في الكاميرا. بقدر ما تكون قيمة ISO عاليةً، بقدر ما تكون الكاميرا حساسةً. ويُعتبر هذا الأمر مفيداً في الحالات الداكنة عندما لا يكون استخدام الفلاش ممكناً. حدد قيمة ISO من ضمن **تلقائي**، و**100**، **200**، **400**، **800**، **1600**.

جودة الصورة - اختر من ضمن **دقيقة جداً**، و**دقيقة** و**عادية**. بقدر ما تكون الجودة دقيقةً بقدر ما تكون الصورة واضحةً. ولكن حجم الملف سيكون أكبر نتيجةً لذلك، ما يعني أنه سيكون باستطاعتك تخزين عدد أقل من الصور في الذاكرة.

الذاكرة المستخدمة - اختر ما إذا كنت تريد حفظ الصور في ذاكرة الهاتف أو في الذاكرة الخارجية.

إخفاء الرموز - اختر ما إذا كنت تريد إخفاء رموز إعدادات الكاميرا يدوياً أو تلقائياً.

تثبيت الصورة - يمكّنك من التقاط صورة من دون اهتزاز الكاميرا أو عدم ثباتها.

تركيز تلقائي - حدد طريقة تركيز الكاميرا. اختر من ضمن **نقطة**، و**يدوي** و**تتبّع الوجه**.

صوت الغالق - حدد خياراً من ضمن خيارات صوت الغالق الأربعة.

عرض الشبكة - اختر من ضمن **إيقاف التشغيل**، أو **شبكة2x2** أو **شبكة 3x3**.

إعادة ضبط - استعادة كل إعدادات الكاميرا الافتراضية.

تلميح! عندما تنهي تشغيل الكاميرا، تعود كل ضبط إلى وضعها الافتراضي، باستثناء حجم الصورة وجودتها. يجب إعادة تعيين ضبط غير الافتراضية، شأن درجة اللون وISO. تحقق من ذلك قبل التقاط الصورة التالية.

تلميح! تقع قائمة ضبط فوق محدد المنظر، وستتمكن بالتالي من مشاهدة معاينة لتغييرات الصورة خلف قائمة ضبط عندما تقوم بتغيير عناصر ألوان الصورة أو جودتها.

تغيير حجم الصورة

بقدر ما يكون عدد عناصر البكسل كبيراً، بقدر ما يكون حجم الملف أكبر، ما يعني أن الملفات ستحتل مسافة أكبر في الذاكرة. إذا أردت تخزين عدد أكبر من الصور في هاتفك، فيمكنك تغيير الدقة لجعل الملفات أصغر حجماً.

1 مستخدماً محدد المنظر، المس في الزاوية العلوية اليسرى.

2 حدد **حجم الصورة** في قائمة المعاينة.

3 حدد قيمة بكسل من ضمن الخيارات الستة

حدد قيمة البكسل من ضمن الخيارات الستة الاتية: 8 ميجا 5 ميجا 1 ميجا VGA خلفية (400*800) QVGA رسالة وسائط متعددة (240*320) الاسماء (480*480)

الكاميرا

اختيار تأثير اللون

1 مستخدماً محدد المنظر، المس في الزاوية العلوية اليسرى.

2 حدد **تأثير الألوان** في قائمة المعاينة.

3 هناك خمسة خيارات لدرجات الألوان: **إيقاف**، **وبني داكن**، **وأحادي**، و **سالب**، **وزخرفة**.

4 حالما تحدد اختيارك، يصبح بالإمكان إغلاق قائمة درجة اللون عبر تحديد زر موافق. وتصبح حينئذٍ جاهزاً لالتقاط صورة.

تلميح! يمكنك تغيير صورة تم التقاطها بالألوان إلى الأسود والأبيض أو البني الداكن، غير أنه لا يمكنك تغيير صورة تم التقاطها بالأسود والأبيض أو البني الداكن إلى صورة ملونة.

استخدام الكاميرا الداخلية

تتوفر في LG GD900 كاميرا داخلية 640x480 لإجراء مكالمات فيديو ولالتقاط الصور أيضاً.

1 للانتقال للكاميرا الداخلية.المس الاعدادات واختر تبديل الكاميرا ثم اختر ثانوي .

2 ستشاهد نفسك بعد مرور بضع ثوانٍ في محدد المنظر. لالتقاط الصورة، اضغط على الزر الجانبي كما تفعل عادةً.

تلميح! تتوفر إعدادات أقل في الكاميرا الداخلية إذ ليس لديها فلاش أو حساسية قابلة للضبط. ويمكنك مع ذلك تغيير حجم الصورة، وتأثير الألوان، وجودة الصورة، وتوازن اللون الأبيض كما يمكنك تعيين المؤقت الذاتي عبر لمس بالطريقة نفسها التي تقوم فيها بذلك عند استخدام الكاميرا الرئيسية.

3 بعد التقاط الصورة، ستتوفر لديك كل الخيارات نفسها التي تتوفر بالنسبة إلى صورة تلتقطها بواسطة الكاميرا الرئيسية.

4 للرجوع للكاميرا الاساسية.المس الاعدادات واختر تبديل الكاميرا ثم اختر اساسي .

عرض الصور المحفوظة

1 يمكنك الوصول إلى الصور المحفوظة من ضمن وضع الكاميرا. ما عليك سوى لمس وسيظهر الاستوديو على الشاشة.

كاميرا فيديو

التعرّف على محدد المنظر

افتح الغطاء لاستخدام الكاميرا الخارجية.

رجوع - المس هنا للعودة إلى الشاشة الرئيسية.

بدء التسجيل

الاستوديو - المس هذا الرمز لعرض الاستوديو.

التباين - راجع ضبط التباين في الصفحة 56.

سرعة التسجيل

حالة الفلاش - قم بتعيين الفلاش أو بإيقاف تشغيله.

ضبط - المس هذا الرمز لفتح قائمة ضبط. راجع استخدام الإعدادات المتقدمة في الصفحة 56 للحصول على التفاصيل.

تلميح! يمكنك إغلاق كل خيارات القائمة المختصرة للحصول على شاشة أوضح لمحدد المنظر. ما عليك إلا لمس وسط محدد المنظر مرة واحدة. لاستدعاء الخيارات، المس الشاشة مرة أخرى.

التقاط فيديو سريع

1 اضغط باستمرار على مفتاح الكاميرا الموجود في الجانب الأيمن من الهاتف.

2 ثم المس ⚙ وحدد **تبديل إلى** في محدد المنظر في وضع الكاميرا للتبديل إلى وضع الفيديو. أو يمكنك دخول هذه القائمة مباشرةً عبر لمس **كاميرا فيديو**.

3 سيظهر محدد المنظر في كاميرا الفيديو على الشاشة.

4 مع حمل الهاتف أفقياً، صوّب العدسة باتجاه موضوع الفيديو.

5 اضغط على زر الالتقاط مرةً واحدةً لبدء التسجيل.

6 **Rec** يظهر في أسفل محدد المنظر مع مؤقت يظهر طول الفيديو.

7 لإيقاف الفيديو مؤقتاً، المس ⏸ ولاستئناف التسجيل حدد ●.

8 المس ■ على الشاشة لإيقاف التسجيل.

بعد التقاط فيديو

تظهر على الشاشة صورةً ثابتةً تمثل الفيديو. سيظهر اسم الفيديو في أسفل الشاشة إضافةً إلى أربعة رموز في الجانب الأيمن.

تشغيل المس لتشغيل الفيديو.

إرسال المس زر ارسال لارسال الصورة عبر رسالة الوسائط المتعددة، البريد الالكتروني، البلوتوث، و اليوتيوب. راجع الصفحة 38 لإرسال رسالة، والصفحة 101 لإرسال الملفات واستلامها باستخدام بلوتوث.

ملاحظة: قد يتم فرض رسم إضافي لدى تنزيل رسائل وسائط متعددة عند التجوال.

كاميرا فيديو

استخدام المس لاستخدام الصورة كخلفية.

إعادة التسمية المس لتعديل اسم الصورة المحددة.

المس للعودة إلى القائمة السابقة.

المس لحذف الفيديو الذي قمت بالتقاطه، وأكّد بلمس **نعم**. يظهر محدد المنظر من جديد.

المس لالتقاط فيديو آخر على الفور. وسيتم حفظ الفيديو الحالي.

المس لعرض معرض الصور وملفات الفيديو المحفوظة.

ضبط التباين

يعرّف التباين الفرق بين المناطق المضيئة والمناطق الداكنة في صورة ما. فتظهر الصورة ذات التباين المنخفض ضبابيةً، بينما تظهر الصورة ذات التباين العالي أكثر دقةً ووضوحاً.

1 المس 0.0 .

2 ادفع مؤشر التباين عبر الشريط نحو للحصول على تباين منخفض وصورة ضبابية، أو نحو للحصول على تباين أعلى وصورة أوضح.

استخدام الإعدادات المتقدمة

مستخدماً محدد المنظر، المس **ضبط** لفتح كل خيارات الإعدادات المتقدمة.

يمكنك تغيير ضبط كاميرا الفيديو عبر تمرير العجلة. بعد تحديد الخيار، المس زر **موافق**.

تبديل إلى - بدّل إلى كاميرا LG GD900 الداخلية لتسجيل فيديو عن نفسك. راجع **استخدام كاميرا الفيديو الداخلية** في الصفحة 59 للحصول على التفاصيل.

حجم الفيديو - غيّر حجم الفيديو لتوفير مسافة في الذاكرة. راجع **تغيير حجم الصورة** في الصفحة 58.

وضع المشهد - اختر من ضمن **تلقائي** أو **وضع الليل**.

تأثير الألوان - اختر درجة اللون التي تريد استخدامها في العرض الجديدة. راجع **اختيار درجة اللون** في الصفحة 59.

موازنة الأبيض - يضمن توازن اللون الأبيض ظهور أي لون أبيض في الفيديو كواقعي. لتمكين الكاميرا من ضبط توازن اللون الأبيض بشكل صحيح، قد تحتاج إلى تحديد ظروف الإضاءة. اختر من ضمن **تلقائي**، أو **متوهج**، أو **مشمس**، أو **فلورسنت** أو **غائم**.

جودة الفيديو - اختر من ضمن **دقيق جداً**، و**دقيق** و**عادي**. كلما تكون الجودة دقيقةً أكثر، يكون الفيديو واضحاً أكثر. سيتزايد حجم الملف نتيجةً لذلك، ما يعني أنك ستتمكن من تخزين مقاطع فيديو أقل في ذاكرة الهاتف.

المدة - قم بتعيين حد لمدة الفيديو. اختر من ضمن **عادي** و**وسائط متعددة** لتحديد الحجم الأقصى للإرسال كرسالة وسائط متعددة.

تلميح! إذا اخترت مدة وسائط متعددة، فإن اختيار جودة أقل للصورة سيمكّنك من التقاط مقطع فيديو أطول.

الذاكرة المستخدمة - اختر ما إذا كنت تريد حفظ مقاطع الفيديو في ذاكرة الهاتف أو في الذاكرة الخارجية.

الصوت ـ اختر كتم لتسجيل فيديو بدون صوت.

إخفاء الرموز - حدد ما إذا كنت تريد إخفاء الرموز الموجودة في قائمة الكاميرا تلقائياً أو يدوياً.

إعادة ضبط - قم بإعادة تعيين إعدادات كاميرا الفيديو كافةً.

كاميرا فيديو

تغيير حجم صورة الفيديو

بقدر ما يكون عدد عناصر البكسل كبيراً، بقدر ما يكون حجم الملف أكبر، ما يعني أن الملفات ستحتل مسافة أكبر في الذاكرة. إذا أردت تخزين عدد أكبر من مقاطع الفيديو في هاتفك، فيمكنك تغيير دقة الفيديو لجعل الملفات أصغر حجماً.

1 مستخدماً محدد المنظر، المس في الزاوية العلوية اليسرى.

2 حدد **حجم الفيديو** في قائمة المعاينة.

3 حدد قيمة بكسل من الخيارات الأربعة:

720X480 (D1) - خيار الشاشة العريضة الأعلى من حيث الجودة.

640x480 - حجم VGA القياسي.

320x240 - حجم صورة أصغر، وبالتالي حجم ملف أصغر. هذا خيار مثالي لتوفير مسافة في الذاكرة.

176x144 - حجم صورة أصغر، وبالتالي حجم ملف أصغر.

4 المس زر موافق للعودة إلى محدد المنظر.

تلميح! يتوافق برنامج التعديل الممتاز المتوفر على LG GD900 مع كل أنواع مقاطع الفيديو باستثناء 720X480 (D1) و640x480. لا تقم بالتسجيل في هذا التنسيق إذا كنت تنوي تعديل الفيديو.

تلميح! بالنسبة إلى برنامج تحويل تنسيق الفيديو، راجع القرص المضغوط الذي يصحب GD900.

اختيار درجة اللون

1 مستخدماً محدد المنظر، المس ⚙ في الزاوية العلوية اليسرى.

2 حدد **تأثير الألوان** في قائمة المعاينة.

3 هناك ستة خيارات لدرجات الألوان، **إيقاف**، أو **بني داكن**، أو **أحادي**، أو **صورة سلبية** أو **زخرفة**.

4 المس درجة اللون التي ترغب في استخدامها.

تلميح! يمكنك تغيير مقطع فيديو تم التقاطه بالألوان إلى الأسود والأبيض أو البني الداكن، غير أنه لا يمكنك تغيير مقطع فيديو تم التقاطه بالأسود والأبيض أو البني الداكن إلى فيديو بالألوان.

استخدام كاميرا الفيديو الداخلية

تتوفر في LG GD900 كاميرا داخلية 320x240 لإجراء مكالمات فيديو وتسجيل مقاطع فيديو.

1 للانتقال للكاميرا الداخلية.المس الاعدادات واختر تبديل الكاميرا ثم اختر ثانوي ⚙ .

2 ستشاهد نفسك بعد مرور بضع ثوانٍ في محدد المنظر. لبدء تسجيل الصورة، اضغط على مفتاح الالتقاط كما تقوم بذلك عادةً، ثم اضغط مرة أخرى لإيقاف التسجيل.

3 بعد التقاط الفيديو، ستتوفر لديك كل الخيارات نفسها التي تتوفر بالنسبة إلى مقطع فيديو تلتقطه بواسطة الكاميرا الرئيسية.

4 للرجوع للكاميرا الاساسية.المس الاعدادات واختر تبديل الكاميرا ثم اختر اساسي ⚙ .

تلميح! ويمكنك مع ذلك تغيير حجم الصورة، وتأثير الألوان، وتوازن اللون الأبيض والجودة وذلك بلمس **ضبط** بالطريقة نفسها التي تقوم فيها بذلك عند استخدام الكاميرا الرئيسية.

كاميرا فيديو

مشاهدة مقاطع الفيديو المحفوظة

1 في محدد المنظر، المس .

2 يظهر الاستوديو على الشاشة.

3 المس مقطع فيديو مرةً واحدةً لإحضاره إلى مقدمة الاستوديو. يبدأ التشغيل تلقائياً.

مشاهدة مقاطع الفيديو على التلفزيون

قم بتوصيل GD900 إلى التلفزيون باستخدام كبل إخراج التلفزيون.

ملاحظة: يمكن شراء كبل إخراج التلفزيون بشكل منفصل.

تلميح! تتوافق كل التنسيقات باستثناء 320x240 و176x144 مع تشغيل الفيديو على التلفزيون.

الصور و مقاطع الفيديو

عرض الصور ومقاطع الفيديو

1 المس على شاشة المعاينة الخاصة بالكاميرا.

2 يظهر الاستوديو على الشاشة.

3 المس الفيديو أو الصورة لفتحهما كلياً.

تلميح! انقر إلى اليمين أو إلى اليسار لعرض صور أخرى أو مقاطع فيديو أخرى.

تلميح! لحذف فيديو أو صورة، افتحه وحدد . المس **نعم** للتأكيد.

استخدام التكبير/التصغير عند مشاهدة فيديو أو صورة

عند عرض صور أو مقاطع فيديو، يمكنك التكبير والتصغير عبر جمع إصبعيك معاً أو إبعادهما عن بعضهما.

ضبط مستوى الصوت عند عرض فيديو

لضبط مستوى الصوت في فيديو أثناء تشغيله، المس شريط مستوى الصوت الموجود في أسفل الشاشة بعد الضغط على رمز مكبّر الصوت. كطريقة بديلة، استخدم مفاتيح مستوى الصوت على جانب الهاتف.

تعيين صورة كخلفية الشاشة

1 المس الصورة التي ترغب في تعيينها كخلفية الشاشة لفتحها.

2 المس الشاشة لفتح قائمة الخيارات.

3 المس **استخدام** .

4 تنتقل الشاشة إلى الوضع العمودي. يمكنك تكبير وتصغير ونقل المقطع المقتص لصورة مستخدماً صورة مصغّرة أسفل الشاشة.

تعديل الصور

يمكنك تطبيق الكثير من الأشياء الرائعة على صورك لتغييرها، أو الإضافة إليها، أو إضفاء بعض الحيوية إليها.

1 افتح الصورة التي ترغب في تعديلها والمس **تحرير** لإظهار الخيارات.

2 المس الرموز لتعديل صورتك:

اقتصاص الصورة. اختر منطقة اقتصاص مربعة أو دائرية وحرّك إصبعك عبر الشاشة لتحديد المنطقة.

أضف رسماً يدوياً إلى صورتك. حدد سماكة الخط من ضمن الخيارات الأربعة واللون الذي تود استخدامه.

إضافة كتابة إلى صورة. راجع **إضافة نص إلى صورة** في الصفحة 63.

قم بتزيين صورتك بواسطة الطوابع. اختر من ضمن الطوابع المتوفرة والمس الصورة حيث ترغب في وضع هذه الطوابع.

احذف التعديل الذي أضفته إلى الصورة. يمكنك اختيار حجم الممحاة التي تستخدمها.

المس للعودة إلى الاستوديو.

حفظ احفظ التغييرات التي أدخلتها على الصور. حدد لحفظ التغييرات كـ **تحديث الموجود** أو كـ **ملف جديد**. إذا حددت **ملف جديد** فأدخل اسم ملف.

تراجع احذف التعديل الذي أضفته إلى الصورة.

الصورة المس لفتح المزيد من خيارات التأثير بما فيها **تدوير**. هناك أيضاً المزيد من خيارات التعديل المتقدمة.

مرشح المس لتطبيق خيارات التأثير على صورة.

تعديل هذا يساعدك على ضبط صورة تم التقاطها باستخدام لون تلقائي، وسطوع تلقائي، إلخ

إضافة نص إلى صورة

1 في شاشة التعديل المس T .

2 حدد **نص** لإضافة نص بدون إطار أو اختر أحد الأشكال الفقاعية للكلام.

3 أدخل النص باستخدام لوحة المفاتيح والمس **حفظ**.

4 حرّك النص وذلك بلمسه ودفعه إلى المكان حيث ترغب بأن يكون.

الصور و مقاطع الفيديو

إضافة تأثير إلى صورة

1 في شاشة التعديل، المس **تصفية** .

2 يمكنك تطبيق أي من الخيارات المختلفة على الصورة.

3 للتراجع عن أحد التأثيرات ما عليك إلا لمس **تراجع** .

اقتصاص صورة

1 في شاشة التعديل المس .

2 اختر الشكل الذي تريد استخدامه لاقتصاص الصورة.

3 قم بسحب الصندوق إلى المنطقة التي تود اقتصاصها.

4 حين تنتهي من التحديد، المس **حفظ** .

إضافة تدرج لون إلى صورة

1 في شاشة التعديل، المس **الصورة** .

2 اختر **تدرج الألوان**.

3 حدد جزءاً من الصورة. يظهر خط مرسوم حول كل شيء موجود في تلك المنطقة يكون من اللون نفسه أو من لون مشابه، مثلاً، شعر شخص ما أو ثيابه.

4 قم بتعديل شدة تدرجات الألوان وذلك بلمس **الشدة** والمس زر '+' أو '-'.

5 المس **موافق**.

6 ستتم إزالة كل الألوان من الصورة، باستثناء القسم المعلّم لتدرجات الألوان.

7 تحديد **حفظ** لحفظ التغييرات.

مبادلة الألوان في صورة

1 في شاشة التعديل، المس الصورة .

2 اختر **مبادلة الألوان**.

3 حدد جزءاً من الصورة. يظهر خط مرسوم حول كل شيء موجود في تلك المنطقة يكون من اللون نفسه أو من لون مشابه. مثلاً، شعر شخص ما أو ثيابه.

4 حدد لوناً.

5 اضغط على **موافق**.

6 يتغيّر لون جزء من الصورة تم تحديده لتدرجات الألوان إلى اللون المحدد.

7 تحديد حفظ لحفظ التغييرات.

تعديل مقاطع الفيديو

تتوفر ميزات تعديل الفيديو لأنواع MPEG4 باستثناء الأنواع ذات الدقة 720x480 (D1).

لا تقم بالتسجيل في هذه التنسيقات إذا كنت تخطط لتعديل الفيديو.

تشذيب طول الفيديو

1 افتح الفيديو الذي تريد تعديله، ثم المس مفتاح الخيار .

2 تحديد تعديل واختر **تشذيب/ تشذيب متعدد**.

3 المس وقم بتعيين نقطتَي البدء والإنهاء الجديدتين باستخدام تشذيب .

4 المس معاينة لتأكيد رضاك عن القصة الجديدة.

5 المس حفظ أو كطريقة بديلة، المس للعودة إلى الاستوديو وتجاهل التغييرات.

دمج مقطعَي فيديو معاً

1 افتح الفيديو الذي تريد تعديله، ثم المس مفتاح الخيار .

2 تحديد **تعديل** واختر **دمج الفيديو**.

3 ستفتح حافظة مقاطع الفيديو خاصتي. اختر الفيديو الذي تريد دمجه.

4 المس وادفع الصورة التي تريد نقلها إلى نهاية الفيديو أو بدايته.

5 المس **معاينة** لاختيار طريقة دمج مقاطع الفيديو معاً.

6 اضغط على **حفظ** ثم على **ملف جديد** لحفظ ملف الفيديو الجديد المدمج. استبدل الملف الموجود أو احفظه كملف جديد.

7 كرر هذه الخطوات لدمج المزيد من مقاطع الفيديو.

دمج صورة بفيديو

1 افتح الفيديو الذي تريد تعديله، ثم المس مفتاح الخيار .

2 تحديد **تعديل** واختر **دمج صورة**.

3 ستفتح حافظة صوري. اختر الصورة التي تريد نقلها إلى الفيديو والمس **تحديد**.

4 المس وادفع الصورة التي تريد دمجها إلى نهاية الفيديو أو بدايته.

5 المس **معاينة** لاختيار طريقة دمج الفيديو والصورة معاً.

6 اضغط على **حفظ** ثم اختر استبدال الملف الموجود أو حفظه كملف جديد.

7 كرر هذه الخطوات لدمج المزيد من الصور.

إضافة نص إلى فيديو

1 افتح الفيديو الذي تريد تعديله، ثم المس مفتاح الخيار .

2 تحديد **تعديل** وحدد **تراكب النص**.

3 المس وقم بإيقاف التشغيل مؤقتاً لتعيين نقطة البدء لمظهر النص.

4 المس بدء واختر أوضاع النص. أدخِل النص باستخدام لوحة المفاتيح والمس **موافق**.

5 المس ناحية الشاشة التي تريد ظهور النص فيها ثم المس **موافق**.

6 المس **حفظ**. استبدل الملف الموجود أو احفظه كملف جديد.

7 كرر هذه الخطوات لإضافة المزيد من النص.

الصور و مقاطع الفيديو

تراكب صورة

1 افتح الفيديو الذي تريد تعديله، ثم المس مفتاح الخيار ☰ .

2 تحديد **تعديل** واختر **تراكب الصورة**.

3 ستفتح حافظة صوري. اختر الصورة التي تريدها أن تراكب الفيديو.

4 المس ▶ وقم بالإيقاف حين تريد ظهور الصورة، ثم حدد اللاشفافية بعد لمس زر بدء.

5 المس **موافق** ثم اضغط على **إنهاء** حين تريد إيقاف تراكب الصورة.

6 المس ناحية الشاشة التي تريد ظهور النص فيها. إذا كانت الصورة كبيرةً جداً فقد تراكب الشاشة بأكملها، وليس فقط المنطقة المحددة.

7 المس **حفظ**. استبدل الملف الموجود أو احفظه كملف جديد.

8 كرر هذه الخطوات لإضافة المزيد من الصور.

إضافة مسار صوتي إلى الفيديو

1 افتح الفيديو الذي تريد تعديله، ثم المس مفتاح الخيار ☰ .

2 تحديد **تعديل** واختر **دبلجة الصوت**.

3 ستفتح حافظة أصواتي. اختر المسار الذي تريد إضافته إلى الفيديو.

4 سيتم مسح المسار الصوتي الأصلي من الفيديو.

5 إذا كان الصوت أقصر من الفيديو، فاختر ما إذا كنت ترغب في تشغيله **مرة واحدة** أو **تكرار** تشغيله.

6 استبدل الملف الموجود أو احفظه كملف جديد.

إضافة مؤثرات صوتية حية إلى الفيديو

1 افتح الفيديو الذي تريد تعديله، ثم المس مفتاح الخيار ☰.

2 تحديد **تعديل** واختر **حية**.

3 تعيين قيمة الصوت إلى الصوت الأصلي أو الصوت المسجَّل.

تغيير سرعة الفيديو

1 افتح الفيديو الذي تريد تعديله، ثم المس مفتاح الخيار ☰.

2 تحديد **تعديل** واختر **مقياس الوقت**.

3 حدد أحد الخيارات. قد يختلف ذلك بحسب معدل الإطار.

4 استبدل الملف الأصلي أو احفظه كملف جديد.

إضافة تأثير التعتيم

1 افتح الفيديو الذي تريد تعديله، ثم المس مفتاح الخيار ☰.

2 تحديد **تعديل** واختر **تأثير التعتيم**.

3 يظهر الفيديو في البداية بشكل تدريجي ويتلاشى في النهاية.

4 استبدل الملف الأصلي أو احفظه كملف جديد.

الوسائط المتعددة

يمكنك تخزين ملفات الوسائط المتعددة في ذاكرة الهاتف بحيث يتوفر لديك وصول سهل إلى كل الصور، والأصوات، ومقاطع الفيديو والألعاب. كما يمكنك حفظ ملفاتك في بطاقة الذاكرة. يسمح لك استخدام بطاقة الذاكرة بتحرير مساحة في ذاكرة الهاتف.

للوصول إلى قائمة الوسائط المتعددة، المس حدد **أشيائي** في علامة التبويب الوسائط المتعددة. يمكنك فتح قائمة بالحافظات حيث يتم تخزين كل ملفات الوسائط المتعددة الخاصة بك.

تلميح! لحذف أي ملف في أشيائي، المس ثم **حذف**.

صور

الصور تحتوي على قائمة بالصور تتضمن الصور الافتراضية التي تم تحميلها مسبقاً إلى هاتفك، وصوراً قمت أنت بتنزيلها وصوراً تم التقاطها بكاميرا الهاتف.

قوائم خيارات صوري

تتوقف الخيارات المتوفرة لك في **الصور** على نوع الصورة التي حددتها. ستتوفر كل الخيارات بالنسبة للصور التي التقطتها بكاميرا الهاتف، أما الخيارات **تعيين المفضلات**، **وفرز حسب**، **وعرض شرائح** و**معلومات الذاكرة** فتتوفر للصور الافتراضية فقط.

إرسال صورة

1. لإرسال صورة، ما عليك سوى تحديد الصورة التي تريدها.
2. المس زر ارسال للاختيار ما بين رسالة الوسائط المتعددة، البريد الالكتروني، البلوتوث.
3. إذا اخترت **رسالة** أو **بريد إلكتروني**، فسيتم إرفاق صورتك بالرسالة ويمكنك كتابة الرسالة وإرسالها بشكل عادي. إذا اخترت **بلوتوث**، فسيبحث الهاتف عن جهاز لإرسال الصورة إليه.

استخدام صورة

يمكنك اختيار الصور لاستخدامها كخلفيات للشاشة وكشاشات توقف، أو حتى لتعريف المتصل.

1 المس ثم حدد **أشيائي** في علامة التبويب الوسائط المتعددة.

2 المس **الصور**.

3 حدد صورة والمس .

4 المس **استخدام كـ** واختر من ضمن:

الشاشات الرئيسية - لضبط خلفية لكل من الشاشات الرئيسية،شاشة ادوات المستخدم، شاشة الاسماء، شاشة الوسائط.

شاشة قفل المفاتيح - قم بتعيين خلفية لشاشة قفل المفاتيح.

الاسماء - تعيين صورة إلى شخص في قائمة جهات الاتصال المتوفرة لديك بحيث تظهر الصورة عند اتصاله بك.

صورة بدء التشغيل - قم بتعيين صورة بحيث تظهر عند تشغيل الهاتف.

صورة إيقاف التشغيل - قم بتعيين صورة بحيث تظهر عند إيقاف تشغيل الهاتف.

صورة مكالمات صادرة - قم بتعيين صورة بحيث تظهر أثناء المكالمات الصادرة.

صورة المكالمات الواردة - قم بتعيين صورة بحيث تظهر أثناء المكالمات الواردة.

طباعة صورة

1 المس ثم حدد **أشيائي** في علامة التبويب الوسائط المتعددة.

2 المس **الصور**.

3 حدد صورة والمس .

4 المس **طباعة**، ثم اختر من ضمن **بلوتوث** و **PictBridge**.

الوسائط المتعددة

نقل صورة أو نسخها

يمكن نقل صورة أو نسخها بين ذاكرة الهاتف وبطاقة الذاكرة. قد تقوم بذلك لتحرير بعض مسافة في إحدى وحدات الذاكرة، أو لمنع فقدان الصور.

1 المس ثم حدد **أشيائي** في علامة التبويب الوسائط المتعددة.

2 المس **الصور**.

3 المس .

4 حدد **نقل** أو **نسخ**.

إنشاء عرض شرائح

إذا أردت عرض كل الصور الموجودة على الهاتف، فيمكنك إنشاء عرض شرائح يوفر عليك عملية فتح كل صورة وإغلاقها بشكل فردي.

1 المس ثم حدد **أشيائي** في علامة التبويب الوسائط المتعددة.

2 المس **الصور**.

3 المس ثم **عرض الشرائح**.

التحقق من حالة الذاكرة

يمكنك التحقق من حالة الذاكرة لمعرفة مسافة التي استخدمتها مسافة المتبقية.

1 المس ثم حدد **أشيائي** في علامة التبويب الوسائط المتعددة.

2 المس **الصور**.

3 المس ثم **مدير الذاكرة**.

أصوات

تحتوي حافظة **أصواتي** على الأصوات التي تم تنزيلها، وعلى **أصوات افتراضية** و**تسجيلات الأصوات**. ومن هنا يمكنك إدارة الأصوات، أو إرسالها أو تعيينها كنغمات رنين.

استخدام صوت

1 المس ثم حدد **أشيائي** في علامة التبويب الوسائط المتعددة.

2 المس **أصواتي**.

3 حدد **أصوات افتراضية** أو **تسجيلات الأصوات**.

4 حدد صوتاً والمس رمز التشغيل. يبدأ التشغيل تلقائياً.

5 يمكنك استخدام الصوت لمجموعة مختلفة من النغمات عبر تحديد قائمة **استخدام كـ**.

6 اختر من ضمن **نغمة رنين الصوت** **نغمة رنين الفيديو** **نغمة الرسائل**.

مقاطع فيديو

تعرض حافظة **مقاطع الفيديو خاصتي** قائمة بمقاطع الفيديو التي قمت بتنزيلها إلى هاتفك أو بتسجيلها عليه.

مشاهدة فيديو

1 المس ثم حدد **أشيائي** في علامة التبويب الوسائط المتعددة.

2 المس **الفيديو** .

3 حدد فيديو ليتم تشغيله.

تلميح! يدعم GD900 تشغيل تنسيقَي الفيديو DivX وXvid لضمان توفر محتوى أفضل. يرجى العودة إلى الصفحة 91 للحصول على التفاصيل.

ملاحظة: يمكن شراء كبل إخراج التلفزيون بشكل منفصل.

الوسائط المتعددة

إرسال ملف فيديو

1 حدد فيديو والمس ☰ .

2 المس زر ارسال للاختيار ما بين رسالة الوسائط المتعددة, البريد الالكتروني, البلوتوث.

3 إذا اخترت **رسالة** أو **بريد إلكتروني**، فسيتم إرفاق ملف الفيديو بالرسالة ويمكنك كتابتها وإرسالها بشكل عادي. إذا اخترت **بلوتوث**، فسيبحث الهاتف عن جهاز لإرسال الفيديو إليه.

ألعاب وتطبيقات

يمكنك تنزيل ألعاب وتطبيقات جديدة إلى هاتفك لمساعدتك على التسلية.

تشغيل لعبة

1 المس ⁞⁞ ثم حدد **ألعاب وتطبيقات** في علامة التبويب الوسائط المتعددة.

2 المس قائمة **ألعاب وتطبيقات**.

3 المس زر بدء التشغيل لتشغيل لعبة أو تطبيق.

استخدام قائمة الخيارات

تتوفر ضمن حافظتي الألعاب والتطبيقات الخيارات التالية:

- **مجلد جديد:** إنشاء حافظة ضمن الألعاب أو التطبيقات
- **ترتيب حسب:** فرز الألعاب والتطبيقات بحسب التاريخ، أو الاسم، أو الحجم أو الذاكرة.
- **مدير الذاكرة:** عرض حالة الذاكرة في الهاتف أو في بطاقة الذاكرة الخارجية.
- **معلومات الحافظة.** : عرض معلومات الحافظة

جار تثبيت لعبة Java وتطبيقها

1 المس ⁞⁞ ثم حدد **أشيائي** في علامة التبويب الوسائط المتعددة.

2 إذا قمت بإدخال بطاقة ذاكرة جديدة، فالمس قائمة الذاكرة الخارجية.

3 حدد الملف(*.jad أو *.jar) الذي تريد تثبيته ثم المس **تثبيت**.

استخدام قائمة M-Toy

تحتوي M-Toy على ألعاب فلاش تم تحميلها مسبقاً تستخدم جهاز استشعار الحركة المضمّن.

محتويات الفلاش

تحتوي حافظة محتويات الفلاش على كل ملفات SWF الافتراضية وتلك التي قمت بتنزيلها.

عرض ملف SWF/ SVG

1 المس ثم حدد **أشيائي** في علامة التبويب الوسائط المتعددة.

2 المس **محتويات الفلاش**.

3 حدد الملف الذي تريد عرضه.

مستندات

هذا ممكن مع ملفات Excel، وPowerPoint، و Word، وText وpdf.

عرض ملف

1 المس ثم حدد **أشيائي** في علامة التبويب الوسائط المتعددة.

2 المس **مستندات**.

3 حدد مستنداً والمس **عرض**.

نقل ملف إلى هاتفك

تُعتبر تقنية بلوتوث الطريقة الأسهل على الأرجح لنقل ملف من الكمبيوتر إلى هاتفك. كما يمكنك استخدام LG PC Suite عبر كابل التزامن. راجع الصفحة 87 للحصول على التفاصيل.

لنقل الملفات (شأن الموسيقى) باستخدام بلوتوث:

1 تأكد من تشغيل بلوتوث على الهاتف والكمبيوتر ومن كونهما ضمن نطاق بعضهما البعض

2 استخدم الكمبيوتر لإرسال الملف عبر بلوتوث.

3 عندما يُرسل الملف إليك، اقبله على الهاتف بلمس **نعم**.

4 يجب أن يظهر الملف في حافظة **مستندات** أو في حافظة **أخرى**.

أخرى

تُستخدم الحافظة **أخرى** لتخزين ملفات ليست عبارة عن صور، أو ملفات صوت، أو مقاطع فيديو، أو ألعاب أو تطبيقات. وهي تُستخدم بالطريقة نفسها التي يتم بها استخدام حافظة **مستندات**. وقد يتبيّن لك عند نقل الملفات من الكمبيوتر إلى الهاتف أنها تظهر في الحافظة **أخرى**.

إذا حدث مثل هذا الأمر، فيمكنك نقل الملفات.

إنشاء فيلم

1 المس ثم حدد **صانع أفلام** في علامة التبويب الوسائط المتعددة.

2 المس **إدراج** لإضافة صورة.

3 المس علامة التبويب **وضع** في الأعلى لاختيار نمط الفيلم.

4 المس علامة التبويب **صوت** على الشاشة لتغيير الصوت، مثلاً صوت تسجيل صوتي.

5 المس زر **معاينة** لمشاهدة النتائج.

6 المس علامة التبويب **ترتيب التشغيل** على الشاشة لتغيير الترتيب.

7 المس علامة التبويب **حفظ في** على الشاشة لاختيار الموقع الذي تريد حفظ الفيلم فيه، والمس علامة التبويب **استخدام** للاختيار بين تخزينه أو إرساله كـ MMS.

8 لحفظ الفيلم، اضغط على تشغيل ثم المس **حفظ الفيلم**.

الموسيقى

يكون مشغّل الموسيقى مضمّناً في الهاتف LG GD900 بحيث يمكنك تشغيل كل مسارات الموسيقى المفضلة لديك. للوصول إلى مشغّل الموسيقى، المس ثم حدد **موسيقى** في علامة التبويب الوسائط المتعددة. من هنا يمكنك الوصول إلى عدد من الحافظات:

كل المسارات - يحتوي هذا الخيار على كل الأغاني المتوفرة في هاتفك.

المفضلات - يحتوي هذا الخيار على الأغاني التي قمت بحفظها كمفضلات.

الفنانون - لعرض مجموعتك الموسيقية حسب الفنان.

الألبومات - لعرض مجموعتك الموسيقية حسب الألبوم.

الأنواع - لعرض مجموعتك الموسيقية حسب النوع.

نقل الموسيقى إلى الهاتف

الطريقة الأسهل لنقل الموسيقى إلى الهاتف تتم عبر بلوتوث أو كبل البيانات.

كما يمكنك استخدام LG PC Suite. راجع الصفحة 87 للحصول على التفاصيل. لنقل الموسيقى باستخدام بلوتوث:

1. تأكد من تشغيل بلوتوث على الجهازين ومن كونهما متصلَين ببعضهما.
2. حدد ملف الموسيقى على الجهاز الآخر ثم حدد إرسال عبر بلوتوث.
3. عندما يُرسل الملف إليك، اقبله على الهاتف بلمس **نعم**.
4. يجب أن يظهر الملف في **موسيقى** > **كل المسارات**.

الوسائط المتعددة

تشغيل أغنية

1 المس ثم حدد **موسيقى** في علامة التبويب الوسائط المتعددة.

2 المس **كل المسارات**.

3 حدد الأغنية التي تريد تشغيلها ثم المس .

4 المس لإيقاف الأغنية مؤقتاً.

5 المس للتجاوز إلى الأغنية التالية.

6 المس للرجوع إلى الأغنية السابقة.

7 المس للعودة إلى قائمة **موسيقى**.

لتغيير مستوى الصوت أثناء الاستماع إلى الموسيقى، المس . أو حرّك عجلة اللمس على شاشة اللمس الشفافة في اتجاه عقارب الساعة لزيادة مستوى الصوت أو باتجاه معاكس لحركة عقارب الساعة لتخفيضه. عليك تنشيط مؤشر التباين أولاً عبر لمس .

إنشاء قائمة تشغيل

يمكنك إنشاء قوائم التشغيل الخاصة بك وذلك بإنشاء مجموعة مختارة من الأغاني من حافظة **كل المسارات**.

1 المس ثم حدد **موسيقى** في علامة التبويب الوسائط المتعددة.

2 المس رمز خيار .

3 المس **قائمة تشغيل جديدة**، ثم أدخِل اسم قائمة التشغيل والمس .

4 فتظهر حافظة كل المسارات. المس كل الأغاني التي تريد تضمينها في قائمة التشغيل، فتظهر علامةً إلى جانب اسم كل مسار.

5 المس **إضافة أغانٍ**.

لتشغيل قائمة تشغيل، حددها والمس تشغيل.

ملاحظة: لإضافة قائمة تشغيل ثانية، المس ثم قائمة تشغيل جديدة.

حذف قائمة تشغيل

1 المس ثم حدد **موسيقى** في علامة التبويب الوسائط المتعددة.

2 المس رمز خيار .

3 المس **حذف** أو **حذف الكل** لحذف كل قوائم التشغيل.

استخدام الراديو

تتوفر في طراز الهاتف LG GD900 ميزة راديو FM بحيث يمكنك ضبط محطاتك المفضلة للاستماع إليها أثناء التنقل.

ملاحظة: ستحتاج إلى توصيل سماعات الرأس لتتمكن من الاستماع إلى الراديو. قم بإدراج سماعات الرأس في المقبس المخصص لها.

البحث عن محطات

يمكنك ضبط محطات الراديو في هاتفك وذلك بالبحث عنها إما يدوياً أو تلقائياً. وسيتم حينئذٍ حفظها في أرقام قنوات معينة بحيث لن تعود بحاجة إلى إعادة ضبطها. ويمكنك تخزين ما يصل إلى 30 قناة في هاتفك.

للضبط تلقائياً

1 المس ثم حدد **راديو FM** في علامة التبويب الوسائط المتعددة.

2 المس .

3 المس **تفحص تلقائي** ثم **نعم**. سيتم تخصيص رقم قناة لكل محطة يتم العثور عليها في هاتفك عبر تحديد **تعيين**، و**تجاوز** و**إيقاف**.

ملاحظة: يمكنك أيضاً ضبط إحدى المحطات يدوياً باستخدام العجلة التي تظهر إلى جانب تردد الراديو.

إعادة تعيين القنوات

1 المس ثم حدد **راديو FM** في علامة التبويب الوسائط المتعددة.

2 المس .

3 اختر **إعادة تعيين** لإعادة تعيين القناة الحالية أو اختر **إعادة تعيين الكل** لإعادة تعيين كل القنوات. إذا قمت بإعادة تعيين كل القنوات، فستعود كل قناة إلى التردد 87.5 ميغا هرتز وهو تردد البداية.

الاستماع إلى الراديو

1 المس ثم حدد **راديو FM** في علامة التبويب الوسائط المتعددة.

2 المس رقم قناة المحطة التي تريد الاستماع إليها.

تلميح! لتحسين استقبال الراديو، قم بتمديد سلك سماعة الرأس الذي يعمل كهوائي الراديو.

تحذير! إذا قمت بتوصيل سماعة الرأس غير المناسبة بالهاتف، فقد يتسبب ذلك بتشويش استقبال الراديو.

المنسّق

إضافة حدث إلى التقويم

1 في الشاشة الرئيسية حدد ثم قم بالتمرير إلى **المنسّق** في علامة التبويب أدوات مساعدة. حدد **التقويم**.

2 حدد التاريخ الذي تريد إضافة حدث إليه.

3 المس ثم **جدول جديد**.

4 المس **فئة** ثم اختر من ضمن **موعد**، أو **ذكرى** أو **عيد ميلاد**. تحقق من التاريخ وأدخِل الوقت الذي تريد أن يبدأ عنده الحدث.

5 بالنسبة إلى المواعيد ومناسبات الذكرى السنوية، أدخِل تاريخ ووقت انتهاء الحدث في المربّعين السفليين للتاريخ والوقت.

6 إذا كنت ترغب في إضافة موضوع أو ملاحظة إلى الحدث، فالمس **موضوع** واكتب التفاصيل.

7 حدد **تعيين منبه** لتعيين تنبيه للحدث. إذا أردت تكرار المنبه، حدد **تعيين التكرار**.

8 المس لحفظ الحدث في التقويم. يقوم مربع ملوّن في التقويم بوضع علامة على كل الأيام التي تم حفظ أحداث فيها، وسيرن منبه في وقت البدء المعيّن للحدث لمساعدتك على تنظيم أوقاتك.

تلميح! يمكنك إدخال أيام العطل إلى التقويم. المس كل يوم من أيام العطل على حدة، ثم المس وحدد **تعيين أيام العطل**. سيتم تحديد كل يوم باللون الأحمر.

تغيير عرض التقويم الافتراضي

1 في الشاشة الرئيسية حدد ثم قم بالتمرير إلى **المنسّق** في علامة التبويب أدوات مساعدة. تحدد **ضوابط** في .

2 المس **عرض افتراضي** واختر التقويم، أو أسبوع، أو جدول زمني، أو قائمة أو كل المهام.

إضافة عنصر إلى قائمة المهام

1 في الشاشة الرئيسية حدد ثم قم بالتمرير إلى **المنسّق** في علامة التبويب أدوات مساعدة.

2 حدد حدد **مهمة جديدة** والمس **ملاحظة**.

3 قم بتعيين تاريخ المهمة، وأضف ملاحظات، ثم حدد مستوى الأولوية: **مرتفع**، أو **متوسط** أو **منخفض**.

4 قم بحفظ المهمة عبر تحديد .

تلميح! يمكنك إجراء نسخ احتياطي للتقويم ومزامنته مع الكمبيوتر. راجع التزامن مع الكمبيوتر الشخصي في الصفحة 87.

استخدام الباحث عن التاريخ

الباحث عن التاريخ هو أداة سهلة تساعدك على احتساب تاريخ الأيام القليلة المقبلة. مثلاً بعد 60 يوماً من التاريخ 10.10.09 سيكون التاريخ 09.12.2009.

تساعدك هذه الأداة على تعقّب المواعيد المحددة.

1 في الشاشة الرئيسية حدد ثم قم بالتمرير إلى **المنسّق** في علامة التبويب أدوات مساعدة.

2 حدد ، حدد **محدد التاريخ**.

3 قم بتعيين التاريخ المطلوب في علامة التبويب **من**.

4 في علامة التبويب **بعد**، قم بتعيين عدد الأيام.

5 يظهر **تاريخ الهدف** أدناه.

تعيين المنبّه

1 في الشاشة الرئيسية حدد ثم قم بالتمرير إلى **تنبيهات** في علامة التبويب أدوات مساعدة.

2 إذا أردت إضافة منبه جديد، فالمس **منبه جديد**. إذا أردت تعيين المنبه للرنين مجدداً بعد ساعة، فالمس **منبه سريع**.

3 قم بتعيين الوقت الذي تريد أن يبدأ فيه المنبه بالرنين.

4 اختر ما إذا كنت ترغب في أن يرن المنبه تكراراً، وذلك بتعيين التكرار والنوع.
تشير الرموز إلى يوم الأسبوع الذي اخترته.

5 حدد **صوت/ اهتزاز** لتحديد نوع المنبه الذي تريده.

6 المس **جرس المنبه** لتحديد نغمة التنبيه أو الصوت. للاستماع إلى الأصوات، المس الصوت يتبعه .

7 إضافة مذكرة إلى المنبه.

إضافة مذكرة

1 في الشاشة الرئيسية حدد ثم قم بالتمرير إلى **مذكرة** في علامة التبويب أدوات مساعدة.

2 المس **مذكرة جديدة**.

3 اكتب مذكرتك، ثم المس .

تلميح! يمكنك تعديل مذكرة موجودة. حدد المذكرة التي تريد تعديلها ، ثم المس **تعديل** وأدخِل التغييرات.

مسجّل الصوت

استخدم مسجّل الصوت لتسجيل مذكرات صوتية أو ملفات صوت أخرى.

تسجيل ملف صوتي أو صوت

1 المس .

2 المس **مسجّل الصوت** في علامة التبويب أدوات مساعدة.

3 اختر اين تريد حفظ التسجيل الصوتي ما بين ذاكرة الهاتف والذاكرة الخارجية.

4 اختر نوع التسجيل ما بين رسالة وسائط متعددة او عام.

5 المس **تسجيل** لبدء التسجيل.

6 المس **إيقاف** لإنهاء التسجيل.

7 إذا رغبت في إعادة تسجيل الصوت، فالمس **جديد** .

إرسال التسجيل الصوتي

1 حالما تنتهي من التسجيل، يمكنك إرسال مقطع صوتي عبر لمس **إرسال**.

2 اختر من ضمن **رسالة**، أو **بريد إلكتروني** أو **بلوتوث**. إذا اخترت **رسالة** أو **بريد إلكتروني**، فسيضاف التسجيل إلى الرسالة ويمكنك كتابتها وإرسالها بشكل عادي. إذا اخترت **بلوتوث**، فسيبحث الهاتف عن جهاز لإرسال التسجيل الصوتي إليه.

استخدام الحاسبة

1 في الشاشة الرئيسية حدد ، ثم قم بالتمرير إلى **الحاسبة** في علامة التبويب أدوات مساعدة.

2 المس مفاتيح الأرقام لإدخال الأرقام.

3 بالنسبة إلى الحسابات البسيطة، المس الوظيفة التي تحتاج إليها (+، أو –، أو x أو ÷)، يليها =.

4 أما بالنسبة إلى العمليات الحسابية الأكثر تعقيداً، فالمس واختر من ضمن **sin**، أو **cos**، أو **tan**، أو **deg**، أو **log**، إلخ.

تحويل وحدة

1 في الشاشة الرئيسية حدد ، ثم قم بالتمرير إلى **الأدوات** في علامة التبويب أدوات مساعدة.

2 حدد **محوّل الوحدة**.

3 اختر ما إذا كنت ترغب في تحويل وحدات **العملة**، أو **المساحة**، أو **الطول**، أو **الوزن**، أو **درجة الحرارة**، أو **الحجم** أو **السرعة**.

4 ثم حدد الوحدة وأدخِل القيمة التي تريد التحويل منها.

5 ستظهر حينئذٍ القيمة المناسبة على الشاشة.

استخدام ساعة إيقاف

1 في الشاشة الرئيسية حدد ، ثم المس **أدوات مساعدة**.

2 حدد **ساعة إيقاف**.

3 المس **بدء** لبدء التوقيت.

4 المس **التداخل** إذا أردت تسجيل وقت الدورة.

5 المس **إيقاف** لإيقاف تشغيل المؤقت.

6 المس **إعادة ضبط** لإعادة بدء التوقيت من جديد.

المنسّق

إضافة مدينة إلى ساعتك العالمية

1 في الشاشة الرئيسية حدد ثم قم بالتمرير إلى **الساعة العالمية** في علامة التبويب أدوات مساعدة.

2 المس اضافة مدينة.اختر القارة و حدد المدينه من الخريطة.او المس الخيارات

3 ثم المس القائمة. ابدأ بكتابة اسم المدينة التي تريدها وسيظهر الاسم على الشاشة.

4 المس المدينة لتحديدها. وستتم إضافتها إلى قائمة الساعة العالمية.

PC Suite

يمكنك مزامنة الكمبيوتر مع الهاتف. يساعدك ذلك على التأكد من تطابق كل التفاصيل والتواريخ الهامة، ولكن أيضاً لتشكيل نسخة احتياطية بحيث تكون مرتاح البال.

تلميح! لتتمكن من فعل ذلك، عليك تثبيت تطبيق PC Suite المزوّد على القرص المضغوط أو المتوفر للتنزيل على الموقع التالي http://update.lgmobile.com. (في www.lgmobile.com > انتقل إلى المنتجات > الدليل والبرنامج > قسم تنزيل الدليل والبرنامج)

تثبيت برنامج LG PC Suite على الكمبيوتر

1 في الشاشة الرئيسية حدد ، ثم قم بالتمرير إلى **التوصيل** في علامة التبويب إعدادات.

2 المس **وضع اتصال USB**.

3 قم بتوصيل الهاتف بالكمبيوتر مستخدماً كبل USB ثم انتظر قليلاً.

4 تظهر رسالة دليل التثبيت

تنبيه! في حال عدم ظهور رسالة دليل التثبيت على جهاز الكمبيوتر، يرجى التحقق من ضبط القرص المضغوط على Windows.

5 قم بإدراج القرص المضغوط المزوّد أو انقر فوق زر التنزيل لتنزيل برنامج LG PC Suite مباشرةً من موقع ويب.

6 انقر فوق مثبّت LG PC Suite الذي يظهر على الشاشة.

توصيل الهاتف والكمبيوتر

1 حدد وضع PC Suite في قائمة التوصيل ثم قم بتوصيل كبل USB بهاتفك والكمبيوتر.

2 سيتم تنشيط برنامج LG PC Suite تلقائياً على جهاز الكمبيوتر.

تنبيه! في حال عدم تنشيط LG PC Suite تلقائياً على جهاز الكمبيوتر لديك، يرجى التحقق من ضبط القرص المضغوط على الكمبيوتر.

3 أصبح الآن هاتفك والكمبيوتر متصلين ببعضهما.

إجراء نسخ احتياطي لمعلومات الهاتف واستعادتها

1 قم بتوصيل الهاتف بالكمبيوتر كما تم توضيحه أعلاه.

2 انقر فوق الرمز **نسخ احتياطي** وحدد **نسخ احتياطي** أو **استعادة**.

3 اختر إجراء نسخ احتياطي لـ **بيانات المحتويات** و/أو بيانات **دليل الهاتف/الجدول/المهمة/المذكرة**. حدد الموقع الذي تريد إجراء نسخ احتياطي للمعلومات فيه، أو استعادة المعلومات منه. انقر فوق **موافق**.

4 سيتم إجراء نسخ احتياطي للمعلومات.

عرض ملفات الهاتف على الكمبيوتر

1 قم بتوصيل الهاتف بالكمبيوتر كما تم توضيحه أعلاه.

2 انقر فوق رمز **إدارة الملفات**.]

3 تظهر على الشاشة في حافظة هاتف LG كل المستندات، ومحتويات الفلاش، والصور، وملفات الصوت ومقاطع الفيديو التي حفظتها في الهاتف.

تلميح! يساعدك عرض محتويات الهاتف على الكمبيوتر على ترتيب الملفات، وتنظيم المستندات وإزالة المحتويات التي لم تعد بحاجة إليها.

مزامنة الأسماء

1 توصيل الهاتف بالكمبيوتر.

2 انقر فوق رمز **جهات الاتصال**.

3 سيقوم الكمبيوتر الآن باستيراد وعرض كل الأسماء المحفوظة في بطاقة SIM والهاتف.

4 انقر فوق **ملف** وحدد **حفظ**. يمكنك الآن تحديد الموقع حيث تريد حفظ الأسماء.

ملاحظة: لإجراء نسخ احتياطي الأسماء المحفوظة في بطاقة SIM، انقر فوق حافظة بطاقة SIM في الجانب الأيسر من شاشة الكمبيوتر. انقر بزر الماوس الأيمن فوق إحدى الأسماء واختر **تحديد الكل**، ثم **نسخ** أو **نقل إلى ذاكرة الهاتف**.

انقر بزر الماوس الأيمن فوق الأسماء وحدد **نسخ إلى جهة اتصال**. انقر الآن فوق حافظة **الهاتف** على يسار الشاشة فتظهر كل الأرقام.

مزامنة الرسائل

1 توصيل الهاتف بالكمبيوتر.

2 انقر فوق رمز الرسائل.

3 تظهر كل رسائل الكمبيوتر والهاتف في حافظات على الشاشة.

4 استخدم شريط الأدوات في أعلى الشاشة لتعديل الرسائل وإعادة ترتيبها.

تزامن الموسيقى

تسمح لك هذه القائمة بإضافة موسيقى إلى الهاتف GD900. قبل البدء بنقل الموسيقى من الكمبيوتر إلى الجهاز، تأكد من تزويد الكمبيوتر بالإعداد والملحق التالي:

- Microsoft Windows XP أو Vista
- Windows Media Player 10 أو إصدار لاحق
- كبل USB

ملاحظة :

إذا لم يتم التعرف على هاتفك، أو إذا تعرّف عليه نظام التشغيل Windows على أنه جهاز صور.

1 اضغط على Start (ابدأ) > Control Panel (لوحة التحكم) على سطح المكتب.

2 حدّد جهاز ماسح ضوئي للصور.

3 سيتم عرض جهاز صور باسم "GD900 Music Sync Player" في لائحة الأجهزة. قم بوصل الهاتف المحمول بالكمبيوتر الشخصي الخاص بك بواسطة كبل USB (إذا لم يكن موصولاً).

4 لإزالة الجهاز، اضغط بزر الماوس الأيمن لتحديد "إزالة" في قائمة المحتويات.

5 قم بفصل كبل USB عن الهاتف المحمول.

6 ثبّت الإصدار 11 من Windows Media Player (WMP 11).

7 عندما يتم تثبيت WMP بنجاح، قم بوصل الهاتف المحمول بالكمبيوتر الشخصي الخاص بك.

نقل الموسيقى باستخدام Windows Media Player

1 في الشاشة الرئيسية حدد ، ثم قم بالتمرير إلى **التوصيل** في علامة التبويب إعدادات.

2 حدد **وضع اتصال USB** واختر **تزامن الموسيقى**.

3 قم بتوصيل الهاتف بالكمبيوتر مستخدماً كبل USB متوافق.

4 حين تحاول توصيل الهاتف بالكمبيوتر، سيقرأ هاتفك: جار تزامن الموسيقى... يتبعها **تم الاتصال**.

5 سيطالبك الكمبيوتر ببدء تشغيل برنامج إدارة الموسيقى المفضل لديك.

6 حدد Windows Media Player.

7 انتقل إلى علامة التبويب تزامن، ثم قم بسحب وإفلات الموسيقى التي ترغب في نقلها إلى هاتفك في الجزء **قائمة التزامن**.

8 انقر فوق زر **بدء التزامن**. سيؤدي ذلك إلى بدء عملية النقل.

⚠ تحذير

لا تقم بقطع اتصال الهاتف أثناء عملية النقل.

ملاحظة: تزامن الموسيقى متوفر فقط لمحتويات الموسيقى.

استخدام iSync

قم بتثبيت ملف تثبيت iSync المعتمد من جهاز Macintosh وأجهزة الكمبيوتر ثم قم بتوصيل الهاتف عن طريق بلوتوث أو USB.

لإجراء عملية التزامن عن طريق بلوتوث، قم بإعداد اقتران بين جهاز Macintosh أو جهاز كمبيوتر والهاتف. وإذا أردت الإعداد عن طريق USB، فحدد قائمة iSync في وضع اتصال USB.

ملاحظة: عند استخدام بلوتوث، عليك تحديد **تشغيل iSync** في قائمة الخيارات.

DivX Converter

قم بتثبيت DivX converter الذي يتم تزويدك به على القرص المضغوط نفسه حيث برنامج التزامن مع الكمبيوتر الشخصي. سيقوم DivX بتحويل ملفات الوسائط الموجودة على جهاز الكمبيوتر إلى تنسيق يسمح لك بتحميلها وعرضها على هاتفك.

حالما ينتهي التثبيت، حدد **DivX** من ملفات البرنامج في جهاز الكمبيوتر، ثم **DivX converter** يتبعه المحوّل.

استخدم الأسهم في التطبيق لتغيير تنسيق التحويل إلى Mobile. إذا نقرت فوق خانة التطبيق بزر الماوس الأيمن وحددت **تفضيلات**، فيمكنك تغيير الموقع الذي تم حفظ الملفات المحوّلة فيه.

قم بسحب الملفات وإفلاتها في التطبيق لإجراء تحليل أولي. ثم حدد **تحويل** كي تبدأ العملية. عندما تكتمل العملية، يظهر إطار منبثق لإعلامك باكتمال عملية التحويل.

حول DIVX VIDEO: DivX® هو تنسيق فيديو ابتكرته شركة DivX, Inc.. هذا جهاز DivX Certified ورسمي يشغّل ملفات الفيديو بتنسيق DivX. تفضل بزيارة www.divx.com للحصول على مزيد من المعلومات وأدوات البرامج لتحويل ملفاتك إلى ملفات فيديو بتنسيق DivX.

حول DIVX VIDEO-ON-DEMAND:
يجب تسجيل جهاز DivX Certified® بهدف تشغيل محتوى DIVX VIDEO-ON-DEMAND (VOD). لإنشاء رمز التسجيل، حدّد موقع قسم DivX VOD في قائمة إعداد الجهاز. انتقل إلى موقع vod.divx. com بواسطة هذا الرمز لإكمال عملية التسجيل واعرف المزيد عن DivX VOD.

المتصفح

المتصفح يصلك بعالم سريع وكامل من الألعاب، والموسيقى، والأخبار، والرياضة، والترفيه وغيرها، مباشرةً من هاتفك المحمول. حيثما كنت ومهما كنت تفعل.

الوصول إلى ويب

1 في الشاشة الرئيسية حدد ثم قم بالتمرير إلى **المتصفح** في علامة التبويب اتصال.

2 للانتقال مباشرةً إلى صفحة المتصفح الرئيسية، حدد **الصفحة الرئيسية**. كطريقة بديلة، حدد **إدخال العنوان** واكتب عنوان URL، يتبعه **اتصال**.

ملاحظة: يتم فرض رسم إضافي عند الاتصال بهذه الخدمات وتنزيل المحتوى. اتصل بموفر الشبكة للتحقق من رسوم البيانات.

إضافة إشارات مرجعية والوصول إليها

لكي تتمكّن من الوصول إلى مواقعك المفضلة على ويب بشكل سريع وسهل، يمكنك إضافة إشارات مرجعية وحفظ صفحات ويب.

1 في الشاشة الرئيسية حدد ثم قم بالتمرير إلى **المتصفح** في علامة التبويب اتصال.

2 حدد **العلامات**. تظهر قائمة بالإشارات المرجعية على الشاشة.

3 لإضافة إشارة مرجعية جديدة، حدد والمس **إشارة مرجعية جديدة**. أدخِل اسماً للإشارة المرجعية يتبعه URL.

4 المس . تظهر إشارتك المرجعية الآن في قائمة الإشارات المرجعية.

5 للوصول إلى الإشارة المرجعية، ما عليك إلا لمس الإشارة المرجعية ومن ثم لمس توصيل. سيتم توصيلك بالإشارة المرجعية.

استخدام قارئ RSS

إنّ RSS (Really Simple Syndication) عي عبارة عن تنسيقات موجز ويب يتم استخدامها لنشر المحتوى الذي يتكرر تحديثه، شأن إدخالات المدونات، أو عناوين الأخبار أو البث الصوتي على ويب. ويحتوي مستند RSS، والذي يُعرف بالموجز، أو بموجز ويب أو قناة، على ملخص محتوى من موقع ويب مقترن أو على النص الكامل. يسمح RSS للأشخاص بالبقاء على اطلاع على آخر أخبار مواقعهم المفضلة على ويب بطريقة مؤتمتة أسهل من التدقيق في المواقع يدوياً. وباستطاعة المستخدم الاشتراك في موجز عبر إدخال ارتباط الموجز في القارئ أو عبر النقر فوق رمز RSS في متصفح يبدأ عملية الاشتراك. ويتحقق القارئ من موجزات ويب التي اشترك فيها المستخدم بشكل دوري بحثاً عن محتوى جديد، ويقوم بتنزيل أي تحديثات يعثر عليها.

الوصول إلى صفحة محفوظة

1 في الشاشة الرئيسية حدد ثم قم بالتمرير إلى **المتصفح** في علامة التبويب اتصال.

2 حدد **الصفحات المحفوظة**.

3 قم بتحديد الصفحة التي تود عرضها وسيتم فتحها.

عرض محفوظات المتصفح

1 في الشاشة الرئيسية حدد ثم قم بالتمرير إلى **المتصفح** في علامة التبويب اتصال. حدد **سجل**.

2 سيتم عرض صفحات ويب التي وصلت إليها مؤخراً. للوصول إلى إحدى هذه الصفحات، ما عليك إلا تحديدها.

تغيير إعدادات متصفح ويب

1 في الشاشة الرئيسية حدد ثم قم بالتمرير إلى **التوصيل** في علامة تبويب الاعدادات.

2 حدد **إعدادات المتصفح**.

3 يمكنك تعديل الاوضاع. اعدادات العرض, الذاكرة المؤقتة\ ملفات الارتباط, الحماية, او اعادة الضبط.

4 يمكنك بكل بساطة تعيينها إلى تشغيل أو إيقاف تشغيل عبر لمس رمز التبديل.

استخدام الهاتف كمودم

يمكن استخدام الهاتف GD900 كمودم للكمبيوتر ما يمنحك وصولاً إلى البريد الإلكتروني وإنترنت حتى عندما لا يكون لديك أي اتصال سلكي. يمكنك القيام بذلك مستخدماً كبل USB أو بلوتوث.

استخدام كبل USB:

1 تأكد من تثبيت LG PC Suite على الكمبيوتر.

2 قم بتوصيل الهاتف GD900 والكمبيوتر باستخدام كبل USB، ثم ابدأ بتشغيل برنامج LG PC Suite.

3 انقر فوق **اتصال** على الكمبيوتر. ثم انقر فوق **ضوابط** وحدد **مودم**.

4 اختر **مودم USB لمحمول LG** وحدد **موافق**. يظهر الآن على الشاشة.

5 انقر فوق اتصال فيتصل الكمبيوتر من خلال GD900.

ملاحظة: للحصول على مزيد من المعلومات حول إجراء التزامن باستخدامLG PC Suite، راجع الصفحة 87.

استخدام بلوتوث:

1. تأكد من كون بلوتوث **قيد التشغيل** و**مرئي** بالنسبة إلى الكمبيوتر والهاتف GD900.
2. قم بإقران الكمبيوتر وهاتف GD900 بحيث يكون رمز المرور مطلوباً للاتصال.
3. استخدم **معالج الاتصال** على LG PC Suite لإنشاء اتصال بلوتوث نشط.
4. انقر فوق **اتصال** على الكمبيوتر. ثم انقر فوق **ضبط**.
5. انقر فوق **مودم**.
6. اختر **مودم قياسي على ارتباط بلوتوث** وانقر فوق **موافق**. يظهر الآن على الشاشة.
7. انقر فوق **اتصال** فيتصل الكمبيوتر من خلال GD900.

ملاحظة: للحصول على مزيد من المعلومات حول بلوتوث، راجع الصفحة 102.

وصول إلى خرائط Google

يمكنك استخدام خدمات التنقل في Google في علامة التبويب اتصال. حدد قائمة خرائط Google في Google لبدء تشغيل التطبيق. يرجى الملاحظة أنه قد يفرض عليك رسماً إضافياً لدى استخدام هذه الخدمة.

الإعدادات

تساعدك هذه الحافظة على تكييف ضبط لتخصيص الهاتف GD900.

ملاحظة: للحصول على معلومات حول إعدادات المكالمة، راجع الصفحة 34.

تغيير إعدادات الشاشة

1 في الشاشة الرئيسية حدد ثم قم بالتمرير إلى **إعدادات الشاشة** في علامة تبويب الاعدادات.

2 يمكنك اختيار قائمة الخيارات من ضمن:

صور الشاشة - اختر صورةً للإقفال، أو تشغيل الهاتف وإيقاف تشغيله، أو إجراء مكالمة أو استلام مكالمة.

ملاحظة: ستتم إعادة تعيين الضبط إذا حددت قائمة **إعادة تعيين**.

شاشات رئيسية - عنصر واجهة الاستخدام/ جهة اتصال/الوسائط المتعددة/ اختصار

إقفال الشاشة - اختر نوع الساعة على الشاشة المقفلة.

الخط - قم بضبط حجم الخط وضع.

الإضاءة الخلفية - اختر فترة تشغيل الإضاءة الخلفية.

ملاحظة: بقدر ما تطول فترة تشغيل الإضاءة الخلفية، بقدر ما يتم استخدام طاقة البطارية وقد تحتاج بالتالي إلى شحن هاتفك بشكل متكرر.

السطوع التلقائي - قم بضبط سطوع الشاشة تلقائياً.

السطوع - قم بضبط سطوع الشاشة.

تخصيص الأوضاع

يمكنك أن تقوم بسرعة بتغيير الوضع على الشاشة الرئيسية. ما عليك سوى لمس رمز ملخص الحالة في الأعلى ولمس علامة التبويب الوضع .

يمكنك تخصيص كل إعدادات الوضع باستخدام قائمة ضبط.

1 في الشاشة الرئيسية حدد ثم قم بالتمرير إلى **الأوضاع** في علامة تبويب الاعدادات.

2 اختر الوضع الذي تريد تعديله: **عادي**، أو **صامت**، أو **بالخارج** أو **وضع الرحلات الجوية**.

3 يمكنك حينئذٍ تغيير كل خيارات الأصوات والتنبيهات المتوفرة في القائمة، بما فيها **نغمة رنين الصوت/نغمة رنين الفيديو**، و**مستوى الصوت**، و**تنبيهات الرسائل** وغيرها.

تغيير إعدادات الهاتف

استخدم حرية تكييف الهاتف GD900 مع تفضيلاتك الخاصة.

1 في الشاشة الرئيسية حدد ثم قم بالتمرير إلى **إعدادات الهاتف** في علامة تبويب الاعدادات.

2 حدد قائمة من الخيارات أدناه:

التاريخ والوقت - قم بضبط ضوابط التاريخ والوقت أو اختر تحديث الوقت بشكل تلقائي عند السفر أو للتوقيت الصيفي.

توفير الطاقة - اختر **تشغيل** أو **إيقاف تشغيل** إعدادات ميزة توفير الطاقة.

اللغات - قم بتغيير لغة شاشة الهاتف GD900.

قفل المفاتيح التلقائي - قم بإقفال لوحة المفاتيح تلقائياً في الشاشة الرئيسية.

الحماية - قم بضبط الحماية، وهذا يشمل رموز PIN وقفل الهاتف.

ضوابط اللمس - قم بتغيير إعدادات ميزة لوحة اللمس.

مدير الذاكرة - راجع **استخدام معلومات الذاكرة** في الصفحة 100 للحصول على مزيد من المعلومات.

إعادة ضبط الإعدادات - يسمح هذا الخيار باستعادة كل ضبط إلى الافتراضية.

معلومات الهاتف - عرض معلومات GD900 التقنية.

تغيير إعدادات اللمس

في الشاشة الرئيسية حدد ثم قم بالتمرير إلى **إعدادات الهاتف** في علامة التبويب إعدادات .

اهتزاز اللمس: - قم بتغيير نوع الاهتزاز.

نوع الاهتزاز - الاهتزاز 1/2/3

مستوى صوت الاهتزاز - يسمح هذا الخيار بالتحكم بقوة الاهتزاز.

صوت اللمس - قم بتغيير النغمة عند لمس الشاشة.

الصوت - الصوت 1/2/3

مستوى الصوت - يسمح هذا الخيار بالتحكم بمستوى صوت النغمة.

تغيير إعدادات التوصيل

تم مسبقاً تعيين إعدادات التوصيل بواسطة مشغّل الشبكة، بحيث يمكنك استخدام هاتفك الجديد مباشرةً. استخدم هذه القائمة لتغيير ضبط.

في الشاشة الرئيسية حدد ثم قم بالتمرير إلى **التوصيل** في علامة التبويب إعدادات .

اختيار الشبكة - يتصل GD900 تلقائياً بالشبكة المفضلة.

أوضاع الإنترنت - قم بتعيين ألأوضاع للاتصال بإنترنت.

نقاط الوصول ـ قام مشغّل الشبكة بحفظ هذه المعلومات مسبقاً. يمكنك إضافة نقاط وصول جديدة باستخدام هذه القائمة.

وضع اتصال USB - قم بمزامنة هاتف GD900 باستخدام برنامج LG PC Suite لنسخ ملفات من الهاتف. راجع الصفحة 87 للحصول على مزيد من المعلومات حول التزامن.

إخراج التلفزيون - اختر **PAL** أو **NTSC** لدى توصيل هاتف GD900 بالتلفزيون.

تسجيل DivX VOD - تستخدم هذه القائمة لإنشاء رمز تسجيل DivX VOD. يرجى زيارة http://vod.divx.com للتسجيل والحصول على الدعم التقني.

اتصال بيانات الحزمة - قم بتعيين اتصال بيانات الحزمة.

إعدادات المتصفح - قم بتعيين القيم المتعلقة بالمستعرض..

إعدادات التدفق - لقد قام مشغّل الشبكة بحفظ هذه المعلومات مسبقاً. يمكنك تعديلها إذا أردت إضافة تغييرات.

إعدادات جافا - يسمح لك هذا الخيار بتعيين ألأوضاع للاتصالات التي تتم عبر برامج Java، كما يسمح أيضاً بعرض الشهادات.

استخدام معلومات الذاكرة

تتوفر في GD900 ثلاثة أنواع من الذاكرة: الهاتف بذاته، وبطاقة SIM وبطاقة ذاكرة خارجية (قد تحتاج إلى شرائها بشكل منفصل). يمكنك استخدام معلومات الذاكرة لتحديد طريقة استخدام كل نوع من أنواع الذاكرة والمساحة المتوفرة فيها.

في الشاشة الرئيسية حدد ثم قم بالتمرير إلى **إعدادات الهاتف** في علامة تبويب الاعدادات. حدد **مدير الذاكرة**.

الذاكرة العامة للهاتف 1/2 - عرض الذاكرة المتوفرة في الهاتف GD900 لرسائل وسائط متعددة، والبريد الإلكتروني، وتطبيقات Java وغيرها.

ذاكرة الوسائط المتعددة في سماعة - عرض الذاكرة المتوفرة لمحتويات الوسائط المتعددة، شأن الملفات، والأفلام، والموسيقى، والصور، والأصوات، والفيديو والفلاش المتدفقة.

ذاكرة الهاتف المحجوزة - عرض الذاكرة المتوفرة في الهاتف لرسائل نصية، وجهات الاتصال، والتقويم، وقائمة المهام، والمذكرات، التنبيهات، سجلات المكالمات، والإشارات المرجعية وعناصر متفرقة.

USIM ذاكرة - عرض الذاكرة المتوفرة في بطاقة SIM.

ذاكرة خارجية - عرض الذاكرة المتوفرة في بطاقة الذاكرة الخارجية (قد تحتاج إلى شرائها بشكل منفصل).

استخدام وضع الرحلات الجوية

قم بتشغيل وضع الرحلات الجوية وذلك بتحديد ثم **ضوابط**. المس **الأوضاع** وحدد **وضع الرحلات الجوية**.

يمنعك وضع الرحلات الجوية من إجراء مكالمات، أو الاتصال بإنترنت، أو إرسال رسائل أو استخدام بلوتوث.

إرسال الملفات واستلامها باستخدام بلوتوث

يعتبر بلوتوث طريقة جيدة لإرسال الملفات وتلقيها إذ لا حاجة إلى أسلاك ويكون الاتصال سريعاً وسهلاً. كما يمكنك الاتصال بسماعات رأس بلوتوث لإجراء مكالمات وتلقيها.

لإرسال ملف:

1 افتح الملف الذي تريد إرساله، وهو عادةً عبارة عن صورة، أو فيديو أو ملف موسيقى.

2 المس واختر **إرسال**.

حدد **بلوتوث**.

3 إذا قمت مسبقاً بإقران جهاز بلوتوث، فلن يقوم GD900 بالبحث تلقائياً عن أجهزة بلوتوث أخرى. وإلا سيبحث الهاتف GD900 تلقائياً عن أجهزة بلوتوث أخرى تم تمكينها ضمن النطاق.

4 اختر الجهاز الذي تريد إرسال الملف إليه والمس **تحديد**.

5 سيتم إرسال ملفك.

تلميح! تحقق من شريط التقدم لتتأكد من إرسال الملف.

لاستلام ملف:

1 لاستلام ملفات، يجب أن يكون بلوتوث قيد **التشغيل**. راجع **تغيير ضوابط الـ بلوتوث** أدناه للحصول على مزيد من المعلومات.

2 تظهر رسالة تطالبك بقبول الملف من المرسل. المس **نعم** لاستلام الملف.

3 ستشاهد اين يتم حفظ الملف واختيار عرض الملف او استخدام ك . يتم عادةً حفظ الملفات في الحافظة المناسبة في أشيائي.

تغيير إعدادات بلوتوث

1 في الشاشة الرئيسية حدد ثم قم بالتمرير إلى **بلوتوث** في علامة تبويب الاعدادات.

2 المس .

أدخل تغييراتك على:

معلومات جهازي - أدخِل اسماً للهاتف GD900.

إمكانية رؤية جهازي - اختر أن يكون الجهاز **مرئياً**، أو **مخفياً** أو **مرئياً لدقيقة**.

تشغيل وضع SIM عن بعد - تنشيط وضع SIM عن بعد.

تشغيل iSync - اختر تنشيط iSync.

حذف - اختر حذف الوضع المحدد.

حذف الكل - اختر حذف كل ألأوضاع.

الخدمات المعتمدة - شاهد خيارات استخدام بلوتوث مع مختلف الخدمات.

الاقتران بجهاز بلوتوث آخر

عند إجراء اقتران لهاتف GD900 بجهاز آخر، يمكنك إعداد اتصال محمي برمز مرور. يجعل هذا الأمر من الاقتران أكثر أماناً.

1 تأكد من كون بلوتوث قيد **التشغيل**.
يمكنك تغيير إمكانية الرؤية في قائمة **ضوابط**.

2 المس **بحث**.

3 سيبحث الهاتف GD900 عن أجهزة بلوتوث. عند اكتمال عملية البحث، يظهر **تجديد** على الشاشة.

4 اختر الجهاز الذي تريد إقرانه وأدخِل رمز المرور، ثم المس **موافق**.

5 يتصل هاتفك حينئذٍ بالجهاز الآخر، حيث عليك إدخال رمز المرور نفسه.

6 لقد أصبح اتصال بلوتوث المحمي برمز مرور آمناً الآن.

استخدام سماعة رأس بلوتوث

1 تأكد من كون بلوتوث قيد **التشغيل**.

2 اتبع الإرشادات التي تصحب سماعة الرأس لوضعها في وضع الاقتران وإجراء اقتران للأجهزة.

3 سيتم تبديل سماعة الرأس تلقائياً إلى وضع سماعة الرأس.

4 المس خيار السؤال قبل الاتصال او الاتصال دائما.

تلميح! راجع الصفحة 34 للحصول على تفاصيل حول **وضع الرد BT** لتتحكم بكيفية الرد على مكالماتك عند توصيل سماعة رأس بلوتوث.

WiFi

يتيح لك مدير التشغيل اللاسلكي إدارة اتصالات إنترنت عبر WiFi (شبكة LAN اللاسلكية) على جهازك. يتيح للهاتف الاتصال بالشبكات اللاسلكية المحلية، أو الوصول إلى إنترنت لاسلكياً. WiFi أسرع وذات نطاق أوسع من تقنية بلوتوث اللاسلكية، وبالتالي يمكن استخدامه لإرسال رسائل بريد إلكتروني سريعاً ولاستعراض إنترنت.

ملاحظة: الهاتف GD900 يدعم WEP، وتشفير WPA-PSK/2، وليس EAP، وتشفير WPS. إذا قام موفر خدمة WiFi أو مسؤول الشبكة بتعيين التشفير لحماية الشبكة، فعليك ملء المفتاح في الإطار المنبثق. إذا لم يتم تعيين التشفير، فلن يظهر الإطار المنبثق هذا. يمكنك الحصول على المفتاح من موفر خدمة WiFi لديك أو من مسؤول الشبكة.

1. كيفية إعداد WiFi

1 المس WiFi في علامة تبويب الاعدادات وقم بتشغيل WiFi

2 البحث عن نقطة وصول (AP)

– البحث عن نقطة الوصول التي يمكن الاتصال بها.

3 الاتصال بنقطة وصول

– الاتصال بنقطة الوصول المطلوبة من قائمة البحث عن نقطة صول.

– إذا كانت نقطة الوصول من نوع الحماية WEP أو WPA-PSK/2، فأدخِل مفتاح الحماية.

2. دعم نمط شبكة WiFi

1 دعم نمط WiFi (كيفية الاتصال بنقطة الوصول الأكثر استخداماً أو نقطة الوصول المخفية)

1) إذا لم تظهر نقطة الوصول في قائمة البحث، فيمكنك توصيلها عبر حفظها كنمط.

2) إن حفظ نقطة الوصول الأكثر استخداماً كنمط يسهّل عملية إدخال مفتاح الحماية عند الاتصال بنقطة وصول بواسطة مفتاح الحماية هذا.

3) إذا لم تكن نقطة الوصول تعتمد DHCP، يمكنك الاتصال بنقطة الوصول مستخدماً عنوان IP استاتي.

2 وصف كل حقل في نمط WiFi.

1) اسم الشبكة: SSID (معرّف)

2) نوع الحماية: دعم WEP، WPA-PSK/2.

3) مفتاح الحماية: حفظ مفتاح الحماية.

4) ضبط IP/DNS: يسمح لك هذا الخيار بالتعيين إلى تلقائي أو استاتي وهذا يتوقف على ما إذا كانت نقطة الوصول تعتمد DHCP.

بالنسبة إلى استاتي، أدخِل قيمة حقل عنوان IP وخادم DNS للاستخدام مع عنوان IP الاستاتي عند الاتصال.

3 كيفية حفظ نمط WiFi

1) حدد الشبكات المحفوظة من قائمة الخيارات، ثم حدد شبكة جديدة وأدخِل قيماً في كل حقل.

2) يمكن تحديد وحفظ قائمة البحث عن نقطة وصول عبر تحديد تشغيل WiFi ومن ثم تجديد (البحث عن نقطة وصول).

3) بعد الاتصال بنقطة وصول بواسطة نوع الحماية هذا، سيتم حفظ النمط تلقائياً.

3. كيفية الحصول على عنوان MAC

لإعداد اتصال في بعض الشبكات اللاسلكية مع عامل تصفية MAC، قد تحتاج إلى إدخال عنوان MAC الخاص بهاتف GD900 إلى جهاز التوجيه.

1 المس WiFi في علامة تبويب الاعدادات، ثم افتح قائمة الخيارات.

2 حدد عنوان MAC الخاص بي فيظهر.

تحديث البرنامج

تحديث البرنامج

برنامج تحديث برنامج الهاتف المحمول من LG

للمزيد من المعلومات حول تثبيت هذا البرنامج واستخدامه، يرجى زيارة http://update.lgmobile.com.

تتيح لك هذه الميزة تحديث برنامجك إلى الإصدار الأخير بسرعة وبشكل مريح على إنترنت من دون الحاجة إلى زيارة مركز الخدمة الخاص بنا.

بما أن برنامج تحديث برنامج الهاتف المحمول يتطلب انتباهك الكامل طيلة عملية التحديث، يرجى التحقق من الإرشادات والملاحظات التي تظهر في كل خطوة قبل الانتقال إلى الخطوة التالية. يرجى ملاحظة أن إزالة كبل اتصال بيانات USB أو البطاريات أثناء التحديث قد يتسبب بإلحاق ضرر بالغ بهاتفك المحمول. وبما أن جهة التصنيع لا تتحمل أي مسؤولية تجاه خسارة بيانات أثناء عملية التحديث، ننصحك بإجراء نسخ احتياطي لأي معلومات مهمة لتوخي الأمان.

الملحقات

تتوفر مجموعة متنوعة من الملحقات التي تناسب هاتفك المحمول، ويمكن شراؤها بشكل منفصل. يمكنك تحديد هذه الخيارات وفقاً لمتطلبات اتصالاتك الشخصية. استشر البائع المحلي للتحقق من إمكانية التوفر. (**قد تكون العناصر الموصوفة أدناه اختياريةً.**)

الشاحن

كبل البيانات والقرص المضغوط للبيانات

قم بتوصيل الهاتف GD900 وبمزامنته مع الكمبيوتر.

البطارية

سماعة رأس الاستيريو

دليل المستخدم

اعرف المزيد حول GD900.

ملاحظة:

- استخدم ملحقات LG الأصلية دائماً.
- يؤدي عدم القيام بذلك إلى إبطال الضمان.
- قد تختلف الملحقات من منطقة إلى أخرى.

خدمة الشبكة

تمت الموافقة على استخدام الهاتف اللاسلكي الذي جاء وصفه في هذا الدليل على الشبكات التالية E-GSM 900، وDCS 1800، وGSM 850، وPCS 1900 وW-CDMA.

وهناك عدد من الميزات المضمّنة في هذا الدليل وتسمى خدمات الشبكة. هذه الخدمات عبارة عن خدمات خاصة يمكنك الحصول عليها عبر موفر خدمة اللاسلكية. قبل أن تتمكّن من الاستفادة من أي خدمة من خدمات الشبكة، عليك الاشتراك فيها عبر موفر الخدمة والحصول على الإرشادات المتعلقة باستخدامها والتي يزودك بها موفر الخدمة.

تسجيل DivX VOD

إنشاء رمز تسجيل DivX VOD.

قم بزيارة <http://vod.divx.com/> للتسجيل وللحصول على الدعم الفني.

بيانات تقنية

عام

اسم المنتج: GD900

النظام: E-GSM 900 / DCS 1800 / GSM 850 / PCS 1900/ WCDMA

درجات الحرارة المحيطة

الحد الأقصى: +55 درجة مئوية (تفريغ)، +45 درجة مئوية (شحن)

الدنيا: -10° درجة مئوية

Declaration of Conformity

LG Electronics

Suppliers Details

Name

LG Electronics Inc

Address

LG Twin Tower 20, Yeouido-dong, Yeongdeungpo-gu, Seoul, Korea 150-721

Product Details

Product Name

E-GSM 900 / DCS 1800 / GSM 850 / PCS 1900 Quad Band and WCDMA Terminal Equipment

Model Name

GD900

Trade Name

LG

CE 0168

Applicable Standards Details

R&TTE Directive 1999/5/EC

EN 301 489-1 V1.6.1 / EN 301 489-7 V1.3.1 / EN 301 489-17 V1.2.1 / EN 301 489-24 V1.3.1
EN 60950-1: 2001
EN 50360 / EN62209-1: 2006
EN 301 511 V9.0.2 / EN 301 908-1 V3.2.1 / EN 301 908-2 V3.2.1
EN 300 328 V1.7.1

Supplementary Information

The conformity to above standards is verified by the following Notified Body(BABT)

BABT, Balfour House, Churchfield Road, Walton-on-Thames, Surrey, KT12 2TD, United Kingdom
Notified Body Identification Number : 0168

Declaration

I hereby declare under our sole responsibility that the product mentioned above to which this declaration relates complies with the above mentioned standards and Directives

Name	Issued Date
Seung Hyoun, Ji / Director	20, May, 2009

Signature of representative

European Standard Center
LG Electronics Logistics and Services B.V.
Veluwezoom 15, 1327 AE Almere, The Netherlands
Tel : +31 - 36- 547 – 8940, Fax : +31 – 36 – 547 - 8794
e-mail : jacob @ lge.com

توجيهات لاستخدام آمن و فعال

يرجى قراءة هذه الإرشادات البسيطة. عدم التقيد بهذه الإرشادات قد يكون أمراً خطراً أو غير قانوني.

التباين لطاقة التردد اللاسلكي

معلومات حول التباين للموجات اللاسلكية ومعدل الامتصاص المحدد (SAR). لقد تم تصميم طراز الهاتف المحمول GD900 هذا بحيث يفي بمتطلبات السلامة القابلة للتطبيق المتعلقة التباين للموجات اللاسلكية. وتستند هذه المتطلبات إلى إرشادات علمية تتضمّن هوامش سلامة مصمّمة لضمان السلامة لكل الأشخاص، بغضّ النظر عن عمرهم وظروفهم الصحيّة.

- وعلى الرغم من وجود اختلافات بين مستويات SAR لمختلف طرازات هاتف LG، فهي كلها مصممة بحيث تفي بالإرشادات المتعلقة التباين للموجات اللاسلكية.
- إن حد SAR الذي توصي به اللجنة الدولية للحماية من الإشعاع غير المؤين (ICNIRP) هو 2 واط/كغ وهو كمعدل إلى 10 غرامات من النسيج.
- أعلى قيمة SAR لطراز الهاتف هذا الذي تم اختباره بواسطة DASY4 للاستخدام على الأذن تعادل 1.47 واط/كيلوجرام (10غرام). وعند الحمل على الجسد تكون 0.802 واط/كيلوجرام (10غرام).
- معلومات بيانات SAR للمقيمين في بلدان/مناطق تتبنى حد SAR الموصى به من قِبل معهد المهندسين الكهربائيين والإلكترونيين (IEEE) هو 1.6 واط/كغ كمعدل لكل غرام واحد (1) من النسيج.

العناية بالمنتج وصيانته

⚠ تحذير

استخدم فقط البطاريات والشواحن والملحقات الموافق على استخدامها مع طراز الهاتف المحمول المعيّن هذا. إن استخدام أي أنواع أخرى قد يؤدي إلى إبطال أي ضمان أو موافقة تنطبق على الهاتف المحمول، وقد يكون خطيراً.

- لا تقم بتفكيك الوحدة. اعمل على نقل الوحدة إلى تقني صيانة مؤهل عندما تكون بحاجة إلى تنفيذ عمل ما عليها لإصلاحها.
- ضع هذه الوحدة في مكان بعيد عن الأجهزة الإلكترونية مثل أجهزة التلفزيون، والراديو، وأجهزة الكمبيوتر الشخصي.
- يجب إبقاء الوحدة بعيدةً عن مصادر السخونة مثل الأجهزة المشعة للحرارة أو الأفران المنزلية.
- تجنب إسقاط الوحدة.
- لا تعرّض هذه الوحدة للاهتزاز الميكانيكي أو الصدمات.
- أوقف تشغيل الهاتف في أي منطقة حيث القوانين الخاصة تمنعك ذلك. على سبيل المثال، لا تستخدم الهاتف في المستشفيات إذ قد يؤثر على المعدات الطبية الحساسة.
- لا تمسك الهاتف بيدين رطبتين فيما يكون شحنه جار. فقد يتسبّب هذا الأمر بحدوث صدمة كهربائية أو إلحاق ضرر بالغ بالهاتف.
- يجب عدم شحن الهاتف بالقرب من مواد قابلة للاشتعال إذ قد يصبح الهاتف ساخناً وقد يؤدي ذلك إلى اندلاع حريق.
- استخدم قطعة قماش جافة لتنظيف الوحدة من الخارج (لا تستخدم مواد مذيبة كالبنزين أو التينر أو الكحول).
- لا تشحن الهاتف عندما يكون موضوعاً على أثاث ناعم.
- يجب أن يتم شحن الهاتف في منطقة ذات تهوية جيدة.

توجيهات لاستخدام آمن و فعال

- لا تعرّض هذه الوحدة للدخان أو الغبار الزائد.
- لا تضع الهاتف بالقرب من بطاقات الائتمان أو تذاكر النقل؛ فقد يؤثر ذلك على المعلومات الموجودة على الأشرطة المعدنية.
- لا تضغط على الشاشة بواسطة شيء حاد إذ قد يؤدي ذلك إلى إلحاق الضرر بالهاتف.
- لا تعرّض الهاتف للسوائل أو الرطوبة.
- استخدم الملحقات كسماعات الأذن بحذر. لا تلمس الهوائي من دون سبب.

تشغيل فعّال للهاتف

الأجهزة الإلكترونية

قد تتعرّض كل الهواتف المحمولة للتشويش، ما قد يؤثر على أدائها.

- لا تستخدم الهاتف المحمول بالقرب من الأجهزة الطبية من دون طلب الإذن للقيام بذلك. تجنّب وضع الهاتف على أجهزة ضبط النبض، مثلاً، في الجيب على مستوى الصدر.
- قد تسبّب بعض الهواتف المحمولة الإزعاج للأدوات المساعدة للسمع.
- قد يؤثر الحد الأدنى من التشويش على أجهزة التلفزيون، والراديو، والكمبيوتر الشخصي.

السلامة على الطرقات

تحقق من القوانين والأنظمة المتعلقة باستخدام الهواتف المحمولة في المناطق أثناء القيادة.

- لا تستخدم هاتفاً محمولاً باليد أثناء القيادة.
- ركّز كامل انتباهك على القيادة.

- استخدم مجموعة أدوات لايدوية، إذا كانت متوفرة.
- توقّف عند جانب الطريق قبل إجراء أو الإجابة على مكالمة إذا كانت ظروف القيادة تستدعي ذلك.
- قد تؤثر طاقة RF على بعض الأنظمة الإلكترونية في المركبة مثل الاستيريو ومعدات السلامة في السيارة.
- عندما تكون المركبة مزودةً بكيس هوائي، عليك عدم إعاقة عمله بواسطة تجهيزات لاسلكية مثبتة أو محمولة. فقد يبطل ذلك عمل الكيس الهوائي أو قد يتسبب ذلك بإصابات خطيرة بسبب الاستخدام غير الصحيح.
- إذا كنت تستمع إلى الموسيقى أثناء تنقلك، فتأكد من كون مستوى الصوت معقولاً بحيث تكون مدركاً لما يحيط بك. يعتبر هذا الأمر ملزماً خاصةً بالقرب من الطرقات.

تجنّب إلحاق الضرر بسمعك

قد يؤدي تعرّضك إلى أصوات عالية لفترات وقت طويلة إلى إلحاق الضرر بسمعك. ونوصي بالتالي بألا تقوم بتشغيل الهاتف أو إيقافه عندما يكون قريباً من أذنك. كما نوصي بضبط صوت الموسيقى والمكالمات على مستوى معقول.

القطع الزجاجية

بعض قطع الجهاز المحمول مصنوعة من الزجاج. قد ينكسر الزجاج في حال وقع الجهاز على سطح صلب أو تلقى ضربةً قوية. في حال انكسر الزجاج، لا تلمسه أو تحاول إزالته. توقف عن استخدام الجهاز المحمول إلى أن يتم استبداله من قِبل موفر خدمة معتمد.

توجيهات لاستخدام آمن و فعال

منطقة تفجير

لا تستخدم الهاتف في الأماكن حيث تكون عمليات التفجير جار. التزم بالقيود. واتبع الأنظمة أو القوانين.

مناطق تتّسم أجواؤها بالقابلية للانفجار

- لا تستخدم الهاتف في محطات إعادة التزويد بالوقود.
- لا تستخدم الهاتف بالقرب من الوقود أو المواد الكيميائية.
- لا تقم بنقل أو تخزين غاز أو سائل قابل للاشتعال، أو متفجرات في حجرة السيارة نفسها التي تحتوي على الهاتف المحمول وملحقاته.

في الطائرة

باستطاعة الأجهزة اللاسلكية أن تتسبّب بحدوث تشويش في الطائرة.

- أوقف تشغيل الهاتف المحمول أو قم بتنشيط وضع الرحلات الجوية قبل الصعود على متن أي طائرة.
- لا تستعمله على الأرض دون الحصول على إذن من قِبل طاقم الطائرة.

أطفال

ضع الهاتف في مكان آمن بعيداً عن متناول الأطفال. فهو يحتوي على أجزاء صغيرة قد تنفصل عنه وتتسبّب بالاختناق.

مكالمات الطوارئ

قد لا تكون مكالمات الطوارئ متوفرةً ضمن كل شبكات الهاتف المحمول. وبالتالي عليك ألا تعتمد فقط على هاتفك المحمول لمكالمات الطوارئ. تحقق من ذلك مع موفر الخدمات المحلي لديك.

معلومات حول البطارية والعناية بها

- لست بحاجة إلى إفراغ البطارية بشكل كامل قبل إعادة شحنها. وبخلاف أنظمة البطاريات الأخرى، ليس هناك من تأثير للذاكرة يمكنه تخفيض أداء البطارية.
- استخدم بطاريات وشواحن LG فقط. فشواحن LG مصمّمة لإطالة فترة عمل البطارية.

- لا تعمل على تفكيك البطارية أو تعريضها لحدوث تماس.
- حافظ على نظافة الموصّلات المعدنية الموجودة على البطارية.
- استبدل البطارية عندما يصبح أداؤها غير مقبول. قد يعاد شحن البطارية مئات المرات قبل أن تصبح بحاجة إلى الاستبدال.
- أعد شحن البطارية إذا كنت قد توقفت عن استخدامها لفترة طويلة وذلك لزيادة صلاحية استعمالها إلى الحد الأقصى.
- لا تعرّض شاحن البطارية لنور الشمس المباشر أو لا تستخدمه في أماكن عالية الرطوبة، مثل الحمام.
- لا تترك البطارية في الأماكن الساخنة أو الباردة، فقد يؤدي ذلك إلى التراجع في أدائها.
- هناك خطر انفجار إذا تم استبدال البطارية بأخرى من النوع غير الصحيح.
- تخلّص من البطاريات المستعملة طبقاً لتعليمات الشركة المصنّعة. يرجى إعادة التصنيع عندما يكون ذلك ممكناً. لا تتخلّص منها في مهملات منزلية.
- إذا كنت بحاجة إلى استبدال البطارية، فقم بأخذها إلى أقرب فرع للصيانة أو وكيل معتمد من LG Electronics للمساعدة.
- قم دائماً بفصل الشاحن عن المقبس بعد شحن الهاتف بالكامل لتفادي استهلاك الشاحن طاقة غير ضرورية.
- تعتمد فترة عمل البطارية الفعلية على تكوين الشبكة وضوابط المنتج والأنماط المستخدمة والبطارية والأوضاع البيئية.

استكشاف الأخطاء وإصلاحها

يسرد هذا الفصل بعض المشاكل التي قد تصادفها أثناء استخدام الهاتف. بعض المشاكل تتطلب منك الاتصال بموفر الخدمة، ولكن معظمها يكون سهلاً ويمكنك تصحيحه بنفسك.

رسالة	الأسباب المحتملة	الحلول المحتملة
خطأ SIM	لا يوجد بطاقة SIM في الهاتف أو ربما قمت بإدراجها بشكل غير صحيح.	تأكد من إدراج بطاقة SIM بطريقة صحيحة.
لا يوجد اتصال بالشبكة	الإشارة ضعيفة خارج شبكة GSM	توجّه نحو نافذة أو نحو مكان مفتوح. تحقق من خريطة التغطية التي يزودك بها موفر الخدمة.
رموز غير متطابقة	لتغيير رمز حماية، عليك تأكيد الرمز الجديد بإدخاله مرة أخرى.	اتصل بموفر الخدمة.
يتعذّر تعيين الوظيفة	غير معتمد من قِبل موفر الخدمة، أو التسجيل مطلوب.	اتصل بموفر الخدمة.
المكالمات غير متوفرة	خطأ في الطلب بطاقة SIM جديدة. تم بلوغ الحد الخاص برسوم المكالمات	شبكة جديدة غير مصرّح لها. تحقق من القيود الجديدة. اتصل بموفر الخدمة أو أعد تعيين الحد بواسطة PIN 2.
يتعذّر تشغيل الهاتف	لم يتم الضغط على مفتاح التشغيل/إيقاف التشغيل لفترة كافية البطارية فارغة ملامسات البطارية متسخة	اضغط على مفتاح التشغيل/إيقاف التشغيل لثانيتين على الأقل. اترك الشاحن متصلاً لفترة أطول. قم بتنظيف ملامسات البطارية.

رسالة	الأسباب المحتملة	الحلول المحتملة
خطأ في الشحن	البطارية فارغة بالكامل	اشحن البطارية.
	درجة الحرارة خارج النطاق	تأكد من أن درجة الحرارة المحيطة جيدة، وانتظر قليلاً، ثم حاول الشحن مرة أخرى.
	مشكلة في الاتصال	تحقق من وحدة التزويد بالطاقة والاتصال بالهاتف. تحقق من ملامسات البطارية، وقم بتنظيفها إذا اقتضى الأمر.
	لا فولتية للخطوط الرئيسية	قم بالتوصيل بمقبس آخر أو تحقق من الفولتية.
	الشاحن فيه خلل	إذا لم يسخن الشاحن، فقم باستبداله.
	الشاحن غير مناسب	استخدم ملحقات LG الأصلية فقط.
	البطارية فيها خلل	استبدل البطارية.
الهاتف ينقطع عن الشبكة	الإشارة ضعيفة جداً	إعادة الاتصال بموفر خدمة آخر تتم تلقائياً.
الرقم غير مسموح به	وظيفة رقم الاتصال المحدد قيد التشغيل.	تحقق من ضبط.

LG

Some of the contents in this manual may differ from your phone depending on the software of the phone or your service provider.

GD900 User Guide

Congratulations on your purchase of the advanced and compact GD900 phone by LG, designed to operate with the latest digital mobile communication technology.

Contents

Set up

Getting to know your phone 8
Open view 10
Installing the SIM and battery 11
Charging your phone 13
Memory card 14
Menu map 16

Your home screen

Touch screen tips 17
Customising the home screen 18
Get in touch with your GD900 19
Quick keys 20
Touch screen 21
Viewing the status bar 26
Using the Multi - tasking function 28

The basics

Calls 29
Making a call or a video call 29
Calling your contacts 29
Answering and rejecting a call 29
In-call options 30
Adjusting call volume 31
Speed dialling 31
Making a second call 31
Turning off DTMF 32
Viewing your call logs 32
Using call divert 33
Using call barring 33
Changing the common call setting 34
Changing your video call settings 34
Contacts 35
Searching for a contact 35
Adding a new contact 35
Creating a group 36
Changing your contact settings 36
Viewing information 37
Messaging 38
Messaging 38
Sending a message 38
Entering text 39
T9 predictive 39
Abc manual 39
Setting up your email 39
Sending an email using your new account 40
Changing your email settings 40
Message folders 41
Using templates 42
Using emoticons 42
Changing your text message settings 42
Changing your multimedia message settings 43
Changing your other settings 44

Get creative

Camera 45
Getting to know the viewfinder 45
Taking a quick photo.....46
Once you've taken the photo 46
Using the flash.....47
Adjusting the exposure.....48
Adjusting the zoom.....48
Taking a continuous shot 49
Using the advanced settings.....49
Changing the image size.....51
Choosing a colour effect.....51
Using the inner camera.....52
Viewing your saved photos 52
Video camera 53
Getting to know the viewfinder.....53
Shooting a quick video 54
After shooting a video.....54
Adjusting the exposure.....55
Using the advanced settings.....55
Changing the video image size.....57
Choosing a colour tone.....58
Using the inner video camera.....58
Watching your saved videos 59
Watching your videos on TV.....59
Your photos and videos 60
Viewing your photos and videos.....60
Using zoom when viewing a video or photo 60
Adjusting the volume when viewing a video 60
Setting a photo as wallpaper.....60
Editing your photos.....61
Adding text to a photo.....62
Adding an effect to a photo 62
Cropping a photo 62
Adding a colour accent to a photo ...63
Swapping colours in a photo.....63
Editing your videos.....63
Trimming the length of the video.....64
Merging two videos 64
Merging a photo with a video 65
Adding text to a video.....65
Overlaying a photo.....66
Adding a soundtrack to your video ..66
Adding live sound to your video 67
Changing the video speed.....67
Adding a dimming effect 67
Multimedia.....68
Pictures 68
My images options menu.....68
Sending a photo.....68
Using an image 69
Printing an image.....69
Moving or copying an image.....70

Contents

Creating a slide show 70
Checking your memory status 70
Sounds 70
Using a sound 70
Videos 71
Sending a video clip 71
Games and Applications 71
Playing a game 72
Using the options menu 72
Installing a Java game and application 72
Use the M-Toy menu 72
Flash contents 72
Viewing an SWF/ SVG file 72
Documents 73
Viewing a file 73
Transferring a file to your phone 73
Others 73
Creating a movie 73
Music 74
Transferring music onto your phone 75
Playing a song 75
Creating a playlist 76
Deleting a playlist 76
Using the radio 76
Searching for stations 77
Resetting channels 77
Listening to the radio 78

Get organised

Organiser 79
Adding an event to your calendar 79
Changing your default calendar view 79
Adding an item to your To Do list 80
Using the date finder 80
Setting your alarm 81
Adding a memo 81
Voice recorder 81
Recording a sound or voice 82
Sending the voice recording 82
Using your calculator 82
Converting a unit 83
Using the stopwatch 83
Adding a city to your world clock 83
PC Suite 84
Installing the LG PC Suite on your computer 84
Connecting your phone and PC 84
Backing up and restoring your phone's information 85
Viewing phone files on your PC 85
Synchronising your contacts 85
Synchronising your messages 86
Music Sync 86
Transferring music using Windows Media Player 87

Using ISync 87
DivX Converter 88

The web

Browser 89
Accessing the web 89
Adding and accessing bookmarks....89
Using the RSS reader.....90
Accessing a saved page 90
Viewing your browser history.....90
Changing web browser settings.....91
Using your phone as a modem 91
Access to Google Maps 92

Settings

Changing your screen settings.....93
Personalising your profiles.....93
Changing your phone settings.....94
Changing your touch settings 95
Changing your connectivity settings.....95
Using memory manager.....96
Using flight mode.....97
Sending and receiving files using Bluetooth.....97
Changing your Bluetooth settings....98
Pairing with another Bluetooth device 99
Using a Bluetooth headset.....99
Wi-Fi..... 100
Software Update..... 102

Accessories 103

Network service 104

Technical data..... 104

Guidelines

Guidelines for safe and efficient use..... 106
Trouble Shooting..... 112

Getting to know your phone

Power key
Turns the phone on/off.

Earpiece

Proximity Sensor

Inner camera

End key
- Rejects a call.
- Press once to return to the home screen.

Multi-tasking key

Send key
Dials a phone number and answers incoming calls.

Battery release button

⚠ **WARNING:** Putting a heavy object on the phone or sitting on it can damage its LCD and touch screen functionality.
Do not cover the protection film on proximity sensor of LCD. It can be caused the malfunction of sensor.

Handsfree or Stereo earphone connector/ Charger, Data cable (USB cable)

TIP: Before connecting the USB cable, wait until the phone has powered up and has registered on the network.

Volume keys

- **When the screen is idle:** key tone volume.
- **During a call:** earpiece volume.
- **When playing a track:** controls volume continuously.

Camera key

- Go to the camera menu directly by pressing and holding the key.

Open view

SIM card socket
Flash light
Battery cover
Battery
Memory card socket
Camera lens
Battery release button

Installing the SIM and battery

1 Remove the battery cover

Use your thumbnail to open the battery release button on the bottom of the phone and lift off the battery cover.

2 Remove the battery

Hold the top edge of the battery and lift it away from the battery compartment.

⚠ **WARNING:** Do not remove the battery when the phone is switched on, as this may damage the phone.

3 Install the SIM card

Slide the SIM card into the SIM card holder. Make sure the gold contact area on the card is facing downwards. To remove the SIM card, gently push it until it clicks. Gently pull it out.

Installing the SIM and battery

4 Install the battery

Insert the top of the battery into the top edge of the battery compartment first. Ensure that the battery contacts align with the phone's terminals. Press the bottom of the battery down until it clips into place.

Charging your phone

Slide back the cover of the charger connector on the side of your GD900. Insert the charger and plug it into a mains electricity socket. Your GD900 must be charged until the "Battery full" message appears on the screen.

NOTE: The battery must be fully charged initially to improve battery lifetime. Disregard the first "Battery full" message and keep the phone on charge overnight.

Memory card

Installing a memory card

You can expand the available memory space on your phone by using a memory card.

NOTE: A memory card is an optional accessory.

Slide the memory card into the slot at the top, until it clicks into place. Make sure the gold contact area is facing downwards.

WARNING: Slide into the memory card to the slot, otherwise, the card can be damaged.

Formatting the memory card

Your memory card may already be formatted. If it isn't, you will need to format it before you can start to use it.

NOTE: All files get deleted while formatting.

1. From the home screen select and choose **Phone settings** from the Settings tab.
2. Scroll and touch **Memory Info** then scroll and select **External memory**.
3. Touch **Format** and then confirm your choice.
4. Enter the password, if one has been set. The card will then be formatted and ready to use.

NOTE: If there is existing content on your memory card, the folder structure may be different after formatting since all files will have been deleted.

Transferring your contacts

To transfer your contacts from your SIM to your phone:

1. From the Communication tab, scroll to **Contacts** and select then **Change location**.
2. Touch **Copy to Handset**.
3. Choose **Select all** or select names one by one and touch **Copy to handset**.

Menu map

Touch in the home screen to open a **Top menu**. From here you can access further menus by scrolling through the icons: **Communication**, **Multimedia**, **Utilities** and **Settings**.

COMMUNICATION

- Contacts
- Recent history
- Browser
- Messaging
- Email
- Dialling
- Video call
- Google

MULTIMEDIA

- Music
- Camera
- Video camera
- Gallery
- My stuff
- Games & Apps
- FM radio
- Movie maker

UTILITIES

- Alarms
- Organiser
- Memo
- Stopwatch
- Voice recorder
- Calculator
- World clock
- Tools

SETTINGS

- Profiles
- Screen settings
- Phone settings
- Bluetooth
- Wi-Fi
- Call settings
- Connectivity
- Message settings

Your home screen

From this screen you can access menu options, make a call, view the status of your phone and much more.

Touch screen tips

The home screen is also a great place to get used to using the touch screen.

To select an item, touch the centre of the icon.

- Do not to press too hard; the touchscreen is sensitive enough to pick up on a light, firm touch.
- Use the tip of your finger to touch the option you require. Be careful not to touch any other keys.
- When the screen light is off, either press the power key or hold down the Unlock/Lock key on the touch screen to return the home screen.
- Whenever your GD900 is not in use, it will return to the lock screen.

Your home screen

Customising the home screen

1 Shortcut home screen

2 Widget home screen (active)

3 Contact home screen

4 Multimedia home screen

- **Home screen customisation** - For each type of home screen you are able to add and remove objects by pressing & holding your finger on the screen, or if already added touching and holding one of the objects.

Get in touch with your GD900

The User Interface is based on four types of Homescreens. To swap between the home screens just wipe quickly over display from left to right or from right to left.

NOTE: Use flicking to navigate without disturbing the display area.

Your home screen

Quick keys

The quick keys on your home screen provide easy, one-touch access to the functions you use the most.

Touch to bring up the touch dialling pad, which lets you make a call. Enter the number using the normal key pad and touch **Voice call** or tap .

To make a video call to this number, touch **Video Call** after entering the number.

Touch to open your contacts. To search for the number you want to call: Enter the name of the contact using the touchpad. You can also create new contacts and edit existing ones.

Touch to access the **Messaging** menu. From here you can create a new SMS.

Touch to open the full Top menu which is divided into four categories.

Touch screen

The controls on the GD900 touch screen change dynamically, depending on the task you are carrying out.

Opening Applications

To open any Application, simply touch its icon.

Scrolling

Drag from side to side to scroll. On some screens, such as web pages, you can also scroll up or down.

Your home screen

Zooming In or Out

When viewing photos, web pages, emails, or maps, you can zoom in and out. Pinch your fingers together or slide them apart.

Transparent Touchpad

Make the most of your Transparent Touchpad.

1 Touchpad Shortcut : You can assign a symbol for the most commonly used menus.
Assign a symbol to each shortcut, so you can instantly access your favourite functions with simple finger gestures.

For example, if you draw on the Transparent Touchpad, it will instantly go to Email.

2 Easy click : You can click on the Transparent Touchpad without covering the main screen while using the Web Browser.

[Browse with mouse pointer]

Your home screen

3 Touch wheel: Adjust the volume or brightness by drawing ↶ and ↷ on the Transparent Touchpad in Music, Divx Playback, Camera and Video Camera. You can also zoom in or zoom out by drawing ↶ or ↷ on the Transparent Touchpad in Camera mode, and Video Camera mode.

[Zoom in/out]

4 Handwriting: Use your finger to write information on the Transparent Touchpad, without covering the main screen.

In Handwriting mode you simply write on the screen and your GD900 will convert your handwriting into your message. If you select capital letter mode (ABC), letters you type will be inserted as capital letters even if you write in small letters, and vice versa. Touch ▲ and Touch . You can write on the screen with your finger.

Letter	Strokes
A	
B	
C	
D	
E	
F	
G	
H	
I	
J	
K	
L	
M	
N	
O	
P	

Letter	Strokes
Q	
R	
S	
T	
U	
V	
W	
X	
Y	
Z	
ß	

Accented characters

Accent	Strokes
Space	
Backspace	
Enter	

Punctuation marks

Mark	Strokes
Full stop	•
At @	@

Numbers

Number	Strokes
0	
1	
2	
3	
4	
5	
6	
7	
8	
9	

Your home screen

5 Normal Keypad : The Transparent Touchpad can also be used to input numbers and text in a familiar way.

6 Favourites : Display your favourite contacts, songs and photos on the screen by touching ★ .

Note The Transparent Touchpad is made of Tempered Glass.

Viewing the status bar

The status bar uses different icons to show conditions such as signal strength, new messages and battery life as well as whether Bluetooth or data connections is active.

Below is a table which explains the meaning of icons you're likely to see in the status bar.

Icon	Description
	No Service
	2G
	3G
	EDGE
	HSDPA
	Wi-fi is on
	Bluetooth Mono Stereo headset

Icon	Description
	Bluetooth Stereo headset
	Bluetooth Mono headset
	Bluetooth on
	Bluetooth Transfer
	Bluetooth Visibility
	Downloading
	Downloading complete.
	Downloading cancelled.
	In-call option
	Internet
	Searching
	Call divert
	Call reject
	Security
	Headset
	HomeZone
	Roaming
	Alarm
	Schedule (Calendar)

Icon	Description
	Multi-tasking
	Music paused
	Music playing
	FM radio playing
	Email being sent
	Email receiving
	MMS
	MMS sending
	MMS receiving
	SMS sending
	New voicemail
	New message
	Message sending has failed
	New email
	Push message
	Flight mode
	Outdoor
	Silent
	Customised ringtones 1-10

Your home screen

Icon	Description
	External memory
	Battery status
	Projector/TV out

Using the Multi - tasking function

Touch the multitasking hard key to open the **Multitasking** menu. From here you can view some applications that are running and access them with one touch.

Calls

TIP! Press the power key to lock the touchscreen to prevent calls being made by mistake.

Making a call or a video call

1 Touch to open the keypad.

2 Type in the number on the keypad. To delete a digit, press the clear key.

3 Touch the key to make the call.

4 To end the call, touch the key.

TIP! To enter + in order to make international calls, touch * twice, or press and hold down 0+.

TIP! You can **Save number, Send message, Search contacts** by tapping .

Calling your contacts

1 From the home screen touch to open your **Contacts**.

2 Scroll through the contact list or enter the first letter(s) of the contact you want to call by touching .

3 From the list, touch the contact you want to call and select the number to use if there is more than one for that contact.

4 Touch **Voice call** or **Video call**.

Answering and rejecting a call

When your phone rings, press the hard key to answer.

Touch twice the hard key to reject an incoming call.

Calls

In-call options

Speaker - Touch to turn the speaker phone on.

Mute - Touch to turn the microphone off so the person you are talking to cannot hear you.

Hold - Touch to put a call on hold.

Options - Choose from a list of further in-call options, including creating new memo and going to messages, so you can check your messages and add contacts during a call. You can also end the call from here by touching End call.

Dialpad - Touch to open a numerical keypad for typing in numbers, e.g. when dialling call centres or other automated telephone services.

Memo - Add a memo during a call.

Contacts - Search your contacts during a call.

Adjusting call volume

To adjust the volume during a call, use the up and down button on the right side of the phone.

Speed dialling

You can assign a frequently-called contact to a speed dial number.

1. From the home screen touch to open your **Contacts**.
2. Touch and select **Speed dials**.
3. Your voicemail is already set to speed dial 1. You cannot change this. Touch any other number to assign it to a speed dial contact.
4. Your contacts list will open. Select the contact you want to assign to that number by touching the phone number once.

To call a speed dial number, touch on the home screen then press and hold the assigned number until the contact appears on the screen.

The call will initiate automatically, without having to touch **Voice call**.

Making a second call

1. During your initial call, touch Dialpad and select the number you want to call.
2. Call the number or search your contacts.
3. Touch to connect the call.
4. Both calls will be displayed on the call screen. Your initial call will be locked and put on hold.
5. To end one or both calls press End .

Calls

NOTE: You will be charged for each call you make.

Turning off DTMF

DTMF lets you use numerical commands to navigate within automated calls. DTMF default is set to on.

To turn it off during a call (to make a note of a number) touch ☰ and select **Disable DTMF**.

Viewing your call logs

From the home screen, touch ⠿, then touch **Recent history** in the Communication tab. Choose from the following:

All history - View a complete list of all dialled, received and missed calls, voice calls only, video calls and messages.

Missed calls - View a list of all calls you have missed.

Calls only - View a list of all calls you have made and missed.

Messages only - View a list of all numbers that have received or sent texts and multimedia messages.

VT only- View a list of all video calls.

TIP! From any call log touch ☰ and **Delete all** to delete all the recorded items.

TIP! Touch any single call log entry to view the date, time and duration of the call.

Using call divert

1 Touch and choose **Call settings** in the Settings tab.

2 Touch **Call divert** and select **Voice calls** and/or **Video calls**.

3 Choose whether to divert all call, when the line is busy, when there is no answer or when you cannot be contacted.

4 Touch **Activate** to activate.

5 Enter the number to divert to.

NOTE: Diverting calls will incur charges. Please contact your network operator for details.

TIP! To turn off all call diverts, choose **Deactivate all** from the **Call divert** menu.

Using call barring

1 Touch and choose **Call settings** in the Settings tab.

2 Touch **Call barring** and select **Voice calls** and/or **Video calls**.

3 Choose any or all of the five options:

All outgoing

Outgoing international

Outgoing international calls except home country

All incoming

Incoming when abroad

4 Enter the call barring password. Please check with your network operator about this service.

TIP! Select **Fixed dial number** to turn on and compile a list of numbers which can be called from your phone. You'll need your PIN2 code, which is available from your operator. Only numbers within the fixed dial list can be called from your phone.

Changing the common call setting

1 Touch and choose **Call settings** in the Settings tab.

2 Touch **Common settings**. This lets you change the following settings:

Call reject - Slide the switch left for **ON**. You can touch the **Reject list** to choose all calls, specific contacts or groups or calls from unregistered numbers or No caller ID (i.e. not in your contacts).

Send my number - Choose whether to display your number on an outgoing call.

Auto redial - Slide the switch left for **ON** or right for **OFF**.

Minute minder - Slide the switch left to **ON** to hear a tone every minute during a call.

BT answer mode - Select **Hands-free** to be able to answer a call using a Bluetooth headset, or select **Handset** to press a handset key to answer a call.

Save new number - Select **ON** or **OFF** to save a new number.

Slide close setting - Choose between End call and Continue call when you close the slide.

Changing your video call settings

1 From the home screen, touch and scroll to **Call settings** in the Settings tab.

2 Touch **Video call settings** and select the settings for your video calls. Decide whether to use still image, then select one and/or switch on the mirror to see yourself on screen when making a video call.

Contacts

Searching for a contact

There are two ways to search for a contact:

From the home screen

1 From the home screen, touch to open your **Contacts**. Touch and enter the contact name using the key pad.

2 Touch **Video call** or **Voice call** or the key to place the call.

TIP! You can search by group by touching the Contacts tab at the top of the screen and selecting **Groups**. This will bring up a list of all your groups.

From the main menu

1 Touch , then touch **Contacts** on the Communication tab.

2 Touch and **Search**.

Adding a new contact

1 From the home screen, touch then select and then touch **New contact** button.

2 Choose whether to save the contact to **Handset** or **USIM**.

3 If you want to add a picture to the new contact, touch **Add picture**.

4 Enter the first and last name of your new contact. You do not have to enter both, but you must enter at least one.

5 Enter up to five different numbers and assign a type to each of them, choosing between **Mobile**, **Home**, **Office**, **Pager**, **Fax**, **VT** and **General**.

6 Add an email address.

7 Assign the contact to one or more groups, choosing between **No group**, **Family**, **Friends**, **Colleagues**, **School** and **VIP**.

8 You can also add a **Ringtone**, **Homepage**, **Home address**, **Company name**, **Job title**, **Company address**, **Birthday**, **Anniversary** and a **Memo**.

9 Touch to save the contact.

TIP! You can create customised groups for your contacts. See **Creating a group**.

Creating a group

1 From the home screen, touch and then touch **Contacts** in the Communication tab.

2 Touch Contacts on the top of the screen then touch **Groups** and select new group.

3 Enter a name for the new group.

4 Touch to save the group.

NOTE: If you delete a group, the contacts assigned to that group will not be lost. They will remain in your contacts.

TIP! You can edit an existing group by touching the selected group once. Choose View members, Edit the group, Send message, Send businesscard or Delete group.

Changing your contact settings

You can adapt your contact settings to suit your own preferences.

1 Touch **Contacts** on the Communication tab, select and scroll to **Contact settings**.

2 From here, you can adjust the following settings:

Display name - Choose whether to display the first or last name of a contact first.

Copy all - Copy your contacts from your SIM to your handset, or vice versa. You can do this one contact at a time, or all at once.

Move all - This works in the same way as Copy, but the contact is stored at the new location only. Therefore, once a contact is moved from the SIM to the handset it will be deleted from the SIM memory.

Clear contacts - Delete all your contacts. Touch **Yes** if you are sure you want to delete all your contacts.

Memory info - View memory capacity information.

Viewing information

1 Touch **Contacts** from the Communication tab select ☰ and touch **Information**.

2 From here you can view **Service dial numbers**, **Own numbers**, **Memory info.** (memory space remaining) and **My business card**.

TIP! To add your own business card, select **My business card** and enter your details as you would for any contact. Touch **Save** icon to finish.

Messaging

Messaging

Your GD900 combines SMS, MMS into one intuitive, easy-to-use menu.

There are two ways of entering the messaging centre:

1 From the home screen, touch or , then scroll to **Messaging** on the Communication tab.

Sending a message

1 Touch then **Write message** to open a blank message.

2 Touch **To** to enter the recipient's number, or open your contacts or favourites. You can add multiple contacts. When you are finished, touch the message box below to start composing the message text.

3 After entering the text, you can send the SMS by touching the send button on top of the message.

TIP! You will be charged for a text message for every person you send the message to.

4 Touch **Insert** to add a text template, multimedia templates, emoticon, name & number, new slide, subject or signature.

WARNING: The 160-character limit may vary from country to country depending on how the SMS is coded.

WARNING: If an image, video or audio file is added to an SMS it will be automatically converted to an MMS, and you will be charged accordingly.

Entering text

Keypad.

T9 Touch to turn on T9 predictive texting.

Touch to change the writing language.

@#* ABC Tap to change between the number, symbol and text keypads.

Use to scroll through the different keyboards in each text entry mode (e.g. capital or lower case letters).

To enter a space touch ␣.

T9 predictive

In T9 mode, you will see T9 .

T9 mode uses a built-in dictionary to recognise your words based on the key sequences you touch. Simply touch the number key associated with the letter you want to enter, and the dictionary will predict the word you want to use.

For example, press 8, 3, 5, 3, 7, 4, 6, 6 and 3 to write 'telephone'.

Abc manual

In Abc mode you have to touch the key repeatedly to enter a letter. For example, to write 'hello', touch 4 twice, 3 twice, 5 three times, 5 three more times, then 6 three times.

Setting up your email

You can keep in touch on the move by using your GD900 to send emails. It's quick and simple to set up a POP3 or IMAP4 email account.

1 Touch from the home screen, and scroll to **Email** on the Communication tab.

2 Touch **Write email**. If the email account is not set up, start the email set up wizard.

TIP! If an email account is already set up, the wizard is not activated automatically.

Sending an email using your new account

1 Touch from the home screen, and scroll to **Email** on the Communication tab to open a new blank message.

2 Enter the recipient's address and write your message. You can also attach images, videos, audio files and other file types.

3 Touch **Send email** to send your email.

TIP! During an active Wi-Fi connection, emails are sent and received via Wi-Fi.

Changing your email settings

You can change your email settings based on your own preferences.

1 Touch from the home screen, then scroll to **Messages settings** on the Settings tab.

2 Select **Email**.

3 You can alter the following settings:

Email accounts - Manage your email accounts.

Allow reply email - Choose whether to allow read confirmation messages to be sent.

Request reply email - Choose whether to request read confirmation messages.

Retrieve interval - Select how often your GD900 checks for new email messages.

Include message in Fwd & Reply- Select to include the original message in any reply.

Include attachment - Select to include the original attachment in any reply.

Auto retrieval when Roaming - Choose whether to retrieve messages automatically when abroad (roaming).

New email noti. info - Choose whether to be alerted about a new e-mail with a pop-up message.

Signature - Create an email signature and switch this feature on.

Message folders

You will recognise the folder structure in your GD900, and it is fairly self-explanatory.

Inbox - All messages you receive are stored in your inbox. From here you can view and delete them, among other functions.

Outbox - This is a temporary storage folder while messages are being sent.

Sent - Messages you sent are stored in this folder.

Drafts - If you don't finish writing a message, you can save what you've done in this folder.

Threaded box - Messages (SMS) exchanged with another party can be displayed in chronological order so that you can conveniently see an overview of your conversation.

My Folders - Create folders to store your messages.

Using templates

Create templates for the SMS and MMS messages you send most often. There are already some templates on the phone, which you can edit.

1. When writing a new message, you can enter **Templates** from **Insert** in the options menu.
2. Choose **Text templates** or **Multimedia templates**. You can add, edit, delete or delete all templates. To edit a message, select it, amend it, and touch **Save template**.

Using emoticons

Liven up your messages using emoticons. There are some commonly used emoticons already on your phone.

1. When writing a new message, you can enter **Emoticons** from **Insert** in the options menu.
2. You can add a new emoticon by touching **New emoticon**.

Changing your text message settings

Your GD900 message settings are pre-defined, so you can send messages immediately. These settings can be changed based on your preferences.

Scroll to **Message settings** on the Settings tab and touch **Text message**. You can changes to the following:

Text message centre - Enter the details of your message centre.

Delivery report - Slide the switch left to receive confirmation that your messages have been delivered.

Validity period - Choose how long your messages are stored at the message centre.

Message types - Convert your text into **Voice**, **Fax**, **X.400** or **Email**.

Character encoding - Choose how your characters are encoded. This affects the size of your messages and therefore your data charges.

Send long text as - Choose to send long messages as multiple SMS or MMS.

Changing your multimedia message settings

Your GD900 message settings are pre-defined, so you can send messages immediately. These settings can be changed based on your preferences.

In **Setting** tap select **Message settings** and **Multimedia message**. You can make changes to the following:

Retrieval mode - Select **Home network** or **Roaming network**. If you then select Manual, you will only receive notifications about MMS messages. You can then decide whether or not to download them in full.

NOTE: Additional cost may occur when MMS are downloaded when roaming.

Delivery report - Choose whether to allow and/or request a delivery report.

Read reply - Choose whether to allow and/or send a read reply.

Priority - Choose the priority level of your MMS.

Validity period - Choose how long your message is stored at the message centre.

Slide duration - Choose how long slides appear on screen.

Creation mode - Restricted/ Warning/ Free

Delivery time - Choose how long to wait before a message is delivered.

Multimedia message centre - Enter the details of your message centre.

Changing your other settings

Scroll to **Message settings** on the Settings tab then:

Voicemail - Touch **New profile** or ☰ to add a new Voicemail service. Contact your network operator for more information about the service they provide.

Service message - Choose whether to receive or block service messages. You can also set message security levels by creating trusted and not trusted sender lists.

Info. service - Choose your reception status, language and other settings.

Camera

Getting to know the viewfinder

Open the slide to use the Outer Camera.

Back - Touch here to return to the menu map.

Camera mode - Shows whether the camera is in video or photo mode, and can also be used to take photos.

Gallery - Touch this icon to view the gallery.

Exposure - See Adjusting the Exposure on page 48.

Macro - Switch this on to take close up shots.

Flash status - Set flash light mode to Auto, Always off or Always on.

Settings - Touch this icon to open the settings menu. See Using the advanced settings on page 49 for details.

TIP! You can close all the shortcut options to give a clearer viewfinder screen. Just touch the centre of the viewfinder once. To recall the options, touch the screen again.

Camera

Taking a quick photo

1. Press and hold down the camera key on the right side of the phone.
2. Holding the phone horizontally, point the lens towards the subject you want to take a picture of.
3. Press the capture button lightly and a focus box will appear in the centre of the viewfinder screen.
4. Position the phone so you can see the photo subject in the focus box.
5. When the focus box turns green, the camera has focused on your subject.
6. Press the capture button and hold it down.

TIP! Face Tracking
This automatically detects and focuses on human faces to help you take clearer pictures.

Once you've taken the photo

Your captured photo will appear on the screen. The image name is shown with four icons on the right-hand side.

Send Touch to send the photo as a **Message**, **Email**, **Bluetooth** or **Blogger**. See page 38 for Sending a message, and page 97 for Sending and receiving your files using Bluetooth.

NOTE: Additional cost may occur when MMS are downloaded when roaming.

Use Touch to use the image as homescreen, Lock screen, contact, Start-up/Shut down and Outgoing/

Incoming call image.

Rename Touch to edit the name of the selected picture.

Edit Touch to edit the image using various tools.

Touch to return to the previous menu.

Touch to delete the image.

Touch to take another photo immediately. Your current photo will be saved.

Touch to view a gallery of your saved photos.

Using the flash

The default flash setting is auto, but there are other options.

1 Select from the left side of the viewfinder to enter the flash sub-menu.

2 There are three flash options:

Auto - Your camera will assess the light available for a good picture and use the flash as necessary.

Always off - The camera will never flash. This is useful if you want to save battery power.

Always on - The camera will always flash.

3 When you touch the option you want, the flash menu will automatically close, allowing you to take a picture immediately.

4 The flash status icon in the viewfinder will change, based on the new flash mode.

Camera

Adjusting the exposure

The exposure defines the difference between light and dark areas in an image. A low contrast image will appear foggy, whereas a high contrast image will appear much sharper.

1 Touch 0.0 .

2 Slide the contrast indicator along the bar towards − for a lower exposure and hazier image or towards + for a higher exposure and a sharper image.

Or make a clockwise touch wheel on the Transparent Touchpad for higher exposure and an anti-clockwise one for lower exposure. You need to activate the contrast indicator first by touching 0.0 .

Adjusting the zoom

You can also zoom in or zoom out. Just make a clockwise touch wheel on the Transparent Touchpad to zoom in, and an anti-clockwise one to zoom out.

Taking a continuous shot

1. From the viewfinder, touch to open all advanced settings options and select **Shot mode** and **Continuous shot**.
2. Position the subject in the viewfinder and press the capture button as if taking a normal photo.
3. The camera will take shots in quick succession.

Using the advanced settings

From the viewfinder, touch to open all advanced settings options.

You can change the camera setting by scrolling the wheel. After selecting the option, touch the **OK** button.

Swap camera - For self portraits, switch to the LG GD900's inner camera.

Image size - Change the size of the photo to save memory space or to take an appropriately sized picture for a contact. See **Changing the image size** on page 51.

Colour effect - Choose a colour tone to use on your new photo. See **Choosing a colour effect** on page 51.

White balance - Choose between **Auto**, **Incandescent**, **Sunny**, **Fluorescent** and **Cloudy**.

Timer - The self-timer allows you to set a delay after the shutter is pressed. Select **Off**, **3 secs**, **5 secs** or **10 secs**. This is ideal if you want to be included in a photo.

Shot mode - Choose the normal or continuous shot mode.

Camera

ISO - The ISO rating determines the sensitivity of the camera's light sensor. The higher the ISO, the more sensitive the camera will be. This is useful in darker conditions when you can not use the flash. Select the ISO value from **Auto**, **100**, **200**, **400**, **800** and **1600**.

Image quality - Choose between **Super fine**, **Fine** and **Normal**. The finer the quality, the sharper the photo. However, the file size will increase as a result, which means you'll be able to store fewer photos in your memory.

Memory in use - Choose whether to save your photos to the Handset memory or the External memory.

Hide icons - Choose the camera settings icons to be hidden manually or automatically.

Image stabilization - Enables you to take a photo without the camera wobbling or shaking.

Auto focus - Select the way the camera will focus. Choose between **Spot**, **Manual** and **Face tracking**.

Shutter sound - Select one of the four shutter sounds.

Grid view - Choose between **Off**, **2x2 grid** or **3x3 grid**.

Reset - Restore all camera default settings.

TIP! When you exit the camera all settings will return to their defaults, except image size and image quality. Any non-default settings will need to be reset, such as colour tone and ISO. Check these before you take your next photo.

TIP! The settings menu is superimposed over the viewfinder, so when you change elements of the image colour or quality you will see a preview of the image change behind the settings menu.

Changing the image size

The more pixels, the larger the file, which means the files take up more memory space. If you want to store more pictures on your phone, you can change the resolution to make the files smaller.

1 Using the viewfinder, touch in the top left corner.

2 Select **Image size** from the Preview menu.

3 Select a pixel value from the six options. (**8Mega**, **5Mega**, **3Mega**, **2Mega**, **1Mega**, **VGA(640X480)**, **Wallpaper**, **QVGA(320X240)**, **MMS**, **Contacts**)

Choosing a colour effect

1 Using the viewfinder, touch in the top left corner.

2 Select **Colour effect** from the Preview menu.

3 There are five colour tone options: **Off**, **Sepia**, **Mono**, **Negative**, **Emboss**.

4 Once you've made your selection, the colour tone menu can be closed by selecting the OK button. You are then ready to take a picture.

TIP! You can change a picture taken in colour to black and white or sepia, but you cannot change a picture taken in black and white or sepia to colour.

Using the inner camera

Your LG GD900 has an inner 640x480 camera for both video calls and taking photos.

1 To switch to the inner camera touch then select Swap camera and select Secondary.

2 After a few seconds you'll see yourself in the viewfinder. To capture the image, press the side button as normal.

TIP! The inner camera has fewer settings as it has no flash nor adjustable sensitivity. You can still alter the image size, colour effect, image quality, white balance and set the self-timer by touching in the same way as when using the main camera.

3 After you've taken the photo you'll be offered all the same options as for an image taken with the main camera.

4 To return to the main camera touch and then select Swap camera and select Main.

Viewing your saved photos

1 You can access your saved photos from within the camera mode. Just touch and your gallery will appear on the screen.

Video camera

Getting to know the viewfinder

Open the slide to use the Outer Camera.

Back - Touch here to return to the home screen.

Start recording

Gallery - Touch this icon to view the gallery.

Exposure - See Adjusting the Exposure on page 55.

Recording speed

Flash status - Set or turn off the flash.

Settings - Touch this icon to open the settings menu. See Using the advanced settings on page 55 for details.

TIP! You can close all shortcut options to give a clearer viewfinder screen. Just touch the centre of the viewfinder once. To recall the options, touch the screen again.

Video camera

Shooting a quick video

1. Press and hold down the camera key on the right side of the phone.
2. Then, switch to . Or, you can enter this menu directly by touching **Video camera**.
3. The video camera's viewfinder will appear on the screen.
4. Holding the phone horizontally, point the lens towards the subject of the video.
5. Press the capture button once to start recording.
6. **Rec** will appear at the bottom of the viewfinder with a timer showing the length of the video.
7. To pause the video, touch and resume recording by selecting .
8. Touch on the screen to stop recording.

After shooting a video

A still image representing your video will appear on the screen. The name of the video will be shown on the bottom of the screen, along with four icons on the right-hand side.

Play Touch to play the video.

Send Touch to send the photo as a **Message**, **Email**, **Bluetooth**, and **YouTube**. See page 38 for Sending a message, and page 97 for Sending and receiving your files using Bluetooth.

NOTE: Additional cost may occur when MMS are downloaded when roaming.

Use Touch to use the video as Ringtone or video call ringtone.

Rename Touch to edit the name of the selected Video.

Touch to return to the previous menu.

Touch to delete the video you have just made, and confirm by touching **Yes**. The viewfinder will reappear.

Touch to shoot another video immediately. Your current video will be saved.

Touch to view the saved videos and pictures gallery.

Adjusting the exposure

The exposure defines the difference between light and dark areas in an image. A low contrast image will appear foggy, whereas a high contrast image will appear much sharper.

1 Touch 0.0 .

2 Slide the exposure indicator along the bar, towards for a lower exposure and fuzzier image, or towards for a higher contrast and sharper image.

Using the advanced settings

Using the viewfinder, touch **Settings** to open all the advanced settings options.

You can adjust the video camera setting by scrolling the wheel. After selecting the option, touch the **OK** button.

Swap camera - Switch to your LG GD900's inner camera to record yourself on video. See **Using the inner video camera** on page 58 for details.

Video size - Change the size of the video to save memory space. See

Video camera

Changing the video image size on page 57.

Scene mode - Choose between **Auto** or **Night mode**.

Colour effect - Choose a colour tone to use on your new view. See **Choosing a colour tone** on page 58.

White balance - The white balance ensures any white parts of your video are realistic. To enable your camera to adjust the white balance correctly, you may need to determine the light conditions. Choose between **Auto**, **Incandescent**, **Sunny**, **Fluorescent** or **Cloudy**.

Video quality - Choose between **Super fine**, **Fine** and **Normal**. The finer the quality, the sharper the video will be. The file size will increase as a result, meaning you'll be able to store fewer videos in the phone's memory.

Duration - Set a duration limit for your video. Choose between **Normal** and **MMS** to limit the maximum size to send as an MMS.

TIP! If you choose MMS duration, choosing a lower image quality will enable you to shoot a longer video.

Memory in use - Choose whether to save your videos to the Handset memory or to the External memory.

Voice - Choose Mute to record a video without sound.

Hide icons - Select whether to hide the icons on the camera menu automatically or manually.

Reset - Reset all the video camera settings.

Changing the video image size

The more pixels, the larger the file size, which means the files take up more memory space. If you want to store more videos on your phone, you can change the video resolution to make the files smaller.

1 Using the viewfinder, touch in the top left corner.

2 Select **Video size** from the Preview menu.

3 Select a pixel value from the four options:

720X480(D1) - The highest quality, widescreen option.

640x480 - Standard sized VGA.

320x240 - Smaller image size, and therefore a smaller file size. This is ideal for saving memory space.

176x144 - Smallest image size and therefore the smallest file size.

4 Touch the OK button to return to the viewfinder.

TIP! The great editing software on your LG GD900 is compatible with all video types except 720X480 (D1). Don't record in this format if you plan to edit your video.

TIP! For video format conversion software, see the CD that came with your GD900.

Video camera

Choosing a colour tone

1 Using the viewfinder, touch in the top left corner.

2 Select **Colour effect** from the Preview menu.

3 There are six colour tone options, **Off**, **Sepia**, **Mono**, **Negative** or **Emboss**.

4 Touch the colour tone you want to use.

TIP! You can change a video shot in colour to black and white or sepia, but you cannot change a video shot in black and white or sepia to colour.

Using the inner video camera

Your LG GD900 has an inner 320x240 camera for both video calls and recording videos.

1 To switch to the inner camera, touch then select Swap camera and select Secondary.

2 After a few seconds you'll see yourself in the viewfinder. To start recording the image press the capture button as normal, and press it again to stop recording.

3 After you have shot the video, you'll be offered all the options available for a video shot using the main camera.

4 To return to the main camera touch and select Swap camera and select Main.

TIP! You can still alter the image size, colour effect, white balance and quality by touching **Settings** in the same way as when using the main camera.

Watching your saved videos

1 In the viewfinder, touch .

2 Your gallery will appear on the screen.

3 Touch a video once to bring it to the front of the gallery. It start to play automatically.

Watching your videos on TV

Connect your GD900 to your TV using the TV output cable.

NOTE: The TV output cable is available for purchase separately.

TIP! All formats except 320x240 and 176x144 are compatible with playing the video through a TV.

Your photos and videos

Viewing your photos and videos

1 Touch on the camera preview screen.

2 Your gallery will appear on the screen.

3 Touch the video or photo to open it fully.

TIP! Flick left or right to view other photos or videos.

TIP! To delete a photo or video, open it and select . Touch **Yes** to confirm.

Using zoom when viewing a video or photo

When viewing photos or videos, you can zoom in and out by pinching your fingers together or spreading them apart.

Adjusting the volume when viewing a video

To adjust the volume of a video while it is playing, touch the volume bar on the screen bottom after pressing the loudspeaker symbol. Alternatively, use the volume keys on the side of the phone.

Setting a photo as wallpaper

1 Touch the photo you want to set as wallpaper to open it.

2 Touch the screen to open the options menu.

3 Touch **Use as** .

4 The screen will switch to portrait mode. You can zoom in and out and move the cropped section of

the picture using a thumbnail at the bottom of the screen.

Editing your photos

You can do lots of great things to your photos to change them, add to them or liven them up.

1 Open the photo you want to edit and touch Edit to show the options.

2 Touch the icons to alter your photo:

Crop your photo. Choose a square or circular crop area and move your finger across the screen to select the area.

Draw something on your photo, freehand. Select the line thickness from the four options, then the colour you want to use.

Adding writing on a picture. See **Adding text to a photo** on page 62.

Decorate your photo with stamps. Choose from the different stamps and touch your photo where you want to place them.

Erase the editing you have done to the picture. You can choose the size of eraser you use.

Touch to return to the gallery.

Save Save the changes you made to the photos. Select to save the changes as an **Original file** or a **New file**. If you select **New file** enter a file name.

Undo Erase the editing you have done to the photo.

Image Touch to open further effect options including **Rotate**. There are also more advanced editing options.

Filter Touch to apply the effect options to a photo.

Adjust ment This helps to adjust a picture taken using automatic colour, brightness etc.

Adding text to a photo

1 From the editing screen, touch T.

2 Select **Text** to add unframed text or choose one of the speech bubble shapes.

3 Enter your text using the keypad and touch **Save**.

4 Move the text by touching it and sliding it to where you want it.

Adding an effect to a photo

1 From the editing screen, touch **Filter**.

2 You can apply any of the various options to the photo

3 To undo an effect simply touch **Undo**.

Cropping a photo

1 From the editing screen, touch ⬚.

2 Choose the shape you want to use to crop the picture.

3 Drag the box over the area you want to crop.

4 When you are finished with your selection, touch Save .

Adding a colour accent to a photo

1 From the editing screen, touch Image .

2 Choose **Colour Accent**.

3 Select part of the photo. A traced line will appear around everything in that area which is the same or a similar colour, for example, a person's hair or jumper.

4 Alter the intensity of the accenting by touching Intensity and touch '+' or '-' button.

5 Touch **OK**.

6 All colour will be removed from the photo, apart from in the section marked for colour accenting.

7 Select Save to save the changes.

Swapping colours in a photo

1 From the editing screen, touch Image .

2 Choose **Colour swapping**.

3 Select part of the photo. A traced line will appear around everything in that area which is the same or a similar colour. For example, someone's hair or jumper.

4 Select a colour.

5 Press **OK**.

6 The part of the photo selected for colour accenting will change to the selected colour.

7 Select Save to save the changes.

Editing your videos

The video editing features are available for MPEG4 types except 720x480 (D1) resolution.

Don't record in these formats if you plan to edit your video.

Trimming the length of the video

1 Open the video you want to edit, touch option key.

2 Select Edit and choose **Trim/ Multi trim**.

3 Touch and set the new start and end points using Trim .

4 Touch Preview to confirm you are satisfied with the new cut.

5 Touch Save or, alternatively, touch to return to the gallery and discard the changes.

Merging two videos

1 Open the video you want to edit, touch option key.

2 Select Edit and choose **Video merge**.

3 The My videos folder will open. Choose the video you want to merge.

4 Touch and slide the photo to move it to the end or the beginning of the video.

5 Touch **Preview** to choose how to merge the videos together.

6 Press **Save** then **New file** to save the new merged video. Replace the existing file or save as a new file.

7 Repeat these steps to merge more videos.

Merging a photo with a video

1 Open the video you want to edit, touch ☰ option key.

2 Select Edit and choose **Image merge**.

3 The My images folder will open. Choose the photo you want to move into your video and touch **Select**.

4 Touch and slide the photo to merge it to the end or the beginning of the video.

5 Touch **Preview** to choose how the photo and video merge together.

6 Press **Save** then choose to replace the existing file or save as a new file.

7 Repeat these steps to merge more photos.

Adding text to a video

1 Open the video you want to edit, touch ☰ option key.

2 Select Edit and select **Text overlay**.

3 Touch ▶ and pause playback for setting the start point for text appearance.

4 Touch Start and choose the text styles. Enter your text using the keypad and select **OK**.

5 Touch the area of the screen you want the text to appear and touch **OK**.

6 Touch **Save**. Replace the existing file or save as a new file.

7 Repeat these steps to add more text.

Overlaying a photo

1 Open the video you want to edit, touch ☰ option key.

2 Select Edit and choose **Image overlay**.

3 The My images folder will open. Choose the photo you want to overlay on your video.

4 Touch ▶ and pause when you want the picture to appear, then select Opacity after touching the Start button.

5 Touch **OK** and then press **End** when the photo overlay shall be stopped.

6 Touch the area of the screen in which you want the text to appear. If the photo is too big it will overlay the whole screen, not just the selected area.

7 Touch **Save**. Replace the existing file or save as a new file.

8 Repeat these steps to add more photos.

Adding a soundtrack to your video

1 Open the video you want to edit, touch ☰ option key.

2 Select Edit and choose **Audio dubbing**.

3 The My sounds folder will open. Choose the track you want to add to your video.

4 The original audio track on your video will be erased.

5 If the audio is shorter than the video, choose whether to play it **Once** or to **Repeat** it.

6 Replace the existing file or save as a new file.

Adding live sound to your video

1 Open the video you want to edit, touch ☰ option key.

2 Select Edit and choose **Live dubbling**.

3 Set the sound value to original sound or recording sound.

Changing the video speed

1 Open the video you want to edit, touch ☰ option key.

2 Select Edit and choose **Time scaling**.

3 Select one of the options. This can vary depending on the frame rate.

4 Replace the original file or save as a new file.

Adding a dimming effect

1 Open the video you want to edit, touch ☰ option key.

2 Select Edit and choose **Dimming Effect**.

3 Your video will now fade in at the start and fade out at the end.

4 Replace the original file or save as a new file.

Multimedia

You can store multimedia files in your phone's memory so you have easy access to all your pictures, sounds, videos and games. You can also save your files to a memory card. Using a memory card allows you to free up space in your phone's memory.

To access the Multimedia menu, touch select **My stuff** from Multimedia tab. You can open a list of the folders that store all your multimedia files.

TIP! To delete any files in My stuff, touch then **Delete**.

Pictures

My images contains a list of pictures including default images pre-loaded onto your phone, images you have downloaded and those taken on your phone's camera.

My images options menu

The options available to you in **My images** depend on the type of image you have selected. All options will be available for pictures you have taken on the phone's camera, but only the **Set favorites, Sort by, Slide show** and **Memory manager** options are available for default images.

Sending a photo

1. To send a photo just select picture you want.
2. Touch **Send**. Choose between **Message**, **Email**, **Bluetooth** or **Blogger**.
3. If you choose **Message** or **Email**, your photo will be attached to a message and you can write and send the message as normal.
   If you choose **Bluetooth**, your phone will search for a device to send the picture to.

Using an image

You can choose images to use as wallpapers and screensavers, or even to identify a caller.

1 Touch then select **My stuff** from Multimedia tab.

2 Touch **My images**.

3 Select an image and touch .

4 Touch **Use as** and choose between:

Homescreens - Set a wallpaper for All homescreens, Widget, Contacts, Multimedia or Shortcut.

Lock screen - Set a wallpaper for the key lock screen.

Contacts image - Allocate an image to a person in your contacts list, so the picture is displayed when they call you.

Start up image - Set an image to appear when you switch the phone on.

Shut down image - Set an image to appear when you switch the phone off.

Outgoing call image - Set an image to appear during outgoing calls.

Incoming call image - Set an image to appear during incoming calls.

Printing an image

1 Touch then select **My stuff** from Multimedia tab.

2 Touch **My images**.

3 Select an image and touch .

4 Touch **Print**, then choose between **Bluetooth** and **PictBridge**.

Moving or copying an image

An image can be moved or copied between the phone memory and the memory card. You may want to do this to clear some space in one of the memories, or to safeguard your images against loss.

1 Touch then select **My stuff** from Multimedia tab.
2 Touch **My images**.
3 Touch .
4 Select **Move** or **Copy**.

Creating a slide show

If you want to view all the images on your phone, you can create a slide show to save you having to open and close each individual image.

1 Touch then select **My stuff** from Multimedia tab.
2 Touch **My images**.
3 Touch then **Slide show**.

Checking your memory status

You can check to see how much memory space you have used and how much you have left.

1 Touch then select **My stuff** from Multimedia tab.
2 Touch **My images**.
3 Touch then **Memory manager**.

Sounds

The **My sounds** folder contains Downloaded sounds, **Default sounds** and **Voice recordings**. From here you can manage or send sounds or set them as ringtones.

Using a sound

1 Touch then select **My stuff** from Multimedia tab.
2 Touch **My sounds**.
3 Select **Default sounds** or **Voice recordings**.

4 Select a sound and touch the play icon. It will start to play.

5 You can use the sound for various tones by selecting the **Use as** menu.

6 Choose between **Voice ringtone**, **Video ringtone** and **Message tone**.

Videos

The **My videos** folder shows a list of videos you have downloaded or recorded on your phone.

Watching a video

1 Touch then select **My stuff** on the Multimedia tab.

2 Touch **My videos**.

3 Select a video to play.

TIP! GD900 supports both DivX & Xvid video format playback to ensure greater content availability. Refer to page 88 for detail.

NOTE: The TV output cable is available for purchase separately.

Sending a video clip

1 Select a video and touch .

2 Touch **Send** and choose between **Message**, **Email**, **Bluetooth** and **YouTube**.

3 If you choose **Message** or **Email**, your video clip will be attached to the message, which you can write and send as normal. If you choose **Bluetooth**, your phone will search for a device to send the video to.

Games and Applications

You can download new games and applications to your phone to keep you enjoy.

Multimedia

Playing a game

1 Touch then select **Games & Apps** on the Multimedia tab.

2 Touch **Games** or **Applications** menu.

3 Touch Launch button to launch a game or an application.

Using the options menu

Within Games and Application folders, the following options are available:

- **New folder**: Create a folder within Games or Applications
- **Sort by**: Sort the games and applications by Date, Name, Size or Memory
- **Memory manager**: View the memory status handset or external memory.
- **Folder info.**:View the folder information.

Installing a Java game and application

1 Touch then select **My stuff** on the Multimedia tab.

2 If you insert new memory card, touch External Memory menu.

3 Select the file(*.jad or *.jar) you want to install and touch **Install**.

Use the M-Toy menu

M-Toy contains preloaded flash games which use the integrated motion sensor.

Flash contents

The Flash contents folder contains all of your default and downloaded SWF files.

Viewing an SWF/ SVG file

1 Touch then select **My stuff** from Multimedia tab.

2 Touch **Flash contents**.

3 Select the file you want to view.

Documents

This is possible with your Excel, PowerPoint, Word, Text and pdf files.

Viewing a file

1 Touch then select **My stuff** from Multimedia tab.

2 Touch **Documents**.

3 Select a document and touch **View**.

Transferring a file to your phone

Bluetooth is probably the easiest way of transferring a file from your computer to your phone. You can also use LG PC Suite via your sync cable, see page 84 for details.

To transfer files (e.g. music) using Bluetooth:

1 Make sure your phone and computer have Bluetooth switched on and are within range of each other

2 Use your computer to send the file via Bluetooth.

3 When the file is sent, accept it on your phone by touching **Yes**.

4 The file should appear in your **Documents** or **Others** folder.

Others

The **Others** folder is used to store files that are not pictures, audio files, videos, games or applications. It is used in the same way as the **Documents** folder. You may find that when you transfer files from your computer to your phone that they appear in the **Others** folder.

If this happens, you can move them.

Creating a movie

1 Touch then select **Movie maker** from Multimedia tab.

2 Touch **Insert** to add an image.

3 Touch the **Style** tab on the top to choose a movie style.

4 Touch the **Sound** tab on the screen to change the sound, e.g. for a voice recording.

5 Touch the **Preview** button to see the results.

6 Touch the **Play Order** tab on the screen to change the order.

7 Touch the **Saved in** tab on the screen to choose where to save the movie, and touch the **Usage** tab to choose between storing it and MMS.

8 To save your movie touch **Save movie**.

Music

Your LG GD900 has a built-in music player that lets you play all your favourite tracks. To access the music player, touch then select **Music** from Multimedia Tab. From here, you can access a number of folders:

All tracks - Contains all the songs you have on your phone.

Favorites - Contains the songs you have saved as favourites.

Artists - Browse your music collection by artist.

Albums - Browse your music collection by album.

Genres - Browse your music collection by genre.

Transferring music onto your phone

The easiest way to transfer music onto your phone is via Bluetooth or the data cable.

You can also use LG PC Suite, see page 84 for details. To transfer music using Bluetooth:

1. Make sure both devices have Bluetooth switched on and are connected to each other.
2. Select the music file on the other device and select send via Bluetooth.
3. When the file is sent, you will have to accept it on your phone by touching **Yes**.
4. The file should appear in **Music** > **All tracks**.

Playing a song

1. Touch then select **Music** from the Multimedia tab.
2. Touch **All tracks**.
3. Select the song you want to play then touch .
4. Touch to pause the song.
5. Touch to skip to the next song.
6. Touch to go back to the previous song.
7. Touch to return to the **Music** menu.

To change the volume while listening to music, touch . Or make a clockwise touch wheel on the Transparent Touchpad to turn up the volume and an anti-clockwise one to turn down the volume.You need to activate the volume indicator first by touching .

Creating a playlist

You can create your own playlists by choosing a selection of songs from the **All tracks** folder.

1 Touch then select **Music** from the Multimedia tab.

2 Touch the option icon.

3 Touch **New playlist**, enter the playlist name and touch .

4 The All tracks folder will be displayed. Touch all of the songs that you would like to include in your playlist; a tick will appear next to these track names.

5 Touch **Add songs**.

To play a playlist, select it and touch Play.

NOTE: To add a second playlist, touch then New playlist.

Deleting a playlist

1 Touch then select **Music** from the Multimedia tab.

2 Touch the option icon.

3 Touch **Delete** or **Delete all** to delete all of the playlists.

Using the radio

Your LG GD900 has an built-in FM radio feature so you can tune into your favourite stations and listen on the move.

NOTE: You will need to attach your headphones to listen to the radio. Insert them into the headphone socket.

Searching for stations

You can tune your phone to radio stations by searching for them manually or automatically. They will then be saved to specific channel numbers, so you don't have to keep re-tuning. You can store up to 30 channels on your phone.

To tune automatically

1 Touch then select **FM radio** from Multimedia tab.

2 Touch .

3 Touch **Auto scan** then **Yes**. The stations found will be allocated to channel numbers in your phone by selecting **Set**, **Skip** and **Stop**.

NOTE: You can also manually tune to a station by using the wheel displayed next to the radio frequency.

Resetting channels

1 Touch then select **FM radio** from Multimedia tab.

2 Touch .

3 Choose **Reset channel** to reset the current channel or choose **Reset all channels** to reset all of the channels. If you reset all of the channels, each channel will return to the starting 87.5Mhz frequency.

Listening to the radio

1 Touch then select **FM radio** from Multimedia tab.

2 Touch the channel number of the station you would like to listen to.

TIP! To improve radio reception, extend the headset cord, which functions as the radio aerial.

Warning! If you connect the headset not specifically made for it to the phone, the radio reception can be interfered.

Organiser

Adding an event to your calendar

1 From the home screen select then scroll to **Organiser** on the Utilities tab.

2 Select the date to which you want to add an event.

3 Touch then **New schedule**.

4 Touch **Category** then choose between **Appointment**, **Anniversary** or **Birthday**. Check the date and enter the time you want your event to begin.

5 For appointments and anniversaries, you can enter the time and date the event finishes in the lower time and date boxes.

6 If you would like to add a subject or note to your event, touch **Subject** and type in the details.

7 Select **Set alarm** to set an alert for the event. If you want to repeat the alarm, select **Set repeat**.

8 Touch to save the event in the calendar. A coloured square in the calendar will mark all days that have saved events, and an alarm will sound at the event start time, to help you staying organised.

TIP! You can enter holidays in your calendar. Individually touch each day of the holiday, then touch and select **Set holiday**. Each day will be marked in red.

Changing your default calendar view

1 From the home screen select then scroll to **Organiser** on the Utilities tab. Select **Settings** in .

2 Touch **Default view** and choose Month, Week, Timetable, List or All tasks.

Organiser

Adding an item to your To Do list

1 From the home screen select then scroll to **Organiser** on the Utilities tab.

2 Select select **New task** and touch **Note**.

3 Set the date for the task, add notes, then select its priority level: **High**, **Medium** or **Low**.

4 Save the task by selecting .

TIP! You can back up and synchronise your calendar with your computer. See PC Sync on page 84.

Using the date finder

Date finder is a handy tool to help you calculate what the date will be once a certain number of days have passed. For example, 60 days from 10.10.09 will be 09.12.2009.
This helps you keeping track of deadlines.

1 From the home screen select then scroll to **Organiser** on the Utilities tab.

2 Select , select **Date finder**.

3 Set the required date in the **From** tab.

4 In the **After** tab set the number of days.

5 The **Target date** will be shown below.

Setting your alarm

1 From the home screen select then scroll to **Alarms** on the Utilities tab.

2 If you want add a new alarm, touch **New alarm**. If you want to set the alarm to sound again within one hour, touch **Quick alarm**.

3 Set the time you would like the alarm to sound.

4 Choose whether you want the alarm to repeat, set the repeat and type. The icons indicate the weekday you select.

5 Select **Sound/ Vibration** to select the type of alarm you want.

6 Touch **Alarm bell** for selecting the alert melody or sound. To listen to the sounds, touch the sound and play.

7 Add a memo to the alarm.

Adding a memo

1 From the home screen select then scroll to **Memo** on the Utilities tab.

2 Touch **New memo**.

3 Type your memo, then touch .

TIP! You can edit an existing memo. Select the one to be edited , touch **Edit** and type in your changes.

Voice recorder

Use your voice recorder to record voice memos or other audio files.

Organiser

Recording a sound or voice

1 Touch .

2 Touch **Voice recorder** in Utilities tap.

3 Choose where to save the recording between Handset and External.

4 Choose recording mode between General and MMS.

5 Touch **Rec.** to begin recording.

6 Touch **Stop** to end recording.

7 If you want to re-record the voice, touch **New**.

Sending the voice recording

1 Once you have finished recording, you can send the audio clip by touching **Send**.

2 Choose **Message**, **Email** or **Bluetooth**. If you choose **Message** or **Email**, the recording will be added to the message which you can write and send it as normal. If you choose **Bluetooth**, your phone will search for a device to send the voice recording to.

Using your calculator

1 From the home screen select , then scroll to **Calculator** on the Utilities tab.

2 Touch the number keys to enter numbers.

3 For simple calculations, touch the function you require (+, –, x or ÷), followed by =.

4 For more complex calculations, touch and choose between **sin, cos, tan, deg, log, etc.**.

Converting a unit

1 From the home screen select , then scroll to **Tools** on the Utilities tab.

2 Select **Unit converter**.

3 Choose whether you want to convert **Currency**, **Area**, **Length**, **Weight**, **Temperature**, **Volume** or **Velocity**.

4 Then select the unit and enter the value you would like to convert from.

5 The corresponding values then will appear on the screen.

Using the stopwatch

1 From the home screen, select .

2 Select **Stopwatch**.

3 Touch **Start** to begin timing.

4 Touch **Lap** if you want to record a lap time.

5 Touch **Stop** to end the timer.

6 Touch **Reset** to start the time again.

Adding a city to your world clock

1 From the home screen, select and scroll to **World clock** in the Utilities tab.

2 Touch **Add city**. Choose continent and select the city from the **Map**. Or touch and touch **List**. Start typing the name of the city you require, and it will be displayed on the screen.

3 Touch the city to select it. This will add it to your World time list.

PC Suite

You can synchronise your PC with your phone. This will ensure all your important details and dates match, and also act as a back up to help your mind at ease.

TIP! To do this, you will need to install the PC Suite application provided on the CD-ROM or available as a download from http://update.lgmobile.com. (From www.lgmobile.com PRODUCTS > Manual & Software > Go to Manual & S/W Download Section)

Installing the LG PC Suite on your computer

1 From the home screen touch , then scroll to **Connectivity** on the Settings tab.

2 Touch **USB connection mode**.

3 Connect handset and PC via USB cable and wait for a while.

4 Installation guide message will be displayed.

Caution! If installation guide message is not displayed in your PC, please check your CD-ROM setting on Windows.

5 Insert the supplied CD or click download button to directly download LG PC Suite program from website.

6 Click on the LG PC Suite Installer which will appear on your screen.

Connecting your phone and PC

1 Select PC Suite mode in Connectivity menu and then connect the USB cable to your phone and your PC.

2 LG PC Suite will be automatically activated on your PC.

Caution! If LG PC Suite is not activated automatically in your PC, please check your CD-ROM setting on PC.

3 Your phone and PC are now connected.

Backing up and restoring your phone's information

1 Connect your phone to your PC as outlined above.

2 Click on the **Backup** icon, and select **Backup** or **Restore**.

3 Choose whether to back up **Contents Data** and/or **Phonebook**/**Schedule**/**Todo**/**Memo Data**. Select the location you want to back up the information to, or restore it from. Click **OK**.

4 Your information will be backed up.

Viewing phone files on your PC

1 Connect your phone to your PC as outlined above.

2 Click on the **Manage Files** icon.

3 All the documents, flash contents, images, audio files and videos you have saved on your phone will be displayed on the screen in the LG Phone folder.

TIP! Viewing the contents of your phone on your PC helps you to arrange files, organise documents and remove content you no longer need.

Synchronising your contacts

1 Connect the phone to your PC.

2 Click on the **Contacts** icon.

3 Your PC will now import and display all the contacts saved on your SIM card and handset.

4 Click on **File** and select **Save**. You can now select where you want to save your contacts to.

NOTE: To back up contacts saved to your SIM card, click on the SIM card folder on the left side of the PC screen. Right click on one of

your contacts and choose **Select all**, then **Copy** or **Move to phone memory**.
Right-click your contacts and select **Copy to contact**. Now click on the **Handset** folder on the left side of the screen and all your numbers will be displayed.

Synchronising your messages

1 Connect the phone to your PC.
2 Click on the Messages icon.
3 All your PC and phone messages will be displayed in folders on the screen.
4 Use the tool bar at the top of your screen to edit and rearrange messages.

Music Sync

This menu allows to add music to GD900. Before you start to transfer music from your PC to your device, make sure your computer has the following set-up and accessory is at hand:

- Microsoft Windows XP or Vista
- Windows Media Player 10 or above
- USB cable

NOTE: If your phone is not recognised, or is recognised as an image device by Windows OS.

1. Click Start > Control Panel on your desktop.
2. Select an image scanner device.
3. An image device named "GD900 Music Sync Player" will be displayed in the device list. Connect the mobile phone to your PC using the USB cable (if it is not connected).
4. To remove the device, right-click it to select Remove in the context menu.
5. Disconnect the USB cable from the mobile phone.

6. Install Windows Media Player version 11(WMP 11).
7. When WMP is successfully installed, connect the mobile phone to your PC.

Transferring music using Windows Media Player

1 From the home screen select , then scroll to **Connectivity** on the Settings tab.

2 Select **USB connection mode** and choose **Music sync**.

3 Connect your handset and PC using a compatible USB cable.

4 When you try to connect the handset to your PC, your handset will read: Music Sync... followed by **Connected**.

5 The PC will prompt you to launch your preferred music management software.

6 Select Windows Media Player.

7 Go to the Sync Tab, then drag and drop the music you wish to transfer to your handset into the **Sync List** pane.

8 Click on **Start Sync** button. This starts the transfer process.

⚠ WARNING

Do not disconnect your phone during the transfer.

NOTE: Music Sync is only available for music contents.

Using ISync

Install the iSync plug-in install file which is supported by Macintosh and connect the phone via Bluetooth or USB.

To synchronise via Bluetooth, set up a pairing between the Macintosh or PC and the phone. If you want to set up via USB, select the iSync menu in USB connection mode.

NOTE: When using Bluetooth, you have to select **ISync on** in option menu.

TIP! To install the iSync menu in Macintosh PC, please visit the website www.lgmobile.com and download the plug-in for iSync.

DivX Converter

Install the DivX converter, which is supplied on the same CD as the PC Sync software. DivX will convert media files on your PC to a format that lets you upload them and view them on your phone.

Once installed select **DivX** from the Program Files on your PC, then **DivX converter** followed by Converter.

Use the arrows in the application to change the conversion format to Mobile. If you right click on the application box and select **Preferences**, you can change the location where the converted files are saved.

Drag and drop the files into the application for initial analysis. Then select **Convert** for the process to begin. When the process is complete, a Conversion complete pop up will be displayed.

ABOUT DIVX VIDEO: DivX® is a digital video format created by DivX, Inc. This is an official DivX Certified device that plays DivX video. Visit **www.divx.com** for more information and software tools to convert your files into DivX video.

ABOUT DIVX VIDEO-ON-DEMAND: This DivX Certified® device must be registered in order to play DivX Video-on-Demand (VOD) content. To generate the registration code, locate the DivX VOD section in the device setup menu. Go to **vod.divx.com** with this code to complete the registration process and learn more about DivX VOD.

The web

Browser

Browser gives you a fast, full-colour world of games, music, news, sport, entertainment and loads more, straight to your mobile phone. Wherever you are and whatever you're into.

Accessing the web

1 From the home screen select then scroll to **Browser** on the Communication tab.

2 To go straight to the browser home page, select **Home**. Alternatively, select **Enter address** and type in the URL.

NOTE: You will incur extra cost by connecting to these services and downloading content. Check data charges with your network provider.

Adding and accessing bookmarks

For easy and fast access to your favourite websites, you can add bookmarks and save web pages.

1 From the home screen select then scroll to **Browser** on the Communication tab.

2 Select **Bookmarks**. A list of your Bookmarks will appear on the screen.

3 To add a new bookmark, select and touch **New bookmark**. Enter a name for the bookmark followed by its URL.

4 Touch . Your Bookmark will now appear in the bookmark list.

5 To access the bookmark simply touch the bookmark then touch connect. You will be connected to the bookmark.

The web

Using the RSS reader

RSS (Really Simple Syndication) is a family of web feed formats used to publish frequently updated content, such as blog entries, news headlines or podcasts. An RSS document, called a feed, web feed or channel, contains either a summary of content from an associated website or its full text. RSS makes it possible for people to keep up-to-date with their favourite web sites in an automated way that is easier than checking manually.
The user subscribes to a feed by entering its link into the reader or by clicking an RSS icon in a browser that starts the subscription process. The reader checks the user's subscribed feeds regularly for new content and downloads any updates that it finds.

Accessing a saved page

1 From the home screen select then scroll to **Browser** on the Communication tab.
2 Select **Saved pages**.
3 Select the page you want to view and it will open.

Viewing your browser history

1 From the home screen select then scroll to **Browser** on the Communication tab. Select **History**.
2 The web pages you have accessed recently will be displayed. To access any of these pages, simply select it.

Changing web browser settings

1 From the home screen select then scroll to **Connectivity** on the Settings tab.

2 Select **Browser settings**.

3 You can edit the **Profiles**, **Appearance settings**, **Cache**/ **Cookies**, **Security** or **Reset settings**.

4 You can simply set these on or off by touching the switch icon.

Using your phone as a modem

Your GD900 can be used as a modem for your PC, giving you email and internet access even when you don't have any wired connection. You can do this via the USB cable or by Bluetooth.

Using the USB cable:

1 Ensure you have the LG PC Suite installed on your PC.

2 Connect your GD900 and your PC using the USB cable and launch the LG PC Suite software.

3 Click Inernetkit on your PCsuite. Then click New and select Modem.

4 Choose **LG Mobile USB Modem** and select **OK**. It will now appear on the screen.

5 Click Connect and your PC will connect via your GD900.

NOTE: For more information on synchronising using the LG PC Suite see page 84.

Using Bluetooth:

1. Ensure Bluetooth is switched **On** and **Visible** for both your PC and GD900.
2. Pair your PC and GD900 so that a passcode is required to connect them.
3. Use the **Connection wizard** on your LG PC Suite to create an active Bluetooth connection.
4. click Inernetkit on your PCsuite. Then click New and select Modem.
5. Click **Modem**.
6. Choose **Standard Modem over Bluetooth link** and click **OK**. It will now appear on the screen.
7. Click **Connect** and your PC will connect via your GD900.

NOTE: For more information on Bluetooth see page 98.

Access to Google Maps

You can use Google navigation services from the Communication tab. Select the Google Maps menu in Google to launch the application. Note that additional cost may occur when using this service.

Settings

This folder lets you adapt your settings to personalise your GD900.

NOTE: For information on call settings see page 34.

Changing your screen settings

1 From the home screen, select then scroll to **Screen settings** on the Settings tab.

2 You can choose the option menu from:

Wallpaper - Choose an image for Home screen, locking, switching the phone on or off, or making or receiving a call.

NOTE: The setting will be reset if you select **Reset** menu.

Homescreens - Shortcut/Widget/Contact/Multimedia.

Lock screen - Choose the clock type on the lock screen.

Menu style - Choose Style.

Font - Adjust the font size and style.

Backlight - Choose how long the backlight stays on.

NOTE: The longer the backlight stays on, the more battery power it uses and you may need to recharge your phone more often.

Auto brightness - Adjust the screen brightness automatically.

Brightness - Adjust the screen brightness.

Personalising your profiles

You can quickly change your profile on the home screen. Just touch the status summary icon on the top, then touch the profile tab.

Using the settings menu, you can personalise each profile setting.

1 From the home screen select then scroll to **Profiles** on the Settings tab.

2 Choose the profile you want to edit: **Normal**, **Silent**, **Outdoor** or **Flight mode**.

3 You can then change all sounds and alert options available in the list, including your **Voice/Video ringtone**, **Volume**, **Message alerts** and others.

Changing your phone settings

Use the freedom of adapting the GD900 to your own preferences.

1 From the home screen, select then scroll to **Phone settings** on the Settings tab.

2 Select a menu from the list below:

Date & Time - Adjust your date and time settings or choose to auto update the time when travelling or for daylight saving.

Power save - Choose to switch the value power saving settings to **On** or **OFF**.

Languages - Change the language on your GD900's display.

Auto lock - Lock the keypad automatically on the home screen.

Security - Adjust your security settings, including PIN codes and handset lock.

Touch settings - Change the touchpad value settings.

Memory manager - See **Using memory manager** on page 96 for more information.

Reset settings - Restores all settings to their factory defaults.

Handset information - View GD900 technical information.

Changing your touch settings

From the home screen select then scroll to **Phone settings** on Settings tab. Choose **Touch settings**.

Touch vibration - Change the vibration On/Off.

Vibration type - Vibration 1/2/3

Vibration volume - Controls the strength of vibration.

Touch sound - Change the tone when touching the screen.

Sound - Sound 1/2/3

Volume - Controls the volume of tone.

Changing your connectivity settings

Your connectivity settings have already been set up by your network operator, so you can use your new phone immediately.
To Use this menu to change your settings.

From the home screen select then scroll to **Connectivity** on Settings tab.

Network selection - Your GD900 will connect automatically to your preferred network.

Internet profile - Set the profiles for connecting to the internet.

Access points - Your network operator has already saved this information. You can add new access points using this menu.

USB connection mode - Synchronise your GD900 using the LG PC Suite software to copy files from your phone. See page 84 for more information on synchronisation.

Projector/TV out - Choose **PAL** or **NTSC** when connecting your GD900 to a TV.

DivX VOD registration - This menu is used to generate a DivX VOD registration code. Please visit http://

vod.divx.com to register and for technical support.

Packet data conn. - Set the packet data connection.

Browser setting - Set the values related to the browser.

Streaming settings - Your network operator has already saved this information. You can edit it if you want to make changes.

Java settings - Allows you to set profiles for connections made by Java programs and to view certificates.

Using memory manager

Your GD900 has three available memories: the phone itself, the SIM Card and an external memory card (which you may need to purchase separately). You can use memory manager to determine how each memory is used and see how much space is available.

From the home screen select then scroll to **Phone settings** on the Settings tab. Select **Memory Info**.

Handset common memory 1/2 - View the memory available on your GD900 for MMS, Email, Java applications and others.

Handset multimedia memory - View the memory for multimedia contents, such as pictures, sounds, videos, flash contents, documents and others.

Handset reserved memory - View the memory available on your handset for SMS, Contacts, Calendar, To do list, Memos, Alarms, Recent history, Bookmarks and Miscellaneous items.

USIM memory - View the memory available on your SIM Card.

External memory - View the memory available on your external memory card (which you may need to purchase separately).

Using flight mode

Turn flight mode on by selecting then **Settings**. Touch **Profiles** and select **Flight mode**.

Flight mode prevents you making calls, connecting to the Internet, sending messages or using Bluetooth.

Sending and receiving files using Bluetooth

Bluetooth is a great way to send and receive files as it uses no wires and connection is quick and easy. You can also connect to a Bluetooth headset to make and receive calls.

To send a file:

1. Open the file you want to send, which will be typically a photo, video or music file.
2. Touch and choose **Send**. Select **Bluetooth**.
3. If you have already paired the Bluetooth device, your GD900 will not automatically search for other Bluetooth devices. If not, your GD900 will search for other Bluetooth enabled devices within range.
4. Choose the device you want to send the file to and touch **Select**.
5. Your file will be sent.

TIP! Check the progress bar to make sure your file has been sent.

To receive a file:

1 To receive files your Bluetooth must be set to **On**. See **Changing your Bluetooth settings** below for more information.

2 A message will prompt you to accept the file from the sender. Touch **Yes** to receive the file.

3 You will see where the file has been saved and choose to **View** the file or **Use as**. Files will usually be saved to the appropriate folder in My stuff.

Changing your Bluetooth settings

1 From the home screen select then scroll to **Bluetooth** on the Settings tab.

2 Touch .

Make your changes to:

My device information - Enter a name for your GD900.

My device visibility - Choose to be **Visible**, **Hidden** or **Visible for 1 min**.

Remote SIM mode on - Activate the remote SIM mode.

iSync on - Choose to activate on iSync.

Supported services - See options to use Bluetooth in a ssociation with different services.

Delete - Choose to delete the selected profile.

Delete all - Choose to delete all profiles.

Pairing with another Bluetooth device

By pairing your GD900 with another device, you can set up a passcode-protected connection. This makes pairing more secure.

1. Check that your Bluetooth is **On**. You can change your visibility using the **Settings** menu.
2. Touch **New Device**.
3. Your GD900 will search for Bluetooth devices. When the search is completed **Refresh** will appear on the screen.
4. Choose the device you want to pair with and enter a passcode, then touch **OK**.
5. Your phone will then connect to the other device, on which you will need to enter the same passcode.
6. Your passcode-protected Bluetooth connection is now ready.

Using a Bluetooth headset

1. Check that your Bluetooth is **On**.
2. Follow the instructions that came with your headset to put it in pairing mode and pair your devices.
3. The headset will be automatically switched to Headset profile.
4. Touch **Ask before connection** or **Always connect**.

TIP! See page 34 for details on **BT answer mode** so that you can control how you answer calls when your Bluetooth headset is connected.

Wi-Fi

Wireless Manager allows you to manage Internet connections per Wi-Fi (Wireless LAN) on your device. It allows the phone to connect to local wireless networks, or access the Internet wirelessly. Wi-Fi is faster and has a greater range than Bluetooth wireless technology and can be used for fast emailing and Internet browsing.

NOTE: The GD900 supports WEP, WPA-PSK/2 encryption, and not EAP, WPS encryption. If your Wi-Fi service provider or network administrator sets encryption for network security, fill in the key in the pop-up window. If encryption is not set, this pop-up window will not be shown. You can obtain the key from your Wi-Fi service provider or network administrator.

1. How to set up Wi-Fi

1 Touch Wi-Fi from the Settings tab and turn Wi-Fi on

2 AP (Access Point) Search

– Searches which AP it can connect to.

3 AP Connect

– Connects to the desired AP from the AP search list.

– If the AP is security type WEP or WPA-PSK/2, enter the security key.

2. Wi-Fi network profile support

1 Wi-Fi profile support (how to connect to a frequently-used AP or Hidden AP)

1) If the AP does not appear in the search list, you can connect to it by saving it as a profile.

2) Saving the frequently-used AP as a profile makes it easier to enter the Security key when connecting to an AP with that Security type.

3) If the AP does not support DHCP, you can connect to the AP using a static IP address.

2 Description of each field in the Wi-Fi profile.

1) Network name: SSID (ID)

2) Security type: WEP, WPA-PSK/2 support.

3) Security key: saves the security key.

4) IP/DNS setting: this allows you to set to Automatic or Static depending on whether the AP supports DHCP.
For Static, enter the field value of the IP address and DNS server to use with the static IP address when connecting.

3 How to save the Wi-Fi profile

1) Select Saved networks from the Options menu, then select **New network** and enter values into each field.

2) It is possible to select and save the AP search list by selecting **Wi-Fi On** and then **Refresh** (Searching AP).

3) After connecting to an AP with this Security type, the profile will be saved automatically.

3. How to obtain MAC-address

For setting up a connection in some wireless networks with MAC filter you may need to enter the MAC address of your GD900 into the router.

1 Touch Wi-Fi from the settings tab, then open the options menu.

2 Select My MAC Address and it will be displayed.

Software Update

Software Update

LG Mobile Phone Software Update Program

For more information on installing and using this program, please visit http://update.lgmobile.com.

This feature allows you to update your software to the latest version quickly and conveniently over the Internet without needing to visit our service centre.

As the mobile phone software update program requires your full attention throughout the update process, please make sure you check all instructions and notes that appear at each step before moving on to the next step. Please note that removing the USB data communication cable or batteries during the update may seriously damage your mobile phone. As the manufacturer takes no responsibility for loss of data during the update process, you are advised to back up any important information in advance for safekeeping.

Accessories

There are a variety of accessories available for your mobile phone, which may be sold separately. You can select these options according to your personal communication requirements. Consult your local dealer for availability. (**Items described below may be optional**.)

Charger

Battery

Stereo headset

Data cable and CD

Connect and synchronise your GD900 and PC.

User Guide

Learn more about your GD900.

NOTE:

- Always use genuine LG accessories.
- Failure to do this may invalidate your warranty.
- Accessories may vary in different regions.

Network service

The wireless phone described in this guide is approved for use on E-GSM 900, DCS 1800, GSM 850, PCS 1900 and W-CDMA networks.

A number of features included in this guide are called Network Services. These are special services that you arrange through your wireless service provider. Before you can take advantage of any of these Network Services, you must subscribe to them through your service provider and obtain instructions for their use from your service provider.

DivX VOD registration

Generate a DivX VOD registration code.

Please visit <http://vod.divx.com/> for registration and technical support.

Technical data

General

Product name: GD900

System: E-GSM 900 / DCS 1800 / GSM 850 / PCS 1900/ WCDMA

Ambient Temperatures

Max: +55°C (discharging),
+45°C (charging)

Min: -10°C

Declaration of Conformity

LG Electronics

Suppliers Details

Name

LG Electronics Inc

Address

LG Twin Tower 20, Yeouido-dong, Yeongdeungpo-gu, Seoul, Korea 150-721

Product Details

Product Name

E-GSM 900 / DCS 1800 / GSM 850 / PCS 1900 Quad Band and WCDMA Terminal Equipment

Model Name

GD900

Trade Name

LG

CE 0168

Applicable Standards Details

R&TTE Directive 1999/5/EC

EN 301 489-1 V1.6.1 / EN 301 489-7 V1.3.1 / EN 301 489-17 V1.2.1 / EN 301 489-24 V1.3.1
EN 60950-1: 2001
EN 50360 / EN62209-1: 2006
EN 301 511 V9.0.2 / EN 301 908-1 V3.2.1 / EN 301 908-2 V3.2.1
EN 300 328 V1.7.1

Supplementary Information

The conformity to above standards is verified by the following Notified Body(BABT)

BABT, Balfour House, Churchfield Road, Walton-on-Thames, Surrey, KT12 2TD, United Kingdom
Notified Body Identification Number : 0168

Declaration

I hereby declare under our sole responsibility that the product mentioned above to which this declaration relates complies with the above mentioned standards and Directives

Name	Issued Date
Seung Hyoun, Ji / Director	20, May, 2009

Signature of representative

European Standard Center
LG Electronics Logistics and Services B.V.
Veluwezoom 15, 1327 AE Almere, The Netherlands
Tel : +31 - 36- 547 – 8940, Fax : +31 – 36 – 547 - 8794
e-mail : jacob @ lge.com

Guidelines for safe and efficient use

Please read these simple guidelines. Not following these guidelines may be dangerous or illegal.

Exposure to radio frequency energy

Radio wave exposure and Specific Absorption Rate (SAR) information This mobile phone model GD900 has been designed to comply with applicable safety requirements for exposure to radio waves. These requirements are based on scientific guidelines that include safety margins designed to assure the safety of all persons, regardless of age and health.

- While there may be differences between the SAR levels of various LG phone models, they are all designed to meet the relevant guidelines for exposure to radio waves.
- The SAR limit recommended by the International Commission on Non-Ionizing Radiation Protection (ICNIRP) is 2W/kg averaged over 10g of tissue.
- The highest SAR value for this model phone tested by DASY4 for use at the ear is 1.47 W/kg (10g) and when worn on the body is 0.802 W/Kg(10g).
- SAR data information for residents in countries/regions that have adopted the SAR limit recommended by the Institute of Electrical and Electronics Engineers (IEEE), which is 1.6 W/kg averaged over 1g of tissue.

Product care and maintenance

⚠ WARNING

Only use batteries, chargers and accessories approved for use with this particular phone model. The use of any other types may invalidate any approval or warranty applying to the phone, and may be dangerous.

- Do not disassemble this unit. Take it to a qualified service technician when repair work is required.
- Keep away from electrical appliances such as TVs, radios, and personal computers.
- The unit should be kept away from heat sources such as radiators or cookers.
- Do not drop.
- Do not subject this unit to mechanical vibration or shock.
- Switch off the phone in any area where you are required by special regulations. For example, do not use your phone in hospitals as it may affect sensitive medical equipment.
- Do not handle the phone with wet hands while it is being charged. It may cause an electric shock and can seriously damage your phone.
- Do not to charge a handset near flammable material as the handset can become hot and create a fire hazard.
- Use a dry cloth to clean the exterior of the unit (do not use solvents such as benzene, thinner or alcohol).
- Do not charge the phone when it is on soft furnishings.
- The phone should be charged in a well ventilated area.

- Do not subject this unit to excessive smoke or dust.
- Do not keep the phone next to credit cards or transport tickets; it can affect the information on the magnetic strips.
- Do not tap the screen with a sharp object as it may damage the phone.
- Do not expose the phone to liquid or moisture.
- Use the accessories like earphones cautiously. Do not touch the antenna unnecessarily.

Efficient phone operation

Electronics devices

All mobile phones may get interference, which could affect performance.

- Do not use your mobile phone near medical equipment without requesting permission. Avoid placing the phone over pacemakers, for example, in your breast pocket.
- Some hearing aids might be disturbed by mobile phones.
- Minor interference may affect TVs, radios, PCs, etc.

Road safety

Check the laws and regulations on the use of mobile phones in the area when you drive.

- Do not use a hand-held phone while driving.
- Give full attention to driving.

- Use a hands-free kit, if available.
- Pull off the road and park before making or answering a call if driving conditions so require.
- RF energy may affect some electronic systems in your vehicle such as car stereos and safety equipment.
- When your vehicle is equipped with an air bag, do not obstruct with installed or portable wireless equipment. It can cause the air bag to fail or cause serious injury due to improper performance.
- If you are listening to music whilst out and about, please ensure that the volume is at a reasonable level so that you are aware of your surroundings. This is particularly imperative when near roads.

Avoid damage to your hearing

Damage to your hearing can occur if you are exposed to loud sound for long periods of time. We therefore recommend that you do not turn on or off the handset close to your ear. We also recommend that music and call volumes are set to a reasonable level.

Glass Parts

Some parts of your mobile device are made of glass. This glass could break if your mobile device is dropped on a hard surface or receives a substantial impact. If the glass breaks, do not touch or attempt to remove. Stop using your mobile device until the glass is replaced by an authorized service provider.

Guidelines for safe and efficient use

Blasting area

Do not use the phone where blasting is in progress. Observe restrictions, and follow any regulations or rules.

Potentially explosive atmospheres

- Do not use the phone at a refueling point.
- Do not use near fuel or chemicals.
- Do not transport or store flammable gas, liquid, or explosives in the same compartment of your vehicle as your mobile phone and accessories.

In aircraft

Wireless devices can cause interference in aircraft.

- Turn your mobile phone off or activate flight mode before boarding any aircraft.
- Do not use it on the ground without permission from the crew.

Children

Keep the phone in a safe place out of the reach of small children. It includes small parts which may cause a choking hazard if detached.

Emergency calls

Emergency calls may not be available under all mobile networks. Therefore, you should never depend solely on the phone for emergency calls. Check with your local service provider.

Battery information and care

- You do not need to completely discharge the battery before recharging. Unlike other battery systems, there is no memory effect that could compromise the battery's performance.
- Use only LG batteries and chargers. LG chargers are designed to maximize the battery life.

- Do not disassemble or short-circuit the battery pack.
- Keep the metal contacts of the battery pack clean.
- Replace the battery when it no longer provides acceptable performance. The battery pack maybe recharged hundreds of times until it needs replacing.
- Recharge the battery if it has not been used for a long time to maximize usability.
- Do not expose the battery charger to direct sunlight or use it in high humidity, such as in the bathroom.
- Do not leave the battery in hot or cold places, this may deteriorate the battery performance.
- There is risk of explosion if the battery is replaced by an incorrect type.
- Dispose of used batteries according to the manufacturer's instructions. Please recycle when possible. Do not dispose as household waste.
- If you need to replace the battery, take it to the nearest authorized LG Electronics service point or dealer for assistance.
- Always unplug the charger from the wall socket after the phone is fully charged to save unnecessary power consumption of the charger.
- Actual battery life will depend on network configuration, product settings, usage patterns, battery and environmental conditions.

Trouble Shooting

This chapter lists some problems you might encounter while using your phone. Some problems require you to call your service provider, but most are easy for you to correct yourself.

Message	Possible causes	Possible Solutions
SIM error	There is no SIM card in the phone or it is inserted incorrectly.	Make sure the SIM card is correctly inserted.
No network connection	Signal weak Outside GSM network area	Move towards a window or into an open area. Check the service provider coverage map.
Codes do not match	To change a security code, you will need to confirm the new code by entering it again.	Contact your Service Provider.
Function cannot be set	Not supported by Service Provider, or registration required	Contact your Service Provider.
Calls not available	Dialling error New SIM card inserted Charge limit reached	New network not authorised. Check for new restrictions. Contact Service Provider or reset limit with PIN 2.
Phone cannot be switched on	On/Off key not pressed long enough Battery empty Battery contacts dirty	Press the On/Off key down for at least two seconds. Keep charger attached for a longer time. Clean the contacts.

Message	Possible causes	Possible Solutions
Charging error	Battery totally empty	Charge battery.
	Temperature out of range	Make sure the ambient temperature is right, wait for a while, and then charge again.
	Contact problem	Check the power supply and connection to the phone. Check the battery contacts and clean them if necessary.
	No mains voltage	Plug in to a different socket or check the voltage.
	Charger defective	If the charger does not warm up, replace it.
	Wrong charger	Only use original LG accessories.
	Battery defective	Replace battery.
Phone loses network	Signal too weak	Reconnection to another service provider is automatic.
Number not permitted	The Fixed dial number function is on.	Check settings.