Contents

Introduction | 3

Important Information

Before You Start | 4

Chapter 1 Getting Started | 8

Cautions 8
Phone Components 9
Phone Overview 10
Onscreen Icons 11
Using the Battery and Charger 12

Chapter 2 Basic Functions | 15

Turning the Phone On and Off 15
Making a Call 15
Receiving Calls 16
Signal Strength 16
About the antenna 16
Quick Adjust 17
Call Waiting 18
Mute 18
Redialing Calls 19
Speed Dialing 19
Caller ID 19
Entering Information Using T9 Text Input 20
Examples Using T9 Text Input 22
Key Mapping For Hindi Entry 24
To Edit in Hindi Mode 25

Chapter 3 Phone Book | 27

Phone Book Features 27

Chapter 4 Menu Features | 32

General Guidelines to Menu Access and Settings 32
Names 32
Messages 36
Call History 45
Profiles 48
Display 50
Settings 53
Organiser 60
R World 64

Chapter 5 Functions Used During a Call | 68

In Call Memo 68
Mute/Unmute 68
Earpiece/Speaker Volume 68
Voice Privacy On/Off 68
Adjusting Speaker On 68

Chapter 6 Accessories | 69

Chapter 7 Menu Tree | 70

Chapter 8 Frequently Asked Questions | 72

Chapter 9 Safety Guidelines | 76

TIA Safety Information
FDA Consumer Update
Consumer Information on SAR

LIMITED WARRANTY STATEMENT | 92

Service Center List | 94

Introduction

Congratulations on your purchase of the LG-RD5130 cellular phone that has been designed to operate with the latest digital mobile communication technology, Code Division Multiple Access (CDMA). The CDMA system has greatly enhanced voice clarity and can provide various types of advanced features.

This is an advanced and compact phone which has diverse features as follows :

- Large, easy-to-read, 6-line, backlight LCD with status icons.
- Paging, Messaging, Voice mail, and Caller ID.
- 18-key keypad(10 number keys / 2 function keys / 2 Soft keys / 1 clear key / 1 navigation key / 1 Call key / 1 End key).
- Long battery stand-by and talk time.
- Choice of 19 ring sounds + 3 downloadable from R World.
- Menu-driven interface with prompt for easy operation and configuration.
- Call privacy inherent with CDMA encoding.
- Any key answer, auto redialing, one touch and speed dialing with 99 memory locations.
- Optional accessories with greater convenience and enhanced functionality.
- You can hear the recipient's voice louder with Speaker On mode during a call.

Important Information

This user's manual provides important information on the use and operation of your phone. Please read all the information carefully prior to using the phone for the best performance and to prevent any damage to or misuse of the phone. Any unapproved change or modification will void your warranty.

Before You Start

Check Accessories

Your mobile phone comes with a AC Adaptor, rechargeable battery and a Headset. Please verify that these accessories are included.

Safety Instructions

WARNING! To reduce the possibility of electric shock, do not expose your phone to high humidity areas, such as the bathroom, swimming pool, etc.

Use only LG-approved batteries and travel chargers to avoid the damage to the phone. Using other batteries or chargers voids your warranty and may cause the explosion.

Do not use batteries and travel chargers for the other purposes other than their original purpose of using for the phone.

Always store your phone away from heat. Never store your phone in settings that may expose it to temperatures less than -20°C or greater than 50°C, such as outside during a snowstorm or in your car on a hot day. Exposure to excessive cold or heat will result in malfunction, damage and/or catastrophic failure.

Use caution when using your phone near other electronic devices. RF emissions from your mobile phone may affect nearby inadequately shielded electronic equipment. You should consult with manufacturers of any personal medical devices such as pacemakers and hearing aides to determine if they are susceptible to interference from your mobile phone. Turn off your phone in a medical facility or at a gas station.

Never place your phone in a microwave oven as it will cause the battery to explode.

IMPORTANT! Please read the TIA SAFETY INFORMATION(on page 76) before using your phone.

FCC RF Exposure Information

WARNING! Read this information before operating the phone.

In August 1996, the Federal Communications Commission (FCC) of the United States, with its action in Report and Order FCC 96-326, adopted an updated safety standard for human exposure to radio frequency (RF) electromagnetic energy emitted by FCC regulated transmitters. Those guidelines are consistent with the safety standard previously set by both U.S. and international standards bodies.

The design of this phone complies with the FCC guidelines and these international standards.

CAUTION

Use only the supplied and approved accessories. Use of unauthorized accessories or modifications could impair call quality, damage the phone, void your warranty.

Do not use the phone with a damaged accessories. If the damaged accessories come into contact with the skin, a minor burn may result. Contact your local dealer for a replacement of accessories.

Body-worn Operation

This device was tested for typical body-worn operations with the back of the phone kept 3/4 inch (2cm) from the body. To comply with FCC RF exposure requirements, a minimum separation distance of 3/4 inches (2cm) must be maintained between the user's body and the back of the phone, including the antenna. Third-party belt-clips, holsters, and similar accessories containing metallic components should not be used. Body-worn accessories that cannot maintain 3/4 inch (2cm) separation distance between the user's body and the back of the phone, and have not been tested for typical body-worn operations may not comply with FCC RF exposure limits and should be avoided.

Vehicle Mounted External Antenna (optional, if available)

A minimum separation distance of 8 inches (20 cm) must be maintained between the user/bystander and the vehicle mounted external antenna to satisfy FCC RF exposure requirements.
For more information about RF exposure, visit the FCC website at www.fcc.gov

FCC Part 15 Class B Compliance

This device and its accessories comply with part 15 of FCC rules. Operation is subject to the following two conditions: (1) This device and its accessories may not cause harmful interference, and (2) this device and its accessories must accept any interference received, including interference that cause undesired operation.

Cautions for Battery

- Do not disassemble.
- Do not short-circuit.
- Do not expose to high temperature : 60°C (140°F)
- Do not incinerate.

Battery Disposal

- Please dispose of your battery properly or bring to your local wireless carrier for recycling.
- Do not dispose of your battery in fire or with hazardous or flammable materials.

Charger Cautions

- Using the wrong battery charger could damage your phone and void your warranty.
- The charger is intended for indoor use only.

Do not expose the battery charger to direct sunlight or use it in places with high humidity, such as the bathroom.

Cautions

- Only use the batteries and chargers provided by LG. The warranty will not be applied to products provided by other suppliers.
- Using the phone in proximity to receiving equipment (i.e., TV or radio) may cause interference in this phone.
- Keep your phone in a safe place when not in use.
- Only authorized personnel should service the phone and its accessories. Faulty installation or service may result in accidents and consequently invalidate the warranty.
- Do not hold the antenna while the phone is in use.
- Use only the antenna provided or approved by LG. Unauthorized antennas, modifications or attachments may affect the quality of phone call, damage the phone or result in a violation of FCC regulations.

  Do not use the cellular phone if the antenna is damaged. If the damaged antenna gets in contact with the skin, it may cause a slight burn. Please contact LG Authorized Service Center to replace the damaged antenna.
- Do not use the cellular phone in areas where its use is prohibited. (For example: aircrafts).
- Do not expose the cellular phone to high temperature or high humidity conditions.
- Do not expose your cellular phone to water. If this happens, turn it off immediately and remove the battery. If the phone does not work, bring it to an LG Authorized Service Center.
- Avoid shock or impact on the cellular phone.

Phone Components

The following shows key components of your mobile phone.

Phone Overview

LCD Screen	Displays messages & indicator icons.
Soft Keys (the names of the functions of these keys appear at the bottom of the screen)	**Soft Key 1** Used to display the function setting menu. **Soft Key 2** Press this key once in a menu, to go back one level.
CALL Key	Allows user to place or answer calls.
END/PWR Key	Used to turn power on/off and to end a call. Using this key, you can return to the main menu display screen.
Alphanumeric Keypad	These keys enable you to enter numbers and characters and choose menu items.
Navigation Key	This Navigation key allows quick access to Messages and Voice Mail notification messages. Ring Tones, R World, Profiles.
Clear Key	Press to delete a single space or character. Press and hold to delete entire words.
Speaker On Key	In standby mode, set the speaker on mode by pressing and holding the key # about 2 seconds.
Vibrate Mode Key	In standby mode, set the vibrate mode by pressing and holding the key * about 2 seconds.

Onscreen Icons

The phone screen displays several onscreen icons which appear when the phone is powered on.

Icons	Descriptions
	Displays the strength of the signal received by the phone and current signal strength is indicated by the number of bars displayed on the screen.
	No service The phone is not receiving a system signal.
	In use A call is in progress. * No icon indicates the phone is in standby mode.
	Indicates that a Text Message or Voice Mail has been received
	In Vibrate mode.
	In Alarm mode.
	Charge level Indicates battery charge level. When the battery gets fully charged the charging indicator becomes yellow in color.

Using the Battery and Charger

Charge the battery fully before the initial use of the phone.

The phone comes with a rechargeable battery. Keep the battery charged while not in use in order to maximize talk and standby time when using the phone.

Installing and Removing the Battery

- To install, insert the battery into the opening on the back of the phone, and insert the bottom of battery into groove at the bottom of the handset. Gently press down the cover until the latch snaps into place.
- To remove, push the back cover down.
  Push the tab with one hand and lift the top of the battery to separate.

Charging the Battery

To use the AC adapter charger provided with your phone:

1. Plug the AC adapter into the electrical outlet.
2. Insert the round end of the adapter into the AC adapter jack on the bottom of the phone. (Make sure the battery is installed.)

- As the phone charges, the battery icon continually displays a progression from empty ( ) to full ( ).

It takes about three hours to fully recharge a completely rundown battery. When the battery gets fully charged the charging indicator becomes yellow in color.

Battery Charge Level

The battery charge level is shown at the top right of the LCD screen.

When the battery charge level becomes low, the low battery sensor will alert you in three ways: sounding an audible tone, blinking the battery icon outline, and displaying **LOW BATTERY WARNING!** If the battery charge level becomes exceedingly low, the phone will automatically switch off and any function in progress will not be saved.

Caring for the Battery

1) If you use the unauthorized battery, it may cause the damage to or explosion of the battery. Therefore, please prohibit using the unauthorized ones.
2) You do not need to wait until the battery completely runs down to recharge the battery.
3) Use only LG batteries and chargers specific to your model of phone. LG's chargers are designed to maximize battery life.
4) Do not disassemble or short-circuit the battery.
5) Keep the battery's metal contacts clean.
6) Replace the battery when it no longer provides acceptable performance. The battery can be recharged several hundred times before it needs replacing.
7) Recharge the battery if it has not been used for a long time to maximize battery life.
8) Do not expose the battery charger to direct sunlight or use it in areas of high humidity, such as the bathroom.
9) Do not leave the battery in hot or cold places as it may deteriorate battery performance.
10) Your battery life may vary by location, use patterns, etc.
11) Long backlight settings, searching for service, data connectivity, and synchronization all may affect battery life, talk, and standby times.

Chapter 2 Basic Functions

Turning the Phone On and Off

Turning the Phone On

1) Install a charged battery pack or connect the phone to an external power source such as the cigarette lighter charger, car kit or AC Adaptor.

2) Hold down the Key PWR END for 2 seconds until the LCD screen flashes.

Note As any other communication device, avoid any unnecessary contact with the antenna while your phone is turned on.

Making a Call

Every time you make a call, follow these steps:

1) Make sure that the phone is turned on. If not, hold down PWR END for 2 seconds.

2) Type the phone number and then press CALL.

- If the phone is locked, type the lock code (see page 57).

3) To end the call press PWR END.

Note In no service area, appears from the screen. When trying voice call in no service area, "**Call not completed. Please try again**" is displayed. It means you are in no service area.

Receiving Calls

1) When the phone rings or vibrate (if the Vibrate Mode is enabled), press any key (except PWR END) or CALL depending on the Call settings.

- When you press PWR END once, when a call is received, the phone stops ringing or vibrating depending on the mode it is in. Press PWR END twice to disconnect.

2) To end an answered call press PWR END.

Signal Strength

Call quality is always best when the antenna is fully raised. If you're inside a building, being near a window may give you better reception. You can see the strength of your signal by the signal indicator ( ) on your phone's display screen.

About the antenna

Your phone has a built-in antenna. As with any other radio transmitting device, do not touch the antenna unnecessarily when the phone is switched on.
Contact with the antenna affects call quality and may cause the phone to operate at a higher power level than needed.
Not touching the antenna during a call optimizes the antenna performance and the talk-time of your phone. Normal position: Hold the phone as you would any other telephone.

Quick Adjust

Adjusting Vibrate Mode

Use Vibrate Mode in a public place.

1) In standby mode, activate Vibrate Mode quickly by pressing the *. (for 2 seconds) instead of using the Menu function.

• When Vibrate Mode is set, Key tone does not sound.

Note To cancel Vibrate Mode, press * for 2 seconds.

Select Profiles

1) In standby mode, press .

2) Select one of four Profiles **Vibrate Only**, **Silent**, **General** and **Outdoor** with .

3) Press Soft Key 1 **Select**.

Adjusting Speaker On

1) In standby mode, activate Speaker On quickly by pressing the # for 2 seconds.

Note To cancel Speaker On, press # for 2 seconds.

Keypad Lock

This function allows you to carry the phone safely without accidentally dialing a number.
When this function is enabled, no call can be made and the access to the Menu will be locked. While the keypad is locked, it is possible to answer a call normally.

To enable the function :

1) Press the key 0 for 2 seconds.

To disable the function :

1) Press the key 0 for 2 seconds.

Call Waiting

Your cellular service may offer a call waiting function. While a call is in progress, you may hear two beeps indicating another incoming call. When call waiting is enabled, you may put the active call on hold while you answer the other incoming call. Check with **your service provider** for information about this function.

1) Press CALL to receive a waiting call.

2) Press CALL again to switch between calls.

Mute

The mute function prevents the other party from hearing your voice, but allows you to hear the other party.

1) Press Soft Key 1 **Menu** and 2 during a call.

2) To cancel Mute, press Soft Key 1 **Menu** and 2 again.

Redialing Calls

1) Press CALL twice to redial the last number in Call History.

- You can also dial any of the last 60 numbers stored in the call history list. (See the Call History List on page 45~47)

Speed Dialing

Speed dialing is a convenient feature, which allows you to make phone calls quickly and easily. Your phone recalls the phone number from your personal directory, displays it briefly and then dials it.

Memory locations 1 through 9 should be used for one-touch dialing for your most frequently used phone numbers.

1) Enter memory location number 1 to 9.
2) Press CALL.

Dialing Speed Dials from 10 to 99

Press the first digit and then press and hold the key of the last digit.

OR

Enter the first and second digits and press CALL.

Caller ID

Caller ID lets you know who is calling by displaying the number of the person calling when your phone rings. If the caller's name and number are already stored in your phone book, the corresponding name appears with the number.

You should check with **your service provider** to ensure they offer this feature.

Entering Information Using T9 Text Input

You can edit the Banner, Scheduler, Short Message and Phone Book using T9 Text Input.
T9 Text is an easy way to write. In this input method, you only need to press a key once for each letter.

Key Functions

Soft Key 2 : Press to scroll and select a mode through menus.

- You can scroll through the modes using Soft Key 2 in the following order : T9En, Abc, 123, Symbol, Smileys, Hindi
- Shift Key : Used to change the letter case.

2 ~ 9 (Type Text): In T9 mode, press one key per letter to enter text.

0 ~ 9 (Type Numbers): In 123 (Numbers) mode, press once to enter numbers.

0 (Next): In T9 mode, press to display other matching words.

1 (Punctuation): In T9 mode, press to insert punctuation in a word and complete a sentence.

(Space): Press to complete a word or insert a space.

CLR (Clear): Press to delete a single space or character. Press and hold to delete entire words.

Input mode

T9 Text Input provides five modes for entering text, numbers, special characters, and punctuation.

T9En (T9) Mode

Type text using one keystroke per letter. The default is T9 mode.

ABC (Multi-tap) Mode

Use ABC mode to add words to the T9 database.

123 (Numbers) Mode

Type numbers using one keystroke per number.
To change to 123 mode in a text entry field, press Soft Key 2 until 123 mode is displayed.

Symbol/Smileys Mode

Insert special characters, punctuation, or smileys.
You may use any of the special characters. When the cursor is located where you want the special character, switch to Symbol/Smileys mode. If you want to add a smiley, switch to the smileys mode. Press the Navigation Key ◀▶ to cycle through the desired characters : To select Character, Press the assigned number key.

Initial Cap (T9En/Abc)

Only the first letter is capitalized.

Caps Lock (T9EN/ABC)

All subsequent letters are capitalized.

Lowercase (T9en/abc)

All subsequent letters are lowercase.

Examples Using T9 Text Input

Typing In T9 Mode

When you want to use **T9 Mode**, check that **T9En** is shown at the bottom of the display. To write the desired word, press each key once for one letter.
For example, to write "**Call the office**", follow these steps:

1. Press: Soft Key 2 to change letter case to T9En mode.
2. Press: 2 2 5 5.
3. Press: # to complete the word and add a space.
4. Press: 8 4 3 # 6 3 3 4 2 3.
5. Display: Call the office.

As you can see, the word changes after each key press. Therefore you don't need to pay much attention to what happens on the display before you have keyed in the whole word.

Using the NEXT Key

After you have finished typing a word, if the word displayed is not the word you want, press 0 NEXT to display additional choices.
For example, follow these steps :

1. Press: 4 6 6 3.
2. Display: Good
3. Press: 0 NEXT.
4. Display: Home, Gone, Hood.....

Adding Words to the T9 Database

If a word is not in the T9 database, add it by using **Abc (Multi-tap) mode** text entry. The word is automatically added to the T9 database when you return to T9 mode. For example, follow these steps:

1. Press: Soft Key 2 to change letter case to Abc (multi-tap) mode.
2. Press: 4 4 4 6 8.
3. Display: Imt
4. Press: Soft Key 2 to change letter case to T9 mode and then the word Imt will be added to the T9 database.
5. Press: CLR to erase the existing word.
6. Press: 4 6 8.
7. Display: Got
8. Press: 0 0.
9. Display: Imt

Examples Using ABC (Multi-tap) Text input

Typing In ABC (Multi-tap) Mode

For example, to type "**LG**", follow these steps:

1. Press: Soft Key 2 to change letter case to ABC mode.
2. Press: * to change to **ABC** Caps Lock mode.
3. Press: 5 5 5 4.
4. Display: LG

Key Mapping For Hindi Entry

In Hindi there are 13 vowels, 36 consonants, 10 matras

The Keys are mapped as follows:

0 NEXT Selection of user data base words.

1 @ अ अ आ इ ई उ ऊ ऋ ए ऐ ओ औ ऑ

A Aa I Ii U Uu R E Ai O Au Awe

2 ABC क क ख ग घ ङ

Ka Kha Ga Gha Nga

3 DEF च च छ ज झ ञ

Cha Chha Ja Jha Nya

4 GHI ट ट ठ ड ढ ण

Tta Ttha Dda Ddha Nna

5 JKL त त थ द ध न

Ta Tha Da Dha Na

6 MNO प प फ ब भ म

Pa Pha Ba Bha Ma

7 PQRS य य र ल व श ष स ह

Ya Ra La Va Sha Sha Sa Ha

8 TUV क्ष त्र ज्ञ

Ksha Tra Gya

9 WXYZ ा ि ी ु ू ृ े ै ो ौ ं ः ँ ॅ ॆ ॊ

Aa I Ee U Uu E Ai O Au An Ah Ch Ch Ch Ri

Bindu E O

Halanth(half character) is also added to 9 WXYZ .

To Edit in Hindi Mode

Press Soft Key 2 , until the soft menu changes to Hindi mode.

Hindi mode Editing

Hindi is a Multi-tap mode.

For E.g., To type "हिन्दी "

1. Press 9 2 times.
2. Press 7 8 times.
3. Press 5 5 times.
4. Press 9 16 times.
5. Press 5 3 times.
6. Press 9 3 times.

Byte Allocation:

In messages : Every character in Hindi takes 3 bytes while it takes 9 bytes for "Ksha" , "Tra" , "Gna".

In all other modules : Every character in Hindi takes 1 byte while "Ksha" , "Tra" , "Gna" takes 3 bytes.

UDB: (Hindi Dictionary)

Messages : Every word typed in Messages will be automatically stored in Hindi Dictionary. About 100 words can be stored in Dictionary. 101st word replaces the oldest word. Thus, a FIFO format is used.

To Store a word in Hindi UDB:

Press the word "हिन्दी" as explained earlier.

Press space. The word gets stored.

To retrieve the word :

Press the first letter of the word .i.e, press 9 2 times.

The word "हिन्दी" appears in the UDB space.

If there are multiple words starting with the same letter, required word can be selected by pressing 0 Key.

Once the required word is selected, Press * Key. The word will be added to the editor.

Chapter 3 Phone Book

Phone Book Features

You can store up to 300(4 Numbers + 1 E-mail id + 1 Memo) entries in your phone book with easy access to your most frequently dialled phone numbers.

Personal Phone Book Memory

The phone has 300 personal phone book memory locations where you can store up to 4 phone numbers with 32 digit capacity for each phone number.

Saving Numbers in Your Personal Phone Book

1. Press Soft Key 1 **Menu**.
2. Select **Names**.
3. Select **Add Name**.
4. Enter the phone numbers.
5. Select the label window using .
6. Select your desired label types, such as **Home**, **Office, Mobile**, **Other** using .
7. Press Soft Key 1 **Select**.
8. Enter a name for the phone number (up to 16 characters). Press Soft Key 1 **Save**.
9. After selecting **Home**/**Office**/**Mobile**/**Other** using , input phone number with number key.
10. To designate **Speed Dial**, press Soft Key 1 **Options** and select **Speed Dial**. Using number key, input **Speed Dial** or select a desired **Speed Dial** with .

Select **Assign** by pressing Soft Key 1 **Options**. When select stored speed dial, **Replace** displays.

11. After selecting **E-mail** by pressing , select **Edit** by pressing Soft Key 1 **Options**.
12. After inputting e-mail address, select **Save** by pressing Soft Key 1 **Options**. Select **Domains** and input e-mail address.
13. After selecting **No Group** by pressing , select a desired group using .
14. After selecting **Memo** using , select **Edit** by pressing Soft Key 1 **Options**. After inputting memos, press Soft Key 1 **Save**.
15. After selecting Ring Tone by pressing , select a desired Ring Tones using .
16. After selecting **Secret off** by pressing , select **Secret off/Secret on** using . When **Secret on** is set, you should input password to check it.
17. Press Soft Key 1 **Save**.

Find Name

To search for a phone number by name.

1. Press the Soft Key 2 **Find**.
2. Names saved in the **Phone Book** will appear in the order of alphabet regardless of type of character, capital or small.

   To view the phone number you want, press Soft Key 1 **Options** and select **View** after scrolling to the phone number you want using .

Find by Number

To find phone numbers you have stored in the Phone Book.

1. Press the Soft Key 2 **Find**.
2. Press the Soft Key 1 **Options** and select **Find Number**.
3. The display prompts you to enter the number on the display screen.

Find Group

To search for a phone number by group.

1. Press the Soft Key 2 **Find**.
2. Press the Soft Key 1 **Options** and select **Find Group**.
3. Select group using .

Changing Information Stored in the Phone Book

1. Press the Soft Key 2 **Find**.
2. You may view the phone number saved in the Phone book in the real time by entering the search string.

   You may view the **Phone Book** List if you press Soft Key 1 **Options** and select **View** after scrolling to the name you want using .

   To delete or edit the **Entry**, press the Soft Key 1 **Options**.

   Select **Edit** after scrolling the data using .

A submenu will appear on the screen with the options:

Edit	Edits information in that memory location.
Send Message	Send the message.
Send MyContact	Sends information in that memory location.
Erase	Erase all existing information in that memory location.

Making a call from Your Phone Book

You can place a call from any memory location either by using speed dialing or by entering the phone number and pressing CALL.

One-Touch Speed Dialing: This feature enables you to store your nine most frequently used numbers in your Speed Dials memory locations (1 through 9)

- For locations 1 through 9, you can use one-touch dialing by pressing and holding the corresponding key to the memory location to be dialled.

OR

- Press a digit, then press CALL.

Two-Touch Speed Dialing: This feature enables you to dial numbers in your Speed Dials through two keys (for locations 10 to 99.)

1) Press the first digit.

2) Press and hold the key of the second digit.

OR

1) Press the first and second digit, then press CALL.

Note To use speed dialing, you first need to assign a number from the phone book to a speed dial location.

Dialing from a Memory List

1) Select Find, press the scroll keys to go to the memory location you want.

2) Press CALL.

Dialing from a Memory Location

- While viewing a memory location, press CALL to call.

General Guidelines to Menu Access and Settings

1. Press Soft Key 1 **Menu**. Eight menu items will appear on the display screen.
2. Press to go through the list of menu features.
3. Press the corresponding number to the menu item that you want to select. Then the sub-menu list will appear on the screen.
4. Press the appropriate key to select the sub-menu you want to access.
5. Select preferred settings, using the . Press Soft Key 2 **Back** to go one step backward while accessing menu or selecting settings.
6. Press Soft Key 1 **Ok** to save the settings or Soft Key 2 **Back** to cancel without saving.

Names (Menu)

Personal Phone Book Memory

The phone has 300 personal phone book memory locations where you can store up to 4 phone numbers with 32 digit capacity for each phone number.

Add Name (Menu)

You can save phone numbers, mobile numbers and so on, up to 300 entries.

1. Press Soft Key 1 **Menu**.
2. Select **Names**.
3. Select **Add Name**.
4. Enter the phone numbers.
5. Select the label window using .
6. Select your desired label types, such as **Home**, **Office, Mobile**, **Other** using .
7. Press Soft Key 1 **Select**.
8. Enter a name for the phone number (up to 16 characters). Press Soft Key 1 **Save**.
9. After selecting **Home/Office/Mobile/Other** using , input phone number with number key.
10. To designate **Speed Dial**, press Soft Key 1 **Options** and select **Speed Dial**. Using number key, input **Speed Dial** or select a desired **Speed Dial** with . Select **Assign** by pressing Soft Key 1 **Options**. When select stored speed dial, **Replace** displays.
11. After selecting **E-mail** by pressing , select **Edit** by pressing Soft Key 1 **Options**.
12. After inputting e-mail address, select **Save** by pressing Soft Key 1 **Options**. Select **Domains** and input e-mail address.
13. After selecting **No Group** by pressing , select a desired group using .
14. After selecting **Memo** using , select **Edit** by pressing Soft Key 1 **Options**. After inputting memos, press Soft Key 1 **Save**.

15. After selecting Ring Tone by pressing , select a desired Ring Tones using .
16. After selecting **Secret off** by pressing , select **Secret off**/**Secret on** using . When **Secret on** is set, you should input password to check it.
17. Press Soft Key 1 **Save**.

Find (Menu 1 2 or Soft Key 2 Find)

To find phone numbers you have stored in the Phone Book.

1. Press Soft Key 1 **Menu**.
2. Select 1 **Names**.
3. Select 2 **Find**.
4. Phone numbers saved in the **Phone Book** will appear in the order of alphabet regardless of type of character, capital or small.

   To view the phone number you want, press Soft Key 1 **Options** and select **View** after scrolling to the phone number you want using .

Groups (Menu 1 3)

This is a function for changing Group Name and setting Ring tones by Group.

1. Press Soft Key 1 **Menu**.
2. Select 1 **Names**.
3. Select 3 **Groups**.
4. Select your desired Group using .

5. Press Soft Key 1 **Options**.

View Members : View the names of members saved in the Group.

Set Ring Tone : Set the Group Ring Tone.

Edit Title : Edit the Group Name.

NOTE The title **No Group** cannot be changed.

Speed Dial (Menu 1 4)

Speed Dial allows you to make a call faster by just pressing a corresponding number.

1. Press Soft Key 1 **Menu**.
2. Select 1 **Names**.
3. Select 4 **Speed Dial**.
4. To register, use Soft Key 1 **Options** and select **Assign** to find information you want, then press Soft Key 1 **Options** and select **Assign**.

NOTE To delete, select press Soft Key 1 **Options** and select **Remove** then press Soft Key 1 **Select**.
Select **Remove All** to delete all stored speed dials. Select **Replace** to change the number assigned to a particular location.
Speed dial is from 01 to 99.

Help (Menu 1 5)

You can get more information about this menu.

Messages (Menu 2 or)

Text message, page and Voice Mailbox become available as soon as the power is on. You can access the above types of messages using the message Key .

In addition, you can make a call to the call back number by pressing CALL during a message check.

The phone can store up to 31 messages (1 voice message: 30 text messages) with 140 characters per message. Every letter in hindi is taken as 3 characters (However, ksha,tra,gna accounts for 9 characters each.) So, an SMS message in Hindi can have upto 46 Characters only.

Users may read and edit messages, saved in the sent during transmission and send them.

However you should check whether your service provider provides the above features.

Character limits: The LG-RD5130 supports up to 140 characters per message. Limits to available byte per message may exist; please check with **your service provider** for system capabilities.

The information that is stored in the message is determined by phone mode and service capability. You can check types of messages by pressing the message Key .

Write (Menu 2 1)

Text messages and page messages are all available.
Text messages: Transmits text.
Page messages: Only numbers without text messages.
Press **Send** in **Options** to send the message.
To send a message enter the destination mobile number in the **Send To** screen.

Menu

There are three optional menus of **Send**, **Save** and **Templates**.

1. Press Soft Key 1 **Menu**, 2 or .
2. Select 1 **Write**.
3. After entering a message to be sent by selecting **Send**, press Soft Key 1 **Options**.
   - **Send** Use to send the message.
   - **Save** Save to Drafts message.
   - **Templates** Select a Templates message.
4. After entering the phone number where the message is to be sent, enter the next recipients address by pressing . You can add up to 10 recipients. Press Soft Key 1 **Options**.
   - **Send** Use to send the message.
   - **Priority** Allows you to give the priority to message. Normal or Urgent.
   - **Delivery Ack** This function allows you to know whether the message is successfully transmitted to other party or

not when the transmitted message is received in other party's phone. If you want to activate this function, set to **On**.

- **Deferred** Allows you to delay sending the message until the programmed time frame.
  Immediate/After 30 Minutes/After 1 Hour/After 2 Hours/After 12 Hours/ After 1 Day/After 2 Days
- **Validity** Indicates the validity of message delivery to the Short Message Center (SMC) without being transmitted to the destination address for certain periods of time. Those messages will be deleted within the programmed time frame. Validity time frames are as follows: Default, 30 Minutes, 1 Hour, 2 Hours, 12 Hours, 1 Day and 2 Days.
- **Save Sent Msg** You can save this message in **Outbox**.

5. If you select **Send**, it notifies you whether the message was sent successfully.

Inbox (Menu 2 2)

Received text messages, page messages, Delivery ack, R World Messages, lists may be searched, and the contents may be viewed. Received messages are sorted in an order of urgent messages, unread messages and read messages. Up to 30 message can be stored.

To view the list of the received messages.

1. Press Soft Key 1 **Menu**, 2 or .
2. Select 2 **Inbox**.
   - Messages are saved in order of **Unread**/**Read**. For example, if a NEW message is read it goes into Read messages.

   : Unread

   : Read

   : R World Messages
3. After selecting the desired message with ; press Soft Key 1 **Options** and select **View**.
   - **View** You can read the selected message.
   - **Erase** Delete the selected message from the Inbox.
   - **Reply** This function allows you to reply to this message.
4. After viewing the message press Soft Key 1 **Options**.
   - **Reply** This function allows you to reply to this message.

- **Forward** Forwards a received message to others. After recipients are entered, the messages can be forwarded.
- **MovetoArchive** Moves the selected message from the Inbox to the **Archive**.
- **Erase** Deletes the selected message from the Inbox.
- **Save Number** Stores the sender's number included in the received message into your phone book. When received number information is displayed, the user can store the number in the corresponding number list in the phone book.

Outbox (Menu 2 5)

Up to 15 sent messages and 15 unsent messages can be stored in the Outbox.

Users may view lists and contents of sent messages or unsent messages in this menu. To save a message in Outbox "Save Sent Message" should be selected in "Msg Settings"

1. Press Soft Key 1 **Menu**, 2 or .
2. Select 5 **Outbox**.
3. Select 1 **Sent** or 2 **Unsent**.
4. After selecting the desired message with ; press Soft Key 1 **Options**. If you select the sent message **View/Erase/Forward** appears on the screen.

- **View** Shows the message currently saved. The view menu has two sub-menus **Forward** and **Erase**.

- **Erase** Delete a selected message in the Outbox.
- **Forward** You can modify the message you've got. Then follow the process for **Write** (see page 37).

Voice Mail (Menu 2 4)

Allows you to view the new voice messages recorded in the voice mail box. Once you exceed the storage limit, the old messages will be overwritten. When you have a new voice message your phone will alert you.

1. Press Soft Key 1 **Menu**, 2 or .
2. Select 4 **Voice Mail**.
   - To delete information press Soft Key 1 **Options** and then select **Listen, Erase**.

While you are answering a call, if you have a new message, the sender's number will be displayed on the screen.

Archive (Menu 2 5)

Archive stores what is preferred to save among messages received(30 messages)

1. Press Soft Key 1 **Menu**, 2 or .
2. Select 5 **Archive**.
3. After selecting the desired message with , press Soft Key 1 **Options**. If you select the message **View/ Erase/Forward** appears on the screen.

- **View** — There are three menus **Forward**, **Reply**, **Erase** and **Save Number**.
- **Erase** — Delete a selected message.
- **Forward** — You can modify the message you've got. Then follow the process for **Write** (see page 37).

Drafts (Menu 2 6)

The text message is saved in Drafts. A total of upto 30 messages can be saved in Drafts. When a user is interrupted by a call while composing a message, messages automatically get saved.

1. Press Soft Key 1 **Menu**, 2 or .
2. Select 6 **Drafts**.
3. After selecting the desired message with , press Soft Key 1 **Options**. If you select the message **View**/ **Erase** appears on the screen.
   - **View** — There are four menus **Send**, **Save**, **Templates** and **Erase**.
   - **Erase** — Delete a selected message.

Templates (Menu 2 7)

There are 10 predefined phrases included in the Templates. You can add up 20 templates more. A total of 30 templates can be saved.

1. Press Soft Key 1 **Menu**, 2 or .
2. Select 7 **Templates**.

3. After selecting the desired message with press Soft Key 1 **Options**. If you select the message **View/ Add** appears on the screen.
   - **View** There are two menus **Send** and **Save**.
   - **Add** You may add new template message to the Templates list.

Erase Msgs (Menu 2 8)

Text messages and page messages are deleted when you select 8 **Erase Msgs** from the Message Menu screen.

Inbox (Menu 2 8 1)
Allows you to delete received text messages, page messages, Delivery Ack messages.

Outbox (Menu 2 8 2)
Allows you to delete all messages saved in the Outbox.

Archive (Menu 2 8 3)
Allows you to delete all messages saved in the Archive.

Drafts (Menu 2 8 4)
Allows you to delete all messages saved in the Drafts.

All Messages (Menu 2 8 5)
Allows you to delete all messages.

Msg Settings (Menu 2 9)

Priority, **Delivery Ack**, **Deferred Delivery**, **Validity Period**, **Save Sent Message** and **Auto Delete Inbox** can be configured for receiving new messages.

Priority (Menu 2 9 1)

When sending a message, select **Normal** or **Urgent**.

Delivery Ack (Menu 2 9 2)

Allows you to select delivery acknowledgement with your messages.

Deferred Delivery (Menu 2 9 3)

Allows you to delay sending the message until the programmed time frame.

Validity Period (Menu 2 9 4)

Indicates the validity of message delivery to the Short Message Center (SMC) without being transmitted to the destination address for certain periods of time.

Save Sent Message (Menu 2 9 5)

With this feature on, messages are automatically saved in the **Outbox** when transmitted.

Auto Delete Inbox (Menu 2 9 6)

With this feature on, old messages are automatically deleted when you exceed storage limit.

Help (Menu 2 0)

You can get more information about this menu.

Call History (Menu 9)

Allows you to view the 60 most recent phone calls. Once you exceed the (total) 60-number storage limit, the oldest Call History record is overwritten. These calls are divided into 4 types of calls.

NOTE You can view Call History in two ways.

- The CALL key in idle mode, upto 60 most recent calls including Missed, Received and Dialled are displayed.
- In Call History menu, total 60 numbers are listed under Missed, Dialled, Received, and In Call Memo.
- Maximum 5 numbers can be saved in In Call Memo.

Making a Call from Call History

1. From the Call History menu, select **Missed**, **Received**, **Dialled** or **In Call Memo** and press Soft Key 1 **Select**.
2. Place a call by selecting the desired entry and press CALL to connect.

Missed (Menu 9 1)

Allows you to view list of all Missed Calls.
Maximum 60(Missed + Received + Dialled + In Call Memo) numbers are possible.

1. From the **Call History** menu, select 1 **Missed**.
2. Press Soft Key 1 **Options**. **View/Send Message/ Save/Erase** appears on the screen.
3. You may place a call by pressing CALL.

Received (Menu 1 2)

Allows you to view list of all Received Calls.
Maximum 60(Missed + Received + Dialled + In Call Memo) numbers are possible.

1. From the **Call History** menu, select 2 **Received**.
2. Press Soft Key 1 **Options**. **View/Send Message/ Save/Erase** appears on the screen.
3. You may place a call by pressing CALL.

Dialled (Menu 1 1)

Allows you to view list of all Dialled Calls.
Maximum 60(Missed + Received + Dialled + In Call Memo) numbers are possible.

1. From the **Call History** menu, select 1 **Dialled**.
2. Press Soft Key 1 **Options**. **View/Send Message/ Save/Erase** appears on the screen.
3. You may place a call by pressing CALL.

In Call Memo (Menu 1 4)

Save the phone numbers taken while talking and can view the list of numbers present in In Call Memo.

Maximum 5 numbers are possible.

1. From the **Call History** menu, select 4 **In Call Memo**.
2. Press Soft Key 1 **Options**. **View/Send Message/ Save/Erase** appears on the screen.
3. You may place a call by pressing CALL.

Call Duration (Menu 3 5)

1. Last Dialled Call (Menu 3 5 1)
It will store information about the last dialled call and will also display the last dialled number.

2. All Dialled Calls (Menu 3 5 2)
Displays total number of dialled calls and total dialled calls duration.

3. All Calls (Menu 3 5 3)
Keeps a running count of the time spent making all calls, dialled and received.

4. Reset Call Duration (Menu 3 5 4)
To reset the counter, select **Yes** using and then Soft key 1 **Select**.

Data History (Menu 3 6)

1. From the **Call History** menu, select 6 **Data History**.
2. Press END.

Erase History (Menu 3 7)

1. From the **Call History** menu, select 7 **Erase History**.
2. Select the item which it will erase with .
3. Press Soft Key 1 **Select**.
4. Select **Yes** using and then Soft key 1 **Select**.

Help (Menu 3 8)

You can get more information about this menu.

Profiles (Menu 4)

Profiles let you set your phone's sound settings to your environment. Each profile contains settings for your phone's Ring Type, Ring Tone, Ringer Volume, Earpiece Volume, Key Volume and Message Alert. Just pick the profile that suits your current environment: **Vibrate Only**, **Silent**, **General** or **Outdoor**.

You can modify the settings in each profile, and (except for the **Vibrate Only** Profile) you can rename them (except for the **Vibrate Only**, **Headset** and **Carkit** Profiles).

Select Profiles

1. Press Soft Key 1 **Menu** and 4 or quickly press .
2. Select one of four Profiles **Vibrate Only**, **Silent**, **General** and **Outdoor** with .
3. Then press Soft Key 1 **Options** and then select **Set**.

NOTE **Headset** or **Carkit** Profile is automatically set when headset or carkit is installed in the mobile phone.

NOTE In standby mode, press long * to select **Vibrate Only** Profile. Press long * once again to return to the previous Profile.

Rename Profiles

1. Press Soft Key 1 **Menu** and 4 .
2. Select **Silent**, **General** or **Outdoor** by using .
3. Then press Soft Key 1 **Options** and then select **Rename**.
4. Enter a name for the Profiles (up to 16 characters).
5. Then press Soft Key 1 **Save**.

NOTE You cannot rename the **Vibrate Only**, **Headset** and **Carkit** profiles.

Customize Profiles

You can customize any of the Profiles except Vibrate Only.

1. Press Soft Key 1 **Menu** and 4 .
2. Scroll to the profile you wish to customize and press Soft Key 1 **Options** and then select **Edit**.
3. Use the scroll keys to display each of the options in the following table:

Ring Type	Select the ring tone style (Ring, Vibrate, Vibrate & Ring, Ring After Vibrate, Silent, Light).
Ring Tone	Select the ring tone for incoming calls from 19 embedded + 3 downloadable from R World.
Ringer Volume	Set the volume of your ring tone. - Mute, 1~7 level
Earpiece Volume	Set the volume during a call. - 1~7 level
Key Volume	Set the volume of your keypad tones (or turn them off) - Mute, 1~7 level
Message Alert	Select the tone for received messages (Alert Type, Alert Tone and Message Reminder).

NOTE

- Ringtones can be downloaded through R World. 19 Ring Tones + 3 R World Ring Tone
- When **Ring Type** is **Vibrate**, **Silent** and **Light**, **Ringer Volume** can not be adjustable. 'Change Ring type' is displayed. After changing current type to **Ring Type**, adjust **Ringer Volume**.
- When press Soft Key 1 **Edit** in **Headset** and **Carkit** Profiles, **Auto Answer** is displayed additionally. Select **Off**, **After 5 secs** or **After 10 secs** by using .
- You cannot customize the **Vibrate Only** Profiles.
- You are alerted in 3 ways when you received a new message.
  By displaying a message on the screen.
  By sounding a beep or vibration.
  By flashing of Backlight just once.

Help (Menu 4 7)

You can get more information about this menu.

Display (Menu 5)

Lets you personalise your phone's display by selecting different graphics.

Language (Menu 5 1)

Set the Bilingual feature according to your preference, choose between English and Hindi.

1. From the **Display** menu, select 1 **Language**.

2. Set **English/ हिन्दी** with and then press Soft Key 1 **Select**.

Service Area (Menu 5 2)

This menu displays the current SDCA/calling area the user is in.

1. From the **Display** menu, select 2 **Service Area**.

Clock (Menu 5 3)

Allows you to select a clock on your mobile phone display.

1. From the **Display** menu, select 3 **Clock**.
2. Select **Off**, **Small** or **Big** and press Soft Key 1 **Select**.

Wallpaper (Menu 5 4)

Enter the string of characters you want to be displayed. You can set up the screen displayed on the LCD screen in the standby mode.

1. From the **Display** menu, select 4 **Wallpaper**.

1. Theme (Menu 5 4 1)

You can set up the screen displayed on the LCD screen in the standby mode.

- Used to choose the theme and then press Soft Key 1 **Save**. If you use **R World Image download**, you can choose the image you downloaded also. (Off / R World Img 1~3 / Image1~2)

2. Profiles (Menu 5 4 2)

Current profile is saved as wallpaper.

- Select **Show** or **Hide** and press Soft Key 1 **Select**.

3. Banner (Menu 5 4 3)

Enter the string of characters you want to be displayed (up to 13 characters.)

- Enter a Banner name and then press Soft Key 1 **Save**.

NOTE Wallpapers can be downloaded through R World.

Menu Style (Menu 5 5)

Allows you to select the menu style.

1. From the **Display** menu, select 5 **Menu Style**.
4. Select **Icon** or **List** with and then press Soft Key 1 **Select**.

Backlight (Menu 5 6)

Choose the settings of the LCD and keypad backlight.

1. From the **Display** menu, select 6 **Backlight**.
2. Choose an options and press Soft Key 1 **Select**.

- **For 1 min** Backlight will be On for 1 min, after that goes in dimming for 20 secs and then completely turns off till the user presses any key to make Backlight On.
- **For 30 secs** Backlight will be On for 30 secs , after that goes in dimming for 20 secs and then completely turns off till the user presses any key to make Backlight On.
- **For 10 secs** Backlight will be On for 10 sec, after that goes in dimming for 20 secs and then completely turns off till the user presses any key to make Backlight On.

Contrast (Menu 5 7)

Using the Navigation Key, select the contrast setting using the scale of lightest to darkest.

1. From the **Display** menu, select 7 **Contrast**.
2. Adjust the contrast with ◀▶.
3. Then press Soft Key 1 **Select** to save the contrast setting.

Help (Menu 5 8)

You can get more information about this menu.

Settings (Menu 6)

My Menu (Menu 6 1)

Lets you access to favorite menu quickly by customising my menu. Max 10 items can be stored in My Menu.

1. From the **Settings** menu, select 1 **My Menu**.
2. Select the menu of your choice by using ⬍, then press Soft Key 1 **Select**.
3. Select the Menu to add to **My Menu** with ⬍, then press Soft Key 1 **Add**. (Select Soft Key 1 **Options** if sub menu is available, then select **More** and **Add** to add the entire Menu selected to **My Menu**.)

NOTE Select the item of choice with CLR + ⬍ from the Stand-by screen, then press Soft Key 1 **Options** to select the required menu from My Menu.

NOTE Select the item to delete with CLR + ⬍ from the

Stand-by screen, then press Soft Key 1 **Options** and select **Remove**, select **Yes** with [↕], then press Soft Key 1 **Select** to delete from **My Menu**.

Call (Menu 6 2)

1. From the **Settings** menu, select 2 **Call**.

1) **Call Forward** (Menu 6 2 1)
Call forward lets you forward all your incoming calls to another number or Voice Mail connection.

► Immediate / When Busy / No Reply/Not Reachable / Disable All

2) **Call Waiting** (Menu 6 2 2)
While a call is in progress, you may hear two beeps indicating another incoming call. When call waiting is enabled, you may put the active call on hold while you answer the other incoming call.

► Select **Enable** or **Disable** and press Soft Key 1 **Select**.

NOTE Contact **your service provider** for more information on Call forward and Call waiting.

3) **Any Key Answer** (Menu 6 2 5)
When your phone rings, press any key to answer except PWR END.

► Select **Off** or **On** and press Soft Key 1 **Select**.

4) **Auto Redial** (Menu 6 2 4)
Set the length of time the phone waits before automatically redialing a number when the attempted call fails.

► Off / Every 60 secs / Every 30 secs / Every 10 secs

5) **Voice Privacy** (Menu 6 2 5)

Set the voice privacy feature for CDMA calls as Enhanced or Standard. CDMA offers inherent voice privacy. Check with **your service provider** for availability of the enhanced voice privacy mode.

▶ Select **Standard** or **Enhanced** and press Soft Key 1 **Select**.

6) **Clear Voice** (Menu 6 2 6)

Enable/Disable the function of Audio AGC(Auto Gain Control) system.

This feature provides a better audio experience by enabling the Audio AGC system to control the dynamic range and volume of the sending and receiving voice across different levels of speaker and environments.

▶ Select **On** or **Off** and press Soft Key 1 **Select**.

7) **Call Timer** (Menu 6 2 7)

You can set your phone to display the running elapsed time while a call is active.

▶ Select **Enable** or **Disable** and press Soft Key 1 **Select**.

8) **Call Connect Alert** (Menu 6 2 8)

This is a function to alert you that the call connection has been established.

▶ Select **On** or **Off** and press Soft Key 1 **Select**.

9) **Help** (Menu 6 2 9)

You can get more information about this menu.

Phone (Menu 6 3)

1. From the **Settings** menu, select 3 **Phone**.

1) **Key Guard** (Menu 6 3 1)

Allows you to protect the keypad of your phone from accidental dialing. When this function is enabled, no call can be made and the access to Menu is locked. When the keypad is locked, it is possible to answer a call normally.

▶ Select **Enable** or **Disable** and press Soft Key 1 **Select**.

To enable quickly : Press the key 0 for 2 seconds.

To disable quickly : Repeat the procedure.

2) **Set NAM** (Menu 6 3 2)

Select the phone's NAM (Number Assignment Module). This options is presently not available on your service provider's network Use **NAM 1** only.

3) **Data Settings** (Menu 6 3 3)

Data/Fax (Menu 6 3 3 1)

In **Data/ Fax** setting, you can use your phone as a wireless modem to avail high speed data services such as browsing Internet and other dial-up networking functions. The wireless phone supports a maximum data rate of 153.6 kbps on the network side. The speed of your connection depends upon network congestion, signal strength, and other variables.

▶ **Off**

- **Data in**: This setting enables a subscriber to receive data calls.
- **Fax in**: Fax Services are currently not supported on **your service provider** Network.

Note You need to purchase the Data Kit in order to be able to use the phone as modem. The data kit includes a suitable cable that has RS-232 interface for connecting the phone to the PC. Please contact your service provider for further information.

Data Baud (Menu 6 5 5 2)

This setting enables the subscriber terminal to set the baud rate.

- Data Baud set **USB/19,200/115,200/230,400**

  By default it is set to USB. If you change this setting on the phone ensure that the PC baud rates are changed to match accordingly.

Note The wireless phone will work with the PC / PDA properly only when the serial port settings on both the PC match with the baud rates set on the phone.

4) **Version** (Menu 6 5 4)

View the S/W, PRL and JAVA version.

5) **Help** (Menu 6 5 5)

You can get more information about this menu.

Security (Menu 6 4)

1) **Lock Mode** (Menu 6 4 1)

Keeps your phone from unauthorized use. Once the phone is locked, it is in restricted mode, until the lock code is entered. This will allow you to receive phone calls and still make emergency calls. The lock code/password on

your phone is **0000** by default. If you need to modify the lock code, you may modify it using the new lock code within the security set menu.

1. From the **Settings** menu, select 4 **Security**.
2. Press 1 **Lock Mode**.
3. Enter the four-digit Lock Code.
4. Select an options and press Soft Key 1 **Select**.
   - **Off** means that the phone is never locked. When locked, you can receive incoming calls or make only emergency calls.
   - **Now** means that the phone is locked immediately.
   - **On Power Up** means the phone is locked when it is turned on.

2) **Clear All Names** (Menu 6 4 2)

Deletes all information saved in Phone Book. Be careful since any deleted information is not recoverable.

1. From the **Settings** menu, select 4 **Security**.
2. Press 2 **Clear All Names**.
3. Enter the four-digit Lock Code.
4. Using the then select **Yes**.
5. Press Soft Key 1 **Select**.

3) **Emergency Numbers** (Menu 6 4 3)

You can call these numbers 100, 101, 102 even when the phone is locked or restricted.
To enter 3 emergency numbers.

1. From the **Settings** menu, select 4 **Security**.
2. Press 3 **Emergency Numbers**.
3. Enter the four-digit Lock Code.

4. Press Soft Key 1 **Edit**.
5. Enter an Emergency number.
6. Press Soft Key 1 **Save**.

4) **Change Lock Code** (Menu 6 4 4)

New Lock Code allows you to enter a new four-digit lock code number.

1. From the **Settings** menu, select 4 **Security**.
2. Press 4 **Change Lock Code**.
3. Enter the four-digit Lock Code.
4. Enter the New Lock Code(four-digit).
5. For confirmation, it will ask you to enter the New Lock Code again.

5) **Reset Phone** (Menu 6 4 5)

You can reset some of the menu settings to their original values. When select Reset phone, all settings become reset except Phone Book.

1. From the **Settings** menu, select 4 **Security**.
2. Press 5 **Reset Phone**.
3. Enter the four-digit Lock Code.
4. Using the ⇕ then select **Yes**.
5. Press Soft Key 1 **Select**.

6) **Help** (Menu 6 4 6)

You can get more information about this menu.

Organiser (Menu 7)

Scheduler (Menu 7 1)

Scheduler Functions

Scheduler keeps your agenda convenient and easy to access. Simply store your appointments and your phone alerts you with a reminder of your appointment. You can also take advantage of the **wake-up** feature.

Up to 160, can be saved.

Note While transmitting SMS or during a call or using Java, at the preset time, it does not ring. After exiting, it will ring the reminder.

Note Handset time is taken from Network time settings.

How to use various keys for navigation in Calendar

- Moves cursor to the left.
- Moves cursor to the right.
- Moves to the previous week.
- Moves to the next week.
- 1 Moves to the previous year.
- 3 Moves to the next year.
- 7 Moves to the previous month.
- 9 Moves to the next month.

Allows you to input your schedule or erase or view. If you input the time and memo, an alarm rings at the set time.

1. From the **Organiser** menu, select 1 **Scheduler**.
2. Select the date using your keypad, then press Soft Key 1 **Option** and select **Add Event**, **View By Day**, **View All**, **Go To Date**, **Go To Today**, **EraseToDate** or **Erase All**.

To Do (Menu 7 2)

Up to 40, can be saved.

1. From the **Organiser** menu, select 2 **To Do**.
2. Press Soft Key 1 **Add** to write a new event.

Note In case there is saved To Do, the function of View, Erase, Erase All, and Add is available with Soft Key 1.

Memo (Menu 7 5)

Up to 40, can be saved.

1. From the **Organiser** menu, select 5 **Memo**.
2. Press Soft Key 1 **Add** to write a new memo.
3. After entering characters (For entering characters, refer to pages 20~24) press Soft Key 1 **Save**.

When Memo is not empty

Following Options are available :

View , **Erase**, **Erase All** and **Add**.

View : To display selected memo.

View screen gives 2 options **Edit** and **Erase**.

Using **Edit** user can modify an existing memo.

Erase: Enable user to delete a selected memo.

Erase All: Enable user to delete all the stored memo.

Add : Enable user to add Memo

When a memo is saved current date and time is also saved.

Alarm (Menu 7 4)

To change an event alarm time.

1. From the **Organiser** menu, select 4 **Alarm**.
2. Select **Alarm1**, **Alarm2** or **Alarm3**.
3. You can change the alarm mode using .
   (**Off /Once/Daily/Mon-Fri/Mon-Sat**)
4. Use to set alarm time, select Ringer and input contents, then press Soft Key 1 **Save**.
   - am/pm may be selected using .
   - Ringer volume is controlled according to settings done in Profiles.

Note Alarm is disabled when the mobile is switched off. Any alarms that have passed the set limits will automatically expire.

How to Set Snooze

Snooze defaults when it is set to alarm.

When no key is input when alarm sounds, Snooze function is set automatically one minute later, and the alarm sounds again ten minutes after set alarm time.

Stopwatch (Menu 7 5)

Stopwatch is available.

1. From the **Organiser** menu, select 5 **Stopwatch**.

Calculator (Menu 7 6)

Calculate simple mathematical computations.
(Can get result upto second decimal place.)

1. From the **Organiser** menu, select 6 **Calculator**.
2. Press 2 and 5 in order.
3. Select (multiplication) using keys.
4. Press 1 , 0 in order.
5. Select using Soft Key 1 **Answer**.
   You will see the result of the calculation **250**.

Note Calculations can be made with up to 50 characters at one time (e.g., 73+01-03 would be 8 characters).

World Clock (Menu 7 7)

Is useful if you need to make a call to another country, and you are not sure about the time difference.

1. From the **Organiser** menu, select 7 **World Clock**.
2. Select the city you desire by using .
   For faster selection, can be used to jump 7 cities on the map.

Note With Soft Key 1 **DST**, set the daylight saving time.

Help (Menu 7 8)

You can get more information about this menu.

R World (Menu 8)

R-Menu (Menu 8 1 or)

This connects you to R World Data Services like video, audio, news, games, messaging etc., provided by **your service provider**.

1. From the **R World** menu, select 1 **R-Menu**.
2. R World logo will be displayed followed by R World Data Services Menu.
3. Scroll through the menu using and launch any Data Service by clicking on Soft Key 1 **Select**.
4. To exit from Data Services any time, hold down END for a few seconds.

Note All Data Services may not be available to every subscriber. Please contact **your service provider** for further information.

Multimedia (Menu 8 2)

The maximum available space that can be saved is 600Kbyte. The total no of file that can be saved in the phone is 20(within 600Kbyte). However if more files are to be saved and if the total size exceeds be deleted. The handset will prompt for deletion of files of there is not sufficient space available for saving new files.

Show List (Menu 8 2 1)

Allows you to see video, audio files which you have saved on your handset.

1. From the **R World** menu, select 2 **Multimedia**.
2. Press 1 **Show List**.

Erase List (Menu 8 2 2)

Allows you to delete item stored in the multimedia.

1. From the **R World** menu, select **Multimedia**.
2. Press 2 **Erase List**.

Game (Menu 8 3)

You can get key information about playing a game if you select **Help** after selecting Cricket game in menu.

Cricket (Menu 8 3 1)

Cricket is a game between two teams of 11 players in which players try to get points by hitting a ball and running between two sets of stumps. You can select country among India, England, Australia and Sri Lanka. Each team has a different ability of batting, pitching and speed.

1. From the **R World** menu, select 3 **Game**.
2. Press 1 **Cricket**.
3. Select **New Game** using .
4. To start the game, press Soft Key 1 .

   1) Keypad Configuration - Menu Screen

   CLR Moves to the Game Selection screen.

   END Ends the game.

   New Game - Starts a new game

   Load Game - Loads the game if saved

   Option - Adjust the sound and vibration

   Help - Display keypad configuration

   Score - Save scores

3) Keypad Configuration - Batting Screen

Choose the batsman's position

Ball's course

4) Keypad Configuration - Batting Screen

7 Pull

8 Defend

9 Drive

5) Keypad Configuration - Bowling Screen

Choose the ball spin

4 Leg Spin

2 No Spin

6 Off Spin

5 Down Spin

Where to bowl

1 ~ 9 ,

Game Settings (Menu 8 5 2)

You can set sound volume of the game and backlight to on or off. To change your phone's setting when you play the game.

1. From the **R World** menu, select 5 **Game**.
2. Press 2 **Game Settings**.
3. Use to choose the setting between 1 **Game Volume** and 2 **Game Backlight**.

Note If backlight is turned on and the phone is kept inactive in the Game menu, battery will drain faster.

Reset R-Menu (Menu 8 4)

If you are experiencing difficulty using R World service frequently, you can reset R World. Doing this will refresh all the services within R World only.

1. From the **R World** menu, select 4 **Reset R-Menu**.
2. Select **Yes** or **No** with and then press Soft Key 1 **Select**.

Help (Menu 8 5)

You can get more information about this menu.

In Call Memo (During a Call : Menu 1)

It allows you to note a phone number that the other person provides you during a call. The number will be stored in the Call History.

1. Press the Soft Key 1 during the call.
2. Press 1 **In Call Memo**.
3. Type the phone number and press the Soft Key 1 **Save**.

Mute/Unmute (During a Call : Menu 2)

This function locks the microphone of your telephone and prevent sounds from your end being heard by the person at the other end.

- **To enable Mute Function**:

1. Press the Soft Key 1 during the call.
2. Press 2 **Mute**.

- **To disable Mute Function**:

1. Repeat the procedure.

Earpiece/Speaker Volume (During a Call : Menu 3)

Adjust the Earpiece/Speaker Volume with during the call.

Voice Privacy On/Off (During a Call : Menu 4)

Set the privacy feature for CDMA calls as **Enhanced** or **Standard**. CDMA offers inherent voice privacy. check with **your service provider** for availability of the enhanced voice privacy mode.

Adjusting Speaker On (During a Call : Press #)

When during a call, active Speaker On press # for 2 seconds. To cancel Speaker On, press # for 2 seconds.

Chapter 6 Accessories

Travel Charger

This adaptor, model AC-20W, allows you to charge the battery. It supports AC 100~240 Volt, 50~60 Hz outlets.

Cigarette Lighter Charger

You can operate the phone and trickle charge the phone's battery from your vehicle by using the cigarette lighter charger, model CLC-60W.

Hands-Free Car Kit (Portable)

The hands-free car kit, model PHF-60W, enables you to attach the phone to the car providing you with hands-free operation.

Headset

Connects to your phone, allowing hands-free operation. Includes earpiece, microphone, and integrated call answer /termination button.

Serial Data Cable

Connect your phone to your PC's serial port. (LG-DC300DJ)

USB Cable

Connect your phone to your PC's USB port. (LG-USB8100)

Chapter 7 Menu Tree

Press Soft Key 1 **Menu**. Press to scroll.

Names

1. Add Name
2. Find
3. Groups
4. Speed Dial
5. Help

Messages

1. Write
2. Inbox
3. Outbox
4. Voice Mail
5. Archive
6. Drafts
7. Templates
8. Erase Msgs
9. Msg Settings
   - Priority
   - Delivery Ack
   - Deferred Delivery
   - Validity Period
   - Save Sent Message
   - Auto Delete Inbox

0. Help

Call History

1. Missed
2. Received
3. Dialled
4. In Call Memo
5. Call Duration
   - Last Dialled Call
   - All Dialled Calls
   - All Calls
   - Reset Call Duration
6. Data History
7. Erase History
   - Erase Missed
   - Erase Received
   - Erase Dialled
   - Erase Data
8. Help

Profiles

1. Vibrate Only
2. Silent
3. General
4. Outdoor
5. Headset
6. Carkit
7. Help

Display

1. Language
   - English
   - हिन्दी
2. Service Area
3. Clock
   - Off
   - Small
   - Big
4. Wallpaper
   - Theme
   - Profile
   - Banner
5. Menu Style
   - Icon
   - List
6. Backlight
   - For 1 min
   - For 30 secs
   - For 10 secs
7. Contrast
8. Help

Press Soft Key 1 **Menu**. Press to scroll.

Settings

1. My Menu
2. Call
   - Call Forward
   - Call Waiting
   - Any Key Answer
   - Auto Redial
   - Voice Privacy
   - Clear Voice
   - Call Timer
   - Call Connect Alert
   - Help
3. Phone
   - Key Guard
   - Set NAM
   - Data Settings
   - Version
   - Help
4. Security
   - Lock Mode
   - Clear All Names
   - Emergency Numbers
   - Change Lock Code
   - Reset Phone
   - Help

Organiser

1. Scheduler
2. To Do
3. Memo
4. Alarm
5. Stopwatch
6. Calculator
7. World Clock
8. Help

R World

1. R-Menu
2. Multimedia
   - Show List
   - Erase List
3. Game
   - Cricket
   - Game Settings
4. Reset R-Menu
5. Help

Frequently asked questions

Q : How do I view the list of Dialled calls, Received calls and Missed calls?

A : Press CALL.

Q : How do I clear Call History ?

A : Press CALL → Press Soft Key 1 **Options** → Select **Erase** or **Erase All** → Press Soft Key 1 **Select** → Select **Yes** → Press Soft Key 1 **Select**

Q : How do I view all numbers stored in memory?

A : Press Soft Key 2 **Find**.

Q : How many events can I add to the schedule ?

A : Total of 160 events.

Q : How do I clear past schedule stored in Scheduler?

A : Press Soft Key 1 **Menu** → 7 **Organiser** → 1 **Scheduler** → Press Soft Key 1 **Option** → 6 **Erase To Date** → Select **Yes** → Press Soft Key 1 **Select**

Q : How many Speed Dial numbers can I store?

A : Total of 99 numbers.

Q : How do I send a text message ?

A : Press ✉ → 1 **Write**

Q : How do I clear the call timer (reset the time used monthly)?

A : Press Soft Key 1 **Menu** → **Call History** → **Call Duration** → **Reset Call Duration** → Select **Yes** → Press Soft Key 1 **Select**

Q : How do I find out my lock code ?

A : The Lock Code/Password on your phone is **0000** by default.

Q : How many groups are there ?

A : In Groups, there are No Group/Family/Relatives/Friends/Business/Colleagues/School/Club/VIP.

You can edit Group title except the title of **No Group** cannot be edited.

To change Group Name,

1. Select group by pressing Soft Key 1 **Menu** → **Names** → **Groups** and .
2. After pressing Soft Key 1 **Options**, select **Edit Title**.

Q : Is Group SMS is possible ?

A : You can send a message to 10 numbers simultaneously. Each number should be selected or entered individually.

Before calling for service

Please check to see if any problem which you may have with your phone is described here before taking it for service or calling a service engineer.

When showing symptoms like:	Check this!
When " Ψ " does not disappear from the screen.	Check whether it is service area, and if you continue to see " Ψ " please turn off the power and wait for approximately 2 minutes to turn it back on. If there is no change, check again after relocating to other areas.
When connection is abrupt or is not audible in certain areas.	When frequency environment is unstable in a certain area, connection may be abrupt and not audible. Relocate to other areas and try again.
When connection is not made well or abrupt even when established.	When frequency is unstable or weak, or if there are too many users, connection may be cut off even after it was established. Please try again a little later or try after relocating to other areas.
When LCD does not turn on.	Remove battery and turn on the power after placing it back on. If there is no change even then, sufficiently charge the battery and try again.
When it echoes while connection is made with a certain telephone in a certain area.	Called "Echo Phenomenon," it occurs if connection volume is too high or caused by special properties(semielectronic telephone exchange) of the machine on the other end.

When showing symptoms like:	Check this!
When the phone is heated.	If connection is made for a significantly long duration, or game and Internet and others are used for a long time, the phone may become hot. This has no effect upon the life of the product or performance.
When the Ringer does not ring, or when Backlight or LCD blinks only.	Ringer Type may be set as "Silent" or "Light". Please select "Ring".
Standby duration for battery gradually becomes shorter.	Because battery wear out, its life gradually becomes shorter. If its life becomes shorter over half of that at the time of purchase, you must purchase a new one.
When usage time of battery becomes shorter	If time for use of battery is short, it may be due to the user environment, or large volume of calls, or weak signals.

TIA Safety Information

Provided herein is the complete TIA Safety Information for Wireless Handheld phones. Inclusion of the text covering Pacemakers, Hearing Aids, and Other Medical Devices is required in the owner's manual for CTIA Certification. Use of the remaining TIA language is encouraged when appropriate.

Exposure to Radio Frequency Signal

Your wireless handheld portable telephone is a low power radio transmitter and receiver. When it is ON, it receives and also sends out radio frequency (RF) signals.

In August, 1996, the Federal Communications Commissions (FCC) adopted RF exposure guidelines with safety levels for hand-held wireless phones. Those guidelines are consistent with the safety standards previously set by both U.S. and international standards bodies:

ANSI C95.1 (1992) *
NCRP Report 86 (1986)
ICNIRP (1996)

Those standards were based on comprehensive and periodic evaluations of the relevant scientific literature. For example, over 120 scientists, engineers, and physicians from universities, government health agencies, and industry reviewed the available body of research to develop the ANSI Standard (C95.1).

The design of your phone complies with the FCC guidelines (and those standards).

Antenna Care

Use only the supplied or an approved replacement antenna. Unauthorized antennas, modifications, or attachments could damage the phone and may violate FCC regulations.

Phone Operation

NORMAL POSITION: Hold the phone as you would any other telephone with the antenna pointed up and over your shoulder.

Tips on Efficient Operation:

- For your phone to operate most efficiently:

Do not touch the antenna unnecessarily when the phone is in use. Contact with the antenna affects call quality and may cause the phone to operate at a higher power level than otherwise needed.

- American National Standards Institute; National Council on Radiation Protection and Measurements; International Commission on Non-Ionizing Radiation Protection

Driving

Check the laws and regulations on the use of wireless telephones in the areas where you drive. Always obey them. Also, if using your phone while driving, please:

- Give full attention to driving -- driving safely is your first responsibility;
- Use hands-free operation, if available;
- Pull off the road and park before making or answering a call if driving conditions so require.

Electronic Devices

Most modern electronic equipment is shielded from RF signals. However, certain electronic equipment may not be shielded against the RF signals from your wireless phone.

Pacemakers

The Health Industry Manufacturers Association recom-

mends that a minimum separation of six(6”) inches be maintained between a handheld wireless phone and a pacemaker to avoid potential interference with the pacemaker. These recommendations are consistent with the independent research by and recommendations of Wireless Technology Research

Persons with pacemakers:

- Should ALWAYS keep the phone more than six inches from their pacemaker when the phone is turned ON;
- Should not carry the phone in a breast pocket
- Should use the ear opposite the pacemaker to minimize the potential for interference
- If you have any reason to suspect that interference in taking place, turn your phone OFF immediately.

Hearing Aids

Some digital wireless phones may interfere with some hearing aids. In the event of such interference, you may want to consult the LG Authorised Service Center to discuss alternatives Optional for each phone manufacturer.

Other Medical Devices

If you use any other personal medical device, consult the manufacturer of your device to determine if they are adequately shielded from external RF energy. Your physician may be able to assist you in obtaining this information.

Turn your phone OFF in health care facilities when any regulations posted in these areas instruct you to do so. Hospitals or health care facilities may be using equipment that could be sensitive to external RF energy.

Vehicles

RF signals may affect improperly installed or inadequately shielded electronic systems in motor vehicles. Check with the manufacturer or its representative regarding your vehicle.

You should also consult the manufacturer of any equipment that has been added to your vehicle.

Posted Facilities

Turn your phone OFF in any facility where posted notices so require.

Aircraft

FCC regulations prohibit using your phone while in the air. Switch OFF your phone before boarding an aircraft.

Blasting Areas

To avoid interfering with blasting operations, turn your phone OFF when in a “blasting area” or in areas posted: “Turn off two-way radio”. Obey all signs and instructions.

Potentially Explosive Atmosphere

Turn your phone OFF when in any area with a potentially explosive atmosphere and obey all signs and instructions. Sparks in such areas could cause an explosion or fire resulting in bodily injury or even death.

Areas with a potentially explosive atmosphere are often, but not always marked clearly. Potential areas may include: fueling areas (such as gasoline stations); below deck on boats; fuel or chemical transfer or storage facilities; vehicles using liquefied petroleum gas (such as propane or butane); areas where the air contains chemicals or particles (such as grain, dust, or metal powders); and any other area where you would normally be advised to turn off your vehicle engine.

For Vehicles Equipped with an Air Bag

An air bag inflates with great force. DO NOT place objects, including either installed or portable wireless equipment, in the area over the air bag or in the air bag deployment area. If in-vehicle wireless equipment is improperly installed and the air bag inflates, serious injury could result.

FDA Consumer Update

The U.S. Food and Drug Administration's Center for Devices and Radiological Health Consumer Update on Mobile Phones.

1. **Do wireless phones pose a health hazard?**

   The available scientific evidence does not show that any health problems are associated with using wireless phones. There is no proof, however, that wireless phones are absolutely safe. Wireless phones emit low levels of radiofrequency energy (RF) in the microwave range while being used. They also emit very low levels of RF when in the stand-by mode. Whereas high levels of RF can produce health effects (by heating tissue), exposure to low level RF that does not produce heating effects causes no known adverse health effects. Many studies of low level RF exposures have not found any biological effects. Some studies have suggested that some biological effects may occur, but such findings have not been confirmed by additional research. In some cases, other researchers have had difficulty in reproducing those studies, or in determining the reasons for inconsistent results.

2. **What is FDA's role concerning the safety of wireless phones?**

   Under the law, FDA does not review the safety of radia-

tion-emitting consumer products such as wireless phones before they can be sold, as it does with new drugs or medical devices. However, the agency has authority to take action if wireless phones are shown to emit radiofrequency energy (RF) at a level that is hazardous to the user. In such a case, FDA could require the manufacturers of wireless phones to notify users of the health hazard and to repair, replace or recall the phones so that the hazard no longer exists.
Although the existing scientific data do not justify FDA regulatory actions, FDA has urged the wireless phone industry to take a number of steps, including the following:

- Support needed research into possible biological effects of RF of the type emitted by wireless phones;

- Design wireless phones in a way that minimizes any RF exposure to the user that is not necessary for device function; and

- Cooperate in providing users of wireless phones with the best possible information on possible effects of wireless phone use on human health.

FDA belongs to an interagency working group of the federal agencies that have responsibility for different aspects of RF safety to ensure coordinated efforts at the federal level. The following agencies belong to this working group:
- National Institute for Occupational Safety and Health
- Environmental Protection Agency
- Occupational Safety and Health Administration

- National Telecommunications and Information Administration

The National Institutes of Health participates in some interagency working group activities, as well

FDA shares regulatory responsibilities for wireless phones with the Federal Communications Commission (FCC). All phones that are sold in the United States must comply with FCC safety guidelines that limit RF exposure. FCC relies on FDA and other health agencies for safety questions about wireless phones.

FCC also regulates the base stations that the wireless phone networks rely upon. While these base stations operate at higher power than do the wireless phones themselves, the RF exposures that people get from these base stations are typically thousands of times lower than those they can get from wireless phones. Base stations are thus not the subject of the safety questions discussed in this document.

3. What kinds of phones are the subject of this update?

The term “wireless phone” refers here to hand-held wireless phons with built-in antennas, often called “cell”, “mobile”, or “PCS” phones. These types of wireless phones can expose the user to measurable radiofrequency energy(RF) because of the short distance between the phone and the user’s head.

These RF exposures are limited by Federal Communications Commission safety guidelines that were developed with the advice of FDA and other federal health and safety agencies. When the phone is locat-

ed at greater distances from the user, the exposure to RF is drastically lower because a person's RF exposure decreases rapidly with increasing distance from the source. The so-called "cordless phones," which have a base unit connected to the telephone wiring in a house, typically operate at far lower power levels, and thus produce RF exposures far below the FCC safety limits.

4. What are the results of the research done already?

The research done thus far has produced conflicting results, and many studies have suffered from flaws in their research methods. Animal experiments investigating the effects of radiofrequency energy (RF) exposures characteristic of wireless phones have yielded conflicting results that often cannot be repeated in other laboratories. A few animal studies, however, have suggested that low levels of RF could accelerate the development of cancer in laboratory animals. However, many of the studies that showed increased tumor development used animals that had been genetically engineered or treated with cancer-causing chemicals so as to be pre-disposed to develop ca ncer in the absence of RF exposure. Other studies exposed the animals to RF for up to 22 hours per day. These conditions are not similar to the conditions under which people use wireless phones, so we don't know with certainty what the results of such studies mean for human health.

Three large epidemiology studies have been published since December 2000. Between them, the studies investigated any possible association between the use of wireless phones and primary brain cancer, glioma, meningioma, or acoustic neuroma, tumors of the brain

or salivary gland, leukemia, or other cancers. None of the studies demonstrated the existence of any harmful health effects from wireless phone RF exposures. However, none of the studies can answer questions about long-term exposures, since the average period of phone use in these studies was around three years.

5. **What research is needed to decide whether RF exposure from wireless phones poses a health risk?**
   A combination of laboratory studies and epidemiological studies of people actually using wireless phones would provide some of the data that are needed. Lifetime animal exposure studies could be completed in a few years. However, very large numbers of animals would be needed to provide reliable proof of a cancer promoting effect if one exists. Epidemiological studies can provide data that is directly applicable to human populations, but 10 or more years follow-up may be needed to provide answers about some health effects, such as cancer. This is because the interval between the time of exposure to a cancer-causing agent and the time tumors develop — if they do — may be many, many years. The interpretation of epidemiological studies is hampered by difficulties in measuring actual RF exposure during day-to-day use of wireless phones. Many factors affect this measurement, such as the angle at which the phone is held, or which model of phone is used.

6. **What is FDA doing to find out more about the possible health effects of wireless phone RF?**
   FDA is working with the U.S. National Toxicology Program and with groups of investigators around the

world to ensure that high priority animal studies are conducted to address important questions about the effects of exposure to radiofrequency energy (RF).

FDA has been a leading participant in the World Health Organization International Electromagnetic Fields (EMF) Project since its inception in 1996. An influential result of this work has been the development of a detailed agenda of research needs that has driven the establishment of new research programs around the world. The Project has also helped develop a series of public information documents on EMF issues.

FDA and the Cellular Telecommunications & Internet Association (CTIA) have a formal Cooperative Research and Development Agreement (CRADA) to do research on wireless phone safety. FDA provides the scientific oversight, obtaining input from experts in government, industry, and academic organizations. CTIA-funded research is conducted through contracts to independent investigators. The initial research will include both laboratory studies and studies of wireless phone users. The CRADA will also include a broad assessment of additional research needs in the context of the latest research developments around the world.

7. How can I find out how much radiofrequency energy exposure I can get by using my wireless phone?

All phones sold in the United States must comply with Federal Communications Commission (FCC) guidelines that limit radiofrequency energy (RF) exposures. FCC established these guidelines in consultation with FDA and the other federal health and safety agencies. The FCC limit for RF exposure from wireless telephones is

set at a Specific Absorption Rate (SAR) of 1.6 watts per kilogram (1.6 W/kg). The FCC limit is consistent with the safety standards developed by the Institute of Electrical and Electronic Engineering (IEEE) and the National Council on Radiation Protection and Measurement. The exposure limit takes into consideration the body's ability to remove heat from the tissues that absorb energy from the wireless phone and is set well below levels known to have effects. Manufacturers of wireless phones must report the RF exposure level for each model of phone to the FCC. The FCC website (http://www.fcc.gov/oet/rfsafety) gives directions for locating the FCC identification number on your phone so you can find your phone's RF exposure level in the online listing.

8. What has FDA done to measure the radiofrequency energy coming from wireless phones ?

The Institute of Electrical and Electronic Engineers (IEEE) is developing a technical standard for measuring the radiofrequency energy (RF) exposure from wireless phones and other wireless handsets with the participation and leadership of FDA scientists anring the rate at which RF is deposited in the heads of wireless phone users. The test method uses a tissue-simulating model of the human head. Standardized SAR test methodology is expected to greatly improve the consistency of measurements made at different laboratories on the same phone. SAR is the measurement of the amount of energy absorbed in tissue, either by the whole body or a small part of the body. It is measured in watts/kg (or milliwatts/g) of matter. This measurement is used to determine whether a wireless phone complies with safety guidelines.

9. What steps can I take to reduce my exposure to radiofrequency energy from my wireless phone?

If there is a risk from these products--and at this point we do not know that there is--it is probably very small. But if you are concerned about avoiding even potential risks, you can take a few simple steps to minimize your exposure to radiofrequency energy (RF). Since time is a key factor in how much exposure a person receives, reducing the amount of time spent using a wireless phone will reduce RF exposure.

- If you must condict extended conversationsby wireless phone every dey, you could place more distance between your body and the source of the RF, since the exposure level drops off dramatically with distamce. For example, you could use a headset and carry the wireless phone away from your body or use a wireless phone connected to a remote antenna

Again, the scientific data do not demonstrate that wireless phones are harmful. But if you are concerned about the RF exposure from these products, you can use measures like those described above to reduce your RF exposure from wireless phone use.

10. What about children using wireless phones?

The scientific evidence does not show a danger to users of wireless phones, including children and teenagers. If you want to take steps to lower exposure to radiofrequency energy (RF), the measures described above would apply to children and teenagers using wireless phones. Reducing the time of wireless phone use and increasing the distance between the user and the RF source will reduce RF exposure.

Some groups sponsored by other national governments have advised that children be discouraged from using wireless phones at all. For example, the government in the United Kingdom distributed leaflets containing such a recommendation in December 2000. They noted that no evidence exists that using a wireless phone causes brain tumors or other ill effects. Their recommendation to limit wireless phone use by children was strictly precautionary; it was not based on scientific evidence that any health hazard exists.

11. What about wireless phone interference with medical equipment?

Radiofrequency energy (RF) from wireless phones can interact with some electronic devices. For this reason, FDA helped develop a detailed test method to measure electromagnetic interference (EMI) of implanted cardiac pacemakers and defibrillators from wireless telephones. This test method is now part of a standard sponsored by the Association for the Advancement of Medical instrumentation (AAMI). The final draft, a joint effort by FDA, medical device manufacturers, and many other groups, was completed in late 2000. This standard will allow manufacturers to ensure that cardiac pacemakers and defibrillators are safe from wireless phone EMI.

FDA has tested hearing aids for interference from handheld wireless phones and helped develop a voluntary standard sponsored by the Institute of Electrical and Electronic Engineers (IEEE). This standard specifies test methods and performance requirements for hearing aids and wireless phones so that no interference occurs when a person uses a “compatible” phone and a “com-

patible" hearing aid at the same time. This standard was approved by the IEEE in 2000.
FDA continues to monitor the use of wireless phones for possible interactions with other medical devices. Should harmful interference be found to occur, FDA will conduct testing to assess the interference and work to resolve the problem.

12. Where can I find additional information?

For additional information, please refer to the following resources:

- FDA wed page on wireless phones
  (http://www.fda.gov/cellphones
- Federal Communications Commission(FCC)RF Safety Program
  (http://www.fcc.gov/oet/rfsafety)
- International Commission on Non-Ionizing Radiation Protection
  (http://www.icnirp.de)
- World Health Organization(WHO) International EMF Project
  (http://www.who.int/emf)
- National Radiological Protection Board(UK)
  (http://www.nrpb.org.uk/)

Consumer Information on SAR (Specific Absorption Rate)

This Model Phone Meets the Government's Requirements for Exposure to Radio Waves.

Your wireless phone is a radio transmitter and receiver. It is designed and manufactured not to exceed the emission limits for exposure to radio frequency (RF) energy set by the Federal Communications Commission of the U.S. Government. These limits are part of comprehensive guidelines and establish permitted levels of RF energy for the general population. The guidelines are based on standards that were developed by independent scientific organizations through periodic and thorough evaluation of scientific studies. The standards include a substantial safety margin designed to assure the safety of all persons, regardless of age and health.

The exposure standard for wireless mobile phones employs a unit of measurement known as the Specific Absorption Rate, or SAR. The SAR limit set by the FCC is 1.6W/kg. * Tests for SAR are conducted using standard operating positions specified by the FCC with the phone transmitting at its highest certified power level in all tested frequency bands. Although SAR is determined at the highest certified power level, the actual SAR level of the phone while operating can be well below the maximum value. Because the phone is designed to operate at multiple power levels to use only the power required to reach the network, in general, the closer you are to a wireless base station antenna, the lower the power output.

Before a phone model is available for sale to the public, it must be tested and certified to the FCC that it does not exceed the limit established by the government-adopted requirement for safe exposure. The tests are performed in positions and locations (e.g., at the ear and worn on the body) as required by the FCC for each model. The highest

SAR value for this model phone when tested for use at the ear is 0.591 W/kg and when worn on the body, as described in this user guide, is 0.335 W/kg. (Body-worn measurements differ among phone models, depending upon available accessories and FCC requirements). While there may be differences between SAR levels of various phones and at various positions, they all meet the government requirement for safe exposure.

The FCC has granted an Equipment Authorization for this model phone with all reported SAR levels evaluated as in compliance with the FCC RF emission guidelines. SAR information on this model phone is on file with the FCC and can be found under the Display Grant section of http://www.fcc.gov/oet/fccid after searching on FCC ID BEJRD5130.

Additional information on Specific Absorption Rates (SAR) can be found on the Cellular Telecommunications Industry Association (CTIA) website at http://www.wow-com.com.

* In the United States and Canada, the SAR limit for mobile phones used by the public is 1.6 watts/kg (W/kg) averaged over one gram of tissue. The standard incorporates a substantial margin of safety to give additional protection for the public and to account for any variations in measurements.

You can call our Customer Contact Centre using One Unique Number.

You can call between 9 a.m. and 9 p.m. seven days.

Your call will be attended immediately.

LIMITED WARRANTY STATEMENT

LG ELECTRONICS Inc. represents and warrants that this subscriber unit and its accessories ("PRODUCT") are free from defects in material and workmanship.

This warranty is subject to the following terms and conditions:

1. This warranty of the PRODUCT extends for a period of 12 months commencing from the date of the activation or 16 months from the date of manufacture whichever is less, except for the battery, for which the warranty is 9 months from the date of activation or 12 months from the date of manufacture whichever is less.
2. During the warranty period, LG ELECTRONICS Inc. or its authorised service network will repair or replace, at LG ELECTRONICS Inc. 's option, the PRODUCT or any relevant parts thereof in the event that the PRODUCT is found to be defective. The repaired PRODUCT or the Product/part provided as a replacement for a defective PRODUCT/part, shall be free from defects. The END USER/ consumer purchaser of the PRODUCT or his/her assignee ("CONSUMER") shall not be charged (whether for parts, labour or otherwise) for the repair or replacement of a defective PRODUCT during the warranty period. All replaced parts, boards or equipment shall become the property of LG ELECTRONICS Inc.
3. The warranty in respect of a repaired or replaced PRODUCT/part shall extend for the remaining warranty period of the repaired PRODUCT or replacement thereof to the CONSUMER.
4. Upon request from LG ELECTRONICS Inc. , the CONSUMER may be required to provide the purchase receipt or other documentation or information in respect of the date and place of purchase.
5. The CONSUMER shall have no coverage or benefits under this warranty in the event that any of the following conditions are applicable:
   (a) The PRODUCT has been subject to abnormal use or conditions, improper storage, exposure to excessive moisture or dampness, exposure to excessive temperatures, unauthorised modifications, unauthorised repair (including but not limited to use of unauthorised spare parts in repairs), abuse, accident, Acts of God, spills of food or liquids, improper installation and breakage or damage to antennae (otherwise than by reason of any defects in material or workmanship).

(b) LG ELECTRONICS Inc. has not been notified by the CONSUMER of the defects of the PRODUCT during the applicable warranty period.

(c) The PRODUCT serial number code or the accessory date code has been removed, defaced or altered.

(d) The PRODUCT has been used with or connected to an accessory (i) not supplied by LG ELECTRONICS Inc. or its affiliates, (ii) not fit for use with the PRODUCT or (iii) used otherwise than in the manner intended.

(e) The seals of the PRODUCT'S battery enclosure have been broken or show evidence of tampering or the PRODUCT'S battery has been used in equipment other than that for which it has been specified usable by LG ELECTRONICS Inc.

(f) All plastic surfaces and all other externally exposed parts that are scratched or damages due to normal customer use.

(g) Breakage or damage to antenna unless caused by defects in material or workmanship

6. In order to derive the benefits of this warranty in respect of any defects in the PRODUCT, the CONSUMER shall ship the PRODUCTS or part thereof at its cost to the authorised service centre of LG ELECTRONICS Inc. LG ELECTRONICS Inc. shall bear the cost of shipping the PRODUCT or part thereof back to the CONSUMER after the completion of the service under this limited warranty.

   NO OTHER EXPRESS WARRANTY IS APPLICABLE TO THIS PRODUCT. THE DURATION OF ANY IMPLIED WARRANTIES, INCLUDING THE IMPLIED WARRANTY OF MARKETABILITY OR MERCHANTABILITY OR FITNESS FOR A PARTICULAR PURPOSE OR USE IS LIMITED TO THE DURATION OF THE EXPRESS WARRANTY HEREIN. LG ELECTRONICS Inc. SHALL NOT BE LIABLE FOR THE LOSS OF USE OF THE PRODUCT, INCONVENIENCE, LOSS OR ANY OTHER CONSEQUENTIAL DAMAGE, ARISING OUT OF THE USE OF, OR INABILITY OF USE, OF THIS PRODUCT OR FOR BREACH OF ANY EXPRESS OR IMPLIED WARRANTY, INCLUDING THE IMPLIED WARRANTY OF MARKETABILITY OR MERCHANTABILITY OR FITNESS APPLICABLE TO THIS PRODUCT.

7. It is hereby expressly clarified that all warranties (express or implied) in respect of the PRODUCT are provided by LG ELECTRONICS Inc. alone.

P/N : MMBB00 Date : 2004. 3. 3

Service Center List

Sr	Circle	City	ASCs Name	Address	Contact Person	Phone
1	Andhra Pradesh	Guntur	Vasavi Associates	Door no 6-20-4, Swarnalok complex, 4/1 Arandal Pet, Guntur-522003	MR.Satyam	0863-2233678, 9848105789, 0863-3155554
2	Andhra Pradesh	Hydrabad	Sri Varun Electronics	D.No 5-8-344/1, " DHAN BHAGYA ESTATE ", Chirag Ali Lane, Abids, Next to Raghava Ratna Towers, Hyderabad - 500 001	Mr.Raghavendra	040-55781999, 040-55253888, 040-56878822, 040-31001463
3	Andhra Pradesh	Hydrabad	JVR Infotech Pvt Ltd	Shop No 8 ,Vanijya Vihar,Nalanda Building, Dilsukh Nagar Main Road, Hydrabad-500060	EV Ramakanth	040-24161848, 040-55109604, 040-56524157, 040-31131067, 040-36060606
4	Andhra Pradesh	Hydrabad	S V Electronics	Shop No. 41, Nilagiri Block, Aditya Enclave, Ameerpet Main Road, Hydrabad-500038	Mr.Vankteshwara Rao	040-55754477/55343030
5	Andhra Pradesh	Kurnool	R K LG CDMA	Shop No 12-A,Abdulla Khan Estate Beside Yamaha Show Room,Kurnool PIN-518002	Mr.G Rama Krishna	08518-220201, 08518-310688
6	Andhra Pradesh	Nellor	Siri Enterprises	Opp.Archana Thearter,A C Centre,Nellore PIN-524001	Mr.Paraveen	0861--3209571, 0861-3100309
7	Andhra Pradesh	Rajamundhary	Siri Infotech	Police Welfare Complex,City Hospitals Junction,Danvai Pet Main Road,Rajhamundry-533103	Mr Raghvendra	0883-2421567, 0883-3125799
8	Andhra Pradesh	Secundrabad	Shweta Computers	# 1-7-69/1 & 2, OPP Aditya Delux Hotel,Near Paradaise circel Sarojini Devi Road, Secunderabad - 500003	Mr.Jagdish	040-55334180, 040-27721076, 040-36532358, 040-31041673
9	Andhra Pradesh	Tirupathi	CMT Computer Services	18-1-624 VV Mahal Road,OPP HDFC BANK, Tirupathi,PIN-517501	Mr.K Vasu Naidu	0877-5561979, 0877-3120209
10	Andhra Pradesh	Vijaywada	K L Computer House	39-9-46 SVS Temple Street,Labbipet,Vijaywada PIN- 520 010	Mr.Kartik	0866-5520461/ 5671461, 0866-3105222
11	Andhra Pradesh	Visakhapatnam	S V Electronics	D No.30-15-111,Daba Garden, Main Road, Visakhapatnam PIN-530020	Mr.Nani	0891-2598610, 0891-2706074, 0891-3706074
12	Andhra Pradesh	Warrangal	S S Marketers	6-1-73/1,Sai Bhavan, Sridevi Theatre Road, Hanamkonda,Warrangal-506001	Mr.L.Srinivas Rao	0870-2552223, 0870-3100708
13	Bihar	Jamshedpur	Prasad Electronics	Shop No. 29, Ground Floor, Yash Kamal Complex, Bistupur, Jamshedpur -831001	Ranjit Kumnar Prasad	0657-2487290, 9835164605
14	Bihar	Patna	Infotek Trading Company	1st floor, City Palace, New Dak Bunglow Road, Patna-800001	Sanjay Chowbey	0612-2227166
15	Bihar	Ranchi	Satya Systems & Solutions	158, Opp Hotel Palace, Kadru, Ranchi-834002	Amit Rastogi	0651-2341361, 9835167667

Sr	Circle	City	ASCs Name	Address	Contact Person	Phone
16	Delhi	Delhi	Comhard Systems	C-1/A Aruna Park, Laxmi Nagar,M S Chamber, Main Vikas Marg, Delhi-110092	Mr Ravi Kant Gupta	011-22533144, 1136783600, 011-30955887
17	Delhi	Delhi	Innovative Telecom	305,Aggarwal Millenium Tower,Netaji Subash Place,Pitam Pura,Delhi-110088	Mr Manoj Garg	011-55154343, 9811682453, 1130925753
18	Delhi	Delhi	Sagar Technologies	2/15, F/Floor,West Patel Nagar, Opp Vivek Cinema, Delhi-110028	Mr Deepak/Mr Amit	011-25888018/023, 9810320170/ 9818341677
19	Delhi	Delhi	Sagar Technologies	J-39,Central Mkt, Lajpat Nagar-II, New Delhi-110024	Mr Prabhat	011-29831108, 9810542287
20	Delhi	Delhi	Ucom Technologies Pvt Ltd.	45, 1st Flr, Corner Mrkt, Malviya Nagar, New Delhi - 110017	Shelendra Verma	011-26675900/55655382, 9810297420
21	Delhi	Delhi	Nice Telecommunication	15/23, DDA Complex, Nangal raya, Delhi - 110046	Umang Premi	011-28521044, 9810341374, 9810138894
22	Delhi	Delhi	Touch Tone Telecom	B-52, First Floor,Kalkaji, New Delhi	Ashish Dey	11 30939031
23	Gujarat	Ahmedabad	Visual Enterprises	104, Saarthak Complex, behind Urja House, Swastik Char Rasta, Navrangpura, Ahmedabad-380009	Mirza Patel	079-6438609, 31037582
24	Gujarat	Ahmedabad	Silicon Valley	F/6,Silver lake,Jagabhai Park,Rambaug Road,Maninagar,Ahmedabad-380008	Rajesh Patel	079-5430634, 9824025430, 36163645
25	Gujarat	Bhavnagar	Teletext Gold	G/8,Radheshyam Complex,Radha Mandir,Vaghavadi Road,Bhavnagar-364001	Nilesh Bagadia	0278-2415545, 9825206498
26	Gujarat	Gandhinagar	Creative Communications	F-11,Meghmalhar Complex,'Ch'-Road,Sector-11,Gandhinagar	K.J.Barot	079-3226241, 9824003132, 31005586
27	Gujarat	Jamnagar	Sudarshan Infosys	1,K.D.Complex,Nr Shrinath Travel Agency,Indira Marg,Gurudwara Chowkdi,Jamnagar-361001	Amit Unadkat	0288-2552696, 9824478203
28	Gujarat	Rajkot	Roopang info-care	Vinod Nivas,4,Sardarnagar(West),Nr Astron Cinema,Rajkot-360001	Kalpesh Rugani	0281-2464485, 9824068880 3103622
29	Gujarat	Surat	Excel Solutions	G-48, Ascon Plaza, Anand Mahal Road, Adajan Surat-395009	Nitesh Ghosal	0261-5544500, 9898038480 3344500, 9825399870
30	Gujarat	Vadodra	Aashnik Infotech	F 50,National Plaza,R.C.Dutt Road,Alkapuri,Vadodara-390005	Aashish Parmar	0265-2323216/3090969/3112123

Service Center List

Sr	Circle	City	ASCs Name	Address	Contact Person	Phone
31	Haryana	Ambala	Bee Ess Aar Communication	92-93, Gandhi market, Ambala Cantt-133001	Rajiv Gupta	0171-2641234, 9416021234
32	Haryana	Faridabad	Hi - Tech Communication	105, Sector 10, Faridabad-121006	Rahul Jindal	0129-2223422, 9810456663
33	Haryana	Gurgaon	Aryan Technologes & Telecommunication	729 A, 1st floor, Mehrauli Road,opp.ITI , Near kalyani hospital, Gurgaon-122001	G D Bhargava	0124- 2220289, 124 3564294
34	Haryana	Karnal	Mass Communication	7, Dayal Singh Colony, Kunj Pura Road, Karnal-132001	Ms Pinki	0184-3090717, 9868354205
35	Haryana	Panipat	INS Telecom	Shop No. 1, West Printing Market, Near Hotel West, G T Road, Panipat-132103	Jagdeep Sachdeva	0180-5005360/59, 9812072860
36	Haryana	Rohtak	Telecentre	Shakti Market, Civil Hospital Road, Near Chhotu Ram Chowk, Rohtak-124001	Mr.Madaan	01262-247242 , 9896243092 01262-371666
37	Haryana	Sonipat	Teleworld	21, M C Market, Subhash Chowk, Sonipat-131001	Vipin Dua	0130-2255955, 9812044888
38	Karnataka	Bangalore	Meenakshi Electronics	#129,Lalbagh Main Road, Bangalore-560027	Mr. Ramesh.	080-56992943/30617345, 8031810375
39	Karnataka	Bangalore	Optima Mobile Services	591-B, Dr Rajkumar road, 2nd block,Rajajinagar,Bangalore-560010	Unni Krishnan	080-3131953, 8031866656
40	Karnataka	Bangalore	Optima Mobile Services	B-3, Mallikaarjun Complex, Opp R T Nagar Police Station, 80 Feet Road, R T Nagar, Bangalore-560032	Prasad	080-30610202
41	Karnataka	Bangalore	Pranav infocom	91/92 ,Hemachandra complex,Near VGP Show room,4th block,jayanagar,Bangalore-560011	S.V.Sirish	080-56697937, 080-31860269
42	Karnataka	Bangalore	Pranav infocom	267/1,1st Main Road,6th Cross, Behind Shanti Sagar,Domlur Layout, Bangalore-560071	S.V.Sirish	80- 56969937, 80-31810269
43	Karnataka	Belgaum	Hello India Telecom	G-4,Maratha Mandir Complex, Khanapur Road, Near Railway Flyover, Belgaum - 590 001.	Sanjay	9845327531/0831-3101800
44	Karnataka	Hubli	Naveen Communication	# 19,20,2nd floor, Eureka Junction, Travellers Bunglow Road,Hubli - 580 029.	Naveenraju S V	0836-2355302, 0836-3403766
45	Karnataka	Mangalore	City Talk Communication	GURU PLAZA, G-5, Near KSRTC Bus stand, Bejai, Mangalore - 575001	A V Prabhu	0824-3344528, 0824-877528

Sr	Circle	City	ASCs Name	Address	Contact Person	Phone
46	Karnataka	Mysore	K.K.Marketing,	1432/9, Tribhuvan Towers, opp Vetenary Hospital, Dewan's Road, Dhanwantri Road Cross, Mysore -570001	Mr. Karunakaran.	0821-2422789, 821 3120789
47	Kerala	Ernakulam	Zenicon Infocom(P) limited	2nd floor, Tharian's Building,opp. Ship Yard, M.G. Road, Ernakulam-682015"	Jaimon Joseph	0484-2371511, 9846127878
48	Kerala	Irinjalkuda	Akbar Mobiles	376-44, Near St. Josephs college junction,Irinjalakuda-680121	Mr Sebastian	0480-830796
49	Kerala	Karunagapally	Supreme Enterprises	Opp to KSRTC Bus stand,Karunagapally-690518	Mr. Ratish	0476-2620282
50	Kerala	Kollam	Digital Infosystems	MC-3087, New Block, Bishop Jeromi Nagar, Chinnakada, Kollem-691001	Johnson Lawrence	0474-2760647, 9846007059
51	Kerala	Kottayam	SVM Technologies	NSS Builbing, Near Pallippurathukavu Temple, Kodimapha,Kottayam - 686 002	Rajesh K S	0481-2565303, 9847310123
52	Kerala	Kozhikode	Domain Infosystems	Domain Infosystems, 2nd Floor, Darussalam Complex, Mavoor Road, Kozhikode - 673 004	Mukundan	0495-2722222
53	Kerala	Manjeri	Akbar Mobiles	16-870A,Ooty Road, Manjeri-676121	Mr Harry	0483-2766835
54	Kerala	Mavellikarra	Ettutharayl Agency	Ettutharayil complex, K P Road,Kayamkulam-690502	Anu T cheriyan	0479-2441760, 0479-3100025
55	Kerala	Pallakad	Akbar Mobiles	N.S. Towers,Kalamandapam junction,Palakkad - 678 001	Suresh	0491-2529829, 9847086446
56	Kerala	Thiruvananthapuram	Appolo Systems	TC 20/2392, Kalpalayam, Karamana P.O., Thiruvananthapuram - 695 002.	Santosh	0471-2340523
57	Kerala	Tirur	Akbar Mobiles	7-2,Ancila Building,Terivazhiambalam,Tirur - 676101	Mr Byju	0494-2427444
58	Kerala	Trichur	Akbar Mobiles	Kadarathodh Building,North Bus stand, Trichur - 680 001	Sojan	0487-2323424
59	Madhya Pradesh	Bhopal	Neha Sales Corporation	F-104, Anmol Tower, E-5/14, Commercial Zone, Arera Colony, Bhopal-462016	Ashok Hirwani	0755-5277247/2424088, 9826072327
60	Madhya Pradesh	Gwalior	Computer Clinic	Global Appartments,City Centre, Opp Income Tax Office, Gwalior.	Rishi Sharma	0751-2233088

Service Center List

Sr	Circle	City	ASCs Name	Address	Contact Person	Phone
61	Madhya Pradesh	Indore	Neha Sales Corporation	M-8,Mezanine Floor, Akash Deep Shopping Complex, Sneh Nagar, Sapana Sangeeta Road, INDORE - 452001(M.P)	Ashok Hirwani	0731-5091833, 9826072327
62	Madhya Pradesh	Jabalpur	S M Shopee	846, Chattarpur Bhavan, Nr. Ashoka Hotel, Wright Town, Jabalpur,Pin 482002	Vikas Jain	0761-5063183
63	Madhya Pradesh	Raipur	Cybernet Systems	B-2,1st Floor, Garchaz Complex, Jail Road, Raipur - 492001	Anand Singh	0771-2524033, 9826132918
64	Maharashtra	Amravati	Scorpio Services	Shop No. 84, Ground Floor,GulshanTowers, Nr. Panchasheel Cinema, Amrawati, Pin-444601	Lakhani	0721-2567302, 0721 3151826, 9422156874
65	Maharashtra	Aurangabad	Unique Teletmatics	Shop no.108/B,Behind Sajawat Handloom, Tapdiya Super Market, Nirala Bazar, Aurangabad-431001	Nivedita	0240-2356447, 9823007730, 0240 3110364
66	Maharashtra	Chinchwad (Pimpri)	Ritz Communication	Shop No 22, Gawde Kunal garden,Pimpri-Chinchwad Link Road, Chinchwad, Pune-411033	Mr Reyaz	020-7485613, 9822275786, 020 31029777
67	Maharashtra	Kohlapur	SMS Services	S5, Diwan Tower, Opp. Nutan Marathi School, Near Mirajkar Tikkty, Kolhapur, Pin -416005.	Prakash Patil	0231-2541120, 9823026120
68	Maharashtra	Margoa	Comlink Synergies India Pvt Limited.	Ground Floor, Shop No.i,Garden view building,,Next to UTI Bank , Near Margao Municipal Garden,Margao-403601	Sunil	0832 3105629, 9822101522, 0832 3105637
69	Maharashtra	Nagpur	Spectrum Marketing	Shop No.2, Dharampeth Towers, West High Court (WHC) Road, Dharampeth , Nagpur - 440010	Sonali	0712-2527823, 9823338333, 0712-30957001/5618186
70	Maharashtra	Nasik	Elcomp Services	B5,Nidhi Park, Vakilwadi, M G Road, Nasik, Pin 422001	Rajesh Laxmikant Joshi	0253-2578394, 9822431774
71	Maharashtra	Panjim	Comlink Synergies Pvt Ltd	Ground Floor, Gomes Building, opp Hotel Delmon, Caetano De Albukuerkue Road, Panjim -403001	Sunil	0832-2426978, 9822101522, 0832 3105629
72	Maharashtra	Pune	Digital Concepts	Shop No. 5, Indulal Complex,Besides Kaka Halvai, LBS Marg, Navi Peth, Pune-411030	A Ahmed	020-4012921, 9822438818, 020 31029798
73	Maharashtra	Sangli	Ramesh Electronics	Opp. Kanya Purohit prashala,Rajwada,Sangli-416416	Suresh Shegane	0233-2327601, 9823085176,0233 3107601
74	Maharashtra	Solapur	Jawaharlal Radio Service	184, Gold Finch Peth, nr Hotel Ritesh, Solapur - 413007.	Prasanna J Chavan	0217-2725030, 9422458830
75	Mumbai	Kalyan	Vinay Technologies Pvt Ltd	SHOP- 14, GROUND FLR,ARCHIES APARTMENT,OAK BAUG,KALYAN-421301	Pawan	022-32977555

Sr	Circle	City	ASCs Name	Address	Contact Person	Phone
76	Mumbai	Vasai	E-Link Solutions	Shop No.5, Type C, Bldg no.5/6, Shanti Vihar, Mira Road -E, Pin Code : 401107.	Kamlesh	022-28552087, 9821734223
77	Mumbai	Mumbai	Roop Technologies Pvt Ltd	12, Pawwala Street, Rajaram mohan Roy Road,Patli Putra Building, Grant Road- East, Mumbai - 400004	Vishwas	022-23864166, 9820098916,022 33864166
78	Mumbai	Mumbai	M R Telecom	Shop No 04, Amar Kunj Building, Peston Sagar Road no.2,Amar Mahel, Lane Opp Shopper Stop, Chembur, Mumbai - 400089	Shailesh	022-25285561, 9820137910,022 32754745
79	Mumbai	Mumbai	Everest International Pvt Ltd	45, Udyog bhavan, Sonavala Road, Goregoan east, Mumbai - 400 063.	Chetan	022- 28775522, 9821048111
80	Mumbai	Mumbai	LG Service Centre	Third Floor, Trade World,Kamala Mills Compound, Senapati Bapat Marg, Lower Parel, Mumbai-400013	Rajib Saha	022-24947375
81	Mumbai	Navi Mumbai	LG Service Centre- DAKC	A Block, Ground Floor, Dhirubhai Ambani Knowledge City, Navi Mumbai-400709	Rajnish	022-30388052, 022-33490405
82	Mumbai	Thane	Vinay Technologies Pvt Ltd	Shop no 3, Minal Chhaya Aptt, Muncipal Corporation Road, Panch Pakhadi, Thane (W) - 400601	Vinod Jakotiya	022-25304960, 9821068231, 022-31013342
83	Mumbai	Navi Mumbai	Hello World	Shop No 53,GF,Welfare Chambers,Sector-17,Vashi,Mumbai-400703	Mahesh	022-27657705, 022 32741396
84	Orissa	Bhubneshwar	S.A.INFOSYS	291.Bomikhal, Opp.Akamra cinema hall, Bhubaneswar-751010	Sarabjeet Singh	0674-2573113/4
85	Orissa	Cuttack	O.A.INFOTECH	Behind Govt Bus Stand, Badambadi, Cuttack -753012	Manas Mahapatro	0671-2312613
86	Punjab	Amritsar	Bajaj Telecommunication	87, G Floor, Nehru Complex, Lawrence Road, Amritsar-143001	Suman Bajaj	0183-5096511, 9417040014
87	Punjab	Barnala	Lalli's Electronic Gallery	Kartar Nagar,Mittal Street, Barnala-148101	Pankaj Goyal	01679-238007, 9815075670
88	Punjab	Bathinda	Lalli's Electronic Gallery	1139-A, First Floor, Amrik Singh Road, Nr Gole Diggi, Bhatinda-151005	Ashok Kakria	0164- 2239500/2236337, 9814222310
89	Punjab	Chandigarh	Global Systems	SCO-3021-22, First Floor, Sector 22-D, Chandigarh-160022	Sulalit Gupta	0172-388833, 9814002284
90	Punjab	Hoshiarpur	Kuldip's Mobile Care	Dhobian Wali Gali,Phagwara Road, Hoshiarpur-146001	Kuldip	01882-226906, 9815073906

Service Center List

Sr	Circle	City	ASCs Name	Address	Contact Person	Phone
91	Punjab	Jallandhar	Mobile Center	Shop No. 5,Hotel Preet Market,Nakoder Road,Jallandhar-144001	Jogesh Diwan	0181-5073344, 9814029696
92	Punjab	Ludhiana	Rahul Telecom	Shop No. 5,Skand Tower, Dr Heera Singh Road,Civil Lines,Ludhiana-141001	Anil Kumar	0161-2412884, 9814651803
93	Punjab	Malerkotla	Image Services	Opp. Main gate,Govt College, MalerKotla-148023	Rohit Bansal/Raj Verma	01675-253899, 9814040066, 01675-331979
94	Punjab	Moga	Super Communication	Pawan Market,Opp shankar Batteries,Court Road, Moga-142001	Jai Deep Mehta	01636-227440
95	Punjab	Patiala	Image Services	84, First Floor, Leela Bhawan, Patiala-147001	Rohit Bansal	0175-2222796, 9814040066
96	Rajasthan	Jaipur	Kamakshi Telecom	1st floor, Sunny house, K-21 Malviya Nagar, C Scheme, Near government press, Jaipur-302001	Rahul Bhargav	0141-5101280, 9829012478, 0141-3112863
97	Rajasthan	Jodhpur	Omega Electronics	UG/4, Adeshwar Tower, Main Chopasani Road, Opp.Gehlot Watch Co, Jodhpur-342003	Pratap Singh	3091219, 0291-3117171
98	Rajasthan	Kota	Cyber Infosystems	26, Ground floor, Kalawati Paliwal market, Gumanpura, Kota-324007	Shyam Maheshwari	0744-2320153, 9829231847
99	Rajasthan	Udaipur	Ficusa Enterprises	13,Darshanpura,Opp.M.B.Commerce College Gate,Nr Computer Zone,Udaipur-313002	Virendra Ranka	0294-2410002, 2413002, 3410002
100	Tamilnadu	Chennai	Unicare Infocomm Services	73, Nutech Plaza, Shop no G-3, G Floor, Arcot Road, Kodambakkam, Chennai - 600 024.	R M Rajesh/Kartik	044-24724666, 9841036466
101	Tamilnadu	Chennai	GS Systems	547/352, F M Towers, Mount Road, Nandanam, Chennai-6000035	Kanirajan	044-24330889, 9884160010
102	Tamilnadu	Chennai	U Com Technologies Pvt. Ltd.	Shop No.2, Old No. 24, New No. 30, Balfour Appartments, Kilpauk, Chennai-600010	Shyam	044-52174656/52175115, 9884187800
103	Tamilnadu	Chennai	Escomm Systems India P Ltd	Arunodaya Complex, New No 57-7, Old No 26-7, Ponnamalai High Road, Chennai-600003	Mrs N S Vijaysri	044-30901688
104	Tamilnadu	Coimbatore	Fast Track	Sudera Complex, 354B, 100 Feet Road, COIMBATORE - 641012	Anand Prakash	0422-2490577, 9843080040, 0422-3100080
105	Tamilnadu	Cuddlore	Kasturi Cellular Service	# 2, Uma Complex,Upstairs,Riverside Road,Opp Tharaikakha Kaliamman Koil,Pudupalayam,Cuddlore-607001	Mr Raghupati	04142-220183

Sr	Circle	City	ASCs Name	Address	Contact Person	Phone
106	Tamilnadu	Erode	JANS Electronics	148,Nattur Road, Opposite shakti vinayak temple,Dana Complex, Erode-638011	M Kanan	0424-2258526, 9443263508
107	Tamilnadu	Madurai	Devaa Electronics	No.4, Thirumakulam North Street,Near Ayyappan koil, Thhallakulam,Madurai-625002	Guna	0452-2526179/3107995
108	Tamilnadu	Pondicherry	Digital Logistics	126/2, Perumal Koil Street (Bharathi Street Cutting), Pondicherry-605001	G Singaravelu	0413-2222148, 9843093348, 0413-3155351
109	Tamilnadu	Salem	Global Care	262-A, Advitha Ashram Road, Salem - 636004	Vasudev Nayak	0427-2335787, 0427-3102124, 0427-3102124
110	Tamilnadu	Thanjavur	Z M Electronics	33,New Municipal Shopping Complex,Opp LIC,Gandhi ji road,Thanjavur-613001	Ziauddin	04362-272595, 04362-313254
111	Tamilnadu	Tirunevelli	Classic Electronic	39, Trivendrum Road, Opposite Kalimark, Welcome Complex, Palayamkottai, Tirunilveli-627002	Erkins	0462-2575801
112	Tamilnadu	Tirupur	Shri Vasavi Electronics	"# 155-303, Mangalam Road,Karuvam palayam, Tirupur -641604"	MR.U.B. Bala Murali	0421-2243005, 98422-74300, 0421-3105560
113	Tamilnadu	Trichy	S K Electronics	2nd Floor, Siva Complex, Bishop Road,Puthur, Trichy-620017	Krishnan	0431-2742646, 9843178104, 0431-3101502
114	Tamilnadu	Vellore	Kelcom Engineers	85A, Officers Line, Toll Gate, Vellore - 632001	MR.V.S.Kumaran	0416-2214396, 9843007761 0562-2528250
115	Uttar pradesh	Agra	NSC Computers	Shop No G-124, Block No- 29, Sanjay Place, Agra – 282 002	Rajiv Singhal	0562-2520032, 562 3111350
116	Uttar pradesh	Aligarh	A V Computer Services	G-1,Ganpati Plaza ,Jha Compund, Marris Rd, Aligarh-202001	Vaibhav	0571-2506148, 9412274391
117	Uttar pradesh	Allahbad	B.P.Electronics	G-11, Indira Bhawan, Ground Floor, Civil Lines, Allahbad-211001	Ms Naina Pandey	0532-2608088
118	Uttar pradesh	Bareilly	Sapan Infotech	106/17 Ist Floor,Civil Lines,Opp Sainik Petrol Pump,Bareilly,Pin 243001	Sanjeev Singh	0581-2477552, 9897209594
119	Uttar pradesh	Dehradun	Krishna Communication	Shop No 15A, Meedo Plaza, Rajpur Road, Dehradun,Uttaranchal-248001	Vinod	135 3090895, 135 3112922/135 3119696
120	Uttar pradesh	Ghaziabad	S P Telecom	G-2, Konark Building Raj Nagar District Centre (RDC), Rajnagar, Ghaziabad	Mr Aagrahari	0120-2706340, 3298089, 3421669

Service Center List

Sr	Circle	City	ASCs Name	Address	Contact Person	Phone
121	Uttar pradesh	Gorakhpur	Eternal Electronics	Shop No.11, Pandey Complex, 33, Kasya Road, Opp DIG Bunglow, Gorakhpur -273001	Ram Pratap	0551-2204520
122	Uttar pradesh	Kanpur	AR Infotech	111/87 Ashok Nagar,Kanpur Pin 208012	Manoj Shukla	0512-3111662, 9839068734, 0512-3093011
123	Uttar pradesh	Lucknow	NET COM	3 way road, City Point, Opp Krishi Bhawan, Lucknow-226024	Kawaljeet	0522-3094222
124	Uttar pradesh	Meerut	Systech Computers	F-124/125 Ist floor Ganga Plaza, Begum Bridge Road, Meerut-250002	Vineet Goyal	0121-2691167, 121 3116631
125	Uttar pradesh	Muzaffarnagar	Jai Computer Services	Shop No. 4, 1st Floor, Roorkee road, Near Shiv Chowk,Central Bank Mkt, Muzaffarnagar-251001	Manohar Singh	0131-2635483, 9412110215
126	Uttar pradesh	Noida	M R Telecom	J-45, First Floor, Sector-18, NOIDA-201301	Kailash Aggarwal	0120-2591440, 9818028061
127	Uttar pradesh	Saharanpur	Maharaj Communications	Near Maharaja Palace,Delhi Road, Saharanpur-247001	Pankaj Malhotra	0132-2720881, 132 3111202
128	Uttar pradesh	Varanasi	Shivam Mobile Distributers	Shop No.5,B37/115-B-1 Baradari Complex,Rathyatra Crossing,Varansi Pin 221010	Rishi Mohan	0542-2363296, 9839241004
129	W Bengal	Assansol	Sky Computer & Telecom	Islam Market, Nuruddin Road, Assansol-713301	Syed Arshad Ali	0341- 2207719, 9832160886
130	W Bengal	Burdwan	San Infosys	Tikonia Bus Stand, Central Mkt, GT Road, Burdawan-713101	Sanjit Debnath	0342-3090265, 9832192170
131	W Bengal	Calcutta	Benma Infosol Pvt Ltd.	344 Canal Street, Sribhumi, Kolkata - 700048	Arun Surana	033-25344377/79, 9831077143
132	W Bengal	Calcutta	JP Computers	5B Ekdalia Place, Kolkata - 700019	Somim Kabir	033-24401923
133	W Bengal	Calcutta	Skylink	8/1A, Little Russel Street, Calcutta-700071	H R Molla	033-30903814, 033-32091037
134	W Bengal	Durgapur	Tech International	Red Cross Road, City Centre, Durgapur-713216	Amitava Banerjee	0343-2546893, 9434002244

विषय -सूचि

प्रस्तावना | 3

महत्वपूर्ण सूचना

शुरू करने से पहले | 4

अध्याय 1 शुरू करना | 8

सावधानियाँ 8
फोन के पुर्जे 9
फोन के बारे में 10
स्क्रीन पर आने वाले चिन्ह 11
बैटरी और चार्जर का उपयोग 12

अध्याय 2 मूलभूत फंक्शन | 15

फोन को बंद और चालू करना 15
कॉल करना 15
कॉल प्राप्त करना 16
संकेत की शक्ति 16
एंटीना के बारे में 16
त्वरित समायोजन 17
कॉल प्रतीक्षा 18
मौन 18
कॉल रीडायल करना 19
शीघ्र डायलिंग 19
कॉलर आईडी 19
T9 टेक्स्ट इनपुट मोड से जानकारी लिखना 20
T9 टेक्स्ट इनपुट उपयोग के उदाहरण 22
हिन्दी **प्रविष्टि** के लिए बटन मैपिंग 24
हिन्दी मोड में संपादन 25

अध्याय 3 फोन बुक | 27

फोन बुक की सुविधाएँ 27

अध्याय 4 सूची की सुविधाएँ । 32

सूची तक पहुँचने और सेटिंग्स के सामान्य दिशानिर्देश . . 32
नाम 32
संदेश 36
कॉल विवरण 45
प्रोफाइल्स. 48
प्रदर्शन 50
सेटिंग्स 53
ऑर्गनाइज़र 60
R वर्ल्ड 64

अध्याय 5 कॉल के दौरान प्रयुक्त फंक्शन । 68

कॉल मेमो में 68
मौन / मौन नहीं 68
ईयरपीस/स्पीकर वॉल्यूम 68
वॉइस प्राइवेसी ऑन/ऑफ 68
स्पीकर ऑन समायोजित करना 68

अध्याय 6 सहायक उपकरण । 69

अध्याय 7 सूची श्रृंखला । 70

अध्याय 8 सामान्य प्रश्न । 72

अध्याय 9 सुरक्षा दिशानिर्देश । 76

टी आई ए सुरक्षा जानकारी
एफ डी ए उपभोक्ता अद्यतन
एस ए आर पर उपभोक्ता जानकारी

प्रस्तावना

LG – RD5130 सेल्युलर फोन खरीदने पर आपको बधाई जिसे नवीनतम डिजिटल मोबाइल संचार तकनीक, कोड डिवीज़न मल्टिपल एक्सेस (सीडीएमए) पर संचालित करने के लिए डिज़ाइन किया गया है. सीडीएमए सिस्टम ने आवाज़ की स्पष्टता बहुत बढ़ाई है और यह विभिन्न प्रकार की उन्नत सुविधाएँ प्रदान कर सकता है. यह एक उन्नत और परिपूर्ण फोन है जिसमें ये विविध सुविधाएँ हैं :

- बड़ी, पढ़ने में आसान, 6–पंक्ति की स्क्रीन लाइट वाली एलसीडी जिसमें स्थिति दिखाने वाले चिन्ह हैं.
- पेजिंग, संदेश भेजना, वॉइस मेल, और कॉलर आईडी.
- 18–बटन वाला बटन पैड (10 नंबर बटन/1 कॉल बटन/ 2 सॉफ्ट बटन/1 क्लीयर बटन / 1 नेविगेशन बटन / 1 कॉल बटन / 1 एंड बटन).
- लंबी बैटरी स्टैंडबाय और टॉक टाइम.
- R वर्ल्ड से 19 रिंग टोन और 3 डाउनलोड का विकल्प.
- आसान संचालन और कॉन्फिगरेशन के लिए सूची–संचालित इंटरफेस.
- कॉल प्राइवेसी सीडीएमए एन्कोडिंग में निहित.
- कोई बटन उत्तर, स्वत: रीडायल, 99 मेमोरी स्थानों वाली एक स्पर्श डायल और स्पीड डायलिंग के साथ.
- अधिक सुविधा और अधिक कार्यक्षमता के लिए वैकल्पिक उपकरण.
- आप कॉल के दौरान स्पीकर ऑन मोड में प्राप्तकर्ता की आवाज़ और ऊँची सुन सकते हैं.

महत्वपूर्ण जानकारी

इस यूज़र मैन्युअल में आपके फोन के उपयोग और कार्यप्रणाली के बारे में महत्वपूर्ण जानकारी है. पूर्ण कार्यक्षमता और फोन को किसी भी प्रकार की क्षति या दुरुपयोग से बचाने के लिए कृपया फोन का उपयोग करने से पहले सारी जानकारी ध्यान से पढ़ लें. कोई भी अनधिकृत परिवर्तन या संशोधन करने से आपकी वॉरंटी रद्द हो जाएगी.

शुरू करने से पहले

सहायक उपकरण जाँच लें

आपके मोबाइल फोन के साथ एक ए सी एडाप्टर, एक रीचार्जेबल बैटरी और एक हेडसेट आता है. कृपया देख लें कि ये उपकरण आपको मिले हैं.

सुरक्षा अनुदेश

चेतावनी! बिजली के झटके की संभावना कम करने के लिए अपना फोन ज़्यादा नमी वाले स्थानों जैसे बाथरूम, स्विमिंग पूल जैसी जगहों पर न ले जाएँ.

फोन को किसी नुकसान से बचाने के लिए केवल LG द्वारा मान्य बैटरियों और ट्रेवल चार्जरों का ही उपयोग करें. दूसरी बैटरियों या चार्जरों का उपयोग करने पर आप वॉरंटी की शर्तों का उल्लंघन करते हैं और इससे विस्फोट भी हो सकता है.

बैटरियों और ट्रेवल चार्जरों को फोन के अलावा अन्य कामों के लिए उपयोग न करें.

अपने फोन को हमेशा ऊष्मा से दूर रखें. फोन को कभी -20 डिग्री सें. से कम या 50 डिग्री सें. से अधिक तापमान की स्थितियों, जैसे बर्फबारी के समय खुले में या किसी गर्म दिन अपनी कार में न रखें. अत्यधिक सर्दी या गर्मी से आपके फोन को नुकसान पहुँच सकता है और/या बहुत बड़ी खराबी आ सकती है.

अन्य इलेक्ट्रॉनिक उपकरणों के पास अपने फोन का उपयोग करते समय सावधानी बरतें. आपके फोन से होने वाला आर एफ उत्सर्जन आसपास के ऐसे इलेक्ट्रॉनिक उपकरणों को नुकसान पहुँचा सकता है, जो समुचित रूप से सुरक्षित नहीं हैं. आपको व्यक्तिगत चिकित्सकीय उपकरणों जैसे पेसमेकर और श्रवण यंत्रों के निर्माताओं से पूछ लेना चाहिए कि कहीं वे आपके मोबाइल फोन के प्रति संवेदनशील तो नहीं हैं. चिकित्सालय में या पेट्रोल पंप पर अपना फोन बंद कर दें.

अपने फोन को कभी भी माइक्रोवेव ओवन में न रखें, इससे बैटरी में विस्फोट हो जाएगा.

महत्वपूर्ण! अपने फोन का उपयोग शुरू करने से पहले कृपया टी आई ए सुरक्षा जानकारी (पृष्ठ 76 पर) पढ़ लें.

एफ सी सी आर एफ एक्सपोज़र जानकारी

चेतावनी! फोन का उपयोग करने से पहले यह जानकारी पढ़ें.

अगस्त 1996 में, संयुक्त राज्य के फेडरल कम्युनिकेशन कमीशन (एफ सी सी) ने रिपोर्ट एंड ऑर्डर एफ सी सी 96–326 पर कार्रवाई के माध्यम से, एफ सी सी नियंत्रित ट्रांसमीटरों द्वारा उत्सर्जित रेडियो फ्रीक्वेंसी (आर एफ) इलेक्ट्रोमैग्नेटिक ऊर्जा से मानव पर पड़ने वाले प्रभाव के लिए अद्यतन सुरक्षा मापदंड अपनाए हैं. ये दिशानिर्देश पूर्व में यू.एस. और अंतर्राष्ट्रीय मानक संस्थानों द्वारा निर्धारित सुरक्षा मानकों के अनुरूप हैं.

इस फोन की डिज़ाइन एफ सी सी दिशानिर्देशों और इन अंतर्राष्ट्रीय मापदंडों को पूरा करती है.

⚠ सावधानी

केवल फोन के साथ आए और प्रामाणिक सहायक उपकरणों का ही उपयोग करें. अनधिकृत उपकरण या परिवर्तन, कॉल की गुणवत्ता पर विपरीत प्रभाव डाल सकते हैं, फोन को नुकसान पहुँचा सकते हैं या आपकी वॉरंटी की शर्तों का उल्लंघन कर सकते हैं.

क्षतिग्रस्त सहायक उपकरण वाले फोन का उपयोग न करें. क्षतिग्रस्त सहायक उपकरण के संपर्क में आने पर त्वचा थोड़ी जल सकती है. सहायक उपकरण बदलने के लिए अपने स्थानीय डीलर से संपर्क करें.

शरीर के साथ रखकर संचालन

इस उपकरण का परीक्षण आमतौर पर उपयोग के समय शरीर और फोन के बीच रहने वाली दूरी, जिसमें फोन का पिछला हिस्सा शरीर से 3/4 इंच (2 सेमी) दूर रहता है, की स्थितियों में किया गया है. एफ सी सी आर एफ एक्सपोज़र मापदंडों के पालन के लिए, उपयोगकर्ता के शरीर और फोन के पिछले हिस्से के बीच, जिसमें एंटीना भी शामिल है, कम से कम 3/4 इंच (2 सेमी) की दूरी होनी चाहिए. अन्य निर्माताओं के बेल्ट क्लिप, होल्स्टर जैसे धातु के पुर्जों वाले सहायक उपकरण उपयोग नहीं किए जाने चाहिए. ऐसे सहायक उपकरण जो उपयोगकर्ता के शरीर और फोन के पिछले भाग के बीच 3/4 इंच (2 सेमी) की दूरी नहीं रख सकते, और जिनका परीक्षण शरीर से आमतौर पर रहने वाली दूरी की स्थितियों में नहीं किया गया है, वे संभवतया एफ सी सी आर एफ एक्सपोज़र सीमाओं के अनुरूप न हों और इनका उपयोग नहीं किया जाना चाहिए.

वाहन पर लगा बाहरी एंटीना
(वैकल्पिक, यदि उपलब्ध हो तो)

एफ सी सी आर एफ एक्सपोज़र मापदंडों के अनुसार उपयोगकर्ता/पास खड़े व्यक्ति और वाहन पर लगे एंटीना के बीच कम से कम 8 इंच (20 सेमी) की दूरी होनी चाहिए. आर एफ एक्सपोज़र के बारे में अधिक जानकारी के लिए, एफसीसी की वेबसाइट www.fcc.gov देखें.

एफ सी सी भाग 15 वर्ग बी अनुपालन

यह उपकरण और इसके सहायक उपकरण, एफ सी सी नियमों के भाग 15 के अनुरूप हैं. इसके संचालन की निम्न दो शर्तें हैं: (1) यह उपकरण और इसके सहायक उपकरण हानिकारक अवरोध पैदा नहीं कर सकते, और (2) यह उपकरण और इसके सहायक उपकरण किसी भी प्राप्त अवरोध को स्वीकार करेंगे, जिसमें वे अवरोध शामिल हैं जिनसे अवांछित संचालन होता हो.

बैटरी के लिए सावधानियाँ

- इसे खोलें नहीं.
- शॉर्ट सर्किट नहीं करें.
- ऊँचे तापमान में न रखें : 60 डिग्री सें. (140 डिग्री फे.)
- इसे जलाएँ नहीं.

बैटरी नष्ट करना

- कृपया अपनी बैटरी को ठीक से नष्ट करें या रिसाइक्लिंग के लिए अपने स्थानीय वायरलेस कैरियर के पास ले जाएँ.
- अपनी बैटरी को आग या घातक अथवा ज्वलनशील सामग्रियों में न डालें.

चार्जर के लिए सावधानियाँ

- गलत बैटरी चार्जर के उपयोग से आपका फोन खराब हो सकता है और वॉरंटी का उल्लंघन हो सकता है.
- चार्जर केवल इनडोर उपयोग के लिए है.

बैटरी चार्जर को सीधे सूर्य के प्रकाश में खुला न ले जाएँ या इसे ज़्यादा नमी वाले स्थानों जैसे बाथरूम में उपयोग न करें.

सावधानियाँ

केवल LG की बैटरियों और चार्जरों का ही उपयोग करें. अन्य निर्माताओं के उत्पादों पर वॉरंटी लागू नहीं होगी.

- संकेत प्राप्त करने वाले उपकरणों (जैसे टीवी या रेडियो) के पास फोन का उपयोग करने पर इसमें अवरोध आ सकता है.
- जब आप फोन का उपयोग नहीं कर रहे हों, तो उसे सुरक्षित स्थान पर रखें.
- केवल अधिकृत व्यक्ति को ही फोन और उसके सहायक उपकरणों की सर्विस करनी चाहिए. गलत मरम्मत या सर्विस के कारण दुर्घटनाएँ हो सकती हैं और परिणामस्वरूप वॉरंटी अमान्य हो जाएगी.
- फोन का उपयोग करते समय एंटीना न पकड़ें.
- केवल LG द्वारा प्रदत्त या मान्य एंटीना का ही उपयोग करें. अनधिकृत एंटीना, परिवर्तन या संलग्नक फोन कॉल्स की गुणवत्ता को प्रभावित कर सकते हैं, फोन को नुकसान पहुँचा सकते हैं या इनसे एफ सी सी नियमों का उल्लंघन हो सकता है. एंटीना क्षतिग्रस्त होने की स्थिति में सेल्युलर फोन का उपयोग न करें. क्षतिग्रस्त एंटीना के त्वचा के संपर्क में आने पर त्वचा थोड़ी जल सकती है. क्षतिग्रस्त एंटीना बदलने के लिए कृपया LG के अधिकृत सर्विस सेंटर से संपर्क करें.
- निषिद्ध स्थानों पर सेल्युलर फोन का उपयोग न करें (उदाहरण के लिए : विमान में).
- सेल्युलर फोन को ऊँचे तापमान या ज़्यादा नमी वाले स्थानों में न ले जाएँ.
- सेल्युलर फोन को पानी के संपर्क में न आने दें. यदि ऐसा होता है, तो इसे तुरंत बंद कर दें और बैटरी निकाल लें. यदि फोन काम नहीं करता है, तो इसे LG के अधिकृत सर्विस सेंटर पर ले जाएँ.
- सेल्युलर फोन को झटके या टक्कर से बचाएँ.

फोन के पुर्जे

निम्न चित्र आपको मोबाइल फोन के मुख्य पुर्जों के बारे में बताता है.

फोन के बारे में

एलसीडी स्क्रीन	संदेश और संकेत चिन्ह प्रदर्शित करती है.
सॉफ्ट बटन (इन बटनों के फंक्शन स्क्रीन के नीचे दिखते हैं)	**सॉफ्ट बटन 1** फंक्शन सेटिंग सूची प्रदर्शित करने के लिए प्रयुक्त . **सॉफ्ट बटन 2** किसी भी सूची में इस बटन को दबाकर एक स्तर पीछे जा सकते हैं.
कॉल बटन	उपयोगकर्ता कॉल कर या ले सकता है
एंड/पावर बटन	पावर बंद/चालू करने और कॉल समाप्त करने के लिए उपयोग किया जाता है. इस बटन से आप मुख्य सूची प्रदर्शन स्क्रीन पर लौट सकते हैं.
अल्फान्यूमेरिक बटन पैड	इससे आप नंबर और अक्षर लिख सकते हैं और सूची आइटम चुन सकते हैं.
नेविगेशन बटन	इस नेविगेशन बटन से आप तुरंत शब्द और वॉइस मेल अधिसूचना संदेश, रिंग स्वर, R वर्ल्ड, प्रोफाइल्स पर पहुँच सकते हैं.
क्लीयर बटन	एक स्थान या अक्षर मिटाने के लिए इसे दबाएँ. पूरे शब्दों को मिटाने के लिए दबाए रखें.
स्पीकर ऑन बटन	स्टैंडबाय मोड में, # SPACE बटन को 2 सेकंड तक दबाए रखकर स्पीकर ऑन मोड सेट करें.
कंपन मोड बटन	स्टैंडबाय मोड में, * बटन को लगभग 2 सेकंड तक दबाए रखने से कंपन मोड सेट हो जाता है.

स्क्रीन पर आने वाले चिन्ह

फोन का पावर चालू होने पर फोन स्क्रीन पर अनेक चिन्ह दिखाई देते हैं.

चिन्ह	वर्णन
	फोन द्वारा प्राप्त संकेत की शक्ति स्क्रीन पर प्रदर्शित करता है और वर्तमान शक्ति स्क्रीन पर दिखने वाली पंक्तियों की संख्या से पता चलती है.
	सर्विस नहीं फोन को किसी सिस्टम से संकेत नहीं मिल रहा है.
	उपयोग में है. कॉल चल रहा है. * कोई संकेत न होना दर्शाता है कि फोन स्टैंडबाय मोड में है.
	दर्शाता है कि कोई शब्द संदेश या वॉइस मेल प्राप्त हुआ है.
	कंपन मोड में.
	अलार्म मोड में.
	चार्ज स्तर बैटरी चार्ज स्तर दर्शाता है. जब बैटरी पूरी तरह चार्ज हो जाती है तो चार्जिंग संकेतक पीले रंग का हो जाता है.

बैटरी और चार्जर का उपयोग

पहली बार फोन का उपयोग करने से पहले पूरी बैटरी चार्ज कर लें.
अधिकतम स्टैंडबाय और टॉक टाइम प्राप्त करने के लिए उपयोग में नहीं होने पर भी बैटरी को पूरी तरह चार्ज रखें.

बैटरी लगाना और निकालना

- बैटरी लगाने के लिए बैटरी को फोन के पिछले हिस्से में खाली जगह में डालें और धीरे से तब तक दबाएँ, जब तक कि लैच अपनी जगह क्लिक न हो जाए.
- इसे निकालने के लिए पिछले हिस्से को नीचे की ओर खींचें. अलग करने के लिए एक हाथ से टैब खींचें और बैटरी के ऊपरी हिस्से को उठाएँ.

बैटरी चार्ज करना

फोन के साथ आए एसी एडाप्टर चार्जर का उपयोग करने के लिए :
1. एसी एडाप्टर को बिजली के प्लग में लगाएँ.
2. एडाप्टर के गोल सिरे को फोन के नीचे स्थित एसी एडाप्टर जैक में लगाएँ. (सुनिश्चित करें कि बैटरी लगी है.)

- जैसे–जैसे फोन चार्ज होता है, बैटरी का चिन्ह खाली ( ) से भरे ( ) होने तक पावर में वृद्धि दिखाता है.

पूरी तरह समाप्त हो चुकी बैटरी को रीचार्ज करने में लगभग तीन घंटे लगते हैं. जब बैटरी पूरी तरह चार्ज हो जाती है तो चार्जिंग संकेतक पीले रंग का हो जाता है.

बैटरी चार्ज स्तर

बैटरी चार्ज एलसीडी स्क्रीन के ऊपर दाईं ओर दिखाई देता है.

जब बैटरी चार्ज स्तर कम हो जाता है, तो कम बैटरी सेंसर आपको तीन प्रकार से चेतावनी देगा : सुनाई देने वाली एक आवाज़ से, बैटरी चिन्ह आउटलाइन टिमटिमा करके और **बैटरी कम होने संबंधी चेतावनी** प्रदर्शित करके! यदि बैटरी चार्ज स्तर बिलकुल कम हो जाता है तो फोन अपने आप बंद हो जाएगा और चल रहा कोई भी फंक्शन सुरक्षित नहीं होगा.

बैटरी की देखभाल

1) यदि आप अनधिकृत बैटरी का उपयोग करते हैं तो इससे बैटरी क्षतिग्रस्त हो सकती है या उसमें विस्फोट हो सकता है. इसलिए, कृपया अनधिकृत बैटरियों का उपयोग न करें.
2) बैटरी को रीचार्ज करने के लिए आपको बैटरी के बिल्कुल निचले स्तर तक पहुँचने का इंतज़ार नहीं करना चाहिए.
3) अपने LG फोन के मॉडल के लिए उपयुक्त बैटरी और चार्जर का ही उपयोग करें. LG के चार्जर बैटरी की आयु बढ़ाते हैं.
4) बैटरी को न तो खोलें और न ही शॉर्ट सर्किट करें.
5) बैटरी के धातु के सिरे साफ रखें.
6) बैटरी ठीक से काम न करे तो उसे बदल दें. बदलने की ज़रूरत पड़ने से पहले बैटरी को सैकड़ों बार चार्ज किया जा सकता है.
7) यदि बैटरी को बहुत समय से उपयोग नहीं किया गया हो तो उसकी आयु बढ़ाने के लिए उसे फिर से चार्ज करें.
8) बैटरी चार्जर को सूर्य की सीधी रोशनी में या बाथरूम जैसी नम जगहों पर न ले जाएँ.
9) बैटरी को गर्म या ठंडी जगह में न छोड़ें, इससे बैटरी की कार्यक्षमता घट सकती है.
10) उपयोग किए जाने के स्थान और तरीके के आधार पर बैटरी की आयु कम या ज़्यादा हो सकती है.
11) लंबी स्क्रीन लाइट सेटिंग्स, सेवाओं की खोज, डेटा कनेक्टिविटी, और सिंक्रनाइज़ेशन बैटरी की आयु, टॉक, और स्टैंडबाय समय को प्रभावित कर सकते हैं.

फोन को बंद और चालू करना

फोन चालू करना

1) कोई चार्ज किया हुआ बैटरी पैक लगाएँ या फोन को सिगरेट लाइटर चार्जर, कार किट या ए सी एडाप्टर से जोड़ें.

2) PWR END बटन को 2 सेकंड तक दबाएँ जब तक कि एलसीडी स्क्रीन चालू न हो जाए.

नोट किसी भी अन्य संचार उपकरण की तरह, फोन के चालू होने पर एंटीना को स्पर्श न करें.

कॉल करना

जब भी आप कॉल करें, तो इन चरणों का पालन करें :

1) सुनिश्चित करें कि फोन चालू है. यदि नहीं है तो PWR END को 2 सेकंड तक दबाए रखें.
2) फोन नंबर लिखें और CALL दबाएँ.

- यदि फोन लॉक है, तो लॉक कोड लिखें (पृष्ठ 57 देखें).

3) कॉल समाप्त करने के लिए PWR END दबाएँ.

नोट यदि आप सर्विस एरिया में नहीं हैं, तो स्क्रीन पर दिखाई देता है. सर्विस एरिया के बाहर से वॉइस कॉल करने पर, 'कॉल पूरा नहीं हो पाया है. कृपया फिर से प्रयास करें' स्क्रीन पर आता है. इसका अर्थ यह है कि आप सर्विस एरिया में नहीं हैं.

कॉल प्राप्त करना

1) जब फोन की घंटी बजे या कंपन हो (यदि कंपन मोड चालू है), तो उत्तर देने के लिए (PWR END को छोड़कर) या कॉल सेटिंग्स के आधार पर CALL दबाएँ.

- कॉल प्राप्त करते समय जब आप PWR END को एक बार दबाते हैं, तो मोड के अनुसार घंटी या कंपन बंद हो जाता है. संपर्क तोड़ने के लिए, PWR END को दो बार दबाएँ.

2) उत्तर दिए गए कॉल को समाप्त करने के लिए, PWR END दबाएँ.

संकेत की शक्ति

एंटीना पूरी तरह खुला होने पर कॉल को अच्छी तरह सुना जा सकता है. यदि आप किसी इमारत के अंदर हैं तो खिड़की के पास रहने पर आपको बेहतर रिसेप्शन मिल सकता है. आप अपने फोन के प्रदर्शन स्क्रीन पर संकेत संकेतक ( ) से संकेत की शक्ति देख सकते हैं.

एंटीना के बारे में

आपके फोन में बिल्ट-इन एंटीना है. किसी भी रेडियो संचार उपकरण की तरह ही जब फोन चालू हो तो एंटीना को अनावश्यक स्पर्श न करें.
एंटीना को स्पर्श करने से कॉल की गुणवत्ता प्रभावित होती है और इससे फोन को आवश्यकता से अधिक पावर पर काम करना पड़ सकता है.
कॉल के दौरान एंटीना न छूने से आपके फोन के एंटीना की कार्य क्षमता व टॉक टाइम में बढ़ोत्तरी होती है. सामान्यत: किसी अन्य फोन की तरह ही फोन को पकड़ें.

त्वरित समायोजन

कंपन मोड समायोजित करना

किसी सार्वजनिक स्थान पर कंपन मोड का उपयोग करें.

1) स्टैंडबाय मोड में, सूची फंक्शन का उपयोग करने के बजाय * दबाकर (2 सेकंड तक) आप तुरंत कंपन मोड सक्रिय कर सकते हैं.

- कंपन मोड के सक्रिय होने पर बटन स्वर की आवाज़ नहीं आती है.

नोट कंपन मोड से बाहर निकलने के लिए, * को 2 सेकंड तक दबाएँ.

प्रोफाइल चुनें

1. स्टैंडबाय मोड में, दबाएँ.
2. चार प्रोफाइल्स- **सिर्फ कंपन**, **Silent**, **General** और **Outdoor** -में से एक चुनने के लिए दबाएँ.
3. सॉफ्ट बटन 1 **चुनें** दबाएँ.

स्पीकर ऑन समायोजित करना

1) स्टैंडबाय मोड में, # SPACE को 2 सेकंड तक दबाकर स्पीकर ऑन सक्रिय करें.

नोट स्पीकर ऑन रद्द करने के लिए, # SPACE को 2 सेकंड तक दबाए रखें.

बटन पैड लॉक

यह फंक्शन सेट होने पर भूल से कोई नंबर डायल होने का डर नहीं रहता.

जब यह फंक्शन सक्रिय होता है, तो कोई कॉल नहीं किया जा सकता है और सूची लॉक हो जाएगी. बटन पैड के लॉक होने पर कॉल का उत्तर दिया जा सकता है.

फंक्शन को सक्रिय करने के लिए:

1) 0 बटन को दो सेकंड तक दबाएँ.

फंक्शन को निष्क्रिय करने के लिए :

1) 0 बटन को दो सेकंड तक दबाए रखें.

कॉल प्रतीक्षा

आपकी सेल्युलर सेवा कॉल प्रतीक्षा की सुविधा उपलब्ध करवा सकती है. जब कोई कॉल चल रहा हो तो आपको आने वाली दूसरी कॉल का संकेत करने वाली दो बीप सुनाई पड़ सकती हैं. कॉल प्रतीक्षा के सक्रिय होने पर, चल रहे कॉल को होल्ड पर रखकर आप आने वाली दूसरी कॉल का उत्तर दे सकते हैं. इस सुविधा के बारे में **अपने सेवा प्रदाता** से जानकारी लें.

1) प्रतीक्षित कॉल प्राप्त करने के लिए CALL दबाएँ.
2) कॉल्स के बीच स्विच करने के लिए फिर से CALL दबाएँ.

मौन

मौन फंक्शन सक्रिय होने पर दूसरा व्यक्ति आपकी आवाज़ नहीं सुन सकता, लेकिन आप उसकी आवाज़ सुन सकते हैं.

1) कॉल करते समय सॉफ्ट बटन 1 **सूची** और 2 दबाएँ.
2) मौन रद्द करने के लिए, सॉफ्ट बटन 1 **सूची** और 2 फिर से दबाएँ.

कॉल रीडायल करना

1) कॉल विवरण का पिछला कॉल फिर से डायल करने के लिए दो बार CALL स्विच दबाएँ.

- आप कॉल विवरण के पिछले संग्रहीत 60 कॉल्स में से भी कोई नंबर डायल कर सकते हैं. (पृष्ठ 45 –47 पर कॉल विवरण सूची देखें)

शीघ्र डायलिंग

यह एक सुविधाजनक विकल्प है जिससे आप तुरंत और आसानी से कॉल कर सकते हैं. आपका फोन आपकी व्यक्तिगत डायरेक्टरी से फोन नंबर लाकर कुछ समय के लिए उसे दिखाता है और फिर उसे डायल करता है. सबसे ज़्यादा डायल किए जाने वाले नंबरों के एक स्पर्श डायल के लिए आप मेमोरी स्थान 1 से 9 का उपयोग कर सकते हैं.

1) मेमोरी स्थान 1 से 9 में से कोई एक लिखें.
2) CALL दबाएँ.

10 से 99 तक शीघ्र डायल करना

पहला अंक दबाएँ और फिर अंतिम अंक का बटन दबाए रखें

या

पहला और दूसरा अंक दबाएँ और CALL दबाएँ.

कॉलर आईडी

कॉलर आईडी से आपके फोन की घंटी बजने पर कॉल करने वाले व्यक्ति का नंबर दिखाई देता है. यदि कॉलर का नाम और नंबर आपके फोन बुक में पहले से दर्ज है तो नंबर के साथ नाम भी दिखाई देता है. आपको **अपने सेवा प्रदाता** से पता कर लेना चाहिए कि वे यह सुविधा प्रदान करते हैं या नहीं.

T9 टेक्स्ट इनपुट मोड से जानकारी लिखना

आप T9 टेक्स्ट इनपुट से बैनर, टाइम मैनेजर, संक्षिप्त संदेश और फोन बुक संपादित कर सकते हैं.
T9 शब्द लिखने का एक आसान तरीका है. इस इनपुट पद्धति में आपको प्रत्येक अक्षर के लिए बटन को सिर्फ एक बार दबाना पड़ता है.

बटनों के कार्य

सॉफ्ट बटन 2 : स्क्रॉल करने और सूचियों में से एक मोड चुनने के लिए दबाएँ.

– आप सॉफ्ट बटन 2 का उपयोग करते हुए मोड्स में निम्न क्रम में स्क्रॉल कर सकते हैं: T9En, Abc, 123, चिन्ह, स्माईलीस, हिन्दी.
– शिफ्ट बटन * : अक्षर का केस बदलने के लिए उपयोग किया जाता है.

2 ~ 9 (शब्द लिखें): T9 मोड में, पाठ लिखने के लिए प्रति अक्षर एक बटन दबाएँ.

0 ~ 9 (अंक लिखें): 123 (अंक) मोड में, अंक लिखने के लिए एक बार दबाएँ.

0 (अगला) : T9 मोड में, अन्य मेल खाते शब्द प्रदर्शित करने के लिए दबाएँ.

1 (विराम चिन्ह): T9 मोड में, किसी शब्द में विराम चिन्ह लिखने और वाक्य पूरा करने के लिए दबाएँ.

(स्थान): शब्द पूरा करने या स्थान शामिल करने के लिए दबाएँ.

CLR (क्लीयर): एक स्थान या अक्षर मिटाने के लिए दबाएँ. सभी शब्द मिटाने के लिए दबाए रखें.

इनपुट मोड

T9 टेक्स्ट इनपुट में शब्द, अंक, विशेष अक्षर और विराम चिन्ह लिखने के लिए पाँच मोड उपलब्ध हैं.

T9En (T9) मोड

प्रत्येक वर्ण के लिए एक बार बटन दबाकर शब्द लिखें. T9 मोड डिफॉल्ट है.

ABC (मल्टी–टैप) मोड

T9 डेटाबेस में शब्द जोड़ने के लिए ABC मोड का उपयोग करें.

123 (अंक) मोड

प्रत्येक अंक के लिए एक बार बटन दबाकर अंक लिखें.
किसी शब्द प्रविष्टि फील्ड में 123 मोड बदलने के लिए, 123 मोड के प्रदर्शित होने तक सॉफ्ट बटन 2 दबाएँ.

चिन्ह/स्माईलीस मोड

विशेष अक्षर, विराम चिन्ह या स्माईलीस शामिल करें. आप किसी भी विशेष अक्षर का उपयोग कर सकते हैं. उस जगह कर्सर आ जाने पर जहाँ आप विशेष अक्षर चाहते हैं, प्रतीक/स्माईलीस मोड में जाएँ. इच्छित अक्षर देखने के लिए नेविगेशन बटन ◀▶ दबाएँ : अक्षर चुनने के लिए, निर्धारित अंक बटन दबाएँ.

प्रारंभिक बड़ा (T9En/Abc)

सिर्फ पहला अक्षर बड़ा होता है.

बड़ा अक्षर लॉक (T9EN/ABC)

बाद के सभी अक्षर बड़े हो जाते हैं.

छोटा केस (T9en/abc)

बाद के सभी अक्षर छोटे होते हैं.

T9 टेक्स्ट इनपुट उपयोग के उदाहरण

T9 मोड में लिखना

जब आप T9 मोड का उपयोग करना चाहें, तो जाँच लें कि T9En नीचे दिखाई दे रहा है. इच्छित शब्द लिखने के लिए प्रत्येक अक्षर के लिए प्रत्येक बटन को एक बार दबाएँ.

उदाहरण के लिए 'Call the office' इस तरह लिखें :

1. अक्षर केस को T9En मोड में बदलने के लिए सॉफ्ट बटन 2 दबाएँ.
2. 2 2 5 5 दबाएँ.
3. शब्द पूरा करने और एक स्थान जोड़ने के लिए # दबाएँ.
4. 8 4 3 # 6 3 3 4 2 3 दबाएँ.
5. 'Call the office' दिखाई देगा.

जैसा कि आप देख सकते हैं, हर बार बटन दबाने पर शब्द बदल जाते हैं. इसलिए पूरा शब्द लिखने तक स्क्रीन पर क्या हो रहा है, इस पर आपको ज्यादा ध्यान देने की आवश्यकता नहीं है.

अगले बटन का उपयोग

एक शब्द लिखने के बाद, यदि सही शब्द दिखाई नहीं देता है, तो अतिरिक्त विकल्प देखने के लिए, 0 दबाएँ.
उदाहरण के लिए, निम्न चरणों का पालन करें:

1. 4 6 6 3 दबाएँ.
2. प्रदर्शन : Good
3. 0 दबाएँ.
4. प्रदर्शन : Home, Gone, Hood...

T9 डेटाबेस में शब्द जोड़ना

यदि कोई शब्द T9 डेटाबेस में नहीं है तो इसे **Abc (मल्टी–टैप) मोड** शब्द प्रविष्टि से रिकॉर्ड में जोड़ें. जब आप T9 मोड में लौटेंगे, तब T9 डेटाबेस में वह शब्द अपने आप जुड़ जाएगा.

उदाहरण के लिए इन चरणों का पालन करें :

1. अक्षर केस को Abc (मल्टी–टैप) मोड में बदलने के लिए सॉफ्ट बटन 2 दबाएँ.
2. 4 4 4 6 8 दबाएँ.
3. प्रदर्शन : Imt
4. अक्षर केस को T9 मोड में बदलने के लिए सॉफ्ट बटन 2 दबाएँ और फिर शब्द Imt, T9 डेटाबेस में जुड़ जाएगा.
5. मौजूदा शब्द मिटाने के लिए CLR दबाएँ.
6. 4 6 8 दबाएँ.
7. प्रदर्शन : Got
8. 0 0 दबाएँ.
9. प्रदर्शन : Imt

ABC (मल्टी–टैप) टेक्स्ट इनपुट उपयोग के उदाहरण

ABC (मल्टी–टैप) मोड में लिखना

उदाहरण के लिए LG लिखने के लिए, इन चरणों का पालन करें:

1. अक्षर केस को ABC मोड में बदलने के लिए सॉफ्ट बटन 2 दबाएँ.
2. ABC बड़ा अक्षर लॉक मोड को बदलने के लिए शिफ्ट बटन * दबाएँ.
3. दबाएँ : 5 5 5 4 .
4. प्रदर्शन : LG

हिन्दी प्रविष्टि के लिए बटन मैपिंग

हिन्दी में 13 स्वर, 36 व्यंजन और 10 मात्राएँ होती हैं.

बटनों की मैपिंग इस प्रकार है:

0 NEXT उपयोगकर्ता डेटाबेस शब्दों का चयन.

1 @ अ अ इ ई उ ऊ ऋ ए ऐ ओ औ ऑ

A Aa I Ii U Uu R E Ai O Au Awe

2 ABC क क ख ग घ ङ

Ka Kha Ga Gha Nga

3 DEF च च छ ज झ ञ

Cha Chha Ja Jha Nya

4 GHI ट ट ठ ड ढ ण

Tta Ttha Dda Ddha Nna

5 JKL त त थ द ध न

Ta Tha Da Dha Na

6 MNO प प फ ब भ म

Pa Pha Ba Bha Ma

7 PQRS य य र ल व श ष स ह

Ya Ra La Va Sha Sha Sa Ha

8 TUV क्ष क्ष त्र ज्ञ

Ksha Tra Gya

9 WXYZ ा ि ी ु ू े ै ो ौ ं ः ँ ् ृ

Aa I Ee U Uu E Ai O Au An Ah Ch Bindu Ch E Ch O Ri

हलंत (आधा अक्षर) भी 9 WXYZ में जोड़ा गया है.

हिन्दी मोड में संपादन

सॉफ्ट बटन 2 को तब तक दबाए रखें, जब तक कि सॉफ्ट सूची हिन्दी मोड में न बदल जाए.

हिन्दी मोड संपादन

हिन्दी एक बहु-टैप मोड है.

उदारण के लिए, **''हिन्दी''** लिखने के लिए

1. 9 WXYZ 2 बार दबाएँ.
2. 7 PQRS 8 बार दबाएँ.
3. 5 JKL 5 बार दबाएँ.
4. 9 WXYZ 16 बार दबाएँ.
5. 5 JKL 3 बार दबाएँ.
6. 9 WXYZ 3 बार दबाएँ.

बाइट का वितरण :

संदेशों में : हिन्दी में प्रत्येक वर्ण में 3 बाइट्स होते हैं, जबकि 'क्ष', 'त्र', 'ज्ञ' में 9 बाइट्स होते है.

अन्य सभी मॉड्यूल्स में : हिन्दी में प्रत्येक वर्ण के लिए 1 बाइट होता है, जबकि 'क्ष', 'त्र', 'ज्ञ' के लिए 3 बाइट्स होते हैं.

यूडीबी : (हिन्दी शब्दकोश)

संदेश : संदेशों में लिखा गया प्रत्येक शब्द हिन्दी शब्दकोश में अपने आप संग्रहीत हो जाएगा. शब्दकोश में लगभग 100 शब्द संग्रहीत किए जा सकते हैं. 101वाँ शब्द अंतिम शब्द की जगह ले लेगा. इसलिए एफआईएफओ फॉर्मेट का प्रयोग किया जाता है.

हिन्दी यूडीबी में कोई शब्द संग्रहीत करने के लिए

पहले बताए अनुसार **''हिन्दी''** शब्द दबाएँ.
स्थान दबाएँ. शब्द संग्रहीत हो जाता है.

शब्द पुनर्प्राप्त करने के लिए :

शब्द का पहला अक्षर दबाएँ, उदाहरण के लिए 9 दो बार दबाएँ.
यूडीबी स्थान में शब्द ''हिन्दी'' दिखाई देता है.
यदि एक ही अक्षर से कई शब्द प्रारंभ होते हैं, तो 0 बटन का उपयोग करके आवश्यक शब्द चुना जा सकता है.
आवश्यक शब्द चुने जाने के बाद, * दबाएँ. संपादक में शब्द जुड़ जाएगा.

अध्याय 3 फोन बुक

फोन बुक की सुविधाएँ

अपने फोन बुक में आप आसान पहुँच के लिए सबसे ज़्यादा डायल किए जाने वाले 300 (4 नंबर + 1 ईमेल आई डी + 1 मेमो) फोन नंबर रख सकते हैं.

व्यक्तिगत फोन बुक मेमोरी

फोन में 300 फोन नंबर सुरक्षित रखने के लिए जगह है जहाँ आप 32 अंकों वाले 4 फोन नंबर तक रख सकते हैं.

आपके व्यक्तिगत फोन बुक में नंबर सुरक्षित करना

1. सॉफ्ट बटन 1 **सूची** दबाएँ.
2. 1 **नाम** चुनें.
3. 1 **नाम जोड़ें** चुनें.
4. फोन नंबर जोड़ें.
5. से विंडो चुनें.
6. से अपना इच्छित लेबल प्रकार जैसे **घर, ऑफिस, मोबाइल, अन्य** चुनें.
7. सॉफ्ट बटन 1 **चुनें** दबाएँ.
8. फोन नंबर के लिए नाम दर्ज करें (16 अक्षरों तक). सॉफ्ट बटन 1 **सुरक्षित** दबाएँ.
9. से **घर/ऑफिस/मोबाइल/अन्य** चुनने के बाद, नंबर बटन से फोन नंबर दर्ज करें.

10. **शीघ्र डायल** देने के लिए, सॉफ्ट बटन 1 **विकल्प** दबाएँ और **शीघ्र डायल** चुनें. नंबर बटन से, **शीघ्र डायल करें** या से कोई इच्छित **शीघ्र डायल** चुनें. सॉफ्ट बटन 1 **विकल्प** से निर्धारित चुनें. संग्रहीत शीघ्र डायल चुना जाने पर, **बदलें** दिखाई देता है.
11. दबाकर **ई–मेल** चुनने के बाद, बटन पैड का उपयोग करके ई–मेल पता लिखें.
12. ई–मेल पता लिखने के बाद, सॉफ्ट बटन 1 **विकल्प** दबाकर **सुरक्षित** चुनें. **डोमेन्स** चुनें और ई–मेल पता लिखें.
13. दबाकर **कोई ग्रुप नहीं** चुनने के बाद, से इच्छित ग्रुप चुनें.
14. से **मेमो** चुनने के बाद, सॉफ्ट बटन 1 विकल्प दबाकर संपादन चुनें. मेमो लिखने के बाद, सॉफ्ट बटन 1 **सुरक्षित** दबाएँ.
15. दबाकर रिंग स्वर चुनने के बाद, से इच्छित रिंग स्वर चुनें.
16. दबाकर **सीक्रेट ऑफ** चुनने के बाद, से **सीक्रेट ऑफ/सीक्रेट ऑन** चुनें. जब **सीक्रेट ऑन** सेट हो, तो आपको इसे देखने के लिए पासवर्ड देना चाहिए.
17. सॉफ्ट बटन 1 **सुरक्षित** दबाएँ.

नाम खोजें

नाम से कोई फोन नंबर खोजने के लिए.

1. सॉफ्ट बटन 2 **खोजें** दबाएँ.
2. **फोन बुक** में सुरक्षित नाम वर्ण के प्रकार, कैपिटल या स्मॉल पर ध्यान दिए बगैर वर्णमाला के क्रम में दिखाई देंगे.
   इच्छित फोन नंबर देखने के लिए, का उपयोग करके फोन नंबर तक जाकर सॉफ्ट बटन 1 **विकल्प** दबाएँ और **देखें** चुनें.

नंबर से खोजें

फोन बुक में आपके द्वारा संग्रहीत फोन नंबर खोजने के लिए.

1. सॉफ्ट बटन 2 **खोजें** दबाएँ.
2. सॉफ्ट बटन 1 **विकल्प** दबाएँ और **नंबर खोजें** चुनें.
3. प्रदर्शन आपको स्क्रीन पर नंबर डालने की सूचना देगा.

ग्रुप खोजें

ग्रुप से कोई फोन नंबर खोजने के लिए.

1. सॉफ्ट बटन 2 **खोजें** दबाएँ.
2. सॉफ्ट बटन 1 **विकल्प** दबाएँ और **ग्रुप खोजें** चुनें.
3. से ग्रुप चुनें.

फोन बुक में संग्रहीत जानकारी बदलना

1. सॉफ्ट बटन 2 **खोजें** दबाएँ.
2. आप खोज स्ट्रिंग लिखकर सही समय में फोन बुक में सुरक्षित फोन नंबर देख सकते हैं.
   यदि आप का उपयोग करके इच्छित नाम तक जाते हैं और सॉफ्ट बटन 1 **विकल्प** दबाते हैं और देखें चुनते हैं तो आप **फोन बुक** सूची **देख** सकते हैं.
   प्रविष्टि मिटाने या संपादित करने के लिए, सॉफ्ट बटन 1 **विकल्प** दबाएँ.
   का उपयोग करके डेटा स्क्रॉल करने के बाद **संपादन** चुनें.

विकल्पों के साथ एक उपसूची स्क्रीन पर दिखाई देगी:

संपादन :	उस मेमोरी स्थान पर जानकारी संपादित करता है.
संदेश भेजें :	संदेश भेजता है.
मेरा संपर्क भेजें :	उस मेमोरी स्थान में जानकारी भेजता है.
मिटाएँ :	उस मेमोरी स्थान में मौजूद सभी जानकारी मिटाता है.

फोन बुक से कॉल करना

आप शीघ्र डायल का उपयोग करके या फोन नंबर लिखकर CALL दबाकर किसी भी मेमोरी स्थान से कॉल कर सकते हैं.

एक स्पर्श शीघ्र डायलिंग : इस सुविधा से आप सबसे ज़्यादा कॉल किए जाने वाले नौ नंबर अपनी शीघ्र डायल मेमोरी स्थान (1 से 9) में संग्रहीत कर सकते हैं.

- स्थान 1 से 9 के लिए, आप डायल किए जाने वाले मेमोरी स्थान से संबंधित बटन को दबाए रखते हुए एक स्पर्श डायल कर सकते हैं.

  या

- एक अंक दबाएँ, और फिर CALL दबाएँ.

दो स्पर्श शीघ्र डायलिंग : इस सुविधा से आप दो नंबर दबाकर (10 से 99 स्थानों के लिए) शीघ्र डायल कर सकते हैं.

1. पहला अंक दबाएँ.
2. दूसरे अंक वाला बटन दबाए रखें.

   या

1. पहला और दूसरा अंक दबाएँ, और फिर CALL दबाएँ.

नोट: शीघ्र डायलिंग करने के लिए, पहले आपको फोन बुक से एक नंबर शीघ्र डायल स्थान के लिए निर्धारित करना होगा.

मेमोरी सूची से डायल करना

1. खोजें चुनें, इच्छित मेमोरी स्थान पर जाने के लिए स्क्रॉल बटन दबाएँ.
2. CALL दबाएँ.

किसी मेमोरी स्थान से डायल करना

कोई मेमोरी स्थान देखते समय, कॉल करने के लिए CALL दबाएँ.

सूची तक पहुँचने और सेटिंग्स के सामान्य दिशानिर्देश

1. सॉफ्ट बटन 1 **सूची** दबाएँ. प्रदर्शन स्क्रीन पर आठ सूची आइटम दिखाई देंगे.
2. सूची सुविधाओं की सूची देखने के लिए ⟐ दबाएँ.
3. जो सूची आइटम आप चुनना चाहते हैं, उससे संबंधित अंक दबाएँ. तब स्क्रीन पर उपसूची दिखाई देगी.
4. इच्छित उपसूची तक पहुँचने के लिए उपयुक्त बटन दबाएँ.
5. ⟐ का उपयोग करके पसंदीदा सेटिंग्स चुनें. सूची तक पहुँचते या सेटिंग्स चुनते समय एक स्तर पीछे जाने के लिए सॉफ्ट बटन 2 **वापस** दबाएँ.
6. सेटिंग्स सुरक्षित करने के लिए सॉफ्ट बटन 1 **ओके** दबाएँ या बिना सुरक्षित किए रद्द करने के लिए सॉफ्ट बटन 2 **वापस** दबाएँ.

नाम (सूची 1@अ)

व्यक्तिगत फोन बुक मेमोरी

फोन में 300 फोन नंबर सुरक्षित रखने के लिए जगह है जहाँ आप 32 अंकों वाले 4 फोन नंबर तक रख सकते हैं.

नाम जोड़ें (सूची 1@अ 1@अ)

आप 300 प्रविष्टियों तक फोन नंबर, मोबाइल नंबर और इसी प्रकार अन्य सुरक्षित कर सकते हैं.

1. सॉफ्ट बटन 1 **सूची** दबाएँ.
2. 1@अ **नाम** चुनें.
3. 1@अ **नाम जोड़ें** चुनें.
4. फोन नंबर लिखें.
5. ⌄ से लेबल विंडो चुनें.
6. ⟐ से इच्छित लेबल प्रकार चुनें, जैसे **घर, ऑफिस, मोबाइल, अन्य**.
7. सॉफ्ट बटन 1 **चुनें** दबाएँ.
8. फोन नंबर के लिए कोई नाम लिखें (16 वर्णों तक). सॉफ्ट बटन 1 **सुरक्षित** दबाएँ.
9. और नंबर सुरक्षित करने के लिए, ⟐ से **घर/ऑफिस/मोबाइल/अन्य** चुनने के बाद, अंक बटन से फोन नंबर लिखें.
10. **शीघ्र डायल** देने के लिए, सॉफ्ट बटन 1 **विकल्प** दबाएँ और **शीघ्र डायल** चुनें. अंक बटन से, **शीघ्र डायल** लिखें या ⟐ से कोई इच्छित **शीघ्र डायल** चुनें. सॉफ्ट बटन 1 **विकल्प** से **निर्धारित** चुनें. संग्रहीत शीघ्र डायल चुना जाने पर, **बदलें** दिखाई देता है.
11. ⌄ दबाकर **ई–मेल** चुनने के बाद, सॉफ्ट बटन 1 **विकल्प** दबाकर **संपादन** चुनें.
12. ई–मेल पता लिखने के बाद, सॉफ्ट बटन 1 **विकल्प** दबाकर **सुरक्षित** चुनें. **डोमेन्स** चुनें और ई–मेल पता लिखें.
13. ⌄ दबाकर **कोई ग्रुप नहीं** चुनने के बाद, ⟐ का उपयोग करके इच्छित ग्रुप चुनें
14. ⌄ से **मेमो** चुनने के बाद सॉफ्ट बटन 1 **विकल्प** दबाकर **संपादन** चुनें. मेमो लिखने के बाद सॉफ्ट बटन 1 **सुरक्षित** दबाएँ.

15. दबाकर रिंग स्वर चुनने के बाद, का उपयोग करके इच्छित रिंग स्वर चुनें.
16. दबाकर **सीक्रेट ऑफ** चुनने के बाद, से **सीक्रेट ऑफ/सीक्रेट ऑन** चुनें. जब **सीक्रेट ऑन** सेट हो, तो आपको इसे देखने के लिए पासवर्ड देना चाहिए.
17. सॉफ्ट बटन 1 **सुरक्षित** दबाएँ.

खोजें (सूची 1@अ 2ABC आ या सॉफ्ट बटन 2 खोजें)

फोन बुक में संग्रहीत फोन नंबर खोजने के लिए.

1. सॉफ्ट बटन 1 **सूची** दबाएँ.
2. 1@अ **नाम** चुनें.
3. 2ABC आ **खोजें** चुनें.
4. **फोन बुक** में सुरक्षित नाम वर्ण के प्रकार, कैपिटल या स्मॉल पर ध्यान दिए बगैर वर्णमाला के क्रम में दिखाई देंगे.
   इच्छित फोन नंबर देखने के लिए, का उपयोग करके फोन नंबर तक जाकर सॉफ्ट बटन 1 **विकल्प** दबाएँ और **देखें** चुनें.

ग्रुप (सूची 1@अ 3DEF द)

यह फंक्शन ग्रुप का नाम बदलने और ग्रुप के लिए रिंग स्वर सेट करने के लिए है.

1. सॉफ्ट बटन 1 **सूची** दबाएँ.
2. 1@अ **नाम** चुनें.
3. 3DEF द **ग्रुप** चुनें.
4. का उपयोग करके इच्छित ग्रुप चुनें.

5. सॉफ्ट बटन 1 **विकल्प** दबाएँ.

सदस्य देखें :	ग्रुप में सुरक्षित सदस्यों के नाम देखें.
रिंग स्वर सेट करें :	ग्रुप रिंग स्वर सेट करें.
शीर्षक संपादन :	ग्रुप का नाम संपादित करें.

नोट : **कोई ग्रुप नहीं** का शीर्षक नहीं बदला जा सकता.

शीघ्र डायल (सूची 1@अ 4GHI ट)

शीघ्र डायल से आप केवल एक संबंधित अंक दबाकर शीघ्रता से कॉल कर सकते हैं.

1. सॉफ्ट बटन 1 **सूची** दबाएँ.
2. 1@अ **नाम** चुनें.
3. 4GHI ट **शीघ्र डायल** चुनें.
4. रजिस्टर करने के लिए, सॉफ्ट बटन 1 **विकल्प** का उपयोग करें और इच्छित जानकारी खोजने के लिए **निर्धारित** चुनें, फिर सॉफ्ट बटन 1 **विकल्प** दबाएँ और **निर्धारित** चुनें.

नोट : मिटाने के लिए, सॉफ्ट बटन 1 **विकल्प** दबाएँ और **मिटाएँ** चुनें, फिर सॉफ्ट बटन 1 **चुनें** दबाएँ.
सभी संग्रहीत शीघ्र डायल मिटाने के लिए **सब मिटाएँ** चुनें.
किसी विशेष स्थान के लिए निर्धारित अंक बदलने के लिए **बदलें** चुनें.
शीघ्र डायल 01 से 99 तक है.

सहायता (सूची 1@अ 5JKL त)

आप इस सूची के बारे में अधिक जानकारी प्राप्त कर सकते हैं.

संदेश (सूची 2 या)

आपके पावर चालू करते ही शब्द संदेश, पृष्ठ और वॉइस मेलबॉक्स उपलब्ध हो जाते हैं. आप उपरोक्त प्रकार के संदेशों तक संदेश बटन का उपयोग करके पहुँच सकते हैं.

इसके अलावा, आप संदेश देखते समय CALL दबाकर उस नंबर पर कॉल कर सकते हैं.

फोन में 31 संदेश (एक वॉइस संदेश : 30 शब्द संदेश) संग्रहीत हो सकते हैं जिसमें प्रत्येक संदेश में 140 वर्ण हो सकते हैं. हिन्दी में प्रत्येक अक्षर को तीन वर्ण माना जाता है (हालाँकि, क्ष, त्र, ज्ञ में से प्रत्येक को 9 वर्ण का माना जाता है.)

इसलिए, हिन्दी के किसी SMS संदेश में केवल 46 वर्ण तक हो सकते हैं.

उपयोगकर्ता भेजते समय, भेजे गए में सुरक्षित संदेश पढ़ और संपादित कर सकते हैं, और उन्हें भेज सकते हैं.

हालाँकि आपको यह देखना चाहिए कि आपका सेवा प्रदाता उपरोक्त सुविधाएँ प्रदान करता है या नहीं.

अक्षर सीमा : LG –RD5130 प्रति संदेश 140 अक्षर लेता है. प्रति संदेश उपलब्ध बाइट्स की सीमा भी हो सकती है; कृपया सिस्टम क्षमताओं के लिए **अपने सेवा प्रदाता** से संपर्क करें.

संदेश में संग्रहीत जानकारी फोन मोड और सेवा क्षमता द्वारा निर्धारित की जाती है. आप संदेश बटन दबाकर संदेश प्रकार देख सकते हैं.

लिखें (सूची 2 1)

शब्द संदेश और पृष्ठ संदेश सभी उपलब्ध हैं.

शब्द संदेश : शब्द भेजता है.

पृष्ठ संदेश : बिना शब्द संदेश के केवल अंक.

संदेश भेजने के लिए **विकल्प** में **भेजें** दबाएँ.

कोई **संदेश** भेजने के लिए **को भेजें** स्क्रीन में गंतव्य मोबाइल नंबर लिखें.

सूची

इसमें तीन वैकल्पिक सूचियाँ **भेजें**, **सुरक्षित** और **टेम्प्लेट्स** होती हैं.

1. सॉफ्ट बटन 1 **सूची**, 2 या दबाएँ.
2. 1 **लिखें** चुनें.
3. **भेजें** चुनकर भेजा जाने वाला संदेश लिखने के बाद, सॉफ्ट बटन 1 **विकल्प** दबाएँ.
   - ▶ **भेजें** संदेश भेजने के लिए उपयोग करें.
   - ▶ **सुरक्षित** ड्राफ्ट संदेश में सुरक्षित करें.
   - ▶ **टेम्प्लेट्स** कोई नमूने का संदेश चुनें.
4. गंतव्य फोन नंबर लिखने के बाद, दबाकर अगले प्राप्तकर्ता का पता लिखें. आप 10 प्राप्तकर्ता तक जोड़ सकते हैं. सॉफ्ट बटन 1 **विकल्प** दबाएँ.
   - ▶ **भेजें** संदेश भेजने के लिए उपयोग करें.
   - ▶ **प्राथमिकता** आप संदेश को प्राथमिकता दे सकते हैं. सामान्य या अति आवश्यक.
   - ▶ **भेज दिया गया** भेजे गए संदेश के दूसरे पक्ष के फोन पर प्राप्त होते समय इस फंक्शन से आप

पता कर सकते हैं कि आपका संदेश दूसरे पक्ष को सफलतापूर्वक भेज दिया गया है या नहीं. यदि आप यह फंक्शन सक्रिय करना चाहते हैं, तो ऑन सेट करें.

- **विलंबित** आपको सेट की गई समय सीमा तक संदेश भेजना विलंबित करने की सुविधा देता है.
- **वैधता** कुछ समय तक गंतव्य पते को संदेश न भेजे जाने पर संक्षिप्त संदेश केन्द्र (SMC) पर संदेश भेजने की वैधता दिखाता है. ये संदेश सेट की गई समय सीमा में मिटा दिए जाएँगे. वैधता समय सीमाएँ निम्न प्रकार हैं: **पूर्व नियत**, 30 मिनट, 1 घंटा, 2 घंटे, 12 घंटे, 1 दिन और 2 दिन.
- **भेजे गए सुरक्षित** आप यह संदेश आउटबॉक्स में सुरक्षित कर सकते हैं.

5. यदि आप **भेजें** चुनते हैं, तो यह आपको दिखाता है कि संदेश सफलतापूर्वक भेज दिया गया है या नहीं.

इनबॉक्स (सूची 2 2)

प्राप्त संदेश, पृष्ठ संदेश, भेज दिया गया, R वर्ल्ड संदेश, सूचियाँ खोजी जा सकती हैं और सामग्री देखी जा सकती है. प्राप्त संदेश अति आवश्यक संदेश, अपठित संदेश और पढ़े हुए संदेशों के क्रम में संक्षिप्त किए जा सकते हैं. 30 संदेशों तक संग्रहीत किए जा सकते हैं. प्राप्त संदेशों की सूची देखने के लिए.

1. सॉफ्ट बटन 1 **सूची**, 2 या दबाएँ.
2. 2 **इनबॉक्स** चुनें.
   - संदेश **नहीं पढ़े हुए/पढ़े** के क्रम में सुरक्षित किए जाते हैं. उदाहरण के लिए, यदि कोई नया संदेश पढ़ लिया जाता है तो यह पढ़े संदेशों में चला जाता है.

   : नहीं पढ़े हुए

   : पढ़े

   : R वर्ल्ड संदेश
3. के साथ इच्छित संदेश चुनने के बाद, सॉफ्ट बटन 1 **विकल्प** दबाएँ और **देखें** चुनें.
   - **देखें** आप चुना हुआ संदेश पढ़ सकते हैं.
   - **मिटाएँ** इनबॉक्स से चयनित संदेश हटाएँ.
   - **जवाब** इस फंक्शन से आप संदेश का जवाब दे सकते हैं.
4. संदेश देखने के बाद सॉफ्ट बटन 1 **विकल्प** दबाएँ.

- **जवाब** इस फंक्शन से आप इस संदेश का उत्तर दे सकते हैं.
- **फॉरवर्ड** किसी प्राप्त संदेश को दूसरों को फॉरवर्ड करता है. प्राप्तकर्ता लिखे जाने के बाद संदेश फॉरवर्ड किए जा सकते हैं.
- **संग्रह में डालें** चयनित संदेश को इनबॉक्स से संग्रह में ले जाता है.
- **मिटाएँ** इनबॉक्स से चयनित संदेश मिटाता है.
- **नंबर सुरक्षित** संदेश प्रेषक के नंबर को आपकी फोन बुक में सुरक्षित करता है. जब प्राप्त नंबर जानकारी प्रदर्शित की जाती है, तो उपयोगकर्ता फोन बुक में संबंधित नंबर सूची में नंबर संग्रहीत कर सकता है.

आउटबॉक्स (सूची 2 3)

आउटबॉक्स में भेजे गए 15 और न भेजे गए 15 संदेश तक संग्रहीत किए जा सकते हैं.

उपयोगकर्ता इस सूची में भेजे गए या न भेजे गए संदेशों की सूची और सामग्री देख सकते हैं. आउटबॉक्स में कोई संदेश सुरक्षित करने के लिए 'संदेश सेटिंग्स' में 'भेजे गए सुरक्षित' चयनित होना चाहिए.

1. सॉफ्ट बटन 1 **सूची**, 2 या दबाएँ.
2. 3 **आउटबॉक्स** चुनें.
3. 1 **भेजे हुए** या 2 **नहीं भेजे हुए** चुनें.
4. से इच्छित संदेश चुनने के बाद; सॉफ्ट बटन 1 **विकल्प** दबाएँ. यदि आप भेजा हुआ संदेश चुनते हैं, तो स्क्रीन पर **देखें/मिटाएँ/फॉरवर्ड** दिखाई देता है.

- **देखें** हाल में सुरक्षित किया गया संदेश दिखाता है. देखें सूची में दो उपसूचियाँ **फॉरवर्ड** और **मिटाएँ** होती हैं.
- **मिटाएँ** आउटबॉक्स में चयनित संदेश मिटाएँ.
- **फॉरवर्ड** आप प्राप्त संदेश को संशोधित कर सकते हैं. फिर संदेश लिखें प्रक्रिया का अनुसरण करें (पृष्ठ 37 देखें).

वॉइस मेल (सूची 2 4)

इससे आप वॉइस मेल बॉक्स में रिकॉर्ड किया गया नया वॉइस संदेश देख सकते हैं. जब आप संग्रह सीमा से बाहर निकल जाते हैं, तो पुराने संदेश अधिलेखित कर दिए जाते हैं. आपके फोन में कोई नया वॉइस संदेश आने पर आपको सूचना दी जाएगी.

1. सॉफ्ट बटन 1 **सूची**, 2 या दबाएँ.
2. 4 **वॉइस मेल** चुनें.
   - जानकारी मिटाने के लिए सॉफ्ट बटन 1 **विकल्प** दबाएँ और फिर **सुनें**, **मिटाएँ** चुनें.

यदि किसी कॉल का जवाब देते समय कोई नया संदेश आता है, तो प्रेषक का नंबर स्क्रीन पर दिखाया जाएगा.

संग्रह (सूची 2 5)

प्राप्त संदेशों में से आपकी पसंद के संदेश संग्रह में संग्रहीत किए जाते हैं (30 संदेश).

1. सॉफ्ट बटन 1 **सूची**, 2 या दबाएँ.
2. 5 **संग्रह** चुनें.
3. से इच्छित संदेश चुनने के बाद,

सॉफ्ट बटन 1 **विकल्प** दबाएँ. यदि आप संदेश चुनते हैं तो स्क्रीन पर **देखें/मिटाएँ/फॉरवर्ड** दिखाई देता है.

- **देखें** तीन मुख्य सूचियाँ होती हैं फॉरवर्ड, जवाब, मिटाएँ और नंबर सुरक्षित.
- **मिटाएँ** चयनित संदेश मिटाता है.
- **फॉरवर्ड** आप प्राप्त संदेश को संशोधित कर सकते हैं. फिर **संदेश लिखें** प्रक्रिया का अनुसरण करें (पृष्ठ 37 देखें).

ड्राफ्ट्स *(सूची 2 6)*

शब्द संदेश ड्राफ्ट में सुरक्षित हो जाता है. ड्राफ्ट में 30 संदेश तक सुरक्षित किए जा सकते हैं. कोई संदेश लिखते समय कोई कॉल आता है, तो संदेश अपने आप सुरक्षित हो जाता है.

1. सॉफ्ट बटन 1 **सूची**, 2 या दबाएँ.
2. 6 **ड्राफ्ट्स** चुनें.
3. से इच्छित संदेश चुनने के बाद, सॉफ्ट बटन 1 **विकल्प** दबाएँ. यदि आप संदेश चुनते हैं, तो स्क्रीन पर **देखें/मिटाएँ** दिखाई देते हैं.
   - **देखें** इसमें चार सूचियाँ **भेजें, सुरक्षित, टेम्प्लेट्स** और **मिटाएँ** होती हैं.
   - **मिटाएँ** चयनित संदेश मिटाता है.

टेम्प्लेट्स *(सूची 2 7)*

टेम्प्लेट्स में 10 पूर्वपरिभाषित वाक्यांश शामिल हैं. आप 20 और टेम्प्लेट्स जोड़ सकते हैं. कुल 30 टेम्प्लेट्स सुरक्षित किए जा सकते हैं.

1. सॉफ्ट बटन 1 **सूची**, 2 या दबाएँ.
2. 7 **टेम्प्लेट्स** चुनें.
3. से इच्छित संदेश चुनने के बाद सॉफ्ट बटन 1 **विकल्प** दबाएँ. यदि आप संदेश चुनते हैं तो स्क्रीन पर **देखें/जोड़ें** दिखाई देता है.
   - **देखें** इसमें दो सूचियाँ **भेजें** और **सुरक्षित** होती हैं.
   - **जोड़ें** आप टेम्प्लेट्स सूची में नए टेम्प्लेट्स संदेश जोड़ सकते हैं.

संदेश मिटाएँ *(सूची 2 8)*

जब आप शब्द संदेश सूची स्क्रीन से 8 **संदेश मिटाएँ** चुनते हैं तो शब्द संदेश और पृष्ठ मिट जाते हैं.

इनबॉक्स (सूची 2 8 1)

इससे आप प्राप्त शब्द संदेश, पृष्ठ संदेश, भेज दिया गया संदेश मिटा सकते हैं.

आउटबॉक्स (सूची 2 8 2)

आउटबॉक्स में सुरक्षित सभी संदेश मिटा सकते हैं.

संग्रह (सूची 2 8 3)

संग्रह में सुरक्षित सभी संदेश मिटा सकते हैं.

ड्राफ्टस (सूची 2 8 4)

ड्राफ्ट में सुरक्षित सभी संदेश मिटा सकते हैं.

सभी संदेश (सूची 2 8 5)

सभी संदेश मिटा सकते हैं.

संदेश सेटिंग्स (सूची 2 9)

नए संदेश प्राप्त करने के लिए **प्राथमिकता, भेज दिया गया, विलंबित डेलिवरी, वैधता समय, भेजे गए सुरक्षित** और **इनबॉक्स स्वत: मिटाएँ** कॉन्फिगर किए जा सकते हैं.

प्राथमिकता (सूची 2 9 1)
संदेश भेजते समय, सामान्य या अति आवश्यक चुनें.

भेज दिया गया (सूची 2 9 2)
आप अपने संदेश के साथ पावती जोड़ सकते हैं.

विलंबित डेलिवरी (सूची 2 9 3)
आप सेट की गई समय सीमा तक संदेश का प्रेषण विलंबित कर सकते हैं.

वैधता समय (सूची 2 9 4)
कुछ समय तक गंतव्य पते पर न भेजे जाने पर संक्षिप्त संदेश केन्द्र (SMC) पर संदेश प्रेषण की वैधता बताता है.

भेजे गए सुरक्षित (सूची 2 9 5)
यदि यह सुविधा चालू होती है, तो भेजते समय संदेश अपने आप आउटबॉक्स में सुरक्षित हो जाते हैं.

इनबॉक्स स्वत: मिटाएँ (सूची 2 9 6)
जब यह सुविधा चालू होती है, तो संग्रह सीमा पार करने पर आपके पुराने संदेश स्वत: मिटा दिए जाते हैं.

सहायता (सूची 2 0)

आप इस सूची के बारे में और जानकारी प्राप्त कर सकते हैं.

कॉल विवरण (सूची 3)

आप 60 हाल के (छूटी हुई+प्राप्त हुए+डायल किये गए) फोन कॉल्स देख सकते हैं. जब आप (कुल) 60 नंबरों की संग्रह सीमा पार कर जाते हैं, तो सबसे पुराना कॉल विवरण अधिलेखित कर दिया जाता है. ये कॉल्स चार प्रकारों में विभाजित हैं.

नोट आप दो तरह से कॉल विवरण देख सकते हैं.

- निष्क्रिय मोड में CALL बटन दबाकर, जिसमें छूटी हुई, प्राप्त हुआ और डायल किये हुए सहित हाल के 60 तक कॉल दिखाए जाते हैं.
- कॉल विवरण सूची में, जहाँ छूटी हुई, डायल किये हुए, प्राप्त हुआ, और कॉल मेमो में के तहत 60 नंबर सूचीबद्ध होते हैं.
- कॉल मेमो में अधिकतर 5 नंबर होते हैं.

कॉल विवरण से कोई कॉल करना

1. कॉल विवरण सूची से, **छूटी हुई, प्राप्त हुआ, डायल किये हुए** या **कॉल मेमो में** चुनें और सॉफ्ट बटन 1 **चुनें** दबाएँ.
2. इच्छित प्रविष्टि चुनने और जोड़ने के लिए CALL दबाकर कॉल करें.

छूटी हुई (सूची 3 1)

आप सभी छूटी हुई कॉल्स की सूची देख सकते हैं.
अधिकतम (छूटी हुई+प्राप्त हुआ +डायल किये हुए+कॉल मेमो में) 60 नंबर आ सकते हैं.

1. **कॉल विवरण** सूची से, 1 **छूटी हुई** चुनें.
2. सॉफ्ट बटन 1 **विकल्प** दबाएँ. स्क्रीन पर **देखें/संदेश भेजें/सुरक्षित/मिटाएँ** दिखाई देते हैं.
3. आप CALL दबाकर कोई कॉल कर सकते हैं.

प्राप्त हुआ (सूची 3 2)

आप सभी प्राप्त कॉल्स की सूची देख सकते हैं.

अधिकतम 60 (छूटी हुई+प्राप्त हुआ+डायल किये हुए+कॉल मेमो में) नंबर आ सकते हैं.

1. **कॉल विवरण** सूची से, 2 **प्राप्त हुआ** चुनें.
2. सॉफ्ट बटन 1 **विकल्प** दबाएँ. स्क्रीन पर **देखें/संदेश भेजें/सुरक्षित/मिटाएँ** दिखाई देते हैं.
3. आप CALL दबाकर कॉल कर सकते हैं.

डायल किये हुए (सूची 3 3)

आप सभी डायल किए गए कॉल्स देख सकते हैं.

अधिकतम 60 (छूटी हुई+प्राप्त हुआ+डायल किये हुए+कॉल मेमो में) नंबर आ सकते हैं.

1. **कॉल विवरण** सूची से, 3 **डायल किये हुए** चुनें.
2. सॉफ्ट बटन 1 **विकल्प** दबाएँ. स्क्रीन पर **देखें/संदेश भेजें/सुरक्षित/मिटाएँ** दिखाई देते हैं.
3. आप CALL दबाकर कॉल कर सकते हैं.

कॉल मेमो में (सूची 3 4)

बातचीत के दौरान आए फोन नंबर सुरक्षित हो जाते हैं और वर्तमान नंबरों की सूची कॉल मेमो में देख सकते हैं.

अधिकतम 5 नंबर आ सकते हैं.

1. **कॉल विवरण** सूची से, 4 **कॉल मेमो में** चुनें.
2. सॉफ्ट बटन 1 **विकल्प** दबाएँ. स्क्रीन पर **देखें/संदेश भेजें/सुरक्षित/मिटाएँ** दिखाई देते हैं.
3. आप CALL दबाकर कॉल कर सकते हैं.

कॉल अवधि (सूची 3 5)

1. अंतिम डायल कॉल (सूची 3 5 1)
   इसमें अंतिम डायल की गई कॉल के बारे में जानकारी संग्रहीत होगी और यह अंतिम डायल किया गया नंबर भी दिखाएगा.
2. सब डायल कॉल (सूची 3 5 2)
   यह डायल किए गए सभी कॉल्स की संख्या और डायल कॉल्स की कुल अवधि दिखाता है.
3. सब कॉल (सूची 3 5 3)
   सभी कॉल करने, डायल करने और प्राप्त करने के समय की गणना करता है.
4. कॉल अवधि पुन: सेट करें (सूची 3 5 4)
   काउंटर रीसेट करने के लिए, का उपयोग करके हाँ चुनें और फिर सॉफ्ट बटन 1 **चुनें** दबाएँ.

डेटा विवरण (सूची 3 6)

1. **कॉल विवरण** सूची से, 6 **डेटा विवरण** चुनें.
2. PWR END दबाएँ.

विवरण मिटाएँ (सूची 3 7)

1. **कॉल विवरण** सूची से, 7 **विवरण मिटाएँ** चुनें.
2. से मिटाया जाने वाला आइटम चुनें.
3. सॉफ्ट बटन 1 **चुनें** दबाएँ.
4. से हाँ चुनें और सॉफ्ट बटन 1 **चुनें** दबाएँ.

सहायता (सूची 3 8)

आप इस सूची के बारे में और जानकारी प्राप्त कर सकते हैं.

प्रोफाइल्स (सूची 4)

प्रोफाइल्स से आप अपने फोन की ध्वनि सेटिंग्स अपने वातावरण के अनुसार कर सकते हैं. प्रत्येक प्रोफाइल में आपके फोन के लिए रिंग प्रकार, रिंग स्वर, रिंग वॉल्यूम, ईयरपीस वॉल्यूम, बटन वॉल्यूम और संदेश सचेतक होता है. आपके वर्तमान वातावरण के अनुसार प्रोफाइल चुनें: **सिर्फ कंपन, Silent, General** या **Outdoor**.

आप प्रत्येक प्रोफाइल की सेटिंग्स संशोधित कर सकते हैं, और (**सिर्फ कंपन** प्रोफाइल को छोड़कर) आप उनका नाम बदल सकते हैं (**सिर्फ कंपन, हेडसेट** और **कार किट** प्रोफाइल को छोड़कर).

प्रोफाइल्स चुनें

1. सॉफ्ट बटन 1 **सूची** दबाएँ और 4 या तुरंत दबाएँ.
2. से चार प्रोफाइल्स **सिर्फ कंपन, Silent, General** और **Outdoor** में से कोई एक चुनें.
3. तब सॉफ्ट बटन 1 **विकल्प** दबाएँ और फिर **सेट करें** चुनें.

नोट **हेडसेट** या **कार किट** प्रोफाइल मोबाइल फोन में हेडसेट या कार किट स्थापित होने पर अपने आप सेट हो जाती हैं.

नोट स्टैंडबाय मोड में, **सिर्फ कंपन** चुनने के लिए लंबा दबाएँ. पिछली प्रोफाइल में वापस जाने के लिए एक बार पुन: लंबा दबाएँ.

प्रोफाइल्स का नाम बदलें

1. सॉफ्ट बटन 1 **सूची** और 4 दबाएँ.
2. से **Silent**, **General** या **Outdoor** चुनें.
3. फिर सॉफ्ट बटन 1 **विकल्प** दबाएँ और तब **नाम बदलें** चुनें.
4. प्रोफाइल्स के लिए कोई नाम लिखें (16 वर्णों तक).
5. फिर सॉफ्ट बटन 1 **सुरक्षित** दबाएँ.

नोट आप सिर्फ कंपन, हेडसेट और कार किट प्रोफाइल्स का नाम नहीं बदल सकते.

प्रोफाइल्स अनुकूलित करें

सिर्फ कंपन को छोड़कर आप कोई भी प्रोफाइल अनुकूलित कर सकते हैं.

1. सॉफ्ट बटन 1 **सूची** और 4 दबाएँ.
2. जो प्रोफाइल आप अनुकूलित करना चाहते हैं, उसे स्क्रॉल करें और सॉफ्ट बटन 1 **विकल्प** दबाएँ और फिर **संपादन** चुनें.
3. निम्न तालिका में प्रत्येक विकल्प देखने के लिए स्क्रॉल बटनों का उपयोग करें:

रिंग प्रकार	रिंग स्वर की शैली चुनें (रिंग, कंपन, कंपन और रिंग, कंपन के बाद रिंग, मौन, लाइट).
रिंग स्वर	आने वाली कॉल्स के लिए R वर्ल्ड से 19 एम्बेडेड + 3 डाउनलोड किए जा सकने वाले रिंग स्वर चुनें.
रिंग वॉल्यूम	अपने रिंग स्वर का वॉल्यूम सेट करें. -मौन, 1~7 स्तर
इयरपीस वॉल्यूम	कॉल के दौरान वॉल्यूम सेट करें. 1~7 स्तर
बटन वॉल्यूम	आपके बटन पैड स्वर का वॉल्यूम सेट करें (या उन्हें बंद करें) - मौन, 1 ~7 स्तर
संदेश सचेतक	प्राप्त संदेशों के लिए स्वर चुनें (सचेतक प्रकार, सचेतक स्वर और संदेश रिमाइंडर).

नोट
- रिंग स्वर R वर्ल्ड से डाउनलोड किए जा सकते हैं. 19 रिंग स्वर + 3 R वर्ल्ड रिंग स्वर
- जब **रिंग प्रकार कंपन, मौन** और **लाइट** होता है तो **रिंग वॉल्यूम** समायोजित नहीं किया जा सकता. 'रिंग प्रकार बदलें' दिखाया जाता है. वर्तमान प्रकार को **रिंग प्रकार** में बदलने के बाद, **रिंग वॉल्यूम** समायोजित करें.
- जब **हेडसेट** और **कार किट** प्रोफाइल्स में सॉफ्ट बटन 1 **संपादन** दबाया जाता है, तो **स्वत: उत्तर** अतिरिक्त रूप से दिखाया जाता है. [⇕] का उपयोग करके **ऑफ**, **5 सेकण्ड के बाद** या **10 सेकण्ड के बाद** चुनें.
- आप **सिर्फ कंपन** प्रोफाइल को अनुकूलित नहीं कर सकते.
- कोई नया संदेश प्राप्त होने पर आपको तीन प्रकार से सचेत किया जाता है.
  स्क्रीन पर संदेश दिखाकर.
  बीप की ध्वनि या कंपन करके.
  स्क्रीन लाइट फ्लैश करके.

सहायता (सूची 4 7)

आप इस सूची के बारे में और जानकारी प्राप्त कर सकते हैं.

प्रदर्शन (सूची 5)

भाषा (सूची 5 1)

आप विभिन्न ग्राफिक्स चुनकर अपने फोन का **प्रदर्शन** व्यक्तिगत बना सकते हैं.

1. **प्रदर्शन** सूची से, 1 **भाषा** चुनें.

2. [⇕] की सहायता से English/हिन्दी सेट करें और तब सॉफ्ट बटन 1 **चुनें** दबाएँ.

सर्विस एरिया (सूची 5 2)

यह सूची उपयोगकर्ता का एस डी सी ए/कॉलिंग क्षेत्र प्रदर्शित करती है.

1. **प्रदर्शन** सूची से 2 **सर्विस एरिया** चुनें.

घड़ी (सूची 5 3)

इससे आप अपने मोबाइल फोन पर प्रदर्शित करने के लिए घड़ी चुन सकते हैं.

1. **प्रदर्शन** सूची से 3 **घड़ी** चुनें.
2. **ऑफ, छोटा** या **बड़ा** चुनें और सॉफ्ट बटन 1 **चुनें** दबाएँ.

वॉलपेपर (सूची 5 4)

अक्षरों की एक पंक्ति लिखें जिसे आप प्रदर्शित करना चाहते हैं. आप स्टैंडबाय मोड में एलसीडी स्क्रीन पर प्रदर्शित स्क्रीन सेट कर सकते हैं.

1. **प्रदर्शन** सूची से 4 **वॉलपेपर** चुनें.
   1. **विषय** (सूची 5 4 1)
      आप स्टैंडबाय मोड में एलसीडी स्क्रीन पर प्रदर्शित स्क्रीन सेट कर सकते हैं.
      ▶ विषय का चयन करें और सॉफ्ट बटन 1 **सुरक्षित** दबाएँ. यदि आप **R वर्ल्ड छवि डाउनलोड** का उपयोग करते हैं तो आप डाउनलोड की गई छवि भी चुन सकते हैं. (ऑफ/R वर्ल्ड छवि 1–3/ छवि 1–2)
2. **प्रोफाइल** (सूची 5 4 2)
   मौजूदा प्रोफाइल वॉलपेपर के रूप में सुरक्षित कर ली जाती है.
   - **दिखाएँ** या **छिपाएँ** चुनें और सॉफ्ट बटन 1 **चुनें** दबाएँ.

3. **बैनर** (सूची 5 4 5)

अक्षरों की वह पंक्ति लिखें जिसे आप प्रदर्शित करना चाहते हैं. (13 वर्णों तक).

▶ बैनर का नाम डालें और बाद में सॉफ्ट बटन 1 **सुरक्षित** दबाएँ.

नोट वॉलपेपर्स, R वर्ल्ड द्वारा डाउनलोड किए जा सकते हैं.

सूची स्टाइल (सूची 5 5)

इससे आप सूची स्टाइल चुन सकते हैं.

1. **प्रदर्शन** सूची से, 5 **सूची स्टाइल** चुनें.
2. ⬍ से **चिन्ह** या **सूची** चुनें, फिर सॉफ्ट बटन 1 **चुनें** दबाएँ.

स्क्रीन लाइट (सूची 5 6)

एलसीडी और बटन पैड स्क्रीन लाइट की सेटिंग्स चुनें.

1. **प्रदर्शन** सूची से, 6 **स्क्रीन लाइट** चुनें.
2. कोई विकल्प चुनें और सॉफ्ट बटन 1 **चुनें** दबाएँ.
   - ▶ **1 मिनट के लिए** स्क्रीन लाइट 1 मिनट तक ऑन रहती है, उसके बाद 20 सेकंड के लिए मंद हो जाती है और फिर स्क्रीन लाइट ऑन करने के लिए उपयोगकर्ता के कोई बटन दबाने तक बंद रहती है.
   - ▶ **30 सेकण्ड के लिए** स्क्रीन लाइट 30 सेकंड तक ऑन रहती है, उसके बाद 20 सेकंड के लिए मंद हो जाती है और फिर स्क्रीन लाइट ऑन करने के लिए उपयोगकर्ता के कोई बटन दबाने तक बंद रहती है.
   - ▶ **10 सेकण्ड के लिए** स्क्रीन लाइट 10 सेकंड तक ऑन रहती है, उसके बाद 20 सेकंड के लिए मंद हो जाती है और फिर स्क्रीन लाइट ऑन करने के लिए उपयोगकर्ता के कोई बटन दबाने तक बंद रहती है.

कॉन्ट्रास्ट (सूची 5 7)

नेविगेशन बटन का उपयोग करते हुए हल्के से लेकर गहरी रोशनी का स्केल उपयोग में लाकर कॉन्ट्रास्ट सेटिंग चुनें.

1. **प्रदर्शन** सूची से, 7 **कॉन्ट्रास्ट** चुनें.
2. ⬌ से कॉन्ट्रास्ट समायोजित करें.
3. बाद में कॉन्ट्रास्ट सेटिंग सुरक्षित करने के लिए सॉफ्ट बटन 1 **चुनें** दबाएँ.

सहायता (सूची 5 8)

आप इस सूची के बारे में और जानकारी प्राप्त कर सकते हैं.

सेटिंग्स (सूची 6)

मेरी सूची (सूची 6 1)

इससे आप मेरी सूची को अनुकूलित कर अपनी पसंद की सूची चुन सकते हैं. मेरी सूची में अधिकतम 10 विषय संग्रहीत किए जा सकते हैं.

1. **सेटिंग्स** सूची से, 1 **मेरी सूची** चुनें.
2. ⬍ से अपनी पसंद की सूची चुनें, और तब सॉफ्ट बटन 1 **चुनें** दबाएँ.
3. **मेरी सूची** में जोड़ने के लिए ⬍ की सहायता से सूची चुनें, फिर सॉफ्ट बटन 1 **जोड़ें** दबाएँ (यदि उपसूची उपलब्ध है तो सॉफ्ट 1 बटन चुनें, फिर **मेरी सूची** से संपूर्ण सूची जोड़ने के लिए **अधिक** व **जोड़ें** चुनें.)

नोट स्टैंडबाय स्क्रीन से CLR + ⬍ के साथ पसंद का विषय चुनें, बाद में सॉफ्ट बटन 1 **विकल्प** दबाकर चुनें चुनकर **मेरी सूची** चुनें.

नोट स्टैंडबाय स्क्रीन से CLR + ⬍ के उपयोग से मिटाने के लिए

विषय चुनें, बाद में सॉफ्ट बटन 1 **विकल्प** दबाकर **मिटाएँ** चुनें.

से **हाँ** चुनें, बाद में **मेरी सूची** से मिटाने के लिए सॉफ्ट बटन 1 **चुनें** दबाएँ.

कॉल (सूची 6 2)

1. **सेटिंग्स** सूची से 2 **कॉल** चुनें.

1) **कॉल फॉरवर्ड** सूची 6 2 1)

कॉल फॉरवर्ड से आप सभी आने वाली कॉल, अन्य नंबर या वॉइस मेल कनेक्शन पर फॉरवर्ड कर सकते हैं.

▶ **तुरन्त/जब व्यस्त/उत्तर नहीं/पहुँच के बाहर/सभी कॉल फॉरवर्ड असमर्थ**

2) **कॉल प्रतीक्षा** (सूची 6 2 2)

जब आप कॉल पर होते हैं तब आपको दो बार बीप की आवाज़ सुनाई दे सकती है जो आपको दूसरी आने वाली कॉल का संकेत देती है. जब कॉल प्रतीक्षा सक्षम हो, तब आप सक्रिय कॉल को होल्ड पर रखकर दूसरी आ रही कॉल का उत्तर दे सकते हैं.

▶ **समर्थ** या **असमर्थ** चुनें और सॉफ्ट बटन 1 **चुनें** दबाएँ.

नोट कॉल फॉरवर्ड और कॉल प्रतीक्षा के बारे में अधिक जानकारी के लिए **अपने सेवा प्रदाता** से संपर्क करें.

3) **किसी बटन उत्तर** (सूची 6 2 3)

जब आपका फोन बजे तो आप PWR END छोड़कर कोई भी बटन दबाकर बात कर सकते हैं.

▶ **ऑफ** या **ऑन** चुनें और सॉफ्ट बटन 1 **चुनें** दबाएँ.

4) **स्वत: रीडायल** (सूची 6 2 4)

कॉल करने की कोशिश असफल होने पर अपने आप नंबर

रीडायल करने से पहले फोन की प्रतीक्षा अवधि सेट करें.

▶ ऑफ/प्रति 60 सेकण्ड/प्रति 30 सेकण्ड/ प्रति 10 सेकण्ड.

5) **वॉइस प्राइवेसी** (सूची 6 2 5)

सी डी एम ए कॉल्स के लिए बढ़ी हुई या सामान्य वॉइस प्राइवेसी सुविधा चुनें. सी डी एम ए में वॉइस प्राइवेसी की सुविधा है. बढ़े हुए वॉइस प्राइवेसी मोड की उपलब्धता के लिए अपने सेवा प्रदाता से संपर्क करें.

▶ **सामान्य** या **बढ़ा हुआ** हुआ चुनें और सॉफ्ट बटन 1 **चुनें** दबाएँ.

6) **साफ वॉइस** (सूची 6 2 6)

यह ऑडियो एजीसी (ऑटोगेन कंट्रोल) सिस्टम प्रणाली सक्रिय/निष्क्रिय करता है.

इस सुविधा से बेहतर आवाज़ मिलती है जो ऑडियो एजीसी सिस्टम को सक्रिय करते हुए डायनामिक रेंज और स्पीकर के भिन्न स्तरों पर आवाज़ भेजने व पाने की तीव्रता और वातावरण नियंत्रित करती है.

▶ **ऑन** या **ऑफ** और सॉफ्ट बटन 1 **चुनें** दबाएँ.

7) **कॉल समयक** (सूची 6 2 7)

जब कोई कॉल चल रहा हो तो बीता हुआ समय प्रदर्शित करने के लिए आप अपना फोन सेट कर सकते हैं.

▶ **समर्थ** या **असमर्थ** चुनें और सॉफ्ट बटन 1 **चुनें** दबाएँ.

8) **कॉल संपर्क सचेतक** (सूची 6 2 8)

यह फंक्शन कॉल संपर्क स्थापित हो जाने पर आपको सचेत करता है.

▶ **ऑन** या **ऑफ** चुनें और सॉफ्ट बटन 1 **चुनें** दबाएँ.

9) **सहायता** (सूची 6 2 9)

आप इस सूची के बारे में और जानकारी प्राप्त कर सकते हैं.

फोन (सूची 6 3)

1. **सेटिंग** सूची से 3 **फोन** चुनें.

1) **बटन रक्षक** (सूची 6 3 1)

इससे आप फोन के बटन पैड की सुरक्षा कर सकते हैं, ताकि गलती से कोई नंबर डायल न हो. जब यह फंक्शन सक्रिय होता है तो कोई कॉल नहीं किया जा सकता और सूची लॉक हो जाती है. जब बटन पैड लॉक होता है तो कॉल प्राप्त करना सामान्य रूप से संभव होता है.

▶ **समर्थ** या **असमर्थ** चुनें और सॉफ्ट बटन 1 **चुनें** दबाएँ.

तत्काल सक्रिय करने के लिए: 0 बटन दो सेकंड तक दबाए रखें.

तत्काल निष्क्रिय करने के लिए: प्रक्रिया दोहराएँ.

2) **NAM सेट करें** (सूची 6 3 2)

फोन का NAM (नंबर असाइनमेंट मॉड्यूल) चुनें. यह विकल्प इस समय आपके सेवा प्रदाता नेटवर्क पर उपलब्ध नहीं है. सिर्फ **NAM 1** का ही उपयोग करें.

3) **डेटा सेटिंग्स** (सूची 6 3 3)

डेटा/फैक्स (सूची 6 3 3 1)

डेटा/फैक्स सेटिंग में, आप अपने फोन को वायरलेस मॉडेम के रूप में प्रयोग करके उच्च गति डेटा सेवाओं, जैसे कि इंटरनेट, और अन्य डायल-अप नेटवर्किंग फंक्शन, का लाभ ले सकते हैं. वायरलेस फोन नेटवर्क साइड पर, 153.6 केबीपीएस की अधिकतम डेटा दर उपलब्ध करा सकता है. आपके कनेक्शन की गति नेटवर्क की व्यस्तता, संकेत की शक्ति और अन्य परिवर्तनीय कारकों पर निर्भर करती है.

▶ **ऑफ**

▶ **डेटा इन :** इस सेटिंग से सब्सक्राइबर डेटा कॉल्स प्राप्त कर सकता है.

▶ **फैक्स इन :** फैक्स सेवाएँ वर्तमान में **आपके सेवा प्रदाता** के नेटवर्क पर उपलब्ध नहीं हैं.

नोट फोन को मॉडेम के रूप में उपयोग करने के लिए आपको डेटा किट खरीदने की आवश्यकता होगी. डेटा किट में उपयुक्त केबल होती है जिसमें फोन को पीसी से कनेक्ट करने के लिए RS-232 इंटरफेस होता है. अधिक जानकारी के लिए कृपया अपने सेवा प्रदाता से संपर्क करें.

डेटा बॉड (सूची 6 3 3 2)

इस सेटिंग से सब्सक्राइबर टर्मिनल पर बॉड दर सेट किया जा सकता है.

▶ डेटा बॉड सेट USB/19,200/115,200/ 230,400

यह पूर्वनियत रूप से 115, 200 पर सेट होता है. यदि आप फोन पर यह सेटिंग बदलते हैं तो सुनिश्चित कर लें कि पी सी बॉड दर भी उसके अनुसार बदले.

नोट वायरलेस फोन पी सी/पी डी ए के साथ ठीक तरह से तभी काम करेगा जब दोनों पी सी की सीरियल पोर्ट सेटिंग्स फोन पर सेट बॉड दरों से मेल करेंगी.

4) **वर्जन** (सूची 6 3 4)

S/W, PRL और जावा वर्जन देखें.

5) **सहायता** (सूची 6 3 5)

आप इस सूची के बारे में और जानकारी प्राप्त कर सकते हैं.

सुरक्षा (सूची 6 4)

1) **लॉक मोड** (सूची 6 4 1)

यह आपके फोन को अनधिकृत उपयोग से सुरक्षित रखता है. एक बार फोन लॉक हो जाने पर यह तब तक प्रतिबंधित मोड में होता है, जब

तक लॉक कोड नहीं लिखा जाता. इससे आप फोन कॉल प्राप्त कर सकते हैं और आपातकालीन कॉल भी कर सकते हैं. आपके फोन पर लॉक कोड/पासवर्ड, पूर्वनियत रूप से **0000** होता है. यदि आपको लॉक कोड बदलना हो तो आप इसे सुरक्षा सेट सूची के भीतर नए लॉक कोड के उपयोग से बदल सकते हैं.

1. **सेटिंग्स** सूची से 4 **सुरक्षा** चुनें.
2. 1 **लॉक मोड** दबाएँ.
3. चार अंकों का लॉक कोड लिखें.
4. कोई विकल्प चुनें और सॉफ्ट बटन 1 **चुनें** दबाएँ.
   - **ऑफ** का अर्थ है कि फोन अभी तक लॉक नहीं किया गया है. लॉक होने पर, आप आने वाला कॉल प्राप्त कर सकते हैं या केवल आपातकालीन कॉल कर सकते हैं.
   - **अभी** का अर्थ है कि फोन तुरंत लॉक हो जाता है.
   - **पावर चालू होने पर** का अर्थ है कि जब फोन चालू किया जाता है, तब फोन लॉक हो जाता है.

2) **सब नाम मिटाएँ** (सूची 6 4 2)

फोन बुक में सुरक्षित सभी जानकारियाँ मिटा देता है. इसका उपयोग करते समय सावधान रहें क्योंकि हटाई गई जानकारी पुन: प्राप्त नहीं की जा सकती.

1. **सेटिंग्स** सूची से 4 **सुरक्षा** चुनें.
2. 2 **सब नाम मिटाएँ** दबाएँ.
3. चार अंकों का लॉक कोड लिखें.
4. के उपयोग से **हाँ** चुनें.
5. सॉफ्ट बटन 1 **चुनें** दबाएँ.

3) **आपातकालीन नंबर** (सूची 6 4 3)

आपका फोन लॉक अथवा प्रतिबंधित होने पर भी आप 100, 101, 102 नंबरों पर कॉल कर सकते हैं. 3 आपातकालीन नंबर लिखने के लिए,

1. **सेटिंग्स** सूची से 4 **सुरक्षा** चुनें.
2. 3 **आपातकालीन नंबर** दबाएँ.
3. चार अंकों का लॉक कोड लिखें.
4. सॉफ्ट बटन 1 **संपादन** दबाएँ.
5. आपातकालीन नंबर लिखें.
6. सॉफ्ट बटन 1 **सुरक्षित** दबाएँ.

4) **लॉक कोड बदलें** (सूची 6 4 4)

नए लॉक कोड से आप एक नए चार अंकों का लॉक कोड नंबर लिख सकते हैं.

1. **सेटिंग्स** सूची से 4 **सुरक्षा** चुनें.
2. 4 **लॉक कोड बदलें** दबाएँ.
3. चार अंकों का लॉक कोड लिखें.
4. नया लॉक कोड लिखें (चार-अंक).
5. पुष्टि के लिए यह आपको नया लॉक कोड फिर से लिखने के लिए कहेगा.

5) **फोन पुन: सेट करें** (सूची 6 4 5)

आप कुछ सूची सेटिंग्स को उनके वास्तविक मान पर पुन: सेट कर सकते हैं. जब फोन पुन: सेट करें चुना जाता है, तो फोन बुक को छोड़ कर सभी सेटिंग्स रीसेट हो जाती हैं.

1. **सेटिंग्स** सूची से 4 **सुरक्षा** चुनें.
2. 5 **फोन पुन: सेट करें** दबाएँ.
3. चार अंकों का लॉक कोड लिखें.
4. के उपयोग से **हाँ** चुनें.
5. सॉफ्ट बटन 1 **चुनें** दबाएँ.

6) **सहायता** (सूची 6 4 6)

आप इस सूची के बारे में और जानकारी प्राप्त कर सकते हैं.

ऑर्गनाइज़र (सूची 7)

टाईम मैनेजर (सूची 7 1)

टाइम मैनेजर फंक्शन्स

टाइम मैनेजर आपकी कार्य सूची को सुविधाजनक व पहुँच में आसान बनाता है. अपने कार्यक्रम इसमें संग्रहीत कर दें और आपका फोन आपके नियत समय के बारे में आपको सतर्क कर देगा.

आप **वेक-अप** सुविधा का भी लाभ ले सकते हैं.

160 तक सुरक्षित कर सकते हैं.

नोट यदि नियत समय पर SMS भेजा जा रहा हो या कॉल चल रहा हो या जावा का उपयोग किया जा रहा हो तो फोन नहीं बजता. इन कार्यों के खत्म होने पर यह अनुस्मारक देगा.

नोट हैंडसेट का समय नेटवर्क टाइम सेटिंग्स से लिया जाता है.

कैलेंडर में नेविगेशन करने के लिए बटनों का उपयोग कैसे करें.

◀ , कर्सर बाईं ओर ले जाता है.

▶ , कर्सर दाईं ओर ले जाता है.

▲ , पिछले सप्ताह में जाता है.

▼ , अगले सप्ताह में जाता है.

1 पिछले वर्ष में जाता है.

3 अगले वर्ष में जाता है.

7 पिछले महीने में जाता है.

9 अगले महीने में जाता है.

इसकी सहायता से आप अपना कार्यक्रम जोड़ सकते हैं. यदि आप समय और मेमो दर्ज करते हैं तो तय समय पर अलार्म बजता है.

1. **ऑर्गनाइज़र** सूची से, 1 **टाइम मैनेजर** चुनें.
2. अपने बटन पैड का उपयोग करते हुए तिथि चुनें, फिर सॉफ्ट बटन 1 **विकल्प** दबाएँ और **कार्य जोड़ें, तिथि से देखें, सब देखें, तिथि पर जाएँ, आज पर जाएँ, तिथि को मिटाएँ** या **सब मिटाएँ** चुनें.

टु डू (सूची 7 2)

इसमें 40 तक सुरक्षित किए जा सकते हैं.

1. **ऑर्गनाइज़र** सूची से 2 **टु डू** चुनें.
2. कोई नया कार्य लिखने के लिए सॉफ्ट बटन 1 **जोड़ें** दबाएँ.

नोट सुरक्षित टु डू की स्थिति में देखें, मिटाएँ, सब मिटाएँ, और जोड़ें के फंक्शन सॉफ्ट बटन 1 के साथ उपलब्ध होते हैं.

मेमो (सूची 7 3)

इसमें 40 तक सुरक्षित किए जा सकते हैं.

1. **ऑर्गनाइज़र** सूची से, 3 **मेमो** चुनें.
2. कोई नया मेमो लिखने के लिए सॉफ्ट बटन 1 **जोड़ें** दबाएँ.
3. वर्ण लिखने के बाद (वर्ण लिखने हेतु पृष्ठ 20-24 देखें) सॉफ्ट बटन 1 **सुरक्षित** दबाएँ.

जब मेमो खाली न हो

निम्न विकल्प उपलब्ध होते हैं:

देखें, मिटाएँ, सब मिटाएँ और **जोड़ें**

देखें : चयनित मेमो प्रदर्शित करने के लिए.

देखें स्क्रीन 2 विकल्प, **संपादन** व **मिटाएँ**, देता है.

संपादन से उपयोगकर्ता वर्तमान मेमो संशोधित कर सकता है.

मिटाएँ : इससे उपयोगकर्ता चुने हुए मेमो मिटा सकता है.

सब मिटाएँ : इससे उपयोगकर्ता संग्रहीत सभी मेमो मिटा सकता है.

जोड़ें : इससे उपयोगकर्ता मेमो जोड़ सकता है.
मेमो के सुरक्षित होने पर वर्तमान तिथि और समय भी सुरक्षित हो जाते हैं.

अलार्म (सूची 7 4)

किसी कार्य का अलार्म समय बदलने के लिए.

1. **ऑर्गनाइज़र** सूची से, 4 **अलार्म** चुनें.
2. **अलार्म 1, अलार्म 2** या **अलार्म 3** चुनें.
3. आप ◀▶ से अलार्म मोड बदल सकते हैं.
   (ऑफ/एक बार/प्रतिदिन/सोम-शुक्र/सोम-शनि)
4. अलार्म समय सेट करने के लिए ▼ का उपयोग करें, रिंगर चुनें और सामग्री लिखें, और फिर सॉफ्ट बटन 1 **सुरक्षित** दबाएँ.
   - ▶ से am/pm चुना जा सकता है.
   - ▶ प्रोफाइल्स में सेटिंग्स के अनुसार रिंगर वॉल्यूम नियंत्रित किया जाता है.

नोट मोबाइल बंद करने पर अलार्म निष्क्रिय हो जाता है. निर्धारित सीमा निकल जाने पर अलार्म स्वत: समाप्त हो जाता है.

स्नूज़ कैसे सेट करें

अलार्म में सेट किए जाने पर स्नूज़ पूर्वनियत स्थिति में होता है.

अलार्म बजने पर जब कोई बटन नहीं दबाया जाता है तो एक मिनट बाद स्नूज़ फंक्शन अपने आप सेट हो जाता है, और सेट किए गए समय के दस मिनट बाद अलार्म फिर से बज उठता है.

स्टॉप वॉच (सूची 7 5)

स्टॉप वॉच उपलब्ध है.

1. **ऑर्गनाइज़र** सूची से 5 **स्टॉप वॉच** चुनें.

कैलक्युलेटर (सूची 7 6)

सरल गणितीय गणना करता है.
(दशमलव के दूसरे स्थान तक परिणाम प्राप्त किया जा सकता है.)

1. ऑर्गनाइज़र सूची से 6 **कैलक्युलेटर** चुनें.
2. 2 और 5 को क्रम से दबाएँ.
3. ◀ से (गुणा) चुनें.
4. 1 , 0 को क्रम से दबाएँ.
5. सॉफ्ट बटन 1 **उत्तर** चुनें.
   आप गणना का परिणाम **250** देखेंगे.

नोट एक बार में 50 अंकों तक की गणना की जा सकती है (उदा., 73+01-03 आठ अंक होंगे).

विश्व घड़ी (सूची 7 7)

यदि आपको किसी दूसरे देश में फोन करना है और आपको समय का अंतर नहीं पता, तो यह घड़ी उपयोगी साबित होगी.

1. **ऑर्गनाइज़र** सूची से 7 **विश्व घड़ी** चुनें.
2. ◀▶ से इच्छित शहर चुनें.
   शीघ्र चयन के लिए मैप पर 7 शहर देखने के लिए ▲▼ का उपयोग किया जा सकता है.

नोट सॉफ्ट बटन 1 **DST** से डे लाइट सेविंग टाइम सेट करें.

सहायता (सूची 7 8)

आप इस सूची के बारे में और जानकारी प्राप्त कर सकते हैं.

R वर्ल्ड (सूची 8)

R-सूची (सूची 8 1 या)

यह आपको **आपके सेवा प्रदाता** द्वारा दी गई R वर्ल्ड डेटा सेवा जैसे वीडियो, ऑडियो, समाचार, गेम्स, संदेश इत्यादि से जोड़ेगी.

1. **R वर्ल्ड** सूची से 1 **R-सूची** चुनें.
2. R वर्ल्ड लोगो के बाद R वर्ल्ड डेटा सेवा सूची प्रदर्शित होगी.
3. से सूची स्क्रॉल करें और सॉफ्ट बटन 1 **चुनें** दबाकर कोई भी डेटा सेवा शुरू करें.
4. किसी भी समय डेटा सेवा से बाहर निकलने के लिए कुछ सेकंड तक END दबाकर रखें.

नोट हो सकता है सभी डेटा सेवाएँ प्रत्येक उपभोक्ता के लिए उपलब्ध न हों. अधिक जानकारी के लिए कृपया **अपने सेवा प्रदाता** से संपर्क करें.

मल्टीमीडिया (सूची 8 2)

सुरक्षित किए जाने के लिए अधिकतम उपलब्ध स्थान 600 के बाइट है. फोन में कुल 20 फाइलें सुरक्षित की जा सकती हैं (600 के बाइट के अंतर्गत). यदि निर्धारित सीमा समाप्त होने पर और भी फाइलें सुरक्षित की जानी हैं, तो नई फाइलें सुरक्षित करने के लिए पर्याप्त स्थान न होने पर हैंडसेट फाइलें मिटाने के लिए संकेत देगा.

सूची दिखाएँ (सूची 8 2 1)

इससे आप अपने हैंडसेट में सुरक्षित वीडियो और ऑडियो फाइलें देख सकते हैं.

1. **R वर्ल्ड** सूची से 2 **मल्टीमीडिया** चुनें.
2. 1 **सूची दिखाएँ** दबाएँ.

सूची मिटाएँ (सूची 8 2 2)

इससे आप मल्टीमीडिया में संग्रहीत आइटम मिटा सकते हैं.

1. **R वर्ल्ड** सूची से **मल्टीमीडिया** चुनें.
2. 2 **सूची मिटाएँ** दबाएँ.

गेम (सूची 8 3)

यदि आप सूची से क्रिकेट गेम चुनने के बाद **सहायता** चुनते हैं तो आपको गेम खेलने के बारे में आवश्यक जानकारी मेनू में मिल सकती है.

क्रिकेट (सूची 8 3 1)

क्रिकेट दो टीमों के बीच खेला जाने वाला गेम है जिसमें प्रत्येक टीम में 11 खिलाड़ी होते हैं जो एक गेंद को मारकर और स्टंप्स के बीच दौड़कर अंक अर्जित करने का प्रयास करते हैं. आप भारत, इंग्लैंड, ऑस्ट्रेलिया और श्रीलंका में से किसी भी देश का चयन कर सकते हैं. प्रत्येक टीम की अपनी बैटिंग, पिचिंग और गति होती है.

1. **R वर्ल्ड** सूची से 3 **गेम** चुनें.
2. 1 **क्रिकेट** दबाएँ.
3. से **नया गेम** चुनें.
4. गेम शुरू करने के लिए सॉफ्ट बटन 1 दबाएँ.

1. बटन पैड संकेत - सूची स्क्रीन

   CLR गेम चयन स्क्रीन पर ले जाता है.

   END गेम समाप्त करता है.

   New Game - नया गेम शुरू करता है.

   Load Game - सुरक्षित किया गया गेम लोड करता है.

   Option - ध्वनि और कंपन को समायोजित करता है.

Help - बटन पैड की रूपरेखा प्रदर्शित करता है.

Score - स्कोर को सुरक्षित करता है.

3) बटन पैड रूपरेखा - बैटिंग स्क्रीन

बल्लेबाज की स्थिति चुनें

गेंद की दिशा

4) बटन पैड रूपरेखा - बैटिंग स्क्रीन

7 पुल

8 डिफेंड

9 ड्राइव

5) बटन पैड रूपरेखा - डिफेंस स्क्रीन

गेंद की स्पिन दिशा चुनें

4 लेफ्ट स्पिन 2 स्पिन नहीं

6 राइट स्पिन 5 डाउन स्पिन

गेंद कहाँ फेंकें

1 ~ 9 ,

गेम सेटिंग्स (सूची 8 3 2)

आप गेम की ध्वनि वॉल्यूम सेट कर सकते हैं और स्क्रीन लाइट चालू या बंद कर सकते हैं. गेम खेलते समय अपने फोन की सेटिंग बदलने के लिए.

1. **R वर्ल्ड** सूची से 3 **गेम** चुनें.
2. 2 **गेम सेटिंग्स** दबाएँ.
3. 1 **गेम वॉल्यूम** और 2 **गेम स्क्रीन लाइट** के बीच सेटिंग चुनने के लिए उपयोग करें.

नोट यदि स्क्रीन लाइट चालू है और गेम्स सूची में फोन निष्क्रिय रखा जाता है तो बैटरी जल्दी खर्च होगी.

R-सूची रीसेट (सूची 8 4)

यदि आपको अक्सर R वर्ल्ड का उपयोग करने में परेशानी होती है तो आप R वर्ल्ड को पुन: सेट कर सकते हैं. ऐसा करने से केवल R वर्ल्ड की सभी सेवाएँ ताज़ा होंगी.

1. **R वर्ल्ड** सूची से 4 **R-सूची रीसेट** चुनें.
2. से **हाँ** या **नहीं** चुनें और फिर सॉफ्ट बटन 1 **चुनें** दबाएँ.

सहायता (सूची 8 5)

आप इस सूची के बारे में और जानकारी प्राप्त कर सकते हैं.

कॉल मेमो में (कॉल के दौरान : सूची 1@अ)

इससे आप कॉल के दौरान अन्य व्यक्ति द्वारा दिया जाने वाला फोन नंबर दर्ज कर सकते हैं. नंबर कॉल विवरण में दर्ज हो जाएगा.

1. कॉल के दौरान सॉफ्ट बटन 1 दबाएँ.
2. 1@अ **कॉल मेमो में** दबाएँ.
3. फोन नंबर लिखें और सॉफ्ट बटन 1 **सुरक्षित** दबाएँ.

मौन / मौन नहीं (कॉल के दौरान : सूची 2ABC)

यह फंक्शन आपके फोन का माइक्रोफोन लॉक कर देता है और दूसरे व्यक्ति तक आपकी आवाज़ नहीं पहुँचने देता.

- **मौन फंक्शन सक्रिय करने के लिए :**

1. कॉल के दौरान सॉफ्ट बटन 1 दबाएँ.
2. 2ABC **मौन** दबाएँ.

- **मौन फंक्शन निष्क्रिय करने के लिए :**

1. प्रक्रिया दोहराएँ.

इयरपीस / स्पीकर वॉल्यूम (कॉल के दौरान : सूची 3DEF)

कॉल के दौरान से ईयरपीस वॉल्यूम समायोजित करें.

वॉइस प्राइवेसी ऑन/ऑफ (कॉल के दौरान : सूची 4GHI)

सी डी एम ए कॉल्स के लिए **एन्हांस** या **स्टैंडर्ड** के रूप में प्राइवेसी सुविधाएँ सेट करें. सी डी एम ए में वॉइस प्राइवेसी सुविधा है. एन्हांस्ड वॉइस प्राइवेसी मोड की उपलब्धता के लिए **अपने सेवा प्रदाता** से संपर्क करें.

स्पीकर ऑन समायोजित करना (कॉल के दौरान : #SPACE दबाएँ)

कॉल के दौरान स्पीकर ऑन सक्रिय करने के लिए, #SPACE को 2 सेकंड के लिए दबाएँ. स्पीकर ऑन रद्द करने के लिए, #SPACE को 2 सेकंड के लिए दबाएँ.

ट्रैवल चार्जर

यह चार्जर मॉडल AC-20W आपकी बैटरी चार्ज करता है. यह AC 100-240 वोल्ट, 50-60 हर्ट्ज़ आउटलेट्स का समर्थन करता है.

सिगरेट लाइटर चार्जर

सिगरेट लाइटर चार्जर, मॉडल CLC-60W का उपयोग करते हुए आप अपने वाहन से फोन संचालित कर सकते हैं और बैटरी को थोड़ा चार्ज कर सकते हैं.

हैंड्स-फ्री कार किट (पोर्टेबल)

हैंड्स-फ्री कार किट मॉडल PHF-60W के उपयोग से आप कार से फोन को जोड़ सकते हैं जिससे आप बिना हाथ लगाए संचालन कर सकते हैं.

हेडसेट

इसे आपके फोन से इसलिए जोड़ा जाता है, ताकि आप हाथ लगाए बिना संचालन करें. इसमें ईयरपीस, माइक्रोफोन और समेकित कॉल उत्तर/समाप्त बटन शामिल हैं.

सीरियल डेटा केबल

आपका फोन पीसी सीरियल पोर्ट से जोड़ता है. (LG-DC300DJ)

USB केबल

आप अपने फोन को अपने पीसी के USB पोर्ट के साथ जोड़ सकते हैं. (LG-USB8100)

सॉफ्ट बटन 1 **सूची** दबाएँ. स्क्रॉल करने के लिए दबाएँ.

नाम

1. नाम जोड़ें
2. खोजें
3. ग्रुप
4. शीघ्र डायल
5. सहायता

संदेश

1. लिखें
2. इनबॉक्स
3. आउटबॉक्स
4. वॉइस मेल
5. संग्रह
6. ड्राफ्टस
7. टेम्प्लेट्स
8. संदेश मिटाएँ
9. संदेश सेटिंग्स
   - प्राथमिकता
   - भेज दिया गया
   - विलंबित डेलिवरी
   - वैधता समय
   - भेजे गए सुरक्षित
   - इनबॉक्स स्वत: मिटाएँ
10. सहायता

कॉल विवरण

1. छूटी हुई
2. प्राप्त हुआ
3. डायल किये हुए
4. कॉल मेमो में
5. कॉल अवधि
   - अंतिम डायल कॉल
   - सब डायल कॉल
   - सब कॉल
   - कॉल अवधि पुन: सेट करें
6. डेटा विवरण
7. विवरण मिटाएँ
   - छूटी हुई कॉल मिटाएँ
   - प्राप्त हुआ कॉल मिटाएँ
   - डायल किये हुए कॉल मिटाएँ
   - डेटा विवरण कॉल मिटाएँ
8. सहायता

प्रोफाइल्स

1. सिर्फ कंपन
2. Silent
3. General
4. Outdoor
5. हेडसेट
6. कार किट
7. सहायता

प्रदर्शन

1. भाषा
   - English
   - हिन्दी
2. सर्विस एरिया
3. घड़ी
   - ऑफ
   - छोटा
   - बड़ा
4. वॉलपेपर
   - विषय
   - प्रोफाइल
   - बैनर
5. सूची स्टाइल
   - चिन्ह
   - सूची
6. स्क्रीन लाइट
   - 1 मिनट के लिए
   - 30 सेकण्ड के लिए
   - 10 सेकण्ड के लिए
7. कॉन्ट्रास्ट
8. सहायता

सॉफ्ट बटन 1 **सूची** दबाएँ. स्क्रॉल करने के लिए दबाएँ.

सेटिंग्स

1. मेरी सूची
2. कॉल
   - कॉल फॉरवर्ड
   - कॉल प्रतीक्षा
   - **किसी बटन उत्तर**
   - स्वत: रीडायल
   - वॉइस प्राइवेसी
   - साफ वॉइस
   - कॉल समयक
   - कॉल संपर्क सचेतक
   - सहायता
3. फोन
   - बटन रक्षक
   - NAM सेट करें
   - डेटा सेटिंग्स
   - वर्ज़न
   - सहायता
4. सुरक्षा
   - लॉक मोड
   - सब नाम मिटाएँ
   - आपातकालीन नंबर
   - लॉक कोड बदलें
   - फोन पुन: सेट करें
   - सहायता

ऑर्गनाइज़र

1. टाइम मैनेजर
2. टु डू
3. मेमो
4. अलार्म
5. स्टॉप वॉच
6. कैलक्युलेटर
7. विश्व घड़ी
8. सहायता

R वर्ल्ड

1. R-सूची
2. मल्टीमीडिया
   - सूची दिखाएँ
   - सूची मिटाएँ
3. गेम
   - क्रिकेट
   - गेम सेटिंग्स
4. R-सूची रीसेट
5. सहायता

सामान्य प्रश्न

प्र : मैं डायल किये हुए, प्राप्त हुए और छूटी हुई कॉल्स की सूची कैसे देख सकता हूँ ?

उ : CALL दबाएँ.

प्र : मैं कॉल विवरण कैसे मिटा सकता हूँ ?

उ : CALL दबाएँ → सॉफ्ट बटन 1 **विकल्प** दबाएँ → **मिटाएँ** या **सब मिटाएँ** दबाएँ → सॉफ्ट बटन 1 **चुनें** दबाएँ → **हाँ** चुनें → सॉफ्ट बटन 1 **चुनें** दबाएँ

प्र : मैं मेमोरी में संग्रहीत सभी नंबर कैसे देख सकता हूँ ?

उ : सॉफ्ट बटन 2 **खोजें** दबाएँ.

प्र : मैं कार्यक्रम में कितने कार्य जोड़ सकता हूँ ?

उ : कुल 160 ईवेंट.

प्र : मैं टाइम मैनेजर में संग्रहीत सभी पिछले कार्यक्रम कैसे साफ कर सकता हूँ ?

उ : सॉफ्ट बटन 1 **सूची** दबाएँ → 7 **ऑर्गनाइज़र** → 1 **टाइम मैनेजर** → सॉफ्ट बटन 1 **विकल्प** → 6 **तिथि को मिटाएँ** → **हाँ** चुनें → सॉफ्ट बटन 1 **चुनें** दबाएँ

प्र : मैं कितने शीघ्र डायल नंबर संग्रहीत कर सकता हूँ ?

उ : कुल 99 नंबर.

प्र : मैं कोई शब्द संदेश कैसे भेज सकता हूँ ?

उ : ✉ → 1 **लिखें** दबाएँ.

प्र : मैं कॉल समयक कैसे साफ कर सकता हूँ (मासिक रूप से समय रीसेट)?

उ : सॉफ्ट बटन 1 **सूची** → 3 **कॉल विवरण** → 5 **कॉल अवधि** → 4 **कॉल अवधि पुन: सेट करें** → **हाँ** चुनें → सॉफ्ट बटन 1 **चुनें** दबाएँ.

प्र : मैं अपना लॉक कोड कैसे पता कर सकता हूँ ?

उ : पूर्वनियत रूप से आपके फोन का लॉक कोड/पासवर्ड 0000 होता है.

प्र : इसमें कितने ग्रुप होते हैं ?

उ : ग्रुप में, कोई ग्रुप नहीं/Family/Relatives/Friends/Busines/Colleagues/School/Club/VIP.
आप ग्रुप का शीर्षक संपादित कर सकते हैं लेकिन **कोई ग्रुप नहीं** संपादित नहीं किया जा सकता.
ग्रुप का नाम बदलने के लिए,

1. सॉफ्ट बटन 1 **सूची** → 1 **नाम** → 3 **ग्रुप** और ⬍ दबाकर ग्रुप चुनें.
2. सॉफ्ट बटन 1 **विकल्प** दबाने के बाद, **शीर्षक संपादन** चुनें.

प्र : क्या ग्रुप SMS संभव है ?

उ : आप एक साथ 10 नंबरों को संदेश भेज सकते हैं. प्रत्येक नंबर अलग-अलग चुना या लिखा जाना चाहिए.

सर्विस के लिए कॉल करने से पहले

कृपया अपने फोन को सर्विस के लिए ले जाने या किसी सर्विस इंजीनियर को बुलाने से पहले देखें कि उसमें यहाँ उल्लेखित कोई समस्या तो नहीं है.

जब ऐसे लक्षण दिखाई दें :	तो यह जाँचें!
जब स्क्रीन से '' ᚠ '' गायब न होता हो.	देखें कि क्या यह सर्विस एरिया है, और यदि आपको अभी भी '' ᚠ '' दिखाई दे रहा हो, तो कृपया पावर बंद करें और लगभग दो मिनट बाद इसे चालू करें. यदि कोई बदलाव न दिखाई दे, तो किसी अन्य क्षेत्र में जाने के बाद जाँचें.
जब कनेक्शन लगातार न मिले या कुछ क्षेत्रों में आवाज़ सुनाई न दे.	जब कुछ क्षेत्रों में आवृत्ति वातावरण अस्थिर होता है, तो कनेक्शन लगातार नहीं मिलता और आवाज़ ठीक से सुनाई नहीं देती. किसी दूसरे क्षेत्र में जाएँ और पुन: प्रयास करें.
जब कनेक्शन ठीक से नहीं मिलता या मिलने पर बीच में टूटता है.	जब आवृत्ति अस्थिर या कमजोर होती है, या जब उपयोगकर्ता अधिक होते हैं, तो स्थापित होने के बाद भी कनेक्शन कट सकता है. कृपया कुछ देर बाद प्रयास करें या किसी दूसरे क्षेत्र में जाकर पुन: प्रयास करें.
जब एलसीडी चालू नहीं होती.	बैटरी निकालें और फिर इसे पुन: लगाकर पावर चालू करें. यदि तब भी स्थिति न बदले, तो बैटरी को पर्याप्त चार्ज करने के बाद पुन: प्रयास करें.
यदि किसी क्षेत्र में किसी टेलीफोन से कनेक्शन मिलने पर प्रतिध्वनि सुनाई देती है.	इसे ''प्रतिध्वनि आभास'' कहा जाता है, यह तब होता है जब कनेक्शन वॉल्यूम बहुत ज़्यादा होता है या दूसरी तरफ मशीन के विशेष गुणधर्मों के कारण होता है (सेमीइलेक्ट्रॉनिक टेलीफोन एक्सचेंज).

जब ऐसे लक्षण दिखाई दें :	तो यह जाँचें!
जब फोन गर्म हो.	यदि कनेक्शन लंबी अवधि के लिए स्थापित होता है, या गेम और इंटरनेट और अन्य लंबी अवधि के लिए चलते हैं, तो फोन गर्म हो सकता है. इससे उत्पाद के जीवनकाल या प्रदर्शन पर कोई प्रभाव नहीं पड़ता.
जब रिंग नहीं बजती, या स्क्रीन लाइट या एल सी डी चमकती है.	रिंग प्रकार ''मौन'' या ''लाइट'' के रूप में सेट हो सकता है. कृपया ''रिंग'' चुनें.
बैटरी की स्टैंडबाय अवधि धीरे-धीरे कम होती जाती है.	चूँकि बैटरी बाहर से लगी होती है, इसलिए इसका जीवनकाल धीरे-धीरे कम होता जाता है. यदि इसका जीवनकाल खरीदे जाने के बाद से आधा रह गया हो, तो आपको नई बैटरी खरीदनी चाहिए.
जब बैटरी के उपयोग का समय कम हो जाता है.	यदि बैटरी के उपयोग का समय कम हो गया है, तो यह उपयोगकर्ता के वातावरण, या अधिक कॉल्स, या कमजोर संकेतों के कारण हो सकता है.

टी आई ए सुरक्षा जानकारी

वायरलेस हैंडहेल्ड फोन के लिए टी आई ए की सुरक्षा संबंधी सारी जानकारी यहाँ दी गई है. सी टी आई ए मान्यता के लिए ग्राहक दिशानिर्देश पुस्तिका में पेसमेकर, श्रवण यंत्र और अन्य चिकित्सकीय उपकरण संबंधी जानकारी शामिल करना आवश्यक होता है. उपयुक्त होने पर शेष टी आई ए भाषाओं के उपयोग के लिए प्रोत्साहन दिया जाता है.

रेडियो फ्रीक्वेंसी संकेतों का एक्सपोज़र

आपका वायरलेस हैंडहेल्ड पोर्टेबल टेलीफोन एक कम शक्ति वाला रेडियो ट्रांसमीटर और रिसीवर है. चालू होने पर यह रेडियो फ्रीक्वेंसी (आर एफ) संकेत प्राप्त करता और भेजता भी है.

अगस्त 1996 में फेडरल कम्युनिकेशन्स कमीशन (एफ सी सी) ने हैंडहेल्ड वायरलेस फोन के लिए सुरक्षा स्तरों सहित आर एफ एक्सपोज़र दिशानिर्देश अपनाए. वे दिशानिर्देश संयुक्त राज्य और अंतर्राष्ट्रीय मानक निकायों द्वारा निर्धारित पिछले सुरक्षा मानकों के अनुरूप हैं :

ए एन एस आई सी 95.1 (1992)
एन सी आर पी रिपोर्ट 86 (1986)
आई सी एन आई आर पी (1996)

ये मानक, प्रासंगिक वैज्ञानिक साहित्य के समग्र और समय-समय पर हुए मूल्यांकनों पर आधारित थे. उदाहरण के लिए ए एन एस आई मानक (सी 95.1) बनाने के लिए विश्वविद्यालयों, सरकारी स्वास्थ्य एजेंसियों, और उद्योगों के 120 से अधिक वैज्ञानिकों, इंजीनियरों और चिकित्सकों ने अनुसंधान की उपलब्ध जानकारी की समीक्षा की.

आपके फोन की डिज़ाइन एफ सी सी दिशानिर्देश (और उन मानकों) का पालन करती है.

एंटीना की देखभाल

केवल प्रदान किए गए या मान्यता प्राप्त बदले गए एंटीना का ही उपयोग करें. अनधिकृत एंटीना, संशोधन या अनुलग्नकों के कारण फोन क्षतिग्रस्त हो सकता है और इससे एफ सी सी नियमों का उल्लंघन हो सकता है.

फोन संचालन

सामान्य स्थिति : किसी अन्य टेलीफोन के समान ही इस फोन को पकड़ें, एंटीना ऊपर की ओर रहे और आपके कंधे से ऊपर हो.

कुशल संचालन की युक्तियाँ

- अपने फोन को अधिक कुशलता से संचालित करने के लिए :

जब फोन का उपयोग हो रहा हो तो अनावश्यक रूप से एंटीना न छुएँ. एंटीना छूने से कॉल की गुणवत्ता प्रभावित होती है और इससे फोन की ऊर्जा आवश्यकता से अधिक खर्च हो सकती है.

- अमेरिकन नेशनल स्टैंडर्ड्स इंस्टीट्यूट, नेशनल काउंसिल ऑन रेडिएशन प्रोटेक्शन एंड मेजरमेंट, इंटरनेशनल कमीशन ऑन नॉन-आयोनाइजिंग रेडिएशन प्रोटेक्शन.

वाहन चालन

जिन क्षेत्रों में आप वाहन चला रहे हैं, उन क्षेत्रों के वायरलेस टेलीफोन के उपयोग संबंधी कानून और नियम देख लें. हमेशा उनका पालन करें. साथ ही वाहन चलाते समय यदि आप अपने फोन का उपयोग कर रहे हैं, तो कृपया :

- वाहन चलाने पर पूरा ध्यान दें-सुरक्षित वाहन चालन आपकी पहली जिम्मेदारी है.
- यदि उपलब्ध हो, तो हैंड्स-फ्री ऑपरेशन का उपयोग करें.
- यदि आवश्यकता हो, तो सड़क से हटकर गाड़ी पार्क करने के बाद कॉल करें या उत्तर दें.

इलेक्ट्रॉनिक उपकरण

अधिकांश आधुनिक इलेक्ट्रॉनिक उपकरण आर एफ संकेतों से सुरक्षित होते हैं. फिर भी, कुछ इलेक्ट्रॉनिक उपकरण आपके वायरलेस फोन से निकलने वाले आर एफ संकेतों से सुरक्षित नहीं भी हो सकते हैं.

पेसमेकर्स

हेल्थ इंडस्ट्री मैन्युफैक्चरर्स एसोसिएशन अनुशंसा करता है कि हैंडहेल्ड

वायरलेस फोन और पेसमेकर के बीच कम से कम छह (6'') इंच की दूरी होनी चाहिए, ताकि पेसमेकर में संभावित अवरोध टाला जा सके. ये अनुशंसाएँ वायरलेस टेक्नोलॉजी रिसर्च के स्वतंत्र अनुसंधान और अनुशंसाओं के अनुरूप हैं.

पेसमेकर वाले व्यक्ति:

- फोन चालू करने पर अपने पेसमेकर और फोन के बीच हमेशा छह इंच से अधिक दूरी बनाए रखें.
- सीने पर बने जेब में फोन न रखें.
- पेसमेकर के दूसरी तरफ के कान का उपयोग करें, ताकि संभावित अवरोध न्यूनतम हो सके.
- यदि किसी कारण आपको संदेह होता है कि अवरोध आ रहा है तो अपना फोन तुरंत बंद कर दें.

श्रवण यंत्र

कुछ डिजिटल वायरलेस फोन श्रवण यंत्रों के कार्य में अवरोध डाल सकते हैं. ऐसा अवरोध आने पर आप विकल्पों की जानकारी प्राप्त करने के लिए LG अधिकृत सर्विस सेंटर से संपर्क कर सकते हैं. प्रत्येक फोन निर्माता के लिए वैकल्पिक.

अन्य चिकित्सकीय उपकरण

यदि आप किसी अन्य व्यक्तिगत चिकित्सकीय उपकरण का उपयोग करते हैं, तो अपने उपकरण के निर्माता से परामर्श कर निर्धारित कर लें कि क्या वे बाहरी आर एफ ऊर्जा से पर्याप्त सुरक्षित हैं. यह जानकारी प्राप्त करने में आपका चिकित्सक आपकी सहायता कर सकता है.

स्वास्थ्य रक्षा से जुड़े संस्थानों में निर्देश दिए जाने पर अपना फोन बंद कर दें. अस्पतालों या स्वास्थ्य रक्षा संस्थानों में ऐसे उपकरण हो सकते हैं जो बाहरी आर एफ ऊर्जा के प्रति संवेदनशील होते हैं.

वाहन

आर एफ संकेत मोटर वाहनों में गलत ढंग से लगाए गए या अपर्याप्त सुरक्षित

इलेक्ट्रॉनिक सिस्टम्स को प्रभावित कर सकते हैं. अपने वाहन के संबंध में निर्माता या उसके प्रतिनिधि से पूछताछ कर लें.

आपके वाहन में लगे उपकरण के निर्माताओं से आपको परामर्श करना चाहिए.

पोस्टेड सुविधाएँ

यदि कहीं पर आपका फोन बंद करने संबंधी सूचना लगी हो, तो इनका पालन करें.

विमान

एफ सी सी नियम के अनुसार विमान में यात्रा करते समय फोन का उपयोग वर्जित है. विमान में चढ़ने से पहले अपना फोन बंद कर दें.

विस्फोट क्षेत्र

विस्फोट कार्यों में अवरोध टालने के लिए ''विस्फोट क्षेत्र'' में या जहाँ ''दोतरफा रेडियो बंद रखें'' की सूचना लगी हो, अपना फोन बंद रखें. सभी संकेतों और सूचनाओं का पालन करें.

संभावित विस्फोटक वातावरण

संभावित विस्फोटक क्षेत्र में होने पर अपना फोन बंद कर दें और सभी संकेतों और निर्देशों का पालन करें. ऐसे क्षेत्रों में चिंगारी उठने से भी विस्फोट हो सकता है या आग लग सकती है जिससे शारीरिक चोट लग सकती है या मौत भी हो सकती है.

संभावित विस्फोटक क्षेत्र अक्सर, लेकिन हमेशा नहीं, स्पष्ट रूप से चिह्नित होते हैं. संभावित क्षेत्रों में ये शामिल हो सकते हैं : ईंधन क्षेत्र (जैसे पेट्रोल पंप); बोट में डेक के नीचे; ईंधन या रसायन परिवहन या भंडारण गृह; तरल पेट्रोलियम गैस (जैसे प्रोपेन या ब्यूटेन) का उपयोग करने वाले वाहन; ऐसे क्षेत्र जहाँ हवा में रसायन या कण होते हैं (जैसे दाने, धूल या धातु के पाउडर) और ऐसे क्षेत्र जहाँ आपको सामान्यत: अपने वाहन का इंजन बंद करने की सलाह दी जाती है.

एयरबैग से सुसज्जित वाहनों के लिए

अधिक बल के कारण एयरबैग फूलता है. स्थापित या पोर्टेबल वायरलेस उपकरण सहित कोई भी वस्तु एयरबैग के ऊपर के क्षेत्र या एयरबैग लगे क्षेत्र में न रखें. यदि वाहन में वायरलेस उपकरण गलत ढंग से लगा हो और एयरबैग फूलता है, तो गंभीर चोट लग सकती है.

एफ डी ए ग्राहक अद्यतन

मोबाइल फोन के बारे में यू.एस. फूड एंड ड्रग एडमिनिस्ट्रेशन सेंटर फॉर डिवाइसेस एंड रेडियोलॉजिकल हेल्प कंज्यूमर का अद्यतन.

1. **क्या वायरलेस फोन स्वास्थ्य के लिए हानिकारक है?**
   उपलब्ध वैज्ञानिक साक्ष्य यह नहीं बताते कि वायरलेस फोन से कोई स्वास्थ्य समस्या जुड़ी है. हालाँकि, इसका कोई प्रमाण भी नहीं है कि वायरलेस फोन बिलकुल सुरक्षित हैं. उपयोग के दौरान वायरलेस फोन माइक्रोवेव रेंज में निम्न रेडियो फ्रीक्वेंसी (आर एफ) ऊर्जा उत्सर्जित करता है. स्टैंडबाय मोड में भी वे बहुत कम आरएफ उत्सर्जित करते हैं. आर एफ का ऊँचा स्तर स्वास्थ्य को प्रभावित (कोशिकाओं को गर्म करके) कर सकता है, जबकि निम्न स्तर की आरएफ के संपर्क से कोई ज्ञात स्वास्थ्य संबंधी दुष्प्रभाव नहीं हैं. निम्न स्तर की आर एफ के संपर्क के लिए हुए कई अध्ययनों में इसका कोई जैविक प्रभाव नहीं पाया गया. कुछ अध्ययन बताते हैं कि इसके कुछ जैविक प्रभाव हो सकते हैं, लेकिन अन्य अनुसंधानों से इसकी पुष्टि नहीं हुई. कुछ मामलों में तो अन्य अनुसंधानकर्ताओं को वही परिणाम पुन: प्राप्त करने, या अनियमित परिणामों की वजह से कारण निर्धारित करने में कठिनाई आई.

2. **वायरलेस फोन की सुरक्षा के संबंध में एफ डी ए की क्या भूमिका है?**
   कानून के अंतर्गत, एफ डी ए वायरलेस फोन जैसे विकिरण पैदा करने

वाले उपभोक्ता उत्पादों की बिक्री से पहले सुरक्षा समीक्षा नहीं करता, जैसा कि यह नई दवाइयों या चिकित्सकीय उपकरणों के साथ करता है. फिर भी, यदि यह पाया जाता है कि वायरलेस फोन उपयोगकर्ता के लिए घातक स्तर की रेडियो फ्रीक्वेंसी ऊर्जा (आर एफ) उत्सर्जित करता है तो एजेंसी को कार्रवाई करने का अधिकार है. ऐसी स्थिति में एफ डी ए, स्वास्थ्य के लिए फोन के खतरों और उसकी मरम्मत, बदलने या वापस लेने की सूचना उपभोक्ताओं को देना वायरलेस फोन निर्माताओं के लिए अनिवार्य कर सकता है, ताकि खतरा समाप्त किया जा सके.

हालाँकि उपलब्ध वैज्ञानिक आँकड़ों के अनुसार एफ डी ए की ये नियामक कार्रवाइयाँ आवश्यक नहीं हैं, फिर भी एफ डी ए ने फोन उद्योग से कई उपाय अपनाने का आग्रह किया है, जिसमें निम्न भी शामिल हैं:

- वायरलेस फोन द्वारा उत्सर्जित आरएफ से संभावित जैविक प्रभावों के लिए अनुसंधान में सहायता देना.
- वायरलेस फोन को इस तरह डिज़ाइन करना, जिससे उपयोगकर्ता के लिए ऐसा आर एफ एक्सपोज़र न्यूनतम किया जा सके जो फोन के कार्य करने के लिए आवश्यक नहीं है; और
- वायरलेस फोन के मानव स्वास्थ्य पर पड़ने वाले संभावित प्रभावों पर हर संभव जानकारी वायरलेस फोन के उपयोगकर्ताओं को उपलब्ध कराने में सहायता करना.

एफ डी ए, संघीय एजेंसियों के अंतर एजेंसी कार्यसमूह से संबद्ध है जो संघीय स्तर पर आर एफ सुरक्षा के विभिन्न पहलुओं पर सामंजस्यपूर्ण प्रयास सुनिश्चित करने के लिए उत्तरदायी है. इस कार्यसमूह में निम्न एजेंसियाँ हैं:

- नेशनल इंस्टीट्यूट फॉर ऑक्युपेशनल सेफ्टी एंड हेल्थ
- एन्वायरनमेंटल प्रोटेक्शन एजेंसी
- ऑक्युपेशनल सेफ्टी एंड हेल्थ एडमिनिस्ट्रेशन
- नेशनल टेलीकम्युनिकेशंस एंड इन्फॉर्मेशन एडमिनिस्ट्रेशन

नेशनल इंस्टीट्यूट ऑफ हेल्थ, कुछ अंतर एजेंसी कार्यसमूह की गतिविधियों में भी भाग लेती है. एफ डी ए फेडरल कम्युनिकेशंस कमीशन (एफ सी सी) के साथ वायरलेस फोन के लिए नियामक उत्तरदायित्वों का निर्वहन करता है. यह अनिवार्य है कि संयुक्त राज्य में बेचे जाने वाले सभी फोन आर एफ एक्सपोज़र को सीमित करने वाले एफ सी सी सुरक्षा दिशानिर्देशों का पालन करें. एफ सी सी वायरलेस फोन संबंधी सुरक्षा के प्रश्नों के लिए एफ डी ए और अन्य स्वास्थ्य एजेंसियों पर निर्भर है.

एफ सी सी उन आधार स्टेशनों का भी नियमन करती है जिन पर वायरलेस फोन नेटवर्क काम करते हैं. हालाँकि ये आधार स्टेशन वायरलेस फोन्स की तुलना में अधिक ऊर्जा पर कार्य करते हैं, लेकिन इनका आर एफ एक्सपोज़र आमतौर पर वायरलेस फोन की तुलना में हज़ारों गुना कम होता है. इसलिए आधार स्टेशन इस दस्तावेज़ की सुरक्षा संबंधी चर्चा का विषय नहीं है.

3. इस अद्यतन का विषय किस प्रकार के फोन हैं?

यहाँ पर ''वायरलेस फोन'' का अर्थ है बिल्ट-इन एंटीना युक्त हैंडहेल्ड वायरलेस फोन, जिन्हें आमतौर पर ''सेल', ''मोबाइल'', या ''पी सी एस'' फोन कहा जाता है. फोन और उपयोगकर्ता के सिर के बीच काफी कम अंतर होने के कारण इस प्रकार के वायरलेस फोन उपयोगकर्ता को रेडियो फ्रीक्वेंसी ऊर्जा (आर एफ) के संपर्क में ला सकते हैं.

ये आर एफ एक्सपोज़र फेडरल कम्युनिकेशन्स कमीशन के सुरक्षा दिशानिर्देशों द्वारा सीमित किए गए हैं, जो एफ डी ए और अन्य संघीय स्वास्थ्य व सुरक्षा एजेंसियों की सलाह पर बनाए गए हैं. जब फोन उपयोगकर्ता से अधिक दूर होता है, तो आर एफ एक्सपोज़र अत्यंत कम होता है क्योंकि स्रोत से दूरी बढ़ने के साथ-साथ व्यक्ति का आर एफ एक्सपोज़र तेजी से कम होता जाता है. तथाकथित ''कॉर्डलेस फोन' जिनकी आधार इकाई घर में टेलीफोन वायरिंग से जुड़ी होती

है, वे अत्यंत कम ऊर्जा स्तरों पर चलते हैं जिससे उत्सर्जित आरएफ एक्सपोज़र एफ सी सी सुरक्षा सीमाओं से काफी कम होता है.

4. पिछले अनुसंधानों के क्या परिणाम हैं?

अब तक हुए अनुसंधानों के परिणाम विरोधाभासी हैं और कई अध्ययनों की अनुसंधान पद्धतियों में त्रुटियाँ रही हैं. पशुओं पर किए गए वायरलेस फोन के रेडियो फ्रीक्वेंसी ऊर्जा (आर एफ) एक्सपोज़र प्रभावों का अध्ययन करने वाले प्रयोगों के विरोधाभासी परिणाम आए हैं, जिन्हें अन्य प्रयोगशालाओं में दोहराया नहीं जा सकता. हालाँकि पशुओं पर किए गए कुछ प्रयोगों से संकेत मिला है कि कम स्तर का आर एफ एक्सपोज़र प्रयोगशाला के पशुओं में कैंसर को बढ़ा सकता है. हालाँकि, ऐसे कई अध्ययन जिनमें ट्यूमर का विकास तेज़ दिखाई दिया, ऐसे पशुओं पर किए गए थे जिन्हें जैव अभियांत्रिक या कैंसर पैदा करने वाले रसायनों से उपचारित किया गया था, जो कि आर एफ एक्सपोज़र की अनुपस्थिति में भी कैंसर का कारण हो सकता है. अन्य अध्ययनों में पशुओं को प्रतिदिन 22 घंटों तक आर एफ के संपर्क में रखा गया था. ये स्थितियाँ वैसी नहीं हैं जिनका सामना लोग वायरलेस फोन का उपयोग करते समय करते हैं, इसलिए निश्चित रूप से यह नहीं कहा सकता कि ऐसे अध्ययनों के परिणाम मानव स्वास्थ्य के लिए क्या अर्थ रखते हैं.

दिसंबर 2000 के बाद तीन बड़े इपिडमियोलॉजिकल अध्ययन प्रकाशित हो चुके हैं. अध्ययनों ने वायरलेस फोन के उपयोग और प्रारंभिक मस्तिष्क कैंसर, ग्लायोमा, मेनिंजियोमा, या एकॉस्टिक न्यूरोमा, मस्तिष्क का ट्यूमर या सलाइवरी ग्लैंड, ल्यूकेमिया या अन्य कैंसर के बीच संभावित संबंधों की जाँच की. इनमें से किसी भी अध्ययन से वायरलेस फोन के आर एफ एक्सपोज़र से मानव स्वास्थ्य पर दुष्प्रभाव के संकेत नहीं मिलते. हालाँकि, कोई भी अध्ययन दीर्घकालीन एक्सपोज़र संबंधी प्रश्नों के उत्तर नहीं दे

सकता, क्योंकि इन अध्ययनों में फोन के उपयोग की औसत अवधि करीब तीन वर्ष थी.

5. यह निर्धारित करने के लिए कि वायरलेस फोन के आर एफ एक्सपोज़र स्वास्थ्य के लिए खतरा है या नहीं, किस शोध की आवश्यकता है?

प्रयोगशाला अध्ययनों और वायरलेस फोन के उपयोगकर्ताओं के इपिडमियोलॉजिकल अध्ययन को मिलाने पर आवश्यक जानकारी मिलेगी. आजीवन पशु एक्सपोज़र अध्ययन कुछ वर्षो में पूर्ण हो सकते हैं. हालाँकि, कैंसर की वृद्धि के विश्वसनीय प्रमाण, यदि है तो, देने के लिए बड़ी संख्या में पशुओं की आवश्यकता होगी. इपिडमियोलॉजिकल अध्ययन ऐसा डेटा प्रदान कर सकते हैं जो सीधे मानव जाति पर लागू हों, लेकिन कैंसर जैसे कुछ स्वास्थ्य प्रभावों संबंधी प्रश्नों के उत्तर देने के लिए 10 या अधिक वर्षो का फॉलो-अप आवश्यक होगा. ऐसा इसलिए क्योंकि कैंसर उत्पन्न करने वाले कारक के एक्सपोज़र और ट्यूमर के विकास - यदि ऐसा होता है तो - के बीच का समय कई, कई वर्ष हो सकता है. वायरलेस फोन के दैनिक उपयोग के दौरान वास्तविक आर एफ एक्सपोज़र मापने में होने वाली कठिनाइयों से इपिडमियोलॉजिकल अध्ययनों की व्याख्या प्रभावित हुई है. इस माप को कई कारक प्रभावित करते हैं जैसे फोन पकड़ने का कोण या उपयोग किए जा रहे फोन का मॉडल.

6. वायरलेस फोन आर एफ के स्वास्थ्य पर पड़ने वाले संभावित प्रभावों के बारे में अधिक जानकारी के लिए एफ डी ए क्या कर रहा है?

रेडियो फ्रीक्वेंसी ऊर्जा (आर एफ) के एक्सपोज़र संबंधी महत्वपूर्ण प्रश्नों के उत्तर प्राप्त करने के लिए उच्च प्राथमिकता वाले पशु अध्ययन सुनिश्चित करने के लिए एफ डी ए द्वारा यू. एस. नेशनल टॉक्सिकोलॉजी प्रोग्राम और विश्व भर के जाँचकर्ताओं के समूहों के

साथ मिलकर कार्य किया जा रहा है. 1996 में वर्ल्ड हेल्थ ऑर्गेनाइज़ेशन इंटरनेशनल इलेक्ट्रॉमैग्नेटिक फील्ड्स (ई एम एफ) प्रोजेक्ट के आरंभ से ही एफ डी ए इसमें अग्रणी भागीदार रहा है. इस कार्य का प्रभावी परिणाम अनुसंधान आवश्यकताओं के लिए एक विस्तृत कार्यसूची का विकास रहा है जिसने विश्व भर में नए अनुसंधान कार्यक्रमों की स्थापना कराई. प्रोजेक्ट ने ई एम एफ मामलों पर सार्वजनिक जानकारी दस्तावेज़ों की एक श्रृंखला विकसित करने में भी मदद की है.

वायरलेस फोन सुरक्षा पर अध्ययन करने के लिए एफ डी ए और सेल्युलर टेलीकम्युनिकेशन एंड इंटरनेट एसोसिएशन (सी टी आई ए) के बीच एक औपचारिक कोऑपरेटिव रिसर्च एंड डेवलपमेंट एग्रीमेंट (सी आर ए डी ए) हुआ है. सरकार के विशेषज्ञों, उद्योगों और शैक्षणिक संस्थानों से जानकारी लेकर एफ डी ए वैज्ञानिक परिदृश्य प्रदान करती है. सी टी आई ए प्रायोजित अनुसंधान स्वतंत्र जाँचकर्ताओं से अनुबंध के माध्यम से चलाया गया है. प्रारंभिक अनुसंधान में प्रयोगशाला अध्ययन और वायरलेस फोन उपयोगकर्ताओं का अध्ययन शामिल होगा. विश्व भर में हुए नवीनतम अनुसंधान विकासों के संदर्भ में सी आर ए डी ए अतिरिक्त अनुसंधान आवश्यकताओं का व्यापक मूल्यांकन भी शामिल करेगा.

7. मुझे कैसे पता चलेगा कि अपने वायरलेस फोन के उपयोग से मुझे कितना रेडियो फ्रीक्वेंसी एक्सपोज़र मिल रहा है?

संयुक्त राज्य में बेचे गए सारे फोन्स को फेडरल कम्युनिकेशन्स कमीशन (एफ सी सी) के दिशानिर्देशों का पालन करना आवश्यक है जो रेडियो फ्रीक्वेंसी ऊर्जा (आर एफ) एक्सपोज़र को सीमित करते हैं. एफ सी सी ने यह दिशानिर्देश एफ डी ए और अन्य संघीय स्वास्थ्य व सुरक्षा एजेंसियों के परामर्श से स्थापित किए हैं. वायरलेस टेलीफोन से आर एफ एक्सपोज़र की एफ सी सी सीमा 1.6 वॉट प्रति किलोग्राम (1.6 वॉ/किग्रा) की स्पेसिफिक एब्ज़ॉर्पशन रेट (SAR)

पर तय की है. एफ सी सी सीमा इंस्टीट्यूट ऑफ इलेक्ट्रिकल एंड इलेक्ट्रॉनिक इंजीनियरिंग (आई ई ई ई) और नेशनल काउंसिल ऑन रेडिएशन प्रोटेक्शन एंड मेज़रमेंट द्वारा विकसित सुरक्षा मानकों के अनुरूप है. एक्सपोज़र सीमा ऊतकों से उस ऊष्मा निकालने की शारीरिक क्षमता जो वायरलेस फोन से अवशोषित की जाती है, के आधार पर निश्चित की जाती हैं और यह प्रभावित करने के स्तर से काफी नीचे सेट की जाती है. वायरलेस फोन निर्माताओं को फोन के हर मॉडल का आर एफ एक्सपोज़र स्तर एफ सी सी को बताना होता है. एफ सी सी की वेबसाइट (http://www.fcc.gov/oet/rfsafety) आपके फोन पर एफ सी सी पहचान क्रमांक ढूँढने का निर्देश देती है जिससे आप ऑनलाइन सूची में अपने फोन का आर एफ एक्सपोज़र स्तर देख सकें.

8. वायरलेस फोन्स से निकलने वाली रेडियो फ्रीक्वेंसी ऊर्जा मापने के लिए एफ डी ए ने क्या किया है?

इंस्टीट्यूट ऑफ इलेक्ट्रिकल्स एंड इलेक्ट्रॉनिक इंजीनियर्स (आई ई ई ई), ने एफ डी ए के वैज्ञानिकों की सहभागिता व अगुवाई में वायरलेस फोन और अन्य वायरलेस हैंडसेट्स से उत्सर्जित रेडियो फ्रीक्वेंसी ऊर्जा (आर एफ) मापने के लिए एक तकनीकी मानक विकसित किया है. यह जाँचता है कि वायरलेस फोन उपयोगकर्ताओं के सिरों में किस दर से आर एफ जमा हुई है. इस जाँच पद्धति में मानव सिर के एक ऊतक उत्प्रेरक मॉडल का उपयोग किया जाता है. मानकीकृत एस ए आर परीक्षण पद्धति से एक ही फोन पर भिन्न प्रयोगशालाओं में किए जाने वाले मापनों में काफी एकरूपता आने की अपेक्षा है. एस ए आर संपूर्ण शरीर या शरीर के छोटे अंग द्वारा ऊतक में अवशोषित ऊर्जा की मात्रा का मापन है. इसे पदार्थ के वॉट/किग्रा. (या मिलिवॉट/ग्रा) में मापा जाता है. इस माप का उपयोग यह निर्धारित करने के लिए किया जाता है कि कोई वायरलेस फोन सुरक्षा दिशानिर्देशों के अनुरूप है या नहीं.

9. अपने वायरलेस फोन से रेडियो फ्रीक्वेंसी ऊर्जा का एक्सपोज़र घटाने के लिए मैं क्या कर सकता हूँ?

यदि इन उत्पादों से कोई खतरा है भी - और इस समय हम नहीं जानते कि कोई खतरा है भी या नहीं - तो संभवत: ये बहुत कम है. लेकिन यदि आप संभावित खतरों से बचने के प्रति चिंतित हैं तो आप रेडियो फ्रीक्वेंसी ऊर्जा (आर एफ) का प्रभाव न्यूनतम करने के लिए कुछ आसान कदम उठा सकते हैं. चूँकि व्यक्ति को कितना एक्सपोज़र मिलता है, इसका सबसे मुख्य कारक समय है, इसलिए वायरलेस फोन के उपयोग की अवधि घटाकर आर एफ एक्सपोज़र घटाया जा सकता है.

- यदि आप प्रतिदिन वायरलेस फोन से लंबी बात करते हैं तो आप शरीर और आरएफ स्रोत के बीच ज़्यादा दूरी रख सकते हैं, क्योंकि दूरी बढ़ने के साथ एक्सपोज़र का स्तर नाटकीय रूप से गिरता है. उदाहरण के लिए आप एक हेड सेट का उपयोग करके वायरलेस फोन को शरीर से दूर रख सकते हैं या रिमोट एंटीना से जुड़े वायरलेस फोन का उपयोग कर सकते हैं.

पुन:, वैज्ञानिक डेटा यह नहीं दर्शाते कि वायरलेस फोन हानिकारक हैं. लेकिन यदि आप इन उत्पादों के आर एफ एक्सपोज़र से चिंतित हैं तो आप उपरोक्त उपाय अपनाकर वायरलेस फोन का आरएफ एक्सपोज़र घटा सकते हैं.

10. वायरलेस फोन का उपयोग करने वाले बच्चों पर क्या प्रभाव होगा?

वैज्ञानिक प्रमाण वायरलेस फोन के उपयोगकर्ताओं के लिए कोई खतरा नहीं बताते, इसमें बच्चे और किशोर भी शामिल हैं. यदि आप रेडियो फ्रीक्वेंसी ऊर्जा (आर एफ) एक्सपोज़र घटाने के लिए कदम उठाना चाहते हैं तो उपरोक्त उपाय वायरलेस फोन का उपयोग करने वाले बच्चे व किशोर भी अपना सकते हैं. वायरलेस फोन के उपयोग का समय कम करके और उपयोगकर्ता व आर एफ स्रोत के बीच की

दूरी बढ़ाकर एक्सपोज़र घटाया जा सकता है.

अन्य राष्ट्रीय सरकारों द्वारा प्रायोजित कुछ समूहों ने सलाह दी है कि बच्चों को वायरलेस फोन के उपयोग से रोकना चाहिए. उदाहरण के लिए, युनाइटेड किंगडम सरकार ने दिसंबर 2000 में एक ऐसा ही पत्रक बाँटा था. उन्होंने कहा कि ऐसा कोई प्रमाण नहीं है कि वायरलेस फोन के उपयोग से ब्रेन ट्यूमर या अन्य बुरे प्रभाव पड़ सकते हैं. बच्चों के लिए वायरलेस का उपयोग सीमित करना सिर्फ सावधानी के रूप में उठाया गया कदम था; यह किसी वैज्ञानिक प्रमाण पर आधारित नहीं था जिसमें स्वास्थ्य पर बुरा प्रभाव पड़ने की बात हो.

11. वायरलेस फोन चिकित्सकीय उपकरणों में क्या हस्तक्षेप करता है?

वायरलेस फोन की रेडियो फ्रीक्वेंसी ऊर्जा (आर एफ) कुछ इलेक्ट्रॉनिक उपकरणों से प्रतिक्रिया कर सकती है. इसी कारण से एफ डी ए ने पेसमेकर्स और डिफिब्रिलेटर्स के कार्य में वायरलेस फोन से पड़ने वाला इलेक्ट्रोमैग्नेटिक अवरोध (ई एम आई) मापने के लिए एक विस्तृत जाँच पद्धति विकसित की है. यह जाँच पद्धति अब एसोसिएशन फॉर द एडवांसमेंट ऑफ मेडिकल इंस्ट्रूमेंटेशन (ए ए एम आई) द्वारा प्रायोजित मानक का एक भाग है. एफ डी ए, चिकित्सकीय उपकरण निर्माताओं और कई अन्य समूहों के संयुक्त प्रयासों से बना अंतिम ड्रॉफ्ट 2000 के अंत तक पूर्ण हुआ था. इस मानक की बदौलत उत्पादक ये सुनिश्चित करेंगे कि पेसमेकर और डिफिब्रिलेटर्स वायरलेस फोन ई एम आई से सुरक्षित हैं.

एफ डी ए ने हैंडहेल्ड वायरलेस फोन से श्रवण यंत्रों में पड़ने वाले अवरोध की भी जाँच की है और इंस्टीट्यूट ऑफ इलेक्ट्रिकल एंड इलेक्ट्रॉनिक इंजीनियर्स (आई ई ई ई) द्वारा प्रायोजित स्वैच्छिक मानक विकसित करने में मदद की. यह मानक श्रवण यंत्र और वायरलेस फोन के लिए परीक्षण विधियाँ और कार्यक्षमता आवश्यकताएँ बताते हैं ताकि जब व्यक्ति एक साथ ''संगत'' फोन और ''संगत'' श्रवण यंत्र उपयोग करे तो कोई अवरोध न आए. यह

मानक 2000 में आई ई ई ई द्वारा स्वीकृत किया गया था.

वायरलेस फोन से अन्य चिकित्सकीय उपकरणों पर पड़ने वाले प्रभावों पर एफ डी ए लगातार निगरानी रख रहा है. यदि हानिकारक अवरोध उत्पन्न होता है तो एफ डी ए अवरोध का आकलन करने हेतु जाँच करेगा और समस्या के समाधान का प्रयास करेगा.

12. मुझे अतिरिक्त जानकारी कहाँ से मिल सकती है?

अतिरिक्त जानकारी के लिए कृपया निम्न स्रोत देखें :

- वायरलेस फोन पर एफ डी ए का वेब पेज (http://www.fda.gov/cellphones
- फेडरल कम्युनिकेशन्स कमीशन (एफ सी सी) आर एफ सुरक्षा कार्यक्रम (http://www.fcc.gov/oet/rfsafety)
- इंटरनेशनल कमीशन ऑन नॉन-आयनाइज़िंग रेडिएशन प्रोटेक्शन (http://www.icnirp.de)
- विश्व स्वास्थ्य संगठन (डब्ल्यू एच ओ) अंतर्राष्ट्रीय ई एम एफ प्रोजेक्ट (http://www.who.int/emf)
- नेशनल रेडियोलॉजिकल प्रोटेक्शन बोर्ड (यू के) (http://www.nrpb.org.uk/)

एस ए आर पर उपभोक्ता जानकारी (स्पेसिफिक एब्ज़ॉर्पशन रेट)

यह मॉडल फोन, रेडियो तरंगों के एक्सपोज़र के लिए सरकार की आवश्यकताओं को पूरा करता है.

आपका वायरलेस फोन एक रेडियो ट्रांसमीटर और रिसीवर है. इसकी रचना व निर्माण इस प्रकार से हुआ है कि यू एस सरकार के फेडरल कम्युनिकेशन्स कमीशन द्वारा निर्धारित रेडियो फ्रीक्वेंसी एक्सपोज़र की सीमा का उल्लंघन न हो.

ये सीमाएँ व्यापक दिशानिर्देशों का ही एक हिस्सा हैं और सामान्य व्यक्ति के लिए आर एफ ऊर्जा का स्वीकृत स्तर निर्धारित करती हैं. दिशानिर्देश उन मानकों पर आधारित हैं जिन्हें स्वतंत्र वैज्ञानिक संस्थानों ने वैज्ञानिक अध्ययनों के समय-समय पर किए गए समग्र मूल्यांकन से विकसित किया है. मानकों में एक पर्याप्त अंतर शामिल है जिसकी रचना उम्र और स्वास्थ्य पर ध्यान दिए बगैर हर व्यक्ति की सुरक्षा सुनिश्चित करने के लिए हुई है.

वायरलेस मोबाइल फोन के लिए एक्सपोज़र मानक माप की एक इकाई देता है जिसे स्पेसिफिक एब्ज़ॉर्पशन रेट, या एस ए आर कहते हैं. एफ सी सी द्वारा एस ए आर सीमा 1.6 वॉ/किग्रा तय की गई है.* एस ए आर के लिए परीक्षण एफ सी सी द्वारा निर्धारित मानक संचालन स्थितियों में होता है जहाँ फोन सभी जाँचे गए आवृत्ति बैंड्स में अपने उच्चतम प्रमाणित पावर स्तर पर कार्य करता है. यद्यपि एस ए आर का निर्धारण उच्चतम प्रमाणित पावर स्तर पर होता है, लेकिन संचालन के दौरान वास्तविक एस ए आर स्तर उच्चतम मान से काफी नीचे हो सकता है. चूँकि फोन एकाधिक पावर स्तरों पर संचालन के लिए बनाया गया है ताकि वह उतनी ही पावर का उपयोग करे जो नेटवर्क तक पहुँचने के लिए आवश्यक है, इसलिए सामान्यत: आप वायरलेस आधार स्टेशन एंटीना के जितने करीब होंगे, पावर की खपत उतनी कम होगी.

किसी फोन को सार्वजनिक बिक्री के लिए उपलब्ध कराने से पहले, इसे एफ सी सी की इस जाँच में खरा उतरना और प्रमाणित होना आवश्यक होता है कि ये सरकार द्वारा सुरक्षित एक्सपोज़र के लिए अपनाई गई सीमा को पार नहीं करता. यह जाँच हर मॉडल के लिए एफ सी सी की आवश्यकता के अनुसार विभिन्न स्थितियों और स्थानों (उदा. कान पर और शरीर पर धारण

करने की स्थिति) पर किए जाते हैं. इस फोन के लिए उच्चतम एस ए आर मान कान के लिए जाँचने पर 0.591 वॉ/किग्रा और शरीर पर धारण करने के लिए, जैसा इस उपभोक्ता मार्गदर्शिका में बताया गया है, 0.620 वॉ/किग्रा है. (शरीर पर धारण करने के माप फोन मॉडल के आधार पर बदलते रहते हैं, जो उपलब्ध उपकरणों और एफ सी सी आवश्यकताओं पर आधारित होते हैं). विभिन्न फोन्स के एस ए आर स्तरों और विभिन्न स्थितियों के बीच अंतर हो सकता है, लेकिन वे सभी सुरक्षित एक्सपोज़र के लिए सरकार की आवश्यकताएँ पूरा करते है.

एफ सी सी ने इस फोन को एफ सी सी आर एफ उत्सर्जन दिशानिर्देशों के अनुरूप सभी एस ए आर स्तरों पर मूल्यांकित करते हुए उपकरण प्रमाणन दिया है. इस फोन की एस ए आर जानकारी एफ सी सी के पास है और इसे एफ सी सी आई डी BEJRD5130 पर खोजने के बाद http://www.fcc.gov/oet/fccid के डिस्प्ले ग्रांट अनुभाग में देखा जा सकता है.

स्पेसिफिक एब्ज़ॉर्पशन रेट्स (एस ए आर) पर अतिरिक्त जानकारी सेल्युलर टेलीकम्युनिकेशन्स इंडस्ट्री एसोसिएशन (सी टी आई ए) की वेबसाइट http://www.wow-com.com पर देखी जा सकती है.

- संयुक्त राज्य और कनाडा में जनता द्वारा उपयोग किए जाने वाले मोबाइल फोन्स के लिए एस ए आर सीमा औसतन एक ग्राम ऊतक पर 1.6 वॉट्स/किग्रा (वॉ/किग्रा) है. जनता को अतिरिक्त सुरक्षा देने और मापन की संभाव्य त्रुटि को ध्यान में रखते हुए मानक में सुरक्षा की पर्याप्त व्यवस्था है.

आप इस नंबर पर हमारे संपर्क केंद्र को कॉल कर सकते हैं.

आप सप्ताह के सातों दिन सुबह 9 से रात 9 के बीच कॉल कर सकते हैं. आपके कॉल का तुरंत उत्तर दिया जाएगा.