Part No. MMBB0163307 (1.0) H

Printed in Korea

LG-G233 使用手冊

繁體中文 / 简体中文 / ENGLISH

LG-G233

使用手冊

本使用手冊之部分內容和您的手機可能視乎手機內之軟件或您的網絡商而有所差異.

CE 0168

LG-G233 使用手冊 －繁體中文

目錄

簡介 6
安全與有效使用準則 7
LG-G233 功能 10
手機圖解 10
顯示資訊 13

開始使用 14
安裝智能咭與手機電池 14
爲電池充電 16
取出充電器 17
開啓/關閉手機電源 17
存取碼 18
限制密碼 18

一般功能 19
撥打與接聽電話 19
通訊錄 25
通話中功能表 25
多方通話 26

功能表結構 28
選擇功能與選項 31
情景模式 32
啓動情景模式 32
自訂情景模式 - 更改 32
自訂情景模式 - 重新命名 33

通話記錄 34
未接來電 34
已接來電 34
已撥電話 34
刪除最近通話記錄 35
通話計費 35
通話時間 35
通話費用 35
設定 35
GPRS記錄 36
通話時間 36
數據用量 36

工具 37
藍芽 37
我的裝置 37
免提裝置 37
設定 37
計數機 37
單位轉換器 37
時區設置 38
錄音器 38
記錄 38
查看列表 38
記憶體狀態 38

記事簿 39
通訊錄 39
搜尋 39
新增 39
群組 39
快速撥號 40
設定 40
複製全部 40
刪除全部 41
資訊 41
日程表 41
備忘錄 42

訊息 43
新訊息 43
寫文字訊息 43
寫多媒體訊息 44
收件箱 45
草稿箱 46
寄件箱 47
收聽留言訊息 48
資訊廣播 48
讀取 48
主題 48
常用範本 48
常用短語 48
多媒體範本 49

目錄

簽名 49

設定 50

文字訊息 50

多媒體訊息 50

留言信箱中心 51

資訊廣播 51

Push訊息 51

相機 52

拍照 52

拍攝在相框中 54

連環拍攝 54

相簿 55

設定 55

記憶體狀態 55

清除相簿 55

自動儲存 55

設定 56

鬧鐘 56

日期和時間 56

日期設定 56

日期格式 56

時間設定 56

時間格式 57

手機設定 57

顯示設定 57

語言 57

通話設定 57

來電轉接 57

接聽模式 58

發送我的號碼 58

來電等候 58

分鐘提示 59

自動重撥 59

密碼設定 59

需要PIN碼 59

手機鎖 59

通話限制 59

固定撥號 60

更改密碼 60
網絡設定 60
自動 60
手動 60
首選網絡 60
恢復原廠設定 61
GPRS設定 61

互聯網 62
互聯網 62
主頁 62
書籤 62
網絡設定 63
轉至URL 64
緩存設定 64
Cookies設定 65
安全認證 65
重新設定 65
瀏覽器版本 65
智能咭服務 65

下載 66
遊戲及更多 66
我的遊戲及更多 66
網絡設定 67
圖片 67
音樂 67

配件 68
技術資料 69

簡介

恭喜您購買 LG-G233 流動電話，本型號手機外形小巧、功能全面，專爲使用最新的數碼手提通訊技術而設計。

本使用手冊包含使用與操作手機的重要資訊， 請仔細閱讀所有資訊，以使手機發揮最大效能，並避免使手機遭到損壞或不當之使用。本手冊內任何未經同意之變更或修改，將使用户喪失設備保養之權益。

請閱讀下列簡單指引， 違反下列規定可能會造成危險或觸犯法律。詳細資訊如本手冊中所述。

曝露於無線電頻率能量

無線電波輻射和電磁波能量特定比吸收率(SAR)資訊

此 LG-G233 型號手機的設計符合有關無線電波輻射的安全要求。此要求根據科學原則而制定，並具有一定的安全範圍，可確保不同年齡和健康狀況之人體安全。

- 無線電波輻射標準所採用的計算單位稱爲「電磁波能量特定比吸收率」(Specific Absorption Rate，SAR)。測量 SAR 所採用的是標準方式，即測量手機在所有可用波段中以最高認可發射功率操作時的 SAR。
- 也許不同型號 LG 手機的 SAR 等級會有所差異，但所有手機的設計均符合無線電波輻射的相關標準。
- 根據國際非電離輻射防護委員會(INCRP)所發展的標準，適用於公眾的無線電話比吸收率(SAR)限制是平均每10克組織2.0瓦特/千克(W/kg)，而SAR在台灣的限制標準爲1.6瓦特/千克。
- LG-G233經政府認可的實驗室測試後, 此型號的最高比吸收率(SAR)值爲0.858瓦特/千克。
- 若要減少電池波的影響，請妥善使用手機!

產品保養與維護

警告：請僅使用此特定手機型號所認可的電池、充電器及配件。使用任何其他類型將會喪失相關的手機之保養權益，並有可能損壞手機。

使用任何其他類型的電池、充電器及配件，將會導致相關的手機保養權益失效，並有可能損壞手機。

- 請勿自行拆卸本裝置。在需要進行維修時，請由合格的維修技術人員維修。
- 手機應遠離電器設備，如電視、收音機或個人電腦。
- 手機應遠離熱源，如散熱器或電鍋附近。
- 切勿掉落手機。
- 避免讓手機承受機械性震動或撞擊。

- 如果用包裝帶或含乙烯基的物品包裝手機，手機表面的塗層可能會受損。
- 請使用乾布來清潔手機外殼 (請勿使用如苯、稀釋劑或酒精等溶劑)。
- 請勿將本裝置置於濃煙或塵埃中。
- 請勿將手機和信用卡或其他磁卡放在一起，否則可能會損壞磁條內的資訊。
- 請勿用尖銳物品觸碰螢幕，以免損壞手機。
- 請勿將手機置於液體或潮濕環境中。
- 小心使用如耳機等配件。
  如無必要請勿觸碰天線。

電子裝置

所有手機都可能受到干擾，從而影響其效能。

- 未經許可，請勿在醫療設備旁邊使用手機。請勿將手機置於心率調整器上，如胸前口袋中。
- 手機可能會對某些助聽器造成干擾。
- 少量干擾也可能會對電視、收音機、電腦等造成影響。

道路安全

請查閱您當地行車區域對於使用流動電話的法令與規定。

- 開車時切勿使用手提式手機。
- 請務必專心開車。
- 如有可能，請使用免提聽筒。
- 如行車狀況允許，請在路邊停車，然後再撥打或接聽電話。
- 無線電波可能會對您車上的電子系統造成影響，如汽車音響、安全設備。
- 如果您的汽車配備安全氣囊，請勿在其附近安裝或放置手提無線設備。不當操作將會導致嚴重傷害。

爆破區域

請勿於正在進行爆破作業的區域使用手機。

請參閱禁止告示，並遵守有關規則或條例。

具有潛在爆炸危險的環境

- 請勿在加油站使用手機。請勿在汽油或化學品附近使用手機。
- 車上攜有流動電話與配件時，請勿運載或儲存可燃氣體、液體或爆炸物在車廂內。

在飛機上

無線裝置會對飛機造成干擾。

- 上機前請務必關掉您的手機。
- 未經空中服務人員許可，請勿於飛機在地面停靠時使用手機。

兒童安全

請將手機置於兒童不易接觸的安全地方。手機有許多細小零件，若在拆解後誤食，可能會造成哽塞窒息的意外。

緊急電話

緊急電話不一定適用於所有手機網絡。

因此，請勿過於依賴手機來撥打緊急電話。詳情請諮詢您當地的服務供應商。

電池使用與保養

- 電池充電前，無須完全放電。與其他系統不同的是，本機所用電池的性能不會受到記憶效應的影響。
- 僅限使用LG電池和充電器。LG充電器是經過特別設計， 能增加電池壽命至最大極限。
- 請勿拆解或讓電池發生短路。
- 電池的金屬接點應保持清潔。
- 更換性能不再令人滿意的電池。充電數百次後，才需要更換電池。
- 已長期未使用的電池，請先進行充電以取得最大的效能。
- 請勿使電池充電器直接曝曬在陽光下，或在浴室等濕度高的場所中使用。
- 請勿把電池留置在過熱或過冷的地方，否則會降低電池效能。

手機圖解

前視圖

1. 耳機插孔
   - 在此連接耳機。
2. 上/下側面按鍵
   - 按此鍵可在副屏幕上顯示目前時間。
   - 在機蓋翻開的備用模式下，控制按鍵音的音量。
   - 控制通話過程中的聽筒音量。
3. 副屏幕
4. 照相機鏡頭

   附註 相機鏡頭上的污跡會影響圖像品質。
5. 閃光燈

右側視圖

數碼相機功能鍵

按住此鍵來啓動相機模式。
此鍵也可用來拍照。

後視圖

機蓋翻開視圖

1. **聽筒**

2, 10. **左軟鍵/右軟鍵:** 各個鍵可執行屏幕上即時顯示文字所示的功能。

3. **日程表鍵:** 「日程表」功能表快速鍵。

4. **發送鍵:** 用於撥打電話號碼與接聽來電。在備用模式下，按下此按鍵可快速存取最近來電、已撥電話及未接來電。

5. **英數字元鍵:** 用於輸入數字、字母及部分特殊字元。

6. **麥克風:** 在通話過程中按下此鍵可靜音以便保密。

7. **主屏幕:** 以全彩色顯示狀態圖示、功能表項目、網絡資訊、圖片等。

8. **導覽鍵:** 用於捲動功能表和移動游標。

9. **確認鍵:** 選擇功能表選項並確認動作。

11. **下載鍵:** 跳至「下載」功能表的快速鍵。

12. **結束/電源鍵:** 用於結束通話、拒接來電以及返回備用模式。按住此按鍵可開啓/關閉手機電源。

13. **清除鍵:** 每按一下可刪除一個字元。按住此按鍵可清除輸入的所有內容。此按鍵也用於返回之前的屏幕。

14. **特殊功能鍵:**

- : 長按此鍵可輸入國際通話字元「+」。
- : 輸入電話號碼時，長按此鍵可輸入代表停頓的符號。

顯示資訊

下表說明手機顯示屏幕上出現的各種顯示指示或圖示。

螢幕圖示

按 鍵	說　明
	表示網絡訊號強度。
	表示正在通話。
	表示正在其他網絡中漫遊。
	表示 GPRS 服務可用。
	表示已設定並啓動鬧鐘。
	表示電池電量狀態。
	表示收到文字訊息。
	表示收到訊息。
	表示「震動」情景模式已啓動。
	表示「大聲」情景模式已啓動。
	表示「靜音」情景模式已啓動。
	表示「聽筒」情景模式已啓動。
	表示「標準」情景模式已啓動。
	表示可以使用 Push 訊息服務。
	表示手機正在存取 WAP。
	表示正在使用 GPRS。
	表示已啓動藍芽功能。

安裝智能咭與手機電池

取出電池前，請先確定電源已經關閉。

1. 取出電池蓋。

按下電池釋放閂，朝手機底部方向滑出電池蓋。取出電池蓋。

附註 在電源開啓時取出手機電池可能會導致手機發生故障。

2. 取出電池。

握住電池上方邊緣，將電池拿出電池盒外。

3. 安裝智能咭。

將智能咭插入智能咭槽。請確定智能咭已正確插入，智能咭的金屬接觸區必須向下。要取出智能咭，請輕輕往下按，然後往反方向拉出。

插入智能咭

取出智能咭

附註 智能咭金屬接點容易因刮傷而損壞。拿取智能咭時請特別注意。請依照智能咭所附之說明書進行安裝。

4. 安裝電池。

先將電池底部插入電池盒下方邊緣。將電池上半部壓入定位。

5. 裝回電池蓋。

把電池蓋裝回手機，並將其滑入直至釋放閂發出卡嗒聲。

爲電池充電

將旅行充電器接駁至手機之前，您必須先安裝好電池。

1. 將旅行充電器的一端接頭插入手機底端。
2. 將充電器的另一端接駁至牆上的交流電源插座。請務必使用手機隨附的充電器。
3. 充電完畢後，電池圖標的移動式指示列將會停止動作。

附註

- 請勿強力推進接頭，這樣可能會損壞手機及/或旅行充電器。
- 將電池充電器垂直插入牆壁的電源插座。
- 若您是在其他國家/地區使用電池充電器，請使用符合當地規格的轉接頭配件。
- 在充電期間，請勿移除您的電池或智能咭。

警告

- 如遇上雷暴，請拔除電源線與充電器以防觸電或失火。
- 請勿讓動物牙齒、指甲等尖銳物接觸電池。這可能會有失火的危險。
- 手機正在充電時，請勿撥打或接聽來電，這可能會造成手機短路或失火。

取出充電器

1. 充電完成後，電池圖示中的狀態列會停止移動，手機屏幕上將會顯示「已滿」。
2. 中斷充電器與電源插座的連接。同時按下充電器接頭兩側的灰色彈片，然後將接頭拔出，以中斷充電器與手機的連接。

附註
- 首次使用手機時，請確保電池已完全充電。
- 在充電過程中，請勿取出電池或智能咭。
- 如果電池未完全充電，請用電源鍵關閉後再開啓手機電源，並重新爲電池充電。取出及重新裝回電池後，請爲電池重新充電。

開啓/關閉手機電源

開啓手機電源

1. 在手機中裝入電池，然後將手機連接至外部電源 (如充電器、車用點煙器充電器或免提車用套件)， 或在手機中裝入已充電的電池。
2. 按住 幾秒鐘，直到LCD屏幕的電源開啓。
3. 按需要PIN碼的狀態而定，您可能需要輸入 PIN 碼。

關閉手機電源

1. 按住 幾秒鐘，直到LCD屏幕的電源關閉。

存取碼

您可使用本章節中說明的存取碼，以防他人未經授權使用您的手機。您可變更存取碼 (PUK碼與PUK2碼除外)：使用**更改密碼**功能 [功能表-7-5-5] 即可。請參閱第60 頁。

PIN碼 (4 到 8 位數)

PIN(個人識別碼) 碼可防止他人未經授權使用您的智能咭。PIN碼通常隨智能咭一同提供。如果將**需要PIN碼**設爲**開啓**，則在每次開機時，手機均會要求輸入PIN碼。如果將**需要PIN碼**設爲**關閉**，則無需輸入PIN碼，手機會直接連線至網絡。

PIN2 碼 (4 到 8 位數)

需要使用 PIN2碼 (部分智能咭中隨附) 來存取如**通話計費**和**固定撥號**等功能。僅在智能咭支援這類功能的情況下才可使用。請諮詢網絡商以取得更多資訊。

PUK 碼 (4 到 8 位數)

需要使用 PUK(PIN解鎖碼) 碼才能更改已鎖定的 PIN碼。PUK碼可能已隨智能咭一同提供。如果智能咭中未提供，請諮詢網絡供應商以取得PUK碼。如果遺失此碼，也請與網絡供應商聯絡。

PUK2 碼 (4 到 8 位數)

需要使用PUK2碼 (部分智能咭中隨附) 才能更改已鎖定的PIN2碼。如果遺失此碼，也請與網絡供應商聯絡。

安全密碼 (4 到 8 位數)

安全密碼可用於防止他人未經授權使用您的手機。預設安全密碼已設爲「0000」，刪除任何手機記錄以及**恢復原廠設定**功能時都需要使用安全密碼。另外，啓動或關閉手機鎖定功能也要使用安全密碼，以防止他人未經授權使用您的手機。安全密碼預設值可在**密碼設定**功能表中修改。

限制密碼

使用**通話限制**功能[功能表-7-5-3] 時需要使用限制密碼。在您使用此功能時，網絡供應商會提供此密碼。請參閱第 59 頁以取得詳細資料。

撥打與接聽電話

撥打電話

1. 確定已開啓手機電源。
2. 輸入電話號碼 (包括區碼)。
   - ► 按住清除鍵 ( ) 可清除整個號碼
3. 按下發送鍵 ( ) 以撥打電話。
4. 要結束通話，請按下結束鍵 ( ) 或右軟鍵。

使用發送鍵撥打電話

1. 在備用模式下，按下發送鍵 ( )，最近來電、已撥電話及未接來電將會顯示。
2. 使用上/下導覽鍵選擇所需的號碼。
3. 按下 。

撥打國際電話

1. 按住 鍵以輸入國際首碼。「+」字元會自動選取國際碼。
2. 依次輸入國碼、區碼及電話號碼。
3. 按下 。

結束通話

結束通話之後，請按一下結束 ( ) 鍵。

透過通訊錄撥打電話

您可以將經常撥打的姓名和電話號碼儲存在智能咭/手機記憶體，也就是「通訊錄」中。 您可以在通訊錄中輕鬆查看聯絡人的姓名進行撥號。

調較音量

如果要在通話時調整聽筒音量，請使用側面按鍵 ( )。按下上側面按鍵可提高音量，按下下側面按鍵可降低音量。

附註 在備用模式下，按下側面按鍵可調整按鍵音的音量。

接聽來電

接到來電時，手機會發出鈴聲且手機圖標會在屏幕上閃爍。 如果手機可以識別來電者，則會顯示來電者的電話號碼 (或儲存在通訊錄中的姓名)。

1. 要接聽來電，請打開手機。(將**揭蓋接聽**設定爲接聽模式時。請參閱第58頁 [功能表-7-4-2]。)

附註 如果將**按任何鍵**設定爲接聽模式 (請參閱第 58 頁)，則按下除左右軟鍵之外的任何鍵，均會接聽來電。

► 要拒接來電，無需打開手機，按住手機左側的任何一側面按鍵即可。

► 使用通訊錄或其他功能表功能時可接聽來電。

2. 要結束通話，請合上機蓋或按下 鍵。

震動模式(快速)

打開手機後，按住左導覽鍵 可啓動震動模式。

訊號強度

透過手機LCD屏幕上的訊號指示 ( )可查看訊號強度。訊號強度會不斷變化，尤其是在建築物內時。靠近窗戶可提升接收效果。

輸入文字

使用手機按鍵可輸入英數字元。例如：在通訊錄中儲存姓名、建立訊息、建立問候語或在日程表中新增/修改事件等，都需要輸入文字。

本手機提供以下文字輸入法。

T9 模式

此模式可讓您以每個字母按一個按鍵的方式來輸入文字。鍵盤上的每個按鍵都具有多個字母。T9模式會自動將按鍵與內建字典進行比較以判斷正確的文字，因此需要按下的按鍵遠遠少於傳統 ABC 模式。這也稱爲預測文字功能。

ABC 模式

此模式可讓您輸入字母，方式爲按一下、兩下、三下或多下標記有所需字母的按鍵，直到所需字母出現爲止。

123 模式(數字模式)

以每個數字按一個按鍵的方式來鍵入數字。要在文字輸入欄位中變更爲 123 模式，請按下 鍵直到顯示 123 模式。

變更文本輸入模式

1. 在您處於允許輸入字元的欄位時，您會發現LCD屏幕右上角出現文字輸入模式指示。

2. 按下 [#] 以變更文字輸入模式。您可以在LCD屏幕的右上角檢查目前所用的文字輸入模式。

► 使用T9 模式

T9 預測文字輸入模式讓您只需按下最少的按鍵即可輕鬆輸入文字。在您按下每個按鍵時，手機會根據內建字典開始顯示它認爲您要鍵入的字元。您也可以在字典中新增文字。新增文字後，文字會發生變更，以反映字典中最可能的待選字。

1. 處於 T9 預測文字輸入模式時，按下按鍵 [2] 至 [9] 即可開始輸入文字。每個字母按一個按鍵。

   - 文字會隨鍵入的字母而變更。輸入完整文字之前，無需理會屏幕上顯示的內容。

   - 輸入完整文字後，如果所顯示的文字仍不正確，請按一下或多下導覽鍵以捲動尋找其他文字選項。

   範例:

   按下 [4] [6] [6] [3] 可鍵入Good 。

   按下 [4] [6] [6] [3] [下導覽鍵] 可鍵入 Home 。

   - 如果文字選項列表中沒有所需的文字，請使用 ABC 模式新增該文字。

   - 您可以選擇T9模式的語言。請按下左軟鍵 [選項]，選擇**T9語言輸入法**， 然後選擇所需的 T9語言。您也可以選擇**關閉T9**以關閉T9模式。本手機的預設值爲開啓T9模式。

2. 輸入完整文字列後再編輯或刪除任何按鍵。

3. 按下 [0] 鍵輸入空格以完成每個文字的輸入。要刪除字母，請按下 [C] 。按住 [C] 可清除整個字元。

附註 要退出文字輸入模式而不儲存已輸入內容，請按下 [⏻] 。手機將返回備用模式。

► 中文 輸入法

1. ST(筆劃輸入法): 如何使用筆劃輸入法選取字元。當您逐一輸入個別筆劃字根後，中文字元便會顯示出來。使用 (*(及)#) 鍵來查看其他字元選項，並按 (OK) 加以選取。同樣地，使用 (*(、)#) 、 及 鍵來尋找更多不同字元。

例如) 要輸入「你們」，請順序按數字鍵 [3] 、 [2] 及 [3] 、然後您將會看到首個字元「你」。現在，按 (OK) 然後再按 [1] 鍵選取「們」。

按 鍵	筆 劃
[1]	一
[2]	丨
[3]	丿
[4]	丶
[5]	乙
[6]	? (通配符號)
(OK)	選擇鍵

<筆劃表>

2. PY(拼音輸入法): 「拼音輸入法」可根據中文字元的英文拼音尋找字元。

拼音輸入法： 在輸入首個拼音符號後便可直接尋找字元。

例如) 要輸入「國民」，請順序按數字鍵 [4] 、 [8] 及 [6] ，然後「GUO 」及「HUO 」將出現在外部編輯屏幕。

在選取「GUO 」後，許多具有相同拼音方式的字元將會出現供您選擇。接下來您可從其中選取字元「國」(按 (OK) 然後再按 [1] 。在選取首個字元後，接著會出現其他各種字元。您可用相同方法選取「民」(按 (OK) 然後再按 [5])。

按 鍵	英文字母
[1]	
[2]	ABC
[3]	DEF
[4]	GHI
[5]	JKL

按　鍵	英文字母
6 mno	MNO
7 pqrs	PQRS
8 tuv	TUV
9 wxyz	WXYZ
0	空格鍵

3. **注音輸入法 (Bopomofo):** 依照注音符號可讓您輸入您所需要的中文字。詳細的輸入方法介紹以及鍵盤對照表，請參考以下說明：

例如) 要輸入「必要」，請順序按數字鍵 1 及 OK，然後「ㄅㄧ」將出現在外部編輯屏幕。因爲許多字元均具有相同的注音方式。所以您應從其中選取字元「必」(按 OK 然後再按 3)。在選取首個字元後， 接著會出現其他各種字元。您可用相同方法選取「要」(按 OK 然後再按 2)。

按　鍵	注　音
1	ㄅㄆㄇㄈ
2 abc	ㄉㄊㄋㄌ
3 def	ㄍㄎㄏ
4 ghi	ㄐㄑㄒ
5 jkl	ㄓㄔㄕㄖ
6 mno	ㄗㄘㄙ
7 pqrs	ㄚㄛㄜㄝ
8 tuv	ㄞㄟㄠㄡ
9 wxyz	ㄢㄣㄤㄥㄦ
0	ㄧㄨㄩ

▶ 使用 ABC 模式

使用按鍵 2 至 9 輸入文字。

1. 按下標記有所需字母的按鍵：
   - 按一下以輸入第一個字母
   - 按兩下以輸入第二個字母
   - 如此類推
2. 要插入空格，請按一下 0 鍵。要刪除字母，請按下 C 鍵。按住 C 鍵可清除整個顯示內容。

附註 請參閱下表以取得更多有關使用英數字元鍵時可用字元的資訊。

按鍵	按順序顯示的字元	
	大寫	小寫
1	. , / ? ! - : ' " 1	. , / ? ! - : ' " 1
2	A B C 2 Ä À Á Â Ã Å Æ Ç	a b c 2 ä à á â ã å æ ç
3	D E F 3 Ë È É Ê	d e f 3 ë è é ê
4	G H I 4 Ï Ì Í Î Ğ	g h i 4 ï ì í î ğ
5	J K L 5	j k l 5
6	M N O 6 Ñ Ö Ø Ò Ó Ô Õ Œ	m n o 6 ñ ö ø ò ó ô õ œ
7	P Q R S 7 ß Ş	p q r s 7 ß ş
8	T U V 8 Ü Ù Ú Û	t u v 8 ü ù ú û
9	W X Y Z 9	w x y z 9
0	[空格鍵] 0	[空格鍵] 0

► 使用 123 (數字) 模式

123 模式可讓您在文字訊息中輸入數字 (如電話號碼)。請按下與所需數字相對應的按鍵，然後再手動切換適當的文字輸入模式。

通訊錄

您可以將電話號碼及其相應姓名儲存在 智能咭記憶體中。此外，您還可以在手機記憶體中最多儲存 255 個號碼與姓名。在**通訊錄**功能表中，智能咭與手機記憶體的使用方式相同。

通話中功能表

本手機提供可在通話時使用的多種控制功能。要在通話時存取這些功能，請按下左軟鍵 [選項]。

通話時

通話時手機屏幕上顯示的功能表，不同於備用模式下顯示的預設主功能表，其中包含的選項如下所述。

啓動喇叭擴音器

喇叭圖標會在通話時顯示。 OK 鍵可以開啓或關閉喇叭擴音器。

撥打第二個電話

您可以從通訊錄中取得要撥打的電話號碼，以撥打第二個電話。請按下右軟鍵，然後執行**搜尋**。要在通話時將已撥號碼儲存在通訊錄中，請按下右軟鍵，然後選擇**新增**。

在兩個電話之間切換

要在兩個電話之間切換，請按下左軟鍵，然後選擇**切換**。

接聽來電

要在耳機響鈴時接聽來電，僅需按下 ⌂ 鍵即可。在通話時，手機還能提醒您收到來電。此時，聽筒會發出鈴聲，且屏幕上會顯示第二個電話正在等待接聽。此功能亦稱爲**來電等候**，在網絡支援時才可使用。要取得有關如何啓動或關閉此功能的詳細資料，請參閱第 58 頁的**來電等候**[功能表-7-4-4]。

如果已啓動**來電等候**，按下 ⌂ 或依次選擇左軟鍵及**保留並接聽**，可保留第一個電話並接聽第二個電話。依次選擇左軟鍵及結束並接聽，可結束目前通話並接聽待接來電。

拒接來電

按下 ⌂ 鍵即可拒接來電。在通話時，按下左軟鍵 [功能表] 並選擇**多方通話/拒絕**或按下 ⌂ 可拒接來電。

使麥克風靜音

在通話時按下 [功能表] 鍵並選擇**靜音開啓**可使麥克風靜音。選擇**靜音關閉**可取消手機靜音。靜音開啓時，來電者聽不到您的聲音，但您仍可聽到對方的聲音。

通話時開啓DTMF音頻

要在通話時開啓DTMF音頻，請按下左軟鍵，然後選擇DTMF開啓。使用相同方式可關閉DTMF音頻。DTMF音頻可讓手機充分利用自動交換機。

多方通話

如果網絡供應商支援此功能，多方通話服務可讓您同時與多個來電者通話。僅在您擁有一個正在接聽的來電及一個保留中的通話，且這兩個電話均已接聽時，才可建立多方通話。建立多方通話後，建立該通話的一方可新增、中斷或隔離 (即從多方通話中移除，但仍與您保持連接)通話。這些選項均可在「通話中」功能表中進行選擇。加入多方通話的來電者人數最多爲五人。開始多方通話後，您即可控制多方通話，並且只有您才能將來電者新增至多方通話。

撥打第二個電話

您可以在通話時撥打第二個電話。請輸入第二個電話號碼，然後按下 ⌂ 鍵。在第二個電話接通時，第一個電話將自動保留。按下左軟鍵並選擇「切換」，即可在兩個電話之間切換。

建立多方通話

在通話時將其中一個電話保留，然後按下左軟鍵並選擇**多方通話/全部加入**。

保留多方通話

按下左軟鍵，然後選擇**多方通話/全部保留**。

啓動保留中的多方通話

按下左軟鍵，然後選擇**多方通話/全部加入**。

將來電新增至多方通話

要將來電新增至現有多方通話，請按下左軟鍵，然後選擇**多方通話/全部加入**。

在多方通話時顯示來電者

要在手機螢幕上捲動進行多方通話的來電者號碼，請使用上/下導覽鍵。

在多方通話時進行私人通話

要與多方通話的其中一個來電者進行私人通話，請在螢幕上顯示要與其通話的來電者號碼，並按下左軟鍵， 然後選擇**多方通話/私人通話**以保留所有其他來電者。

結束多方通話

要結束多方通話，請按下 鍵。按下左軟鍵後選擇**結束通話**也可結束多方通話。要結束電話會議，請按左軟鍵，然後選擇「會議/結束多方通話」。 按下左軟鍵後，選擇「會議/全部結束」即可結束所有現有和保留的通話。

功能表結構

1. 情景模式

1 震動
2 靜音
3 標準
4 大聲
5 聽筒

2. 通話記錄

1 未接來電
2 已接來電
3 已撥電話
4 刪除最近通話記錄
5 通話計費
6 GPRS記錄

3. 工具

1 藍芽
2 計數機
3 單位轉換器
4 時區設置
5 錄音器
6 記憶體狀態

4. 記事簿

1 通訊錄
2 日程表
3 備忘錄

5. 訊息

1 新訊息
2 收件箱
3 草稿箱
4 寄件箱
5 收聽留言訊息
6 資訊廣播
7 常用範本
8 設定

6. 相機

1 拍照
2 拍攝在相框中
3 連環拍攝
4 相簿
5 設定

7. 設定

1 鬧鐘
2 日期和時間
3 手機設定
4 通話設定
5 密碼設定
6 網絡設定
7 恢復原廠設定
8 GPRS設定

8. 互聯網

1 互聯網

2 智能咭服務
(視乎智能咭和網絡商的支援)

9. 下載

1 遊戲及更多

2 圖片

3 音樂

您的手機提供了一組功能，可讓您自訂手機。這些功能設定在功能表與子功能表中，可透過兩個標有 與 的軟鍵存取。每個功能表與子功能表可讓您檢視與變更特定功能的設定。

軟鍵的功能因不同操作環境而不同；每個按鍵正上方之屏幕底部的標籤會指示其目前功能。

按下左軟鍵可存取可用功能表。

按下右軟鍵可啓動相應動作。

情景模式

在情景模式中，您可以調整和自訂不同事件、環境或來電者群組的手機鈴聲。
預設的模式有五種:「**震動**」、「**靜音**」、「**標準**」、「**大聲**」及「**聽筒**」。除震動及靜音外，每種情景模式都可以進行個人化設定。
按左軟鍵 [**功能表**]，然後使用上下導覽鍵選取「**情景模式**」。

啓動情景模式 功能表-1-x-1

1. 顯示情景模式列表。
2. 在**情景模式**列表中，捲動到想要啓動的情景模式，然後按左軟鍵 [選擇] 或[確認]鍵。
3. 然後，選擇「**啓動**」。

附註 當耳機或免提聽筒套件連接至耳機時，**聽筒**情景模式會分別自動啓動。

自訂情景模式 – 更改 功能表-1-x-2

您可以自訂除**震動**與**靜音**之外的情景模式。在情景模式列表中捲動至所需的情景模式。按「確認」鍵或左軟鍵後，選擇「更改」。情景模式設定選項將會開啓。請依照所需設定選項。

- **來電提示:** 設定來電提示的類型。
- **鈴聲:** 從列表中選取所需的鈴聲。
- **鈴聲音量:** 設定 鈴聲音量。
- **訊息提示:** 設定收到訊息提示的類型。
- **訊息提示音:** 選取收到訊息的提示音。
- **按鍵音:** 選取所需的按鍵音。
- **按鍵音量:** 設定按鍵音量。
- **揭蓋音效:** 可根據不同環境設定揭蓋音。
- **確認音音量:** 設定音效音量。
- **開/關機音量:** 設定開啓/關閉手機時的鈴聲音量。
- **自動接通:** 可供您設定自動接聽來電以配合環境狀況。請注意，只有聽筒情景模式包含此子功能表，可供您啓動此功能。
  - **關閉:** 手機不會自動接聽電話。
  - **5秒後**: 5秒後手機將會自動接聽。
  - **10秒後:** 10秒後手機將會自動接聽。

自訂情景模式 – 重新命名　功能表-1-x-3

您可以重新命名情景情景模式，設定任何你想要的名稱。

附註 「**震動**」、「**靜音**」及「**聽筒**」情景模式均無法重新命名。

1. 要更改情景模式名稱，請在情景模式列表中捲動至想要的情景模式，在按左軟鍵或[確認]鍵後選取「重新命名」。
2. 鍵入所需的名稱後，再按[確認]鍵或左軟鍵[確認]。

如果網絡支援服務區域內的來電線路識別 (CLI)，您則可以查看未接、已接和已撥的電話。

號碼與姓名 (如果有的話) 會和通話的日期與時間一起顯示。您也可以查看通話時間。

未接來電 功能表-2-1

使用此選項可以查看最近10個未接來電。

您也可以：

- 查看號碼 (如果有的話) 及撥打該號碼，或將其儲存在通訊錄中。
- 爲該號碼輸入新的姓名並將兩者同時儲存在通訊錄中。
- 使用此號碼傳送訊息。
- 刪除列表中的電話號碼。

附註 您可以使用**刪除最近通話記錄**功能表 [功能表2-4]刪除列表中的所有通話記錄。

已接來電 功能表-2-2

使用此選項可以查看最近10個已接來電。

您也可以：

- 查看號碼 (如果有的話) 及撥打該號碼，或將其儲存在通訊錄中。
- 爲該號碼輸入新的姓名並將兩者同時儲存在通訊錄中。
- 使用此號碼傳送訊息。
- 刪除列表中的電話號碼。

附註 您可以使用**刪除最近通話記錄**功能表 [功能表2-4]刪除列表中的所有通話記錄。

已撥電話 功能表-2-3

使用此選項可以查看最近20個已撥電話(已撥出或嘗試撥出)。

您也可以：

- 查看號碼 (如果有的話) 及撥打該號碼，或將其儲存在通訊錄中。
- 爲該號碼輸入新的姓名並將兩者同時儲存在通

訊錄中。

- 使用此號碼傳送訊息。
- 刪除列表中的電話號碼。

附註 您可以使用**刪除最近通話記錄**功能表 [功能表2-4]刪除列表中的所有通話記錄。

刪除最近通話記錄 功能表-2-4

使用此功能表可清除未接來電、已接來電或已撥電話列表。您也可選擇**所有通話**，一次清除所有通話記錄列表。

通話計費 功能表-2-5

通話時間 功能表-2-5-1

使用此功能表可檢視來電與撥出電話的通話時間。爲避免意外重設，手機會請您確認此動作。

- **最後通話:** 上次通話時間。
- **所有通話:** 從上次重設計時器算起，所有撥打或接聽來電的總通話時間。
- **已接來電:** 來電的通話時間。
- **已撥電話:** 已撥電話的通話時間。
- **全部重設:** 重設通話計時器。

通話費用 功能表-2-5-2

您可以查看最後及所有的通話費用與餘額，並可重設費用。要重設通話費用，需要輸入 PIN 2 碼。

設定 (取決於智能咭) 功能表-2-5-3

- **設定收費率:** 您可以設定貨幣類型及單位價格。請聯絡您的服務供應商以取得計費的單位價格。如要在本功能表中選擇貨幣或單位，您必須有PIN2碼。
- **設定限額:** 這項網絡服務可讓您按照選取的計費單位來限制您的通話費用。當您選擇讀取時，屏幕上會顯示出剩餘的單位數量。當您選擇更改時，您可更改您的計費限制。
- **自動顯示:** 這項網絡服務可讓您自動查看您最後通話的費用。如果您在自動顯示功能表中選擇開啓，您可以在通話結束時查看上次通話的費用。

GPRS記錄 功能表-2-6

您可查詢已在GPRS網絡傳送的數據量。而且，您亦可查看線上連接時間。

通話時間 功能表-2-6-1

查看**最後通話**與**所有通話**的通話時間。您也可以全部重設通話計時器。

數據用量 功能表-2-6-2

查看 **已傳送**、**已接收**、**全部**及**全部重設**。

藍芽 功能表-3-1

藍芽讓位於附近相容的行動裝置、周邊設備和電腦能夠直接與彼此通訊，而不需用到連接線。

本手機內建藍芽，可支援藍芽連線，讓您可以將手機與相容的藍芽耳機、電腦應用程式等連接。

我的裝置 功能表-3-1-1

您可以檢視所有與藍芽電話相容的裝置。

免提裝置 功能表-3-1-2

您可以檢視與藍芽電話相容的免提裝置列表。

設定 功能表-3-1-3

您可以註冊與藍芽相容的新裝置。 如果您已經新增裝置，您可以在輸入密碼後進行搜尋。

- **設定藍芽:** 您可以開啓或關閉藍芽功能。
- **顯示我的手機:** 選擇是否讓您的手機可由其他藍芽裝置偵測，或隱藏您的手機。
- **我的手機名稱:** 您可以設定藍芽裝置的名稱。 預設名稱爲 LG-G233。

計數機 功能表-3-2

此功能表包含標準的計算功能，例如 +、－、x、÷：**加、減、乘、除**。

1. 使用數字鍵輸入第一個數字。
2. 按下相應的導覽鍵以選擇數學符號。

   附註
   - 要清除任何錯誤或顯示，請使用 鍵。
   - 要包含小數點，請按下 鍵。
   - 要包含負號，請按下 鍵。
3. 要計算結果，請按下左軟鍵 [結果] 或「確認」鍵。
4. 計算後，按下左軟鍵[重設]以返回起始狀態。

單位轉換器 功能表-3-3

這項功能可將任何測量單位轉換成您所需的單位。總共可轉換成4種單位：**長度、面積、重量、體積**。

1. 您可以按 [單位] 鍵從這4種單位中選擇一種。
2. 使用左/右導覽鍵選擇要換算的單位。

3. 按下下導覽鍵以移至「轉換值」部分。
4. 使用左/右導覽鍵選擇要換算成的單位。
5. 使用數字鍵輸入數字。系統會自動計算換算。

附註 您可以按下 鍵輸入小數點。

時區設置 功能表-3-4

您可以使用左/右導覽鍵，查看目前格林威治時間 (GMT) 與世界主要 51 個城市的時間。螢幕上會顯示城市名稱、目前日期與時間。

要選擇您所在的時區，請如下述進行：

1. 按一下或多下左/右導覽鍵以選擇與您的時區相對應的城市。當地日期與時間將會顯示。
2. 如果要將在備用模式下的時間顯示變更爲選定時間，請按下左軟鍵 [設定]。

附註 網絡狀況可能會影響**時區設置**功能表中每個城市的時區設定值。

錄音器 功能表-3-5

您可以錄製備忘錄。您最多可以錄製10則錄音，每則錄音最長20秒。

記錄 功能表-3-5-1

1. 若要錄製語音備忘，請選取「記錄」。
2. 開始錄製後，會顯示「錄音中...」訊息與剩餘錄製時間。
3. 錄製完後，按下左軟鍵 [儲存]。
4. 輸入語音備忘標題，然後按確認鍵。

附註 如果全部備忘錄位置都已滿，您必須刪除舊備忘錄才能錄製新備忘錄。

查看列表 功能表-3-5-2

手機會從最近的備忘錄開始顯示備忘錄列表。您可以按下左軟鍵[選項] 來播放或刪除錄製的備忘錄，或透過多媒體訊息加以傳送。您也可以刪除所有備忘錄。

記憶體狀態 功能表-3-6

您可以查看每個資料庫、智能咭記憶體的剩餘空間與使用狀況。 您可以按左軟鍵 [轉到] 進入各資料庫功能表。

通訊錄 功能表-4-1

附註 在備用模式中，按右軟鍵[通訊錄] 可直接進行存取。

搜尋
(由通訊錄撥號) 功能表-4-1-1

1. 按左軟鍵或 OK 鍵選取「搜尋」。
2. 輸入要搜尋的名稱，或選擇左軟鍵[列表]以檢視所有聯絡人。

附註 輸入要搜尋的名稱之首個字母亦可進行即時搜尋。

3. 找到所需的名稱後，您可以按下發送鍵來撥打號碼，或按下左軟鍵 [選項] 以使用下列選項。

- **修改:** 您可以使用導覽鍵編輯名稱、號碼、群組、圖像及圖片。
- **寫文字訊息/多媒體訊息:** 編寫文字訊息/多媒體訊息後傳送到選取的號碼。
- **透過藍芽傳送:** 透過藍芽傳送聯絡人。
- **複製:** 您可將智能咭的記錄複製至手機，或從手機複製至智能咭。
- **主要號碼:** 可從手機號碼、住宅號碼或公司號碼之中選出一個經常使用的號碼。如已設定此號碼，搜尋時會先顯示主要號碼。
- **刪除:** 您可刪除一項記錄。

新增 功能表-4-1-2

您可以使用此功能新增通訊錄項目。

共有 2 個記憶體：手機記憶體與智能咭記憶體。要選擇記憶體，請移至**儲存至**[功能表-4-1-5-1] 手機記憶體容量爲 200個項目。在手機記憶體中，每個姓名最多可以輸入 20個字元。智能咭記憶體容量視智能咭而定。

群組 功能表-4-1-3

在每一個群組中您最多可以編列20個成員。您總共可建立7個群組。

- **成員列表:** 顯示選定的群組成員。
- **來電群組鈴聲設定:** 您可以按照群組設定來電鈴聲。
- **群組圖示:** 您可以設定每個群組的動畫。
- **新增成員:** 您可以在來電群組中加入新成員。

► **刪除成員:** 您可以刪除已儲存在通訊錄中的成員。

► **重新命名:** 您可以更改群組名稱。

快速撥號 功能表-4-1-4

您可以為 2 至 9 之間的任何一鍵指派一個姓名列表項目。您可以按住此鍵 2-3 秒來直接撥號。

1. 先在備用模式下按鍵 [通訊錄] 開啓通訊錄。
2. 捲動至**快速撥號**，然後按[選擇]鍵進入本功能表。
3. 如果您要加入快速撥號，請選擇 <**空**>。然後，您可以在通訊錄中搜尋名稱。
4. 您可以按下左軟鍵 [選項] 來更改或刪除快速撥號號碼，撥打電話或傳送訊息。

設定 功能表-4-1-5

► **儲存至**

您可以在智能咭與手機之間為通訊錄功能表選擇記憶體。 如果您在新增項目時選取「自選」，手機會詢問儲存號碼的位置。

► **搜尋方式**

您可以將手機設定為依照**名稱**或**號碼**搜尋通訊錄。 如果您選取「自選」，手機會詢問您搜尋通訊錄的方法。

► **查看選項**

您可以設定通訊錄顯示選項。

- **只顯示姓名:** 當您搜尋通訊錄時，列表僅會顯示姓名。
- **通訊錄圖片:** 當您搜尋通訊錄時，列表會顯示姓名和相對應的圖片。
- **姓名及號碼:** 當您搜尋通訊錄時，列表會顯示姓名與號碼。

複製全部 功能表-4-1-6

您可以將記錄從智能咭記憶複製/轉至手機記憶，或者從手機記憶複製/轉至智能咭記憶。

- **智能咭轉至手機:** 您可以將記錄從智能咭複製至手機記憶。
- **手機轉至智能咭:** 您可以將記錄從手機記憶複製至智能咭。

您可以使用下列選項。

- **保留原號碼:** 複製時，保留原有號碼。
- **刪除原號碼:** 複製時，清除原有號碼。

刪除全部 功能表-4-1-7

您可以刪除智能咭及手機中的所有記錄。這功能需要安全密碼。
按下 以返回備用模式

資訊 功能表-4-1-8

► **特別服務號碼**

利用這項功能可進入您的服務供應商提供的特別服務號碼列表(若智能咭可支援)。

1. 捲動至**特別服務號碼**，然後按鍵 [選擇] 進入本功能表。
2. 屏幕上將顯示可用的服務名稱。
3. 使用 與 選取服務。按 「發送鍵」。

► **記憶體狀態**

您可以檢查智能咭或手機記憶體目前的記憶體狀態。

► **本手機號碼(取決於智能咭)**

您可以儲存並查看智能咭內的本手機號碼。

日程表 功能表-4-2

進入此功能表時，日曆會出現。目前日期會顯示方形游標。使用導覽鍵可將游標移至其他日期。您可以在日曆中使用下列按鍵。

每按一下	1	會倒退一年。
	3	會前進一年。
	*	會倒退一個月。
	#	會前進一個月。

您可以按左軟鍵[選項] 在日程表中輸入日程或備忘錄。

► **新增:** 選擇此項目可輸入新日程。 在某個日期中輸入日程後，日期會以不同顏色顯示，並出現在屏幕的右下角。 此功能會提醒您已安排的日

程。 另外，如果您將手機設定爲要發出提醒，手機會發出提示音。

- **查看:** 顯示選定日期的日程或備忘錄。按左軟鍵 [選項] 進行修改或刪除您選取的日程。
- **查看全部:** 顯示手機中所有輸入的日程。 使用上/下導覽鍵瀏覽日程列表。
- **刪除已過日程:** 選取此項目以刪除過期的日程，過期的日程均已發出通知。系統會提示您確認此操作。
- **刪除全部:** 選取此項目以刪除所有日程與備忘錄。系統會提示您確認此操作。

備忘錄 功能表-4-3

使用此項目記下備忘錄。 手機最多可以儲存20則備忘錄。

附註 如果您要變更文字輸入模式，請依序按 [#] 鍵。

此功能表包括SMS(短訊服務)、MMS(多媒體訊息服務)、留言、 以及網絡服務訊息之相關功能。

新訊息 功能表-5-1

寫文字訊息 功能表-5-1-1

輸入及編輯文字訊息、查看訊息頁數。

1. 按鍵[**選擇**]以進入訊息功能表。
2. 如果您想輸入新訊息，請選取寫文字訊息。
3. 要使文字輸入更方便，請使用 T9。
4. 按[加入]可插入隨訊息一起傳送的附檔。
5. 如果您要設定文字選項或結束輸入，請按[選項]。

附註 支援 EMS 第 5 版的手機可以傳送彩色相片、聲音及文字式樣等。如果對方的手機不支援此類選項，則可能無法接收相片、聲音或文字式樣。

加入

- **符號:** 新增特定字元。
- **圖片:** 在短訊中插入預設圖片或我的文件夾中可用的圖片。
- **歌曲:** 在短訊中插入可用的聲音。
- **常用短語:** 使用手機已設定的常用短語。
- **通訊錄:** 您可以在通訊錄中新增電話號碼或電郵地址。
- **簽名:** 在訊息中加入您的簽名。

選項

- **發送:** 發送文字訊息。
  1. 輸入聯絡人電話號碼。
  2. 按 新增更多聯絡人。
  3. 您可以在通訊錄中新增電話號碼。
  4. 輸入電話號碼後按[發送]。

  所有訊息將會自動儲存在寄件箱資料夾內，即使在傳送失敗時也不例外。
- **儲存:** 將訊息儲存在草稿中。
- **字體:** 您可以選取字體**大小**和**式樣**。
- **顏色:** 選取前景與背景的顏色。
- **對齊:** 調整訊息內容的對齊方式爲**靠左**、**靠中**或**靠右**。

- **新增至字典:** 新增個人常用語。僅在編輯模式爲 T9Abc/T9abc/T9ABC 時才會顯示此功能表。
- **T9語言輸入法:** 選取T9輸入模式。
- **結束:** 如果您在輸入訊息時按結束，則可以結束輸入並返回 訊息功能表。您輸入的訊息將不會被儲存。

寫多媒體訊息

功能表-5-1-2

多媒體訊息可以包含文字、影像及/或聲音片段。此功能僅在您的網絡供應商或服務供應商提供支援時才能使用。僅提供與多媒體訊息或電郵功能相容的裝置才能接收與傳送多媒體訊息。
您可以建立最多 10 頁的多媒體訊息 (約 100 KB)

1. 輸入訊息主題後，按確認鍵。
2. 輸入文字訊息。 使用右軟鍵[加入]，您可以插入符號、相片、歌曲、語音備忘錄、常用短語、存在通訊錄中的電話號碼或簽名。
3. 按左軟鍵 [選項]。 可以使用的選項如下。

- **發送:** 您可以同時傳送多媒體訊息給多位收件者。

  1) 輸入電話號碼。 您也可以使用左軟鍵 [搜尋]，從最近通話號碼列表或通訊錄中搜尋電話號碼。

  2) 按右軟鍵 [設定]。 您可以設定以下選項：

  - **優先:** 設定多媒體訊息的優先順序。
  - **有效期:** 設定在網絡伺服器保留多媒體訊息的時間。可供選擇的值有：1 小時、12 小時、1 天、一週，以及網絡商允許的最長期限。
  - **發送報告:** 選擇「是」以啓動報告功能。 當此功能啓動時，網絡會通知您是否已成功發送訊息。

  3) 按左軟鍵[發送]。

- **預覽:** 選取此選項以查看您已建立的多媒體訊息。 會自動連續播放每頁投影片。 您也可以使用左/右導覽鍵從目前播放的投影片移至其他投影片。 要重播訊息，請按左軟鍵 [重播]。
- **儲存:** 將訊息儲存至草稿箱或作爲範本。
- **新增投影片:** 在目前投影片之前或之後加入投影片。
- **轉到:** 選擇此選項以從目前投影片移至另一個投影片。

- **刪除投影片:** 刪除目前的投影片。
- **設定訊息格式:** 您可以設定下列投影片格式。
  - **設定計時器:** 使用數字按鍵輸入各欄位的計時器。
  - **切換文字和圖片:** 交換文字與圖片。
- **刪除媒體(只當媒體存在訊息中時才會顯示):** 您可以刪除投影片的相片或聲音。
- **新增至字典:** 如果 T9 文字輸入模式中沒有你想要的單字，您可以使用此選項在爲 T9 字典增加單字。 輸入單字後，按左軟鍵[儲存]。
- **T9語言輸入法:** 選擇 T9 輸入模式的 T9 語言。您也可以選擇關閉T9來關閉 T9 輸入模式。 如需 T9 模式的詳細資料，請參考第 20 到 25 頁。
- **結束:** 結束編寫多媒體訊息。

收件箱

功能表-5-2

手機會在收到訊息時提示您。收到的訊息會儲存在「收件箱」中。您可以透過圖示識別各訊息。要取得詳細資料，請參閱下列圖示說明。

圖 示	說　明
	已讀智能咭訊息
	未讀智能咭訊息
	已讀訊息
	未讀訊息
	已讀傳遞報告
	未讀傳遞報告

如果手機顯示「訊息儲存空間不足」，您可透過刪除部分訊息、多媒體及應用程式來取得空間。

附註 訊息是指儲存在智能咭記憶體中的訊息。網絡會將收到的訊息區分爲智能咭訊息或單純的訊息。

收到的每個訊息都可以使用下列選項。按左軟鍵[選項]。

- **查看:** 您可以檢視選定的訊息。
- **回覆訊息:** 回覆收到的訊息。
- **轉發:** 將收到的訊息轉發給其他收件者。

► **回覆電話:** 您可以自動回覆電話給發送這封訊息的寄件人。

► **儲存訊息資料:** 儲存訊息中的圖片、聲音、網頁或電郵地址， 這些資料將會儲存到「我的文件夾」、「通訊錄」或書籤中。

► **刪除**: 刪除收件箱中的選定訊息。

► **查看資訊:** 顯示訊息的相關資訊。

圖 示	說　明
	讀取多媒體訊息
	未讀取多媒體訊息
	讀取已通知的多媒體訊息
	未讀取已通知的多媒體訊息

收到的每個多媒體訊息都可以使用下列選項。按左軟鍵 [選項]。

- **回覆訊息:** 您可用訊息回覆給寄件人。
- **轉發:** 將選定的訊息轉寄給其他收件者。
- **回覆電話:** 您可以自動回覆電話給發送這封訊息的寄件人。
- **刪除**: 刪除收件箱中的選定訊息。
- **儲存訊息資料:** 擷取圖片或聲音。 將會儲存在「我的文件夾」或「通訊錄」
- **查看資訊:** 查看已接收的訊息之相關資訊：寄件者地址、主題 (僅限於多媒體訊息)、訊息日期與時間、類型與大小。

草稿箱

功能表-5-3

您可以檢視儲存爲草稿的訊息。 草稿訊息儲存後，會以顯示日期與時間的方式列出。 使用上/下導覽鍵捲動列表。

圖 示	說　明
	多媒體訊息
	文字訊息

每個草稿都下列選項。

按左軟鍵[選項]。

► **查看:** 您可以檢視選定的訊息。

- **修改:** 您可以修改選定的訊息。
- **刪除 :** 從草稿箱刪除選定的訊息。
- **查看資訊:** 您可以檢視選定訊息的資訊：主題 (僅限多媒體訊息)、儲存的日期與時間、輸入的訊息、大小及重要性 (僅限多媒體訊息)。
- **刪除全部:** 從草稿箱刪除所有訊息。

寄件箱

功能表-5-4

您可在此功能表中檢視傳送訊息的列表與內容，還可以確認傳輸是否成功。

圖 示	說　明
	已傳送的多媒體訊息
	未發送的多媒體訊息
	轉發的多媒體訊息
	已傳送的文字訊息
	未發送的文字訊息
	轉發的文字訊息

在每個訊息中，按下左軟鍵 [選項] 即可使用下列選項。

完成傳送的訊息有下列選項。

- **查看:** 您可以檢視選定的訊息。
- **轉發:** 您可以將選定的訊息轉寄給其他收件者。
- **刪除:** 從寄件箱刪除選定的訊息。
- **查看資訊:** 您可以檢視選定訊息的資訊：主旨 (僅限多媒體訊息)、傳送的日期與時間、輸入的訊息、大小、重要性及收件者 (僅限多媒體訊息)。
- **刪除全部:** 刪除寄件箱中的所有訊息。

傳送中的訊息有下列選項。

- **查看:** 您可以檢視選定的訊息。
- **取消:** 取消傳送訊息。
- **刪除:** 取消傳送訊息，然後刪除訊息。
- **查看資訊:** 您可以檢視選定訊息的資訊：主題 (僅限多媒體訊息)、傳送的日期與時間、輸入的訊息、大小、重要性及收件者 (僅限多媒體訊息)。

- **取消全部:** 取消所有訊息傳送。
- **刪除全部:** 取消所有訊息傳送並全部刪除。

收聽留言訊息 功能表-5-5

此功能表可讓您快速存取留言訊息(如果網絡提供此服務)。使用此功能之前，您必須輸入從網絡供應商取得的語音伺服器號碼。

收到新的語音訊息時，此符號 “ ∞ ” 會在螢幕上顯示。請諮詢您的網絡供應商以取得其服務的詳細資料，以便正確設定手機。

資訊廣播 功能表-5-6

資訊廣播訊息是網絡傳送給手機用戶的文字訊息，其內容主要爲一般資訊，例如：天氣預報、交通新聞、出租車資訊、醫藥及股票行情。每種類型的資訊以數字代表，此數字可向網絡供應商取得。在收到資訊服務訊息時，會有一則快顯訊息提示您收到新訊息，或資訊服務訊息會直接顯示。在備用模式下，檢視資訊服務訊息時有下列可用選項。

讀取 功能表-5-6-1

如果收到資訊服務訊息並選取**讀取**以查看訊息，訊息則會顯示在屏幕上。

主題 功能表-5-6-2

要建立新的主題，請按下左軟鍵 [選擇]，然後選擇**新增**。如果已經建立主題，則可使用左軟鍵 [選項] 來關閉、修改或刪除主題。

常用範本 功能表-5-7

建立某些常用範本 (短語、多媒體、簽名) 後，發送訊息時只要選擇它們便可以使用。

常用短語 功能表-5-7-1

下列爲預設的文字範本。

- **請覆電話！**
- **我遲到了，會立刻到達。**
- **您在哪裡？**
- **我在路途中。**
- **非常緊急，請速聯絡！**

- 我愛你！

您可以使用下列選項。

- **查看:** 選擇此項檢視選定的範本。
- **修改:** 用來修改選定範本。
- **寫訊息**
  - **寫文字訊息:** 使用此選項可透過文字訊息傳送選定範本訊息。
  - **寫多媒體訊息:** 使用此選項可透過多媒體訊息傳送選定範本訊息。
- **新增:** 使用此選項可建立新的範本。
- **刪除:** 刪除常用短語列表中的選定範本訊息。
- **刪除全部:** 刪除所有範本。

多媒體範本 功能表-5-7-2

您可以按下左軟鍵 [新增] 建立多媒體範本。 而當您在 [寫多媒體訊息] 中建立多媒體訊息時，也可以建立儲存作爲範本的多媒體範本 (請參閱第 44 頁)。

- **查看:** 您可以查看多媒體範本。
- **修改:** 編輯多媒體範本。
- **新增:** 新增多媒體範本。
- **寫訊息:** 您可以使用多媒體範本編寫多媒體訊息。
- **刪除:** 從多媒體範本列表刪除選定的範本訊息。
- **刪除全部:** 清除多媒體範本列表。

簽名 功能表-5-7-3

1. 按下左軟鍵 [修改]。
2. 輸入名稱欄後，請按下左軟鍵[確認]。
3. 輸入名稱、手機號碼、住宅及公司電話號碼、傳真號碼及電郵地址。
4. 按下左軟鍵 [儲存]。

建立簽名範本後，按左軟鍵 [選項] 便可存取下列功能表。

- **修改:** 用來修改簽名。
- **刪除:** 用來刪除簽名。
- **發送:** 您可以透過 文字訊息、多媒體訊息 或藍芽傳送您的簽名。

- **接收:** 您可以透過藍芽接收其他簽名。
- **交換簽名:** 您可以利用藍芽與他人交換簽名。

設定 功能表-5-8

文字訊息 功能表-5-8-1

利用本功能表設定預設的短訊資訊。

- **訊息類型:** 設定預設訊息類型 (文字、語音、傳真、國內 傳呼、X.400、電子郵件、ERMES)。網絡可以將訊息轉換爲選取的格式。
- **有效期:** 設定傳送文字訊息給收件者時，訊息儲存在短訊中心的期限。預設時間爲 1 小時、12 小時、1 天、一週、及網絡供應商授權的最長期限。
- **發送報告:** 請選擇是否要啓動或關閉報告功能。啓動此功能後，網絡會通知您是否已經成功發送訊息。
- **通過同一訊息中心回覆:** 如果服務是由網絡提供的，將允許訊息收件人透過您的短訊中心傳送回覆給您。
- **訊息中心:** 傳送文字訊息時，儲存或變更您的 短訊中心號碼。 此號碼必須由服務供應商提供。

多媒體訊息 功能表-5-8-2

透過此功能表，您可以設定預設多媒體訊息資訊。

您可以使用下列選項。

- **重要性:** 設定要傳送的多媒體訊息之重要性。
- **有效期:** 設定傳送多媒體訊息給收件者時，訊息儲存在網絡伺服器的期限。預設時間爲 1 小時、12 小時、1 天、一週、及網絡商授權的最長期限。
- **發送報告:** 請選擇是否要啓動或關閉報告功能。若啓動此功能，網絡會通知您是否已經成功發送訊息。
- **自動下載:**
  - **開啓:** 如果選擇此選項，收到訊息時會自動下載。
  - **關閉:** 要求您確認是否要下載訊息。
  - **僅限本地網絡:** 若選擇此選項，訊息會在您的本地網絡區域中，自動爲收件人下載訊息。 若

在您的本地網絡服務區域以外，則會要求您確認後再下載訊息。

► **網絡設定:** 如果選用多媒體訊息伺服器，您可設定多媒體伺服器的URL。

► **允許類型:** 設定允許類型。設定爲「個人」、「廣告」及「資訊」。

留言信箱中心 功能表-5-8-3

如果您的網絡服務供應商支援這項功能，您就可以聽取留言 訊息。當您收到新的留言訊息時，屏幕上將會顯示一個符號。 請向您的網絡服務供應商瞭解他們的服務詳情，以適當地設定 手機。

► **本地留言中心:** 在開戶網絡中收聽留言信箱所撥打的號碼。

► **漫遊地中心:** 在其他網絡聽取留言訊息所撥打的號碼。

資訊廣播 功能表-5-8-4

► **接收**

是: 若您選擇本功能表，您的手機將可接收資訊廣播訊息。

否: 若您選擇本功能表，您的手機將無法再接收資訊廣播訊息。

► **來電提示**

是: 若您選擇本功能表，您的手機在收到資訊廣播訊息時將會發出一聲嗶聲。

否: 若您選擇本功能表，您的手機在收到資訊廣播訊息時將不會發出一聲嗶聲。

► **語言**

按[開/關]選取所需的語言。然後資訊廣播訊息將會以您選取的語言顯示。

Push訊息 功能表-5-8-5

您可以設定選項是否接收訊息。

有了 LG-G233 手機，您就可以隨拍隨存！ 拍照後，您也可以立即利用多媒體訊息或電郵傳送相片。

附註 如果電池電量過低，您可能無法使用「相機」功能。

拍照 功能表-6-1

- **開蓋拍照**

選取「拍照」，然後按下 。若您要直接使用此功能，在備用模式下按住 。

拍照前您可以先設定下列的值。

預覽功能列

1. **數碼縮放** ( ): 可用的五種層次
2. **提示音** ( ): 彩色, 深褐色, 黑白
3. **亮度** ( ): +2、 +1、 0、 -1、 -2
4. **計時器** ( ): 關閉、3 秒、5 秒
5. **記憶體** ( ): 顯示目前記憶體狀態。

   附註 若記憶體滿了，會跳出「記憶體已滿」訊息，您將無法儲存相片。 請刪除相簿中的舊相片以釋放空間。

6. **閃光燈** ( ): 使用上/下導覽鍵選擇開啓 ( )/關閉( ) 閃光燈
7. **解像度** ( ): 640x480 (VGA)、320x240 (QVGA)、128x160 (屏幕)。
   48x48 (通訊錄)。
8. **圖像品質** ( ): 細緻/標準/基本

1. 使用左/右導覽鍵將所需的選項功能表置中。
2. 使用上/下導覽鍵選擇所需的值。
3. 完成所有設定後，對準拍攝目標按「照相機」鍵或「確認」鍵。只要按一下即可擷取圖像，同時並會顯示下列功能表列。

附註 解像度設為 48x48 (通訊錄) 時，會顯示下列功能表列。

如果**自動儲存** [功能表-6-5-3] 設定為「是」，拍攝圖像會被自動儲存，而不會顯示上述功能列。

4. 要儲存圖像，將“ ”置中然後按「確認」鍵。如您不想儲存此圖像，將“ ”置中然後按「確認」鍵。
   您也可以透過選擇“ ”，以多媒體訊息發送圖像。
   更多有關寫多媒體訊息的資訊，請參閱第 44-49 頁。拍攝 48x48 (通訊錄) 大小的照片後，您可以選擇“ ”將圖像直接儲存在通訊錄內。

- 闔蓋拍照

請按側邊照相機鍵取得相機功能表。可以使用的子功能表如下。

利用側邊按鍵反白要用的功能表以後，請按側邊照相機鍵選擇功能表。

1. 拍照
   選擇此功能來拍攝照片。 您可以爲自己拍照。 要拍照的話，請按側邊照相機鍵。 要回到相機功能表，請按住側邊照相機鍵。

2. 放投影片
   連續顯示相簿中的每一張圖像。您可以用上/下側面按鍵，手動移動上一張/下一張圖像。 要停止放投影片並回到相機功能表，請按側邊照相機鍵。

3. 照明燈
   利用上/下側面按鍵選擇照明燈開啓 ( )/關閉 ( ) 。

4. 返回
   選此選項可返回備用模式。

拍攝在相框中 功能表-6-2

利用預設邊框享受拍照樂趣。

7 種預設邊框可供使用。 使用上/下導覽鍵選擇想要的邊框。

附註 在此模式中，您無法變更解像度與色彩的設定。

連環拍攝 功能表-6-3

每次最多只可連環拍攝 9 張相片。拍照後，您可以使用上/下導覽鍵進行檢視。 您也可以按下「確認」鍵加以儲存。

附註 如果您設定的解像度爲 320x240，您僅能連環拍攝 6 張相片。如果設定爲 128x160，可以連環拍攝 9 張相片。

相簿 功能表-6-4

所有拍攝的相片都儲存在此功能表中。 相片分爲「通用圖片」、「相框圖片」以及「通訊錄圖片」。在「全部圖片」中，您可以檢視所有圖片。按下左軟鍵 [選項] 即可存取以下的子功能表。

- **預覽圖片:** 屏幕上最多只可檢視 9 幅縮圖。
- **寫多媒體訊息:** 透過多媒體訊息傳送照片。
- **設定爲牆紙:** 您可以將圖片設爲牆紙。
- **放映投影片:** 您可使用這個功能，以放映投影片的方式檢視圖片。
- **刪除:** 刪除圖片。
- **編輯主題:** 編輯圖片主題。
- **查看資訊:** 您可以檢視圖片資訊，例如主題、大小、日期、時間。
- **保護:** 如果每張圖片均啓動此功能，您便無法傳送、編輯或刪除圖片。

設定 功能表-6-5

記憶體狀態 功能表-6-5-1

您可以檢查手機目前的記憶體狀態。

清除相簿 功能表-6-5-2

使用此功能表來刪除所有圖片。 您必須確認此動作。

自動儲存 功能表-6-5-3

如果您將此設定爲「是」，畫面則不會顯示「儲存」功能表列，所拍攝的影像會自動加以儲存。

按下「功能表」鍵 ( ) 並使用導覽鍵選擇設定。

鬧鐘 功能表-7-1

功能表中設有5個鬧鐘。 將鬧鐘鈴響設定在特定時間。
使用左軟鍵 [選擇]

1. **鬧鐘開啓/關閉:** 使用左/右導覽鍵選擇開啓。要關閉鬧鐘功能，請選擇關閉。
2. **鬧鐘時間:** 使用數字鍵輸入鬧鐘時間。
3. **重複:** 選定鬧鐘後，請使用左/右導覽鍵選擇「一次」、「星期一～星期五」、「星期一～星期六」或「每天」任何一個想要的選項。
4. **鬧鐘鈴聲:** 使用左/右導覽鍵選擇所需的鈴聲。
5. 按下左軟鍵[確認] 或「確認」鍵。
6. 您可以編輯鬧鐘名稱。 鍵入 名稱後，按下左軟鍵[確認]。

啓動鬧鐘功能後，在備用模式下會加以顯示 “ ”。達到鬧鐘時間時，鬧鐘鈴聲會響起。

► 要關閉鬧鐘，請按下右軟鍵[返回]。

日期和時間 功能表-7-2

此選項讓您能更改目前顯示的時間與日期。

您可以使用下列選項。

日期設定 功能表-7-2-1

使用此選項輸入日、月、年。您可透過**日期格式**功能表選項更改日期格式。

日期格式 功能表-7-2-2

DD/MM/YYYY (日/月/年)

MM/DD/YYYY (月/日/年)

YYYY/MM/DD (年/月/日)

時間設定 功能表-7-2-3

使用此選項輸入目前的時間。您可透過**時間格式**功能表選項選擇時間格式。

時間格式 功能表-7-2-4

24小時制

12小時制

手機設定 功能表-7-3

許多手機功能可以配合個人喜好而自行設定。所有功能均由**手機設定**功能表存取。

顯示設定 功能表-7-3-1

- **牆紙:** 選擇在備用模式中於主屏幕與副屏幕顯示的桌布。
- **功能表風格:** 您可以從4種配置中選擇一種想要的手機顯示配置。 捲動配置時即可進行預覽。
- **問候語:** 如果您選擇**開啓**，本功能表可讓您選擇備用時顯示的問候語。您可在文字模式下修改問候語的文字。
- **背景燈:** 使用此選項可選擇手機是否需要使用背景燈。關閉背景燈可以稍微增加備用/通話時間。
- **資訊視窗提示:** 開啓功能表之前，預覽選定功能表的目前狀態。狀態會在畫面底部顯示。
- **網絡名稱:** 如果您選擇「開啓」，您則會看到備用模式中網絡服務供應商的名稱。

語言 功能表-7-3-2

您可以選擇顯示的語言。當語言選項設定爲**自動**時，手機會自動根據所用的智能咭選擇語言。如果手機不支援智能咭上的語言，則會使用英文。

通話設定 功能表-7-4

變更來電轉駁的設定。

來電轉接 功能表-7-4-1

當本網絡服務啓動時，您可將來電轉接至另一個號碼，例如，您的留言中心號碼。如需詳盡說明，請與您的服務供應商聯絡。

選擇其中一項轉接選項，例如，忙線中或拒絕來電時，請選擇「繁忙時」轉接語音通話。

您可以使用下列選項。

轉接所有語音來電: 無條件轉接所有語音通話。

繁忙時: 當手機正在使用時，轉接語音通話。

無人接聽時: 轉接未接來電到語音通話。

無網絡或關機時: 手機關機或無法接收時，轉接語音通話。

轉接所有數據來電: 無條件透過 PC 連線轉接號碼。

轉接所有傳真來電: 無條件透過傳真連線轉接號碼。

每個選項有下列功能表：

- **啓動:** 啓動對應的服務。
  - **留言信箱:** 轉接至訊息中心。此功能無法在**轉接所有數據來電**及**轉接所有傳真來電**功能表中使用。
  - **其他號碼:** 輸入來電轉駁號碼。
  - **常用號碼:** 顯示最近5個轉駁號碼的列表。
- **取消:** 取消選擇的來電轉接。
- **查詢狀態:** 您可以查詢該服務狀態。

取消全部: 取消所有來電轉接設定。

接聽模式 功能表-7-4-2

選擇所需的接聽模式。

- **揭蓋接聽:** 當手機響鈴時，您只需打開機蓋便可接聽。
- **按任何鍵:** 手機響鈴時，您可按下除 鍵和右軟鍵(\•]) 以外的任何鍵來接聽來電。
- **按發送鍵:** 只限按發送鍵才可接聽來電。

發送我的號碼 功能表-7-4-3

本網絡服務讓您決定是否讓通話對象顯示 (開啓) 或隱藏 (關閉) 您的手機號碼。選擇**按網絡設定**重新將手機設定爲您與服務供應商所達成協議之設定。

來電等候 (網絡服務) 功能表-7-4-4

當您正在通話時，網絡將會通知您有新的來電。選擇**啓動**要求網絡啓動來電等候；選擇**取消**要求網絡關閉來電等候；或選擇**查詢狀態**檢查功能是否正在運作。

分鐘提示 功能表-7-4-5

當設定成**開啓**時，手機在撥出電話期間將每分鐘發出提示音，提醒您通話長度。

自動重撥 功能表-7-4-6

選擇**開啓**，當撥號失敗時，您的手機最多將嘗試撥號五次。

密碼設定 功能表-7-5

使用各種密碼來保護您的手機之某些功能。如要瞭解各種密碼，請查閱第18頁。

需要PIN碼 功能表-7-5-1

當**需要PIN碼**功能啓動時，您每次開機都需輸入PIN碼。此情況下，除非經過您的允許，任何人如果沒有您的PIN碼，都無法使用您的手機。

附註 停用需要PIN碼功能前，您必須輸入您的PIN碼。

您可以使用下列選項：

- **開啓：**您必須在每次開機時輸入PIN碼 。
- **關閉：**當您開機時，手機直接連接網絡。

手機鎖 功能表-7-5-2

當手機鎖 功能啓動時，手機處於鎖定狀態，您每次開機都必須輸入密碼。 出廠時密碼預設爲0000。 如要更改手機密碼，請參閱「更改密碼 – 安全密碼」功能表選項 [功能表-7-5-5-2]。 輸入正確密碼後，您便可使用手機，直到關機爲止。

通話限制 功能表-7-5-3

通話限制服務讓您限制手機撥打和接聽電話。要使用本功能，您需要向服務供應商取得網絡密碼。

您可以使用下列選項：

- **所有撥出電話:** 不能撥打電話。
- **國際撥號:** 不能撥打國際電話。
- **漫遊時的國際撥號:** 置身國外時，只能撥打所在地和本國 (網絡供應商所在地) 的電話號碼。
- **所有來電:** 不能接聽電話。
- **漫遊時來電:** 當您置身國外時，不能接聽電話。
- **取消全部:** 關閉所有通話限制設定；可以正常撥打和接聽電話。

- **更改密碼:** 使用此選項來設定和更改您之前向服務供應商所取得之網絡密碼。更改爲新密碼前必須輸入舊網絡密碼。輸入新密碼後，您必須再次輸入表示確認。

附註 想使用**通話限制**，您必須輸入網絡密碼。通話限制期間，某些網絡上也許能夠撥打特定的緊急電話號碼。

固定撥號 (FDN) (視智能咭而定)

功能表-7-5-4

使用此功能將您的撥出電話限制爲選定的電話號碼(若您的智能咭支援此功能)。需要 PIN2 碼。

您可以使用下列選項：

- **啓動:** 使用此選項後，手機僅能撥打儲存在通訊錄中的電話號碼。您必須輸入您的PIN2碼。
- **取消:** 您可以撥打任何號碼。
- **號碼列表:** 使用此選項檢視儲存爲固定撥號的電話號碼。

附註 並非所有智能咭都有PIN2碼。如果您的智能咭沒有PIN2碼，便不會顯示此功能表選項。

更改密碼

功能表-7-5-5

此**更改密碼**功能讓您能將舊密碼更改成新的密碼。更改爲新密碼前必須輸入舊密碼。

使用此選項更改存取碼：**PIN2碼**及**安全密碼**

附註 PIN：個人辨識碼。

網絡設定

功能表-7-6

此**網絡設定**功能使您能夠在漫遊時(在國外)標示使用的網絡：自動、手動、首選。

附註 只要該網絡與本國網絡之間具有有效漫遊合約，您便可選擇本國網絡外的其他網絡。

自動

功能表-7-6-1

使用此功能將手機設定自動搜尋， 選擇您所在區域可使用的任何一家手機網絡。

一旦關機時，手機會回復爲「自動」的預設值。

手動

功能表-7-6-2

如果您要從網絡列表中手動選擇想要的網絡，您可啓動此功能。 如果手動連線至選定的網絡中斷時，手機會發出錯誤音效，要求您再次選擇網絡。

選定的網絡與您本國的網絡，亦即手機內智能咭的網絡商，必須簽署漫遊協定。 如果手機無法存取選定的網絡，手機則會讓您選擇另一個網絡。 如果關機，手機會重設爲「自動」。

首選網絡 功能表-7-6-3

您可以設定首選的網絡列表，手機會先嘗試登入該網絡，然後再嘗試登入其他網絡。此列表是透過手機的已知網絡預定列表而建立的。

恢復原廠設定 功能表-7-7

您可以將手機重設爲預設設定。如要這麼做，請依照下列步驟進行。

1. 選取「**恢復原廠設定**」功能表選項。
2. 輸入 4 位安全密碼。

附註 安全密碼預設爲 0000。

GPRS設定 功能表-7-8

GPRS (整合封包無線電服務技術) 是一種使手機能在流動網絡上發送和接收數據的技術。GPRS 是一種傳輸方式，能夠無線存取數據網絡，例如互聯網。

在您能使用 GPRS 技術前：

- 您必須訂購 GPRS 服務。對於是否提供 GPRS 服務及其訂購，請與您的網絡供應商或服務供應商聯繫。
- 您必須儲存 GPRS 設定，以便使用 GPRS 上的應用程式。

選擇電源啓動時若您正好位於支援 GPRS 的網絡內，您可透過GPRS 使用手機向 GPRS 網絡註冊並發送訊息。此外，啓動使用中的封包數據連線，便能縮短接收電郵的時間。如果您選擇需要時，手機只會在開始應用程式或需要時才會使用 GPRS連線。如果沒有任何應用程式需要GPRS連線時，GPRS連線就會結束。

附註 如果沒有GPRS訊號，而您已經選擇自動，手機則會定時建立連線。

您可以存取各種 WAP (無線應用協定) 服務，例如銀行業務、新聞、天氣報導與航機班次等資訊。這些服務是專爲流動電話而設計的，並由 WAP 服務供應商支援。

請向提供服務的網絡商與/或服務供應商查詢您可以使用的WAP 服務、價格與收費表。服務供應商也會提供如何使用服務的說明。

連線後即會顯示主頁。主頁內容因服務供應商而異。輸入URL位址即可存取任何網頁。任何時候要結束瀏覽器，請按 鍵。手機將會返回備用模式。

使用 WAP 瀏覽器瀏覽

使用手機按鍵或 WAP 瀏覽器功能表即可上網。

使用手機按鍵

上網時，手機按鍵的功能和手機模式時不同。

按 鍵	說　明
	捲動內容區的每一行。
	回到上一頁。
OK	選擇選項並確認動作。

使用 WAP 瀏覽器功能表

流動上網時可以使用各種功能表選項。

附註 WAP 瀏覽器的功能表將因您的瀏覽器版本而有所不同。

互聯網 功能表-8-1

主頁 功能表-8-1-1

連線到主頁。主頁是目前啓用之網絡設定中定義的網站。如果您還未在已啓用的網絡設定中定義主頁，服務供應商將爲您定義一個主頁。

書籤 功能表-8-1-2

您可以在此功能表中，將喜愛的網頁之網址儲存起來，方便日後存取。
手機已預載許多書籤。這些預載書籤無法刪除。

建立書籤

1. 按左軟鍵[選項]。
2. 選擇「新增」，然後按[確認]鍵。
3. 輸入所需的地址和主題後，按[確認]鍵。

* **要訣:** 使用 1 鍵和 0 鍵來輸入符號。要輸入“.”，請按 1 。

選定所需的書籤後，便可以使用下列選項。

► **連接:** 連接至您選取的書籤。

► **新增:** 選此建立新書籤。

► **修改:** 您可以編輯選定書籤的地址和/或主題。

► **刪除:** 刪除選定的書籤。

刪除全部: 刪除全部書籤。

網絡設定

功能表-8-1-3

網絡設定即用來連接互聯網的網絡資訊。

每個網絡設定的功能表如下：

► **啓動:** 啓用選定網絡設定。

► **設定:** 用來編輯與變更選定網絡設定的 WAP 設定。

- **主頁:** 此設定可讓您輸入要當作主頁使用的URL位址。您不需要在每一個URL位址前面輸入 “http://” ，因爲WAP瀏覽器會自動爲您加入。

- **連接方式:** 你可設定連接方式。

1 數據

2 GPRS

- **數據設定:** 僅在您選擇「數據設定」作爲連接方式時才會出現。

IP地址: 輸入您要登入之WAP閘道的IP地址。

撥出號碼: 輸入您登入WAP閘道須撥打的電話號碼。

用戶名稱: 您的撥號伺服器（而非WAP閘道）將以此用戶名稱來確認您的身份。

密碼: 您的撥號伺服器（而非WAP閘道）將以此密碼來確認您的身份。

通話類型: 選擇數據通訊的類型：類比或數字(ISDN)。

連接速度: 數據連接的速度。

空閒時限: 您需要輸入逾時時間。輸入逾時時間後， 如果沒有輸入或傳送任何資料，將停用WAP 導覽服務。

- **GPRS設置:** 僅在選擇 GPRS 作爲連接方式時，才可使用這些服務設定。

  IP地址: 輸入您要存取之 WAP閘道的IP地址。

  APN: 輸入 GPRS的 APN。

  用戶名稱: APN伺服器的用戶身份。

  密碼: APN伺服器所需的密碼。

- **連接類型:** 連接類型可分爲暫時性或固定連接，視乎您使用的閘道 而定。

  固定連接

  一個穩定的資料傳輸系統，但會產生較多的網絡流量。

  暫時性

  一個未確定(未連接狀態)的服務。

  HTTP

  正在透過 HTTP 將用戶連線至伺服器

- **設定代理服務器**

  IP地址: 輸入代理的IP地址。

  端埠: 輸入代理連接埠號碼。

- **DNS設定**

  主伺服器: 輸入您要存取的主DNS伺服器之IP地址。

  次伺服器: 輸入您要存取的次DNS伺服器之IP地址。

- **安全設定:** 視乎您使用的閘道而定，您可以選擇此項爲開啓/關閉。

- **顯示圖像:** 您可選擇是否要顯示WAP網頁上的圖像。

► **重新命名:** 變更設定名稱。

► **刪除:** 刪除列表中選定的網絡設定。

► **新增:** 新增網絡設定。

轉至URL　　功能表-8-1-4

直接連接至想要瀏覽的網站。輸入指定網址後，按[確認]鍵。

緩存設定　　功能表-8-1-5

您已存取的資訊或服務會儲存在手機的快取記憶體中。

- **清除緩存:** 移除所有儲存在快取記憶體中的文字。
- **查詢緩存:** 設定是否透過快取記憶體進行連線。

附註 快取記憶體是一種緩衝記憶體，可用來暫時儲存資料。

Cookies設定 功能表-8-1-6

您已存取的資訊或服務會儲存在手機的快取記憶體中。

- **清除 cookies:** 移除所有儲存在 cookies內的文字。
- **查詢 cookies:** 檢查是否已使用cookies。

安全認證 功能表-8-1-7

在此功能表下將顯示一列現有的安全認證標準。

- **授權方:** 您可以查看手機儲存的機關憑證。
- **個人:** 您可以查看手機儲存的個人憑證。

重新設定 功能表-8-1-8

您可將網絡設定重設回原廠設定值。

瀏覽器版本 功能表-8-1-9

顯示 WAP 瀏覽器版本。

智能咭服務 (視乎智能咭和網絡商的支援) 功能表-8-2

您的服務供應商能夠透過智能咭提供特別申請，例如家庭銀行、股票市場等等。如果您註冊其中一項服務，服務名稱就會顯示在主功能表底部。透過智能咭服務功能表，您的手機能永保新穎，並能支援網絡供應商所增加的服務。如需進一步資訊，請與服務供應商聯絡。

遊戲及更多 功能表-9-1

我的遊戲及更多 功能表-9-1-1

在此功能表中，您可以管理手機中安裝的 Java 應用程式。您可以播放 或刪除已下載的應用程式，或設定連線選項。已下載的應用程式會整理在文件夾內。按左軟鍵 [選擇] 來開啓選定文件夾，或啓動選定 MIDlet。

按左軟鍵 [功能表]，即可使用下列目錄。

- **開始:** 開始執行選定應用程式。
- **資訊:** 顯示應用程式資訊。
- **更新:** 使用 WAP 更新應用程式。
- **選項:** 某些 Java 應用程式可能需要建立數據連線。選擇此項目以設定連線選項。
  - **允許:** 立即建立連線，不需事先通知。
  - **提示:** 在應用程式連線前先提問。
  - **從不查詢:** 不容許連線。

附註 您無法將內建子文件夾或其內的遊戲移動或重新命名。

Java™ 是 Sun Microsystems 所開發的技術。和使用標準 Netscape 或 MS Internet Explorer 瀏覽器下載 Java Applet 的方式類似，您也可以使用具 WAP 功能的手機下載 Java MIDlet。取決於服務供應商，您可以下載所有 Java 程式，例如 Java 遊戲，並在手機上執行。下載後，您可以在應用程式功能表內查看 Java 程式並進行選取、執行或刪除。本手機會以 .JAD 與 .JAR 格式儲存 Java 程式的檔案。

附註
- JAR檔案是 Java 程式的壓縮格式，JAD檔案則是包含所有詳細資訊的說明檔案。在下載之前，您可以透過網絡查看JAD檔案內全部檔案的詳細說明。
- 即使它們是以標準語言 (J2ME) 建立，並非所有 Java 應用程式均兼容於全部市售手機，因爲它們可能只針對某款手機使用特定的程式庫。若下載的 Java 應用程式，並非專門針對本手冊所述之手機設計時，軟件可能被封鎖或自行啓動，導致必須「重新啓動」手機。我們必須指出，造成這種問題的原因是應用程式不兼容，並非產品發生任何問題。

注意 只有 J2ME(Java 2 Micro Edition，Java 2 微型版)程式才能在手機環境中執行。J2SE(Java 2 Standard Edition，Java 2標準版) 程式只能在電腦環境中執行。

網絡設定 功能表-9-1-2

此功能表包含與互聯網功能表相同的設定。實際上，如要下載新應用程式，將需要使用WAP連線。

圖片 功能表-9-2

按左軟鍵 [選項] 可顯示下列選項。

- **設定爲牆紙:** 您可以將選定圖片設爲牆紙。
- **寫多媒體訊息:** 您可以透過多媒體訊息傳送圖片。

音樂 功能表-9-3

按左軟鍵 [選項] 可顯示下列選項。

- **設爲鈴聲:** 選擇此項將聲音設定爲鈴聲。
- **寫訊息:** 您可以透過文字訊息或多媒體訊息傳送聲音。

配件

手機配有多種配件。您可根據個人需要選擇所需配件。

標準電池

立體聲耳機

進行免提聽筒操作。包括耳機與麥克風。

旅行充電器

您可在離家或辦公室時使用充電器充電。

數據傳輸組件/光碟

您可使用數據傳輸組件連接 PC 進行通訊。

附註
- 請務必使用原裝 LG 配件。
- 不使用原裝配件可能會導致保養失效。
- 以上配件可因區域不同而有所差異,詳情可諮詢我們的區域服務商或代理商。

一般資料

產品名稱: LG-G233

系　　統: GSM 900 / DCS 1800

適用溫度

最高: +55℃

最低 : -10℃

LG-G233 用户手册 一简体中文

目录

产品介绍 6
安全及有效使用指南 7
LG-G233 功能 10
手机正面 10
显示信息 14

开始 15
安装 SIM 卡和手机电池 15
给电池充电 17
断开充电器 18
开机和关机 18
访问代码 19
限制密码 19

常规功能 20
拨打和应答电话 20
电话本 25
呼叫中菜单 25
多方通话或会议通话 26

菜单树 28
选择功能和选项 31
情景模式 32
启动情景模式 32
自定义情景模式-更改 32
自定义情景模式-重命名 33

通话记录 34
未接来电 34
已接来电 34
拨出电话 34
删除最近呼叫..... 35
通话计费..... 35
通话计时 35
通话费用 35
设定 35
GPRS信息 36
浏览计时 36
数据量 36

附件 37
蓝牙..... 37
我的设备 37
免提耳机 37
设定 37
计算器 37
单位转换器 38
时区设置 38
语音备忘录 39
记录 39
查看列表 39
内存状态 39

公文包 40
电话本 40
查找 40
新增 40
群组 40
快速拨号 41
设定 41
全部复制 42
全部删除 42
信息提示 42
日程表 43
备忘录 43

信息 44
新信息 44
写文本信息 44
写多媒体信息 45
收信箱 47
草稿箱 48
发信箱 49
收听语音邮件 50
小区广播 50
读取 50
栏目 50
模板 50
常用短语 50
多媒体模板 51

目录

名片 51
设定 **52**
文本信息 52
多媒体信息 52
语音邮件中心 53
小区广播 53
PUSH 信息 53

照相 **54**
照相 **54**
照在相框中 **56**
连续拍摄 **56**
相册 **57**
设定 **57**
内存状态 57
清空相册 57
自动保存 57

设定 **58**
闹钟 **58**
日期和时间 **58**
日期设定 58
日期格式 58
时间设定 58
时间格式 59
手机设定 **59**
显示设定 59
Language 59
通话设定 **59**
呼叫转接 59
接听模式 60
发送号码 60
呼叫等待 60
分钟提示 61
自动重拨 61
保密设定 **61**
需要PIN码 61
手机锁 61
呼叫限制 61
固定拨号 62

更改密码 62
网络设定 62
自动 62
手动 63
首选网络 63
恢复初始设定 63
GPRS设定 63

服务 64
互联网 64
主页 64
书签 64
上网设定 65
转到URL 67
缓存 67
Cookies设置 67
安全设置 67
重新设定 67
浏览器版本 67
SIM 服务 67

下载 68
游戏 68
我的游戏 68
上网设定 69
图片 69
音乐 69

附件 70
技术数据 71

产品介绍

祝贺您购买了此款精巧时尚的LG-G233蜂窝式电话，它是当今尖端数字移动通信科技的完美体现。

本用户手册包括重要的手机使用和操作信息。请仔细阅读以使您的手机发挥最佳性能、防止手机损坏和不正当使用。本手册未明确认可的任何更改和修改可使手机的保修失效。

请仔细阅读这些指南。违反这些规则可能造成危险或引起法律责任。我们将在本手册中为您详细地介绍相关信息。

射频能量照射

辐射波照射和吸收比率(SAR)信息

该款LG-G233型移动电话的设计完全遵循了辐射波照射的相关安全要求。该要求基于科学的指导原则，包括用于确保所有人(无论年龄和健康状况)安全的辐射允许限度。

- 辐射波照射指导原则采用了一种称为吸收比率(或SAR)的测量单位。进行SAR测试时，手机将使用一种标准化的方法，在所有可用的频段上以其最高测定能量级发射频率。
- 虽然各种型号LG手机的SAR 级可能不尽相同，但它们均是遵循辐射波曝露的相关规定设计制造而成。
- 国际非电离辐射保护委员会(ICNIRP)所规定的SAR界限是在十(10)克人体组织上平均为2W/kg。
- 经DASY3测试表明，此型号手机在手持使用时SAR的最大值为0.858W/kg(10克)。
- 各国/地区政府所采用的SAR 数据信息是由电气和电子工程师协会(IEEE)评估制定，其标准是在一(1)克人体组织上平均为1.6W/kg。

产品的保养与维护

警告：请仅使用经过认可且与特定手机型号相符的电池、充电器和配件。使用其它类型的配件将可能终止该手机的相关证明或担保，甚至可能造成危险。

- 请勿擅自拆装手机。(如需任何维修，请将其交给具备相关资格的服务技术人员。)
- 手机应远离诸如电视机、收音机或个人计算机等电器设备。
- 切勿将手机置于散热设备或炊具附近。
- 切勿抛掷手机。
- 切勿对手机造成任何机械振动或震荡。
- 手机套或乙烯基外包装均有可能对手机表面造成损伤。
- 使用干布清洁手机外壳。
  (不要使用如苯、稀释剂或酒精之类的溶剂)。

- 切勿将手机置于过度烟尘环境中。
- 切勿将手机靠近信用卡或交通票卡；这有可能影响磁条中存储的信息。
- 切勿以尖锐物体接触屏幕；否则将对手机造成损伤。
- 切勿将手机置于液体或潮湿的环境中。
- 谨慎使用耳机等手机配件。

电器设备

所有无线电话均会造成干扰，这可能会影响电器设备的性能。

- 在未得到允许的情况下，切勿将手机靠近医疗设备。请避免将手机放置在起搏器上方，例如，放在您胸前的口袋中。
- 手机还可能对某些助听设备造成影响。
- 少量干扰还可能影响到电视机、收音机、PC等。

道路安全

在您驾驶时，请查阅所在区域有关手机使用的法规。

- 请勿在驾驶时使用手持电话。
- 驾驶时应全神贯注。
- 如有条件，可使用免提装置。
- 如驾驶条件不允许，请将车停在路边或空地旁，然后再拨打或接听电话。
- 射频能量可能影响机动车辆上的某些电子系统，例如车载音响、安全设备等。
- 当车辆配备气囊时，不要让安装的或便携式的无线设备阻挡气囊。由于不适当的执行情况，可能造成严重伤害。

爆破现场

切勿在引爆过程中使用手机。请遵守相关限制，并按照规定行事。

潜在的爆炸性环境

- 切勿在加油站使用手机。切勿将手机靠近燃料或化学物品。
- 如车辆上携带有移动电话或其配件，请勿在车厢里装载或运输可燃性气体、液体或易爆物品。

飞机上

无线设备将对飞机通讯造成影响。

- 登机前请关闭移动电话。
- 未经乘务人员允许，请勿擅自使用手机。

儿童

将手机放在儿童接触不到的安全地方。手机中包含细小零件，如果吞咽可能导致窒息危险。

紧急电话

并非在所有蜂窝网络中均可使用紧急电话。因此，您不应仅依赖于手机的紧急电话功能。请与当地的服务提供商核对。

电池信息与保养

- 您不必在充电前将电池完全放电。与其它电池系统不同，该手机电池不存在影响电池性能的记忆效应。
- 请仅使用LG电池和充电器。LG充电器根据电池而设计，可最大限度地延长电池寿命。
- 切勿拆卸电池，或造成电池短路。
- 保持电池组上金属触点的干净清洁。
- 电池无法再使用时，请更换电池组。电池组在更换前一般可进行数千次充电。
- 新换电池应继续充电，以利发挥其最大功效。
- 切勿将电池充电器直接曝露于阳光下，也不应在过度潮湿的环境中使用(如浴室)。
- 切勿将电池置于高温或寒冷的环境中，这将影响电池的性能。

手机正面

手机正面

1. **耳机插孔**
   - 连接一个耳机以通过耳机进行通话。
2. **音量调节侧键**
   - 当合上翻盖时，按此键在外屏上显示当前时间。
   - 当翻盖打开时，在待机模式控制按键音音量。
   - 在通话中控制听筒音量。
3. **外屏**
4. **相机镜头**

   注意 如果相机镜头上有灰尘，将会影响图像质量。
5. **闪光灯**

右视图

侧相机键

按住此键可启动相机模式。也可用此键拍摄照片。

手机背面

翻盖打开的情况下

1. **听筒**

2, 10. **左软键/ 右软键：**这两个按键分别执行屏幕下方文字指示的功能。

3. **日程表热键：**直接激活“日程表”菜单。

4. **发送键：**拨打电话号码并应答来电。在待机模式中按此键，您可以快速访问最近的已接来电、拨出电话和未接来电。

5. **字母数字键：**输入数字、字母和一些特殊字符。

6. **话筒：**用于进行通话和录音，在通话中为保护隐私可以静音。

7. **主显示屏：**全彩显示手机的状态图标、菜单项目、Web信息、图片等等。

8. **导航键：**用于滚动查看菜单和移动光标。

9. **确认键：**选择菜单选项并确认操作。

11. **下载热键：**显示下载菜单列表

12. **结束/电源键：**用于结束呼叫或拒接呼叫，也用于返回待机模式。按住此键开关手机电源。

13. **清除/取消键：** 每按一下删除一个字符。按住此键清除所有输入内容。 也可使用此键返回上一屏幕。

14. **特殊功能键：**

- ： 长按此键可启动/停用振动模式。
- ： 长按此键可输入国际电话符号“+”。
- ： 输入电话号码时，长按此键可输入一个暂停。

显示信息

下表说明出现在手机显示屏上的各种指示符或图标。

屏幕上的图标

图 标	描 述
	表示网络信号的强度。
	通话连接成功。
	您正在使用漫游服务。
	您可以使用GPRS服务。
	闹铃已设定并启动。
	显示电池电量。
	收到文本信息。
	收到语音邮件。
	情景模式中的振动功能。

图 标	描 述
	情景模式中的大声功能。
	情景模式中的无声功能。
	情景模式中的耳机功能。
	情景模式中的私人功能。
	指示您可以使用 Push 信息服务。
	指示手机目前正在访问WAP。
	指示您目前正在使用GPRS。
	表示已激活蓝牙功能

安装 SIM 卡和手机电池

在卸下电池前确保电源已关闭。

1. **卸下电池盖。**

   按电池释放闩，将电池盖沿着手机底部滑动。卸下电池盖。

注意 如果在电源打开时从手机上卸下电池，可能导致手机出现故障。

2. **卸下电池。**

   握住电池边缘，将电池从电池室取出。

3. 安装 SIM卡

将SIM卡插入插槽内。将SIM卡滑进SIM卡插槽中。确保SIM卡以正确方式插入并且卡上的金色接触区域面朝下。要取出SIM卡，轻轻将卡向下按并反向推出。

插入SIM卡

取出SIM卡

小心 SIM 卡的金属触点很容易因刮擦而损坏。操作时请对SIM卡多加注意。遵守随SIM卡提供的说明。

4. 安装电池。

先将电池后端插入电池室底部。向下推电池前端，直至电池卡入到位。

5. 安装电池盖。

将电池盖放到手机的适当位置，并滑动它直至闩锁卡入到位。

给电池充电

要用旅行充电器为手机充电，您必须先装上电池。

1. 将旅行充电器的一端插入手机底部。
2. 将旅行充电器的另一端连接到墙上的AC电源插座。仅使用原装充电器。
3. 完全充电后电池图标条棒将停止闪烁。

小心

- 不可强行插入充电接口，因为这将损坏手机及旅行充电器。
- 将电池组充电器垂直插到墙上电源插座。
- 如果在本国外使用电池组充电器，务必使用附属的适配插头进行适当的配置。
- 充电时切勿取出电池或SIM卡。

警告

- 在发生雷电时，务必拔掉电线和充电器，以免遭受电击或发生火灾。
- 确保没有细尖的物体，如动物牙齿、指甲等进入手机内触碰电池。这存在引发火灾的危险。
- 手机在充电时，不要拨打或接听电话，否则会使手机短路和/或发生电击或引发火灾。

断开充电器

1. 充电结束后，电池图标的移动条停止并且屏幕上显示“电量已满”字样。
2. 从电源插座上拔下适配器。按住接头两侧的灰色凸钮并拉出接头，将适配器从手机上断开。

注意
- 手机原装电池在使用前必须完全充电。
- 不要在充电过程中取出电池或SIM卡。
- 如果出现电池未正确充电的情况，请使用电源键关闭并重新打开手机，然后再次对电池进行充电。在取出并重新装入电池之后，请尝试再次对电池进行充电。

开机和关机

开机

1. 在手机中装入电池，并将手机通过旅行充电器连接到外部电源。或者在手机中装入已充电的电池。
2. 按下 数秒钟，直到LCD屏幕亮起。
3. 视**需要PIN码**设置的状态而定，您可能需要输入PIN码。

关机

1. 按下 数秒钟，直到LCD屏幕关闭。

访问代码

您可以使用本节所述的访问代码来防止他人未经允许使用您的手机。可以使用更改密码功能[菜单-7-5-5]来更改访问代码(除PUK和PUK2码)。请参阅第62页。

PIN码(4至8位数字)

PIN(个人身份号码)码防止他人未经允许使用您的SIM卡。PIN码通常随SIM卡提供。当**需要PIN码**设置为开时，每次开机时手机都会要求PIN码。当**需要PIN码**设置为关时，手机将直接连接到网络，而无需PIN码。

PIN2码(4至8位数字)

某些SIM卡会提供PIN2码。仅当您的SIM卡支持此类功能时，才可以使用这些功能。请咨询网络运营商以获得进一步的信息。

PUK码(4至8位数字)

更改被锁定的PIN码时需要PUK(PIN解锁密码)码。SIM卡可能会提供PUK码。如果未提供，请联系您的网络运营商以获得该密码。如果丢失了该密码，请同样与您的网络运营商联系。

PUK2码(4至8位数字)

某些SIM卡会提供PUK2码，更改被锁定的PIN2码时需要PUK2码。如果丢失了该密码，请同样与您的网络运营商联系。

安全密码(4至8位数字)

安全密码防止他人未经允许使用您的手机。默认的安全密码设置为“0000”删除所有电话记录及激活**恢复初始设定**菜单时需要安全密码。并且，开关手机锁定功能以防止未经允许使用手机时，也需要安全密码。从**保密设定**菜单中可以修改安全密码默认设置。

限制密码

当使用**呼叫限制**[菜单-7-5-3]功能时需要限制密码。当预订了此功能时，您将从网络运营商处获得此密码。有关详细信息，请参阅第61页。

拨打和应答电话

拨打一个电话

1. 确保手机已开机。
2. 输入电话号码，包括区号。
   - 若要删除已输入的数字,您只需按 即可。
3. 按 [发送]键来拨打该号码。
4. 按 [结束]键来结束通话。

使用发送键拨打电话

1. **在待机模式中，按发送键**( )，将显示最近的已接来电、拨出电话和未接来电号码。
2. 使用向上/向下导航键选择所需的号码。
3. 按 。

拨打国际电话

1. 拨打国际电话先长按 得到国际电话前缀，符号“+”在拨叫过程中将被替代为国际通话接入码。
2. 输入国家代码，区位号以及电话号码。
3. 按 。

结束呼叫

当完成呼叫后，按结束 ( ) 键。

从电话本中拨打一个电话。

您可以将常用的联系人姓名和电话号码保存在SIM卡和（或）手机内存中，这就是电话本功能。通过在电话本中查找所需的姓名，即可拨打相应电话号码。

调节音量

如果需要在呼叫期间调节听筒音量，请使用侧键( )。

注意 按上面的侧键以提高音量，按下面的侧键以降低音量。

应答电话

当接收到电话时，手机响铃并且外部 LCD 指示灯闪烁。如果可以识别致电者，则会显示该致电者的电话号码（或保存在电话本中的姓名）。

1. 要应答来电，请打开翻盖。
   （当已将**翻盖接听**设置为接听模式时。请参阅第60页[菜单-7-4-2]。）

   注意 如果已将“**任意键接听**”设置为接听模式（请参阅第60页），则按除 或右软键和音量侧键以外的任何按键都可应答电话。

   备注

   - 要拒接来电，请在不打开翻盖的状态下按住手机左侧的侧键之一。
   - 当正在使用电话本或其它菜单功能时，也可以应答电话。

2. 要结束呼叫，请关闭翻盖或按 。

静音速拨模式（快速）

开机后，按住左导航键，可以激活静音速拨模式。

信号强度

如果是在建筑物内部，移到窗口附近可以改善信号接收质量。您可以通过手机 LCD 屏幕上的信号指示符（ ）检查信号强度。

输入文本

您可以使用手机键盘输入字母数字字符。例如，在电话本中存储姓名、写短信、创建个人问候语或者在日历中安排事件等，都需要输入文本。

本款手机提供以下文本输入方法。

T9 模式

此模式允许以每个字母只需一次击键的方式输入单词。键盘上的每个按键对应于多个字母。T9 模式自动将所击按键与内部词典进行比较，然后确定正确的单词，因此所需的击键次数比传统的 ABC 模式要少。有时这也称为预测性文本。

ABC 模式

在此模式中，输入字母时，按标示为所需字母的按键一次、两次、三次或更多，直到显示该字母。

123 模式（数字模式）

以每个数字一次击键的方式输入数字。要在文本输入区域中更改为 123 模式，按 # 键直到显示 123 模式。

更改文本输入模式

1. 当处于允许输入字符的区域中时，在 LCD 屏幕的右上角可以看到文本输入模式指示符。
2. 通过按 # 更改文本输入模式。T9模式 只能通过左软键选定。

► 使用 T9 模式

T9 预测性文本输入模式允许您以最少的按键次数输入单词。当您按每个按键时，手机开始显示它根据内置词典认为正确的字符。您还可以在词典中添加新单词。当添加新单词时，手机将从词典中选择可能性最大的单词。

1. 当处于 T9 预测性文本输入模式时，通过按 2 到 9 键开始输入单词。每个字母按一次键。
   - 在输入字母时，单词不断更改。请忽略屏幕上显示的单词，直到整个单词输入完毕。
   - 如果在完成输入之后单词仍不正确，按向下导航键一次或多次以循环选择其它单词。

     例： 按 4 6 6 3 输入 Good

     按 4 6 6 3 [向下导航键] 输入 Home
   - 如果供选单词列表中没有所需的单词，请使用 ABC 模式添加该单词。

– 您可以选择T9模式的语言。按左软键[选项]，然后选择**T9语言**输入法选择T9模式的所需语言。手机的默认设置为“**T9开启**”模式。

2. 输入整个单词之后再对输入的内容进行编辑或删除。

3. 按 0+ 键以空格结束每个单词。要删除字母，按 C 。按住 C 删除整个单词。

注意 要从文本输入模式中退出而不保存输入内容，按 ☎ 。手机返回待机模式。

► 中文输入法

1. **ST(笔划)**：如何使用笔划来选择中文字符。在您依次输入中文笔划时，屏幕上将显示相关的中文字符。使用 (和) 键来查看符合条件的其它字符，按 OK 钮选定字符。同样，使用 (、)、 和 键也可以查看更多类型的字符。

例如) 要输入“你好”请依次按数字 3、2、3。随后，您便可以看到第一个字符为“你”。请按 OK，然后再按 1 按钮选定“你”。

按　键	笔　划
1	一
2	丨
3	丿
4	丶
5	乛
6	？(通配符号)
OK	选择键

<汉字笔划表>

2. PY(拼音)：“拼音”输入是通过中文字符的发音来查找中文字符。
   拼音：当输入发音的第一个字母时，您便可以直接查找字符。

按　键	英文字母
1	
2	ABC
3	DEF
4	GHI
5	JKL
6	MNO
7	PQRS
8	TUV
9	WXYZ
OK	选择键

〈汉语拼音表〉

► **使用 ABC 模式**

使用 2 至 9 键输入文本。

1. 按标示为所需字母的按键：
   - 按一次输入第一个字母
   - 按两次输入第二个字母
   - 依此类推
2. 要插入空格，按 0 键一次。要删除字母，按 C 键。按住 C 键以清除显示的所有内容。

注意 有关可使用字母数字键输入的字符，请参阅下表了解更多信息。

按键	按顺序显示的字符	
	大　写	小　写
1	.,/?!-:'" 1	.,/?!-:'"1
2	A B C 2 Ä À Á Â Ã Å Æ Ç	a b c 2 ä à á â ã å æ ç
3	D E F 3 Ë È É Ê	d e f 3 ë è é ê
4	G H I 4 Ï Ì Í Î Ğ	g h i 4 ï ì í î ğ
5	J K L 5	j k l 5
6	M N O 6 Ñ Ö Ø Ò Ó Ô Õ Œ	m n o 6 ñ ö ø ò ó ô õ œ
7	P Q R S 7 ß Ş	p q r s 7 ß ş
8	T U V 8 Ü Ù Ú Û	t u v 8 ü ù ú û
9	W X Y Z 9	w x y z 9
0	[空格键] 0	[空格键] 0

► 使用 123（数字）模式

使用 123 模式，您可以在文本信息中输入数字(例如电话号码)。按与所需数字对应的按键，然后手动切换回适当的文本输入模式。

电话本

您可以将电话号码及其对应的姓名存储在SIM卡的内存中。此外，您还可以在手机内存中存储最多1000个号码和姓名。电话本菜单中以同样方式使用SIM卡和手机内存两者。

呼叫中菜单

您的手机提供许多可以在呼叫期间使用的控制功能。要在呼叫期间访问这些功能，按左软键[选项]。

呼叫期间

在手机屏幕上，在呼叫期间显示的菜单与在待机模式中显示的默认主菜单不同，下面对这些选项进行说明。

开启扬声器

在通话期间会显示扬声器图标。按住OK键您可以开启/关闭扬声器。

拨打第二个电话

您可以从电话本中查到号码以拨打第二个电话。按右软键，然后选择**查找**。要在呼叫期间将所拨的号码保存到电话本中，请按右软键，然后选择**新增**。

在两通话间切换

要在两个呼叫之间切换，按左软键[选项]，然后选择切换通话。

接听来电

要在手机响铃时应答来电，只需按 键。当您已处于呼叫中时，手机还能够提示您有新入来电。听筒中发出提示音，显示屏上将显示第二个呼叫正在等待。此功能称为**呼叫等待**，仅当网络支持此功能时才可使用。有关如何激活和停用此功能的详细信息，请参阅第60页的**呼叫等待**[菜单-7-4-4]。

如果激活了**呼叫等待**功能，您可以按 从而保持第一个呼叫并应答第二个呼叫。

拒接来电

只需按 键，您可以拒接来电而不作应答。在呼叫期间，您也可以通过按 ，拒绝接听来电。

使麦克风静音

在呼叫期间，您可以通过按[选项]键，然后选择静音，使麦克风静音。通过选择**取消静音**，可以解除手机的静音。当手机静音时，致电者不能听到您的声音，但您仍可以听到他们的声音。

在呼叫期间打开双音多频音调

要在呼叫期间打开双音多频音调，按左软键，然后选择**开启双音多频**。可以使用同样方式关闭双音多频音调。双音多频音调允许您的手机使用自动电话交换台。

多方通话或会议通话

通过多方通话服务，您能够与多个致电者同时通话（如果您的网络运营商支持此功能）。仅当您具有一个活动的呼叫及一个保持的呼叫时（已应答这两个呼叫），才可以建立多方通话。一旦建立多方通话，则建立多方通话的用户可以添加、断开或分离

（即从多方通话中撤出，但仍与您相连接）呼叫。所有这些选项均在“通话中”菜单中提供。在多方通话中最多可以与五位致电者通话。开始之后，您即可以控制多方通话，并且只有您能将致电者加入多方通话。

拨打第二个电话

当目前已处于呼叫中时，您可以拨打第二个电话。输入第二个号码并按 键。当连接第二个呼叫之后，第一个呼叫自动置于保持状态。您可以通过按左软键，然后选择**切换通话**，在两个呼叫之间切换。

建立多方通话

保持一个呼叫，并在一个呼叫处于活动状态时，按左软键，然后选择**多方通话/全部加入**。

保持多方通话

按左软键，然后选择**多方通话/全部保持**。

激活保持的多方通话

按左软键，然后选择**多方通话/全部加入。**

向多方通话加入呼叫

要将呼叫加入现有的多方通话，按左软键，然后选择**多方通话/全部加入**。

显示多方通话中的所有致电者

要在手机屏幕上滚动显示组成多方通话的致电者号码，请使用向上/向下导航键。

在多方通话期间拨打私人电话

要与多方通话中的某个致电者进行私人通话，在屏幕上显示该致电者的号码，然后按左软键。选择**多方通话/私人通话**将其他致电者置于保持状态。

结束多方通话

要结束多方通话，请按 键。您也可以通过按左软键后选择结束通话来结束多方通话。要结束多方通话，按左软键，然后选择**多方通话/结束多方通话**。在按左软键后，选择**全部结束**，所有活动和保持的呼叫都将结束。

菜单树

1. 情景模式

1 振动

2 无声

3 私人

4 大声

5 耳机

2. 通话记录

1 未接来电

2 已接来电

3 拨出电话

4 删除最近呼叫

5 通话计费

6 GPRS信息

3. 附件

1 蓝牙

2 计算器

3 单位转换器

4 时区设置

5 语音备忘录

6 内存状态

4. 公文包

1 电话本

2 日程表

3 备忘录

5. 信息

1 新信息
2 收信箱
3 草稿箱
4 发信箱
5 收听语音邮件
6 小区广播
7 模板
8 设定

6. 照相

1 照相
2 照在相框中
3 连续拍摄
4 相册
5 设定

7. 设定

1 闹钟
2 日期和时间
3 手机设定
4 通话设定
5 保密设定
6 网络设定
7 恢复初始设定
8 GPRS设定

8. 服务

1 互联网

2 SIM 服务

9. 下载

1 游戏

2 图片

3 音乐

本款手机提供一系列可供您使用和自定义手机的功能。这些功能位于菜单和子菜单中，可以通过标记为左软键 和右软键 的两个软键来访问。

每个菜单和子菜单允许您查看和更改特定功能的设置。根据当前的操作环境，软键发挥的作用也不同。每个按键上方、屏幕底部一行的文字指示其当前的作用。

按左软键访问可用的菜单。

按右软键激活相应的操作。

情景模式

在“情景模式”中，您可以调节和自定义手机铃声，用于不同的事件、环境或群组。有五种预设的情景模式：**振动、无声、私人、大声、耳机**
情景模式均可以加以个人化（振动和无声除外）。

启动情景模式 菜单-1-x-1

1. 屏幕上显示情景模式的列表。
2. 在**情景模式**列表中，滚动到要启动的情景模式，然后按左软键[选择]或“确定”键。
3. 然后，选择**启动**。

注意 当连接耳机时，**耳机**模式自动启动。

自定义情景模式-更改 菜单-1-x-2

您可以自定义除振动和无声以外的情景模式。在情景模式列表中，滚动到所需的情景模式。按左软键或 OK 键后，选择“**更改**”。情景模式设置选项打开。按需要设置该选项。

- **来电提示：**设置来电提示类型。
- **铃声类型：**从列表中选择所需的铃声类型。
- **铃声音量：**设置铃声的音量。
- **信息提示：**选择所需的信息提示类型。
- **信息提示音：**设置信息提示音。
- **按键音：**选择所需的按键音。
- **按键音量：**设置按键音的音量。
- **翻盖音：**可设置翻盖音，从而适应环境。
- **确认音音量：**设置声效的音量。
- **开/关机音量：**设置开机/关机时的铃声音量。
- **自动应答：**请注意只有耳机模式拥有该子功能表。
  - **关：**即使您的手机响铃，也不会自动应答。
  - **5秒后：**在来电话5秒后自动应答。
  - **10秒后：**在来电话10秒后自动应答。

自定义情景模式-重命名 菜单-1-x-3

您可以将情景模式重命名为所要的任何名称。

注意 不能重命名振动、无声和耳机情景模式。

1. 要更改情景模式的名称，在情景模式列表中滚动到该情景模式，在按“OK”键或左软键之后，选择**重命名**。
2. 键入所需的名称，然后按左软键[确认]。

仅当网络支持服务区内的主叫线路识别(CLI)时，您才能检查未接来电、已接来电和拨出电话。屏幕上显示电话号码和姓名（如果有）以及通话日期和时间。您还可以查看通话计时和计费。

未接来电 菜单-2-1

此选项允许您查看最后10个未应答的来电。在按左软键[选项]之后，您还可以：

- 查看详情（如果可用）。
- 为这个号码编辑新姓名并保存。
- 向该号码发送信息。
- 从列表中删除该呼叫。

注意 使用**删除最近呼叫**菜单[菜单-2-4]，您可以从列表中删除所有通话记录。

已接来电 菜单-2-1

此选项允许您查看最近10个来电。在按左软键[选项]之后，您还可以：

- 查看详情（如果可用）。
- 为这个号码编辑新姓名并保存。
- 向该号码发送信息。
- 从列表中删除该呼叫。

注意 使用**删除最近呼叫**菜单[菜单-2-4]，您可以从列表中删除所有通话记录。

拨出电话 菜单-2-3

此选项允许您查看最后20个去电（拨出或尝试）。使用[选项]键，您还可以：

- 查看详情（如果可用）。
- 为这个号码编辑新姓名并保存。
- 向该号码发送信息。
- 从列表中删除该呼叫。

注意 使用**删除最近呼叫**菜单[菜单-2-4]，您可以从列表中删除所有通话记录。

删除最近呼叫 菜单-2-4

使用此功能删除未接来电列表、已接来电列表或拨出电话列表。您也可以选择**全部通话**一次性删除所有通话列表。

通话计费 菜单-2-5

通话计时 菜单-2-5-1

可查看来电和去电的通话时间长度。选择全部清零，还可以将通话计时器复零。为了防止意外复零，手机将提示您确认。

- **最后通话**：最后一次通话的时间长度。
- **全部通话**：上次计时器重设之后，所有来电和去电的总时间长度。
- **已接来电**：来电的时间长度。
- **拨出电话**：去电的时间长度
- **全部清零**：将通话计时器复零。

通话费用 菜单-2-5-2

可检查最后通话、全部通话的费用，余额或重置费用。要重置费用，您需要输入PIN2码。

设定 菜单-2-5-3

- **通话费率**：您可设置货币类型和计费单价。与通话费率的服务提供商联系以获得计费单价。要在该功能表选择货币或单位，您需要PIN2码。
  如果您想输入 @，£，$ ，清除全部货币符号，然后按 键，如果您想更换符号，再次按 键。
- **设定话费**：该网络服务可让您通过选择计费单位来限制您的通话费用。如果您选择**读取**，将显示余额。如果您选择**更改**，您可以更改计费限制。
- **自动显示**：该网络服务可让您自动查看最后通话的费用。如果您在自动显示功能表中选择开，通话结束时，您即可查看最后通话的费用。

GPRS信息 菜单-2-6

您可以查看通过GPRS在网络上传输的数据量。另外，您还可以查看您的在线时间。

浏览计时 菜单-2-6-1

您能查看GPRS的**最后**浏览时间和**全部**浏览时间，您也可以将浏览计时器复零。

数据量 菜单-2-6-2

您可以查看**已发送**,**已接收**或者**全部**和**全部清零**。

蓝牙 菜单-3-1

使用蓝牙，您可以与近距离的可兼容移动设备、外围设备和计算机直接通信，而无需任何连线。本手机支持内置蓝牙连接，这样使其可与兼容的蓝牙手机、计算机应用程序等连接。

我的设备 菜单-3-1-1

您可以查看与蓝牙手机兼容的所有设备。

免提耳机 菜单-3-1-2

您可以查看与蓝牙手机兼容的免提设备列表。

设定 菜单-3-1-3

您可以查找与蓝牙兼容的新设备。如果您已经查找到新设备，您可以在输入密码后要求添加该设备。

- **蓝牙设定：**您可以开启或关闭蓝牙功能。
- **是否可见：**您可以设定是否允许别的蓝牙设备搜索到您的手机。
- **手机昵称：**您可以设置您的蓝牙设备的昵称，默认昵称是G233。

计算器 菜单-3-2

计算器提供基本的数学运算功能：**加**、**减**、**乘**、**除**。

1. 使用数字键输入数字。
2. 按相应导航键选择数学运算功能。

   注意
   - 要删除任何错误的输入并清空显示屏，按 C 键。
   - 要输入小数点，按 * 键。
   - 要输入负号，按 # 键。
3. 要计算结果，按左软键[结果]或“确定”键。
4. 计算之后，按左软键[重设]返回初始状态。

单位转换器 菜单-3-3

该功能可将任何单位转换为您需要的单位。有4种可以转换的单位类型：**长度**、**面积**、**重量**、和 **体积**。

1. 您可以通过按 [单位]键选择4种单位类型中的一种。
2. 使用向左/向右导航键选择要转换的单位。
3. 按向下导航键移到“转换值”单位部分。
4. 使用向左/向右导航键选择要转换到的目标单位。
5. 使用数字键输入数字。手机自动进行转换计算。

注意 您可以按 键输入小数点。

时区设置 菜单-3-4

使用向左/向右导航键，您可以查看格林威治标准时间(GMT)和世界各地69个主要城市的时间。屏幕上显示城市名、当前日期和时间。

要选择您所位于的时区，请按以下步骤操作：

1. 按向左/向右导航键一次或多次，选择与您的时区对应的城市。屏幕上显示当地日期和时间。
2. 如果您想在待机模式中更改时间显示以反映正确的时间，按左软键[设定]。

注意 在“**时区设置**”菜单中每个城市的时区设置可能受网络条件的影响。

语音备忘录 菜单-3-5

您可以录制语音备忘录。最多可以录制10条语音备忘录，每条最长20秒。

记录 菜单-3-5-1

1. 要录制语音备忘录，请选择“**记录**”。
2. 一旦开始录音，屏幕上显示“录音中……”字样以及录音时间。
3. 完成录音之后，按左软键[保存]。
4. 输入语音备忘录标题，按左软键[确认]。

注意 如果所有备忘录位置均已满，您必须删除旧的备忘录之后才能录制新备忘录。

查看列表 菜单-3-5-2

手机从最近的备忘录开始显示语音备忘录列表。您可以按左软键[选项]播放或删除所录制的备忘录。您也可以删除所有备忘录。

内存状态 菜单-3-6

您可以检查各个存储器，SIM卡内存的可用空间和内存使用率。您也可以使用左软键[转到]转到各个存储器菜单。

电话本 菜单-4-1

注意 您可以在待机模式下按左软键进入功能表并选择公文包，进入[电话本];或者，在待机模式中按右软键[电话本]。

查找
(从电话簿呼叫) 菜单-4-1-1

1. 按左软键[选择] 或 [确定] 进行搜索。
2. 输入要搜索的姓名或选择左软键 [列表] 查看所有电话簿列表。

注意 在英文状态下，也可以通过输入要搜索的姓名的第一个字母或号码立即进行搜索。

3. 找到所需的姓名之后，您可以按[发送]键拨打该号码。或者按左软键[选项]以使用以下选项。

- **编辑：**可通过使用导航键编辑姓名、号码、群组、头像和图片。
- **写文本信息/写多媒体信息：**找到您要的号码后，则可给选定的号码发送一条短信/彩信。
- **通过蓝牙发送：**通过蓝牙发送找到的电话本条目。
- **复制：**可将一个条目从 SIM 卡复制到手机或从手机复制到 SIM 卡。
- **主要号码：**可从您常用的移动电话、家庭电话和办公电话中选择一个号码作为主号码。设置此号码后，在搜索时主号码将优先显示。
- **删除：**可删除一个条目。

新增 菜单-4-1-2

您可以使用该功能来添加电话簿条目。共有两个内存:手机内存和SIM 内存。要选择内存，请转到保存至[菜单-4-1-5-1]。
手机内存容量为1000个条目。SIM卡内存容量取决于移动电话服务提供商。

群组 菜单-4-1-3

每个群组最多可以列出20个成员。您可以设定7个群组列表。

- **成员列表：**您可以查看群组的成员。
- **群组来电铃声：**您可以根据群组不同设定来电铃声。
- **群组标志：**您可以根据群组不同设定标志。

► **添加成员：**

- 选择添加成员
- 每个群组不能超过20名成员。

► **删除成员：**您可以把成员从该群组中删除。

► **重命名：**您可以修改和编辑群组名称。

快速拨号

菜单-4-1-4

您可以为姓名列表条目指定按键 2abc ～ 9wxyz 中的任一键。直接按此键2-3 秒即可拨打相应号码。

1. 首先，在待机模式下按[电话本]打开电话簿。
2. 滚动到**快速拨号**，然后按[选择]进入该功能表。
3. 要将号码添加到**快速拨号**，选择**空**。然后，您可以在电话簿中查找姓名。
4. 通过按左软键[选项]，您可以更改或删除快速拨号号码、拨打电话或发送信息。

设定

菜单-4-1-5

► **保存至**

您可以选择电话本条目保存的内存，SIM卡或手机。如果您选择自选，在添加条目时，手机将提示保存至何处。

► **查找方式**

当您查找电话本条目时，您可以设置通过姓名或号码查找。如果您选择自选，在查找时，手机将提示如何查找。

► **查看选项**

您可以设置电话本显示选项。

- **只显示姓名：**当您查找电话本时，只显示姓名列表。
- **图片电话本：**当您查找电话本时，显示姓名和相应图片。
- **姓名与号码：**当您查找电话本时，显示姓名和号码列表。

全部复制 菜单-4-1-6

您可以将条目从SIM卡内存复制/移动到手机内存或从手机内存复制/移动到SIM卡内存。

- **SIM卡转到手机：**将SIM卡中的条目复制到手机内存。
- **手机转到SIM卡：**将手机内存中的条目复制到SIM卡。

可以使用以下选项。

- **保留原号码：**复制时保留原来的拨号号码。
- **删除原号码：**复制时删除原来的拨号号码。

全部删除 菜单-4-1-7

您可以删除 SIM 卡或手机中的所有条目。此功能要求安全密码。 按 返回待机模式。

信息提示 菜单-4-1-8

► **特别服务号码**

使用该功能访问您的网络运营商提供的特殊服务(如果您的SIM卡支持)。

1. 滚动到**特别服务号码**，然后按[选择]进入。
2. 将显示可用的服务名称。
3. 使用 键和 键选择服务。按 键[发送]。

► **内存状态**

您可以查看当前的SIM卡和手机内存内存状态。

► **本手机号码（取决于SIM卡）**

您可以存储并查看自己的SIM卡号码。

日程表 菜单-4-2

当进入此菜单时，屏幕上出现日历。当前日期上有一方形光标。您可以使用导航键将光标移到另一日期。在日程表上，您可以使用以下按键。

每按一下	1	后退一年。
	3	前进一年。
	*	后退一个月。
	#	前进一个月。

您可以通过按左软键[选项]在日历中输入一个日程。

- **新增：** 选择此菜单输入一个新的日程表。当在一个日期上输入日程表后，此日期将以不同的颜色显示，并且在屏幕右下角显示 。该功能可以提醒您记住您的日程表。如果您已设定提示，手机将发出提示音。
- **查看：** 显示您所选日期的日程表提示。按左软键[选项]编辑或删除您选择的提示。
- **查看全部：** 显示手机中已设定的所有提示。通过向上/向下导航键在提示列表中移动。
- **删除已过日程：** 通过此功能删除已经过期的日程。您将被确认此操作。
- **全部删除：** 通过此功能删除所有日程提示。您将被确认此操作。

备忘录 菜单-4-3

通过此功能添加一个备忘录。最多可以存储20个备忘录。

注意 如果要更改文本输入模式，请按 # 依次转换拼音/笔划/123/abc/ABC模式。

本功能表涉及的功能包括：SMS(短消息服务)，MMS(多媒体信息服务)，语音邮件和网络服务信息。

新信息 菜单-5-1

写文本信息 菜单-5-1-1

您可写入并编辑文本信息。您也可以查询信息页数。

1. 按[选择]进入**信息**功能表。
2. 如果您想编写新信息，在功能表中选择新信息/**写文本信息**。
3. 使用T9文本可更容易地输入信息。
4. 选择[添加]来选择添加以下各项。
5. 当您想设置信息选项或已经编辑完信息时，按[选项]。

注意 支持EMS R5的手机可以发送彩色图片、音乐、文字字体等等，但其他不支持此功能的手机可能并不能正确接收您发送的彩色图片、音乐或文字字体。

添加

- **符号：**您可以添加特殊符号。
- **图片：**可插入默认图片或我的文件夹中的图片，以便用短信发送。
- **歌曲：**您可以添加支持短信的歌曲。
- **常用短语：**您可以使用已在手机中设置过的常用短语。
- **电话本：**您可以添加电话本中的电话号码或e－mail地址。
- **名片：**您可以添加您的个人联系信息。

选项

- **发送：**发送文本信息。
  1. 输入接收者的号码。
  2. 按 键可加入更多的接收者。
  3. 您可以加入电话本中已存的号码。
  4. 输入号码后按[发送]键。

所有信息均会自动保存在发信箱中，即使在发送失败之后。

- **保存**：将信息储存在草稿箱内。
- **字体**：您可以选择文字的**大小**和**风格**。
- **颜色**：您可以选择背景和文字的**颜色**。
- **对齐**：您可以将信息内容调整为右对齐、居中或左对齐。
- **字典**：您可以添加您自己的单词。此功能表只有在T9英文输入模式(T9Abc/T9abc/T9ABC)时才会显示。
- **T9语言输入法**：选择T9输入法。
- **退出**：如果在写信息时按“退出”，可结束写信息并返回“信息”菜单。您写的信息不会保存。

写多媒体信息

菜单-5-1-2

多媒体信息可以包含文本、图像和(或)声音剪辑。仅当您的网络运营商或服务提供商支持此功能时，才能使用多媒体信息。只有提供多媒体信息或电子邮件功能的设备可以收发多媒体信息。

您可以编辑多达10页的多媒体信息。(大约是100KB)

1. 输入信息主题后按左软键[确认]。
2. 输入信息。使用右软键[添加]，您可以添加符号，照片，图片，歌曲，语音备忘录，常用短语，电话本，名片。
3. 按左软键[选项]。可以使用以下选项。

- **发送**：您可以同时发送多媒体信息给多个接收人。

  1) 输入号码。您可以从近期号码或电话本中查找号码，按左软键[查找]。

  2) 按右软键[设定]，您可以设定以下选项：

  - **优先级**：设定多媒体信息的优先级。
  - **有效期**：设定多媒体信息在网络服务器中保存的时间。可能的值有1小时、12小时、1天、1星期及由网络运营商批准的最长时间。
  - **发送报告**：选择是，启用发送报告功能。当此功能被激活后，网络将通知您信息是否已发送成功。

3) 按左软键[发送]。

- **预览：**选择此功能查看您编写的多媒体信息。每一页面都连续的自动播放。使用向左/向右导航键可以从当前页转到另一页。要重放信息，按左软键[重放]。
- **保存：**您可以将多媒体信息保存到草稿箱或者保存为模板。
- **增加页面：**您可以在当前编辑的页面之前或之后增加新的页面。
- **转到：**通过此功能您可以移动到前一页或后一页。
- **删除幻灯片：**删除当前页。
- **设置信息格式：**您可以设定以下幻灯片格式。
  - **设定定时器：**使用数字键为每一页设置定时器。
  - **置换文本和图片：**置换信息中文本和图片的位置。
- **删除多媒体(这一选项仅在有多媒体存在时才显示)：**您可以删除页面中的图片，歌曲或者语音。
- **字典：**在T9文本输入模式下没有找到您需要的单词时，您可以使用此功能在T9字典中添加新的单词。
- **T9语言输入法：**选择T9语言输入法激活T9输入模式。关于T9模式的详细信息，请参阅21～23页。
- **退出：**退出多媒体信息编辑。

收信箱 菜单-5-2

当收到信息时，手机会给予提示。收到的信息会存储到收信箱中。当收到彩信时，您将会收到提示。这些彩信保存在收信箱中。您可以通过图标识别每条短信。有关详细信息，请参阅以下图标说明。

图 标	指 示 图 标
	已读SIM卡短信
	未读SIM卡短信
	已读信息
	未读信息
	已读状态报告
	未读状态报告

如果手机上提示“内存已满”，您可以通过删除信息、媒体和应用程序获得空间。

注意 SIM短信是指保存在SIM内存中的短信。网络将识别收到的短信是SIM短信或普通短信。

每条收到的短信具有以下选项。

按左软键[选项]。

- **查看：** 您可以查看选择的信息。
- **回复信息：** 您可以向发送方回复信息。
- **转发：** 您可以转发信息给另一方。
- **回复电话：** 您可以向发送方回复电话。
- **删除：** 删除所选信息。
- **保存信息资料：** 从短信中提取图片、声音、文本web页面或电子邮件地址。这些内容将被保存到“我的文件夹”、“电话本”或书签中。.
- **查看详情：** 显示有关消息的信息。

图 标	指 示 图 标
	已读多媒体信息
	未读多媒体信息
	已读通知多媒体信息
	未读通知多媒体信息

每条收到的多媒体信息具有以下选项。

按左软键[选项]。

- **回复信息**：您可以向发送方回复信息。
- **转发**：您可以转发当前信息给其他接收方。
- **回复电话**：您可以向发送方回复电话。
- **删除**：删除所选信息。
- **保存信息资料**：提取图片或声音。这些内容将保存在“我的文件夹”或“电话本”中。
- **查看详情**：您可以查看收信箱中信息的标题（仅适用于多媒体信息）、信息发送的日期和时间、信息的类型和信息的大小及发送报告。

草稿箱 菜单-5-3

您可以查看存在草稿箱中的信息。信息按照保存的日期和时间保存在草稿箱中。您可以使用向上/向下键在列表中移动。

图 标	指 示 图 标
	多媒体信息
	文本信息

每个草稿信息具有如下选项。

按左软键[选项]。

- **查看**：您可以查看所选的信息。
- **编辑**：您可以编辑所选的信息。
- **删除**：从草稿箱中删除所选的信息。
- **查看详情**：您可以查看所选信息的详情：标题（仅适用于多媒体信息），信息保存的日期和时间，信息类型和大小，优先级（仅适用于多媒体信息）。
- **全部删除**：删除草稿箱中的所有信息。

发信箱 菜单-5-4

您可以看到已经被发送和没有被发送的信息。对于已经发送的信息，您可以看到发送状态报告。

同在收信箱中一样，您可以通过图标识别信息。

图 标	指 示 图 标
	多媒体信息已发
	多媒体信息未发
	多媒体信息发送已确认
	短信息已发
	短信息未发
	短信息发送已确认

每条信息具有以下选项。

按左软键[选项]。

每条发送成功的信息具有以下选项。

- **查看**：您可以查看所选的信息。
- **转发**：您可以转发所选的信息给其他接收者。
- **删除**：从发信箱中删除已经发送的信息。
- **查看详情**：您可以查看所选信息的详情：标题(仅适用于多媒体信息)，信息发送日期和时间，信息类型和大小，优先级(仅适用于多媒体信息)和收件人。
- **全部删除**：删除发信箱中所有的信息。

每条正在发送的信息具有以下选项。

- **查看**：您可以查看所选的信息。
- **取消**：取消发送所选的信息。
- **删除**：取消发送并删除所选的信息。
- **查看详情**：您可以查看所选信息的详情：标题(仅适用于多媒体信息)，信息发送的日期和时间，信息类型和大小，优先级(仅适用于多媒体信息)和收件人。
- **全部取消**：取消所有信息的发送。
- **全部删除**：取消发送并删除所有信息。

收听语音邮件 菜单-5-5

此菜单提供访问语音邮箱的快速方法(如果网络提供语音邮箱)。
在使用此功能之前，您必须输入从网络运营商处获得的语音服务号码。
当收到新的语音邮件时，屏幕上显示相应符号“ ”。请向您的网络服务提供商查询服务详情，以便相应地配置手机。

小区广播 菜单-5-6

小区广播短信是网络向手机用户发送的文本信息。它们提供诸如天气报告、交通新闻、出租车、药店和股票行情之类的一般信息。每种类型的信息均有相关的服务号码，这可以从网络运营商处获得。当您收到信息服务短信时，将出现说明收到新短信的弹出信息或者直接显示信息服务短信。查看信息服务短信时可以使用以下选项。

读取 菜单-5-6-1

当您接收到小区广播信息时，可以通过选择读取显示信息。

栏目 菜单-5-6-2

要创建新栏目，按左软键[选择]，然后选择**新增**。如果已有栏目，您可以通过左软键[选项]来关闭、修改或删除它们。

模板 菜单-5-7

创建一些模板（文本信息、多媒体信息、名片）后，在您发送消息时，选择这些模板即可使用。

常用短语 菜单-5-7-1

以下是预定义的文本模板。

- **请回电！**
- **对不起！我迟到了，我马上到。**
- **你现在在哪里？**
- **我在路上。**
- **非常紧急，请速联系！**
- **我爱你！**

可以使用以下选项。

► **查看：**选择它以便查看所选的模板。

- **编辑** ：使用此功能在常用短语列表中编辑所选短语。
- **添加**：使用此功能添加新的常用短语。
- **写信息**：您可以使用模板写文本信息或多媒体信息。
- **删除**：您可以删除模板。
- **全部删除**：允许您删除所有模板。

多媒体模板 菜单-5-7-2

您可以按左软键[添加]创建一个多媒体模板。当您写多媒体信息时也可以把创建的多媒体信息保存为模板(参阅45页)。

- **查看**：您可以查看多媒体信息模板。
- **修改**：您可以编辑多媒体信息模板。
- **新增**：允许您添加新的多媒体信息模板。
- **写信息**：您可以使用模板写多媒体信息。
- **删除**：从多媒体模板列表删除所选的多媒体模板。
- **全部删除**：允许您删除所有模板。

名片 菜单-5-7-3

1. 按左软键［添加］。
2. 输入姓名后，按左软键［确认］。
3. 输入手机号码、住宅电话号码、办公室电话号码、传真号码和电子邮件地址。
4. 按左软键［保存］。

创建签名模板后，您可以按左软键［选项］访问以下菜单。

- **编辑**：使用此菜单编辑签名。
- **删除**：使用此菜单删除签名。
- **发送**：您可以通过短信，彩信或蓝牙发送您的名片。
- **通过蓝牙接收**：您可以通过蓝牙接收其它名片。
- **通过蓝牙互换**：您可以通过蓝牙与他人交换名片。

设定 菜单-5-8

文本信息 菜单-5-8-1

此菜单允许您设置默认的SMS信息。

- **信息类型：** 设置默认的信息类型(文本、语音、传真、国内传呼、X.400、电子邮件和ERMES)。网络可以将信息转换为所选格式。
- **信息有效期：** 设置当尝试向接收人发送文本信息时将文本信息保存在SMS中心的时间。可能的值有1小时、12小时、1天、1星期及由网络运营商批准的最长时间。
- **状态报告：** 激活或停用报告功能。当激活此功能时，网络通知您短信是否已成功发送。
- **回复付费：** 允许SMS短信的接收人通过您的信息中心向您发送回复(如果网络提供此服务)。
- **短信中心：** 当发送文本信息时，保存或更改SMS中心的号码。您必须从服务提供商处获得此号码。

多媒体信息 菜单-5-8-2

此菜单允许您设置默认的MMS信息。

可以使用以下选项。

- **优先级：** 设置您要发送的多媒体信息的优先级。
- **有效期：** 设置当尝试向接收人发送多媒体信息时将多媒体信息保存在彩信中心的时间。可能的值有1小时、12小时、1天、1星期及由网络运营商批准的最长时间。
- **状态报告：** 激活或停用报告功能。当激活此功能时，网络通知您彩信是否已成功发送。
- **自动下载：**
  - **开：** 如果您选择开启，您将自动接收多媒体信息。
  - **关：** 如果您选择关闭，您需要确认是否下载多媒体信息。
  - **仅限本地网络：** 如果您选择此功能，当您在本地网络时将自动下载彩信。当您不在本地网络时，您需要确认是否接收彩信。

- **网络设定：**如果选择多媒体信息中心，您可以设置多媒体信息中心的URL地址。
- **允许的类型：**设置允许的类型。可用的值有个人，广告，信息提示。

语音邮件中心 菜单-5-8-3

如果您的网络服务提供商支持此功能，则可接收语音邮件。
当新语音邮件已接收，屏幕上将显示符号。请向您的网络服务提供商查询服务详情，以便相应地配置手机。

- **本地中心：**选择本地中心听取语音邮件。
- **漫游地中心：**如果支持漫游服务，您在漫游中可以收取语音邮件。

小区广播 菜单-5-8-4

- **接收**

  是：如果您选择此选项，您的手机将接收小区广播信息。

  否：如果您选择此选项，您的手机将不再接收小区广播信息。

- **信息提示**

  是：如果您选择该功能，当您收到小区广播信息时，手机将发出提示音。

  否：如果您选择该功能，尽管您收到小区广播信息，您的手机也不会发出提示音。

- **语言**

  您可以通过[开/关]选择您想要的语言。然后手机将以您所选的语言来接收小区广播信息。

PUSH 信息 菜单-5-8-5

选择是否接收 Push 信息。

您可以用G233手机进行照相并保存照片。照相后您还可以通过MMS发送照片。

注意 如果电池电量低的话您可能不能使用照相机功能。

照相 菜单-6-1

- **要在手机翻盖打开时拍照**

选择**照相**，然后按 ，如果您想直接进入此功能表，可以长按 。

在拍照之前，您可以设定以下值。

预览选项菜单栏

1. **数码变焦** ( )：5种变焦可用。
2. **色调** ( )：彩色，怀旧，黑白
3. **亮度** ( )：+2，+1，0，-1，-2
4. **计时器** ( )：关，3秒，5秒。
5. **内存状态** ( )：显示当前的内存状态。

   注意 如果内存状态满的话，您将不能保存照片，手机将提示“内存已满”。您可以通过删除旧照片释放内存空间。

6. **闪光灯** ( )：通过向上/向下导航键选择闪光灯开启或关闭。
7. **分辨率** ( )：640x480(VGA)，320x240(QVGA)，128x160(屏幕)。48x48(电话本图片)
8. **图像质量** ( )：精细/标准/基本

1. 使用向左/向右导航键使所需的选项菜单居中。
2. 使用向上/向下导航键选择所需的值。
3. 完成所有设置后，对准要拍摄的物体，然后按相机键或“确定”键。听到“咔嚓”一声，照片被拍摄，以下菜单栏出现。

注意 分辨率设为 48x48（电话本）时，以下菜单栏出现。

如果设置**自动保存**[菜单－6－5－3]为“是”，拍的照片将被自动保存而不显示上面的菜单栏。(参照57页。)

4. 要保存图像，使“ ”居中，然后按“确定”键。如果不想保存图像，使“ ”居中，然后按“确定”键。
   您也可以通过按“ ”以彩信发送图像。关于写多媒体信息的更多信息请参照45－46页。以 48x48（电话本）分辨率拍摄照片后,您可以直接在电话本中保存图片，通过按“ ”。

● **要在手机翻盖关闭时拍照**

按侧相机键进入照相菜单。以下菜单将出现。

通过音量调节侧键移动光标到需要的菜单，按侧相机键选择相应的菜单。

1. **照相**
   您可以选择照相给自己拍照。通过按侧相机键进行拍照。长按侧相机键回到照相菜单。
2. **放映幻灯片**
   连续显示相册中的所有图片。您可以用上下调节侧键移动到想要的或下一张图片。按侧相机键停止放映并回到照相菜单。
3. **闪光灯**
   通过上下侧键选择闪光灯开启（ ）/关闭（关）。
4. **返回**
   选择此菜单返回待机模式。

照在相框中 菜单-6-2

您可以在预设的相框中拍摄有趣的照片。有7种预设的相框可供选择。通过向上/向下导航键选择需要的相框。

注意 在这种模式下，您不可以更改分辨率设置。

连续拍摄 菜单-6-3

您可以连续拍摄最多9张照片。照相之后，您可以通过向上/向下导航键查看。还可以按OK键保存照片。

注意 如果您将分辨率设置为320X240,您只能照6张照片。如果是128X160, 则可以照9张照片。

相册 菜单-6-4

所有的照片都保存在相册中。照片分为普通图片，相框图片，电话本图片。在全部图片中您可以预览所有图片。按左软件[选项]可以进行以下操作。

- **图片预览：**可以在一个屏幕中查看最多9个缩略图。
- **写多媒体信息：**可以通过多媒体信息发送照片。
- **设为墙纸：**可以将照片设置为墙纸。
- **放映幻灯片：**您可以通过此菜单自动的连续浏览照片。
- **删除：**可以删除照片。
- **编辑标题：**可以编辑照片的标题。
- **查看详情：**您可以查看照片的详细信息，例如标题，大小，日期，时间。
- **保护：**如果照片启用此功能，您将不能删除照片。

设定 菜单-6-5

内存状态 菜单-6-5-1

可以检查手机的当前内存状态。

清空相册 菜单-6-5-2

通过这个菜单可以删除全部照片。您需要确认是否删除。

自动保存 菜单-6-5-3

如果您设置自动保存为“是”，拍的照片将自动保存到手机，而不显示保存菜单栏。

按“功能表”键( )。使用导航键选择**设定**。

闹钟 菜单-7-1

最多可以设置5个闹钟。设置一个特定时间的闹钟。

通过左软键[选择]选择一个闹钟。

1. **闹钟开/关：**使用向左/向右导航键选择**开**。要停用闹钟功能，选择**关**。
2. **闹钟时间：**使用数字键输入闹钟时间。
3. **重复：**使用向左/向右导航键从一次，周一～周五，周一～周六，每天中选择一个。
4. **闹钟提示音：**使用向左/向右导航键选择所需的提示音。
5. 按左软键[确认]。
6. 您可以编辑闹钟名称。输入名称后按左软键[确认]。

如果闹钟功能已启用，待机模式中将显示“ ”。当到达闹钟时间时，手机将发出闹钟提示音。

► 要关闭闹钟，按右软键[退出]。

日期和时间 菜单-7-2

此选项允许您更改显示的当前时间和日期。

可以使用以下选项。

日期设定 菜单-7-2-1

使用此功能输入年、月、日。您可以通过日期格式菜单选项更改**日期格式**。

日期格式 菜单-7-2-2

DD/MM/YYYY（日/月/年）

MM/DD/YYYY（月/日/年）

YYYY/MM/DD（年/月/日）

时间设定 菜单-7-2-3

使用此功能输入当前时间。 您可以通过时间格式菜单选项选择**时间格式**。

时间格式 菜单-7-2-4

24小时制

12小时制

手机设定 菜单-7-3

您可以根据自己的需要设置手机特征。所有这些特征都可以在手机设定菜单中设置。

显示设定 菜单-7-3-1

- **墙纸：**选择在待机模式下内屏或翻盖关闭时外屏中显示的墙纸。
- **手机方案：**您可以根据需要从4种方案中选择手机的显示方案。您可以移动光标预览这些方案。
- **问候语：**要输入问候语，选择“开”。使用键盘输入问候语。在待机模式中，问候语将显示在屏幕上。
- **背景灯：**使用此功能选择手机是否使用背景灯。将背景灯关闭，可以稍微延长待机/通话时间。
- **信息提示：**您可以在打开功能表之前预览该功能表当前设置。提示显示在屏幕的下端。
- **网络名称：**如果您选择**开**，网络名称(服务供应商的名称)将会出现在内屏上。

Language 菜单-7-3-2

可以选择显示语言。

通话设定 菜单-7-4

更改与通话相关的设置。

呼叫转接 菜单-7-4-1

当激活此网络服务时，您可以将来电转接到另一号码，例如，您的语音信箱号码。有关详细信息，请联系您的网络运营商。选择转接选项之一，例如，选择正在通话时转接来电以在您的号码正忙时或拒接来电时转接语音来电。

可以使用以下选项。

转接所有语音来电：无条件转移语音来电。

正在通话时转接来电：当手机正在通话时转移语音来电。

无人接听时转接来电：转移您没有应答的语音来电。

无网络或关机时转接来电：当手机关机或不在服务区时转移语音来电。

转接所有数据来电：无条件转移到使用PC连接的号码。

转接所有传真来电：无条件转移到使用传真连接的号码。

每个选项具有以下菜单：

- **启动：**启动相应服务。
  - **其他号码**：输入接受转移呼叫的电话号码。
  - **常用号码**：您可以查询5个转移号码。
- **关闭**：取消相应服务。
- **查询状态**：查看相应服务的状态。

全部取消：取消所有呼叫转接设置。

接听模式 菜单-7-4-2

选择所需的接听电话模式。

- **翻盖接听：**当手机响铃时，只需打开翻盖即可接听电话。
- **任意键接听：**当手机响铃时，可以按除 ，右软键和音量侧键以外的任何按键接听电话。
- **按发送键接听：**只能按发送键接听电话。

发送号码 菜单-7-4-3

此网络服务允许您确定是否向接电人显示您的手机号码（“开”或“关”）。选择网络设定将手机重设为您已与服务提供商达成协议的设置。

呼叫等待（网络服务） 菜单-7-4-4

当已在通话中时，网络将通知您有新入来电。选择**启动**以要求网络激活呼叫等待功能，选择**关闭**以要求网络停用呼叫等待功能，或选择**查询状态**以检查该功能是否已激活。

分钟提示 菜单-7-4-5

当设置为“开”时，在通话期间每隔一分钟手机鸣音一次，让您知道通话时间。

自动重拨 菜单-7-4-6

选择开，如果拨打电话不成功，手机将最多重拨十次该号码。

保密设定 菜单-7-5

不同的密码用于保护手机的特定功能。有关各种密码，请参阅第19页。

需要PIN码 菜单-7-5-1

当需**要PIN码**功能启用时，每次开机时均必须输入PIN。因此，未经允许，任何不知道此PIN的人均无法使用您的手机。

注意 在禁用**需要PIN码**功能之前，必须输入您的PIN。

可以使用以下选项：

- **开：**每次开机时必须输入PIN。
- **关：**手机开机后直接连接到网络。

手机锁 菜单-7-5-2

当手机锁功能启用时，则每次开机将要求您输入安全密码。默认的安全密码设置为0000。可以通过[菜单-7－5－5－1]更改手机的安全密码。输入安全密码后您可以使用手机，直到您关闭手机。

呼叫限制 菜单-7-5-3

可以限制使用您的手机拨打和接听电话。此功能要求提供呼叫限制密码，您可以从服务提供商处获得此密码。

可以使用以下选项：

- **所有拨出电话：**不能拨打电话。
- **拨出国际电话：**不能拨打国际电话。
- **国际漫游时拨打电话：**在国外时，只能向您目前所在的国家及您本国(网络提供商所在的国家)国内的号码拨打电话。
- **所有来电：**不能接收电话。
- **国际漫游时来电：**当在本国服务区以外的国家使用手机时，不能接收电话。

- **全部取消：**停用所有呼叫限制设置，恢复正常接收和拨打电话。
- **更换密码：**使用此功能设置和更改由服务提供商提供的呼叫限制密码。必须输入当前密码，才能指定新密码。输入新密码之后，必须再次输入以作确认。

注意 必须输入网络密码，才能使用**呼叫限制服**务。当呼叫受限时，在某些网络上仍允许拨打特定的紧急电话号码。

固定拨号(FDN)(需SIM卡支持)

菜单-7-5-4

如果SIM卡支持固定拨号功能，使用此功能限制为仅拨打所选的电话号码。要求PIN2码。

- **激活：**使用此功能限制为仅拨打固定的电话号码。必须输入PIN2码。
- **取消：**允许拨打任何号码。
- **成员列表：**使用此功能查看保存为固定拨号的号码。

注意 并非所有SIM 卡都具有PIN2 。如果您的SIM卡没有PIN2 ，则不显示此菜单选项。

更改密码

菜单-7-5-5

更改密码功能允许您将当前密码更改为新密码。必须输入当前密码，才能指定新密码。
使用此功能更改访问密码：**安全密码**、**PIN2码**

注意 PIN：个人身份号码。

网络设定

菜单-7-6

通过**网络设定**功能，您可以指定当漫游时(本地区以外)是以自动、手动还是优先方式选择网络。

注意 对于本地网络以外的其它网络，仅当其与您的本地网络之间具有有效的漫游协议时，才可以选择该网络。

自动

菜单-7-6-1

如果您选择“自动”，手机会自动搜索和选择在您区域内的一个可用网络。

关机后手机将默认为“自动”。

手动 菜单-7-6-2

如果您想从网络列表中手动选择一个特定的网络，您可以启用该功能。如果连接手动选择的网络失败，手机将发出错误提示音并且允许您选择另一个网络。您选择的网络必须与您本地网络运营商已签订漫游协议。关机后，手机将恢复为“自动”。

首选网络 菜单-7-6-3

您可以设定手机在注册其它网络前首先注册的首选网络列表。该列表从手机预设的已知网络列表中创建。

恢复初始设定 菜单-7-7

您可以将手机恢复为其默认配置。要恢复初始设定，请按以下步骤操作。

1. 选择恢复初始设定菜单选项。
2. 输入4位数的安全密码。

注意 默认的安全密码是0000。

GPRS设定 菜单-7-8

GPRS(通用分组无线业务)是一种允许使用手机通过移动网络收发数据的技术。GPRS是允许以无线方式访问数据网络(如Internet)的数据载体。 在可以使用GPRS技术之前:

- 您需要预订GPRS服务。有关GPRS服务的提供和预订情况，请联系您的网络运营商或服务提供商。
- 您需要为通过GPRS使用的应用程序保存GPRS设置。

您可以选择两种连接类型:1开机 2当需要时。

注意 如果没有开通 GPRS 服务，并且已选择“开机”，则手机将定期尝试建立连接。

您可以访问不同的 WAP（无线应用协议）服务，如银行业务、新闻、天气报告和航班信息等。这些服务专为手机应用而设计，由WAP服务提供商负责进行维护。

向您的网络运营商及（或）希望使用其服务的服务提供商咨询，了解WAP服务的提供、定价和收费情况。服务提供商将向您提供有关如何使用其服务的说明。

一旦建立连接，屏幕上即显示主页。主页内容视服务提供商而定。要在任何时间退出浏览器，按 键。手机将返回待机模式。

使用WAP浏览器导航

您可以使用手机按键或 WAP 浏览器菜单上网。

使用手机按键

上网期间，手机按键的功能有所不同。

按 键	说 明
	将内容区域向上 / 向下滚动一行
	返回上一页
OK	选择选项并确认操作。

使用WAP浏览器菜单

当无线上网时，有多个菜单选项可供使用。

注意 视浏览器版本而定，WAP 浏览器菜单可能有所不同。

互联网 菜单-8-1

主页 菜单-8-1-1

回到主页。主页是您在启动的上网设定中所设定的WAP站点。
如果您没有进行设置，将使用运营商预先设定的站点。

书签 菜单-8-1-2

此菜单使您可以存储您所喜爱网页的 URL 以便以后访问。

要创建书签

1. 按左软键[选项]。
2. 选择“添加”，然后按 OK 键。
3. 输入相应的 URL 和标题后，按[确认]键。

* **提示：** 使用 “ ” 键和 键可输入符号。要输入 “.”，请按 “ ”。

选择需要的书签后，将出现以下选项。

- **连接：** 连接到所选书签。
- **添加：** 选择此选项创建新的书签。
- **修改：** 您可以编辑所选书签的 URL 和/或标题。
- **删除书签：** 删除所选书签。

全部删除： 删除所有书签。

上网设定 菜单-8-1-3

上网设定为用于连接互联网的网络信息。

每个上网设定均有子菜单，如下所示：

- **启动：** 启动所选上网设定。
- **设置：** 使用此功能编辑和更改所选上网设定的 WAP 设置。
  - **主页：** 该设定可让您输入您想作为主页使用的网站地址(URL)。您不需要在每个URL前键入“http://”,因为WAP浏览器会自动加入。
  - **连接方式**

    1 **数据**(电路交换)

    2 GPRS(通用分组无线业务)
  - **数据设定**

    IP地址： 输入访问WAP网关的IP地址。

    拨出号码： 输入访问WAP网关的拨号号码。

    用户名： 拨号服务器（不是WAP网关）的用户身份。

    密码： 拨号服务器（不是WAP网关）识别您身份所需的密码。

    呼叫类型： 选择数据来电的类型：模拟或ISDN（数码）。

    呼叫速度： 数据连接的速度，9600 或者14400。

    空闲时限： 您可以设定限制时间。超过此时间限制而没有数据输入或传输时，服务将自动关闭。

- **GPRS设置：**只有当选择GPRS作为载体服务时，服务设定才可用。

  IP地址：输入访问WAP网关的IP地址。

  APN：输入APN

  用户ID：APN服务器的用户身份。

  密码：APN服务器识别您身份所需的密码。

- **连接类型：**连接类型的选项为临时或持续，视网关而定。

  固定连续

  固定的传输机制，会增加网络通信量。

  自选连接

  非固定（无连接）的服务。

  HTTP

  直接在 HTTP 中将客户端连接至服务器

- **代理设置**

  IP地址：输入您访问的代理服务器的 IP 地址。

  端口：输入代理服务器端口

- **DNS设置**

  主服务器：输入您访问的首选 DNS 服务器的 IP 地址

  从服务器：输入您访问的备用 DNS 服务器的 IP 地址

- **安全设置：**该选项可以设定为开或关，视网关而定。

- **显示图象：**您可以选择是否要显示WAP卡上的图象。

► **重命名：**编辑上网设定的名称。

► **删除：**删除上网设定。

► **添加：**您可手动添加上网设定。

转到URL 菜单-8-1-4

您可以直接连接到想要的站点。输入特定的 URL 后，按 OK 键。

缓存 菜单-8-1-5

您已访问的信息或服务保存在手机的缓存中。

- **清除缓存：** 删除缓存中保存的所有信息。
- **查询缓存：** 设置是否通过缓存尝试进行连接。

注意 缓存是一种缓冲存储器，可以暂时保存数据。

Cookies设置 菜单-8-1-6

您已访问的信息或服务保存在手机的缓存中。

- **清除 cookies：** 删除保存在 cookie 中的所有上下文。
- **查询 cookies：** 检查是否使用了 cookie。

安全设置 菜单-8-1-7

显示安全证书的列表。

- **权威：** 您可以查看存储在手机中的官方证书的列表。
- **私人：** 您可以查看存储在手机中的个人证书的列表。

重新设定 菜单-8-1-8

您可以将上网设定的所有当前设定复零为初始设定。

浏览器版本 菜单-8-1-9

显示WAP浏览器的版本。

SIM 服务 菜单-8-2

您的服务提供商可以通过SIM卡提供如家庭银行业务、股市行情之类的特殊应用。如果已注册这些服务之一，该服务名称将出现在主菜单末尾。
通过“移动梦网”菜单，您的手机能够满足将来的使用需要，并能够支持服务提供商所提供的额外服务。有关详细信息，请联系您的服务提供商。

游戏 菜单-9-1

我的游戏 菜单-9-1-1

在此菜单中，您可以管理手机中安装的 Java 应用程序。您可以播放或删除下载的应用程序，或者设置连接选项。下载的应用程序可在文件夹中整理。按左软键[选择] 打开所选的文件夹或启动选定的 Midlet。使用左软键[功能表]，以下菜单将会出现。

- **开始：** 启动选定的应用程序。
- **信息：** 显示应用程序的信息。
- **升级：** 使用 WAP 更新应用程序。
- **选项：** 某些 Java 应用程序可能需要建立数据连接。选择此项以设置连接选项。
  - **经常查询：** 立即建立连接，而不显示通知。
  - **提示：** 在应用程序建立连接时进行询问。
  - **从不查询：** 不允许建立连接。

注意 您不可删除或重命名预先安装的文件夹或文件夹中的游戏。

Java是由Sun Microsystems开发的一项技术。与使用标准Netscape或微软Internet Explorer浏览器下载Java Applet的方式相同，可以使用具有WAP功能的手机下载Java MIDlet。视服务提供商而定，所有基于Java的程序（如Java游戏）均可以下载到手机上并运行。一旦下载之后，即可以在“我的游戏”菜单中查看 Java 程序，并可在此选择执行和删除 Java程序。

注意
- JAR文件是Java程序的压缩格式，JAD文件是包含所有详细信息的描述文件。在下载之前，您可以从网络上的JAD文件中查看所有详细的文件说明。
- 视标准语言 (J2ME) 而定，并非所有 Java 应用程序均兼容当前市场上销售的各种手机，这是因为不同手机型号所使用的库可能不同。如果下载了不是为本手册中所述的手机专门开发的 Java 应用程序，软件可能会被屏蔽或自动开启，这时候您有必要“重新启动”手机。我们希望让您知道这些问题是由于应用程序不兼容导致的，而不是产品故障。

注意 只有基于J2ME的程序会在手机上运行。
基于J2SE的程序只能在PC环境中运行。

上网设定 菜单-9-1-2

此功能表含有与“互联网”功能表相同的设置。事实上，要下载新的应用程序，必需具有 WAP 连接。

图片 菜单-9-2

左软键[选项]可激活以下选项。

- **设为墙纸：** 可将选定的图片设置为墙纸。
- **写多媒体信息：** 您可以通过彩信发送图片。

音乐 菜单-9-3

左软键[选项]可激活以下选项。

- **设为铃声：** 此选项可将当前选定的音乐设置为铃声。
- **写信息：** 您可以通过短信或彩信发送音乐。

附件

我们为您的手机准备了多种附件。您可以根据个人的通信要求来选择合适的附件。

标准电池

耳机

用于免提操作。包括听筒和麦克风。

旅行用适配器

当您不在办公室或家中时，可以使用此充电器为电池充电。

数据套件/CD

您可以将手机与PC相连，进行数据交换。

注意

- 确保使用正规的LG配件。
- 仿冒品或替代品及非原厂配件可能会让您丧失保修权益。
- 各个地区的配件可能不同；如有任何疑问，请与我们的地区服务公司或代理查证核实。

常规

产品名称： LG-G233

系　　统： GSM 900 / DCS 1800

环境温度

最高： +55℃

最低： -10℃

LG-G233 User Guide - **ENGLISH**

Table of Contents

Introduction 6

Guidelines for safe and efficient use 7

F2410 features 11

Parts of the phone 11

Display information 14

Getting started 16

Installing the SIM card and the handset battery 16

Charging the battery 18

Disconnecting the adapter 19

Turning your phone on and off 19

Access codes 20

Barring password 21

General functions 22

Making and answering calls 22

Contacts 26

In-call menu 27

Multiparty or conference calls 28

Menu Tree 30

Selecting functions and options 33

Profiles 34

Changing the profile 34

Customising profiles – Personalise 34

Customising profiles – Rename 35

Call register 36

Missed calls 36

Received calls 36

Dialled calls 36

Delete recent calls 37

Call charges 37

Call duration 37

Call costs 37

Settings 37

GPRS information 38

Call duration 38

Data volumes 38

Tools **39**
Bluetooth **39**
My devices 39
Handsfree devices 39
Settings 39
Calculator **39**
Unit converter **40**
World time **40**
Voice recorder **41**
Record 41
View list 41
Memory status **41**

Organiser **42**
Contacts **42**
Search 42
Add new 42
Caller groups 43
Speed dial 43
Settings 43
Copy all 44
Delete all 44
Information 44
Scheduler **45**
Memo **45**

Messages **46**
New message **46**
Write text message 46
Write multimedia message 47
Inbox **49**
Drafts **51**
Outbox **51**
Listen to voice mail **52**
Info message **53**
Read 53
Topics 53
Templates **53**
Text templates 53
Multimedia templates 54

Table of Contents

Signature 54

Settings 55

Text message 55

Multimedia message 55

Voice mail centre 56

Info message 56

Push messages 57

Camera 58

Take picture 58

Take in modes 60

Take continuously 61

Album 61

Settings 62

Memory status 62

Clear album 62

Auto save 62

Settings 63

Alarm clock 63

Date & Time 63

Set date 63

Date format 63

Set time 64

Time format 64

Phone settings 64

Display settings 64

Language 64

Call settings 65

Call divert 65

Answer mode 66

Send my number 66

Call waiting 66

Minute minder 66

Auto redial 66

Security settings 67

PIN code request 67

Phone lock 67

Call barring 67

Fixed dial number (FDN) 68

Change codes 68
Network settings 69
Automatic 69
Manual 69
Preferred 69
Reset settings 69
GPRS setting 70

Service 71
Internet 71
Home 71
Bookmarks 72
Profiles 72
Go to URL 74
Cache settings 74
Cookies settings 74
Security certification 75
Reset profiles 75
Browser version 75
SIM service 75

Downloads 76
Games & more 76
My games & more 76
Profiles 77
Pictures 77
Sounds 77

Accessories 78
Technical Data 79

Introduction

Congratulations on your purchase of the advanced and compact LG-G233 mobile phone, designed to operate with the latest digital mobile communication technology.

This user's guide contains important information on the use and operation of this phone. Please read all the information carefully for optimal performance and to prevent any damage to or misuse of the phone. Any changes or modifications not expressly approved in this user's guide could void your warranty for this equipment.

Read these simple guidelines. Breaking the rules may be dangerous or illegal. Further detailed information is given in this manual.

Exposure to radio frequency energy

Radio wave exposure and Specific Absorption Rate (SAR) information

This mobile phone model LG-G233 has been designed to comply with applicable safety requirement for exposure to radio waves. This requirement is based on scientific guidelines that include safety margins designed to assure this safety of all persons, regardless of age and health.

- The radio wave exposure guidelines employ a unit of measurement known as the Specific Absorption Rate, or SAR. Tests for SAR are conducted using standardized method with the phone transmitting at its highest certified power level in all used frequency bands.
- While there may be differences between the SAR levels of various LG phone models, they are all designed to meet the relevant guidelines for exposure to radio waves.
- The SAR limit recommended by the international Commission on Non-Ionizing Radiation Protection (ICNIRP), which is 2W/kg averaged over ten (10) gram of tissue.
- The highest SAR value for this model phone tested by DASY3 for use at the ear is 0.858 W/kg (10g).
- SAR data information for residents in countries/regions that have adopted the SAR limit recommended by the Institute of Electrical and Electronics Engineers (IEEE), which is 1.6 W/kg averaged over one (1) gram of tissue.

Product care and maintenance

Warning: Use only batteries, charger and accessories approved for use with this particular phone model. The use of any other types may invalidate any approval or warranty applying to the phone, and may be dangerous.

- Do not disassemble this unit. Take it to a qualified service technician when repair work is required.
- Keep away from electrical appliance such as a TV, radio or personal computer.

- The unit should be kept away from heat sources such as radiators or cookers.
- Do not drop.
- Do not subject this unit to mechanical vibration or shock.
- The coating of the phone may be damaged if covered with wrap or vinyl wrapper.
- Use dry cloth to clean the exterior of the unit. (Do not use solvent such as benzene, thinner or alcohol.)
- Do not subject this unit to excessive smoke or dust.
- Do not keep the phone next to credit cards or transport tickets; it can affect the information on the magnetic strips.
- Do not tap the screen with a sharp object; otherwise, it may damage the phone.
- Do not expose the phone to liquid or moisture.
- Use the accessories like an earphone cautiously. Do not touch the antenna unnecessarily.

Electronics devices

All mobile phones may get interference, which could affect performance.

- Do not use your mobile phone near medical equipment without requesting permission. Avoid placing the phone over the pacemaker, i.e. in your breast pocket.
- Some hearing aids might be disturbed by mobile phones.
- Minor interference may affect TVs, radios, PCs, etc.

Road safety

Check the laws and regulations on the use of mobile phones in the areas when you drive.

- Do not use a hand-held phone while driving.
- Give full attention to driving.
- Use a hands-free kit, if available.
- Pull off the road and park before making or answering a call if driving conditions so require.

- RF energy may affect some electronic systems in your motor vehicle such as car stereo, safety equipment.
- When your vehicle is equipped with an air bag, do not obstruct with installed or portable wireless equipment. It can cause serious injury due to improper performance.

Blasting area

Do not use the phone where blasting is in progress. Observe restrictions, and follow any regulations or rules.

Potentially explosive atmospheres

- Do not use the phone at a refueling point. Don't use near fuel or chemicals.
- Do not transport or store flammable gas, liquid, or explosives in the compartment of your vehicle, which contains your mobile phone and accessories.

In aircraft

Wireless devices can cause interference in aircraft.

- Turn off your mobile phone before boarding any aircraft.
- Do not use it on the ground without crew permission.

Children

Keep the phone in a safe place out of small children's reach. It includes small parts which if detached may cause a choking hazard.

Emergency calls

Emergency calls may not be available under all cellular networks. Therefore, you should never depend solely on the phone for emergency calls. Check with your local service provider.

Battery information and care

- You do not need to completely discharge the battery before recharging. Unlike other battery systems, there is no memory effect that could compromise the battery's performance.
- Use only LG batteries and chargers. LG chargers are designed to maximize the battery life.
- Do not disassemble or short-circuit the battery pack.
- Keep the metal contacts of the battery pack clean.
- Replace the battery when it no longer provides acceptable performance. The battery pack may be recharged hundreds of times until it needs replacing.
- Recharge the battery if it has not been used for a long time to maximize usability.
- Do not expose the battery charger to direct sunlight or use it in high humidity, such as the bathroom.
- Do not leave the battery in hot or cold places, this may deteriorate the battery performance.

Parts of the phone

Front view

1. Headset jack

- Connect a headset here.

2. Up/down side keys

- Press this key to display the current time on the front screen.
- Controls the volume of keypad tone in standby mode with the clamshell open.
- Controls the earpiece volume during a phone call.

3. Front screen

4. Camera lens

Note Dirt on the camera lens could affect the image quality.

5. Flash

Right side view

Camera key

Press and hold down this key to activate the camera mode. Also use this key to take a shot.

Rear view

Open view

1. Earpiece

2, 10. Left soft key/ Right soft key: Performs the function indicated by the text on the screen immediately above it.

3. Scheduler key: A shortcut key to the Scheduler menu.

4. Send key: Dials a phone number and answers incoming calls. You can also quickly access the latest incoming, outgoing and missed calls by pressing the key in standby mode.

5. Alphanumeric keys: Enter numbers, letters and some special characters.

6. Microphone: Can be muted during a call for privacy.

7. Main screen: Displays phone status icons, menu items, Web information, pictures and more in full colour.

8. Navigation keys: Use to scroll through menus and move the cursor.

9. Confirm key: Selects menu options and confirms actions.

11. **Downloads key:** A shortcut key to the Downloads menu.
12. **End/Power key:** Used to end a call or reject a call and also to go back to standby mode. Hold this key down to turn the phone on/off.
13. **Clear key:** Deletes a character by each press. Hold the key down to clear all input. Also use this key to go back to the previous screen.
14. **Special function keys:**
    - : A long press of this key enters the international call character "+".
    - : While keying in a phone number, a long press of this key enters a pause.

Display information

The table below describes various display indicators or icons that appear on the phone's display screen.

On-Screen Icons

Icon	Description
	Indicates the strength of the network signal.
	Indicates a call is in progress.
	Indicates that you are roaming on another network.
	Indicates that GPRS service is available.
	Indicates the alarm has been set and is on.
	Indicates the status of the battery charge.
	Indicates the receipt of a text message.
	Indicates the receipt of a message.

Icon	Description
	Indicates that the vibration ringer has been set.
	Indicates the Loud profile is activated.
	Indicates the Silent profile is activated.
	Indicates the Headset profile is activated.
	Indicates the General profile is activated.
	Indicates that you can use the push message service.
	Indicates that the phone is accessing the WAP.
	Indicates that you are using GPRS.
	Indicates the Bluetooth feature is activated.

Installing the SIM card and the handset battery

Make sure the power is off before you remove the battery.

1. Remove the battery cover.

Press the battery release latch and slide the battery cover toward the bottom of the phone. And remove the battery cover.

Note Removing the battery from the phone when the power is on may cause the phone to malfunction.

2. Remove the battery.

Hold the top edge of the battery and lift the battery from the battery compartment.

3. Install the SIM card

Insert the SIM card into the holder. Slide the SIM card into the SIM card holder. Make sure that the SIM card is inserted properly and that the gold contact area on the card is facing downwards. To remove the SIM card, press down lightly and pull it in the reverse direction.

To insert the SIM card

To remove the SIM card

Caution The metal contact of the SIM card can be easily damaged by scratches. Pay special attention to the SIM card while handling. Follow the instructions supplied with the SIM card.

4. Install the battery.

Insert the bottom of the battery first into the bottom edge of the battery compartment. Push down the top of the battery until it snaps into space.

5. Replace the battery cover.

Lay the battery cover in place of the phone and slide it until the latch clicks.

Charging the battery

To connect the mains adapter to the phone, you must have installed the battery.

1. With the arrow facing you as shown in the diagram push the plug on the battery adapter into the socket on the bottom of the phone until it clicks into place.
2. Connect the other end of the mains adapter to the mains socket. Use only the included packing charger.
3. The moving bars of battery icon will stop after charging is complete.

Caution

- Do not force the connector as this may damage the phone and/or the travel adapter.
- Insert the battery pack charger vertically to wall power outlet.
- If you use the battery pack charger out of your own country, use an attachment plug adapter for the proper configuration.
- Do not remove your battery or the SIM card while charging.

Warning

- Unplug the power cord and charger during lightning storms to avoid electric shock or fire.
- Make sure that no sharp-edged items such as animal teeth, nails, come into contact with the battery. There is a risk of this causing a fire.
- Do not place or answer calls while charging the phone as it may short-circuit the phone and/or cause electric shock or fire.

Disconnecting the adapter

1. When charging is finished, the moving bars of the battery icon stop and 'Full' is displayed on the screen.
2. Unplug the adapter from the power outlet. Disconnect the adapter from the phone by pressing the grey tabs on both sides of the connector and pull the connector out.

Note
- Ensure the battery is fully charged before first using the phone.
- Do not remove the battery or SIM card while charging.
- In the case the battery is not properly charged, please turn the phone off and on using the power key, then recharge the battery. After detaching and reattaching the battery, please recharge the battery.

Turning your phone on and off

Turning your phone ON

1. Install a battery to the handset and connect the phone to an external power source such as the travel adapter, cigarette lighter adapter or hands-free car kit. Or install a charged battery pack to the handset.
2. Press for a few seconds until the LCD screen is turned on.
3. Depending on the status of the **PIN code request** setting you may need to enter your PIN code.

Turning your phone OFF

1. Press for a few seconds until the LCD screen is turned off.

Access codes

You can use the access codes described in this section to avoid unauthorised use of your phone. The access codes (except PUK and PUK2 codes) can be changed by using the **Change codes** feature [Menu-7-5-5]. See page 68.

PIN code (4 to 8 digits)

The PIN (Personal Identification Number) code protects your SIM card against unauthorised use. The PIN code is usually supplied with the SIM card. When the **PIN code request** is set to **Enable**, your phone will request the PIN code every time the phone is switched on. When the **PIN code request** is set to **Disable**, your phone connects to the network directly without the PIN code.

PIN2 code (4 to 8 digits)

The PIN2 code, supplied with some SIM cards, is required to access functions such as **Advice of Call Charge** and **Fixed dial number**. These functions are only available if supported by your SIM card. Check with your network for further information.

PUK code (4 to 8 digits)

The PUK (PIN Unblocking Key) code is required to change a blocked PIN code. The PUK code may be supplied with the SIM card. If not, contact your network operator for the code. If you lose the code, also contact your network operator.

PUK2 code (4 to 8 digits)

The PUK2 code, supplied with some SIM cards, is required to change a blocked PIN2 code. If you lose the code, also contact your network operator.

Security code (4 to 8 digits)

The security code protects the unauthorised use of your phone. The default security code is set to **'0000'** and the security code is required to delete all phone entries and to activate the **Reset settings** menu. Also, the security code is required to enable or disable the phone lock function to prevent unauthorised use of the phone. The security code default setting can be modified from the **Security settings** menu.

Barring password

The barring password is required when you use **Call barring** [Menu-7-5-3] function. You obtain the password from your network operator when you subscribe to this function. See page 67 for further details.

Making and answering calls

Making a call

1. Make sure your phone is switched on.
2. Enter a phone number, including the area code.
   - Press and hold the clear key ( ) to erase the entire number.
3. Press the send key ( ) to call the number.
4. To end the call, press the end key ( ) or the right soft key.

Making a call using the send key

1. In standby mode, press the send key ( ), and the latest incoming, outgoing and missed phone numbers will be displayed.
2. Select the desired number by using the up/down navigation key.
3. Press .

Making an international call

1. Press and hold the key for the international prefix. The '+' character automatically selects the international access code.
2. Enter the country code, area code, and the phone number.
3. Press .

Ending a call

When you have finished your call, press the end ( ) key.

Making a call from the contacts

You can save the names and phone numbers dialled regularly in the SIM card and/or phone memory, which is the Contacts. You can dial a number by simply looking up the desired name in the contacts.

Adjusting the volume

If you want to adjust the earpiece volume during a call, use the side keys ( ) . Press the up side key to increase and down side key to decrease the volume.

Note In standby mode, pressing the side keys adjusts the key tone volume.

Answering a call

When you receive a call, the phone rings and the flashing phone icon appears on the screen. If the caller can be identified, the caller's phone number (or name if saved in the contacts) is displayed.

1. To answer an incoming call, open the phone. (When **Flip open** has been set as the answer mode. See page 66 [Menu-7-4-2].)

   Note If **Press any key** has been set as the answer mode (see page 66), any key press will answer a call except for the or the right soft key.

   ▶ To reject an incoming call, press and hold one of the side keys on the left side of the phone without opening the phone.

   ▶ You can answer a call while using the Contacts or other menu features.

2. To end the call, close the phone or press the key.

Manner mode (Quick)

You can activate the manner mode by pressing and holding down the key after opening the phone.

Signal strength

You can check the strength of your signal by the signal indicator ( ) on the LCD screen of your phone. Signal strength can vary, particularly inside buildings. Moving near to a window may improve reception.

Entering text

You can enter alphanumeric characters by using the phone's keypad. For example, storing names in the contacts, writing a message, creating a personal greeting.

The following text input methods are available in the phone.

T9 mode

This mode lets you enter words with only one keystroke per letter. Each key on the keypad has more than one letter. The T9 mode automatically compares your keystrokes with an internal dictionary to determine the correct word, thus requiring far fewer keystrokes than the traditional ABC mode. This is sometimes known as predictive text.

ABC mode

This mode lets you enter letters by pressing the key labelled with the required letter once, twice, three or four times until the letter is displayed.

123 mode (Number mode)

Type numbers using one keystroke per number. To change to 123 mode in a text entry field, press the key until 123 mode is displayed.

Changing the text input mode

1. When you are in a field that allows characters to be entered, you will notice the text input mode indicator in the upper right corner of the LCD screen.
2. Change the text input mode by pressing . You can check the current text input mode in the upper right corner of the LCD screen.

▶ Using the T9 mode

The T9 predictive text input mode lets you enter words easily with a minimum number of key presses. As you press each key, the phone begins to display the characters that it thinks you are typing based on the built-in dictionary. You can also add new words in the dictionary. As new words are added, the word changes to reflect the most likely candidate from the dictionary.

1. When you are in the T9 predictive text input mode, start entering a word by pressing keys 2 to 9. Press one key per letter.
   - The word changes as letters are typed. Ignore what's on the screen until the word is typed completely.
   - If the word is still incorrect after typing completely, press the down navigation key once or more to cycle through the other word options.

   Example:

   Press 4 6 6 3 to type ***Good***

   Press 4 6 6 3 [Down navigation key] to type ***Home***
   - If the desired word is missing from the word choice list, add it using the ABC mode.
   - You can select the language of the T9 mode. Press the left soft key [Option], then select **T9 languages**. Select the desired language of T9 mode. You can also turn off the T9 mode by selecting **T9 off**. The default setting on the phone is T9 enabled mode.
2. Enter the whole word before editing or deleting any keystrokes.
3. Complete each word with a space by pressing the key. To delete letters, press . Press and hold down to erase entire words.

Note To exit from the text input mode without saving your input, press . The phone goes back to standby mode.

Using the ABC mode

Use the 2 to 9 keys to enter your text.

1. Press the key labelled with the required letter:
   - Once for the first letter
   - Twice for the second letter
   - And so on
2. To insert a space, press the key once. To delete letters, press the key. Press and hold down the key to clear the whole display.

Note Refer to the table below for more information on the characters available using the alphanumeric keys.

Key	Characters in the order display	
	Upper Case	Lower Case
1	. , / ? ! - : ' " 1	. , / ? ! - : ' " 1
2 abc	A B C 2 Ä À Á Â Ã Å Æ Ç	a b c 2 ä à á â ã å æ ç
3 def	D E F 3 Ë È É Ê	d e f 3 ë è é ê
4 ghi	G H I 4 Ï Ì Í Î Ğ	g h i 4 ï ì í î ğ
5 jkl	J K L 5	j k l 5
6 mno	M N O 6 Ñ Ö Ø Ò Ó Ô Õ Œ	m n o 6 ñ ö ø ò ó ô õ œ
7 pqrs	P Q R S 7 ß Ş	p q r s 7 ß ş
8 tuv	T U V 8 Ü Ù Ú Û	t u v 8 ü ù ú û
9 wxyz	W X Y Z 9	w x y z 9
	Space 0	Space 0

Using the 123 (Number) mode

The 123 mode enables you to enter numbers in a text message (a telephone number, for example).

Press the keys corresponding to the required digits before manually switching back to the appropriate text entry mode.

Contacts

You can store phone numbers and their corresponding names in the memory of your SIM card.

In addition, you can store up to 200 numbers and names in the phone memory.

The SIM card and phone are both used in the same way in the **Contacts** menu.

In-call menu

Your phone provides a number of control functions that you can use during a call. To access these functions during a call, press the left soft key [Options].

During a call

The menu displayed on the handset screen during a call is different to the default main menu displayed when in standby mode, and the options are described below.

Activating the speaker phone

The speaker icon appears during a call. You can turn the speaker phone on/off by a long press of OK key.

Making a second call

You can get a number you wish to dial from the contacts to make a second call. Press the right soft key then select **Search**. To save the dialled number into the contacts during a call, press the right soft key then select **Add new**.

Switching between two calls

To switch between two calls, press the left soft key then select **Swap**.

Answering an incoming call

To answer an incoming call when the handset is ringing, simply press the key. The handset is also able to warn you of an incoming call while you are already on a call. A tone sounds in the earpiece, and the display will show that a second call is waiting.

This feature, known as **Call waiting**, is only available if your network supports it. For details of how to activate and deactivate it see **Call waiting** [Menu-7-4-4] on page 66.

If **Call waiting** is activated, you can put the first call on hold and answer the second, by pressing or by selecting left soft key, then **Hold & Answer**. You can end the current call and answer the waiting call by selecting left soft key and then End & Answer.

Rejecting an incoming call

You can reject an incoming call without answering by simply pressing the key.

During a call, you can reject an incoming call by pressing the left soft key [Menu] key and selecting the **Conference/Reject** or by pressing the .

Muting the microphone

You can mute the microphone during a call by pressing the [Menu] key then selecting **Mute on**. The handset can be unmuted by selecting **Mute off**. When the handset is muted, the caller cannot hear you, but you can still hear them.

Switching DTMF tones on during a call

To turn DTMF tones on during a call, press the left soft key, and then select **DTMF on**. DTMF tones can be turned off the same way. DTMF tones allow your phone to make use of an automated switchboard.

Multiparty or conference calls

The multiparty or conference service provides you with the ability to have a simultaneous conversation with more than one caller, if your network operator supports this feature. A multiparty call can only be set up when you have one active call and one call on hold, both calls having been answered. Once a multiparty call is set up, calls can be added, disconnected or separated (that is, removed from the multiparty call but still connected to you) by the person who set up the multiparty call. These options are all available from the In-Call menu. The maximum callers in a multiparty call are five. Once started, you are in control of the multiparty call, and only you can add callers to the multiparty call.

Making a second call

You can make a second call while currently on a call. Enter the second number and press the key. When the second call is connected, the first call is automatically placed on hold. You can swap between calls by pressing the left soft key then selecting **Swap**.

Setting up a conference call

Place one call on hold and while the active call is on, press the left soft key and then select the **Conference/Join all**.

Putting a conference call on hold

Press the left soft key, then select the **Conference/Hold all**.

Activate the conference call on hold

Press the left soft key, then select the **Conference/Join all**.

Adding calls to the conference call

To add a call to an existing conference call, press the left soft key, then select the **Conference/Join all**.

Displaying callers in a conference call

To scroll through the numbers of the callers who make up a conference call on the handset screen, use the up/down navigation keys.

Taking a private call during a conference call

To have a private call with one caller from a conference call, display the number of the caller you wish to talk to on the screen, then press the left soft key. Select the **Conference/Private** to put all the other callers on hold.

Ending a conference call

The currently displayed caller from a conference call can be disconnected by pressing the key. To end a conference call, press the left soft key, then select the **Conference/End multiparty**. After pressing the left soft key, selecting **Conference/End all** will end all the active and on-hold calls.

Menu Tree

1. Profiles

1 Vibrate only

2 Silent

3 General

4 Loud

5 Headset

2. Call register

1 Missed calls

2 Received calls

3 Dialled calls

4 Delete recent calls

5 Call charges

6 GPRS information

3. Tools

1 Bluetooth

2 Calculator

3 Unit converter

4 World time

5 Voice recorder

6 Memory status

4. Organiser

1 Contacts

2 Scheduler

3 Memo

5. Messages

1 New message

2 Inbox

3 Drafts

4 Outbox

5 Listen to voice mail

6 Info message

7 Templates

8 Settings

6. Camera

1 Take picture

2 Take in modes

3 Take continuously

4 Album

5 Settings

7. Settings

1 Alarm clock

2 Date & Time

3 Phone settings

4 Call settings

5 Security settings

6 Network settings

7 Reset settings

8 GPRS setting

8. Service

1 Internet

2 SIM service

9. Downloads

1 Games & more

2 Pictures

3 Sounds

Your phone offers a set of functions that allow you to customise the phone. These functions are arranged in menus and sub-menus, accessed via the two soft keys marked [ ] and [ ]. Each menu and sub-menu lets you view and alter the settings of a particular function.

The roles of the soft keys vary according to the current context; the label on the bottom line of the screen just above each key indicates its current role.

Press the left soft key to access the available menu.

Press the right soft key to activate the corresponding action.

Profiles

In Profiles, you can adjust and customise the phone tones for different events, environments, or caller groups. There are six preset profiles: **Vibrate only**, **Silent**, **General**, **Loud** and **Headset**. Each profile can be personalised.

Press the left soft key **[Menu]** and select **Profiles** using up/down navigation keys.

Changing the profile Menu-1-x-1

1. A list of profiles is displayed.

2. In the **Profiles** list, scroll to the profile you want to activate and press the left soft key [Select] or OK key.

3. Then, select **Activate**.

Note When a headset is connected to the phone, **Headset** profile is automatically activated.

Customising profiles – Personalise Menu-1-x-2

You can customise profiles except **Vibrate only** and **Silent**. Scroll to the desired profile in the Profile list. After pressing the left soft key or the OK key, select **Personalise**. The profile setting option opens. Set the option as required.

- **Call alert type:** Set the alert type for incoming calls.
- **Ring tone:** Select the desired ring tone from the list.
- **Ring volume:** Set the volume of the ring tone.
- **Message alert type:** Set the alert type for message receipt.
- **Message tone:** Select the alert tone for message receipt.
- **Keypad tone:** Select the desired keypad tone.
- **Keypad volume:** Set the volume of keypad tone.
- **Flip tone:** Allows to set the flip tone for adjusting environment.
- **Effect sound volume:** Set the volume of effect sound.

- **Power on/off volume:** Set the volume of the ring tone when switching the phone on/off.
- **Auto answer:** This function will be activated only when your phone is connected to the headset.
  - **Off:** The phone will not answer automatically.
  - **After 5 secs:** After 5 seconds, the phone will answer automatically.
  - **After 10 secs:** After 10 seconds, the phone will answer automatically.

Customising profiles – Rename

Menu-1-x-3

You can rename a profile and give it any name you want.

Note **Vibrate only**, **Silent** and **Headset** profiles cannot be renamed.

1. To change the name of a profile, scroll to the profile in the profile list and after pressing the left soft key or the OK key, select **Rename**.
2. Key in the desired name and press the OK key or the left soft key [OK].

Call register

You can check the record of missed, received, and dialled calls only if the network supports the Calling Line Identification (CLI) within the service area.

The number and name (if available) are displayed together with the date and time at which the call was made. You can also view call times.

Missed calls Menu-2-1

This option lets you view the last 10 unanswered calls. You can also:

- View the number if available and call it, or save it in the Contacts.
- Enter a new name for the number and save both in the Contacts.
- Send a message to this number.
- Delete the call from the list.

Note You can delete all the call records from the list using the **Delete recent calls** menu [Menu-2-4].

Received calls Menu-2-2

This option lets you view the last 10 incoming calls. You can also:

- View the number if available and call it, or save it in the Contacts.
- Enter a new name for the number and save both in the Contacts.
- Send a message to this number.
- Delete the call from the list.

Note You can delete all the call records from the list using the **Delete recent calls** menu [Menu-2-4].

Dialled calls Menu-2-3

This option lets you view the last 20 outgoing calls (called or attempted).
You can also:

- View the number if available and call it, or save it in the Contacts.
- Enter a new name for the number and save both in the Contacts.

- Send a message to this number.
- Delete the call from the list.

Note You can delete all the call records from the list using the **Delete recent calls** menu [Menu-2-4].

Delete recent calls Menu-2-4

Use this to clear up the missed call list, received call list, or dialled call list. You can also clear up all call lists at a time by selecting **All calls**.

Call charges Menu-2-5

Call duration Menu-2-5-1

Allows you to view the duration of your incoming and outgoing calls. You can also reset the call timer by selecting **Reset all**. To prevent accidental reset, the phone asks you to confirm the action.

- **Last call:** Length of the last call.
- **All calls:** Total length of all calls made and incoming calls since the timer was last reset.
- **Received calls:** Length of the incoming calls.
- **Dialled calls:** Length of the outgoing calls.
- **Reset all:** Resets the call timer.

Call costs Menu-2-5-2

Allows you to check the cost of your last call, all calls, remaining and reset the cost. To reset the cost, you need to enter the PIN2 code.

Settings (SIM Dependent) Menu-2-5-3

- **Set tariff:** You can set the currency type and the unit price. Contact your service providers to obtain charging unit prices. To select the currency or unit in this menu, you need the PIN2 code.
- **Set credit:** This network allows you to limit the cost of your calls by selected charging units.If you select **Read**, the number of remaining unit is shown. If you select **Change**, you can change your change limit.
- **Auto display:** This network service allows you to see automatically the cost of your last calls. If set to **On**, you can see the cost of the last call when the call is released.

GPRS information Menu-2-6

You can check the amount of data transferred over the network through the GPRS information option. In addition, you can also view how much time you are online.

Call duration Menu-2-6-1

You can check the duration of **Last call** and **All calls**. You can also reset the call timers.

Data volumes Menu-2-6-2

You can check the **Sent**, **Received** or **All** data volumes and **Reset all**.

Bluetooth Menu-3-1

Bluetooth enables compatible mobile devices, peripherals and computers that are in close proximity to communicate directly with each other without wires. This handset supports built-in Bluetooth connectivity, which makes it possible to connect them with compatible Bluetooth headsets, computer applications and so on.

My devices Menu-3-1-1

You can view all devices which are compatible with Bluetooth phone.

Handsfree devices Menu-3-1-2

You can view the list of handsfree devices which are compatible with Bluetooth phone.

Settings Menu-3-1-3

You can register a new device which is compatible with Bluetooth. If you already have added the device, you can search it after entering a password.

- **Set bluetooth:** You can activate or cancel the Bluetooth function.
- **My phone's visibility:** Select whether to let your phone be shown to other Bluetooth devices or hidden.
- **My phone's name:** You can set the name of Bluetooth device. The default name is LG-G233.

Calculator Menu-3-2

The calculator provides the basic arithmetic functions: **addition, subtraction, multiplication** and **division**.

1. Enter the first number using the numeric keys.
2. Press the corresponding navigation key to select a mathematical function.

   Note
   - To erase any mistake or clear the display, use the key.
   - To include a decimal point, press the key.
   - To include a minus sign, press the key.
3. To calculate the result, press the left soft key [Result] or OK key.
4. After calculation, press the left soft key [Reset] to return to the initial state.

Unit converter Menu-3-3

This converts any measurement into a unit you want. There are 4 types that can be converted into units: **Length**, **Area**, **Weight**, and **Volume**.

1. You can select one of four unit types by pressing [Unit] key.
2. Select the unit you want to convert using the left/right navigation keys.
3. Move to the Convert unit section by pressing the down navigation key.
4. Select the unit you want to convert to, using the left/right navigation keys.
5. Input numbers using the numeric keys. Conversion is calculated automatically.

Note You can input a decimal number by pressing the key.

World time Menu-3-4

You can check the current time of Greenwich Mean Time (GMT) and 76 major cities around the world, using the left/right navigation keys. The screen shows the city name, current date and time.
To select the time zone in which you are located, proceed as follows:

1. Select the city corresponding to your time zone by pressing the left/right navigation keys one or more times. The local date and time are displayed.
2. If you want to change the time display in standby mode to the selected time, press the left soft key [Set].

Note The time zone setting of each city in **World time** menu may be affected by the network condition.

Voice recorder Menu-3-5

You can record up to 10 voice memos up to a maximum of 20 seconds each.

Record Menu-3-5-1

1. To record a voice memo, select Record.

2. Once recording is started, the message 'Recording...' and the remaining time is displayed.

3. When you finish recording, press the left soft key [Save].

4. Key in the voice memo title and press the OK key.

Note If all memo locations are full, you must delete an old memo before recording a new one.

View list Menu-3-5-2

The phone shows the voice memo list, starting with the most recent memo. You can play or delete the recorded memo, or send it via MMS by pressing the left soft key [Options]. You can also delete all the voice memos.

Memory status Menu-3-6

You can check free space and the memory usage of each repository. You can go to each repository menu by pressing the left soft key [Goto].

Contacts Menu-4-1

Note In standby mode, press the right soft key [Names] to access directly.

Search
(Calling from the contacts) Menu-4-1-1

1. Select **Search** by pressing the left soft key or OK key.
2. Enter the name that you want to search or select left soft key [List] to view all the Contacts.

Note Instant searching is available by inputting the initial letter of the name or number you want to search.

3. After finding the desired name, you can make a call to the number by pressing the send key. Or you can do the followings by pressing the left soft key [Options].

- **Edit:** You can edit the name, number, group, character and picture by using the navigation key.
- **Write text/multimedia message:** After you have found the number you want, you can send a text/multimedia message to the selected number.
- **Send via Bluetooth:** Sends the contact entry via Bluetooth.
- **Copy:** You can copy an entry from SIM to phone or from phone to SIM.
- **Main number:** You can select the one out of mobile, home, office that you often use. After you set this, the main number will be displayed first, when you search.
- **Delete:** You can delete an entry.

Add new Menu-4-1-2

You can add a contact entry by using this function. There are 2 memories: Phone memory and SIM memory. To select the memory, go to **Set memory** [Menu-4-1-5-1]. Phone memory capacity is 200 entries. SIM card memory capacity depends on the cellular service provider. You can enter up to 20 characters in each name in the phone memory. The SIM card memory capacity depends on the SIM card.

Caller groups Menu-4-1-3

You can list up to 20 members per one group. There are 7 groups you can make lists to.

- **Member list:** Shows the group members you have selected.
- **Group ring tone:** Allows you to specify the ring tone for the group members' call.
- **Group icon:** Allows you to select the icon dependent on Group.
- **Add member:** You can add group members. Each group member shouldn't exceed 20.
- **Remove member:** You can remove the member from the Group member list. But the name and the number still remain in the Contacts.
- **Rename:** You can change a group name.

Speed dial Menu-4-1-4

You can assign any of the keys, 2 to 9 with a name list entry. You can call directly by pressing this key for 2-3 seconds.

1. Open the Contacts first by pressing the right soft key [Names] in standby mode.
2. Scroll to **Speed dial**, then press the left soft key [Select].
3. To add a number to Speed dial, select **(empty)**. Then, you can search the name in contacts.
4. You can change or delete a speed dial number, make a call or send a message by pressing the left soft key [Options].

Settings Menu-4-1-5

- **Set memory**

  You can select the memory for the Contacts feature between the SIM and the phone. If you select **Variable**, when adding entry, the phone will ask where to save the number.

- **Search by**

  You can set the phone to search by **name** or **number**, when you search the Contacts. If you select **Variable**, the phone will ask how to search when you search the Contacts.

▶ View options

You can set the contact display option.

- **Name only:** When you search the contacts, the list displays only names.
- **With pictures:** When you search the contacts, the list displays names and corresponding pictures.
- **Names & number:** When you search the contacts, the list displays names and number.

Copy all Menu-4-1-6

You can copy/move entries from SIM card memory to Phone memory and vice versa.

- **SIM to Phone:** You can copy the entry from SIM Card to Phone memory.
- **Phone to SIM:** You can copy the entry from Phone memory to SIM Card.

The following options are available.

- **Keep original:** When copying, the original dial numbers are kept.
- **Delete original:** When copying, the original dial numbers will be erased.

Delete all Menu-4-1-7

You can delete all entries in the SIM and/or the phone. This function requires the security code.

Press to return to standby mode.

Information Menu-4-1-8

▶ Service dial number

Use this function to access a particular list of services provided by your network operator (if supported by the SIM card).

1. Scroll to **Service dial number**, then press the left soft key [Select] to enter.
2. The names of the available services will be shown.
3. Use and to select a service. Press [Send].

▶ **Memory status**

You can check the current memory status of the SIM card or the phone memory.

▶ **Own number (SIM dependent)**

You can save and check your own number in SIM card.

Scheduler Menu-4-2

When you enter this menu, a calendar appears. A square cursor is located on the current date. You can move the cursor to another date using navigation keys. On the calendar, you can use the following keys.

Each press of	1	skips back a year.
	3	skips forward a year.
	*	skips back a month.
	#	skips forward a month.

You can enter a schedule or memo in the scheduler by pressing the left soft key [Options].

▶ **Add new:** Select this to enter a new schedule. After a schedule note is entered on a date, the date is shown in a different colour and appears on the right bottom of the screen. This function reminds you of your schedule. And the phone will sound an alarm tone if you set the phone to do so.

▶ **View:** Shows the schedule note or memo for the chosen day. Press the left soft key [Options] to edit or delete the note you selected.

▶ **View all:** Shows all the notes that are entered in the phone. Use the up/down navigation keys to browse through the note lists.

▶ **Delete past:** Select this to delete the expired schedule notes that have already been notified. You are asked to confirm this action.

▶ **Delete all:** Select this to delete all the schedule notes and memos. You are asked to confirm this action.

Memo Menu-4-3

Use this to take a memo. The phone can store up to 20 memos.

Note If you want to change the text input mode, press the # in order.

This menu includes functions related to SMS (Short Message Service), MMS (Multimedia Message Service), voice mail, as well as the network's service messages.

New message Menu-5-1

Write text message Menu-5-1-1

You can write and edit text message, checking the number of message pages.

1. Enter the **Messages** menu by pressing the left soft key [Select].
2. If you want to write a new message, select **Write text message.**
3. To make text input easier, use T9.
4. Press [Insert] to attach the followings.
5. If you want to set option for your text, or to finish your writing, press the left soft key [Options].

Note The phone which supports EMS release 5 is available to send colour pictures, sounds, text styles, etc.. The other party may not receive pictures, sounds or text styles you sent properly if the phone does not support such options.

Insert

- **Symbol:** You can add special characters.
- **Picture:** You can insert the Default graphics or graphics in My pictures that are available for short messages.
- **Sound:** You can insert sounds that are available for short messages.
- **Text templates:** You can use Text templates already set in the phone.
- **Contacts:** You can add phone numbers or e-mail addresses in the Contacts.
- **Signature:** You can add your signature to the message.

Options

- **Send:** Sends text messages.
  1. Enter numbers of recipient.
  2. Press key to add more recipients.
  3. You can add phone numbers in the contacts.
  4. Press the left soft key after entering numbers.

All messages will be automatically saved in the outbox folder, even after a sending failure.

- **Save:** Stores messages in Drafts.
- **Font:** You can select **Size** and **Style** of fonts.
- **Colour:** You can select **Colour** of foreground and background.
- **Alignment:** You can make the message contents aligned **Left, Center** or **Right**.
- **Add T9 dictionary:** You can add your own word. This menu can be shown only when edit mode is **Predictive (T9Abc/T9abc /T9ABC)**.
- **T9 languages:** Select a T9 input mode.
- **Exit:** If you press Exit while writing a message, you can end the writing message and back to the Message menu. The message you have written is not saved.

Write multimedia message Menu-5-1-2

A multimedia message can contain text, images, and/or sound clips. This feature can be used only if it is supported by your network operator or service provider. Only the devices that offer compatible multimedia message or e-mail features can receive and send multimedia messages.
You can create a multimedia message up to 10 slides. (approximately 100 KB)

1. After entering the subject of the message, press the OK key.
2. Key in the text message. Using the right soft key [Insert], you can insert a symbol, a photo, a picture, a sound, a voice memo, text templates, phone numbers stored in the contacts or a signature.
3. Press the left soft key [Options]. The following options are available.

- **Send:** You can send the multimedia message to multiple recipients at the same time.

  1) Key in the phone number. You can also search the phone number from the recent number list or the Contacts using the left soft key [Search].

  2) Press the right soft key [Settings]. You can set the following options:

  - **Priority:** Set the priority of the MMS.

  - **Validity period:** Set the duration for keeping the multimedia messages on the network server. Possible values are 1 hour, 12 hours, 1 day, 1 week and the maximum authorized by the network operator.

  - **Delivery report:** Select **Yes** to activate the report function. When this function is activated, the network informs you whether or not your message has been delivered.

  3) Press the left soft key [Send].

- **Preview:** Select this option to check out the multimedia message you've created. Each slide is sequentially played back automatically. You can also move to another slide from the currently played slide using the left/right navigation keys. To replay the message, press the left soft key [Replay].

- **Save:** Saves the message in drafts or as a template.

- **Add Slide:** Add a slide before or after the current slide.

- **Move to slide:** Select this option to move to another slide from the current slide.

- **Delete slide:** Deletes the current slide.

- **Set slide format:** You can set the following slide format.

  - **Set timer:** Enter the timer in each field using the numeric keypad.

  - **Swap text and picture:** Swaps the text and picture.

- **Remove media (shown when any media exists in the message):** You can remove picture, sound or video in the slide.

- **Add T9 dictionary:** When you didn't find a desired word in the T9 text input mode, you can add a word in the T9 dictionary using this option. After typing a word, press the left soft key [Save].
- **T9 langauges:** Select the T9 language for T9 input mode. You can also deactivate the T9 input mode by selecting **T9 off**. For further details on the T9 mode, refer to page 23 through 26.
- **Exit:** Exits from the **Write multimedia message** menu.

Inbox

Menu-5-2

You will be alerted when you have received messages. They will be saved in the Inbox. You can identify each message by icons. For details, see the icon description below.

Icon	Description
	Read SIM message
	Unread SIM message
	Read message
	Unread message
	Read delivery report
	Unread delivery report

If the phone has 'No space for messages', you can make space by deleting messages, media and applications.

Note SIM message refers the message saved in the SIM memory. And the network distinguishes an incoming message into the SIM message or just message.

Each received message has the following options available. Press the left soft key [Options].

- **View:** You can view the selected message.
- **Reply:** Replies to the received message.
- **Forward:** Forwards the received message to other recipients.
- **Return call:** Calls back to the sender.
- **Extract:** Extracts a picture, sound, text web page or email address from the message. These will be saved in My folder, Contacts, or bookmarks.
- **Delete:** Deletes the selected message from the Inbox.
- **View information:** Displays information about the received message.

Icon	Description
	Read multimedia messages
	Unread multimedia messages
	Read notified multimedia messages
	Unread notified multimedia messages

Each received multimedia message has the following options available. Press the left soft key [Options].

- **Reply:** Replies to the sender.
- **Forward:** Forwards the selected message to other recipients.
- **Return call:** Calls back to the sender.
- **Delete:** Deletes the selected message from the Inbox.
- **Extract:** Extracts pictures or sounds. They will be saved in My folder or Contacts.
- **View information:** Displays information about received messages; Sender's address, Subject (only for Multimedia message), Message date & time, Message type, Message size.

Drafts Menu-5-3

You can view the messages saved as a draft. The draft messages are listed with the date and time when they were saved. Scroll through the list using up/down navigation keys.

Icon	Description
	Multimedia message
	Text message

Each draft has the following options.

Press the left soft key [Options].

- **View:** You can view the selected message.
- **Edit:** You can edit the selected message.
- **Delete:** Deletes the selected message from the drafts folder.
- **View information:** You can view the information of selected message: subject (only for multimedia message), the date and time when saved, message type and size and the priority (only for multimedia message).
- **Delete all:** Deletes all the messages from drafts folder.

Outbox Menu-5-4

You can view the list and contents of sent messages in this menu and can also verify if the transmission was successful.

Icon	Description
	MMS sent
	MMS unsent
	MMS delivery confirmed
	SMS sent
	SMS unsent
	SMS delivery confirmed

In each message, the following options are available by pressing the left soft key [Options].

The messages of which transmission was completed has the following options.

- **View:** You can view the selected message.
- **Forward:** You can forward the selected message to other recipients.
- **Delete:** Deletes the selected message from outbox.
- **View information:** You can view the information of selected message: subject (only for multimedia message), the date and time when you sent it, message type and size, the priority (only for multimedia message), and recipients.
- **Delete all:** Deletes all the messages in the outbox folder.

The messages of which transmission is in progress has the following options.

- **View:** You can view the selected message.
- **Cancel:** Cancels transmitting of the message.
- **Delete:** Cancels transmitting the message and deletes the message.
- **View information:** You can view the information of selected message: subject (only for multimedia message), the date and time when you sent it, message type and size, the priority (only for multimedia message), and recipients.
- **Cancel:** Cancels all the message transmission.
- **Delete all:** Cancels all the message transmission and deletes all of them.

Listen to voice mail Menu-5-5

This menu provides you with a quick way of accessing your voice mailbox (if provided by your network). Before using this feature, you must enter the voice server number obtained from your network operator.

When new voice message is received, the ∞ symbol will be displayed on the screen. Please check with your service operator for details of their service in order to configure the handset correctly.

Info message Menu-5-6

Info service messages are text messages sent by the network to mobile phone users. They provide general information such as weather reports, traffic news, taxis, pharmacies, and stock prices. Each type of information is associated with a number, which can be obtained from the network operator. When you receive an info service message, a popup message will indicate a new message receipt or the info service message will be displayed directly.
The following options are available when viewing info service messages.

Read Menu-5-6-1

When you have received broadcast messages and select **Read** to view the message, it will be displayed on the screen.

Topics Menu-5-6-2

To create new topics, press the left soft key [Option] then select **Add new**. If you already have topics, you can deactivate, edit, or delete them by using the left soft key [Options].

Templates Menu-5-7

After creating some templates (text, multimedia, signature), you can use them by just selecting them when you send messages.

Text templates Menu-5-7-1

The followings are pre-defined text templates.

- **Please call me back.**
- **I'm late. I will be there at...**
- **Where are you now?**
- **I'm on the way.**
- **Top urgent. Please contact.**
- **I love you.**

The following options are available.

▶ **View:** Select this to view the selected template.

▶ **Edit:** Use this to edit the selected template.

- **Write messages**
  - **Write text message:** Use this to send the selected template message by SMS.
  - **Write multimedia message:** Use this to send the selected template message by MMS.
- **Add new:** Use this to create a new template.
- **Delete:** Deletes the selected template from the text template list.
- **Delete all:** Deletes all templates.

Multimedia templates Menu-5-7-2

You can create a multimedia template after pressing the left soft key [Add new]. And the multimedia templates you saved as a template while creating a multimedia message in the **Write multimedia message** (See page 47).

- **View:** You can view the multimedia template.
- **Edit:** You can edit the multimedia template.
- **Add new:** Allows you to add a new multimedia template.
- **Write messages:** You can write a multimedia message with the multimedia template.
- **Delete:** Deletes the selected template message from the multimedia template list.
- **Delete all:** Clears the multimedia template list.

Signature Menu-5-7-3

1. Press the left soft key [Edit].
2. After keying in the name, press the left soft key [OK].
3. Key in the mobile phone number, home number, office number, fax number, and E-mail address.
4. Press the left soft key [Save].

After creating the signature template, you can access the following menus by pressing the left soft key [Options].

- **Edit:** Use this to edit the signature.
- **Delete:** Use this to delete the signature.
- **Send:** You can send your business card via SMS, MMS or Bluetooth.

- **Receive:** You can receive other business cards via Bluetooth.
- **Exchange:** You can exchange your business card and others' business cards ia Bluetooth.

Settings Menu-5-8

Text message Menu-5-8-1

This menu lets you set up default SMS information.

- **Message types:** Set the default message type (Text, Voice, Fax, Natl. paging, X.400, E-mail, ERMES). The network can convert the messages into the selected format.
- **Validity period:** Set the length of time for which your text messages will be saved at the SMS center while attempts are made to deliver them to the recipient. Possible values are 1 hour, 12 hours, 1 day, 1 week and the maximum authorised by your network operator.
- **Delivery report:** Select whether to activate or deactivate the report function. When this function is activated, the network informs you whether or not your message has been delivered.
- **Reply via same service centre:** Allows the recipient of your SMS message to send you a reply via your message centre, if the service is provided by the network.
- **SMS centre:** Saves or changes the number of your SMS centre when sending text messages. You must obtain this number from your service provider.

Multimedia message Menu-5-8-2

Via this menu, you can set up the default multimedia message information.

The following options are available.

- **Priority:** Set the priority for the multimedia messages you will send.
- **Validity period:** Set the length of time for which your multimedia messages will be saved in the network server while attempts are made to deliver them to the recipient. Possible values are 1 hour, 12 hours, 1 day, 1 week and the maximum authorised by your network operator.

- **Delivery report:** Select whether to activate or deactivate the report function. When this function is activated, the network informs you whether or not your message has been delivered.
- **Auto download:**
  - **On:** If you select this, messages are downloaded automatically on receipt.
  - **Off:** Requires you to confirm you want to download the message.
  - **Home network only:** If you select this, messages are downloaded automatically on receipt in your home network area. And outside your home service area, it requires you to confirm you to download the message.
- **Network settings:** If you select the multimedia message server, you can set the URL for multimedia message server.
- **Permitted types:** Set the permitted type. Possible values are Personal, Advertisements and Information.

Voice mail centre Menu-5-8-3

You can receive the voicemail if your network service provider supports this feature. When a new voicemail is arrived, the symbol will be displayed on the screen. Please check with your network service provider for details of their service in order to configure the phone accordingly.

- **Home:** You can listen to voice mails by selecting Home.
- **Roaming:** Even when you are in abroad, you can listen to voice mails if roaming service is supported.

Info message Menu-5-8-4

- **Receive**

  Yes: If you select this menu, your phone will receive Info service messages.

  No: If you select this menu, your phone will not receive Info service messages any more.

▶ Alert

Yes: Your phone will beep when you have received Info service message numbers.

No: Your phone will not beep even though you have received info service messages.

▶ Languages

You can select the language you want by pressing [On/Off]. Then, the info service message will be shown in the language that you selected.

Push messages Menu-5-8-5

You can set the option whether you will receive the message or not.

With the LG-G233 phone, you can takes pictures and save them. After taking a picture, you can also send it via MMS or E-mail right away.

Note If the battery is too low, you may not use the Camera feature.

Take picture Menu-6-1

• Taking a picture with the clamshell open

Select **Take picture**, and then press . If you want to reach this menu directly, press and hold down in standby mode.

Before shooting, you can set the following values.

1. Digital zoom ( ): 5 levels are available.

2. Tone ( ): Colour, Sepia, Black and white

3. Brightness ( ): +2, +1, 0, -1, -2

4. Timer ( ): Off, 3 sec., 5 sec.

5. Memory ( ): Shows the current memory status.

Note If the memory is full, "Memory full" message is popped up and you cannot save a photo. Create space by deleting old photos in **Album**.

6. Flash ( ): Select the flash on ( )/ off ( ) by the up/down navigation keys.

7. Resolution ( ): 640x480(VGA), 320x240(QVGA), 128x160(Screen). 48x48(phonebook)

8. Image quality ( ): Fine/Normal/Basic

1. Center the desired option menu using the left/right navigation keys.
2. Select the desired value with the up/down navigation keys.
3. After finishing all the settings, focus on the subject to capture and press the OK key. With a click, the image is captured and the following menu bar appears.

Note When the resolution is set to 48x48 (phonebook), the following menu bar appears.

If **Auto save** [Menu-6-5-3] is set to **Yes**, the captured image is automatically saved without displaying the above menu bar.

4. To save the image, centre the " " and press the OK key. If you don't want to save the image, centre the " " and press the OK key.
   You can also send the image via MMS by selecting " ".
   For further information regarding multimedia message writing, refer to page 47-49.
   After taking a photo in 48x48 (phonebook), you can directly save the image in the Contacts by selecting " ".

• Taking a picture in the clamshell closed state

Press the side camera key to access the camera menu. The following submenus are available.

After highlighting the desired menu using side keys, press the side camera key to select it.

1. Take picture

Select this to take photos. You can take self-shots. To capture the image, press the side camera key. To go back to the camera menu, press and hold down the side camera key.

2. Slide show

Displays every image in the **Album** in succession. You can move to previous/next images manually with the up/down side keys. To stop the slide show and go back to the camera menu, press the side camera key.

3. Torch

Select the flash on( )/off( ) with the up/down side keys.

4. Back

Select this to go back to standby mode.

Take in modes Menu-6-2

You can enjoy taking pictures in diverse preset frames. 7 preset frames are available. Select the desired frame using the up/down navigation keys.

Note In this mode, you can't change the settings of resolution.

Take continuously Menu-6-3

You can take the maximum of 9 pictures subsequently at the same time. After taking a picture, you can view it using the up/down navigation keys. You can also save them by pressing the OK key.

Note If you set 320x240 in resolution, you can take only 6 pictures. In case of 128x160, it is available to 9 pictures.

Album Menu-6-4

All the pictures taken are stored in this menu. The pictures are classified into **General pictures, Mode pictures**, and **Phonebook pictures**. And in All pictures, you can view all the **pictures.** You can access the following submenus by pressing the left soft key [Options].

- **Multi view:** You can view the maximum of 9 thumbnails in a screen.
- **Write multimedia message:** You can send a picture through MMS.
- **Set as wallpaper:** You can set a picture as a wallpaper.
- **Slide show:** You can view the pictures in slide show.
- **Delete:** You can delete a picture.
- **Edit title:** You can edit the title of picture.
- **View information:** You can view the information of the picture such as title, size, date, time.
- **Protection:** If you activate this function on each picture, you can't send, edit or delete.

Settings Menu-6-5

Memory status Menu-6-5-1

You can check the current memory status on the phone.

Clear album Menu-6-5-2

Use this menu to delete all the photos. You are asked to confirm this action.

Auto save Menu-6-5-3

If you set this **Yes**, the captured images are automatically saved without displaying the Save menu bar.

Press the Menu key ( ) and select **Settings** using navigation keys.

Alarm clock Menu-7-1

There are 5 alarm clocks available. Set the alarm to ring at a specific time.

After selecting an alarm clock using the left soft key [Select],

1. **Alarm on/off :** Select On using the left/right navigation key. To deactivate the alarm function, select Off.
2. **Alarm time:** Enter the alarm time using the numeric keys
3. **Repeat:** Select the desired one from Once, Mon~Fri, Mon~Sat, and Everyday using the left/right navigation key.
4. **Alarm melody:** Select the desired alarm melody using the left/right navigation key.
5. Press the left soft key [OK].
6. You can edit the alarm clock name. After keying in the name, press the left soft key [OK].

When an alarm function is activated, " " is shown in standby mode.

When the alarm time is reached, it sounds the alarm melody.

▶ To turn off the alarm, press the right soft key [Quit].

Date & Time Menu-7-2

This option lets you change the current time and date displayed.

The following options are available.

Set date Menu-7-2-1

Use this to enter the day, month and year. You can change the date format via the **Date format** menu option.

Date format Menu-7-2-2

DD/MM/YYYY (day/month/year)

MM/DD/YYYY (month/day/year)

YYYY/MM/DD (year/month/day)

Set time Menu-7-2-3

Use this to enter the current time. You can choose the time format via the **Time format** menu option.

Time format Menu-7-2-4

24-hour

12-hour

Phone settings Menu-7-3

Many features of your phone can be customised to suit your preferences. All of these features are accessed via the **Phone settings** menu.

Display settings Menu-7-3-1

- **Wallpaper:** Select the wallpaper which will be displayed on the main LCD and the sub LCD screen each in standby mode.
- **Handset scheme:** You can select the desired handset display scheme out of 4 schemes. You can preview them by scrolling the shemes.
- **Greeting note:** If you select **On**, you can edit the text which will be displayed in standby mode.
- **Backlight:** Use this to select whether or not the phone uses the backlight. A small increase in standby/talk time can be achieved by turning the backlight off.
- **Information window:** You can preview the current status of the selected menu before opening the menu. The status is shown at the bottom of the screen.
- **Network name:** If you select **On**, you can see the name of network service provider which is displayed in standby mode.

Language Menu-7-3-2

You can select the display language. When the language option is set to **Automatic**, the language is automatically selected according to the language of the SIM card used. English will be set if the language on the SIM card is not supported by the phone.

Call settings Menu-7-4

To change the settings for call diverting.

Call divert Menu-7-4-1

When this network service is activated, you can direct your incoming calls to another number, for example, to your voice mailbox number. For details, contact your service provider. Select one of the divert options, for example, select **If busy** to divert voice calls when your number is busy or when you reject incoming calls.

The following options are available.

All voice calls: Diverts all voice calls unconditionally.

If busy: Diverts voice calls when the phone is in use.

If no reply: Diverts voice calls which you do not answer.

If out of reach: Diverts voice calls when the phone is switched off or out of coverage.

All data calls: Diverts to a number with a PC connection unconditionally.

All fax calls: Diverts to a number with a fax connection unconditionally.

Each option has the following menu:

- **Activate:** Activates the corresponding service.
  - **To voice mail centre:** Forwards to message centre. This function does not apply to **All data calls** and **All fax calls** menus.
  - **To other number:** Input the number for call diverting.
  - **To favourite number:** You can check recent five diverted numbers.
- **Cancel:** Cancels the selected call divert.
- **View status:** You can check the status of the service.

Cancel all: Cancels all call divert settings.

Answer mode

Menu-7-4-2

Select the desired mode to answer a call.

- **Flip open:** When the phone rings, you can answer a call simply by opening the flip.
- **Press any key:** When the phone rings, you can answer a call by pressing any key except the key and the right soft key ( ).
- **Send only:** You can answer a call only by pressing the send key ( ).

Send my number

Menu-7-4-3

This network service lets you decide whether your phone number is displayed (On) or hidden (Off) from the person you are calling. Select **Set by network** to reset the phone to the setting that you have agreed upon with your service provider.

Call waiting (Network Service)

Menu-7-4-4

The network will notify you of a new incoming call while you have a call in progress. Select **Activate** to request the network to activate call waiting, **Cancel** to request the network to deactivate call waiting, or **View status**, to check if the function is active or not.

Minute minder

Menu-7-4-5

When set to **On**, the phone will beep every minute during an outgoing call to keep you informed of the length of the call.

Auto redial

Menu-7-4-6

Select **On**, and your phone will make a maximum of five attempts to connect the call after an unsuccessful call attempt.

Security settings Menu-7-5

Various passwords are used to protect certain features of your phone. Refer to page 20 for the various passwords.

PIN code request Menu-7-5-1

When the **PIN code request** feature is enabled, you must enter your PIN each time you switch the phone on. Consequently, any person who does not have your PIN cannot use your phone without your approval.

Note Before disabling the PIN code request feature, you must enter your PIN.

The following options are available:

- **On:** You must enter the PIN each time the phone is switched on.
- **Off:** The phone connects directly to the network when you switch it on.

Phone lock Menu-7-5-2

When the **Phone lock** feature is enabled, the phone is locked and you must enter the phone password each time the phone is switched on. The password is factory set to **0000**. To change the phone password, refer to the **Change codes – Security code** menu option [Menu-7-5-5-2]. Once the correct password has been entered, you can use the phone until you switch it off.

Call barring Menu-7-5-3

Call barring lets you restrict the making and receiving of calls with your phone. For this function, you need the barring password, which you can obtain from your service provider.

The following options are available:

- **All outgoing:** No call can be made.
- **International:** International calls cannot be made.

- **International when roaming:** When abroad, calls can be made only to numbers within the current country and to your home country, the country where your home network provider is located.
- **All incoming:** No call can be received.
- **Incoming when roaming:** Calls cannot be received when you are using your phone outside your home service area.
- **Cancel all:** All call barring settings are deactivated; calls can be made and received normally.
- **Change password:** Use this to set and change the call barring password obtained from your service provider using this option. You must enter the current password before you can specify a new one. Once you have entered a new password, you are asked to confirm it by entering it again.

Note To use **Call barring**, you must input the network password. When calls are barred, calls may be possible to certain emergency numbers on some networks.

Fixed dial number (FDN)

(SIM dependent) Menu-7-5-4

Use this to restrict your outgoing calls to selected phone numbers, if this function is supported by your SIM card. The PIN2 code is required.

The following options are available:

- **Activate:** Use this to only call phone numbers saved in the phonebook. You must enter your PIN2 code.
- **Cancel:** Allows you to call any number.
- **Number list:** Use this to view the numbers saved as fixed dial numbers.

Note Not all SIM cards have a PIN2. If your SIM card does not, this menu option is not displayed.

Change codes

Menu-7-5-5

The **Change codes** feature lets you change your current password to a new one. You must enter the current password before you can specify a new one. Use this to change the access codes: **PIN2 code**, **Security Code**

Note PIN: Personal Identification Number

Network settings Menu-7-6

The **Network settings** feature enables you to indicate whether the network used when roaming(outside your home area) is selected automatically, manually or preferably.

Note You can select a network other than your home network only if it has a valid roaming agreement with your home network.

Automatic Menu-7-6-1

Use this to set the phone to automatically search for and select one of the cellular networks available in your area.

The phone will default back to **Automatic** if it is switched off.

Manual Menu-7-6-2

If you want to select the desired network manually from a list of network, you can activate this function. If the connection to the manually selected network is lost, the phone will sound an error tone and ask you to select a network again. The selected network must have a roaming agreement with your home network, that is, the operator whose SIM card is in your phone. The phone will let you select another network if the phone fails to access the selected network. If you switch off the phone, the phone will be reset to **Automatic**.

Preferred Menu-7-6-3

You can set a list of preferred networks and the phone attempts to register with first, before attempting to register to any other networks. This list is set from the phone's predefined list of known networks.

Reset settings Menu-7-7

You can reset your phone to its default configuration. To do so, proceed, as follows.

1. Select the **Reset settings** menu option.

2. Enter the 4-digit security code.

Note The security code is preset to 0000.

GPRS setting

Menu-7-8

GPRS(General Packet Radio Service) is a technology that allows mobile phones to be used for sending and receiving data over the mobile network. GPRS is a data bearer that enables wireless access to data network such as the Internet.

Before you can use GPRS technology

- You need to subscribe to the GPRS service. For availability and subscription to GPRS service, contact your network operator or service provider.
- You need to save the GPRS settings for the applications used over GPRS.

If you select Power on and you are in a network that supports GPRS, the phone registers to the GPRS network and sending short messages will be done via GPRS. Also, starting an active packet data connection, for example, to send and receive e-mail, is quicker. If you select When needed, the phone will use a GPRS connection only if you start an application or action that needs it. The GPRS connection is closed after it is no longer required by any application.

Note If there is no GPRS coverage and you have chosen Automatic, the phone will periodically try to establish a connection.

You can access various WAP (Wireless Application Protocol) services such as banking, news, weather reports and flight information. These services are specially designed for mobile phones and they are maintained by WAP service providers.

Check the availability of WAP services, pricing and tariffs with your network operator and/or the service provider whose service you wish to use. Service providers will also give you instructions on how to use their services.

Once connected, the homepage is displayed. The content depends on the service provider. To exit the browser at any time, press the key. The phone will return to the previous menu.

Navigating with the WAP browser

You can surf the Internet using either the phone keys or the WAP browser menu.

Using the phone keys

When surfing the Internet, the phone keys function differently to phone mode.

Key	Description
	Scrolls each line of the content area.
	Returns to the previous page.
OK	Selects options and confirms actions.

Using the WAP browser menu

There are various menu options available when surfing the Mobile Web.

Note The WAP browser menus may vary, depending on your browser version.

Internet Menu-8-1

Home Menu-8-1-1

Connects to a homepage. The homepage will be the site which is defined in the activated profile. It will be defined by the service provider if you have not defined it in the activated profile.

Bookmarks Menu-8-1-2

This menu allows you to store the URL of favourite web pages for easy access at a later time. Your phone has several pre-installed bookmarks. These pre-installed bookmarks cannot be deleted.

To create a bookmark

1. Press the left soft key [Options].

2. Select Add new and press the OK key.

3. After entering the desired URL and title, press the OK key.

* ***Tip:*** *Use the "1 " key and * key to enter symbols. To enter ".", press "1 ".*

After selecting a desired bookmark, the following options are available.

- **Connect:** Connects to the selected bookmark.
- **Add new:** Select this to create a new bookmark.
- **Edit:** You can edit the URL and/or the title of the selected bookmark.
- **Delete:** Deletes the selected bookmark.

Delete all: Deletes all the bookmarks.

Profiles Menu-8-1-3

A profile is the network information used to connect to the Internet.
Each profile has submenus as follows:

- **Activate:** Activates the selected profile.
- **Settings:** Use this to edit and change WAP settings for the selected profile.
  - **Homepage:** This setting allows you to enter the address (URL) of a site you want to use as homepage. You do not need to type http:// at the front of each URL as the WAP Browser will automatically add it.
  - **Bearer:** You can set the bearer data service.

    1 Data

    2 GPRS
  - **Data settings:** Appears only if you select Data Settings as a bearer service.

IP address: Enter the IP address of the WAP gateway you want.

Dial number: Enter the telephone number to dial to access your WAP gateway.

User ID: The users identity for your dial-up server (and NOT the WAP gateway).

Password: The password required by your dial-up server (and NOT the WAP gateway) to identify you.

Call type: Select the type of data call : Analogue of Digital (ISDN)

Call speed: The speed of your data connection ; 9600 or 14400

Linger time: You need to enter timeout period. After entering that, the WAP navigation service will be unavailable if any data is not input or transferred.

- **GPRS settings:** The service settings are only available when GPRS is chosen as a bearer service.

IP address: Input the IP address of the WAP gateway you access.

APN: Input the APN of the GPRS.

User ID: The users identify for your APN server.

Password: The password required by your APN server.

- **Connection Type:** The options for connection type are Temporary or Continuous and depend on the gateway you are using.

Continuous

A confirmed delivery mechanism but generates more network traffic.

Temporary

A non-confirmed (connectionless) service.

HTTP

Connecting Clients to Server directly in HTTP

- **Proxy settings**

IP address: Input the IP address of the Proxy server you access.

Port: Input the Proxy Port

- **DNS settings**

  Primary server: Input the IP address of the primary DNS server you access

  Secondary server: Input the IP address of the secondary DNS server you access

- **Secure settings:** According to the used gateway port, you can choose this option as On or Off.

- **Display image:** You can select whether images on WAP cards are displayed or not.

▶ **Rename:** You can change the profile name.

▶ **Delete:** Deletes the selected profile from the list.

▶ **Add new:** You can add a new profile.

Go to URL Menu-8-1-4

You can connect directly to the site you want. After entering a specific URL, press the OK key.

Cache settings Menu-8-1-5

The information or services you have accessed are saved in the cache memory of the phone.

▶ **Clear cache:** Removes all context saved in cache.

▶ **Check cache:** Set a value whether a connection attempt is made through cache or not.

Note A cache is a buffer memory, which is used to save data temporarily.

Cookies settings Menu-8-1-6

The information or services you have accessed are saved in the cache memory of the phone.

▶ **Clear cookies:** Removes all context saved in cookie.

▶ **Check cookies:** Check whether a cookie is used or not.

Security certification Menu-8-1-7

A list of the available certification is shown.

- **Authority:** You can see the list of authority certificates that have been stored in your phone.
- **Personal:** You can see the list of personal certificates that have been stored in your phone.

Reset profiles Menu-8-1-8

You can reset profiles to return to original settings.

Browser version Menu-8-1-9

The WAP browser version is displayed.

SIM service Menu-8-2

Your service provider can offer special application through SIM card, such as home banking, stock market, etc. If you are registered for one of these services, the service name will appear at the end of the Main Menu. With the SIM Services menu your phone is future-proof and will support additions to your service provider's service.

For more information contact your service provider.

Games & more Menu-9-1

My games & more Menu-9-1-1

In this menu, you can manage the Java applications installed in your phone. You can play or delete downloaded applications, or set the connect option. The downloaded applications are organised in folders. Press the left soft key [Select] to open the selected folder or launch the selected midlet. Using the left soft key [Menu], the following menus are available.

- **Launch:** Start the selected application.
- **Info:** Shows the information of the application.
- **Update:** Updates an application using WAP.
- **Options:** Some Java applications may require a data connection to be made. Select this to set the connecting options.
  - **Always:** The connection is created immediately without a notification.
  - **Prompt:** You will be asked before the application makes the connection.
  - **Never:** No connection is allowed.

Note You cannot remove or rename the preinstalled folder or a game in the folder.

Java™, is a technology developed by Sun Microsystems. Similar to the way you would download the Java Applet using the standard Netscape or MS Internet Explorer browsers, Java MIDlet can be downloaded using the WAP enabled phone. Depending on the service provider, all Java based programs such as Java games can be downloaded and run on a phone. Once downloaded, the Java program can be viewed in the **My games & more** menu where you can select, execute, or delete. The Java program files saved in the phone are in .JAD or .JAR format.

Note
- The JAR file is a compressed format of the Java program and the JAD file is a description file that includes all detailed information. From the network, prior to download, you can view all detailed file descriptions from the JAD file.
- While being based on a standard language (J2ME), not all Java applications are compatible with all handsets on sale insofar as specific libraries may be used for a telephone model. The software may be blocked or switch itself on when Java applications not specifically developed for the phone this manual refers to are downloaded, making it necessary to "restart" the handset. We would like to point out that these problems are caused by incompatible applications and are not a product fault.

Caution Only J2ME (Java 2 Micro Edition) based programs will run in a phone environment. The J2SE (Java 2 Standard Edition) based programs will only run in a PC environment.

Profiles Menu-9-1-2

This menu contains the same settings of the Internet menu. In fact, in order to download new applications, a WAP connection is needed.

Pictures Menu-9-2

The left soft key [Options] will bring up the following options.

- **Set as wallpaper:** Currently selected picture can be set as a Wallpaper.
- **Write multimedia message:** You can send the picture via MMS.

Sounds Menu-9-3

The left soft key [Options] will bring up the following options.

- **Set as ringtone:** Select this to set the sound as the ring tone.
- **Write messages:** You can send the sound via SMS or MMS.

Accessories

There are various accessories for your mobile phone. You can select these options according to your personal communication requirements.

Standard Battery

Headset

Allows hands-free operation. Includes earpiece and microphone.

Travel Adapter

This charger allows you to charge the battery while away from home or your office.

Data cable/CD

You can connect your phone to PC to exchange the data between them.

Note
- Always use genuine LG accessories.
- Failure to do this may invalidate your warranty.
- Accessories may be different in different regions; please check with our regional service company or agent for further enquires.

General

Product name: LG-G233

System : GSM 900 / DCS 1800

Ambient Temperatures

Max: +55°C

Min: -10°C

Declaration of Conformity

LG Electronics

Suppliers Details

Name

LG Electronics Inc

Address

LG Electronics Inc. LG Twin Towers 20,
Yeouido-dong, Yeongdeungpo-gu, Seoul, Korea 150-721

Product Details

Product Name

E-GSM 900 / DCS 1800 Dual-Band Terminal Equipment

Model Name

LG-G233

Trade Name

LG

CE 0168

Applicable Standards Details

R&TTE Directive 1999/5/EC

EN 301 489-1 V1.4.1(2002-08), EN 301 489-7 V1.2.1(2002-08)
EN 60950 : 2000
EN 50360 2001, EN50361 2001
EN 300 328 V1.4.1(2003)
TS51.010-1 V5.10.0
Selection according to GCF-CC 3.16.0 including requirements of EN 301 511 V.9.0.2(2003)

Supplementary Information

The conformity to above standards is verified by BABT with Certificate No.(NC/12456) and GSM test report (no.WG613452/01 Issue 1,WG613450/03 Issue 1,74902806 Issue 1,74903687 Issue 2), EMC test report(no. HCT-C05-0511), safety test report(no. ITYA0105485, ITYZ0915465), SAR test report (no. TCMA0813785) and Bluetooth (no. HCT-RF05-0201, 74903686-01)

Declaration

I hereby declare under our sole responsibility that the product mentioned above to which this declaration relates complies with the above mentioned standards and Directives

Name	Issued Date
Jin Seog, Kim / Director	21. June . 2005

Signature of representative

LG Electronics Inc. Amsterdam Office
Veluwezoom 15, 1327 AE Almere, The Netherlands
Tel : +31 - 36- 547 - 8940, e-mail : seokim @ lge.com