ENGLISH

RD6250 | USER GUIDE

Please read this manual carefully before operating your mobile phone. Retain it for future reference.

P/N : MMBB0223301 (1.0) H

LG Life's Good

RD6250 | USER GUIDE

LG Electronics Inc.

LG Life's Good

हिन्दी

RD6250 | उपयोक्ता मार्गदर्शिका

सेट का उपयोग करने से पहले कृपया इस उपयोक्ता मार्गदर्शिका को ध्यान से पढ़ें भविष्य में संदर्भ के लिये इसे संभाल कर रखें

Read these simple guidelines. Breaking the rules may be dangerous or illegal. Further detailed information is given in this user guide.

Violation of the instructions may cause serious injury or death.

- Never use an unapproved battery since this could damage the phone and/or battery and could cause the battery to explode.

- Never place your phone in a microwave oven as it will cause the battery to explode.
- Do not dispose of your battery by fire or with hazardous or flammable materials.

- Make sure that no sharp-edged items such as animal's teeth, nails, come into contact with the battery. There is a risk of this causing a fire.

- Store the battery in a place out of reach of children.
- Be careful that children do not swallow any parts such as rubber plugs (earphone, connection parts of the phone, etc.). This could cause asphyxiation or suffocation.

- Unplug the power cord and charger during lightning storms to avoid electric shock or fire.

- When riding in a car, do not leave your phone or set up the hands-free car kit near to the air bag. If wireless equipment is improperly installed and the air bag is activated, you may be seriously injured.
- Do not use a hand-held phone while driving.

- Do not use the phone in areas where its use is prohibited. (For example: aircraft).

- Do not expose the battery charger or adapter to direct sunlight or use it in places with high humidity, such as a bathroom.
- Never store your phone in temperatures less than -15°C or greater than 50°C.

- Do not use harsh chemicals(such as alcohol, benzene, thinners, etc.) or detergents to clean your phone. There is a risk of this causing a fire.

- Do not drop, strike, or shake your phone severely. Such actions may harm the internal circuit boards of the phone.

- Do not use your phone in high explosive areas as the phone may generate sparks.
- Do not damage the power cord by bending, twisting, pulling, or heating. Do not use the plug if it is loose as it may cause a fire or electric shock.

- Do not place any heavy items on the power cord. Do not allow the power cord to be crimped as it may cause fire or electric shock.
- Do not handle the phone with wet hands while it is being charged. It may cause an electric shock or seriously damage your phone.

- Do not disassemble the phone.
- Do not place or answer calls while charging the phone as it may short-circuit the phone and/or cause electric shock or fire.

- Only use the batteries, antennas, and chargers provided and approved by LG. The warranty will not be applied to products provided by other suppliers.
- Only authorized personnel should service the phone and its accessories. Faulty installation or service may result in accidents and consequently invalidate the warranty.

- Do not hold or let the antenna come in contact with your body during a call.

- 3 emergency calls can be made only within a service area. For emergency call(100, 101, 102), make sure that you are within a service area and that the phone is turned on.

Contents

Introduction 3

Before You Start 4

Cautions 6

Getting Started 8

Phone Components 8

Phone Overview 9

Onscreen Icons 10

Menu Tree 11

Using the Battery and Charger 13

Installing and Removing the Battery 13

Charging the Battery 13

Battery Charge Level 14

Caring for the Battery 14

Basic Functions 15

Turning the Phone On and Off 15

Making a Call 15

Receiving Calls 15

Signal Strength 16

About the antenna 16

Quick Adjust 16

Call Waiting 17

Mute 18

Redialing Calls 18

Speed Dialing 18

Caller ID 18

Entering and Editing Information 19

Entering Information Using T9 Text Input 19

Examples Using T9 Text Input 20

Examples Using Abc (Multi-tap) Text input 21

Key Mapping For Hindi Entry 22

To Edit in Hindi Mode 23

Examples Using T9Hin Text Input for Hindi 23

Menu Features 24

General Guidelines to Menu Access and Settings 24

1. Names 24

1.1 Add Name 24

1.2 Find 25

1.3 Groups 25

1.4 Speed Dial 26

1.5 Copy & Move 26

1.6 Erase Names 27

1.7 My Profile 27

1.8 Memory Info 27

1.9 Help 27

2. Messages 28

2.1 Write 29

2.2 Inbox 33

2.3 1234 Services 35

2.4 Outbox 35

2.5 Voice Mail 36

2.6 Archive in UIM 37

2.7 Drafts 37

2.8 Templates 38

2.9 Msg Groups 39

2.0 Erase Msgs 40

2.* Msg Settings 40

2.# Help 41

3. Call History 42

3.1 Missed 42

3.2 Received 42

3.3 Dialled 42

3.4 In Call Memo 43

3.5 Call Duration 43

Contents

3.6 Erase History 43
3.7 Help 43
4. Display 44
4.1 Language 44
4.2 Service Area 44
4.3 Clock & Shortcut 44
4.4 Time & Date 44
4.5 Wallpaper 44
4.6 Menu Style 45
4.7 Colour Scheme 45
4.8 Rhythmic Lighting 45
4.9 Backlight 45
4.0 Help 46
5. Mobile World 46
5.1 R-Menu 46
5.2 Mobile TV 46
5.3 Play N Shop 47
5.4 Dial 1234 47
5.5 Write MMS 47
5.6 MMS Inbox 48
5.7 Reset R-Menu 48
5.8 UIM Toolkit 48
5.9 Games 48
5.0 Help 48
6. Profiles 48
Select Profiles 48
Rename Profiles 49
Customize Profiles 49
6.7 Help 50
7. Organ.&Tools 50
7.1 Bluetooth 50
7.2 Voice Tools 52
7.3 Schedule 55
7.4 Memo 56
7.5 Reserved Call 57
7.6 Alarm 57
7.7 Stopwatch 58
7.8 Calculator 58
7.9 Unit Converter 58
7.0 World Clock 59
7.* Help 59
8. Multimedia 59
8.1 Camera 59
8.2 FM Radio 63
8.3 MP3 63
8.4 My Stuff 64
9. Settings 65
9.1 My Menu 65
9.2 Call 66
9.3 Phone 67
9.4 Security 69
Functions Used During a Call 72
In Call Memo 72
Mute/Unmute 72
Voice Privacy On/Off 72
Voice Memo 73
Adjusting Speaker Mode On 73
Earpiece/Speaker Volume 73
Accessories 74
Frequently Asked Questions .75
Frequently asked questions 75
Before calling for service 79
Safety Guidelines 81
TIA Safety Information 81
Safety Information 84
FDA Consumer Update 87

Congratulation on your purchase of the LG-RD6250 cellular phone that has been designed to operate with the latest digital mobile communication technology, Code Division Multiple Access (CDMA). The CDMA system has greatly enhanced voice clarity and can provide various types of advanced features.
This is an advanced and compact phone which has diverse features as follows:

- Large, Easy-to-read, 5 lines display + 1 icon line + 1 menu line
- Keypad: 10 Alphanumeric keys / 2 Function keys / 2 Soft keys / 1 Clear key / 1 Joystick key for 4 way navigation and OK function / 1 Call key / 1 End key / 1 Camera key / 1 Side key for MP3 and FM / side UP-DOWN key
- Bluetooth Wireless Technology
- FM Radio
- MP3 Player
- Hot Swappable External Memory
- Digital Camera with Zoom
- English and Hindi Languages
- SMS, MMS, LMS, E-mail, SMS Chat
- Voice Memo, Recorder and Dialing
- 2500 dynamics Phonebook memory
- 72 polyphonic, MP3 and Voice quality Ringtones
- Speaker Phone
- Flash Light cum Torch
- In call memo, Rhythmic Lighting, Airplane Mode
- English and Hindi language
- PC Sync for Phonebook, Organizer, Camera, MP3

Check Accessories

Your mobile phone comes with a AC Adaptor, rechargeable battery, handstrap, microSD card, data cable and headset. Please verify that these accessories are included.

Important Information

This user's manual provides important information on the use and operation of your phone. Please read all the information carefully prior to using the phone for the best performance and to prevent any damage to or misuse of the phone. Any unapproved change or modification will void your warranty.

Safety Instructions

WARNING! To reduce the possibility of electric shock, do not expose your phone to high humidity areas, such as the bathroom, swimming pool, etc.
Use only LG-approved batteries and travel chargers to avoid the damage to the phone. Using other batteries or chargers voids your warranty and may cause an explosion.
Do not use batteries and travel chargers for the other purposes other than their original purpose of using for the phone.
Always store your phone away from heat. Never store your phone in settings that may expose it to temperatures less than -15°C or greater than 50°C, such as outside during a snowstorm or in your car on a hot day. Exposure to excessive cold or heat will result in malfunction, damage and/or catastrophic failure.
Use caution when using your phone near other electronic devices. RF emissions from your mobile phone may affect nearby inadequately shielded electronic equipment. You should consult with manufacturers of any personal medical devices such as pacemakers and hearing aids to determine if they are susceptible to interference from your mobile phone. Turn off your phone in a medical facility or at a gas station.
Never place your phone in a microwave oven as it will cause the battery to explode.

IMPORTANT! Please read the TIA Safety Information (on page 81) before using your phone.

FCC RF Exposure Information

WARNING! Read this information before operating the phone.

In August 1996, the Federal Communications Commission (FCC) of the United States, with its action in Report and Order FCC 96-326, adopted an updated safety standard for human exposure to radio frequency (RF) electromagnetic energy emitted by FCC regulated transmitters. Those guidelines are consistent with the safety standard previously set by both U.S. and international standards bodies.
The design of this phone complies with the FCC guidelines and these international standards.

⚠ CAUTION

Use only the supplied and approved accessories. Use of unauthorized accessories or modifications could impair call quality, damage the phone, void your warranty.

Do not use the phone with a damaged accessories. If the damaged accessories come into contact with the skin, a minor burn may result. Contact your local dealer for a replacement of accessories.

Body-worn Operation

This device was tested for typical body-worn operations with the back of the phone kept 3/4 inches (2 cm) from the body. To comply with FCC RF exposure requirements, a minimum separation distance of 3/4 inches (2 cm) must be maintained between the user's body and the back of the phone, including the antenna. Third-party belt-clips, holsters, and similar accessories containing metallic components should not be used. Body-worn accessories that cannot maintain 3/4 inches (2 cm) separation distance between the user's body and the back of the phone, and have not been tested for typical body-worn operations may not comply with FCC RF exposure limits and should be avoided.

Vehicle Mounted External Antenna
(optional, if available)

A minimum separation distance of 8 inches (20 cm) must be maintained between the user / bystander and the vehicle mounted external antenna to satisfy FCC RF exposure requirements.

For more information about RF exposure, visit the FCC website at http://www.fcc.gov/.

FCC Part 15 Class B Compliance

This device and its accessories comply with part 15 of FCC rules. Operation is subject to the following two conditions: (1) This device and its accessories may not cause harmful interference, and (2) this device and its accessories must accept any interference received, including interference that cause undesired operation.

Cautions for Battery

- Do not disassemble.
- Do not short-circuit.
- Do not expose to high temperature : 60°C (140°F).
- Do not incinerate.

Battery Disposal

- Please dispose of your battery properly.
- Do not dispose of your battery in fire or with hazardous or flammable materials.

Charger Cautions

- Using the wrong battery charger could damage your phone and void your warranty.
- The charger is intended for indoor use only.

Do not expose the battery charger to direct sunlight or use it in places with high humidity, such as the bathroom.

Cautions

- Only use the batteries and chargers provided or approved by LG. The warranty will not be applied to products provided by other suppliers.
- Using the phone in proximity to receiving equipment (i.e., TV or radio) may cause interference in this phone.
- Keep your phone in a safe place when not in use.
- Only authorized personnel should service the phone and its accessories. Faulty installation or service may result in accidents and consequently invalidate the warranty.
- This phone has a built-in antenna. As with any other radio-transmitting device, do not touch the upper part which antenna is mounted while the phone is in use.
- Use only the antenna provided or approved by LG. Unauthorized antennas, modifications or attachments may affect the quality of phone call, damage the phone or result in a violation of FCC regulations.

- Do not use the cellular phone if the antenna is damaged. If the damaged antenna gets in contact with the skin, it may cause a slight burn. Please contact LG Authorized Service Center (ASC) to replace the damaged antenna.
- Do not use the cellular phone in areas where its use is prohibited. (For example : aircrafts).
- Do not expose the cellular phone to high temperature or high humidity conditions.
- Do not expose your cellular phone to water. If this happens, turn it off immediately and remove the battery. If the phone does not work, bring it to an LG Authorized Service Center.
- Avoid shock or impact on the cellular phone.

Phone Components

The following shows key components of your mobile phone.

Phone Overview

LCD Screen	Displays messages & indicator icons.
Soft Keys (the names of the functions of these keys appear at the bottom of the screen)	**Soft Key 1** Used to display the function setting menu. **Soft Key 2** Searches Phone Book, change text input mode. Press to reject the call and send predefind SMS.
CALL Key	Allows user to place or answer calls.
END / PWR Key	Used to turn power on/off and to end a call. Using this key, you can return to the standby mode. When you press once, when a call is received, the phone stops ringing or vibrating depending on the mode it is in. Press twice to reject the call.
OK / Speaker Mode ON~OFF Key / Up / Down / Left / Right	Accepts the highlighted choice when navigating through a menu. When pressed long in idle model, activate speaker mode On/Off. This allows quick access to Message Menu (Long press to go directly to Write Msg) Voice Dialling (Press long to activate Voice Recorder) Mobile World Profile (Press long to activate Ring tone menu).

Alphanumeric Keypad	These keys enable you to enter numbers and characters and choose menu items.
Clear / My Menu / Torch ON~OFF	Press to delete a single space or character. Press and hold to delete entire words. Press this key once in any menu to go back to the previous menu. In standby mode, press button long to activate Torch ON. Press to access My Menu.
Vibrate Mode Key	In standby mode, set the vibrate mode by pressing and holding the key about 2 seconds.
Key Guard Key	In standby mode, set the Key Guard enabled by pressing and holding the key about 2 seconds.
Camera Key	Press button shortly to Camera Menu. Press button long to Camera preview.
International Call Prefix Key	To make an international call, press key for 2 or 3 seconds. + means international calling code.
Side FM/MP3 key	Press once to activate MP3 player and press long to activate FM radio.
Side volume key	Adjust volume of MP3 / FM radio.

Onscreen Icons

The phone screen displays several onscreen icons which appear when the phone is powered on.

Icons	Descriptions				
	Displays the strength of the signal received by the phone and current signal strength is indicated by the number of bars displayed on the screen.				
	No service. The phone is not receiving a system signal.				
	In use. A call is in progress. ∗ No icon indicates the phone is in standby mode.				
	Indicates that a Text Message or E-mail Message has been received.				
	Indicates speaker mode is on.		Indicates key guard is enabled.		
	In Vibrate mode.		In Alarm mode.		In Silent mode.
	Bluetooth is on.		SMS on Call Reject. (Only shown on incoming mode)		
	DUN Active is enable.		Bluetooth headset or handsfree is connected.		
	Bluetooth Visibility is on		Indicates a microSD memory card is present.		
	Indicates voice answering machine is activated.				Indicates there is MMS.
	Indicates voice mail has been received or there are recorded voice messages.				
	Indicates battery charge level. When fully charged, battery icon indicates charging by twinkling.				Indicates there are SMS and MMS

Press Soft Key 1 **Menu**. Press to scroll.

Names	Messages	Call History	Display	Mobile World
1. Add Name	1. Write	1. Missed	1. Language	1. R-Menu
2. Find	2. Inbox	2. Received	2. Service Area	2. Mobile TV
3. Groups	3. 1234 Services	3. Dialled	3. Clock & Shortcut	3. Play N Shop
4. Speed Dial	4. Outbox	4. In Call Memo	4. Time & Date	4. Dial 1234
5. Copy & Move	5. Voice Mail	5. Call Duration	5. Wallpaper	5. Write MMS
6. Erase Names	6. Archive in UIM	6. Erase History	6. Menu Style	6. MMS Inbox
7. My Profile	7. Drafts	7. Help	7. Colour Scheme	7. Reset R-Menu
8. Memory Info	8. Templates		8. Rhythmic Lighting	8. UIM Toolkit
9. Help	9. Msg Groups		9. Backlight	9. Games
	0. Erase Msgs		0. Help	0. Help
	*. Msg Settings			
	#. Help			

Press Soft Key 1 **Menu**. Press ⟨◇⟩ to scroll.

Profiles

1. Vibrate Only
2. Silent
3. General
4. Outdoor
5. Headset
6. Carkit
7. Help

Organ.&Tools

1. Bluetooth
2. Voice Tools
3. Schedule
4. Memo
5. Reserved Call
6. Alarm
7. Stopwatch
8. Calculator
9. Unit Converter
0. World Clock
*. Help

Multimedia

1. Camera
2. FM Radio
3. MP3
4. My Stuff

Settings

1. My Menu
2. Call
   - Call Forward
   - Call Waiting
   - Any Key Answer
   - Auto Redial
   - Voice Privacy
   - Clear Voice
   - Call Timer
   - Call Connect Alert
   - Edit SMS on Call Reject
   - Int'l Call Prefix
   - Help
3. Phone
   - Key Guard
   - Airplane Mode
   - Data Settings
   - Service Alert
   - Version
   - Help
4. Security
   - PIN Code Request
   - Lock Mode
   - Emergency Numbers
   - Change Code
   - Clear Memory
   - Reset Default
   - Help

Charge the battery fully before the initial use of the phone. The phone comes with a rechargeable battery. Keep the battery charged while not in use in order to maximize talk and standby time when using the phone.

Installing and Removing the Battery

- To install, insert the battery into the opening on the back of the phone, and insert the bottom of battery into groove at the bottom of the handset. Gently press down the cover until the latch snaps into place.
- To remove, push the back cover down. Push the tab with one hand and lift the top of the battery to separate.

Charging the Battery

To use the AC adapter charger provided with your phone :

1. Plug the AC adapter into the electrical outlet.
2. Insert the round end of the adapter into the AC adapter jack on the bottom of the phone. (Make sure the battery is installed.)

- As the phone charges, the battery icon continually displays a progression from empty ( ) to full ( ).

It takes about three hours to fully recharge a completely rundown battery. When fully charged, battery icon indicates charging by twinkling.

Battery Charge Level

The battery charge level is shown at the top right of the LCD screen.

When the battery charge level becomes low, the low battery sensor will alert you in three ways: sounding an audible tone, blinking the battery icon outline, and displaying low battery. Recharge soon. If the battery charge level becomes exceedingly low, the phone will automatically switch off and any function in progress will not be saved.

* The colors which are displayed at various stages of charging are different : Blue / Green / Yellow / Red.

Caring for the Battery

1) If you use the unauthorized battery, it may cause the damage to or explosion of the battery. Therefore, please prohibit using the unauthorized ones.
2) You do not need to wait until the battery completely runs down to recharge the battery.
3) Use only LG batteries and chargers specific to your model of phone. LG's chargers are designed to maximize battery life.
4) Do not disassemble or short-circuit the battery.
5) Keep the battery's metal contacts clean.
6) Replace the battery when it no longer provides acceptable performance. The battery can be recharged several hundred times before it needs replacing.
7) Recharge the battery if it has not been used for a long time to maximize battery life.
8) Do not expose the battery charger to direct sunlight or use it in areas of high humidity, such as the bathroom.
9) Do not leave the battery in hot or cold places as it may deteriorate battery performance.
10) Long backlight settings, searching for service, data connectivity, and synchronization all may affect battery life, talk, and standby times.

Turning the Phone On and Off

Turning the Phone On

1) Install a charged battery pack or connect the phone to an external power source such as the cigarette lighter charger, car kit or AC Adaptor.
2) Hold down the Key for 2 seconds until the LCD screen flashes.

Note As any other communication device, avoid any unnecessary contact with the antenna while your phone is turned on.

Turning the Phone Off

1) Press and hold until the display turns off.

Making a Call

Every time you make a call, follow these steps :

1) Make sure that the phone is turned on. If not, hold down for 2 seconds.
2) Type the phone number and then press .
   - If the phone is locked, type the lock code.
3) To end the call press .

Note In no service area, appears from the screen. When trying voice call in no service area, “Call could not be completed. Please try again” is displayed. It means you are in no service area.

Receiving Calls

1) When the phone rings or vibrate (if the Vibrate Mode is enabled), press any key (except) or depending on the Call settings.
   - When you press once, when a call is received, the phone stops ringing or vibrating depending on the mode it is in. Press twice to disconnect.
2) To end an answered call press .
3) If you are not in the condition to receive call, pressing Soft key 2 will disconnect the call and send a preset SMS to Caller. The SMS can be edited using "Edit SMS on Call Reject" function given under Settings.

Signal Strength

If you're inside a building, being near a window may give you better reception. You can see the strength of your signal by the signal indicator ( ) on your phone's display screen.

About the antenna

Your phone has a built-in antenna. As with any other radio transmitting device, do not touch the antenna unnecessarily when the phone is switched on. Contact with the antenna affects call quality and may cause the phone to operate at a higher power level than needed.
Not touching the antenna during a call optimizes the antenna performance and the talk-time of your phone.
Normal position: Hold the phone as you would any other telephone.

Quick Adjust

Adjusting Vibrate Mode

Use Vibrate Mode in a public place.

1) In standby mode, activate Vibrate Mode quickly by pressing the . (for 2 seconds) instead of using the Menu function.

- When Vibrate Mode is set, Key tone does not sound.

Note To cancel Vibrate Mode, press for 2 seconds.

Select Profiles

1) In standby mode, press .
2) Select one of four Profiles Vibrate Only, Silent, General and Outdoor with .
3) Press or Soft Key 1 **Set**.

Adjusting Speaker Mode On

During a call, to activate or cancel Speaker quickly, press .

1) In standby mode, activate Speaker Mode by pressing the for 2 seconds.

Note To cancel Speaker Mode On, press for 2 seconds.

In case speaker is activated on in standby mode, speaker mode is continued even after a call without respect to adjustment during a call.

Select My Menu

1) In standby mode, press C/Torch to select My Menu.
2) Select the item of choice with and then press or to select the required menu from My Menu under **Settings** menu.

   * To add items in My Menu add it from Setting Menu.

Keypad Lock

This function allows you to carry the phone safely without accidentally dialing a number.
When this function is enabled, no call can be made and the access to the Menu will be locked. While the keypad is locked, it is possible to answer a call normally.

To enable the function :

1) Press the key 0 next for 2 seconds.

To disable the function :

1) Press the key 0 next for 2 seconds.

Note After the set time in idle mode, Key Guard is automatically enabled.
When set as Key Guard before incoming call, lock is enabled after the call.

Call Waiting

Your cellular service may offer a call waiting function. While a call is in progress, you may hear two beeps indicating another incoming call. When call waiting is enabled, you may put the active call on hold while you answer the other incoming call. Check with your service provider for information about this function.

1) Press to receive a waiting call.
2) Press again to switch between calls.

Mute

The mute function prevents the other party from hearing your voice, but allows you to hear the other party.

1) Press Soft Key 1 Menu and 2 during a call.
2) To cancel Mute, press Soft Key 1 Menu and 2 again.

Redialing Calls

1) Press twice to redial the last number in Recent Calls.
   - You can also dial any of the last 120 (Missed + Received + Dialled) numbers stored in the Recent Calls. (See the Call History List on page 42~43)

Speed Dialing

Speed dialing is a convenient feature, which allows you to make phone calls quickly and easily. Your phone recalls the phone number from your personal directory, displays it briefly and then dials it.
Memory locations 1 through 9 should be used for one-touch dialing for your most frequently used phone numbers.

1) Enter memory location number 1 to 9.
2) Press .

Dialing Speed Dials from 10 to 99

Press the first digit and then press and hold the key of the last digit.
OR
Enter the first and second digits and press .

Caller ID

Caller ID lets you know who is calling by displaying the number of the person calling when your phone rings. If the caller's name and number are already stored in your phone book, the corresponding name appears with the number.
You should check with your service provider to ensure they offer this feature.

Entering Information Using T9 Text Input

You can edit the Banner, Scheduler, Text Message, Multimedia Message, E-Mail and Phone Book using T9 Text Input.
T9 Text is an easy way to write. In this input method, you only need to press a key once for each letter.

Key Functions

Soft Key 2 : Press to select mode.

- You can select the modes using Soft Key 2 : T9En, Abc, 123, Symbols, Smileys, T9Hin, Hindi
- Shift Key [*] : Used to change the letter case.

[2] ~ [9] (Type Text) : In T9 mode, press one key per letter to enter text.

[0] ~ [9] (Type Numbers) : In 123 (Numbers) mode, press once to enter numbers.

[0] (Next) : In T9En / T9Hin mode, press to display other matching words.

[1] (Punctuation) : In T9En / Abc mode, press to insert punctuation in a word and complete a sentence.

[#] (Space) : Press to complete a word or insert a space.

[C/Torch] (Clear) : Press to delete a single space or character. Press and hold to delete entire words.

Input mode

T9 Text Input provides Seven Modes for entering text, numbers, special characters, and punctuation.

T9En (T9) Mode

Type text using one keystroke per letter. The default is Abc mode.

Abc (Multi-tap) Mode

Use Abc mode to add words to the T9 database.

123 (Numbers) Mode

Type numbers using one keystroke per number.
To change to 123 mode in a text entry field, press Soft Key 2 until 123 mode is displayed.

Symbols/Smileys Mode

Insert special characters, punctuation, or smileys. You may use any of the special characters. When the cursor is located where you want the special character, switch to Symbols/Smileys mode. If you want to add a smiley, switch to the smileys mode. Press the Navigation Key to cycle through the desired characters : To select Character, Press the assigned number key.

T9Hin(T9) Mode

Type text using one keystroke per letter in Hindi with the help of T9 Hindi dictionary function.

Hindi(Multi-tap) Mode

Use Hindi mode to input text in Hindi language.

Initial Cap (T9En/Abc)

Only the first letter is capitalized.

Caps Lock (T9EN/ABC)

All subsequent letters are capitalized.

Lowercase (T9en/abc)

All subsequent letters are lowercase.

Examples Using T9 Text Input

Typing In T9 Mode

When you want to use T9 Mode, check that T9En is shown at the right bottom of the display. To write the desired word, press each key once for one letter. For example, to write “Call the office”, follow these steps :

1. Press Soft Key 2 to change letter case to T9En mode.
2. Press 2 2 5 5.
3. Press # to complete the word and add a space.
4. Press 8 4 3 # 6 3 3 4 2 3.
5. Display **Call the office**.

As you can see, the word changes after each key press. Therefore you don’t need to pay much attention to what happens on the display before you have keyed in the whole word.

Using the NEXT Key

After you have finished typing a word, if the word displayed is not the word you want, press [0 next] to display additional choices.
For example, follow these steps :

1. Press [4 ghi] [6 mno] [6 mno] [3 def].
2. Display **Good**.
3. Press [0 next].
4. Display **Home**, **Gone**, **Hood**.....

Examples Using Abc (Multi-tap) Text input

Typing In Abc (Multi-tap) Mode

For example, to type "LG", follow these steps:

1. Press Soft Key 2 to change letter case to Abc mode.
2. Press [* shift] to change to ABC Caps Lock mode.
3. Press [5 jkl] [5 jkl] [5 jkl] [4 ghi].
4. Display **LG**.

Adding Words to the T9 Database

If the word is not in the T9 database, add it by using Abc(Multi-tap) mode text entry. The word is automatically added to the T9 database when you return to T9 mode and press Space key.
For Example, follow these steps :

1. Press Soft Key 2 to change letter case to Abc (multi-tap) mode.
2. Press [4 ghi] [4 ghi] [4 ghi] [6 mno] [8 tuv].
3. Display **Imt**.
4. Press Soft Key 2 to change letter case to T9 mode and press [# space]. Now the word Imt has been added in the T9 Database.
5. Press [C/Torch] to erase the existing word.
6. Press [4 ghi] [6 mno] [8 tuv].
7. Display **Imt**.
8. Press [0 next] to see other matching words.

Key Mapping For Hindi Entry

In Hindi there are 13 vowels, 44 consonants, 15 matras

Characters in magenta are available only in Multitap mode.

The Keys are mapped as follows :

Key	Hindi Entry
0 next	0
1 @	ँ ं ः ् ़ 1
2 abc अ-ऊ	ा ि ी ु ू ृ अ आ इ ई उ ऊ ऋ 2
3 def ए-औ	े ै ॅ ो ौ ॉ ए ऐ ऍ ओ औ ऑ 3
4 ghi क-ङ	क ख ग घ ङ 4 क़ ख़ ग़
5 jkl च-ञ	च छ ज झ ञ 5 ज़
6 mno ट-ण	ट ठ ड ढ ण 6 ड़ ढ़
7 pqrs त-न	त थ द ध न 7 ऩ
8 tuv प-म	प फ ब भ म 8 फ़
9 wxyz य-ह	य र ल व श ष स ह 9 ळ ऱ ऴ य़

To Edit in Hindi Mode

Press Soft Key 2 and changes to Hindi mode.

Hindi mode Editing

Hindi is a Multi-tap mode.
For example, To type "हिन्दी "

1. Press 2 abc अ-ऊ 2 times.
2. Press 9 wxyz य-ह 8 times.
3. Press 7 pqrs त-न 5 times.
4. Press 1 4 times.
5. Press 7 pqrs त-न 3 times.
6. Press 2 abc अ-ऊ 3 times.

Examples Using T9Hin Text Input for Hindi

For example, To type "भारतीय"

1. Press Soft Key 2 to change letter case to T9Hin mode.
2. Press 8 tuv प-न 2 abc अ-ऊ 9 wxyz य-ह 7 pqrs त-न 2 abc अ-ऊ 9 wxyz य-ह.
3. Press # space to complete the word and add a space.
4. Display भारतीय.

Byte Allocation:

In messages : Every character in Hindi takes 3 bytes while it takes 9 bytes for "Ksha" , "Tra" , "Gya".
In all other modules : Every character in Hindi takes 1 byte while "Ksha" , "Tra" , "Gya" takes 3 bytes.

Entering Predicted Words

Sometimes T9 places in the selection list predicted words. Predicted words are words T9 thinks you may want to enter, based on text you've recently entered. Available in both T9 and Abc mode, predicted words are underlined.
If the predicted word you see isn't the one you want, press the next key to view additional predicted words. When you find the one you want, press the # space key to add a space and begin the next word.
If none of the predicted words in the selection list is the word you want, just keep entering letters. T9 will remove the predicted word for you automatically.

General Guidelines to Menu Access and Settings

1. Press Soft Key 1 **Menu**. Nine menu items will appear on the display screen.
2. Press to go through the list of menu features.
3. Press the corresponding number to the menu item that you want to select. Then the sub-menu list will appear on the screen.
4. Press the appropriate key to select the sub-menu you want to access.
5. Select preferred settings, using the . Press C/Torch to go one step backward while accessing menu or selecting settings.
6. Press to save the settings or C/Torch to cancel without saving.

Note key is equivalent to pressing Soft Key 1, in the case of Soft Key 1 is associated with "**Select**" option.

key is equivalent to pressing Soft Key + selecting first option of popup menu in the case of Soft Key 1 is associated with "**Options**" option.

1. Names

1.1 Add Name

You can store multiple contact details under a name: 4 contact numbers, 1 e-mail id. You can also add the name to a group, assign a ring tone for incoming call and message, may add any additional details in Memo. You can also insert and assign the different picture with contact name, calls etc. Total 2500 entries can be stored. UIM card has separate memory.

1. Press Soft Key 1 **Menu**.
2. Select 1 **Names**.
3. Select 1 **Add Name**.

- Select location '**Phone**' or '**UIM**' where you want to store.

4. Insert your desire items by pressing .
5. Press to save entry in your record.

Note
- Please contact your service provider for the memory of UIM card.
- Speed dial may not be assigned in UIM card.

1.2 Find

To find phone numbers you have stored in the Phone Book.

1. Press Soft Key 1 **Menu**.
2. Select 1 **Names**.
3. Select 2 **Find**.
4. You can entry by name or by number.
5. Type the starting letter of name or number. Screen will display your choice of entries.
6. Press to edit and Soft key 2 to send message to selected contact.
7. Press Soft key 1 for following options:

   Edit / Reserved Call / Send Contact / Copy to UIM / Move to UIM / Send via Bluetooth / Erase

1.3 Groups

This is a function for changing Group Name and setting Ring tones by Group.

1. Press Soft Key 1 **Menu**.
2. Select 1 **Names**.
3. Select 3 **Groups**.
4. Select your desired Group using .
5. Press Soft Key 1 **Options**.

   View Members : View the names of members saved in the Group.

   Set Ring Tone : Set the Group Ring Tone.

   Set Msg Tone : Set the Group Msg Tone.

   Press Soft Key 2 **Edit** : Edit the Group Name.

Note The title No Group cannot be changed.

1.4 Speed Dial

Speed Dial allows you to make a call faster by just pressing a corresponding number.

1. Press Soft Key 1 **Menu**.
2. Select 1 **Names**.
3. Select 4 ghi **Speed Dial**.
4. To register, use Soft Key 1 **Options** and select Assign to find information you want, then press Soft Key 1 **Assign**.

Note To delete, select press Soft Key 2 **Erase** and select Yes.
Press Soft Key 1 **Options** and select **Erase All** to delete all stored speed dials. Select Replace to change the number assigned to a particular location.
Speed dial is from 01 to 99.

1.5 Copy & Move

You can copy/move entries from UIM card memory to Phone memory.

1. Press Soft Key 1 **Menu**.
2. Select 1 **Names**.
3. Select 5 jkl **Copy & Move**.
4. Select **Phone -> UIM** or **UIM -> Phone** and press .

► UIM supports only one number in each contact. So, only default number will be copied in case of **Phone -> UIM**.

5. Select the option **Yes** or **No**.

► To Copy or Move the source file, select **Yes**.
Copy : Copy the source file.
Move : Delete the source file.

1.6 Erase Names

To erase all the entries stored in the Names.

1. Press Soft Key 1 **Menu**.
2. Select 1 **Names**.
3. Select 6 **Erase Names**.
4. Select the name of choice with .
5. Press , then press Soft Key 1 **Options** and select **Erase**.

1.7 My Profile

Allows you to save and view your phone number and contact information.

1. Press Soft Key 1 **Menu**.
2. Select 1 **Names**.
3. Select 7 **My Profile**.
4. Insert your desire items by pressing .
5. Press to save entry in your record.

1.8 Memory Info

Memory Info indicates quantity of phone book presently saved in the card and the phone. It is indicated as used quantity/available quantity.

1. Press Soft Key 1 **Menu**.
2. Select 1 **Names**.
3. Select 8 **Memory Info**.

1.9 Help

You can get more information about this menu.

2. Messages

Text message, page, E-mail and Voice Mailbox become available as soon as the power is on. You can access the above types of messages using the Message Key .
In addition, you can make a call to the call back number by pressing during a message check.

The phone can store up to 31 messages (1 voice message : 30 text messages) with 160 byte per message. Every letter in Hindi is taken as 3 characters (However, ksha, tra, gya accounts for 9 characters each.) So, an SMS message in Hindi can have up to 46 characters only.

Users may read and edit messages, saved in the Outbox during transmission and send them. However you should check whether your service provider provides the above features.

Phone can store SMS messages each in Inbox(30), Outbox(15 Sent / 15 Unsent), Archive(30), Drafts(30) and Templates(10 fixed / 20 editable).
OR Total 120 messages and 1 Voice Mail.
SMS supports 160 characters(160 in English / about 46 in Hindi). E-Mail subject supports 20 and message supports 140 characters.
E-Mail is consist of subject + E-Mail address + E-Mail message. E-Mail subject supports up to 20 and E-Mail address supports up to 50.
So, message characters is calculated by 160 - subject character - E-Mail address character.

MMS (Multimedia Message Service)

The phone can store up to 30 MMS / 50 notifications in MMS Inbox, total 50 (Sent / Unsent) in MMS Outbox and 20 in MMS Drafts. 11 fixed / 4 editable Templates available for fast MMS writing. LG-RD6250 MMS supports up to 1000 characters in English / 333 characters in Hindi. 1 Picture and 1 Sound / 1 Movie can be attached in each MMS up to 300 kbytes size. The information that is stored in the message is determined by phone mode and service capability. You can check types of messages by pressing the Message( ) key .

2.1 Write

LMS(Long Message Service) allows you to send a message up to 462 characters at a time. Before sending LMS message, total number of sms packets formed are intimated to the user and confirmation is taken to send.
Maximum 3 packets for English and 4 for Hindi messages can be sent. Each LMS packet is received as individual message. Every LMS message shows the packet sequence number in the message for ex: In case of 3 packets, <1/3> <2/3> <3/3>.

2.1.1 Write Text

Text messages and page messages are all available.
Text messages : Transmits text.
Page messages : Only numbers without text messages.
Press **Send** in **Options** to send the message.
To send a message enter the destination mobile number in the Send To screen.

There are five optional menus of Send, Templates, Save, Add Signature and Insert Number.

1. Press Soft Key 1 **Menu**, 2 or .
2. Select 1 **Write**.
3. Select 1 **Write Text**.
4. After entering a message to be sent by selecting Send, press Soft Key 1 **Options**.

▶ **Send**	Use to send the message.
▶ **Templates**	Select a Templates message.
▶ **Save**	Save to Drafts message.
▶ **Add Signature**	You can add signature.
▶ **Insert Number**	Insert phone number from your phonbook to send via SMS.

5. After entering the phone number where the message is to be sent, enter the next recipients address by pressing . You can add up to 10 recipients. Press Soft Key 1 **Options**.

▶ **Send**	Use to send the message.
▶ **The Last**	Select a recent sent number.
▶ **SMS Groups**	Select SMS Group.
▶ **Find Names**	Select a phonebook entry.

6. If you select Send, it notifies you whether the message was sent successfully.

▶ **Send**	Use to send the message.
▶ **Priority**	Allows you to give the priority to message. Normal or Urgent.

▶ **Delivery Ack** This function allows you to know whether the message is successfully transmitted to other party or not when the transmitted message is received in other party's phone. If you want to activate this function, set to On.

▶ **Deferred** Allows you to delay sending the message until the programmed time frame. Immediate/After 30 Minutes/ After 1 Hour/After 2 Hours/After 12 Hours/After 1 Day/After 2 Days

▶ **Validity** Indicates the validity of message delivery to the Short Message Center (SMC) without being transmitted to the destination address for certain periods of time. Those messages will be deleted within the programmed time frame. Validity time frames are as follows: Default, 30 Minutes, 1 Hour, 2 Hours, 12 Hours, 1 Day and 2 Days.

▶ **Save Sent Msg** You can save this message in Outbox.

2.1.2 Write E-mail

Send SMS to E-mail ID.

1. Press Soft Key 1 **Menu**, 2 or .
2. Select 1 **Write**.
3. Select 2 **Write E-mail**.

   There are four optional menus of Send, Last, E-mail Groups and Names.

   ▶ **Send** Use to send the message.
   ▶ **The Last** Select a recent sent E-mail.
   ▶ **E-mail Groups** Select a E-mail Group.
   ▶ **Find Names** Select a phonebook entry.

4. After entering the e-mail address where the message is to be sent, enter the next recipients address by pressing . You can add up to 10 recipients. Press Soft Key 1 **Options**.

   ▶ **Send** Use to send the message.
   ▶ **Domains** Select a domain.

5. After entering a Subject, press Soft Key 1 **Next**.

6. After entering a message to be sent by selecting Send, press Soft Key 1 **Options**.

- ▶ **Send** Use to send the message.
- ▶ **Templates** Select a Templates message.
- ▶ **Save** Save to Drafts message.
- ▶ **Priority** Allows you to give the priority to message. Normal or Urgent.
- ▶ **Delivery Ack** This function allows you to know whether the message is successfully transmitted to other party or not when the transmitted message is received in other party's phone. If you want to activate this function, set to On.
- ▶ **Deferred** Allows you to delay sending the message until the programmed time frame. Immediate/After 30 Minutes/After 1 Hour/After 2 Hours/After 12 Hours/After 1 Day/After 2 Days
- ▶ **Validity** Indicates the validity of message delivery to the Short Message Center (SMC) without being transmitted to the destination address for certain periods of time. Those messages will be deleted within the programmed time frame. Validity time frames are as follows: Default, 30 Minutes, 1 Hour, 2 Hours, 12 Hours, 1 Day and 2 Days.
- ▶ **Save Sent Msg** You can save this message in Outbox.
- ▶ **Add Signature** You can add signature.
- ▶ **Insert Number** Insert your phone number.

2.1.3 Write Multimedia Msg

- You can insert image and sound for 1 Movie with your message.
- Send to E-mail ID and Phone Number.
- Each message supports up to 1000 characters, 1 image and 1 sound.

Menu

There are eight optional menus of Send, Insert Img/Mov, Insert Sound, Templates, Preview, Save, Remove Img/Mov, Remove Sound.

1. Press Soft Key 1 **Menu**, 2 or .
2. Select 1 **Write**.
3. Select 3 **Write Multimedia Msg**.
4. After entering a message to be sent by selecting Send, press Soft Key 1 **Options**.

▶ **Send**	Use to send the message.
▶ **Insert Img/Mov**	Insert image to editing multimedia msg.
▶ **Insert Sound**	Insert sound to editing multimedia msg.
▶ **Insert Number**	Insert your number to message.
▶ **Templates**	Select a Templates message.
▶ **Preview**	Preview edited multimedia msg.
▶ **Save**	Save to Drafts msg.
▶ **Remove Img/Mov**	Remove image from editing multimedia msg.
▶ **Remove Sound**	Remove sound from editing multimedia msg.

There are four optional menus of Last, Name, Number, MMS Groups.

▶ **Send**	Use to send the message.
▶ **The Last**	Select a recent sent Number/ E-mail.
▶ **Find Names**	Find name from your number entry.
▶ **MMS Groups**	Select a MMS group.

5. After entering the e-mail or phone number where the message is to be sent, enter the next recipients address by pressing . You can add up to 10 recipients. Press Soft Key 1 **Options**.

▶ **Send**	Use to send the message.
▶ **Domains**	Select a domain.
▶ **Save Sent MMS**	Select option whether save or not save sent msg.

6. If you select Send, it notifies you whether the message was sent successfully.

2.1.4 SMS Chat

SMS Chat enhances you text message experience. It generally uses a normal text message. However, each separated chat message is displayed in the same screen like MSN Messenger. During a chat, each received and sent message does not saved in inbox and outbox. However, the whole contents of the last chat is saved for your convenience.

1. Press Soft Key 1 **Menu**, 2 or .
2. Select 1 **Write**.
3. Select 4 **SMS Chat**.
4. Insert mobile number of other party and your chat name and press .
5. Type your message and press to communicate.
6. Press Soft key 1 **Option**:

- ▶ **Send** Send the Chat message.
- ▶ **Template** Select message from preloaded template.
- ▶ **Change Chat Name** Change your chat name.
- ▶ **Change Receiver** Change contact number of receiver.
- ▶ **Single/Two Line Edit** Select editing mode from Single and Two.
- ▶ **Scroll Mode** Select scroll mode.
- ▶ **Exit** Exit from SMS Chat.

2.2 Inbox

Received Text messages, Page, E-mail messages, Delivery ack, lists may be searched, and the contents may be viewed. Received messages are sorted in an order of unread messages and read messages. Up to 30 message can be stored.
The phone can store up to Max. 80 MMS(for example, 50 notification messages and 30 MMS).

To view the list of the received messages.

2.2.1 SMS Inbox

1. Press Soft Key 1 **Menu**, 2 or .
2. Select 2 **Inbox**.
3. Select 1 **SMS Inbox**.
   - ▶ Messages are saved in order of Unread/Read. For example, if a New message is read it goes into Read messages.

: Unread SMS : Unread E-mail

: Read SMS : Read E-mail

4. After selecting the desired message with ; press or Soft Key 1 **Options** and select View.
   - ▶ **View** You can read the selected message.
   - ▶ **Erase** Delete the selected message from the SMS Inbox.
5. After viewing the message press Soft Key 1 **Options** or Soft Key 2 **Reply**.
   - ▶ **Reply** This function allows you to reply to this message.
   - ▶ **Erase** Deletes the selected message from the SMS Inbox.
   - ▶ **SMS Chat** Allows you to chat with others.
   - ▶ **Forward** Forwards a received message to others. After recipients are entered, the messages can be forwarded.
   - ▶ **To Archive** Moves the selected message from the SMS Inbox to the Archive.
   - ▶ **Save Address** Stores the sender's number or E-mail address or Other numbers included in the received message into your phone book. When received number information is displayed, the user can store the number in the corresponding number list in the phone book.
   - ▶ **Reserved Call** Set the reserved call.
   - ▶ **Reply w Copy** Allows you to reply with received message.
   - ▶ **Add to Template** Allows you to save the received message by adding to template.

2.2.2 MMS Inbox

1. Press Soft Key 1 **Menu**, 2 or .
2. Select 2 **Inbox**.
3. Select 2 **MMS Inbox**.
4. After selecting the desired message with ; press or Soft Key 1 **Options** and select **View**.
   - ▶ **View** You can read the selected message.
   - ▶ **Erase** Delete the selected message from the MMS Inbox.

   or **Connect** or **Reply** with Soft Key 2.
   - ▶ **Connect** Connect the selected message.

► **Reply** This function allows you to reply to this message.

5. After viewing the message press Soft Key 1 **Connect** to download message.

2.3 1234 Services

Exciting SMS-based Infotainment services such as News, Jokes, Horoscope, etc. are available to Reliance subscribers. Using the SMS 1234 Services, the user will be able to access interesting information on common subjects through SMS. User needs to select the Menu corresponding to the Service Keyword.

1. Press Soft Key 1 **Menu**, 2 or .
2. Select, 3 **1234 Services**.
3. Place the cursor on the item that you wants to be served, and then press Soft key 1 **Select**. You may select from 11 items. (1.News 2. Cricket 3.Joke of The Day 4.Thought of The Day 5.Contest 6. Beauty Tips 7.Health 8.Horoscope 9.Bill Info 0.Unbilled Info ∗.Help) You may select the keyword that you want to send in subsequent-Menu.

Example

For example, to receive the "sports news" you can operate the phone as follow;

1. Press Menu +2(Messages) + 3(1234 Services) + 1(News) + 6(NEWS SPORTS)

Display : Sending.. To : 1234

2.4 Outbox

Up to 15 sent messages and 15 unsent messages can be stored in the Outbox. Max. 50 (sent + unsent) MMS can be saved in the Outbox. Users may view lists and contents of sent messages or unsent messages in this menu. To save a message in Outbox “Save Sent Messages” should be selected in “Msg Settings”.

2.4.1 SMS Outbox

1. Press Soft Key 1 **Menu**, 2 or .
2. Select 4 **Outbox**.
3. Select 1 **SMS Outbox**.
4. Select 1 **Sent** or 2 **Unsent**.
5. After selecting the desired message with ; press Soft Key 1 **Options** and select **View** / **Erase**.

Press Soft Key 2 **Forward** or **Resend**.

▶ **View**	Shows the message currently saved. The view menu has two sub-menus Forward and Erase.
▶ **Erase**	Delete a selected message in the SMS Outbox.
▶ **Forward**	You can modify the message you've got. Then follow the process for Write.
▶ **Resend**	Use to resend the message.

2.4.2 MMS Outbox

1. Press Soft Key 1 **Menu**, 2 or .
2. Select 4 **Outbox**.
3. Select 2 **MMS Outbox**.
4. Select 1 **Sent** or 2 **Unsent**.
5. After selecting the desired message with ; press Soft Key 1 **Options** and select **View / Forward / Lock(Unlock) / Erase** . Press Soft Key 2 **Resend**.

▶ **View**	Shows the message currently saved. The view menu has two sub-menus Forward and Erase.
▶ **Forward**	You can modify the message you've got. Then follow the process for Write (see page 32).
▶ **Lock/Unlock**	Allows you not to delete message automatically.
▶ **Erase**	Delete a selected message in the MMS Outbox.

2.5 Voice Mail

Allows you to view the new voice messages recorded in the voice mail box. Once you exceed the storage limit, the old messages will be overwritten. When you have a new voice message your phone will alert you.

1. Press Soft Key 1 **Menu**, 2 or .
2. Select 5 **Voice Mail**.

▶ To delete information press Soft Key 2 **Erase**.
To listen information press Soft Key 1 **Listen**.

While you are answering a call, if you have a new message, the sender's number will be displayed on the screen.

2.6 Archive in UIM

Archive allows you to store your messages in a different folder in the UIM card. Storage capacity depends on your UIM card.

1. Press Soft Key 1 **Menu**, 2 or .
2. Select 6 **Archive in UIM**.
3. After selecting the desired message with , press Soft Key 1 **Options** and select **View** / **Erase**. Press Soft Key 2 **Reply**.

▶ **View**	There are three sub-menus Erase, Reply and Save Address.
▶ **Erase**	Delete a selected message.
▶ **Reply**	This function allows you to reply to this message.

4. After viewing message, press Soft Key 1 **Options**:

Inbox	(Erase / Forward / Reply W Copy / To Inbox / Save Address) Press Soft Key 1 **Reply**.
Sent	(Forward / To Outbox) Press Soft Key 1 **Erase**.
Unsent	(Erase / Forward / To Outbox) Press Soft Key 1 **Resend**.

Note Options may be different for Inbox, Sent or Unsent.

Inbox : Options are (View / Erase) and with Soft Key 2 **Reply**.

Sent : Options are (View / Erase) and with Soft Key 2 **Forward**.

Unsent : Options are (View / Forward / Erase) and with Soft Key 2 **Resend**.

2.7 Drafts

The text message is saved in Drafts. A total of up to 30 messages can be saved in Drafts. And 20 MMS can be saved in Drafts. When a user is interrupted by a call while composing a message, messages automatically get saved. If you press during writing messages, pop up window (to save or not) is displayed.

2.7.1 SMS Drafts

1. Press Soft Key 1 **Menu**, 2 or .
2. Select 7 **Drafts**.
3. Select 1 **SMS Drafts**.

4. After selecting the desired message with ◆, press Soft Key 1 **View** or press Soft Key 2 **Erase**.
   - ▶ **View** You can view the selected message.
   - ▶ **Erase** Delete a selected message.

2.7.2 MMS Drafts

1. Press Soft Key 1 **Menu**, 2 or ◆.
2. Select 7 **Drafts**.
3. Select 2 **MMS Drafts**.
4. After selecting the desired message with ◆, press Soft Key 1 **Options** or press Soft Key 2 **Erase**.
   - ▶ **View** You can view the selected message.
   - ▶ **Erase** Delete a selected message.
   - ▶ **Lock/Unlock** Allows you not to delete messages automatically.

2.8 Templates

2.8.1 SMS Templates

There are 10 predefined phrases included in the Templates. You can add up 20 templates more. A total of 30 templates can be saved.

1. Press Soft Key 1 **Menu**, 2 or ◆.
2. Select 8 **Templates**.
3. Select 1 **SMS Templates**.
4. After selecting the desired message with ◆ and press ● or Soft Key 1 **View**. Then follow the process for Write (see page 29).

   Press Soft Key 2 **Add** to add new template message to the Templates list.

Note For user defined new templates, options are follows:
View / Erase
After viewing template, press Soft Key 1 **Options**:
Send / Save / Erase

2.8.2 MMS Templates

There are 11 predefined phrases included in the Templates. You can add up 4 templates more. A total of 15 templates can be saved.

1. Press Soft Key 1 **Menu**, 2 or .
2. Select 8 **Templates**.
3. Select 2 **MMS Templates**.
4. After selecting the desired message with and press or Soft Key 1 **View**. Then follow the process for Write (see page 32).
   Press Soft Key 2 **Add** to add new template message to the Templates list.

2.9 Msg Groups

Msg Groups consists of 5 SMS/E-mail/MMS Groups with each group consisting of maximum 10 members. After selecting group and moving input display, send a message to the phone number of the selected group member.

1. Press Soft Key 1 **Menu**, 2 or .
2. Select 9 **Msg Groups**.
3. Select 1 **SMS Groups**, 2 **E-mail Groups** or 3 **MMS Groups**.
4. After selecting the desired group with , press Soft Key 1 **Options**.

▶ **View**	Display the selected group's member list. You may add new member.
▶ **Rename**	Rename the group's title.
▶ **Clear Group**	Clear the selected group's member.
▶ **Clear All**	Clear all 5 group's member.

Note To register contact entry in E-mail group, saving e-mail address to contact entry is necessary.

Note Selecting option in View's group member list.

▶ **Send**	Moves to message input screen and send a message to the selected group member.
▶ **Send to All**	Moves to message input screen and send a message to the selected group.
▶ **Replace**	Replace the selected group member.
▶ **Remove Member**	Remove the selected group member.
▶ **Clear Group**	Clear the selected group's member.

2.0 Erase Msgs

Allows you to erase messages in each message box.

1. Press Soft Key 1 **Menu**, 2 or .
2. Select 0 **Erase Msgs**.
3. Select the item of choice with then press .
   - ▶ **Erase SMS** : Inbox / Outbox / Archive in UIM / Drafts / All Messages
   - ▶ **Erase MMS** : Inbox / Outbox / Drafts / All MMS

Note Inbox options (SMS inbox: Read / All / Delivery Ack MMS inbox: Read Msg / Read Noti / All)

4. Select **Yes** / **No** with , then press .

2.* Msg Settings

Allows you to configure settings for messages.

2.*.1 Text/E-mail Msg Settings

1. Press Soft Key 1 **Menu**, 2 or .
2. Select * **Msg Settings**.
3. Select 1 **Text/E-mail Msg Settings**.

2.*.1.1 Priority

When sending a message, select Normal or Urgent.

2.*.1.2 Delivery Ack

Allows you to select delivery acknowledgement with your messages.

2.*.1.3 Deferred Delivery

Allows you to delay sending the message until the programmed time frame.

2.*.1.4 Validity Period

Indicates the validity of message delivery to the Short Message Center (SMC) without being transmitted to the destination address for certain periods of time.

2.*.1.5 Save Sent Message

With this feature on, messages are automatically saved in the Outbox when transmitted.

2.*.1.6 Archive Lock

When access Archive, enter your lock code.

2.*1.7 Auto Scroll

Allows you to scroll through menus at 2-second intervals.

2.*.2 Multimedia Msg Settings

1. Press Soft Key 1 **Menu**, 2 or .
2. Select * **Msg Settings**.
3. Select 2 **Multimedia Msg Settings**.

2.*.2.1 Delivery Ack

Allows you to select delivery acknowledgement with your messages.

2.*.2.2 Save Sent MMS

With this feature on, messages are automatically saved in the Outbox when transmitted.

2.*.2.3 MMS Auto Download

Allows you to receive MMS automatically.

2.*.3 General Settings

1. Press Soft Key 1 **Menu**, 2 or .
2. Select * **Msg Settings**.
3. Select 3 **General Settings**.

2.*.3.1 Auto Erase Inbox

With this feature on, old messages are automatically deleted when you exceed storage limit.

2.*.3.2 Signature

With this feature custom, add signature to editor when editing is start.

2.*.4 Sent Counter

Allows you to view count of sent Text message, E-mail and MMS.

2.# Help

You can get more information about this menu.

3. Call History

Allows you to view the 120 most recent phone calls. Once you exceed the (total) 120-number storage limit, the oldest Call History record is overwritten. These calls are divided into 4 types of calls.

Note You can view Call History in two ways.

- The key in idle mode, up to 120 most recent calls including Missed, Received and Dialled are displayed.
- In Call History menu, total 120 numbers are listed under Missed, Dialled, and Received.
- Maximum 20 numbers can be saved in In Call Memo.

Making a Call from Call History

1. From the Call History menu, select Missed, Received, Dialled or In Call Memo and press Soft Key 1 **Select**.
2. Place a call by selecting the desired entry and press to connect.

3.1 Missed

Allows you to view list of all Missed Calls. Maximum 120 (Missed + Received + Dialled) numbers are possible.

1. Press Soft Key 1 **Menu**, 3, 1.
2. Press Soft Key 1 **Options**. View / Edit Number / Save / Reserved Call / Erase appears on the screen. Press Soft Key 2 **Message** to send a message.
3. You may place a call by pressing .

3.2 Received

Allows you to view list of all Received Calls. Maximum 120 (Missed + Received + Dialled) numbers are possible.

1. Press Soft Key 1 **Menu**, 3, 2.
2. Press Soft Key 1 **Options**. View / Edit Number / Save / Reserved Call / Erase appears on the screen. Press Soft Key 2 **Message** to send a message.
3. You may place a call by pressing .

3.3 Dialled

Allows you to view list of all Dialled Calls. Maximum 120 (Missed + Received + Dialled) numbers are possible.

1. Press Soft Key 1 **Menu**, 3, 3.

2. Press Soft Key 1 **Options**. View / Edit Number / Save / Reserved Call / Erase appears on the screen. Press Soft Key 2 **Message** to send a message.
3. You may place a call by pressing .

3.4 In Call Memo

Save the phone numbers taken while talking and can view the list of numbers present in In Call Memo. Maximum 20 numbers are possible.

1. Press Soft Key 1 **Menu**, 3 def tz-sh, 4 ghi sz-sz.
2. Press Soft Key 1 **Options**. View / Save / Erase / Erase All appears on the screen. Press Soft Key 2 **Message** to send a message.
3. You may place a call by pressing .

3.5 Call Duration

1. Press Soft Key 1 **Menu**, 3 def tz-sh, 5 jkl tz-sz.

3.5.1. Last Dialled Call

It will store information about the last dialled call and will also display the last dialled number.

3.5.2. All Dialled Calls

Displays total number of dialled calls and total dialled calls duration.

3.5.3. All Calls

Keeps a running count of the time spent making all calls, dialled and received.

3.5.4. Reset Call Duration

To reset the counter, select **Yes** using and then Soft Key 1 **Select**.

3.6 Erase History

1. Press Soft Key 1 **Menu**, 3 def tz-sh, 6 mno tz-sz.
2. Select the item which it will erase with .
3. Press Soft Key 1 **Select**.
4. Select **Yes** using and then Soft Key 1 **Select**.

3.7 Help

You can get more information about this menu.

4. Display

Lets you personalize your phone's display by selecting different graphics.

4.1 Language

Set the Bilingual feature according to your preference, choose between English and हिन्दी .

1. Press Soft Key 1 **Menu**, 4, 1.
2. Set English / हिन्दी with and then press Soft Key 1 **Select**.

4.2 Service Area

This menu displays the current SDCA/calling area the user is in.

1. Press Soft Key 1 **Menu**, 4, 2.

4.3 Clock & Shortcut

Allows you to select a clock on your mobile phone display.

1. Press Soft Key 1 **Menu**, 4, 3.
2. Select the item of your choice by using , then press Soft key 1 **Select**.

4.4 Time & Date

Allows you to choose the kind of Time and Date to be displayed on the LCD screen.

1. Press Soft Key 1 **Menu**, 4, 4.
2. Select the item of your choice by using , then press Soft key 1 **Select**.

4.5 Wallpaper

Enter the string of characters you want to be displayed. You can set up the screen displayed on the LCD screen in the standby mode.

1. Press Soft Key 1 **Menu**, 4, 5.

4.5.1 Theme

You can set up the screen displayed on the LCD screen in the standby mode.

► Select the item of your choice by using , then press Soft key 1 **Select**.

4.5.2 Get Themes

Allows you to download theme files through Mobile World. Access to Reliance Mobile World and select the desired file.

4.5.3 Profile

Current profile is saved as wallpaper.

▶ Select **Show** or **Hide** and press Soft Key 1 **Select**.

4.5.4 Banner

Enter the string of characters you want to be displayed. (up to 13 characters.)

▶ Enter a Banner name and then press Soft Key 1 **Save**

4.6 Menu Style

Allows you to select the menu style.

1. Press Soft Key 1 **Menu**, 4 ghi, 6 mno.
2. Select **Icon** or **List** with ⬍ and then press Soft Key 1 **Select**.

4.7 Colour Scheme

Allows you to select the colour scheme.

1. Press Soft Key 1 **Menu**, 4 ghi, 7 pqrs.
2. Select **Violet**, **Blue**, **Olive**, **Pink** with ⬍ and then press Soft Key 1 **Select**.

4.8 Rhythmic Lighting

Choose the setting of the rhythmic lighting for an incoming call.

1. Press Soft Key 1 **Menu**, 4 ghi, 8 tuv.
2. Select **On** or **Off** and press Soft Key 1 **Select**.

4.9 Backlight

Choose the settings of the LCD and keypad backlight.

1. Press Soft Key 1 **Menu**, 4 ghi, 9 wxyz.
2. Choose an options and press Soft Key 1 **Select**.
   - ▶ **For 1 min** Backlight will be On for 1 min, after that goes in dimming for 20 secs and then completely turns off till the user presses any key to make Backlight On.
   - ▶ **For 30 secs** Backlight will be On for 30 secs , after that goes in dimming for 20 secs and then completely turns off till the user presses any key to make Backlight On.
   - ▶ **For 20 secs** Backlight will be On for 20 secs, after that goes in dimming for 20 secs and then completely turns off till the user presses any key to make Backlight On.

- **For 10 secs** Backlight will be On for 10 sec, after that goes in dimming for 20 secs and then completely turns off till the user presses any key to make Backlight On.
- **Always off** Backlight turns off and be dimming within 20 secs.

4.0 Help

You can get more information about this menu.

5. Mobile World

For quick access, press left navigation key in idle mode.

5.1 R-Menu

This connects you to Mobile World Data Services like Ringtones, Cricket, Dating, Contests, News, Astro, City & TV Guides, and more provided by your service provider. 99 downloadable 72 Poly Ringtones through Mobile World.

1. Press Soft Key 1 **Menu**, 5 jkl, 1.

5.2 Mobile TV

Use your Reliance Mobile phone to watch TV. Keep in touch with “breaking news” as they comes up on India’s 24-hour news channels, even when you are miles away from the nearest TV set.

1. Press Soft Key 1 **Menu**, 5 jkl, 2 abc.
   or
   Press key for 2 seconds.
2. Reliance Mobile World logo will be displayed followed by Reliance Mobile World Data Services Menu.

3. Scroll through the menu using and launch any Data Service by clicking on Soft Key 1 **Select**.

4. To exit from Data Services any time, hold down for a few seconds.

5.3 Play N Shop

Hear the phone talk to you! Play and save Ringtones that suit your personality and taste. You can download, save and replay the tunes. It also offers Voice Ringtones where you can listen to the Voice tunes in Hindi, English and also in regional dialects like Telegu, Malayalam, Kannada, Gujarati.

1. Press Soft Key 1 **Menu**, 5 jkl, 3 def.
   or
   Press key for 2 seconds.

2. Reliance Mobile World logo will be displayed followed by Reliance Mobile World Data Services Menu.

3. Scroll through the menu using and launch any Data Service by clicking on Soft Key 1 **Select**.

4. To exit from Data Services any time, hold down for a few seconds.

Note All Data Services may not be available to every subscriber. Please contact your service provider for further information.

5.4 Dial 1234

Dial 1234 to listen to Reliance Mobile World and simply ask for what you want, loud and clear. The Service will help you with your selection. It will understand your Command (e. g., 'Play a song'), be it in any accent and even in noisy surroundings, and give you the desired Service.

1. Press Soft Key 1 **Menu**, 5 jkl, 4 ghi.

   ► Please contact to your service provider for the charges of this service.

   ► Contents of this service may be changed time to time depends on service provider.

5.5 Write MMS

(Refer to 32 page)

1. Press Soft Key 1 **Menu**, 5 jkl, 5 jkl.

5.6 MMS Inbox

(Refer to 35 page)

1. Press Soft Key 1 **Menu**, 5 jkl, 6 mno.

5.7 Reset R-Menu

You can reset R-Media. When activated, downloaded VOD is reset.

1. Press Soft Key 1 **Menu**, 5 jkl, 7 pqrs.

5.8 UIM Toolkit

Allows you to customize UIM toolkit.

1. Press Soft Key 1 **Menu**, 5 jkl, 8 tuv.

5.9 Games

1. Press Soft Key 1 **Menu**, 5 jkl, 9 wxyz.
2. Select **Cricket** / **Marine Commando** / **Atomic Crusher** with then press .

5.0 Help

You can get more information about this menu.

6. Profiles

Profiles let you set your phone's sound settings to your environment. Each profile contains settings for your phone's Ring Type, Ring Tone, Ringer Volume, Earpiece Volume, Key Volume and Message Alert. Just pick the profile that suits your current environment: Vibrate Only, Silent, General or Outdoor. You can modify the settings in each profile, and (except for the Vibrate Only Profile) you can rename them (except for the Vibrate Only, Headset and Carkit Profiles).

Select Profiles

1. Press Soft Key 1 **Menu**, 6 mno or quickly press .
2. Select one of four Profiles Vibrate Only, Silent, General and Outdoor with .
3. Press or Soft Key 1 **Options** and then select **Set**.

Note Headset or Carkit Profile is automatically set when headset or carkit is installed in the mobile phone.

Note In standby mode, press long [*] to select Vibrate Only Profile. Press long [*] once again to return to the previous Profile.

Rename Profiles

1. Press Soft Key 1 **Menu**, [6].
2. Select Silent, General or Outdoor by using [◆].
3. Then press Soft Key 1 **Options** and then select **Rename**.
4. Enter a name for the Profiles (up to 13 characters).
5. Then press Soft Key 1 **Save** or [●].

Note You cannot rename the Vibrate Only, Headset and Carkit profiles.

Customize Profiles

You can customize any of the Profiles except Vibrate Only.

1. Press Soft Key 1 **Menu**, [6].
2. Scroll to the profile you wish to customize and press Soft Key 2 **Edit**.
3. Use [◆] to highlight one of the settings and press [●] to select it.
   - **Ring Type** - Ring, Vibrate, Vibrate & Ring, Ring After Vibrate, Ascending, One Beep, Silent, Light
   - **Ring Tone** - Default, Downloaded, MP3, Voice Records
   - **Get Ringtones** - 100 Reliance Mobile World downloadable.
   - **Key Tone** - (Beep, Piano, Xylophone)
   - **Ringer Volume** - Mute, 1~7 level
   - **Earpiece Volume** - 1~7 level
   - **Key Volume** - Mute, 1~7 level
   - **Message Alert** - Alert Type, Alert Tone, Message Reminder, Alert Volume
   - **Auto Answer** - Off, After 5 secs, After 10 secs

Note

- When Ring Type is Vibrate, Silent and Light, Ringer Volume can not be adjustable. 'Change Ring type' is displayed. After changing current type to Ring Type, adjust Ringer Volume.
- When press Soft Key 2 **Edit** in Headset and Carkit Profiles, Auto Answer is displayed additionally. Select Off, After 5 secs or After 10 secs by using .
- You cannot customize the Vibrate Only Profiles.
- You are alerted in 3 ways when you received a new message.
  – By displaying a message on the screen.
  – By sounding a beep, ring or vibration.
  – By flashing of Backlight just once.
- During a Call if the message comes Two Beeps will be heard irrespective of the Message Alert type selection.

6.7 Help

You can get more information about this menu.

7. Organ.&Tools

7.1 Bluetooth

The RD6250 is compatible with devices that support the Bluetooth® headset (HSP), hands-free (HFP), serial port (SPP), dial-up networking (DUN), object push (OPP) for Vcard, Vcalendar, Vnote, JPG, MP3 and MP4. FTP profile functions only for server. You may create and store 12 pairings within the RD6250 and connect to one device at a time. The approximate communication range for Bluetooth® wireless technology is up to 30 feet (10 meters).

Note Read the user guide of each Bluetooth® accessory that you are trying to pair with your phone because the instructions may be different.
When downloading over resolution 1280 x 960 image through Bluetooth®, the image is not displayed on the phone.
Your phone is based on the Bluetooth® specification, but it is not guaranteed to work with all devices enabled with Bluetooth® wireless technology. Phone does not support ALL Bluetooth® OBEX Profiles.
When using Carkit, Bluetooth is not available. To activate Bluetooth activity On, remove carkit from the phone.

7.1.1 Bluetooth Active

Allows you to phone's Bluetooth® power Enable/Disable.

1. Press Soft Key 1 **Menu**, 7, 1, 1.
2. Select **Enable** / **Disable** by using then press .

Note By default, your phone's Bluetooth® functionality is turned off.

7.1.2 Paired Devices

Pairing is the process that allows the handset to locate, establish, and register 1-to-1 connection with the target device.

For pairing new Bluetooth® device

1. Follow the Bluetooth® accessory instructions to set the device to pairing mode.
2. Press Soft Key 1 **Menu**, 7, 1, 2.
   Set the desired device to pairing.
   Press Soft Key 2 **Search**.
3. If Bluetooth® power is set to off, you will be prompted to turn power on. Select 1 **Yes** and press .
4. The device will appear in Searched Devices menu once it has been located. Highlight the device and press .
5. The handset will prompt you for the passcode. When paired, move to Paired Devices. Consult the Bluetooth® accessory instructions for the appropriate passcode (typically “0000” - 4 zeroes). Enter the passcode and press .
6. Press Soft Key 1 **Options** and select 1 **Connect**. (Bluetooth Headset or Bluetooth Handsfree are available to connect.)
7. Once connected, you will see the device listed in the Paired Devices menu and the Bluetooth® device connected icon will show up on your enunciator when connected to the Bluetooth® device. You can also check out the connection with a orange icon on the list.

Tip Bluetooth® wireless connection is dependent on your Bluetooth® devices. You may only be able to connect with one at one time. RD6250 only support Mono Headset, even if you use Stereo Headset.

7.1.3 My Visibility

Allows you to set whether your device is able to be searched by other Bluetooth® devices in the area.

1. Press Soft Key 1 **Menu**, 7, 1, 3.
2. Select **Once** / **Disable** by using then press .

Note Duration time of Visibility On lasts for 3 minutes.

7.1.4 DUN Active

Dial-up Networking to use your phone as a modem to connect to the Internet. While your phone is connected to a PC or PDA, you can dial up the phone to connect to the Internet. To use Sync with Bluetooth, set the DUN Active On.

1. Press Soft Key 1 **Menu**, 7, 1, 4.
2. Select **Enable** / **Disable** by using then press .

7.1.5 My Device Info

Allows you to edit the Bluetooth® name of your phone when Add New Device menu is highlighted.

1. Press Soft Key 1 **Menu**, 7, 1, 5.
2. Press Soft Key 1 **Edit**.
3. Press C/Torch to clear the existing name.
4. Use the numeric keypad to enter a new custom name.
5. Press to save and exit.

7.2 Voice Tools

With Voice Tools, you can use Voice Recorder, Answering Machine, Voice Messages and Voice Dialling. Up to 300 for Internal and up to 300 for External. Recording time is limited by 2 hours.

Note VOR(Voice Only Recording): When there is no voice input for 1 second, recording does not activate for saving memory.

7.2.1 Voice Recorder

Using voice recorder, save up to Max. 2 hours for each file. Recording time may diminish according to the function circumstances. Max. 300 files can be saved into each Internal and External folders. and check voice records list on Internal or External folders.

1. Press Soft key 1 **Menu**, 7, 2, 1.
2. Select **Record New** / **Voice Records** / **Recorder**

Settings with then press .

7.2.1.1 Record New

1. Press to begin recording.
2. Press to stop recording.

▶ Press to save.

▶ Press Soft Key 2 **Rename**.

▶ Press Soft Key 1 **Options** to select: **Save / Erase**

7.2.1.2 Voice Records

1. Select **Internal** or **External**.
2. After selecting the desired voice memo with ,

▶ Press to play.

▶ Press Soft Key 2 **Set As**.

▶ Press Soft Key 1 **Options** to select: **Play / File / Send By / All Files**

7.2.1.3 Recorder Settings

Use to highlight one of the settings and press to select it.

- Memory Usage - (**Internal / External**)
- Auto Saving - (**On** / **Off**)
- Playback Speed - (**Slow** / **Normal** / **X2** / **X3**)
- VOR - (**On** / **Off**)
- Reset Settings - (**Yes** / **No**)

7.2.2 Answering Machine

You can receive a call with your voice and record caller's voice messages. User-defined greeting message is savable up to 30 seconds.

1. Press Soft Key 1 **Menu**, 7 pqrs, 2 abc, 2 abc.
2. Select **On / Off**, **Greeting Message**, **Settings** with then press .

7.2.2.1 On / Off

Select **On** or **Off**.

7.2.2.2 Greeting Message

▶ Default — When set as, pre-programmed greeting message is activated.

▶ User Defined — After recording User Defined greeting message, set as Greeting Message.

7.2.2.3 Settings

After setting Screening and Time setting, press Soft Key 1 **Save**.

Note In case there are 20 voice messages or voice memory is full, Answering Machine does not function even if it is set as On.
When does not receive a call or the other party hangs up the phone, "Voice Memory Full" is displayed.

7.2.3 Voice Messages

Voice messages have voice files from answering machine and In call voice memos. Up to 100 for Internal. Received Voice message is savable up to 20 for Internal. And recording time is limited by 9 minutes. In case memory is full, delete files saved in internal or external memory in advance.

Note Recording time of Voice Memo is limited by 2 hours and In Call Voice Memo is limited by 30 minutes.

1. Press Soft Key 1 **Menu**, 7 pqrs, 2 abc, 3 def.
2. Press Soft Key 1 **Options**.
   - ► Play : Play the recorded voice message.
   - ► Erase All : Erase the recorded all voice messages.
   - ► File Info : Display file name, size, recorded date and time.

7.2.4 Voice Dialling

Voice dialing make a call with voice and you can access to voice dialing with hot key in idle screen. Up to 20 numbers can be assigned. You can set voice dialling up to 20.

1. Press Soft Key 1 **Menu**, 7 pqrs, 2 abc, 4 ghi.
2. Enter or highlight the entry name in the phonebooks and press .
3. After you are prompted to say the name you wish to program, wait for the beep and then say the name into your phone's microphone.
4. Respond to the prompt by repeating the name after the beep.

7.2.5 Help

You can get more information about this menu.

7.3 Schedule

Scheduler Functions

Scheduler keeps your agenda convenient and easy to access. Simply store your appointments and your phone alerts you with a reminder of your appointment. You can also take advantage of the wake-up feature. Up to 160, can be saved.

Note While transmitting SMS or during a call at the preset time, it does not ring. After exiting, it will ring the reminder.

Note Handset time is taken from Network time settings.

How to use various keys for navigation in Calendar

Moves cursor to the left.

Moves cursor to the right.

Moves to the previous week.

Moves to the next week.

1 Moves to the previous year.

3 def Moves to the next year.

5 jkl Moves to today.

7 pqrs Moves to the previous month.

9 wxyz Moves to the next month.

7.3.1 Scheduler

Allows you to input your schedule or erase or view. If you input the time and memo, an alarm rings at the set time.

1. Press Soft Key 1 **Menu**, 7 pqrs, 3 def, 1.
2. Select the date using your keypad, then press Soft Key 1 **Options** and select View, Erase To Date, Erase All, Go To Date, or Go To Today or press Soft Key 2 **Add**.

7.3.2 To Do

Up to 40, can be saved.

1. Press Soft Key 1 **Menu**, 7 pqrs, 3 def, 2 abc.
2. Press Soft Key 1 **Add** to write a new event.

Note In case there is saved To Do, the function of View, Erase, and Erase All is available with Soft Key 1 Options. Add is available with Soft Key 2.

7.3.3 D-Day Counter

Up to 5, can be saved.

1. Press Soft Key 1 **Menu**, 7 pqrs, 3 def, 3 def.
2. Press Soft Key 1 **Add** to write a new event.
3. After entering characters (For entering characters, refer to pages 19~23) press Soft Key 1 **Save**.
4. Use to set D-Day then press Soft Key 1 **Save**.

Note In case there is saved D-Day, the function of View, Show, and Erase is available with Soft Key 1 Options.

7.4 Memo

Up to 40, can be saved.

1. Press Soft Key 1 **Menu**, 7 pqrs, 4 ghi.
2. Press Soft Key 1 **Add** to write a new memo. (When there is saved memo in phone, to add use Soft Key 2.)
3. After entering characters (For entering characters, refer to pages 19~23) press Soft Key 1 **Save**.

When Memo is not empty

Following Options are available :
View , Erase, Erase All and Send via Bluetooth.
View : To display selected memo.
View screen gives 2 options Edit and Send via Bluetooth.
Using Edit user can modify an existing memo.
Erase : Enable user to delete a selected memo.
Erase All : Enable user to delete all the stored memo.
Send via Bluetooth : Send memo via Bluetooth to other devices.
When a memo is saved current date is also saved.
In case there is no memo, **Add** is displayed in Soft Key 1.

7.5 Reserved Call

This option allows you to create reserved call with calling time and date. Phone will alert you on set time and date to dial. Up to 5 can be saved.

1. Press Soft Key 1 **Menu**, 7 pqrs, 5 jkl.
2. Select Reserved Call 1~5.
3. Enter the phone number, then press . (You must enter any phone number)
4. You can change the mode using .
   (Off / Once / Daily / Mon - Fri / Mon - Sat / Weekends / Every Sun / Every Mon / Every Tue / Every Wed / Every Thu / Every Fri / Every Sat)
5. After moving with , enter the date with number key.
6. After moving with , enter the time with number key. (Select am / pm with)
7. After moving with , choose melody with .
8. After moving with , enter memo up to 32 characters, then press .

7.6 Alarm

To change an event alarm time.

1. Press Soft Key 1 **Menu**, 7 pqrs, 6 mno.
2. Select Alarm1, Alarm2 or Alarm3.
3. You can change the alarm mode using .
   (Off / Once / Daily / Mon-Fri / Mon - Sat / Weekends / Every Sun / Every Mon / Every Tue / Every Wed / Every Thu / Every Fri / Every Sat)
4. Use to set alarm time, select Ringer or FM Radio channel and input contents, then press Soft Key 1 **Save**.
   - ▶ am / pm may be selected using .
   - ▶ Ringer volume is controlled according to settings done in Profiles. Also FM Radio volume is controlled according to settings done in FM Radio main volume.

Note Alarm is disabled when the mobile is switched off. Any alarms that have passed the set limits will automatically expire.

You can set **Quick Alarm** (10 mins later / 30 mins later / 1 hour later / 3 hours later / Off).
When Quick Alarm is set, the scheduled alarm time is displayed.

How to Set Snooze

Only when alarm type is ringer, snooze is automatically activated.
When no key is input when alarm sounds, Snooze function is set automatically one minute later, and the alarm sounds again ten minutes after set alarm time.
If alarm type is FM Radio, snooze is not activated until you input snooze key.

7.7 Stopwatch

Stopwatch is available.

1. Press Soft Key 1 **Menu**, 7 pqrs, 7 pqrs.

7.8 Calculator

Calculate simple mathematical computations.
(Can get result upto second decimal place.)

1. Press Soft Key 1 **Menu**, 7 pqrs, 8 tuv.
2. Press 2 abc and 5 jkl in order.
3. Select (multiplication) using ◀ keys.
4. Press 1 and 0 next in order.
5. Select using Soft Key 1 **Answer**.
   You will see the result of the calculation 250.

Note Calculations can be made with up to 50 characters at one time (e.g., 73+01-03 would be 8 characters).

7.9 Unit Converter

Unit Converter provides various conversion unit like Currency, Length, Surface, Mass, Volume, Temperature and Velocity.

1. Press Soft Key 1 **Menu**, 7 pqrs, 9 wxyz.

7.9.1 Currency

Before you can make currency conversions, you need to choose a base Currency (usually the domestic currency) and estimate exchange rates.

1. Set the domestic currency or press ▼ to set the foreign currency.
2. Then press Soft Key 1 **Rate** and press Soft Key 1 **Save** to set the currency rates.

Note The base currency determines the conversion rates of the other currency. After you have inserted all the needed exchange rates, you can make currency con-version.

Length, Surface, Mass, Volume, Temperature and Velocity

1. Enter the Input for Source unit and it displays the result in destination unit.
2. Press ◀ or ▶ to select different units of measurement.
3. Press ▲ or ▼ to switch between source and destination units.

7.0 World Clock

Is useful if you need to make a call to another country, and you are not sure about the time difference.

1. Press Soft Key 1 **Menu**, 7 pqrs, 0 next.
2. Select the city you desire by using ◀▶.

   For faster selection, ▲▼ can be used to jump 7 cities on the map.
3. When press ●, the set city becomes the default city of world clock.

Note With Soft Key 2 **DST**, set the daylight saving time. With Soft Key 1 **List**, you can also select city.

7.* Help

You can get more information about this menu.

8. Multimedia

8.1 Camera

Your multimedia phone comes with an easy-to-use built-in camera, which allows you to instantly take, view, and share photos and movies with your friends and family. Flash option is available with Camera.

Note **Internal Memory** : Up to 1000 is available including photo and movie.
External Memory : Up to 4000 is available including photo and movie. [For files and folder structure saved in external memory, DCF(Design rule for Camera File system) is applied.]

Quick Access to Camera Feature

Pressing the Camera Key (📷) from standby mode is a hot key to Camera.

8.1.1 Take Photo

Taking a photo with your camera.

1. Press Soft Key 1 **Menu**, 8 tuv, 1, 1.

Note Pressing the Camera Key (📷) for 4 seconds from standby mode is a hot key to Take Photo.

2. Set the brightness ◀◉▶, zoom ⬍, and press Soft Key 1 **Options** to change other settings.
   ▶ Select the option(s) to customize.
   1. **Zoom** : 4X Zoom is available except 640 x 480.
   2. **Exposure** : -2.0 EV ~ +2.0 EV
   3. **Flash** : Off / On
   4. **Multi** : 3 / 6 / 9 shots is available except 640 x 480.
      Multi shot is not available for 640 x 480.
   5. **W/B** : Auto / Fluore / Tungsten / Daylight / Cloudy
   6. **Quality** : High / Middle / Low
   7. **Timer** : No / 3 secs / 5 secs / 10 secs / 15 secs
   8. **Filter** : No / B&W / Sepia
   9. **Resol.** : 640x480 / 320x240 / 160x120 / 128x128
   0. **Memory** : Internal / External

Note Can control the zoom function by 10 steps at the resolution (320x240 / 160x120 / 128x128)

Note When the Flash is On, take a photo within 30 cm.

3. Take a photo by pressing [📷] or ◉.
4. Press [📷] or ◉. The photo is stored in the Gallery.
   - Press Soft Key 2 **Rename**.
   - Press Soft Key 1 **Options** to select **Save** or **Send**.

Note When making photos with 160 x 120 resolution, there is white margin to up and down.

8.1.2 Take Fun Photos

1. Press Soft Key 1 **Menu**, [8 tuv], [1], [2 abc].
2. Set the brightness ◀◉▶, zoom ⬍, and press Soft Key 1 **Options** to change other settings.
   ▶ Select the option(s) to customize.
   Frame : 01~40
   W/B : Auto / Fluore / Tungsten / Daylight / Cloudy
   Quality : High / Middle / Low
   Timer : No / 3 secs / 5 secs / 10 secs / 15 secs
   For frame 31 ~ 40, timer is not available.
   Filter : No / B&W / Sepia
   Memory : Internal / External
   Exposure : -2.0 EV ~ +2.0 EV
   Flash : Off/On
3. Take a photo by pressing [📷] or ◉.
4. Press [📷] or ◉. The photo is stored in the Gallery.
   - Press Soft Key 2 **Rename**.
   - Press Soft Key 1 **Options** to select **Save** or **Send**.

8.1.3 Take Movie

Recoding 2 hours 128 x 96 sized movies with sound.

1. Press Soft Key 1 **Menu**, [8 tuv], [1], [3 def].

Note Only for the movies over 3 seconds can be saved.

8.1.4 My Photo Gallery

Look around your photo saved in the phone.

1. Press Soft Key 1 **Menu**, 8 tuv, 1, 4 ghi.

8.1.5 My Movie Gallery

Sees the recorded movies.

1. Press Soft Key 1 **Menu**, 8 tuv, 1, 5 jkl.

8.1.6 Slide Show

Shows you the selected photo consecutively.

1. Press Soft Key 1 Menu, 8 tuv, 1, 6 mno.
2. Press Soft Key 2 **Add** and set the desired images for slide show and select Soft Key 1 **Select**, and then press Soft Key 1 **Save** to save it.

View	Play the selected slide show.
Erase	Erase the selected slide show.
Rename	Rename the selected slide show.
Effect	Customize several effect on slide show.
Wallpaper	Set the selected photo as wallpaper.
Erase All	Erase all slide show.

8.1.7 Photo Editor

You can edit your captured photo with various options.

1. Press Soft Key 1 Menu, 8 tuv, 1, 7 pqrs.
2. Use ◀◉▶ to select a photo,
   - ▶ Press Soft Key 2 **Grid**.
   - ▶ Press Soft Key 1 **Options** to select : **Retouch / Lettering / Crop**

8.1.8 Settings

1. Press Soft Key 1 **Menu**, 8 tuv, 1, 8 tuv.

8.1.8.1 Auto Saving

1. Press Soft Key 1 **Menu**, 8 tuv, 1, 8 tuv, 1.
2. Select **On** or **Off** with ◉ then press ◉ .

8.1.8.2 Shutter Sound

Choose a sound in 4.

1. Press Soft Key 1 **Menu**, 8 tuv, 1, 8 tuv, 2 abc.
2. Select **Sound 1~4** or **Off** with ◉ then press ◉ .

8.1.8.3 Erase Gallery

1. Press Soft Key 1 **Menu**, 8 tuv, 1, 8 tuv, 3 def.
2. Enter the four-digit Lock Code.
3. Select the menu of your choice by using , then press .
   - ▶ Press Soft Key 1 **Options** to select: **Mark(Unmark) / Erase / Mark all / Unmark all**

8.1.8.4 Lock All Galleries

1. Press Soft Key 1 **Menu**, 8 tuv, 1, 8 tuv, 4 ghi.
2. Enter the four-digit Lock Code.
3. Select **Yes** or **No** with then press .

8.1.8.5 Memory Usage

Select the target memory (internal or external).

1. Press Soft Key 1 **Menu**, 8 tuv, 1, 8 tuv, 5 jkl.
2. Select **Internal** or **External** with then press .

8.1.8.6 Reset Settings

Reset all camera settings on factory default settings.

1. Press Soft Key 1 **Menu**, 8 tuv, 1, 8 tuv, 6 mno.
2. Select **Yes** or **No** with then press .

8.1.9 Memory Info

You can check free space and memory usage of each Internal memory and External memory.

1. Press Soft Key 1 **Menu**, 8 tuv, 1, 9 wxyz.
2. Select **Internal** or **External** with then press .

8.1.0 Help

You can get more information about this menu.

8.2 FM Radio

8.2.1 Listen To Radio

1. Attach headset to the headset jack.
2. Press Soft Key 1 **Menu**, 8, 2, 1. or Press FM/MP3 for long time in idle mode.
3. Press Soft key 1 for below options:

▶ **Switch Off**	Switch off the FM Radio.
▶ **Edit Channels**	Adjust and save channels manually.
▶ **Auto Scanning**	Auto scan and save channels.
▶ **Reset All**	Reset all channels to default mode.
▶ **Listen Via**	Listen FM Radio via Speaker or Headset.

Note Up to 12 channels can be configured.
When using headset, just press headset button to move to next saved channel.

8.2.2 Help

You can get more information about this menu.

8.3 MP3

Quick Access to MP3 Feature

Pressing the MP3 Key (FM/MP3) from standby mode is a hot key to MP3 Player.

8.3.1 Music Box

Shows the list and play MP3 music.

1. Press Soft Key 1 **Menu**, 8, 3, 1.
2. Select **Internal** or **External** with ⬍ then press ●.

Keys functions are as following:

- Soft Key 1: Allows you to select another file during listening to MP3 file.
- Soft Key 2: Allows you to change Repeat mode during listening to MP3 file.
- Up Navigation Key: Allows you to set repeating section.
- Right Navigation Key: Press once to go to next song. Press long to fast forward.
- Left Navigation Key: Press once to go to previous song. Press long to fast rebind.
- OK Key: Pause / Play.
- Down Navigation Key: Stop and Exit from MP3 player.

Note

• **MP3 Player with Internal / External Memory**

- You can play songs directly from external micorSD Card.
- Listen music via headset or inbuilt speaker.
- Volume can adjust by side button.

Note Place MP3 song at SOUND folder. Although you can store MP3 songs over 300 on your micorSD card, only 300 out of them can be listed and played. Photos and video will be saved at IMAGE and MOVIE folder respectively.

8.3.2 My List

A list can holds 100 music. Only 1 mylist is available

1. Press Soft Key 1 **Menu**, 8 tuv, 3 def, 2 abc.

8.3.3 Settings

1. Press Soft Key 1 **Menu**, 8 tuv, 3 def, 3 def.
2. Use to highlight one of the settings and press to select it.
   - Skin - (**Wave** / **Ball**)
   - Timer - (**Off** / **30 mins** / **1 hour** / **User-set**)
   - Key Guard - (**Enable** / **Disable**)

8.3.4 Help

You can get more information about this menu.

8.4 My Stuff

1. Press Soft Key 1 **Menu**, 8 tuv, 4 ghi.
2. Select **Internal** or **External** with then press .

Images

Shows you the images of default, downloaded and camera photos.

▶ Select Default, Downloaded or My Photo Gallery and check it.

Movies

Shows the videos which you captured or downloaded.

▶ Select Downloaded or My Movie Gallery and check it. Files downloaded from MMS and Bluetooth are saved into Download folder.

Sounds

Show you the list of sounds (Default, Downloaded, MP3, Voice Records), and you can play them.

Memory Info

You can check free space and memory usage of each Internal memory or External memory.

Help

You can get more information about this menu.

9. Settings

9.1 My Menu

Lets you access to favorite menu quickly by customizing my menu. Max 10 items can be stored in My Menu.

1. Press Soft Key 1 **Menu**, 9, 1.
2. Select the menu of your choice by using , then press Soft Key 1 **Select**.
3. Select the Menu to add to My Menu with , then press Soft Key 1 **Add**.

Note Select the item of choice with C/Torch from the Stand-by screen, then press Soft Key 1 or to select the required menu from My Menu.

Note Select the item to delete with C/Torch from the Stand-by screen, then press Soft Key 2 **Remove**, select Yes with , then press Soft Key 1 **Select** or to delete from My Menu.

9.2 Call

1. Press Soft Key 1 **Menu**, 9, 2.

9.2.1 Call Forward

Call forward lets you forward all your incoming calls to another number or Voice Mail connection.

► Immediate / When Busy / No Reply/Not Reachable / Disable All

9.2.2 Call Waiting

While a call is in progress, you may hear two beeps indicating another incoming call. When call waiting is enabled, you may put the active call on hold while you answer the other incoming call.

► Select **Enable**, **Disable** or **Edit Feature Code** and press Soft key 1 **Select**.

Note Contact your service provider for more information on Call Forward and Call Waiting.

9.2.3 Any Key Answer

When your phone rings, press any key to answer except .

► Select **On** or **Off** and press Soft Key 1 **Select**.

9.2.4 Auto Redial

Set the length of time the phone waits before automatically redialing a number when the attempted call fails.

► Off / Every 60 secs / Every 30 secs / Every 10 secs

9.2.5 Voice Privacy

Set the voice privacy feature for CDMA calls as Enhanced or Standard. CDMA offers inherent voice privacy. Check with your service provider for availability of the enhanced voice privacy mode.

► Select **Standard** or **Enhanced** and press Soft Key 1 **Select**.

9.2.6 Clear Voice

Enable/Disable the function of Audio AGC(Auto Gain Control) system.
This feature provides a better audio experience by enabling the Audio AGC system to control the dynamic range and volume of the sending and receiving voice across different levels of speaker and environments.

► Select **On** or **Off** and press Soft Key 1 **Select**.

9.2.7 Call Timer

You can set your phone to display the running elapsed time while a call is active.

► Select **Enable** or **Disable** and press Soft Key 1 **Select**.

9.2.8 Call Connect Alert

This is a function to alert you that the call connection has been established.

► Select **On** or **Off** and press Soft Key 1 **Select**.

9.2.9 Edit SMS on Call Reject

You can edit your message which can be sent during Call Reject.

9.2.0 Int'l Call Prefix

Allows you to set international call prefix.

► After inputting international call prefix, press Softkey 1 **Save**.

9.2.* Help

You can get more information about this menu.

9.3 Phone

1. Press Soft Key 1 **Menu**, 9 wxyz, 3 def.

9.3.1 Key Guard

Allows you to protect the keypad of your phone from accidental dialing. When this function is enabled, no call can be made and the access to Menu is locked. When the keypad is locked, it is possible to answer a call normally.

► Select **Enable** or **Disable** and press Soft Key 1 **Select**. If Enable is selected, insert the desire time. Key pad will automatically get locked on set time.

To enable quickly : Press the key 0 next for 2 seconds.

To disable quickly : Repeat the procedure.

Note After the set time in idle mode, Key Guard is automatically enabled.
When set as Key Guard before incoming call, lock is enabled after the call.

9.3.2 Airplane Mode

When your phone is in Airplane Mode, it cannot send or receive any calls or access online information. You may use the phone's other features, such as Game, Scheduler, Memo, etc. When Airplane Mode is enabled, a message "Airplane Mode" is displayed on the screen.

► Select **On** or **Off** and press Soft Key 1 **Select**.

9.3.3 Data Settings

9.3.3.1 Data In

In Data setting, you can use your phone as a wireless modem to avail high speed data services such as browsing Internet and other dial-up networking functions. The wireless phone supports a maximum data rate of 153.6 kbps on the network side. The speed of your connection depends upon network congestion, signal strength, and other variables.

► **On** : This setting enables a subscriber to receive data calls.

► **Off**

Note You need to purchase the Data Kit in order to be able to use the phone as modem. The data kit includes a suitable cable that has USB interface for connecting the phone to the PC. Please contact your service provider for further information.

9.3.3.2 Data Baud

This setting enables the subscriber terminal to set the baud rate.

► Data Baud set 19,200 / 115,200 / 230,400 / USB
By default it is set to USB. If you change this setting on the phone ensure that the PC baud rates are changed to match accordingly.

Note The wireless phone will work with the PC / PDA properly only when the serial port settings on both the PC match with the baud rates set on the phone.

9.3.4 Service Alert

Alerts you when service changes.

► Select **On** or **Off** and press Soft Key 1 **Select**.

9.3.5 Version

View the S/W, PRL and H/W version.

9.3.6 Help

You can get more information about this menu.

9.4 Security

Prevents unauthorized use of your phone.

Note The lock code/password on your phone is **0000** by default.

9.4.1 PIN Code Request

Sets the phone to disable the use of it if incorrect password is entered for times provided by UIM card.

1. Press Soft Key 1 **Menu**, 9, 4, 1.
2. Enter the four-digit lock code.
3. Select **On** / **Off** by using then press .
4. After selecting **On**, enter 4~8 digits PIN number and press .

▶ Please contact your service provider for more information.

9.4.2 Lock Mode

Keeps your phone from unauthorized use. Once the phone is locked, it is in restricted mode, until the lock code is entered. This will allow you to receive phone calls and still make emergency calls. The lock code/password on your phone is 0000 by default. If you need to modify the lock code, you may modify it using the new lock code within the security set menu.

1. Press Soft Key 1 **Menu**, 9, 4, 2.
2. Enter the four-digit Lock Code.
3. Select an options and press Soft Key 1 **Select**.

▶ **Off** means that the phone is never locked. When locked, you can receive incoming calls or make only emergency calls.

▶ **Now** means that the phone is locked immediately.

▶ **On Power Up** means the phone is locked when it is turned on.

9.4.3 Emergency Numbers

You can call these numbers 100, 101, 102 even when the phone is locked.
To enter 3 emergency numbers.

1. Press Soft Key 1 **Menu**, 9, 4, 3.
2. Enter the four-digit Lock Code.
3. Press Soft Key 1 **Edit**.
4. Enter an Emergency number.
5. Press Soft Key 1 **Save**.

9.4.4 Change Code

9.4.4.1 Phone Lock Code

Phone Lock Code allows you to enter a new four-digit lock code number.

1. Press Soft Key 1 **Menu**, 9, 4, 4, 1.
2. Enter the four-digit Lock Code.
3. Enter the New Lock Code (four-digit).
4. For confirmation, it will ask you to enter the New Lock Code again.

9.4.4.2 PIN Code

Change PIN code is a function that enables changing of the PIN number, which is saved in the card. First, Select PIN Code request On and, if correct PIN is entered, then followed by entering new password for 2 times. If the new password entered for 2 times do not match each other, a message notifies so and new password shall be entered again. Initial PIN number differs depending on the card manufacturer.

1. Press Soft Key 1 **Menu**, 9, 4, 4, 2.
2. Enter the 4~8 digits PIN Code and press .
3. Enter the New PIN Code (4~8 digits) and press .
4. Re-enter PIN Code and press .

9.4.5 Clear Memory

Deletes All Names or All Data saved in phone and UIM.

1. Press Soft Key 1 **Menu**, 9, 4, 5.
2. Enter the four-digit Lock Code.
3. Select 1 **All Names** or 2 **All Data**.
4. After clearing memory, phone is reset to defaults.

9.4.6 Reset Default

You can reset some of the menu settings to their original values. When select Reset phone, all settings become reset.

1. Press Soft Key 1 **Menu**, 9 wxyz, 4 ghi, 6 mno.
2. Enter the four-digit Lock Code.
3. Using the then select **Yes**.
4. Press Soft Key 1 **Select**.

9.4.7 Help

You can get more information about this menu.

In Call Memo

(During a Call : Menu 1)

It allows you to note a phone number that the other person provides you during a call. The number will be stored in the Call History. Upto 32 number may be saved.

1. Press the Soft Key 1 during the call.
2. Press 1 **In Call Memo**.
3. Type the phone number and press the Soft Key 1 **Save**.

Note "Use Headset / Use Phone" is menu which is used for transferring voice between phone and Bluetooth device during a call.

- When Bluetooth headset/handsfree are connected to phone, Menu 1 is Use Headset / Use Phone.
- When making a call with Bluetooth device, Menu 1 is Use Phone.
- When making a call with Send Key, Menu 1 is Use Headset.

Mute/Unmute

(During a Call : Menu 2)

This function locks the microphone of your telephone and prevent sounds from your end being heard by the person at the other end.

- **To enable Mute Function:**

1. Press the Soft Key 1 during the call.
2. Press 2 **Mute**.

- **To disable Mute Function:**

1. Repeat the procedure.

Voice Privacy On/Off

(During a Call : Menu 3)

Set the privacy feature for CDMA calls as Enhanced or Standard. CDMA offers inherent voice privacy. check with your service provider for availability of the enhanced voice privacy mode.

Voice Memo

(During a Call : Menu 4 ghi)

It allows you to record a conversation during a phone call. As it is recording, the phone displays a countdown timer that shows how many seconds are left for recording.

Note Recording time of Voice Memo is limited up to Max. 2 hours and In Call Voice Memo is limited up to 3o minutes. Recording time may diminish according to the function circumstances.

Adjusting Speaker Mode On

(During a Call : Press)

During a call, to activate or cancel speaker quickly, press .

Earpiece/Speaker Volume

Adjust the Earpiece/Speaker Volume with during the call.

Accessories

There are a variety of accessories available for your mobile phone. You can select these options according to your personal communication requirements. Consult your local dealer for availability.

Travel Adaptor

This adaptor allows you to charge the battery. It supports AC 100~240 Volt, 50~60 Hz outlets.

Micro SD Card

The RD6250 is equipped with a slot on the side for a memory card.
You can use this card to save data files such as photos, video, mp3, voice.

Headset

Connects to your phone, allowing hands- free operation. Includes earpiece, microphone, and integrated call answer / termination button.

USB Data Cable(Without Charging)

Connect your phone to your PC. (LG-USB5200)

Frequently asked questions

Q : How do I view the list of Dialled calls, Received calls and Missed calls?

A : Press .

Q : How do I clear Call History ?

A : Press → Press Soft Key 1 **Options** → Select **Erase** or **Erase All** → Press → Select **Yes** → Press .

Q : How do I view all numbers stored in memory?

A : Press Soft Key 2 **Find**.

Q : How many events can I add to the schedule ?

A : Total of 160 events.

Q : How do I clear past schedule stored in Scheduler?

A : Press Soft Key 1 **Menu** → 7 **Organ.&Tools** → 3 **Schedule** → 1 **Scheduler** → Press Soft Key 1 **Options** → 2 **Erase To Date** → Select **One week / One month / One day** → Press .

Q : How many Speed Dial numbers can I store?

A : Total of 99 numbers.

Q : How do I send a text message ?

A : Press → 1 **Write** → 1 **Write Text** .

Q : How do I clear the call timer (reset the time used monthly)?

A : Press Soft Key 1 **Menu** → 3 **Call History** → 5 **Call Duration** → 4 **Reset Call Duration** → Select **Yes** → Press .

Q : How do I find out my lock code ?

A : The Lock Code / Password on your phone is **0000** by default.

Q : How many groups are there ?

A : In Groups, there are No Group / Business / Personal / Family / Friends / Workgroup / VIP / School / Club. You can edit Group title except the title of **No Group** cannot be edited. To change Group Name,

1. Select group by pressing Soft Key 1 **Menu** → 1 **Names** → 3 **Groups** and ◆.
2. Press Soft Key 2 **Edit**.

Q : Is Group SMS possible ?

A : You can send a message to 10 numbers simultaneously. Each number should be selected or entered individually. There are 5 SMS Groups where you can add 10 members in each group.

Q : Is Group E-mail possible ?

A : You can send a message to 10 address simultaneously. Each address should be selected or entered individually. There are 5 E-mail Groups where you can add 10 members in each group.

Q : How to send SMS/E-mail sending to multiple recipients ?

A : After writing message, select SMS / E-mail Groups in Options. You can add up to 10 recipients.

Q: How to send MMS sending?

A: After writing multimedia message, select Insert Img / Mov or Insert Sound in Options. The phone can store up to 30 MMS / 50 notifications in MMS.

Q : What is the significance of key ?

A : key is equivalent to pressing Soft Key 1, in the case of Soft Key 1 is associated with "**Select**" option.

key is equivalent to pressing Soft Key + selecting first option of popup menu, in the case of Soft Key 1 is associated with "**Options**" option.

key for turning the speaker on / off during the call properly.

Q : What is the difference between activating speaker during a call and activating it in Idle mode?

A : If user want to use speaker ON as default always, user can enable the speaker mode by pressing LONG key.

If user want to use speaker temporarily, he can enable it by pressing key. User can toggle speaker by pressing the same key.

Q : What is Airplane Mode?

A : This 'Airplane Mode' function will turn off radio frequency (RF) of mobile, so user can not make the following Incoming / Outgoing Calls, Sending / Receiving SMS and Data Communication etc.

Q : How to send LMS ?

A : With this new feature LMS message, user can compose a message upto 460 characters. To send an LMS message, compose a message in the message editor with more then 160 characters. Title of the message editor is changed to "Write LMS(XXX)" displaying the total number of characters left. On the selection of send option, total number of segments formed are displayed and the confirmation is taken from the user. User can continue or can cancel. Each segment is sent as a simple SMS message over the network. Messages are stored in the Outbox on the return of

acknowledgement. Each LMS packet is received as individual message. Every LMS message shows the packet sequence number in the message body for ex: In case of 3 packets, <1/3>, <2/3>, <3/3>.

Q : Is Group MMS possible?

A : To send MMS to MMS Groups, press Soft Key 1 **Menu** → 2 **Messages** → 9 **Msg Groups** → 3 **MMS Groups** with . After pressing Soft Key 2 **Send**, compose messages and press . In **Options**, select **Send** with .

Q : How to send SMS to E-mail and E-mail to SMS ?

A : To send an SMS To E-mail : Go to **Messages** → **Write** → **Write E-mail**. On selection of this option, an E-mail editor is displayed where user need to enter the E-mail IDs. Maximum 10 E-mail IDs can be entered each of maximum 40 characters. On the selection of Send option in this screen, Subject editor is enabled. This screen allows user to edit up to 20 characters. On the selection of Next option in the subject editor, message editor is enabled, here user can compose a message upto X characters (X=480-Subject size-Max E-mail ID size in the list - packet formation characters). E-mail message can be an LMS message. To receive an E-mail as SMS: An E-mail can be sent to the mobile device RD6250 as SMS. An received email on the device can have subject and the email body.

Received email on the mobile device will have different icon in the Inbox list.

For more details. Contact your Service Provider.

Before calling for service

Please check to see if any problem which you may have with your phone is described here before taking it for service or calling a service engineer.

When showing symptoms like:	Check this!
When " " does not disappear from the screen.	Check whether it is in service area, and if you continue to see " " please turn off the power and wait for approximately 2 minutes to turn it back on. If there is no change, check again after relocating to other areas.
When connection is abrupt or is not audible in certain areas.	When frequency environment is unstable in a certain area, connection may be abrupt and not audible. Relocate to other areas and try again.
When connection is not made well or abrupt even when established.	When frequency is unstable or weak, or if there are too many users, connection may be cut off even after it was established. Please try again a little later or try after relocating to other areas.
When LCD does not turn on.	Remove battery and turn on the power after placing it back on. If there is no change even then, sufficiently charge the battery and try again.
When FM Radio is not audible.	Check whether headset is connected to the phone. Fully pressed to the headset to the phone.

When showing symptoms like:	Check this!
When it echoes while connection is made with a certain telephone in a certain area.	Called "Echo Phenomenon," it occurs if connection volume is too high or caused by special properties(semi electronic telephone exchange) of the machine on the other end.
When the phone is heated.	If connection is made for a significantly long duration, or game and Internet and others are used for a long time, the phone may become hot. This has no effect upon the life of the product or performance.
When the Ringer does not ring, or when Backlight or LCD blinks only.	Ringer Type may be set as "Silent" or "Light". Please select "Ring".
Standby duration for battery gradually becomes shorter.	Because battery wear out, its life gradually becomes shorter. If its life becomes shorter over half of that at the time of purchase, you must purchase a new one.
When usage time of battery becomes shorter.	If time for use of battery is short, it may be due to the user environment, or large volume of calls, or weak signals.

TIA Safety Information

Provided herein is the complete TIA Safety Information for Wireless Handheld phones. Inclusion of the text covering Pacemakers, Hearing Aids, and Other Medical Devices is required in the owner's manual for CTIA Certification. Use of the remaining TIA language is encouraged when appropriate.

Exposure to Radio Frequency Signal

Your wireless handheld portable telephone is a low power radio transmitter and receiver. When it is ON, it receives and also sends out radio frequency (RF) signals.
In August, 1996, the Federal Communications Commissions (FCC) adopted RF exposure guidelines with safety levels for hand-held wireless phones. Those guidelines are consistent with the safety standards previously set by both U.S. and international standards bodies:

ANSI C95.1 (1992) *
NCRP Report 86 (1986)
ICNIRP (1996)

Those standards were based on comprehensive and periodic evaluations of the relevant scientific literature. For example, over 120 scientists, engineers, and physicians from universities, government health agencies, and industry reviewed the available body of research to develop the ANSI Standard (C95.1).
The design of your phone complies with the FCC guidelines (and those standards).

Antenna Care

Use only the supplied or an approved replacement antenna. Unauthorized antennas, modifications, or attachments could damage the phone and may violate FCC regulations.

Phone Operation

NORMAL POSITION : Hold the phone as you would any other telephone with the antenna pointed up and over your shoulder.

Tips on Efficient Operation :

- For your phone to operate most efficiently:

Do not touch the antenna unnecessarily when the phone is in use. Contact with the antenna affects call quality and may cause the phone to operate at a higher power level than otherwise needed.

- American National Standards Institute; National Council on Radiation Protection and Measurements; International Commission on Non-Ionizing Radiation Protection.

Driving

Check the laws and regulations on the use of wireless telephones in the areas where you drive. Always obey them. Also, if using your phone while driving, please:

- Give full attention to driving -- driving safely is your first responsibility;
- Use hands-free operation, if available;
- Pull off the road and park before making or answering a call if driving conditions so require.

Electronic Devices

Most modern electronic equipment is shielded from RF signals. However, certain electronic equipment may not be shielded against the RF signals from your wireless phone.

Pacemakers

The Health Industry Manufacturers Association recommends that a minimum separation of six(6”) inches be maintained between a handheld wireless phone and a pacemaker to avoid potential interference with the pacemaker. These recommendations are consistent with the independent research by and recommendations of Wireless Technology Research.

Persons with pacemakers:

- Should ALWAYS keep the phone more than six inches from their pacemaker when the phone is turned ON;
- Should not carry the phone in a breast pocket.
- Should use the ear opposite the pacemaker to minimize the potential for interference.

Hearing Aids

Some digital wireless phones may interfere with some hearing aids. In the event of such interference, you may want to consult the LG Authorised Service Center to discuss alternatives Optional for each phone manufacturer.

Other Medical Devices

If you use any other personal medical device, consult the manufacturer of your device to determine if they are adequately shielded from external RF energy. Your physician may be able to assist you in obtaining this information.
Turn your phone OFF in health care facilities when any regulations posted in these areas instruct you to do so. Hospitals or health care facilities may be using equipment that could be sensitive to external RF energy.

Vehicles

RF signals may affect improperly installed or inadequately shielded electronic systems in motor vehicles. Check with the manufacturer or its representative regarding your vehicle.
You should also consult the manufacturer of any equipment that has been added to your vehicle.

Posted Facilities

Turn your phone OFF in any facility where posted notices so require.

Aircraft

FCC regulations prohibit using your phone while in the air. Switch OFF your phone before boarding an aircraft.

Blasting Areas

To avoid interfering with blasting operations, turn your phone OFF when in a “blasting area” or in areas posted : “Turn off two-way radio”. Obey all signs and instructions.

Potentially Explosive Atmosphere

Turn your phone OFF when in any area with a potentially explosive atmosphere and obey all signs and instructions. Sparks in such areas could cause an explosion or fire resulting in bodily injury or even death.

Areas with a potentially explosive atmosphere are often, but not always marked clearly. Potential areas may include: fueling areas (such as gasoline stations); below deck on boats; fuel or chemical transfer or storage facilities; vehicles using liquefied petroleum gas (such as propane or butane); areas where the air contains chemicals or particles (such as grain, dust, or metal powders); and any other area where you would normally be advised to turn off your vehicle engine.

For Vehicles Equipped with an Air Bag

An air bag inflates with great force. DO NOT place objects, including either installed or portable wireless equipment, in the area over the air bag or in the air bag deployment area. If in-vehicle wireless equipment is improperly installed and the air bag inflates, serious injury could result.

Safety Information

Please read and observe the following information for safe and proper use of your phone and to prevent damage. Also, keep the user guide in an accessible place at all the times after reading it.

⚠Warning **Violation of the instructions may cause minor or serious damage to the product.**

Charger and Adapter Safety

- The charger and adapter are intended for indoor use only.

Battery Information and Care

- Please dispose of your battery properly.
- The battery does not need to be fully discharged before recharging.
- Use only LG-approved chargers specific to your phone model since they are designed to maximize battery life.
- Do not disassemble or short-circuit the battery.
- Keep the battery's metal contacts clean.

- Replace the battery when it no longer provides acceptable performance. The battery can be recharged several hundred times before replacement.
- Recharge the battery after long periods of non-use to maximize battery life.
- Battery life will vary due to usage patterns and environmental conditions.
- Use of extended backlighting, Mini Browser, and data connectivity kits affect battery life and talk/standby times.
- The self-protection function of the battery cuts the power of the phone when its operation is in an abnormal state. In this case, remove the battery from the phone, reinstall it, and turn the phone on.

Explosion, Shock, and Fire Hazards

- Do not put your phone in a place subject to excessive dust and keep the minimum required distance between the power cord and heat sources.
- Unplug the power cord prior to cleaning your phone, and clean the power plug pin when it is dirty.
- When using the power plug, ensure that it is firmly connected. If it is not, it may cause excessive heat or fire.
- If you put your phone in a pocket or bag without covering the receptacle of the phone (power plug pin), metallic articles (such as a coin, paperclip or pen) may short-circuit the phone. Always cover the receptacle when not in use.
- Do not short-circuit the battery. Metallic articles such as a coin, paperclip or pen in your pocket or bag may short-circuit the + and – terminals of the battery (metal strips on the battery) upon moving. Short-circuit of the terminal may damage the battery and cause an explosion.

General Notice

- Using a damaged battery or placing a battery in your mouth may cause serious injury.

- Do not place items containing magnetic components such as a credit card, phone card, bank book or subway ticket near your phone. The magnetism of the phone may damage the data stored in the magnetic strip.
- Talking on your phone for a long period of time may reduce call quality due to heat generated during use.
- When the phone is not used for a long period time, store it in a safe place with the power cord unplugged.
- Using the phone in proximity to receiving equipment (i.e., TV or radio) may cause interference to the phone.
- When listening to radio near LCD monitor or notebook, it may cause malfunction of radio module, interference or noise. For near LCD monitor, stay phone away over 30 Cm.
  FM Radio is only activated when headset is inserted into the phone.
- Do not use the phone if the antenna is damaged. If a damaged antenna contacts skin, it may cause a slight burn. Please contact an LG Authorized Service Center to replace the damaged antenna.
- Do not immerse your phone in water. If this happens, turn it off immediately and remove the battery. If the phone does not work, take it to an LG Authorized Service Center.
- The power cord on this product will expose you to lead, a chemical known to the State of California to cause (cancer) birth defects or other reproductive harm. Wash hands after handling.
- Do not paint your phone.
- The data saved in your phone might be deleted due to careless use, repair of the phone, or upgrade of the software. Please backup your important phone numbers. (Ring tones, text messages, voice messages, pictures, and videos could also be deleted.)
  The manufacturer is not liable for damage due to the loss of data.
- When you use the phone in public places, set the ring tone to vibration so as not to disturb others.
- Do not turn your phone on or off when putting it in your ear.

FDA Consumer Update

The U.S. Food and Drug Administration's Center for Devices and Radiological Health Consumer Update on Mobile Phones.

1. Do wireless phones pose a health hazard?

The available scientific evidence does not show that any health problems are associated with using wireless phones. There is no proof, however, that wireless phones are absolutely safe. Wireless phones emit low levels of radiofrequency energy (RF) in the microwave range while being used. They also emit very low levels of RF when in the stand-by mode. Whereas high levels of RF can produce health effects (by heating tissue), exposure to low level RF that does not produce heating effects causes no known adverse health effects. Many studies of low level RF exposures have not found any biological effects. Some studies have suggested that some biological effects may occur, but such findings have not been confirmed by additional research. In some cases, other researchers have had difficulty in reproducing those studies, or in determining the reasons for inconsistent results.

2. What is FDA's role concerning the safety of wireless phones?

Under the law, FDA does not review the safety of radiation-emitting consumer products such as wireless phones before they can be sold, as it does with new drugs or medical devices. However, the agency has authority to take action if wireless phones are shown to emit radiofrequency energy (RF) at a level that is hazardous to the user. In such a case, FDA could require the manufacturers of wireless phones to notify users of the health hazard and to repair, replace or recall the phones so that the hazard no longer exists.

Although the existing scientific data do not justify FDA regulatory actions, FDA has urged the wireless phone industry to take a number of steps, including the following:

- Support needed research into possible biological effects of RF of the type emitted by wireless phones;
- Design wireless phones in a way that minimizes any RF exposure to the user that is not necessary for device function; and
- Cooperate in providing users of wireless phones

with the best possible information on possible effects of wireless phone use on human health.

FDA belongs to an interagency working group of the federal agencies that have responsibility for different aspects of RF safety to ensure coordinated efforts at the federal level. The following agencies belong to this working group:

- National Institute for Occupational Safety and Health
- Environmental Protection Agency
- Occupational Safety and Health Administration
- National Telecommunications and Information Administration

The National Institutes of Health participates in some interagency working group activities, as well
FDA shares regulatory responsibilities for wireless phones with the Federal Communications Commission (FCC). All phones that are sold in the United States must comply with FCC safety guidelines that limit RF exposure. FCC relies on FDA and other health agencies for safety questions about wireless phones. FCC also regulates the base stations that the wireless phone networks rely upon. While these base stations operate at higher power than do the wireless phones themselves, the RF exposures that people get from these base stations are typically thousands of times lower than those they can get from wireless phones. Base stations are thus not the subject of the safety questions discussed in this document.

3. What kinds of phones are the subject of this update?

The term “wireless phone” refers here to hand-held wireless phons with built-in antennas, often called “cell”, “mobile”, or “PCS” phones. These types of wireless phones can expose the user to measurable radiofrequency energy(RF) because of the short distance between the phone and the user’s head. These RF exposures are limited by Federal Communications Commission safety guidelines that were developed with the advice of FDA and other federal health and safety agencies. When the phone is located at greater distances from the user, the exposure to RF is drastically lower because a person's RF exposure decreases rapidly with increasing distance from the source. The so-called "cordless phones," which have a base unit connected to the telephone wiring in a house, typically operate at far lower power levels, and thus produce RF

exposures far below the FCC safety limits.

4. What are the results of the research done already?

The research done thus far has produced conflicting results, and many studies have suffered from flaws in their research methods. Animal experiments investigating the effects of radiofrequency energy (RF) exposures characteristic of wireless phones have yielded conflicting results that often cannot be repeated in other laboratories. A few animal studies, however, have suggested that low levels of RF could accelerate the development of cancer in laboratory animals. However, many of the studies that showed increased tumor development used animals that had been genetically engineered or treated with cancer causing chemicals so as to be pre-disposed to develop cancer in the absence of RF exposure. Other studies exposed the animals to RF for up to 22 hours per day. These conditions are not similar to the conditions under which people use wireless phones, so we don't know with certainty what the results of such studies mean for human health.

Three large epidemiology studies have been published since December 2000. Between them, the studies investigated any possible association between the use of wireless phones and primary brain cancer, glioma, meningioma, or acoustic neuroma, tumors of the brain or salivary gland, leukemia, or other cancers. None of the studies demonstrated the existence of any harmful health effects from wireless phone RF exposures. However, none of the studies can answer questions about long-term exposures, since the average period of phone use in these studies was around three years.

5. What research is needed to decide whether RF exposure from wireless phones poses a health risk?

A combination of laboratory studies and epidemiological studies of people actually using wireless phones would provide some of the data that are needed. Lifetime animal exposure studies could be completed in a few years. However, very large numbers of animals would be needed to provide reliable proof of a cancer promoting effect if one exists. Epidemiological studies can provide data that is directly applicable to human populations, but 10 or more years follow-up may be needed to provide answers about some health effects, such as cancer. This is because the interval between the time of

exposure to a cancer-causing agent and the time tumors develop — if they do — may be many, many years. The interpretation of epidemiological studies is hampered by difficulties in measuring actual RF exposure during day-to-day use of wireless phones. Many factors affect this measurement, such as the angle at which the phone is held, or which model of phone is used.

6. What is FDA doing to find out more about the possible health effects of wireless phone RF?

FDA is working with the U.S. National Toxicology Program and with groups of investigators around the world to ensure that high priority animal studies are conducted to address important questions about the effects of exposure to radiofrequency energy (RF). FDA has been a leading participant in the World Health Organization International Electromagnetic Fields (EMF) Project since its inception in 1996. An influential result of this work has been the development of a detailed agenda of research needs that has driven the establishment of new research programs around the world. The Project has also helped develop a series of public information documents on EMF issues.

FDA and the Cellular Telecommunications & Internet Association (CTIA) have a formal Cooperative Research and Development Agreement (CRADA) to do research on wireless phone safety. FDA provides the scientific oversight, obtaining input from experts in government, industry, and academic organizations. CTIA-funded research is conducted through contracts to independent investigators. The initial research will include both laboratory studies and studies of wireless phone users. The CRADA will also include a broad assessment of additional research needs in the context of the latest research developments around the world.

7. How can I find out how much radiofrequency energy exposure I can get by using my wireless phone?

All phones sold in the United States must comply with Federal Communications Commission (FCC) guidelines that limit radiofrequency energy (RF) exposures. FCC established these guidelines in consultation with FDA and the other federal health and safety agencies. The FCC limit for RF exposure from wireless telephones is set at a Specific Absorption Rate (SAR) of 1.6 watts per kilogram (1.6 W/kg). The FCC limit is consistent with the safety standards developed by the Institute of

Electrical and Electronic Engineering (IEEE) and the National Council on Radiation Protection and Measurement. The exposure limit takes into consideration the body's ability to remove heat from the tissues that absorb energy from the wireless phone and is set well below levels known to have effects. Manufacturers of wireless phones must report the RF exposure level for each model of phone to the FCC. The FCC website (http://www.fcc.gov/oet/rfsafety/) gives directions for locating the FCC identification number on your phone so you can find your phone's RF exposure level in the online listing.

8. What has FDA done to measure the radiofrequency energy coming from wireless phones ?

The Institute of Electrical and Electronic Engineers (IEEE) is developing a technical standard for measuring the radiofrequency energy (RF) exposure from wireless phones and other wireless handsets with the participation and leadership of FDA scientists anring the rate at which RF is deposited in the heads of wireless phone users. The test method uses a tissue-simulating model of the human head. Standardized SAR test methodology is expected to greatly improve the consistency of measurements made at different laboratories on the same phone. SAR is the measurement of the amount of energy absorbed in tissue, either by the whole body or a small part of the body. It is measured in watts/kg (or milliwatts/g) of matter. This measurement is used to determine whether a wireless phone complies with safety guidelines.

9. What steps can I take to reduce my exposure to radiofrequency energy from my wireless phone?

If there is a risk from these products--and at this point we do not know that there is--it is probably very small. But if you are concerned about avoiding even potential risks, you can take a few simple steps to minimize your exposure to radiofrequency energy (RF). Since time is a key factor in how much exposure a person receives, reducing the amount of time spent using a wireless phone will reduce RF exposure.

- If you must convict extended conversations by wireless phone every day, you could place more distance between your body and the source of the RF, since the exposure level drops off dramatically with distance. For example, you could use a headset and carry the wireless phone away from

your body or use a wireless phone connected to a remote antenna

Again, the scientific data do not demonstrate that wireless phones are harmful. But if you are concerned about the RF exposure from these products, you can use measures like those described above to reduce your RF exposure from wireless phone use.

10. What about children using wireless phones?

The scientific evidence does not show a danger to users of wireless phones, including children and teenagers. If you want to take steps to lower exposure to radiofrequency energy (RF), the measures described above would apply to children and teenagers using wireless phones. Reducing the time of wireless phone use and increasing the distance between the user and the RF source will reduce RF exposure.

Some groups sponsored by other national governments have advised that children be discouraged from using wireless phones at all. For example, the government in the United Kingdom distributed leaflets containing such a recommendation in December 2000. They noted that no evidence exists that using a wireless phone causes brain tumors or other ill effects. Their recommendation to limit wireless phone use by children was strictly precautionary; it was not based on scientific evidence that any health hazard exists.

11. What about wireless phone interference with medical equipment?

Radiofrequency energy (RF) from wireless phones can interact with some electronic devices. For this reason, FDA helped develop a detailed test method to measure electromagnetic interference (EMI) of implanted cardiac pacemakers and defibrillators from wireless telephones. This test method is now part of a standard sponsored by the Association for the Advancement of Medical instrumentation (AAMI). The final draft, a joint effort by FDA, medical device manufacturers, and many other groups, was completed in late 2000. This standard will allow manufacturers to ensure that cardiac pacemakers and defibrillators are safe from wireless phone EMI.

FDA has tested hearing aids for interference from handheld wireless phones and helped develop a voluntary standard sponsored by the Institute of Electrical and Electronic Engineers (IEEE). This standard specifies test methods and performance requirements for hearing aids and wireless phones so

that no interference occurs when a person uses a "compatible" phone and a "compatible" hearing aid at the same time. This standard was approved by the IEEE in 2000.
FDA continues to monitor the use of wireless phones for possible interactions with other medical devices. Should harmful interference be found to occur, FDA will conduct testing to assess the interference and work to resolve the problem.

12. Where can I find additional information?

For additional information, please refer to the following resources:

- FDA wed page on wireless phones
  (http://www.fda.gov/cellphones/)
- Federal Communications Commission(FCC) RF Safety Program
  (http://www.fcc.gov/oet/rfsafety/)
- International Commission on Non-ionizing Radiation Protection
  (http://www.icnirp.de/)
- World Health Organization(WHO) International EMF Project
  (http://www.who.int/peh-emf/en/)
- National Radiological Protection Board(UK)
  (http://www.hpa.org.uk/radiation/)

LIMITED WARRANTY STATEMENT

LG ELECTRONICS Inc. represents and warrants that this subscriber unit and its accessories ("PRODUCT") is free from defects in material and workmanship.
This warranty is subject to the following terms and conditions;

1. This warranty of the PRODUCT extends for a period of 12 months commencing from the date of the activation or 15 months from the date of manufacture whichever is less, except for the battery, for which the warranty is 9 months from the date of activation or 12 months from the date of manufacture whichever is less.
2. During the warranty period, LG ELECTRONICS Inc. or its authorized service network will repair or replace, at LG ELECTRONICS Inc.'s option, the PRODUCT or any relevant parts thereof in the event that the PRODUCT is found to be defective. The repaired PRODUCT or the Product/part provided as a replacement for a defective PRODUCT/part, shall be free from defects. The END USER/consumer purchaser of the PRODUCT or his/her assignee ("CONSUMER") shall not be charged (whether for parts, labour or otherwise) for the repair or replacement of a defective PRODUCT during the warranty period. All replaced parts, boards or equipment shall become the property of LG ELECTRONICS Inc.
3. The warranty in respect of a repaired or replaced PRODUCT/part shall extend for the remaining warranty period of the repaired PRODUCT or replacement thereof to the CONSUMER.
4. Upon request from LG ELECTRONICS Inc. , the CONSUMER may be required to provide the purchase receipt or other documentation or information in respect of the date and place of purchase.
5. The CONSUMER shall have no coverage or benefits under this warranty in the event that any of the following conditions are applicable:
   (a) The PRODUCT has been subject to abnormal use or conditions, improper storage, exposure to excessive moisture or dampness, exposure to excessive temperatures, unauthorized modifications, unauthorized repair (including but not limited to use of unauthorized spare parts in repairs), abuse, accident, Acts of God, spills of food or liquids, improper installation and breakage or damage to antennae (otherwise than by reason of any defects in material or workmanship).
   (b) LG ELECTRONICS Inc. has not been notified by the CONSUMER of the defects of the PRODUCT during the applicable warranty period.

(c) The PRODUCT serial number code or the accessory date code has been removed, defaced or altered.

(d) The PRODUCT has been used with or connected to an accessory (i) not supplied by LG ELECTRONICS Inc. or its affiliates, (ii) not fit for use with the PRODUCT or (iii) used otherwise than in the manner intended.

(e) The seals of the PRODUCT'S battery enclosure have been broken or show evidence of tampering or the PRODUCT'S battery has been used in equipment other than that for which it has been specified usable by LG ECLECTRONICS Inc.

(f) All plastic surfaces and all other externally exposed parts that are scratched or damages due to normal customer use.

(g) Breakage or damage to antenna unless caused by defects in material or workmanship.

6. In order to derive the benefits of this warranty in respect of any defects in the PRODUCT, the CONSUMER shall ship the PRODUCTS or part thereof at its cost to the authorized service center of LG ELECTRONICS Inc. LG ELECTRONICS Inc. shall bear the cost of shipping the PRODUCT or part thereof back to the CONSUMER after the completion of the service under this limited warranty.

   NO OTHER EXPRESS WARRANTY IS APPLICABLE TO THIS PRODUCT. THE DURATION OF ANY IMPLIED WARRANTIES, INCLUDING THE IMPLIED WARRANTY OF MARKETABILITY OR MERCHANTABILITY OR FITNESS FOR A PARTICULAR PURPOSE OR USE IS LIMITED TO THE DURATION OF THE EXPRESS WARRANTY HEREIN. LG ELECTRONICS Inc. SHALL NOT BE LIABLE FOR THE LOSS OF USE OF THE PRODUCT, INCONVENIENCE, LOSS OR ANY OTHER CONSEQUENTIAL DAMAGE, ARISING OUT OF THE USE OF, OR INABILITY OF USE, OF THIS PRODUCT OR FOR BREACH OF ANY EXPRESS OR IMPLIED WARRANTY, INCLUDING THE IMPLIED WARRANTY OF MARKETABILTY OR MERCHANTABILITY OR FITNESS APPLICABLE TO THIS PRODUCT.

   THE CONSUMER UNDERSTANDS THAT LG ELECTRONICS INC. HAS EMBEDDED RELIANCE SOFTWARE AND ITS NETWORK PARAMETERS IN THE PRODUCT. IN CASE THE CONSUMER DELETES, REMOVES, ALTERS OR MODIFIES SUCH SOFTWARE AND THE PARAMETERS AND/OR INSTALLS ANY THIRD PARTY SOFTWARE, THE WARRANTY AND REMEDIES HEREUNDER SHALL NOT BE AVAILABLE TO THE CONSUMER.

7. It is hereby expressly clarified that all warranties (express or implied) in respect of the PRODUCT are provided by LG ELECTRONICS Inc. alone.

Service Center List

Subject to change without prior notice.

	Circle	City	ASCs Name	Address	Contact Person	Phone
1	Andhra Pradesh	Hyderabad	Bhagya Communications	Shop no:109, Upper Ground Floor,#12-2-825, S.G.M. Mall, Mehdipatnam, Hyderabad-500028.	Mr.Bipin	9399334493,040-32972308/ 32001406
2	Andhra Pradesh	Guntur	Vasavi Associates	Shop No:21,Central Plaza,Naaz Center,Guntur-522001	MR.Satyam	08633957789, 9397602470, 9848105789
3	Andhra Pradesh	Hyderabad	JVR Infotech Pvt Ltd	Shop No 8 ,Vaniya Vihar,Nalanda Building, Dilsukh Nagar Main Road, Hydrabad-500060	EV Ramakanth	040-24161848, 040-55109604, 9391047214, 9391363047
4	Andhra Pradesh	Hyderabad	Reliable Communication	G-8, 3-6-561, AALTO'S A & M Trade Centre, HIMAYATNAGAR, HYDERABAD - 500029	Mr.Sandeep.soni	04032913251,09346320705, 09849251173
5	Andhra Pradesh	Hyderabad	S V Electronics	Shop No. 41, Nilagiri Block, Aditya Enclave, Ameerpet Main Road, Hydrabad-500038	Mr.Pradeep	040-55754477, 9346449323, 040-32977389
6	Andhra Pradesh	Hyderabad	Shweta Communications	Shop No.9, Ground Floor, Pavani Ansuya Complex, Opp. Huda Complex, Tarnaka, Hyderabad	Mr. Sandeep Heda	04-32968162, 9346698606,
7	Andhra Pradesh	Hyderabad	Sri Varun Electronics	D.No 5-8-344/1, " DHAN BHAGYA ESTATE ", Chirag Ali Lane, Abids, Next to Raghava Ratna Towers, Hyderabad - 500 001	Mr.Alokh Mohan	9346263736, 040-32900909, 040-55781999,
8	Andhra Pradesh	Hyderabad	Sri Surya Communications	#Madhu Enclave,Street no 06,Shyamlal Buildings, Begumpet , Hyderabad	Mr.Nageswara Rao	9346940701,9347325450, 040-32961127
9	Andhra Pradesh	Hyderabad	Sreenivasa Technologies	SAI VIKRAM TOWERS,SHOP NO :4,RELIANCE WEB WORLD BUILDING, Balagi Nagar Kukatpally	Mr.Praveen	040-32961479, 9347033153
10	Andhra Pradesh	Cuddapah	Srinivasa Communication	Shop No.4, Siddapriya Complex, Opp. HP Petrol Pumping Point, Cuddapah	Mr.Sahadeva Reddy	9346350224
11	Andhra Pradesh	Kakinada	Delta Infotech	Door No. 6-1-29, Opp. Swami Vivekananda Park, Jawahar Street, Surya Rao Pet, Kakinada - 533001	Mr. Shivanand	0884-5593533 9346846009
12	Andhra Pradesh	Khammam	Sriven Technologies	D.No:11-2-37,Shop No.3, D.V.Krishna Complex, Beside Baburao Petrol Bunk, Balaji Nagar, Wyra Road, Khammam-507002	Mr.Bhaskar Reddy	08742395567 / 9399330461
13	Andhra Pradesh	Kurnool	R K LG CDMA	Shop no:13, First floor, UCON Plaza, Kurnool-518001	Mr.G Rama Krishna	08518-220201, 09393810688, 9848076354
14	Andhra Pradesh	Mahabubnagar	SRI Chakra mobile care centre	Shop,no:15,Shareef Complex,Near Bus stand, Mahbubnagar - 509002	Mr.Anil	9396348999, 9396333111
15	Andhra Pradesh	Nellore	Siri Enterprises	Co-Operative Bank Complex, 1st Floor,Shop No: 26,Near Gandhi Statue, G.N.T.Road, NELLORE. Andhra Pradesh.	Mr.Pratap	861-3290339, 9398309571, 9347100309
16	Andhra Pradesh	Rajamundhary	Siri Infotech	Police Welfare Complex,City Hospitals Junction,Danvai Pet Main Road,Rajhamundry-533103	Mr Raghvendra	0883-2421567,09397925799
17	Andhra Pradesh	Secundrabad	Shweta Computers	# 1-7-69/1 & 2, OPP Aditya Delux Hotel,Near Paradaise circel, Sarojini Devi Road, Secunderabad - 500003	Mr.Jagdish	040-27721076, 040-32977548, 09396532358, 09391041673
18	Andhra Pradesh	Shad Nagar	Sri Gana Electronics,	Shop No : 2, Khaja Veeresam Complex, College Road, Shadnagar - 509216	Mr.Vigneswar	9392633111
19	Andhra Pradesh	Tirupathi	CMT Computer Services	18-1-624 VV Mahal Road,OPP HDFC BANK, Tirupathi, PIN-517501	Mr.K Vasu Naidu	9393620209, 0877-3296979
20	Andhra Pradesh	Vijaywada	K L Computer House	39-9-46 SVS Temple Street,Labbipet,Vijaywada PIN- 520 010	Mr.Kartik	0866-5520461/ 5671461, 09392105222
21	Andhra Pradesh	Vijaywada	V V Communications	28-23-31/32,OPP.SWARUGHA FOODS,VIJAY TALKIES CENTER,VIJAYAWADA	Mr.Rahul	9396467789

Service Center List

Subject to change without prior notice.

	Circle	City	ASCs Name	Address	Contact Person	Phone
22	Andhra Pradesh	Visakhapatnam	GVS Enterprises	G5, Ground Floor, Backside of Sangam-Sarat Theatre, 1st Lane, Dwarka Nagar, Visakhapatnam - 530 016.	Mr. Satish Kumar	0891-2598610, 9394206074, 0891-3956263
23	Andhra Pradesh	Warrangal	S S Marketers	6-1-73/1,Sai Bhavan, Sridevi Theatre Road, Hanamkonda, Warrangal-506001	Mr.L.Srinivas Rao	0870-2552223,09390100708
24	Bihar	Patna	Competent Mobile Service	Shop 1, Hotel Lalitha Complex, East Bowring Canal Road, Patna	Mohit Ahluwalia	9334022706
25	Bihar	Patna	Infotek Trading Company	1st floor, City Palace, New Dak Bunglow Road, Patna-800001	Sanjay Chowbey	0612-2227166
26	Bihar	Patna	Synerzy Trading Company	G-01, Chanakya Plaza Complex, Main Road, Kankarabagh, Patna.8000020	Mr.Vikas Chandra	0612-2356900, 09334409609
27	Chhatisgarh	Bhilai	R B automation	Shop No 117 , Ground Floor , Chouhan Estate , Supela	Mr. Harish Singh	9329750711
28	Chhattisgarh	Raipur	Cybernet Systems	B-2,1st Floor, Garchaz Complex, Jail Road, Raipur - 492001	Anand Singh	077-15069971
29	Delhi	Delhi	Active Telecom	Shop No.1, CW 242, Sanjay Gandhi TPT Nagar, Delhi	Mr. Shailendra Garg	011 39627080, 9311227080
30	Delhi	Delhi	Aegiss Infotech	UG-25 , Ansal Chamber -2, 6, Bhikaji Cama Place - New Delhi-110066	Mr. Atul Gupta	55477740 , 9312294105, 9313796774.
31	Delhi	Delhi	Arham Infotech Services	1/1, Regal Building, Near Malik Sweets, Connaught Place New Delhi - 110 001.	Mr. Anil Surana	011-41501124, 011-39584421
32	Delhi	Delhi	Cornhard Systems	D-30,31, First floor, Near Hotel Shipra, Main Vikas Marg, Lakshmi Nagar	Mr Ravi Kant Gupta	011-30955887, 9818867678
33	Delhi	Delhi	Cornhard Systems	B-120, Hardev Puri, 100 Feet Main Road, Near MTNL Office, Nathu Colony Chowk,Shahdra, New Delhi - 110 093.	Mr. Ravi Kant Gupta	011-39572430 , 011-39572427
34	Delhi	Delhi	Connexions and Communications	183, Avtar Enclave , Opposite Nirula's , Pashchim vihar, New Delhi-110063	Mr. Bhupinder Agrawal	011-39451431, 011-55237374
35	Delhi	Delhi	Cube Engineers and Consultants Pvt Ltd	A-65, Naraina Industrial Area, Phase-1, New Delhi	Atul Gupta	09312224103, 011-55450272, 41411623
36	Delhi	Delhi	Innovative Telecom	304, GDITL Northex Towers, A-09 ,3rd Floor, Northex Tower, Netaji Subhash Place - Pitampura, New Delhi - 110 088.	Mr Manoj Garg	011-32925753, 011-55154343, 9811682453.
37	Delhi	Delhi	Nice Telecommunication	15/19 & 15/21, DDA Complex, Nangal raya, Near D Block, Janakpuri, Delhi - 110046	Ripul Garg	011-39607072, 0-9213264403
38	Delhi	Delhi	R K Communications	2516 Hudson Lines , Kingsway Camp-Nr. Kamla Nagar, New Delhi	Mr. Pradeep Aggarwal	011-39508861
39	Delhi	Delhi	Sagar Technologies	W-8, First Floor,Main Patel Road,West Patel Nagar, New Delhi- 110008	Mr Deepak/Mr Amit	9810320170,011 55433100
40	Delhi	Delhi	Sagar Technologies	J-39,Central Mkt, Lajpat Nagar-II, New Delhi-110024	Mr.Manoj	011- 55425644, 011-55425645
41	Delhi	Delhi	Sukriti Communication	101 Patparganj- Mayur Vihar phase -1 - New Delhi -110091	Mr.Dipendra kumar chaturvedi	011-39498011, 011-55238011
42	Delhi	Delhi	Touch Tone Telecom	B-52, First Floor,Kalkaji, New Delhi	Ashish Dey	11 32939031
43	Delhi	Delhi	Ucom Technologies Pvt Ltd.	45, 1st Flr, Corner Mrkt, Malviya Nagar, New Delhi - 110017	Mr. Rajeev Tiwari	011-41745458, 09350833388

Service Center List

Subject to change without prior notice.

	Circle	City	ASCs Name	Address	Contact Person	Phone
44	Gujarat	Ahmedabad	A Com Technologies	Shop No-40, 1st Floor, Shubh Complex,Near Rajasthan Hospital, Camp Road,Shahibaug, Ahmedabad-380004	Vijay.S.Gohel	9824544230, 079-30940560
45	Gujarat	Ahmedabad	Mishree Communication	12, Akshar Commercial Complex, Opp. Kalupur Coop.Bank, Near Apollo Clinic, Shivranjani Cross Road, Satellite, Ahmedabad 380015.	Mitesh Patel	09327037582,
46	Gujarat	Ahmedabad	Silicon Valley	F/6.Silver lake,Jagabhai Park,Rambaug Road,Maninagar,Ahmedabad-380008	Rajesh Patel	079-25430634, 9824025430
47	Gujarat	Ahmedabad	Visual Enterprises	104, Saarthak Complex, behind Urja House, Swastik Char Rasta, Navrangpura, Ahmedabad-380009	Vallabh Patel	079-26463305,9376171851
48	Gujarat	Anand	Desktop Infosystems	B/10, Vaibhav Tower, V V Nagar Road, Anand	Dipesh Patel	02692-249117, 246885, 248470,9375031617
49	Gujarat	Bhavnagar	Shivshruti Services	98/B,Makvana Building,Down Chowk,Bhavnagar,364001	Mr.P D Jala	0278-3092396
50	Gujarat	Gandhinagar	Creative Communications	Shop No 102,Suman City,Sector 11,Gandhinagar-382011	K.J.Barot	079-23226241,9825059590
51	Gujarat	Jamnagar	Sudarshan Infosys	"Shraddha", Park Colony, Motor House, Near UTI Bank, P.N.Marg, Jamnagar 361008	Amit Unadkat	0288-2552696,9824478203, 9377552696
52	Gujarat	Rajkot	Roopang infocare	Vinod Nivas,4,Sardarnagar(West),Nr Astron Cinema, Rajkot-360001	Kishore Patel	0281-2464485 ,9824477555
53	Gujarat	Surat	Excel Solutions	S-3, Ground Floor, Ruchi Flats, Opp: Bhulka Bhawan School, Near Iqara Bldg., Adajan Hazira Road, Surat-395009.	Nitesh Jain	0261-5544500,09327344500
54	Gujarat	Surat	Omsai Services	39,Golden Point,Near Science Laboratory,Ring Road, Surat -3940003	Dharmesh Patel	0261-5593716,9374710610, 9825406129
55	Gujarat	Surat	Yas Telecom	323,Bhatiya Complex,Opp.Petrol pump,Bamroli Road,Sosyo Circle,Surat.-395002	Rehan Shaikh	9377172001
56	Gujarat	Vadodara	Shreeji Communication	GF 13, Sterling Shopping Center,R.C.Dutt Road,Alkapuri, Vadodara - 390002	Mr.Jignesh Maru	0265-3059363,9328093424
57	Gujarat	Vapi	Klassik Statino Products	116,Bhanudarshan Co-Op Society, Koparli Road, Near Gunjan Cinema, GIDC, Vapi	Avishek Suhasaria	0260-3092363, 9377000911
58	Haryana	Ambala	Bee Ess Aar Communication	92-93, Gandhi market, Ambala Cantt-133001	Rajiv Gupta	0171-2641234,9416021234
59	Haryana	Bhiwani	Sandeep Electronics	10 th Plot, First Floor, Circular road, Mahem Gate Chowk, Near Dr. Kajal's Nursing Home, Adjacent to Rameshwar's Sweet House, Bhiwani, Haryana - 127021	Mr.Sukhveer Saini	01664-252000, 09315377909
60	Haryana	Faridabad	Comsoft Computers	601/1 Gopi Colony Chowk- Sector-19 , Near Prem Prakash Ashram, OLD Faridabad-121002	Mr. Ashwani Jindal	0129-5521456, 0129-3093512 , 9310977888 ,
61	Haryana	Faridabad	VR Infocomm	Shop No.3 , Plot No 61 , Neelam Bata Road , NIT Faridabad - Main Market Nr. Bajaj Showroom.	Mr. Vinod Kumar Gupta.	0129-4031959.
62	Haryana	Gurgaon	Lalji Communication	SCO-31, - First Floor, Above MTNL Sanchar Haat, Main Market, Opp. BSNL Exchange, Sector-12A, OLD Gurgaon -122001.	Mr.Bharat Bhushan	95124-3200900
63	Haryana	Gurgaon	Signature Communications	B-100 A , South City - 1 , Opposite - Huda Gymkhana Club - Gurgaon 122001	Raj Kumar Garg	0124-3956565, 0124-5102709
64	Haryana	Hissar	Parnami Communication	32,Neel Kamal Complex,Red sqaure Market,Near Elite Cinema Hall, Hissar, Haryana-125001	Mr.Pradeep Garg	09354332000, 9315867532
65	Haryana	Karnal	Mass Communication	Shop No.69, Main Market, Ground Floor, Moughal Canal, Karnal - 132001	Mr.Harish	0184-3290717,9354761148

Service Center List

Subject to change without prior notice.

	Circle	City	ASCs Name	Address	Contact Person	Phone
66	Haryana	Panipat	INS Telecom	2,Bishan Sarup Colony, Opp Bus Stand, Near Hotel Deep, Panipat	Jagdeep Sachdeva	0180-3291860,0180-4005360
67	Haryana	Rohtak	Telecentre	Shakti Market, Civil Hospital Road, Near Chhotu Ram Chowk, Rohtak-124001	Mr.Madaan	01262-247242, 09355671666
68	Haryana	Sonipat	Teleworld	Shop No 20,1st Floor,M.C.Market,Subhash Chowk, Sonipat, Haryana-138001	Vipin Dua	0130-3290889,
69	Haryana	Yamunanagar	Manish Communications	Shop No.3, Sharma Colony, Near Mahindra Petrol Pump, Yamunanagar - 135005	Vinod Kumar Mittal	9355327374, 01732-233277
70	JHARKHAND	BOKARO	Digital Equipment Centre	GB-11,City Palace,Opp.Indian Bank,Bokaro.	Dewashish Ojha	9334072270
71	Jharkhand	Dhanbad	Nirmala Entreprises	Ground Floor, Muskan Complex, Nr.Subhash Chowk, Dhanbad.	Mr.Niraj Sinha	9334027583
72	Jharkhand	Jamshedpur	Tirupati Teletech	Chakravarti Compound,Near Hotel Castel,Contractors area, Bistupur, Jamshedpur-831001	Abhijeet Mukherjee	9334800350
73	Jharkhand	Ranchi	Satya Systems & Solutions	158, Opp Hotel Palace, Kadru, Ranchi-834002	Amit Rastogi	0651-2341361,9835167667
74	Karnataka	Bijapur	Turning point computers	Khed building,opp Vijaya college,Sholapur road, Bijapur-586103	S.M.Hiremath	94483-53070, 93421-93521/ 08352-329318
75	Karnataka	Bangalore	Ascent Communication	No:113, St Johns Church road, Bangalore - 560005	Mr.Kumaresan	080-32914856
76	Karnataka	Bangalore	Insta Service Point	NO:64,Mission road, SATHI COMPLEX, BANGALORE-27	Mr.Venkatesh	080-22107560 / 32970962
77	Karnataka	Bangalore	Optima Mobile Services	24/2,Dr.Rajkumar Road, Near Subramanyanagar Police Station, 2nd Block, Rajajinagar, Bangalore - 560 010	Unni Krishnan	080-23131953, 080- 57722205, 09341266656
78	Karnataka	Bangalore	Optima Mobile Services	P-3, Mallikaarjun Complex, Opp R T Nagar Police Station, 80 Feet Road, R T Nagar, Bangalore-560032	Ms.Nirmala	080-32710202 / 08041492033
79	Karnataka	Bangalore	Pranav infocom	91/92 ,Hemachandra complex,Near VGP Show room, 4th block,jayanagar,Bangalore-560011	S.V.Sirish	080-26639564, 26552551, 98457-60350
80	Karnataka	Bangalore	Pranav infocom	267/1,1st Main Road,6th Cross, Behind Shanti Sagar, Domlur Layout, Bangalore-560071	S.V.Sirish	080- 56969937, 51256309
81	Karnataka	Belgaum	Hello India Telecom	G-4,Maratha Mandir Complex, Khanapur Road, Near Railway Flyover, Belgaum - 590 001.	Mr.Mohan	09341101800,0831-2420533, 93424-41998
82	Karnataka	Davangere	Kruthika Communication	Shop No: 6, Park View Plaza, (Income Tax Office's Ground Floor) , 4th Main, Near Vishweshwaraiah Park, P.J. Extension, Davangere-577002	Sujay	8192-395444 / 93422-53666
83	Karnataka	Gulbarga	Aishwaraya Communication	C-3, Asian Plaza S.V.P.Chowk Main road Gulbarga-585102	Mallikarjun	9342355116, 08472-329447/ 93438-02000
84	Karnataka	Hubli	Shruti Services	shop no : B6, Laxmi complex, Court circle , Hubli- 580020	Mr.Mahendar	0836-3290671,93412-10890
85	Karnataka	Mangalore	Innovative Infocom	15-10-537/11, Jayavarma Centre, Mallikatte Circle, Kadri, Mangalore - 575002.	SEBASTIAN FERNANDES	0824-5663244,93411-10027
86	Karnataka	Mysore	K.K.Marketing,	1432/9, Tribhuvan Towers, opp Vetenary Hospital, Dewan's Road, Dhanwantri Road Cross, Mysore -570001	Mr. Karunakaran.	09342120789, 0821-3120789 / 093421-15003
87	Karnataka	Udupi	Sanman Mobile Services	Shop No: 15, Simaz complex, Diana circule, Court road, Udupi- 576101.	Mr. Prakash	9880927864,0820-3955770, 93431-63334,

Service Center List

Subject to change without prior notice.

	Circle	City	ASCs Name	Address	Contact Person	Phone
88	Kerala	ALLEPPY	GETRONICS	FIRST FLOOR,KARTHIKA BUILDING,OPP SDV BOYS HIGH SCHOOL,COURT ROAD,ALLEPPY.	OMPRAKASH	0477-3090446
89	Kerala	Ernakulam	TELETECH SYSTEMS	SHOP NO-5, SUNNY ESTATES, MAMANGALAM PALARIVATTAM, COCHIN-682025.	SONY THOMAS	0484-3207554 98 472 80093
90	Kerala	Ernakulam	Zenicon Infocom(P) limited	Building No 39 / 5473, Alappat Cross Road, Ravipuram, Cochin -15.	Jaimon Joseph	0484-2359511, 9349271511
91	Kerala	Irinjalkuda	Akbar Mobiles	376-44, Near St. Josephs college junction,Irinjalakuda-680121	Mr Sebastian	0480-3091515
92	Kerala	KANNUR	SAHAR COMMUNICATIONS	SB-666-C & D, PRESTIGE CENTRE, GROUND FLOOR, SUB REGISTER OFFICE ROAD, KANNUR.	AJAI ABHIRAM	9387218065,0497-3098585
93	Kerala	Karunagapally	Supreme Enterprises	Opp to KSRTC Bus stand,Karunagapally-690518	Mr. Ratish	0476-2620282
94	Kerala	Kollam	Digital Infosystems	MC-3087, New Block, Bishop Jeromi Nagar, Chinnakada, Kollam-691001	Johnson Lawrence	0474-2760647,3091781
95	Kerala	Kottayam	SVM Technologies	NSS Building, Near Pallippurathukavu Temple, Kodimapha,Kottayam - 686 002	Rajesh K S	0481-2565303,9847310123
96	Kerala	Kozhikode	Domain Infosystems	Domain Infosystems, 2nd Floor, Darussalam Complex, Mavoor Road, Kozhikode - 673 004	Mukundan	0495-2722222
97	Kerala	Manjeri	Integrated Computer Systems	Royal Tower, TB Road, Manjeri - 676121	Mr. Thomason Chacko	0483-3099686
98	Kerala	Pallakad	Akbar Mobiles	N.S. Towers,Kalamandapam junction,Palakkad - 678 001	Suresh	0491-2529829,9847086446
99	Kerala	Thiruvananthapuram	Appolo Systems	Thelungu Chetty Complex, Shop No 23-24, Kalpalayam JN Karamana, Thiruvananthapuram 695 002.	Santosh	0471-2340523
100	KERALA	TRICHUR	CELL TECH	SHOP NUMBER 5B,TC23/326,N.P.TOWER,GURUVAYOOR ROAD,WEST FORT	SANTOM KALLOOR	9387415222
101	Madhya Pradesh	Bhopal	Akanksha Enterprises	25-26 , CENTRAL MARKET , ROSHANPURA SQUARE , BHOPAL , MP	Mr. Dinesh Asija	7553201626
102	Madhya Pradesh	Bhopal	Neha Sales Corporation	F-104, Anmol Tower, E-5/14, Commercial Zone, Arera Colony, Bhopal-462016	Ashok Hirwani	93001327923
103	Madhya Pradesh	Gwalior	Galav Computers	Ground floor ,Ganpati Plaza , City Centre , Gwalior	Pradeep Dixit	9425120821
104	Madhya Pradesh	Indore	Ayushi Electronics	UG-10,Ratnamani Complex, 7/1,New Palasia, Indore-452001	Santosh Dwivedi	0731 - 3251284
105	Madhya Pradesh	Indore	Apurva Electronics	UG 11 , B M Tower , Sapna Sangeeta Road , Opp. Lotus , Indore	Nitin Kulkarni	9300348666
106	Madhya Pradesh	Jabalpur	Sri Sai Communication	SHOP NO : 2, GOODWILL APPARTMENT, ANAND TALKIS ROAD, JABALPUR.	MOHIT SAREEN	09300644201
107	Madhya Pradesh	Ujjain	Galaxy Computers & Communication	43/2, Varruchi Marg,Opp Madhav Nagar Police Staion, Freeganj, Ujjain	Anurag Chhajjhani	0734-2515995, 2530777
108	Maharashtra	Amravati	Scorpio Services	Shop No. 84, Ground Floor,GulshanTowers, Nr. Panchasheel Cinema, Amrawati, Pin-444601	Mr. Pramod	0721-2567302, 09370151826
109	Maharashtra	Aurangabad	Unique Teletmatics	Shop no.108/B,Behind Sajawat Handloom, Tapdiya Super Market, Nirala Bazar, Aurangabad-431001	Mr. Mahesh	0240-2356447,9823007730, 09325210364

Service Center List

Subject to change without prior notice.

	Circle	City	ASCs Name	Address	Contact Person	Phone
110	Maharashtra	Chinchwad (Pimpri)	Ritz Communication	Shop No 22, Gawde Kunal garden,Pimpri-Chinchwad Link Road, Chinchwad, Pune-411033	Mr Reyaz	020-7485613, 020 30961900, 09890339777
111	Maharashtra	Jalgaon	GLOBAL ENTERPRISES	E-81, 1st floor, Golani Market, Jalgaon -425001	Mr. Pramod	0257-2236899, 9370164545
112	Maharashtra	Kohlapur	SMS Services	S5, Diwan Tower, Opp. Nutan Marathi School, Near Mirajkar Tikkty, Kolhapur, Pin -416005.	Prakash Patil	0231-2541120,9823026120
113	Maharashtra	Margoa	Comlink Synergies India Pvt Limited.	Ground Floor, Shop No.i,Garden view building,,Next to UTI Bank , Near Margao Municipal Garden,Margao-403601	Sunil	0832-3291001, 9326105637
114	Maharashtra	Nagpur	EPOCH SERVICES	274, B/8, Scendre Komplex, Chapru Nagar Square, Central Avenue, Nagpur 440008	Mr. Girish	0712-3244449, 09326047982
115	Maharashtra	Nagpur	Spectrum Marketing	Shop No.2, Dharampeth Towers, West High Court (WHC) Road, Dharampeth , Nagpur - 440010	Sonali	0712-2527823, 09373100692
116	Maharashtra	Nasik	MOBS Associates	SHOP NO. 12, FIRST FLOOR,'KAPOTE-MEHER' MARKET, RENUKA NAGAR, WADALA NAKA, DAWRKA, NASIK - 422 001.	Girish Bhangre	0253-5623613,09370291070, 09371531078
117	Maharashtra	Panjim	Comlink Synergies India Pvt Ltd	Shop No. 5 , Dr Atmaram Borkar Road, Next to RIL Mutual Fund, Panjim, Goa-403001	Sunil	0832-3291000, 9326105629
118	Maharashtra	Pune	Horizon	30, Time Square, Near Hotel Panchami, Pune Satara Road, Pune.	Mr. Nilesh Pundye	39501222 / 9325002399
119	Maharashtra	Pune	Mobile World	G-25,AKSHAY COMPLEX,DHOLE PATIL ROAD,PUNE-411 001	Pawan Mantri	30942268, 9325088055
120	Maharashtra	Sangli	Ramesh Electronics	Opp. Kanya Purohit prashala,Rajwada,Sangli-416416	Suresh Shegane	0233-2327601,9823085176, 09372107601
121	Maharashtra	Solapur	Jawaharlal Radio Service	184, Gold Finch Peth, nr Hotel Ritesh, Solapur - 413007.	Prasanna J Chavan	0217-2725030,9422458830, 9823317081
122	Mumbai	Mumbai	Grace Tele Services	Shop no 3, C/1, Manik Nagar Soc, Punjabi lane, Borivali (W), Mumbai 400092	Hemant	022-32455033, 9320355033
123	Mumbai	Mumbai	Trident Communications	8-A,Vasant Smruti, Dadasaheb Phalke Road, Beside "BharatKhsetra Building", Near Dadar station(E), Dadar -East, Mumbai - 400 014.	JYOTI	9323960027, 022-56047270
124	MUMBAI	KALYAN	M/S SKY LARK ASSOCIATES	Shop:1, 'A' Wing, Suresh Tower Co-op. Hsg. Soc, Opp. Municipal Vegetable Market, Santoshi Mata Road, Kalyan (W)	MR. NASEER	0251-3209899, 9324141999
125	Mumbai	Mumbai	Komplex Telecom Corporation	1,Satguru Shopping Center, IIIrd road, Khar(W), Mumbai	Mr. Haq	022-26461917, 9322416962, 09323395024
126	Mumbai	Mumbai	Absolute Networks	A007. Vishal Shopping Centre, Next to Vishal Hall, Near Station, M.V.Road, Andheri (E), Mumbai - 400 069	Arun	022 32544800, 022 26820900, 9324796183
127	Mumbai	Mumbai	Bombay Telecom Services	211, 212, Navjeewan Commercial Society. Building No:3., Second Floor, Above Hasmukh Tea, Mumbai Central (E),Mumbai: 400004.	Ajay	9323900612, 022 32566891
128	Mumbai	Mumbai	Creative Solutions	SHOP NO 6 AMBIKA COOPERATIVE HOUSING SOCIETY, JAWAHAR NAGAR ROAD NO 2 NEAR RAILWAY CROSSING, GOREGAON WEST, MUMBAI 400062	Anand	022-28769003, 9322356722
129	Mumbai	Mumbai	CYBER-GYAN CONVERGENCE & SERVICES (INDIA) PVT. LTD.	43/44, Gold Filled Plaza, Sion Bandra Link Road, Sion, Mumbai-400017	Mr. Jatin Parekh	022-32614914, 9322017251
130	Mumbai	Mumbai	G.P.ELECTRONIC	A/27, Gr. floor, Sagar Tech Plaza, Andheri-Kurla Road, Saki-Naka, Andheri (E), Mumbai 400072	Suyog / MAYUR	02232633960, 9322693369

Service Center List

Subject to change without prior notice.

	Circle	City	ASCs Name	Address	Contact Person	Phone
131	Mumbai	Mumbai	LG Service Centre	Third Floor, Trade World,Kamala Mills Compound, Senapati Bapat Marg, Lower Parel, Mumbai-400013	RAKESH / OMKAR	022-24947375 , 09323190401, 9323190404
132	Mumbai	Mumbai	PARAS TELECOM	2nd floor, Rear Side Capital Cinema Building, Wauddy Road, Opp. Mumbai CST Railway Station, Mumbai	CHETAN	022-326072572, 9323929062
133	Mumbai	Mumbai	Sai Tele Services	A-110, Satyam Commercial Complex, M.G.Road, Ghatkoper (E), Mumbai - 400 077.	ISHA	02232543982, 9324201030
134	Mumbai	Mumbai	TERABYTE	Shop 27, Vikas Paradise, Bhakti Marg, Off L.B.S. Road, Near R Mal, Mulund (W), Mumbai 400080	Mr. Chirag	022-56067666, 09323846578
135	Mumbai	Vashi	Hello World	Shop No 53,GF,Welfare Chambers,Sector-17,Vashi, Mumbai-400703	Mahesh	022- 32972537
136	Mumbai	Vashi	LG Service Centre- DAKC	H Block, Ground Floor, Dhirubhai Ambani Knowledge City, Navi Mumbai-400709	Rajnish	022-30386032, 09323190405
137	Mumbai	Panvel	Oceanic Tele System	Shop No.10, Prajapati Arcade,Sector 15, New Panvel (E), Dist. Raigad.	Swapnaja	022-56104542, 09322217221
138	Mumbai	Mumbai	VARAD ELECTRONICS	SHOP NO2, PRABHU CHAYA BLGD, PRABHU ALI, NEAR OLD GOVT. HOSPITAL, MANDAI, BHIWANDI, DIST THANE	BHIWANDI MANDAI	02522- 222653, 9323480787
139	MUMBAI	Mumbai	SAHIL INFOTECH	SHOP NO 11, GANESH NIWAS BLDG NO 3, NEAR CHARAI TELEPHONE EXCHANGE, CHARAI, THANE (W)	MR. SALIL	022-25381047, 09323003111
140	Mumbai	Vasai	E-Link Solutions	Shop No.5, Type C, Bldg no.5/6, Shanti Vihar, Mira Road -E, Pin Code : 401107.	OMKAR	022 39538643, 09323182084
141	Mumbai	Vashi	BEEKEYEN ENTERPRISES	Block No 1, Shop No. 17, Mahaveer Milan, Sector 28, Near Blue Diamond, Hotel, Vashi, New Mumbai	Mr. Joseph	022-56114304, 9324296068
142	MUMBAI	Virar	Siddhivinayak Tele Services	Shop no 5&6, Vishnu Prasad Complex, Opp Utkarsha School, Near S.T. Bus stand, P.P. Marg., Virar (West) Pin 401305. Land mark: Vishnu Pratibha Hall	Mrs. Yogita Kadam	0250-3258111, 9323134584
143	Orissa	Bhubaneswar	Agrawal Brothers	129/135,1st.Floor,Bharati Towers,Forest Park,Bhubaneswar.	Mr.Ashok Agrawal	0674-3950056
144	Orissa	Bhubneshwar	S.A.INFOSYS	291.Bomikhal, Opp.Akamra cinema hall, Bhubaneswar-751010	Sarabjeet Singh	0674-2573113/4
145	Orissa	Cuttack	O.A.INFOTECH	Behind Govt Bus Stand, Badambadi, Cuttack -753012	Manas Mahapatro	0671-3299800, 9338912613
146	Punjab	Amritsar	Bajaj Telecommunication	87, G Floor, Nehru Complex, Lawrence Road, Amritsar-143001	Suman Bajaj	9814650314, 0183-3258599
147	Punjab	Barnala	Unique Infotech	Mittal Street, Near M C Office, Barnala-148101	Pankaj Goyal	01679- 238007, 9317510667
148	Punjab	Bathinda	Lalli's Electronic Gallery	1139-A, First Floor, Amrik Singh Road, Nr Gole Diggi, Bhatinda-151005	Ashok Kakria	0164- 2239500/2236337, 9356200069
149	Punjab	Chandigarh	Vignesh Services	S.C.O- 189-90,Sec- 34,Chandigarh	Mukesh Arya	0172-3018028, 09316134655
150	Punjab	Hoshiarpur	Kuldip's Mobile Care	Dhobian Wali Gali,Phagwara Road, Hoshiarpur-146001	Kuldip	01882-226906,9815073906
151	Punjab	Jallandhar	Mobile Center	233/1, Saheed Udham Singh Nagar,Backside Hotel Preet, Nakodar Road, Jalandhar-144001.	Vikas Sangar	0181-329266, 9316081603
152	Punjab	Ludhiana	Shahi Communication	Shop No.5, 4X International, 583 L, Model Town, Ludhiana	Amit Shahi	0161-3244190, 9316112440

Service Center List

Subject to change without prior notice.

	Circle	City	ASCs Name	Address	Contact Person	Phone
153	Punjab	Malerkotla	Prime Infocomm	Opp. Main gate,Govt College, MalerKotla-148023	Raj Verma	01675-253899,9814040066, 01675-331979
154	Punjab	Patiala	Image Services	84, First Floor, Leela Bhawan, Patiala-147001	Rohit Bansal	0175-2222796, 9872281524, 9316200071
155	Punjab	Pathankot	Touch InfoSys	189 Opp. Guru Nanak Park, Model Town, Pathankot.	Mr.Navdeep Singh Bedi	0186-3290300,09417015812
156	Rajasthan	Jaipur	Alpha Infotech Systems	F-1, First Floor, Krishna Mall, Lakshmi Mandir Crossing, Tonk Road, Jaipur-302015	Shatrughan Mangal	0141-5106777,9829077136, 0141-3099724
157	Rajasthan	Jaipur	Alliance Communication	G6,City Plaza,Space Cinema,Jhotwara Road, Jaipur-16	Mr.Amit Pal Singh	09351371549, 09351655509, 0141-2280052
158	Rajasthan	Jaipur	Kamakshi Telecom	105,1st floor,Paradise, C-61(A), Sarojini Marg, C-Scheme, Jaipur-302001	Rahul Bhargav	0141-2365575,09314512863
159	Rajasthan	Jaipur	Vishwas Infoteck	13-14,Indira Switch,Opp Chambal Power House,Hawa Sarak,Civil Lines, Jaipur-302016	Mr.Madan Mohan Gupta	0141-3942050,5572050, 09314190400
160	Rajasthan	Jodhpur	Omega Electronics	UG/4, Adeshwar Tower, Main Chopasani Road, Opp.Gehlot Watch Co, Jodhpur-342003	Pratap Singh	0291-3091214, 09314717171
161	Rajasthan	Kota	Cyber Infosystems	26, Ground floor, Kalawati Paliwal market, Gumanpura, Kota-324007	Shyam Maheshwari	0744-2398153, 09352603354 , 09352620153
162	Rajasthan	Udaipur	Ficusa Enterprises	13,Darshanpura,Opp.M.B.Commerce College Gate,Nr Computer Zone, Udaipur-313002	Virendra Ranka	0294-2410002,2413002, 09314410002
163	Rajasthan	Alwar	R.K.Telecom	SHOP NO.112, FIRST FLOOR, GANPATI TOWER NEAR NANGLI CIRCLE , ALWAR.	Mr.Varun Sharma	0144-3093449,9351390057
164	Rajasthan	Sikar	Rita computers	Kabra Market ,Shramdan Marg,Sikar-332001	Saurab Chakraborthy	9352850656
165	Tamilnadu	Chennai	Escomm Systems India P Ltd	No 57-7, Arunodaya Apartments Next to Hotel Sindhoori, Near by Everest Bus Stop,Ponnamalai High Road, Chennai-600003	Mrs N S Vijaysri	044-32901688, 25612212
166	Tamilnadu	Chennai	Genesis Communication	63/3, First main road, Gandhi Nagar, Adyar, Chennai-600020	Mr Suresh	044-24401188
167	Tamilnadu	Chennai	GS Systems	547/352, F M Towers, Mount Road, Nandanam, Chennai-6000035	Mr.Nicholus	044-24330889,044-24350529
168	Tamilnadu	Chennai	Unicare Infocomm Services	No.293, Arcot Road,Next to Indian Overseas Bank, Kodambakkam Chennai - 24	Kartik	044 24724666, 044 52047059, 09382306857
169	Tamilnadu	Coimbatore	Fast Track	Sudera Complex, 354B, 100 Feet Road, COIMBATORE - 641012	Anand Prakash	0422-2490577,9843080040, 09344837706
170	Tamilnadu	Coimbatore	Nucom Services	3/61, Master Building, Kattoor Road, Pappa Naicken, Palayam, Coimbatore - 641037.	Mr.Uthaman	9344862178, 0422-4351569
171	Tamilnadu	Cuddlore	Kasturi Cellular Service	NO: 37 (2C) BHARATHI ROAD,CUDDALORE. 607 001, CUDDALORE DISTRICT,TAMIL NADU.	Mr Raghupati	04142 - 220183
172	Tamilnadu	Erode	JANS Electronics	148,Mettur Road, Opposite shakti vinayak temple,Dana Complex, Erode-638011	M Kanan	0424-2258526,3258526
173	Tamilnadu	Madurai	Devaa Electronics	No.4, Thirumakulam North Street,Near Ayyappan koil, Thhallakulam, Madurai-625002	Guna	0452-5360995,0452-2526179, 09344107995
174	Tamilnadu	Pondicherry	Digital Logistics	126/2, Perumal Koil Street (Bharathi Street Cutting), Pondicherry-605001	G Singaravelu	9843093348, 09345455351, 0413-4210148

Service Center List

Subject to change without prior notice.

	Circle	City	ASCs Name	Address	Contact Person	Phone
175	Tamilnadu	Port Blair	UNIVERSAL SERVICE CARE	R.G.T. ROAD, PORT BLAIR, ANDAMAN-744101	Mr.Naveen	03192-329588
176	Tamilnadu	Salem	Vishwesh Mobiles	Sixer Complex, 121/19A, Sarada College Road, Next to Abi Medical Centre, Salem - 636007	Vasudev Nayak	0427-3290535 , 09362093629
177	Tamilnadu	Thanjavur	Z M Electronics	33,New Municipal Shopping Complex,Opp LIC,Gandhi ji road,Thanjavur-613001	Ziauddin	04362-272595,329554
178	Tamilnadu	Tirunevelli	Classic Electronic	39, Trivendrum Road, Opposite Kalmark, Welcome Complex, Palayamkottai, Tirunelveli-627002	Erkins	0462-2575801 , 3290339
179	Tamilnadu	Tirupur	Shri Vasavi Electronics	# 155-303, Mangalam Road,Karuvam palayam, Tirupur -641604	MR.U.B. Bala Murali	0421-3091438,98422-74300, 09363005560
180	Tamilnadu	Trichy	S K Electronics	Raj Complex, 9/A EVR Road, Puthur, Trichy- 620017	Krishnan	0431-2771946,9843178104, 09345101502
181	Tamilnadu	Vellore	Matha Communication	4, S.L.N Plaza, Opposite Odai Pillar Koil, Gandhinagar, Vellor - 632006	Gunaa Shekhar	0416-2240800
182	Uttar pradesh	Agra	Ankur Care Centre	6/1, M.G.Road, Near Subhash Park, Agra.	Mr.Ankur Goyal	0562-3264353,9412254152
183	Uttar pradesh	Agra	NSC Computers	Shop No G-124, Block No- 29, Sanjay Place, Agra – 282 002	Rajiv Singhal	0562-2520032, 09319111350
184	Uttar pradesh	Agra	Space Consultancy & Services	UG 1 & 2, Opp. Jaihind Hotel, Merchant Chamber, Sadar Bazar, Agra-282001.	Tanvir	0562-3257826, 09358504140
185	Uttar pradesh	Aligarh	A V Computer Services	G-1,Ganpati Plaza ,Jha Compund, Marris Rd, Aligarh-202001	Vaibhav	0571-2506148,9412274391
186	Uttar pradesh	Aligarh	Infocare	17, Vikram Arcade, Railway Road, Aligarh -202001	Mr.Kamal Jain	0571-3258080
187	Uttar pradesh	Allahbad	B.P.Electronics	G-11, Indira Bhawan, Ground Floor, Civil Lines, Allahbad-211001	Ms Naina Pandey	0532-2608088
188	Uttar pradesh	Allahabad	SWASTIK INFOCOM	49, Vivekanand Marg, National Bank, Allahabad	MR.Vikas	9335110333
189	Uttar pradesh	Bareilly	Sapan Infotech	G - 64 A Kunwar Complex,Near Gupta Watch Co,116 Civil Lines,Bareilly	Sanjeev Singh	9359102467
190	Uttar pradesh	Dehradun	Krishna Communication	Shop No 15A, Meedo Plaza, Rajpur Road, Dehradun,Uttaranchal-248001	Vinod	0135 3290895,09358112922, 09358119696
191	Uttar pradesh	FAIZABAD	Microworld Computer Hardware Lab	1st floor,Baldev Plaza,Rekhabganj,Faizabad	Kapil/Sunil	9335098244,05278-395744
192	Uttar pradesh	Ghaziabad	Concessionair Documentation India Pvt Ltd **(CDIL)**	C-83, Rajnagar District Center (RDC), Ghaziabad	Arun Sharma	0120-3092011
193	Uttar pradesh	Ghaziabad	Charu Enterprises	Shop No.15,Opp. Sales Tax Check Post , G.T.Road,Mohan Nagar	Mr.Chander Shekher	0120-3223417
194	Uttar pradesh	Gorakhpur	Eternal Electronics	Shop No.11, Pandey Complex, 33, Kasya Road, Opp DIG Bunglow, Gorakhpur -273001	Ram Pratap	0551-2204520
195	Uttar pradesh	Gorakhpur	MM Communication	Udai Trade Centre, Opp Dr H.N.Singh Medical College, Basharatpur, Gorakhpur	Mr.Ashwani	9336422769
196	Uttar pradesh	Haldwani	Fairdeal Agencies	1st Floor,Nainital Road,Uttaranchal Trade Centre,Tikonia Chouraha, Tikonia, Haldwani	Mr.Ajay Gupta	9359412203,05946-282116

Service Center List

Subject to change without prior notice.

	Circle	City	ASCs Name	Address	Contact Person	Phone
197	Uttar pradesh	Kanpur	AAKARSH ELECTRONICS	63/2 C(9)BALAJI COMPLEX,THE MALL, KANPUR	Mr.Raman	9335360303
198	Uttar pradesh	Kanpur	AR Infotech	111/402 Ashok Nagar,Kanpur Pin 208012	Manoj Shukla	0512 3111662,9839068734, 0512-3093011
199	Uttar pradesh	Kanpur	LB Infotech	124/122A GOVIND NAGAR, KANPUR	Deepak Bhatia	0512-3207303
200	Uttar pradesh	Lucknow	ALFA ELECTRONICS	Shop No.GF20 ABC Complex, Kanpur Road, Lucknow	Harjinder Singh	0522-3948730
201	Uttar pradesh	Lucknow	Hitech Communication	SS 205, Road Cross Plaza, Badshah Nagar Crossing, Lucknow.	MR.RAVI PRAKASH/ MR.RAJENDRA RAMAN	9335088061
202	Uttar pradesh	Lucknow	NET COM	3 way road, City Point, Opp Krishi Bhawan, Lucknow-226024	Kawaljeet	0522-3094222
203	Uttar pradesh	Mathura	R.K.Infocare	G-1,Atithya Palace,Sonkh Adda,Junction Road, Mathura-281001	Alok Gupta	9719119657,0565-3292274
204	Uttar pradesh	Meerut	Systech Computers	F-124/125 Ist floor Ganga Plaza, Begum Bridge Road, Meerut-250002	Vineet Goyal	0121-4003194, 09358416631
205	Uttar pradesh	Meerut	Care Centre	G-5 , Vardaman Plaza, Garh Road, Meerut-250005	Mr.Ajay Mittal	0121-3249666,9897400001
206	Uttar pradesh	Moradabad	Bhavya Technologies	A12, 1st Floor, Rampur Road,Gandhi Nagar, Moradabad	Vivek Kumar Singh	0591-3092318
207	Uttar pradesh	Muzaffarnagar	Jai Computers	Shop No, 4, 1st Floor, Roorkee road, Near Shiv Chowk, Central Bank Mkt, Muzaffarnagar-251001	Manohar Singh	0131-3294447,9412110215
208	Uttar pradesh	Noida	M R Telecom	J-45, First Floor, Sector-18, NOIDA-201301	Kailash Aggarwal	0120-4312715,9871197801
209	Uttar pradesh	Noida	JAINS MOBICARE	B1A,Main Dadri Road,Choudhury House, Kalyankunj, Barula, Sector-49,Noida	Mr. Shreyansh Daga	9313622002
210	Uttar pradesh	Roorkee	Geetanjali Telecom	Shop No.6,Shyam Market,BSM Tiraha,NehruNagar, Dehradun Road, Roorkee-247667.	Mr. Manish Kumar	9897379007, 01332-326510
211	Uttar pradesh	Saharanpur	Maharaj Communications	Near Maharaja Palace,Delhi Road, Saharanpur-247001	Pankaj Malhotra	0132-2720881, 09358311202
212	Uttar pradesh	Shahjanpur	Sunny Mobile Point	258 B TARIN BAHADURGANJ,SHAHJANPUR	Shashi	9335019616
213	Uttar pradesh	Varanasi	Jaiswal Electronics	S6/107 KACHAHRI CROSSING,NEAR COURT, VARANSI	Mr.Sujeet	9336910210
214	Uttar pradesh	Varanasi	Shivam Mobile Distributers	Shop No.5,B37/115-B-1 Baradari Complex, Rathyatra Crossing, Varansi Pin 221010	Rishi Mohan	9839241003, 9335418998, 9335497424
215	W Bengal	Assansol	Sky Computer & Telecom	Islam Market, Nuruddin Road, Assansol-713301	Syed Arshad Ali	0341- 2207719 ,9832160886
216	W Bengal	Kolkata	Friends Communication	32(B) Barasat Road, N/L, 15 no railgate, PC-nonachandanpukur, PS- Titagarh, Barrackpore, Dist- North 24PGS, PIN-743102	Arup Sarkar & Tarasankar Mukherjee	033-25921263' 9330986253
217	W Bengal	Burdwan	San Infosys	27/1 G.T Road , East End, Burdwan -713103.	Sanjit Debnath	0342-3290265, 9832192170

Service Center List

Subject to change without prior notice.

	Circle	City	ASCs Name	Address	Contact Person	Phone
218	W Bengal	Kolkata	Benma Infosol Pvt Ltd.	P-168/1 CIT Road,Scheme VIIM,KOLKATA 700 067	Arun Surana	033-30943176/7
219	W Bengal	Kolkata	Jaksom Engineering Pvt Ltd	Block-A, Shop-1, Ambika Vihar,1/1 Harduttrai Chamaria Road, Howrah- 711001	P.Mukherjee	033- 30950383
220	W Bengal	Kolkata	JP Computers	5B Ekdalia Place, Kolkata - 700019	Somim Kabir	033-24401923
221	W Bengal	Kolkata	Skylink	8/1A, Little Russel Street, Calcutta-700071	H R Molla	033-30903814,033-32091037
222	W Bengal	Kolkata	SOURAV TELECOM	195 BLOCK-J NEW ALIPUR , KOLKATA-700053 N/L New Alipur State Bank	Amit Ghosh	033-39511256,9330998399
223	W Bengal	Kolkata	Sun Mobile Service	15 B.T. Road, N/L Paikpara Bus Stop, Kolkata -700002	VIVEK KUMAR GUPTA	033-3950-5444,55198810
224	West Bengal	Durgapur	Digitech Service	Ashok Bhavan J.K.Pal Lane .Benachity, Durgapur -713213	Mr.Pintu Chatterjee	0343-3093600,9333900524
225	West Bengal	Serampore	Sri Guru Mobile Service	87 B/15 G.T.Road (West) ,Hooghly Pin-712203	Shyamal Kumar Das	033-39528581,9330995160

इन सरल दिशानिर्देषों को पढ़ें, नियमों का उल्लंघन खतरनाक या अवैधानिक हो सकता है. विस्तृत जानकारी इस उपभोक्ता मार्गदर्शिका में दी गई हैं.

⚠सावधान **निर्देशों का उल्लंघन करने से गंभीर चोट लग सकती है या मृत्यु हो सकती है.**

- कभी भी अनाधिकृत बैटरियों का उपयोग न करें क्योंकि ऐसा करने से फोन या बैटरी को नुकसान हो सकता है और बैटरी में विस्फोट हो सकता है.

- अपने फोन को कभी माइक्रोवेव ओवन में न रखें, इससे बैटरी में विस्फोट हो जाएगा.
- अपनी बैटरी को आग या घातक या ज्वलनशील सामग्रियों में न डालें.

- ध्यान रखें कि जानवरों के दाँतों, नाखूनों जैसी कोई नुकीली चीजें बैटरी के संपर्क में न आये. इससे आग लगने का डर है.

- बैटरी को बच्चों की पहुँच से दूर रखें.
- ध्यान रखें कि बच्चे रबर के प्लग (इयरफोन, फोन के कनेक्शन पुर्जे आदि) न निगल लें. इससे साँस रुकने से बेहोशी आ सकती है या दम घुट सकता है.

- बिजली के झटके या आग से बचने के लिए बिजली कड़कने पर पावर कार्ड और चार्जर निकाल दें.

- कार में सफर करते समय अपने फोन को एयर बैग के पास न रखें या हैंड्स फ्री किट को उसके पास न लगाएँ. यदि वायरलेस उपकरण ठीक से स्थापित न हो और एयर बैग खुल जाएँ, तो आपको गंभीर चोट लग सकती है.
- वाहन चलाते समय किसी हैंड हेल्ड फोन का उपयोग न करें.

- निषिद्ध स्थानों पर फोन का उपयोग न करें (उदाहरण के लिए: विमान में).

- बैटरी के चार्जर या एडॉप्टर पर धूप न पड़ने दें या उसे ज़्यादा नमी वालें स्थानों, जैसे बाथरुम में उपयोग न करें.
- अपने फोन को -15°C से कम और 50°C से ज़्यादा तापमान में न रखें.

महत्वपूर्ण सुरक्षा सावधानियाँ

- अपने फोन को साफ करने के लिए तेज़ रसायनों (जैसे अल्कोहल, बेंज़ीन, थिनर्स आदि) या डिटर्जेंट्स का उपयोग न करें. इससे आग लगने का डर है.

- अपने फोन को गिरने, टकराने या जोर से हिलाएँ जाने से बचाएँ. इससे फोन के आंतरिक सर्किट बोर्ड्स को नुकसान पहुँच सकता है.

- अपने फोन को तेज विस्फोटकों वाले क्षेत्र के आसपास उपयोग न करें क्योंकि फोन में स्पार्क हो सकते है.
- पावर कॉर्ड को मोड़कर, खींचकर, गर्म करके नुकसान न पहुँचाये. यदि प्लग ढीला हो, तो उसका उपयोग न करें क्योंकि इससे आग लग सकती है या बिजली का झटका लग सकता है.

- पावर कॉर्ड पर कोई भारी चीज न रखें. पावर कॉर्ड को चटकने न दें क्योंकि इससे आग या बिजली का झटका लग सकता है.
- फोन को चार्ज करते समय गीले हाथों से न पकड़ें, इससे बिजली का झटका लग सकता है या आपके फोन को गंभीर नुकसान पहुँच सकता है.

- फोन को खोलें नहीं.
- फोन को चार्ज करते समय न तो कॉल करें न ही प्राप्त करें क्योंकि इससे फोन में शॉर्ट – सर्किट हो सकता है और आग या बिजली का झटका लग सकता है.

- केवल LG द्वारा अधिकृत बैटरियों, एंटीना, और चार्जर्स का ही उपयोग करें. अन्य प्रदाताओं के सहायक उपकरणों या उत्पादों पर वॉरंटी लागू नहीं होगी.
- केवल अधिकृत व्यक्ति को ही फोन और उसके सहायक उपकरणों की सर्विस करनी चाहिए. गलत मरम्मत या सर्विस के कारण दुर्घटनाएँ हो सकती हैं और परिणामस्वरुप वॉरंटी रदद् हो जाएगी.

- कॉल के दौरान एंटीना को पकड़ें नहीं और न इसे अपने शरीर से छूने दें.

- आपके फोन में 3 आपातकालीन कॉल की सुविधा है. आप 100, 101, 102 नंबरों पर फोन के लॉक होने या प्रतिबंधित होने की स्थिति में भी कॉल कर सकते हैं.

प्रस्तावना 3

सुरक्षा अनुदेश 4

सावधानियाँ.....6

शुरु करने से पहले.....8

फोन के पुर्जे.....8

बटनों के फंक्शन 9

स्क्रीन पर आने वाले चिन्ह 10

सूची शृंखला.....11

बैटरी और चार्जर का उपयोग करना ..13

बैटरी लगाना और निकालना 13

बैटरी चार्ज करना 13

बैटरी चार्ज स्तर 14

बैटरी की देखभाल 14

मूलभूत फंक्शन.....15

फोन को बंद और चालू करना 15

कॉल करना 15

कॉल प्राप्त करना 15

संकेत की शक्ति 16

एंटीना के बारे में.....16

त्वरित समायोजन 16

कॉल प्रतीक्षा 17

मौन 18

कॉल पुनः डायल करना 18

शीघ्र डायल 18

कॉलर फ 18

जानकारी लिखना और संपादित करना.....19

T9 शब्द इनपुट मोड से लिखने की जानकारी.....19

T9 शब्द इनपुट उपयोग के उदाहरण 20

Abc (मल्टी–टैप) शब्द इनपुट उपयोग के उदाहरण 21

हिन्दी में लिखने के लिये बटन मैपिंग.....22

हिन्दी मोड में संपादन के लिए 23

हिन्दी के लिय T9 शब्द इनपुट उपयोग के उदाहरण.....23

सूची की सुविधाएँ.....24

सूची तक पहुँचने और सेटिंग्स के सामान्य दिशानिर्देश.....24

1. नाम 24

1.1 नाम जोड़ें.....24

1.2 खोजें.....25

1.3 ग्रुप्स.....25

1.4 शीघ्र डायल.....26

1.5 कॉपी – भेजें.....26

1.6 नाम मिटाएँ.....27

1.7 मेरी प्रोफाइल.....27

1.8 मेमोरी की जानकारी 27

1.9 सहायता 27

2. संदेश 28

2.1 लिखें 29

2.2 इनबॉक्स 33

2.3 1234 सर्विसेस.....35

2.4 आउटबॉक्स 35

2.5 वॉइस मेल 36

2.6 न्ड में संग्रह 37

2.7 ड्राफ्ट्स 37

2.8 टेम्प्लेट्स 38

2.9 संदेश ग्रुप्स.....39

2.0 संदेश मिटाएँ.....40

2.* संदेश सेटिंग्स 40

2.# सहायता 41

3. कॉल विवरण 42

3.1 छूटी.....42

3.2 प्राप्त 42

3.3 डायल किये हुए 42

3.4 कॉल मेमो में 43

3.5 कॉल अवधि 43

3.6 विवरण मिटाएँ 43

3.7 सहायता 43

अनुक्रमणिका

4. प्रदर्शन 44
4.1 भाषा 44
4.2 सर्विस एरिया 44
4.3 घड़ी और शॉर्टकद 44
4.4 समय और तिथि 44
4.5 वॉलपेपर 44
4.6 सूची स्टाइल 45
4.7 रंग संरचना 45
4.8 लयबध्द रोशनी 45
4.9 स्क्रीन लाइट 45
4.0 सहायता 46
5. मोबाइल वर्ल्ड 46
5.1 R–सूची 46
5.2 मूवी और संगीत 46
5.3 प्ले और शॉप 47
5.4 डायल 1234 47
5.5 MMS लिखें 47
5.6 MMS इनबॉक्स 48
5.7 R-सूची पुनः सेट 48
5.8 UIM टूलकिट 48
5.9 गेम्स 48
5.0 सहायता 48
6. प्रोफाइल्स 48
प्रोफाइल्स चुनें 48
प्रोफाइल्स का नाम बदलें 49
प्रोफाइल्स अनुकूलित करें 49
6.7 सहायता 50
7. निर्धारक/टूल्स 50
7.1 Bluetooth 50
7.2 वॉयस टूल्स 52
7.3 टाईम मैनेजर 55
7.4 मेमो 56
7.5 आरक्षित कॉल 57
7.6 अलार्म 57
7.7 स्टॉप वॉच 58
7.8 कैलक्युलेटर 58
7.9 इकाई रुपांतरक 58
7.0 विश्व घड़ी 59
7.* सहायता 59
8. मल्टीमीडिया 59
8.1 कैमरा 59
8.2 FM रेडियो 63
8.3 MP3 63
8.4 मेरी सामग्री 64
9. सेटिंग्स 65
9.1 मेरी सूची 65
9.2 कॉल 66
9.3 फोन 67
9.4 सुरक्षा 69
कॉल के दौरान प्रयुक्त होने वाले फंक्शन 72
कॉल मेमो में 72
मौन/मौन नहीं 72
वॉइस प्राइवेसी ऑन/ऑफ 72
वॉयस मेमो में 73
स्पीकर मोड ऑन 73
इयरपीस/स्पीकर वॉल्यूम 73
सहायक उपकरण 74
सामान्य प्रश्न 75
सामान्य प्रश्न 75
सर्विस के लिये कॉल करने से पहले 79
सुरक्षा अनुदेश 81
टीआईए सुरक्षा जानकारी 81
सुरक्षा जानकारी 84
एफडीए ग्राहक अद्यतन 87

आपको उन्नत और परिपूर्ण RD-6250 मोबाइल फोन खरीदने पर बधाई. यह फोन नवीनतम डिजिटल मोबाइल कम्युनिकेशन तकनीक CDMA (Code Division Multiple Access) पर काम करने के लिये डिजाइन किया गया है. इसमे CDMA सिस्टम की कई उन्नत सुविधाएँ हैं जैसे इसकी आवाज़ बहुत स्पष्ट है और निम्न विविध सुविधाएँ है:

- चौड़ा, पढ़ने में आसान, 5 लाईनो वाला प्रदर्शन + 1 आइकान लाईन + 1 सूची लाईन.
- बटन पैड: 10 अल्फान्युमेरिक बटन / 2 फंक्शन बटन / 2 सॉफ्ट बटन / 1 क्लियर बटन / 4–तरफा नेविगेशन और ओके फंक्शन के लिये 1 जॉयस्टिक बटन / 1 कॉल बटन / 1 एंड बटन / MP3 और FM के लिये 1 साइड बटन / साइड अप–डाउन बटन.
- Bluetooth वायरलेस तकनीकी
- FM रेडियो
- MP3 प्लेयर
- नवीन विशेषताओं वाली बाहरी मेमोरी
- डिजिटल कैमरा जूम सुविधा के साथ
- अंग्रेजी और हिन्दी भाषाएँ
- SMS, MMS, LMS, ई–मेल SMS Chat
- वॉयस मेमो, रिकार्डर, और डायलिंग
- 2500 नंबरो वाली डायनमिक फोनबुक.
- 72 पॉलिफोनिक, MP3 और वॉयस रिकार्डिंग रिंग स्वर
- स्पीकर फोन
- फ्लैश लाईट और टार्च
- इन कॉल मेमो, लयबध्द रोशनी, एयर प्लेन मोड
- फोनबुक, आर्गनाइजर, कैमरा, MP3 के लिये पीसी सिंक

उपकरण जाँच लें

आपके मोबाइल फोन के साथ एक एसी एडॉप्टर, रीचार्जेबल बैटरी, हैंडस्ट्रेप microSD कार्ड, डेटा केबल और हेडसेट आता है. कृपया देख लें कि ये उपकरण आपको मिले हैं.

महत्वपूर्ण जानकारी

यह उपभोक्ता मार्गदर्शिका आपके फोन के उपयोग और कार्यप्रणाली के बारे में महत्वपूर्ण जानकारी देता हैं. श्रेष्ठ कार्य–प्रदर्शन के लिए और फोन को किसी भी प्रकार की क्षति या दुरुपयोग से बचाने के लिए कृपया फोन का उपयोग करने से पहले सारी जानकारी ध्यान से पढ़ ले. कोई भी अनाधिकृत परिवर्तन या संशोधन करने से आपकी वॉरंटी रद्द हो जाएगी.

सुरक्षा अनुदेश

चेतावनी! बिजली के झटके का खतरा कम करने के लिए अपना फोन ज्यादा नमी वालें स्थानों जैसे बाथरुम, स्विमिंग पूल जैसी जगह पर न ले जाएँ.

फोन को किसी नुकसान से बचाने के लिए केवल LG द्वारा मान्य बैटरियों और ट्रेवल चार्जरों का ही उपयोग करें. दूसरी बैटरियों या चार्जर का उपयोग करने पर आप वांरटी की शर्तों का उल्लंघन करतें है और इससे विस्फोट भी हो सकता है. बैटरियों और ट्रेवल चार्जरों को फोन के अलावा अन्य कामो के लिए उपयोग न करें.

अपने फोन को हमेशा ऊष्मा से दूर रखें. फोन को कभी –15 डिग्री सें. से कम या 50 डिग्री सें. से अधिक तापमान की स्थितियों, जैसे बर्फबारी के समय खुले में या किसी गर्म दिन में अपनी कार में न रखें. अत्यधिक सर्दी या गर्मी से आपके फोन को नुकसान पहुँच सकता है और गंभीर खराबी आ सकती है.

अन्य इलेक्ट्रॉनिक उपकरणों के पास अपने फोन का उपयोग करते समय सावधानी बरतें. आपके फोन से होने वाला आरएफ उत्सर्जन आसपास के ऐसे इलेक्ट्रॉनिक उपकरणों को नुकसान पहुँचा सकता है, जो समुचित रुप से सुरक्षित नहीं हैं. आपको व्यक्तिगत चिकित्सकीय उपकरणों जैसे पेसमेकर और श्रवण यंत्रों के निर्माताओं से पूछ लेना चाहिए कि कहीं वे आपके मोबाईल फोन के प्रति संवेदनाशील तो नहीं है.

चिकित्सालय में या पेट्रोल पंप पर अपना फोन बंद कर दें.

अपने फोन को कभी भी माइक्रोवेव ओवन में न रखें, इससे बैटरी में विस्फोट हो जाएगा.

महत्वपूर्ण ! अपने फोन का उपयोग शुरु करने से पहले कृपया टीआईए सुरक्षा जानकारी (पृष्ठ 81 पर) पढ़ लें.

एफसीसी आरएफ एक्सपोज़र जानकारी

चेतावनी! फोन का उपयोग करने से पहले यह जानकारी पढ़ें.

अगस्त 1996 में, संयुक्त राज्य के फेडरल कम्युनिकेशन कमीशन (एफ.सी.सी.) ने रिपोर्ट एंड ऑर्डर एफसीसी 96-326 पर कारवाई के माध्यम से, एफसीसी नियंत्रित ट्रांसमीटरों द्वारा उत्सर्जित रेडियो फ्रीक्वेंसी (आरएफ) इलेक्ट्रोमैग्नेटिक ऊर्जा से मानव पर पड़ने वाले प्रभाव के लिए अद्यतन सुरक्षा मापदंड अपनाए. ये दिशानिर्देष पूर्व में यू.एस. और अंतर्राष्ट्रीय मानक संस्थानों द्वारा निर्धारित सुरक्षा मानकों के अनुरुप है.

इस फोन की डिज़ाइन एफसीसी दिशानिर्देषों और इन अंतर्राष्ट्रीय मापदंडों को पूरा करती है.

सावधान

केवल फोन के साथ दिए गए और अनुशंसित सहायक उपकरणों का ही उपयोग करें. अनाधिकृत उपकरण या परिवर्तन, कॉल की गुणवत्ता पर विपरीत प्रभाव डाल सकते हैं, फोन को नुकसान पहुँचा सकते हैं या आपकी वॉरंटी का उल्लंघन कर सकते हैं.

फोन का उपयोग क्षतिग्रस्त सहायक उपकरण के साथ न करें. क्षतिग्रस्त सहायक उपकरण के संपर्क में आने पर त्वचा थोड़ी जल सकती हैं. सहायक उपकरण बदलने के लिए अपने स्थानीय डीलर से संपर्क करें.

शरीर के साथ रखकर संचालन

इस उपकरण का परीक्षण आमतौर पर उपयोग के समय शरीर और फोन के बीच रहने वाली दूरी, जिसमें फोन का पिछला हिस्सा शरीर से 3/4 इंच (2 सेमी) दूर रहता है, की स्थितियों में किया गया है. एफसीसीआरएफ एक्सपोज़र मापदंडों के पालन के लिए, उपयोगकर्ता के शरीर और फोन के पिछले हिस्से के बीच, जिसमें एंटीना भी शामिल है, कम से कम 3/4 इंच (2 सेमी) दूरी होनी चाहिए. अन्य निर्माताओं के बेल्ट क्लिप, होल्स्टर जैसे धातु के पुर्जों वाले सहायक उपकरण उपयोग नहीं किए जाने चाहिए. ऐसे उपकरण जो उपयोगकर्ता के शरीर और फोन के पिछले भाग के बीच 3/4 इंच (2 सेमी) की दूरी नहीं रख सकते, और जिनका परीक्षण शरीर से आमतौर पर रखने वाली दूरी की स्थितियों में नहीं किया गया है, वे संभवतया एफसीसीआरएफ एक्सपोज़र सीमाओं के अनुरुप न हों और इनका उपयोग नहीं किया जाना चाहिए.

वाहन पर लगा बाहरी एंटीना (वैकल्पिक, यदि उपलब्ध हो तो)

एफसीसीआरएफ एक्सपोज़र मापदंडों के अनुसार उपयोगकर्ता/पास खड़े व्यक्ति और वाहन पर लगे एंटीना के बीच कम से कम 8 इंच (20 सेमी) की दूरी होनी चाहिए. आरएफ एक्सपोज़र के बारें में अधिक जानकारी के लिए, एफसीसी की वेबसाईट http:/www.fcc.gov/ देखें.

एफसीसी भाग 15 वर्ग बी अनुपालन

यह उपकरण और इसके सहायक उपकरण, एफसीसी नियमों के भाग 15 के अनुरुप हैं. इसके संचालन की निम्न दो शर्तें हैं. (1) यह उपकरण और इसके सहायक उपकरण हानिकारक अवरोध पैदा नहीं कर सकते, और (2) यह उपकरण और इसके सहायक उपकरण किसी भी प्राप्त अवरोध को स्वीकार करेंगे, जिसमे वे अवरोध शामिल हैं जिनमे आवांछित संचालन होता है.

बैटरी के लिए सावधानियाँ

- इसे खोले नहीं.
- शॉर्ट –सर्किट नहीं करें.
- ऊँचें तापमान में न रखें : 60 डिग्री सें. (140 डिग्री फे.).
- इसे जलाएँ नहीं.

बैटरी नष्ट करना

- कृपया अपनी बैटरी को ठीक से नष्ट करें.
- अपनी बैटरी को आग या घातक अथवा ज्वलनशील सामग्रियों में न डालें.

चार्जर के लिए सावधानियाँ

- गलत बैटरी चार्जर के उपयोग से आपका फोन खराब हो सकता है और वॉरंटी का उल्लंघन हो सकता हैं.
- चार्जर केवल इनडोर उपयोग के लिए है.

बैटरी चार्जर को सीधे सूर्य के प्रकाश में खुला न ले जाएँ या इसे नमी वाले स्थानों जैसे बाथरुम में उपयोग न करें.

सावधानियाँ

- केवल LG की बैटरियों और चार्जरों का ही उपयोग करें. अन्य निर्माताओं के उत्पादों पर वॉरंटी लागू नहीं होगी.
- संकेत प्राप्त करने वाले उपकरणों (जैसे टीवी या रेडियो) के पास फोन का उपयोग करने पर इसमे अवरोध आ सकता है.
- जब आप फोन का उपयोग नहीं कर रहे हो, तो उसे सुरक्षित स्थान पर रखें.
- केवल अधिकृत व्यक्ति को ही फोन और उसके सहायक उपकरणों की सर्विस करनी चाहिए, गलत मरम्मत या सर्विस के कारण दुर्घटनाएँ हो सकती हैं और परिणामस्वरुप वॉरंटी अमान्य हो जाएगी.
- इस फोन में एक बिल्ट–इन एंटीना है. किसी भी दूसरे रेडियो ट्रांस्मिटिंग उपकरण की तरह फोन का उपयोग करते समय ऊपरी भाग को न पकड़ें जहाँ एंटीना लगा रहता है.
- केवल LG द्वारा प्रदत्त या मान्य एंटीना का ही उपयोग करें. अनाधिकृत एंटीना, परिवर्तन या संलग्नक फोन कॉल्स की गुणवत्ता को प्रभावित कर सकते हैं, फोन को नुकसान पहुँचा सकते हैं या इनसे एफसीसी नियमों का उल्लंघन हो सकता है.

- एंटीना क्षतिग्रस्त होने की स्थिति में सेल्युलर फोन का उपयोग न करें. क्षतिग्रस्त एंटीना के त्वचा के संपर्क में आने पर त्वचा थोड़ी जल सकती है. क्षतिग्रस्त एंटीना बदलने के लिए कृपया LG के अधिकृत सर्विस सेंटर (ASC) से संपर्क करें.
- निषिद्ध स्थानों पर सेल्युलर फोन का उपयोग न करें (उदाहरण के लिए : विमान में).
- सेल्युलर फोन को ऊँचे तापमान या ज्यादा नमी वाले स्थानो में न ले जाएँ.
- सेल्युलर फोन को पानी के संपर्क में न आने दें. यदि ऐसा होता है, तो इसे तुरंत बंद कर दें और बैटरी निकाल लें. यदि फोन काम नहीं करता है, तो इसे LG के अधिकृत सर्विस सेंटर पर ले जाएँ.
- सेल्युलर फोन को झटके या टक्कर से बचाएँ.

फोन के पुर्जे

निम्न चित्र आपको मोबाईल फोन के मुख्य पुर्जों के बारे में बताता है.

बटनों के फंक्शन

LCD स्क्रीन	संदेश और संकेत चिन्ह प्रदर्शित करती है.
सॉफ्ट बटन (इन बटनों के फंक्शन के नाम स्क्रीन में नीचे दिखतें हैं)	**सॉफ्ट बटन 1** [–] फंक्शन सेटिंग सूची प्रदर्शित करने के लिए प्रयुक्त. **सॉफ्ट बटन 2** [–] फोनबुक खोजनें, शब्द इनपुट मोड बदलने. निरस्त कॉल को SMS आदि के लिए प्रयुक्त.
कॉल बटन	उपयोगकर्ता कॉल कर या प्राप्त कर सकता है.
एंड/पावर बटन	पावर बंद/चालू करने और कॉल समाप्त करने के लिए उपयोग किया जाता है. इस बटन से आप मुख्य सूची प्रदर्शन स्क्रीन पर लौट सकते है. कॉल प्राप्त करते समय जब आप एक बार दबाते हैं, तो मोड के अनुसार घंटी या कंपन बंद हो जाता है. संपर्क तोड़ने के लिए दोबारा दबाएँ.
ओके/स्पीकर ऑन–ऑफ बटन/ऊपर/नीचे/बायाँ/दायाँ (संदेश/वॉयस डायल/मोबाइल वर्ल्ड/प्रोफाइल्स)	किसी सूची में नेविगेट करते समय हाइलाईट किए गए विकल्प को स्वीकार करता है. कॉल के दौरान, स्पीकर मोड ऑन/ऑफ सक्रिय करें. इस नेविगेशन बटन से आप तुरंत ▲ संदेश और वॉइस मेल अधिसूचना संदेश (देर तक दबाने पर लिखें सूची में), ▼ वॉयस डायल (देर तक दबाने पर वॉयस रिकार्डर सक्रिय), ◀ मोबाइल वर्ल्ड, ▶ प्रोफाइल्स (देर तक दबाने पर रिंग स्वर सूची सक्रिस) पर पहुँच सकते है.

अल्फान्यूमेरिक बटन पैड	इससे आप नंबर और अक्षर लिख सकते हैं, और सूची आइटम चुन सकते हैं.
क्लीयर/मेरी सूची/टॉर्च बटन	एक स्थान या अक्षर मिटाने के लिए इसे दबाएँ. पूरे शब्दों को मिटाने के लिए दबाएँ रखें. पिछले सूची में वापस जाने के लिए किसी सूची में इस बटन को एक बार दबाएँ. स्टैंडबॉय मोड में, बटन देर तक दबाएँ रखकर टॉर्च ऑन करें. मेरी सूची में जाने के लिये एक बार दबाएँ.
कंपन मोड बटन	स्टैंडबॉय मोड में, बटन [*] को लगभग 2 सेकंड तक दबाएँ रखकर कंपन मोड सेट करें.
बटन रक्षक बटन	स्टैंडबॉय मोड में, बटन [0] को लगभग 2 सेकंड तक दबाएँ रखकर बटन रक्षक मोड सेट करें.
कैमरा बटन	कैमरा सूची में जाने के लिये एक बार दबाएँ. फोटो मोड में जाने के लिये देर तक दबाएँ.
अन्तर्राष्ट्रीय कॉल प्रेफिक्स बटन	अंतर्राष्ट्रीय कॉल करने के लिये, [#] बटन को 2 या 3 सेकंड के लिये दबाएँ. + का मतलब अन्तर्राष्ट्रीय कॉलिंग कोड.
साइड FM/MP3 बटन	एक बार दबाने पर MP3 प्लेयर और देर तक दबाये रख कर FM रेडियो सक्रिय करें
साइड वॉल्युम बटन	MP3/FM रेडियो का वाल्युम सेट करें

स्क्रीन पर आने वाले चिन्ह

फोन का पावर चालू होने पर फोन स्क्रीन पर अनेक चिन्ह दिखाई देते हैं.

चिन्ह	वर्णन				
	फोन द्वारा प्राप्त संकेत की शक्ति स्क्रीन पर प्रदर्शित करता है और स्क्रीन पर दिखने वाली पंक्तियों की संख्या से वर्तमान शक्ति पता चलती है.				
	सर्विस नहीं. फोन को किसी सिस्टम से संकेत नहीं मिल रहा है.				
	उपयोग में है. कॉल चल रही है. * कोई संकेत न होना दर्शाता है कि फोन स्टैंडबॉय मोड में है.				
	दर्शाता है कि कोई शब्द संदेश या ई–मेल संदेश प्राप्त हुआ है.				
	दर्शाता है कि स्पीकर मोड ऑन है.		बटन रक्षक सक्रिय होना दर्शाता है.		
	कंपन मोड में.		अलार्म मोड में.		मौन मोड में.
	Bluetooth ऑन है.		अस्वीकृत कॉल को SMS.		
	DUN मोड सक्रिय है.		Bluetooth हेडसेट या हैंडसघे कनेक्ट होना दर्शाता है.		
	Bluetooth आनॅ होना दशार्त है.		फोन में microSD कॉर्ड लगाये जाने पर प्रदर्शित होता है.		
	दर्शाता है कि वॉयस उत्तर मशीन सक्रिय है.				MMS होना दर्शाता है.
	दर्शाता है कि वॉयस मेल प्राप्त हुआ है या कोई वॉयस संदेश रिकॉर्ड हुआ है.				
	चार्ज स्तर बैटरी चार्ज स्तर दर्शाता है. चार्ज पूर्ण होने पर, बैटरी चार्जिंग संकेतक झपकता है.				SMS और MMS होना दर्शाता है.

सॉफ्ट बटन 1 **सूची** दबाएँ, स्क्रॉल करने के लिए दबाएँ.

नाम	संदेश	कॉल विवरण	प्रदर्शन	मोबाइल वर्ल्ड
1. नाम जोड़ें	1. लिखें	1. छूटी	1. भाषा	1. R–सूची
2. खोजें	2. इनबॉक्स	2. प्राप्त	2. सर्विस एरिया	2. मूवी और संगीत
3. ग्रुप्स	3. 1234 सर्विसेस	3. डायल किये हुए	3. घड़ी और शॉर्टकद	3. प्ले और शॉप
4. शीघ्र डायल	4. आउटबॉक्स	4. कॉल मेमो में	4. समय और तिथि	4. डायल 1234
5. कॉपी & भेजें	5. वॉइस मेल	5. कॉल अवधि	5. वॉलपेपर	5. MMS लिखें
6. नाम मिटाएँ	6. UIM में संग्रह	6. विवरण मिटाएँ	6. सूची स्टाइल	6. MMS इनबॉक्स
7. मेरी प्रोफाइल	7. ड्राफ्ट्स	7. सहायता	7. रंग संरचना	7. R–सूची पुनः सेट
8. मेमोरी की जानकारी	8. टेम्प्लेट्स		8. लयबध्द रोशनी	8. UIM टूलकिट
9. सहायता	9. संदेश ग्रुप्स		9. स्क्रीन लाइट	9. गेम्स
	0. संदेश मिटाएँ		0. सहायता	0. सहायता
	*. संदेश सेटिंग्स			
	#. सहायता			

सॉफ्ट बटन 1 **सूची** दबाएँ. स्क्रॉल करने के लिये [⇕] दबाएँ.

प्रोफाइल्स

1. सिर्फ कंपन
2. Silent
3. General
4. Outdoor
5. हेडसेट
6. कारकिट
7. सहायता

निर्धारक/टूल्स

1. Bluetooth
2. वॉयस टूल्स
3. टाईम मैनेजर
4. मेमो
5. आरक्षित कॉल
6. अलार्म
7. स्टॉप वॉच
8. कैलक्युलेटर
9. इकाई रुपांतरक
0. विश्व घड़ी
*. सहायता

मल्टीमीडिया

1. कैमरा
2. FM रेडियो
3. MP3
4. मेरी सामग्री

सेटिंग्स

1. मेरी सूची
2. कॉल
   - कॉल फॉरवर्ड
   - कॉल प्रतीक्षा
   - किसी बटन उत्तर
   - स्वतः रिडायल
   - वॉइस प्राइवेसी
   - स्पष्ट आवाज़
   - कॉल समयक
   - कॉल संपर्क सचेतक
   - अस्वीकृत कॉल को SMS लिखें
   - अंतर्राष्ट्रीय कॉल प्रेफिक्स
   - सहायता
3. फोन
   - बटन रक्षक
   - एयर प्लेन मोड
   - डेटा सेटिंग्स
   - सर्विस सचेतक
   - वर्शन
   - सहायता
4. सुरक्षा
   - पिन कोड निवेदन
   - लॉक मोड
   - आपातकालीन नंबर
   - कोड बदलें
   - मेमोरी मिटाएँ
   - पूर्वनियत पर सेट करें
   - सहायता

पहली बार फोन का उपयोग करने से पहले पूरी बैटरी चार्ज कर लें. फोन के साथ एक रीचार्जेबल बैटरी आती है. अधिकतम स्टैंडबॉय और टॉक टाइम प्राप्त करने के लिए उपयोग में नहीं होने पर भी बैटरी को पूरी तरह चार्ज रखें.

बैटरी लगाना और निकालना

- बैटरी लगाने के लिए बैटरी को फोन के पिछले हिस्से में खाली जगह में डालें और धीरे से तब तक दबाएँ. जब तक कि लैच अपनी जगह क्लिक न हो जाएँ.
- इसे निकालने के लिए, फोन का पॉवर ऑफ करें और पिछले हिस्से को नीचे की ओर खीचें, अलग करने के लिए एक हाथ से टैब खीचें और बैटरी के ऊपरी हिस्से को उठाएँ.

बैटरी चार्ज करना

फोन के साथ दिये गये एसी एडॉप्टर चार्जर का उपयोग करने के लिए :

1. एसी एडॉप्टर को बिजली के प्लग में लगाएँ.
2. एडॉप्टर के गोल सिरे को फोन के नीचे स्थित एसी एडॉप्टर जैक में लगाएँ (सुनिश्चित करें कि बैटरी लगी हैं).

- जैसे – जैसे फोन चार्ज होता है, बैटरी का चिन्ह खाली ( )से भरे ( )होने तक पावर में वृद्धि दिखाता है.

पूरी तरह समाप्त हो चुकी बैटरी को रीचार्ज करने में लगभग तीन घंटे लगते हैं. जब बैटरी पूरी तरह चार्ज हो जाती है तो चार्जिंग संकेतक झपकता है.

बैटरी चार्ज स्तर

बैटरी चार्ज स्तर एलसीडी स्क्रीन के ऊपर दाई ओर दिखाई देता है.

जब बैटरी चार्ज स्तर कम हो जाता है, तो कम बैटरी सेंसर आपको तीन प्रकार से चेतावनी देगाः सुनाई देने वाली एक आवाज़ से, बैटरी चिन्ह आउटलाईन टिमटिमा कर और कम रीचार्ज करें प्रदर्शित करके, यदि बैटरी चार्ज स्तर बिलकुल कम हो जाता है तो फोन अपने आप बंद हो जाएगा और चल रहा कोई भी फंक्शन सुरक्षित नहीं होगा.

* चार्जिंग के विभिन्न स्तर पर अलग–अलग रंग प्रदर्शित होते हैं : नीला/हरा/पीला/लाल

बैटरी की देखभाल

1) यदि आप अनाधिकृत बैटरी का उपयोग करते हैं तो इससे बैटरी क्षतिग्रस्त हो सकती है या उसमे विस्फोट हो सकता है. इसलिए, कृपया अनाधिकृत बैटरियों का उपयोग न करें.
2) बैटरी को रीचार्ज करने के लिए आपको बैटरी के बिलकुल निचले स्तर तक पहुँचने का इंतजार नहीं करना चाहिये.
3) अपने LG फोन के मॉडल के लिए उपयुक्त बैटरी और चार्जर का ही उपयोग करें. LG के चार्जर बैटरी की आयु बढ़ातें हैं.
4) बैटरी को न तो खोलें और न ही शॉर्ट सर्किट करें.
5) बैटरी के धातु के सिरे साफ रखें.
6) बैटरी ठीक से काम न करे तो उसे बदल दें. बदलने की जरुरत पड़ने से पहले बैटरी को सैकड़ों बार चार्ज किया जा सकता हैं.
7) यदि बैटरी को बहुत समय से उपयोग नहीं किया गया हो तो उसकी आयु बढ़ाने के लिए उसे फिर से चार्ज करें.
8) बैटरी चार्जर को सूर्य की सीधी रोशनी में या बाथरुम जैसी नम जगहों पर न लें जाएँ.
9) बैटरी को गर्म या ठंडी जगह में न छोड़ें, इससे बैटरी की कार्यक्षमता घट सकती है.
10) लंबी स्क्रीन लाईट सेटिंग्स, सेवाओं की खोज, डेटा कनेक्टिविटी, और सिंक्रनाइजेशन बैटरी की आयु, टॉक और स्टैंडबॉय समय को प्रभावित कर सकते हैं.

फोन को बंद और चालू करना

फोन चालू करना

1) चार्ज किया हुआ बैटरी पैक लगाएँ या फोन को बाहरी पावर स्रोत से जोड़ें. जैसे कि सिगरेट लाईटर चार्जर, कार किट या AC एडॉप्टर.

2) बटन को 2 सेंकड तक दबाएँ जब तक कि एलसीडी स्क्रीन चालू न हो जाएँ.

नोट किसी भी अन्य संचार उपकरण की तरह, फोन के चालू होने पर एंटीना को स्पर्श न करें.

फोन बंद करना

1) बटन को स्क्रीन ऑफ होने तक दबाएँ रखें.

कॉल करना

जब भी आप कॉल करें, तो इन चरणों का पालन करें :

1) सुनिश्चित करें कि फोन चालू है, यदि नहीं है तो को 2 सेंकड तक दबाएँ रखें.

2) फोन नंबर लिखें और दबाएँ.
   - यदि फोन लॉक है, तो लॉक कोड डालें.

3) कॉल समाप्त करने के लिए दबाएँ.

नोट यदि आप सर्विस एरिया में नहीं हैं, तो स्क्रीन पर दिखाई देता है, सर्विस एरिया के बाहर से वॉइस कॉल करने पर, "कॉल पूरा नहीं हो पाया हैं. कृपया फिर से प्रयास करें", स्क्रीन पर आता हैं, इसका अर्थ यह है कि आप सर्विस एरिया में नही हैं.

कॉल प्राप्त करना

1) जब फोन की घंटी बजे या कंपन हो (यदि कंपन मोड चालू है), तो उत्तर देने के लिए (के अलावा) या कॉल सेटिंग्स के आधार पर बटन दबाएँ.
   - कॉल प्राप्त करते समय जब आप को एक बार दबाते हैं, तो मोड के अनुसार घंटी या कंपन बंद हो जाता है. संपर्क तोड़नें के लिए को दोबारा दबाएँ.

2) उत्तर दिए गए कॉल को समाप्त करने के लिए, दबाएँ.

3) यदि आप कॉल प्राप्त करने की स्थिति में नहीं हैं तो ,सॉफ्ट बटन 2 दबाकर आप कॉल करने वाले को एक संदेश भेज सकते हैं. सेटिंग्स में दिये "अस्वीकृत कॉल को SMS लिखें" फंक्शन से संदेश लिखा जा सकता है.

संकेत की शक्ति

यदि आप किसी इमारत के अंदर हैं तो खिड़की के पास रहने पर आपको बेहतर रिसेप्शन मिल सकता है. आप अपने फोन के प्रदर्शन स्क्रीन पर संकेतक ( ) से संकेत की शक्ति देख सकते हैं.

एंटीना के बारे में

आपके फोन में बिल्ट–इन एंटीना है. किसी भी रेडियो संचार उपकरण की तरह ही जब फोन चालू हो तो एंटीना को अनावश्यक स्पर्श ना करें. एंटीना को स्पर्श करने से कॉल की गुणवत्ता प्रभावित होती है और इससे फोन को आवश्यकता से अधिक पावर पर काम करना पड़ सकता है. कॉल के दौरान एंटीना ना छुने से आपके फोन के एंटीना की कार्य क्षमता व टॉक टाइम में बढ़ोतरी होती है. फोन को किसी अन्य फोन की तरह ही पकड़ें.

त्वरित समायोजन

कंपन मोड समायोजित करना

किसी सार्वजनिक स्थान पर कंपन मोड का उपयोग करें.

1) स्टैंडबॉय मोड में, सूची फंक्शन का उपयोग करने के बजाय * shift दबाकर (2 सेकंड तक) आप तुरंत कंपन मोड सक्रिय कर सकते हैं.
   - कंपन मोड के सक्रिय होने पर बटन स्वर की आवाज़ नहीं आती हैं.

नोट कंपन मोड से बाहर निकलने के लिए, * shift को 2 सेकंड तक दबाएँ.

प्रोफाइल्स चुनें

1) स्टैंडबॉय मोड में, ▶ दबाएँ.
2) चार प्रोफाइल्स – सिर्फ कंपन, Silent, General, और Outdoor में से एक चुनने के लिए ⬍ दबाएँ.
3) ● या सॉफ्ट बटन 1 **चुनें** दबाएँ.

स्पीकर मोड ऑन समायोजित करना

कॉल के दौरान स्पीकर मोड ऑन जल्दी से सक्रिय या रद्द करने के लिए, ● दबाएँ.

1) स्टैंडबॉय मोड में, ● को 2 सेकंड तक दबाकर स्पीकर मोड ऑन सक्रिय करें.

नोट स्पीकर मोड ऑन रद्द करने के लिए, को 2 सेकंड तक दबाएँ रखें.

यदि स्पीकर स्टैंडबॉय मोड में सक्रिय हो, तो कॉल के दौरान समायोजन कुछ भी हो, कॉल के बाद स्पीकर मोड जारी रहता है.

मेरी सूची चुनना

1) स्टैंडबॉय मोड में, मेरी सूची चुनने के लिए, C/Torch दबाएँ.

2) से इच्छित आइटम चुनें फिर सेटिंग सूची के अन्तर्गत मेरी सूची से आवश्यक सूची चुनने के लिए **सेटिंग्स** या दबाएँ.

* मेरी सूची में सामग्री जोड़नें के लिये सेटिंग सूची में जाकर जोड़ें.

बटन पैड लॉक

यह फंक्शन सेट होने पर भूल से कोई नंबर डायल होने का डर नहीं रहता.
जब यह फंक्शन सक्रिय होता है, तो कोई कॉल नहीं किया जा सकता है और सूची लॉक हो जाएगी. बटन पैड के लॉक होने पर भी कॉल का उत्तर दिया जा सकता है.

फंक्शन के सक्रिय करने के लिए :

1) 0 next बटन को दो सेकंड तक दबाएँ रखें.

फंक्शन को निष्क्रिय करने के लिए :

1) 0 next बटन को दो सेकंड तक दबाएँ रखें.

नोट सेटिंग सूची में बटन रक्षक समर्थ पर सेट होने पर बटन पैड तय समय पर स्वतः लॉक हो जायेगा.
आनेवाली कॉल समाप्त होने के बाद बटन पैड स्वतः लॉक हो जायेगा.

कॉल प्रतीक्षा

आपकी सेल्युलर सेवा कॉल प्रतीक्षा की सुविधा उपलब्ध करवा सकती है. जब कोई कॉल चल रहा हो तो आपको आने वाली दूसरी कॉल का संकेत करने वाली दो बीप सुनाई पड़ सकती हैं. कॉल प्रतीक्षा के सक्रिय होने पर, चल रहे कॉल को होल्ड पर रखकर आप आने वाली दूसरी कॉल को उत्तर दे सकते हैं. इस सुविधा के बारे में अपने सेवा प्रदाता से जानकरी लें.

1) प्रतीक्षित कॉल प्राप्त करने के लिए दबाएँ.

2) कॉल्स के बीच स्विच करने के लिए फिर से दबाएँ.

मौन

मौन फंक्शन सक्रिय होने पर दूसरा व्यक्ति आपकी आवाज नहीं सुन सकता, लेकिन आप उसकी आवाज सुन सकते हैं.

1) कॉल के दौरान सॉफ्ट बटन 1 सूची और 2abc दबाएँ.

2) मौन रद्द करने के लिए, सॉफ्ट बटन 1 सूची और फिर से 2abc दबाएँ.

कॉल पुनः डायल करना

1) नवीन कॉलों में से अंतिम नंबर डायल करने के लिए को दो बार दबाएँ.
   - आप कॉल विवरण में संग्रहीत पिछले 120 (छूटी + प्राप्त + डायल किये हुए) कॉल्स में से भी कोई नंबर डायल कर सकते हैं. (कॉल विवरण सूची पृष्ठ 42–43 देखें).

शीघ्र डायल

यह एक सुविधाजनक विकल्प है जिससे आप तुरंत और आसानी से कॉल कर सकते है. आपका फोन आपकी व्यक्तिगत डायरेक्टरी से फोन नंबर लाकर कुछ समय के लिए उसे दिखाता है और फिर उसे डायल करता है. सबसे ज्यादा डायल किए जाने वाले नंबरों के एक स्पर्श डायल के लिए आप मेमोरी स्थान 1 से 9 का उपयोग कर सकते हैं.

1) मेमोरी स्थान 1 से 9 डालें.

2) दबाएँ.

10 से 99 तक शीघ्र डायल करना

पहला अंक दबाएँ और फिर अंतिम अंक का बटन दबाएँ रखें
या
पहला और दूसरा अंक दबाएँ और दबाएँ.

कॉलर ID

कॉलर ID से आपके फोन की घंटी बजने पर कॉल करने वाले व्यक्ति का नंबर दिखाई देता है. यदि कॉल करने वाले का नाम और नंबर आपकी फोन बुक में पहले से दर्ज है तो नंबर के साथ नाम भी दिखाई देता है.
आपको अपने सेवा प्रदाता से पता कर लेना चाहिए कि वे यह सुविधा प्रदान करते हैं या नहीं.

T9 शब्द इनपुट मोड से लिखने की जानकारी

आप T9 शब्द इनपुट से बैनर, टाईम मैनेजर, शब्द संदेश, मल्टीमीडिया संदेश, ई–मेल और फोन बुक संपादित कर सकते हैं.

T9 शब्द लिखने का एक आसान तरीका है, इस इनपुट पद्धति में आपको प्रत्येक अक्षर के लिए बटन को सिर्फ़ एक बार दबाना पड़ता हैं.

बटनों के कार्य

सॉफ्ट बटन 2 : मोड चुनने के लिये दबाएँ.

– आप सॉफ्ट बटन 2 से निम्न मोड्स चुन सकते हैं : T9En, Abc, 123, प्रतीक, स्माईलीस, T9Hin, हिन्दी.

– शिफ्ट बटन [*] : अक्षर केस बदलने के लिए उपयोग करें.

[2] – [9] (शब्द लिखें) : T9 मोड में, शब्द लिखने के लिए प्रति अक्षर पर एक बार बटन दबाएँ.

[0] – [9] (नंबर लिखें) : 123 (नंबर) मोड में, नंबर लिखने के लिए एक बार बटन दबाएँ.

[0] (अगला) : T9En / T9Hin मोड में, अन्य मेल खाते शब्द प्रदर्शित करने के लिए दबाएँ.

[1] (विराम चिन्ह) : T9En / Abc मोड में, किसी शब्द में विराम चिन्ह सम्मिलित करने और वाक्य पूरा करने के लिए दबाएँ.

[#] (स्थान) : शब्द पूरा करने या स्थान सम्मिलित करने के लिए दबाएँ.

[C/Torch] (क्लीयर) : एक स्थान या अक्षर मिटाने के लिए दबाएँ, पुरे शब्दों को मिटाने के लिये दबाएँ रखे.

इनपुट मोड

T9 शब्द इनपुट में शब्द, नंबर, विशेष अक्षर और विराम चिन्ह लिखने के लिए 7 मोड्स उपलब्ध हैं.

T9En (T9) मोड

प्रत्येक अक्षर के लिए एक बार बटन दबाकर शब्द लिखें. पूर्वनियत मोड Abc हैं.

Abc (मल्टी – टेप) मोड

T9 डेटाबेस में शब्द जोड़ने के लिए Abc मोड का उपयोग करें.

123 (नंबर) मोड

प्रत्येक नंबर के लिए एक बार बटन दबाकर नंबर लिखें. किसी शब्द प्रविष्टि फील्ड में 123 मोड में बदलने के लिए, 123 मोड के प्रदर्शित होने तक सॉफ्ट बटन 2 दबाएँ.

प्रतीक/स्माईलीस मोड

विशेष अक्षर, चिन्ह या स्माईलीस सम्मिलित करें. आप किसी भी विशेष अक्षर का उपयोग कर सकते हैं, उस जगह कर्सर आ जाने पर जहाँ आप विशेष अक्षर चाहते हैं, चिन्ह/स्माईलीस मोड में जाएँ. यदि आप स्माईली जोड़ना चाहते हैं, तो स्माईलीस मोड में जाएँ. इच्छित अक्षर देखने के लिए नेविगेशन बटन ◀◉▶ दबाएँ : अक्षर चुनने के लिए, निर्धारित नंबर बटन दबाएँ.

T9Hin (T9) मोड

T9 हिन्दी शब्दकोश फंक्शन की सहायता से प्रत्येक वर्ण के लिए एक बार बटन दबाकर हिन्दी शब्द लिखें.

हिन्दी (मल्टी–टैप) मोड

हिन्दी भाषा में शब्द जोड़ने के लिए इस मोड का उपयोग करें.

प्रारंभिक बड़ा (T9En/Abc)

सिर्फ पहला अक्षर बड़ा होता है.

बड़ा अक्षर लॉक (T9EN/ABC)

सभी अक्षर बड़े हो जाते हैं.

छोटा केस (T9en/abc)

सभी अक्षर छोटे होते हैं.

T9 शब्द इनपुट उपयोग के उदाहरण

T9 मोड में लिखना

जब आप T9 मोड का उपयोग करना चाहें, तो जाँच लें कि T9En नीचे दाई ओर दिखाई दे रहा हैं. इच्छित शब्द लिखने के लिए प्रत्येक अक्षर के लिए प्रत्येक बटन को एक बार दबाएँ.

उदाहरण के लिए 'Call the Office' इस तरह लिखें :

1. अक्षर केस को T9En मोड में बदलने के लिए सॉफ्ट बटन 2 दबाएँ.
2. 2 2 5 5 दबाएँ.
3. शब्द पूरा करने और एक स्थान जोड़ने के लिए # दबाएँ.
4. 8 4 3 # 6 3 3 4 2 3 दबाएँ.
5. प्रदर्शन **Call the office**.

जैसा कि आप देख सकते हैं, हर बार बटन दबाने पर शब्द बदल जाते हैं, इसलिए पूरा शब्द लिखने तक स्क्रीन पर क्या हो रहा हैं, इस पर आपको ज्यादा ध्यान देने की आवश्यकता नहीं हैं.

अगला बटन का उपयोग

एक शब्द लिखने के बाद, यदि सही शब्द दिखाई नहीं देता है, तो अतिरिक्त विकल्प देखने के लिए, [0 next] दबाएँ.
उदाहरण के लिए, निम्न चरणों का पालन करें :

1. [4 ghi] [6 mno] [6 mno] [3 def] दबाएँ.
2. प्रदर्शन **Good**.
3. [0 next] दबाएँ.
4. प्रदर्शन **Home , Gone, Hood**…..

Abc (मल्टी–टैप) शब्द इनपुट उपयोग के उदाहरण

Abc (मल्टी–टैप) मोड में लिखना

उदाहरण के लिए, "LG" लिखने के लिए, इन चरणों का पालन करें :

1. अक्षर केस को Abc मोड में बदलने के लिए सॉफ्ट बटन 2 दबाएँ.
2. ABC बड़ा अक्षर लॉक मोड को बदलने के लिए [* shift] बटन दबाएँ.
3. [5 jkl] [5 jkl] [5 jkl] [4 ghi] दबाएँ.
4. प्रदर्शन **LG**.

T9 डेटाबेस में शब्द जोड़ना

यदि कोई शब्द T9 डेटाबेस में नहीं है तो इसे Abc (मल्टी – टैप) मोड शब्द प्रविष्टि से रिकॉर्ड में जोड़े. जब आप T9 मोड में लौटेंगे तब T9 डेटाबेस में वह शब्द अपने आप जुड़ जाएगा.
उदाहरण के लिए, इन चरणों का पालन करें :

1. अक्षर केस को Abc (मल्टी – टैप) मोड में बदलने के लिए सॉफ्ट बटन 2 दबाएँ.
2. [4 ghi] [4 ghi] [4 ghi] [6 mno] [8 tuv] दबाएँ.
3. प्रदर्शन **Imt**.
4. सॉफ्ट बटन 2 दबाकर इनपुट मोड को T9 मोड में बदलें और [# space] बटन दबाएँ. अब Imt शब्द T9 डेटाबेस में जुड़ जाएगा.
5. मौजूदा शब्द मिटाने के लिए [C/Torch] दबाएँ.
6. [4 ghi] [6 mno] [8 tuv] दबाएँ.
7. प्रदर्शन **Imt**.
8. दूसरे मेल के शब्द देखने के लिये [0 next] दबाएँ.

हिन्दी में लिखने के लिये बटन मैपिंग

हिन्दी में 13 स्वर, 44 व्यंजन और 15 मात्राएँ होती है.

बैंगनी रंग वाले अक्षर केवल मल्टी टैप मोड में उपलब्ध है.

बटनों की मैपिंग इस प्रकार है :

Key	Hindi Entry
0 next ्र्ो	0
1@ ँ ं ः ् ़	ँ ं ः ् ़ 1
2 abc अ-ऊ	ा ि ी ु ू ृ अ आ इ ई उ ऊ ऋ 2
3 def ए-औ	े ै ॅ ो ौ ॉ ए ऐ ऍ ओ औ ऑ 3
4 ghi क-ङ	क ख ग घ ङ 4 क़ ख़ ग़
5 jkl च-ञ	च छ ज झ ञ 5 ज़
6 mno ट-ण	ट ठ ड ढ ण 6 ड़ ढ़
7 pqrs त-न	त थ द ध न 7 ऩ
8 tuv प-म	प फ ब भ म 8 फ़
9 wxyz य-ह	य र ल व श ष स ह 9 ळ ऱ ऴ य़

हिन्दी मोड में संपादन के लिए

सॉफ्ट बटन 2 दबाकर घहिन्दी" मोड बदलें.

हिन्दी मोड संपादन

हिन्दी एक बहु – टैप मोड है.
उदाहरण के लिए, "**हिन्दी**" लिखने के लिए:

1. 2 2 बार दबाएँ.
2. 9 8 बार दबाएँ.
3. 7 5 बार दबाएँ.
4. 1 4 बार दबाएँ.
5. 7 3 बार दबाएँ.
6. 2 3 बार दबाएँ.

हिन्दी के लिय T9 शब्द इनपुट उपयोग के उदाहरण

उदाहरण के लिए '**भारतीय**' इस तरह लिखें

1. अक्षर केस को T9Hin मोड में चुनें
2. 8 2 9 7 2 9 दबाएँ.
3. शब्द पूरा करने और एक स्थान जोड़ने के लिए # दबाएँ.
4. प्रदर्शन **भारतीय**.

बाइट का वितरण:

संदेशों में : हिन्दी में प्रत्येक अक्षर 3 बाइट्स लेता है, जबकि 'क्ष', 'त्र', 'ज्ञ' में 9 बाइट्स होते हैं.
अन्य सभी मॉड्यूल्स में : हिन्दी में प्रत्येक अक्षरों के लिए 1 बाइट होता है, जबकि 'क्ष', 'त्र', 'ज्ञ' के लिए 3 बाइट्स होते हैं.

पूर्वनियोजित शब्द का संपादन

कभी–कभी T9 चुनाव सूची पूर्वनियोजित शब्द दर्शाता है.
पूर्वनियोजित शब्द से तात्पर्य है कि T9 इसे आपके डाले गये अक्षरों को देखते हुये आपकी जरुरत का शब्द समझता है.
पूर्वनियोजित शब्द T9 और Abc दोनो मोड में नीचे रेखांकित कर दर्शाये जाते हैं.
यदि प्रदर्शित किया गया पूर्वनियोजित शब्द आपकी जरुरत का नहीं है, तो अगला बटन दबाकर दूसरे पूर्वनियोजित शब्द देखे जा सकते हैं.
इच्छित शब्द प्रदर्शित होने पर # दबाकर शब्द और एक जगह जोड़ें और दूसरा शब्द लिखना शुरु करें.
अगर आपका इच्छित पूर्वनियोजित शब्द चुनाव सूची में नहीं है, तो आपना शब्द पूर्ण करने के लिये अक्षर लिखते रहें. T9 पूर्वनियोजित शब्द स्वतः हट जायेगा.

सूची तक पहुँचने और सेटिंग्स के सामान्य दिशानिर्देश

1. सॉफ्ट बटन 1 **सूची** दबाएँ. प्रदर्शन स्क्रीन पर 9 सूची आइटम दिखाई देगें.
2. सूची सुविधाओं की सूची देखने के लिए दबाएँ.
3. जो सूची आइटम आप चुनना चाहते हैं, उससे संबंधित नंबर दबाएँ. तब स्क्रीन पर उपसूची दिखाई देगी.
4. इच्छित उपसूची तक पहुँचने के लिए उपयुक्त बटन दबाएँ.
5. का उपयोग करके पसंदीदा सेटिंग्स चुनें. सूची तक पहुँचते या सेटिंग्स चुनते समय एक स्तर पीछे जाने के लिए C/Torch दबाएँ.
6. सेटिंग्स सुरक्षित करने के लिए दबाएँ या बिना सुरक्षित किए रद्द करने के लिए C/Torch दबाएँ.

नोट

बटन, सॉफ्ट बटन 1 के 'चुनें' विकल्प से संबंधित होने की स्थिति में सॉफ्ट बटन 1 **'चुनें'** का काम करता हैं.

बटन, सॉफ्ट बटन 1 के पॉपअप सूची से संबंधित होने की स्थिति में सॉफ्ट बटन 1 **'विकल्प'** का काम करता है.

1. नाम

1.1 नाम जोड़ें

आप फोनबुक में किसी नाम के साथ एक से ज्यादा संपर्क विवरण दर्ज कर सकते हैं: 4 फोन नंबर, 1 ई–मेल. आप नाम को किसी ग्रुप में भी जोड़ सकते हैं, आने वाली कॉल या संदेश के लिये रिंग स्वर भी सेट कर सकते हैं, अतिरिक्त विवरण मेमो में नोट कर सकते हैं. आप किसी नाम के साथ पिक्चर भी निर्धारित कर सकते हैं. फ़ोन बुक में 2500 तक संपर्क जोड़े जा सकते हैं. UIM कार्ड में अलग से मेमोरी है.

1. सॉफ्ट बटन 1 **सूची** दबाएँ.
2. 1 **नाम** चुनें.
3. 1 **नाम जोड़ें** चुनें.

- **फोन** या **UIM** की जगह चुनें जहाँ आप सुरक्षित करना चाहते हैं.

4. से अपना इच्छित आइटम चुनें.
5. अपने रिकार्ड को सुरक्षित करने के लिए दबाएँ.

नोट

- UIM कार्ड की मेमोरी के लिए अपने सर्विस प्रदाता से सम्पर्क करें.
- UIM कार्ड में शीघ्र डायल निर्धारित नहीं कर सकते हैं.

1.2 खोजें

फोन बुक में सुरक्षित फोन नंबर खोजने के लिये.

1. सॉफ्ट बटन 1 **सूची** दबाएँ.
2. 1 **नाम** चुनें.
3. 2 **खोजें** चुनें.
4. आप नाम द्वारा या नंबर द्वारा खोज सकते हैं.
5. नाम या नंबर के वर्ण लिखना शुरू करें. स्क्रीन पर आपकी पसंदीदा प्रविष्टि प्रदर्शित होती है.
6. सम्पादन के लिए दबाएँ और चुनें हुए नंबर पर संदेश भेजने के लिए सॉफ्ट बटन 2 दबाएँ.
7. निम्नलिखीत विकल्पों को चुनने के लिए सॉफ्ट बटन 1 दबाएँ.

   संपादन/आरक्षित कॉल/संपर्क भेजें/UIM **में कॉपी/**UIM **में भेजें/**Bluetooth **द्वारा भेजें/मिटाएँ**

1.3 ग्रुप्स

यह फंक्शन ग्रुप का नाम बदलने और ग्रुप के लिए रिंग स्वर सेट करने के लिए है.

1. सॉफ्ट बटन 1 **सूची** दबाएँ.
2. 1 **नाम** चुनें.
3. 3 **ग्रुप्स** चुनें.
4. का उपयोग करके इच्छित ग्रुप चुनें.
5. सॉफ्ट बटन 1 **विकल्प** दबाएँ.

   सदस्य देखें : ग्रुप में सुरक्षित सदस्यों के नाम देखें.
   रिंगस्वर सेट करें : ग्रुप रिंग स्वर सेट करें.
   संदेश स्वर सेट करें : ग्रुप संदेश स्वर सेट करें.

   सॉफ्ट बटन 2 **संपादन** दबाएँ : ग्रुप का नाम संपादित करें.

नोट शिर्षक कोई ग्रुप नहीं बदला नहीं जा सकता.

1.4 शीघ्र डायल

शीघ्र डायल से आप केवल एक संबंधित अंक दबाकर शीघ्रता से कॉल कर सकते हैं.

1. सॉफ्ट बटन 1 **सूची** दबाएँ.
2. 1 **नाम** चुनें.
3. 4 **शीघ्र डायल** चुनें.
4. रजिस्टर करने के लिए, सॉफ्ट बटन 1 **विकल्प** का उपयोग करें और इच्छित जानकारी खोजने के लिए निर्धारित चुनें, फिर सॉफ्ट बटन 1 **निर्धारित** दबाएँ.

नोट

मिटाने के लिए, सॉफ्ट बटन 2 **मिटाएँ** दबाएँ और हाँ चुनें. सॉफ्ट बटन 1 चुनें दबाएँ.

सभी संग्रहीत शीघ्र डायल मिटाने के लिए सॉफ्ट बटन 1 **विकल्प** दबाएँ और **सभी मिटाएँ** चुनें. किसी विशेष स्थान के लिए निर्धारित अंक बदलने के लिए बदलें चुनें.

शीघ्र डायल 01 से 99 तक है.

1.5 कॉपी & भेजें

आप UIM कार्ड मेमोरी से फोन मेमोरी में प्रविष्टियॉ कॉपी/भेज सकते हैं.

1. सॉफ्ट बटन 1 **सूची** दबाएँ.
2. 1 **नाम** चुनें.
3. 5 **कॉपी** & **भेजें** चुनें.
4. **फोन -> UIM** या **UIM -> फोन** चुनें और ● दबाएँ.

▶ UIM प्रत्येक संपर्क के लिए केवल एक नंबर ही लेता है, इसलिए **फोन -> UIM** में केवल पूर्वनियत नंबर ही कॉपी होगा.

5. **हाँ** या **नहीं** विकल्प चुनें.

▶ सोर्स फाईल को कॉपी या भेजनें के लिए **हाँ** चुनें.

कॉपी : सोर्स फाईल को कॉपी करें.

भेजें : सोर्स फाईल को मिटाएँ.

1.6 नाम मिटाएँ

नाम में सुरक्षित की गयी प्रविष्टियों को मिटाएँ.

1. सॉफ्ट बटन 1 **सूची** दबाएँ.
2. 1 **नाम** चुनें.
3. 6 **नाम मिटाएँ** चुनें.
4. से इच्छित नाम चुनें.
5. दबाएँ, बाद में सॉफ्ट बटन 1 **विकल्प** दबाएँ और **मिटाएँ** चुनें.

1.7 मेरी प्रोफाइल

आप खुद की संपर्क जानकारी और फोन नंबर सुरक्षित कर सकते हैं और देख सकते हैं.

1. सॉफ्ट बटन 1 **सूची** दबाएँ.
2. 1 **नाम** चुनें.
3. 7 **मेरी प्रोफाइल** चुनें.
4. से अपना इच्छित आइटम डालें.
5. विवरण को अपने रिकार्ड में सुरक्षित करने के लिए दबाएँ.

1.8 मेमोरी की जानकारी

मेमोरी की जानकारी कॉर्ड और फोन में सुरक्षित फोनबुक की वर्तमान नंबर दर्शाता है. यह सुरक्षित किये गये/उपलब्ध नंबर दर्शाता है.

1. सॉफ्ट बटन 1 **सूची** दबाएँ.
2. 1 **नाम** चुनें.
3. 8 **मेमोरी की जानकारी** चुनें.

1.9 सहायता

आप इस सूची के बारे में और जानकारी प्राप्त कर सकते हैं.

2. संदेश

पावर चालू करते ही शब्द संदेश, पेज, ई–मेल और वॉइस मेलबॉक्स उपलब्ध हो जाते हैं. आप उपरोक्त प्रकार के संदेशों तक संदेश बटन का उपयोग करके पहुँच सकते हैं.

इसके अलावा, आप संदेश देखते समय दबाकर उस नंबर पर कॉल कर सकते हैं.

फोन में 31 संदेश (1 वॉइस संदेश : 30 शब्द संदेश) संग्रहीत हो सकते हैं, जिसमें प्रत्येक संदेश में 160 बॉइट हो सकते हैं. हिन्दी में प्रत्येक अक्षर को तीन वर्ण माना जाता है (हालाँकि, क्ष, त्र, ज्ञ में से प्रत्येक का 9 वर्ण का माना जाता है) इसलिए, हिन्दी के किसी एसएमएस संदेश में केवल 46 अक्षर तक हो सकते हैं.

उपयोगकर्ता संदेश पढ़ और संपादित कर सकता है, भेजने के दौरान आउटबॉक्स में सुरक्षित कर सकता है और फिर उन्हे भेज सकता है.

हालाँकि आपको यह देखना चाहिए कि आपका सेवा प्रदाता उपरोक्त सुविधाएँ प्रदान करता है या नहीं.

आपके फोन में एस एम एस संदेश इनबॉक्स (30), आउटबॉक्स (15 भेजे हुए/15 नहीं भेजे हुए), संग्रह (30), ड्राफ्ट्स (30), और 30 टेम्प्लेट्स (10 पूर्वनियत/20 अतिरिक्त) संग्रहित किये जा सकते हैं.

या पूरे 120 संदेश और 1 वॉइस मेल.

अक्षर सीमा : LG – RD6250 भेजने और प्राप्त होने वाले प्रति संदेश अंग्रेजी में 160 और हिन्दी में 46 अक्षर तक लेता हैं. ई–मेल में 20 अक्षरों तक का विषय और 140 अक्षरों तक का संदेश लिखा जा सकता है.

ई–मेल, विषय + ई–मेल पता + ई–मेल संदेश के रुप में रहता हैं ई–मेल विषय 20 और ई–मेल पता 50 अक्षरों तक हो सकता है.

इसलिये, कुल संदेश अक्षर 160 – विषय अक्षर – ई–मेल पता अक्षर के रुप में जोड़ा गया हैं.

MMS (मल्टीमीडिया संदेश सर्विस)

फोन के MMS इनबॉक्स में 30 MMS/50 अधिसूचना, आउटबॉक्स में 50 (भेजे गये/नहीं भेजे गये) और ड्राफ्ट्स में 20 मल्टीमीडिया संदेश सुरक्षित हो सकते हैं. तेज और आसान तरीके से संदेश लिखने के लिये 11 तैयार/4 लिखें जा सकने वाले टेम्प्लेट्स उपलब्ध हैं.

LG-RD6250 MMS में अंग्रेजी के 1000 अक्षरों तक/हिन्दी में 333 अक्षरों तक के संदेश लिखें जा सकते हैं. प्रत्येक संदेश में 300 Kbytes साइज तक के एक चित्र और एक ध्वनि/एक मूवी जोड़ सकते हैं. संदेशो में संग्रहित जानकारी फोन के मोड और सर्विस पर निर्भर करती है. आप संदेशों के प्रकार पर बटन दबाकर पहुँच सकते हैं.

2.1 लिखें

एलएमएस (लॉग मैसेज सर्विस) से आप एक बार में 462 अक्षरों तक का कोई संदेश भेज सकते हैं. एलएमएस संदेश भेजने से पहले, बनने वाले एसएमएस पैकेट्स की कुल संख्या उपयोगकर्ता को बताकर उससे भेजने की पुष्टि कर ली जाती है. अंग्रेजी के अधिकतम 3 पैकेट और हिन्दी संदेश के अधिकतम 4 पैकेट भेजे जा सकते हैं. प्रत्येक एलएमएस पैकेट एक एकल संदेश के रुप में प्राप्त किया जाता है. प्रत्येक एलएमएस संदेश, संदेश में पैकेटो के क्रम की संख्या दर्शाता है, जैसे 3 पैकेट होने पर, <1/3>, <2/3>, <3/3>.

2.1.1 शब्द लिखें

शब्द संदेश और पेज संदेश सभी उपलब्ध हैं.
शब्द संदेश : शब्द भेजता है.
पेज संदेश : बिना शब्द संदेश के केवल नंबर भेजता है.
संदेश भेजने के लिए **विकल्प** में **भेजें** दबाएँ.
कोई संदेश भेजने के लिए को भेजें स्क्रीन में गंतव्य मोबाइल नंबर लिखें.

इसमे चार वैकल्पिक सूचियाँ भेजें, टेम्प्लेट्स, सुरक्षित और हस्ताक्षर जोड़ें होती हैं.

1. सॉफ्ट बटन 1 **सूची**, 2 abc या दबाएँ.
2. 1 **लिखें** चुनें.
3. 1 **शब्द लिखें** चुनें.
4. भेजें चुनकर भेजा जाने वाला संदेश लिखने के बाद, सॉफ्ट बटन 1 **विकल्प** दबाएँ.
   - ▶ **भेजें** — संदेश भेजने के लिए उपयोग करें.
   - ▶ **टेम्प्लेट्स** — कोई नमूने का संदेश चुनें.
   - ▶ **सुरक्षित** — ड्राफ्ट्स संदेश में सुरक्षित करें.
   - ▶ **हस्ताक्षर जोड़ें** — आप हस्ताक्षर जोड़ सकते हैं.
   - ▶ **नंबर डालें** — फोनबुक में से नंबर देखें और संदेश के साथ जोड़ें.
5. गंतव्य फोन नंबर लिखने के बाद, दबाकर अगले प्राप्तकर्ता का पता लिखें, आप 10 प्राप्तकर्ता तक जोड़ सकते हैं. सॉफ्ट बटन 1 **विकल्प** दबाएँ.
   - ▶ **भेजें** — संदेश भेजने के लिए उपयोग करें.
   - ▶ **अंतिम** — किसी नवीन भेजे गये नंबरों में से चुनें.
   - ▶ SMS **ग्रुप्स** — एसएमएस ग्रुप चुनें.
   - ▶ **नाम खोजें** — कोई फोन बुक प्रविष्टि चुनें.
6. यदि आप भेजें चुनते हैं, तो यह आपको सूचित करेगा कि संदेश सफलतापूर्वक भेज दिया गया है या नहीं.
   - ▶ **भेजें** — संदेश भेजने के लिए उपयोग करें.
   - ▶ **प्राथमिकता** — आप संदेश को प्राथमिकता दे सकते हैं. सामान्य या अति आवश्यक.

- **भेज दिया गया** — भेजे गए संदेश के दूसरे पक्ष के फोन पर प्राप्त होते समय, इस फंक्शन से आप पता कर सकते हैं कि आपका संदेश दूसरे पक्ष को सफलतापूर्वक भेज दिया गया है या नहीं. यदि आप फंक्शन सक्रिय करना चाहते हैं, तो ऑन सेट करें.
- **विलंबित** — आपको सेट की गई समय सीमा तक संदेश भेजना विलंबित करने की सुविधा देता है. तुरंत, 30 मिनट के बाद, 1 घंटे के बाद, 2 घंटे के बाद, 12 घंटे के बाद, 1 दिन के बाद और 2 दिन के बाद.
- **वैधता** — कुछ समय तक गंतव्य पते को संदेश न भेजे जाने पर संक्षिप्त संदेश केन्द्र (SMC) पर संदेश भेजने की वैधता दिखाता है, ये संदेश सेट की गई समय सीमा में मिटा दिए जायेगें. वैधता समय सीमाएँ निम्न प्रकार हैं: पूर्वनियत, 30 मिनट, 1 घंटे, 2 घंटे, 12 घंटे, 1 दिन और 2 दिन.
- **भेजे गए सुरक्षित** — आप यह संदेश आउटबॉक्स में सुरक्षित कर सकते हैं.

2.1.2 ई–मेल लिखें

ई–मेल से संदेश भेजें

1. सॉफ्ट बटन 1 **सूची**, 2 या दबाएँ.
2. 1 **लिखें** चुनें.
3. 2 **ई–मेल लिखें** चुनें.

   यहाँ भेजें, अंतिम, ई–मेल ग्रुप्स और नाम की चार वैकल्पिक सूचियाँ हैं.
   - **भेजें** — संदेश भेजने के लिए उपयोग करें.
   - **अंतिम** — अभी भेजा हुआ ई–मेल संदेश चुनें.
   - **ई–मेल ग्रुप्स** — कोई ई–मेल समूह चुनें.
   - **नाम रगेजें** — फोन बुक प्रविष्टि चुनें.
4. संदेश भेजने के लिए ई–मेल पता लिखने के बाद, दबाकर अगले प्राप्तकर्ता का पता दर्ज करें. आप 10 प्राप्तकर्ता जोड़ सकते हैं. सॉफ्ट बटन 1 **विकल्प** दबाएँ.
   - **भेजें** — संदेश भेजने के लिए उपयोग करें.
   - **डोमेन्स** — कोई डोमेन चुनें.
5. विषय लिखने के बाद, सॉफ्ट बटन 1 **अगला** दबाएँ.

6. संदेश लिखने के बाद, भेजें चुनकर सॉफ्ट बटन 1 **विकल्प** दबाएँ.

- ▶ **भेजें** संदेश भेजने के लिए उपयोग करें.
- ▶ **टेम्प्लेट्स** कोई नमूने का संदेश चुनें.
- ▶ **सुरक्षित** संदेश ड्राफ्ट्स में सुरक्षित करें.
- ▶ **प्राथमिकता** आप संदेश को प्राथमिकता दे सकते है. सामान्य या अति आवश्यक.
- ▶ **भेज दिया गया** भेजे गए संदेश दूसरे पक्ष के फोन पर प्रात होते समय इस फंक्शन से आप पता कर सकते हैं कि आपका संदेश दूसरे पक्ष को सफलतापूर्वक भेज दिया या है या नहीं. यदि आप यह फंक्शन सक्रिय करना चाहते हैं, तो ऑन सेट करें.
- ▶ **विलंबित** आपको प्रोग्राम्ड समय सीमा तक संदेश भेजना विलंबित करने की सुविधा देता है. तुरंत/30 मिनट के बाद/1 घंटे के बाद/2 घंटे के बाद/12 घंटे के बाद/1 दिन के बाद/2 दिन के बाद.
- ▶ **वैधता** कुछ समय तक गंतव्य पते को संदेश न भेजे जाने पर संक्षिप्त संदेश केन्द्र (SMC) पर संदेश भेजने की वैधता दिखाता है, ये संदेश सेट की गई समय सीमा में मिटा दिए जाएँगे. वैधता समय सीमाएँ निम्न प्रकार हैं: पूर्वनियत, 30 मिनट, 1 घंटे, 2 घंटे, 12 घंटे, 1 दिन और 2 दिन.
- ▶ **भेजे गए सुरक्षित** आप यह संदेश आउटबॉक्स में सुरक्षित कर सकते हैं.
- ▶ **हस्ताक्षर जोड़ें** आप हस्ताक्षर जोड़ सकते हैं.
- ▶ **नंबर डालें** संदेश के लिए नंबर डालें.

2.1.3 मल्टीमीडिया संदेश लिखें

– आप एक मूवी के लिए अपने संदेश के साथ चित्र और ध्वनि शामिल कर सकते हैं.
– ई–मेल ID और फोन नंबर पर भेजें.
– प्रत्येक संदेश में 1000 तक अक्षर, एक चित्र और एक ध्वनि सपोर्ट करता है.

सूची

इसमे 8 वैकल्पिक सूचियाँ भेजें, चित्र/मूवी शामिल करें, ध्वनि शामिल करें, टेम्प्लेट्स, पूर्व दर्शन, सुरक्षित, चित्र/मूवी हटायें और ध्वनि बंद करें हैं.

1. सॉफ्ट बटन 1 **सूची**, 2 या दबाएँ.
2. 1 **लिखें** चुनें.
3. 3 **मल्टीमीडिया संदेश लिखें** चुनें.
4. भेजें चुनकर भेजा जाने वाला संदेश लिखने के बाद, सॉफ्ट बटन 1 **विकल्प** दबाएँ.
   - ▶ **भेजें** — संदेश भेजने के लिए उपयोग करें.
   - ▶ **चित्र/मूवी डालें** — मल्टीमीडिया संदेश संपादन के लिये चित्र शामिल करें.
   - ▶ **ध्वनि शामिल करें** — मल्टीमीडिया संदेश संपादन के लिये ध्वनि शामिल करें.
   - ▶ **नंबर डालें** — संदेश के लिए नंबर डालें.
   - ▶ **टेम्प्लेट्स** — कोई नमूने का संदेश चुनें.
   - ▶ **पूर्व दर्शन** — तैयार किया मल्टीमीडिया संदेश देखें
   - ▶ **सुरक्षित** — संदेश ड्राफ्ट्स में सुरक्षित करें.
   - ▶ **चित्र/मूवी मिटाएँ** — तैयार किया मल्टीमीडिया संदेश से चित्र मिटाएँ.
   - ▶ **ध्वनि मिटाएँ** — तैयार किया मल्टीमीडिया संदेश से ध्वनि मिटाएँ

   यहाँ अंतिम, नाम, नंबर, और MMS ग्रुप्स की चार वैकल्पिक सूचियाँ हैं.
   - ▶ **भेजें** — संदेश भेजने के लिए उपयोग करें.
   - ▶ **अंतिम** — अभी भेजा हुआ नंबर चुनें.
   - ▶ **नाम खोजें** — फोन बुक प्रविष्टि में से चुनें.
   - ▶ MMS **ग्रुप** — कोई MMS ग्रुप्स चुनें.
5. संदेश भेजने के लिए फोन नंबर या ई–मेल पता लिखने के बाद, दबाकर अगले प्राप्तकर्ता का पता दर्ज करें. आप 10 प्राप्तकर्ता जोड़ सकते हैं. सॉफ्ट बटन 1 **विकल्प** दबाएँ.
   - ▶ **भेजें** — संदेश भेजने के लिए उपयोग करें.
   - ▶ **डोमेन्स** — कोई डोमेन चुनें.
   - ▶ **भेजा** MMS **सुरक्षित करें** — आप संदेश सुरक्षित करना चाहते हैं या नहीं का विकल्प चुनें.
6. अगर आप भेजें चुनते हैं तो, आपको सुचना दी जायेगी कि संदेश दूसरे पक्ष को सफलतापूर्वक भेज दिया या है या नहीं.

2.1.4 संदेश Chat

संदेश Chat आपके संदेश भेजने के अनुभव को और बढ़ाता है. यह साधारण शब्द संदेश की तरह ही इस्तेमाल होता है. जैसेकि, प्रत्येक Chat संदेश MSN मैसेजंर की तरह एक ही स्क्रीन में दिखता है. Chat के दौरान, कोई भी भेजा गया या प्राप्त संदेश इनबॉक्स या आउटबॉक्स में सुरक्षित नहीं होता है. परन्तु अंतिम Chat की सभी सामग्री आपकी सुविधा के लिये सुरक्षित होती है.

1. सॉफ्ट बटन 1 **सूची**, 2 या दबाएँ.
2. 1 **लिखें** चुनें.
3. 4 **संदेश** Chat चुनें.
4. दूसरी पार्टी का मोबाइल नंबर और अपना Chat का नाम लिखें और फिर दबाएँ.
5. अपना संदेश टाइप करें और भेजने के लिये दबाएँ.
6. सॉफ्ट बटन 1 **विकल्प** दबाएँ.

▶ **भेजें**	बैंज संदेश भेजें
▶ **टेम्प्लेट**	मौजुद टेम्प्लेट में से संदेश चुनें
▶ **Chat नाम बदलें**	अपना Chat का नाम बदलें
▶ **प्राप्तकर्ता बदलें**	प्राप्तकर्ता बदलने के लिये नंबर बदलें
▶ **एक/दो लाईन संपादन**	संपादन मोड एक या दो लाईनों में से चुनें
▶ **स्क्रॉल मोड**	स्क्रॉल मोड चुनें
▶ **निकलें**	Chat संदेश से बाहर निकलें

2.2 इनबॉक्स

प्राप्त शब्द संदेश, पेज, ई–मेल संदेश, भेज दिया गया, सूचियाँ खोजी जा सकती हैं और सामग्री देखी जा सकती है. प्राप्त संदेश, अति आवश्यक संदेश, अपठित संदेश और पढ़े हुए संदेशों में छाँटे जा सकते हैं. इसमें 30 संदेश सुरक्षित किए जा सकते हैं.

MMS इनबॉक्स में अधिकतम 80 MMS और 50 अधिसूचना संदेश सुरक्षित किए जा सकते हैं.

प्राप्त संदेशों की सूची देखने के लिए.

2.2.1 SMS इनबॉक्स

1. सॉफ्ट बटन 1 **सूची**, 2 या दबाएँ.
2. 2 **इनबॉक्स** चुनें.
3. 1 SMS **इनबॉक्स** चुनें.
   - ▶ संदेश नहीं पढ़े हुए/पढ़े के क्रम में सुरक्षित किए जाते हैं. उदाहरण के लिए, यदि कोई नया संदेश पढ़ लिया जाता है तो यह पढ़े संदेशों में चला जाता हैं.

: नहीं पढ़े हुए एसएमएस

: नहीं पढ़े हुए ई–मेल

: पढ़े हुए एसएमएस : पढ़े हुए ई–मेल

4. से इच्छित संदेश चुनने के बाद या सॉफ्ट बटन 1 **विकल्प** दबाएँ और देखें चुनें.
   - ▶ **देखें** आप चुना हुआ संदेश पढ़ सकते हैं.
   - ▶ **मिटाएँ** SMS इनबॉक्स से चयनित संदेश हटाएँ.
5. संदेश देखने के बाद सॉफ्ट बटन 1 **विकल्प** या सॉफ्ट बटन 2 **जवाब** दबाएँ.
   - ▶ **जवाब** इस फंक्शन से आप इस संदेश का उत्तर दे सकते हैं.
   - ▶ **मिटाएँ** SMS इनबॉक्स से चयनित संदेश मिटाता है.
   - ▶ **संदेश** Chat आप दूसरो के साथ Chat कर सकते हैं.
   - ▶ **फॉरवर्ड** किसी प्राप्त संदेश को दूसरों को फॉरवर्ड करता है. प्राप्तकर्ता लिखें जाने के बाद संदेश फॉरवर्ड किए जा सकते हैं.
   - ▶ **संग्रह को** चयनित संदेश को SMS इनबॉक्स से संग्रह में ले जाता है.
   - ▶ **पता सुरक्षित** प्रेषक के नंबर या ई–मेल पते या प्राप्त संदेश में शामिल अन्य नंबरों को आपकी फोन बुक में सुरक्षित करता है. जब प्राप्त नंबर जानकारी प्रदर्शित की जाती है, तो उपयोगकर्ता फोन बुक में संबंधित नंबर सूची में नंबर संग्रहीत कर सकता हैं.
   - ▶ **आरक्षित कॉल** आरक्षित कॉल सेट करें.
   - ▶ **उत्तर और कॉपी** आप उत्तर में प्राप्त संदेश के साथ अपना जवाब जोड़ सकते हैं.
   - ▶ **टेम्पलेट में जोड़ें** आप प्राप्त संदेश को टेम्प्लेट से जोड़ कर सुरक्षित कर सकते हैं.

2.2.2 MMS इनबॉक्स

1. सॉफ्ट बटन 1 **सूची**, 2 या दबाएँ.
2. 2 **इनबॉक्स** चुनें.
3. 2 MMS **इनबॉक्स** चुनें.
4. से इच्छित संदेश चुनने के बाद या सॉफ्ट बटन 1 **विकल्प** दबाएँ और देखें **चुनें**.
   - ▶ **देखें** आप चुना हुआ संदेश पढ़ सकते हैं.
   - ▶ **मिटाएँ** MMS इनबॉक्स से चयनित संदेश हटाएँ.

   या सॉफ्ट बटन 2 **कनेक्ट** या **जवाब** चुनें.
   - ▶ **कनेक्ट** आप चुना हुये संदेश को कनेक्ट कर सकते हैं.

▶ **जवाब** इस फंक्शन से आप इस संदेश का उत्तर दे सकते हैं.

5. संदेश देखने के बाद डाउनलोड करने के लिये सॉफ्ट बटन 1 **कनेक्ट** दबाएँ.

2.3 1234 सर्विसेस

एसएमएस के द्वारा उपलब्ध सर्विस जैसे न्यूज, जोक्स, भविष्यफल आदि भी रिलायंस के सभी उपभोक्ताओं को उपलब्ध है. 1234 सर्विसेस पर संदेश भेज कर आप कई विषयों पर आकर्षक जानकारी प्राप्त कर सकते हैं. इसके लिये उपभोक्ता को इस सेवा से संबधित सूची चुननी होगी.

1. सॉफ्ट बटन 1 **सूची**, 2abc या ⬆ दबाएँ.
2. 3def **1234 सर्विसेस** चुनें.
3. कर्सर को इच्छित आइटम पर ले जाएं जिसे आप देखना चाहते है, और सॉफ्ट बटन 1 **चुन** ओके दबाएँ. आप इन 11 विकल्पों में से चुन सकते है (1. समाचार 2. क्रिकेट 3. आज का जोक 4. आज का विचार 5. प्रतियोगिता 6. ब्यूटी टिप्स 7. स्वस्थ्य 8. भविष्यफल 9. बिल की जानकारी 0. अनबिल की जानकारी *. सहायता) आप इच्छित आइटम से संबधित बटन दबाकर भी विकल्प चुन सकते हैं.

उदाहरण

उदाहरण के लिये, आप फोन में निम्नलिखित प्रकार से "sports news" प्राप्त कर सकते हैं;

1. सूची + 2(संदेश) + 3(1234 सर्विसेस) + 1(समाचार) + 6(NEWS SPORTS) दबाएँ.
2. प्रदर्शन : भेज रहा.. को : 1234

2.4 आउटबॉक्स

SMS आउटबॉक्स में भेजे हुए 15 और नहीं भेजे हुए 15 संदेश तक संग्रहीत किये जा सकते हैं. MMS आउटबॉक्स में 50 भेजे गए और 50 नहीं भेजे गए संदेश सुरक्षित कर सकते हैं. उपयोगकर्ता इस सूची में भेजे हुए या नहीं भेजे हुए संदेशों की सूची और सामग्री देख सकते हैं. आउटबॉक्स में कोई संदेश सुरक्षित करने के लिए 'संदेश सेटिंग्स' में 'भेजे गए सुरक्षित' चयनित होना चाहिए.

2.4.1 SMS आउटबॉक्स

1. सॉफ्ट बटन 1 **सूची**, 2abc या ⬆ दबाएँ.
2. 4ghi **आउटबॉक्स** चुनें.
3. 1 SMS **आउटबॉक्स** चुनें.
4. 1 **भेजे हुए** या 2abc **नहीं भेजे हुए** चुनें.
5. ⬆⬇ से इच्छित संदेश चुनने के बाद, सॉफ्ट बटन 1 **विकल्प** दबाएँ और **देखें/मिटाएँ** चुनें. सॉफ्ट बटन 2 **फॉरवर्ड** या **पुनः भेजें** दबाएँ.

- ▶ **देखें** हाल में सुरक्षित किया गया संदेश दिखाता है. देखें सूची में दो उपसूचियाँ मिटाएँ और फॉरवर्ड होती हैं.
- ▶ **मिटाएँ** आउटबॉक्स में चयनित संदेश मिटाएँ.
- ▶ **फॉरवर्ड** आप प्राप्त संदेश संशोधित कर सकते हैं. फिर लिखें प्रक्रिया का अनुसरण करें.
- ▶ **पुनः भेजें** संदेश पुनः भेजने के लिए उपयोग करें.

2.4.2 MMS आउटबॉक्स

1. सॉफ्ट बटन 1 **सूची**, 2 या दबाएँ.
2. 4 **आउटबॉक्स** चुनें.
3. 2 MMS **आउटबॉक्स** चुनें.
4. 1 **भेजे हुए** या 2 **नहीं भेजे हुए** चुनें.
5. से इच्छित संदेश चुनने के बाद, सॉफ्ट बटन 1 **विकल्प** दबाएँ और **देखें/मिटाएँ** चुनें. सॉफ्ट बटन 2 **फॉरवर्ड** या **पुनः भेजें** दबाएँ.
   - ▶ **देखें** हाल में सुरक्षित किया गया संदेश दिखाता है. देखें सूची में दो उपसूचियाँ मिटाएँ और फॉरवर्ड होती हैं.
   - ▶ **फॉरवर्ड** आप प्राप्त संदेश संशोधित कर सकते हैं. फिर लिखें प्रक्रिया का अनुसरण करें (पृष्ठ 32 देखें.)
   - ▶ **लॉक/लॉक खोलें** संदेश स्वतः मिटाना निस्क्रिय करता है.
   - ▶ **मिटाएँ** आउटबॉक्स में चयनित संदेश मिटाएँ.

2.5 वॉइस मेल

इससे आप वॉइस मेल बॉक्स में रिकॉर्ड किया गया नया वॉइस संदेश देख सकते हैं. जब आप संग्रह सीमा से बाहर निकल जाते हैं, तो पुराने संदेश अधिलेखन कर दिए जाते हैं. आपके फोन में कोई नया वॉइस संदेश आने पर आपको सूचना दी जाएगी.

1. सॉफ्ट बटन 1 **सूची**, 2 या दबाएँ.
2. 5 **वॉइस मेल** चुनें.
   - ▶ जानकारी मिटाने के लिए सॉफ्ट बटन 2 **मिटाएँ** चुनें. सुनने के लिये सॉफ्ट बटन 1 **सुनें** दबाएँ.

यदि किसी कॉल का जवाब देते समय कोई नया संदेश आता है, तो प्रेषक का नंबर स्क्रीन पर दिखाया जाएगा.

2.6 UIM में संग्रह

प्राप्त संदेशों को अलग फोल्डर जो कि UIM कॉर्ड में है, में संग्रहीत कर सकते हैं. संग्रह की संख्या UIM कॉर्ड पर निर्भर करती है.

1. सॉफ्ट बटन 1 **सूची**, 2 या दबाएँ.
2. 6 UIM **में संग्रह** चुनें.
3. से इच्छित संदेश चुनने के बाद, सॉफ्ट बटन 1 **विकल्प** दबाएँ और **देखें/मिटाएँ** चुनें. सॉफ्ट बटन 2 **जवाब** दबाएँ.
   - ▶ **देखें** हाल में सुरक्षित किया गया संदेश दिखाता है. देखें सूची में दो उपसूचियाँ मिटाएँ और फॉरवर्ड होती हैं.
   - ▶ **मिटाएँ** आउटबॉक्स में चयनित संदेश मिटाएँ.
   - ▶ **जवाब** आप प्राप्त संदेश संशोधित कर सकते हैं. फिर लिखें प्रक्रिया का अनुसरण करें.
4. संदेश देखने के बाद सॉफ्ट बटन 1 **विकल्प** दबाएँ:

इनबॉक्स (मिटाएँ/फॉरवर्ड/उत्तर और कॉपी/इनबॉक्स में/पता सुरक्षित)
सॉफ्ट बटन 1 **जवाब** दबाएँ.

भेजा गया (फॉरवर्ड/ऑउटबॉक्स में)
सॉफ्ट बटन 1 **मिटाएँ** दबाएँ.

नहीं भेजा गया (मिटाएँ/फॉरवर्ड/आउटबॉक्स में)
सॉफ्ट बटन 1 **पुनः भेजें** दबाएँ.

नोट इनबॉक्स के लिए अलग विकल्प है, भेजा गया या नहीं भेजा गया.
इनबॉक्स : विकल्प है (देखें/मिटाएँ) और सॉफ्ट बटन 2 **जवाब** के साथ.
भेजा गया : विकल्प है (देखें/मिटाएँ) और सॉफ्ट बटन 2 **फॉरवर्ड** के साथ.
नहीं भेजा गया : विकल्प है (देखें/फॉरवर्ड/मिटाएँ) और सॉफ्ट बटन 2 **पुनः भेजें** के साथ.

2.7 ड्राफ्ट्स

शब्द संदेश ड्राफ्ट्स में सुरक्षित हो जाता है. ड्राफ्ट्स में 30 संदेश सुरक्षित किए जा सकते हैं और 20 MMS ड्राफ्ट्स में सुरक्षित किए जा सकते हैं. कोई संदेश लिखते समय कोई कॉल आने पर संदेश अपने आप सुरक्षित हो जाता हैं. कोई संदेश लिखने के दौरान दबाने पर संदेश अपने आप ड्राफ्ट्स में सुरक्षित हो जाता हैं.

2.7.1 SMS ड्राफ्ट्स

1. सॉफ्ट बटन 1 **सूची**, 2 या दबाएँ.
2. 7 **ड्राफ्ट्स** चुनें.
3. 1 SMS **ड्राफ्ट्स** चुनें.

4. से इच्छित संदेश चुनने के बाद, सॉफ्ट बटन 1 **देखें** या सॉफ्ट बटन 2 **मिटाएँ** दबाएँ.
   - ▶ **देखें** आप चयनित संदेश देख सकते हैं.
   - ▶ **मिटाएँ** चयनित संदेश मिटाता हैं.

2.7.2 MMS ड्राफ्ट्स

1. सॉफ्ट बटन 1 **सूची**, 2 या दबाएँ.
2. 7 **ड्राफ्ट्स** चुनें.
3. 2 MMS **ड्राफ्ट्स** चुनें.
4. से इच्छित संदेश चुनने के बाद, सॉफ्ट बटन 1 **विकल्प** या सॉफ्ट बटन 2 **मिटाएँ** दबाएँ.
   - ▶ **देखें** आप चयनित संदेश देख सकते हैं.
   - ▶ **मिटाएँ** चयनित संदेश मिटाता हैं.
   - ▶ **लॉक/लॉक खोलें** स्वतः संदेश मिटाने नहीं देता है.

2.8 टेम्प्लेट्स

2.8.1 SMS टेम्प्लेट्स

टेम्प्लेट्स में 10 पूर्वनिर्धारित वाक्यांश शामिल हैं. आप 20 और टेम्प्लेट्स जोड़ सकते हैं. कुल 30 टेम्प्लेट्स सुरक्षित किए जा सकते हैं.

1. सॉफ्ट बटन 1 **सूची**, 2 या दबाएँ.
2. 8 **टेम्प्लेट्स** चुनें.
3. 1 SMS **टेम्प्लेट्स** चुनें.
4. से इच्छित संदेश चुनने के बाद या सॉफ्ट बटन 1 **देखें** दबाएँ. फिर लिखें प्रक्रिया का अनुसरण करें (पृष्ठ 29 देखें).

   टेम्प्लेट्स सूची में नए टेम्प्लेट्स संदेश जोड़ने के लिए सॉफ्ट बटन 2 **जोड़ें** दबाएँ.

नोट उपभोक्ता द्वारा तैयार किये जाने वाले नये टेम्प्लेट के लिये विकल्प निम्न हैं:

देखें/मिटाएँ

टेम्प्लेट देख लेने के पश्चात, सॉफ्ट बटन 1 **विकल्प** दबाएँ:

भेजें/सुरक्षित/मिटाएँ

2.8.2 MMS टेम्प्लेट्स

टेम्प्लेट्स में 11 पूर्वनिर्धारित वाक्यांश शामिल हैं. आप 4 और टेम्प्लेट्स जोड़ सकते हैं. कुल 15 टेम्प्लेट्स सुरक्षित किए जा सकते हैं.

1. सॉफ्ट बटन 1 **सूची**, 2 या ⬆ दबाएँ.
2. 8 **टेम्प्लेट्स** चुनें.
3. 2 MMS **टेम्प्लेट्स** चुनें.
4. ⬆⬇ से इच्छित संदेश चुनने के बाद ● या सॉफ्ट बटन 1 **देखें** दबाएँ. फिर लिखें प्रक्रिया का अनुसरण करें (पृष्ठ 32 देखें).
   टेम्प्लेट्स सूची में नए टेम्प्लेट्स संदेश जोड़ने के लिए सॉफ्ट बटन 2 **जोड़ें** दबाएँ.

2.9 संदेश ग्रुप्स

संदेश ग्रुप्स में 5 SMS/ई–मेल/MMS समूह होते है एवं हर समूह में अधिकतम 10 सदस्य हो सकते हैं. समूह चुनने और इनपुट प्रदर्शन को मूव करने के बाद, चुने गए ग्रुप सदस्य के फोन नंबर पर एक संदेश भेजें.

1. सॉफ्ट बटन 1 **सूची**, 2 या ⬆ दबाएँ.
2. 9 **संदेश ग्रुप्स** चुनें.
3. 1 SMS **ग्रुप्स**, 2 **ई–मेल ग्रुप्स** या 3 MMS **ग्रुप्स** चुनें.
4. ⬆⬇ से इच्छित ग्रुप्स चुनने के बाद या सॉफ्ट बटन 1 **विकल्प** दबाएँ.

▶ **देखें**	चुने गये ग्रुप की सदस्य सूची देख सकते है. आप नये सदस्य भी जोड़ सकतें हैं.
▶ **नाम बदलें**	ग्रुप का नाम बदलें.
▶ **ग्रुप मिटाएँ**	चुने गये ग्रुप से सदस्य हटाएँ.
▶ **सभी मिटाएँ**	सभी 5 ग्रुपों से सदस्य हटाएँ.

नोट ई–मेल ग्रुप में संपर्क प्रविष्टि रजिस्टर करने के लिए, ई–मेल पते को संपर्क प्रविष्टि में सुरक्षित करना आवश्यक है.

नोट 'देखें' की ग्रुप सदस्य सूची में विकल्प चुनना.

▶ **भेजें**	संदेश इनपुट स्क्रीन में ले जाता हैं और चुनें गए ग्रुप सदस्य को संदेश भेजता हैं.
▶ **सभी को भेजें**	संदेश इनपुट स्क्रीन में ले जाता है और चुनें गए ग्रुप को संदेश भेजता है.
▶ **बदलें**	चुनें गए ग्रुप सदस्य को बदलें.
▶ **सदस्य निकालें**	चुनें गए ग्रुप सदस्य हटाएँ.
▶ **ग्रुप मिटाएँ**	चुनें गए ग्रुप के सदस्य निकालें.

2.0 संदेश मिटाएँ

आपको प्रत्येक संदेश बॉक्स में से संदेश मिटाने देता हैं.

1. सॉफ्ट बटन 1 **सूची**, 2 या दबाएँ.
2. 0 **संदेश मिटाएँ** चुनें.
3. से अपने पसन्द के आइटम चुनें और फिर दबाएँ.
   - ▶ **SMS संदेश मिटाएँ** इनबॉक्स/आउटबॉक्स/UIM में संग्रह/ड्राफ्ट्स/सभी संदेश
   - ▶ **MMS संदेश मिटाएँ** इनबॉक्स/आउटबॉक्स/ड्राफ्ट्स/सभी MMS

नोट इनबॉक्स विकल्प (पढ़ें /पूरा/भेजा दिया गया)

4. से **हाँ/नहीं** विकल्प चुनें, फिर दबाएँ.

2* संदेश सेटिंग्स

संदेश सेटिंग्स के लिए कॉन्फिगर किए जा सकते हैं.

2*.1 शब्द/ई–मेल संदेश सेटिंग्स

1. सॉफ्ट बटन 1 **सूची**, 2 या दबाएँ.
2. * **संदेश सेटिंग्स** चुनें.
3. 1 **शब्द/ई–मेल संदेश सेटिंग्स** चुनें.

2*.1.1 प्राथमिकता

संदेश भेजते समय, सामान्य या अति आवश्यक चुनें.

2*.1.2 भेज दिया गया

आप अपने संदेश के साथ पावती जोड़ सकते हैं.

2*.1.3 विलंबित डेलिवरी

इससे आप सेट की गई समय सीमा तक संदेश का प्रेषण विलंबित कर सकते हैं.

2*.1.4 वैधता समय

कुछ समय तक गंतव्य पते पर न भेजे जाने पर संक्षिप्त केन्द्र (SMC) पर संदेश प्रेषण की वैधता बताता हैं.

2*.1.5 भेजे गए सुरक्षित

यदि यह सुविधा चालू होती है, तो भेजते समय संदेश अपने आप आउटबॉक्स में सुरक्षित हो जाते हैं.

2*.1.6 संग्रह लॉक

संग्रह में जाने के लिए अपना लॉक कोड दर्ज करें.

2*.1.7 स्वतः स्क्रॉल

सूचियों के द्वारा 2 सेकेंड के अन्तराल में स्क्रॉल करने देता है.

2.*.2 मल्टीमीडिया संदेश सेटिंग्स

1. सॉफ्ट बटन 1 **सूची**, 2 या दबाएँ.
2. * **संदेश सेटिंग्स** चुनें.
3. 2 **मल्टीमीडिया संदेश सेटिंग्स** चुनें.

2.*.2.1 भेज दिया गया

आप अपने संदेश के साथ पावती जोड़ सकते हैं.

2.*.2.2 भेजा MMS सुरक्षित करें

यदि यह सुविधा चालू होती है, तो भेजते समय संदेश अपने आप आउटबॉक्स में सुरक्षित हो जाते हैं.

2.*.2.3 MMS स्वतः डाउनलोड

आपको MMS स्वतः प्राप्त करने देता है.

2.*.3 सामान्य सेटिंग्स

1. सॉफ्ट बटन 1 **सूची**, 2 या दबाएँ.
2. * **संदेश सेटिंग्स** चुनें.
3. 3 **सामान्य सेंटिंग्स** चुनें.

2.*.3.1 इनबॉक्स स्वतः मिटाएँ

यदि यह सुविधा चालू होती है, तो इनबॉक्स पूरा भर जाने पर पुराने संदेश स्वतः मिट जाते हैं.

2.*.3.2 हस्ताक्षर

यदि यह सुविधा चालू है, तो संदेश लिखना शुरु करते ही हस्ताक्षर स्वतः जुड़ जाते हैं.

2.*.4 भेजी गई संख्या

आप भेजे गये शब्द संदेश, ई–मेल और MMS की संख्या देख सकते हैं.

2.# सहायता

आप इस सूची के बारे में और जानकारी प्राप्त कर सकते हैं.

3. कॉल विवरण

इसमे आप नवीनमत 120 फोन कॉल्स देख सकते हैं. जब आप (कुल) 120 नंबरों की संग्रह सीमा पार कर जाते हैं, तो सबसे पुराना कॉल विवरण अधिलेखन कर दिया जाता है. ये कॉल्स चार प्रकारो में विभाजित हैं.

नोट

आप दो तरह से कॉल विवरण देख सकते हैं.

- निष्क्रिय मोड में बटन दबाकर, जिसमें छूटी, प्राप्त और डायल किये हुए सहित हाल के 120 तक कॉल दिखाए जाते हैं.
- कॉल विवरण सूची में, जहाँ छूटी, डायल किये हुए और प्राप्त के तहत 120 नंबर सूचीबद्ध होते हैं.
- कॉल मेमो में अधिकतम 20 नंबर सुरक्षित किए जा सकते हैं.

कॉल विवरण से कोई कॉल करना

1. कॉल विवरण सूची से छूटी, प्राप्त, डायल किये हुए या कॉल मेमो में चुनें आर सॉफ्ट बटन 1 **चुनें** दबाएँ.
2. इच्छित प्रविष्टि चुन कर संपर्क जोड़ने के लिए दबाकर कॉल करें.

3.1 छूटी

आप सभी छूटी हुई कॉल्स की सूची देख सकते हैं. इसमें अधिकतम 120 (छूटी + प्राप्त + डायल किये हुए) नंबर आ सकते हैं.

1. सॉफ्ट बटन 1 **सूची**, 3, 1 दबाएँ.
2. सॉफ्ट बटन 1 **विकल्प** दबाएँ. स्क्रीन पर देखें/नंबर संपादन/सुरक्षित/आरक्षित कॉल/मिटाएँ दिखाई देते हैं. संदेश भेजने के लिए सॉफ्ट बटन 2 **संदेश** दबाएँ.
3. आप दबाकर कॉल कर सकते हैं.

3.2 प्राप्त

आप सभी प्राप्त हुई कॉल्स की सूची देख सकते हैं. इसमें अधिकतम 120 (छूटी + प्राप्त + डायल किये हुए) नंबर आ सकते हैं.

1. सॉफ्ट बटन 1 **सूची**, 3, 2 दबाएँ.
2. सॉफ्ट बटन 1 **विकल्प** दबाएँ. स्क्रीन पर देखें/नंबर संपादन/सुरक्षित/आरक्षित कॉल/मिटाएँ दिखाई देते हैं. संदेश भेजने के लिए सॉफ्ट बटन 2 **संदेश** दबाएँ.
3. आप दबाकर कॉल कर सकते हैं.

3.3 डायल किये हुए

आप सभी डायल किए हुए कॉल्स की सूची देख सकते हैं. इसमें अधिकतम 120 (छूटी + प्राप्त + डायल किये हुए) नंबर आ सकते हैं.

1. सॉफ्ट बटन 1 **सूची**, 3, 3 दबाएँ.

2. सॉफ्ट बटन 1 **विकल्प** दबाएँ. स्क्रीन पर देखें/नंबर संपादन/सुरक्षित/आरक्षित कॉल/मिटाएँ दिखाई देते हैं. संदेश भेजने के लिए सॉफ्ट बटन 2 **संदेश** दबाएँ.

3. आप दबाकर कॉल कर सकते हैं.

3.4 कॉल मेमो में

बातचीत के दौरान आए फोन नंबर सुरक्षित करें और इससे आप वर्तमान नंबरों की सूची कॉल मेमो में देख सकते हैं. इसमें अधिकतम 20 नंबर आ सकते हैं.

1. सॉफ्ट बटन 1 **सूची**, 3, 4 दबाएँ.

2. सॉफ्ट बटन 1 **विकल्प** दबाएँ. स्क्रीन पर देखें/सुरक्षित/मिटाएँ/सभी मिटाएँ दिखाई देते हैं. संदेश भेजने के लिए सॉफ्ट बटन 2 **संदेश** दबाएँ.

3. आप दबाकर कॉल कर सकते हैं.

3.5 कॉल अवधि

1. सॉफ्ट बटन 1 **सूची**, 3, 5 दबाएँ.

3.5.1 अंतिम डायल कॉल

इसमे अंतिम डायल की गई कॉल के बारे में जानकारी संग्रहीत होगी और यह अंतिम डायल किया गया नंबर भी दिखाएगा.

3.5.2 सभी डायल कॉल

यह डायल किए गए सभी कॉल्स की संख्या और डायल कॉल्स की कुल अवधि दिखाता है.

3.5.3 सभी कॉल

सभी कॉल करने, डायल करने और प्राप्त करने के समय की गणना करता है.

3.5.4 कॉल अवधि पुनः सेट करें

भेजी गई संख्या पुनः सेट करने के लिए, से **हाँ** चुनें और सॉफ्ट बटन 1 **चुनें** दबाएँ.

3.6 विवरण मिटाएँ

1. सॉफ्ट बटन 1 **सूची**, 3, 6 दबाएँ.

2. से मिटायाँ जाने वाला आइटम चुनें.

3. सॉफ्ट बटन 1 **चुनें** दबाएँ.

4. से **हाँ** चुनें और सॉफ्ट बटन 1 **चुनें** दबाएँ.

3.7 सहायता

आप इस सूची के बारे में और जानकारी प्राप्त कर सकते हैं.

4. प्रदर्शन

आप विभिन्न ग्राफिक्स चुनकर अपने फोन का प्रदर्शन व्यक्तिगत बना सकते हैं.

4.1 भाषा

अपनी पसंद के अनुसार दो भाषाओं की सुविधा का उपयोग करें. English या **हिन्दी** में से चुनें.

1. सॉफ्ट बटन 1 **सूची**, 4, 1 दबाएँ.
2. से English/**हिन्दी** सेट करें और तब सॉफ्ट बटन 1 **चुनें** दबाएँ.

4.2 सर्विस एरिया

यह सूची उपयोगकर्ता का SDCA/कॉलिंग क्षेत्र प्रदर्शित करती हैं.

1. सॉफ्ट बटन 1 **सूची**, 4, 2 दबाएँ.

4.3 घड़ी और शॉर्टकद

इससे आप अपने मोबाइल फोन पर प्रदर्शित करने के लिए घड़ी चुन सकते हैं.

1. सॉफ्ट बटन 1 **सूची**, 4, 3 दबाएँ.
2. से अपने पसन्द के आइटम चुनें और सॉफ्ट बटन 1 **चुनें** दबाएँ.

4.4 समय और तिथि

फोन पर प्रदर्शित करने के लिए समय और तिथि का प्रकार चुन सकते हैं.

1. सॉफ्ट बटन 1 **सूची**, 4, 4 दबाएँ.
2. के द्वारा अपनी पसंद का आइटम चुनें और सॉफ्ट बटन 1 **चुनें**.

4.5 वॉलपेपर

अक्षरों की एक पंक्ति लिखें जिसे आप प्रदर्शित करना चाहते हैं. आप स्टैंडबाय मोड में LCD स्क्रीन पर प्रदर्शित स्क्रीन सेट कर सकते हैं.

1. सॉफ्ट बटन 1 **सूची**, 4, 5 दबाएँ.

4.5.1 थीम

आप स्टैंडबाय मोड में LCD स्क्रीन पर प्रदर्शित स्क्रीन सेट कर सकते हैं.

► विषय चुनें और सॉफ्ट बटन 1 **चुनें** दबाएँ.

4.5.2 थीम प्राप्त करें

मोबाइल वर्ल्ड द्वारा थीम डाउनलोड करने देता है. रिलायंस मोबाइल वर्ल्ड को चालू करके आप पसन्द की फाइल चुनें.

4.5.3. प्रोफाइल

मौजूदा प्रोफाइल वॉलपेपर के रुप में सुरक्षित कर ली जाती हैं.

▶ **दिखाएँ** या **छुपाएँ** चुनें और सॉफ्ट बटन 1 **चुनें** दबाएँ.

4.5.4 बैनर

अक्षरों की वह पंक्ति लिखें जिसे आप प्रदर्शित करना चाहते हैं. (13 अक्षरों तक).

▶ बैनर का नाम डालें और सॉफ्ट बटन 1 **सुरक्षित** दबाएँ.

4.6 सूची स्टाइल

इससे आप सूची स्टाइल चुन सकते हैं.

1. सॉफ्ट बटन 1 **सूची**, 4 ghi, 6 mno दबाएँ.
2. से **चिन्ह** या **सूची** चुनें और सॉफ्ट बटन 1 **चुनें** दबाएँ.

4.7 रंग संरचना

इससे आप रंग संरचना चुन सकते हैं.

1. सॉफ्ट बटन 1 **सूची**, 4 ghi, 7 pqrs दबाएँ.
2. से **बैगनी**, **नीला**, **ऑलिव**, **गुलाबी** चुनें और सॉफ्ट बटन 1 **चुनें** दबाएँ.

4.8 लयबध्द रोशनी

प्राप्त होने वाली कॉल के लिये लयबध्द रोशनी की सेटिंग्स चुनें.

1. सॉफ्ट बटन 1 **सूची**, 4 ghi, 8 tuv दबाएँ.
2. **ऑन** या **ऑफ** चुनें और सॉफ्ट बटन 1 **चुनें** दबाएँ.

4.9 स्क्रीन लाइट

LCD और बटन पैड की स्क्रीन लाइट की सेटिंग्स चुनें.

1. सॉफ्ट बटन 1 **सूची**, 4 ghi, 9 wxyz दबाएँ.
2. कोई विकल्प चुनें और सॉफ्ट बटन 1 **चुनें** दबाएँ.
   - ▶ **1 मिनट के लिए** स्क्रीन लाइट 1 मिनट तक ऑन रहती है, उसके बाद 20 सेकण्ड के लिए मंद हो जाती है और फिर स्क्रीन लाइट ऑन करने के लिए उपयोगकर्ता के द्वारा कोई बटन दबाने तक बंद रहती है.
   - ▶ **30 सेकण्ड के लिए** स्क्रीन लाइट 30 सेकण्ड तक ऑन रहती है, उसके बाद 20 सेकण्ड के लिए मंद हो जाती है और फिर स्क्रीन लाइट ऑन करने के लिए उपयोगकर्ता के द्वारा कोई बटन दबाने तक बंद रहती है.
   - ▶ **20 सेकण्ड के लिए** स्क्रीन लाइट 20 सेकण्ड तक ऑन रहती है, उसके बाद 20 सेकण्ड के लिए मंद हो जाती है और फिर स्क्रीन लाइट ऑन करने के लिए उपयोगकर्ता के द्वारा कोई बटन दबाने तक बंद रहती है.

- **10 सेकण्ड के लिए** स्क्रीन लाइट 10 सेकण्ड तक ऑन रहती है, उसके बाद 20 सेकण्ड के लिए मंद हो जाती है और फिर स्क्रीन लाइट ऑन करने के लिए उपयोगकर्ता के द्वारा कोई बटन दबाने तक बंद रहती है.
- **हमेशा ऑफ** बैकलॉइट ऑफ रहती है और 20 सेकण्ड के लिये धुंधली रहती.

4.0 सहायता

आप इस सूची के बारे में और जानकारी प्राप्त कर सकते हैं.

5. मोबाइल वर्ल्ड

सीधे ईस्तमाल के लिए, आइडियल मोड में बायाँ नेविगेशन बटन दबाएँ.

5.1 R–सूची

यह आपको आपके सेवा प्रदाता द्वारा दी गई वर्ल्ड डेटा सर्विस सेवा जैसे रिंग स्वर, क्रिकेट, डेटिंग, कॉन्टेस्ट, समाचार, भविष्यफल, शहर और टीवी गाइड, या और भी बहुत सारी अन्य सर्विसो से जोड़ता हैं. आप मोबाइल वर्ल्ड से 72 पॉलीफोनिक वाली, 99 रिंग स्वर डाउनलोड कर सकते हैं.

1. सॉफ्ट बटन 1 **सूची**, 5 jkl, 1 दबाएँ.

5.2 मूवी और संगीत

आप मोबाइल फोन पर टीवी प्रोग्राम देख सकते हैं. टीवी सेट से दूर होने पर भी आप भारत में 24 घंटे दिखाये जाने वाले समाचार चैनल के "ब्रेकिंग न्यूज" देख सकते हैं.

1. सॉफ्ट बटन 1 **सूची**, 5 jkl, 2 abc दबाएँ.

   या

   ◀ 2 सेकण्ड के लिए दबाएँ.

2. रिलायंस मोबाइल वर्ल्ड डेटा सर्विसेस सूची के अनुसरण द्वारा रिलायंस मोबाइल वर्ल्ड लोगो प्रदर्शित होगा.

3. से सूची स्क्रॉल करें और सॉफ्ट बटन 1 **चुनें** दबाकर कोई भी डेटा सेवा शुरु करें.

4. किसी भी समय डेटा सेवा से बाहर निकलने के लिये को कुछ सेकेण्ड तक दबाकर रखें.

5.3 प्ले और शॉप

यहाँ आपका फोन आपसे बातें करता है! अपने व्यतित्व और पसंद से मेल खाते रिंग स्वर को सुने और सुरक्षित करें. आप रिंग स्वर डाउनलोड, सुरक्षित कर सकते हैं और पुनः प्ले कर सकते हैं. यहाँ वॉयस रिंग स्वर भी है, जहाँ आप वॉयस रिंग स्वर हिन्दी, अंग्रेजी या और भी कई प्रादेशिक भाषा जैसे तेलगु, मलयालम, कन्नड़, गुजराती में सुन सकते हैं.

1. सॉफ्ट बटन 1 **सूची**, 5 jkl, 3 def दबाएँ.

   या

   2 सेकण्ड के लिए दबाएँ.

2. रिलायंस मोबाइल वर्ल्ड डेटा सर्विसेस सूची के अनुसरण द्वारा रिलायंस मोबाइल वर्ल्ड लोगो प्रदर्शित होगा.

3. से सूची स्क्रॉल करें और सॉफ्ट बटन 1 **चुनें** दबाकर कोई भी डेटा सेवा शुरु करें.

4. किसी भी समय डेटा सेवा से बाहर निकलने के लिये को कुछ सेकेण्ड तक दबाकर रखें.

नोट हो सकता है, सभी डेटा सेवाएँ प्रत्येक उपभोक्ता के लिये उपलब्ध ना हो. अधिक जानकारी के लिये कृपया अपने सेवा प्रदाता से संपर्क करें.

5.4 डायल 1234

डायल 1234 से आप रिलायंस मोबाइल वर्ल्ड को जोर से और साफ सुन सकते हैं और अपनी आवश्यकता के बारे में पूछ सकते हैं. यह सर्विस आपके चुनाव पर सहायता करती है. यह आपके निर्देशो को समझेगी (जैसेः प्ले ए सांग), आपके एक्सेंट को या आपके चारो ओर शोर होने पर भी यह आपको इच्छित जानकारी देती है.

1. सॉफ्ट बटन 1 **सूची**, 5 jkl, 4 ghi दबाएँ.
   - ► कृपया इस सर्विस पर लगने वाले चार्जेज के लिये अपने सर्विस प्रदाता से संपर्क करें
   - ► इस सर्विस के विषय समय समय पर सर्विस प्रदाता द्वारा बदले जा सकते हैं.

5.5 MMS लिखें

(पेज नं 32 का अनुसरण करें)

1. सॉफ्ट बटन 1 **सूची**, 5 jkl, 5 jkl दबाएँ.

5.6 MMS इनबॉक्स

(पेज नं 35 का अनुसरण करें)

1. सॉफ्ट बटन 1 **सूची**, 5 jkl, 6 mno दबाएँ.

5.7 R-सूची पुनः सेट

आप R मिडिया को पुनः सेट कर सकते हैं. जबकि सक्रिय, डाउनलोड किया गया VOD पुनः सेट हो.

1. सॉफ्ट बटन 1 **सूची**, 5 jkl, 7 pqrs दबाएँ.

5.8 UIM टूलकिट

UIM टूलकिट को संयोजित कर सकते हैं.

1. सॉफ्ट बटन 1 **सूची**, 5 jkl, 8 tuv दबाएँ.

5.9 गेम्स

1. सॉफ्ट बटन 1 **सूची**, 5 jkl, 9 wxyz दबाएँ.
2. से **क्रिकेट/मेरिन कमांडो/एटोमिक क्रुशॉर** में से चुनें और दबाएँ.

5.0 सहायता

आप इस सूची के बारे में और जानकारी प्राप्त कर सकते हैं.

6. प्रोफाइल्स

प्रोफाइल्स से आप अपने फोन की ध्वनि सेटिंग्स अपने वातावरण के अनुसार सेट कर सकते हैं. प्रोफाइल में आपके फोन के लिए रिंग प्रकार, रिंग स्वर, रिंग वॉल्यूम, इयरपीस वॉल्यूम, बटन वॉल्यूम और संदेश सचेतक होता है. आपके वर्तमान वातावरण के अनुसार प्रोफाइल चुनें: सिर्फ कंपन, Silent, General या Outdoor.

आप प्रत्येक प्रोफाइल की सेटिंग्स संशोधित कर सकते हैं, और (सिर्फ कंपन प्रोफाइल को छोड़कर) आप उनका नाम बदल सकते हैं. (सिर्फ कंपन, हेडसेट और कारकिट प्रोफाइल को छोड़कर).

प्रोफाइल्स चुनें

1. सॉफ्ट बटन 1 **सूची** 6 mno दबाएँ या तुरंत दबाएँ.
2. से चार प्रोफाइल्स सिर्फ कंपन, Silent, General और Outdoor में से कोई एक चुनें.
3. या सॉफ्ट बटन 1 **विकल्प** दबाएँ और फिर **सेट करें** चुनें.

नोट हेडसेट या कारकिट प्रोफाइल मोबाईल फोन में हेडसेट या कारकिट स्थापित होने पर अपने आप सेट हो जाती हैं.

नोट स्टैंडबॉय मोड में, सिर्फ कंपन चुनने के लिए [*shift] को लंबे समय तक दबाएँ. पिछली प्रोफाइल में वापस जाने के लिए [*shift] को एक बार फिर लंबे समय तक दबाएँ.

प्रोफाइल्स का नाम बदलें

1. सॉफ्ट बटन 1 **सूची**, [6 mno] दबाएँ.
2. से Silent, General या Outdoor चुनें.
3. फिर सॉफ्ट बटन 1 **विकल्प** दबाएँ और तब **नाम बदलें** चुनें.
4. प्रोफाइल्स के लिए कोई नाम लिखें (13 अक्षरों तक).
5. सॉफ्ट बटन 1 **सुरक्षित** या दबाएँ.

नोट आप सिर्फ कंपन, हेडसेट और कारकिट प्रोफाइल्स का नाम नहीं बदल सकते.

प्रोफाइल्स अनुकूलित करें

सिर्फ कंपन को छोड़कर आप कोई भी प्रोफाइल अनुकूलित कर सकते हैं.

1. सॉफ्ट बटन 1 **सूची**, [6 mno] दबाएँ.
2. जो प्रोफाइल आप अनुकूलित करना चाहते हैं, उस तक स्क्रॉल करें और सॉफ्ट बटन 2 **संपादन** दबाएँ.
3. दबाकर किसी एक सेटिंग को हॉइलाइट करें और चुनने के लिये दबाएँ.
   - **रिंग प्रकार** – रिंग, कंपन, कंपन और रिंग, कंपन के बाद रिंग, बढ़ती हुई, एक बीप, मौन, लाइट.
   - **रिंग स्वर** – पूर्वनियत, डाउनलोडेड, MP3, वॉयस रिकॉर्डर.
   - **रिंग स्वर प्राप्त करें** – रिलायंस मोबाइल वर्ल्ड से डाउनलोड की जा सकने वाले 100 रिंग स्वर.
   - **बटन स्वर** – (बीप, पियॉनो, जॉलोफोन)
   - **रिंग वॉल्यूम** – मौन, 1~7 स्तर
   - **इयरपीस वॉल्यूम** – 1~7 स्तर
   - **बटन वॉल्यूम** – मौन, 1~7 स्तर
   - **संदेश सचेतक** – सचेतक प्रकार, सचेतक स्वर, संदेश रिमाइंडर, सचेतक वॉल्यूम
   - **स्वतः उत्तर** – ऑफ, 5 सेकण्ड के बाद, 10 सेकण्ड के बाद.

नोट

- जब रिंग प्रकार कंपन, मौन और लाइट होता है तो रिंग वॉल्यूम समायोजित नहीं किया जा सकता. 'रिंग प्रकार बदलें' दिखाया जाता है. वर्तमान प्रकार को रिंग प्रकार में बदलने के बाद, रिंग वॉल्यूम समायोजित करें.
- जब हेडसेट और कारकिट प्रोफाइल्स में सॉफ्ट बटन 2 **संपादन** दबाया जाता है, तो स्वतः उत्तर अतिरिक्त रुप से दिखाया जाता है. से ऑफ, 5 सेकण्ड के बाद या 10 सेकण्ड के बाद चुनें.
- आप सिर्फ कंपन प्रोफाइल को अनुकूलित नहीं कर सकते.
- कोई नया संदेश प्राप्त होने पर आपको तीन प्रकार से सचेत किया जाता हैं.
  - स्क्रीन पर संदेश दिखाकर.
  - बीप की ध्वनि या कंपन करके.
  - स्क्रीन लाइट फ्लैश करके.
- कॉल के दौरान कोई नया संदेश प्राप्त होने पर आपको दो बीप से सचेत किया जाता हैं.

6.7 सहायता

आप इस सूची के बारे में और जानकारी प्राप्त कर सकते हैं.

7. निर्धारक/टूल्स

7.1 Bluetooth

RD6250 में जुड़ी हुयी डिवायस Bluetooth हेडसेट (HSP), हैंड्स फ्री (HFP), सीरीयल पोर्ट (SPP), डायल– अप नेटवर्किंग (DUN), object push (OPP) for Vcard, टबंसमदकंतए Vnote, JPG, MP3 और MP4, को सपोर्ट करती हैं. FTP प्रोफाइल फंक्शन केवल सर्वर के लिये है. आप RD6250 में 12 पेयरिंग बना कर सुरक्षित कर सकते हैं और एक समय में एक डिवायस को जोड़ सकते हैं. Bluetooth वायरलेस तकनीक की कम्युनिकेशन की क्षमता लगभग 30 फीट (10 मीटर) है.

नोट

उपभोक्ता मार्गदर्शिका में Bluetooth सहायक उपकरण की प्रत्येक जानकारी पढ़ें क्योकि निर्देशो में फर्क हो सकता है जब आप फोन को जोड़ने की कोशिश करते हैं.

जब Bluetooth द्वारा 1280x960 रेजोल्युशन के चित्र डाउनलोड करते हैं तो चित्र फोन पर प्रदर्शित नहीं होता है.

आपका फोन Bluetooth की विशेषताओं के साथ है, परन्तु इसकी Bluetooth वायरलेस तकनीक के सभी डिवायस के साथ काम करने की गारंटी नहीं है. फोन सभी Bluetooth OBEX प्रोफाइल को सपोर्ट नहीं करता है.

कारकिट इस्तेमाल के समय, Bluetooth काम नहीं करता. Bluetooth सक्रिय करने के लिये, फोन से कारकिट निकालना पड़ेगा.

7.1.1 Bluetooth सक्रिय

आप Bluetooth® पॉवर समर्थ/असमर्थ कर सकते हैं.

1. सॉफ्ट बटन 1 **सूची**, 7 pqrs स-ज, 1 @ ., 1 @ ., दबाएँ.
2. दबाकर **समर्थ/असमर्थ** चुनें और दबाएँ.

नोट पूर्वनियत में, आपके फोन का Bluetooth® फंक्शन ऑफ होता है.

7.1.2 डिवाइसों का जोड़ा

इस प्रक्रिया में हैंडसेट को खोजा जाता है, स्थापित करते हैं और टार्गेट डिवायस के साथ 1 से 1 जोड़ने के लिये रजिस्टर्ड करते हैं.

नयी Bluetooth® डिवायस जोड़ने के लिये

1. डिवायस को पेयरिंग मोड में सेट करने के लिये Bluetooth® सहायक उपकरण के निर्देशो को पढ़ें.
2. सॉफ्ट बटन 1 **सूची**, 7 pqrs स-ज, 1 @ ., 2 abc अ-ऊ दबाएँ. इच्छित डिवायस को जोड़ने के लिये सेट करें. सॉफ्ट बटन 2 **खोजें** दबाएँ.
3. अगर Bluetooth® पॉवर ऑफ पर सेट है, तो आपको पॉवर ऑन करने के लिये इंगित किया जाता है. 1 @ . **हाँ** चुनें और दबाएँ.
4. एक बार मिल जाने पर डिवायस खोजें सूची में दिखती है. डिवायस को हॉइलाईट करें और दबाएँ.
5. हैंडसेट पासकोड के लिये पुछता है. जुड़ जाने पर, जोड़ी गयी डिवायस भेजें.

   उचित पासकोड के लिये Bluetooth के सहायक उपकाण के निर्देशों को देखें (सामान्यतः "0000"—चार शुन्य). पासकोड डालें और दबाएँ.
6. सॉफ्ट बटन 1 **विकल्प** दबाएँ और **जोड़ें** चुनें. (Bluetooth हेडसेट या Bluetooth हैंडसफ्री जोड़ने के लिये उपलब्ध होते हैं.)
7. एक बार जुड़ जाने पर, आप डिवायस की सूची जोड़ी गयी डिवायस सूची में देख सकते हैं और डिवायस जुड़ने को इंगित करने वाला आइकान आपको प्रदर्शित किया जाता है, जब Bluetooth® डिवायस में जुड़ जाता है. आप सूची में नारंगी आयकॉन से भी कनेक्शन जाँच सकते हैं.

टिप Bluetooth® वॉयरलेस कनेक्शन आपके Bluetooth® डिवायस पर निर्भर करता है. आप एक समय में सिर्फ एक से ही जोड़ सकते हैं. RD6250 स्टिरियो हेडसेट जोड़ने पर भी सिर्फ मोनो हैडसेट पर काम करता है.

7.1.3 मेरी प्रत्यक्षता

आप दूसरे Bluetooth® डिवायस द्वारा अपने Bluetooth® डिवायस को खोजने के लिये सेट कर सकते हैं.

1. सॉफ्ट बटन 1 **सूची**, 7, 1, 3 दबाएँ.
2. दबाकर **एक बार/असमर्थ** चुनें और दबाएँ.

नोट समय की प्रत्यक्षता 3 मिनट में खत्म हो जाती है.

7.1.4 DUN सक्रिय

इंटरनेट से जोड़ने के लिये डायल–अप नेटवर्किंग आपके फोन को मॉडम की तरह इस्तेमाल करता है. जब आपका फोन पीसी या पीडीए से जुड़ा होता है, तो आप इंटरनेट जोड़ने के लिये फोन को डायल–अप कर सकते हैं. Bluetooth द्वारा सिंक इस्तेमाल करने के लिये DUN सक्रिय को ऑन पर सेट करें.

1. सॉफ्ट बटन 1 **सूची**, 7, 1, 4 दबाएँ.
2. दबाकर **समर्थ/असमर्थ** चुनें और दबाएँ.

7.1.5 मेरी डिवाइस जानकारी

आप अपने फोन के Bluetooth का नाम संपादित कर सकते हैं, जबकि नया डिवायस जोड़ें सूची हॉयलाईट होता है.

1. सॉफ्ट बटन 1 **सूची**, 7, 1, 5 दबाएँ.
2. सॉफ्ट बटन 1 **संपादन**, दबाएँ.
3. C/Torch दबाकर पहले से मौजूद नाम मिटाएँ.
4. न्युमेरिक बटनपैड दबाकर नया कस्टम नाम डालें.
5. सुरक्षित करने और बाहर जाने के लिये दबाएँ.

7.2 वॉयस टूल्स

वॉयस टूल्स से आप वॉयस रिकॉर्डर, उत्तर मशीन, वॉयस संदेश और वॉयस डायल इस्तेमाल कर सकते हैं. आंतरिक के लिये 300 और बाहरी के लिये 300. इसमे कुल 2 घंटे तक की रिकॉर्डिंग की जा सकती है.

नोट VOR (Voice Only Recording): अगर 1 सेकण्ड तक कोई वॉयस इनपुट नहीं है तो, सेविंग मेमोरी के लिये रिकार्डिंग सक्रिय नहीं होती.

7.2.1 वॉयस रिकॉर्डर

आप 2 घंटे तक की अपनी आवाज वॉयस मेमो में रिकॉर्ड कर सकते हैं. फंक्शन में बदलाव से रिकॉर्डिंग समय धट बढ़ भी सकती है. आंतरिक या बाहरी प्रत्येक फोल्डर में अधिकतम 300 फाईल सुरक्षित हो सकती है. वॉयस रिकॉर्ड सूची आंतरिक या बाहरी प्रत्येक फोल्डर में देख सकते हैं.

1. सॉफ्ट बटन 1 **सूची**, 7, 2, 1 दबाएँ.
2. से **नया रिकार्ड/वॉयस रिकॉर्ड/रिकार्डर सेटिंग्स** में से चुनें और दबाएँ.

7.2.1.1 नया रिकार्ड

1. रिकॉर्डिंग शुरु करने के लिये ● दबाएँ.
2. रिकॉर्डिंग बंद करने के लिये ● दबाएँ.

▶ सुरक्षित करने के लिये ● दबाएँ.

▶ सॉफ्ट बटन 2 **नाम बदलें**, दबाएँ.

▶ सॉफ्ट बटन 1 **विकल्प**, दबाकर **सुरक्षित/मिटाएँ** चुनें.

7.2.1.2 वॉयस रिकॉर्डर

1. **आंतरिक** या **बाहरी** चुनें.
2. ⬍ से इच्छित वॉयस मेमो चुनने के पश्चात,

▶ बजाने करने के लिये ● दबाएँ.

▶ सॉफ्ट बटन 2 **की तरह सेट**, दबाएँ.

▶ सॉफ्ट बटन 1 **विकल्प**, दबाकर **बजाएँ/फाईल/से भेजें/सभी फाईल** चुनें.

7.2.1.3 रिकार्डर सेटिंग्स

⬍ से किसी एक सेटिंग को हॉयलाईट करें और चुनने के लिये ● दबाएँ.

- मेमोरी उपयोग - (**आंतरिक/बाहरी**)
- स्वतः सुरक्षित - (**ऑन/ऑफ**)
- प्लेबैक स्पीड - (**धीमा/सामान्य/**X2/X3)
- VOR - (**ऑन/ऑफ**)
- सेटिंग्स पुनः सेट - (**हाँ/नहीं**)

7.2.2 उत्तर मशीन

आप अपनी रिकॉर्ड की गयी आवाज के साथ आने वाली कॉल प्राप्त कर सकते हैं और कॉल करने वाले का वॉयस संदेश रिकॉर्ड कर सकते हैं. उपभोक्ता द्वारा तैयार किया जा सकने वाला अभिवादन संदेश 30 सेकण्ड तक सुरक्षित किया जा सकता हैं.

1. सॉफ्ट बटन 1 **सूची**, 7 pqrs स-ञ, 2 abc अ-ऊ, 2 abc अ-ऊ दबाएँ.
2. ⬍ दबाकर **ऑन/ऑफ**, **अभिवादन संदेश**, **सेटिंग्स** चुनें और ● दबाएँ.

7.2.2.1 ऑन/ऑफ

ऑन या **ऑफ** चुनें.

7.2.2.2 अभिवादन सन्देश

▶ पूर्वनियत	जब की तरह सेट चुनते हैं तो, पूर्वनियत अभिवादन संदेश सक्रिय हो जाता है.
▶ उपभोक्ता द्वारा तैयार	उपभोक्ता द्वारा तैयार अभिवादन संदेश रिकॉर्ड करने के बाद, अभिवादन संदेश की तरह सेट करें.

7.2.2.3 सेटिंग्स

स्पीकर मोड और टाईम सेट करने के बाद सॉफ्ट बटन 1 **सुरक्षित** दबाएँ.

नोट अगर 20 वॉयस संदेश पूर्ण हैं या वॉयस मेमोरी भरी है, तो वॉयस मशीन ऑन पर सेट होने के बाद भी फंक्शन नहीं करेगी.
अगर कॉल प्राप्त नहीं की जाती है या दूसरी पार्टी फोन काट देती है तो, "वॉयस मेमोरी पूर्ण" प्रदर्शित होता है.

7.2.3 वॉयस संदेश

वॉयस उत्तर और वॉयस मेमो से प्राप्त संदेश वॉयस संदेश में सुरक्षित होते हैं. आंतरिक में 100 तक सुरक्षित हो सकते हैं. आंतरिक में 20 तक प्राप्त होने वाले वॉयस संदेश सुरक्षित हो सकते हैं. और रिकॉर्डिंग 9 मिनट तक हो सकती है. मेमोरी पूर्ण होने की स्थिति में, पहले से आंतरिक और बाहरी मेमोरी में से फाईल मिटाएँ.

नोट वॉयस मेमो के लिये रिकॉर्डिंग समय 2 घंटे और कॉल मेमो में के लिये 30 मिनट है.

1. सॉफ्ट बटन 1 **सूची**, 7 pqrs, 2 abc, 3 def दबाएँ.
2. सॉफ्ट बटन 1 **विकल्प** दबाएँ.
   - ▶ बजाएँ : रिकॉर्ड किया गया वॉयस संदेश बजाएँ.
   - ▶ सभी मिटाएँ : रिकॉर्ड किया गया वॉयस संदेश मिटाएँ.
   - ▶ फाईल जानकारी : फाईल का नाम, साइज, रिकॉर्ड का समय और तिथि प्रदर्शित करता है.

7.2.4 वॉयस डायल

वॉयस डायल से आप वॉयस द्वारा कॉल कर सकते हैं. आप वॉयस डायल निष्क्रिय स्क्रिन पर हॉट बटन दबा कर उपयोग कर सकते हैं. 20 तक नंबर निर्धारित किये जा सकते हैं.

1. सॉफ्ट बटन 1 **सूची**, 7 pqrs, 2 abc, 4 ghi दबाएँ.
2. फोनबुक में नाम डाल कर या हॉइलाईट करके नाम चुनें और ● दबाएँ.
3. फोन द्वारा पुछे जाने पर, इंतजार करें और बीप के बाद वह नाम बोले जिसे आप प्रोग्राम करना चाहते हैं.
4. फोन द्वारा पुछे जाने पर पुष्टि के लिये नाम पुनः बोलें.

7.2.5 सहायता

आप वॉयस उपकरण के बारे में जानकारी प्राप्त कर सकते हैं.

7.3 टाईम मैनेजर

टाईम मैनेजर फंक्शन

टाईम मैनेजर आपकी कार्य सूची को सुविधाजनक व आसान पहुँच में रखता है. अपने कार्यक्रम इसमे संग्रहीत कर दें और आपका फोन आपके नियत समय के बारे में आपको सर्तक कर देगा. आप वेक–अप सुविधा का भी लाभ ले सकते हैं. 160 तक सुरक्षित कर सकते हैं.

नोट यदि नियत समय पर SMS भेजा जा रहा हो या कॉल चल रही हो, तो फोन नहीं बजता. इन कार्यों के खत्म होने पर यह अनुस्मारक देगा.

नोट हैंडसेट का समय नेटवर्क टाईम सेटिंग्स से लिया जाता हैं.

कैलेंडर में नेविगेशन करने के लिए बटनों का उपयोग कैसे करें

◀ कर्सर बाई ओर ले जाता हैं.

▶ कर्सर दाई ओर ले जाता हैं.

▲ पिछले सप्ताह में जाता हैं.

▼ अगले सप्ताह में जाता हैं.

1 पिछले वर्ष में जाता हैं.

3 अगले वर्ष में जाता हैं.

5 आज की तिथि पर लाता हैं.

7 पिछले महीने में जाता हैं.

9 अगले महीने में जाता हैं.

7.3.1 टाईम मैनेजर

इसकी सहायता से आप अपना कार्यक्रम जोड़ सकते हैं, मिटा सकते है और देख सकते हैं. यदि आप समय और मेमो दर्ज करते हैं तो तय समय पर अलार्म बजता हैं.

1. सॉफ्ट बटन 1 **सूची**, 7, 3, 1 दबाएँ.
2. अपने बटन पैड से, तिथि चुनें, फिर सॉफ्ट बटन 1 **विकल्प** दबाएँ और देखें, तिथि को मिटाएँ, सभी मिटाएँ, तिथि पर जाएँ या आज पर जाएँ चुनें या सॉफ्ट बटन 2 **जोड़ें** दबाएँ.

7.3.2 टु डू

इसमें 40 सुरक्षित किए जा सकते हैं.

1. सॉफ्ट बटन 1 **सूची**, 7 pqrs त-न, 3 def ए-आ, 2 abc अ-ऊ दबाएँ.
2. कोई नया कार्य लिखने के लिए सॉफ्ट बटन 1 **जोड़ें** दबाएँ.

नोट सुरक्षित टु डू की स्थिति में देखें, मिटाएँ और सभी मिटाएँ फंक्शन सॉफ्ट बटन 1 विकल्प के साथ उपलब्ध होते हैं. जोड़ें सॉफ्ट बटन 2 के साथ उपलब्ध होते हैं.

7.3.3 D-Day गणक

इसमें 5 संख्याएँ सुरक्षित की जा सकती हैं.

1. सॉफ्ट बटन 1 **सूची**, 7 pqrs त-न, 3 def ए-आ, 3 def ए-आ दबाएँ.
2. नया कार्य लिखने के लिए, सॉफ्ट बटन 1 **जोड़ें** दबाएँ.
3. अक्षर लिखने के बाद लिखने के लिए पृष्ठ क्रं. (19—23 देखें) सॉफ्ट बटन 1 **सुरक्षित** दबाएँ.
4. D-Day सेट करने के लिए का उपयोग करें और तब सॉफ्ट बटन 1 **सुरक्षित** दबाएं.

नोट कोई D-Day सुरक्षित होने के स्थिति, में सॉफ्ट बटन 1 के साथ देखें, छिपाएँ, मिटाएँ और सभी मिटाएँ फंक्शन उपलब्ध होते हैं.

7.4 मेमो

इसमें 40 मेमो सुरक्षित किए जा सकते हैं.

1. सॉफ्ट बटन 1 **सूची**, 7 pqrs त-न, 4 ghi क-ङ दबाएँ.
2. कोई नया मेमो लिखने के लिए सॉफ्ट बटन 1 **जोड़ें** दबाएँ. (जब सुरक्षित किया मेमो फोन में है, तो जोड़ने के लिये साफ्ट बटन 2 इस्तेमाल करें.)
3. मेमो लिखने के बाद (मेमो लिखने हेतु पृष्ठ 19—23 देखें) सॉफ्ट बटन 1 **सुरक्षित** दबाएँ.

जब मेमो खाली न हो

निम्न विकल्प उपलब्ध होते हैं:
देखें, मिटाएँ, सभी मिटाएँ और Bluetooth द्वारा भेजें.
देखें : चयनित मेमो प्रदर्शित करने के लिए
देखें स्क्रीन में 2 विकल्प, संपादन एवं मिटाएँ, होते हैं.
संपादन से उपयोगकर्ता वर्तमान मेमो संशोधित कर सकता हैं.
मिटाएँ : इससे उपयोगकर्ता चुना हुआ मेमो मिटा सकता है.
सभी मिटाएँ : इससे उपयोगकर्ता संग्रहीत सभी मेमो मिटा सकता हैं.
Bluetooth **द्वारा भेजें** : मेमो को Bluetooth द्वारा दूसरे डिवायस को भेजें.
मेमो के सुरक्षित होने पर वर्तमान तिथि भी सुरक्षित हो जाती हैं. कोई मेमो सुरक्षित नहीं होने की स्थिति में, सॉफ्ट बटन 1 पर **जोड़ें** प्रदर्शित होता है.

7.5 आरक्षित कॉल

आप इस विकल्प से कॉल करने के समय एवं तिथि के साथ आरक्षित कॉल संग्रहीत कर सकते हैं. सेट किये गये समय और दिन पर फोन आपको कॉल करने के लिये सचेत कर देगा, इसमें 5 सुरक्षित किए जा सकते हैं.

1. सॉफ्ट बटन 1 **सूची**, 7 pqrs त-ञ, 5 jkl क-ज्ञ दबाएँ.
2. आरक्षित कॉल चुनें 1~5.
3. फोन नंबर लिखें, और दबाएँ (कोई फोन नंबर लिखना जरुरी हैं).
4. से आप मोड बदल सकते हैं.
   (ऑफ/एक बार/प्रतिदिन/सोम–शुक्र/सोम–शनि/सप्ताह अंत/प्रत्येक रवि/प्रत्येक सोम/प्रत्येक मंगल/प्रत्येक बुध/प्रत्येक गुरु/प्रत्येक शुक्र/प्रत्येक शनि)
5. इसके बाद दबा कर, नंबर बटन से तिथि डालें.
6. इसके बाद दबा कर, नंबर बटन से समय डालें. (से am/pm चुनें).
7. इसके बाद दबा कर, से रिंग स्वर चुनें.
8. इसके बाद दबा कर, 32 अक्षरों तक का मेमो डालें और दबाएँ.

7.6 अलार्म

किसी कार्य का अलार्म समय बदलने के लिए.

1. सॉफ्ट बटन 1 **सूची**, 7 pqrs त-ञ, 6 mno ट-ण दबाएँ.
2. अलार्म 1, अलार्म 2 या अलार्म 3 चुनें.
3. आप से अलार्म मोड बदल सकते हैं.
   (ऑफ/एक बार/प्रतिदिन/सोम–शुक्र/सोम–शनि/सप्ताह अंत/प्रत्येक रवि/प्रत्येक सोम/प्रत्येक मंगल/प्रत्येक बुध/प्रत्येक गुरु/प्रत्येक शुक्र/प्रत्येक शनि)
4. अलार्म समय सेट करने के लिए का उपयोग करें, रिंगर या FM रेडियो चैनल चुनें और सामग्री लिखें, और फिर सॉफ्ट बटन 1 **सुरक्षित** दबाएँ.
   - से am/pm चुना जा सकता हैं.
   - प्रोफाइल्स में सेटिंग्स के अनुसार रिंगर वॉल्यूम नियंत्रित किया जाता हैं. FM रेडियो मुख्य वॉल्यूम सूची में सेटिंग्स के अनुसार FM वॉल्यूम नियंत्रित किया जाता हैं.

नोट मोबाइल बंद करने पर अलार्म निष्क्रिय हो जाता है. निर्धारित सीमा निकल जाने पर अलार्म स्वतः समाप्त हो जाता हैं.

आप **त्वरीत अलार्म** से (10 मिनट बाद/30 मिनट बाद/1 घंटे बाद/3 घंटे बाद/ऑफ) चुन सकते हैं.
जब त्वरीत अलार्म सेट किया जाता हैं, तो अलार्म बजने का समय प्रदर्शित होता हैं.

स्नूज कैसे सेट करें

अलार्म में सेट किए जाने पर स्नूज पूर्वनियत स्थिती में होता हैं. अलार्म बजने पर जब कोई बटन नहीं दबाया जाता हैं तो एक मिनट बाद स्नूज फंक्शन अपने आप सेट हो जाता है, और सेट किए गए समय के दस मिनट बाद अलार्म फिर से बज उठता है. अगर अलार्म का प्रकार FM रेडियो है, तो स्नूज तब तक सक्रिय नहीं होता है जब तक कि FM रेडियो बंद नहीं किया जाता या स्नूज बटन नहीं दबाया जाता.

7.7 स्टॉप वॉच

स्टॉप वॉच उपलब्ध है.

1. सॉफ्ट बटन 1 **सूची**, 7 pqrs, 7 pqrs दबाएँ.

7.8 कैलक्युलेटर

यह सरल गणितीय गणनाएँ करता हैं.
(इससे दशमलव के दूसरे स्थान तक परिणाम प्राप्त किया जा सकता है.)

1. सॉफ्ट बटन 1 **सूची**, 7 pqrs, 8 tuv दबाएँ.
2. 2 abc और 5 jkl को क्रम से दबाएँ.
3. से (गुण) चुनें.
4. 1 और 0 next को क्रम से दबाएँ.
5. सॉफ्ट बटन 1 **उत्तर** चुनें.
   आप गणना का परिणाम 250 देखेंगे.

नोट एक बार में 50 अंकों तक की गणना की जा सकती है. (उदा., 73+10–30 आठ अंक होंगे).

7.9 इकाई रुपांतरक

युनिट कन्वरटर से कई प्रकार की युनिट रुपांतरित की जा सकती है. जैसे करेंसी, लम्बाई, सतह, ढ़ेर, वाल्यूम, तापमान, गति.

1. सॉफ्ट बटन 1 **सूची**, 7 pqrs, 9 wxyz दबाएँ.

7.9.1 करेंसी

करेन्सी रुपांतर कर सकने से पहले, आपको कोई आधार करेन्सी चुननी होती है. (आमतौर पर आपकी घरेलु करेन्सी) और विनियम दर देनी होती है.

1. अपनी घरेलु करेन्सी सेट करें, फिर दबा कर विनिमय दर सेट करें.
2. फिर सॉफ्ट बटन 1 **दर** दबाएँ और करेन्सी पर सेट करने के लिए सॉफ्ट बटन 1 **सुरक्षित** दबाएँ.

नोट आधार करेन्सी अन्य करेन्सी के लिए विनिमय की दर निर्धारित करती है. आवश्यक विनियम दर डालने के बाद, आप करेन्सी रुपांतर कर सकते है.

लम्बाई, सतह, ढेर, वॉल्यूम, तापमान और गति

1. आप आधार इकाई डालें और यह आपको इच्छित रुपांतरक इकाई देगा.
2. ◀ या ▶ दबा कर आप नापने की विभिन्न इकाई चुन सकते हैं.
3. ▲ या ▼ दबा कर आप आधार और रुपांतरक इकाई चुन सकते हैं.

7.0 विश्व घड़ी

यदि आपको किसी दूसरे देश में फोन करना है और आपको समय का अंतर नहीं पता है, तो यह घड़ी उपयोगी साबित होगी.

1. सॉफ्ट बटन 1 **सूची**, 7 pqrs, 0 next दबाएँ.
2. ◀▶ से इच्छित शहर चुनें.

   शीघ्रता से चुनने के लिए, नक्शे पर 7 शहर देखने के लिए ▲▼ का उपयोग किया जा सकता है.
3. ● दबाने पर, सेट किया गया शहर विश्व घड़ी में डिफॉल्ट शहर हो जाता है.

नोट सॉफ्ट बटन 2 DST से डे–लाइट सेविंग टाइम सेट करें.
आप सॉफ्ट बटन 1 **सूची** से भी शहर चुन सकते हैं.

7.* सहायता

आप इस सूची के बारे में और जानकारी प्राप्त कर सकते हैं.

8. मल्टीमीडिया

8.1 कैमरा

आपका मल्टीमीडिया फोन में आसानी से उपयोग किये जा सकने वाला बिल्ट – इन कैमरा है. इससे आप कभी भी चित्र या वीडियो ले सकते हैं, देख सकते हैं. या अपने परिवार और दोस्तो के साथ अदान–प्रदान कर सकते हैं. कैमरे के साथ फ्लैश का विकल्प भी है.

नोट **आंतरिक मेमोरी** : चित्र और वीडियो के लिये 1000 उपलब्ध.
बाहरी मेमोरी : चित्र और वीडियो के लिये 4000 उपलब्ध. [फाईल और फोल्डर की संरचना के लिये बाहरी मेमोरी में सुरक्षित करें, DCF(Design rule for Camera File system) प्रयोग होता है.]

कैमरा सूची का आसान उपयोग

कैमरा सूची के आसान संचालन के लिये स्टैंडबॉय मोड में, कैमरा बटन (📷) दबाएँ.

8.1.1 फोटो लें

कैमरे से फोटो लेना.

1. सॉफ्ट बटन 1 **सूची**, 8 tuv, 1, 1 दबाएँ.

नोट हॉट बटन के द्वारा फोटो लेने के लिये स्टैंडबॉय मोड में कैमरा बटन (📷) लगभग 4 सेकेण्ड्स तक दबाएँ रखें.

2. ◀▶ से चमक, ▲▼ से जूम और सॉफ्ट बटन 1

विकल्प दबा कर आप जरुरत के अनुसार सेटिंग्स में परिवर्तन कर सकते हैं.

▶ समायोजित करने के लिये विकल्प चुनें

1. **ज़ूम** : 4X ज़ूम फंक्शन 640x480 के अलावा सभी के साथ उपलब्ध है.
2. **प्रकाशयुक्त** : 2.0 EV ~ +2.0 EV
3. **फ्लैश** : ऑन/ऑफ
4. **मल्टी** : 3/6/9 शॉट्स उपलब्ध हैं. 640x480 रिज़ोल्यूशन के साथ विकल्प उपलब्ध नहीं हैं.
5. W/B : स्वतः/बादल/दिन की रोशनी/टंगस्टन/फ्लोरोसेंट
6. **क्वालिटी** : तेज/मध्यम/कमजोर
7. **समयक** : नहीं/3 सेकेंड/5 सेकेंड/10 सेकेंड/15 सेकेंड
8. **फिल्टर** : नहीं/B&W/सेफिया
9. **रेज़ोल्यूशन** : 640x480/320x240/160x120/128x128
0. **मेमोरी** : बाहरी/आंतरिक

नोट ज़ूम फंक्शन को रिज़ोल्यूशन के 10 स्टेप तक कंट्रोल कर सकते हैं. (320x240 / 160x120 / 128x128)

नोट फ्लैश ऑन होने पर, 30cm तक फोटो ली जा सकती है.

3. फोटो लेने के लिये [📷], या [●] दबाएँ.
4. फोटो को गैलरी में सुरक्षित करने के लिये [📷], या [●] दबाएँ.
   - सॉफ्ट बटन 2 **नाम बदलें**.
   - सॉफ्ट बटन 1 **विकल्प** दबा कर **सुरक्षित** करें या **भेजें** चुनें.

नोट 160x120 रिज़ोल्यूशन के साथ फोटो लेने पर ऊपर और नीचे सफेद पंक्ति दिखती है.

8.1.2 फन चित्र खिचें

1. सॉफ्ट बटन 1 **सूची**, [8 tuv पर्न], [1], [2 abc अ-ऊ].
2. [◀●▶] से चमक, [⇕] से ज़ूम और सॉफ्ट बटन 1 **विकल्प** दबा कर आप जरुरत के अनुसार सेटिंग्स में परिवर्तन कर सकते हैं.

   ▶ समायोजित करने के लिये विकल्प चुनें

फ्रेम : 01~40

W/B : स्वतः/बादल/दिन की रोशनी/टंगस्टन/फ्लोरोसेंट

क्वालिटी : तेज/मध्यम/कमजोर

समयक : नहीं/3 सेकेंड/5 सेकेंड/10 सेकेंड/15 सेकेंड
फ्रेम 31~40 तक में समयक सुविधा नहीं है.

फिल्टर : नहीं/B&W/सेफिया

मेमोरी : बाहरी/आंतरिक

प्रकाशयुक्त : 2.0 EV ~ +2.0 EV

फ्लैश : ऑन/ऑफ

3. फोटो लेने के लिये [📷], या [●] दबाएँ.
4. फोटो को गैलरी में सुरक्षित करने के लिये [📷], या [●] दबाएँ.
   - सॉफ्ट बटन 2 **नाम बदलें**.
   - सॉफ्ट बटन 1 **विकल्प** दबा कर **सुरक्षित** करें या **भेजें** चुनें.

8.1.3 मूवी खींचें

आप आवाज के साथ 2 घंटे की 128x96 साइज़ के वीडिओ रेकार्ड कर सकते हैं.

1. सॉफ्ट बटन 1 **सूची**, 8 tuv प-ज्ञ, 1, 3 def प-ज्ञ दबाएँ.

नोट सिर्फ 3 सेकण्ड से ज्यादा की मूवी ही सुरक्षित हो सकती है.

8.1.4 मेरी फोटो गैलरी

फोन में सुरक्षित हुये फोटो देखें.

1. सॉफ्ट बटन 1 **सूची**, 8 tuv प-ज्ञ, 1, 4 ghi प-ज्ञ दबाएँ.

8.1.5 मेरी मूवी गैलरी

फोन में सुरक्षित हुये मूवी देखें.

1. सॉफ्ट बटन 1 **सूची**, 8 tuv प-ज्ञ, 1, 5 jkl प-ज्ञ दबाएँ.

8.1.6 स्लाइड शो

इससे आप चुनें गये चित्रों को क्रमवार देख सकते हैं.

1. सॉफ्ट बटन 1 **सूची**, 8 tuv प-ज्ञ, 1, 6 mno प-ज्ञ दबाएँ.
2. सॉफ्ट बटन 2 **जोड़ें** दबाएँ और सॉफ्ट बटन 1 **चुनें** दबा कर इच्छित चित्रों को स्लाइड शो के लिये सेट करें, सॉफ्ट बटन 2 **पुर्ण** और सुरक्षित करने के लिये सॉफ्ट बटन 1 **सुरक्षित** दबाएँ.

देखें	चुनें गये स्लाइड शो को देखें.
मिटाएँ	चुनें गये स्लाइड शो को मिटाएँ.
नाम बदलें	चुनें गये स्लाइड शो का नाम बदलें.
प्रभाव	आप स्लाइड शो के कई प्रभावों को समायोजित कर सकते हैं.
वॉलपेपर	चुनें गये स्लाइड शो को वॉलपेपर के रुप में सेट करें
सभी मिटाएँ	सभी स्लाइड शो मिटाएँ.

8.1.7 चित्र संपादन

आप खिचे गये चित्र को कई प्रकार से संपादित कर सकते हैं.

1. सॉफ्ट बटन 1 **सूची**, 8 tuv प-ज्ञ, 1, 7 pqrs प-ज्ञ दबाएँ.
2. ◀◉▶ दबाकर चित्र चुनें.
   - ▶ सॉफ्ट बटन 1 **ग्रिड** दबाएँ.
   - ▶ सॉफ्ट बटन 1 **विकल्प** दबाकर : **सुधारें/लिखने का तरीका/छाँटा हुआ**

8.1.8 सेटिंग्स

1. सॉफ्ट बटन 1 **सूची**, 8 tuv प-ज्ञ, 1, 8 tuv प-ज्ञ दबाएँ.

8.1.8.1 स्वतः सुरक्षित

1. सॉफ्ट बटन 1 **सूची**, 8 tuv प-ज्ञ, 1, 8 tuv प-ज्ञ, 1 दबाएँ.
2. ⬍ से **ऑन** या **ऑफ** चुनें और ◉ दबाएँ.

8.1.8.2 शटर ध्वनि

4 ध्वनियों में से चुनें.

1. सॉफ्ट बटन 1 **सूची**, 8 tuv प-ज, 1 @ ., 8 tuv प-ज, 2 abc अ-ऊ दबाएँ.
2. ◆ से **ध्वनि 1–4** या **ऑफ** चुनें और ● दबाएँ.

8.1.8.3 गैलरी मिटाएँ

1. सॉफ्ट बटन 1 **सूची**, 8 tuv प-ज, 1 @ ., 8 tuv प-ज, 3 def ए-ओ दबाएँ.
2. 4 अंको का लॉक कोड डालें.
3. ◆ से इच्छित सूची चुनें और ● दबाएँ.
   ▶ सॉफ्ट बटन 1 **विकल्प** दबाएँ और चुनें:
   चुनें (चुनाव रद्द)/मिटाएँ/सभी चुनें/सभी चुनाव हटाएँ

8.1.8.4 सभी गैलरी लॉक

1. सॉफ्ट बटन 1 **सूची**, 8 tuv प-ज, 1 @ ., 8 tuv प-ज, 4 ghi क-ङ दबाएँ.
2. 4 अंको का लॉक कोड डालें.
3. ◆ से **हाँ** या **नहीं** चुनें और ● दबाएँ.

8.1.8.5 मेमोरी उपयोग

मेमोरी का प्रकार चुनें (आंतरिक या बाहरी).

1. सॉफ्ट बटन 1 **सूची**, 8 tuv प-ज, 1 @ ., 8 tuv प-ज, 5 jkl ट-ज दबाएँ.
2. ◆ से **आंतरिक** या **बाहरी** चुनें और ● दबाएँ.

8.1.8.6 सेटिंग्स पुनः सेट

कैमरे की सभी सेटिंग्स को फैक्ट्री की पूर्वनियत सेटिंग पर सेट करें.

1. सॉफ्ट बटन 1 **सूची**, 8 tuv प-ज, 1 @ ., 8 tuv प-ज, 6 mno ट-ज दबाएँ.
2. ◆ से **हाँ** या **नहीं** चुनें और ● दबाएँ.

8.1.9 मेमोरी की जानकारी

आप आंतरिक और बाहरी प्रत्येक मेमोरी में खाली और ईस्तेमाल हो चुकी जगह देख सकते हैं.

1. सॉफ्ट बटन 1 **सूची**, 8 tuv प-ज, 1 @ ., 9 wxyz ह-ह दबाएँ.
2. ◆ से **आंतरिक** या **बाहरी** चुनें और ● दबाएँ.

8.1.0 सहायता

आप इस सूची के बारे में और जानकारी प्राप्त कर सकते हैं.

8.2 FM रेडियो

8.2.1 रेडियो सुनें

1. हेडसेट जैक में हेडसेट जोड़ें.
2. सॉफ्ट बटन 1 **सूची**, 8 tuv प-ज्ञ, 2 abc अ-ऊ, 1 ☺, दबाएँ या स्टैंडबाय मोड में FM बटन को देर तक दबाएँ.
3. सॉफ्ट बटन 1 दबाकर निम्न विकल्पों में से चुनें:

- ▶ **स्विच ऑफ** FM रेडियो बन्द करें.
- ▶ **चैनल सेट करें** चैनल को मैनुअली व्यवस्थित एवं सुरक्षित करें.
- ▶ **स्वतः चैनल खोजें** चैनल स्वतः स्कैन एवं सुरक्षित करें.
- ▶ **सभी पुनः सेट** सभी चैनल को पूर्वनियत सेटिंग पर सेट करें.
- ▶ **सुनने के लिये चुनें** FM रेडियो हेडसेट या स्पीकर द्वारा सुने.

नोट 12 चैनल तक सुरक्षित किये जा सकते हैं. हेडसेट इस्तेमाल करते समय, अगले चैनल पर जाने के लिये हैडसेट का बटन दबाएँ.

8.2.2 सहायता

आप इस सूची के बारे में और जानकारी प्राप्त कर सकते हैं.

8.3 MP3

MP3 का आसान संचालन

MP3 प्लेयर के आसान संचालन के लिये स्टैंडबॉय मोड में MP3 बटन ( ) को दबाएँ.

8.3.1 संगीत बॉक्स

सूची देखें और MP3 संगीत सुने.

1. सॉफ्ट बटन 1 **सूची**, 8 tuv प-ज्ञ, 3 def द-ओ, 1 ☺, दबाएँ.
2. ⬍ से **आंतरिक** या **बाहरी** चुनें और ● दबाएँ.

बटनों के फंक्शन इस प्रकार हैं:

- ▭ सॉफ्ट बटन 1: कोई MP3 संगीत बजने के दौरान दूसरी फाईल चुनें.
- ▭ सॉफ्ट बटन 2: कोई MP3 संगीत बजने के दौरान पुनः बजाये मोड बदलें.
- ⬆ ऊपरी नेविगेशन बटन : आप दोहराने के मोड को सेट कर सकते हैं.
- ▶ दायाँ नेविगेशन बटन : अगले गाने पर जाने के लिये एक बार दबाएँ. तेज फॉरवर्ड के लिये कुछ देर तक दबाएँ.
- ◀ बायाँ नेविगेशन बटन : पिछले गाने पर जाने के लिये एक बार दबाएँ. तेज रिवाइंड के लिये कुछ देर तक दबाएँ.
- ● ओके बटन : रुकें/प्ले
- ⬇ नीचे नेविगेशन बटन : MP3 प्लेयर बंद कर बाहर आने के लिये.

नोट

• MP3 **प्लेयर में आंतरिक/बाहरी मेमोरी की सुविधा है**

- आप बाहरी microSD कॉर्ड से भी गाने प्ले कर सकते हैं.
- संगीत हेडसेट या आंतरिक स्पीकर से सुना जा सकता है.
- साइड बटन से वॉल्यूम समायोजित की जा सकती है.

नोट म्युजिक बॉक्स में MP3 गाने सहेजे जाते हैं. आप microSD कॉर्ड में 300 से ज्यादा गाने संग्रहित कर सकते हैं, पर एक बार में अधिकतम 300 गाने ही प्ले करने के लिये चुनें जा सकते हैं. चित्र और वीडियो फोटो गैलरी और मूवी गैलरी में संग्रहित होते हैं.

8.3.2 मेरी सूची

अपनी पसंद की 1 म्युजिक सूची बनाये. आप इसमे 100 म्युजिक सम्मलित कर सकते हैं.

1. सॉफ्ट बटन 1 **सूची**, 8 tuv प-ज, 3 def प-औ, 2 abc अ-ऊ दबाएँ.

8.3.3 सेटिंग्स

1. सॉफ्ट बटन 1 सूची, 8 tuv प-ज, 3 def प-औ, 3 def प-औ दबाएँ.
2. ⬍ से कोई एक सेटिंग हॉयलाईट करें और चुनने के लिये ● दबाएँ.
   - स्किन – **(तरंग/बॉल)**
   - टाइमर – **(ऑफ/30 मिनट/1 घंटे/ उपयोगकर्ता–सेट)**
   - बटन रक्षक – **(समर्थ/असमर्थ)**

8.3.4 सहायता

आप इस सूची के बारे में और जानकारी प्राप्त कर सकते हैं.

8.4 मेरी सामग्री

1. सॉफ्ट बटन 1 **सूची**, 8 tuv प-ज, 4 ghi ह-ङ दबाएँ.
2. ⬍ से **आंतरिक/बाहरी** चुनें और ● दबाएँ.

चित्र

आप पूर्वनियत, डाउनलोडेड, और कैमरा फोटो चित्र देख सकते हैं.

▶ पूर्वनियत, डाउनलोड, या मेरी फोटो गैलरी में से चुन कर देखें.

मूवी

आप खिची गयी या डाउनलोड की गयी मूवी देख सकते हैं.

▶ डाउनलोड, या मेरी फोटो गैलरी में से चुन कर देखें. MMS या Bluetooth द्वारा डाउनलोड की गयी फाईल डाउनलोड फोल्डर में सुरक्षित होती है.

ध्वनि

आप ध्वनि की सूची देख सकते हैं. (पूर्वनियत, डाउनलोडेड, MP3, वॉयस रिकॉर्डर),

मेमोरी की जानकारी

आप आंतरिक और बाहरी प्रत्येक में खाला जगह और इस्तेमाल हो चुकी जगह जाँच सकते हैं.

सहायता

आप इस सूची के बारे में और जानकारी प्राप्त कर सकते हैं.

9. सेटिंग्स

9.1 मेरी सूची

इससे आप मेरी सूची को अनुकूलित कर अपनी पसंद की सूची चुन सकते हैं. मेरी सूची में अधिकतम 10 विषय संग्रहीत किए जा सकते हैं.

1. सॉफ्ट बटन 1 **सूची**, 9, 1 दबाएँ.
2. से अपनी पसंद की सूची चुनें और सॉफ्ट बटन 1 **चुनें** दबाएँ.
3. मेरी सूची में जोड़ने के लिए से सूची चुनें और सॉफ्ट बटन 1 **जोडें** दबाएँ.

नोट स्टैंडबॉय स्क्रीन में C/Torch से पसंद का विषय चुनें, बाद में मेरी सूची से इच्छित विषय चुनने के लिए सॉफ्ट बटन 1 **जाएँ** या दबाएँ.

नोट स्टैंडबाय स्क्रीन में C/Torch से उपयोग से मिटाने के लिए विषय चुनें, तब सॉफ्ट बटन 2 **मिटाएँ** दबाएँ, से हाँ चुनें, फिर मेरी सूची से मिटाने के लिए सॉफ्ट बटन 1 **चुनें** या दबाएँ.

9.2 कॉल

1. सॉफ्ट बटन 1 **सूची**, 9, 2 दबाएँ.

9.2.1 कॉल फॉरवर्ड

कॉल फॉरवर्ड से आप सभी आने वाली कॉल, अन्य नंबर या वॉइस मेल कनेक्शन पर फॉरवर्ड कर सकते हैं.

▶ तुरंत/जब व्यस्त/कोई उत्तर नहीं/पहुँच से बाहर/सभी असमर्थ

9.2.2 कॉल प्रतीक्षा

जब आप कॉल पर होते हैं तब अपको दो बार बीप की आवाज सुनाई दे सकती है जो आपको दूसरी आने वाली कॉल का संकेत देती हैं. जब कॉल प्रतीक्षा सक्षम हो, तब आप सक्रिय कॉल को होल्ड पर रखकर दूसरी आ रही कॉल का उत्तर दे सकते हैं.

▶ **समर्थ** या **असमर्थ** या **फीचर कोड संचादन** चुनें और सॉफ्ट बटन 1 **चुनें** दबाएँ.

नोट कॉल फॉरवर्ड और कॉल प्रतीक्षा के बारे में अधिक जानकारी के लिए अपने सेवा प्रदाता से संपर्क करें.

9.2.3 किसी बटन उतर

जब आपके फोन की घंटी बजती हैं, तो आप के अलावा कोई भी बटन दबाकर बात कर सकते हैं.

▶ **ऑन** या **ऑफ** चुनें और सॉफ्ट बटन 1 **चुनें** दबाएँ.

9.2.4 स्वतः रिडायल

कॉल करने की कोशिश असफल होने पर अपने आप नंबर रिडायल करने से पहले फोन की प्रतीक्षा अवधि सेट करें.

▶ ऑफ/प्रति 60 सेकण्ड्स/प्रति 30 सेकण्ड्स / प्रति 10 सेकण्ड्स.

9.2.5 वॉइस प्राइवेसी

CDMA कॉल्स के लिए बढ़ी हुई या सामान्य वॉइस प्राइवेसी सुविधा चुनें. CDMA में वॉइस प्राइवेसी की सुविधा है. बढ़े हुये वॉइस प्राइवेसी मोड की उपलब्धता के लिए अपने सेवा प्रदाता से संपर्क करें.

▶ **सामान्य** या **बढ़ा हुआ** चुनें और सॉफ्ट बटन 1 **चुनें** दबाएँ.

9.2.6 स्पष्ट आवाज़

यह ऑडियो AGC (ऑटोगेन कंट्रोल) सिस्टम प्रणाली को सक्रिय/निष्क्रिय करता हैं.
इस सुविधा के बेहतर आवाज मिलती हैं जो ऑडियो AGC सिस्टम को सक्रिय करते हुए डायनामिक रेंज और स्पीकर के भिन्न स्तरों पर आवाज भेजने व पाने की तीव्रता और वातावरण नियंत्रित करती हैं.

▶ **ऑन** या **ऑफ** चुनें और सॉफ्ट बटन 1 **चुनें** दबाएँ.

9.2.7 कॉल समयक

जब कोई कॉल चल रही हो तो उसमे लगा समय प्रदर्शित करने के लिए आप अपना फोन सेट कर सकते हैं.

▶ **समर्थ** या **असमर्थ** चुनें और सॉफ्ट बटन 1 **चुनें** दबाएँ.

9.2.8 कॉल संपर्क सचेतक

यह फंक्शन कॉल संपर्क स्थापित हो जाने पर आपको सचेत करता हैं.

▶ **ऑन** या **ऑफ** चुनें और सॉफ्ट बटन 1 **चुनें** दबाएँ.

9.2.9 अस्वीकृत कॉल को SMS लिखें

आप कॉल अस्वीकृत किये जाने पर भेजा जाने वाला अपना संदेश लिख सकते हैं.

9.2.0 अंतर्राष्ट्रीय कॉल प्रेफिक्स

आपको अंतर्राष्ट्रीय कॉल प्रेफिक्स सेट करने देता है.

▶ अन्तर्राष्ट्रीय कॉल प्रेफिक्स डालने के बाद सॉफ्ट बटन 1 **सुरक्षित** दबाएँ.

9.2.* सहायता

आप इस सूची के बारे में और जानकारी प्राप्त कर सकते हैं.

9.3 फोन

1. सॉफ्ट बटन 1 **सूची**, 9 wxyz, 3 def दबाएँ.

9.3.1 बटन रक्षक

इससे आप फोन के बटन पैड की सुरक्षा कर सकते हैं, ताकि गलती से कोई नंबर डायल न हो. जब यह फंक्शन सक्रिय होता है तो काई कॉल नहीं किया जा सकता और सूची लॉक हो जाती हैं. जब बटन पैड लॉक होता है तो कॉल प्राप्त करना सामान्य रुप से संभव होता है.

▶ **समर्थ** या **असमर्थ** चुनें और सॉफ्ट बटन 1 **चुनें** दबाएँ. अगर समर्थ चुनते हैं तो, इच्छित समय डालें. बटन पैड सेट किये गये समय पर स्वतः लॉक हो जायेगा.

तत्काल समर्थ करने के लिए : 0 next बटन दो सेकंड तक दबाए रखें.

तत्काल असमर्थ करने के लिए : प्रक्रिय दोहराएँ.

नोट कॉल समाप्त होने के लगभग 2–3 सेकेण्ड्स बाद बटन पैड लॉक हो जाएगा.
इनकमिंग कॉल के पहले बटन पैड समर्थ होने पर, बटन पैड लॉक कॉल के बाद भी सक्रिय रहता है.

9.3.2 एयर प्लेन मोड

जब आपका फोन एयर प्लेन मोड में होता है, तब इससे न तो कोई कॉल किया जा सकता है न प्राप्त किया जा सकता है और न ही ऑनलाइन जानकारी तक पहुँचा जा सकता है. आप फोन की अन्य सुविधाओं जैसे गेम, आर्गनाइज़र, मेमो आदि का उपयोग कर सकते हैं. एयर प्लेन मोड सक्षम होने पर, स्क्रीन पर ''एयर प्लेन मोड'' संदेश प्रदर्शित होता है.

▶ **ऑन** या **ऑफ** चुनें और सॉफ्ट बटन 1 **चुनें** दबाएँ.

9.3.3 डेटा सेटिंग्स

9.3.3.1 डेटा इन

डेटा सेटिंग्स में आप हाई स्पीड डेटा सेवाओं जैसे इंटरनेट ब्राउज करने या अन्य डायल–अप नेटवर्किंग फंक्शन का उपयोग करने के लिए अपने फोन को वायरलेस मॉडेम के रुप में उपयोग कर सकते हैं. वायरलेस फोन नेटवर्क पर 153.6 केबीपीएस की अधिकतम डेटा गति को सपोर्ट करता हैं. आपके कनेक्शन की गति नेटवर्क की व्यस्तता, संकेत की शक्ति और अपरिवर्तनीय कारकों पर निर्भर करती है.

▶ **ऑन :** इस सेटिंग से उपभोक्ता डेटा कॉल प्राप्त कर सकता है.

▶ **ऑफ**

नोट फोन को मॉडेम के रुप में उपयोग करने के लिए अपको डेटा किट खरीदनी होगी. डेटा किट में उपयुक्त केबल होती हैं. जिसमें फोन को पीसी से जोड़ने के लिए USB इंटरफेस होता है. अधिक जानकारी के लिए कृपया अपने सेवा प्रदाता से संपर्क करें.

9.3.3.2 डेटा बॉड

इस सेटिंग्स से उपभोक्ता टर्मिनल पर बॉड रेट सेट कर सकता है.

▶ डेटा बॉड सेट 19,200 / 115,200 / 230,400 / USB
यह पूर्वनियत रुप से USB पर सेट होता है. यदि आप फोन पर यह सेटिंग बदलते हैं तो सुनिश्चित कर लें कि पीसी बॉड रेट भी उसके अनुसार बदला गया है.

नोट वायरलेस फोन PC/PDA के साथ ठीक तरह से तभी काम करेगा जब दोनों PC की सीरियल पोर्ट सेटिंग्स फोन पर सेट बॉड रेट के समान होगी.

9.3.4 सर्विस सचेतक

सर्विस के बदलने पर आपको सूचित करता है.

▶ **ऑन** या **ऑफ** चुनें और सॉफ्ट बटन 1 **चुनें** दबाएँ.

9.3.5 वर्शन

S/W, PRL और H/W वर्शन देखें.

9.3.6 सहायता

आप इस सूची के बारे में और जानकारी प्राप्त कर सकते हैं.

9.4 सुरक्षा

यह आपके फोन को अनाधिकृत उपयोग से सुरक्षित रखता है.

नोट आपके फोन का पूर्वनियत लॉक कोड/पासवर्ड **0000** है.

9.4.1 पिन कोड निवेदन

जब ऑन सक्रिय करते हैं, तो फोन कॉर्ड–होल्डर सत्यापन के लिये पिन कोड निवेदन करता है. UIM कॉर्ड द्वारा उपलब्ध कराया जाता है.

1. सॉफ्ट बटन 1 **सूची**, 9 wxyz, 4 ghi, 1 दबाएँ.
2. चार अंको का लॉक कोड डालें.
3. से **ऑन/ऑफ** चुनें और दबाएँ.
4. **ऑन** चुनने के पश्चात, 4–8 वर्णो का पिन नंबर डालें और दबाएँ.

▶ अधिक जानकारी के लिए कृपया अपने सेवा प्रदाता से संपर्क करें.

9.4.2 लॉक मोड

यह आपके फोन को अनाधिकृत उपयोग से सुरक्षित रखता है. एक बार फोन लॉक हो जाने पर यह तब तक प्रतिबंधित मोड में होता है, जब तक लॉक कोड नहीं लिखा जाता. इसमे आप फोन कॉल प्राप्त कर सकते हैं और आपातकालीन कॉल भी कर सकते हैं. आपके फोन का पूर्वनियत लॉक कोड/पासवर्ड 0000 है. यदि आपको लॉक कोड बदलना है तो आप इसे सुरक्षा सेट सूची में लॉक कोड बदलें से बदल सकते हैं.

1. सॉफ्ट बटन 1 **सूची**, 9 wxyz, 4 ghi, 2 abc दबाएँ.
2. चार अंकों का लॉक कोड लिखें.
3. कोई विकल्प चुनें और सॉफ्ट बटन 1 **चुनें** दबाएँ.

▶ **ऑफ** का अर्थ है कि फोन अभी तक लॉक नहीं किया गया है. लॉक होने पर, आप आने वाला कॉल प्राप्त कर सकते हैं या केवल आपातकालीन कॉल कर सकते हैं.

▶ **अभी** का अर्थ है कि फोन तुरंत लॉक हो जाता है.

▶ **पावर चालू होने पर** का अर्थ है कि जब फोन चालू किया जाता है, तब फोन लॉक हो जाता हैं.

9.4.3 आपतकालीन नंबर

आपका फोन लॉक अथवा प्रतिबंधित होने पर भी आप 100, 101, 102 नंबरो पर कॉल कर सकते हैं.
आपातकालीन नंबर लिखने के लिए,

1. सॉफ्ट बटन 1 **सूची**, 9, 4, 3 दबाएँ.
2. चार अंकों का लॉक कोड लिखें.
3. सॉफ्ट बटन 1 **संपादन** दबाएँ.
4. आपातकालीन नंबर लिखें.
5. सॉफ्ट बटन 1 **सुरक्षित** दबाएँ.

9.4.4 कोड बदले

9.4.4.1 फोन लॉक कोडं

नए लॉक कोड से आप एक नया चार अंकों का लॉक कोड नंबर लिख सकते हैं.

1. सॉफ्ट बटन 1 **सूची**, 9, 4, 4, 1 दबाएँ.
2. चार अंकों का लॉक कोड लिखें.
3. नया लॉक कोड लिखें (चार–अंक).
4. पुष्टि के लिए यह आपको नया लॉक कोड फिर से लिखने के लिए कहेगा.

9.4.4.2 पिन कोड

पिन कोड बदले फंक्शन से पिन नंबर बदल सकते हैं, जो कि कॉर्ड में सुरक्षित होता है. पहले पिन कोड निवेदन ऑन चुनें और, अगर सही पिन नंबर डालते हैं, तो नया पासवर्ड दो बार डालना पड़ता है. अगर दो बार डाला गया पासवर्ड आपस में मेल नहीं खाता है, तो एक संदेश सूचित करता है और फिर नया पासवर्ड दूबारा डालना पड़ता है. शुरुआती पिन नंबर भिन्न हो सकता है जो कॉर्ड निर्माता पर निर्भर करता है.

1. सॉफ्ट बटन 1 **सूची**, 9, 4, 4, 2 दबाएँ.
2. 4–8 अंक का लॉक कोड लिखें और ● दबाएँ.
3. नया पिन कोड डाल (4–8 अंक) और ● दबाएँ.
4. पिन कोड दूबारा डालें और ● दबाएँ.

9.4.5 मेमोरी मिटाएँ

यह फोन बुक और UIM कॉर्ड में सुरक्षित सभी जानकारियाँ मिटाएँ.

1. सॉफ्ट बटन 1 **सूची**, 9, 4, 5 दबाएँ.
2. चार अंकों का लॉक कोड लिखें.
3. 1 **सभी नाम** या 2 **सभी डेटा** चुनें.
4. मेमोरी खाली हो जाने फोन पूर्वनियत सेटिंग पर आ जायेगा.

9.4.6 पूर्वनियत पर सेट करें

आप कुछ सूची सेटिंग्स को उनके वास्तविक मान पर पुनः सेट कर सकते हैं. जब पूर्वनियत पर सेट करें चुना जाता है, तो फोन बुक को छोड़ कर सभी सेटिंग्स रीसेट हो जाती हैं.

1. सॉफ्ट बटन 1 **सूची**, 9 wxyz, 4 ghi, 6 mno दबाएँ.
2. चार अंकों का लॉक कोड लिखें.
3. से **हाँ** चुनें.
4. सॉफ्ट बटन 1 **चुनें** दबाएँ.

9.4.7 सहायता

आप इस सूची के बारे में और जानकारी प्राप्त कर सकते हैं.

कॉल मेमो में

(कॉल के दौरान : सूची 1)

इससे आप कॉल के दौरान अन्य व्यक्ति द्वारा दिया जाने वाला फोन नंबर नोट कर सकते हैं. ये नंबर कॉल विवरण में सुरक्षित होते हैं. अधिकतम 32 नंबर तक सुरक्षित किये जा सकते हैं.

1. कॉल के दौरान सॉफ्ट बटन 1 दबाएँ.
2. 1 **कॉल मेमो में** दबाएँ.
3. फोन नंबर डालें और सॉफ्ट बटन 1 **सुरक्षित** दबाएँ.

नोट

"हेडसेट इस्तेमाल/फोन इस्तेमाल" सूची कॉल के दौरान फोन और Bluetooth के बीच वॉयस का अदान प्रदान करने के लिये इस्तेमाल होती है.

- जब Bluetooth हेडसेट/हैंड्सफ्री फोन से जुड़ा होता है, तो सूची 1 "हेडसेट इस्तेमाल/फोन इस्तेमाल" प्रदर्शित करती है.
- Bluetooth डिवायस द्वारा कॉल लगाये जाने पर, सूची 1 फोन इस्तेमाल करता है.
- Send बटन द्वारा कॉल लगाये जाने पर, सूची 1 हेडसेट इस्तेमाल करता है.

मौन/मौन नहीं

(कॉल के दौरान : सूची 2)

यह फंक्शन आपके फोन का माइक्रोफोन लॉक कर देता है और दूसरे व्यक्ति तक आपकी आवाज़ नहीं पहुँचने देता.

- **मौन फंक्शन सक्रिय करने के लिये:**

1. कॉल के दौरान सॉफ्ट बटन 1 दबाएँ.
2. 2 **मौन** दबाएँ.

- **मौन फंक्शन निष्क्रिय करने के लिये:**

1. पहले जैसा दोहरायें.

वॉइस प्राइवेसी ऑन/ऑफ

(कॉल के दौरान : सूची 3)

CDMA कॉल्स के लिये मानक या बढ़ा हुआ के रुप में प्राइवेसी सुविधा सेट करें. CDMA में वॉइस प्राइवेसी सुविधा है.

वॉयस मेमो में

(कॉल के दौरान : सूची 4)
इससे आप कॉल के दौरान की बातचीत रिकॉर्ड कर सकते हैं. रिकॉर्डिंग के दौरान, फोन काउंटडाउन समयक प्रदर्शित करता हैं जिससे पता चलता है कि रिकॉर्डिंग का कितना समय बचा है.

नोट वॉइस मेमो रिकॉर्ड की क्षमता 2 घंटे और कॉल वॉइस रिकॉर्ड मेमो की क्षमता 30 मिनट है.

स्पीकर मोड ऑन

(कॉल के दौरान : सॉफ्ट)
कॉल के दौरान स्पीकर ऑन मोड को तुरंत सक्रिय या रद्द करने के लिए, दबाएँ.

इयरपीस/स्पीकर वॉल्यूम

कॉल के दौरान से इयरपीस/स्पीकर वॉल्यूम समायोजित करें.

आपके मोबाईल फोन के लिए कई प्रकार के सहायक उपकरण उपलब्ध है. इनकी उपलब्धता के बारे में अपने स्थानीय वितरक से संपर्क करें.

ट्रेवल चार्जर

यह एडॉप्टर मॉडल बैटरी चार्ज करता है. यह AC 100-240 वोल्ट, 50-60 हट्र्ज़ आउटलेट्स का समर्थन करता है.

Micro SD कॉर्ड

RD6250 के साइड में मेमोरी कॉर्ड लगाने की सुविधा है.
आप इस कॉर्ड को चित्र, वीडियो, MP3, वॉयस इत्यादि सुरक्षित करने के लिए प्रयोग कर सकते है.

हेडसेट

इसे आप फोन से कनेक्ट करके, हाथ लगाए बिना फोन का संचालन कर सकते हैं. इसमे इयरपीस, माइक्रोफोन और मेकित कॉल उत्तर/समाप्त बटन शामिल हैं.

USB डेटा केबल (बिना चार्जिंग वाली)

अपने फोन को अपने पीसी से कनेक्ट करें. (LG-USB5200)

सामान्य प्रश्न

प्र : मैं डायल किये हुए, प्राप्त हुए और छुटी हुई कॉल्स की सूची कैसे देख सकता हूँ?

उ : दबाएँ.

प्र : मैं कॉल विवरण कैसे मिटा सकता हूँ?

उ : दबाएँ → सॉफ्ट बटन 1 **विकल्प** दबाएँ → **मिटाएँ** या **सभी मिटाएँ** दबाएँ → दबाएँ. → **हाँ** चुनें → दबाएँ.

प्र : मै मेमोरी में संग्रहीत सभी नंबर कैसे देख सकता हूँ?

उ : सॉफ्ट बटन 2 **खोजें** दबाएँ.

प्र : मै टाईम मैनेजर में कितने कार्य जोड़ सकता हूँ?

उ : कुल 160 कार्य.

प्र : मै टाईम मैनेजर में संग्रहीत सभी पिछले कार्यक्रम कैसे साफ कर सकता हूँ?

उ : सॉफ्ट बटन 1 **सूची** दबाएँ → 7 **निर्धारक/टूल्स** → 3 **टाईम मैनेजर** → 1 **टाईम मैनेजर** → सॉफ्ट बटन 1 **विकल्प** दबाएँ → 2 **तिथि को मिटाएँ** → **एक सप्ताह/एक महीना/एक दिन** चुनें → दबाएँ.

प्र : मै कितने शीघ्र डायल नंबर संग्रहीत कर सकता हूँ?

उ : कुल 99 नंबर.

प्र : मै कोई शब्द संदेश कैसे भेज सकता हूँ?

उ : दबाएँ → 1 **लिखें**. → 1 **शब्द लिखें** .

प्र : मै कॉल समयक कैसे साफ कर सकता हूँ?(मासिक समय रीसेट).

उ : सॉफ्ट बटन 1 **सूची** दबाएँ → 3 **कॉल विवरण** → 5 **कॉल अवधि** → 4 **कॉल अवधि पुनः सेट करें** → **हाँ** चुनें → दबाएँ.

प्र : मै अपना लॉक कोड कैसे पता कर सकता हूँ?

उ : आपके फोन का पूर्वनियत लॉक कोड/पासवर्ड **0000** है.

प्र : इसमें कितने ग्रुप होते हैं?

उ : ग्रुप्स में कोई ग्रुप नहीं / Business / Personal / Family / Friends / Workgroup / VIP / School / Club होते हैं. आप ग्रुप का नाम शीर्षक संपादित कर सकते हैं. शीर्षक '**कोई ग्रुप नहीं**' बदला नहीं जा सकता.

1. सॉफ्ट बटन 1 **सूची** → 1 **नाम** → 3 **ग्रुपस** और दबा कर ग्रुप चुनें.
2. सॉफ्ट बटन 2 **संपादन** चुनें.

प्र : क्या ग्रुप SMS संभव हैं?

उ : आप एक साथ 10 नंबरों को संदेश भेज सकते हैं. प्रत्येक नंबर अलग–अलग चुना या लिखा जाना चाहिये. 5 संदेश ग्रुप्स होते है एवं हर समूह में अधिकतम 10 सदस्य हो सकते हैं.

प्र : क्या ग्रुप ई–मेल संभव हैं?

उ : आप एक साथ 10 नंबरों को संदेश भेज सकते हैं. प्रत्येक नंबर अलग–अलग चुना या लिखा जाना चाहिये. 5 ई–मेल ग्रुप्स होते है एवं हर समूह में अधिकतम 10 सदस्य हो सकते हैं.

प्र : SMS/ई–मेल एक से ज्यादा प्राप्तकर्ताओं को कैसे भेज सकते हैं?

उ : संदेश लिखने के बाद, विकल्प से SMS/ई–मेल ग्रुप्स चुनें. आप इसमें 10 प्राप्तकर्ता जोड़ सकतें हैं.

प्र : मैं MMS कैसे भेज सकते हैं?

उ : मल्टीमीडिया संदेश लिखने के बाद, विकल्प से चित्र शामिल करें/ध्वनि शामिल करें चुनें. फोन में 30 MMS/50 MMS अधिसूचना संग्रहित हो सकती हैं.

प्र : ● बटन की क्या उपयोगिता हैं?

उ : ● बटन सॉफ्ट बटन 1 के चुनें विकल्प से संबन्धित होने की स्थिति में सॉफ्ट बटन 1 **चुनें** का काम करता हैं.

● बटन सॉफ्ट बटन 1 के विकल्प से संबन्धित होने की स्थिति में सॉफ्ट बटन + पॉपअप सूची में पहला **विकल्प** चुननें का काम करता हैं.

● बटन का उपयोग कॉल के दौरान स्पीकर ऑन/ऑफ करने के लिये किया जाता हैं.

प्र : स्पीकर को कॉल के दौरान सक्रिय करने और आइडल मोड में सक्रिय करने में क्या अंतर हैं?

उ : यदि उपयोगकर्ता स्पीकर ऑन को हमेशा पूर्वनियत के रुप में उपयोग करना चाहता हैं, तो स्पीकर मोड को लंबे समय के लिये ● बटन दबा कर सक्षम किया जाना चाहिये. अगर उपभोक्ता स्पीकर अल्प काल के लिये ईस्तेमाल करना चाहता है, तो ● बटन दबाकर स्पीकर सक्रिय किया जा सकता है. उपभोक्ता ● बटन को दोबारा दबाकर स्पीकर ऑफ कर सकता है.

प्र : एयर प्लेन मोड क्या हैं?

उ : जब आपका फोन एयर प्लेन मोड में होता है, तब इससे न तो कोई कॉल किया जा सकता है न प्राप्त किया जा सकता है और न ही ऑनलाइन जानकारी तक पहुँचा जा सकता है.

प्र : एलएमएस कैसे उपयोग करें?

उ : एलएमएस संदेश की नई सुविधा से, अब उपयोगकर्ता एक बार में 460 अक्षरों तक का कोई संदेश लिख सकता हैं. एलएमएस संदेश भेजने के लिये, संदेश संपादक में 160 से ज्यादा अक्षरो तक का संदेश लिखें. संदेश संपादक का शीर्षक बदल कर 'लिखें LMS (XXX)' हो जाता है जो शेष अक्षरों की संख्या बताता है. भेजें विकल्प चुननें पर, कुल बने खंड प्रदर्शित किये जाते हैं और उपयोगकर्ता से पुष्टि करायी जाती है. उपयोगकर्ता जारी रखने या रद्द करने का विकल्प चुन सकता है. हर खंड नेटवर्क पर साधारण एसएमएस के रुप में भेजा जाता है. संदेश प्राप्त होने की पुष्टि होने पर संदेश आउटबॉक्स में संग्रहित होते हैं. प्रत्येक एलएमएस पैकेट एक एकल संदेश के रुप में प्राप्त किया जाता है. प्रत्येक एलएमएस संदेश संदेश में पैकेट के क्रम की संख्या दर्शाता है, जैसे 3 पैकेट होने पर, <1/3>, <2/3>, <3/3>.

प्र : क्या ग्रुप MMS संभव है ?

उ : एमएमएस ग्रुप्स को एमएमएस भेजने के लिये, सॉफ्ट बटन 1 **सूची** → 2 **संदेश** → 9 **संदेश ग्रुप्स** → **स** 3 **MMS ग्रुप्स** दबाएँ. सॉफ्ट बटन 2 **भेजें** दबाने के बाद, संदेश लिखें और .
दबाएँ. **विकल्प** में, से **भेजें**.

प्र : एसएमएस से ई–मेल और ई–मेल से एसएमएस कैसे भेजें ?

उ : एसएमएस से ई–मेल भेजने के लिये : **संदेश** → **लिखें** → **ई–मेल लिखें** पर जाएँ. यह विकल्प चुनने के बाद एक ई–मेल संपादक प्रदर्शित होता है जहाँ आप ई–मेल आईडी लिख सकते हैं. अधिकतम 40 अक्षरों वाले 10 ई–मेल आईडी दर्ज किये जा सकते हैं. इस स्क्रीन से भेजें विकल्प चुनने पर विषय संपादक सक्षम होता है, यहाँ उपभोक्ता अधिकतम 20 अक्षरों तक दर्ज कर सकता है. विषय संपादक से अगला विकल्प चुनने पर, संदेश संपादक सक्षम होता है, यहाँ उपयागकर्ता X अक्षरों का संदेश लिख सकता है. (X=480– विषय का आकार–सूची में ईमेल आईडी का आकार–पैकेट जानकारी अक्षर). ई–मेल संदेश एलएमएस संदेश भी हो सकते हैं.

ई–मेल को एसएमएस पर प्राप्त करने के लिये: मोबाइल डिवाइस RD6250 पर रिलायंस द्वारा दी गयी ई–मेल आईडी पर ई–मेल भेजा जा सकता है. डिवाइस पर प्राप्त ई–मेल में विषय और संदेश का पाठ हो सकता है. प्राप्त ई–मेल के लिये इनबॉक्स सूची में अलग चिन्ह होगें.

ज्यादा जानकारी के लिये अपने सर्विस प्रदाता से संपर्क करें.

सर्विस के लिये कॉल करने से पहले

कृपया अपने फोन को सर्विस के लिये ले जाने या किसी सर्विस इंजीनियर को बुलाने से पहले देखें कि उसमें यहाँ उल्लेखित कोई समस्या तो नहीं है.

जब ऐसे लक्षण दिखाई दें :	तो यह जाँचें !
जब " " स्क्रीन से नहीं हटता है.	देखें कि क्या यह सर्विस एरिया है, और यदि आपको अभी भी " " दिखाई दे रहा हो, तो कृपया पावर बंद करें और लगभग 2 मिनट बाद इसे चालू करें यदि कोई बदलाव न दिखाई दे, किसी अन्य क्षेत्र में जाने के बाद जाँचें.
जब कनेक्शन लगातार न मिले या कुछ क्षेत्रों में आवाज सुनाई न दे.	जब कुछ क्षेत्रों में फ्रीक्वेंसी वातावरण अस्थिर होता है, तो कनेक्शन लगातार नहीं मिलता है और आवाज ठीक से सुनाई नहीं देती है. किसी अन्य क्षेत्र में जाने के बाद जाँचें.
जब कनेक्शन ठीक से नहीं मिल रहा हो या मिलने पर बीच में टूट रहा हो.	जब फ्रीक्वेंसी अस्थिर या कमजोर होती है, या जब उपयोगकर्ता अधिक होते हैं, तो स्थापित होने के बाद भी कनेक्शन कट सकता है, कृपया कुछ देर बाद प्रयास करें या किसी अन्य क्षेत्र में जाने के बाद जाँचें.
जब LCD चालू नहीं हो रही हो.	बैटरी निकालें और इसे फिर से लगा कर चालू करें. यदि तब भी स्थिति ना बदले, तो बैटरी को प्र्याप्त चार्ज करने के बाद चुनः प्रयास करें.
जब FM रेडियो चालू नहीं हो रही हो.	जाँच ले कि हेडसेट फोन से कनेक्ट है. हेडसेट को पूरी तरह से फोन में दबाएँ.

जब ऐसे लक्षण दिखाई दें :	तो यह जाँचें !
यदि किसी क्षेत्र में किसी टेलीफोन से कनेक्शन मिलने पर प्रतिध्वनि सुनाई देती है.	इसे "प्रतिध्वनि आभास" कहा जाता है, यह कनेक्शन वॉल्यूम बहुत ज्यादा दूसरी तरफ मशीन के विशेष गुणधर्मों के कारण हो सकता है. (सेमीइलेक्ट्रॉनिक टेलीफोन एक्सचेंज).
जब फोन गर्म हो जाये	यदि कनेक्शन लंबी अवधि के लिये स्थापित होता है, या गेम या इंटरनेट और अन्य चीजें लम्बी अवधि के लिये चलती हैं, तो फोन गर्म हो सकता है, इससे उत्पाद के जीवनकाल या प्रदर्शन पर कोई प्रभाव नहीं पड़ता है.
रिंग की आवाज नहीं सुनाई दे रही हो या केवल स्क्रीन लाइट या LCD चमकती हो.	रिंग प्रकार "मौन" या "लाइट" के रुप में सेट हो सकता है. कृपया "रिंग" चुनें.
बैटरी की स्टैंडबॉय अवधि धीरे – धीरे कम होती जाती है.	चूँकि बैटरी धीरे – धीरे खर्च होती है, इसलिये इसका जीवनकाल धीरे – धीरे कम होता जाता है. यदि इसका जीवनकाल खरीदे जाने के बाद से आधा रह गया हो, तो आपको नई बैटरी खरीदनी चाहिये.
जब बैटरी के उपयोग का समय कम हो जाता है.	यदि बैटरी के उपयोग का समय कम हो जाता है, तो यह उपयोगकर्ता के वातावरण, या अधिक कॉल्स , या कमजोर संकेतों के कारण हो सकता है.

टीआईए सुरक्षा जानकारी

वायरलेस हैंडहेल्ड फोन के लिए टीआईए की सुरक्षा संबंधी सारी जानकारी यहाँ दी गई है. सीटीआईए मान्यता के लिये ग्राहक दिशानिर्देश पुस्तिका में पेसमेकर, श्रवण यंत्र और अन्य चिकित्सकीय उपकरण संबंधी जानकारी शामिल करना आवश्यक होता है. उपयुक्त होने पर शेष टीआईए भाषाओं के उपयोग के लिये प्रोत्साहन दिया जाता है.

रेडियो धिक्वेंसी संकेतों का एक्सपोजर

आपका वायरलेस हैंडहेल्ड पोर्टेबल टेलीफोन एक कम शक्तिवाला रेडियो ट्रांसमीटर और रिसीवर है. चालू होने पर यहा रेडियो धिक्वेंसी घ्आरएफघ् संकेत प्राप्त करता और भेजता भी है.

अगस्त 1996 में फेडरल कम्युनिकेशन कमीशन घ्एफसीसीघ् ने हैंडहेल्ड वायरलेस फोन के लिए सुरक्षा स्तरों सहित आरएफ एक्सपोजर दिशानिर्देश अपनाए. वे दिशानिर्देश संयुक्त राज्य और अंतर्राष्ट्रीय मानक निकायों द्वारा निर्धारित पिछले सुरक्षा मानकों के अनुरुप है :

एएनएसआई सी 95.1 (1992)*
एनसीआरपी रिपोर्ट 86 (1986)
आईसीएनआईआरपी (1996)

ये मानक, प्रासंगिक वैज्ञानिक साहित्य के समग्र और समय–समय पर हुए मूल्यांकनों पर आधारित थे. उदाहरण के लिए एएनएसआई मानक घ्सी 95ण्1घ् बनाने के लिए विश्वविद्यालयों, सरकारी स्वास्थ्य एजेंसियों, और उद्योगों के 120 से अधिक वैज्ञानिकों, इंजीनियरों और चिकित्सकों ने अनुसंधान की उपलब्ध जानकारी की समीक्षा की.

आपके फोन की डिजाईन एफसीसी दिशानिर्देश घ्और उन मानकोंघ् का पालन करती है.

एंटीना की देखभाल

बदलने के लिए केवल प्रदान किए गए या मान्यता प्राप्त एंटीना का ही उपयोग करें. अनधिकृत एंटीना, संशोधन या अनुलग्नकों के कारण फोन क्षतिग्रस्त हो सकता है और इससे एफसीसी नियमों का उल्लंघन हो सकता है.

फोन संचालन

सामान्य स्थिति : किसी अन्य टेलीफोन के समान ही इस फोन को पकडे, एंटीना ऊपर की ओर रहें और दूसरे इलेक्ट्रानिक उपकरण से कुछ दूरी पर हो.

कुशल संचालन की युक्तियाँ :

• अपने फोन को अधिक कुशलता से संचालित करने के लिए : जब फोन का उपयोग करना हो रहा हो तो अनावश्यक रुप से एंटीना न छूएँ. एंटीना छूने से कॉल की गुणवत्ता प्रभावित होती है और इससे आवश्यकता से अधिक ऊर्जा खर्च हो सकती है.

• अमेरिकन नेशनल स्टैंडर्ड्स इंस्टीट्यूट, नेशनल काउंसिल ऑन रेडिएशन प्रोटेक्शन एंड मेज़रमेंट, इंटरनेशनल कमीशन कॉन नॉनआयनाइजिंग रेडिएशन प्रोटेक्शन.

वाहन चालन

जिन क्षेत्रों में आप वाहन चला रहें हैं, उन क्षेत्रों के वायरलेस टेलीफोन के उपयोग संबंधी कानून और नियम देख लें. हमेशा पालन करें. साथ ही वाहन चलाते समय यदि आप अपने फोन का उपयोग कर रहें हैं, तो कृप्याः

- वाहन चलाने पर पूरा ध्यान दें – सुरक्षित वाहन चलाना आपकी पहली जिम्मेदारी है;
- यदि उपलब्ध हो, तो हैंड्स–फ्री ऑपरेशन का उपयोग करें;
- यदि आवश्यकता हो, तो सड़क से हटकर गाड़ी पार्क करने के बाद कॉल करें या उत्तर दें.

इलेक्ट्रॉनिक उपकरण

अधिकांश आधुनिक इलेक्ट्रॉनिक उपकरण आरएफ संकेतों से सुरक्षित होते हैं. फिर भी संभव है, कुछ इलेक्ट्रॉनिक उपकरण आपके वायरलेस फोन से निकलने वाले आरएफ संकेतों से सुरक्षित नहीं हों.

पेसमेकर्स

हेल्थ इंडस्ट्री मैन्युफैक्चरर्स एसोसिएशन अनुशंसा करता है कि वायरलेस फोन और पेसमेकर के बीच कम से कम छह(6”) इंच की दूरी होनी चाहिए, ताकि पेसमेकर में संभावित अवरोध टाला जा सके. ये अनुशंसाएँ वायरलेस टेक्नोलॉजी रिसर्च के स्वतंत्र अनुसंधान और अनुशंसाओं के अनुरुप हैं.

पेसमेकर वाले व्यक्तिः

- फोन चालू करने पर अपने पेसमेकर और फोन के बीच हमेशा छह इंच से अधिक दूरी बनाए रखें;
- पेसमेकर के दूसरी तरफ के कान का उपयोग करें, ताकि संभावित अवरोध न्यूनतम हो सके.
- यदि किसी कारण आपको संदेह होता है कि अवरोध आ रहा है तो अपना फोन तुरंत बंद कर दें.

श्रवण यंत्र

कुछ डिजिटल वायरलेस फोन श्रवण यंत्रों के कार्य में अवरोध डाल सकतें है. ऐसा अवरोध आने पर आप विकल्पों की जानकारी प्राप्त करने के लिए स्ळ अधिकृत सर्विस सेंटर से संपर्क कर सकतें हैं. प्रत्येक फोन निर्माता के लिए वैकल्पिक.

अन्य चिकित्सकीय उपकरण

यदि आप किसी अन्य व्यक्तिगत चिकित्सकीय उपकरण का उपयोग करतें हैं, तो अपने उपकरण के निर्माता से परामर्श कर निर्धारित कर लें कि क्या वे बाहरी आरएफ ऊर्जा से पर्याप्त सुरक्षित हैं. यह जानकारी प्राप्त करने में आपका चिकित्सक आपकी सहायता कर सकता हैं.
स्वास्थ्य रक्षा से जुडे संस्थानों में निर्देष दिए जाने पर अपना फोन बंद कर दें। अस्पतालों या स्वास्थ्य रक्षा संस्थानों में ऐसे उपकरण हो सकते हैं जो बाहरी आरएफ ऊर्जा के प्रति संवेदनाशील होते हैं.

वाहन

आरएफ संकेत मोटर वाहनों में गलत ढंग से लगाए गए या अपर्याप्त सुरक्षित इलेक्ट्रॉनिक सिस्टम्स को प्रभावित कर सकतें है. अपने वाहन के संबंध में निर्माता या उसके प्रतिनिधी से पुछताछ कर लें.
आपके वाहन में लगाए गए किसी अतिरिक्त उपकरण के निर्माताओं से आपको परामर्श करना चाहिए.

पोस्टेड सुविधाएँ

यदि कहीं पर आपका फोन बंद करने संबंधी सूचना लगी हो, तो उसका पालन करें.

विमान

एफसीसी नियमों के अनुसार विमान में यात्रा करतें समय फोन का उपयोग वर्जित है. विमान में चढ़ने से पहलें अपना फोन बंद कर दें.

विस्फोट क्षेत्र

विस्फोट कार्यो में अवरोध से बचनें के लिए "विस्फोट क्षेत्र" में या जहाँ : "दोतरफा रेडियो बंद रखें" की सूचना लगी हो, अपना फोन बंद रखें. सभी संकेतों और सुचनाओं का पालन करें..

संभावित विस्फोटक वातावरण

संभावित विस्फोटक क्षेत्र में होने पर अपना फोन बंद कर दें और सभी संकेतों और निर्देषों का पालन करें. ऐसे क्षेत्रों में चिंगारी उठने से भी विस्फोट हो सकता है या आग लग सकती है जिससे चोट लग सकती है या मृत्यु भी हो सकती है.

संभावित विस्फोटक क्षेत्र अक्सर, लेकिन हमेशा नहीं, स्पष्ट रुप सें चिह्नित होते हैं. संभावित क्षेत्रों में ये क्षेत्र शामिल हो सकते हैं : ईंधन (जैसे पेट्रोल पंप); बोट में डेक के नीचे; ईंधन या रसायन परिवहन या भंडारण गृह; तरल पेट्रोलियम गैस (जैसे प्रोपेन या ब्यूटेन) का उपयोग करने वाले वाहन; ऐसे क्षेत्र जहाँ हवा में रसायन या कण होतें हैं (जैसे दाने, धूल या धातु के पाउडर) और ऐसे क्षेत्र जहाँ आपको सामन्यतः अपने वाहन का इंजन बंद करने की सलाह दी जाती हैं.

एयरबैग वाले वाहनों के लिए

एरयबैग बहुत तेजी से फूलता हैं. स्थापित या पोर्टेबल वायरलेस उपकरण सहित कोई भी वस्तु एयरबैग के ऊपर के क्षेत्र या एयरबैग लगें क्षेत्र में न रखें. यदि वाहन में वायरलेस उपकरण गलत ढंग से लगा हो और एयरबैग फूलता है, तो गंभीर चोट लग सकती हैं.

सुरक्षा जानकारी

बिक्री के लिए और आपके फोन के सही इस्तेमाल के लिए और क्षति से बचने के लिए कृपया निम्न जानकारी पढ़ें और इसका पालन करें. साथ हीं, पढ़नें के बाद इस उपभोक्ता मार्गदर्शिका को हमेशा आसान पहुँच वाली जगह पर रखें.

⚠ चेतावनी **इन निर्देषों का पालन न किए जाने पर उत्पाद को मामूली या गंभीर क्षति पहुँच सकती हैं.**

चार्जर और एडाप्टर सुरक्षा

- चार्जर और एडाप्टर केवल इंडोर उपयोग के लिए हैं.

बैटरी की जानकारी और देखभाल

- कृपया बैटरी को ठीक से डिस्पोज़ करें.
- बैटरी को फिर से चार्ज करने के पहले उसका पूरी तरह डिस्चार्ज होना ज़रुरी नहीं हैं.
- केवल LG-द्वारा आपके फोन के मॉडल के लिए अधिकृत चार्जर का ही उपयोग करें जिनका उपयोग बैटरी की आयु बढ़ाता हैं.
- बैटरी को न तो खोलें न शॉर्ट – सर्किट करें.
- बैटरी के धातु के सिरों को साफ रखें.

- जब बैटरी का प्रदर्शन स्वीकार्य स्तर पर नहीं रहे तो इसे बदल दें. बदलने से पहले बैटरी को सैकडों बार रीचार्ज किया जा सकता हैं.
- बैटरी की आयु बढ़ाने के लिए लंबे समय तक उपयोग से बाहर रहने के बाद बैटरी को फिर से चार्ज करें.
- बैटरी का प्रदर्शन उपयोग के तरीकों और पर्यावरण की स्थितियों से प्रभावित के आधार पर अलग–अलग होगा.
- बढ़ी हुई स्क्रीन लाइट, मिनी ब्राउजर और डेटा कनेक्टिविटी किट्स बैटरी की आयु और टॉक/स्टैंडबाय टाइम को प्रभावित कर सकतें हैं.
- असामान्य स्थिति में संचालित किए जाने पर बैटरी की आंररिक सुरक्षा प्रणाली फोन का पावर ऑफ कर देती हैं. इस स्थिति में, बैटरी को फोन से निकालें, इसे फिर से लगाएँ और फोन को ऑन करें.

विस्फोट, झटका और आग

- फोन को बहुत ज़्यादा धुल भरी जगह पर न रखें और पावर कॉर्ड और ऊष्मा के स्रोत के बीच आवश्यक न्यूनतम दूरी रखें.
- फोन को साफ करने से पहले पावर कॉर्ड को प्लग से निकाल लें और गंदा होने पर पावर प्लग को साफ करें.
- पावर प्लग का उपयोग करते, समय सुनिश्चित करें की यह ठीक से कनेक्टेड हैं. यदि यह ठीक से कनेक्टेड नहीं है तो इससे बहुत ज़्यादा ऊष्मा पैदा हो सकती है और आग लग सकती है.
- यदि आप फोन के रिसेप्टेकल (पावर प्लग इन) को कवर किए बिना जेब में या किसी ऐसे बैग में रखते हैं जिसमें धातु की वस्तुएँ जैसे कोई सिक्के, पेपर क्लिप या पेन है तो फोन शॉर्ट – सर्किट हो सकता है. उपयोग में नहीं होने पर रिसेप्टेकल को हमेशा कवर करके रखें.
- बैटरी को शॉर्ट – सर्किट नहीं करें. आपकी जेब या बैग में रखी धातु की वस्तुएँ जैसे कोई सिक्का, पेपर क्लिप या पेन हिलाए जाने पर बैटरी के + या – टर्मिनल (बैटरी की धातु स्ट्रिप) को शॉर्ट – सर्किट कर सकती हैं. टर्मिनल का शॉर्ट – सर्किट बैटरी को नुकसान पहुँचा सकता है और इससे विस्फोट हो सकता है.

सामान्य नोटिस

- क्षतिग्रस्त बैटरी का उपयोग करने का बैटरी को मुँह में रखने से गंभीर चोट लग सकती है.
- चुंबकीय घटको वाली चीजें जैसे क्रेडिट कार्ड, फोन कार्ड, बैंक बुक, या सबवे टिकट को फोन के पास न रखें. फोन का चुंबकत्व इनकी चुंबकीय स्ट्रिप में संग्रहीत डेटा को नुकसान पहुँचा सकता है.
- फोन पर लंबे समय तक बात करने से उपयोग के दौरान पैदा हुई ऊष्मा के कारण कॉल की गुणवता कम हो सकती है.

- जब फोन का उपयोग लंबे समय तक नहीं हो, तो इसकी पावर कॉर्ड का प्लग निकाल कर इसे सुरक्षित जगह पर रखें.
- फोन को किसी भी रिसीविंग उपकरण (जैसे टीवी या रेडियों) के पास उपयोग करने से फोन में व्यवधान आ सकता है.
- रेडियो को LCD मॉनिटर या नोटबुक के पास सुनें जाने पर, रेडियो मॉड्युल काम करना बंद कर देता है, व्यवधान आ जाता है या शोर सुनाई देता है. LCD मॉनिटर पास होने पर, फोन को लगभग 30 मीटर दूर रखें. FM रेडियो तभी सक्रिय होता है जबकि उसमे हेडसेट लगा हो.
- एंटीना क्षतिग्रस्त होने पर फोन का उपयोग न करें. यदि क्षतिग्रस्त एंटीना चमड़ी के त्वचा के संपर्क में आता है, तो इससे त्वचा थोड़ी जल सकती है. क्षतिग्रस्त एंटीना को बदलने के लिए कृपया अधिकृत LG सर्विस सेंटर से संपर्क करें.
- फोन को पानी में डुबोएँ नहीं. यदि ऐसा हो जाता है, तो इसे तुरंत बंद कर दें और बैटरी निकाल दें. यदि फोन काम नहीं करता है, तो इसे अधिकृत LG सर्विस सेंटर पर ले जाएँ.
- इस उत्पाद की पावर कॉर्ड का उपयोग करने पर आप लेड के संपर्क में आएँगें, जिसे कैलिफोर्निया राज्य में ऐसा रासायनिक तत्व माना जाता है जो कैसंर, प्रसव या अन्य प्रजनन संबंधी बाधाओं का कारण हो सकता है. इसे हाथ लगाने के बाद हाथ धोएँ.
- फोन पर रंग नहीं करें.
- असावधानीपूर्वक उपयोग किए जाने, फोन को सुधारने या सॉफ्टवेयर के अपग्रेडेशन के कारण आपके फोन में संग्रहीत डेटा हट सकता है. कृपया अपने महत्वपूर्ण फोन नंबरों का बैकअप रखें. (रिंग टोन, शब्द मैसेज, वॉइस मेल, चित्र और वीडियो भी हट सकते हैं.)

  डेटा की हानि के लिए निर्माता उत्तरदायी नहीं हैं.
- सार्वजनिक स्थानों पर फोन का उपयोग करते समय फोन को कंपन मोड पर सेट करें ताकि अन्य लोगों को परेशानी न हो.
- अपने फोन को कान में लगाते समय इसे ऑन या ऑफ नहीं करें.

एफडीए ग्राहक अद्यतन

यूएस. फूड एंड ड्रग एडमिनिस्ट्रेशन सेंटर फॉर डिवाइसेज़ एंड रेडियोलॉजिकल हेल्थ कंज़्यूमर का मोबाईल फोन के बारे में अद्यतन.

1. क्या वायरलेस फोन स्वास्थ्य के लिए हानिकारक हैं ?

उपलब्ध वैज्ञानिक साक्ष्य यह नहीं बताते कि वायरलेस फोन से कोई स्वास्थ्य समस्या जुड़ी है. हाँलाकि, इसका भी कोई प्रमाण नहीं है कि वायरलेस फोन बिलकुल सुरक्षित हैं. उपयोग के दौरान वायरलेस फोन माइक्रोवेव रेंज में निम्न रेडियो फ्रीक्वेंसी (आरएफ) ऊर्जा उत्सार्जित करते हैं. स्टैंडबॉय मोड में भी वे बहुत कम आरएफ उत्सार्जित करते हैं. आरएफ का ऊँचा स्तर स्वास्थ को प्रभावित (कोशिकाओं को गर्म करके) कर सकता है, जबकि निम्न स्तर की आरएफ के संपर्क से कोई स्वास्थ संबंधी दुष्प्रभाव ज्ञात नहीं हैं. निम्न स्तर की आरएफ के संपर्क के लिए हुए कई अध्ययनों में इसका कोई जैविक प्रभाव नहीं पाया गया. कुछ अध्ययन बताते हैं कि इसके कुछ जैविक प्रभाव हो सकते हैं., लेकिन अन्य अनुसंधानों से इसकी पुष्टि नहीं हुई. कुछ मामलों में तो अन्य अनुसंधानकर्ताओं को वही परिणाम पुनः प्राप्त करने, या अनियमित परिणामों की वजह से कारण निर्धारित करने में कठिनाई आई.

2. वायरलेस फोन की सुरक्षा के संबंध में एफडीए की क्या भूमिका हैं ?

कानून के अंतर्गत, एफडीए उपभोक्ता उत्पादों की बिक्री से पहले सुरक्षा समीक्षा नहीं करता, जैसा कि यह नई दवाईयों या चिकित्सकीय उपकरणों के साथ करता है. फिर भी, यदि यह पाया जाता है कि वायरलेस फोन उपयोगकर्ता के लिए घातक स्तर की रेडियो फ्रीक्वेंसी ऊर्जा (आरएफ) उत्सार्जित करता है तो एजेंसी को कार्यवाई करने का अधिकार है. ऐसी स्थिती में एफडीए, स्वास्थ के लिए फोन के खतरों और उसकी मरम्मत, बदलने या वापस लेने की सूचना उपभोक्ताओं को देना वायरलेस फोन निर्माताओं के लिए अनिवार्य कर सकता हैं, ताकि खतरा समाप्त किया जा सके. हाँलाकि उपलब्ध वैज्ञानिक आँकड़ों के अनुसार एफडीए की ये नियामक कार्यवाईयाँ आवश्यक नहीं हैं, फिर भी एफडीए ने फोन उद्योग से कई उपाय अपनाने का आग्रह किया है, जिसमें निम्न भी शामिल हैं:

- वायरलेस फोन द्वारा उत्सार्जित आरएफ से संभावित जैविक प्रभावों के लिए अनुसंधान में सहायता देना;
- वायरलेस फोन को इस तरह डिजाइन करना, जिससे उपयोगकर्ता के लिए ऐसा आरएफ एक्यपोज़र न्यूनतम किया जा सके जो फोन के कार्य करने के लिए आवश्यक नहीं है; और
- वायरलेस फोन के मानव स्वास्थ्य पर पड़ने वाले संभावित प्रभावों पर हर संभव जानकारी वायरलेस फोन के

उपयोगकर्ताओं को उपलब्ध कराने में सहायता करना. एफडीए, संघीय एजेंसियों के अंतर एजेंसी कार्यसमूह से संबद्ध है जो संघीय स्तर पर आरएफ सुरक्षा के विभिन्न पहलुओं पर सामंजस्यपूर्ण प्रयास सुनिश्चित करने के लिए उत्तरदायी है. इस कार्यसमूह में निम्न एजेंसियाँ हैं:

- नेशनल इंस्टीट्यूट फॉर ऑक्युपेशनल सेफ्टी एंड हेल्थ
- एन्वायरनमेंटल प्रोटेक्शन एजेंसी
- ऑक्युपेशनल सेफ्टी एंड हेल्थ एडमिनीस्ट्रेशन
- नेशनल टेलीकम्युनिकेशंस एंड इन्फॉर्मेशन एडमिनीस्ट्रेश

नेशनल इंस्टीट्यूट ऑफ हेल्थ, कुछ अंतर एजेंसी कार्यसमूह की गतिविधिओं में भी भाग लेती है. एफडीए फेडरल कम्युनिकेशंस कमीशन (एफसीसी) के साथ वायरलेस फोन के लिए नियामक उत्तरदायित्वों का निर्वहन करता हैं. यह अनिवार्य है कि संयुक्त राज्य में बेचे जाने वाले सभी फोन आरएफ एक्सपोजर को सीमित करने वाले एफसीसी सुरक्षा दिशानिर्देषों का पालन करें. एफसीसी वायरलेस फोन संबंधी सुरक्षा के प्रश्नों के लिए एफडीए और अन्य स्वास्थ एजेंसियों पर निर्भर हैं.

एफसीसी उन आधार स्टेशनों का भी नियमन करती है जिन पर वायरलेस फोन नेटवर्क काम करते हैं. हालाँकि ये आधार स्टेशन वायरलेस फोन्स की तुलना में हजारों गुना कम होता हैं. इसलिए आधार स्टेशन इस दस्तावेज की सुरक्षा संबंधी चर्चा का विषय नहीं है.

3. इस अद्यतन का विषय किस प्रकार के फोन हैं ?

यहाँ पर ''वायरलेस फोन'' का अर्थ है बिल्ट – इन एंटीना युक्त हैडहेल्ड वायरलेस फोन, जिन्हें आमतौर पर ''सेल'', ''मोबाईल'', या ''पीसीएस'' फोन कहा जाता है. फोन और उपयोगकर्ता के सिर के बीच काफी कम अंतर होने के कारण इस प्रकार के वायरलेस फोन उपयोगकर्ता को रेडिया फ्रीक्वेंसी ऊर्जा (आरएफ) के संपर्क में ला सकते हैं.

ये आरएफ एक्सपोजर फेडरल कम्युनिकेशन कमीशन के सुरक्षा दिशानिर्देषों द्वारा सीमित किए गए हैं, जो एफडीए और अन्य संघीय स्वास्थ्य व सुरक्षा एजेंसियों की सलाह पर बनाए गए हैं. जब फोन उपयोगकर्ता से अधिक दूर होता है, तो आरएफ एक्सपोजर अत्यंत कम होता है क्योंकि स्त्रोत से दूरी बढ़ने के साथ – साथ व्यक्ति का आरएफ एक्सपोजर तेजी से कम होता जाता है. तथाकथित ''कॉर्डलेस फोन'' जिनकी आधर इकाई घर में टेलीफोन वायरिंग से जुडी होती है, वे अत्यंत कम ऊर्जा स्तरों पर चलते हैं जिससे उत्सर्जित आरएफ एक्सपोजर एफसीसी सुरक्षा सीमाओं से काफी कम होता हैं.

4. पिछले अनुसंधानों के क्या परिणाम हैं ?

अब तक हुए अनुसंधानों के परिणाम विरोधाभासी हैं और कई अध्ययनों की अनुसंधान पध्दतियों में त्रुटियाँ रही हैं. पशुओं पर किए गए वायरलेस फोन के रेडियो फ्रीक्वेंसी ऊर्जा (आरएफ) एक्सपोजर प्रभावों का अध्ययन करने वाले प्रयोगों के विरोधाभासी परिणाम आए हैं., जिन्हें अन्य प्रयोगशालाओं मे दोहराया नहीं जा सकता. हालाँकि पशुओं पर किए गए कुछ प्रयोगों से संकेत मिला है कि कम स्तर का आरएफ एक्सपोजर प्रयोगशाला के पशुओं के कैंसर को बढ़ा सकता है. हालाँकि, ऐसे कई अध्ययन जिनमें ट्यूमर का विकास तेज दिखाई दिया, ऐसे पशुओं पर किए गए थे जिन्हें जैव अभियांत्रिक या कैंसर पैदा करने वाले रसायनों से उपचारित किया गया था, जो कि आरएफ एक्सपोजर की अनुपस्थिती में भी कैंसर का कारण हो सकता है. अन्य अध्ययनों में पशुओं को प्रतिदिन 22 घंटो तक आरएफ के संपर्क में रखा गया था, ये स्थितियाँ वैसी नहीं हैं जिनका सामना लोग वायरलेस फोन का उपयोग करते समय करते हैं, इसलिए निश्चत रुप से यह नहीं कहा सकता कि ऐसे अध्ययनों के परिणाम मानव स्वास्थ के लिए क्या अर्थ रखते हैं. दिसंबर 2000 के बाद तीन बड़े इपिडमियोलॉजिकल अध्ययन प्रकाशित हो चुके हैं. अध्ययनों ने वायरलेस फोन के उपयोग और प्रारंभिक मस्तिष्क कैंसर, ग्लायोमा, मेनिंजियोमा, या एकॉस्टिक न्यूरोमा, मस्तिष्क का ट्यूमर या सलाइवरी ग्लैंड, ल्यूकेमिया या अन्य कैंसर के बीच संभावित संबंधों की जाँच की. इनमें से किसी भी अध्ययन से वायरलेस फोन के आरएफ एक्सपोजर से मानव स्वास्थ्य पर दुष्प्रभाव के संकेत नहीं मिलते. हालाँकि, कोई भी अध्ययन दीर्घकालीन एक्सपोजर संबंधी प्रश्नों के उत्तर नहीं दे सकता, क्योंकि इन अध्ययनों में फोन के उपयोग की औसत अवधि करीब तीन वर्ष थी.

5. यह निर्धारित करने के लिए कि वायरलेस फोन के आरएफ एक्सपोजर स्वास्थ्य के लिए खतरा है या नहीं, किस शोध की आवश्यकता हैं ?

प्रयोगशाला अध्ययनों और वायरलेस फोन के उपयोगकर्ताओं के इपिडमियोलॉजिकल अध्ययन को मिलाने पर आवश्यक जानकारी मिलेगी. आजीवन पशु एक्सपोजर अध्ययन कुछ वर्षों में पूर्ण हो सकते हैं. हालाँकि, कैसर की वृद्धि के विश्वसनीय प्रमाण, यदि हैं तो, देने के लिए बड़ी संख्या में पशुओं की आवश्यकता होगी. इपिडमियोलॉजिकल अध्ययन ऐसा डेटा प्रदान कर सकते हैं जो सीधे मानव जाति पर लागू हों, लेकिन कैंसर जैसे कुछ स्वास्थ्य प्रभावों संबंधी प्रश्नों के उत्तर देने के लिए 10 या अधिक वर्षों का फॉलो – अप आवश्यक होगा. ऐसा इसलिए क्योंकि कैंसर उत्पन्न करने वाले कारक के एक्सपोजर और टयूमर के विकास (यदि ऐसा होता है तो) के बीच का समय कई, कई वर्ष हो सकता है. वायरलेस फोन के दैनिक उपयोग के दौरान वास्तविक आरएफ एक्सपोजर मापने में होने वाली कठिनाईयों से इपिडमियोलॉजिकल अध्ययनों की व्याख्या प्रभावित हुई हैं. इस माप को कई कारक प्रभावित करते हैं. जैसे फोन पकड़ने का कोण या उपयोग किए जा रहे फोन का मॉडल.

6. वायरलेस फोन आरएफ के स्वास्थ्य पर पड़ने वाले संभावित प्रभावों के बारे में अधिक जानकारी के लिए एफडीए क्या कर रहा हैं ?

रेडियों फ्रीक्वेंसी ऊर्जा (आरएफ) के एक्सपोजर संबंधी महत्वपूर्ण प्रश्नों के उत्तर प्राप्त करने के लिए उच्च प्राथमिकता वाले पशु अध्ययन सुनिश्चित करने के लिए एफडीए द्वारा यू.एस.नेशनल टॉक्सिकोलॉजी प्रोग्राम और विश्व भर के जाँचकर्ताओं के समूहों के साथ मिलकर कार्य किया जा रहा हैं. 1996 में वर्ल्ड हेल्थ ऑर्गेनाइजेशन इंटरनेशनल इलेक्ट्रोमैग्नेटिक फील्ड्स (ईएमएफ) प्रोजेक्ट के आरंभ से ही एफडीए इसमें अग्रणी भागीदार रहा हैं. इस कार्य का प्रभावी परिणाम अनुसंधान आवश्यकताओं के लिए एक विस्तृत कार्यसूची का विकास रहा है जिसने विश्व भर में नए अनुसंधान कार्यक्रमों की स्थापना कराई. प्रोजेक्ट ने ईएमएफ मामलों पर सार्वजनिक जानकारी दस्तावेजों की एक श्रृंखला विकसित करने में भी मदद की हैं.

वायरलेस फोन सुरक्षा पर अध्ययन करने के लिए एफडीए और सेल्युलर टेलीकम्युनिकेशन एंड इंटरनेट एसोसिएशन (सिटीआईए) के बीच एक औपचारिक कोऑपरेटिव रिसर्च एंड डेवलपमेंट (सीआरएडीए) हुआ है. सरकार के विशेषज्ञों, उद्योगों और शैक्षणिक संस्थानों से जानकारी लेकर एफडए वैज्ञानिक परिदृश्य प्रदान करती है. सीटीआईए प्रायोजित अनुसंधान स्वतंत्र जॉचकर्ताओं से अनुबंध के माध्यम से चलाया गया हैं. प्रारंभिक अनुसंधान में प्रयोगशाला अध्ययन और वायरलेस फोन उपायेगकर्ताओं का अध्ययन शामिल होगा. विश्व भर में हुए नवीनतम अनुसंधान विकसों के संदर्भ में सीआरएडीए अतिरिक्त अुनसंधान आवश्यकताओं का व्यापक मूल्यांकन भी शामिल करेगा.

7. मुझे कैसे पता चलेगा कि अपने वायरलेस फोन के उपयोग से मुझे कितना रेडियो फ्वेंसी एक्सपोजर मिल रहा हैं ?

संयुक्त राज्य में बेचे गए सारे फोन्स को फेडरल कम्युनिकेशन कमीशन (एफसीसीं) के दिशानिर्देषों का पालन करना आवश्यक हैं जो रेडियों फ्रीक्वेंसी ऊर्जा (आरएफ) एक्सपोजर को सीमीत करते हैं. एफसीसी ने यह दिशानिर्देष एफडीए और अन्य संघीय स्वास्थ व सुरक्षा एजेंसियों के परामर्श के स्थापित किए हैं. वायरलेस टेलीफोन से आरएफ एक्सपोजर की एफसीसी सीमा 1.6 वॉट प्रति किलोग्राम (1.6 वॉ/किग्रा) की स्पेसिफिक एब्जॉर्पशन रेट (SAR) तय की है. एफसीसी सीमा इंस्टीटयूट ऑफ इलेक्ट्रिकल एंड इलेक्ट्रॉनिक इंजीनियरिंग (आईईईई) और नेशनल काउंसिल ऑन रेडिएशन प्रोटेक्शन एंड मेजरमेंट द्वारा विकसित सुरक्षा मानको के अनुरुप है एक्सपोजर सीमा ऊतकों से उस ऊष्मा निकालनेकी शारीरिक क्षमता जो वायरलेस फोन से अवशोषित की जाती है, के आधार पर निश्चित की हाती है और यह प्रभावित करने के स्तर से काफी नीचे सेट की जाती है. वायरलेस फोन निर्माताओं को फोन के हर मॉडल का आरएफ एक्सपोजर को बताना होता है. एफसीसी की वेबासाईट (http://www.fcc.gov/oet/rfsafety/) आपके फोन पर एफसीसी

पहचान क्रमांक ढुंढ़ने का निर्देश देती है जिससे आप ऑनलाईन सूची में अपने फोन का आरएफ एक्सपोजर स्तर देख सकें.

8. वायरलेस फोन्स से निकलने वाली रेडियो फ्रिक्वेंसी ऊर्जा मापने के लिए एफडीए ने क्या किया है?

इंस्टीट्यूट ऑफ इलेक्ट्रिकल्स एंड इलेक्ट्रॉनिक इंजीनियर्स (आईईईई), ने एफडीए के वैज्ञानिकों की सहभागिता व अगुवाई में वायरलेस फोन और अन्य वायरलेस हैंडसेट्स से ऊत्सर्जित रेडियो फ्रिक्वेंसी ऊर्जा (आरएफ) मापने के लिए एक तकनीकी मानक विकसीत किया है. यह जाँचता है कि वायरलेस फोन उपयोगकर्ताओं के सिरों में किस दर से आरएफ जमा हुई हैं. इस जाँच पद्धति में मानव सिर से ऊतक उत्प्रेरक मॉडल का उपयोग किया जाता है. मानकीकृत एसएआर परीक्षण पद्धति से एक फोन पर भिन्न प्रयोगशालाओं में किए जाने वाले मापनों में काफी एकरुपता आने की अपेक्षा है। एसएआर संपूर्ण शरीर या शरीर के छोटे अंग द्वारा ऊतक में अवषोशित ऊर्जा की मात्रा का मापन है.इसे पदार्थ के वॉट/किग्रा. (या मिलिवॉट/ग्रा.) में मापा जाता है. इस माप का उपयोग यह निर्धारित करने के लिए किया जाता है कि कोई वायरलेस फोन सुरक्षा दिशानिर्देषों के अनुरुप है या नहीं.

9. अपने वायरलेस फोन से रेडियो फ्रिक्वेंसी ऊर्जा का एक्सपोजर घटाने के लिए मैं क्या कर सकता हूँ?

यदि इन उत्पादों से कोई खतरा है भी--और इस समय हम नहीं जानते की कोई खतरा है भी या नहीं--तो संभवतः यह बहुत कम हैं। लेकिन यदि आप संभावित खतरों से बचने के प्रति चिंतित है तो आप रेडियो फ्रिक्वेंसी ऊर्जा (आरएफ) का प्रभाव न्यूनतम करने के लिए कुछ आसान कदम उठा सकते है. चुँकी व्यक्ति को कितना एक्सपोज़र मिलता है, इसका सबसे मुख्य कारक समय है, इसलिए वायरलेस फोन के उपयोग की अवधि घटाकर आरएफ एक्सपोजर घटाया जा सकता है.

- यदि आप प्रतिदिन वायरलेस फोन से लंबी बात करते हैं तो आप शरीर और आरएफ स्रोत के बीच ज़्यादा दूरी रख सकतें हैं, क्योंकि दूरी बढ़ने के साथ एक्सपोजर का स्तर नाटकीय रुप से गिरता है.

उदाहरण के लिए आप एक हैडसेट का उपयोग करके वायरलेस फोन को शरीर से दूर रख सकतें है या रिमोट एंटीना से जुड़े वायरलेस फोन का उपयोग कर सकते है. पुनः, वैज्ञानिक डेटा यह नहीं दर्शाते कि वायरलेस फोन हानिकारक हैं. लेकिन यदि आप इन उत्पादों के आरएफ एक्सपोजर से चिंतित हैं तो आप उपरोक्त उपाय अपनाकर वायरलेस फोन का आरएफ एक्सपोज़र घटा सकते हैं.

10. वायरलेस फोन का उपयोग करने वाले बच्चों पर क्या प्रभाव होगा?

वैज्ञानिक प्रमाण वायरलेस फोन के उपयोगकर्ताओं के लिए कोई खतरा नहीं बताते, इसमें बच्चें और किशोर भी शामिल हैं. यदि आप रेडियो धिक्वेंसी ऊर्जा (आरएफ) एक्सपोजर घटाने के लिए कदम उठाना चाहते हैं तो उपरोक्त उपाय वायरलेस फोन का उपयोग करने वाले बच्चें व किशोर भी अपना सकतें हैं. वायरलेस फोन के उपयोग का समय कम करके और उपयोगकर्ता व आरएफ स्रोत के बीच की दूरी बढ़ाकर आरएफ एक्सपोजर घटाया जा सकता है. अन्य राष्ट्रीय सरकारों द्वारा प्रायोजित कुछ समूहों ने सलाह दी हैं कि बच्चों को वायरलेस फोन के उपयोग से रोकना चाहिएँ. उदाहरण के लिए, युनाइटेड किंगडम सरकार ने दिसंबर 2000 में एक ऐसा ही पत्रक बाँटा था. उन्होने कहा कि ऐसा कोई प्रमाण नहीं है कि वायरलेस फोन के उपयोग से ब्रेन ट्यूमर या अन्य बूरे प्रभाव पड़ सकते है. बच्चों के लिए वायरलेस का उपयोग सीमित करना सिर्फ सावधानी के रुप में उठाया गया कदम था; यह किसी वैज्ञानिक प्रमाण पर आधारित नहीं था जिसमें स्वास्थ्य पर बुरा प्रभाव पड़ने की बात हो.

11. वायरलेस फोन चिकित्सकीय उपकरणों में क्या हस्तक्षेप करता है?

वायरलेस फोन की रेडियो धिक्वेंसी ऊर्जा (आरएफ) कुछ इलेक्ट्रॉनिक उपकरणों से प्रतिक्रिया कर सकती है. इसी कारण से एफडीए ने पेसमेकर्स और डिफिब्रिलेटर्स के कार्य में वायरलेस फोन से पड़ने वाला इलेक्ट्रोमैग्नेटिक अवरोध (इएमआई) मापने के लिए एक विस्तृत जाँच पद्धति विकसित की है. यह जाँच पद्धति अब एसोसिएशन फॉर द एडवांसमेंट ऑफ मेडिकल इंस्ट्रूमेंटेशन (एएएमआई) द्वारा प्रायोजित मानक का एक भाग है. एफडीए, चिकित्सकीय उपकरण निर्माताओं और कई अन्य समूहों के संयुक्त प्रयासों से बना अंतिम ड्रॉफ्ट 2000 के अंत पूर्ण हुआ था. इस मानक की बदौलत उत्पादक ये सुनिश्चित करेंगे कि पेसमेकर और डिफिब्रिलेटर्स वायरलेस फोन ईएमआई से सुरक्षित हैं.

एफडीए ने हैंडहेल्ड वायरलेस फोन से श्रवण यंत्र में पड़नेवाले अवरोध की भी जाँच की है और इंस्टीट्यूट ऑफ इलेक्ट्रिकल एंड इलेक्ट्रॉनिक इंजीनियर्स (आईईईई) द्वारा प्रायोजित स्वैच्छिक मानक विकसित करनो में मदद की. यह मानक श्रवण यंत्र और वायरलेस फोन के लिए परिक्षण विधियाँ और कार्यक्षमता आवश्यकताएँ बताते है ताकि जब व्यक्ती एक साथ "संगत" फोन और "संगत" श्रवण यंत्र उपयोग करे तो कोई अवरोध न आए. यह मानक 2000 में आईईईई द्वारा स्वीकृत किया गया था.

वायरलेस फोन से अन्य चिकित्सकीय उपकरणों पर पड़ने वाले प्रभावों पर एफडीए लगातार निगरानी रख रहा है. यदि हानिकारक अवरोध उत्पन्न होता है तो एफडीए अवरोध का आकलन करनें हेतु जाँच करेगा और समस्या के समाधान का प्रयास करेगा.

12. मुझे अतिरिक्त जानकारी कहाँ से मिल सकती है?

अतिरिक्त जानकारी के लिए कृपया निम्न स्रोत देखें:

- वायरलेस फोन पर एफडीए का वेब पेज
  (http://www.fda.gov/cellphones/)
- फेडरल कम्युनिकेशन्स कमीशन (एफसीसी) आरएफ सुरक्षा कार्यक्रम
  (http://www.fcc.gov/oet/rfsafety/)
- इंटरनेशनल कमीशन ऑन नॉन – आयनाइज़िंग रेडिएशन प्रोटेक्शन
  (http://www.icnirp.de/)
- विश्व स्वास्थ्य संगठन (डब्ल्यूएचओ) अंतर्राष्ट्रीय ईएमएफ प्रोजेक्ट
  (http://www.who.int/peh-emf/en/)
- नेशनल रेडिओलॉजिकल प्रोटेक्शन बोर्ड (यूके)
  (http://www.hpa.org.uk/radiation/)