LG
Life's Good

ENGLISH
हिन्दी

USER GUIDE

LG-C375

PRINTED WITH SOY INK™

CE0168

P/NO : MFL67264401(1.1)

www.lg.com

Note: Changing the local language settings.
You can change the language setting for your phone by pressing Menu->Settings->Device->Languages->Device language, then select Language.

टिप्पणी: स्थानीय भाषा सेटिंग्स बदलें |
मेनू का उपयोग करके आप अपने फोन के लिए भाषा सेटिंग को बदल सकते हैं.मेनू ->सेटिंग्स->यंत्र->भाषाएं ->डिवाइस भाषा, भाषा का चयन करें .

ಗಮನಿಸಿ : ಸ್ಥಳೀಯ ಭಾಷೆಯ ಸೆಟ್ಟಿಂಗ್ ಗಳನ್ನು ಬದಲಾಯಿಸಲಾಗುತ್ತಿದೆ.
ನೀವು ನಿಮ್ಮ ಫೋನ್ ನ ಭಾಷೆಯ ಸೆಟ್ಟಿಂಗ್ ಗಳನನ್ನು ಬದಲಾಯಿಸಲು, ಮೆನು ->ಸೆಟ್ಟಿಂಗ್ಸ್ ->ಸಾಧನ -> ಭಾಷೆಗಳು -> ಸಾಧನ ಭಾಷೆ-> ಅನ್ನು ಒತ್ತಿ ಆನಂತರ ಭಾಷೆಯನ್ನು ಆಯ್ಕೆ ಮಾಡಿ.

குறிப்பு: உள்ளூர் மொழிகளின் அமைப்புகளை மாற்றியமைத்தல்.
உங்களது தொலைபேசிக்கு மொழியை மாற்ற வேண்டுமானால் மெனு->அமைப்புகள்->கருவி->மொழிகள்->கருவி மொழி பிறகு மொழியை தேர்வு செய்யவும்.

નોંધ: સ્થાનિક ભાષા માટે સેટિંગ્સ બદલો.
મેનૂ -> સેટિંગ્સ->ઉપકરણ ->ભાષાઓ ->યંત્ર ભાષા. પછી ભાષા પસંદ કરો, આનો ઉપયોગ કરી તમે તમારા ફોન માટે ભાષા સેટિંગ્સ ને બદલિ શકો છો,.

ગમનિક : స్థానిక బాషా సెట్టింగులను మార్పుట.
మీరు మీ ఫోన్ బాషా సెట్టింగులను మార్చాలనుకొంటే మెను -> సెట్టింగులు-> పరికరం-> భాషలు->పరికరం భాష->తర్వాత తెలుగు భాషను ఎంచుకోండి.

ਨੋਟ : ਆਪਣੇ ਸਥਾਨੀ ਭਾਸ਼ਾ ਦੀ ਸੈਟਿੰਗਾ ਬਦਲੋ.
ਤੁਸੀ ਮੀਨੂੰ ਦਬਾ ਕੇ ਆਪਣੇ ਫੋਨ ਦੀਆ ਭਾਸ਼ਾ ਸੈਟਿੰਗਾ ਬਦਲ ਸਕਦੇ ਹੋ, ਮੀਨੂ->ਸੈਟਿੰਗਾ->ਉਪਕਰਨ->ਭਾਸ਼ਵਾਂ->ਉਪਕਰਨ ਭਾਸ਼ਵਾਂ->ਫੋਨ ਭਾਸ਼ਾ ਚੁਣੋ |

LG-C375 User Guide - English

This guide will help you understand your new mobile phone. It will provide you with useful explanations of features on your phone.

Some of the content of this manual may differ from your phone depending on the software of the phone or your service provider.

Product Registration Program

Dear LG Mobile customer,

You are entitled for one year warranty on this model.
For automatic registration, One SMS containing the IMEI no. of your phone will be automatically sent to LG servers @ Rs.0.06p only.
In return you will get one year warranty from the date of purchase at any authorized LG Mobile Service center.
We assure you the information will be kept confidential and used for internal purpose only.
LG Electronics India Pvt. Ltd. does not have any revenue sharing with any cellphone operators for proceeds from SMS of automatic registration.

Contents

Guidelines for safe and efficient use 4

Getting to Know Your Phone 10

Installing the SIM and battery . 12

Using Dual SIM-card 14

Memory card 15

Menu map 16

Your home screen 17

The status bar 17

Calling 18

Making a call 18

Making a call from your Contacts 18

Answering and rejecting a call . 18

Speed dialling 18

Games & apps. 20

Games 20

Applications 20

Google Search 20

More contents 20

Logs 20

All logs 20

Calls Only 20

Messages Only 20

Missed logs 20

Outgoing logs 20

Incoming logs 20

Camera 21

Camera 21

Video Camera 21

Album 21

Internet 21

SNS (Social network services) 22

Facebook 22

Twitter 22

Orkut 22

Windows Live! 22

Messaging 23

Messaging 23

Sending a message 23

Entering text 23

Text input mode using the keypad 24

Managing your messages 24

Settings 25

Music 31

MP3 Player 31

FM Radio 33

E-Mail 34

Sending an email using your new account 34

Retrieving your email 34

Message folders 34

Changing your email settings ... 35

Phonebook 36
Searching for a contact.....36
Adding a new contact.....36
Contact options 36
Creating a group 37
Changing your contact settings 37
Tools 39
Quick menu.....39
Organiser 39
Alarm clock.....39
Calculator 39
Voice recorder.....39
Using the stopwatch 39
Converting a unit 40
Adding a city to your World clock.....40
LED Banner 40
Settings 41
Dual SIM 41
Profiles.....41
Device.....41
Display.....42
Call 43
Connectivity.....44
Wi-Fi.....47
Phone Software update.....47
Synchronise your phone with your PC 47
Backing up and restoring your phone's information 48
Viewing your phone files on your PC.....48
Accessories 49
Technical Data.....50
Troubleshooting.....51

Guidelines for safe and efficient use

Please read these simple guidelines. Not following these guidelines may be dangerous or illegal.

Exposure to radio frequency energy

Radio wave exposure and Specific Absorption Rate (SAR) information
This mobile phone model LG-C375 has been designed to comply with applicable safety requirements for exposure to radio waves.
These requirements are based on scientific guidelines that include safety margins designed to assure the safety of all persons, regardless of age and health.

- The radio wave exposure guidelines employ a unit of measurement known as the Specific Absorption Rate, or SAR. Tests for SAR are conducted using standardised methods with the phone transmitting at its highest certified power level in all used frequency bands.
- While there may be differences between the SAR levels of various LG phone models, they are all designed to meet the relevant guidelines for exposure to radio waves.
- The SAR limit recommended by the International Commission on Non-Ionizing Radiation Protection (ICNIRP) is 2 W/Kg averaged over 10g of tissue.
- The highest SAR value for this model phone tested by DASY4 for use at the ear is 1.25 W/Kg (10g) and when worn on the body is 1.28 W/Kg (10g).
- SAR data information for residents in countries/regions that have adopted the SAR limit recommended by the Institute of Electrical and Electronics Engineers (IEEE), which is 1.6 W/Kg averaged over 1g of tissue.

Product care and maintenance

⚠ **WARNING:** Only use batteries, chargers and accessories approved for use with this particular phone model. The use of any other types may invalidate any approval or warranty applying to the phone, and may be dangerous.

- Do not disassemble this unit. Take it to a qualified service technician when repair work is required.
- Keep away from electrical appliances such as TVs, radios, and personal computers.
- The unit should be kept away from heat sources such as radiators or cookers.
- Do not drop.
- Do not subject this unit to mechanical vibration or shock.
- Switch off the phone in any area where you are required by special regulations. For example, do not use your phone in hospitals as it may affect sensitive medical equipment.
- Do not handle the phone with wet hands while it is being charged. It may cause an electric shock and can seriously damage your phone.
- Do not to charge a handset near flammable material as the handset can become hot and create a fire hazard.
- Use a dry cloth to clean the exterior of the unit (do not use solvents such as benzene, thinner or alcohol).
- Do not charge the phone when it is on soft furnishings.
- The phone should be charged in a well ventilated area.
- Do not subject this unit to excessive smoke or dust.
- Do not keep the phone next to credit cards or transport tickets; it can affect the information on the magnetic strips.
- Do not tap the screen with a sharp object as it may damage the phone.
- Do not expose the phone to liquid or moisture.
- Use the accessories like earphones cautiously. Do not touch the antenna unnecessarily.
- Do not use your device for a long period of time with any part of your body in direct contact with it. During normal operation, the temperature of the product may increase, which may cause your skin to be harmed or burnt.

Guidelines for safe and efficient use

Efficient phone operation

Electronics devices

All mobile phones may get interference, which could affect performance.

- Do not use your mobile phone near medical equipment without requesting permission. Avoid placing the phone over pacemakers, for example, in your breast pocket.
- Some hearing aids might be disturbed by mobile phones.
- Minor interference may affect TVs, radios, PCs, etc.

Road safety

Check the laws and regulations on the use of mobile phones in the area when you drive.

- Do not use a hand-held phone while driving.
- Give full attention to driving.
- Use a hands-free kit, if available.
- Pull off the road and park before making or answering a call if driving conditions so require.
- RF energy may affect some electronic systems in your vehicle such as car stereos and safety equipment.
- When your vehicle is equipped with an air bag, do not obstruct with installed or portable wireless equipment. It can cause the air bag to fail or cause serious injury due to improper performance.
- If you are listening to music whilst out and about, please ensure that the volume is at a reasonable level so that you are aware of your surroundings. This is particularly imperative when near roads.

Avoid damage to your hearing

Damage to your hearing can occur if you are exposed to loud sound for long periods of time. We therefore recommend that you do not turn on or off the handset close to your ear. We also recommend that music and call volumes are set to a reasonable level.

Blasting area

Do not use the phone where blasting is in progress. Observe restrictions, and follow any regulations or rules.

Potentially explosive atmospheres

- Do not use the phone at a refueling point.
- Do not use near fuel or chemicals.
- Do not transport or store flammable gas, liquid, or explosives in the same compartment of your vehicle with your mobile phone and accessories.

In aircraft

Wireless devices can cause interference in aircraft.

- Turn your mobile phone off before boarding any aircraft.
- Do not use it on the aircraft without permission from the crew.

Children

Keep the phone in a safe place out of the reach of small children. It includes small parts which may cause a choking hazard if detached.

Emergency calls

Emergency calls may not be available under all mobile networks. Therefore, you should never depend solely on the phone for emergency calls. Check with your local service provider.

Battery information and care

- You do not need to completely discharge the battery before recharging. Unlike other battery systems, there is no memory effect that could compromise the battery's performance.
- Use only LG batteries and chargers. LG chargers are designed to maximise the battery life.
- Do not disassemble or short-circuit the battery pack.
- Keep the metal contacts of the battery pack clean.
- Replace the battery when it no longer provides acceptable performance. The battery pack maybe recharged hundreds of times until it needs replacing.

Guidelines for safe and efficient use

- Recharge the battery if it has not been used for a long time to maximise usability.
- Do not expose the battery charger to direct sunlight or use it in high humidity, such as in the bathroom.
- Do not leave the battery in hot or cold places, this may deteriorate the battery performance.
- There is risk of explosion if the battery is replaced by an incorrect type.
- Dispose off used batteries according to the manufacturer's instructions. Please recycle when possible. Do not dispose as household waste.
- If you need to replace the battery, take it to the nearest authorised LG Electronics service point or dealer for assistance.
- Always unplug the charger from the wall socket after the phone is fully charged to save unnecessary power consumption of the charger.
- Actual battery life will depend on network configuration, product settings, usage patterns, battery and environmental conditions.

Disposal of your old appliance

1 When this crossed-out wheeled bin symbol is attached to a product it means the product is covered by the e-waste (Management and Handling) Rules, 2011.

2 All electrical and electronic products should be disposed of separately from the municipal waste stream via designated collection facilities appointed by the government or the local authorities.

3 The correct disposal of your old appliance will help prevent potential negative consequences for the environment and human health.

4 For more detailed information about disposal of your old appliance, please contact your city office, waste disposal service or the shop where you purchased the product.

5 This product does not contain any of the hazardous substances as specified in the rule 13 (1) and (2) of the e-waste (Management and Handling) Rules, 2011.

Getting to Know Your Phone

Earpiece

Send key

- Dials a phone number and answers a call.
- **In standby mode:** Shows the history of calls.

Alpha numeric keys

- **In standby mode:** Input numbers to dial. Hold down below keys.
  - 0 - Insert '+' symbol to make international calls.
  - 1 - Connect voice Mail centre.
  - 2 To 8 - Speed dials.
  - 9 - SOS Mode.
  - SYM - Hold the key down to Activate or deactivate silent mode.
- **In editing mode:** Enter numbers & characters.

Message blinker

- This led flashes up to 10 minutes if you don't check new IM, Email ,Message and Missed call.

Soft keys (Left soft key / Right soft key)

- These keys perform the function Indicated in the bottom of the display.

Main LCD

End key

- Switch on/off (hold down)
- End or reject a call.

Confirm key / OK key

- Selects menu options and confirms actions.

Lock key

- Key lock at any screen (long press)
- Unlock at lock screen (long press)

Navigation key

- **In standby mode:**

Press Up Navigation Key: Widget when it was set. (Menu >Settings > Display > Homescreen > Widget settings)

Press Down Navigation Key: My stuff

Press Right Navigation Key: MP3 player

Press Left Navigation Key: Camera

- **In menu:** Scroll up, down, Right & left.

Charger/USB cable connector

TIP: Please ensure the phone is powered on , external memory card is inserted and in idle mode before connecting the USB cable for Mass Storage.

Side keys

- **In standby mode**: Controls the ring volume.
- **During a call**: Earpiece volume adjustment.
- **During playing MP3 music**: Audio volume adjustment.

SIM Switching Key (SIM1 and SIM2 selection)

Headset

Back cover

Memory card holder

Camera lens

SIM Card holder

Battery pack

Installing the SIM and battery

1 Remove the back cover
Lift the back cover upwards.

2 Remove the battery
Lever the top edge of the battery and remove it carefully from the battery compartment.

⚠ **WARNING:** Do not remove the battery when the phone is switched on, as this may damage the phone.

3 Install the SIM card
Slide the SIM card into the SIM card holder. Make sure that the gold contact area on the card is facing downwards. To remove the SIM card, pull it gently in the reverse direction.

4 Install the battery
First insert the bottom of the battery into the bottom edge of the battery compartment. Ensure that the battery contacts align with the terminals on the phone. Press top of the battery until it clips into place.

5 Insert the back cover

6 Charging your phone

Open the cover of the charger socket on the right of your LG-C375. Insert the charger and plug into a mains electricity socket. Your LG-C375 will need to be charged until a message reading “Battery full” appears on screen.

Using Dual SIM-card

You can see two Network Signal icons on the left-top of the screen when you insert two SIM-Card.

Activating and switching SIM cards

The SIM Switching key allows you to select the default SIM card for call or message in Contact, Call logs and Message box in standby mode.

User can also press SIM switching key simply on the left side of the LG-C375. Dual SIM key makes it easy for you to switch SIM-Card whenever you call, send messages and so on.

Note: If there is only one SIM card installed, this SIM card would be activated as default

TIP! You can see the network signals highlighted by background colour when you switch them. It makes you easily identify the strength of your signal of the selected SIM-Card.

TIP! You must choose SIM1 or SIM2 to use some function. For example, Call, Messaging, Phonebook, Settings etc.

Memory card

Installing a memory card

You can expand the memory available on your phone using a memory card.

Note: A memory card is an optional accessory.

Slide the memory card into the slot until it clicks into place. Make sure that the gold contact area is facing downwards.

WARNING: External memory cannot be exceeded 8GB.

Removing a memory card

Carefully remove the memory card by gently pushing it in to the phone and quickly releasing it.

Formatting the memory card

Your memory card may already be formatted. If your memory card isn't formatted, you will need to format it before you can begin using it.

1. From the home screen press **Menu** then select **Settings**.
2. Choose **Device** and **Memory info**. and select **External memory**.
3. Press **Format** and enter the password, which is set to 0000 as default. Your memory card will be formatted and ready to use.
4. To view the new formatted folders on your LG-C375 press **Menu** and select **My stuff**. Press right navigation key two times to choose memory card.

WARNING: When you format your memory card, all the content will be wiped. If you do not want to lose the data on your memory card, back it up first.

WARNING: Do not remove your MicroSD card during the data transfer.

Menu map

Games & apps.
1 Games
2 Applications
3 Google Search
4 More contents

Logs
1 All logs
2 Calls only
3 Messages only
4 Missed logs
5 Outgoing logs
6 Incoming logs
7 Call duration
8 Data volume

Camera
1 Camera
2 Video camera
3 Album

Internet

SNS
1 Facebook
2 Twitter
3 Orkut
4 Windows Live!

Messaging

Music
1 MP3 player
2 FM radio

E-Mail

My stuff
1 Images
2 Sounds
3 Videos
4 Others

Phonebook

Tools
1 Quick menu
2 Organiser
3 Alarm clock
4 Calculator
5 Voice recorder
6 Stopwatch
7 Unit converter
8 World clock
9 LED Banner
0 USIM services

Settings
1 Dual SIM
2 Profiles
3 Device
4 Display
5 Call
6 Connectivity
7 Wi-Fi

Your home screen

The status bar

The status bar uses various icons to indicate things like signal strength, new messages and battery life, as well as telling you whether your Bluetooth connection is active.

The table below explains the meaning of icons you're likely to see in the status bar.

Icon	Description
	Network signal strength (number of bars will vary)
	No network signal
	GPRS available
	EDGE available
	Flight mode is activated
	Calls are diverted
	Roaming service
	Bluetooth® is activated
	Data connecting

Icon	Description
	An alarm is set
	Schedule
	New message
	New voice message
	New Email
	Normal profile in use
	Silent profile in use
	Outdoor profile in use
	Headset inserted
	Remaining battery life
	Battery empty
	External memory
	FM radio
	MP3 music playing
	Wi-Fi

Calling

Making a call

1 Make sure your phone is on.

2 You can use the keypad. To delete a digit press back arrow.

3 Press to begin the call.

4 To end the call, press .

TIP! To enter + when making an international call, press and hold 0.

Making a call from your Contacts

It's easy to call anyone whose number you have stored in your **Phonebook**.

1 Press **Menu** to open the main menu. Select **Phonebook**.

2 Using the keypad, enter the first letter of the contact you want to call and scroll to the **Phonebook**.

3 Press to begin the call.

Answering and rejecting a call

When your phone rings, press **Accept** or press to answer the call.

While your phone is ringing you can press **Silent** to mute the ringing.

This is useful if you have forgotten to change your profile to silent for a meeting.

Press or select **Reject** in order to reject an incoming call.

Note: In call when speaker is activated, the speaker icon is displayed with red colour cross, when the speaker is deactivated speaker icon is displayed without red colour cross.

Speed dialling

You can assign a speed dial number to a contact you call frequently.

1 Press **Menu** to open the main menu. Select **Phonebook**, then select **Options** and **Speed dials**.

2 Your voicemail is preset to speed 1 Key and SOS Mode is preset to 9 key. Hence you cannot change this. Select any other number either by using the navigation keys and selecting **Set** or by pressing the hard key number and selecting Set.

3 Your **Phonebook** will open. Select the contact you'd like to assign to that number using the navigation keys then Press **Select**.

To call a speed dial number in standby mode, press and hold the assigned number until the contact appears on screen.

Games & apps.

Press **Menu** and select **Games & apps**.

You can install new games and applications on your phone to keep you amused when you have spare time.

Games

Access Games on your LG-C375, or download new ones by browsing the catalog of games available for purchase.

Applications

You can use the NewsHunt.

News Hunt - News Hunt is a unique mobile application designed to enable viewing and reading newspapers in the regional languages on the go.

> **Note:** Please ensure Auto Update is On before using this Applications.

Google Search

Used for an Internet search.

More contents

User can access AccuWeather and Yahoo news from this menu.

Logs

Press **Menu** and select **Logs**.

All logs

View a complete list of all your dialled, received and missed calls and also send and received messages.

Calls Only

View a list of all the numbers you have called, received calls and missed calls.

Messages Only

View a list of all the numbers you have sent or received messages.

Missed logs

View a list of any calls you have missed.

Outgoing logs

View a list of all the numbers you have called.

Incoming logs

View a list of all the numbers that have received.

> **TIP!** From any call log select **Options** and then **Delete** to delete selected items.

Camera

Camera

1 Press **Menu** and select **Camera** and **Camera**.

2 When the camera has focused on your subject, select the Capture icon on the bottom-centre of the screen and press **OK Key** to take a photo.

Video Camera

1 Press **Menu** and select **Camera** and choose **Video Camera**. The video camera's viewfinder will appear on screen.

2 Focus the camera on what to record.

3 Select the Rec. icon on the bottom-centre of the screen and press **OK Key** to take a video. Rec will appear at the bottom of the viewfinder. Press again to stop recording.

Album

View the pictures and videos you have taken in your Album.

Internet

You can launch the internet browser and access the homepage of the activated profile on web settings. You can also manually enter a URL address and access the associated WEB page.

1 In Menu mode, select **Internet** → **Yes** to launch your service provider' homepage.

2 Navigate web pages using the following keys:

Navigation - Scroll up or down on a web page.

OK - Select an item.

Back - Return to the previous page.

Options - Access a list of browser options.

Note: You will incur extra cost by connecting to these services and downloading content.
Check data charges with your network provider.

SNS (Social network services)

Your LG-C375 has SNS that lets you enjoy and manage your social network. You can update your own SN place status and view your friends' SN updates.

Note: SNS feature is a data intensive application. An additional costs may be incurred when connecting and using online services. Check your data charges with your network provider.

Facebook

Home: Log in and you will see your friend's updated status. Input your comment about new status or check others. Select Options to choose Refresh and main menu.

Twitter

Twitter is a micro blogging service that enables its users to send and read messages known as tweets.

Orkut

Orkut is an online community designed to make your social life more active and stimulating.

Windows Live!

This indicates the Instant Messaging Client Information such as Client Name and Version Number.

Note: Please ensure Auto Update is On before using this Applications.

Messaging

Messaging

Your LG-C375 includes functions related to SMS (Short Message Service), MMS (Multimedia Message Service) as well as the network's service messages.

Sending a message

1 Press **Menu**, select **Messaging** and choose **Write message**.

2 A new message editor will open. Message editor combines **SMS** and **MMS** in one intuitive mode that is easy to switch between. The default setting of the message editor is **SMS** mode.

3 Enter your message using the keypad. See **Entering text** on the right for more information on how to enter text.

4 Select **Options** and choose **Insert** to add an **Image**, **Video**, **Sound**, **Text template, Multimedia template, Emoticon**, **Name & Number**, **Slide**, **Subject** or **More** (**Business card/Schedule/Memo/Task/My profile**).

5 Choose **Send to**.

6 Choose a contact from the list of contacts or enter the phone number.

7 Select **Send**.

⚠ **WARNING**: Image, Sound, Video, Slide, Subject, Business card, Schedule or My profile is added to the message editor, it will be automatically converted to MMS mode and you will be charged accordingly.

Entering text

You can enter alphanumeric characters using the phone's keypad. For example, storing names in contacts, writing a message and creating scheduling events in the calendar all require entering text. The following text input methods are available in the phone: Abc mode, and 123 mode.

Note: Some fields may allow only one input mode (e.g. telephone number in contact fields).

Messaging

Text input mode using the keypad

When you want to enter text, for example when writing a message, the keypad will default to Abc mode. If you are entering a number, for example when making a call, the keypad number keys will default to numbers. To enter the small symbol (such as @) or the number (such as 0) at upper right of the keys, press the Fn Key . Press it once for just the next letter, or twice quickly for all letters.

Managing your messages

1 Press **Menu**, select **Messaging** and choose messages.

2 Select **Options** and then choose to:

Reply - Send a reply to the selected message.

Write message - Write a new message regardless who sent you message.

Call - Call the person who sent you the message.

Save number - Save the number of the message.

Delete - Delete the selected message.

Drafts - If you don't have time to finish writing a message, you can save what you have written so far in here.

Outbox - This is a temporary storage folder used while messages are being sent.

My folders - You can move messages of **Inbox** or **Sent** into **My folders**. Also you can move those messages of **My folders** into the original message box.

Templates - A list of pre written useful messages, useful for a quick reply.

Emoticons - You can create a new emoticon or edit it. You can also delete it depending on your preference.

Settings - This menu allows you to set features of your network service provider.

Settings

Message view - Choose to Conversation view or Standard view. By default conversation view is displayed. When you open one message in a conversation, all of your related messages will be stacked neatly, like a deck of cards. You can change this setting to Standard View using Message view menu. To do so, go to Message > Settings > Message view.

Text message - You can configure text message related options.

Multimedia message - You can configure multimedia message related options.

Spam message - You can store the massage set as spam.

Voicemail - Add a new voicemail service. Contact your network operator for more information on the service they provide.

Service message - Choose to receive or block service messages. You can also set your message security by creating trusted and untrusted lists of senders.

Save sent message - You can select to save message you sent.

Message counter - You can check amount of messages you sent during period you want to know.

Info. service - Choose the reception status, channels and language of your info messages.

Note: Info message will display only for slot 1.

TIP! While viewing the received message, press **Options** and select **Quick reply**. This is useful if you need to reply the message during a meeting.

TIP! While you see the message, press **Options** and select **Extract**. You can extract the information such as a number, email address or web address from the selected message.

Regional language's QWERTY Key maps

TIP! Keypad help is provided in all the editors > option > select Keymap help.

GUJARATI

Q	W	E	R	T	Y	U	I	O	P
ૌ ઔ ૧	ૈ ઐ ૨	ા આ ૩	ી ઈ ૪	ૂ ઊ ૫	બ ભ ૬	હ ડ ૭	ગ ઘ ્ગ ૮	દ ધ ૯	જ ઝ ગ ચ છ ૦

A	S	D	F	G	H	J	K	L
ો ઓ	ે એ ઍ ૅ	્ અ ્ર	િ ઇ	ુ ઉ	પ ફ	ર ર્ ઋ	ક ખ ક્ષ	ત થ ટ ઠ ડ ઢ

Z	X	C	V	B	N	M
ૉ ઑ	ં ઃ ઁ ૃ	મ ણ	ન	વ ચ	લ ળ	સ શ ષ શ્ર

KANNADA

Q	W	E	R	T	Y	U	I	O	P
ೌ ಔ ೧	ೈ ಐ ೨	ಾ ಆ ೩	ೀ ಈ ೪	ೂ ಊ ೫	ಬ ಭ ೯	ಹ ಙ ೭	ಗ ಘ ಲ	ದ ಧ ಡ ಢ ೯	ಜ ಚ ಛ ಝ ಞ ೦

A	S	D	F	G	H	J	K	L
ೋ ೊ ಒ ಓ	ೇ ಏ	್ ಅ	ಿ ಇ	ು ಉ	ಪ ಫ	ರ ೃ ಿ ಋ ಱ	ಕ ಖ	ತ ಥ ಟ ಠ ತ್ರ

Z	X	C	V	B	N	M
ೆ ಎ	ಂ ಃ	ಮ ಣ	ನ ಞ	ವ ಯ ಱ	ಲ ಳ	ಸ ಶ ಷ ಶ್ರ

PUNJABI

Q	W	E	R	T	Y	U	I	O	P
ੇ ਐ ੧	ੈ ਐ ੨	ਾ ਆ ੩	ੀ ਈ ੪	ੂ ਊ ੫	ਥ ਭ ੬	ਹ ਝ ੭	ਗ ਘ ਗ਼ ੮	ਦ ਧ ੯	ਜ ਝ ਜ਼ ੦

A	S	D	F	G	H	J	K	L
ੋ ਓ ੧ੱ	ੇ ਏ	੍ ਅ	ਿ ਇ	ੁ ਉ	ਪ ਫ ਫ਼	ਰ ਟ ਠ	ਕ ਖ ਖ਼	ਤ ਥ ੜ

Z	X	C	V	B	N	M
ਯ । ੰ	ੰ ं ੱ ः	ਮ ਣ	ਨ ਙ ਢ	ਵ ੜ ਚ ਛ	ਲ ਲ਼	ਸ ਸ਼

TAMIL

Q	W	E	R	T	Y	U	I	O	P
ௌ ஔ ஃ க	ை ஐ உ	ா ஆ ங	ீ ஈ ச	ூ ஊ ரு	ச ஷ க்ஷ ஷ்ர கூ	ஹ ங எ ஞ	ட அ	ொ ஒ கு	ஜ 0

A	S	D	F	G	H	J	K	L
ோ ஓ	ே ஏ	்	ி இ	ு உ	ப	ர ற ய	க	த

Z	X	C	V	B	N	M
ெ எ	ீ	ம ண	ந ன	வ ழ	ல ள	ஸ ஶ

TELUGU

Q	W	E	R	T	Y	U	I	O	P
ౌ ఔ ౧	ై ఐ ౨	ా ఆ ౩	ి ఈ ి ౪	ా ఊ ౫	బ భ ౬	హ జ ౭	గ ఘ జ్ఞ ౮	ద ధ డ ఢ ౯	జ ఝ ట ఠ ౦

A	S	D	F	G	H	J	K	L
ో ీ బ ఓ	ే ఏ	్ అ ః	ి ఇ	ు ఉ ఋ ృ	ప ఫ	ర ఱ ్ర	క ఖ చ ఛ	త థ త్ర

Z	X	C	V	B	N	M
ె ఎ	ం ఁ	మ ణ య	న ఞ	వ	ల ళ క్ష	స శ శ్ర ష

Music

MP3 Player

Your LG-C375 has a built-in music player so you can play all your favourite music.

Note:

- Before using music player, you will need to transfer music file onto your phone.
- Music player supports codec types as follows: MP3, WMA, AAC. Music player does not necessarily support all features and variations of file formats.

To access the music player, press **Menu** and select **Music** and select **MP3 player**. From here you can access to:

Recently played - View all of the songs you have played recently.

All songs - Contains all of the songs you have on your phone.

Artists - Allows you to view all tracks sorted by artist.

Albums - Allows you to view all tracks sorted by album.

Genres - Allows you to view all tracks sorted by genre.

Playlists - Contains all playlists you have created.

Shuffle all songs - Allows you to play all of the songs in random order.

Transferring music onto your phone

The easiest way to transfer music onto your phone is via Bluetooth or sync cable.
To transfer music using Bluetooth:

1. Make sure both devices have Bluetooth switched on and are visible to one another.
2. Select the music file on the other device and choose to send it via Bluetooth.
3. When the file is sent you should to accept it on your phone by selecting **Yes**.
4. The file should appear in **All songs**.

Music

Playing a song

1 Press **Menu** and select **Music**, then choose **MP3 player**.

2 Choose **All songs** then select the song you want to play. Select ▬.

3 Select ▬ to pause the song.

4 Select ▶▶| to skip to the next song.

5 Select |◀◀ to skip to the previous song.

TIP! To change the volume while listening to music, use the volume keys on the left hand side of your phone.

Note:
The copyright of music files can be protected in international treaties and national copyright laws. Therefore, it may be necessary to obtain a permission or a license to reproduce or copy music. In some countries national law prohibits private copying of copyrighted material. Before downloading or copying the file, please check the national legislation of the applicable country concerning the use of such material.

Using options while playing music

Select **Options** and choose from:

Minimize - Hide the music player screen so that you can continue using your phone as normal while music is playing.

Repeat - You can listen the music repeated.

Shuffle - Play your tracks in a random order.

Equalizer - You can view Equalizer on the screen.

Add to playlist - Adds the current track to a playlist.

Set as - Use the song as **Ringtone, Message**.

Send via - Send the song as a **Message, Email** or via **Bluetooth**.

File info. - You can view information about the music file you are listening to.

FM Radio

Using the FM radio

Your LG-C375 supports Wireless **FM radio** feature so you can tune into your favorite stations and listen on the move.

> **Note:** If you are in an area with bad radio reception, you may have difficulty listening to the radio. You will need to insert your headphones in order to listen to the radio. Insert them into the headphone socket.

Listening to the radio

1 Press **Menu**, select **Music** and choose **FM radio**.

2 Select the channel number of the station you would like to listen to.

Searching for stations

You can tune your phone to radio stations by searching for them either manually or automatically. They will then be saved to specific channel numbers, so you don‘t have to keep re-tuning

To auto tune:

1 Press **Menu** and select **Music**.

2 Select **FM radio** choose **Options**.

3 Select **Auto-scan**. A confirmation message appears. Press Ok key for Select, then the stations will be automatically found and allocated to a channel in your phone.

> **Note:** You can also manually tune into a station by using (and) displayed in the centre of the screen.

Recording the Radio

1 Press **Rec.** during listening to the radio.

2 The recording time is displayed on your phone.

If you want to stop the recording, press Stop. If recording is done, the recorded contents will be saved in My stuff -> Sounds as mp3 file.

Pre-Recording the Radio

1 Press Options and select Recording settings.

2 Choose Before 3/10/30 sec on Pre-recording tap.

> **Note:** This feature has some exceptions.

E-Mail

Sending an email using your new account

To send/receive an email, you should set up an email account.

1 Press **Menu**, select **E-Mail** and choose the account you want to use.

2 From Options choose **Write e-mail** and a new email window will open.

3 Enter address in To field then Write a subject line and press down navigation key.

4 Enter your message using the keypad then Press Ok to send the email.

Retrieving your email

1 Press **Menu** and select **E-mail**.

2 Select the account you want to use.

3 Select **Inbox.**

4 Choose **Refresh** and the phone will connect to your email account and retrieve your new messages.

Message folders

Press **Menu** and select **E-mail**. The folder structure used on your LG-C375 should be self-explanatory.

Write e-mail - Create your new message.

Mailboxes

Inbox - All the e-mails you receive are placed into your **Inbox**. From here you can reply, forward and more.

Drafts - If you don't have time to finish writing a e-mail, you can save what you have written so far in here.

Outbox - This is a temporary storage folder while e-mail are being sent or stores the messages that are failed to sent.

Sent - Copies of all the e-mail you send are kept into your Sent folder.

Phone Trash - All the e-mail you remove are placed into your Phone Trash.

Changing your email settings

1 Press **Menu**, choose **E-mail** > **Options** > **Mailboxes** > **Accounts**.

2 Select the account you want to use.

3 Select Options then settings from options then you can adapt the following settings:

Accounts - You can edit e-mail account settings.

Frequency - Choose how often your LG-C375 checks for new email messages.

Schedule - Choose the time period during when the Push Email will be active.

Notification - Choose whether or not to be alerted to new emails.

Default Account - Choose which account to compose e-mail by default.

Signature - Create an email signature and switch this feature on.

Phonebook

Searching for a contact

1 Press **Menu** and select **Phonebook**.

2 Using the keypad enter the first letter of the name of the contact you want to call.

3 To scroll through the contacts and their different numbers use the navigation keys.

Or, using the slightly quicker method…

1 Enter the number you wish to search on the home screen and select **Options**.

2 Choose **Search contacts** in option menu.

Adding a new contact

1 Press **Menu** and select **Phonebook**.

2 Press **Option** and select **New contact**.

3 Enter the information you want in the fields provided and select **Done**.

Contact options

There are many things you can do when viewing a contact. Here's how to access and use the options menu.

1 Press **Menu** and select **Phonebook**.

2 Select **Options** to open the list of options. From here you can:

Send message - Send a message to the contact.

Call by - Directly make voice call from SIM1 / SIM2 to a contact you choose.

Edit - Change any of the contact's details.

Delete - Delete the contact. Select **Yes** only if you are sure.

New contact - Add a new contact.

Storage location - Choose to move or copy to the phone or SIM card (depending on where you originally saved the contact).

Send contact - Send the contact's details to another person as a business card. Choose to send as a **Text message**, **MMS**, **E-mail** or via **Bluetooth**.

Selection Mode - Choose whether to mark a contact or unmark.

Speed dials - You can assign a frequently-called contact to a speed dial number.

Sort by - Sort a contact by **ABC↑** or **ABC↓**.

Creating a group

1 Press **Menu** and select **Phonebook**.

2 Select **Groups** and choose **Options**.

3 Select **New group**.

4 Enter a name for your new group.

5 Press **Done**.

Note: If you delete a group, the contacts which were assigned to that group will not be lost. They will remain in your contacts.

Changing your contact settings

1 Press **Menu** and select **Phonebook**.

2 Select **Option** and choose **Settings**. From here you can adjust the following settings:

Display name - You can select to show the **First name first** or **Last name first** or **Last name, First name**.

Main store and view - Choose whether to store contacts **SIM1** or **SIM2** or **Handset**. And also choose whether to view contacts saved to **Both handset & SIM, Handset only** or **SIM1 only** or **SIM2 only.**

Copy all - Copy your all contacts from your **SIM1** or **SIM2** to your handset or from your handset to your **SIM1** or **SIM2** or from **SIM1** to **SIM2** or from **SIM2** to **SIM1**.

Move all - This works in the same way as **Copy all**, but the contact will only be saved to the location you've moved. If you move a contact from the SIM card to the handset it will be deleted from the SIM card memory.

Phonebook

Export contacts - You can save all the phonebook data in the handset to an external memory card by the form of vcard.

Import contacts - You can restore all the phonebook data in an external memory card to the phone memory by the form of vcard.

Send all contacts via Bluetooth - Send all contacts information to another handset by Bluetooth.

Tools

Quick menu

Press Add and choose the menu you want to quickly approach.

Organiser

You can access Calendar, Tasks, Memo and Calculate date to get the Target Date.

> **Tips:** User can schedule an SMS, so that it can be sent to the pre defined number on Set date and Set time. From Menu > Tools > Organiser > Calendar > Options > Choose New Schedule SMS to save a scheduler SMS.

Alarm clock

You can set up to 5 alarm clocks to go on at a specified time.

Calculator

1 Press the numeric keys to input numbers.

2 For simple calculations, select the function you require (+, –, ×, ÷) using the navigation keys followed by =.

3 For more complex calculations, select **Options** to choose a command.

4 Select – to clear the screen and start a new calculation.

Voice recorder

Use your **Voice recorder** to record voice memos or other sounds. Once you have finished recording, select Options for playing, sending etc.

Recording your voice memo

1 Press **Rec.** to begin recording.

2 Choose **Stop** to end the recording.

3 Press **Options** and select **Play** to listen to the recording.

Using the stopwatch

1 Select **Start** to begin the timer.

2 Choose **Lap** if want to record a lap time. Up to 99 lap times can be saved.

3 Select **Stop** to end the timer.

4 Choose **Resume** to restart the stopwatch at the time you stopped it at or select **Reset** to return to zero.

Tools

Converting a unit

Choose whether you would like to convert **Currency**, **Area**, **Length**, **Weight**, **Temperature**, **Volume** or **Velocity**.

> **Note:** For **Currency** convert, you need to set **Rate** according to current exchange rate first.

Adding a city to your World clock

1 Press Menu and select Tools, then choose World clock.

2 To add or find out the time of specific city, press Options and select New city.

LED Banner

Select different colors to use as an Indicator.

Settings

Dual SIM

You can select the default SIM card for call or message in Contact, Call logs and Message box.

Profiles

Choose the profile you want to edit.

Using flight mode - Flight mode will not allow you to make calls, connect to the internet or send message.

Device

Choose from the list below.

Date and time - Select Auto update On, and the phone will automatically update the date and time.

Battery status - Choose to switch the factory set power save settings On or Off.

Languages - Change the language of for your LG-C375's display.

Auto key lock - Lock the keypad automatically in standby screen.

Security - Change your security to keep your LG-C375 and the important information it holds protected.

- **Anti-theft mobile tracker** - When the handset is stolen, handset sends the SMS to the numbers configured by real Owner. To activate the ATMT feature, you will need to set ATMT on, and configure the ATMT settings with Owner name and Alternate numbers. Default ATMT Code is "0000".
- **Application lock** - To prevent unauthorized use of phone applications, you can enable application lock which requires user to enter a password when accessing applications. Password is the same as the security code (Default password is 0000).

SOS service

- **SOS service** - This enables SOS service. After enabling if you press long key of 9 in Idle screen, the SOS message is sent and the phone stays in SOS Mode.
- **Message** - In the emergency situation, press and hold '9' to change to SOS mode. In SOS mode, SOS message will be sent to the assigned receivers and incoming calls by them will be automatically accepted. All notification sound will be muted. To exit the SOS mode, press the End key in Homescreen.

- **Recipient list** - The list of recipients to whom SOS Message is sent and during SOS Mode, the phone will accept calls from these numbers only.
- **Help** - Further details about SOS Mode are mentioned here.

Memory info - Your LG-C375 has three memories available: the phone, the SIM card and an external memory card (you may need to purchase the memory card separately). You can use the memory manager to determine how each memory is used and see how much space is available.

Primary storage setting - If you insert an external memory card in your phone, you can also select Primary storage settings then choose the default location you prefer items to be saved to.

Reset device - Reset all the settings to the factory definitions. You need the security code to activate this function.

Device info - View the technical information for your LG-C375.

Display

Choose from the list below.

Homescreen - Adjust the **Wallpaper, Widget settings** and **Key assignments**.

Menu theme - Quickly change the whole look of your screen.

Menu style - Change the menu view from **List style** or **Grid style**.

Font - Adjust the font size.

Backlight - Choose how long the backlight remains on. Also, use the navigation keys to adjust the main screen brightness.

> **TIP!** The longer the backlight is on, the more battery power is used and you may need to charge your phone more often.

Greeting message - After selecting **On**, you can write a welcome message. The message will appear on screen whenever you start-up the phone.

Other screens - Choose the image for start up/shut down screen.

Call

Select **SIM1** or **SIM2**.

From here you can amend the settings for:

Call divert - Choose whether to divert your calls.

- Choose whether to divert all voice calls, when the line is busy, when there is no answer and when you are out of reach.
- Enter your divert number or select Search to browse for your divert number.

Note: Charges are incurred for diverting calls. Please contact your network provider for details.

> **TIP!** To turn off all call diverts, choose Call divert from calling menu then select Options then select Deactivate all.

Call barring - Select which calls you would like to be barred.

- Choose any or all of the options:
  All outgoing calls
  Outgoing international
  Outgoing international calls
  Incoming calls
  Incoming when abroad
- Enter the call barring password. Please check with your network operator for this service.

Call waiting - Be alerted when you have a call waiting.

Fixed dial numbers - Choose a list of numbers that can be called from your phone. You'll need your PIN2 code from your operator. When activated, only numbers included in the fixed dial list can be called from your phone.

Call reject settings - This menu shows you the phone numbers of person you have chosen to reject. you can add the new number using add button. The incoming calls received from the Call rejection list numbers will be automatically rejected. In call log, rejected icon would be shown for such calls.

> **Note:** To Open Call reject settings,it requires a password and the default password is "0000".

Send my number - Choose whether your number will be displayed when you call someone. (Depends on your network provider.)

Auto redial - Allows you to set the auto redial function when a call attempt has failed.

Minute minder - Determines whether to sound a tone every 1 minute when you are in the call.

Save new number - Selecting this option 'on' will save numbers that are not already in your contacts upon ending the call.

Select **Common setting.**

From here you can amend the settings for:

Self call - Self call imitates a real incoming call. Press '#*#' on the home screen to make a self call. This doesn't charge any fee.

Pre-recording - You can record the voice in call from some seconds before press the record button.

Excuse message - Before you reject an incoming call, you can use "Excuse messages" to send a message to explain why you do not receive an incoming call.

Bluetooth answer mode - Choose how to answer a call when using a Bluetooth headset. Select **Hands-free** or **Handset**.

Connectivity

Bluetooth

Set up your LG-C375 for Bluetooth use. You can adapt your visibility to other devices or search through devices your phone is paired with.

Choose **Bluetooth** then **Settings.**

Make your changes to:

My device visibility - Set Visible or **Visible for 1** min so that other devices can detect your phone when they are searching for a Bluetooth device. If you select **Hidden**, other devices will not be able to detect your phone when they are searching for a Bluetooth device.

My device name - You can name or rename your phone as it will appear on other devices. Your phone's name will be shown on other devices only when **My device visibility** is set to **Visible**.

Supported services - You can view the list of devices such as headsets and handsfree supported by Bluetooth enabled phone.

My address - Check your Bluetooth address here.

Pairing with another Bluetooth device

By pairing your LG-C375 and another device, you can set up a passcode protected connection. This means your pairing is more secure.

1 Check your Bluetooth is **Activated** and **Visible**. You can change your visibility in the **Settings** of **Bluetooth** menu, by selecting My device visibility, then Visible.

2 From **Bluetooth**, choose **Activate Bluetooth** and select **Search new device**.

3 Your LG-C375 will search for devices. When the search is completed **Add** and **Refresh** will appear on screen.

4 Choose the device you want to pair with, select **Add** and enter a passcode then choose **OK**.

5 Your phone will then connect to the other device, on which you should enter the same passcode.

6 Your passcode protected Bluetooth connection is now ready.

Note:

1 Pair LG-C375 with any device supporting BT version above 2.0, then passcode is not asked, since passcode is auto generated.

2 Pair LG-C375 with any device supporting lesser BT versions such as 1.2 etc, then passcode is asked.

Sending and receiving your files using Bluetooth

Bluetooth is a great way to send and receive files as no wires are needed and connection is quick and easy. You can also connect to a Bluetooth headset to make and receive calls. Before you can start sharing files using Bluetooth, you will need to pair your phone with another Bluetooth device. For information on pairing devices, see **Pairing with another Bluetooth device.**

To switch Bluetooth on:

1 Press **Menu** and select **Settings**. Choose **Connectivity** then select **Bluetooth**.

2 Select **Activate Bluetooth**.

3 Select **Deactivate Bluetooth** to switch Bluetooth off.

To send a file:

1 Open the file you want to send, typically this will be a photo, video or music file.

2 Select **Options** and choose **Send via**, then select Bluetooth.

3 Select **Yes** to turn Bluetooth on if it is not already activated.

4 If you have already paired the Bluetooth device, your LG-C375 will not automatically search for other Bluetooth devices. If not, your LG-C375 will search for other Bluetooth enabled devices within range.

5 Choose the device you want to send the file to and select **OK**.

To receive a file:

1 To receive files, your Bluetooth must be **Activated** and **Visible**.

2 A message will prompt you to accept the file from the sender. Select **Yes** to receive the file.

TIP! Keep an eye on the progress bar to make sure your file is sent.

TIP! The Bluetooth® word mark and logos are owned by the Bluetooth SIG, Inc. and any use of such marks by LG Electronics is under licence. Other trademarks and trade names are those of their respective owners.

TIP!

1 When you use a Bluetooth headset, A2DP and AVRCP profiles are not supported while you play video. It means you cannot listen video sound and cannot control video player using Bluetooth headset.

2 Bluetooth file transferring function will be blocked under some applications running. (Camera/Camcorder, MusicPlayer, Video player, UMS/PCSync)

USB connection mode - You can select the USB connection mode on your phone for several uses.

Data network SIM - To access network, you can select the default SIM card.

Wi-Fi

Wireless Manager allows you to manage Internet connections via Wi-Fi (Wireless LAN) on your device.

It allows the phone to connect to local wireless networks or access the Internet wirelessly. Wi-Fi is faster and has a greater range than Bluetooth wireless technology and can be used for fast emailing and Internet browsing.

NOTE: The LG-C375 supports WEP and WPA-PSK/2 encryption, but not EAP or WPS encryption. If your Wi- Fi service provider or network administrator sets encryption for network security, fill in the key in the pop-up window. If encryption is not set, this popup window will not be shown. You can obtain the key from your Wi-Fi service provider or network administrator.

Phone Software update

LG Mobile Phone Software update from internet

For more information on using this function, please visit the http://update.lgmobile.com or http://www.lg.com/common/index.jsp → select country.

This Feature allows you to update the Software of your phone to the latest version conveniently from the internet without the need to visit a service centre.

As the mobile phone Software update requires the user's full attention for the duration of the update process, please make sure to check all instructions and notes that appear at each step before proceeding. Please note that removing the USB data cable or battery during the upgrade may seriously damage your mobile phone.

Synchronise your phone with your PC

You can synchronise your phone with your PC to make sure all your important details and dates match, but also to backup your files to put your mind at ease.

Backing up and restoring your phone's information

1 Connect the USB cable to your phone and your PC.

2 Select the PC suite from the popup menu in your phone and run PC Suite Program in your PC.

3 Click the "Phone Backup & Restore" in PC suite (Tools > Phone Backup & Restore), and select Backup or Restore.

4 Mark the contents you would like to back up or restore. Select the location you would like to backup information to, or restore information from. Now select Backup or Restore and Click Finish.

5 Your information will be Backed up or Restored.

NOTE: Install PC Suite using CD provided and follow the Installation Guide.

Viewing your phone files on your PC

1 Connect the USB cable to your phone and your PC.

2 Select the PC suite from the popup menu in your phone and run PC Suite Program in your PC.

3 Open LG PC Suite icon in your PC which is already installed, after searching the phone it will be connected automatically.

TIP! Viewing the contents of your phone on your PC helps you to arrange files, organise documents and remove contents you no longer need.

Accessories

Various accessories are available for your mobile phone. These are detailed below.

Charger

Battery

Data cable

User Guide

Stereo headset

CD

NOTE

- Always use genuine LG accessories.
- Failure to do so may invalidate your warranty.
- Accessories may be different in different regions. Please check with our regional service company or agent for further enquires.

Technical Data

Ambient Temperatures

Max.: +55°C (discharging) +45°C (charging)

Min.: -10°C

Declaration of Conformity

LG Electronics

Suppliers Details

Name

LG Electronics Inc

Address

LG Twin Tower 20,Yeouido-dong, Yeongdeungpo-gu Seoul, Korea 150-721

Product Details

Product Name

GSM 850 / E-GSM 900 / DCS 1800 / PCS 1900 Quad Band Terminal Equipment

Model Name

LG-C375

Trade Name

LG

CE 0168

Applicable Standards Details

R&TTE Directive 1999/5/EC

EN 301 489-01 V1.8.1, EN 301 489-07 V1.3.1, EN 301 489-17 V2.1.1
EN 301 511 V9.0.2
EN 50360:2001/AC:2006, EN 62209-1:2006, EN 62209-2:2010
EN 60950-1:2006+A11:2009
EN300328 V1.7.1

Supplementary Information

The conformity to above standards is verified by the following Notified Body(BABT)

BABT, Forsyth House-Churchfield Road - Walton-on-ThamesSurrey - KT12 2TD , United Kingdom

Notified Body Identification Number : 0168

Declaration

I hereby declare under our sole responsibility that the product mentioned above to which this declaration relates complies with the above mentioned standards, regulation and directives

LG Electronics Inc. – EU Representative
Veluwezoom 15, 1327 AE Almere, The Netherlands

Name	Issued Date
Doo Haeng Lee / Director	18. May. 2011

Signature of representative

Troubleshooting

This section lists some problems that you might encounter while using your phone. Some problems require that you call your service provider, but most of problems you encounter are easy to correct yourself.

Symptom	Possible causes	Possible Corrective measures
No connection to the network	Signal is weak or you're outside of the carrier network.	Move to a window or open space. Check service provider coverage map.
Codes do not match	When you want to change a security code you have to confirm the new code by entering it again. The two codes that you have entered do not match.	Contact your Service Provider.
Function cannot be set	Not supported by Service Provider or registration required.	Contact your Service Provider.
Calls not available	Dialing error or service limitations.	Check the number dialed and check the reception. Contact your service provider.
Calls not available	Dialing error New SIM card inserted Prepaid Charge limit reached	New network not authorized. Check for new restrictions. Contact Service Provider or reset limit with PIN 2.
Phone cannot be switched on	On/Off key pressed too briefly. Battery is not charged. Battery contacts are dirty.	Press On/Off key for at least two seconds. Charge battery. Check charging indicator in the display. Clean the battery contacts.

Troubleshooting

Symptom	Possible causes	Possible Corrective measures
Charging error	Battery totally empty.	Charge battery.
	Contact problem.	Check power supply and connection to the phone. Check the battery contacts, clean them if necessary.
	No power from outlet.	Plug in to a different socket or check voltage.
	Charger defective.	Test with another charger.
	Wrong charger.	Only use original LG accessories.
	Battery defective.	Replace battery.
Network connection is lost.	Signal too weak.	Reconnection to another service provider if network mode is automatic.
Number not permitted	The Fixed Dial Number function is on.	Check the Settings menu and turn the function off.

LG-C375 उपयोगकर्ता मार्गदर्शिका - हिन्दी

यह मार्गदर्शिका आपके नए मोबाइल फ़ोन को समझने में आपकी मदद करेगी.

यह आपको, आपके फ़ोन में दी गई सुविधाओं के बारे में उपयोगी स्पष्टीकरण प्रदान करेगी.

इस मैन्युअल की कुछ सामग्री आपके फ़ोन के सॉफ़्टवेयर या आपके सेवा प्रदाता के आधार पर आपके फ़ोन से अलग हो सकती है.

उत्पाद पंजीकरण प्रोग्राम

प्रिय एलजी मोबाइल ग्राहक,

आप इस मॅडल पर एक वर्ष की वारंटी के पात्र हैं ।स्वतः पंजीकरण के लिए, एक एसएमएस @रू.0.06p IMEI सहित आप के फोन से एलजी सर्वर पर भेजा जाएगा । इसके

बदले में आप को किसी भी अधिकृत एलजी मोबाइल सेवा केंद्र पर खरीद की तारीख से एक साल की वारंटी मिलेगी ।हम आपको विश्वास दिलाते हैं, की यह जानकारी गोपनीय रखी जाएगी और केवल आंतरीक उद्देश्य के लिए ही इस्तेमाल कि जायेगी ।

एलजी इलेक्ट्रॉनिक्स इंडिया प्राइवेट लिमिटेड का स्वतः पंजीकरण के एसएमएस से आय के लिए किसी भी सेल फोन ऑपरेटरों के साथ किसी भी प्रकार का राजस्व साझा नहीं है ।

सामग्रियाँ

सुरक्षित और प्रभावी उपयोग के लिए मार्गदर्शिकाएँ....4

अपने फ़ोन को जानना....10

सिम और बैटरी स्थापित करना....12

डुअल सिम–कार्ड का उपयोग करना...14

मेमोरी कार्ड....15

मेनू मैप....16

आपकी होम स्क्रीन....17

स्थिति पट्टी....17

कॉलिंग....18

कॉल करना....18

अपने संपर्कों में से कॉल करना....18

कॉल का उत्तर देना और कॉल रद्द करना....18

स्पीड डायलिंग....18

गेम्स और एप्लिकेशंस....20

गेम्स....20

सुविधायें....20

लॉग्स....20

सभी लॉग्स....20

केवल कॉल्स....20

केवल संदेश....20

छूटे हुए लॉग....20

जावक कॉल्स....20

आवक लॉग्स....20

कैमरा....21

कैमरा....21

वीडियो कैमरा....21

अल्बम....21

इंटरनेट....21

SNS (सामाजिक नेटवर्क सेवाएँ)....22

Facebook....22

Twitter....22

Orkut....22

Windows Live!....22

संदेश....23

संदेश....23

संदेश भेजना....23

पाठ दर्ज करना....23

कीमैपिंग तालिका....24

कीपैड का उपयोग करते हुए पाठ इनपुट मोड....25

अपने संदेशों को प्रबंधित करना....25

संदेश....26

संगीत....27

MP3 प्लेयर....27

FM रेडियो....29

ई–मेल....30

अपने नए खाते का उपयोग करते हुए ईमेल भेजना....30

अपने ईमेल की पुनः प्राप्ति....30

संदेश फ़ोल्डर....30

अपनी ईमेल सेटिंग्स बदलना....31

फोन पुस्तिका **32**
संपर्क के लिए खोजना 32
नया संपर्क जोड़ना 32
संपर्क विकल्प 32
समूह बनाना 33
अपनी संपर्क सेटिंग्स को बदलना 33

उपकरण **35**
त्वरित मेनू 35
आयोजक 35
अलार्म घड़ी 35
कैलकुलेटर 35
वॉइस रिकॉर्डर 35
स्टॉपवॉच का उपयोग करना 35
इकाई परिवर्तक 36
अपनी विश्व घड़ी में कोई शहर जोड़ना 36

सेटिंग्स **37**
डुअल सिम 37
प्रोफ़ाइल्स 37
यंत्र 37
प्रदर्शन 38
कॉल 39
संयोजकता 40
Wi-Fi 43
फ़ोन सॉफ़्टवेयर अपडेट 43
अपने फ़ोन को अपने PC के साथ सिंक्रनाइज़ करें 43
अपने फ़ोन की जानकारी बैकअप करना और पुनर्स्थापित करना 44
अपनी फ़ोन फ़ाइलों को अपने पीसी पर देखना. 44

सहायक उपकरण **45**

तकनीकी डेटा **46**

समस्या निवारण **47**

सुरक्षित और प्रभावी उपयोग के लिए मार्गदर्शिकाएँ

कृपया, इन सरल दिशानिर्देशों को पढ़ें. इन दिशानिर्देशों का पालन न करना खतरनाक या गैरकानूनी हो सकता है.

रेडियो फ्रीक्वेंसी ऊर्जा के संपर्क में आना

रेडियो तरंग एक्सपोज़र और स्पेसिफ़िक अब्ज़ार्पशन रेट (SAR) सूचना यह मोबाइल फ़ोन मॉडल LG–C375 रेडियो तरंगों के प्रति एक्सपोज़र के लिए लागू की जाने वाली सुरक्षा आवश्यकताओं का अनुपालन करने हेतु डिज़ाइन किया गया है.

ये उपाय वैज्ञानिक दिशानिर्देशों पर आघारित होते हैं जिनमें हर उम्र के व्यक्तियों की सुरक्षा सुनिश्चित करने के लिए डिज़ाइन किए गए सुरक्षात्मक तरीके शामिल होते हैं.

- रेडियो तरंग एक्सपोज़र दिशानिर्देश, विशिष्ट अवशोषण दर या SAR कहलाने वाली एक मापन इकाई का उपयोग करते हैं. फ़ोन पर SAR के परीक्षण मानक विधियों के उपयोग से किए जाते हैं, इसके लिए उपयोग होने वाले सभी फ्रीक्वेंसी बैंड्स में फ़ोन के उच्चतम प्रमाणित पॉवर स्तर पर संप्रेषण किया जाता है.
- वैसे तो विभिन्न LG फ़ोन मॉडल के SAR स्तर में भिन्नता हो सकती है, किंतु उन सभी को रेडियो तरंगों के प्रति एक्सपोज़र के लिए संबद्ध दिशानिर्देशों को पूरा करने के लिए बनाया गया है.
- नॉन–आयोनाइज़िंग रेडिएशन प्रोटेक्शन (ICNIRP) के लिए अंतररा ट्रीय आयोग द्वारा अनुशंसित SAR सीमा 10ग्रा टिश्यू पर औसतन 2 वॉटधकिग्रा होती है.
- DASY4 द्वारा जांचे गए इस मॉडल फ़ोन का सबसे उच्च SAR मान सीधे कान पर उपयोग के लिए 1.25 वॉट/किग्रा (10ग्रा) है और शरीर के अन्य भाग में रखने पर 1.28 वॉटधकिग्रा (10ग्रा) है.
- जिन देशोंध्क्षेत्रों ने इंस्टीट्यूट ऑफ इलेक्ट्रिकल एंड इलेक्ट्रॉनिक्स इंजीनियर्स (IEEE) द्वारा अनुशंसित SAR सीमा को स्वीकार किया है, वहाँ के निवासियों के लिए SAR डेटा जानकारी 1ग्रा टिश्यू पर औसतन 1.6 वॉटधकिग्रा है.

उत्पाद की देखभाल और रखरखाव

⚠ **चेतावनी**: इस विशेष फ़ोन मॉडल के साथ उपयोग करने के लिए केवल स्वीकृत बैटरियों, चार्जर्स और सहायक उपकरणों का ही उपयोग करें. किसी भी दूसरे प्रकार का उपयोग करने पर फ़ोन पर लागू होने वाले अनुमोदन या वॉरंटी अमान्य हो सकते हैं और यह खतरनाक हो सकता है.

- इस यूनिट को डिसअसेंबल न करें. सुधारने की आवश्यकता होने पर इसे योग्य सेवा तकनीशियन के पास ले जाएँ.
- बिजली के उपकरणों जैसे टीवी, रेडियो और पर्सनल कंप्यूटर से दूर रखें.
- यूनिट को गर्म स्रोतों जैसे रेडिएटर्स या कुकर से दूर रखना चाहिए.
- इसे गिराएँ नहीं.
- यूनिट को मैकेनिकल कंपन या झटकों से बचाएँ.
- जिस किसी भी क्षेत्र में विशेष नियम के तहत आवश्यक हो, वहाँ फ़ोन बंद कर दें. उदाहरण के लिए, अपने फ़ोन का उपयोग अस्पतालों में न करें, क्योंकि यह संवेदनशील मेडिकल उपकरणों को प्रभावित कर सकता है.
- चार्ज होते समय फ़ोन को गीले हाथों से न पकड़ें. इससे बिजली का झटका लग सकता है और आपके फ़ोन को गंभीर रूप से क्षति हो सकती है.
- हैंडसेट को ज्वलनशील सामग्री के पास चार्ज न करें, क्योंकि हैंडसेट गर्म होकर आग का कारण बन सकता है.
- यूनिट को बाहर से साफ़ करने के लिए सूखे कपड़े का उपयोग करें (बेंजीन, थिनर, या एल्कोहल जैसे विलायकों का उपयोग न करें).
- फ़ोन को हल्के साज–सामान पर रख कर चार्ज न करें.
- फ़ोन अच्छे हवादार क्षेत्र में चार्ज किया जाना चाहिए.
- इस यूनिट को अत्यधिक धुएं या धूल में न रखें.
- फ़ोन को क्रेडिट कार्ड्स या ट्रांसपोर्ट टिकटों के पास न रखेंय यह चुंबकीय पट्टियों पर अंकित जानकारी को प्रभावित कर सकता है. स्क्रीन को नुकीली वस्तु से न ठकठकाएँ, क्योंकि इससे फ़ोन को नुकसान हो सकता है.
- फ़ोन को तरल पदार्थ या नमी में न रखें.
- सहायक उपकरण जैसे ईयरफ़ोन का सावधानीपूर्वक उपयोग करें.
- एंटीना को अनावश्यक रूप से न छुएँ.
- अपने डिवाइस को लंबे समय तक आपके शरीर के कोई भी भाग के साथ सीधे संपर्क में उपयोग न करें. सामान्य स्थितियों में, उत्पाद के तापमान बढ सकती है, जो आपके त्वचा को हानि या झुलस उत्पन्न कर सकता है.

सुरक्षित और प्रभावी उपयोग के लिए मार्गदर्शिकाएँ

कार्यकुशल फ़ोन कार्रवाई

इलेक्ट्रॉनिक्स डिवाइस

सभी मोबाइल फ़ोनों में व्यवधान आ सकता है, जो कार्यक्षमता को प्रभावित कर सकता है.

- बिना अनुमति लिए अपने मोबाइल फ़ोन का उपयोग मेडिकल उपकरण के पास न करें. फ़ोन को पेसमेकर के ऊपर रखने से बचें, जैसे कि, ऊपरी जेब में.
- मोबाइल फ़ोन द्वारा कुछ श्रवण सुविध ाएँ बाधित हो सकती हैं.
- छोटा–सा व्यवधान भी टीवी, रेडियो, पीसी इत्यादि को प्रभावित कर सकता है.

सड़क सुरक्षा

जिन क्षेत्रों में आप वाहन चलाते हैं, वहाँ मोबाइल फ़ोन के उपयोग से संबंधित कानूनों और विनियमों को जाँच लें.

- वाहन चलाते समय हैंड–हेल्ड फ़ोन का उपयोग न करें.
- वाहन चलाने पर पूरा ध्यान दें.
- यदि उपलब्ध हो, तो हैंड्स–फ्री किट का उपयोग करें.
- यदि वाहन चलाते समय आवश्यक हो, तो कॉल करने या उत्तर देने से पहले वाहन को सड़क के किनारे लगाएँ.
- RF ऊर्जा आपके वाहन के कुछ इलेक्ट्रॉनिक सिस्टम्स जैसे कार स्टीरियो और सुरक्षा उपकरण को प्रभावित कर सकती है.
- जब आपके वाहन में एयर बैग की सुविधा हो, तो लगे हुए या पोर्टेबल वायरलेस उपकरण से व्यवधान न डालें. इससे एयर बैग विफल हो सकता है या अनुपयुक्त कार्य के चलते गंभीर चोट पहुँचा सकता है.
- यदि आप यात्रा के समय संगीत सुन रहे हैं, तो कृपया सुनिश्चित करें कि वॉल्यूम उचित स्तर पर रहे, जिससे आप अपने चारों ओर के वातावरण के प्रति सचेत रहें. यह तब विशेष रूप से ज़रूरी है, जब आप रास्ते में हों.

अपने सुनने की क्षति से बचें

यदि आप लंबे समय तक तेज ध्वनि सुनते हैं तो आपकी सुनने की क्षमता को क्षति पहुंच सकती है. इसलिए हम सलाह देते हैं कि आप अपना हैंडसेट कान के पास चालू या बंद न करें. हम इसकी भी सलाह देते हैं कि संगीत और कॉल वॉल्यूम उचित स्तर पर सेट हों.

विस्फ़ोटन क्षेत्र

फ़ोन का उपयोग ऐसे स्थान पर न करें, जहाँ विस्फ़ोट हो रहे हों. प्रतिबंधों पर ध्यान दें और विनियमों या नियमों का पालन करें.

संभावित रूप से विस्फ़ोट वाले वातावरण

- फ़ोन का उपयोग ईंधन भरने के स्थान पर न करें.
- ईंधन या रसायनों के पास उपयोग न करें.
- मोबाइल फ़ोन और सहायक उपकरण ों को ज्वलनशील गैस, तरल या विस्फ़ोटकों के साथ अपने वाहन में न ले जाएँ या न ही रखें.

विमान में

वायरलेस डिवाइसेज़ से एयरक्रॉफ्ट में व्यवधान उत्पन्न हो सकता है.

- किसी भी विमान में चढ़ते समय अपना मोबाइल फ़ोन बंद कर दें.
- इसका उपयोग विमान में कर्मीदल की अनुमति के बिना न करें.

बच्चे

फ़ोन को छोटे बच्चों की पहुँच से दूर किसी सुरक्षित स्थान पर रखें. इसमें छोटे–छोटे भाग होते हैं जो यदि अलग हो जाएँ तो गले में फँस सकते हैं.

आपातकालीन कॉल्स

संभव है कि आपातकालीन कॉल्स सभी मोबाइल नेटवर्क्स के तहत उपलब्ध न हों. इसलिए, आपको आपातकालीन कॉल्स के लिए केवल फ़ोन पर ही निर्भर नहीं रहना चाहिए. अपने स्थानीय सेवा प्रदाता से इसकी जानकारी लें.

बैटरी जानकारी और देखभाल

- बैटरी रिचार्ज करने के पहले आपको उसे पूरी तरह डिस्चार्ज करने की आवश्यकता नहीं है. अन्य बैटरी सिस्टम्स के विपरीत, ऐसा कोई मेमोरी प्रभाव नहीं है जिससे बैटरी के प्रदर्शन पर असर पड़ता है.
- केवल LG बैटरियों और चार्जर्स का उपयोग करें. LG चार्जर्स, बैटरी की आयु अधिकतम सीमा तक बढ़ाने के लिए डिज़ाइन किए गए हैं.
- बैटरी पैक को डिसअसेंबल न करें या उसे शॉर्ट–सर्किट से बचाएँ.
- बैटरी पैक के धातु वाले हिस्सों को साफ़ रखें.
- बैटरी का प्रदर्शन अपेक्षानुसार न रहने पर उसे बदल दें. बैटरी पैक को सैकड़ों बार रीचार्ज किया जा सकता है, जब तक कि उसे बदलने की आवश्यकता न हो.

सुरक्षित और प्रभावी उपयोग के लिए मार्गदर्शिकाएँ

- यदि बैटरी को लंबे समय से प्रयोग नहीं किया गया है,तो इसकी उपयोगिता को अधिकतम बढ़ाने के लिए इसे रीचार्ज करें.
- बैटरी चार्जर को सीधे धूप में न रखें या बाथरूम जैसी अधिक नमी वाली जगहों पर इसका उपयोग न करें.
- बैटरी को गर्म या ठंडे स्थानों पर न रखें, इससे बैटरी के प्रदर्शन पर बुरा असर हो सकता है.
- यदि बैटरी को किसी गलत प्रकार की बैटरी से बदला जाता है तो विस्फ़ोट का खतरा होता है.
- उपयोग की गई बैटरियों का निपटान, निर्माता के निर्देशों के अनुसार ही करें. जब भी संभव हो इसे रीसायकल करें. इसे घरेलू कचरे की तरह न फेंकें.
- यदि आपको बैटरी बदलने की आवश्यकता हो, तो सहायता के लिए इसे निकटतम अधिकृत LG Electronics सर्विस पॉइंट या डीलर के पास ले जाएं.
- फ़ोन पूरी तरह चार्ज हो जाने पर चार्जर को वॉल सॉकेट से निकाल दें ताकि चार्जर की अनावश्यक पॉवर खपत को बचाया जा सके.
- वास्तविक बैटरी जीवन, नेटवर्क कॉन्फ़िगरेशन, उत्पाद सेटिंग्स, उपयोग पद्धति, बैटरी और वातावरण की परिस्थितियों पर निर्भर करेगा.

अपने पुराने उपकरण का निपटान

1 जब यह पहिये वाले क्रॉस बिन का चिन्ह किसी उत्पाद के साथ संलग्न होता हैं तो इसका अर्थ है उत्पाद ई–वेस्ट (प्रबंधन और हैंडलिंग) नियम 2011 के अन्तर्गत आता है ।

2 सभी इलेक्ट्रीकल और इलेक्ट्रॉनिक उत्पादों को सरकार या स्थानीय अधिकारियों के द्वारा नियुक्त नगरपालिका अपशिष्ट धारा से अलग प्रधिकृत की गई संग्रह सुविधाओं के माध्यम से नष्ट किया जाना चाहिए ।

3 सही तरीके से अपने पुराने उपकरणों का निपटान, वातावरण और मानवीय स्वास्थ्य के लिए संभावित ऋणात्मक परिणामों को रोकने में मदद करेगा ।

4 अपने पुराने उपकरणों के निपटान के संबध में और अधिक विस्तृत जानकारी के लिए, कृपया अपने नगर कार्यालय, अपशिष्ट निपटान सेवा या जहां से आपने उत्पाद खरीदा था, वहां संपर्क करें ।

5 इस उत्पाद में ई–वेस्ट (प्रबंधन और हैंडलिंग) नियम, 2011 नियम 13(1) और 13(2) में निर्दिष्ट अनुसार कोई भी हानिकारक पदार्थ शामिल नहीं हैं।

अपने फ़ोन को जानना

इयरपीस

भेजें कुंजी

- फ़ोन नंबर डायल करती है और कॉल का उत्तर देती है.
- **स्टैंडबाय मोड में**: कॉल्स का इतिहास दिखाती है.

अल्फ़ान्यूमेरिक कुंजियाँ

- **स्टैंडबाय मोड में**: डायल करने के लिए नंबर इनपुट करें नीचे की कुंजियाँ दबाकर रखें.

  0 – अंतर्राष्ट्रीय कॉल्स करने के लिए '+' चिह्न डालें.

  1 – वॉइस मेल केंद्र से कनेक्ट करें.

  2 इन्हें 9 – स्पीड डायल्स.

  9 – SOS मोड.

  SYM – शांत मोड सक्रिय या निष्क्रिय करने के लिए कुंजी को दबाकर रखें.

  संपादन मोड में: नंबर और वर्ण दर्ज करें

संदेश ब्लिंकर

- यदि आप नया IM, ईमेल, संदेश और छूटी कॉल नहीं जाँचते हैं तो यह LED 10 मिनट तक फ्लैश करता है.

सॉफ़्ट कुंजियाँ (बाईं सॉफ़्ट कुंजी / दाईं सॉफ़्ट कुंजी)

- ये कुंजियाँ डिसप्ले के नीचे इंगित किया गया फ़ंक्शन पूरा करती हैं.

मुख्य LCD

समाप्त करें कुंजी

- स्विच चालू/बंद (दबाकर रखें)
- किसी कॉल को समाप्त या अस्वीकार करें.

पुष्टि कुंजी / ठीक कुंजी

- मेनू विकल्प का चयन करता है और क्रियाओं को नियत करता है.

लॉक कुंजी

- किपेड को लॉक करने के लिए देर तक दबाएँ।
- किपेड को अनलॉक करने के लिए लॉक स्क्रिन में देर तक दबाएँ।

नेविगेशन कुंजी

- **स्टैंडबाय मोड में**:

ऊपरी नेवीगेशन कुंजी दबाएँ: विजेट जब यह सेट किया गया था.
(मेनू > सेटिंग्स > प्रदर्शन > होमस्क्रीन > विजेट सेटिंग्स)

नीचे की नेवीगेशन कुंजी दबाएँ: मेरी चीजें

दाईं नेवीगेशन कुंजी दबाएँ: MP3 प्लेयर

बाईं नेवीगेशन कुंजी दबाएँ: कैमरा

- **मेनू में**: ऊपर, नीचे, दाएँ और बाएँ स्क्रॉल करें.

चार्जर/ USB केबल कनेक्टर

युक्ति: समूह संग्रहण के लिए USB केबल कनेक्ट करने से पहले कृपया सुनिश्चित करें कि फ़ोन चालू किया गया है.

किनारे की कुंजियाँ

- **स्टैंडबाय मोड में**: रिंग वॉल्यूम नियंत्रित करता है.
- **कॉल के दौरान**: ईयरपीस वॉल्यूम समायोजन.
- **MP3 संगीत चलाने के दौरान**: ऑडियो वॉल्यूम समायोजन.

सिम स्विच करने की कुंजी (सिम1 और सिम2 का चयन)

हेडसेट

मेमोरी कार्ड होल्डर

बैक कवर

कैमरा लेंस

सिम कार्ड होल्डर

बैटरी पैक

सिम और बैटरी स्थापित करना

1 **बैक कवर निकालें**
बैक कवर निकालने वाला लैच दबाएँ.

2 **बैटरी निकालें**
की ऊपरी सतह उठाएँ और उसे सावधानी से बैटरी कंपार्टमेंट से निकालें.

⚠ **चेतावनी**: जब फ़ोन चालू हो तब बैटरी न निकालें, क्योंकि इससे फ़ोन को क्षति हो सकती है.

3 **सिम कार्ड डालें**
सिम कार्ड को सिम कार्ड होल्डर में डालें. ध्यान रखें कि कार्ड का सुनहरा हिस्सा नीचे की ओर रहे. सिम कार्ड निकालने के लिए, उसे विपरीत तरफ़ धीरे से खींचें.

4 **बैटरी स्थापित करें पहले**
बैटरी स्थापित करें पहले बैटरी का निचले सिरे बैटरी कंपार्टमेंट के निचले किनारे में डालें. सुनिश्चित करें कि बैटरी के संपर्क फ़ोन के टर्मिनल से संरेखित हों. अब बैटरी का ऊपरी भाग दबाकर उसके स्थान पर लगाएँ.

5 बैक कवर लगाएँ

6 अपना फ़ोन चार्ज करना

अपना फ़ोन चार्ज करना आपके LG-C375 की दाईं ओर साइड में बने चार्जर सॉकेट के कवर को हटाएँ. चार्जर डालें और उसे बिजली के मुख्य सॉकेट में प्लग करें. आपके LG-C375 को तब तक चार्ज करने की आवश्यकता होगी जब तक कि स्क्रीन पर "बैटरी पूर्ण" का संदेश नहीं दिखाई देता.

डुअल सिम–कार्ड का उपयोग करना

जब आप दो सिम–कार्ड डालते हैं तो स्क्रीन के ऊपरी–बाएँ तरफ़ दो नेटवर्क सिग्नल आइकन देख सकते हैं.

सिम कार्ड्स सक्रिय और स्विच करना

स्टैंडबाय मोड में, सिम स्विच करने का कुंजी, आपको संपर्क, कॉल लॉग और संदेश बॉक्स में डिफ़ॉल्ट सिम कार्ड का चयन करने की अनुमति देती है.

उपयोगकर्ता LG-C375 के बाएं ओर आसानी के साथ सिम स्विच करने की कुंजी दबा सकते हैं. डुअल सिम कुंजी आपको कभी भी कॉल करते समय, संदेश भेजते समय और इसी तरह और भी कार्य करते समय सिम–कार्ड स्विच करना आसान बनाता है.

नोट: यदि केवल एक सिम कार्ड लगा है, तो यह सिम कार्ड डिफ़ॉल्ट रूप से सक्रिय हा जाएगा.

युक्ति! जब आप नेटवर्क सिग्नल स्विच करते हैं तो उन्हें पब्ठभूमि रंग से हाइलाइट किया गया देख सकते हैं. यह आपके चयनित सिम कार्ड की सिग्नल क्षमता की पहचान करना आसान बनाता है.

युक्ति! आपको किसी फ़ंक्शन का उपयोग करने के लिए सिम1 या सिम2 चुनने की आवश्यकता है. उदाहरण के लिए, कॉल, मैसेजिंग, फ़ोनबुक, सेटिंग्स.

मेमोरी कार्ड

मेमोरी कार्ड स्थापित करना

आप एक मेमोरी कार्ड का उपयोग करके अपने फ़ोन पर उपलब्ध मेमोरी स्थान बढ़ा सकते हैं.

नोट: मेमोरी कार्ड एक वैकल्पिक सहायक उपकरण है.

बैटरी कवर निकालें. चित्र में दिखाए गए के अनुसार मेमोरी कार्ड का गोल्ड संपर्क भाग निचे की तरफ़ कर उसे अंदर पुश करें । मेमोरी कार्ड निकालने के लिए, उसे धीरे से धकेलें ।

चेतावनी: बाहरी मेमोरी 8GB से अधिक नहीं हो सकती.

मेमोरी कार्ड स्वरूपित करना

हो सकता है आपका मेमोरी कार्ड पहले से स्वरूपित हो. यदि आपका मेमोरी कार्ड स्वरूपित नहीं है, तो उसका उपयोग प्रारंभ करने से पहले आपको उसे स्वरूपित करना होगा.

1 होम स्क्रीन से मेनू दबाएँ और फिर सेटिंग्स का चयन करें.

2 मेमोरी जानकारी चुनें. और बाह्य मेमोरी का चयन करें.

3 स्वरूपित करें दबाएँ और पासवर्ड दर्ज करें, जो डिफ़ॉल्ट रूप से 0000 पर सेट है. आपका मेमोरी कार्ड स्वरूपित और उपयोग के लिए तैयार हो जाएगा.

4 अपने LG-C375 पर नए स्वरूपित फ़ोल्डर्स देखने के लिए मेनू दबाएँ और मेरी चीजें का चयन करें. मेमोरी कार्ड चुनने के लिए दाईं नेविगेशन कुंजी को दो बार दबाएँ.

चेतावनी: जब आप अपने मेमोरी कार्ड का स्वरूपण करते हैं तो सभी सामग्री मिट जाएगी. यदि आप अपने मेमोरी कार्ड का डेटा खोना नही चाहते हैं तो पहले उसका बैकअप लें.

चेतावनी: डेटा ट्रांस्फ़र के दौरान अपने MicroSD को न निकालें.

मेनू मैप

गेम्स और एप्लिकेशंस
1 गेम्स
2 सुविधायें
3 Google खोज
4 ओर सामग्री

लॉग्स
1 सभी लॉग्स
2 केवल कॉल्स
3 केवल संदेश
4 छूटे हुए लॉग
5 जावक कॉल्स
6 आवक लॉग्स
7 कॉल अवधि
8 डेटा वॉल्यूम

कैमरा
1 कैमरा
2 वीडियो कैमरा
3 अल्बम

इंटरनेट

SNS
1 Facebook
2 Twitter
3 Orkut
4 Windows Live!

संदेश

संगीत
1 MP3 प्लेयर
2 FM रेडियो

ई–मेल

मेरी चीजें

फोन पुस्तिका

उपकरण
1 त्वरित मेनू
2 आयोजक
3 अलार्म घड़ी
4 कैलकुलेटर
5 वॉइस रिकॉर्डर
6 स्टॉपवॉच
7 इकाई परिवर्तक
8 विश्व घड़ी
9 एलईडी बैनर
0 USIM सेवा

सेटिंग्स
1 डुअल सिम
2 प्रोफ़ाइल्स
3 यंत्र
4 प्रदर्शन
5 कॉल
6 संयोजकता
7 Wi-Fi

आपकी होम स्क्रीन

स्थिति पट्टी

सिग्नल शक्ति, नए संदेश और बैटरी जीवन के साथ साथ आपको यह बताने के लिए कि क्या आपका ब्लूटूथ कनेक्शन सक्रिय है, स्थिति पट्टी विभिन्न चिह्नों का उपयोग करती है.

निम्न तालिका उन चिह्नों का वर्णन करती है जिन्हें आप स्थिति पट्टी में देख सकते हैं.

चिह्न	वर्णन
	नेटवर्क सिर्गनल क्षमता (पट्टियों की संर्खया में अंतर होगा)
	कोई नेटवर्क सिग्नल नहीं
	GPRS उपलब्ध
	EDGE उपलब्ध
	फ्लाइट मोड सक्रिय किया गया है
	कॉल्स को डायवर्ट किया गया है.
	रोमिंग सेवा
	Bluetooth® सक्रिय किया गया है
	डेटा कनेक्ट हो रहा है

चिह्न	वर्णन
	एक अलार्म सेट है
	शेड्यूल
	नया संदेश
	नया ध्वनि संदेश
	नया ईमेल
	सामान्य प्रोफ़ाइल उपयोग में है
	मौन प्रोफ़ाइल उपयोग में है
	आउटडोर प्रोफ़ाइल उपयोग में है
	हेडसेट लगाया गया
	शेष बैटरी जीवन
	बैटरी खाली
	बाह्य मेमोरी
	FM रेडियो
	MP3 संगीत चल रहा है
	Wi-Fi

कॉलिंग

कॉल करना

1 सुनिश्चित करें कि आपका फ़ोन चालू है.

2 आप कीपैड का उपयोग कर सकते हैं. किसी अंक को हटाने के लिए पीछे तीर को दबाएँ.

3 कॉल प्रारंभ करने के लिए दबाएँ.

4 कॉल समाप्त करने के लिए, दबाएँ.

युक्ति! अंतर्राष्ट्रीय कॉल करते समय + दर्ज करने के लिए, 0 दबाकर रखें.

अपने संपर्कों में से कॉल करना

आपके द्वारा फ़ोनबुक में संग्रहीत किए गए किसी भी नंबर पर कॉल करना आसान है.

1 मुख्य मेनू खोलने के लिए मेनू दबाएँ. फ़ोन पुस्तिका का चयन करें.

2 कीपैड का उपयोग करते हुए उस संपर्क का पहला अक्षर टाइप करें जिसे आप कॉल करना चाहते हैं और फिर फ़ोन पुस्तिका पर स्क्रॉल करें.

3 कॉल प्रारंभ करने के लिए दबाएँ.

कॉल का उत्तर देना और कॉल रद्द करना.

जब आपका फ़ोन रिंग करता है, तो कॉल का उत्तर देने के लिए स्वीकार करें या दबाएँ.

जब आपके फ़ोन की घंटी बज रही हो तो आप घंटी को म्यूट करने के लिए मौन दबा सकते हैं.

यह तब उपयोगी है यदि आप एक मीटिंग के लिए अपनी प्रोफ़ाइल को मौन पर करना भूल गए हैं.

किसी इनकमिंग कॉल को अस्वीकृत करने के लिए दबाएँ या अस्वीकार का चयन करें.

नोट:
कॉल के दौरान जब स्पीकर सक्रिय हो, स्पीकर आइकन लाल रंग के क्रॉस के साथ प्रदर्शित होता है, जब स्पीकर सक्रिय न हो तो स्पीकर आइकन बिना लाल रंग के क्रॉस के साथ प्रदर्शित होता है.

स्पीड डायलिंग

आप ऐसे संपर्क को स्पीड डायल नंबर असाइन कर सकते हैं, जिसे आप बार–बार कॉल करते हैं.

1 मुख्य मेनू खोलने के लिए मेनू दबाएँ. फ़ोन पुस्तिका का चयन करें, और विकल्प और शिध्र डायल्स का चयन करें.

2 आपका वॉइसमेल पहले ही से स्पीड 1 कुंजी और SOS मोड पहले से ही 9 कुंजी पर सेट किया गया है. इसलिए आप इसे बदल नहीं सकते. या तो नेविगेशन कुंजी का उपयोग कर सेट का चयन करते हुए या हार्ड कुंजी संख्या दबाते हुए और सेट का चयन करते हुए किसी अन्य संख्या का चयन करें.

3 आपकी फ़ोनबुक खुलेगी. उस सदस्य को आप जो संख्या असाइन करना चाहते हैं उसका चयन नेविगेशन कुंजी का उपयोग करते हुए करें और फिर चयन करें दबाएँ.

निष्क्रिय स्क्रीन से, स्टैंडबॉय मोड में स्पीड डायल नंबर पर कॉल करने के लिए, असाइन किए गए नंबर को तब तक दबा कर रखें जब तक कि संपर्क स्क्रीन पर प्रकट नहीं होता है. कॉल स्वचालित रूप से प्रारंभ हो जाएगी और को दबाने की कोई आवश्यकता नहीं है.

गेम्स और एप्लिकेशंस

मेनू दबाएँ और गेम्स और एप्लिकेशंस का चयन करें.

आप अपने खाली समय में मनोरंजन के लिए अपने फ़ोन पर नए गेम्स और एप्लिकेशंस स्थापित कर सकते हैं.

गेम्स

अपने LG-C375 पर गेम्स तक पहुँच प्राप्त करें, या खरीदने के लिए उपलब्ध गेम्स की कैटालॉग में से नए डाउनलोड करें.

सुविधायें

NewsHunt : राह में होने पर भी क्षेत्रीय में न्यूज़पेपर्स देखने और पढ़ने हेतु सक्षम किए जाने के लिए डिज़ाइन किया गया एक विशिष्ट मोबाइल अनुप्रयोग हैं ।

नोट : उपर दिए गये अनुप्रयोग उपयोग करने से पहले कृपाया सुनिश्चीत करे कि स्वतः अधतम चालु हैं ।

लॉग्स

मेनू दबाएँ और लॉग्स का चयन करें.

सभी लॉग्स

अपनी सभी डॉयल की गई, प्राप्त की गई और छूटी कॉल्स और साथ ही भेजी गए और प्राप्त किए गए संदेशों की पूर्ण सूची देखें.

केवल कॉल्स

जिन्हें आपने कॉल की, जिनसे कॉल प्राप्त हुई और छूटी कॉल्स के सभी नंबर्स की सूची देखें.

केवल संदेश

उन सभी नंबर्स की सूची देखें, जिन्हें आपने संदेश भेजे या प्राप्त किए.

छूटे हुए लॉग

आपके द्वारा छूटी किसी भी कॉल की सूची देखें.

जावक कॉल्स

आपके द्वारा कॉल किए गए सभी नंबरों की सूची देखें.

आवक लॉग्स

आपके द्वारा प्राप्त किए गए सभी नंबरों की सूची देखें.

युक्ति! चयनित आइटम को हटाने के लिए किसी भी कॉल लॉग से विकल्प और फिर हटाएँ का चयन करें.

कैमरा

कैमरा

1 मेनू दबाएँ और कैमरा और कैमरा का चयन करें.

2 जब कैमरा आपके विबय पर केंद्रित हो, तो फ़ोटो लेने के लिए स्क्रीन के नीचें–केंद्र पर कैप्चर आइकन का चयन करें और ठीक दबाएँ.

वीडियो कैमरा

1 मेनू दबाएँ और कैमरा का चयन करें और वीडियो कैमरा चुनें. वीडियो कैमरा का व्यूफ़ाइंडर र्सक्रीन पर दिखाई देगा.

2 जो भी रिकॉर्ड करना है, उस पर कैमरा फ़ोकस करें.

3 वीडियो बनाने के लिए स्क्रीन के नीचें–केंद्र पर Rec. आइकन का चयन करें और ठीक दबाएँ. Rec व्यूफ़ाइंडर के नीचे दिखाई देगा. रिकॉर्डिंग बंद करने के लिए फिर से ■ दबाएँ.

अल्बम

आपके द्वारा ली गई छवियाँ और वीडियोज़ अपनी एल्बम में देखें.

इंटरनेट

आप इंटरनेट ब्राउज़र लॉन्च कर सकते हैं और वेब सेटिंग्स पर सक्रिय प्रोफ़ाइल के होमपेज पर पहुँच सकते हैं. आप मैन्युअल रूप से भी URL पता दर्ज कर सकते हैं और संबद्ध वेब पृष्ठ तक पहुँच सकते हैं.

1 मेनू मोड में, अपने सेवा प्रदाता का मुखपृष्ठ लॉन्च करने के लिए, इंटरनेट → हाँ का चयन करें.

2 निम्न कुंजियों के उपयोग द्वारा वेब पृष्ठ नेविगेट करें:

नेविगेशन – वेब पृष्ठ पर ऊपर या नीचे स्क्रॉल करें.

ठीक – किसी आइटम का चयन करें.

वापस – पिछले पृष्ठ पर वापस जाएँ.

विकल्प – ब्राउज़र विकल्पों की एक सूची तक पहुँच प्राप्त करें.

नोट: इन सेवाओं से कनेक्ट करने और सामग्री डाउनलोड करने से आपको अतिरिक्त शुल्क देना पड़ेगा.अपने नेटवर्क प्रदाता से डेटा शुल्क जाँचें.

SNS (सामाजिक नेटवर्क सेवाएँ)

आपके LG-C375 में SNS है, जो आपको आपके सामाजिक नेटवर्क का आनंद लेने और उसे प्रबंधित करने देता है. आप अपने स्वयं के SN स्थान की स्थिति अपडेट कर सकते हैं और अपने मित्र के SN अपडेट देख सकते हैं.

नोट: SNS सुविधा एक डेटा प्रधान अनुप्रयोग है. ऑनलाइन सेवाएँ कनेक्ट और उपयोग करते समय, अतिरिक्त शुल्क लग सकता है. अपने नेटवर्क प्रदाता से अपना डेटा शुल्क जाँचें.

Facebook:

होम: लॉग इन करें और आप अपने मित्र की अपडेट की गई स्थिति देखेंगे. नई स्थिति के बारे में अपनी टिप्पणी इनपुट करें या अन्य की जांच करें. ताज़ा करने, न्यूज़ फ़ीड फ़िल्टर (स्थिति अपडेट, फ़ोटो), हटाना या सेटिंग्स को चुनने के लिए विकल्पों का चयन करें.

Twitter

Twitter एक माइक्रोब्लॉगिंग सेवा है जो अपने उपयोगकर्ताओं को ट्वीट्स नामित संदेश भेजने और पढ़ने में सक्षम बनाता है.

Orkut

orkut यह एक ऑनलाइन समुदाय है जो अपने सामाजिक जीवन को अधिक सक्रिय और दोस्ताना बनाने के लिए बनाया गया हैं ।

Windows Live!

यह इंस्टेंट मैसेजिंग क्लायंट जानकारी का संकेत देता है जैसा कि क्लायंट नाम और संस्करण संख्या.

संदेश

संदेश

आपके LG-C375 में SMS (संक्षिप्त संदेश सेवा), MMS (मल्टीमीडिया संदेश सेवा) साथ ही साथ नेटवर्क के सेवा संदेशों से संबंधित फ़ंक्शंस शामिल हैं.

संदेश भेजना

1 मेनू दबाएँ, संदेश का चयन करें और संदेश लिखें चुनें.

2 नया संदेश संपादक खुल जाएगा. संदेश संपादक में SMS और MMS एक सहज मोड में संयोजित होते हैं, जिनके बीच स्विच करना आसान होता है. संदेश संपादक की डिफ़ॉल्ट सेटिंग SMS मोड है.

3 कीपैड का उपयोग करते हुए अपना संदेश दर्ज करें. पाठ दर्ज करने के बारे में अधिक जानकारी के लिए दाहिनी ओर पाठ दर्ज करना देखें.

4 कोई छवि, वीडियो, ध्वनि, पाठ टेम्पलेट, मल्टीमीडिया टेम्पलेट, इमॉटिकॉन, नाम और नंबर, स्लाइड, विषय या अधिक (**व्यावसायिक कार्ड/शेड्यूल/मेमो/कार्य/मेरी प्रोफ़ाइल**) जोड़ने के लिए विकल्प का चयन करें और डालें चुनें.

5 इसे भेजें चुनें.

6 संपर्कों की सूची से संपर्क चुनें या फ़ोन नंबर दर्ज करें.

7 भेजें का चयन करें.

⚠ **चेतावनी**: छवि, ध्वनि, वीडियो, स्लाइड, विषय, व्यावसायिक कार्ड, शेड्यूल या मेरी प्रोफ़ाइल को संदेश संपादक में जोड़ा गया है, यह स्वचालित रूप से MMS मोड में कनवर्ट हो जाएगा और आपसे उसके अनुसार शुल्क लिया जाएगा.

पाठ दर्ज करना

आप फ़ोन के कीपैड का उपयोग करते हुए अल्फ़ान्यूमेरिक वर्ण दर्ज कर सकते हैं. उदाहरण के लिए, संपर्कों में नाम संग्रहीत करना, संदेश लिखना और कैलेंडर में इवेंट शेड्यूल बनाना सभी के लिए पाठ दर्ज करना आवश्यक है.

फ़ोन में निम्न पाठ इनपुट पद्धतियाँ उपलब्ध हैं: Abc मोड और 123 मोड.

नोट: कुछ फ़ील्ड में केवल एक इनपुट मोड की ही अनुमति होती है (उदाहरण, संपर्क फ़ील्ड्स में टेलीफोन नंबर).

कीमैपिंग तालिका

Q	W	E	R	T	Y	U	I	O	P
ौ औ १	ै ऐ ॆ ऎ २	ा आ ॉ ऑ ३	ी ई ४	ू ऊ ृ ऋ ५	ब भ ६	ह ङ ञ ७	ग घ ८	द ध ९	च छ ज झ ञ 0

A	S	D	F	G	H	J	K	L
ो ओ ॊ ऒ	े ए ॅ ऍ	्	ि इ	ु उ	प फ	र ऱ ऱ ऱ	क ख क्ष	त थ त्र

Z	X	C	V	B	N	M
ट ठ ड ढ	म ण	न ।	व ं ़ ः	ल ळ	स श श्र	य ष य़ ँ

कीपैड का उपयोग करते हुए पाठ इनपुट मोड

जब आप पाठ दर्ज करना चाहते हैं, उदाहरण के लिए, संदेश लिखते समय, तो कीपैड डिफ़ॉल्ट रूप से Abc मोड पर होगा. यदि आप कोई नंबर दर्ज कर रहे हैं, उदाहरण के लिए कोई कॉल करते समय तो कीपैड नंबर कुंजियाँ डिफॉल्ट रूप से नंबर मोड पर होंगी. मोड को बदलने के लिए संपादक स्क्रीन में Fn कुंजी दबाएँ.

अपने संदेशों को प्रबंधित करना

1 मेनू दबाएँ, संदेश का चयन करें और संदेश चुनें.

2 विकल्प का चयन करें और फिर चुनें:

उत्तर दें – चयनित संदेश को उत्तर भेजें.

संदेश लिखें – एक नया संदेश लिखें इस पर ध्यान दिए बिना कि किसने आपको संदेश भेजा.

कॉल – उस व्यक्ति को कॉल करें, जिसने आपको संदेश भेजा है.

नंबर रक्षित करें – संदेश का नंबर सहेजें.

हटाएँ – चयनित संदेश हटाएँ.

प्रारूप – यदि किसी संदेश को पूर्ण लिखने के लिए आपके पास प्रयाप्त समय नहीं है, तो आप अभी तक लिखे गए संदेश को यहाँ सहेज सकते हैं.

आउटबॉक्स – जब संदेश भेजे जा रहे हों, तो यह उपयोग किए जाने के लिए एक अस्थायी संग्रहण फ़ोल्डर होता है.

मेरे फ़ोल्डर्स – आप इनबॉक्स या भेजे के संदेशों को मेरे फ़ोल्डर्स में ले जा सकते हैं. साथ ही आप मेरे फ़ोल्डर्स के उन संदेशों को मूल संदेश बॉक्स में भेज सकते हैं.

टेम्पलेट्स – पहले से लिखे गए उपयोगी संदेशों की सूची, त्वरित उत्तर के लिए उपयोगी.

भावनाएं – आप एक नया इमोटीकॉन जोड़ सकते हैं या इसे संपादित कर सकते हैं. आप अपनी प्राथमिकताओं के आधार पर इसे हटा भी सकते हैं.

सेटिंग्स – यह मेनू आपको अपने नेटवर्क सेवा प्रदाता की सुविधाएँ सेट करने की अनुमति देता है.

संदेश

संदेश दृश्य – वार्तालाप दृश्य या मानक दृश्य में से चुनें. डिफ़ॉल्ट रूप से वार्तालाप दृश्य प्रदर्शित होता है. जब आप वार्तालाप में एक संदेश खोलते हैं, तब अपनी सभी संबंधित संदेश कार्ड के डेक की तरह सफ़ाई से स्टैक किया जाएगा. आप इस सेटिंग को संदेश दृश्य मेनू का उपयोग कर मानक दृश्य में बदल सकते हैं. ऐसा करने के लिए, संदेश > सेटिंग्स > संदेश दृश्य पर जाएँ.

पाठय संदेश – आप पाठ संदेश संबंधित विकल्पों को कॉन्फ़िगर कर सकते हैं.

मल्टीमीडिया संदेश – आप मल्टीमीडिया संदेश संबंधित विकल्पों को कॉन्फ़िगर कर सकते हैं.

स्पैम संदेश – आप स्पैम के रूप में सेट किए गए संदेश का संग्रहण कर सकते हैं.

वॉइस मेल – एक नई वॉयसमेल सेवा जोड़ें. आपके नेटवर्क ऑपरेटर द्वारा प्रदान की जाने वाली सेवा पर अधिक जानकारी के लिए अपने नेटवर्क ऑपरेटर से संपर्क करें.

सेवा संदेश – सेवा संदेशों को प्राप्त करने या ब्लॉक करने का चयन करें. विश्वस्त और अविश्वस्त प्रेषकों को सूची बनाकर आप अपनी संदेश सुरक्षा को भी सेट कर सकते हैं.

भेजे गए संदेश सहजे – आप अपने द्वारा भेजे गए संदेशों को सहेजने का चयन कर सकते हैं.

संदेश काउंटर – आप इच्छित समयावधि के अंदर भेजे गए संदेशों की मात्रा जाँच सकते हैं.

सूचना सेवा – अपने जानकारी संदेशों के लिए रिसेप्शन स्थिति, चौनल्स और भाषा चुनें.

यदि आप यह संदेश देखते हैं, सिम संदेश के लिए कोई स्थान नहीं, तो स्थान बनाने के लिए आपको अपने इनबॉक्स से कुछ संदेशों को हटा देना चाहिए.

यदि आप यह संदेश देखते हैं, संदेशों के लिए कोई स्थान नहीं, तो आप अधिक स्थान बनाने के लिए या तो संदेशों या सहेजी गई फ़ाइल्स को हटा सकते हैं.

युक्ति! प्राप्त संदेश देखते समय, विकल्प दबाएँ और त्वरित उत्तर का चयन करें. यह उपयोगी है यदि आपको मीटिंग के दौरान किसी संदेश का उत्तर देने की आवश्यकता है.

युक्ति! जब आप संदेश देखते हैं, विकल्प दबाएँ और एक्सट्रैक्ट का चयन करें. आप चयनित संदेश से जानकारी एक्सट्रैक्ट कर सकते हैं जैसे कि नंबर, ईमेल पता या वेब पता.

संगीत

MP3 प्लेयर

आपके LG-C375 में एक अंतर्निहित संगीत प्लेयर है, अतः आप अपने सभी पसंदीदा संगीत चला सकते हैं.

नोट:
- संगीत प्लेयर का उपयोग करने से पहले, आपको अपने फ़ोन पर संगीत फ़ाइलें ट्रांस्फ़र करने की आवश्यकता होगी.
- संगीत प्लेयर निम्न अनुसार कोडेक प्रकारों का समर्थन करता हैरू MP3, WMA, AAC. यह आवश्यक नहीं की संगीत प्लेयर फ़ाइल स्वरूपों की सभी सुविधाओं और संस्करणों का समर्थन करे.

संगीत प्लेयर तक पहुँच प्राप्त करने के लिए, मेनू दबाएँ और संगीत का चयन करें और MP3 प्लेयर का चयन करें. यहाँ से आप इन तक पहुँच सकते हैं:

हाल ही में चलाया गया – हाल में चलाए गए सभी गीत देखें.

सभी गाने – इसमें वे सभी गीत होते हैं जो आपके फ़ोन पर हैं.

कलाकार – आपको कलाकार अनुसार सॉर्ट की गई सभी ट्रैक्स देखने की अनुमति देता है.

एल्बम्स – आपको एल्बम अनुसार सॉर्ट की गई सभी ट्रैक्स देखने की अनुमति देता है.

विद्या – आपको शैली अनुसार सॉर्ट की गई सभी ट्रैक्स देखने की अनुमति देता है.

प्लेलिस्ट – आपके द्वारा बनाई गयी सभी प्लेलिस्ट शामिल होती हैं.

सभी गीत शफ़ल करें – आपको सभी गीतों को आकस्मिक क्रम में चलाने की अनुमति देता है.

अपने फ़ोन पर संगीत स्थानांतरित करना

अपने फ़ोन पर संगीत स्थानांतरित करने का सबसे आसान तरीका ब्लूटूथ या सिंक केबल के माध्यम से है.

ब्लूटूथ का उपयोग करते हुए संगीत स्थानांतरित करने के लिए:

1 सुनिश्चित करें कि दोनों डिवाइसेज़ में ब्लूटूथ चालू है और एक दूसरे को दृश्यमान है.

2 अन्य डिवाइस पर संगीत फ़ाइल का चयन करें और उसे ब्लूटूथ के माध्यम से भेजना चुनें.

3 जब फ़ाइल भेजी गई है, तो आपको हाँ का चयन करते हुए इसे स्वीकार करना चाहिए.

4 फ़ाइल को सभी गीतों में प्रकट होना चाहिए.

संगीत

कोई गीत चलाना

1 मेनू दबाएँ और संगीत का चयन करें, फिर MP3 प्लेयर चुनें.

2 सभी गीतों का चयन करें और फिर इच्छित गाना चुनें. का चयन करें.

3 गीत रोकने के लिए का चयन करें.

4 अगले गीत को छोड़ने के लिए ▶▶| का चयन करें.

5 पिछले गीत को छोड़ने के लिए |◀◀ का चयन करें.

युक्ति! संगीत सुनते समय वॉल्यूम बदलने के लिए, आपके फ़ोन के बाईं ओर वॉल्यूम कुंजियों का उपयोग करें.

नोट:
संगीत फ़ाइलों का कॉपीराइट अंतर्राष्ट्रीय संधियों और राष्ट्रीय कॉपीराइट कानूनों में संरक्षित किया जा सकता है. इसलिए, संगीत को पुनर्प्रस्तुत करने या उसकी कॉपी बनाने के लिए अनुमति या लाइसेंस प्राप्त करना अनिवार्य हो सकता है.

कुछ देशों में राष्ट्रीय कानून कॉपीराइट की गई सामग्रियों की निजी कॉपी बनाने से प्रतिबंधित करता है. फ़ाइल को कॉपी या डाउनलोड करने से पहले, कृपया ऐसी सामग्री के उपयोग के संदर्भ में लागू होने वाले देश का राष्ट्रीय कानून जाँचें.

संगीत चलाते समय विकल्प उपयोग करना

विकल्प का चयन करें और निम्न में से चुनें:

छोटा करें – संगीत प्लेयर स्क्रीन को छुपा दें ताकि आप संगीत के चलते समय अपने फ़ोन का सामान्य रूप से उपयोग करना जारी रख सकें.

दोहराएँ – आप संगीत को दोहराते हुए सुन सकते हैं.

शफल चालू – आपके ट्रैक्स को आकस्मिक क्रम में चलाता है.

ईक्वेलाइजर – आप स्क्रीन पर ईक्वेलाइजर को देख सकते हैं.

सूचि में जोड़ें – वर्तमान ट्रैक को प्लेलिस्ट में जोड़ता है.

ऐसे सेट करें – गीत का उपयोग रिंगटोन, संदेश के रूप में करें.

से भेजें – गीत को संदेश, ईमेल या ब्लूटूथ के माध्यम से भेजें.

फ़ाइल जानकारी – आप उस संगीत फ़ाइल के बारे में जानकारी देख सकते हैं, जिसे आप सुन रहे हैं.

FM रेडियो

FM रेडियो का उपयोग करना

आपके LG-C375 में एक वायरलेस FM रेडियो सुविधा है ताकि आप कभी भी अपने मनपसंद रेडियो स्टेशन को ट्यून करके सुन सकें.

रेडियो सुनना

1 मेनू दबाएँ, संगीत का चयन करें और FM रेडियो चुनें.

2 उस स्टेशन के चौनल नंबर का चयन करें, जिसे आप सुनना चाहते हैं.

स्टेशन खोजना

आप या तो मैन्युअल रूप से या स्वचालित रूप से रेडियो स्टेशन की खोज करके, अपने फ़ोन को रेडियो स्टेशन्स पर ट्यून कर सकते हैं.
वे फिर विशिष्ट चौनल नंबर पर सहेजे जाएँगे, इसलिए आपको पुनरू ट्यून नहीं रखना पड़ता.

स्वत - स्कैन करने के लिए:

1 मेनू दबाएँ और संगीत का चयन करें.

2 FM रेडियो का चयन करें विकल्प चुनें.

3 स्वत - स्कैन का चयन करें.
पुष्टिकरण संदेश दिखाई देता है. चयन करने के लिए ठीक कुंजी दबाएँ, फिर स्टेशंस स्वचालित रूप से ढूँढे जाएँगे और आपके फ़ोन में किसी चौनल को आवंटित कर दिए जाएँगे.

नोट: आप स्क्रीन के मध्य में प्रदर्शित (और) का उपयोग करते हुए किसी स्टेशन में मैन्युअल रूप से भी ट्यून कर सकते हैं.

रेडियो से रिकॉर्ड करना

1 रेडियो सुनते समय रिकॉर्ड दबाएँ.

2 रिकॉर्डिंग समय आपके फ़ोन पर प्रदर्शित होता है.

यदि आप रिकॉर्डिंग रोकना चाहते हैं, तो रोकें कुँजी दबाएँ. रिकॉर्डिंग पूरी होने पर, रिकॉर्ड की गई सामग्री मेरी चीज़ें –> ध्वनि में mp3 फ़ाइल के रूप में सहेजी जाएँगी.

रेडियो की पूर्व–रिकॉर्डिंग करना

1 विकल्प दबाएँ और रिकॉर्डिंग सेटिंग्स का चयन करें.

2 पूर्व–रिकॉर्डिंग टैप पर 3/10/30 सेकेंड पहले चुनें.

नोट: इस सुविधा के कुछ अपवाद हैं.

ई–मेल

अपने नए खाते का उपयोग करते हुए ईमेल भेजना

ईमेल भेजने/प्राप्त करने के लिए, आपको ईमेल खाता सेट करना होगा.

1 मेनू दबाएँ, ई–मेल का चयन करें और उपयोग करने के लिए इच्छित खाता चुनें.

2 विकल्प से ई–मेल लिखें चुनें और एक नई ईमेल विंडो खुलेगी.

3 इन्हें फ़ील्ड में पता दर्ज करें फिर एक विषय पंक्ति लिखें और नेवगेशन कुंजी दबाएँ.

4 कीपैड के उपयोग द्वारा अपना संदेश लिखें फिर ईमेल भेजने के लिए भेजें दबाएँ.

अपने ईमेल की पुनः प्राप्ति

1 मेनू दबाएँ और ई–मेल का चयन करें.

2 आपके द्वारा उपयोग किए जाने के लिए इच्छित खाते का चयन करें.

3 इनबॉक्स का चयन करें.

4 ताज़ा करें चुनें और फ़ोन आपके ईमेल खाते से कनेक्ट किया जाएगा और आपके नए संदेशों को प्राप्त करेगा.

संदेश फ़ोल्डर

मेनू दबाएँ और ई–मेल का चयन करें. आपके LG-C375 पर उपयोग की गई फ़ोल्डर संरचना स्वतः विवरणात्मक होनी चाहिए.

ई–मेल लिखें – अपना नया संदेश लिखें.

इनबॉक्स – आपको प्राप्त सभी ई–मेल आपके इनबॉक्स में स्थित होते हैं. यहाँ से आप उत्तर दे सकते हैं, अग्रेषित कर सकते हैं और भी अधिक कर सकते हैं.

प्रारूप – यदि किसी ई–मेल को पूर्ण लिखने के लिए आपके पास प्रयाप्त समय नहीं है, तो आप अभी तक लिखे गए संदेश को यहाँ सहेज सकते हैं.

आउटबॉक्स – यह ई–मेल भेजे जाते समय एक अस्थायी संग्रहण फ़ोल्डर है या भेजे जाने में विफ़ल संदेशों को संग्रहीत करता है.

प्रेषित – आपके द्वारा भेजे गए सभी ई–मेल की कॉपी आपके प्रेषित फ़ोल्डर में रखी जाती हैं.

फ़ोन ट्रैश – आपके द्वारा निकाले गए सभी ई–मेल आपके फ़ोन ट्रैश में रखे जाते हैं.

अपनी ईमेल सेटिंग्स बदलना

1 मेनू दबाएँ, ई–मेल > विकल्प > मेलबॉक्स > खाते चुनें.

2 आपके द्वारा उपयोग किए जाने के लिए इच्छित खाते का चयन करें.

3 विकल्प और फिर विकल्प में से सेटिंग्स का चयन करें तब आप निम्न सेटिंग्स अनुकूलित कर सकते हैं:

खाते – आप ई–मेल खाता सेटिंग्स संपादित कर सकते हैं.

आवृत्ति – चुनें कि आपका LG-C375 कितनी बार नए ईमेल संदेशों के लिए जाँचें.

शेड्यूल – वह समयावधि चुनें जिस दौरान पुश ईमेल सक्रिय होगा.

सूचना – चुनें कि नए ईमेल के लिए सूचना दी जानी है या नहीं.

डिफ़ॉल्ट खाता – चुनें कि डिफ़ॉल्ट रूप से कौन सा खाता ई–मेल लिखे.

हस्ताक्षर – एक ईमेल हस्ताक्षर बनाएँ और इस सुविधा को चालू करें.

फोन पुस्तिका

संपर्क के लिए खोजना

1 मेनू दबाएँ और फोन पुस्तिका का चयन करें.

2 कीपैड का उपयोग करते हुए उस संपर्क के नाम का पहला अक्षर टाइप करें जिसे आप कॉल करना चाहते हैं.

3 संपर्कों और उनके भिन्न नंबर्स के अंतर्गत स्क्रॉल करने के लिए नेविगेशन कुंजियों का उपयोग करें.

या, थोड़ा–सी त्वरित पद्धति का उपयोग करना...

1 होम स्क्रीन पर वह नंबर दर्ज करें जिसकी आप खोज करना चाहते हैं और विकल्प का चयन करें.

2 विकल्प मेनू में संपर्क खोजें चुनें.

नया संपर्क जोड़ना

1 मेनू दबाएँ और फोन पुस्तिका का चयन करें.

2 विकल्पों दबाएँ और नया संपर्क का चयन करें.

3 प्रदान किए गए फ़ील्ड्स में इच्छित जानकारी दर्ज करें और पूर्ण का चयन करें.

संपर्क विकल्प

ऐसी अनेक चीजें हैं जो आप एक संपर्क देखते हुए कर सकते हैं. यहाँ बताया गया है कि विकल्प मेनू तक कैसे पहुँचें और उपयोग करें.

1 मेनू दबाएँ और फ़ोनबुक का चयन करें.

2 विकर्लपों की सूची खालेने के लिए विकल्प का चयन करें. यहाँ से आप यह कर सकते हैं:

संदेश भेजें – संपर्क को एक संदेश भेजें.

कॉल द्वारा – आपके द्वारा चुने जाने वाले संपर्क को सीधे ही वॉयस कॉल करें.

संम्पर्क भेजें – किसी भी संपर्क का विवरण परिवर्तित करें.

हटाएँ – संपर्क हटाएँ. यदि आप निश्चित हैं तो हाँ का चयन करें.

नया संपर्क – एक नया संपर्क जोड़ें.

संग्रहण स्थान – फ़ोन या सिम कार्ड पर ले जाने या कॉपी करने के लिए चुनें (इस आधार पर कि आपने वास्तविक रूप से संपर्क को कहाँ सहेजा था).

संपर्क भेजें – संपर्क के विवरण एक व्यावसायिक कार्ड के रूप में किसी अन्य व्यक्ति को भेजें. पाठ संदेश , MMS, ई–मेल या ब्लूटूथ के माध्यम से भेजना चुनें.

चयन मोड – चुनें कि क्या किसी संपर्क को चिह्नित करना है या चिह्नित करना रद्द करना है.

शीघ्र डायल्स – आप बारबार कॉल किए जाने वाले किसी संपर्क को एक शीघ्र डायल नंबर असाइन कर सकते हैं.

इस आधार पर सॉर्ट करें – किसी संपर्क को ABC↑ या ABC↓ द्वारा सॉर्ट करें.

समूह बनाना

1 मेनू दबाएँ और फ़ोनबुक का चयन करें.

2 समूह का चयन करें और विकल्प चुनें.

3 नया समूह का चयन करें.

4 अपने नए समूह के लिए नाम दर्ज करें.

5 पूर्ण दबाएँ.

नोट: यदि आप कोई समूह हटाते हैं, तो वे संपर्क जो उस समूह को असाइन किए गए थे, नहीं खोएंगे. वे आपके संपर्कों में ही रहेंगे.

अपनी संपर्क सेटिंग्स को बदलना

1 मेनू दबाएँ और फ़ोनबुक का चयन करें.

2 विकल्पों की सूची खालेने के लिए विकल्प का चयन करें. यहाँ से आप निम्नलिखित सेटिंग्स को समायोजित कर सकते हैं:

नाम दर्शाएँ – आप पहले प्रथम नाम या पहले अंतिम नाम, प्रथम नाम दिखाने के लिए चयन कर सकते हैं.

मुख्य स्टोर और दृश्य – चुनें कि संपर्कों का संग्रहण सिम1 या सिम2 या हैंडसेट पर किया जाए. और साथ ही चुनें कि क्या वे संपर्क दिखाने हैं जो कि हैंडसेट और सिम दोनों पर, केवल हैंडसेट या केवल सिम1 या केवल सिम2 पर सहेजे गए हैं.

सभी की प्रतिलिपि बनाएँ – अपने सिम1 या सिम2 से अपने सभी संपर्कों को अपने हैंडसेट पर या अपने हैंडसेट से अपने सिम1 या सिम2 पर या सिम1 से सिम2 पर या सिम2 से सिम1 पर कॉपी करें.

सब स्थानांतरित करें – यह सभी कॉपी करें के समान ही कार्य करता है, लेकिन संपर्क वहीँ पर सहेजा जाएगा जहाँ आपने उसे ले जाने का चयन किया है. यदि आप किसी संपर्क को सिम कार्ड से हैंडसेट पर भेजते हैं, तो वह सिम मेमोरी से हटा दिया जाएगा.

फोन पुस्तिका

निर्यात संपक – आप हैंडसेट के सभी फ़ोनबुक डेटा को Vकार्ड के रूप में किसी बाहरी मेमोरी कार्ड पर सहेज सकते हैं.

संपर्क आयात करें – आप बाहरी मेमोरी कार्ड के सभी फ़ोनबुक डेटा को Vकार्ड के रूप में फ़ोन मेमोरी पर पुनर्स्थापित कर सकते हैं.

ब्लूटूथ द्वारा सभी सपंर्क भेजें – सभी संपर्क जानकारी को ब्लूटूथ के माध्यम से किसी अन्य हैंडसेट पर भेजें.

उपकरण

त्वरित मेनू

जोड़ें दबाएँ और उस मेनू को चुनें जिस तक आप त्वरित रूप से जाना चाहते हैं.

आयोजक

आप कैलेंडर, कार्य, मेमो तक पहुँच कर सकते हैं और लक्ष्य दिनांक प्राप्त करने के लिए गणना तारीक्ष चुन सकते हैं

सुझाब: उपयोगकर्ता कोई SMS शेड्यूल कर सकते है, ताकि विकल्प सूची से यह सेट की गई दिनांक और सेट किए गए समय पर पहले से निर्धारित नंबर भेजा जा सके ।

मेनू > उपकरण > आयोजक > कैलेंडरं > विकल्प > नया सूची SMS चयन करके शेडयूल सन्देश भेज सकते हैं।

अलार्म घड़ी

आप स्नूज़ अंतराल को 5, 10, 20, 30 मिनट, 1 घंटा या बंद पर सेट कर सकते हैं.

कैलकुलेटर

1 इनपुट संख्याओं के लिए सांख्यायिक कुंजियों को दबाएँ.

2 सामान्य परिकलन के लिए, = के बाद नेविगेशन कुंजियों का उपयोग करके आवश्यक (+, –, ×, ÷) फ़ंक्शन का उपयोग करें.

3 जटिल परिकलनों के लिए, आदेश को चुनने के लिए विकल्प का चयन करें.

4 स्क्रीन साफ़ करने के लिए – का चयन करें और नया परिकलन प्रारंभ करें.

वॉइस रिकॉर्डर

वॉइस मेमो या अन्य ध्वनियाँ रिकॉर्ड करने के लिए अपने वॉइस रिकॉर्डर का उपयोग करें. आपके द्वारा रिकॉर्डिंग पूर्ण करने के बाद, चलाने, भेजने आदि के लिए विकल्प का चयन करें.

आपके वॉइस मेमो को रिकॉर्ड करना

1 रिकॉर्डिंग शुरू करने के लिए रिकॉर्ड दबाएँ.

2 रिकॉर्डिंग बंद करने के लिए रोकें चुनें.

3 विकल्प का चयन करें और रिकॉर्डिंग को सुनने के लिए ध्वनियों पर जाएँ का चयन करें.

स्टॉपवॉच का उपयोग करना

1 टाइमर शुरू करने के लिए प्रारंभ का चयन करें.

2 यदि आप लैप समय रिकॉर्ड करना चाहते हैं तो लैप चुनें. 99 लैप समय तक सहेजे जा सकते हैं.

3 टाइमर को रोकने के लिए रोकें का चयन करें.

4 जिस समय आपने स्टॉपवॉच को रोका है उसी समय से शुरू करने के लिए जारी रखें चुनें या फिर शून्य पर जाने के लिए रीसेट करें चुनें.

इकाई परिवर्तक

चुनें कि क्या आप मुद्रा, क्षेत्र, लंबाई, भार, तापमान, वॉल्यूम या गति को कनवर्ट करना चाहेंगे.

नोट: मुद्रा कनवर्ट करने के लिए, आपको पहले वर्तमान विनिमय दर के अनुसार दर को सेट करने की आवश्यकता होगी.

अपनी विश्व घड़ी में कोई शहर जोड़ना

1 मेनू दबाएँ और उपकरण का चयन करें, फिर विश्व घड़ी चुनें.

2 किसी विशिष्ट शहर का समय जोड़ने या पता लगाने के लिए, विकल्प दबाएँ और नया शहर का चयन करें.

सेटिंग्स

डुअल सिम

आप संपर्क, कॉल लॉग्स और संदेश बॉक्स में कॉल या संदेश के लिए डिफ़ॉल्ट सिम का चयन कर सकते हैं.

प्रोफ़ाइल्स

वह प्रोफ़ाइल चुनें, जिसे आप संपादित करना चाहते हैं.

फ्लाइट मोड का उपयोग करना – फ्लाइट मोड आपको कॉल करने, इंटरनेट से कनेक्ट करने या संदेश भेजने की अनुमति नहीं देगा.

यंत्र

नीचे दी गई सूची में से चुनें.

दिनांक और समय – स्वतः अपडेट चालू का चयन करें और फ़ोन स्वचालित रूप से दिनांक और समय अपडेट करेगा.

बैट्री स्थिति – फ़ैक्टरी सेट ऊर्जा बचत सेटिंग्स स्विच करने के लिए चालू या बंद चुनें.

भाषाएं – अपने LG-C375 के डिसप्ले की भाषा परिवर्तित करें.

स्वत: की लॉक – कीपैड को स्टैंडबाय स्क्रीन में स्वचालित रूप से लॉक करता है.

सुरक्षा – अपना LG-C375 और इसके द्वारा रखी जाने वाली सामग्री को सुरक्षित रखने के लिए अपनी सुरक्षा सेटिंग्स परिवर्तित करें.

- **अनुप्रयोग लॉक** – फोन के अनुप्रयोग का अनअधिकृत इस्तमाल रोकने के लीए, अनुप्रयोग लॉक सक्रिय कर सकते है. एक बार अनुप्रयोग लॉक सक्रिय होने पर सिर्फ पासवर्ड से हीं अनुप्रयोग मैं प्रवेश कर सकते हैं. डिफॉल्ट पासवर्ड 0000 हैं ।
- **एंटी–थेफ्ट मोबाइल ट्रैकर** – हैंडसेट चोरी हो जाने पर, हैंडसेट वास्तविक स्वामि द्वारा कॉन्फ़िगर किए गए नंबर्स पर SMS भेजता है. ATMT सुविधा सक्रिय करने के लिए, आपको ATMT को चालू पर सेट करने और ATMT सेटिंग्स को स्वामी के नाम और वैकल्पिक नंबर्स के साथ कॉन्फ़िगर करने की आवश्यकता होगी. डिफ़ॉल्ट ATMT कोड "0000" है.

संकट संदेश सेवा

- **संकट संदेश सेवा** – यह SOS मोड सक्षम करता है. सक्षम करने के बाद निष्क्रिय स्क्रीन में यदि आप 9 कुंजी को देर तक दबाते हैं, तो SOS संदेश भेजा जाता है और फ़ोन SOS मोड में रेहता हैं ।
- **संदेश** – आपातकालीन स्थिति में, SOS मोड में बदलने के लिए '9' दबाकर रखें. मोड में, असाइन किए गए प्राप्तकर्ताओं को SOS संदेश भेजा जाता है और उनके इनकमिंग कॉल स्वचालित रूप से स्वीकार किए जाते हैं. सभी सूचना ध्वनि म्यूट किए

जाएंगे. SOS मोड से बाहर निकलने के लिए, होम स्क्रीन में समाप्ति कुंजी दबाएँ.

- **ग्रहक सूची** – प्राप्तकर्ता के सूची जिसे संदेश भेज दी गई है और SOS मोड के दौरान, फ़ोन केवल इन नंबर से ही कॉल्स स्वीकार करेंगे ।
- **मदद** – SOS मोड के बारे में अन्य विवरण यहाँ उल्लेख किया हैं।

मेमोरी की जानकारी – आपके LG-C375 में तीन मेमोरी उपलब्ध हैंरू फ़ोन, सिम कार्ड और बाहरी मेमोरी कार्ड (आपको अलग से मेमोरी कार्ड खरीदने की आवश्यकता हो सकती है). आप यह निर्धारित करने के लिए मेमोरी प्रबंधक का उपयोग कर सकते हैं कि कितनी मेमोरी उपयोग हो चुकी है और कितनी रिक्ति उपलब्ध है.

प्राथमिक संग्रह सेटिंग – यदि आप अपने फ़ोन में कोई बाहरी मेमोरी कार्ड डालते हैं, तो आप प्राथमिक संग्रहण सेटिंग्स का भी चयन कर सकते हैं फिर वह डिफ़ॉल्ट स्थान चुनें जहाँ आप आइटम्स का संग्रहण किया जाना चाहेंगे.

डिवाइस रीसट करें – सभी सेटिंग्स को उनकी फ़ैक्टरी परिभाषाओं पर रीसेट करें. यह फ़ंक्शन सक्रिय करने के लिए आपको सुरक्षा कोड की आवश्यकता होगी.

यंत्र जानकारी – अपने LG-C375 के लिए तकनीकी जानकारी देखें.

प्रदर्शन

नीचे दी गई सूची में से चुनें.

होम स्क्रीन – वॉलपेपर, विजेट सेटिंग्स और मुख्य असाइनमेंट्स समायोजित करें.

मेनू स्टाईल – मेनू दृश्य को सूची स्टाईल या ग्रिड दृश्य से परिवर्तित करें.

फ़ॉन्ट – फ़ॉन्ट आकार को समायोजित करें.

बैकलाईट – चुनें कि बैकलाइट कब तक चालू रहेगी. साथ ही, मुख्य स्क्रीन की चमक समायोजित करने के लिए नेविगेशन कुंजियों का उपयोग करें.

> **युक्ति!** जितनी देर तक बैकलाईट चालू रहती है, उतनी ही बैटरी पॉवर का उपयोग होता है और आपको अपने फ़ोन को बार–बार चार्ज करने की आवश्यकता पड़ सकती है.

शुभकामना संदेश – चालू का चयन करने के बाद, आप एक स्वागत संदेश लिख सकते हैं. आप जब भी अपने फ़ोन को प्रारंभ करेंगे, यह संदेश स्क्रीन पर प्रकट होगा.

अन्य स्क्रीन्स – स्टार्ट अप /शट डाउन के लिए छवि चुनें.

कॉल

सिम1 या सिम2 का चयन करें.

यहाँ से आप इसके लिए सेटिंग्स में सुधार कर सकते हैं:

कॉल अंतरण – चुनें कि आपकी कॉल्स डायवर्ट करें या नहीं.

- जब लाइन व्यस्त हो, जब कोई उत्तर न मिले, जब आप पहुँच से बाहर हों, तब चुनें कि क्या सभी कॉल्स को डायवर्ट करना है.
- अपना डायवर्ट नंबर दर्ज करें या अपने डायवर्ट नंबर के लिए ब्राउज़ करने हेतू खोजें का चयन करें.

नोट: कॉल डायवर्ट करने के लिए शुल्क लिए गए हैं. कृपया विवरण के लिए अपने नेटवर्क प्रदाता से संपर्क करें.

> **युक्ति!** सभी कॉल डायवर्ट बंद करने के लिए, कॉलिंग मेनू से कॉल डायवर्ट चुनें फिर विकल्प का चयन करें फिर सभी निष्क्रिय करें का चयन करें.

कॉल रोधन – उन कॉल्स का चयन करें जिन्हें आप रोकना चाहते हैं.

- इनमें से किसी एक या सभी विकल्पों का चयन करें:

  सभी जावक

  बाहर जाने वाले अतंराष्ट्रीय

  गुह देश के अलावा आउटगोइंग अतंराष्ट्रीय

  आनेवाली कॉल

  विदेश में आनेवाली कॉल

- कॉल अवरोधन पासवर्ड दर्ज करें. कृपया इस सेवा के लिए अपने नेटवर्क ऑपरेटर से जाँचें.

कॉल प्रतीक्षा – कोई कॉल प्रतीक्षा में होने पर सचेत रहें.

सीमित डायल नम्बर – उन नंबर्स की सूची चुनें, जिसे आपके फ़ोन से कॉल किया जा सके. आपको अपने ऑपरेटर से PIN2 कोड की आवश्यकता होगी. सक्रिय होने पर, केवल फ़िक्स्ड डायल सूची के नंबरों को ही आपके फ़ोन से कॉल किया जा सकता है.

कॉल अस्वीकार सेटिंग्स – बंद या चालू का चयन करें और उन सभी कॉल्स को अस्वीकार करना चुनें, जो विशिष्ट समूहों, संपर्कों, अपंजीकृत नंबर्स (जो आपके संपर्कों की सूची में नहीं हैं) या वे जो किसी कॉलर ID के साथ नहीं हैं.

> **नोट**: कॉल अस्वीकार सेटिंग्स खोलने के लिए, एक पासवर्ड की आवश्यकता होती है और डिफ़ॉल्ट पासवर्ड "0000" है.

मेरा नंबर भेजें – चुनें कि किसी व्यक्ति को कॉल करने पर आपका नंबर प्रदर्शित हो या नहीं. (आपके नेटवर्क प्रदाता पर निर्भर करता है.)

ऑटो रीडायल – जब कॉल करने का प्रयास विफल हो जाता है, तो आपको ऑटो रीडायल फ़ंक्शन सेट करने की अनुमति देता है.

मिनट माइंडर – यह निर्धारित करता है कि जब आप फ़ोन पर हों, तो क्या प्रत्येक 1 मिनट के बाद एक टोन बजाई जाए.

नया नंबर सहेजें – इस विकल्प को 'चालू' पर चयनित करने से कॉल समाप्त होने पर वे नंबर्स सहेजे जाएँगे, जो पहले से आपके संपर्क में नहीं हैं.

सामान्य सेटिंग का चयन करें.

यहाँ से आप इसके लिए सेटिंग्स में सुधार कर सकते हैं:

सेल्फ़ कॉल – सेल्फ़ कॉल एक वास्तविक आवक कॉल की नकल करती है. सेल्फ़ कॉल करने के लिए होम स्क्रीन पर '#*#' दबाएँ. यह कोई शुल्क चार्ज नहीं करता है.

पूर्व–रिकॉर्डिंग – आप कॉल की वॉइस को रिकॉर्ड बटन दबाने से कुछ सेकंड्स पहले से रिकॉर्ड कर सकते हैं.

बहाना संदेश – इससे पहले कि आप कोई इनकमिंग कॉल अस्वीकार करें, आप यह बताने के लिए कि आप उत्तर क्यों नहीं दे रहे हैं, "बहाना संदेशों" का उपयोग कर सकते हैं.

ब्लूटूथ उत्तर विधा – चुनें कि वॉल्यूम हेडसेट का उपयोग करते समय, कॉल का उत्तर कैसे दें. हैंड्स–फ्री या हैंडसेट का चयन करें.

संयोजकता

ब्लूटूथ

अपने LG-C375 को ब्लूटूथ उपयोग के लिए सेट अप करें. आप अपनी दृश्यता को अन्य डिवाइसेज़ पर अनुकूलित या अपने फ़ोन से जुड़े डिवाइसेज़ से खोज सकते हैं.

ब्लूटूथ और फिर सेटिंग्स चुनें.

इनमें अपने बदलाव करें:

मेरा डिवाइस दृश्यता – दृश्यमान सेट करें या 1 मिनट के लिए दृश्यमान हो ताकि अन्य डिवाइस आपके फ़ोन को तब खोज सकें जब वे ब्लूटूथ डिवाइस को खोज रहे हों. यदि आप छुपाएँ का चयन करते हैं तो अन्य डिवाइस आपके फ़ोन को खोजने में तब सक्षम नहीं हो पाएँगे जब वे ब्लूटूथ डिवाइस को खोज रहे हों.

मेरे हैंडसेट का नाम – आप अपने फ़ोन को नाम दे सकते हैं या नाम बदल सकते हैं, जैसा कि यह अन्य डिवाइसेज़ पर प्रकट होगा. आपके फ़ोन का नाम अन्य डिवाइसेस पर केवल तभी दिखाया जाएगा कि जब मेरी डिवाइस दृश्यता, दृश्यमान पर सेट होती है.

समर्थित सेवाएँ – आप इस ब्लूटूथ सक्षम फ़ोन से समर्थित डिवाइसेज़ की सूची देख सकते हैं जैसे की हेडसेट्स और हैंड्सफ्री.

मेरा पता – अपने ब्लूटूथ पते की यहाँ जाँच करें.

किसी अन्य ब्लूटूथ डिवाइस से युग्मित करना

अपने LG-C375 और अन्य डिवाइस को युग्मित करने के द्वारा, आप एक पासकोड सुरक्षित कनेक्शन सेट अप कर सकते हैं. इसका अर्थ है कि आप अधिक सुरक्षित तरीके से युग्मित हैं.

1 जाँचे कि आपका ब्लूटूथ सक्रिय और दृश्यमान है. ब्लूटूथ के सेटिंग्स मेनू में मेरी डिवाइस दृश्यता, फिर दृश्यमान का चयन कर आप अपनी दृश्यता को परिवर्तित कर सकते हैं.

2 ब्लूटूथ से, ब्लूटूथ सक्रिय करें चुनें और नया डिवाइस खोजें का चयन करें.

3 आपका LG-C375 डिवाइसेज़ के लिए खोज करेगा. खोज पूर्ण होने पर स्क्रीन पर जोड़ें और ताज़ा करें प्रकट होंगे.

4 आप उस डिवाइस को चुनें जिससे जुड़ना चाहते हैं, जोड़ें का चयन करें और एक पासकोड दर्ज करें और फिर ठीक चुनें.

5 इसके बाद आपका फ़ोन दूसरी डिवाइस से कनेक्ट हो जाएगा, जिसमें आपको वही पासकोड लिखना होगा.

6 अब आपका पासकोड रक्षित ब्लूटूथ कनेक्शन तैयार है.

नोट:

1 LG-C375 को किसी भी ऐसे डिवाइस के साथ युग्मित करें जो कि BT संस्करण 2.0 से ऊपर का समर्थन करता है, फिर पासकोड नहीं पूछा जाता है, क्योंकि पासकोड स्वतः जनरेट किया जाता है.

2 LG-C375 को किसी भी ऐसे डिवाइस के साथ युग्मित करें जो कि कमतर BT संस्करणों जैसे कि 1.2 आदि का समर्थन करता है, फिर पासकोड पूछा जाता है.

ब्लूटूथ का उपयोग करके अपनी फ़ाइलें भेजना और प्राप्त करना

फ़ाइलें भेजने और प्राप्त करने के लिए ब्लूटूथ अच्छा तरीका है क्योंकि किसी भी तार की आवश्यकता नहीं होती है और कनेक्शन त्वरित और आसान है. आप कॉल्स करने और प्राप्त करने के लिए एक ब्लूटूथ हेडसेट से भी कनेक्ट कर सकते हैं. ब्लूटूथ के उपयोग से फ़ाइलें साझा करने के पहले, आपको अपने फ़ोन को दूसरे ब्लूटूथ डिवाइस से जोड़ना होगा.

डिवाइसेज़ युग्मित करने के बारे में जानकारी के लिए, किसी अन्य ब्लूटूथ डिवाइस के साथ युग्मित करना देखें.

ब्लूटूथ को चालू करने के लिए:

1 मेनू दबाएँ और सेटिंग्स का चयन करें. कनेक्टिविटि चुनें फिर ब्लूटूथ का चयन करें.

2 ब्लूटूथ सक्रिय करें का चयन करें.

3 ब्लूटूथ को बंद करने के लिए ब्लूटूथ निष्क्रिय करें का चयन करें.

फ़ाइल भेजने के लिए:

1 उस फ़ाइल को खोलें जिसे आप भेजना चाहते हैं, विशिष्ट रूप से यह कोई फ़ोटो, वीडियो या संगीत फ़ाइल होगी.

2 विकल्प चयनित करें और इसके द्वारा भेजें चुनें फिर ब्लूटूथ का चयन करें.

3 अगर ब्लूटूथ पहले से सक्रिय नहीं है तो इसे चालू करने के लिए हाँ का चयन करें.

4 यदि आपने पहले से ब्लूटूथ डिवाइस युग्मित किया है, तो आपका LG-C375 स्वचालित रूप से अन्य ब्लूटूथ डिवाइसेज़ नहीं खोजेगा. यदि नहीं, तो आपका LG-C375 सीमा के अंतर्गत अन्य ब्लूटूथ सक्षम डिवाइसेज़ के लिए खोज करेगा.

5 वह डिवाइस चुनें जिसे आप फ़ाइल भेजना चाहते हैं और ठीक का चयन करें.

फ़ाइल प्राप्त करने के लिए:

1 फ़ाइलें प्राप्त करने के लिए, आपका ब्लूटूथ सक्रिय और दृश्यमान होना आवश्यक है.

2 आपको प्रेषक की ओर से फ़ाइल स्वीकार करने के लिए एक संदेश द्वारा संकेत मिलेगा. फ़ाइल को प्राप्त करने के लिए हाँ का चयन करें.

युक्ति! आपकी फ़ाइल भेज दी गई है यह सुनिश्चित करने के लिए प्रगति पट्टी पर नज़र रखें.

युक्ति! Bluetooth® संबंद चिह्न और लोगो पर Bluetooth SIG, Inc. का स्वामित्व है और LG Electronics द्वारा इस प्रकार के किसी भी चिह्न का उपयोग लायसेंस के अंतर्गत है. अन्य ट्रेडमार्क और ड्रेड नाम उनके संबंधित स्वामियों के होते हैं.

युक्ति!

1 जब आप ब्लूटूथ हेडसेट का उपयोग करते हैं, तो जब आप वीडियो चलाते हैं तो A2DP और AVRCP प्रोफ़ाइल समर्थित नहीं होते हैं. इसका अर्थ है कि आप ब्लूटूथ हेडसेट का उपयोग करते हुए वीडियो ध्वनि नहीं सुन सकते और वीडियो प्लेयर का नियंत्रण नहीं कर सकते.

2 ब्लूटूथ फ़ाइल हस्तांतरण कुछ चलते हुए अनुप्रयोग के अंतर्गत ब्लॉक कर दिया जाएगा. (कैमरा/कैमकॉर्डर, संगीत प्लेयर, वीडियो प्लेयर, UMS/PCSync)

USB संयोग मोड – आप अपने फ़ोन पर कई कार्यों के लिए USB कनेक्शन मोड का चयन कर सकते हैं.

डेटा नेटवर्क सिम – नेटवर्क तक पहुँच प्राप्त करने के लिए, आप डिफ़ॉल्ट सिम कार्ड का चयन कर सकते हैं.

Wi-Fi

वायरलेस प्रबंधक आपके डिवाइस पर Wi-Fi (वायरलेस LAN) के माध्यम से आपको इंटरनेट कनेक्शंस प्रबंधित करने की अनुमति देता है.

यह फ़ोन को स्थानीय वायरलेस नेटवर्क्स से कनेक्ट करने या इंटरनेट तक वायरलेस पहुँच की अनुमति देता है. Wi-Fi तेज है और ब्लूटूथ वायरलेस तकनीक से अधिक रेंज है और त्वरित ईमेल करने और इंटरनेट ब्रॉउज़ करने के लिए उपयोग किया जा सकता है.

नोट: LG-C375, WEP और WPA-PSK/2 एन्क्रिप्शन का समर्थन करता है, लेकिन EAP या WPS एन्क्रिप्शन का नहीं. यदि आपके Wi-Fi सेवा प्रदाता या नेटवर्क व्यवस्थापक, नेटवर्क सुरक्षा के लिए एन्क्रिप्शन सेट करते हैं, तो पॉप अप विंडो में कुंजी भरें. यदि एन्क्रिप्शन सेट नहीं है, तो यह पॉप–अप विंडो दिखाई नहीं देगी. आप अपने Wi-Fi सेवा प्रदाता या नेटवर्क व्यवस्थापक से कुंजी प्राप्त कर सकते हैं.

फ़ोन सॉफ़्टवेयर अपडेट

LG मोबाइल फ़ोन सॉफ़्टवेयर इंटरनेट से अपडेट होता है

इस फ़ंक्शन उपयोग करने के बारे में अधिक जानकारी के लिए, कृपया यहाँ जाएँ http://update.lgmobile.com या http://www.lg.com/common/index.jsp → देश का चयन करें.

यह सुविधा आपको सेवा केंद्र जाए बिना ही आसानी से इंटरनेट द्वारा अपने फ़ोन के सॉफ़्टवेयर को नवीनतम संस्करण से अपडेट करने की अनुमति देती है.

जैसा कि मोबाइल फ़ोन सॉफ़्टवेयर अपडेट को अपडेट प्रक्रिया के लिए उपयोगकर्ता के संपूर्ण ध्यान की आवश्यकता होती है, कृपया आगे बढ़ने से पहले प्रत्येक चरण पर प्रकट होने वाले निर्देशों और नोट्स की जाँच करना सुनिश्चित करें. कृपया ध्यान दें कि नवीनीकरण के दौरान USB डेटा केबल या बैटरी निकालना आपके मोबाइल फ़ोन को गंभीर रूप से क्षतिग्रस्त कर सकता है.

अपने फ़ोन को अपने PC के साथ सिंक्रनाइज़ करें

यह सुनिश्चित करने के लिए कि आपके सभी महत्वपूर्ण विवरण और दिनांक मेल खाएँ, लेकिन साथ ही साथ निशचिंत रहने के लिए अपनी फ़ाइलों का बैकअप रखने हेतू आप अपने फ़ोन को अपने PC के साथ सिंक्रनाइज़ कर सकते हैं.

अपने फ़ोन की जानकारी बैकअप करना और पुनर्स्थापित करना

1 अपने फ़ोन और PC से अपने USB केबल को कनेक्ट करें.

2 अपने फ़ोन के पॉप अप मेनू से PC सुइट का चयन करें और अपने PC में PC सुइट प्रोग्राम चलाएँ.

3 PC सुइट में "फ़ोन बैकअप और पुनर्स्थापना" (उपकरण > फ़ोन बैकअप और पुनर्स्थापना) पर क्लिक करें और बैकअप या पुनर्स्थापना का चयन करें.

4 आप जिस सामग्री को बैकअप या पुनर्स्थापित करना चाहते हैं उसे चिह्नित करें. उस स्थान का चयन करें जहाँ आप जानकारी को बैकअप करना चाहते हैं, या जहाँ से जानकारी को पुनर्स्थापित करना चाहते हैं. अब बैकअप या पुनर्स्थापना का चयन करें और समाप्त क्लिक करें.

5 आपकी जानकारी बैकअप या पुनर्स्थापित हो जाएगी.

नोट: प्रदान की गई CD का उपयोग करते हुए PC सुइट स्थापित करें और स्थापना मार्गदर्शिका का अनुपालन करें.

अपनी फ़ोन फ़ाइलों को अपने पीसी पर देखना.

1 अपने फ़ोन और PC से अपने USB केबल को कनेक्ट करें.

2 अपने फ़ोन के पॉप अप मेनू से PC सुइट का चयन करें और अपने PC में PC सुइट प्रोग्राम चलाएँ.

3 अपने PC में LG PC सुइट आइकन खोलें जो कि पहले ही से स्थापित है, फ़ोन खोजे जाने के बाद यह स्वचालित रूप से कनेक्ट किया जाएगा.

युक्ति! अपने फ़ोन की सामग्री को अपने PC पर देखने से आपको फ़ाइलों को व्यवस्थित करने, दस्तावेज़ों को संगठित करने और अब जिस सामग्री की आवश्यकता न हो उसे हटाने में मदद मिलती है.

सहायक उपकरण

आपके फ़ोन के लिए विभिन्न सहायक उपकरण उपलब्ध हैं. इनका विवरण नीचे दिया गया है.

चार्जर

बैटरी

डेटा केबल

उपयोगकर्ता मार्गदर्शिका

स्टीरियो हेडसेट

CD

नोट

- हमेशा प्रामाणिक LG सहायक उपकरणों का उपयोग करें.
- ऐसा नहीं करने पर आपकी वॉरंटी अमान्य हो सकती है.
- भिन्न क्षेत्रों में सहायक उपकरण भिन्न हो सकते हैं. अधिक पूछताछ के लिए कृपया हमारी क्षेत्रीय सेवा कंपनी या एजेंट से संपर्क करें.

तकनीकी डेटा

परिवेश के तापमान

अधिकतम्: +55°C (डिसचार्जिंग) +45°C (चार्जिंग)

न्यूनतम्: −10°C

Declaration of Conformity

LG Electronics

Suppliers Details

Name

LG Electronics Inc

Address

LG Twin Tower 20,Yeouido-dong, Yeongdeungpo-gu Seoul, Korea 150-721

Product Details

Product Name

GSM 850 / E-GSM 900 / DCS 1800 / PCS 1900 Quad Band Terminal Equipment

Model Name

LG-C375

Trade Name

LG

CE 0168

Applicable Standards Details

R&TTE Directive 1999/5/EC

EN 301 489-01 V1.8.1, EN 301 489-07 V1.3.1, EN 301 489-17 V2.1.1
EN 301 511 V9.0.2
EN 50360:2001/AC:2006, EN 62209-1:2006, EN 62209-2:2010
EN 60950-1:2006+A11:2009
EN300328 V1.7.1

Supplementary Information

The conformity to above standards is verified by the following Notified Body(BABT)

BABT, Forsyth House-Churchfield Road - Walton-on-ThamesSurrey - KT12 2TD , United Kingdom

Notified Body Identification Number : 0168

Declaration

I hereby declare under our sole responsibility that the product mentioned above to which this declaration relates complies with the above mentioned standards, regulation and directives

LG Electronics Inc. – EU Representative
Veluwezoom 15, 1327 AE Almere, The Netherlands

Name	Issued Date
Doo Haeng Lee / Director	18. May. 2011

Signature of representative

समस्या निवारण

यह भाग कुछ ऐसी समस्याएं सूचीबद्ध करता है जिससे आपका सामना अपने फ़ोन का उपयोग करते समय हो सकता है. कुछ समस्याओं में आवश्यकता होती है कि आप अपने सेवा प्रदाता से संपर्क करें, लेकिन अधिकतर समस्याएं जिनका आप सामना करते हैं, उसे स्वयं ही सही करना सरल होता है.

लक्षण	संभावित कारण	संभावित सुधार उपाय
नेटवर्क से कोई कनेक्शन नहीं	सिग्नल कमज़ोर है या आप संवाहक नेटवर्क से बाहर हैं.	किसी खिड़की या खुले स्थान पर ले जाएँ. सेवा प्रदाता कवरेज मैप की जाँच करें.
कोड्स मैच नहीं करते	यदि आप किसी सुरक्षा कोड को बदलना चाहते हैं, तो आपको नया कोड पुनरू दर्ज करके इसकी पुष्टि करनी होगी. जिन दो कोड्स को आपने दर्ज किया है वे मेल नहीं खाते हैं.	अपने सेवा प्रदाता से संपर्क करें.
फ़ंक्शन सेट नहीं किए जा सकते	सेवा प्रदाता द्वारा समर्थित नहीं या पंजीकरण आवश्यक है.	अपने सेवा प्रदाता से संपर्क करें.
कॉल्स उपलब्ध नहीं	डायलिंग त्रुटि या सेवा सीमाएँ.	डायल किया गया नंबर जाँचें और रिसेप्शन की जाँच करें. अपने सेवा प्रदाता से संपर्क करें.
कॉल्स उपलब्ध नहीं	डायलिंग त्रुटि नया सिम कार्ड डाला गया प्रीपेड चार्ज सीमा समाप्त	नया नेटवर्क प्राधिकृत नहीं. नए प्रतिबंधों के लिए जाँच करें. सेवा प्रदाता से संपर्क करें या PIN 2 के साथ सीमा रीसेट करें.
फ़ोन चालू नहीं किया जा सकता	चालूध्बंद कुंजी बहुत थोड़ी देर के लिए दबाई गई. बैटरी चार्ज नहीं है. बैटरी संपर्क गंदे हैं.	कम से कम दो सेकंड के लिए चालू/बंद कुंजी दबाएँ. बैटरी चार्ज करें. डिसप्ले में चार्जिंग सूचक की जांच करें. बैटरी संपर्कों को साफ़ करें.

समस्या निवारण

लक्षण	संभावित कारण	संभावित सुधार उपाय
चार्ज करने में त्रुटि	बैटरी पूर्ण रूप से खाली.	बैटरी चार्ज करें.
	संपर्क समस्या.	फ़ोन के लिए पॉवर पूर्ति और कनेक्शन जाँचें. बैटरी संपर्कों को जाँचें, यदि आवश्यक हो तो उन्हें साफ करें.
	आउट्लेट से बिल्कुल पॉवर नहीं.	भिन्न सॉकेट से प्लग इन करें या वॉल्टेज जाँचें.
	दूषित चार्जर.	अन्य चार्जर से परीक्षण करें.
	गलत चार्जर.	केवल असली LG सहायक सामग्री का उपयोग करें.
	दूषित बैटरी.	बैटरी बदलें.
नेटवर्क कनेक्शन खो गया है.	सिग्नल बहुत कमज़ोर है.	अन्य सेवा प्रदाता से पुन: कनेक्शन यदि यदि नेटवर्क मोड स्वचालित है.
नंबर की अनुमति नहीं है	फ़िक्सड डायल नंबर फ़ंक्शन चालू है.	सेटिंग्स मेनू जाँचें और फ़ंक्शन को बंद करें.

Chola MS
GENERAL INSURANCE

LG
Life's Good

CHOLAMANDALAM MS GENERAL INSURANCE CO. LTD.
Delhi Regional Office Plot no. 6, First Floor,Opp.
HP Petrol Pump, Near Metro Pillar No. 81
Pusa Road, Delhi - 110005

TO

DATE...../...../.....

CHOLAMANDALAM MS GENERAL
INSURANCE CO. LTD.
Delhi Regional Office Plot no. 6,
First Floor,Opp. HP Petrol Pump,
Near Metro Pillar No. 81 Pusa Road,
Delhi - 110005

Dear Sir,

RE: Loss of mobile phone no.: …….....…….

MAKE …….....…MODEL …….....…….....

This is to inform that my mobile phone has been lost due to theft on …….....…..at…….....….....…FIR/DD entry has been lodged with ..... Police Station. I am enclosing the Claim Form cum Bill along with required documents for settlement of the claims.

Thanking you

Yours Sincerely,

Signature of the Insured

Name

Chola MS
GENERAL INSURANCE

LG
Life's Good

CLAIM FORM CUM CLAIM BILL

To be filled in by the ultimate consumer

Name

Present Address

Tel. No.

Make & Model of the Handset

Invoice No. Date of Purchase

Dealer Name

Address

Tel. No.

IMEI No.

Date of Theft Time

Place of Theft

Details of Theft

FIR No./DD No. Date

Police Station

Amount Claimed

Block the SIM Card within 3 days YES ☐ NO ☐

DATE

PLACE SIGNATURE OF CUSTOMER

TERMS AND CONDITIONS:

POLICY COVERAGE

1. Theft coverage of LG GSM HANDSET for one year from the date of purchase/invoice only. No other loss covered.
2. Offer applicable on all purchases made from **April 7, 2011 to April 6, 2012.** under Policy No. **PBG-00030389-000-00. Dated 07/04/11**
3. Only theft registered under section 379 IPC or theft reported under Daily Dairy with Police FIR is covered.
4. Reimbursement will be subject to following depreciation/ deduction on the invoice value from date of purchase:

Handset upto 3 months old	-10%
More than 3 months upto 6 months	-15%
More than 6 months upto 9 months	-25%
More than 9 months upto 12 months	-35%

Chola MS
GENERAL INSURANCE

LG
Life's Good

CLAIM PROCESSING DOCUMENTS

In the event of handset loss, the buyer should follow the understated procedure:

a) (i) Lodge FIR under Section 379 IPC or theft to be entered in Daily Dairy with the Police Station in whose jurisdiction the theft occurred within 24 hours of occurrence of the same.

(ii) Block the SIM Card with your service provider within 3 days.

(iii) Send information to the insurance company within 7 days of the loss.

b) Documents required:

(i) Original Invoice & Cash Memo.

(ii) Original certified copy of DD/FIR u/s 379 by the police authority.

(iii) Translation of vernacular documents in English/Hindi.

(iv) Complete claim Form cum Bill and Discharge Voucher.

These documents should be sent to the Policy Issuing Office within 7 days of the loss by regd. post/courier. All document to be submitted in English/Hindi language. The company reserves the right to call for any other necessary document in addition to the documents listed above.

Subject to all the conditions being fulfilled, claim will be settled within 15 days of our receipt of the above documents.

Deduction of Rs. 350/- will be applicable towards accessories.

Chola MS
GENERAL INSURANCE

LG
Life's Good

Note: In case the handset cost is more than Rs. 20,000/-, a survey is required. Contact nearest office of Cholamandalam MS General Insurance Co. Ltd. for survey.

For any future queries assistance related to the policy exclusion and claim settlement you may write to Cholamandalam MS General Insurance Co. Ltd. **Delhi Regional Office Plot no. 6, First Floor,Opp. HP Petrol Pump, Near Metro Pillar No. 81 Pusa Road, Delhi - 110005**

Tel: +91-11-39813100, Fax: +91-11-39813110

e-mail id : customercare@cholams.murugappa.com

DISCHARGE VOUCHER

Received from Cholamandalam MS General Insurance Co. Ltd. under Policy No……..... in full and final discharge of our claim, the sum of …..……..…..... (in words) Rs.…….....

Signature of Insured /Customer Affix Re.1 revenue stamp across revenue stamp

Date:

Place:

Customer Information Center

For any query related to the after sales service and customer support please contact us at below details

LG 24 × 7 CALL CENTER

CALL 1800-180-9999 (Toll Free)

SMS 5757554 (Send SMS)

CLICK www.lg.com serviceindia@lge.com

Memo

Memo

Memo

Memo

Memo

Memo

Memo