LG
Life's Good

OWNER'S MANUAL

# AIR PURIFIER

Read before using product (safety instruction), use properly.
About ensuring users safety and property.
Product warranty card is enclosed with the user manual.
After careful read through the user manual, do keep it in a handy place.

PS-P800 Series

MFL67455103

www.lg.com

# The advantages are

It’s grateful to use our LG air purifier.
After reading through this manual, using this product for a long-term would be safe and convenient.

## Multidimensional Catalyst Sterilization System

- Sterilized by Washable HEPA filter Inside, and once again sterilized outside.
  Only LG air purifier can sterilize perfectly both inside and outside.

## Easy-use refreshing HEPA filter system.

- Easy to check out the filter status immediately through the convenient filter separating system.
- Don't worry about the filter becomes dirty. Use again after cleaning by water.

## Powerful Allergen filter

- The Allergen filter could absorbs and decomposes the ingredients which causes the allergy, having the allergy preventive effect also removing the odor and anti-bacteria effect.

# Table of Contents

## Before Use


❑ The advantages are ..... 2
❑ Cautions for Safety ..... 4~13
❑ Installation ..... 14
❑ Air purifier Start Guide ..... 15
❑ Name of Each Part ..... 16~19
– Mainframe
– Display and Controller
– Filters System
– Remote Controller
❑ Remote Controller Guide ..... 20
– First operation
– Battery Replacement
– Caution


## During Use


❑ Operation Mode ..... 21~24
– Air Purifying Operation
– Speed Mode
– Automatic Mode
– Quick Clean Mode
– Silent Mode
– Sandstorm Mode
❑ Additional Functions ..... 25~28
– ION Mode
– Filter Cleaning Function
– Off-timer Operation Function
– Filter Cleaning Lamp


## After Use


❑ Exterior and Dust Sensors Cleaning Method ..... 29
❑ Filter Cleaning ..... 30~31
❑ Dustbin Cleaning ..... 32
❑ Maintenance ..... 33
❑ Confirming Items Before Reporting Defect ..... 34~35
❑ Product Specification ..... 36

# Cautions for Safety

The following precautions related to safety marked as follows are to prevent unexpected danger or damage by safely and accurately using the product.

## Warning / Caution

| | |
|---|---|
| ⚠ | This is the symbol to get attention focused for the details and operations that can cause any type of danger. To prevent any danger, observe carefully and follow the directions appropriately. |
| ⚠ **WARNING** | If not followed, it can cause death or major injury to the user. |
| ⚠ **CAUTIONS** | If not followed, it can cause injury to the user or property damage. |

All batteries (whether installed or attached) should not be exposed to excess heat like sunlight or similar source.

# ⚠ Warning

## Installation

**Do not change or extend power cords at random.**
Otherwise, it may cause fire or electrical shock.

**Never use an octopus feet-type of socket.**
Unreasonable use of power may cause fire or electrical shock.

**Never use the damaged or loose power cords.**
Otherwise, it may cause fire or electrical shock.

**Open the window for air ventilation before operating the air purifier when gas leaks.**
Otherwise, it may cause explosion, fire and physical injury.

**Do not use the product a place where there are much moistures or oils such as toilet, bathroom or washing room.**
Otherwise, it may cause fire or electrical shock.

**Do not disassemble or repair the product at random.**
It will cause fire and electrical shock.

## Warning

**Don’t keep and use combustible gas, flammable substance around the product.**
Otherwise, it may cause fire and failure of product.

**Do not lay fire appliances around the product.**
Otherwise, it may cause fire.

**If abnormal noise comes or smell or smoke emits from the product, pull the power plugs out and call our service center.**
Otherwise, it may cause fire or electrical shock.

**Keep this product out of the direct rays of the sun, heating source and moisture.**
Otherwise, it may cause electric shock, fire or failure of product.

**Don’t put heavy things on power cords or take care so that they should not be pressed under the product.**
Otherwise, it may cause fire or electrical shock.

# Warning

## Operation

**Securely insert power plugs to the end so that they should not shake.**
Incomplete connection may cause fire.

**Pull power plugs by grasping the head and never touch with power plugs with the wet hands.**
Otherwise, it may cause electrical shock or physical injury.

**Never damage, process, forcedly bend, twist, pull, lay between gaps or heat power cords.**
Damaged cords may cause fire and electrical shock.

**Do not hold the power cable to pull out the power plug.**
May cause fire or electric shock.

**Do not install a place where there are much industrial Oil dust or metallic dust.**
If may cause fire and failure of product.

**When the power code is damaged, it should be repaired by the qualified person to prevent any risk.**
Otherwise, it may cause electric shock, fire or failure of product.

**Keep in Mind that water should not run into the product.**
Otherwise, it may cause electrical shock or fire.

## Warning

**Do not lay obstacles around the product.**
Otherwise, it may cause failure.

**Do not cover with a rug, cushion etc over power cords.**
Power cords may be damaged and result in fire and electrical shock in case of putting heavy things on in the manner power cords cannot be seen.

**Do not use thermal appliances near power cords.**
Otherwise, it may cause fire or electrical shock.

**Do not allow children to climb up this product.**
May cause the breakdown, injury.

**Do not sprinkle in insecticide or hair spray.**
It may cause damage or accident.

**Do not use this product when is in moving.**
May cause fire or electric shock or damage to some parts of the product.

## ⚠ Warning

**Do not move the product by holding the front-panel.**
May cause electric shock or damage to some parts of the product.

**Do not put coffee or all types of beverage on the air discharge outlet.**
Otherwise, it may cause fire or electrical shock.

**Contact with the service center for repairing the product.**
Any arbitrary disconnection or repairing may cause electric shock or fire.

**Do not put pressure on the front glass.**
It can cause injury and product damage or cause electric shock.

**Do not insert the hands or bars into the suction inlet or the outlet.**
Otherwise, it may cause failure of product or physical injury.

**If the product is submersed in the water, you must contact the service center.**
It can cause electric shock or fire.

# Cautions

## Installation

**Maintain distance of more than 1m when installing the product near TV or audio.**

**Avoid a place near fire arms or heating devices or subject to direct sunlight.**
It will cause fire.

**Do not use the product for removing toxic gas as CO.**
Otherwise, it may cause failure.

**Do not use the product as ventilation fan or range hood at the kitchen.**
It may cause shorten the lifetime of the product.

**Install the product at a flat place and do not drop the product.**
Otherwise, it may cause damage or accident.

**Maintain a minimum distance of 1.5m from any heat producing light source. For proper ventilation, maintain a distance of 10cm or more from a wall.**

## Cautions

**Do not use except AC 220-240 V.**
Otherwise, it may cause fire or electrical shock.

**When using the product with a burner within the airtight room, sometimes let fresh air into the room.**
Some toxic substances such as carbon dioxide may not be removed.

**Do not install the air purifier on the transportation vehicle (car, ship etc.).**
It may cause failure.

# Cautions

## Operation

**Do not use the product for special purpose such as animals or vegetables, precision machine or conservation of art articles.**
Otherwise, it may cause damage of property.

**Don't use strong detergent like solvent, etc but use a soft cloth.**
Otherwise, fire or distortion of the product may occur.

**Never operate or stop the product while inserting or removing power plugs.**
Otherwise, it may cause electrical shock or fire.

**Pull power plugs out when not using the product for a long time.**
Otherwise, it may cause failure of product or fire.

**Use it with the large particles filter firmly secured and clean once every 6 months.**
It may cause failure of product.

**Secure all filters and regularly clean them.**
Otherwise, it may cause failure of product.

**Start cleaning after turning off the power and when the fan stops.**
It can cause electric shock or injury.

## Cautions

**Do not let the moisture from the humidifier directly touch the product.**
Otherwise, it may cause electric shock, fire or failure of product.

**Do not use this product as ventilating fan or so.**
It may cause shorten the lifetime of the product.

**Pull power plugs out for cleaning.**
Otherwise, it may cause fire and electrical shock.

**Do not open the front panel during the operation of the product.**
Opening the front panel stops the operation.

**Keep batteries out of the reach of children after removing batteries from remote controller.**
Ensure batteries out of the reach of children. If children swallow the batteries, contact the doctor immediately.

**Wash the washing filter and dry it completely in the shade.**
Otherwise, it may cause failure.

**Do not insert any inflammable into the product.**
Otherwise, it may cause fire or failure of product.

# Installation

## Places to Install

**Mainframe**

- places with handy power connections
- places with no obstacle to clog air inlet
- places with horizontal surface and rich air circulation

**⚠ Warning**

Install the air purifier on moving objects (car or ship etc) may cause the product defect, therefore do not install on those places.

**⚠ Warning**

This appliance is not intended for use by persons (including children) with reduced physical, sensory or mental capabilities, or lack of experience and knowledge, unless they have been given supervision or instruction concerning use of the appliance by person responsible for their safety.

Children should be supervised to ensure that they do not play with the appliance.

# Air Purifier Start Guide



## Turn off air purifier when cleaning.

• Cleaning the air purifier with opened windows would disturb the natural air circulation to cause intake too much particles, it may shorten the filter life. After complete cleaning process with enough air circulation, close the windows, turn on the air purifier is the appropriate way to purify air.

## Use after enough air circulation when cooking

• When roast meat or fishs, remove the smell by air purifier is not appropriate. The oil particle will block cells on filter, it may cause filter life shorten or filter polluting etc. negative effects. Under this circumstance enough air circulation is necessary. Remove leftover odors by air purifier after no oil particle is the correct and effective way to use product in long-term scale.

## Do not stay too closed when sleeping.

• Air purifier fan speed is not strong, before fallen asleep feel cool, after fallen asleep would feel cold. The appropriate way is to keep at least 1 meter distance with air purifier.

## Do not place in the corner edge.

• Avoid to install at places surrounded by furniture, appliances etc. or in the edge corner. Install in the edge corner may cause difficulty to purify indoor air from the rest space.

## Ensure air circulate 30 minutes at least everyday.

• For those families use the air purifier, air circulation is the prerequisite to ensure enough oxygen supply. Ensure air circulation 30 minutes at least everyday could brings fresh air inflow. Keep opposite windows open may gain a better result for air circulation. In case of being lazy may weaken air refreshing function, therefore it is necessary to ensure clean and maintenance.

# Name of Each Part

## Mainframe

## Operation Display and Controller

# Name of Each Part

## Filter system (It introduces only filter part.)

| Filter name | Function |
|---|---|
| **1 Large particles filter** | It is filter for large particles removal and is done with anti-biotic treatment, which helps the life extension. |
| **2 Allergen filter** | It absorbs and decomposes Allergen which could cause allergy. |
| **3 Washable carbon deodorization filter** | The comprehensive deodorization filter removes cigarette smoke(odor), putrid food smell, animal hair odor, NO2, toilet odor, alkali & acid smell, organic compound(VOCs). |
| **4 Washable HEPA filter** | Washable HEPA filter removes minute particles such as acarid dead body, pollen, cigarette smoke(particles), minute dust, floating fungus, animal hair and so on. |

※ For washable filter, please dry it completely in a shade without any dampness
(The dry time depends on the seasons. If it is not completely dried, it may cause failure or bad odor.)
※ When the pollution of washable filter is so serious and it is impossible to be clean after washing, it is better to replace it with new one.
※ The filter washing and replacement cycles may depend on the user environment.

# Name of Each Part

## Remote Controller

**Power On/Off button**
button uses to start or close this product

**Fan speed button**
Set Fan speed

**Operation Mode Button**
Operation Selection (Manual, Automatic, Speed Purification, Sleep, Yellow Sandstorm)

**Off timer Button**
It sets the time to turn off the purifier.

**ION button**
It sets the sanitization function.

**How to use the remote controller**

When using the remote controller, direct the remote controller to the remote controller receiver part of the main unit.

# Remote Controller Guide

## First operation of remote controller

Pull the plastic-bag cap for battery protection lower and remove it.

## Battery replacement

Open the battery lid

Ensure to install batteries as instructed

Close the battery lid

## Caution

**Press only 1 key at one time**
Press several keys at the same time, the remote controller does not work properly

**Do not stand on the remote controller or punch it**

**Do not use at places have water or humid**

**Do not use near fire source or heating source**

- Remove batteries when the product is stored for an extended period of time. In the unlikely event that battery fluid leak may cause remote controller defect.
- Replace all batteries of a set at the same time. Contact the post-sales service center if remote controller defect occurs after replacing batteries.

# Operation Mode

## Air Purifying Operation Purify Indoor Air.

**1 Press On/Off button, after a 'DI-RI-LIN' sound, start working as the led light on.**

(Reference according to the following 'preparatory operation' category)
The air outlet on top will exhaust fresh air.

- Press On/Off button again to turn off.
- When connect the power supply plug, there will be a 'DI-RI-RI-LIN' reminding sound.

### What is 'preparatory operation'?

During the 2 minutes after turning on, preparatory operation starts when sensor is initiating.
Dust/odor indicator level are up and down during the preparatory operation.

# Operation Mode

## Speed mode User may manually adjust fan speed.

**1 Press On/Off button.**

**2 Switch to the speed mode by pressing the mode button.**

**3 Press the fan speed button to choose expected fan speed**

- Default fan speed is weak.
- When restart under speed mode, system will retrieve to the previous fan speed.
  Fan speed has ‘weak-soft-strong-turbo’ 4 modes.
  (Switch to the next mode according to the Up-to-Down sequence.)

## Automatic mode Air Purifier will automatically set the most appropriate Fan speed.

**1 Press On/Off button.**

**2 Switch to the automatic mode by pressing the mode button.**

- Auto-control fan speed, no more attention to manage.
- Press fan speed button under automatic mode will switch to speed mode and increase fan speed by one level.
- Except for the fan speed function, users need to set the rest functions.

## Quick Clean Mode

It operates strongly in a moment and purifies indoor air.

**1 Press On/Off button.**

**2 Switch to the quick clean mode by pressing the mode button.**

- When pressing airflow button in the speed purification operation, it switches into the manual operation and it operates on “LOW” condition.
- In the speed Purification Operation, it works in the turbo mode for around 10 mins, then changes into the auto mode.

## Silent Mode

Provide quiet indoor atmosphere while sleeping.

**1 Press On/Off button.**

**2 Switch to the silent mode by pressing the mode button.**

- Fan speed will switch to weak level under sleep mode, sleeping light on the LED indicator will be on 3 seconds later.
- Press fan speed button will switch to speed mode and increase fan speed by one level.

## Sandstorm Mode Purify indoor air effectively when the sandstorm occurs.

**1 Press On/Off button.**

**2 Switch to the sandstorm mode by pressing the mode button.**

- Press fan speed button under yellow sandstorm mode will switch to speed mode and increase fan speed by one level.
- Fan speed will be controlled according to previously inputted sequence.
- In addition to fan speed function, users need to set the rest functions.

# Additional Function

## ION Mode

It generates sterilization ion which is harmless and removes various bacteria.

**1 Press On/Off button.**

**2 Press the ION button to choose expected function.**

- Whenever press one time, it switches to sanitary purification → deactivation → sanitary purification in order.

## Filter Cleaning Function Remove large particles.

When operating Filter Cleaning Function, the purifier operation stops. The cleaning brush for large particles filter starts rotating to remove the particles settled on the filter.
The particles removed from the large particles filter come together into the dustbin lower.
Clean the dustbin periodically.
Refer to page 32 for the dustbin cleaning.

### For automatic operation

- It operates automatically filter cleaning after use for a certain period. You don't need to do separate operation.
- It shows 5 minutes on the operation display and performs cleaning filter for specified time.
- It doesn't activate while sleep operation.

### For manual operation

**1 Press Filter clean button.**

- It starts filter cleaning in 5 seconds.
- It shows 5 minutes on the operation display and performs cleaning filter for specified time.
- Whenever press one time, it switches into Filter Cleaning → Deactivation → Filter Cleaning in order.
- When you want to operate the purifier while cleaning filter, press the Filter Cleaning button once again to cancel.

## Off-timer Operation Function

Automatically shut down after sleeping several hours.

**Example:shut down automatically after 3 hours**

**1 Press On/Off button.**

**2 Press timer button to set 3 hours.**

- Each time pressing the button, operation time will increase 1 more hour.

- Maximum reservation time is 9 hours.
- Shut down automatically.

- Automatically shut down 3 hours later.

## Filter Cleaning Lamp

It will let you know filter cleaning cycle and its replacement cycle after use for a certain period.

1. **When turning on Filter Washing Lamp, open the front panel while operating the purifier and check the filter. If it is polluted, wash or replace it.**
2. **When opening the front panel after stopping its operation by pressing (ON/OFF) button, it doesn't turn off the filter washing lamp. Open the front panel to check while operating the purifier.**
3. **Refer to the pages 30-31 for the detail of filter washing.**

- The filter condition may depend on the user environment.
- When closing the front panel after checking it, it switches the air flow to “LOW”.

# Exterior and Dust Sensors Cleaning Method

## Exterior Cleaning Method

Soak soft cloth with warm water, wipe the air purifier after wring dry.

**Caution**
- Do not clean mainframe controller and indicator by alkaline liquid.
- Do not wipe air purifier's surface by vitriol, hydrochloric acid or organic solvent.

## Dust sensor cleaning method

The dust sensor is a device that senses the minute and large dust particles. The lens part must be periodically cleaned to maintain the performance.

**1 Open the front panel.**

**2 Open the dust sensor cover.**

**3 Wipe the lens of the dust sensor with a cotton stick.**

After cleaning the lens, close the cover of the dust sensor in the reverse order.

Clean the lens of the dust sensor once every 6 months.
But the cleaning frequency can differ according to the using environment and time. So in an environment where it is dusty, clean more frequently.

# Filter Cleaning

1. **Ensure to shut down before cleaning. Hold knob then pull forward, open the front panel.**
2. **Lift the knob of dustbin to the upper direction to pull it out.**
3. **Pull the filter case out of the main unit.**
4. **Place the filter case down on the even ground and lift the fixed hanger of big particles filter to the upper direction to open it.**
5. **Disassemble large particles filter.**
6. **Clean the dissembled filter according to the filter cleaning method of the next page.**

**Caution**

- For your safety, unplug the power before cleaning.
- After cleaning with water, completely dry the product under a shade. (If it is not dried completely, it may cause amalfunction)
- Replace the filter when it is impossible to clean it due to over clogging.
- If the filter is not dried completely after cleaning, it may cause a bad odor.
- Please, do not rub the product with your hand.

# Filter Cleaning

## Filter Cleaning Method Filter maintenance may vary depending on the environment.

| Filter Category | Classification | Washing & replacement cycle | Cleaning Method | |
|---|---|---|---|---|
| **Large particles filter** | **For washing** | **Around 6 months washing cycle** | You don't need to clean separately, thanks to the filter cleaning function. However, when you clean other filters by the vacuum cleaner or water, just clean together with this filter. You can use more cleaned one. | **Picture 1** |
| **Allergen filter** | **For washing** | **About a month washing cycle** | Using a natural detergent and water to clean it off. | **Picture 2** |
| **Deodorization filter** | **For washing** | **Around 6 months washing cycle** | Soak the filter in warm water for 1 hour.<br>Remove particles from the filter by shaking the water from the filter. | **Picture 3** |
| **HEPA filter** | **For washing** | **Around 6 months washing cycle** | Rinse washable HEPA filter by shower machine. | **Picture 4** |

1 Large particles filter

2 Allergen filter

3 Deodorization filter

4 HEPA filter

# Clean the dustbin (Cover the front panel after cleaning dustbin. Please cover it tightly, otherwise it doesn't operate.)

1 **Ensure that you turn off the power while operation.**
**Pull the front panel forward to open.**

2 **Lift the knob of dustbin to the upper direction to pull it out.**

3 **Empty the dustbin.**

4 **To settle the dustbin, you should fit the side hole of dustbin into the guide of large particles filter.**

# Maintenance

**1 Ensure to run air purifier over 1 hour in shiny day, press On/Off button to shut down.**

**2 Plug out the power.**

**3 Ensure to clean and protect air purifier's mainframe. Use vinylbag to pack when store air purifier for an extended period of time, avoid dust or particle enter interior.**

Clean by soft cloth.
Scratch may easily cause exterior damage.

# Confirming Items Before Reporting Defect

When product goes wrong, before contacting the service center please confirm the following items.

| Symptom | Confirmation | Procedures |
|---|---|---|
| **Total malfunction** | • Has the power plug been pulled out? | • Correctly connect with power point. |
| | • Does the remote controller have problems? | • Replace the battery or adjust the battery(+, -) pole. |
| | • Is the power fuse broken? | • Ask for assistance from service center. |
| | • Whether the front panel open or not? | • Stop working when front panel is opened, close it completely. (Left/right close) |
| **Low fan speed with cacophony** | • Whether too much dust clog on the HEPA filter or not?<br>• Whether too much dust clog on the Allergen filter? | • Wash filter according to its cleaning cycle and the Allergen filter should be replaced by its cycle. |
| **The off-timer doesn't set.** | • Whether checked the operation indicator or not? | • Set again according to manual. |
| **Air purify function do not work well** | • Whether indoor air pollution is too severe or not? | • Use after enough air circulation. |
| | • Is filter polluted? | • Wash by clean water. (Do not use over 40 degrees hot water or volatile solvent) Dry completely at shadowed place, avoid places near fire source or direct illumination. |
| | • Whether using environment is too spacious or not? | • Use at appropriate space. (Avoid to use at well-ventilated places such as exit and entrance and window etc.) |
| | • Whether there are surrounding obstacles or not? | • Remove obstacles. |
| | • Whether install at non-ventilated places or not? | • Install at other places. |
| **The button doesn't work properly.** | • Check if your hand(s) wear(s) mittens and etc? | • Use it after removing any strange things including mittens. |

# Confirming Items Before Reporting Defect

| Symptom | Confirmation | Procedures |
|---|---|---|
| **Air outlet has abnormal smell.** | • Is it the smell that gives off right after buying the product? | • It is the smell of active carbon. It would be gone in 1-2 weeks after operating the product. The smell isn't harmless. (It is the phenomenon same as the first smell of new car.) |
| | • Whether complete dry washable filter or not? | • Wet washable filter may cause odor, please use after complete dry. |
| | • Whether use at place with food odor or not? | • Food odor may penetrate into filter, use after enough air circulation. |
| | • Whether use at smoky, odor places or not? | • Use at smoky, odor places may cause weaken air purifying function. |
| **Sensor indicator has problem.** | • Dust sensor keeps high level always. | • Clean dust sensor or filter. |
| | • Odor sensor level goes up? | • LG air purifier is designed to detect polluted air, therefore odor sensor may not react to food odors. But odor removing filter will remove odor. Steam particle from cooking or boiling water may cause odor sensor level goes up. |
| | • Does the numbers of dust sensor and smell sensor keep moving up and down? | • It is the preliminary operation phenomenon to stabilize the initial sensor working during 2 min. after starting the operation.<br>In 2 mins., the working stops and the sensor operates (Refer to page 21). |

# Product Specification

The external dimension, design and product standard can change to improve the quality of the product.

| | |
|---|---|
| **Model Name** | PS-P800 Series |
| **Power Supply** | 220-240 V~ 50/60 Hz |
| **Weight of Product** | 15 kg |
| **Appearance Size(mm)** | 475 (Width) x 680 (Height) x 300 (Depth) |
| **Power consumption** | 90 W |

LG
Life's Good

دليل المالك

# منقي الهواء

اقرأ قبل استخدام المنتج (تعليمات السلامة، واستخدمه بشكل صحيح.
بشأن ضمان سلامة المستخدمين والممتلكات.
بطاقة ضمان المنتج مرفقة مع دليل المستخدم.
بعد القراءة المتأنية لدليل المستخدم؛ احتفظ به في متناول اليد.

الفئة PS-P800

MFL67455103

www.lg.com

# المميزات

مندو اعي الفخر استخدام منقي الهواء من LG.
بعد القراءة الشاملة لهذا الدليل؛ فإن استخدامهذا المنتج لفترة طويلة يعد آمنًا وملائماً.

## نظام التعقيم الحفاز متعدد الأبعاد

– معقم من الداخل بواسطة فلتر HEPA القابل للغسل، ومعقم أيضًا من الخارج.
يستطيع فقط معقم الهواء LG العقيم بشكل كامل من الداخل والخارج.

## نظام مرشح HEPA المنعش سهل الاستخدام.

– سهولة التعرف الفوري على حالة المرشح من خلال نظام فصل المرشح المتميز.
– لا تقلق بشأن اتساخ المرشح. حيث يمكن استخدامه مرة أخرى بعد تنظيفه بالماء.

## مرشح قوي مقاوم للحساسية

– يمكن لهذا المرشح امتصاص وتحليل المكونات المسببة للحساسية، مما له الأثر الوقائي بالإضافة إلى منع آثار الروائح والبكتيريا.

# جدول المحتويات



## قبل الاستخدام


- ❑ المميزات.....2
- ❑ تعليمات السلامة.....4~13
- ❑ التركيب.....14
- ❑ دليل بدءمنقي الهواء.....15
- ❑ أسماء قطع الغيار.....16~19
  - – الهيكل الأساسي
  - – عرض التشغيل والتحكم فيه
  - – نظام الفلتر
  - – وحدة التحكم عن بعد
- ❑ دليل وحدة التحكم عنبعد.....20
  - – التشغيل الأول لوحدة التحكم عن بعد
  - – استبدال البطارية
  - – تنبيه


## أثناء الاستخدام


- ❑ وضع التشغيل.....21~24
  - – تشغيل تنقية الهواء
  - – وضع السرعة
  - – الوضع التلقائي
  - – وضع تنظيف سريع
  - – وضع هادئ
  - – وضع عاصفة رملية
- ❑ وظائف إضافية.....25~28
  - – وظيفة أيون
  - – وظيفة تنظيف الفلتر
  - – وظيفة تشغيل مؤقت الإيقاف
  - – مصباح تنظيف الفلتر


## بعد الاستخدام


- ❑ وضع تنقية الهواء طريقةتنظيفـمستشعراتالترابـوالجسم الخارجي.....29
- ❑ تنظيف المرشح.....30~31
- ❑ تنظيف الأتربة.....32
- ❑ الصيانة.....33
- ❑ التأكد من العناصر قبل الإبلاغ عن العيب.....34~35
- ❑ مواصفات المنتج.....36

# تنبيهات السلامة

تم وضع تحذير ات السلامة كما هي موضحة أدناه للمنع المسبق لأية مخاطر غير متوقعة أو تلف وذلك عن طريق استخدام المنتج بسلامة ودقة.

## تحذير/ تنبيهات

⚠ هذا الرمز لتركيز التنبيه على التفاصيل وعمليات التشغيل التي من شأنها أن تتسبب في أي نوع من الأخطار. ولمنع أي خطر، اتبع التوجيهات بعناية وبطريقة مناسبة.

⚠ **تحذير** في حالة عدم الاتباع، فقد يؤدي ذلك للوفاة أو إصابات خطيرة للمستخدم.

⚠ **تنبيه** في حالة عدم الاتباع، فقد يؤدي ذلك إلى إصابات للمستخدم أو تلف للمتلكات.

جميع البطاريات (سواء كانت مثبتة أو ملحقة) لا يجب تعريضه للحرارة الزائدة مثل ضوء الشمس أو أي مصدر مشابه.

# ⚠ تحذير

## التركيب

**لا تقم بتعديل أوتغيير طول سلك التيار الكهربي بطريقة عشوائية.**

وإلا سيتسبب ذلكفي حدوث حريق أو ماس كهربائي.

**استخدم القابس المخصص لقابسالهواء. (لا تستخدم قابس طراز أرجل الأخطبوط.)**

فالاستخدام غير المعقول للتيار الكهربي سيتسبب في حدوث حريق أو ماس كهربائي.

**لا تستخدم أسلاك كهربية تالفة أو بالية.**

وإلا سيتسبب ذلك في حدوث حريق أو ماس كهربائي.

**افتح النوافذ لتهوية الهواء قبل تشغيل منقي الهواء عند تسرب الغاز.**

وإلا قد يتسبب ذلك في حدوث انفجار وحريق أو إصابة جسدية.

**لا تستخدم المنتج في مكان يكون فيه رطوبة عالية أو زيوت مثل الحمامات أو المغاسل.**

وإلا سيتسبب ذلك في حدوث حريق أو ماس كهربائي.

**لا تقم بفك المنتج أو إصلاحه بطريقة عشوائية.**

قد يؤدي ذلك إلى حدوث حريق أو ماس كهربائي.

## ⚠ تحذير

**لا تحتفظ وتستخدم غاز قابل للاحتراق أو مواد قابلة للاحتراق حول المنتج.**

وإلا قد يتسبب ذلك في حدوث حريق وتعطل المنتج.

**لاتضع أجهزة نارية حول المنتج.**

قد يؤدي ذلك إلى حدوث حريق.

**في حالة صدور ضوضاء غريبة أو رائحة أو انبعاث دخان من المنتج، انزع مقبس التيار الكهربي واتصل بمركز الخدمة.**

وإلا سيتسبب ذلك في حدوث حريق أو ماس كهربائي.

**احتفظ بهذا المنتج بعيداً عن أشعة الشمس المباشرة، أو مصدر الحرارة أو الرطوبة.**

وإلا فقد يؤدي ذلك إلى صدمة كهربائية، أو حريق أو تعطل المنتج.

**لا تضع أشياءً ثقيلة على أسلاك التيار الكهربي أو توخى الحرص بحيث لا يتم الضغط عليها أسفل المنتج.**

وإلا سيتسبب ذلك في حدوث حريق أو ماس كهربائي.

# ⚠ تحذير

## التشغيل

**أدخل مقابس التيار الكهربي بإحكام حتى النهاية وذلك حتى لا تتحرك.**

فالتوصيل غير المكتمل قد يؤدي إلى حدوث حريق.

**انزع مقابس التيار الكهربي بإمساكها من الرأس ولا تلمسها أبداً ويداك مبتلتان.**

وإلا، قد يسبب ذلك صدمة كهربية أو إصابة جسدية.

**لا تتلف أسلاك التيار الكهربي أو تلويها بعنف أو تضعها بين الشقوق أو تسخنها.**

فأسلاك التيار الكهربي التالفة قد تؤدي إلى حدوث حريق أو ماس كهربائي.

**لا تمسك من الكابل عند سحب مأخذ الكهرباء.**

فقد يتسبب ذلك في حدوث حريق أو صدمة كهربية.

**لا تركب هذا المنتج في مكان يكثر به تراب الزيوت الصناعية أو تراب المعادن.**

وإلا قد يتسبب ذلك في حدوث حريق وتعطل المنتج.

**عند تلف سلك الطاقة، فيجب إصلاحه من قبل شخص مؤهل لمنع أي مخاطرة.**

وإلا فقد يؤدي ذلك إلى صدمة كهربائية، أو حريق أو تعطل المنتج.

**احرص علىألا يتسرب الماء داخل الجهاز.**

وإلا فقد يؤدي ذلك في حدوث صدمة كهربائية أو حريق.

## ⚠ تحذير

**لا تضع عوائق حول المنتج.**

وإلا قد يؤدي ذلك إلى تعطل المنتج.

**لا تضع سجادة أو وسادة على أسلاك التيار الكهربي.**

فقد تتلف أسلاك التيار الكهربي مما يؤدي إلى صعق كهربي في حالة وضع أشيا ءثقيلة بطريقة لا يمكن معها رؤية أسلاك التيار الكهربي.

**لا تستخدم أجهزة حرارية بالقرب من أسلاك التيار الكهربي.**

وإلا سيتسبب ذلك في حدوث حريق أو ماس كهربائي.

**لا تسمح للأطفال بتسلق هذا المنتج.**

فقد ينكسر وينجرحون.

**لا تنضح المنتج بمبيد حشرات أو رذاذ الشعر.**

فقد يؤدي ذلك إلى تلف المنتج أو حادثة.

**لا تستخدم هذا المنتج أثناء النقل.**

فقد يتسبب ذلك في حدوث حريق أو صدمة كهربائية أو تلف بعض أجزاء المنتج.

## ⚠ تحذير

**لا تحرك المنتج بإمساك اللوحة الأمامية.**

فقد يتسبب ذلك في ماس كهربائي أو تلف بعض مكونات المنتج.

**لا تضع أي أثقال من شأنها الضغط على الزجاج الأمامي.**

فقد يؤدي ذلك إلى الإصابة أو تلف المنتج أو صدمة كهربائية.

**لاتضع قهوة أو كل أنواع المشروبات على منفذ إخراج الهواء.**

وإلا سيتسبب ذلك في حدوث حريق أو ماس كهربائي.

**لا تدخل يديك أو القضبان داخل فتحات دخول الهواء أو خروجه.**

وإلا، قد يسبب ذلك تعطل المنتج أو إصابة جسدية.

**اتصل بمركز الخدمة لإصلاح المنتج.**

فقد يؤدي أي فصل أو إصلاح غير مؤهل إلى حدوث صدمة كهربائية أو حريق.

**في حالة غمر المنتج بالماء، يجب الاتصال بمركز الخدمة.**

فقد يؤدي ذلك إلى حدوث صدمة كهربائية أو حريق.

## تنبيه

### التركيب

**احتفظ بمسافة 1 متر عند تركيب المنتج بالقرب من التلفاز أو الر اديو.**

**تجنب الأماكن القريبة من ألسنة النار أو أجهزة التسخين أو تعريض المنتج لأشعة الشمس المباشرة.**

قد يؤدي ذلك إلى حدوث حريق.

**لا تستخدم المنتج في إزالة غاز سام مثل الكاربون.**

وإلا قد يؤدي ذلك إلى تعطل المنتج.

**لا تستخدم المنتج كمروحة للتهوية أو موقد مسطح للطعام في المطبخ.**

فقد يؤدي ذلك إلى تقصير عمر المنتج.

**ركب المنتج في مكان مستوى ولا تسقطه أو تخبطه.**

وإلا قد يؤدي ذلك إلى تلف المنتج أو حادثة.

**احتفظ بمسافة 1.5 متر من أجهزة الإزالة واحتفظ بمسافة 10 سم أو ما يقرب من ذلك.**

## تنبيه

**لا تستخدم أي فولطية غير 220-240 فولط.**

وإلا فقد يتسبب ذلك في حدوث حريق أو صدمة كهربائية.

**عند استخدام المنتج مع مضرم داخل حجرة محكمة التهوية، فقم بتهوية الحجرة من وقت لآخر.**

في الأماكن محكمة التهوية، لا يتم إزالة بعض المواد السامة مثل ثاني أكسيد الكربون.

**لا تقم بتركيب منقي الهواء على حافلة نقل (السيارة، السفينة، إلخ).**

فقد يؤدي ذلك إلى تعطل المنتج.

## تنبيه

### التشغيل

**لا تستخدم الجهاز في أغراض خاصة مثل الحيوانات أو الخضروات أو آلة الضبط أو حفظ الأعمال الفنية.**

وإلا قد يؤدي ذلك إلى تلف المنتج.

**لا تستخدم منظفات قوية مثل المذيبات، ولكن استخدم قطعة قماش ناعمة.**

وإلا فقد يحدث حريق أو تشوه للمنتج.

**لا تشغل المنتج أو توقف تشغيله أثناء إدخال مقابس التيار الكهربي أو نزعها.**

وإلا سيتسبب ذلك في حدوث حريق أو ماس كهربائي.

**انزع مقبس التيار الكهربي في حالة عدم لفترة طويلة.**

وإلا، قد يسبب ذلك تعطل المنتج أو حريق.

**للاستخدام مع فلتر الجسيمات الكبيرة بحيث يؤمن بإحكام، وينظف مرة كل 6 أشهر.**

قد يتسبب هذا في تعطل المنتج.

**أحكم تثبيت كافة المرشحات ونظفها بشكل دوري.**

وإلا فقد يؤدي ذلك إلى تعطل المنتج.

**ابدأ التنظيف بعد إيقاف تشغيل الطاقة وعند توقف المروحة.**

يمكن أن يتسبب في التعر ض لصدمة كهربائية أو للإصابة.

## تنبيه

**لا تترك الرطوبة تتسرب من المرطب لملامسة المنتج مباشرة.**

وإلا فقد يؤدي ذلك إلى صدمة كهربائية، أو حريق أو تعطل المنتج.

**لا تستخدم هذا المنتج كمروحة للتهوية أو ما إلى ذلك.**

يؤدي ذلك إلى تقصير عمر المنتج. فقد

**انزع مقابس التيار الكهربي للتنظيف.**

وإلا سيتسبب ذلك في حدوث حريق أو ماس كهربائي.

**لا تفتح اللوحة الأمامية أثناء تشغيل المنتج.**

ففتح اللوحة الأمامية يوقف التشغيل.

**احتفظ بالبطاريات بعيداً عن متناول الأطفال بعد إخراجها من وحدة التحكم عن بعد.**

أو صدمة كهربائية.تأكدأن البطارياتليستفي متناول الأطفال.

إذا ابتلع الأطفال البطاريات؛ فاذهب للطبيب فوراً.

**اغسل المرشح القابل للغسيل ثم جففه تماماً في الظل.**

وإلا فقد يؤدي ذلك إلى تعطل المنتج.

**لا تدخل أية مواد قابلة للاشتعال داخل المنتج.**

وإلا فقد يؤدي ذلك إلى حدوث حريق أو تعطل المنتج.

# التركيب

## أماكن التركيب

**الهيكل الأساسي**

- الأماكن ذات الوصلات الكهربية القريبة
- الأماكن الخالية من عوائق مداخل الهواء
- الأماكن ذات السطح الأفقي وحركة الهواء الكثيرة

**تحذير** تركيب منقي الهواء على أجسام متحركة (سيارة أو سفينة، إلخ) يؤدي إلى إتلاف المنتج، ولذا لاتر كبه في تلك الأماكن.

**تحذير** هذا الجهاز غير معد للاستخدام من قبل الأشخاص (بما في ذلك الأطفال) ذوي القدرات الصحية المحدودة، أو الذين يعانون من فرط في الحساسية، أو الاضطرابات العقلية، أو ذوي الخبرة والمعرفة المحدودة، دون إشراف أو تعليمات فيما يتعلق باستخدام الجهاز من قبل الأشخاص المسؤولين عن سلامتهم.

يجب الإشراف على الأطفال للتأكد من عدم عبثهم بالجهاز.

# دليل بدء منقي الهواء

## أوقف منقي الهواء عند التنظيف.

• تنظيف منقي الهواء مع فتح النوافذ يؤدي إلى تغيير دورة الهواء الطبيعي ودخول أجسام كثيرة جداً، ويقلل من عمرالمرشح. إتمام عملية التنظيف في دورة الهواء الكافية؛ ثم إغلاق النوافذ، ثم تشغيل منقي الهواء هي الوسيلة المثلى لتنقية الهواء.

## الاستخدام بعد دورة هواء كافية عند الطهي

• عند تحمير اللحوم أو الأسماك؛ فإن التخلص من الرائحة بأستخدام المنقي ليس صحيحًا. فالأجسام الزيتية تسد الخلايا في المرشح، وتقلل من عمره أو تلوثه، وحدوث آثار سلبية. وفي هذه الحالة؛ يجب توفر دورة هواء كافية. التخلص من الروائح المتبقية بمنقي الهواء بعد التخلص من الأجسام الزيتية هو الطريقة الصحيحة والفعالة لاستخدام المنتج لمدة طويلة.

## لا تنم بالقرب من الوحدة.

• مروحة منقي الهواء ليست قوية، وقد تشعر بالانتعاش قبل النوم، ولكن بعد النومقد تشعر بالبرودة. والطريقة المثلى هي المحافظة على وجود مسافة متر إلى منقي الهواء.

## لا تضعه في الزاوية.

• لاتضع الجهاز في أماكن محاطة بالأثاث أو الأجهزة، إلخ، أو الزاوية. فوضعه في ذلك المكان يجعل من الصعب تنقية الهواء الداخلي من المساحة المتبقية.

## تأكد من تغيير الهواء لمدة 30 دقيقة على الأقل كل يوم.

• يجب على العائلات التي تستخدم منقي الهواء ضمان وصول الأوكسجين الكافي. ويجب تغيير الهواء لمدة 30 دقيقة على الأقل كل يوم لإدخال الهواء الجديد إلى المكان. ويعمل فتح النافذة المقابلة على تحقيق نتائج أفضل لتغيير الهواء. الكسل يضعف تجديد الهواء، لذلكيجب التنظيفـو الصيانة.

# اسم كل قطعة غيار

## الهيكل الأساسى

## عرض التشغيل والتحكم فيه

# اسم كل قطعة غيار

## نظام الفلتر (يقدم فقط أجزاء الفلتر)

| اسم الفلتر | الوظيفة |
|---|---|
| 1 فلتر الجسيمات الكبيرة | هو فلتر للتخلص من الجسيمات الكبيرة ويقوم بالمعالجة بمقاومة البكتيريا، بحيث يساعد في تحسين الوضع الصحي. |
| 2 فلتر مثيرات الحساسية | يمتص ويحلل مثيرات الحساسية التي قد تسبب الحساسية. |
| 3 وظيفة المادة الحافزة الكربونية القابلة للغسل (الفلتر الحيوي للتخلص من الروائح القابل للغسل) | فلتر التخلص من الروائح الشامل يتخلص من دخان السجائر (الرائحة)، وروائح الأطعمة، وروائح شعر الحيوانات، و$NO_2$، ورائحة الحمام، وروائح الأحماض والقلويات، والمركب العضوي VOCs. |
| 4 فلتر HEPA القابل للغسل | فلتر HEPA القابل للغسل يتخلص من الجسيمات الدقيقة مثل الحشرات الصغيرة، وحبوب اللقاح، ودخان السجائر (الجسيمات)، والأتربة الدقيقة، والفطريات المتطايرة، وشعر الحيوانات، وغيرها. |

* بالنسبة إلى الفلتر القابل للغسل، يجب أن يجف تماماً في الظل والتخلص من أي رطوبة به.
(يعتمد زمن التجفيف على الظروف الجوية. فإن لم يجف الفلتر تماماً، قد يؤدي ذلك إلى تعطل المنتج أو خروج رائحة كريهة).
* حينما يتلوث الفلتر القابل للغسل بشكل كبير، قد يستحيل تنظيفه حتى بعد غسله، يفضل استبداله بآخر جديد.
* تعتمد فترات غسيل الفلتر واستبداله على بيئة الاستخدام.تعتمد فترات غسيل الفلتر واستبداله على بيئة الاستخدام.تعتمد فترات غسيل الفلتر واستبداله على بيئة الاستخدام.

## وحدة التحكم عن بعد

**زرالتشغيل/الإنهاء**
زر بدء أو إغلاق هذا المنتج

**زر سرعة المروحة**
ضبط سرعة المروحة

**زر وضع التشغيل**
اختيار التشغيل (يدوي، آلي، التنقية السريعة، النوم، الأتربة الصفراء)

**زر إيقاف المؤقت**
يضبط زمن إيقاف تشغيل منقي الهواء.

**زر أيون**
ضبط وظيفة التنقية.

**استخدام وحدة التحكم عن بعد**
أثناء استخدام وحدة التحكم عن بعد؛ أشر إلى مستقبل الأشعة في الهيكل الرئيسي بالجهاز.

# دليل وحدة التحكم عن بعد

## التشغيل الأول لوحدة التحكم عن بعد

اسحب غلاف الكيس البلاستيكي الحامي للبطاريات وانزعه.

## استبدال البطارية

1 افتح غطاء البطارية

2 تأكد من تركيب البطارية وفقًا للتعليمات

3 أغلق غطاء البطارية

## تنبيه

**اضغط زرًا واحدًا في المرة**

لأن وحدة التحكم عن بعد لا تعمل بشكل صحيح عند الضغط على أكثر من زر

**لا تقف على وحدة التحكم عن بعد أو تثقبها**

**لا تستخدمها في أماكن بها ماء أو رطوبة**

**لا تستخدمها بالقرب من مصدر للنار أو الحرارة**

- أخرج البطاريات عند تخزين المنتج لفترة طويلة. فقد تتسرب سوائل البطارية وتؤثر على وحدة التحكم عن بعد.
- استبدل كافة البطاريات في كل مرة. اتصل بمركز خدمة ما بعد البيع إذا حدث عيب في وحدة التحكم عنبعد، بعد استبدال البطاريات.

## تشغيل تنقية الهواء تنقية الهواء الداخلي

**1 اضغط زر ON/OFF(التشغيل/الإنهاء)، ثمبعد أن ينتهي الصوت، ابدأ التشغيل عند إضاءة المصباح.**

(المرجع وفقًا لفئة "التشغيل التحضيري" التالية)
يخرج الهواء النقي من مخرج الهواء في الأعلى.

- اضغط زر التشغيل / الإنهاء للإنهاء.
- عند توصيل قابس التيار الكهربي، يصدر صوت تذكيري.

### ما هو"التشغيل التحضيري"؟

خلال الدقيقتين الأوليين بعد التشغيل؛ يبدأ التشغيل التحضيري عند بدء المستشعر.
ويتحرك مستوى مؤشر الأتربة / الروائح لأعلى ولأسفل أثناء التشغيل التحضيري.

## وضع السرعة يختار المستخدم سرعة المروحة يدويًا.

1 اضغط زر ON/OFF(التشغيل / الإنهاء).

2 الانتقال إلى وضع SPEED(السرعة) بالضغط على زر MODE(الوضع).

3 اضغط زر المروحة لاختيار FAN SPEED(سرعة المروحة) المتوقعة للمروحة.

- السرعة الافتراضية للمروحة ضعيفة.
- عند إعادة التشغيل في وضع السر عة؛ يعود النظام إلى سرعة المروحة السابقة.
  سرعة المروحة لها أربعة أوضا ع، هي: ضعيفة، هادئة، قوية، شديدة.
  (انتقل إلى الوضع التالي وفقًا للترتيب الأعلى إلى الأقل).

## الوضع التلقائي يختار الجهاز سرعة المروحة المناسبة.

1 اضغط زر ON/OFF(التشغيل / الإنهاء).

2 الانتقال إلى وضع AUTOMATIC(التلقائي) بالضغط على زر MODE(الوضع).

- التحكم التلقائي في سرعة المروحة، دون بذل المزيد من الجهد معها.
- اضغط زر سرعة المروحة في الوضع التلقائي للانتقال إلى وضع السرعة وزيادة سرعة المروحة مستوى واحداً.
- وباستثناء وظيفة سرعة المروحة؛ يجب على المستخدم ضبط باقي الوظائف.

## وضع تنظيف سريع يعمل بقوة للحظة لتنقية الهواء الداخلي.

1 اضغط زر ON/OFF(التشغيل/الإنهاء).

2 الانتقال إلى وضع QUICK CLEAN(تنظيف سريع) بالضغط على زر MODE(الوضع).

- عند ضغط زر تدفق الهواء في تشغيل التنقية السريعة، يتحول إلى التشغيل اليدوي ويعمل في الوضع المنخفض "LOW".
- تعمل عند تشغيل التنقية السريعة في وضع التربو لحوالي 10 دقائق ثم تتحول إلى الوضع الأوتوماتيكي

## وضع هادئ يوفر جوًا هادئًا أثناء النوم.

1 اضغط زر ON/OFF(التشغيل/الإنهاء).

2 الانتقال إلى وضع SILENT(هادئ) بالضغط على زر MODE(الوضع).

- تنتقل سرعة المروحة إلى الوضع البطيء في وضع النوم؛ ويتأخر الضوء في المصباح 3 ثواني.
- اضغط زر سرعة المروحة للانتقال إلى وضع السرعة وزيادة سرعة المروحة مستوى واحداً.

## وضع عاصفة رملية لتنقية الهواء الداخلي بفعالية في العواصف الترابية.

1 **اضغط زر ON/OFF (التشغيل / الإنهاء).**

2 **الانتقال إلى وضع SAND STORM (عاصفة رملية) بالضغط على زر MODE (الوضع).**

- اضغط زر سرعة المروحة في وضع التراب الكثيف للانتقال إلى وضع السرعة وزيادة سرعة المروحة مستوى واحداً.
- سرعة المروحة يتم التحكم بها وفقًا للترتيب الضبط المسبق.
- وبالإضافة إلى وظيفة سرعة المروحة؛ يجب على المستخدم ضبط باقي الوظائف.

## وظيفة أيون

يصدر أيون للتعقيم غير ضار يتخلص من البكتيريا.

1 اضغط زر ON/OFF(التشغيل/الإنهاء).

2 اضغط زر ION(أيون) لاختيار الوظيفة المتوقعة.

- عند ضغط الزر لمرة واحدة، يتم التحول إلى الأوضاع بالترتيب (التنقية الصحية) ← (إيقاف التنشيط) ← (التنقية الصحية).

## وظيفة تنظيف الفلتر التخلص من الجسيمات الكبيرة

عند تشغيل وظيفة تنظيف الفلتر، يتوقف تشغيل منقي الهواء. تبدأ فرشاة التنظيف الخاصة بفلتر الجسيمات الكبيرة في الدوران للتخلص من الجسيمات الموجودة في الهواء.
الجسيمات التي يتخلص منها فلتر الجسيمات الكبيرة تتجمع في صندوق الأتربة.
نظف صندوق الأتربة دوريًا.
راجع صفحة 32 للتعرف على تنظيف صندوق الأتربة.

### للتشغيل الآلى

- يشغل آليًا تنظيف الفلتر بعد استخدامه لفترة معينة. لن تحتاج إلى تشغيل منفصل.
- يعرض 5 دقائق على شاشة التشغيل وينظف الفلتر للفترة الزمنية المحددة.
- لن يعمل أثناء تشغيل وظيفة النوم.

### للتشغيل اليدوى

**1 اضغط زر تنظيف الفلتر**

- يبدأ تنظيف الفلتر خلال 5 ثوان.
- يعرض 5 دقائق على شاشة التشغيل وينظف الفلتر للفترة الزمنية المحددة.
- عند ضغط الزر لمرة واحدة، يتم التحول إلى الأوضاع بالترتيب (تنظيف الفلتر) ← (تنظيف الفلتر) ← (إيقاف التنشيط).
- حينما تريد تشغيل المنقي أثناء تنظيف الفلتر، اضغط زر تنظيف الفلتر مرة أخرى للإلغاء.

## وظيفة تشغيل مؤقت الإيقاف يتوقف تلقائيًا بعد عدة ساعات من النوم

### مثال: يتوقف العمل تلقائيًا بعد 3 ساعات

**1 اضغط زر ON/OFF (التشغيل / الإنهاء).**

**2 اضغط زر TIMER (إيقاف الموقت) لضبط 3 ساعات.**

- عند الضغط على الزر؛ يزيد وقت التشغيل بمقدار ساعة.

- أقصى وقت متاح هو 9 ساعات.
- يتوقف العمل تلقائيًا.

- يتوقف تلقائيًا بعد 3 ساعات.

## مصباح تنظيف الفلتر

يسمح لك بالتعرف على دورة تنظيف الفلتر ودورة استبداله بعد الاستخدام لفترة محددة.

1 عند التشغيل (مصباح غسل الفلتر)، افتح اللوحة الأمامية أثناء تشغيل المنقي وافحص الفلتر. إن كان الفلتر ملوثًا، اغسله أو استبدله.

2 عند فتح اللوحة الأمامية بعد إيقاف التشغيل بالضغط على زر التشغيل والإيقاف، هذا لا يوقف مصباح غسل الفلتر.
افتح اللوحة الأمامية للفحص أثناء تشغيل المنقي.

3 راجع الصفحات 30-31 للتعرف على تفاصيل غسل الفلتر.

- قد تعتمد حالة الفلتر على بيئة الاستخدام.
- عند إغلاق اللوحة الأمامية بعد الفحص، يتم التحول إلى وضع تدفق الهواء المنخفض "LOW".

# طريقة تنظيف مستشعرات التراب والجسم الخارجي

## طريقة تنظيف الجسم الخارجي

ضع قطعة قماش لينةفي ماء دافئ، ثم امسح بها الجهاز بعد عصرها جيداً.

**تنبيه**
- لا تنظف وحدة التحكم والمؤشر بالجسم الخارجي بسائل قلوي.
- لا تمسح سطح الجهاز بحامض الكبريتيك، أو حمض الكلور، أو المذيب العضوي.

## طريقة تنظيف مستشعر الأتربة

مستشعر الأتربة عبارة عن جهاز يستشعر جسيمات الأتربة الكبيرة والصغيرة. يجب تنظيف الجزء الخاص بالعدسة بشكل دوري للمحافظة على أداء المستشعر.

**1 افتح اللوحة الأمامية.**

**2 افتح غطاء مستشعر الأتربة.**

**3 قم بمسح عدسة مستشعر الأتربة بدعامة قطنية.**

بعد الفراغ من تنظيف العدسة، أغلق غطاء مستشعر الأتربة بترتيب عكسي.

قم بتنظيف عدسة مستشعر الأتربة مرة واحدة كل 6 أشهر.
ولكن يمكن أن تتفاوت مرات التنظيف بناء على البيئة والوقت المستخدم فيهما المستشعر.
وبناء عليه، قم بتنظيف عدسة المستشعر بشكل متكرر في البيئة التي تسود فيها الأتربة.

# تنظيف المرشح

1 تأكد من إيقاف التشغيل قبل التنظيف.
أمسك المقبض ثماسحب للأمام لفتح اللوحة الأمامية.

2 ارفع مقبض صندوق الأتربة إلى الاتجاه العلوي ثم اسحبه نحو الخارج.

3 اسحب حاوية الفلتر خارج الوحدة الرئيسية.

4 ضع حاوية الفلتر على سطح مستو وارفع العلاقة المثبتة في فلتر الجسيمات الكبيرة إلى الاتجاه العلوي لفتحه.

5 فك فلتر الجسيمات الكبيرة.

6 قم بتنظيف المرشح المفكوك بالرجوع إلى إرشادات تنظيف المرشح الواردة بالصفحة التالية.

**تنبيه**

- لسلامتك؛ افصل التيار قبل التنظيف.
- بعد التنظيف بالماء؛ جفف الجهاز جيداً في الظل. (لأنه إذا لم يجف جيداً؛ فقد لا يعمل جيداً).
- استبدل المرشح إذا تعذر التنظيف بسبب زيادة الانسداد.
- إذا لم يجف المرشح جيداً بعد التنظيف؛ فقد يصدر رائحة سيئة.
- يرجى عدم ضرب المنتج باليد.

## طريقة تنظيف المرشح قد تختلف صيانة المرشح بحسب البيئة

| فئة المرشح | التصنيف | تكرر التنظيف | طريقة التنظيف | |
|---|---|---|---|---|
| فلتر الجسيمات الكبيرة | قابل للغسل | دورة غسيل تقدر بحوالي 6 أشهر | لن تحتاج إلى تنظيفه منفصلاً، وذلك بفضل وظيفة تنظيف الفلتر. ولكن عند تنظيف فلاتر أخرى بواسطة المكنسة الكهربائية أو بالماء، نظفها مع هذا الفلتر. حيث يمكنك استخدام فلاتر أنظف. | صورة 1 |
| فلتر مثيرات الحساسية | قابل للغسل | دورة التنظيف أو الاستبدال تنظيف كل شهر واحد تقريبا | استخدام المنظفات الطبيعية والمياه النظيفة لتشغيله. | صورة 2 |
| فلتر التخلص من الروائح | قابل للغسل | دورة غسيل تقدر بحوالي 6 أشهر | إنقع المرشح فى ماء دافىء لمدة ساعة واحدة. ازالة الجسيمات من المرشح بواسطة هز الماء من المرشح. | صورة 3 |
| فلتر HEPA | قابل للغسل | دورة غسيل تقدر بحوالي 6 أشهر | اشطف المرشح القابل للغسيل HEPA بواسطة الدش. | صورة 4 |

1 فلتر الجسيمات الكبيرة

2 فلتر مثيرات الحساسية

3 فلتر التخلص من الروائح

4 فلتر HEPA

# نظف صندوق الأتربة

(قم بتغطية اللوحة الأمامية بعد تنظيف صندوق الأتربة. يرجى تغطيته بإحكام، وإلا لن يشتغل الجهاز).

1 تأكد من فصل التيار أثناء العمل.
ادفع اللوحة الأمامية للأمام لفتحها.

2 ارفع مقبض صندوق الأتربة بالاتجاه العلوي واسحبه نحو الخارج.

3 تفريغ صندوق الأتربة.

4 لتثبيت صندوق الأتربة، لا بد من تثبيت الفتحة الجانبية من صندوق الأتربة داخل المكان المخصص في فلتر الجسيمات الكبيرة.

1 تأكد من تشغيل منقي الهواء لأكثر من ساعة في يوم مشمس، اضغط زر التشغيل/الإنهاء لإيقاف التشغيل.

2 افصل التيار.

3 تأكد من تنظيف وحماية جسم منقي الهواء.
استخدم حقيبة من الفنيل عند تخزين منقي الهواء لفترة طويلة، تفاديًا لدخول الهواء أو الأجسام فيه.

نظف بقطعة قماش لينة.
فالخدوش تؤدي بسهولة إلى تلف الجسم الخارجي.

# التأكد من العناصر قبل الإبلاغ عن العيب

عند حدوث خلل بالمنتج، تأكد من الأجزاء التالية قبل الاتصال بمركز الخدمة.

| الأعراض | التأكيد | الإجراءات |
|---|---|---|
| إجمالي الأعطال | • هل تم جذب قابس الطاقة؟ | • قم بتوصيل المنتج بنقطة الطاقة بشكل صحيح. |
| | • هل توجد أي مشكلات بوحدة التحكم عن بعد؟ | • أعد تركيب البطارية أو اضبط القطب (+، −). |
| | • هل تلف مصهر الطاقة؟ | • اطلب المساعدة من مركز الخدمة. |
| | • هل اللوحة الأمامية مفتوحة أم لا؟ | • توقف عن العمل عندما تكون اللوحة الأمامية مفتوحة وقم بإغلاقها بشكل كامل. (زر الإغلاق الأيسر/الأيمن) |
| انخفاض سرعة المروحة مع وجود صوت غير جيد | • هل هناك الكثير من الأتربة التي تسد مرشح HEPA؟<br>• هل هناك الكثير من الأتربة التي تسد المرشح المضاد للحساسية؟ | • قم بغسل المرشح وفقًا لدورة التنظيف الخاصة به ويجب استبدال المرشح المضاد للحساسية وفقًا لدورته. |
| تعذر ضبط إيقاف الموقت. | • هل تم فحص مؤشر التشغيل أم لا؟ | • اضبط المنتج مرة أخرى وفقًا للدليل. |
| عدم عمل وظيفة تنقية الهواء بالشكل الملائم | • هل التلوث الهوائي الداخلي شديد أم لا؟ | • استخدم المنتج بعد توفر دورة هواء كافية. |
| | • هل المرشح ملوثًا؟ | • استخدم ماء نظيفًا في الغسيل. (لا تستخدم ماء ساخنًا تتجاوز درجة حرارته 40 درجة مئوية أو مذيبًا متطايرًا) قم بالتجفيف بشكل كامل في مكان ظليل وتجنب الأماكن القريبة من مصادر النيران أو الإضاءة المباشرة. |
| | • هل بيئة الاستخدام كبيرة أم لا؟ | • يجب الاستخدام في مساحة ملائمة. (تجنب الاستخدام في الأماكن جيدة التهوية مثل المداخل والمخارج والنوافذ وما شابه ذلك). |
| | • هل توجد عوائق محيطة أم لا؟ | • قم بإزالة العوائق. |
| | • هل يتم التركيب في أماكن غير جيدة التهوية أم لا؟ | • قم بالتركيب في أماكن أخرى. |
| لا يعمل الزر بشكل صحيح. | • تحقق من ارتدائك لقفاز (قفازات) وما شبه ذلك؟ | • استخدمه بعد إزالة أي أشياء غريبة بما في ذلك القفازات. |

# التأكد من العناصر قبل الإبلاغ عن العيب

| الأعراض | التأكيد | الإجراءات |
|---|---|---|
| **مخرج الهواء به رائحة غريبة.** | • هل صدرت هذه الرائحة مباشرة بعد شراء المنتج؟ | • إنها رائحة الكربون النشط. وستختفي هذه الرائحة في غضون 1–2 أسبوع بعد تشغيل المنتج.<br>هذه الرائحة غير ضارة. (إنها ظاهرة تشبه الرائحة الأولى عند شرائك لسيارة جديدة.) |
| | • هل يستخدم في أماكن دخانية أو ذات روائح أم لا؟ | • الاستخدام في أماكن دخانية أو ذات روائح يضعف وظيفة تنقية الهواء. |
| | • هل يستخدم في مكان به رائحة طعام أم لا؟ | • روائح الطعام تخترق المرشح، استخدم بعد دورة هواء كافية. |
| | • هل جف المرشح تماماً أم لا؟ | • المرشح المبتل يصدر روائح، يرجى الاستخدام بعد أن يجف تماماً. |
| **مشكلة في مؤشر المستشعر.** | • مستشعر الأتربة دائماً في المستويات المرتفعة. | • نظف مستشعر التراب أو المرشح. |
| | • ارتفاع مستوى مستشعر الروائح؟ | • منقي الهواء LG مصمم لاكتشاف الهواء الملوث؛ ولذا لن يتفاعل مستشعر الروائح مع روائح الطعام. ولكن مرشح إزالة الروائح سيزيل الرائحة. أجسام البخار من الطهي أو الماء المغلي قد تجعل مستوى مستشعر الرائحة مرتفعاً. |
| | • هل أرقام مستشعر الأتربة ومستشعر الروائح تواصل الصعود والهبوط؟ | • تمثل هذه العملية ظاهرة التشغيل الأولية لاستقرار العمل الأولي للمستشعر خلال دقيقتين بعد بدء تشغيل العملية. وسيتوقف هذا الإجراء في غضون دقيقتين ويبدأ المستشعر في العمل (ارجع إلى صفحة 21). |

# معايير المنتج

لتحسين جودة المنتج؛ قديختلف شكل هذا المنتج أو تصميمه أو مواصفاته نسبياً.

| | |
|---|---|
| اسم الطراز | الفئة PS-P800 |
| مصدر التيار الكهربي | أحادي الطور، 220–240 فولت، 60/50 هيرتز |
| وزن المنتج | 15 كجم |
| حجم الشكل (مم) | 475(عرض) × 680(ارتفاع) × 300(طول) |
| استهلاك التيار الكهربي | 90 واط |