LG

Life's Good

使用说明书

吸尘器

干湿两用
吹风功能

VP0116WNAU
VP0116WNAN

中文 ⟶ 1-14页
English ⟶ Page 15-27

售后服务电话

LG电子
400-819-9999
售后热线
一号通

使用前请仔细阅读说明书，阅读完后请妥善保管以备需要时查阅。

目 录

产品规格 2
使用前注意事项 3-4
吸尘器的组装及吸力调节 5
部分名称与连接方法
附件
吸力调节
尖吸嘴、鸭嘴刷及刷头的使用 6
吸尘器吸尘的使用方法 7
吸尘器吸水的使用方法 8
吸尘器吹风功能的使用方法 9
皮搋子的使用方法及集尘桶的清理方法 10
HEPA过滤器及排气过滤海绵的清洁方法 11
吸尘器使用后的保管方法 12
故障通告前需确认事项 13
故障通告前请先确认
装箱单 14

产品规格

型号: VP0116WNAU / VP0116WNAN
额定电压: 220V~ 50Hz
额定功率: 1400W
最大功率: 1600W
净重: 4.6kg
集尘容量: 吸尘：11L（使用桶身集尘）
吸水：4. 3L
防水等级: IPX4
外形尺寸: 328mm x 374mm x 376mm
本产品执行标准: GB4706.1-2005
GB4706.7-2004
GB17625.1-2003
GB4343.1-2009

※ 为了提高产品质量而进行的外观及设计规格上的变更将不再另行通知。

使用前注意事项

忽视说明而导致的错误操作将会对您造成不同程度的损害，请认真阅读以下提示说明。

危险 此标识表明违反标记事项时，会立刻发生严重伤害或死亡现象。

警告 此标识表明违反标记事项时，有可能发生严重伤害或死亡现象。

注意 此标识表明违反此标记事项时，有可能发生财产损失或轻微伤害。

危险

请不要在易燃液体附近使用吸尘器，以免发生火灾。

插拔电源插头时，请先关闭电源开关，以免发生火灾或触电的危险。请不要用湿手触摸电源插头，以防触电。（不要在220V以外的电源上使用产品）

警告

请不要让大头钉等金属物存留在软管、机体延长管内，否则会造成短路故障。
请不要吸入头发团、大纸团等物品，否则容易堵塞软管，如有堵管现象，请及时清理。

为保护吸尘器电机，避免发生火灾或触电的危险，在清扫时，注意不要让机体吸入刀片、火种以及水泥、石膏粉等小微粒。

15A以上的电流请单独使用插线板，在一个插线板上同时使用多种电器可能会引发火灾。建议不要使用电源线延长线，以免引起不必要的危险。本吸尘器最大电流为6A。

长时间不使用电器时，请记住拔掉电源插头；正处于通电时，请您不要离开。

警告

请不要让电源线与吸尘器接近电暖器等热源，以免使机体变形或发生火灾。请您不要使用破损的电源和插头，如有破损，必须由指定维修站更换。

请不要在吸入口和排气口堵塞时，继续长时间运作，否则可能造成机体变形或损坏。

请不要让儿童把吸尘器及组件，如延长管等当做玩具，以防止意外。

使用过程中，延长管和机体有产生静电的可能，请您使用时注意。

注意

非专业维修人员请勿开机修理。

请不要弯曲、践踏、拉拽软管，如软管受损，请不要继续使用。
请不要用重物或尖刃物压线。

注意不要使电源线夹在门缝里或用电源线提拉吸尘器，防止电源线受损。

集尘桶集满时，请及时对集尘桶进行清理。
请您注意不要在没有安装HEPA过滤器时使用吸尘器。

吸尘器的组装及吸力调节

部分名称与连接方法

提 示

首先，您应该按照图片的示意将小脚轮用力安装到桶体下端的孔里。

附件	
	● 吸水刷头 ● 尖吸嘴 ● 鸭嘴刷 ● 皮撅子 ● 编织袋 ● 纸 袋 ● 吹风板

吸力调节

请按图示使用

按下电源开关可启动机器，再次按下关闭机器。

软管手柄处有一个手动的气流控制钮，使您可以简单方便的调节吸力大小。

尖吸嘴、鸭嘴刷及刷头的使用

尖吸嘴的使用

请按图示使用

使用方法

用来清洁一般不容易接触的地方，如窗框，墙缝，画框，家具边缘，书或其它不平物体。

鸭嘴刷的使用

请按图示使用

使用方法

用来清洁平面，如沙发、电视柜、书柜等。

地板地毯刷头的使用

组合

- 地板地毯刷头可以清洁普通的地板也可以进行地毯的清扫。

使用

- 通过操作刷头上的功能按键，可以实现地板和地毯功能的切换。

吸水刷头的使用

使用

- 吸水刷头可以清洁地板上的水渍。

吸尘器吸尘的使用方法

注意：• 当集尘桶集满时，请及时清理集尘桶或者集尘袋。
• 集尘桶至少三个月清理一次，或根据使用频率酌情清理。

1 将HEPA过滤网装入上盖。

2 将纸袋或者编织袋装入集尘桶内。

3 合上上盖。

4 锁死上盖两端的卡扣。

5 将软管和吸尘器组装到一起。

6 将软管、伸缩管、刷头组装到一起。

7 打开电源开关。

吸尘器吸水的使用方法

注意：• 在吸尘器吸水的情况下，当您突然听到一个大的异常声响时，请清空集尘桶。因为它表明吸尘器已经达到了吸收液体容量的极限，安全阀自动关闭了吸入口，不能再有液体被吸入。

1 将HEPA过滤网装入上盖。

2 将纸袋或者编织袋集从集尘桶内取出。

3 合上上盖，并锁死上盖两侧的卡扣。

4 将软管和吸尘器组装到一起。

5 将软管、伸缩管、吸水刷头组装到一起。

6 打开电源开关。

7 清洁地板上的水渍。

8 关闭电源开关。

9 打开上盖。

10 将桶内的液体倒出。

吸尘器吹风功能的使用方法

1 将软管从机体前端取下。

2 将吸尘器后端的排气盖取下。

3 将吹风板装置安装到吸尘器的后部，并将软管插入到吹风板上。

4 打开电源开关

5 吹风清洁

皮搋子的使用方法及集尘桶的清理方法

皮搋子的使用方法

- 将皮搋子与吸尘器连接组装后，对准盥洗盆的盆口，打开电源开关开始清理。

集尘桶的清理方法

1 将上盖从机体上分离。

2 清洗集尘桶。

3 将集尘桶内的水倒掉。

HEPA过滤器及排气过滤海绵的清洁方法

HEPA过滤器的清洁方法

1 将HEPA过滤器从上盖取下。

2 将HEPA过滤器上的污物清除。

3 用水清洗HEPA过滤器。

排气过滤海绵的清洁方法

1 从后端取下排气海绵盖。

2 从排气海绵盖中取下海绵。

注意：• 清洗后，请将排气过滤海绵放在阴凉处阴干后再进行使用。

3 用水清洗海绵后，请放在阴凉处阴干。

4 将海绵和排气海绵盖重新装回机体上。

吸尘器使用后的保管方法

- 请将使用后的刷头挂钩插于机体后端的插槽内。
- 也可将其他附件插在机体上的凸出部位。

故障通告前请先确认

▶ *如果您怀疑产品发生故障，请先确认故障发生原因，再与售后服务中心或代理商联系，以确保检修的效率。*

故　障	检　查	措　施
吸尘器为何不能工作？	● 电源插头是否插上？ ● 电源插座有电吗？ ● 软管是否插上？	● 请将电源插牢（本产品适用于220V电压）。 ● 确认插座是否有电。 ● 将软管插牢。
机体内有噪音。	● 吸尘器吸力过大或电机高速运转时所发出的声音，不属于异常情况，请正常使用。 ● 如果不是正常的电机响声，而是异常的噪音，请打电话与维修中心联系。 ● 集尘桶已满。 ● 集尘桶滤芯堵塞。 ● 吸入口阻塞。 ● 伸缩管阻塞。 ● 软管阻塞。	● 清理集尘桶。 ● 用软毛刷轻刷滤芯，用水冲洗后放置于阴凉处风干一天。 ● 将吸入的异物取出再使用。 ● 将伸缩管内异物取出后再使用。 ● 将软管内异物取出后再使用。
机体出现异味。	● 电机运作时，用于固定电机的橡胶圈会受热而产生少量气味，不会影响运作或使机器发生损坏。 ● 集尘桶长期不清理时，会有一些异味排出，此时应及时清理集尘桶。	
机体或排出的气体过热。	● 吸力是否正常？	● 从机体内排出的热气，是由电机导热产生的热量所致，属正常温度，请继续使用。

装箱单

吸尘器	一台
软管	一根
伸缩管	一根
地板地毯刷头	一个
吸水刷头	一个
尖吸嘴	一个
鸭嘴刷	一个
吹风板	一个
皮搋子	一个
编织袋	一个
纸袋	两个
小脚轮	四套
说明书	一本
保修卡	一本

Table of contents

Product specifications 15
Attention before using the appliance ..... 16 ~ 17
Assembling and adjusting the Cleaner 18
Parts description and assembly
Accessories
Adjusting the cleaner
Using nozzle 19
How to vacuum dust 20
How to vacuum water 21
How to using the blower function 22
How to use the drain nozzle and How to cleanthe dust tank 23
How to clean the HEPA filter and exhaust filter 24
How to keep the cleaner after using 25
If you have a problem 26
Packing List 27

Product specifications

Model: VP0116WNAU / VP0116WNAN
220V~ 50Hz
IEC: 1400W
MAX: 1600W
Net Weight: 4.6kg
Dust Capacity: 1.2L
Max Dust Capacity : Dry : 11L (Dust Tank)
Wet: 4.3L
IPX4
Dimension: 328mm x 374mm x 376mm
This appliance complies with the following GB Directives:
GB4706.1-2005
GB4706.7-2004
GB17625.1-2003
GB4343.1-2009

※ You will not be informed otherwise of any changes in appearance and standard deriving for improvement of product quality.

Attention before using the appliance

Please read all the following information, which contains important instructions for the safety, the use of the appliance.

DANGER	May immediately cause serious injury or death.
WARNING	May possibly cause serious injury or death.
ATTENTION	May possibly cause losses of property or light injury.

DANGER

Do not pick up anything that is burning or smoking, such as cigarettes, matches or hot ashes.

Please turn off the power before pulling out the plug to prevent fire or electric shock. Never handle plug or appliance with wet hands. (Do not use the appliance on the power above 220V.)

WARNING

Avoid picking up hard, sharp objects with the cleaner.They may damage the cleaner and the tank.
Do not vacuum the objects like hair ball or big paper ball, otherwise the hose is possibly blocked up. Please clear the hose in time when it is blocked.

To avoid the danger of fire or electric shock, do not vacuum blade, flammable substances, or small particles like cement and gesso in cleaning.

Independently use a socket when the current is ≥15A. It may cause fire when many electric appliances share one socket. In order to avoid the needless danger, you had better not use the prolonged thread of power cord.
The current at most 6A is allowed

Unplug cleaner when not in use. Turn off all controls before unplugging.

Attention before using the appliance

WARNING

Do not let the power cord near the electric heater or other heat source, lest that the cleaner should be deformed or it should cause fire. Do not use the appliance when the power cord or plug is damaged.
The damaged power cord or plug must be replaced in the approved service station.

Do not operate the appliance for long when the nozzle inlet or nozzle outlet is blocked, which may have it deformed or damaged.

Close supervision is necessary when any appliance is used by or near children.
Do not allow vacuum cleaner to be used as a toy or to run unattended at any time.

In using the appliance, pay attention to the electrostatic effect generated on the telescopic tube and cleaner body.

ATTENTION

Do not allow the non-professional maintenance people to repair.

Do not bend, stamp on, or drag the hose.
Do not continue to use the hose if it is damaged.
Do not use any heavy or sharp object to press the power cord.

Do not pull or carry by cord, use cord as a handle,close door on cord or pull cord around sharp edges or corners. Do not run appliance over cord. Keep cord away from heated surfaces.

Do not use it without HEPA.
Dust tank should be cleaned frequently.

Assembling and adjusting the Cleaner

Parts description and assembly

Tips

Firstly , you should fix up the wheel according to picture. Push the wheel into the hole.

Accessories

- Wet nozzle
- Crevice nozzle
- Upholstery nozzle
- Drain nozzle
- H-bag
- Paper bag
- Blower cover

Adjusting the Cleaner

Use it as shown in the diagram

Press power switch to start the vacuum cleaner, press once again to turn off it.

The flexible hose handle has a manual air flow regulator which allows you to briefly reduce the suction level.

Using nozzle

Using crevice tool

Use it as shown in the diagram

Using method

Crevice nozzle can be used for cleaning the place hard to reach.

Using Upholstery nozzle

Use it as shown in the diagram

Using method

Upholstery nozzle can be used for sofa ，book cabinet，and so on.

Using carpet and floor nozzle

Assembling

- Carpet and floor nozzle can be used to clean common floor, also can be used to clean carpet.

Using

- By operation of the release button, change the function of Carpet and Floor.

Using wet nozzle

Using

- Wet nozzle can be used to clean water on the floor.

How to vacuum dust

Warning:
- *Empty dust tank or filter bag when they are full.*
- *Dust tank or filter bag should be cleaned at least once per 3 months.*

1 Connecting the Air Filter

2 Taking in the filter bag assembly

3 Closing the Top Cover Assy

4 Closing the Top Cover Assy

5 Connecting the Hose

6 Assembling Hose and Pipes

7 Turning on the Power Switch

How to vacuum water

⚠ *Warning:* • *When you hear the big noise from the main body during the operation, empty the dust tank. Because it indicates that the safety float automatically closes the suction inlet and you will notice that no more liquid is sucked up.*

1 Connecting the Air Filter

2 Taking out Paper filter assembly

3 Closing the Tank Cap and the Top Cover Assy

4 Connecting the Hose

5 Assembling Hose & Pipes

6 Turning on the power switch

7 Wet Cleaning

8 Turning off the power switch

9 Opening the Top Cover Assy

10 Pouring the Cleaning Liquid

How to using the blower function

1 Separating the Hose

2 Separating the Exhaust Cover

3 Connecting the Blower Cover and Hose

4 Turning on the Power Switch

5 Blow Cleaning

How to use the drain nozzle and How to clean the dust tank

Drain nozzle

How to clean the dust tank

1 Separating Cover

2 Cleaning the Dust Tank

3 Pour out the water

How to clean the HEPA filter and exhaust filter

Cleaning the HEPA filter

1 Separating the HEPA filter

2 Cleaning the HEPA filter

3 Cleaning the HEPA filter with water

Cleaning the exhaust filter

1 Separating the exhaust filter cover

2 Separating the exhaust filter from exhaust filter cover

Warning: • *Dry in the well-ventilated shade for a day before using.*

3 Washing and drying the exhaust filter

4 Connecting the exhaust filter

How to keep the cleaner after using

- Insert the nozzle into the groove in the back of the body
- Install the accessories into the body

If you have a problem

Please check before notifying malfunction

▶ If you doubt the product meets with malfunction, please check the cause of such malfunction before contacting with the after-sales service center or agent, so as to ensure efficiency of repair.

Malfunction	Check	Troubleshooting
The vacuum does not work?	• Is the plug inserted? • Is the socket powered on? • If the hose inserted?	• Insert the plug tight (This product is applicable for 220V) • Verify the power of socket is on • Insert the hose tight
The vacuum does not work?	• When the vacuum cleaner's suction is too large or the motor is under high speed running, they do not belong to the abnormal conditions. So, please use the vacuum cleaner properly. • If it is the noise rather than the normal motor sound, please phone the repair center. • The duster collector is filled up. • The filter is clogged. • Suction inlet is jammed. • Drawtube is clogged. • Hose is clogged.	• Clean out the dust collector. • Purge the sponge filter with water and air-dry in the shady and cool place for one day. • Take out the sucked objects before use. • Take out the objects inside the drawtube before use. • Take out the objects inside the hose before use.
Peculiar smell exists inside the vacuum cleaner	• When the motor is running, the rubber band used for fixing the motor will produce a little smell due to the heat, but it will not affect the operation or damage the machine. • When the dust collector is not cleaned for a long period of time, the peculiar smell will be produced. So, clean up the dust collector timely.	
The vacuum cleaner or the discharged air is too heat.	• Is the suction normal?	• The heat air discharged from the machine is arising from the heat produced by motor. So, the temperature is normal, please use the machine continuously.

Packing List

Packing List

Vacuum Cleaner	1
Hose	1
Telescopic pipe	1
Carpet and floor nozzle	1
Wet nozzle	1
Crevice nozzle	1
Upholstery nozzle	1
Blower cover	1
Drain nozzle	1
H-bag	1
Paper bag	2
Caster	4
Owner's manual	1
Service card	1

如有问题

请打电话

瞬间感动 Moment Of Truth LG售后

LG电子

400-819-9999

售后热线 一号通

LG电子 (天津)电器有限公司

地址: 中国 · 天津市北辰区津围公路9号

传真: 022-26903476

邮编: 300402

全国技术服务中心服务咨询电话：400-819-9999

LG电子

http://www.lg.com/cn

P/No.: MFL67206006