LG
Life's Good

OWNER'S MANUAL

CLEANING ROBOT

Before using, please carefully read the Safety Precautions pages to allow for safe operation of the product. After reading the operation manual, please keep it in an easily accessible location.

VR6260 Ser.
VR6270 Ser.

MFL67680025

www.lg.com

FEATURES

Corner Master

By having adopted a brand new concept design that is appropriate for walls, the Robot Cleaner's cleaning performance is incredibly efficient.

Learning Mode

The Robot Cleaner is capable of memorizing the cleaning environment via its Smart Operation feature for smarter cleaning.

Turbo Mode

In the "Turbo" mode, the Robot Cleaner runs more powerful giving cleaner results.
When selected, the "Turbo" mode is automatically activated on carpets, which enables the Robot Cleaner to run more efficiently.

Drawer Mop Plate

The "Drawer mop plate" makes it much easier for users to change the mop without having to flip the device over.

My Space Mode

By commanding it to clean a particular space, the Robot Cleaner quickly cleans the desired space.

Repeat Cleaning

The Robot Cleaner will continuously clean until the battery runs out.

Location Search Function

When the Robot Cleaner is moved from a spot while operating, the device will automatically search for the previous location and return to the spot from where it was interrupted.

CONTENTS

1
BEFORE USING

2~5 Safety precautions
6 Included with product
7~8 Parts description
9~10 Button functions
11 Display status information
12 Before you start
13 Overview

2
METHOD OF USE

14 How to install the home station
15 How to turn the Robot Cleaner power supply on & off
16 How to start and stop cleaning
17~18 How to charge the battery
19~20 Cleaning modes
21~22 Auxiliary cleaning modes
23 Time setting
24 Scheduled cleaning
25 Mop cleaning (option)
26 Location search function
27~28 Smart diagnosis

3
HANDLING METHOD AFTER USE

29 Cleaning the dust bin
30 Cleaning the dust bin filter
31 Cleaning the brush
32 Cleaning the sensor/charging terminal
33 Cleaning the side brush
34 Cleaning the ultra microfiber mop (option)

4
ADDITIONAL INFORMATION

35~37 Troubleshooting
38 Before you call for service

5
REFERENCE

39 Product specifications
40 Open source software notice

SAFETY PRECAUTIONS

The purpose of the safety precautions described below is for the user to use the product safely and correctly to prevent any unexpected risk of injury or damage.

Basic safety precautions

After reading this manual, please keep it in an easily accessible location.

⚠	This is the safety alert symbol. This symbol alerts you to potential hazards that can result in property damage and/or serious bodily harm or death.
⚠ **WARNING**	Indicates a hazardous situation which, if not avoided, could result in death or serious injury.
⚠ **CAUTION**	Indicates a hazardous situation which, if not avoided, could result in minor or moderate injury.

⚠ WARNING

1. This appliance is not intended for use by persons (including children) with reduced physical, sensory or mental capabilities, or lack of experience and knowledge, unless they have been given supervision or instruction concerning use of the appliance by a person responsible for their safety.
2. Children should be supervised to ensure that they do not play with the appliance.
3. If the supply cord is damaged, it must be replaced by LG Electronics Service Agent in order to avoid a hazard
4. This appliance can be used by children aged from 8 years and above and persons with reduced physical, sensory or mental capabilities or lack of experience and knowledge if they have been given supervision or instruction concerning use of the appliance in a safe way and understand the hazards involved. Children shall not play with the appliance. Cleaning and user maintenance must not be made by children without supervision.

For your safety, do not remove the battery from the Robot Cleaner. If you need to replace the battery or the Robot Cleaner, take it to the nearest authorized LG Electronics service center or dealer for assistance.

Failure to follow this warning can cause fire or product failure.

Never use the Robot Cleaner with a battery and/or home station from any other product than the Robot Cleaner.

Doing so can cause fire or product failure.

⚠ WARNING

Make sure the power cord of the home station is not crushed under a heavy object or damaged by contact with sharp objects.

Failure to follow this warning can cause electric shock, fire or product failure. If the power cord is broken, do not plug it in. Take the product to an LG Electronics Authorised service repairer.

Do not place the home station and the Robot Cleaner near a heating device.

Doing so can cause product deformation, fire, or product failure.

Do not force the power plug to bend. Do not use the power plug when it has been damaged or loosened.

Doing so can cause fire or product failure.

Do not touch the power plug with wet hands.

Doing so can cause electric shock.

Do not spray or use inflammable materials, surfactants, or drinking water in the vicinity of the Robot Cleaner.

Doing so can cause fire or product failure.

* Inflammable materials: gasoline, thinner, etc.
* Surfactant: detergent, articles for bath, etc.

Do not insert any part of the body, such as a hand or foot, below the brush or wheels of the Robot Cleaner while in use.

Doing so can cause injury or product damage.

Do not operate the Robot Cleaner on narrow and high furniture such as a wardrobe, refrigerator, desk, table, etc.

Doing so can cause injury, product failure or damage which is not covered by the warranty.

Do not activate the device on a floor that has more than a 10 degree incline.

The device may not work properly.

Do not use the Robot Cleaner when candles or fragile objects are placed on the floor.

Doing so can cause fire or product failure.

Always use a dedicated power outlet with a 10 amp rating.

If multiple appliances are connected to an outlet simultaneously, they can generate enough heat to cause a fire.

When pulling out the home station power plug, always pull it out by grabbing the plug, not the cord. When pulling out the power plug, do not to touch the prongs with your fingers.

Doing so can cause an electric shock.

Do not allow children or pets to play with or rest upon the Robot Cleaner at any time. Do not use the Robot Cleaner while an object is hanging from it.

Doing so can cause injury or product damage.

Turn the power supply off immediately if any abnormal sound, odor, or smoke is generated from the Robot Cleaner by removing it from the home station and turning off the main switch on the rear side of the unit.

Failure to do so can cause fire or product failure.

Do not operate the Robot Cleaner in a room where a child is sleeping.

Doing so can cause injury or product damage.

Do not leave Children or pets near the Robot Cleaner unsupervised.

Doing so can cause injury or product damage.

SAFETY PRECAUTIONS

⚠ CAUTION

Frequently empty the dust bin and maintain its cleanliness.

The dust collected in the dust bin can trigger allergies and may contain harmful insects.

Use the Robot Cleaner indoors only.

Using it outdoors can cause product failure and irreparable damage to the unit.

Close the cover of the dust bin on the main unit before starting cleaning.

If the cover is not closed, it can cause injury or product damage.

DO NOT use the Robot Cleaner around a banister, staircase or any other dangerous place.

Otherwise, the user or the product can be exposed to damage.

In rare cases, the Robot Cleaner's brush can damage the carpet. If this happens, immediately stop the cleaning operation.

When a carpet has long tassels, the tassels can be damaged.

Do not let the main unit and charging terminal of the home station come into contact with metallic objects.

Doing so can cause product failure.

Do not put water, detergent, etc. into the Robot Cleaner.

Doing so can cause product failure. Do not put any water or detergent on the Robot Cleaner. If liquids get inside of the Robot Cleaner, turn off the power supply and contact an LG Electronics sales agent or customer care center.

Do not drop the Robot Cleaner or subject it to strong impacts.

Doing so can cause injury or product failure not covered by the warranty.

Do not expose the Robot Cleaner to cold temperatures (less than -5 ℃) for a long period of time.

Doing so can cause product failure.

Remove any cables or string from the floor before starting.

Cable or string can get tangled in the wheels of Robot Cleaner and cause product failure or the cord of an appliance can be disconnected.

Make sure the Robot Cleaner is not put on a table or desk, with the power ON.

It may result in injury of the user or damage in the product.

Do not allow the Robot Cleaner to sweep up liquids, blades, thumb tacks, kindling, etc.

These items can cause product failure.

Do not put sharp objects into the opening of the Robot Cleaner's ultrasonic sensor.

Doing so can cause product failure.

Do not use the Robot Cleaner when the dust bin is completely filled up.

Doing so can cause product failure.

CAUTION

If the floor is wet or has wet spots, wipe them up before using the Robot Cleaner. Do not use the Robot Cleaner on a wet surface.

Failure to do so can cause product failure.

When the robot cleaner is operating, it may hit the chair leg, desk leg, table leg or other narrow pieces of furniture.

For quicker and better cleaning, place the dining chairs on top of the dining table.

When attaching the mop, do not block the bottom camera sensor.

Blocking the bottom camera sensor may not allow the product to work smoothly.

Make sure the plate on the floor is higher than 2 cm from the ground before starting the cleaning.

If the threshold is low, the Robot Cleaner can go over it and perhaps into an undesirable location. Make sure that all the doors of the rooms that are not to be cleaned are closed.

If you do not use it to save the energy, turn off the power switch, and turn on the power switch when you are cleaning or recharging it.

Tip Check the following items before use:

- Empty the dust bin after each operation or prior to it filling up.
- Remove any cables or long strings from the floor.
- Remove any moisture from the floor before cleaning.
- Close the cover of the dust bin before cleaning.
- Remove fragile or unnecessary objects from the room to be cleaned.
  For example, remove expensive ceramics and valuables from the floor.
- Confirm whether the battery has sufficient power, and if it is low, recharge it.
- Close the doors of any room that you do not want the Robot Cleaner to enter.
  During cleaning, the Robot Cleaner may enter another room and continue cleaning.
- Do not use this product in the room where a child is sleeping alone. The child can be hurt or woken.
- Remove towels, foot towel or any other thin cloth from the floor as they can get caught by the brush.
- Before starting the device, it's better to remove carpets that are thicker than 20 mm as they may cause it to malfunction.
- Please close any balcony doors. The wheels may get stuck while cleaning.

INCLUDED WITH PRODUCT

Robot Cleaner

Remote controller

Home station

► Figures can be different from actual objects.

Cleaning Tool

Dust bin filter (spare)
(option)

Quick guide

Operation manual

Cleaning brush
(It's on the dust bin cover)

Mop plate (option)

Ultra microfiber mop
(2 pieces) (option)

Dry cell for remote controller
(2 units of AAA size)

Side brush (2 pieces)
(option)

Carpet Master
(option)

PARTS DESCRIPTION - ROBOT CLEANER

Plan view

Front view

Rear view

Bottom view

► Figures can be different from actual objects.

PART DESCRIPTION – HOME STATION / DUST BIN

Home station

Dust bin

► Figures can be different from actual objects.

BUTTON FUNCTIONS – ROBOT CLEANER

TURBO	• If the button is pressed, 'Turbo Mode' will be set with a voice confirmation. • If the button is pressed whilst in 'Turbo Mode', it will be canceled.
START/STOP	• Used to turn the power ON, start or stop cleaning. • If the button is pressed whilst the unit is powered ON, it will start cleaning. • If button is pressed during the cleaning, it will stop the cleaning. • If the button is pressed for about 2 sec. whilst the power is ON, the power will be OFF. • If the button is pressed in 'Smart Diagnosis' mode, it will end the diagnosis.
MODE	• Used to change the clean mode setting. • If the machine is at the Home Station, 'Spot Clean' option is not available. • The 'My Space' mode can only be selected by remote control (when the Robot Cleaner is not on the home station).
HOME	• Used to return the Robot Cleaner back to the home station for charging. • If cleaning is finished or the battery is low, the Robot Cleaner will return to the Home Station by itself to recharge its battery.
BUTTON LOCK On/Off	• Pressing the 'Turbo' and 'Mode' button for 3 seconds will activate or deactivate the Lock function. • If 'Lock' is ON, a voice announcement "Key has been locked" will be heard each time a button is pressed.

BUTTON FUNCTIONS – REMOTE CONTROLLER

Start
Pressing this button will start the cleaning. (p16)

Mode
Change the cleaning mode. (p19)

Directional button
This button enables Manual Operation and selection of an area in 'My Space cleaning' mode.

Repeat
This button allows activating or deactivating 'Repeat Cleaning' mode. (p22)

Schedule
Used to start cleaning at a scheduled time.
Pressing the button for 3 sec. will cancel the scheduled cleaning.
※ Schedule Setting/Cancel options are available only in 'Charge' mode. (p24)

Clock
Used to set the current time indicated on the Robot Cleaner. (p23)

Home
Used to recharge the Robot Cleaner by making it return to the Home Station. (p17)

Turbo
Used to activate or deactivate 'Turbo' mode. (p22)

Stop/OK
Pressing the button will stop the Robot Cleaner, or confirm a cleaning schedule or time setting.

My Space
Used to put the Robot Cleaner in 'My Space clean' mode. (p20)

Mute
Used to activate or deactivate 'Mute' mode. (p11)

Diagnosis
Used to run Smart Diagnosis. Available only when Robot Cleaner is recharging. (p27)

Tip

- Remote Controller does NOT provide a Power ON function.
- With the machine's power OFF, the Remote Controller will not work.
- To turn the power ON/OFF, use the 'Start/Stop' button on the upper section of the Robot Cleaner.
- Only use the 'Mode', 'My Space' or 'Clock' button after stopping Robot Cleaner.

DISPLAY STATUS INFORMATION

Tip

- Once the clean mode is selected (Zigzag or Cell by Cell) it will be remembered even if the power is OFF.
- To cancel the reservation, please press the 'Schedule' button on the remote for 3 seconds while the Robot Cleaner is recharging.

BEFORE YOU START

Check these items before cleaning

- Do not use this device in a room where a child is left alone. The child could be injured.
- Remove fragile or unnecessary objects from the room to be cleaned.
  Especially, remove expensive ceramics and valuables from the floor.
- Close the cover of the dust bin before cleaning.
- Remove any moisture that might be on the floor.
- Remove cables, strips, towels, mats etc. from the floor so they will not get caught by the brush.
- Confirm whether the battery charge is sufficient, and if it is low, recharge it.
- Empty the dust bin before or after each clean, or before it becomes full.
- Close the doors of any room that you do not want the Robot Cleaner to enter. During cleaning, the Robot Cleaner may enter another room and continue cleaning.
- When the mop is attached, Robot Cleaner will not be able to go over thresholds of 5 mm or higher.
  If you are not planning to use the mop for cleaning, separate the mop before using Robot Cleaner.
- Before starting the device, it's better to remove carpets that are thicker than 20 mm as they may cause it to malfunction.
- Please close any balcony doors. The wheels may get stuck while cleaning.

Loading the remote controller battery

1. Open the battery cover by lifting the rear hook of the remote controller.
2. Insert two AAA batteries, checking for +, - nodes while loading.
3. Close the battery cover completely so that the batteries will not fall out.

Precautions while using the remote control

- Only press one button at a time.
- Do not drop or subject it to forceful impact.
- Do not store it near devices that give off heat, fire or hot air.
- Certain fluorescent lamps, such as the three band radiation lamp, can interfere with the activation of the remote control. Therefore, use it as far away as possible from such lamps.
- If the remote control is far from the Robot Cleaner when activated, it may fail to operate properly. Use the device within 3 m of the Robot Cleaner if possible.

1 Install the home station. (p14)

Insert the power cord plug into an outlet and locate the station against a wall. If power is not supplied to the home station, the Robot Cleaner will not charge.

2 Turn on the power supply of the Robot Cleaner. (p15)

Turn ON the power switch on the rear-left of Robot Cleaner, and press the 'Start/Stop' button on the top.

※ If the power supply is not turned on, refer to page 15.

3 Check the dust bin.

Check the cleanness of the dust bin before start cleaning and close the cover of the dust bin on the main unit.

4 Start cleaning. (p16)

Press the START/STOP button once again while the Robot Cleaner is turned on. You will hear the sound of cleaning and cleaning will begin.

5 Automatic charge. (p17~18)

The Robot Cleaner will self-diagnose and automatically return to the home station to recharge before the complete discharge of the battery. It takes approximately three hours to charge the battery.

6 Use the cleaning mode and auxiliary functions. (p19~25)

Use the buttons on Robot cleaner and Remote Controller to use each cleaning mode and supporting feature.

Cleaning modes include ZigZag, Cell by Cell, Spot, My space, and Repeat cleaning; supporting features include Manual, Scheduled and Microfiber Mop cleaning.

< Warning > **When Robot Cleaner is operated with the cover of the dust bin open, it can cause an injury or serious damage to the product.**

HOW TO INSTALL THE HOME STATION

How to Install the Home Station

1. Position the home station against a wall on hard level flooring to prevent sliding during docking.

   Remove objects within 1.5 m to the right and left side and within 2 m to the front.

2. Plug the power cord into an outlet.

   Wrap the power cord around the fixed hook on the back side of the home station or along the wall surface so that the travel path of the Robot Cleaner will not be obstructed.

3. Fix the home station against the wall so that it does not move. Please turn on the power switch.

4. When the remote controller is not used, store it on the remote controller holder on the home station.

Tip

- Always keep the home station plugged in. If the home station is not plugged in, the Robot Cleaner will not return to the station to charge automatically.

< Warning > **Do not operate the Robot Cleaner if the Home Station has a damaged cord or plug, if it is not working properly, or if it has been damaged or dropped. To avoid hazard, the cord must be replaced by LG Electronics, Inc. or a qualified service person.**

HOW TO TURN THE ROBOT CLEANER POWER SUPPLY ON & OFF

Turning on the main power supply

Make sure the Power Switch on the rear-left of the Robot Cleaner.

If the power is OFF, turn the switch ON.

※ When turning on the power switch, do not press the button located at the upper section of the Robot Cleaner. Operation of the button can be delayed.

※ Turn off the power switch if the Robot Cleaner will not be used for a long period of time, in order to protect the battery. The Robotic Cleaner cannot charge if the main switch is in the "OFF" position.

Turning on from Stand By power.

With the power of Robot Cleaner OFF, press 'Start/Stop' button for 1 second until a "Ting" sound is heard. In about 10 seconds, the power will be on and a melody will sound.

※ If 10 minutes elapse without the Robot Cleaner having being given an active command after being turned on, the power will automatically turn OFF.

Turning off the power supply

Press the START/STOP button for two seconds while the Robot Cleaner is turned on. A melody will sound when the power is turned off.

Tip

- If the power cannot be turned on, do the following.
  - Turn on the power switch and wait for more than 3 seconds.
  - Press the 'START/STOP' button when the power switch is turned on.
  - If the power is not turned on or if there is no display but only the "Ting" sound, put the Robot Cleaner manually on to the home station.

HOW TO START AND STOP CLEANING

Using the buttons on the Robot Cleaner

After the Robot Cleaner is turned on, press the START/STOP button to begin cleaning. A melody will sound and cleaning will begin.

Press the START/STOP button during the cleaning cycle to stop cleaning.

※ When the 'START/STOP' button is pressed while the power supply of the Robot Cleaner is turned off, the power will be turned on. Press the 'START/STOP' button one more time to start cleaning.

Using the remote controller

After the Robot Cleaner is turned on from the Robotic Cleaner, press the START button on the remote control. A melody will sound and cleaning will begin.

Press the STOP button during the cleaning cycle to stop cleaning.

※ The Robot Cleaner cannot be turned on from Stand By, by using the remote controller when the power of the Robot Cleaner is off. When the power is off, press the 'START/STOP' button on the upper side of Robot Cleaner to turn the power on and to allow the remote to be used.

※ During cleaning, collisions can happen when the sensor cannot detect objects because of their shape (Thin chairs and table legs, furniture corner). When this happens, the internal impact detecting sensor will react by using a backward motion.

※ If the Robot Cleaner is set to start cleaning at a location away from the home station, put the Robot Cleaner on a flat floor in order to prevent a malfunction of the obstacle detecting sensor. In addition, start cleaning from a location where there are no obstacles such as curtains or walls within 30 cm of the Robot Cleaner.

Tip For best results:

- Briefly scan the area to be cleaned for big and small objects that will cause difficulty for the Robot Cleaner.
- If cleaning is started when the Robot Cleaner is at the home station, the device can rapidly be returned to the home station as the current home position has been accurately read.
- When the mop plate is installed, to prevent a 2nd contamination from the contaminated mop, it will not go over door sills of 5 mm or higher.

HOW TO CHARGE THE BATTERY

Automatic charging

The Robot Cleaner returns to the home station at the end of a cleaning cycle or when its battery is running low.

※ If 10 minutes elapse without the Robot Cleaner moving or the battery is too low, the power will automatically be turned OFF.

※ **Do NOT turn OFF the Main Power Switch as the battery will not be recharged. If the machine is returned manually with the Main Power Switch OFF, it shows an error message, "Main power switch on the back of the HOM-BOT is turned off. Please turn the switch on."**

※ In the event that the unit returns to the Home Station due to a low battery during the cleaning, cleaning will be started, after the charging, from the nearest place of the area which has not been cleaned before. (Page 18)

※ If Robot Cleaner is unable to dock to the home station on its first attempt, it will try again until it docks successfully.

※ When Robot Cleaner has completed all areas that it can clean, it will return to the home station even when the battery level is not low.

Manual charging

If using the Robot Cleaner for the first time or when charging the battery during cleaning, you can manually charge the battery.

Method 1. Attach the Robot Cleaner to the home station by aligning to the front side of the home station. A melody sound will be generated along with an audio message to start charging.

※ **If a voice message, "Main power switch on the back of the HOM-BOT is turned off. Please turn the switch on." is announced repeatedly, then turn on the Main Power Switch.**

Method 2. When the 'HOME' button of the remote control or the Robot Cleaner is pressed, charging will be prompted by automatically generating a searching signal and returning the Robot Cleaner to the home station.

※ **If the Robot Cleaner did not start cleaning from the home station or if the Robot Cleaner is manually charged by pressing the Home button, it may take slightly longer to find the home station.**

※ If the Robot Cleaner is within 10 cm of the front of the charging terminal while the power supply is turned on, it will automatically be returned to the home station and charging will begin.

Tip Take the following precautions when using the home station:

- If foreign material is caught in the charging terminal, charging may not proceed smoothly. Wipe the terminal from time to time with a dry cloth after the power plug is disconnected.(p32)
- To prevent electric shock or damage to the home station, do not touch the charging terminal with any metallic objects.
- To avoid fire or electric shock, never disassemble or modify the home station.
- Do not to place the home station or power plug near a heating source.

HOW TO CHARGE THE BATTERY

Remaining Battery Charge Indicator

Battery level is indicated on Status Display, as follows.
- If recharging is in progress, the Battery Level Lamp flickers.
- If recharging is complete, only the 'Battery' and 'Clean Mode' icons are displayed to save the energy.
- Upon the need for recharging, only the first level of Battery Level Lamp will be on and flickering.

Charging is required | Low | Middle | High

※ If Robot Cleaner goes back to Home Station, with a low level of battery while it is the 'Clean Mode' lamp starts to flicker.

- When the 'Clean Mode' lamp starts to flicker after recharging is complete, Robot Cleaner will then resume cleaning the areas which were not covered.
- Pressing the 'Start' button on the Remote Controller or 'Stop' button on main unit whilst it is recharging, with the 'Clean Mode' lamp flickering, will also make Robot Cleaner find and clean uncovered spots.
- Pressing the "Start" button on the remote control or the "Start/Stop" button on the device after changing the mode will make the Robot Cleaner start to clean from beginning again.

The status indication lamp while the robot is charged (In spatial Zigzag mode)

In the case of no existing area to be cleaned

In the case of an existing area to be cleaned (Flickering)

If the Battery is Not Charging

Check 1:

If the battery is not charging even when the Robot Cleaner is attached to the home station, check the following items.
- Turn the power switch on the rear-left of the Robot Cleaner off once and then on again.
- Check the power lamp of the home station.
- Wipe the terminal on the home station with a dry cloth. (p32)

Zigzag Cleaning

In 'Zigzag Clean' mode, Robot Cleaner repeats a zigzag operation to clean every and each spot in the cleaning area.

If you need to quickly clean an area choose 'Zigzag Clean' mode.
Press 'Mode' button on Remote Controller or main unit to select 'Zigzag Clean' mode and press 'Start' button.

※ Factory release default setting is 'Zigzag Clean.'

Cell by Cell Cleaning

In 'Cell by Cell' mode, Robot Cleaner cleans the area by dividing it into rectangular spaces.
For meticulous cleaning, select this mode.

Press 'Mode' button on Remote Controller to select 'Cell by Cell' mode and press 'Start' button.

The 1st stage:
The maximum outline of 3 m x 3 m of cleaning area will be cleaned. (The size of the outline may vary in accordance with the shape of the area to be cleaned.)

The 2nd stage:
The 2nd stage of Cell by Cell cleaning engages a Zigzag mode automatically.

When the 1st, 2nd stages are completed, the cleaned area will be cleaned through the repetition of the above cleaning method as the device is being moved to the next part of cleaning area.

Tip

- Once set up, the cleaning mode(Zigzag, Cell by Cell) setting will be maintained even after the power supply is turned off.
- During operation, if a mode change is required, press the Stop/OK button and then select the mode. Cleaning will then start from the beginning.

CLEANING MODES

My Space Cleaning

Pressing 'My Space' on Remote Controller will set the My Space cleaning mode with a voice message.
For cleaning of particular spaces, select this mode.

The 1st stage:
Use the Remote Controller to manually run the cleaning on outskirts of each cleaning block.

※ This cleaning mode will be accepted when the distance of the start and end position is less than 1 m.

The 2nd stage:
Pressing the 'Start' button will then make the Robot Cleaner clean the manually outlined area by itself.

※ Upon failure to correctly outline a zone, a voice will announce, which says "Area does not meet the specified conditions. Please continue to make specified area for cleaning process."
Use the Remote Controller to assign a zone, again.

※ Upon completion of cleaning for all selected areas, the Robot Cleaner will be placed in the cleaning mode (Zigzag or Cell by Cell) which was run, right before.

Tip

- While recharging, you cannot activate 'My Space clean' mode.
- To change the cleaning mode while Robot Cleaner is in operation, press 'Stop/OK' button first to select a mode The cleaning will the start from the begining.

Manual cleaning

By pressing a direction key on Remote Controller, you can move Robot Cleaner in a Manual mode.
Robot Cleaner will clean the area, moving forward/backward/left/right, according to the input of the direction key.
While in 'Manual' mode, the robot cleaner will run into obstacles placed behind it if the backward key on the remote remains held down.

Spot Cleaning

Is best used used to clean certain parts of the house.
Press 'Mode' button on Remote Controller to select 'Spot Clean' mode, indicated on Status Display, and 'Start' button, then Robot Cleaner will start Spot cleaning for a space within a 1.5 m diameter.

※ While recharging, 'Spot Clean' cannot be selected.

It stops at the started position after completing the cleaning(takes 4~5 min.).

AUXILIARY CLEANING MODES

Turbo Mode

Pressing 'Turbo' button on Remote Controller or main unit will activate 'Turbo' mode, with a voice message.

While in 'Turbo' mode, pressing the same button will cancel 'Turbo' mode, with a voice message.

In 'Turbo' mode, Robot Cleaner runs more intensely for a powerful clean.

※ **<Turbo Mode (Floor Master Function)>**
'Turbo mode' will automatically operate when the Robot Cleaner cleans carpets.

Repeat Mode

Pressing 'Repeat' button on Remote Controller will activate 'Repeat' mode, with a voice message.

While in 'Repeat' mode, pressing the same button will cancel 'Repeat' mode, with a voice message.

In 'Repeat' mode, Robot Cleaner repeats the cleaning in progress until the battery runs out.

Learning Mode

Robot Cleaner is capable of memorising the cleaning environment through its Learning mode for an intelligent cleaning operation.

※ 'Learning Mode' is available only when the machine starts cleaning from the Home Station.

Tip

- Precautions with Smart Operation
  - This Learning mode enables memorizing locations with obstacles to bypass them. Robot Cleaner memorizes every aspect of the environment it was put under from when it started cleaning from the Home Station to the moment it finishes its course.
  - Robot Cleaner learns the new conditions when the location of Home Station has been changed.
  - If the learning mode is accepted, a voice message will say "The learning cleaning process is complete."

You can set the current time on the Robot Cleaner.
Pressing 'Clock' button on Remote Controller, when Robot Cleaner is waiting, will start the current time setting.

Select by using '◀ ▶' buttons on the Remote Controller. The function can be heard through the voice guide.		Set the time units by using '▲▼' buttons on Remote Controller.
		Set the unit of minutes using '▲▼' buttons on Remote Controller.
		Set the AM/PM using '▲▼' buttons on Remote Controller.
		Pressing 'Clock' or 'Stop/OK' button on Remote Controller will complete the time setting process.

Tip

- Any scheduled cleaning will be activated based on the time on the Robot Cleaner. You must set the clock before setting scheduled cleaning.
- If there is no input for 10 seconds, the clock setting is canceled.

SCHEDULED CLEANING

You can schedule a cleaning so that the Robot Cleaner starts cleaning at a scheduled time.
Pressing 'Schedule' button on Remote Controller, when the battery is recharging, will start the scheduled cleaning setting.

Setting/Cancelling the reservation is only possible when the unit is recharging.

 Select a level by using '◄ ►' buttons on Remote Controller. 'One time' 'Everyday'		Select 'One Time' or 'Everyday' option by using '▲▼' buttons on Remote Controller. A voice message will confirm the schedule.
		Set the hour units by using the '▲▼' buttons on Remote Controller.
		Set the minutes by using the '▲▼' buttons on Remote Controller.
		Set the AM/PM using the '▲▼' buttons on Remote Controller.
		Pressing 'Schedule' or 'Stop/OK' button on Remote Controller will then complete the scheduling process.

Tip

- When the scheduled time comes up, Robot Cleaner will start cleaning by itself.
- Scheduled cleaning can only be set when the Robot Cleaner is recharging.
- While recharging, by pressing the 'Schedule' button on the Remote Controller for 3 seconds will cancel the set schedule.
- If there is no input when setting the schedule time within 10 seconds, the setting is canceled.

MOP CLEANING (OPTION)

By attaching the ultra microfiber mop, you can effectively use the Robot Cleaner to remove dust.

When the mop plate is attached, the Robot Cleaner will not climb on to carpets or over thresholds, in order to prevent transferring dirt from the mop.

⚠ **Caution**
Do not cover the bottom camera sensor by mop.

For mop cleaning, mount the mop and mop plate to the Robot Cleaner according to the following instructions:

1. Attach the ultra microfiber mop to the Velcro of the mop plate as shown in the figure.

2. Firmly push the Mop Plate into the furrows until you hear a 'click' sound.
   ※ Note that, if the Mop Plate is not secured correctly, it may separate during the cleaning.

3. It is essential that the fixing hooks on the Mop Plate align correctly on to the fixing grooves on the underside of the cleaner.

Tip

- To avoid odors, wash any foreign material or dust off the mop after cleaning is complete.
- To avoid staining floors, do not use the ultra microfiber mop to clean when dirt is mixed with liquids such as coffee or ink.
- To avoid damage to carpets from the Velcro or dirt transfer from the mop, do not clean the carpet while the mop plate or mop is attached.
- Keep the ultra microfiber mop dry. Do not use it on wet surfaces.
  If there is moisture, it can interfere with the navigation.
- Smart Diagnosis feature is not available, when the Mop Plate is attached.

LOCATION SEARCH FUNCTION

The Robot Cleaner remembers its location while cleaning.
If the user moves the Robot Cleaner while it is operating, it will search for the location it was moved from by using its navigational location search function before continuing to clean.

※ The navigating function will be activated after the Robot Cleaner adequately recognizes the cleaning environment.

Change location

When the location search function is activated, the cleaning mode of the status indicator will flash

Manual Relocation.

1. Locate the Robot Cleaner near the location where it was originally moved from.
   ※ The location search is more effective when the Robot Cleaner is closer to the location where it was moved from.
   ※ If it is moved from its original cleaning position by more than 1 m, it becomes difficult for the Robot Cleaner to search for it's previous location.

Location of incident

2. Press the START/STOP button on the Robot Cleaner or START button on the remote controller. Robot Cleaner will then start the location search function along with an audio guide.
   ※ When the location search is successfully completed, it will continue cleaning from where it was moved. If the location search fails, it will start again from the beginning.

Location of incident

Tip

- When the power is turned off after the location search function is set, the location search function will be canceled.
- Location search will be more effective when the Robot Cleaner is closer to the location where it was moved from.

Robot Cleaner uses this Smart Diagnosis feature to run a self-diagnosis.
If any irregularity is found from the diagnosis, please contact the local LG Electronics service center.

※ During Smart Diagnosis, the Robot Cleaner will move about within a 50 cm radius. So, make sure no objects are in the way within a 1 m radius around the Home Station, before starting Smart Diagnosis.

1. Turn ON the Main Power Switch on the back after making sure the Robot Cleaner is attached to the Home Station.

   ※ Smart Diagnosis is only possible when the Robot Cleaner is attached to the Home Station.

2. Press 'Diagnosis' button on the Remote Controller, then the process will start with a voice message which says "Starting HOM-BOT smart diagnosis. Please step away and remove any items within 1 meter, or about 3 feet."

   ※ If the Mop Plate is attached, the process will not be activated.

3. When the Smart Diagnosis has successfully finished, Robot Cleaner will return back to the Home Station and inform the result through a voice message. After the voice message, pressing the 'HOME' button on the Remote Controller or main unit will allow the voice message to be repeated. To terminate the diagnosing process, press the 'Stop/OK' button on the Remote Controller or main unit.

   ※ After the Smart Diagnosis voice message, the Robot Cleaner will start recharging after 1minute.

   ※ If an error is detected with any of the Sensors whilst in Smart Diagnosis, a voice message will announce, and the unit will not return to the home station.

Tip

- Be careful not to touch the Robot Cleaner or disturb its operation before Smart Diagnosis is complete. If it is accidently interrupted, turn the main power switch OFF then ON again to resume the diagnosis.
- Smart Diagnosis will not be activated in each of the following cases. In each case, check the problem and try again.
  - Robot Cleaner is detached from Home Station
  - Battery level is insufficient
  - No Dust Bin Filter is fitted.
  - Mop Plate is attached

SMART DIAGNOSIS

If a voice message is announced after Smart Diagnosis, refer to the following table to take proper actions.

Voice message	Measures (for reference)
Starting HOM-BOT smart diagnosis. Please step away and remove any items within 1 meter, or about 3 feet.	Clear any object within a 1 m radius around Home Station, and stay back until the diagnosis is complete.
HOM-BOT needs to be charging in order to activate smart diagnosis. Please dock the HOM-BOT to the home station.	Move Robot cleaner to the Home Station to recharge it.
Starting HOM-BOT smart diagnosis. Reservation has been cancelled for smart diagnosis. Please step away and remove any items within 1 meter, or about 3 feet.	
No defect found during diagnosis.	
Unable to initiate smart diagnosis due to a low battery. Please try again after battery is charged.	Try the Smart Diagnosis again after recharging the battery.
Please check that the dust bin and filter are properly installed.	Open the Dust Bin Cover and examine the bin.
HOM-BOT will not charge due to infrared sensor error. Please try smart diagnosis again after turning the main power switch on the back of the HOM-BOT 'Off' then 'On' again. If the problem continues, please contact LG Electronics customer care.	Run Smart Diagnosis again and, if the same message is announced, contact an LG Electronics service center.
HOM-BOT will not charge due to ultrasonic sensor error.	Run Smart Diagnosis again and, if the same message is announced, contact an LG Electronics service center.
HOM-BOT will not charge due to a problem with the cliff sensors on bottom. Please wipe the sensors clean.	Clean the three Cliff Sensors on the bottom at the front of the unit.
Please clean the camera sensor on bottom right side.	Clean the lens of Camera Sensor on the bottom-right
Please clean the obstacle detecting sensor windows on the left and right side of the HOM-BOT.	Clean the lens of the Obstacle Sensors on both the left and right hand sides.
A problem has been found on the Gyro Sensor. Please try smart diagnosis again after turning the main power switch on the back of the HOM-BOT 'Off' then 'On' again. If the problem continues, please contact LG Electronics customer care.	Run Smart Diagnosis again and, if the same message is announced, contact an LG Electronics service center.
Please check for foreign material on the left wheel.	Check for foreign materials on the left wheel.
Please check for foreign material on the right wheel.	Check for foreign materials on the right wheel.
A problem has been found on the left wheel sensor. Please try smart diagnosis again after turning the main power switch on the back of the HOM-BOT 'Off' then 'On' again. If the problem continues, please contact LG Electronics customer care.	Run Smart Diagnosis again and, if the same message is announced, contact an LG Electronics service center.
A problem has been found on the right wheel sensor. Please try smart diagnosis again after turning the main power switch on the back of the HOM-BOT 'Off' then 'On' again. If the problem continues, please contact LG Electronics customer care.	Run Smart Diagnosis again and, if the same message is announced, contact an LG Electronics service center.
A problem has been found with the brush. Please check for any foreign material.	Check for any foreign material stuck in the Brush.
A problem has been found in the suction motor. Please try smart diagnosis again after turning the main power switch on the back of the HOM-BOT 'Off' then 'On' again. If the problem continues, please contact LG Electronics customer care.	Run Smart Diagnosis again and, if the same message is announced, contact an LG Electronics service center.
A problem has been found in the acceleration sensor. Please try smart diagnosis again after turning the main power switch on the back of the HOM-BOT 'Off' then 'On' again. If the problem continues, please contact LG Electronics customer care.	Run Smart Diagnosis again and, if the same message is announced, contact an LG Electronics service center.
In order to listen to the smart diagnosis result again, please press the charging button. To stop, please press the stop button.	If you need to repeat the diagnosis result, press the 'Home' button, or press 'Stop/OK' button to finish the diagnosis.
Smart diagnosis mode will be turned off.	
Smart Diagnosis mode will not operate with the mop plate attached. Please try again after removing it.	Run Smart Diagnosis again after removing the Mop Plate.
Smart diagnosis has failed to complete its diagnostics. Please try again after turning the main power switch on the back of the HOM-BOT 'Off' then 'On' again.	Turn the main power switch OFF and then ON again to resume the diagnosis. Do NOT touch the robot or disturb its operation until the diagnosis is complete.
Please check if the charging terminal is damaged or dirty.	Clean the bottom of the machine and Charging Terminal on Home Station.

CLEANING THE DUST BIN

If the dust bin is full, suction power can be reduced. Clean the dust bin before and after each cleaning session. Clean the dust bin using the following sequence:

1. Open the dust bin cover by pressing the PUSH button on the Robot Cleaner.

2. Grab the handle of the dust bin and pull it upward.

3. Pull the hook on the left of Filter Cover on the rear of Dust Bin to separate the filter and the sponge.
   ※ Note that separating the filter may result in dust dropping.
   ※ Refer to p.30 when cleaning the Dust Bin Filter.

4. Lift the cover upward while pressing the separation button on the dust bin.

5. Empty the dust bin and clean it with a cleaning brush or under running water.

6. After cleaning with water, completely dry the dust bin in a well-ventilated area out of the direct sunlight.

7. When reassembling or fitting the cleaned Dust Bin, close the cover and put in the Sponge and HEPA Filter.
   ※ Refer to p.30 for detailed assembly guides.

8. Put the dust bin into the Robot Cleaner and close the dust bin cover.

Tip

- Operating the unit without Filters fitted to the dust bin can cause a motor malfunction not covered by warranty.
- After cleaning the Dust Bin, make sure to assemble the filter and fit it to the Dust Bin.
  If you initiate cleaning, with no filters fitted to the dust bin or Filter Cover not assembled, a voice message will be announced which says "Please check that the dust bin and filter are properly installed."
- Always ensure that the dust bin cover is refitted correctly after cleaning the dust bin so that it closes easily and accurately.

CLEANING THE DUST BIN FILTER

The Dust Bin Filter consists of a HEPA Filter and Sponge Filter.
Clean both the HEPA and Sponge filters as per the following sequence.

1. Pull the hook on the left of the HEPA Filter module on the rear side of Dust Bin to separate the HEPA Filter and the sponge.

2. Thoroughly clean out the fine dust particles on the HEPA Filter, with a vacuum cleaner or cleaning brush.
   ※ Do NOT wash the HEPA Filter with water. Its suction power will be reduced.

3. Use a cleaning brush to clean the Sponge Filter. If using water to clean it, allow it to dry completely in the shade before refitting.

4. Assemble the HEPA and Sponge filters back onto the Filter Cover as per the following sequence.

   ※ Fit the rectangular locator on the HEPA Filter into the locating slot of the filter body.

   ※ Be careful not to incorrectly assemble HEPA and Sponge Filter onto the Filter Cover.

Tip

- To preserve the performance of Robot Cleaner, clean the HEPA Filter at least once a week, with a brush or vacuum cleaner.
- If you run Robot Cleaner, with the Filter Cover assembled onto Dust Bin and without no filters inserted, it may involve dusts coming inside to cause a failure.

CLEANING THE BRUSH

The rotating Brush, located on the bottom of Robot Cleaner, helps collect the dust. Clean the Brush as per the following sequence.

※ **Before turning over the main unit, lay a soft cloth on the floor and remove the Dust Bin. Otherwise, the main unit can get scratches and dust will fall from Dust Bin.**

1 Turn the Main Power Switch OFF before starting the clean. Put the Robot Cleaner upside down on a soft cloth.

2 After checking for foreign materials, press down the Fixing Hook and pull it up to separate the brush Cover.

3 By using a cleaning tool, clear hairs and other debris and foreign materials on the Brush and from the 2 smaller jockey wheels.

4 Push the Brush all the way into the yellow protrusion.

5 While pushing the Brush, lift the white protrusion part up to separate it from the main unit.

6 Carefully clean the Brush with a vacuum cleaner or scissors.

7 Fit the Fixing Hook (rectangular shape) on the side of the Brush into the slots, with the colors matching.

8 While pushing the Brush to the arrow direction, fit the Fixing Hook (rectangular shape) on the opposite side into the slot.

9 Press down and close the Cover until a 'crack' sound is heard from both sides of Fixing Hook.

※ Be careful not to trap the side brush bristles under the cover when closing it.

CLEANING THE SENSOR/CHARGING TERMINAL

There are sensors on the Robot Cleaner that detect obstacles, stairways and the home station for charging the battery. In order to maintain the performance of the Robot Cleaner, regularly clean the sensors and charging terminal as follows:

1. Turn off the power switch on the bottom of the Robot Cleaner. Injury can be caused by the activation of the Robot Cleaner if the main power is not turned off.

2. Lay a smooth cloth on the floor, overturn the Robot Cleaner and put it on the cloth.

※ **Please make sure to remove the dust bin before rotating the main body. Otherwise, the dust in the dust bin may fall out.**

3. Use a smooth cloth or cleaning brush to wipe the dust off each cliff sensors, camera sensors and ultrasonic sensors and the charging terminal as described below.

Upper camera sensor

Ultrasonic sensors

Obstacle detecting sensor window
Detecting sensors of home station & Receiving sensors of remote controller

Cliff detection sensor

Charging terminal

Bottom camera sensor

Charging terminal

Lens

Tip

- Do not clean the Robot Cleaner by directly spraying it with water, thinner, benzene, or any other liquids.
- Call the service center if the sensor or charging terminal is damaged. Sensor and terminal damage can cause the product to malfunction.
- To clean the sensor/charging terminal, use the cleaning brush.

CLEANING THE SIDE BRUSH

Foreign objects/materials such as hair can easily adhere to the side brush. Remove such materials at least once a week.

If excessive amounts of foreign materials are stuck to the brush, there is the risk of damage to the brushes.

If the floor is rough or walls are frequently cleaned, the side brush may bend or become damaged. In this case, use the following method to straighten the side brush.

1. The following procedure is helpful in restoring deformed brushes.
2. Turn off the power by switching the main switch off on the rear off the unit.
3. Place the Robot Cleaner at the end of a table to make cleaning the side brush easier. Make sure that the Robot Cleaner is not in danger of falling.
4. Soak the side brush in warm water.
5. Press down on the side brush for about ten seconds so that it is completely submerged in the water.
6. Slowly wipe the side brush by sliding it through your hand.
7. Rotate the side brush and repeat steps 4-6 for each section of the brush.
8. Use the side brush only after it has completely dried.

Side Brush management

1. Remove the screws by using a driver and separate the Side Brush from the main unit.
2. Remove any hair after the separation.
3. Assemble the Side Brush by replacing it onto the bottom of the Robot Cleaner, with the 'R' and 'L' marking of the Brush matching the counterparts on Robot Cleaner.

CLEANING THE ULTRA MICROFIBER MOP (OPTION)

To avoid odors, dirt and dust should be washed off the mop after it is used for cleaning. Follow these directions to wash the ultra microfiber mop:

1. Separate the ultra microfiber mop from the mop plate.

2. Carefully clean it with warm water.

3. Use the Mop after completely drying it in direct sunlight.

   ※ If the Mop is used in a damp or wet state, it will cause the Robot Cleaner to malfunction.

Tip

- To avoid product malfunction, only use the ultra microfiber mop provided with the Robot Cleaner.
- Additional microfiber mops can be purchased by visiting a nearby LG Electronics service center.

Upon a voice message, "The wheels are not touching the floor. Please move HOM-BOT onto flat floor."

A warning message will be given if a wheel does not contact the floor surface for any reason.

• Is a wheel trapped in the front door, balcony, stairway, etc?
  ▶ Move the Robot Cleaner on to the flat floor.

Upon a voice message, "Please remove any foreign material on the left/right wheel."

• Is any foreign material wound around the wheel?
  ▶ Lay smooth cloth on the floor, overturn the Robot Cleaner, and put it on the cloth.
  Remove foreign material after observing the wheel.

  ※ Please make sure to remove the dust bin before flipping the main body.
  Otherwise, the dust in the dust bin may fall out.

Upon a voice message, "HOM-BOT cannot continue cleaning. Please check the area around it."

A warning message will be given if Robot Cleaner cannot go on cleaning due to any unfavourable condition.

• Is the Robot Cleaner stuck?
  ▶ After removing the part that is stuck, place the Robot Cleaner on flat floor.

TROUBLESHOOTING

Upon a voice message, "Please check that the dust bin and filter are properly installed."

A warning message will be given if there is no Dust Bin or Filter Cover fitted.

• Is the Dust Bin fitted to the Robot Cleaner?
  ▶ Open the Dust Bin Cover and check to ensure the Dust Bin is in place.
  ▶ Do NOT leave the Dust Bin Cover open.

• Make sure the Filter Cover is assembled onto the Dust Bin.

Upon a voice message, "Battery is low. Please move HOM-BOT onto the home station to charge."

When the remaining amount of battery power is almost nil, the voice, "Battery is low", is generated.

• Initiate battery charging of the Robot Cleaner by moving it to the home station.
  ▶ When the Robot Cleaner is attached to the docking station successfully, it will start the recharging with the recharging start melody.

Upon a voice message, "Please remove any foreign material from the brush on the bottom of the HOM-BOT."

A warning message will be given if foreign materials restrict the Brush's rotation.

Lay a soft cloth on the floor and put the Robot Cleaner upside down on it.

※ **Before turning over the main unit, remove the Dust Bin.**
Otherwise, it will cause dust to fall from Dust Bin.

• The brush is making a loud, abnormal sound.
► Confirm the correct assembly of the brush by checking the separation groove of the brush
► Remove the brush from Robot Cleaner and remove any foreign material from the brush.

• The brush or side brush is stuck.
► Remove any foreign materials such as cables, thread of hair caught in the side brush or the brush.

※ For a more detailed description of this process, refer to the instructions on page 31, 33.

BEFORE YOU CALL FOR SERVICE

Confirm before reporting the failure of Robot Cleaner.

Problem	Solutions (Reference page)
The power supply cannot be turned on.	Check that the power switch is turned on. (Page 15)
The power supply automatically turns off.	This is not a failure. Robot Cleaner has its own power saving function. If it is not used for ten minutes after the power supply is turned on, the power will automatically turn off. (Page 17)
The Robot Cleaner will not charge.	▶ Check whether the main power switch is turned on. ▶ Remove objects around the home station. (Page 15) ▶ Confirm that the power supply is connected to the home station. (Page 14) ▶ Wipe the charging terminal with a dry cloth.
Suction power becomes weak.	▶ Check whether there is foreign material blocking the suction port. (Page 31) ▶ Empty the dust bin. (Page 29) ▶ Clean the dust bin filter. (Page 30)
Noise becomes louder.	▶ Confirm that the dust bin has been mounted properly. ▶ Confirm that the dust bin filter has been mounted properly. (Page 30) ▶ Check whether foreign material is caught in the brush. (Page 31)
The Robot Cleaner will not activate.	▶ Confirm that the power switch is turned on. (Page 15) ▶ Confirm that the battery has been charged. (Page 18)
The brush does not rotate.	▶ Clean the brush. (Page 31) ▶ Confirm that the brush has been mounted properly. (Page 31)
Movements or travel path are abnormal.	▶ Carefully wipe the sensor with a smooth cloth. (Page 32) ▶ If the ultra microfiber mop is attached, confirm that it is mounted properly. (Page 25) ▶ Turn the power switch off and on.
The Robot Cleaner cannot be activated with the remote control.	▶ Replace the remote control batteries. (Page 12) ▶ Confirm that the control is within the coverage area of the main unit, which is less than 3 m. (Page 12) ▶ Check whether the main power switch is turned on. (Page 15)

PRODUCT SPECIFICATIONS

Item/Model	LG HOM-BOT VR6260 Ser. / VR6270 Ser.
External Dimensions	340 mm × 340 mm × 89 mm
Weight	3 kg
Power Consumption	18 W
Battery (Fully Charging)	DC 16.8 V
Traveling Velocity	350 mm/s (Maximum)
Use Time	Approx. 100 minutes (Based on general wooden floor)
Charging Time	3 hours
Main Functions	Turbo Mode Learning Mode Obstacle Sensing Anti-Plunge function Scheduled Cleaning Error Displaying Navigation Auto/Manual Recharging Dry Mopping (cleaning) Corner Clean Voice Messaging Map Drawing Spot Cleaning Repeat Cleaning My Space Cleaning Cell by Cell cleaning Zigzag Cleaning

Item/Model	Home Station (VR621)
External Dimensions	236 mm X 181 mm X 128 mm
Rating	230 V~ 50 Hz
Output Voltage/Current	DC 17.1 V / 1.1 A
Power Consumption	23 W

Item/Model	Battery
Type	Lithium Ion Polymer Battery
Rating	DC 14.8 V / 1900 mAh

Open source software notice

To obtain the source code under GPL, LGPL, MPL and other open source licenses, that is contained in this product, please visit http://opensource.lge.com.
In addition to the source code, all referred license terms, warranty disclaimers and copyright notices are available for download.

Dis/Assembling the battery

Turn off the main power switch on the back-left side of the Robot Cleaner.

Place a soft cloth on the floor, remove the dust bin, and flip the Robot Cleaner over.

Remove the screw by using the screwdriver.

Remove the battery from the device.

Separate the wire from the battery while pressing the connector hook.

Please assemble the battery in the reverse order.

⚠ WARNING

Please be careful of fire, explosion, electric shock, or breakdown.

- Do not charge this Battery Pack(Pack hereafter) with any other type of charger than the one originally provided whit the charger.
- Do not damage the Pack in such ways as drop, crush, puncture, cut or short external contacts.
- Do not attempt to disassembly the pack In any case. When the Pack is damaged or malfunctioning, bring it to the service center.
- Do not place this pack near a heat source or do not dispose of in fire or water.
- Please keep the Pack away from damp or wet environment when the pack is charged.
- Please keep away from children, infant or pets.

Disposal of waste batteries/accumulators

1. When this crossed-out wheeled bin symbol is attached to batteries/accumulators of Your product it means they are covered by European Directive 2006/66/CE.
2. This symbol may be combined with chemical symbols for mercury(Hg), cadmium(Cd) or lead(Pb) if the battery Contains more that 0.0005% of mercury, 0.002% of cadmium or 0.004% of lead.
3. All batteries/accumulators should be disposed separately from the municipal waste stream via designated collection facilities appointed by the government or the local authorities.
4. The correct disposal of Your old batteries/accumulators will help to prevent potential negative consequences for the environment, animal and human health.
5. For more detailed information about disposal of Your old batteries/accumulators, please contact Your city office, waste disposal service or the shop where You purchased the product.

Disposal of your old appliance

1. When this crossed-out wheeled bin symbol is attached to a product it means the product is covered by the European Directive 2002/96/EC.
2. All electrical and electronic products should be disposed of separately from the municipal waste stream via designated collection facilities appointed by the government or the local authorities.
3. The correct disposal of your old appliance will help prevent potential negative consequences for the environment and human health.
4. For more detailed information about disposal of your old appliance, please contact your city office, waste disposal service or the shop where you purchased the product.

Warranty Certificate
For offer a 24-month warranty for this apparatus

During the 24-month warranty period, (Battery of cleaning robot : 12month) we will repair your apparatus at no cost to you or make available spare parts to your dealer free, if this apparatus fails due to manufacturing or material defects. Further claims are excluded.
We are not liable for damages due to acts of providence or damages occurring during transport. The buyer assumes shipping and packaging costs.
Your warranty conditions on the rear also apply!

Type of apparatus: _____ Serial number: [ ]

Name of buyer: _____

Purchase date: _____ Dealer's stamp and signature

Warranty conditions for vacuum cleaner

1. **The warranty period begins** on the purchase date and is valid for 24 months. Begin of warranty period is proven if, the buyer submits purchase receipt together with the warranty card, filled in and signed by the seller. The serial number of the product must agree with the number entered onto the warranty card.

2. **During the warranty period, we will** correct any defects at no cost to you, if it can be proven that these are attributed to manufacturing or material defects.

3. Damages due to incorrect handling, non-compliance with instructions for use and normal wear **are not covered by this warranty.** Also, the warranty does not cover wear parts or easily broken parts (for example, viewing glass, light bulbs). The buyer is responsible for any damages during transport as well as shipping and packaging costs.

4. **We decide whether to make repairs, exchange or replace parts.** Exchanged or replaced parts are our property. The original warranty period is not prolonged if a refrigerator is repaired or certain parts are replaced.

5. **The warranty is nullified** if any person intervenes in the apparatus that are not authorised by LG Electronics, if the apparatus is used for commercial purposes.

6. **Always keep the original packaging,** so that if the apparatus requires servicing, it can be transported without damaging it.

7. **If a repair is covered by this warranty,** always contact your dealer or an authorised service centre.

8. **Further claims are excluded.** If parts of these provisions are invalid, they apply in the sense of the wording. The validity of the other provisions is not effected.

LG
Life's Good

מדריך למשתמש

שואב רובוטי

לפני השימוש, קרא בתשומת לב את העמודים העוסקים
באמצעי בטיחות, להפעלה בטוחה של המוצר.
לאחר קריאת מדריך ההפעלה, שמור אותו במיקום נגיש.

VR6260 Ser.
VR6270 Ser.

www.lg.com

MFL67680025

תכונות

Corner Master
הודות לתכנון קונספט חדש לחלוטין המתאים לקירות, ביצועי הניקוי של Robot Cleaner הינם יעילים באופן יוצא מן הכלל.

מצב למידה
Robot Cleaner מסוגל לזכור את סביבת הניקוי באמצעות התכונה Smart Operation, לניקוי חכם יותר.

מצב טורבו
במצב "טורבו", Robot Cleaner פועל בעצמה גבוהה יותר, ומשיג תוצאות נקיות יותר.
כאשר מצב "טורבו" נבחר, הוא מופעל באופן אוטומטי על-גבי שטיחים, מה שמאפשר ל-Robot Cleaner פעולה יעילה יותר.

לוחית סמרטוט נשלפת
לוחית הסמרטוט הנשלפת מקלה על המשתמש להחליף את הסמרטוט ללא צורך בהפיכת המכשיר.

מצב My Space
הפקודה לנקות שטח מסוים גורמת ל-Robot Cleaner לנקות במהירות את אותו השטח.

ניקוי חוזר
Robot Cleaner ינקה שוב ושוב, עד שתיגמר הסוללה.

פונקציית חיפוש מיקום
כאשר Robot Cleaner מועבר מנקודה מסוימת תוך כדי פעולתו, המכשיר יחפש באופן אוטומטי את המיקום הקודם, וישוב לאותה נקודה שבה פעולתו הופרעה.

תוכן העניינים

1
לפני השימוש

2~5 אמצעי בטיחות
6 כלול במוצר
7~8 תיאור חלקים
9~10 פונקציות לחצנים
11 מידע מצב תצוגה
12 לפני שתתחיל
13 מבט כולל

2
אופן השימוש

14 כיצד להתקין את תחנת הבית
15 כיצד להפעיל ולכבות את אספקת המתח ל-Robot Cleaner
16 כיצד להתחיל בניקוי ולהפסיק אותו
17~18 כיצד לטעון את הסוללה
19~20 מצבי ניקוי
21~22 מצבי עזר לניקוי
23 הגדרת זמן
24 ניקוי מתוזמן
25 ניקוי בסרמטוט (אופציונלי)
26 פונקציית חיפוש מיקום
27~28 אבחון חכם

3
אופן הטיפול לאחר השימוש

29 ניקוי מכל האבק
30 ניקוי מסנן מכל האבק
31 ניקוי המברשת
32 ניקוי חיישן/מסוף הטעינה
33 ניקוי המברשת הצדית
34 ניקוי סמרטוט אולטרא מיקרופייבר (אופציונלי)

4
מידע נוסף

35~37 פתרון בעיות
38 לפני פנייה לקבלת שירות

5
עיון

39 מפרטי מוצר
40 הודעה של תוכנת מקור פתוח

אמצעי בטיחות

אמצעי הבטיחות המתוארים להלן נועדו לאפשר למשתמש להשתמש במוצר באופן בטוח ונכון, כדי למנוע סיכונים בלתי-צפויים לפציעה או נזק.

אמצעי בטיחות בסיסיים
לאחר קריאת מדריך זה, שמור אותו במיקום נגיש.
⚠ זהו סמל התראת הבטיחות. סמל זה מתריע בפני סכנות אפשריות העלולות להוביל לנזק לרכוש ו/או פציעה קשה או מוות.
⚠ **אזהרה** מציין מצב מסוכן שאם יתממש, עלול לגרום למוות או לפציעה קשה.
⚠ **שים לב** מציין מצב מסוכן שאם יתממש, עלול לגרום לפציעה קלה או בינונית.

⚠ אזהרה

1. מכשיר זה אינו מיועד לשימוש על-ידי אנשים (בכלל זה ילדים) עם ליקויים פיזיים, שכליים או ליקויי חושים, או עם היעדר הניסיון והידע הדרושים, אלא אם הם נמצאים תחת השגחה או הנחיה בנוגע לשימוש במכשיר מצד אדם האחראי לבטיחותם.
2. יש להשגיח על ילדים, על מנת להבטיח כי אינם משחקים עם המכשיר.
3. אם כבל המתח פגום, יש להחליפו על-ידי נציג שירות של Brimag Service כדי להימנע מסכנה.
4. מכשיר זה מתאים לשימוש על-ידי ילדים מגיל 8 ומעלה ואנשים עם ליקויים פיזיים, שכליים או ליקויי חושים, או ללא הניסיון והידע הדרושים, אם הם נמצאים תחת השגחה או הנחיה עבור שימוש בטוח במכשיר, ומבינים את הסכנות הכרוכות בכך.

אין לאפשר לילדים לשחק במכשיר.
אין לאפשר ניקוי או תחזוקת משתמש של המכשיר על- ידי ילדים ללא השגחה.

למען בטיחותך, הימנע מלהוציא את הסוללה מ-Robot Cleaner. אם ברצונך להחליף את הסוללה או את Robot Cleaner, קח את המכשיר אל מוקד השירות או הספק המורשה הקרוב של LG Electronics לקבלת סיוע.

אי ציות לאזהרה זו עלול לגרום לשריפה או לתקלה במוצר.

אין להשתמש ב-Robot Cleaner עם סוללה ו/או תחנת בית מכל מוצר כלשהו שאינו Robot Cleaner.

פעולה זו עלולה לגרום לשריפה או לתקלה במוצר.

אמצעי בטיחות

אזהרה

ודא כי כבל המתח של תחנת הבית אינו מעוך מתחת לעצם כבד ושלא ניזוק כתוצאה ממגע עם עצמים חדים.

אי ציות לאזהרה זו עלול לגרום למכת חשמל, לשריפה או לתקלה במוצר. אם כבל המתח קרוע, אל תחבר אותו לחשמל. קח את המוצר למתקן שירות מורשה של LG Electronics.

אל תשתמש ב-Robot Cleaner כאשר נרות או עצמים שבירים מונחים על הרצפה.

פעולה זו עלולה לגרום לשריפה או לתקלה במוצר.

אל תניח את תחנת הבית ואת Robot Cleaner בסמוך למכשיר פולט חום.

פעולה זו עלולה לגרום לעיוות המוצר, לשריפה או לתקלה במוצר.

תמיד השתמש בשקע ייעודי בדירוג 10 אמפר.

אם מכשירים מרובים מחוברים לאותו השקע בו-זמנית, הם עלולים להפיק מספיק חום לגרימת שריפה.

אל תכופף בכוח את התקע החשמלי. אל תשתמש בתקע החשמלי אם ניזוק או התרופף/התפרק.

פעולה זו עלולה לגרום לשריפה או לתקלה במוצר.

בעת משיכת התקע החשמלי של תחנת הבית, משוך אותו על-ידי אחיזה בתקע, ולא בכבל. בעת משיכת התקע החשמלי לניתוק, אל תיגע בשיני התקע באצבעות.

פעולה זו עלולה לגרום למכת חשמל.

אל תיגע בתקע החשמלי בידיים רטובות.

פעולה זו עלולה לגרום למכת חשמל.

אל תאפשר לילדים או לחיות מחמד לשחק עם Robot Cleaner או לנוח עליו אף פעם. אל תשתמש ב-Robot Cleaner כאשר עצם כלשהו תלוי ממנו.

פעולה זו עלולה לגרום לפציעה או לנזק למוצר.

אין לרסס או להשתמש בחומרים דליקים, חומרים פעילי שטח או מי שתייה בקרבת Robot Cleaner.

פעולה זו עלולה לגרום לשריפה או לתקלה במוצר.

* חומרים דליקים: בנזין, חומר מדלל וכדומה
* חומר פעיל שטח: חומר ניקוי, מוצרי רחצה וכדומה.

כבה מיד את אספקת המתח במקרה של צליל או ריח חריג או עשן מ-Robot Cleaner, על-ידי ניתוקו מתחנת הבית וכיבוי המתג הראשי בצדה האחורי של היחידה.

אחרת, עלולה להיגרם שריפה או תקלה במוצר.

אין להכניס שום איבר, כגון יד או רגל, אל מתחת למברשת או לגלגלים של Robot Cleaner במהלך השימוש.

פעולה זו עלולה לגרום לפציעה או לנזק למוצר.

אל תפעיל את Robot Cleaner בחדר שבו נמצא ילד ישן.

פעולה זו עלולה לגרום לפציעה או לנזק למוצר.

אל תפעיל את Robot Cleaner על-גבי רהיטים צרים וגבוהים, כגון ארון בגדים, מקרר, שולחן וכדומה.

פעולה זו עלולה לגרום לפציעה, לתקלה במוצר או לנזק שאינו מכוסה במסגרת האחריות.

אל תשאיר ילדים או חיות מחמד ללא השגחה ליד Robot Cleaner.

פעולה זו עלולה לגרום לפציעה או לנזק למוצר.

אל תפעיל את המכשיר על-גבי רצפה עם שיפוע של יותר מ10- מעלות.

המכשיר עלול שלא לפעול כראוי.

מוצר זה נועד לשימוש ביתי פנימי, ואין להשתמש בו ליישומים ניידים. אין להשתמש במוצר ליישומים מסחריים, כגון סדנאות עבודה, מוסכים וכדומה.

אמצעי בטיחות

שים לב

יש לרוקן בתכיפות את מכל האבק ולשמור על ניקיונו.

האבק הנאסף במכל האבק עלול לעורר תגובות אלרגיות ולהכיל חרקים מזיקים.

אין להפיל את Robot Cleaner או לחשוף אותו למכות חזקות.

פעולה זו עלולה לגרום לפציעה או לתקלה במוצר שאינה מכוסה במסגרת האחריות.

השתמש ב-Robot Cleaner בתוך הבית בלבד.

שימוש חיצוני במוצר עלול לגרום לתקלות ולנזק בלתי-הפיך ליחידה.

אין לחשוף את Robot Cleaner לטמפרטורות קרות (פחות מ-5-°C) למשך פרק זמן ארוך.

פעולה זו עלולה לגרום לתקלה במוצר.

סגור את כיסוי מכל האבק ביחידה הראשית לפני שתתחיל בניקוי.

אם הכיסוי אינו סגור, קיימת סכנת פציעה או נזק למוצר.

סלק כבלים או חוטים מהרצפה לפני תחילת הפעולה.

כבלים או חוטים עלולים להסתבך בגלגלי Robot Cleaner ולגרום לתקלה במוצר או לניתוק כבלי מכשירים.

אין להשתמש ב-Robot Cleaner בסמוך למעקה, מדרגות או כל מקום מסוכן אחר.

אחרת, המשתמש או המוצר עשוי להיחשף לנזק.

ודא כי Robot Cleaner אינו מונח על-גבי שולחן כאשר מתג ההפעלה פועל.

פעולה זו עלולה לגרום לפציעת המשתמש או לנזק למוצר.

במקרים נדירים, המברשת של Robot Cleaner עלולה לגרום נזק לשטיח. במקרה כזה, הפסק מיד את פעולת הניקוי.

במקרה של שטיח עם סיבים ארוכים, ייתכן נזק לסיבים.

אין לאפשר ל-Robot Cleaner לנקות נוזלים, להבים, סיכות, חומרי בעירה וכדומה.

פריטים אלה עלולים לגרום לתקלה במוצר.

אין לאפשר ליחידה הראשית ולמסוף הטעינה של תחנת הבית לבוא במגע עם עצמים מתכתיים.

פעולה זו עלולה לגרום לתקלה במוצר.

אין להחדיר עצמים חדים לפתח של חיישן האולטראסאונד של Robot Cleaner.

פעולה זו עלולה לגרום לתקלה במוצר.

אין להחדיר ל-Robot Cleaner מים, חומרי ניקוי וכדומה.

פעולה זו עלולה לגרום לתקלה במוצר. אין לשפוך על Robot Cleaner מים או חומרי ניקוי כלשהם. במקרה של חדירת נוזלים ל-Robot Cleaner, כבה את אספקת המתח ופנה לנציג מכירות או למוקד שירות לקוחות של LG Electronics.

אין להשתמש ב-Robot Cleaner כאשר מכל האבק מלא.

פעולה זו עלולה לגרום לתקלה במוצר.

אמצעי בטיחות

שים לב

אם הרצפה רטובה או שחלקים ממנה רטובים, נגב וייבש אותה לפני השימוש ב-Robot Cleaner. אין להשתמש ב-Robot Cleaner על-גבי משטח רטוב.

אחרת, עלולה להיגרם תקלה במוצר.

כאשר Robot Cleaner פועל, הוא עלול להתנגש ברגלי כיסאות, רגלי שולחנות או בחלקי ריהוט צרים אחרים.

לניקוי מהיר וטוב יותר, הנח כיסאות על-גבי השולחן.

בעת חיבור הסמרטוט, הימנע מלחסום את חיישן המצלמה התחתון.

חסימת חיישן המצלמה התחתון עלולה למנוע פעולה חלקה של המוצר.

ודא כי הלוחית על-גבי הרצפה גבוהה ביותר מ2- ס"מ מהקרקע לפני שתתחיל בניקוי.

אם הסף נמוך, Robot Cleaner עלול לעבור מעליה ואולי להגיע למיקום בלתי רצוי. ודא כי כל דלתות החדרים שאינם מיועדים לניקוי סגורות.

אם אינך משתמש ביחידה, כדי לחסוך באנרגיה, כבה את מתג ההפעלה, והפעל אותו בעת ניקוי או טעינה.

טיפ

בדוק את הפריטים הבאים לפני השימוש:

- רוקן את מכל האבק לאחר כל הפעלה או לפני שיתמלא.
- סלק כבלים או חוטים ארוכים כלשהם מהרצפה.
- נקה את הרצפה מכל לחות שהיא לפני הניקוי.
- סגור את כיסוי מכל האבק לפני הניקוי.
- סלק כל עצם שביר או מיותר מהחדר המיועד לניקוי.
  לדוגמה, סלק פריטי קרמיקה יקרים וחפצי ערך מהרצפה.
- ודא כי הסוללה מלאה דיה, ואם אינה, טען אותה.
- סגור את דלתות החדרים שאינך מעוניין כי Robot Cleaner ייכנס אליהם.
  במהלך הניקוי, Robot Cleaner עשוי להיכנס לחדר אחר ולהמשיך בניקוי.
- אל תשתמש במוצר זה בחדר שבו ילד ישן לבדו. הילד עלול להיפצע או להתעורר.
- סלק מגבות או כל אריג דק אחר מהרצפה, משום שהם עלולים להיתפס במברשת.
- לפני הפעלת המכשיר, כדאי לסלק שטיחים שהינם עבים יותר מ20- מ"מ, משום הם עלולים לגרום לתקלות.
- סגור דלתות מרפסת. הגלגלים עלולים להיתקע במהלך הניקוי.

כלול במוצר

Robot Cleaner

תחנת בית

שלט רחוק

◀ האיורים עשויים להיות שונים מהפריטים בפועל.

מדריך הפעלה

מדריך מהיר

מסנן מכל אבק (חלופי)
(אופציונלי)

כלי ניקוי

סמרטוט אולטרא מיקרופייבר
(שניים) (אופציונלי)

לוחית סרמטוט (אופציונלי)

מברשת ניקוי
(נמצאת על-גבי כיסוי מכל האבק)

Carpet Master (אופציונלי)

מברשת צדית (שתיים)
(אופציונלי)

סוללה יבשה עבור השלט הרחוק
(שתי יחידות בגודל AAA)

תיאור חלקים - ROBOT CLEANER

מבט מישורי

מבט קדמי

מבט אחורי

מבט תחתון

◄ **האיורים עשויים להיות שונים מהפריטים בפועל.**

תיאור חלקים - תחנת בית/מכל אבק

תחנת בית

מכל אבק

◀ **האיורים עשויים להיות שונים מהפריטים בפועל.**

פונקציות לחצנים - ROBOT CLEANER

TURBO	• לחיצה על הלחצן תגדיר את מצב טורבו, עם אישור קולי. • לחיצה על הלחצן במצב טורבו תבטל את המצב.
START/STOP	• משמש להפעלת המכשיר, להתחלת הניקוי ולהפסקתו. • לחיצה על הלחצן כאשר היחידה מופעלת תתחיל בניקוי. • לחיצה על הלחצן במהלך הניקוי תפסיק את הניקוי. • לחיצה על הלחצן למשך שתי שניות כאשר המכשיר מופעל תכבה את המכשיר. • לחיצה על הלחצן במצב 'אבחון חכם' תסיים את האבחון.
MODE	• משמש לשינוי הגדרת מצב הניקוי. • אם המכשיר נמצא בתחנת הבית, האפשרות 'ניקוי נקודתי' אינה זמינה. • ניתן לבחור במצב My Space באמצעות השלט הרחוק בלבד (כאשר Robot Cleaner אינו נמצא בתחנת הבית).
HOME	• משמש להחזרת Robot Cleaner לתחנת הבית לצורך טעינה. • בסיום הניקוי או כשהסוללה חלשה, Robot Cleaner יחזור בעצמו לתחנת הבית כדי לטעון את הסוללה.
לחצנים מנעול On/Off	• לחיצה על הלחצנים Turbo ו-Mode למשך שלוש שניות תבטל את פונקציית הנעילה. • אם אפשרות הנעילה מופעלת, ההודעה הקולית "Key has been locked" תישמע בכל לחיצה על לחצן כלשהו.

פונקציות לחצנים - שלט רחוק

Start
לחיצה על לחצן זה תתחיל בניקוי.
(עמ' 16)

Mode
שינוי מצב הניקוי.(עמ' 19)

לחצן כיוונים
לחצן זה מאפשר הפעלה ידנית ובחירת אזור במצב 'ניקוי My Space'.

Repeat (חזרה)
לחצן זה מאפשר הפעלה או ביטול של מצב 'ניקוי חוזר'.
(עמ' 22)

Schedule
משמש להתחלת הניקוי בזמן מסוים.
לחיצה על הלחצן למשך שלוש שניות תבטל את הניקוי המתוזמן.
※ אפשרויות קביעת תזמון/ביטול זמינות במצב 'טעינה' בלבד.
(עמ' 24)

Clock
משמש להגדרת השעה הנוכחית המצוינת ב-Robot Cleaner.
(עמ' 23)

Home
משמש לטעינת Robot Cleaner על-ידי החזרתו לתחנת הבית. (עמ' 17)

Turbo
משמש להפעלה וביטול של מצב 'טורבו'. (עמ' 22)

Stop/OK
לחיצה על הכפתור תפסיק את פעולת השואב הרובוטי, או תאשר את הגדרת זמן הניקוי או לוח הזמנים.

My Space
ממשמש להעברת Robot Cleaner 'ניקוי My Space'. (עמ' 20)

Mute
משמש להפעלה וביטול של מצב 'השתק'. (עמ' 11)

Diagnosis
משמש להפעלת 'אבחון חכם'.
זמין רק כאשר Robot Cleaner נמצא בטעינה. (עמ' 27)

טיפ

- השלט הרחוק אינו מספק פונקציית הפעלת מכשיר.
- כאשר המכשיר כבוי, השלט הרחוק לא יפעל.
- כדי להפעיל/לכבות את המכשיר, השתמש בלחצן Start/Stop בחלק העליון של Robot Cleaner.
- השתמש בלחצן Mode, My Space או Clock רק לאחר עצירת פעולת Robot Cleaner.

מידע מצב תצוגה

סמל השתקה
סמל זה מציין אם מצב השתקה פועל או מבוטל.

סמל סוללה
סמל זה מציין את רמת הסוללה הנוכחית, ומהבהב כאשר יש לטעון את הסוללה.

סמל AM/PM
מציין אם השעה הינה AM או PM, בהתאם להגדרת השעון.

סמל טורבו
מוצג כאשר מצב 'טורבו' מופעל.

סמל חזרה הביתה
סמל זה מוצג אם Robot Cleaner נמצא במצב 'חזרה הביתה'.

ניקוי My Space
מוצג כאשר Robot Cleaner פועל במצב ניקוי My Space.

ניקוי נקודתי
סמל זה מופיע כאשר Robot Cleaner מתחיל בניקוי נקודתי.

סמל מנעול
מציין אם 'נעילה' מופעלת או לא.

סמל תזמון
מציין את מצב הגדרת התזמון/'פעם אחת' או 'כל יום'.

ניקוי חוזר
מוצג אם המכשיר נמצא במצב 'ניקוי חוזר'.

ניקוי זיגזג
סמל זה מוצג כדי לציין כי Robot Cleaner פועל במצב 'ניקוי זיגזג'.

ניקוי Cell by Cell
סמל זה מוצג כדי לציין כי Robot Cleaner פועל במצב 'ניקוי Cell by Cell'.

תצוגת זמן
מציין את השעה הנוכחית והשעה המתוזמנת.

טיפ

- לאחר בחירה במצב הניקוי (זיגזג או Cell by Cell), הבחירה תישמר גם לאחר כיבוי המכשיר.
- כדי לבטל את ההגדרה, לחץ על הלחצן Schedule בשלט הרחוק למשך שלוש שניות כאשר Robot Cleaner נמצא בטעינה.

לפני שתתחיל

בדוק פריטים אלה לפני הניקוי

- אל תשתמש במכשיר זה בחדר שבו ילד נמצא לבדו. הילד עלול להיפצע.
- סלק כל עצם שביר או מיותר מהחדר המיועד לניקוי.
  בייחוד, סלק פריטי קרמיקה יקרים וחפצי ערך מהרצפה.
- סגור את כיסוי מכל האבק לפני הניקוי.
- יבש כל לחות שעשויה להימצא על הרצפה.
- סלק כבלים, רצועות, מגבות, מחצלות וכדומה מהרצפה, כדי שלא ייתפסו במברשת.
- ודא כי הסוללה מלאה דיה, ואם אינה, טען אותה.
- רוקן את מכל האבק לפני או אחרי כל ניקוי, או לפני שיתמלא.
- סגור את דלתות החדרים שאינך מעוניין כי Robot Cleaner ייכנס אליהם. במהלך הניקוי, Robot Cleaner עשוי להיכנס לחדר אחר ולהמשיך בניקוי.
- כאשר הסמרטוט מחובר, Robot Cleaner לא יוכל לעבור מעל לסף בגובה 5 מ״מ ומעלה.
  אם אינך מתכנן להשתמש בסמרטוט לניקוי, נתק את הסמרטוט לפני השימוש ב-Robot Cleaner.
- לפני הפעלת המכשיר, כדאי לסלק שטיחים שהינם עבים יותר מ20- מ״מ, משום הם עלולים לגרום לתקלות.
- סגור דלתות מרפסת. הגלגלים עלולים להיתקע במהלך הניקוי.

טעינה של סוללת השלט הרחוק

1. פתח את מכסה הסוללות על-ידי הרמת הקרס האחורי של השלט הרחוק.
2. הכנס שתי סוללות AAA - שים לב לנקודות +/- בעת הכנסתן.
3. סגור את מכסה הסוללות לחלוטין, כדי שהסוללות לא ייפלו החוצה.

אמצעי זהירות לשימוש בשלט הרחוק

- לחץ על לחצן אחד בלבד בכל פעם.
- אל תפיל את הפריט, ואל תחשוף אותו למכות חזקות.
- אל תאחסן את הפריט בסמוך למכשירים הפולטים חום, אש או אוויר חם.
- מנורות פלורסנט מסוימות, כגון נורת קרינה תלת-תדרית, עלולות להפריע להפעלת השלט הרחוק.
  לכן, השתמש בפריט במרחק רב ככל האפשר ממנורות כאלה.
- אם השלט הרחוק נמצא במרחק רב מ-Robot Cleaner בעת הפעלתו, הוא עלול שלא לפעול כראוי.
  השתמש במכשיר בטווח של 3 מטרים מ-Robot Cleaner במידת האפשר.

מבט כולל

1 התקן את תחנת הבית. (עמ' 14)

הכנס את תקע כבל המתח לשקע, והצב את התחנה בסמוך לקיר.
אם לא יסופק מתח לתחנת הבית, Robot Cleaner לא ייטען.

2 הפעל את אספקת המתח ל-Robot Cleaner. (עמ' 15)

הפעל את מתג ההפעלה בצדו האחורי-שמאלי של Robot Cleaner, ולאחר מכן לחץ על הלחצן Start/Stop בחלקו העליון.
※ אם אספקת המתח אינה מופעלת, עיין בעמוד 15.

3 בדוק את מכל האבק.

בדוק את מידת הניקיון של מכל האבק לפני שתתחיל בניקוי, וסגור את כיסוי מכל האבק ביחידה הראשית.

4 התחל בניקוי. (עמ' 16)

לחץ על לחצן START/STOP פעם נוספת כאשר Robot Cleaner מופעל. צליל הניקוי יישמע, והניקוי יתחיל.

5 טעינה אוטומטית. (עמ' 17~18)

Robot Cleaner יבצע אבחון עצמי ויחזור לתחנת הבית באופן אוטומטי כדי להיטען, לפני שהסוללה תתרוקן לחלוטין.
טעינת הסוללה נמשכת כשלוש שעות.

6 השתמש במצב הניקוי ופונקציות העזר. (עמ' 19~25)

השתמש בלחצנים ב-Robot Cleaner ובשלט הרחוק כדי להשתמש במצבי הניקוי השונים ובתכונות התמיכה.
מצבי הניקוי כוללים ניקוי זיגזג, Cell by Cell, נקודתי, My Space וניקוי חוזר; תכונות התמיכה כוללות ניקוי ידני, מתוזמן וסמרטוט מיקרופייבר.

< אזהרה > כאשר Robot Cleaner פועל עם מכסה מכל אבק פתוח, עלולה להיגרם פציעה או נזק חמור למוצר.

כיצד להתקין את תחנת הבית

כיצד להתקין את תחנת הבית

1. הצב את תחנת הבית כנגד קיר, על-גבי רצפה ישרה וקשיחה, כדי למנוע החלקה במהלך העגינה.

סלק עצמים בטווח 1.5 מטר מימין ומשמאל ובטווח 2 מטר מלפנים.

2. חבר את כבל המתח לשקע.

לפף את כבל המתח מסביב לקרס ההחזקה בצדה האחורי של תחנת הבית או לאורך פני הקיר, כך שנתיב הנסיעה של Robot Cleaner לא ייחסם.

3. הצמד את תחנת הבית לקיר, כך שלא תזוז ממקומה.
הפעל את מתג ההפעלה.

4. כאשר השלט הרחוק אינו נמצא בשימוש, אחסן אותו במחזיק השלט הרחוק בתחנת הבית.

טיפ

- תמיד השאר את תחנת הבית מחוברת לחשמל. אם אינה מחוברת לחשמל, Robot Cleaner לא יחזור באופן אוטומטי לטעינה בתחנת הבית.

< אזהרה > **אל תפעיל את Robot Cleaner אם הכבל או התקע של תחנת הבית ניזוק או במקרה של פעולה לא-תקינה, נזק או הפלה של תחנת הבית. כדי למנוע סכנה, יש להחליף את הכבל באמצעות .Brimag Service או איש שירות מוסמך.**

כיצד להפעיל ולכבות את אספקת המתח ל-Robot Cleaner

הפעלת אספקת המתח הראשית

ודא כי מתג ההפעלה בצדו האחורי-שמאלי של Robot Cleaner נמצא במצב מופעל. אם המכשיר במצב כבוי, הפעל את המתג.

※ בעת הפעלת מתג ההפעלה, אל תלחץ על הלחצן שבחלקו העליון של Robot Cleaner. פעולת הלחצן עלולה להתעכב.

※ כבה את מתג ההפעלה אם Robot Cleaner אינו נמצא בשימוש למשך פרק זמן ממושך, כדי להגן על הסוללה. לא ניתן לטעון את טוברה פוגב אם המתג הראשי נמצא במצב OFF (כבוי).

הפעלה ממצב 'המתנה'.

כאשר Robot Cleaner כבוי, לחץ על הלחצן Start/Stop למשך שנייה אחת עד שיישמע צלצול. לאחר כ10- שניות, המכשיר יופעל, ותישמע מנגינה.

※ אם חלפו 10 דקות מבלי שניתנה ל-Robot Cleaner פקודה פעילה כלשהי לאחר ההפעלה, המכשיר ייכבה באופן אוטומטי.

כיבוי אספקת המתח

לחץ על לחצן START/STOP למשך שתי שניות כאשר Robot Cleaner מופעל. תישמע מנגינה בעת הכיבוי.

טיפ

- אם לא ניתן להפעיל את המכשיר, בצע את הפעולות הבאות.
  - הפעל את מתג ההפעלה והמתן למשך יותר משלוש שניות.
  - לחץ על הלחצן START/STOP כאשר מתג ההפעלה נמצא במצב מופעל.
  - אם המכשיר אינו מופעל או אם אין תצוגה מלבד הצלצול, העבר את Robot Cleaner לתחנת הבית באופן ידני.

כיצד להתחיל בניקוי ולהפסיק אותו

שימוש בלחצנים של Robot Cleaner

לאחר הפעלת Robot Cleaner, לחץ על הלחצן START/STOP כדי להתחיל בניקוי. תישמע מנגינה, והניקוי יתחיל.

לחץ על הלחצן START/STOP במהלך מחזור הניקוי כדי להפסיק את הניקוי.

※ לחיצה על הלחצן START/STOP כאשר אספקת המתח ל-Robot Cleaner כבויה תפעיל את המכשיר.
לחץ על הלחצן START/STOP פעם נוספת כדי להתחיל בניקוי.

שימוש בשלט הרחוק

לאחר הפעלת Robot Cleaner מ-טובורה פוגב, לחץ על הלחצן START בשלט הרחוק. תישמע מנגינה, והניקוי יתחיל.

לחץ על הלחצן Stop/OK במהלך מחזור הניקוי כדי להפסיק את הניקוי.

※ לא ניתן להפעיל את Robot Cleaner ממצב 'המתנה' באמצעות השלט הרחוק כאשר Robot Cleaner כבוי. כאשר המכשיר כבוי, לחץ על הלחצן START/STOP בצדו העליון של Robot Cleaner כדי להפעיל את המכשיר ולאפשר שימוש בשלט הרחוק.

※ במהלך הניקוי, ייתכנו התנגשויות כאשר לחיישן אין אפשרות לזהות עצמים בשל צורתם (רגלי כיסא ושולחן צרות, פינות רהיטים). במקרה כזה, חיישן הפגיעה הפנימי יגיב בתנועה אחורה.

※ אם Robot Cleaner מוגדר להתחיל בניקוי כאשר אינו בתחנת הבית, הנח את Robot Cleaner על רצפה שטוחה כדי למנוע תקלות בחיישן זיהוי המכשולים. כמו כן, התחל בניקוי ממיקום שבו אין מכשולים כגון וילונות או קירות בטווח של 30 ס"מ מ-Robot Cleaner.

טיפ לתוצאות מיטביות:

- בצע סריקה קצרה של האזור המיועד לניקוי לאיתור עצמים גדולים וקטנים שיקשו על Robot Cleaner.
- אם הניקוי מתחיל כאשר Robot Cleaner נמצא בתחנת הבית, המכשיר מסוגל לחזור במהירות לתחנת הבית, משום שמיקום הבית הנוכחי נקלט בבירור.
- כאשר לוחית הסמרטוט מותקנת, כדי למנוע זיהום שני מהסמרטוט המלוכלך, היא לא תעבור מעל מפתן דלת בגובה 5 מ"מ ומעלה.

כיצד לטעון את הסוללה

טעינה אוטומטית

Robot Cleaner חוזר לתחנת הבית בסיום מחזור הניקוי או כאשר הסוללה חלשה.

※ אם חלפו 10 דקות ללא תנועה של Robot Cleaner או אם הסוללה חלשה, המכשיר ייכבה באופן אוטומטי.

※ **אל תכבה את מתג ההפעלה הראשי, משום שהסוללה לא תיטען. אם המכשיר מוחזר באופן ידני כאשר מתג ההפעלה הראשי כבוי, תופיע הודעת השגיאה "Main power switch on the back of the HOM-BOT is turned off. Please turn the switch on."**

※ במקרה שבו היחידה חוזרת לתחנת הבית עקב סוללה חלשה במהלך הניקוי, הניקוי יתחיל, לאחר הטעינה, מהמיקום הקרוב ביותר באזור שטרם נוקה. (עמוד 18)

※ אם ל-Robot Cleaner אין אפשרות לעגון בתחנת הבית בניסיון הראשון, הוא ינסה שוב עד לעגינה מוצלחת.

※ לאחר ש-Robot Cleaner סיים לנקות את כל האזורים האפשריים, הוא יחזור לתחנת הבית, גם אם הסוללה אינה חלשה.

טעינה ידנית

בשימוש ב-Robot Cleaner בפעם הראשונה או בעת טעינת הסוללה במהלך הניקוי, תוכל לטעון את הסוללה ידנית.

שיטה 1. חבר את Robot Cleaner לתחנת הבית על-ידי יישורו עם צדה הקדמי של התחנה. תישמע מנגינה, יחד עם הודעה קולית לגבי תחילת הטעינה.

※ **בהישמע ההודעה הקולית:**
"Main power switch on the back of the HOM-BOT is turned off. Please turn the switch on."

שיטה 2. לחיצה על הלחצן HOME בשלט הרחוק או ב-Robot Cleaner תתחיל בתהליך הטעינה על-ידי שידור אוטומטי של אות חיפוש והחזרת Robot Cleaner לתחנת הבית.

※ **אם Robot Cleaner לא התחיל בניקוי מתחנת הבית או אם מתבצעת טעינה ידנית של Robot Cleaner על-ידי לחיצה על הלחצן Home, ייתכן שאיתור תחנת הבית יימשך מעט יותר זמן.**

※ אם Robot Cleaner נמצא בטווח של 10 ס"מ מצדו הקדמי של מסוף הטעינה כאשר אספקת המתח פועלת, הוא יוחזר באופן אוטומטי לתחנת הבית, והטעינה תתחיל.

טיפ בשימוש בתחנת הבית, יש לנקוט באמצעי הזהירות הבאים:

- במקרה שבו חומר זר נתפס במסוף הטעינה, ייתכן שהטעינה לא תתבצע באופן חלק. נגב את המסוף מדי פעם באמצעות מטלית יבשה, לאחר ניתוק כבל המתח. (עמ' 32)
- כדי למנוע מכת חשמל או נזק לתחנת הבית, הימנע ממגע במסוף הטעינה באמצעות עצם מתכתי כלשהו.
- כדי למנוע שריפה או מכת חשמל, יש למנוע מפירוק או שינוי של תחנת הבית.
- אל תניח את תחנת הבית או תקע המתח בסמוך למקור חום.

כיצד לטעון את הסוללה

מחוון טעינת הסוללה הנותרת

רמת הסוללה מצוינת בתצוגת המצב, באופן הבא.
- אם מתבצעת טעינה, נורת רמת הסוללה מהבהבת.
- בסיום הטעינה, רק הסמלים 'סוללה' ו'מצב ניקוי' מוצגים, כדי לחסוך באנרגיה.
- כשיש צורך בטעינה, רק הרמה הראשונה של נורת רמת הסוללה תופיע ותהבהב.

※ אם Robot Cleaner חוזר לתחנת הבית עם סוללה חלשה, נורת 'מצב ניקוי' תתחיל להבהב.
- כאשר נורת 'מצב ניקוי' מתחילה להבהב בסיום הטעינה, Robot Cleaner ימשיך בניקוי האזורים שטרם כוסו.
- לחיצה על הלחצן Start בשלט הרחוק או הלחצן Stop ביחידה הראשית תוך כדי טעינה, כאשר הנורה 'מצב ניקוי' מהבהבת, תגרום גם היא ל-Robot Cleaner למצוא ולנקות אזורים שטרם כוסו.
- לחיצה על הלחצן Start בשלט הרחוק או הלחצן Start/Stop במכשיר לאחר שינוי המצב תגרום ל-Robot Cleaner להתחיל לנקות מההתחלה שוב.

נורת חיווי המצב כאשר הרובוט נמצא בטעינה (במצב 'זיגזג' מרחבי)

אם לא נותר שטח לניקוי

אם נותר שטח לניקוי (מהבהב)

אם הסוללה לא נטענת

בדיקה 1:
אם הסוללה לא נטענת גם כאשר Robot Cleaner מחובר לתחנת הבית, בדוק את הפריטים הבאים.
- כבה את מתג ההפעלה בצדו האחורי-שמאלי של Robot Cleaner והפעל אותו שוב.
- בדוק את נורת ההפעלה בתחנת הבית.
- נגב את המסוף בתחנת הבית באמצעות מטלית יבשה. (עמ' 32)

מצבי ניקוי

ניקוי זיגזג

במצב 'ניקוי זיגזג', Robot Cleaner חוזר על פעולת זיגזג לניקוי כל הנקודות באזור הניקוי.

אם ברצונך לנקות אזור מסוים במהירות, בחר במצב 'ניקוי זיגזג'.
לחץ על הלחצן Mode בשלט הרחוק או ביחידה הראשית כדי לבחור במצב 'ניקוי זיגזג', ולחץ על הלחצן Start.

※ הגדרת ברירת המחדל של היצרן היא 'ניקוי זיגזג'.

ניקוי Cell by Cell

במצב Cell by Cell, Robot Cleaner מנקה את האזור על-ידי חלוקתו לשטחים מרובעים.
לניקוי קפדני, בחר במצב זה.

לחץ על הלחצן 'Mode' בשלט הרחוק או בחר במצב Cell by Cell ולחץ על הלחצן Start.

שלב ראשון:
התוואי המרבי לאזור הניקוי, 3 על 3 מטר, ינוקה.
(גודל התוואי עשוי להשתנות בהתאם לצורת האזור המיועד לניקוי.)

שלב שני:
השלב השני של ניקוי Cell by Cell מבצע באופן אוטומטי ניקוי במצב 'זיגזג'.

בסיום השלבים הראשון והשני, האזור שנוקה ינוקה על-ידי חזרה על שיטת הניקוי שלעיל, כאשר המכשיר מועבר אל החלק הבא באזור הניקוי.

טיפ

- לאחר ההגדרה, מצב הניקוי (זיגזג, Cell by Cell) יישמר, גם לאחר כיבוי אספקת המתח.
- במהלך הפעולה, אם יש צורך בשינוי מצב, לחץ על הלחצן Stop/OK ובחר במצב הרצוי. הניקוי יתחיל מההתחלה.

מצבי ניקוי

ניקוי My Space

לחיצה על My Space בשלט הרחוק תגדיר את מצב הניקוי My Space, ותישמע הודעה קולית.
לניקוי אזורים מסוימים, בחר במצב זה.

שלב ראשון:
השתמש בשלט הרחוק לניהול ידני של הניקוי בשוליים של בלוקי הניקוי השונים.

※ מצב ניקוי זה יתקבל כאשר המרחק מנקודת היעד לנקודת המוצא קצר מ1- מטר.

שלב שני:
לאחר מכן, לחיצה על הלחצן Start תגרום ל-Robot Cleaner לנקות בעצמו את האזור שהותווה באופן ידני.

※ אם התוויה נכונה של האזור תיכשל, תישמע ההודעה הקולית:
"Area does not meet the specified conditions. Please continue to make specified area for cleaning process."
השתמש בשלט הרחוק כדי להקצות שוב אזור.

※ בסיום ניקוי כל האזורים שנבחרו, Robot Cleaner יעבור למצב הניקוי שבו הופעל לפני כן (זיגזג או Cell by Cell).

טיפ

- במהלך הטעינה, לא ניתן להפעיל את מצב הניקוי My Space.
- כדי לשנות את מצב הניקוי במהלך פעולת Robot Cleaner, לחץ על הלחצן Stop/OK תחילה כדי לבחור מצב כלשהו. פעולת הניקוי תתחיל מההתחלה.

מצבי עזר לניקוי

ניקוי ידני

תוכל להזיז את Robot Cleaner במצב "ידני" על-ידי לחיצה על מקש כיוון בשלט הרחוק.
Robot Cleaner ינקה את האזור, תוך תנועה קדימה/אחורה/שמאלה/ימינה, בהתאם לקלט ממקש הכיוון.
במצב "ידני", החזקת מקש התנועה אחורה תגרום ל-Robot Cleaner להתנגש במכשולים הנמצאים מאחוריו.

ניקוי נקודתי

מתאים במיוחד לניקוי חלקים מסוימים בבית.
לחץ על הלחצן Mode בשלט הרחוק כדי לבחור במצב Spot Clean (ניקוי נקודתי), המצוין בתצוגת המצב, לחץ על הלחצן Start, ו-Robot Cleaner יתחיל בניקוי נקודתי בשטח שברדיוס של 1.5 מטר.

※ במהלך הטעינה, לא ניתן לבחור ב"ניקוי נקודתי".

המכשיר נעצר במקום שבו התחיל בסיום הניקוי (נמשך 4-5 דקות).

מצבי עזר לניקוי

מצב טורבו

לחיצה על הלחצן Turbo בשלט הרחוק או ביחידה הראשית תפעיל את מצב 'טורבו', ותישמע הודעה קולית.

במצב טורבו, לחיצה על אותו הלחצן תבטל את מצב טורבו, ותישמע הודעה קולית.

במצב טורבו, Robot Cleaner פועל באופן אינטנסיבי יותר, לניקוי עצמתי.

※ **<מצב טורבו (פונקציית Floor Master)>**
מצב טורבו יופעל באופן אוטומטי כאשר Robot Cleaner מנקה שטיחים.

מצב חזרה

לחיצה על הלחצן Repeat בשלט הרחוק תפעיל את מצב 'חזרה', ותישמע הודעה קולית.

במצב חזרה, לחיצה על אותו הלחצן תבטל את מצב חזרה, ותישמע הודעה קולית.

במצב חזרה, Robot Cleaner יחזור על פעולת הניקוי המתבצעת, עד שהסוללה תיגמר.

מצב למידה

Robot Cleaner מסוגל לזכור את סביבת הניקוי באמצעות מצב 'למידה', לפעולת ניקוי חכמה.

※ 'מצב למידה' זמין רק כאשר המכשיר מתחיל את הניקוי מתחנת הבית.

טיפ

- אמצעי זהירות עם 'הפעלה חכמה'
  - מצב למידה זה מאפשר למכשיר לזכור מיקומים עם מכשולים שיש לעקוף.
  Robot Cleaner זוכר כל כל היבט של הסביבה שבה הוצב, מהרגע שבו התחיל בניקוי מתחנת הבית ועד לרגע סיום המסלול.
  - Robot Cleaner לומד את התנאים החדשים כאשר מיקום תחנת הבית משתנה.
  - אם מצב הלמידה התקבל, תישמע ההודעה הקולית:
  "The learning cleaning process is complete."

הגדרת זמן

תוכל להגדיר את השעה הנוכחית ב-Robot Cleaner.
לחיצה על הלחצן Clock בשלט הרחוק, כאשר Cleaner Robot ממתין,
תתחיל בהגדרת השעה הנוכחית.

בחר באמצעות הלחצנים ◄ ► בשלט הרחוק. ניתן לשמוע את הפונקציה דרך המדריך הקולי.		הגדר את יחידות השעות באמצעות הלחצנים ▲▼ בשלט הרחוק.
		הגדר את יחידות הדקות באמצעות הלחצנים ▲▼ בשלט הרחוק.
		הגדר AM/PM השעות באמצעות הלחצנים ▲▼ בשלט הרחוק.
		לחיצה על הלחצן 'Clock' או 'Stop/OK' בשלט הרחוק תשלים את הגדרת השעה.

טיפ

- פעולות הניקוי המתוזמנות יופעלו בהתאם לשעה שב-Robot Cleaner.
  יש להגדיר את השעון לפני קביעת ניקוי מתוזמן.
- במקרה של היעדר קלט למשך 10 שניות, הגדרת השעון תבוטל.

ניקוי מתוזמן

תוכל לתזמן ניקוי כך ש-Robot Cleaner יתחיל בו בשעה שנקבעה.
לחיצה על הלחצן Schedule בשלט הרחוק, כאשר הסוללה בטעינה, תתחיל בהגדרת ניקוי מתוזמן.

קביעה/ביטול של ההגדרה אפשרית רק כאשר היחידה נמצאת בטעינה.

בחר רמה באמצעות הלחצנים ◄ ► בשלט הרחוק. פעם אחת כל יום		בחר באפשרות 'פעם אחת' או 'כל יום' באמצעות הלחצנים ▲▼ בשלט הרחוק. הודעה קולית תאשר את התזמון.
		הגדר את יחידות השעות באמצעות הלחצנים ▲▼ בשלט הרחוק.
		הגדר את הדקות באמצעות הלחצנים ▲▼ בשלט הרחוק.
		הגדר AM/PM השעות באמצעות הלחצנים בשלט ▲▼ הרחוק.
		לחיצה על הלחצן 'Schedule' או 'Stop/OK' בשלט הרחוק תשלים את תהליך התזמון.

טיפ

- בהגיע השעה שנקבעה, Robot Cleaner יתחיל בניקוי לבד.
- ניתן להגדיר ניקוי מתוזמן רק כאשר Robot Cleaner נמצא בטעינה.
- במהלך הטעינה, לחיצה על הלחצן Schedule בשלט הרחוק למשך שלוש שניות תבטל את התזמון שנקבע.
- אם אין קלט בעת הגדרת התזמון למשך 10 שניות, תהליך ההגדרה מבוטל.

ניקוי בסרמטוט (אופציונלי)

על-ידי חיבור סמרטוט האולטרא מיקרופייבר, תוכל להשתמש ב-Robot Cleaner לניקוי יעיל של אבק.

כאשר לוחית הסמרטוט מחוברת, Robot Cleaner לא יטפס על שטיחים או מעל ספים, כדי למנוע העברת לכלוך מהסמרטוט.

⚠ **שים לב**
אל תכסה את חיישן המצלמה התחתון באמצעות הסמרטוט.

לניקוי בסמרטוט, הרכב את הסמרטוט ולוחית הסמרטוט על Robot Cleaner בהתאם להנחיות הבאות:

1. חבר את סמרטוט האולטרא מיקרופייבר למשטח הוולקרו של לוחית הסמרטוט, כמתואר באיור.

2. לחץ בחוזקה את לוחית הסמרטוט כלפי החריצים, עד לשמיעת צליל נקישה.
   ※ שים לב כי אם לוחית הסמרטוט אינה מחוברת כראוי למקומה, היא עלולה להתנתק במהלך הניקוי.

3. חשוב להקפיד כי קרסי ההחזקה שעל לוחית הסמרטוט יהיו מיושרים כראוי לעומת מסילות ההחזקה בצדו התחתון של Robot Cleaner.

טיפ

- כדי למנוע ריחות, שטוף חומרים זרים או אבק מהסמרטוט בסיום הניקוי.
- כדי למנוע כתמי רצפה, אין להשתמש בסמרטוט האולטרא מיקרופייבר לניקוי כאשר הלכלוך מעורבב עם נוזלים, כגון קפה או דיו.
- כדי למנוע נזק לשטיחים ממשטח הוולקרו או מהעברת לכלוך מהסמרטוט, הימנע מניקוי השטיח כאשר לוחית הסמרטוט או הסמרטוט מחוברים.
- שמור על סמרטוט האולטרא מיקרופייבר יבש. אל תשתמש בו במשטחים רטובים. לחות עלולה להפריע בניווט.
- התכונה 'אבחון חכם' אינה זמינה כאשר לוחית הסמרטוט מחוברת.

פונקציית חיפוש מיקום

Robot Cleaner זוכר את המיקום בעת הניקוי.
אם המשתמש יזיז את Robot Cleaner במהלך הפעולה, המכשיר יחפש את המיקום שממנו הוזז באמצעות פונקציית הניווט לחיפוש מיקום, לפני שימשיך בניקוי.

※ פונקציית הניווט תופעל לאחר ש-Robot Cleaner יזהה כראוי את סביבת הניקוי.

שינוי מיקום

כאשר הפונקציה לחיפוש המיקום מופעלת, מצב הניקוי במחוון המצב יהבהב

שינוי מיקום ידני.

1. הצב את Robot Cleaner בסמוך למיקום המקורי שממנו הוזז.
※ חיפוש המיקום יעיל יותר כאשר Robot Cleaner קרוב יותר למיקום שממנו הוזז.
※ אם הוא הוזז למרחק של יותר ממטר אחד ממיקום הניקוי המקורי שלו, Robot Cleaner יתקשה לחפש את מיקומו הקודם.

2. לחץ על הלחצן START/STOP ב-Robot Cleaner או הלחצן START בשלט הרחוק.
Robot Cleaner יפעיל אז את פונקציית חיפוש המיקום, בשילוב עם הדרכה קולית.
※ לאחר סיום מוצלח של חיפוש המיקום, המכשיר ימשיך מהמיקום שממנו הוזז.
אם חיפוש המיקום נכשל, המכשיר יתחיל שוב מההתחלה.

טיפ
- כאשר המכשיר מכובה לאחר הגדרת הפונקציה של חיפוש המיקום, פונקציית חיפוש המיקום תבוטל.
- חיפוש המיקום יעיל יותר כאשר Robot Cleaner קרוב יותר למיקום שממנו הוזז.

אבחון חכם

Robot Cleaner משתמש בתכונה זו של 'אבחון חכם' לביצוע אבחון עצמי.
אם האבחון יזהה חריגה, פנה למוקד השירות של LG Electronics.

※ במהלך האבחון החכם, Robot Cleaner ינוע בתוך רדיוס של כ50- ס"מ. לפיכך, ודא כי שום עצמים אינם חוסמים את הדרך ברדיוס של מטר אחד מסביב לתחנת הבית, לפני הפעלת האבחון החכם.

1. הפעל את מתג ההפעלה הראשי בצד האחורי לאחר שתוודא כי Robot Cleaner מחובר לתחנת הבית.

※ האבחון החכם אפשרי רק כאשר Robot Cleaner מחובר לתחנת הבית.

2. לחץ על הלחצן Diagnosis בשלט הרחוק, והתהליך יתחיל, עם ההודעה הקולית:
"Starting HOM-BOT smart diagnosis. Please step away and remove any items within 1 meter, or about 3 feet."

※ אם לוחית הסמרטוט מחוברת, התהליך לא יופעל.

3. לאחר סיום מוצלח של האבחון החכם, Robot Cleaner יחזור לתחנת הבית, ויודיע על התוצאה באמצעות הודעה קולית. לאחר ההודעה הקולית, לחיצה על הלחצן HOME בשלט הרחוק או ביחידה הראשית יאפשר חזרה על ההודעה הקולית. כדי להפסיק את תהליך האבחון, לחץ על הלחצן Stop/OK בשלט הרחוק או ביחידה הראשית.

※ לאחר ההודעה הקולית לגבי האבחון החכם, Robot Cleaner יתחיל בטעינה כעבור דקה אחת.

※ במקרה של זיהוי שגיאה בחיישן כלשהו במהלך 'אבחון חכם', תישמע הודעה קולית, והיחידה לא תחזור לתחנת הבית.

טיפ

- הקפד שלא לגעת ב-Robot Cleaner ולא להפריע לפעולתו לפני סיום האבחון החכם. אם הפעולה הופסקה בטעות, כבה את מתג ההפעלה הראשי והפעל אותו שוב, כדי להמשיך באבחון.
- האבחון החכם לא יופעל במקרים הבאים. בכל אחד מהמקרים, בדוק את הבעיה ונסה שוב.
  - Robot Cleaner מנותק מתחנת הבית
  - הסוללה חלשה מדי
  - מסנן מכל האבק אינו מורכב.
  - לוחית הסמרטוט מחוברת

אבחון חכם

אם תישמע הודעה קולית לאחר האבחון החכם, עיין בטבלה הבאה כדי לברר את הפעולות המתאימות.

הודעה קולית	צעדים (לעיון)
Starting HOM-BOT smart diagnosis. Please step away and remove any items within 1 meter, or about 3 feet.	פנה את כל העצמים ברדיוס של מטר אחד מסביב לתחנת הבית, והתרחק עד לסיום האבחון.
HOM-BOT needs to be charging in order to activate smart diagnosis. Please dock the HOM-BOT to the home station.	העבר את Robot Cleaner לתחנת הבית כדי לטעון אותו.
Starting HOM-BOT smart diagnosis. Reservation has been cancelled for smart diagnosis. Please step away and remove any items within 1 meter, or about 3 feet.	פנה את כל העצמים ברדיוס של מטר אחד מסביב לתחנת הבית והתרחק עד לסיום האבחון.
No defect found during diagnosis.	לא נמצאה תקלה במהלך האבחון.
Unable to initiate smart diagnosis due to a low battery. Please try again after battery is charged.	נסה לבצע שוב את האבחון החכם לאחר טעינת הסוללה.
Please check that the dust bin and filter are properly installed.	פתח את כיסוי מכל האבק ובדוק את המכל.
HOM-BOT will not charge due to infrared sensor error. Please try smart diagnosis again after turning the main power switch on the back of the HOM-BOT 'Off' then 'On' again. If the problem continues, please contact LG Electronics customer care.	הפעל שוב את האבחון החכם, ואם אותה ההודעה מושמעת, פנה למוקד שירות של Brimag Service.
HOM-BOT will not charge due to ultrasonic sensor error.	הפעל שוב את האבחון החכם, ואם אותה ההודעה מושמעת, פנה למוקד שירות של Brimag Service.
HOM-BOT will not charge due to a problem with the cliff sensors on bottom. Please wipe the sensors clean.	נקה את שלושת חיישני הקרקע בחלקה התחתון-קדמי של היחידה.
Please clean the camera sensor on bottom right side.	נקה את עדשת חיישן המצלמה בצדה התחתון-ימני של היחידה.
Please clean the obstacle detecting sensor windows on the left and right side of the HOM-BOT.	נקה את העדשה של חיישני המכשולים בצדדים השמאלי והימני.
A problem has been found on the Gyro Sensor. Please try smart diagnosis again after turning the main power switch on the back of the HOM-BOT 'Off' then 'On' again. If the problem continues, please contact LG Electronics customer care.	הפעל שוב את האבחון החכם, ואם אותה ההודעה מושמעת, פנה למוקד שירות של Brimag Service.
Please check for foreign material on the left wheel.	בדוק אם יש חומרים זרים על הגלגל השמאלי.
Please check for foreign material on the right wheel.	בדוק אם יש חומרים זרים על הגלגל הימני.
A problem has been found on the left wheel sensor. Please try smart diagnosis again after turning the main power switch on the back of the HOM-BOT 'Off' then 'On' again. If the problem continues, please contact LG Electronics customer care.	הפעל שוב את האבחון החכם, ואם אותה ההודעה מושמעת, פנה למוקד שירות של Brimag Service.
A problem has been found on the right wheel sensor. Please try smart diagnosis again after turning the main power switch on the back of the HOM-BOT 'Off' then 'On' again. If the problem continues, please contact LG Electronics customer care.	הפעל שוב את האבחון החכם, ואם אותה ההודעה מושמעת, פנה למוקד שירות של Brimag Service.
A problem has been found with the brush. Please check for any foreign material.	בדוק אם נתקעו במברשת חומרים זרים.
A problem has been found in the suction motor. Please try smart diagnosis again after turning the main power switch on the back of the HOM-BOT 'Off' then 'On' again. If the problem continues, please contact LG Electronics customer care.	הפעל שוב את האבחון החכם, ואם אותה ההודעה מושמעת, פנה למוקד שירות של Brimag Service.
A problem has been found in the acceleration sensor. Please try smart diagnosis again after turning the main power switch on the back of the HOM-BOT 'Off' then 'On' again. If the problem continues, please contact LG Electronics customer care.	הפעל שוב את האבחון החכם, ואם אותה ההודעה מושמעת, פנה למוקד שירות של Brimag Service.
In order to listen to the smart diagnosis result again, please press the charging button. To stop, please press the stop button.	אם ברצונך לחזור על תוצאת האבחון, לחץ על הלחצן Home או על הלחצן Stop/OK כדי לסיים את האבחון.
Smart diagnosis mode will be turned off.	האבחון החכם יכובה.
Smart Diagnosis mode will not operate with the mop plate attached. Please try again after removing it.	הפעל שוב את האבחון החכם לאחר ניתוק לוחית הסמרטוט.
Smart diagnosis has failed to complete its diagnostics. Please try again after turning the main power switch on the back of the HOM-BOT 'Off' then 'On' again.	כבה את מתג ההפעלה הראשי והפעל אותו שוב כדי להמשיך באבחון. אל תיגע ברובוט ואל תפריע לפעולתו עד לסיום האבחון.
Please check if the charging terminal is damaged or dirty.	נקה את חלקו התחתון של המכשיר ואת מסוף הטעינה בתחנת הבית.

ניקוי מכל האבק

אם מכל האבק מלא, תיתכן פגיעה בעצמת השאיבה. נקה את מכל האבק לפני ואחרי כל הפעלת ניקוי.
נקה את מכל האבק בסדר הבא:

1. פתח את כיסוי מכל האבק על-ידי לחיצה על הלחצן PUSH ב-Robot Cleaner.

2. אחוז בידית מכל האבק, ומשוך כלפי מעלה.

3. משוך את הקרס שמשמאל לכיסוי המסנן בצדו האחורי של מכל האבק, כדי להפריד את המסנן והספוג.
※ שים לב כי הפרדת המסנן עלולה לגרום לשפיכת אבק.
※ עיין בעמ' 30 בעת ניקוי מסנן מכל האבק.

4. הרם את הכיסוי כלפי מעלה תוך לחיצה על לחצן ההפרדה של מכל האבק.

5. רוקן את מכל האבק ונקה אותו באמצעות מברשת ניקוי או תחת מים זורמים.

6. לאחר ניקוי באמצעות מים, יבש לחלוטין את מכל האבק באזור מאוורר היטב, המוגן מאור שמש ישיר.

7. בעת הרכבה או חיבור מחדש של מכל האבק המנוקה, סגור את הכיסוי והכנס את מסנן ה-HEPA והספוג.
※ עיין בעמ' 30 להדרכת הרכבה מפורטת.

8. הכנס את מכל האבק ל-Robot Cleaner, וסגור את כיסוי מכל האבק.

טיפ

- הפעלת היחידה כאשר המסננים אינם מחוברים למכל האבק עלולה לגרום לתקלות במנוע שאינן מכוסות במסגרת האחריות.
- לאחר ניקוי מכל האבק, הקפד להרכיב את המסנן ולחבר אותו למכל האבק. אם תתחיל בפעולת ניקוי כאשר המסננים אינם מחוברים למכל האבק או כשכיסוי מכל האבק אינו מורכב, תישמע ההודעה הקולית: "Please check that the dust bin and filter are properly installed."
- תמיד ודא כי כיסוי מכל האבק מורכב כראוי לאחר ניקוי מכל האבק, כך שייסגר בקלות ובמדויק.

ניקוי מסנן מכל האבק

מסנן מכל האבק כולל מסנן HEPA ומסנן ספוג.
נקה את מסנני ה-HEPA והספוג בסדר הבא.

1. משוך את הקרס שמשמאל למודול מסנן ה-HEPA בצדו האחורי של מכל האבק, כדי להפריד את מסנן ה-HEPA והספוג.

2. נקה היטב את מסנן ה-HEPA מחלקיקי האבק הקטנים באמצעות שואב אבק או מברשת ניקוי.
   ※ אל תשטוף את מסנן ה-HEPA במים.
   כוח השאיבה ייחלש.

3. השתמש במברשת ניקוי לניקוי מסנן הספוג.
   אם אתה משתמש במים לניקוי המסנן, המתן עד שיתייבש לחלוטין בצל לפני הרכבתו מחדש.

4. הרכב את מסנני ה-HEPA והספוג בחזרה בכיסוי המסנן, בסדר הבא.

※ חבר את התוחם המלבני של מסנן ה-HEPA לחריץ המלבני בגוף המסנן.

※ הקפד שלא להרכיב באופן שגוי את מסנן ה-HEPA והספוג בכיסוי המסנן.

טיפ

- כדי לשמור על ביצועי Robot Cleaner, נקה את מסנן ה-HEPA פעם אחת בשבוע לפחות, באמצעות מברשת או שואב אבק.
- אם תפעיל את Robot Cleaner כאשר כיסוי המסנן מורכב במכל האבק וללא מסננים, תיתכן חדירה פנימית של אבק שתגרום לתקלות.

ניקוי המברשת

המברשת המסתובבת, הנמצאת בצדו התחתון של Cleaner Robot, עוזרת באיסוף האבק. נקה את המברשת בסדר הבא.

※ לפני הפיכת היחידה הראשית, הנח מטלית לחה על-גבי הרצפה, והוצא את מכל האבק.
אם לא, היחידה הראשית עלולה להישרט, ואבק יישפך ממכל האבק.

1 כבה את מתג ההפעלה הראשי לפני שתתחיל בניקוי.
הנח את Robot Cleaner הפוך על-גבי מטלית רכה.

2 לאחר חיפוש חומרים זרים, לחץ את קרס ההחזקה כלפי מטה, ומשוך אותו כלפי מעלה כדי להפריד את כיסוי המברשת.

3 באמצעות כלי ניקוי, נקה שערות ופסולת וחומרים זרים אחרים מהמברשת ומשני הגלגלים הקטנים.

4 דחוף את המברשת עד הסוף לתוך הבליטה הצהובה.

5 בעת דחיפת המברשת, הרם את חלק הבליטה הלבנה כדי להפריד אותו מהיחידה הראשית.

6 נקה בזהירות את המברשת באמצעות שואב אבק או מספריים.

7 הכנס את קרס ההחזקה (צורה מרובעת) בצד המברשת לתוך החריצים, כאשר הצבעים תואמים.

8 תוך כדי לחיצת המברשת בכיוון החץ, הכנס את קרס ההחזקה (צורה מרובעת) שבצד הנגדי לתוך החריץ.

9 לחץ כלפי מטה וסגור את הכיסוי עד שיישמע צליל סגירה משני צדי קרס ההחזקה.
※ הקפד שלא ללכוד את סיבי המברשת הצדית מתחת לכיסוי בעת סגירתו.

ניקוי חיישן/מסוף הטעינה

Robot Cleaner כולל חיישנים המאתרים מכשולים, מדרגות ואת תחנת הבית לטעינת הסוללה. כדי לשמור על ביצועי Robot Cleaner, נקה באופן שוטף את החיישנים ואת מסוף הטעינה באופן הבא:

1. הפעל את מתג ההפעלה בחלקו התחתון של Robot Cleaner.
   הפעלת Robot Cleaner עלולה לגרום לפציעה אם אספקת המתח הראשית אינה כבויה.

2. הנח מטלית חלקה על הרצפה, הפוך את Robot Cleaner, והנח אותו על המטלית.

※ הקפד להסיר את מכל האבק לפני סיבוב הגוף הראשי. אחרת, האבק שבמכל האבק עלול להישפך.

3. השתמש במטלית חלקה או מברשת ניקוי לניגוב האבק מחיישני הקרקע, חיישני המצלמה וחיישני האולטראסאונד וכן ממסוף הטעינה כמתואר להלן.

טיפ

- אל תנקה את Robot Cleaner על-ידי ריסוס ישיר במים, חומר מדלל, בנזן או כל נוזל אחר.
- התקשר למוקד השירות במקרה של נזק לחיישן או למסוף הטעינה. נזק לחיישן ולמסוף הטעינה עלול לגרום לתקלות במוצר.
- כדי לנקות את החיישן/מסוף הטעינה, השתמש במברשת הניקוי.

ניקוי המברשת הצדית

עצמים/חומרים זרים כגון שערות עלולים להיצמד בקלות למברשת הצדית.
יש לסלק חומרים כאלה פעם בשבוע לפחות.

במקרה של כמויות חריגות של חומרים זרים הנתקעים במברשת,
קיים סיכון לנזק למברשות.

אם הרצפה מחוספסת או שהקירות מנוקים בתדירות גבוהה, המברשת הצדית עשויה להתכופף או להינזק.
במקרה כזה, השתמש בשיטה הבאה ליישור המברשת הצדית.

1. ההליך הבא עוזר בשחזור מברשות שצורתן עוותה.

2. כבה את המכשיר על-ידי כיבוי מתג אספקת המתח הראשית בצדה האחורי של היחידה.

3. הנח את Robot Cleaner בקצה שולחן כלשהו כדי על ניקוי המברשת הצדית.
ודא כי Robot Cleaner אינו בסכנת נפילה.

4. הרטב את המברשת הצדית במים חמימים.

5. לחץ את המברשת הצדית כלפי מטה למשך כעשר שניות, כדי שתיטבל לחלוטין במים.

6. נגב באיטיות את המברשת הצדית, על-ידי החלקתה כנגד כף ידך.

7. סובב את המברשת הצדית, וחזור על שלבים 4-6 עבור כל מקטע במברשת.

8. השתמש במברשת הצדית רק לאחר שהתייבשה לחלוטין.

טיפול במברשת הצדית

1. הסר את הברגים באמצעות מברג, והפרד את המברשת הצדית מהיחידה הראשית.
2. הסר שיער כלשהו לאחר ההפרדה.
3. הרכב את המברשת הצדית על-ידי חיבורה לחלקו התחתון של Robot Cleaner, כאשר הסימונים R ו-L על-גבי המברשת תואמים למקביליהם על-גבי Robot Cleaner.

ניקוי סמרטוט אולטרא מיקרופייבר (אופציונלי)

כדי למנוע ריחות לא נעימים, יש לשטוף לכלוך ואבק מהסמרטוט לאחר השימוש בו לצורך ניקוי.
בצע הנחיות אלה לשטיפת סמרטוט האולטרא מיקרופייבר:

1. הפרד את סמרטוט האולטרא מייקרופייבר מלוחית הסמרטוט.

2. נקה בזהירות באמצעות מים חמימים.

3. השתמש בסמרטוט לאחר שהתייבש לחלוטין באור שמש ישיר.

※ אם הסמרטוט נמצא בשימוש כאשר הינו לח או רטוב,
ייתכנו תקלות ב-Robot Cleaner.

טיפ

- כדי למנוע תקלות במוצר, יש להשתמש אך ורק בסמרטוט האולטרא מיקרופייבר המסופק עם Robot Cleaner.
- ניתן לרכוש סמרטוטי מיקרופייבר נוספים במוקד השירות הקרוב של Brimag Service.

בהישמע ההודעה הקולית:
"The wheels are not touching the floor. Please move HOM-BOT onto flat floor."

הודעת אזהרה תינתן במקרה שבו גלגל מסוים אינו נוגע במשטח הרצפה מסיבה כלשהי.

• האם הגלגל לכוד בדלת הקדמית, במרפסת, במדרגות וכדומה?
◀ הזז את Robot Cleaner אל הרצפה השטוחה.

בהישמע ההודעה הקולית:
"Please remove any foreign material on the left/right wheel."

• האם חומר זר כלשהו מלופף מסביב לגלגל?
◀ הנח מטלית חלקה על הרצפה, הפוך את Robot Cleaner, והנח אותו על המטלית.
הסר חומרים זרים לאחר בדיקת הגלגל.

※ הקפד להסיר את מכל האבק לפני הפיכת הגוף הראשי.
אחרת, האבק שבמכל האבק עלול להישפך.

בהישמע ההודעה הקולית:
"HOM-BOT cannot continue cleaning. Please check the area around it."

תינתן הודעת אזהרה אם ל-Robot Cleaner אין אפשרות להמשיך בפעולת הניקוי עקב תנאים מפריעים כלשהם.

• האם Robot Cleaner תקוע?
◀ לאחר חילוץ החלק התקוע, הנח את Robot Cleaner על רצפה שטוחה.

בהישמע ההודעה הקולית:
"Please check that the dust bin and filter are properly installed."

תינתן הודעת אזהרה אם מכל האבק או כיסוי המסנן אינן מורכבים.

• האם מכל האבק מחובר ל-Robot Cleaner?
◀ פתח את כיסוי מכל האבק וודא כי מכל האבק מורכב במקומו.
◀ אל תשאיר את כיסוי מכל האבק פתוח.

• ודא כי כיסוי המסנן מחובר למכל האבק.

בהישמע ההודעה הקולית:
"Battery is low. Please move HOM-BOT onto the home station to charge."

כאשר אנרגיית הסוללה הנותרת כמעט ריקה, תישמע ההודעה הקולית "Battery is low".

• טען את סוללת Robot Cleaner על-ידי העברתו אל תחנת הבית.
◀ כאשר Robot Cleaner מחובר לתחנת העגינה כראוי, הטעינה תתחיל, ומנגינת הטעינה תושמע.

פתרון בעיות

בהישמע ההודעה הקולית:
"Please remove any foreign material from the brush on the bottom of the HOM-BOT."

הודעת אזהרה תינתן במקרה שבו חומרים זרים מגבילים את סיבוב המברשת.

הנח מטלית רכה על-גבי הרצפה, והנח את Robot Cleaner עליה במצב הפוך.
※ לפני הפיכת היחידה הראשית, הסר את מכל האבק.
אחרת, מכל יישפך ממכל האבק.

• המברשת משמיעה רעש חזק וחריג.
◀ ודא כי המברשת מורכבת כראוי על-ידי בדיקת מסילת ההפרדה של המברשת
◀ נתק את המברשת מ-Robot Cleaner, וסלק מהמברשת כל חומר זר.

• המברשת או המברשת הצדית תקועה.
◀ סלק חומרים זרים כלשהם כגון כבלים, חוטים או שיער שנלכדו במברשת הצדית או במברשת.

※ לתיאור מפורט יותר של תהליך זה, עיין בהוראות שבעמודים 31 ו33-.

לפני פנייה לקבלת שירות

ודא לפני הדיווח על תקלה ב-Robot Cleaner.

בעיה	פתרונות (עמוד להפניה)
לא ניתן להפעיל את אספקת המתח.	ודא כי מתג החשמל נמצא במצב פועל. (עמוד 15)
אספקת המתח נכבית באופן אוטומטי.	לא מדובר בתקלה. ל-Robot Cleaner פונקציה משלו לחיסכון בחשמל. אם המכשיר אינו נמצא בשימוש למשך עשר דקות ממועד ההפעלה של אספקת המתח, הוא ייכבה באופן אוטומטי. (עמוד 17)
Robot Cleaner לא נטען.	◀ ודא כי מתג החשמל נמצא במצב פועל. ◀ סלק עצמים הנמצאים מסביב לתחנת הבית. (עמוד 15) ◀ ודא כי אספקת המתח מחוברת לתחנת הבית. (עמוד 14) ◀ נגב את מסוף הטעינה באמצעות מטלית יבשה.
כוח השאיבה נחלש.	◀ בדוק אם חומרים זרים חוסמים את פתח השאיבה. (עמוד 31) ◀ רוקן את מכל האבק. (עמוד 29) ◀ נקה את מסנן מכל האבק. (עמוד 30)
רעש המכשיר מתגבר.	◀ ודא כי מכל האבק מורכב כראוי. ◀ ודא כי מסנן מכל האבק מורכב כראוי. (עמוד 30) ◀ בדוק אם חומרים זרים נלכדו במברשת. (עמוד 31)
לא ניתן להפעיל את Robot Cleaner.	◀ ודא כי מתג החשמל נמצא במצב פועל. (עמוד 15) ◀ ודא כי הסוללה טעונה. (עמוד 18)
המברשת לא מסתובבת.	◀ נקה את המברשת. (עמוד 31) ◀ ודא כי המברשת מורכבת כראוי. (עמוד 31)
התנועות או נתיב הנסיעה אינם רגילים.	◀ נקה בזהירות את החיישן באמצעות מטלית רכה. (עמוד 32) ◀ אם סמרטוט האולטרא מיקרופייבר מחובר, ודא כי הוא מורכב כראוי. (עמוד 25) ◀ כבה את מתג ההפעלה, והפעל אותו שוב.
לא ניתן להפעיל את Robot Cleaner באמצעות השלט הרחוק.	◀ החלף את סוללות השלט הרחוק. (עמוד 12) ◀ ודא כי השלט הרחוק נמצא באזור הכיסוי של היחידה הראשית, שהינו פחות מ3- מטרים (עמוד 12) ◀ ודא כי מתג החשמל נמצא במצב פועל. (עמוד 15)

מפרטי מוצר

פריט/דגם	LG Robot Cleaner VR6260 Ser. / VR6270 Ser
ממדים חיצוניים	89 × 340 × 340 מ"מ
משקל	3 ק"ג
צריכת חשמל	18 ואט
סוללה (טעינה מלאה)	DC 16.8 V
מהירות נסיעה	350 מ"מ/ש' (מרבית)
זמן שימוש	כ100- דקות (בהתבסס על רצפת עץ כללית)
זמן טעינה	3 שעות
פונקציות ראשיות	מצב טורבו מצב למידה חישת מכשולים פונקציה למניעת נפילה ניקוי מתוזמן תצוגת שגיאות ניווט טעינה אוטומטית/ידנית סמרטוט יבש (ניקוי) ניקוי פינות הודעות קוליות שרטוט מפה ניקוי נקודתי ניקוי חוזר ניקוי My Space ניקוי Cell by Cell ניקוי זיגזג

פריט/דגם	תחנת בית (VR621)
ממדים חיצוניים	128 × 181 × 236 מ"מ
דירוג	230 V~ 50 Hz
מתח/זרם פלט	DC 17.1 V / 1.1 A
צריכת חשמל	23 ואט

פריט/דגם	סוללה
סוג	סוללה פולימרית ליתיום-יון
דירוג	DC 14.8 V / 1900 mAh

הודעה של תוכנת מקור פתוח

כדי לקבל את קוד המקור הכלול במוצר זה במסגרת GPL, LGPL, MPL ורישיונות מקור פתוח אחרים, בקר באתר http://opensource.lge.com.
בנוסף לקוד המקור, כל תנאי הרישוי, מיאוני האחריות והודעות זכויות היוצרים המאוזכרים הינם זמינים להורדה.

הרכבת/פירוק הסוללה

כבה את מתג ההפעלה הראשי בצדו האחורי-שמאלי של Robot Cleaner.

הנח מטלית רכה על-גבי הרצפה, נתק את מכל האבק, והפוך את Robot Cleaner.

הסר את הבורג באמצעות מברג.

נתק את הסוללה מהמכשיר.

הפרד את החוט מהסוללה תוך לחיצה על קרס החיבור.

הרכב את הסוללה בסדר הפוך.

⚠ אזהרה

אנא היזהר מאש, מפיצוץ, מהתחשמלות או מקריסה.

- אל תטען מארז סוללות זה (שייקרא בהמשך 'מארז') עם מטען מכל סוג שונה מזה שסופק עם המארז.
- אל תגרום נזק למארז, למשל ע"י נפילה, התרסקות, ניקוב, חיתוך או מגעים חיצוניים קצרים.
- אל תנסה לפרק את המארז, בכל מקרה. במידה והמארז ניזוק או שאינו מתפקד כראוי, הבא אותו למרכז השירות.
- אל תמקם מארז זה ליד מקור חום, ואל תשליך אותו לאש או למים.
- אנא שמור את המארז הרחק מסביבה לחה או רטובה, כשהוא טעון.
- אנא הרחק מילדים, מפעוטות ומחיות-מחמד.

השלכת סוללות/מצברים לאשפה

1. כאשר סמל זה של פח אשפה מסומן ב-X מצורף לסוללות/מצברים של המוצר, פירוש הדבר הוא שהם מכוסים בהנחיית האיחוד האירופי CE/66/2006.
2. סמל זה עשוי להופיע לצד סימונים כימיים עבור כספית (Hg), קדמיום (Cd) או עופרת (Pb) אם הסוללה מכילה יותר מ0.0005%- כספית, 0.002% קדמיום או 0.004% עופרת.
3. יש להשליך את כל הסוללות/המצברים בנפרד מהפסולת העירונית הרגילה באמצעות מתקני האיסוף המיועדים לכך, שהוקצו על-ידי הממשלה או הרשויות המקומיות.
4. השלכה נכונה של סוללות/מצברים ישנים תעזור במניעת השפעה שלילית על בריאות הסביבה, בעלי-החיים ובני האדם.
5. למידע מפורט יותר בנוגע להשלכת הסוללות/המצברים הישנים, פנה למשרד העירוני, לשירות סילוק הפסולת המקומי או לחנות שבה רכשת את המוצר.

השלכת מכשירים ישנים

1. כאשר סמל זה של פח אשפה המסומן באיקס מצורף למוצר, פירוש הדבר הוא שהמוצר מכוסה בהנחיית האיחוד האירופי EC/96/2002.
2. יש להשליך כל מוצר חשמלי ואלקטרוני בנפרד מהפסולת העירונית הרגילה באמצעות מתקני האיסוף המיועדים לכך, שהוקצו על-ידי הממשלה או הרשויות המקומיות.
3. השלכה נכונה של מכשירים ישנים תעזור במניעת השפעה שלילית על בריאות הסביבה ובני האדם.
4. למידע מפורט יותר בנוגע להשלכת המכשירים הישנים, פנה למשרד העירוני, לשירות סילוק הפסולת המקומי או לחנות שבה רכשת את המוצר.

יש לבדוק מדי פעם את תקינותו של כבל החשמל.
אין להשתמש במכשיר במקרה שכבל החשמל ניזוק.
תיקון או החלפה של כבל החשמל יבוצעו אך ורק במעבדת שירות מוסמכת.
ראו רשימת מעבדות שירות בתעודת האחריות.

הערות