Model	VH920*DS		
Language	English+Chinese		
Page	26	Color(cover/body)	4/2
Material	Weight 100g	Size(W*H)	150 x 220(mm)
Date	2013.08.07	Designer	Dufeng
Part No.	MFL67888201	Description	Owner's manual

Chage Record

No.	Change content	ECO No.	Date	Designer	Confirm
1					
2					
3					
4					
5					
6					
7					
8					
9					

LG
Life's Good

使用说明书

床褥专用吸尘器

强力拍打

VH920*DS

中文 ⟶ 1-13页
English ⟶ Page 14-25

售后服务电话

LG 电子
400-819-9999
售后热线 一号通

使用前请仔细阅读说明书，阅读完后请妥善保管以备需要时查阅。

MFL67888201

目 录

产品规格 2
使用前注意事项 3–4
吸尘器的部件名称 5
吸尘器的使用说明 6
吸尘器的使用方法 7
吸尘器进气口的清理 8
拆卸方法
清洁方法
安装方法
集尘盒的倾倒/清洁方法 9
过滤器的拆分/清洁 10
拆卸方法
清洁方法
安装方法
故障通告前确认的事项 11-12
装箱单 13

产品规格

型号: VH920*DS
额定电压: 220V~ 50Hz
额定功率: 280W
净重: 1.7Kg(吸尘器), 0.7Kg(吸尘器存放底座)
电源线长度: 5m(吸尘器)
外形尺寸: 200mmX417mmX267mm(吸尘器)
265mmX300mmX214mm(吸尘器存放底座)
本产品执行标准: GB4706.1-2005
GB4706.7-2004
GB17625.1-2012
GB4343.1-2009

※ 为了提高产品质量而进行的外观及设计规格上的变更将不再另行通知。

使用前注意事项

忽视说明而导致的错误操作将会对您造成不同程度的损害，请认真阅读以下提示说明。

危险 此标识表明违反标记事项时，会立刻导致严重伤害甚至发生死亡事故。

警告 此标识表明违反标记事项时，有可能导致严重伤害甚至发生死亡事故。

注意 此标识表明违反此标记事项时，有可能导致财产损失或轻微伤害。

危险

请不要在易燃液体附近使用吸尘器，以免发生火灾。

插拔电源插头时，请先关闭电源开关，以免发生火灾或触电的危险。请不要用潮湿的手触摸电源插头，以防触电。(不要在220V以外的电源上使用产品)

警告

请不要吸入头发团、大纸团等物品，如有堵塞现象，请及时清理。

为避免发生火灾或触电的危险，在清扫时，注意不要让机体吸入液体、刀片、火种以及水泥、石膏粉等小微粒。

15A以上的电流请单独使用插线板，在一个插线板上同时使用多种电器可能会引发火灾。建议不要使用电源线延长线，以免引起不必要的危险。

长时间不使用电器时，请记住拔掉电源插头；正处于通电时，请您不要离开。

警告

请不要让电源线与吸尘器接近电暖器等热源，以免使机体变形或发生火灾。请您不要使用破损的电源和插头，如有破损，必须由指定维修站更换。

请不要在进气口或排气口堵塞时，继续长时间运行，否则可能造成机体变形或损坏。

请不要让儿童把吸尘器及附件当做玩具，以防意外。

使用过程中，机体有产生静电的可能，请您使用时注意。

请不要在地板或桌子等坚硬物体的表面使用吸尘器

注意

非专业维修人员请勿开机修理。

集尘盒集满时，请您正确开启集尘盒清理。请您注意不要在没安装集尘盒或过滤器时使用吸尘器。

注意不要使电源线夹在门缝里或用电源线提拉吸尘器，防止电源线受损。

请您注意保护自身安全，使身体各部位远离吸尘器吸口或活动部位。

吸尘器的部件名称

部件名称

使用说明

请按图示使用

1 将电源线插头插入电源插座。
- 当插头插入插座时，将发出“嘀”的声音。

2 开始清扫工作时，必须按触碰电源开关才能够启动。
- 当按下触碰电源开关时，发出“嘀”的声音，指示灯亮同时吸尘器开始工作。

3 关闭吸尘器
- 当再次按下触碰电源开关时，发出“嘀”的声音，指示灯熄灭同时吸尘器停止工作。

4 使用吸尘器存放底座
- 要使用吸尘器存放底座时，必须将吸尘器本体的电源线插头插入电源插座内。
- 当您将吸尘器主体放入吸尘器存放底座后，吸尘器存放底座蓝色指示灯会点亮，与此同时紫外线灯开始进行紫外线照射的工作。
- 当吸尘器主体放入吸尘器存放底座五分钟左右时，吸尘器存放底座蓝色指示灯和紫外线灯会同时自动关闭，紫外线照射的工作完成。若想重复照射，需将吸尘器提起并间隔十五秒左右后再次放入底座中。

* 如果在清扫过程中反复将吸尘器主体放置于吸尘器存放底座中，且均未超过五分钟，请在清扫完毕后，将吸尘器主体放置于吸尘器存放底座中进行五分钟紫外线照射。

5 吸尘器本体放入吸尘器存放底座方法。
- 使吸尘器存放底座的凸台嵌入吸尘器机体的拍打板槽中。

- 将吸尘器本体下方凹槽镶嵌到吸尘器存放底座上方凸起中。

- 当机体正确放置后，紫外线灯指示窗口显示出蓝光。

使用方法

请按图示使用

● 床垫,床罩

床上用品:床垫、床罩

将所要清扫的区域分成两半。
在每一半空间内来回推拉从头到尾的进行清理。

● 枕头，坐垫等等

用做枕头的物品：大靠垫,一般的坐垫,枕头

由于被清扫的物品宽度较窄，故将吸尘器放置于被清扫物品上然后采用来回推拉的方式进行清理。

● 薄被

毛毯：厚毛毯、薄毛毯
在全部清扫区域内来回推拉从头到尾的进行清理。

● 厚被

其他：沙发
正常清扫方式。

⚠ 警告：不同于一般的手持吸尘器产品，该产品不能长时间持续运转使用，按照吸入灰尘重量分类,它属于小容量且只能吸入较小的灰尘，因此切勿使用本机吸入较大的物体。

吸尘器进气口的清理

拆卸方法

在机体插头没有插入到插座的状态下，地板上放置一块软布，将吸尘器主体翻转后放在上面。检查是否有异物后，将清扫毛刷支架左右两侧凸起向上抬起进行分离，握住毛刷，将其取出。

清洁方法

1 用抹布擦拭主机进气口表面较脏的部位。

2 用清水清洗清扫毛刷支架，并在阴凉处晾干。

3 用其他吸尘器或剪刀对毛刷进行清理。

安装方法

1 将毛刷插入与其处轮廓匹配的主机固定槽中。

2 将清扫毛刷支架按照吸尘器本体形状放置后，向下按清扫毛刷支架两侧进行结合。

集尘盒的倾倒/清洁方法

集尘盒的倾倒方法

MAX ▲ ▲ ▲ 当细小的灰尘到达MAX线时，此时应该清空集尘盒内的灰尘，同时在下次使用前清理过滤器和海绵。

集尘盒的清洁方法

1 向下按集尘盒脱离按键，待集尘盒弹起后将其从机体中取出。

2 握住集尘盒两端，取出过滤器（海绵过滤器和HEPA过滤器），清空集尘盒内的灰尘。倾倒灰尘时请小心打开过滤器，防止灰尘飞溅。

3 集尘盒和过滤器分离后，用清水将集尘盒清洗干净。

4 将集尘盒放置于通风良好，避光处充分晾干后，再使用。

5 将过滤器(海绵过滤器和HEPA过滤器)插入集尘盒。

6 将集尘盒插入吸尘器主体内，向下按直到听到“咔哒”的声音。

*如果集尘盒没有完全插入机体内，会降低使用时的吸力。

⚠ 警告：使用时请将集尘盒和过滤器结合紧密后，再装入吸尘器

拆卸方法

如上图所示，将过滤器从集尘盒中分离出来后，再将海绵过滤器从 HEPA 过滤器中分离出来。

清洁方法

1 使用其他吸尘器或集尘盒上的毛刷对HEPA过滤器以及内部间隙进行清理 。

2 用清水将海绵过滤器进行清洗，放置于通风良好的避光处充分晾干后，再使用。

安装方法

按照拆分相反的顺序进行组装。

故障申告前确认的事项

故障 申告前请先确认

▶ 如果您怀疑产品发生故障，请先确认故障发生原因，再与售后服务中心或代理商联系，以确保检修的效率。

故障现象	可能的原因	解决方法
吸尘器吸力下降并发出震动的声响。	①进气口或集尘盒被较大的异物堵塞 ②集尘盒过滤器被细小的灰尘严重堵塞。	①用木棍等将堵塞物清理干净 ②清洗海绵过滤器。
吸尘器不能启动	①电源插头没有插好 ②未按照吸尘器开机操作流程进行操作 ③电源插座无电	①插好电源插头 ②按照操作流程操作 ③确认电源插座的故障或室内电源是否跳闸。
吸尘器突然停止工作。	①本产品具有电机过热保护装置，可能已经启动。 此装置启动的原因如下： -集尘盒内灰尘过满 -过滤器或者进气口被严重堵塞 -产品使用时间过长 ②使用此产品时不小心碰到了电源开关或插头 ③本产品具有长时间持续运转保护功能，可能已经启动。 此装置启动原因为吸尘器本体已经持续运转90分钟左右。	①将集尘盒、过滤器和进气口堵塞物清理干净，然后等待大概40分钟左右，此产品的电机过热保护装置会自动解除，之后可以继续正常使用。 ②再次按动开关或者插好插头并按动开关后即可。 ③按照吸尘器使用说明重新启动吸尘器。
吸尘器只振动但无吸力。	①同故障3，由于吸尘器突然停止工作造成无吸力 ②过滤器或集尘盒堵塞严重 ③进气口堵塞严重	①同故障3 ②使用前清理过滤器和集尘盒 ③使用前清除进气口堵塞物
吸尘器存放底座不能正常工作。	①电源插头没有插好 ②吸尘器主机没有按正确方法放入底座中 ③紫外线灯未能正常工作	①插好电源插头 ②按照说明书的操作提示将吸尘器主机放入底座中 ③紫外线灯的工作温度是5℃到60℃之间，请在这个温度下使用吸尘器存放底座

故障申告前确认的事项

故障现象	可能的原因	解决方法
机体内有异味	①由于机器含有橡胶部件，新购买的机器（3个月内）可能会有轻微的橡胶味道。 ②当电机正常运转时，用于固定电机的橡胶圈会因为受热而产生少量气味。 ③长时间使用吸尘器，异味可能会由集尘盒中的灰尘产生。	①不会影响健康，可放心使用。 ②不会影响吸尘器正常运行或者造成损坏，可放心使用。 ③及时清理集尘盒并且用清水洗净晾干后再次使用。
机体排出的气体过热	①机体排出的热气是由气流在冷却电机时受热导致的。	①正常现象，可放心使用。
机体内有噪音	①部分噪音可能来自吸尘器的进气口，这是由于高功率电机叶轮的高速旋转引起的。另外可能来自于吸尘器前端的拍打板，这是由于拍打功能而引起的。 ②集尘盒没有完全组装到机体上。	①正常现象，可放心使用。 ②将集尘盒按照说明书提示安装到位。

装箱单

吸尘器	一个
吸尘器存放底座	一个
说明书	一本
保修卡	一份

Table of contents

Product specifications 14
Attention before using the appliance 15-16
The cleaner parts description 17
Product using instructions 18
Using the product 19
How to Wash Inlet 20
Disassembling
Cleaning
Assembling
How to empty, clean and assemble the dust tank 21
How to Separate/Clean Dust Filter 22
Disassembling
Cleaning
Assembling
Check before reporting the trouble 23-24
Packing List 25

Product specifications

Model: VH920*DS
Voltage rating: 220V~ 50Hz
IEC: 280W
Net weight: 1.7Kg(Vacuum cleaner), 0.7Kg(Station)
Power cord length: 5m(Vacuum cleaner),
Dimension: 200mm×417mm×267mm(Vacuum cleaner)
265mm×300mm×214mm(Station)
This appliance complies with the following
GB directives: GB4706.1-2005
GB4706.7-2004
GB17625.1-2012
GB4343.1-2009

※ You will not be informed if any changes appearance and standard deriving improvement of product quality.

Attention before using the appliance

Attention before using the appliance

Please read all the following information, which contains important instructions for the safety, the use of the appliance.

DANGER May immediately cause serious injury or death.

WARNING May possibly cause serious injury or death.

ATTENTION May possibly cause losses of property or light injury.

DANGER

Do not pick up anything that is burning or smoking, such as cigarettes, matches or hot ashes.

Please turn off the power before pulling out the plug to prevent fire or electric shock. Never handle plug or appliance with wet hands. (Do not use the appliance on the power above 220V.)

WARNING

Do not vacuum the objects like hair ball or big paper ball, please clean it in time when it block.

To avoid the danger of fire or electric shock, do not vacuum liquid, blade, flammable substances, or small particles like cement and gesso in cleaning.

Independently use a socket when the current is ≥15A. It may cause fire when many electric appliances share one socket. In order to avoid the needless danger, you had better not use the prolonged thread of power cord.

Unplug cleaner when not in use. Turn off all controls before unplugging.

Attention before using the appliance

WARNING

Do not let the power cord near the electric heater or other heat source, lest that the cleaner should be deformed or it should cause fire. Do not use the appliance when the power cord or plug is damaged.
The damaged power cord or plug must be replaced in the approved service station.

Close supervision is necessary when any appliance is used by or near children.
Do not allow vacuum cleaner to be used as a toy or to run unattended at any time.

Do not use the appliance on hard surface such as floor or desk and so on.

Do not operate the appliance for long when the inlet is blocked,which may have it deformed or damaged.

In using the appliance, pay attention to the electrostatic effect generated on the vacuum cleaner body.

ATTENTION

Do not allow the non-professional maintenance people to repair.

Do not pull or carry by cord, use cord as a handle,close door on cord or pull cord around sharp edges or corners. Do not run appliance over cord. Keep cord away from heated surfaces.

Do not use without dust tank or filters in place. Change tank frequently when picking up very fine materials such as powder.

Keep hair, loose clothing, fingers, feet and all parts of body away from the nozzle or movable portion.

The cleaner parts description

Parts Description

Product using instructions

Use it as shown in the diagram

1 Insert the power plug into the power socket.

- When the power plug is inserted into the power socket, it makes a sound with 'ddee~' sound.

2 Touch power switch must be pressed for operation.

- If touch switch is pressed vacuum cleaner is converted to operation status with a buzzer sound 'ddee~', and the Indicator lamp turns on.

3 When you want to stop the operation.

- When you press the touch switch of the power indicator part, the operation stops with the buzzer sound "ddee~", and the lamp is turned off.

4 When you use vacuum cleaner station

- Insert the power plug of the vacuum cleaner into the power socket.
- After you place the vacuum cleaner on the station, blue lamp on the indicator window is turned on, and UV lamp starts operation for the ultraviolet irradiation at the same time.
- If it passes about 5 minutes after placing the vacuum cleaner, the indicator window lamp and UV lamp are automatically turned off at the same time, and the ultraviolet irradiation is completed.

If you want to repeat ultraviolet irradiation, please lift the vacuum cleaner for about 15 seconds and place it on the station again.

* If placing and removing is repeated while it does not pass 5 minutes, When you stop the operation , please place the vacuum cleaner on the station for 5 minutes ultraviolet irradiation.

5 Put vacuum cleaner into vacuum cleaner station

- Make the boss in front of vacuum cleaner station embed in groove of vacuum cleaner vibration plate.

- Make the boss below vacuum cleaner mosaic to the bulge of vacuum cleaner station.

- When the vacuum cleaner is placed correctly, the UV lamp indicator window show blue light.

Using the product

Product specifications

Use it as shown in the diagram

- **Bed Mattress, Bed Cover**

Beddings:Mattress, Bed Cover

Divide the target space to half,and use it pushing and pulling back and forth from the end.

- **Pillows, Cushions, etc**

Pillows: Large cushion, normal cushion, pillow

The targets are narrow,so place the cleaner on it and use it by pushing and pulling back and forth.

- **Thin cover**

Blankets: Thick cover,thin cover

Use it by pulling back and forth the entire space.

- **Thick covers with fillings**

Others:Sofa

General Cleaning Type.

CAUTION

Unlike general handy type products, this product is not to be held and used, but is to place on the cleaning target and to clean the fine dust by pressing the target with the weight of the product, so do not use it to inhale big foreign objects.

How to Wash Inlet

Disassembling

Place a soft cloth on the floor,and flip over the main body on it .Check for foreign objects, separate the cleaning brush holder by releasing the two side hook. Hold the roller brush and separate it by lifting it up.

Cleaning

1 Wipe the dirty surfaces of inlet vacuum cleaner with a rag.

2 Wash the separated cleaning brush holder with water and dry it in a shade.

3 Clean the roller brush with other vacuum cleaner or scissors.

Assembling

1 Insert the fixing hooks on both sides of the roller brush matching the roller brush fixing grooves.

2 Insert the fixing guide at the front of the cleaning brush holder according to the fixing groove of the vacuum cleaner,press the doming on both sides of cleaning brush holder and fix it.

How to empty, clean and assemble the dust tank

How to empty the dust tank

If the nap and fine dust are filled up to the max line, it is the time to clean the filter, so empty the dust inside the dust bin, separate and clean the filter, before using it again.

How to clean the dust tank

1 Press dust bin release button until the dust bin jumps then take out it from the vacuum cleaner.

2 Hold both ends, open the filter (sponge filter + HEPA filter),and empty the dust.
In order to avoid dust clouds, please open the filter (sponge filter + HEPA filter) carefully when you empty the dust.

3 After separating dust bin and filter, wash dust bin cleanly with running water.

4 Dry in a shade with good ventilation for about a day, and use it again.

5 Insert Filter (Sponge filter + HEPA filter) into dust bin.

6 Insert dust bin into vacuum cleaner, and push down until it sounds “click”.
*If dust bin is not completely assembled, the inhaling may be weakened.

⚠ Caution: Use it after dust bin and filter are combined exactly.

How to Separate/Clean Dust Filter

Disassembling

After separating the filter from dust bin, separate sponge filter from HEPA Filter as in the figure.

Cleaning

1. Clean the filter by cleaning the HEPA filter and the gaps around the filter using the brush on the dust tank or other vacuum cleaner.
2. Wash Sponge Filter in a running water, and completely dry it in a shade with good ventilation for about a day before using it again.

Assembling

Assemble in the reverse order of disassembly.

Check before reporting the trouble

Please check before notifying malfunction

▶ If you doubt the product meets with malfunction, please check the cause of such malfunction before contacting with the after-sales service center or agent, so as to ensure efficiency of repair.

Malfunction	Possible Cause	Possible Solution
Inhaling gets weakened and vibrating sound is heard	①The inlet or dust bin is blocked by a big foreign object ②The filters are dirty.	①Remove the object with sticks, etc. ②Clean the filter
Cleaner does not work at all	①The power cord plug is not plugged in the socket properly. ②Wrong operation procedure of each function ③Socket no power	①Plug into the socket properly. ②Operation under the guide of Manual ③Make sure the power on of socket
Cleaner stops suddenly	①This product has inlet motor overheat prevention device, and it may stop temporarily when the following cases occur. – If it is used when dust and wastes are full in dust bin and filters. – If it is used with the inlet blocked – If the product is used excessively for a long time. ② When touch switch was operated by other touches. ③This product has long-time running prevention device, and it may stop temporarily when the vacuum cleaner has been running for about 90 minutes.	①Clean the filter, dust bin and remove the items that cause clogging firstly, then it can be used normally when the protection device is released after about 40 minutes. ②Press the switch again or plug and press the switch again to let the power on ③It is the character of this product, just use it normally. Restart the vacuum cleaner according to product using instructions.
It only vibrates, but no inhaling	①Same to Malfunction 3,the suddenly power stop cause no inhaling ②Filter or dust bin is badly clogged ③Inlet is badly clogged	①Same to Malfunction 3 ②Clean the filter or dust bin before using ③Remove the items that cause the clogging
Vacuum cleaner station does not work	①The power cord plug is not plugged in the socket properly. ②The main body is not placed on the station properly. ③UV lamp does not work properly.	①Plug into the socket properly. ②Place the main body on the station under the guide of manual. ③UV lamp's normal working temperature is 5°C to 60°C , please make sure using vacuum cleaner station under working temperature.

Check before reporting the trouble

Malfunction	Possible Cause	Possible Solution
Odor comes out of the cleaner	①It is a new product for 3 months from the purchase, so it may smell rubbers. ②When the cleaner is running ,the inner rubber mounting would give off less smell ③It is used for a long time, odor is caused by the dust in the dust bin.	①No harm to healthy, Do not worry ②It would not make damage or have bad effect on running cleaner. Do not worry ③Empty the dust bin and use it after washing.
Hot air comes out, and main body is hot?	①The air coming out of the outlet is the wind after cooling the motor heat.	①Normal status. Do not worry.
Big noise coming from the cleaner?	①It is the sound of the motor's high speed rotation by high power of cleaner's inlet, or the sound from the front of the nozzle is caused by punching function, ②Dust bin is not assembled properly.	①Normal status. Do not worry ②Assemble the dust bin properly under the guide of manual.

Packing list

Packing list

Vacuum Cleaner	1
Vacuum Cleaner Station	1
Owner's Manual	1
Card service	1

如有问题

请打电话

快到家 乐在心
101 快·乐服务
LG售后 400-819-9999

LG 电子

400-819-9999

售后热线 一号通

乐金电子电器有限公司
制造商地址：韩国首尔市永登浦区汝矣岛洞20号
生产厂地址：中国·天津·北辰区·津围公路9号
传真：022-26903476
邮编：300402
全国技术服务中心服务咨询电话：400-819-9999

LG 电子

http://www.lg.com/cn